

## show redundancy line-card

---

**Syntax** show redundancy line-card [ *filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays redundancy information specific to line modules.

**Options** ■ *filter*—See Filtering show Commands

**Mode** Privileged Exec

---

Published: 2010-04-08