

Clearing QoS Statistics on the Fabric Queue

To clear statistics from the fabric queue for the specified traffic class and egress slot:

- Issue the **clear fabric-queue** command.

host1#**clear fabric-queue traffic-class class15 egress-slot 3**

By default, statistics for all traffic classes and all slots are cleared.

- Related Topics**
- Monitoring QoS Statistics for Rates and Events
 - clear fabric-queue

Published: 2010-03-24