

Table 1: Status LEDs on Line Cards for EX 8200 series Switches

| LED | Color | State and Description |
|-----|--------|--|
| ON | Green | The line card is enabled/online. |
| | Yellow | The line card is disabled/offline. |
| | Unlit | There is no power being supplied to the line card. |
| ST | Green | <ul style="list-style-type: none">■ On steadily—The line card is functioning normally.■ Blinking—The line card is booting. |
| | Yellow | <ul style="list-style-type: none">■ On steadily—There is a line card failure or alarm.■ Blinking—The line card is in diagnostic mode. |
| | Unlit | The line card is disabled/offline. |

- Related Topics**
- 48-port RJ-45 Line Card in an EX 8200 series Switch
 - 48-port SFP Line Card in an EX 8200 series Switch
 - 8-port SFP + Line Card in an EX 8200 series Switch
 - Network Port LEDs in an EX 8200 series Switch