

## address

---

**Syntax** address *address* {  
    destination *address*;  
}

**Hierarchy Level** [edit interfaces *interface-name* unit *logical-unit-number* family *family*],  
[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*  
family *family*]

**Release Information** Statement introduced before JUNOS Release 7.4.

**Description** For CoS on ATM interfaces, configure the interface address.

**Options** *address*—Address of the interface.

The remaining statements are explained separately.

**Usage Guidelines** See Example: Configuring CoS for ATM2 IQ VC Tunnels or the *JUNOS Network Interfaces Configuration Guide*.

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

---

Published: 2010-04-15