

alarm

Syntax alarm *index* {
 description *description*;
 falling-event-index *index*;
 falling-threshold *integer*;
 falling-threshold-interval *seconds*;
 interval *seconds*;
 request-type (get-next-request | get-request | walk-request);
 rising-event-index *index*;
 rising-threshold *integer*;
 sample-type (absolute-value | delta-value);
 startup-alarm (falling-alarm | rising-alarm | rising-or-falling alarm);
 syslog-subtag *syslog-subtag*;
 variable *oid-variable*;
}

Hierarchy Level [edit snmp rmon]

Release Information Statement introduced before JUNOS Release 7.4.
Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Configure RMON alarm entries.

Options *index*—Identifies this alarm entry as an integer.

The remaining statements are explained separately.

Required Privilege Level snmp—To view this statement in the configuration.
snmp-control—To add this statement to the configuration.

Related Topics

- Configuring an Alarm Entry and Its Attributes
- event

Published: 2010-04-27