

buildout (E3 or T3 over ATM Interfaces)

| | |
|---------------------------------|---|
| Syntax | <code>buildout feet;</code> |
| Hierarchy Level | [edit interfaces <i>at-fpc/pic/port</i> e3-options], [edit interfaces <i>at-fpc/pic/port</i> t3-options] |
| Release Information | Statement introduced before JUNOS Release 7.4. |
| Description | For E3 and T3 traffic over ATM interfaces, set the buildout value. |
| Options | <i>feet</i> —The buildout value in feet. Range: 0 through 450 feet (137 meters) Default: 10 feet (3 meters) |
| Required Privilege Level | <i>interface</i> —To view this statement in the configuration. <i>interface-control</i> —To add this statement to the configuration. |
| Related Topics | ■ Configuring E3 and T3 Parameters on ATM Interfaces |

Published: 2010-04-20