

control-slot-numbers

Syntax control-slot-numbers [*slot-numbers*];

Hierarchy Level [edit chassis system-domains protected-system-domains psdn]

Release Information Statement introduced in JUNOS Release 9.1.

Description Configure the slot numbers for the Routing Engines on the JCS1200 platform that are part of the specified Protected System Domain (PSD).

Options *slot-numbers*—Slot numbers for the Routing Engines on the JCS1200 platform to be assigned to the PSD.

Range: 1 through 12



NOTE: The slot numbers for the Routing Engines for the specified PSD must match the REP (primary Routing Engine) and REB (backup Routing Engine) values set through the JCS management module **baydata** command. In the absence of any JUNOS CLI configuration that affects mastership, the Routing Engine in the slot indicated by REP will boot as the master, and the Routing Engine in slot REB will boot as the backup.

The **baydata** command assigns the corresponding PSD through the PSD parameter.

Required Privilege Level view-level—To view this statement in the configuration.
control-level—To add this statement to the configuration.

- Related Topics**
- Configuring an RSD and Creating PSDs
 - baydata

Published: 2010-04-12