

delimiter

Syntax delimiter *delimiter-character*;

Hierarchy Level [edit interfaces *interface-name* auto-configure vlan-ranges authentication username-include],
[edit interfaces *interface-name* auto-configure stacked-vlan-ranges authentication username-include]

Release Information Statement introduced in JUNOS Release 10.0.

Description Specify the character used as the delimiter between the concatenated components of the username. You cannot use the semicolon (;) as a delimiter.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics ■ [Configuring VLAN Interface Username Information for AAA Authentication](#)

Published: 2010-04-20