

## demux0

---

**Syntax** demux0 {  
    unit *logical-unit-number* {  
        demux-options {  
            underlying-interface *interface-name*  
        }  
        family *family* {  
            {  
                *destination-prefix*;  
            }  
            {  
                *source-prefix*;  
            }  
        } unnumbered-address *interface-name* <preferred-source-address *address*>;  
    }  
    vlan-id *number*;  
    vlan-tags outer [*tpid*].*vlan-id* [inner [*tpid*].*vlan-id*];  
}

**Hierarchy Level** [edit interfaces],  
[edit logical-systems *logical-system-name* interfaces]

**Release Information** Statement introduced in JUNOS Release 9.0.

**Description** Configure the logical demultiplexing (demux) interface.  
  
The statements are explained separately.

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

**Related Topics**

- Specifying the Demux Underlying Interface
- Configuring IP Demux Prefixes