

## deny-configuration

---

<b>Syntax</b>	deny-configuration " <i>regular-expression</i> ";
<b>Hierarchy Level</b>	[edit system login class]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4. Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	Specify the configuration mode commands that the user is denied permission to issue even though the permissions set with the <b>permissions</b> statement would allow it.
<b>Default</b>	If you omit this statement and the <b>allow-configuration</b> statement, users can issue only those commands for which they have access privileges through the <b>permissions</b> statement.
<b>Options</b>	<i>regular-expression</i> —Extended (modern) regular expression as defined in POSIX 1003.2. If the regular expression contains any spaces, operators, or wildcard characters, enclose it in quotation marks.
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Specifying Access Privileges for JUNOS Software Operational Mode Commands</li><li>■ allow-configuration</li><li>■ user</li></ul>

---

Published: 2010-04-26