

description

Syntax `description description;`

Hierarchy Level [edit chassis redundancy feb redundancy-group *group-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Provide a description of the FEB redundancy group.

Options *description*—Provide a description for the FEB redundancy group.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics ■ [Configuring FEB Redundancy on the M120 Router](#)

Published: 2010-04-28