

direction (EX Series Switch Only)

Syntax	direction down;
Hierarchy Level	[edit protocols oam ethernet connectivity-fault-management maintenance-domain domain-name maintenance-association ma-name mep mep-id]
Release Information	Statement introduced in JUNOS Release 10.2 for EX Series switches.
Description	Specify that connectivity fault management (CFM) packets (CCMs) be transmitted only in one direction for the MEP, that is, the direction be set as down so that CCMs are transmitted only out of (not into) the interface configured on this MEP.
Options	down —Down MEP CCMs are transmitted only out (not into) of the interface configured on this MEP.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Configuring Ethernet OAM Connectivity Fault Management (CLI Procedure)■ <i>JUNOS Software Network Interfaces Configuration Guide</i> at http://www.juniper.net/techpubs/software/junos/index.html

Published: 2010-04-29