

failover-cold

Syntax	failover-cold (failover-920 restart-901);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications up]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Registration ServiceChange commands when it attempts to register with a new gateway controller following a cold failover.
Default	If you do not specify an option, the virtual BGF includes RS/901 (<i>restart-901</i>).
Options	<i>failover-920</i> —Cold failover. The virtual BGF is registering following a graceful Routing Engine switchover. The installed state is reset. <i>restart-901</i> —Cold boot. The virtual BGF is transitioning to In-Service. The previously installed state is not retained.
Required Privilege Level	<i>interface</i> —To view this statement in the configuration. <i>interface-control</i> —To add this statement to the configuration.
Related Topics	Configuring the Method and Reason in ServiceChange Commands for Control Associations in <i>Session Border Control Solutions Guide Using BGF and IMSG</i>

Published: 2010-04-28