

fill-level (Interpolated Value)

Syntax fill-level [*values*];

Hierarchy Level [edit class-of-service drop-profiles *profile-name* interpolate]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define up to 64 values for interpolating queue fill level.

Options *values*—Data points for mapping queue fill percentage.
Range: 0 through 100

Usage Guidelines See Configuring RED Drop Profiles.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Published: 2010-04-15