

## forwarding-cache (Multicast)

---

**Syntax** forwarding-cache {  
    threshold suppress *value* <reuse *value*>;  
    timeout *minutes*;  
}

**Hierarchy Level** [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* routing-options multicast],  
[edit logical-systems *logical-system-name* routing-options multicast],  
[edit routing-instances *routing-instance-name* routing-options multicast],  
[edit routing-options multicast]

**Release Information** Statement introduced before JUNOS Release 7.4.  
Statement introduced in JUNOS Release 9.0 for EX Series switches.

**Description** Configure multicast forwarding cache properties. These properties include threshold suppression and reuse limits and timeout values.

The remaining statements are explained separately.

**Required Privilege Level** routing—To view this statement in the configuration.  
routing-control—To add this statement to the configuration.

**Related Topics** ■ Configuring General Multicast Forwarding Cache Properties

---

Published: 2010-04-16