

forwarding-options

```
Syntax  helpers {
        bootp {
            dhcp-option82 {
                circuit-id {
                    prefix hostname;
                    use-interface-description;
                    use-vlan-id;
                }
                remote-id {
                    prefix hostname | mac;
                    use-interface-description;
                    use-string string;
                }
                vendor-id [string];
            }
        }
        interface {
            interface-name {
                dhcp-option82 {
                    circuit-id {
                        prefix hostname;
                        use-interface-description;
                        use-vlan-id;
                    }
                    remote-id {
                        prefix hostname | mac;
                        use-interface-description;
                        use-string string;
                    }
                    vendor-id [string];
                }
            }
        }
    }
```

Hierarchy Level [edit]

Release Information Statement introduced in JUNOS Release 9.3 for EX-series switches.

Description Configure traffic forwarding.

The statements are explained separately

Required Privilege Level interface—To view this statement in the configuration.
interface-level—To add this statement to the configuration.

- Related Topics**
- Example: Setting Up DHCP Option 82 with an EX Series Switch as Relay Agent Between Clients and a DHCP Server
 - Setting Up DHCP Option 82 with the Switch as a Relay Agent Between Clients and DHCP Server (CLI Procedure)
 - Understanding DHCP Option 82 for Port Security on EX Series Switches
 - For more information about the [edit forwarding-options] hierarchy and all its options, see the *JUNOS Software Policy Framework Configuration Guide* at <http://www.juniper.net/techpubs/software/junos//index.html>.
-

Published: 2010-01-19