

## hardware-address

---

**Syntax** hardware-address *mac-address*;

**Hierarchy Level** [edit access address-assignment pool *pool-name* family (inet | inet6) host *hostname*]

**Release Information** Statement introduced in JUNOS Release 9.0.

**Description** Specify the MAC address of the client. This is the hardware address that identifies the client on the network.

**Options** *mac-address*—The MAC address of the client.

**Required Privilege Level** admin—To view this statement in the configuration.  
admin-control—To add this statement to the configuration.

**Related Topics** ■ Configuring Address-Assignment Pools

---

Published: 2010-04-26