

holddown-interval

Syntax `holddown-interval holddown-interval;`

Hierarchy Level [edit logical-systems *logical-system-name* protocols ldp oam bfd-livenesss-detection],
[edit logical-systems *logical-system-name* protocols ldp oam fec *address*
bfd-livenesss-detection],
[edit protocols ldp oam bfd-livenesss-detection],
[edit protocols ldp oam fec *address* bfd-livenesss-detection]

Release Information Statement introduced in JUNOS Release 9.4.

Description Specify how long the BFD session should be up before adding the route or next hop. Specifying a time of 0 seconds causes the route or next hop to be added as soon as the BFD session comes back up.

Options *holddown-interval*—Number of seconds the BFD session should remain up before adding the route or next hop.

Default: 0 seconds

Range: 0 through 65,535 seconds

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics ■ [Configuring the Holddown Interval for the BFD Session](#)

Published: 2010-04-28