

interface (DNS and TFTP Packet Forwarding or Relay Agent)

Syntax interface *interface-name* {
 broadcast;
 description *text-description*;
 no-listen;
 server *address* <logical-system *logical-system-name*> <routing-instance
 routing-instance-name>;
}

Hierarchy Level [edit forwarding-options helpers domain],
[edit forwarding-options helpers tftp]

Release Information Statement introduced before JUNOS Release 7.4.
Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Specify the interface for monitoring and forwarding DNS or TFTP requests.

Options *interface-name*—Name of the interface.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics ■ Configuring DNS and TFTP Packet Forwarding

Published: 2010-04-15