

## ipv4-multicast-metric

---

**Syntax** ipv4-multicast-metric *metric*;

**Hierarchy Level** [edit logical-systems *logical-system-name* protocols isis interface *interface-name* level *level-number*],  
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* protocols isis interface *interface-name* level *level-number*],  
[edit protocols isis interface *interface-name* level *level-number*],  
[edit routing-instances *routing-instance-name* protocols isis interface *interface-name* level *level-number*]

**Release Information** Statement introduced before JUNOS Release 7.4.  
Statement introduced in JUNOS Release 9.0 for EX Series switches.

**Description** Specify the multicast topology metric value for the level.

**Options** *metric*—Metric value.  
**Range:** 0 through 16,777,215

**Required Privilege Level** routing—To view this statement in the configuration.  
routing-control—To add this statement to the configuration.

**Related Topics** ■ [Configuring IS-IS Multicast Topologies](#)

---

Published: 2010-04-14