

## max-areas

---

<b>Syntax</b>	<code>max-areas number;</code>
<b>Hierarchy Level</b>	[edit logical-systems <i>logical-system-name</i> protocols isis], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> protocols isis] [edit protocols isis], [edit routing-instances <i>routing-instance-name</i> protocols isis]
<b>Release Information</b>	Statement introduced in JUNOS Release 8.1. Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	Modify the maximum number of IS-IS areas advertised.
<b>Options</b>	<i>number</i> —Maximum number of areas to include in the IS-IS hello (IIH) PDUs and link-state PDUs. <b>Range:</b> 3 through 36 <b>Default:</b> 3
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	■ Limiting the Number of Advertised IS-IS Areas

---

Published: 2010-04-14