

## member

---

<b>Syntax</b>	<code>member interface-name;</code>
<b>Hierarchy Level</b>	[edit interfaces interface-range <i>interface-range-name</i> ]
<b>Release Information</b>	Statement introduced in JUNOS Release 10.0 for EX Series switches.
<b>Description</b>	Specify the name of the member interface belonging to an interface range on the EX Series switch.
<b>Options</b>	<i>interface-name</i> —Name of the interface.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Configuring Gigabit Ethernet Interfaces (CLI Procedure)</li><li>■ Understanding Interface Ranges on EX Series Switches</li><li>■ EX Series Switches Interfaces Overview</li><li>■ <i>JUNOS Software Network Interfaces Configuration Guide</i> at <a href="http://www.juniper.net/techpubs/software/junos/junos100/index.html">http://www.juniper.net/techpubs/software/junos/junos100/index.html</a></li></ul>

---

Published: 2009-10-04