

multicast-statistics

Syntax multicast-statistics

Hierarchy Level [edit interfaces *interface-name*]

Description For Ethernet, SONET, aggregated Ethernet, and aggregated SONET interfaces in T Series or TX Matrix routers, specify support for multicast statistics on a physical interface to enable multicast accounting for all the logical interfaces below the physical interface.

Default not enabled—must be configured to enable

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

- Related Topics**
- Configuring Multicast Statistics Collection on Aggregated Ethernet Interfaces
 - Configuring Multicast Statistics Collection on Aggregated SONET Interfaces
 - Configuring Multicast Statistics Collection on Ethernet Interfaces
 - Configuring Multicast Statistics Collection on SONET Interfaces

Published: 2010-04-20