

partition (PTSP)

Syntax partition *partition-name* {
destination-host *hostname*;
destination-realm *realm*;
diameter-instance *instance-name*;
}

Hierarchy Level [edit system services packet-triggered-subscribers]

Release Information Statement introduced in JUNOS Release 10.2.

Description Configure a PTSP partition.

Options *partition-name*—Name of the PTSP partition.

The remaining statements are explained separately.

Required Privilege Level admin—To view this statement in the configuration.
admin-control—To add this statement to the configuration.

Related Topics ■ Configuring the PTSP Partition

Published: 2010-04-15