

## priority (ATM2 IQ Schedulers)

---

<b>Syntax</b>	priority (high   low);
<b>Hierarchy Level</b>	[edit interfaces <i>at-fpc/pic/port</i> atm-options scheduler-maps <i>map-name</i> forwarding-class <i>class-name</i> ]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	For ATM2 IQ interfaces only, assign queuing priority to a forwarding class.
<b>Options</b>	low—Forwarding class has low priority. high—Forwarding class has high priority.
<b>Usage Guidelines</b>	See Configuring Scheduler Maps on ATM Interfaces.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

---

Published: 2010-04-15