

## protected-system-domains

---

**Syntax** protected-system-domains psdn {  
control-plane-bandwidth-percent *percent*  
description *description*;  
fpcs [ *slot-numbers* ];  
control-system-id *control-system-id*;  
control-slot-numbers [ *slot-numbers* ];  
}

**Hierarchy Level** [edit chassis system-domains]

**Release Information** Statement introduced in JUNOS Release 9.1.

**Description** Configure the Protected System Domain (PSD) identification.

**Options** psdn—PSD identification as a numeric value.  
**Range:** The range values is 1 through 31.

The remaining statements are described separately.

**Usage Guidelines** See Configuring an RSD and Creating PSDs.

**Required Privilege Level** view-level—To view this statement in the configuration.  
control-level—To add this statement to the configuration.

**Related Topics** ■ Configuring an RSD and Creating PSDs

