

## redundancy-group

---

**Syntax** redundancy-group *group-number* {  
    [Unresolved xref] *seconds*;  
    map {  
        local-mac *mac-address* request *mac-address*;  
    }  
    preempt hold-time *seconds*;  
    no-preempt;  
    [Unresolved xref] *priority*;  
    track {  
        dls {  
            peer *ip-address* priority-cost *priority*;  
            [Unresolved xref] *mac-address* priority-cost *priority*;  
        }  
        [Unresolved xref] *interface-name* priority-cost *priority*;  
    }  
}

**Hierarchy Level** [edit interfaces *interface-name* unit *logical-unit-number* family llc2],  
[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*  
family llc2]

**Release Information** Statement introduced in JUNOS Release 7.5.

**Description** For J-series Services Routers only. On Ethernet interfaces configured for DLSw, configure the router for DLSw redundancy.

The statements are explained separately.

**Usage Guidelines** See Configuring LLC2 Options.

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

**Related Topics** *J-series Services Router Advanced WAN Access Configuration Guide*

