

remote-peer

Syntax remote-peer *peer-address* {
 circuit-weight *weight*;
 cost *cost*;
}

Hierarchy Level [edit protocols dlsw]

Release Information Statement introduced in JUNOS Release 7.4.

Description Configure the IP address of the remote DLSw peer.

Options *peer-address*—IP address of the remote DLSw peer.

The remaining statements are explained separately.

Usage Guidelines See Configuring DLSw.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Published: 2009-07-20