

request-type

Syntax request-type (get-next-request | get-request | walk-request);

Hierarchy Level [edit snmp rmon alarm *index*]

Release Information Statement introduced in JUNOS Release 8.3.
Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Extend monitoring to a specific SNMP object instance (**get-request**), or extend monitoring to all object instances belonging to a MIB branch (**walk-request**), or extend monitoring to the next object instance after the instance specified in the configuration (**get-next-request**).

Options get-next-request—Performs an SNMP get next request.

get-request—Performs an SNMP get request.

walk-request—Performs an SNMP walk request.

Default: walk-request

Required Privilege Level snmp—To view this statement in the configuration.
snmp-control—To add this statement to the configuration.

Related Topics

- Configuring the Request Type
- variable

Published: 2010-04-27