

rule (Configuring)

Syntax rule *rule-name* {
 count-type (application | rule);
 demux (destination-address | source-address);
 forward-rule *forward-rule-name*;
 match-direction (input | input-output | output);
 term *precedence* {
 from {
 application-group-any;
 application-groups [*application-group-name*];
 applications [*application-name*];
 local-port-range low *low-value* high *high-value*;
 local-ports [*value-list*];
 protocol *protocol-number*;
 remote-address *address* <except>;
 remote-address-range low *low-value* high *high-value* <except>;
 remote-ports [*value-list*];
 remote-port-range low *low-value* high *high-value*;
 remote-prefix-list *prefix-list-name* <except>;
 }
 then {
 (accept | discard);
 count (application | application-group | application-group-any | rule | none);
 forwarding-class *forwarding-class*;
 police *policer-name*;
 }
 }
}

Hierarchy Level [edit services ptsp]

Release Information Statement introduced in JUNOS Release 10.2.

Description Specify the rule the router uses when applying this service.

Options *rule-name*—Identifier for the collection of terms that constitute this rule.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics ■ [Configuring Static PTSP Rules in *JUNOS Subscriber Access Configuration Guide*](#)