

static

Syntax

```
static {
  address address {
    group-ranges {
      destination-ip-prefix</prefix-length>;
    }
    version version;
  }
}
```

Hierarchy Level [edit logical-systems *logical-system-name* protocols pim rp],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* protocols pim rp],
[edit protocols pim rp],
[edit routing-instances *routing-instance-name* protocols pim rp]

Release Information Statement introduced before JUNOS Release 7.4.
Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Configure static RP addresses. The default static RP address is 224.0.0.0/4. To configure other addresses, include one or more **address** statements. You can configure a static RP in a logical system only if the logical system is not directly connected to a source.

For each static RP address, you can optionally specify the PIM version and the groups for which this address can be the RP. The default PIM version is version 1.

The remaining statements are explained separately.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics ■ Configuring Static PIM RPs

Published: 2010-04-16