

swap

Syntax `swap out-label;`

Hierarchy Level [edit logical-systems *logical-system-name* protocols mpls static-label-switched-path *lsp-name* transit *incoming-label*],
[edit protocols mpls static-label-switched-path *lsp-name* transit *incoming-label*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Remove the label at the top of the label stack and replace it with the specified label.

Options *out-label*—Label value.

Range: 1,000,000 through 1,048,575. Labels 0 through 999,999 are for internal use. Labels 1,000,000 through 1,048,575 are unassigned by the JUNOS Software and are available for static LSPs. When you configure static LSPs, you can use only this range of labels.

Default: If you do not define the *out-label* option, the original label value remains unchanged.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics

- pop
- Configuring Static LSPs

Published: 2010-04-28