

## Juniper Networks Enterprise-Specific LDP Traps

---

For information about the enterprise-specific LDP traps, see LDP MIB.

### ***Disabling LDP Traps***

You can disable the LDP LSP notifications by including the `trap disable` statement at the `[show protocols ldp log-updown]` hierarchy level.

- Related Topics**
- Juniper Networks Enterprise-Specific SNMP Traps
  - Standard SNMP Traps Supported on Devices Running JUNOS Software
  - Juniper Networks Enterprise-Specific MIBs
  - Standard SNMP MIBs Supported by JUNOS Software

---

Published: 2010-04-27