

## Configuring Graceful Restart for Aggregate and Static Routes

---

To configure graceful restart for aggregate and static routes, include the `graceful-restart` statement at the `[edit routing-options]` hierarchy level. To disable graceful restart, include the `disable` statement at the `[edit routing-options graceful-restart]` hierarchy level.

- Related Topics**
- Graceful Restart Concepts
  - Graceful Restart System Requirements
  - Aggregate and Static Routes
  - Example: Configuring Graceful Restart

---

Published: 2010-04-28