

Configuring the Hostname of the Router or Switch

To configure the name of the router or switch, include the `host-name` statement at the `[edit system]` hierarchy level:

```
[edit system]
host-name hostname;
```

The name value must be less than 256 characters.

- Related Topics**
- [Configuring Basic Router or Switch Properties](#)
 - [Example: Configuring the Name of the Router, IP Address, and System ID](#)

Published: 2010-04-26