

Forcing a Group of Static Subscribers to Be Logged Out

You can force the static subscribers on all interfaces in a group to be logged out. After you do so, no subscriber can subsequently log in on an interface in that group until the interface state is reset either by a router reset or by entering the `request services static-subscribers login group` command.

- To forcibly log out all static subscribers on a static interface group:

```
user@host> request services static-subscribers logout group boston
```

- Related Topics** ■ [Resetting the State of an Interface Group for Static Subscriber Login](#)

Published: 2010-04-15