

Directing Messages to the Console

To direct system log messages to the console of the local Routing Engine, include the `console` statement at the `[edit system syslog]` hierarchy level:

```
[edit system syslog]
console {
  facility severity;
}
```

For the list of facilities and severity levels, see [Specifying the Facility and Severity of Messages to Include in the Log](#).

Published: 2010-04-28