

JUNOScope 8.1 Software Release Notes

Release 8.1R4
28 August 2007
Part No. 530-016902-01
Revision 4

These release notes accompany Release 8.1R4 of the JUNOScope software. They describe the key features, documentation, and known problems with the software. The JUNOScope software is a network management application that provides router configuration management, inventory management, operational status, and troubleshooting tools for Juniper Networks J-series, M-series, and T-series routing platforms.

You can also find these release notes on the Juniper Networks Technical Publications Web page, which is located at <http://www.juniper.net/>.

Contents	Release 8.1 Features	2
	Current Software Release	2
	Installing the JUNOScope Software	3
	System Requirements	4
	Red Hat Enterprise Linux ES File Package Requirements	4
	JUNOScope Client Workstation Requirements	5
	RADIUS Server Requirements	5
	Syslog Server Requirements	5
	Installing the JUNOScope Software	6
	Reconfiguring the JUNOScope Software	7
	Reinstalling or Upgrading the JUNOScope Software	8
	Uninstalling the JUNOScope Software	8
	Related Juniper Networks Documentation	8
	How To Request Support	11
	Revision History	12

Release 8.1 Features

The following features have been added to JUNOScope Release 8.1. For more detailed information, see the appropriate sections of the *JUNOScope 8.1 Software User Guide*.

- **Import Options**—To support synchronizing JUNOScope settings imported from multiple servers, the JUNOScope software provides the following import methods to use if a conflict occurs between existing records stored in the JUNOScope server and imported records:
 - **Ignore**—(Default) An existing record stored in the JUNOScope server takes precedence over any imported record. The imported record is ignored and the existing record is not affected. Any imported record that does not exist in the JUNOScope server is inserted.
 - **Merge**—If a record exists in the JUNOScope server and also exists in the imported record, the imported record merges with the existing record and is augmented as necessary. If an imported record is in conflict with an existing record, the imported record takes precedence over the existing record. The existing record is merged with the imported record; however the fields of imported record take precedence over the fields of the existing record. Any imported record that does not exist in the JUNOScope server is inserted.
 - **Override**—All records in the JUNOScope server are deleted, then all imported records are inserted. Before the override operation occurs, a message window appears with the following confirmation prompt: “The import with override option will delete all the existing records. Do you want to continue?”
- **Application Data Backup and Restoration**—The administrator can now back up and restore application data stored by JUNOScope, including settings, operational, and inventory data; archived device configurations; archived inventory reports; and imported JUNOS software images.

Current Software Release

The current JUNOScope software release is Release 8.1R4. For information about installing the software release, see “Installing the JUNOScope Software” on page 3.

Installing the JUNOScope Software

Before installing the JUNOScope software, ensure that your network meets the requirements described in the following sections:

- System Requirements on page 4
- Red Hat Enterprise Linux ES File Package Requirements on page 4
- JUNOScope Client Workstation Requirements on page 5
- RADIUS Server Requirements on page 5

To install, reconfigure, reinstall or upgrade, or deinstall the JUNOScope software, see the following sections:

- Installing the JUNOScope Software on page 6
- Reconfiguring the JUNOScope Software on page 7
- Reinstalling or Upgrading the JUNOScope Software on page 8
- Uninstalling the JUNOScope Software on page 8

System Requirements

The JUNOScope software runs on both Sun Solaris servers (see Table 1) and Red Hat Linux servers (see Table 2). Before you install the JUNOScope software, ensure that the supported UNIX server workstation on which you install the software meets the following system requirements.

Table 1 shows the minimum system requirements for a Sun Solaris server.

Table 1: Sun Solaris Server System Minimum Requirements

System	Minimum Requirement
Operating system	Solaris 5.8 or later
Processor	UltraSPARC III or equivalent
Speed	1.3 GHz or faster
RAM	1 GB
Free disk space	1 GB

Table 2 shows the minimum system requirements for a Red Hat Linux server. (See also “Red Hat Enterprise Linux ES File Package Requirements” on page 4.)

Table 2: Red Hat Linux Server System Minimum Requirements

System	Minimum Requirement
Hardware	Red Hat certified hardware platforms
Operating system	Red Hat Enterprise Linux ES version 3 and 4
Processor	Pentium 4 processor
Speed	2.8 GHz or faster
RAM	1 GB
Free disk space	1 GB

Red Hat Enterprise Linux ES File Package Requirements

If a minimal install of Red Hat Enterprise Linux ES is performed on the server, the JUNOScope software administrator should ensure that the following file packages are installed for the JUNOScope software to run properly. All packages should be available in a full install of Red Hat Enterprise Linux ES.

Table 3: Red Hat Enterprise Linux ES File Package Requirements

Version	Required File Packages
Red Hat Enterprise Linux ES version 3 (Update 6)	krb5-libs-1.2.7-47.i386.rpm XFree86-libs-4.3.0-97.EL.i386.rpm
Red Hat Enterprise Linux ES version 4 (Update 2)	compat-libcom_err-1.0-5.i386.rpm krb5-libs-1.3.4-17.i386.rpm xorg-x11-deprecated-libs-6.8.2-1.EL.13.20.i386.rpm xorg-x11-libs-6.8.2-1.EL.13.20.i386.rpm

To verify that the file package `krb5-libs-1.3.4-17.i386.rpm` is installed, use the following command:

```
hostname% rpm -queryformat "%{NAME}-%{VERSION}-%{RELEASE}-%{ARCH}\n" --query krb5-libs
```

You can install each package individually via `rpm`, from the original Red Hat Enterprise Linux ES distribution.

To install the file package `xorg-x11-libs-6.8.2-1.EL.13.20.i386.rpm`, use the following command:

```
hostname% rpm -install xorg-x11-libs-6.8.2-1.EL.13.20.i386.rpm
```

JUNOScope Client Workstation Requirements

Ensure that the client workstation from which you connect to the JUNOScope software is running either Microsoft Internet Explorer 6 or Netscape Navigator 6 or later with JavaScript enabled.

RADIUS Server Requirements

Ensure that the RADIUS server complies with RFC 2865, *Remote Authentication Dial-In User Service*.

Syslog Server Requirements

Ensure that the syslog server (`syslogd`) is running and configured to receive JUNOScope system log messages.

Installing the JUNOScope Software

You can install the JUNOScope software in one of the following ways:

- Installing the JUNOScope Software from the CD on page 6
- Downloading the JUNOScope Software from the Software Download Page on page 7

To upgrade the JUNOScope software, see “Reinstalling or Upgrading the JUNOScope Software” on page 8.

For more information about installing the JUNOScope software, see the *JUNOScope Software User Guide*.

Installing the JUNOScope Software from the CD

To install the JUNOScope software from the product CD, follow these steps:

1. Insert the JUNOScope software CD into the CD drive of the server workstation.
2. Mount the CD.

If the volume management (volmgt) daemon, vold, is running on your server, the CD automatically mounts itself. To mount the CD manually, follow the procedure for your operating system.

3. Start the JUNOScope installation:

```
hostname% cdrom-mount-directory/jtk-installer install-directory
```

Replace *cdrom-mount-directory* with the directory on which the CD is mounted: */mnt*, */cdrom*, or */cdrom/JUNOScope*, depending on your host setup.

Replace *install-directory* with the directory in which to install the JUNOScope software. If you do not specify an installation directory, the software is installed in the current directory.

For more information about installing the JUNOScope software, see the *JUNOScope Software User Guide*.

Downloading the JUNOScope Software from the Software Download Page

To download the JUNOScope software from the Juniper Networks Web site and start the JUNOScope installation, follow these steps:

1. Using a Web browser, go to the following location:

```
https://www.juniper.net/junos/swdist/encryption/index.htm
```

2. Log in to the Juniper Networks authentication system using the username (generally your e-mail address) and password supplied by a Juniper Networks representative.
3. Download the appropriate JUNOScope software to the server workstation.
4. Start the JUNOScope installation program:

```
hostname% download-directory/jtk-install-8.1R4.X-sunos5-sparc.sh install-directory
```

or

```
hostname% download-directory/jtk-install-8.1R4.X-linux2-i386.sh install-directory
```

Replace *download-directory* with the directory into which you downloaded the JUNOScope software from the software download page.

jtk-install-8.1R4.X-sunos5-sparc.sh or **jtk-install-8.1R4.X-linux2-i386.sh** is the JUNOScope software file. Replace *X* with the software version to download.

Replace *install-directory* with the directory in which to install the JUNOScope software. If you do not specify an installation directory, the software is installed in the current directory.

Reconfiguring the JUNOScope Software

You can change the following JUNOScope software installation settings without rerunning the installation program. For more information about these settings, see the *JUNOScope Software User Guide*.

- HTTPS and HTTP ports on which the JUNOScope Web server should listen
- Port on which the JUNOScope server listens for control messages
- HTTP port on which the JUNOScope report server should listen
- Java Database Connectivity (JDBC) URL for accessing the JUNOScope database and demo database
- Enable or disable access for SQL interface to Inventory Management System
- Debug logging
- Syslog facility
- Idle session timeout
- Licensed software modules

You cannot change some settings, such as passwords.

To change JUNOScope software settings, use the following command:

```
hostname% <install-directory>/jtk/bin/jtk-setup.sh
```

Reinstalling or Upgrading the JUNOScope Software

The process for reinstalling or upgrading the JUNOScope software is the same as for installing the software. To install the JUNOScope software, see “Installing the JUNOScope Software from the CD” on page 6 or “Downloading the JUNOScope Software from the Software Download Page” on page 7.

To reinstall or upgrade JUNOScope software, you must use the same user ID as the one used for the currently installed software.

Uninstalling the JUNOScope Software


To uninstall the JUNOScope software, follow these steps:

1. Stop the JUNOScope software and database by changing to the directory where you installed the JUNOScope software and typing the following command:

```
hostname% <install-directory>/jtk/rc.d/jtk stop
```

2. Remove the JUNOScope software by typing the following command:

```
hostname% rm -rf <install-directory>
```



WARNING: This command removes the JUNOScope <install-directory>, including all data.

Related Juniper Networks Documentation

Table 4 lists the software and hardware guides and release notes for the supported Juniper Networks routing platforms and describes the contents of each document. Table 5 lists the books included in the *Network Operations Guide* series.

Table 4: Technical Documentation for Supported Routing Platforms (Sheet 1 of 4)

Document	Description
JUNOS Internet Software Configuration Guides	
<i>Class of Service</i>	Provides an overview of the class-of-service (CoS) functions of the JUNOS software and describes how to configure CoS features, including configuring multiple forwarding classes for transmitting packets, defining which packets are placed into each output queue, scheduling the transmission service level for each queue, and managing congestion through the random early detection (RED) algorithm.

Table 4: Technical Documentation for Supported Routing Platforms (Sheet 2 of 4)

Document	Description
<i>CLI User Guide</i>	Describes how to use the JUNOS command-line interface (CLI) to configure, monitor, and manage Juniper Networks routing platforms. This material was formerly covered in the <i>JUNOS System Basics Configuration Guide</i> .
<i>Feature Guide</i>	Provides a detailed explanation and configuration examples for several of the most complex features in the JUNOS software.
<i>High Availability</i>	Provides an overview of hardware and software resources that ensure a high level of continuous routing platform operation and describes how to configure high availability (HA) features such as nonstop routing (NSR) and graceful Routing Engine switchover (GRES).
<i>MPLS Applications</i>	Provides an overview of traffic engineering concepts and describes how to configure traffic engineering protocols.
<i>Multicast Protocols</i>	Provides an overview of multicast concepts and describes how to configure multicast routing protocols.
<i>Network Interfaces</i>	Provides an overview of the network interface functions of the JUNOS software and describes how to configure the network interfaces on the routing platform.
<i>Network Management</i>	Provides an overview of network management concepts and describes how to configure various network management features, such as SNMP and accounting options.
<i>Policy Framework</i>	Provides an overview of policy concepts and describes how to configure routing policy, firewall filters, forwarding options, and cflowd.
<i>Routing Protocols</i>	Provides an overview of routing concepts and describes how to configure routing, routing instances, and unicast routing protocols.
<i>Secure Configuration Guide for Common Criteria and JUNOS-FIPS</i>	Provides an overview of secure Common Criteria and JUNOS-FIPS protocols for the JUNOS Internet software and describes how to install and configure secure Common Criteria and JUNOS-FIPS on a routing platform.
<i>Services Interfaces</i>	Provides an overview of the services interfaces functions of the JUNOS software and describes how to configure the services interfaces on the routing platform.
<i>Software Installation and Upgrade Guide</i>	Provides a description of JUNOS software components and packaging, and includes detailed information about how to initially configure, reinstall, and upgrade the JUNOS system software. This material was formerly covered in the <i>JUNOS System Basics Configuration Guide</i> .
<i>System Basics</i>	Describes Juniper Networks routing platforms, and provides information about how to configure basic system parameters, supported protocols and software processes, authentication, and a variety of utilities for managing your router on the network.
<i>VPNs</i>	Provides an overview and describes how to configure Layer 2 and Layer 3 virtual private networks (VPNs), virtual private LAN service (VPLS), and Layer 2 circuits. Provides configuration examples.
JUNOS References	
<i>Hierarchy and RFC Reference</i>	Describes the JUNOS configuration mode commands. Provides a hierarchy reference that displays each level of a configuration hierarchy, and includes all possible configuration statements that can be used at that level. This material was formerly covered in the <i>JUNOS System Basics Configuration Guide</i> .
<i>Interfaces Command Reference</i>	Describes the JUNOS software operational mode commands you use to monitor and troubleshoot interfaces.
<i>Routing Protocols and Policies Command Reference</i>	Describes the JUNOS software operational mode commands you use to monitor and troubleshoot routing protocols and policies, including firewall filters.

Table 4: Technical Documentation for Supported Routing Platforms (Sheet 3 of 4)

Document	Description
<i>System Basics and Services Command Reference</i>	Describes the JUNOS software operational mode commands you use to monitor and troubleshoot system basics, including commands for real-time monitoring and route (or path) tracing, system software management, and chassis management. Also describes commands for monitoring and troubleshooting services such as CoS, IP Security (IPSec), stateful firewalls, flow collection, and flow monitoring.
<i>System Log Messages Reference</i>	Describes how to access and interpret system log messages generated by JUNOS software modules and provides a reference page for each message.
J-Web User Guide	
<i>J-Web Interface User Guide</i>	Describes how to use the J-Web GUI to configure, monitor, and manage Juniper Networks routing platforms.
JUNOS API and Scripting Documentation	
<i>JUNOScript API Guide</i>	Describes how to use the JUNOScript application programming interface (API) to monitor and configure Juniper Networks routing platforms.
<i>JUNOS XML API Configuration Reference</i>	Provides reference pages for the configuration tag elements in the JUNOS XML API.
<i>JUNOS XML API Operational Reference</i>	Provides reference pages for the operational tag elements in the JUNOS XML API.
<i>JUNOS Configuration and Diagnostic Automation Guide</i>	Describes how to use the commit script and self-diagnosis features of the JUNOS software. This guide explains how to enforce custom configuration rules defined in scripts, how to use commit script macros to provide simplified aliases for frequently used configuration statements, and how to configure diagnostic event policies.
<i>NETCONF API Guide</i>	Describes how to use the NETCONF API to monitor and configure Juniper Networks routing platforms.
JUNOS Comprehensive Index and Glossary	
<i>Comprehensive Index and Glossary</i>	Provides a complete index of all JUNOS software books, the <i>JUNOScript API Guide</i> , and the <i>NETCONF API Guide</i> . Also provides a comprehensive glossary.
JUNOScope Documentation	
<i>JUNOScope Software User Guide</i>	Describes the JUNOScope software GUI, how to install and administer the software, and how to use the software to manage routing platform configuration files and monitor routing platform operations.
J-series Services Router Documentation	
<i>Getting Started Guide</i>	Provides an overview, basic instructions, and specifications for J-series Services Routers. The guide explains how to prepare your site for installation, unpack and install the router and its components, install licenses, and establish basic connectivity. Use the <i>Getting Started Guide</i> for your router model.
<i>Basic LAN and WAN Access Configuration Guide</i>	Explains how to configure the interfaces on J-series Services Routers for basic IP routing with standard routing protocols, ISDN backup, and digital subscriber line (DSL) connections.
<i>Advanced WAN Access Configuration Guide</i>	Explains how to configure J-series Services Routers in virtual private networks (VPNs) and multicast networks, configure data link switching (DLSw) services, and apply routing techniques such as policies, stateless and stateful firewall filters, IP Security (IPSec) tunnels, and class-of-service (CoS) classification for safer, more efficient routing.
<i>Administration Guide</i>	Shows how to manage users and operations, monitor network performance, upgrade software, and diagnose common problems on J-series Services Routers.
M-series and T-series Hardware Documentation	
<i>Hardware Guide</i>	Describes how to install, maintain, and troubleshoot routing platforms and components. Each platform has its own hardware guide.

Table 4: Technical Documentation for Supported Routing Platforms (Sheet 4 of 4)

Document	Description
<i>PIC Guide</i>	Describes the routing platform PICs. Each platform has its own PIC guide.
Release Notes	
<i>JUNOS Release Notes</i>	Summarize new features and known problems for a particular software release, provide corrections and updates to published JUNOS, JUNOScript, and NETCONF manuals, provide information that might have been omitted from the manuals, and describe upgrade and downgrade procedures.
<i>Hardware Release Notes</i>	Describe the available documentation for the routing platform and the supported PICs, and summarize known problems with the hardware and accompanying software. Each platform has its own release notes.
<i>JUNOScope Software Release Notes</i>	Contain corrections and updates to the published JUNOScope manual, provide information that might have been omitted from the manual, and describe upgrade and downgrade procedures.
<i>J-series Services Router Release Notes</i>	Briefly describe the J-series Services Router features, identify known hardware problems, and provide upgrade and downgrade instructions.

Table 5: JUNOS Internet Software Network Operations Guides

Book	Description
<i>Baseline</i>	Describes the most basic tasks for running a network using Juniper Networks products. Tasks include upgrading and reinstalling JUNOS software, gathering basic system management information, verifying your network topology, and searching log messages.
<i>Interfaces</i>	Describes tasks for monitoring interfaces. Tasks include using loopback testing and locating alarms.
<i>MPLS</i>	Describes tasks for configuring, monitoring, and troubleshooting an example MPLS network. Tasks include verifying the correct configuration of the MPLS and RSVP protocols, displaying the status and statistics of MPLS running on all routers in the network, and using the layered MPLS troubleshooting model to investigate problems with an MPLS network.
<i>MPLS Log Reference</i>	Describes MPLS status and error messages that appear in the output of the <code>show mpls lsp extensive</code> command. The guide also describes how and when to configure Constrained Shortest Path First (CSPF) and RSVP trace options, and how to examine a CSPF or RSVP failure in a sample network.
<i>Hardware</i>	Describes tasks for monitoring M-series and T-series routing platforms.

How To Request Support

For technical support, open a support case using the Case Manager link at <http://www.juniper.net/support/> or call 1-888-314-JTAC (from the United States, Canada, or Mexico) or 1-408-745-9500 (from elsewhere).

For documentation issues, fill out the bug report form located at <https://www.juniper.net/techpubs/docbug/docbugreport.html>.

Revision History

28 August 2007—Revision 4, JUNOScope Release 8.1R4

13 April 2007—Revision 3, JUNOScope Release 8.1R3

4 January 2007—Revision 2, JUNOScope Release 8.1R2

6 November 2006—Revision 1, JUNOScope Release 8.1R1

Copyright © 2006, Juniper Networks, Inc. All rights reserved.

Juniper Networks, the Juniper Networks logo, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. JUNOS and JUNOSe are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.