

authentication

Syntax authentication {
 password *password-string*;
 username-include {
 circuit-type;
 delimiter *delimiter-character*;
 domain-name *domain-name-string*;
 logical-system-name;
 mac-address;
 option-60;
 option-82 [circuit-id] [remote-id];
 routing-instance-name;
 user-prefix *user-prefix-string*;
 }
}

Hierarchy Level [edit forwarding-options dhcp-relay],
[edit forwarding-options dhcp-relay group *group-name*],
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay],
[edit logical-systems *logical-system-name* forwarding-options group *group-name*],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name*
 forwarding-options dhcp-relay],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name*
 forwarding-options dhcp-relay group *group-name*],
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay],
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay group
 group-name]

Release Information Statement introduced in JUNOS Release 9.1.

Description Configure the parameters the router sends to the external AAA server. A group configuration takes precedence over a global DHCP relay or DHCP local server configuration.

The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics ■ Using External AAA Authentication Services with DHCP

