

Supported Interface Types for QoS Profiles

Each QoS profile command begins with a keyword that designates an interface type.

Table 1 lists the interface types and the commands that you can use with them.

Table 1: Interface Types and Supported Commands

Interface Type	Queue	Node	Group	Shadow Node
atm	✓	✓	✓	✓
atm-vc	✓	✓	–	✓
atm-vp	✓	✓	–	✓
bridge	✓	✓	–	✓
ethernet	✓	✓	✓	✓
fr-vc	✓	✓	–	✓
ip	✓	✓	–	✓
ip-tunnel	✓	✓	–	✓
ipv6	✓	✓	–	✓
l2tp-session	✓	✓	–	✓
l2tp-tunnel	✓	✓	–	✓
lsp	✓	✓	–	✓
serial	✓	✓	✓	✓
server-port	✓	✓	✓	✓
svlan	✓	✓	–	✓
vlan	✓	✓	–	✓

- Related Topics**
- Supported Interface Types for QoS Profiles on page 1
 - Configuring a QoS Profile
 - Configuring Shadow Nodes