

Removing a J-series or SRX-series Device from NSM Management (NSM Procedure)

Deleting a device removes all device configuration information from the management system, but might be the best solution if you need to perform extensive troubleshooting or reconfigure the device locally.

To remove a J-series or SRX-series device from NSM management:

1. In the NSM navigation tree, select **Device Manager > Devices**.
2. Click the **Device Tree** tab and then select the device that you want to remove from NSM management.
3. Right-click and select **Delete**, or click the **Delete** button. The Delete dialog box appears. If the device is referenced in a firewall rule, this dialog box displays the rules that reference it. You can click the links that appear to display the security policies to view or edit those references.
4. Remove the device by clicking **Next**. The Delete dialog box displays the progress of the deletion.
5. After NSM finishes, click **Finish** to close the dialog box.

Related Topics ■ Adding J-series Services Routers or SRX-series Services Gateways in NSM Overview

