

## About this Manual

This chapter provides a high-level overview of the *JUNOS Internet Software Configuration Guide: MPLS Applications* :

Objectives on page xvii

Audience on page xviii

Document Organization on page xviii

Related Documentation on page xx

Manual Part Organization on page xx

Using the Index on page xxi

Documentation Conventions on page xxi

Documentation Feedback on page xxiii

How to Request Support on page xxiii

## Objectives

This manual provides an overview of the MPLS applications functions of the JUNOS Internet software and describes how to configure MPLS applications on the router.

This manual fully documents MPLS applications configurations in Release 4.2 of the JUNOS Internet software.

To obtain additional information about the JUNOS software—either corrections to information in this manual or information that might have been omitted from this manual—refer to the printed software release notes that accompany your router.

To obtain the most current version of this manual and the most current version of the software release notes, refer to the product documentation page on the Juniper Networks Web site, which is located at <http://www.juniper.net/>.

To order printed copies of this manual or to order a documentation CD-ROM, which contains this manual, please contact your sales representative.

## Audience

This manual is designed for network administrators who are configuring a Juniper Networks router. It assumes that you have a broad understanding of networks in general, the Internet in particular, networking principles, and network configuration. This manual assumes that you are familiar with one or more of the following Internet routing protocols: Border Gateway Protocol (BGP), Intermediate System-to-Intermediate System (IS-IS), Open Shortest Path First (OSPF), Internet Control Message Protocol (ICMP), Resource Reservation Protocol (RSVP), Routing Information Protocol (RIP), and Simple Network Management Protocol (SNMP).

## Document Organization

This manual is divided into several parts. Each part describes a major functional area of the JUNOS software, and the individual chapters within a part describe the software components of that functional area.

This manual contains the following parts and chapters:

Part 1, “Overview,” provides an overview of Traffic Engineering concepts and configuration statements.

Chapter 1, “Traffic Engineering Overview,” provides a functional description of the four major components of traffic engineering, as well as the various methods of calculating and configuring label-switched paths (LSPs).

Chapter 2, “Complete Traffic Engineering Configuration Mode Statements,” provides a comprehensive list of all the configuration statements available and displays their hierarchy.

Part 2, “MPLS,” describes how to configure the JUNOS software to support Multiprotocol Label Switching.

Chapter 3, “MPLS Overview,” provides a short overview of Multiprotocol Label Switching (MPLS), which provides a mechanism for engineering network traffic patterns that is independent of the shortest path determined by a routing protocol.

Chapter 4, “MPLS Configuration Statements,” lists of all the minimum and optional configuration statements for MPLS.

Chapter 5, “Configure MPLS Signaled LSPs,” describes how to configure the ingress router for signaled LSPs and how to enable RSVP.

Chapter 6, “Configure Static LSPs,” describes how to configure the ingress, intermediate, and egress routers for static MPLS.

Chapter 7, “Configure Explicit-Path LSPs,” describes how to manually configure LSPs by specifying each router hop between the ingress and egress routers.

Chapter 8, “Configure Miscellaneous MPLS Properties,” describes how to configure MPLS to gather statistics and trace protocol packets and operations, as well as how to control syslog messages and SNMP traps.

Chapter 9, “Summary of MPLS Configuration Statements,” lists all of the statements used to configure MPLS.

Part 3, “RSVP,” describes how to configure the JUNOS software to support Resource Reservation Protocol.

Chapter 10, “RSVP Overview,” provides a short overview of the Resource Reservation Protocol (RSVP), a setup protocol designed to interact with integrated services on the Internet to request a specific quality of service (QoS).

Chapter 11, “RSVP Configuration Guidelines,” describes the minimum and optional configurations for RSVP.

Chapter 12, “Summary of RSVP Configuration Statements,” describes all RSVP configuration statements.

Part 4, “LDP,” describes how to configure the JUNOS software to support Label Distribution Protocol.

Chapter 13, “LDP Overview,” provides a short overview of the Label Distribution Protocol (LDP), a protocol used to establish LSPs through a network by mapping network-layer routing information directly to data-link label-switched paths.

Chapter 14, “Configure LDP,” describes the minimum and optional configurations for LDP.

Chapter 15, “Summary of LDP Configuration Statements,” describes all LDP configuration statements.

Part 5, “CCC,” describes how to configure the JUNOS software to support circuit cross-connect.

Chapter 16, “CCC Overview,” describes a description of the types of CCCs.

Chapter 17, “CCC Configuration,” describes all CCC configuration statements.

Chapter 18, “Summary of CCC Configuration Statements,” describes all CCC configuration statements.

A glossary and an index are provided at the end of this manual.

## Related Documentation

The following additional documentation describes the JUNOS Internet software:

*JUNOS Internet Software Configuration Guide: Installation and System Management* —Provides an overview of the JUNOS Internet software and describes how to install and upgrade the software. This manual also describes how to configure system management functions, including user accounts, passwords, and SNMP.

*JUNOS Internet Software Configuration Guide: Interfaces and Chassis* —Provides an overview of routing interfaces and describes how to configure routing interfaces, router chassis, firewalls, and CoS.

*JUNOS Internet Software Configuration Guide: Routing and Routing Protocols* —Provides an overview of routing concepts and describes how to configure routing, routing policy, and unicast and multicast routing protocols.

*JUNOS Internet Software Command Reference*—Describes the JUNOS Internet software commands you use to monitor and troubleshoot Juniper Networks routers.

## Manual Part Organization

The parts in this manual typically contain the following chapters:

**Overview**—Provides background information about and discusses concepts related to the software component described in that part of the book.

**Configuration statements**—Lists all the configuration statements available to configure the software component. These chapters provide an overview of the configuration statement hierarchy for each software component.

**Configuration guidelines**—Describes how to configure all the features of the software component. The first section of the configuration guidelines describes the minimum configuration for that component, listing the configuration statements you must include to enable the software component on the router with only the bare minimum functionality. The remaining sections in the configuration guidelines are generally arranged so that the most common features are near the beginning.

**Statement summary**—A reference that lists all configuration statements alphabetically and explains each statement and all its options. The explanation of each configuration statement consists of the following parts:

**Syntax**—Describes the full syntax of the configuration statement. For an explanation of how to read the syntax statements, see “Documentation Conventions” on page xxi.

**Hierarchy level**—Tells where in the configuration statement hierarchy you include the statement.

**Description**—Describes the function of the configuration statement.

**Options**—Describes the configuration statement’s options if there are any. For options with numeric values, the allowed range and default value, if any, are listed. For multiple options, if one option is the default, that fact is stated. If a configuration statement is at the top of a hierarchy of options that are other configuration statements, these options are generally explained separately in the statement summary section.

**Usage guidelines**—Points to the section or sections in the configuration guidelines section that describes how to use the configuration statement.

**Required privilege level**—Indicates the permissions that the user must have to view or modify the statement in the router configuration. For an explanation of the permissions, see the *JUNOS Internet Software Configuration Guide: Installation and System Management* .

**See also**—Indicates other configuration statements that might provide related or similar functionality.

## Using the Index

In the index, bold page numbers point to pages in the statement summary sections of configuration chapters. The index entry for each configuration statement always contains at least two entries. The first, with a bold page number on the same line as the statement name, references the statement summary section. The second entry, “usage guidelines,” references the section in the configuration guidelines section that describes how to use the statement.

## Documentation Conventions

### **General Conventions**

In general text, this manual uses the following conventions:

Statements, commands, filenames, directory names, IP addresses, and configuration hierarchy levels are shown in a sans serif font. In the following example, “stub” is a statement name and “[edit protocols ospf area-*id*]” is a configuration hierarchy level:

To configure a stub area, include the stub statement at the [edit protocols ospf area-*id*] hierarchy level:

In examples, text that you type literally is shown in a bold font. In the following example, you type the word “show”:

```
[edit protocols ospf area-id]
Cli# show
stub <default-metric>
```

Examples of command output are generally shown in a fixed-width font to preserve the column alignment. For example:

```
> show interfaces terse
Interface      Adman Link Prato Local          Remote
at-1/3/0       up
at-1/3/0.0     up   net 1.0.0.1      --> 1.0.0.2
                is
fxp0           up
fxp0.0         up   net 192.168.5.59/24
```

### **Conventions for Software Commands and Statements**

When describing the JUNOS software, this manual uses the following type and presentation conventions:

Statement or command names that you type literally are shown in a non-italicized font. In the following example, the statement name is “area”:

You configure all these routers by including the following area statement at the [edit protocols ospf] hierarchy level:

Options, which are variable terms for which you substitute appropriate values, are shown in italics. In the following example, “area-id” is an option. When you type the area statement, you substitute a value for *area-id*.

```
area-id;
```

Optional portions of a configuration statement are enclosed in angle brackets. In the following example, the “default-metric” portion of the statement is optional:

```
stub <default-metric>;
```

For text strings separated by a pipe ( | ), you must specify either *string1* or *string2*, but you cannot specify both or neither of them. Parentheses are sometimes used to group the strings.

```
string1 | string2  
(string1 | string2)
```

In the following example, you must specify either broadcast or multicast, but you cannot specify both:

```
broadcast | multicast
```

For some statements, you can specify a set of values. The set must be enclosed in square brackets. For example:

```
community name members [community-id]
```

The configuration examples in this manual are generally formatted in the way that they appear when you issue a show command. This format includes braces ( { } ) and semicolons. When you type configuration statements in the CLI, you do not type the braces and semicolons. However, when you type configuration statements in an ASCII file, you must include the braces and semicolons. For example:

```
[edit]
cli# set routing-options static route default nexthop address retain
[edit]
cli# show
routing-options {
  static {
    route default {
      nexthop address;
      retain;
    }
  }
}
```

Comments in the configuration examples are shown either preceding the lines that the comments apply to, or more often, on the same line. When comments are shown on the same line, they are preceded by a pound sign (#) to indicate where the comment starts. In an actual configuration, comments can only precede a line; they cannot be on the same line as a configuration statement. For example:

```

protocols {
  mpls {
    interface (interface-name | all);    # Required to enable MPLS on the interface
  }
  rsvp {
    interface-name;                      # Required for dynamic MPLS only
  }
}

```

The general syntax descriptions provide no indication of the number of times you can specify a statement, option, or keyword. This information is provided in the text of the statement summary.

## Documentation Feedback

We are always interested in hearing from our customers. Please let us know what you like and do not like about the Juniper Networks documentation, and let us know of any suggestions you have for improving the documentation. Also, let us know if you find any mistakes in the documentation. Send your feedback to [tech-doc@juniper.net](mailto:tech-doc@juniper.net).

## How to Request Support

For technical support, contact Juniper Networks at [support@juniper.net](mailto:support@juniper.net), or at 888-314-JTAC within the United States and 408-745-2121 from outside the United States.

