

## Verifying That the Virtual Chassis Ports Are Operational

**Purpose** Use the show virtual-chassis vc-port command to display the status of Virtual Chassis ports (VCPs).



**NOTE:** The interfaces for VCPs are not displayed when you issue the show interfaces command.

**Action** Display the VCP interfaces:

```
user@SWA-0> show virtual-chassis vc-portall-members
```

```
fpc0:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up
1/0	Configured	Up

```
fpc1:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up
1/0	Configured	Up

```
fpc2:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up
1/0	Configured	Up

```
fpc3:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up
1/0	Configured	Up

**Meaning** The dedicated VCPs are displayed as vcp-0 and vcp-1. The uplinks set as VCPs are displayed as 1/0. The FPC slots for EX-series switches are the same as the member IDs.

- Related Topics**
- Monitoring Virtual Chassis Configuration Status and Statistics
  - Configuring a Virtual Chassis (CLI Procedure)
  - Configuring a Virtual Chassis (J-Web Procedure)
  - Example: Configuring a Virtual Chassis Interconnected Across Multiple Wiring Closets