



Junos[®] OS for EX Series Ethernet Switches

Power over Ethernet (PoE) for EX Series Switches

Release

15.1



Published: 2015-05-15

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Junos[®] OS for EX Series Ethernet Switches Power over Ethernet (PoE) for EX Series Switches
Release 15.1
Copyright © 2015, Juniper Networks, Inc.
All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

	About the Documentation	ix
	Documentation and Release Notes	ix
	Supported Platforms	ix
	Using the Examples in This Manual	ix
	Merging a Full Example	x
	Merging a Snippet	x
	Documentation Conventions	xi
	Documentation Feedback	xiii
	Requesting Technical Support	xiii
	Self-Help Online Tools and Resources	xiii
	Opening a Case with JTAC	xiv
Part 1	Overview	
Chapter 1	Power over Ethernet Overview	3
	Understanding PoE on EX Series Switches	3
	PoE, PoE+, and Enhanced PoE	3
	PoE Power Allocation	5
	PoE Power Budget	5
	PoE Interface Power Allocation	9
	PoE Interface Power Priority	11
Part 2	Configuration	
Chapter 2	Configuration Examples	15
	Example: Configuring PoE Interfaces on an EX Series Switch	15
	Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch	17
	Example: Configuring PoE on an EX6200 or EX8200 Switch	22
Chapter 3	Configuration Tasks	31
	Configuring PoE on EX Series Switches (CLI Procedure)	31
	PoE Configurable Options	32
	Configuring the PoE Controller on EX2200, EX3200, EX3300, EX4200, and EX4300 Switches	34
	Configuring the PoE Controllers on EX6200 and EX8200 Switches	36
	Configuring PoE Interfaces	37
	Configuring PoE (J-Web Procedure)	38
	Configuring PoE on EX2200, EX2200-C, EX3200, EX3300, EX4200, and EX4300 Switches	38
	Configuring PoE on EX6200 Switches	39

Chapter 4	Configuration Statements	43
	[edit poe] Configuration Statement Hierarchy on EX Series Switches	43
	Supported Statements in the [edit poe] Hierarchy Level	44
	af-mode	45
	disable (Power over Ethernet)	46
	duration	47
	fpc (Line Card)	48
	fpc (Notification Control)	49
	guard-band	50
	interface (Power over Ethernet)	51
	interval (Power over Ethernet)	52
	management	53
	maximum-power (Interface)	54
	maximum-power (Line Card)	56
	notification-control	57
	poe	58
	priority (Power over Ethernet)	59
	telemetries	60
Part 3	Administration	
Chapter 5	Upgrading	63
	Upgrading the PoE Controller Software	63
	Determining Whether the PoE Controller Software Needs Upgrading	64
	Upgrading the PoE Controller Software	64
	Monitoring the Upgrade Progress	65
Chapter 6	Routine Monitoring	67
	Monitoring PoE	67
	Monitoring PoE Power Consumption (CLI Procedure)	68
	PoE Power Consumption on a Switch	68
	Current Power Consumption for PoE Interfaces	69
	Power Consumption for PoE Interfaces over Time	70
	Verifying PoE Configuration and Status (CLI Procedure)	71
	PoE Controller Configuration and Status	71
	PoE Interface Configuration and Status	72
	PoE SNMP Trap Generation Status	73
	PoE Line Card Configuration and Status	74
Chapter 7	Operational Commands	77
	clear poe telemetries interface	78
	request system firmware upgrade poe	79
	show poe controller	81
	show poe interface	84
	show poe notification-control	88
	show poe telemetries	90

Part 4	Troubleshooting	
Chapter 8	Troubleshooting Procedures	95
	Troubleshooting PoE Interfaces	95

List of Tables

	About the Documentation	ix
	Table 1: Notice Icons	xi
	Table 2: Text and Syntax Conventions	xi
Part 1	Overview	
Chapter 1	Power over Ethernet Overview	3
	Table 3: PoE Version Support	4
	Table 4: PoE Power Budget for EX2200 Switches	6
	Table 5: PoE Power Budget for EX3200 Switch Models	6
	Table 6: PoE Power Budget EX3300 Switch Models	6
	Table 7: PoE Power Budget for EX4200 Switch Models	7
	Table 8: PoE Power Budget for EX4300 Switch Models	7
	Table 9: Class of Powered Device and Power Levels	10
	Table 10: Maximum Power per Port in Static Mode	11
	Table 11: LLDP Power Priority Conversion	12
Part 2	Configuration	
Chapter 2	Configuration Examples	15
	Table 12: Components of the PoE Configuration Topology	16
	Table 13: Components of the PoE Configuration Topology	18
	Table 14: Components of the PoE Configuration Topology	23
	Table 15: Line Card PoE Power Budget and Power Priority	25
Chapter 3	Configuration Tasks	31
	Table 16: Configurable PoE Options and Default Settings	32
	Table 17: PoE Edit Settings	39
	Table 18: System Settings	39
	Table 19: Edit PoE Settings	40
	Table 20: FPC PoE Settings	40
Part 3	Administration	
Chapter 7	Operational Commands	77
	Table 21: show poe controller Output Fields	81
	Table 22: show poe interface Output Fields	84
	Table 23: show poe notification-control Output Fields	88
	Table 24: show poe telemetries interface Output Fields	90

Part 4	Troubleshooting	
Chapter 8	Troubleshooting Procedures	95
	Table 25: Troubleshooting a PoE Interface	95

About the Documentation

- Documentation and Release Notes on page ix
- Supported Platforms on page ix
- Using the Examples in This Manual on page ix
- Documentation Conventions on page xi
- Documentation Feedback on page xiii
- Requesting Technical Support on page xiii

Documentation and Release Notes

To obtain the most current version of all Juniper Networks[®] technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

Supported Platforms

For the features described in this document, the following platforms are supported:

- EX Series

Using the Examples in This Manual

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xml;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the **load** command, see the *CLI User Guide*.

Documentation Conventions

Table 1 on page xi defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 2 on page xi defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: user@host> configure

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> show chassis alarms No alarms currently active
<i>Italic text like this</i>	<ul style="list-style-type: none">Introduces or emphasizes important new terms.Identifies guide names.Identifies RFC and Internet draft titles.	<ul style="list-style-type: none">A policy <i>term</i> is a named structure that defines match conditions and actions.<i>Junos OS CLI User Guide</i>RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i>
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none">To configure a stub area, include the stub statement at the [edit protocols ospf area area-id] hierarchy level.The console port is labeled CONSOLE.
< > (angle brackets)	Encloses optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Encloses a variable for which you can substitute one or more values.	community name members [<i>community-ids</i>]
Indentation and braces ({ })	Identifies a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
GUI Conventions		
Bold text like this	Represents graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none">In the Logical Interfaces box, select All Interfaces.To cancel the configuration, click Cancel.

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select Protocols>Ospf .

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can provide feedback by using either of the following methods:

- Online feedback rating system—On any page at the Juniper Networks Technical Documentation site at <http://www.juniper.net/techpubs/index.html>, simply click the stars to rate the content, and use the pop-up form to provide us with information about your experience. Alternately, you can use the online feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>.
- E-mail—Send your comments to techpubs-comments@juniper.net. Include the document or topic name, URL or page number, and software version (if applicable).

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>

- Download the latest versions of software and review release notes:
<http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications:
<http://kb.juniper.net/InfoCenter/>
- Join and participate in the Juniper Networks Community Forum:
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

PART 1

Overview

- [Power over Ethernet Overview on page 3](#)

CHAPTER 1

Power over Ethernet Overview

- [Understanding PoE on EX Series Switches on page 3](#)

Understanding PoE on EX Series Switches

Power over Ethernet (PoE) enables electric power, along with data, to be passed over a copper Ethernet LAN cable. Powered devices—such as VoIP telephones, wireless access points, video cameras, and point-of-sale devices—that support PoE can receive power safely from the same access ports that are used to connect personal computers to the network. This reduces the amount of wiring in a network, and also eliminates the need to position a powered device near an AC power outlet, making network design more flexible and efficient.



NOTE: We recommend that you do not connect an enabled PoE port on one switch to an enabled PoE port on a second switch. If there is a large voltage difference between the power supplies of the two switches, the resulting negative current will trigger a fail-safe mechanism on the second switch that prevents the power sourcing equipment (PSE) from delivering power to the other PoE ports on that switch.

This topic describes PoE on Juniper Networks EX Series Ethernet Switches.

- [PoE, PoE+, and Enhanced PoE on page 3](#)
- [PoE Power Allocation on page 5](#)

PoE, PoE+, and Enhanced PoE

PoE was first defined in the IEEE 802.3af standard. In this standard, the amount of power that can be supplied to a powered device is limited to 15.4 W. A later standard, IEEE 802.3at, defined PoE+, which increases the amount of power to 30 W. The PoE+ standard provides support for legacy PoE devices—an IEEE 802.3af powered device can operate normally when connected to IEEE 802.3at (PoE+) power sourcing equipment.

Beginning in Juniper Networks Junos operating system (Junos OS) Release 11.1, Juniper Networks provides enhanced PoE on EX3200 and EX4200 switches. Enhanced PoE is a Juniper Networks extension to the IEEE 802.3af standard that provides power of up to 18.6 W per PoE port.

Table 3 on page 4 lists EX Series switches and line cards and the version of PoE they support.

Table 3: PoE Version Support

Switch or Line Card	PoE Version
EX2200 switch (EX2200-C-12P-2G, EX2200-24P-4G, EX2200-48P-4G models)	PoE+ (IEEE 802.3at) NOTE: Starting with Junos OS Release 12.2R1, PoE commands are enabled on all non-PoE-capable EX2200 switch models. The PoE commands do not provide any meaningful configuration on standalone non-PoE-capable switch models. However, in an EX2200 Virtual Chassis, you can execute PoE commands from a non-PoE-capable master switch to configure PoE on PoE-capable Virtual Chassis members.
EX3200 switch (EX3300-24P, EX3300-24T, EX3300-48P, EX3300-48T models)	Enhanced PoE
EX3300 switch (EX3300-24P, EX3300-48P models)	PoE+ (IEEE 802.3at)
EX4200 switch—P and T models (EX4200-24P, EX4200-24T, EX4200-48P, EX4200-48T)	Enhanced PoE
EX4200 switch—PX models (EX4200-24PX and EX4200-48PX)	PoE+ (IEEE 802.3at)
EX4300 switch (EX4300-24P and EX4300-48P)	PoE+ (IEEE 802.3at)
EX6200-48P (48-port PoE+) line card	PoE+ (IEEE 802.3at)
EX8200-2XS-40P (40-port PoE+ with 4-port SFP and 2-port SFP+) line card EX8200-48PL (2-port SFP+ and 48-port PoE+ 20 Gbps) line card	PoE+ (IEEE 802.3at)—Ports 0 through 11, and PoE (IEEE 802.3af)—remaining PoE ports.



NOTE: This topic and its related topics use the term PoE as a generic term to refer to PoE, PoE+, and enhanced PoE.

PoE Power Allocation

A switch or line card that supports PoE has a PoE controller that keeps track of the PoE power consumption on the switch or line card, and allocates power to the PoE ports. The following factors determine how the PoE controller allocates power to the PoE ports:

- [PoE Power Budget on page 5](#)
- [PoE Interface Power Allocation on page 9](#)
- [PoE Interface Power Priority on page 11](#)

PoE Power Budget

The PoE power budget is the total amount of power available for the PoE controller to allocate to the PoE ports. In allocating power, the PoE controller cannot exceed its PoE power budget and does not allocate power to a PoE port if the allocation exceeds the PoE power budget.

How the PoE power budget is determined depends on the switch model:

- [PoE Power Budget on EX2200, EX3200, EX3300, EX4200, and EX4300 Switches on page 5](#)
- [PoE Power Budget on EX6200 and EX8200 Switches on page 8](#)

PoE Power Budget on EX2200, EX3200, EX3300, EX4200, and EX4300 Switches

The PoE power budget on EX2200, EX3200, EX3300, EX4200, and EX4300 switches depends on the switch model and the capacities of the power supplies installed. To find the PoE power budget for each switch model, see [Table 4 on page 6](#) for EX2200 switch models, [Table 5 on page 6](#) for EX3200 switch models, [Table 6 on page 6](#) for EX3300 switch models, [Table 7 on page 7](#) for EX4200 switch models, and [Table 8 on page 7](#) for EX4300 switch models.

Use the `show poe controller` command to display a switch's PoE power budget.

If your switch supports power supplies of different capacities, keep the following points in mind:

- If you change your existing power supply to a lower-capacity power supply, the PoE power budget might no longer be sufficient to power all the PoE ports on the switch.
- If your switch supports redundant power supplies and you have installed power supplies of different capacities, the PoE power budget is based on the wattage of the lowest-capacity power supply.
- You cannot increase the number of PoE-capable ports on a switch by installing a power supply that has a higher capacity.

[Table 4 on page 6](#) lists the EX2200 switch models, number of PoE-enabled ports, power supply ratings, and PoE power budgets.

Table 4: PoE Power Budget for EX2200 Switches

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX2200-C-12T	–	30 W	–
EX2200-C-12P	12	180 W	100 W
EX2200-24T	–	75 W	–
EX2200-24P	24	550 W	405 W
EX2200-24T-DC	–	100 W	–
EX2200-48T	–	75 W	–
EX2200-48P	48	550 W	405 W

[Table 5 on page 6](#) lists the EX3200 switch models, number of PoE-enabled ports, power supply ratings, and PoE power budgets.

Table 5: PoE Power Budget for EX3200 Switch Models

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX3200-24T	8	320 W	130 W
EX3200-48T	8	320 W	130 W
EX3200-24P	24	600 W	410 W
EX3200-48P	48	930 W	740 W
EX3200-24T-DC	–	190 W	–
EX3200-48T-DC	–	190 W	–

[Table 6 on page 6](#) lists the EX3300 switch models, number of PoE-enabled ports, power supply ratings, and PoE power budgets.

Table 6: PoE Power Budget EX3300 Switch Models

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX3300-24T	–	100 W	–
EX3300-24P	24	550 W	405 W
EX3300-24T-DC	–	100 W	–

Table 6: PoE Power Budget EX3300 Switch Models (*continued*)

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX3300-48T	–	100 W	–
EX3300-48T-BF	–	100 W	–
EX3300-48P	48	900 W	740 W

[Table 7 on page 7](#) lists the EX4200 switch models, number of PoE-enabled ports, power supply ratings, and PoE power budgets.

Table 7: PoE Power Budget for EX4200 Switch Models

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX4200-24T	8	320 W	130 W
EX4200-48T	8	320 W	130 W
EX4200-24P	24	600 W	410 W
EX4200-48P	48	930 W	740 W
EX4200-24PX	24	930 W	740 W
EX4200-48PX	48	930 W	740 W
EX4200-24F	–	320 W	–
EX4200-24F-DC	–	190 W	–
EX4200-24T-DC	–	190 W	–
EX4200-48T-DC	–	190 W	–

[Table 8 on page 7](#) lists the EX4300 switch models, number of PoE-enabled ports, power supply ratings, and PoE power budgets.

Table 8: PoE Power Budget for EX4300 Switch Models

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX4300-48P	48	1100 W	900 W
EX4300-48T	0	350 W	–
EX4300-48T-AFI	0	350 W	–

Table 8: PoE Power Budget for EX4300 Switch Models (*continued*)

Switch Model Number	Number of PoE-Enabled Ports	Power Supply Rating	PoE Power Budget
EX4300-24P	24	715 W	565 W
EX4300-24T	0	350 W	-
EX4300-48T-DC	0	550 W	-
EX4300-48T-DC-AFI	0	550 W	-

PoE Power Budget on EX6200 and EX8200 Switches

For EX6200 and EX8200 switches, each line card that supports PoE has its own PoE controller and PoE power budget. The PoE power budget is allocated to the line card by the switch's power management, while PoE power is allocated to the ports on the line card by the PoE controller. Because EX6200 and EX8200 switches can differ in the number and capacity of power supplies installed and in the number and types of line cards installed, the amount of power available for PoE power can vary for switches of the same model.

Power management allocates PoE power to line cards that support PoE only after it has allocated base power to and powered on all line cards. It then allocates the remaining power to the PoE power budgets of PoE line cards in order of line card power priority. (In a default configuration, power priority is determined by the line card slot number, with slot 0 having the highest priority.) If the remaining power is insufficient to provide PoE power to all PoE line cards, a low-priority line card might receive no PoE power or partial PoE power.

By default, power management allocates enough PoE power to a line card to power all PoE ports at their maximum supported power. If the powered devices connected to that line card require less power than that, you can configure a smaller PoE power budget for the line card. For example, power management normally allocates 915 W of PoE power to a 48-port PoE+ 20 Gbps (EX8200-48PL) line card. If the powered devices connected to that line card consume no more than a total of 250 W, you can set the PoE power budget for the line card to 250 W. Doing so frees 665 W, which then can be used to fulfill the PoE power needs of lower-priority line cards.

You can also configure the power priority of the PoE ports on a line card. If power management is unable to allocate enough power to a line card to meet its PoE power budget, the line card PoE controller turns off power to PoE ports in reverse priority order as required to meet the reduced power allocation.

Power management adjusts PoE power allocations as power availability and demand in a switch changes. As a general rule, power management allocates power to power on line cards before it allocates PoE power. For example, if you add a line card and there is insufficient power available to power it on, power management reduces the PoE power it provides to line cards, starting with the lowest priority line card, until it frees enough

power to power on the new line card. When power management reduces the PoE power budget for a line card because of insufficient power, it logs a message in the system log.

Note that the actual power consumed by the powered devices does not affect power management's power allocation for a line card. If you have set the PoE budget for a line card to 500 W, power management allocates 500 W even if the powered devices are consuming less power than that. Similarly, the PoE power budget is not increased if you add additional powered devices: if the powered devices require more than the 500 W PoE budget that you have configured, lower-priority devices do not receive power.

You can display the switch's power budget maintained by power management, including its PoE power allocations, by using the **show chassis power-budget-statistics** command. You can also display the PoE power budget for each line card in a switch by using the **show poe controller** command.

For more information about how power management allocates power, including PoE power, see *Understanding Power Management on EX Series Switches*.

PoE Interface Power Allocation

You can configure how the switch determines the maximum power for a PoE interface and how power is allocated to the PoE interfaces. If the power consumption of a powered device exceeds the maximum power allocated to the interface, the switch turns off power to the interface.

These PoE power allocation methods are available:

- [LLDP Power Negotiation on page 9](#)
- [Class PoE Management Mode on page 9](#)
- [Static PoE Management Mode on page 10](#)

LLDP Power Negotiation

Link Layer Discovery Protocol (LLDP) power negotiation enables the PoE controller to dynamically allocate power to LLDP-enabled powered devices based on their power needs. The PoE controller allocates to an interface only the power currently required by the connected powered device, and it can allocate the power in small increments.

When the PoE **management** is set to **class** and LLDP is enabled (both are default settings), LLDP power negotiation is enabled by default. If you disable LLDP power negotiation or the powered device does not support it, the switch uses the class of the powered device to determine the maximum power for interfaces.



NOTE: LLDP power negotiation is not supported on EX3200 and EX4200 (except EX4200 PX models) switches.

Class PoE Management Mode

In the **class** PoE management mode, the maximum power for an interface is determined by the class of the connected powered device. The PoE standards IEEE 802.3af and IEEE

802.3at define classes of powered devices based on the levels of power that they require. [Table 9 on page 10](#) lists the classes of powered devices and associated power levels.

Table 9: Class of Powered Device and Power Levels

Standard	Class	Maximum Power Delivered by PoE Port	Power Range of Powered Device
IEEE 802.3af (PoE) and IEEE 802.3at (PoE+)	0	15.4 W	0.44 through 12.95 W
	1	4.0 W	0.44 through 3.84 W
	2	7.0 W	3.84 through 6.49 W
	3	15.4 W	6.49 through 12.95 W
IEEE 802.3at (PoE+)	4	30.0 W	12.95 through 25.5 W

Because of line loss, the power range of the powered device is less than the maximum power delivered at the PoE port for each class. Line loss is influenced by cable length, quality, and other factors and is typically less than 16 percent of the maximum power.

The powered device communicates to the PoE controller which class it belongs to when it is connected. The PoE controller then allocates to the interface the maximum power required by the class (see [Table 9 on page 10](#)). It does not allocate power to an interface until a powered device is connected. **Class 0** is the default class for powered devices that do not provide class information. Class 4 powered devices are supported only by PoE ports that support IEEE 802.3at (PoE+).

By default, when the **management** option is set to **class** and LLDP are enabled, LLDP power negotiation is also enabled on supported switches. See [“LLDP Power Negotiation” on page 9](#) for more information.

Static PoE Management Mode

In the **static** PoE management mode, you specify the maximum power for each PoE interface. The PoE controller then allocates this amount of power to the interface from its total budget. For example, if you specify a maximum value of 8.0 W for ge-0/0/3, the PoE controller allocates 8.0 W out of its total power budget for this interface. This amount is allocated to the interface irrespective of whether a powered device is connected to the interface or the connected powered device uses less power than 8.0 W.

Because of line loss, the power received by the powered device can be less than the power available at the PoE port. [Table 10 on page 11](#) shows the maximum power available at a PoE port and the resulting power guaranteed to the powered device.

Table 10: Maximum Power per Port in Static Mode

Switch or Line Card	Maximum Power Delivered by PoE Port	Guaranteed Power to Powered Devices
EX2200 switches, EX3300 switches, EX4200 PX model switches, and EX4300 switches operating in a mixed Virtual Chassis	30 W	25.5 W
EX3200 switches and EX4200 P and T model switches running Junos OS Release 10.4 or earlier	15.4 W	12.95 W
EX3200 switches and EX4200 P and T model switches running Junos OS Release 11.1 or later	18.6 W <i>NOTE:</i> Switches that are upgraded to Junos OS Release 11.1 from a previous release require an upgrade of the PoE controller software to obtain 18.6 W.	15.64 W
EX6200-48P line cards	30 W	25.5 W
EX8200-2XS-40P line cards and EX8200-48PL line cards	30 W (ports 0 through 11) 15.4 W (remaining PoE ports)	25.5 W 12.95 W

PoE Interface Power Priority

You can configure a PoE interface to have a power priority. The power priority determines which interfaces receive power if PoE power demands are greater than the PoE power budget. If the total power allocated for all interfaces exceeds the switch budget, PoE power to lower-priority interfaces is turned off and the power allocated to those interfaces drops to 0. Thus you must set interfaces that connect to critical powered devices, such as security cameras and emergency phones, to high priority.

Among PoE interfaces that have the same assigned priority, power priority is determined by the port number, with lower-numbered ports having higher priority.

For EX6200 and EX8200 switches, interface power priority determines the relative priority of the interfaces on a line card, not on the switch as a whole. The relative priority of interfaces residing on different line cards is determined by line card priority. For example, if line card 1 has a higher power priority than line card 2 and a power shortage occurs, power is removed from the PoE interfaces in this order:

- Low-priority interfaces on line card 2
- High-priority interfaces on line card 2
- Low-priority interfaces on line card 1
- High-priority interfaces on line card 1

You can manually configure PoE interface power priority, or you can enable LLDP power priority, which assigns each interface the power priority provided by the connected LLDP-enabled powered device. [Table 11 on page 12](#) describes how the switch converts LLDP power priorities to switch power priorities.

Table 11: LLDP Power Priority Conversion

LLDP Power Priority	Switch Power Priority
Critical, High	High
Low	Low



NOTE: LLDP power priority requires LLDP power negotiation to be enabled, which is enabled by default when the PoE management option is set to class.



NOTE: LLDP power priority is not supported on EX3200 and EX4200 (except EX4200 PX model) switches.

Related Documentation

- [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
- [Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22](#)
- [Upgrading the PoE Controller Software on page 63](#)

PART 2

Configuration

- [Configuration Examples on page 15](#)
- [Configuration Tasks on page 31](#)
- [Configuration Statements on page 43](#)

CHAPTER 2

Configuration Examples

- [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
- [Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22](#)

Example: Configuring PoE Interfaces on an EX Series Switch

Power over Ethernet (PoE) ports supply electric power over the same ports that are used to connect network devices and enable you to plug in devices that require both network connectivity and electric power, such as VoIP phones, wireless access points, and some IP cameras. This reduces the amount of wiring in a network, and also eliminates the need to position a powered device near an AC power outlet, making network design more flexible and efficient.

You do not need to configure PoE unless you want to modify the default values or disable PoE on a specific interface.

This example describes a default configuration of PoE interfaces on an EX Series switch:

- [Requirements on page 15](#)
- [Overview and Topology on page 16](#)
- [Configuration on page 16](#)
- [Verification on page 17](#)

Requirements

This example uses the following hardware and software components:

- One EX Series switch that supports PoE
- Avaya IP telephones
- Wireless access point
- Junos OS Release 9.0 or later for EX Series switches

Before you configure PoE, be sure you have:

- Performed the initial switch configuration. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* or *Connecting and Configuring an EX Series Switch (J-Web Procedure)* for details.

Overview and Topology

The topology used in this example consists of a switch that has 24 ports. Eight of the ports support PoE (IEEE 802.3af), which means they provide both network connectivity and electric power for powered devices such as VoIP telephones, wireless access points, and IP security cameras that require 12.95 W or less. The remaining 16 ports provide only network connectivity. You use the standard ports to connect devices that have their own power sources, such as desktop and laptop computers, printers, and servers.

[Table 12 on page 16](#) details the topology used in this configuration example.

Table 12: Components of the PoE Configuration Topology

Property	Settings
Switch hardware	EX Series switch with 24 Gigabit Ethernet ports: 8 PoE interfaces (ge-0/0/0 through ge-0/0/7) and 16 non-PoE interfaces (ge-0/0/8 through ge-0/0/23)
VLAN name	default
Connection to a wireless access point (requires PoE)	ge-0/0/0
Connections to Avaya IP telephones with integrated hubs that allow phone and desktop PC to connect to a single port (requires PoE)	ge-0/0/1 through ge-0/0/7
Direct connections to desktop PCs, file servers, integrated printer/fax/copier machines (no PoE required)	ge-0/0/8 through ge-0/0/20
Unused ports (for future expansion)	ge-0/0/21 through ge-0/0/23

Configuration

To enable the default PoE configuration on the switch:

CLI Quick Configuration

To quickly enable the default configuration on the switch:

Simply connect the powered devices to the PoE ports.

Step-by-Step Procedure

To use the PoE interfaces with default values:

1. Make sure the switch is powered on.
2. Connect the wireless access point to interface ge-0/0/0.
3. Connect the Avaya phones to interfaces ge-0/0/1 through ge-0/0/7.

Verification

To verify that PoE interfaces have been created and are operational, perform this task:

- [Verifying That the PoE Interfaces Have Been Created on page 17](#)

Verifying That the PoE Interfaces Have Been Created

Purpose Verify that the PoE interfaces have been created on the switch.

Action List all the PoE interfaces configured on the switch:

```
user@switch> show poe interface
```

Interface	Admin status	Oper status	Max power	Priority	Power consumption	Class
ge-0/0/0	Enabled	ON	15.4W	Low	7.9W	0
ge-0/0/1	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/2	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/3	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/4	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/5	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/6	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/7	Enabled	ON	15.4W	Low	3.2W	2

Meaning The **show poe interface** command lists PoE interfaces configured on the switch, with their status, priority, power consumption, and class. This output shows that eight interfaces have been created with default values and are consuming power at the expected rates.

- Related Documentation**
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
 - [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
 - [Troubleshooting PoE Interfaces on page 95](#)

Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch

Power over Ethernet (PoE) ports supply electric power over the same ports that are used to connect network devices. These ports enable you to plug in devices that need both network connectivity and electric power, such as VoIP phones, wireless access points, and some IP cameras.

By default, PoE ports on EX Series switches are set to low power priority. You can configure a PoE port to have a high power priority setting. If a situation arises where there is not sufficient power for all the PoE ports, the available power is directed to the higher priority ports, while power to the lower priority ports is shut down as needed. Thus you must set ports that connect to security cameras, emergency phones, and other high priority powered devices to high-priority.

This example describes how to configure a few high-priority PoE interfaces.

- [Requirements on page 18](#)
- [Overview and Topology on page 18](#)
- [Configuration on page 19](#)
- [Verification on page 21](#)

Requirements

This example uses the following hardware and software components:

- One EX Series switch that supports PoE
- Powered devices—wireless access point, VoIP telephones, and IP security cameras—that require PoE
- Junos OS Release 9.0 or later for EX Series switches

Before you configure PoE, be sure you have:

- Performed the initial switch configuration. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* or *Connecting and Configuring an EX Series Switch (J-Web Procedure)* for details.

Overview and Topology

The topology used in this example consists of a switch that has 24 ports. Eight of the ports support PoE (IEEE 802.3af), which means they provide both network connectivity and electric power for powered devices such as VoIP telephones, wireless access points, and IP security cameras that require 12.95 W or less. The remaining 16 ports provide only network connectivity. You use the standard ports to connect devices that have their own power sources, such as desktop and laptop computers, printers, and servers.

[Table 13 on page 18](#) details the topology used in this configuration example.

Table 13: Components of the PoE Configuration Topology

Property	Settings
Switch hardware	Switch with 24 Gigabit Ethernet ports: 8 PoE interfaces (ge-0/0/0 through ge-0/0/7) and 16 non-PoE interfaces (ge-0/0/8 through ge-0/0/23)
VLAN name	default
Connection to a wireless access point (requires PoE)	ge-0/0/0
Security IP Cameras (require PoE)	ge-0/0/1 and ge-0/0/2 high
Emergency VoIP phone (requires PoE)	ge-0/0/3 high
VoIP phone in Executive Office (requires PoE)	ge-0/0/4 high
Other VoIP phones (require PoE)	ge-0/0/5 through ge-0/0/7

Table 13: Components of the PoE Configuration Topology (*continued*)

Property	Settings
Direct connections to desktop PCs, file servers, integrated printer/fax/copier machines (no PoE required)	ge-0/0/8 through ge-0/0/20
Unused ports (for future expansion)	ge-0/0/21 through ge-0/0/23

Configuration

To configure PoE interfaces:

CLI Quick Configuration

By default, PoE interfaces are created for all PoE ports and PoE is enabled. The default priority for PoE interfaces is **low**.

To quickly set some interfaces to high priority and to include descriptions of the interfaces, copy the following commands and paste them into the switch terminal window:

```
[edit]
set poe interface ge-0/0/1 priority high telemetries
set poe interface ge-0/0/2 priority high telemetries
set poe interface ge-0/0/3 priority high telemetries
set poe interface ge-0/0/4 priority high telemetries
set interfaces ge-0/0/0 description "wireless access point"
set interfaces ge-0/0/1 description "security camera front door"
set interfaces ge-0/0/2 description "security camera back door"
set interfaces ge-0/0/3 description "emergency phone"
set interfaces ge-0/0/4 description "Executive Office VoIP phone"
set interfaces ge-0/0/5 description "staff VoIP phone"
set interfaces ge-0/0/6 description "staff VoIP phone"
set interfaces ge-0/0/7 description "staff VoIP phone"
```

Step-by-Step Procedure

To configure PoE interfaces with different priorities:

1. Set the interfaces connected to high-priority powered devices to high priority. Include the **telemetries** statement for the high-priority interfaces, thus enabling the logging of power consumption on those interfaces:

```
[edit poe]
user@switch# set interface ge-0/0/1 priority high telemetries
user@switch# set interface ge-0/0/2 priority high telemetries
user@switch# set interface ge-0/0/3 priority high telemetries
user@switch# set interface ge-0/0/4 priority high telemetries
```

2. Provide descriptions for the PoE interfaces:

```
[edit interfaces]
user@switch# set ge-0/0/0 description "wireless access point"
user@switch# set ge-0/0/1 description "security camera front door"
user@switch# set ge-0/0/2 description "security camera back door"
user@switch# set ge-0/0/3 description "emergency phone"
user@switch# set ge-0/0/4 description "Executive Office VoIP phone"
user@switch# set ge-0/0/5 description "staff VoIP phone"
user@switch# set ge-0/0/6 description "staff VoIP phone"
user@switch# set ge-0/0/7 description "staff VoIP phone"
```

3. Connect the wireless access point to interface ge-0/0/0. This interface uses the default PoE settings.

4. Connect the two security cameras to interfaces ge-0/0/1 and ge-0/0/2. These interfaces are set to high priority with telemetries enabled.
5. Connect the emergency VoIP phone to interface ge-0/0/3. This interface is set to high priority with telemetries enabled.
6. Connect the Executive Office VoIP phone to interface ge-0/0/4. This interface is set to high priority with telemetries enabled.
7. Connect the staff VoIP phones to ge-0/0/5, ge-0/0/6, and ge-0/0/7. These interfaces use the default PoE settings.

Results

Check the results of the configuration:

```
[edit]
user@switch# show
interfaces {
  ge-0/0/0 {
    description "wireless access point";
    unit 0 {
      family ethernet-switching;
    }
  }
  ge-0/0/1 {
    description "security camera front door";
    unit 0 {
      family ethernet-switching;
    }
  }
  ge-0/0/2 {
    description "security camera back door";
    unit 0 {
      family ethernet-switching;
    }
  }
  ge-0/0/3 {
    description "emergency phone";
    unit 0 {
      family ethernet-switching;
    }
  }
  ge-0/0/4 {
    description "Executive Office VoIP phone";
    unit 0 {
      family ethernet-switching;
    }
  }
  ge-0/0/5 {
    description "staff VoIP phone";
    unit 0 {
      family ethernet-switching;
    }
  }
}
```

```

}
ge-0/0/6 {
  description "staff VoIP phone";
  unit 0 {
    family ethernet-switching;
  }
}
ge-0/0/7 {
  description "staff VoIP phone";
  unit 0 {
    family ethernet-switching;
  }
}
}
poe {
  interface all;
  interface ge-0/0/1 {
    priority high;
    telemetries;
  }
  interface ge-0/0/2 {
    priority high;
    telemetries;
  }
  interface ge-0/0/3 {
    priority high;
    telemetries;
  }
  interface ge-0/0/4 {
    priority high;
    telemetries;
  }
}
}

```

Verification

To verify that PoE interfaces have been created and are operational, perform the following tasks:

- [Verifying That the PoE Interfaces Have Been Created with the Correct Priorities on page 21](#)

Verifying That the PoE Interfaces Have Been Created with the Correct Priorities

Purpose Verify that the PoE interfaces on the switch are now set to the correct priority settings.

Action List all the PoE interfaces configured on the switch:

```
user@switch> show poe interface
```

Interface	Admin	Oper	Max	Priority	Power	Class
	status	status	power		consumption	
ge-0/0/0	Enabled	ON	15.4W	Low	7.9W	0
ge-0/0/1	Enabled	ON	15.4W	High	4.8W	0
ge-0/0/2	Enabled	ON	15.4W	High	4.8W	0
ge-0/0/3	Enabled	ON	15.4W	High	3.3W	2
ge-0/0/4	Enabled	ON	15.4W	High	4.7W	2

ge-0/0/5	Enabled	ON	15.4W	Low	3.2W	2
ge-0/0/6	Enabled	ON	15.4W	Low	3.3W	2
ge-0/0/7	Enabled	ON	15.4W	Low	3.3W	2

Meaning The **show poe interface** command lists PoE interfaces configured on the switch, with their status, priority, power consumption, and class. This output shows that eight PoE interfaces are enabled. Interfaces ge-0/0/1 through ge-0/0/4 are configured as priority **high**. The remaining PoE interfaces are configured with the default priority value of **low**.

Related Documentation

- [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
- [Troubleshooting PoE Interfaces on page 95](#)

Example: Configuring PoE on an EX6200 or EX8200 Switch

Power over Ethernet (PoE) ports supply electric power over the same ports that are used to connect network devices. These ports allow you to plug in devices that need both network connectivity and electric power, such as voice over IP (VoIP) phones, wireless access points, and IP cameras.

On EX6200 and EX8200 switches, the PoE power budget—that is, the total amount of PoE power that is available to the PoE ports on the switch—can vary according to the number and type of power supplies installed and the power requirements of other components, such as line cards. To make the most efficient use of the PoE power budget for the switch, you can configure the PoE power budget for each PoE line card so that the line card power budget is tailored to the power requirements of the connected powered devices.

This example shows how to configure PoE on an EX8200 switch. The principles illustrated by this example apply to EX6200 switches as well.

This example covers:

- [Requirements on page 22](#)
- [Overview and Topology on page 23](#)
- [Configuration on page 26](#)
- [Verification on page 27](#)

Requirements

This example uses the following software and hardware components:

- Junos OS Release 11.2 or later for EX Series switches
- An EX8208 switch with the following components installed:
 - Six 2000 W AC power supplies using low-line power inputs
 - Two EX8200-48T (48-port RJ-45) line cards

- Two EX8200-2XS-40P (40-port PoE+ with 4-port SFP and 2-port SFP+) line cards
- Three EX8200-48PL (48-port PoE+ 20 Gbps) line cards

Before you configure PoE, be sure you have:

- Performed the initial switch configuration. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* or *Connecting and Configuring an EX Series Switch (J-Web Procedure)* for details.

Overview and Topology

For EX6200 and EX8200 switches, each line card that supports PoE has its own PoE controller and PoE power budget. The PoE power budget for a line card is allocated by the switch power management out of the total power available on the switch. By default, power management allocates to each PoE card the maximum power for that card—that is, the amount of power needed to supply all PoE ports on the cards with their maximum supported power.

Depending on the number and capacity of power supplies installed and the power requirements of the installed line cards in a switch, there might not be enough power available to provide the maximum power to all PoE line cards. Because power management by default allocates maximum power to each line card in priority order until available power runs out, lower-priority PoE line cards might receive partial or no PoE power, while higher-priority PoE line cards might receive more PoE power than the connected powered devices require.

To avoid this issue, you can configure smaller power budgets for line cards than the maximum. For example, power management allocates 915 W of PoE power to a EX8200-48PL line card by default. If the connected powered devices consume no more than a total of 250 W, you can set the PoE power budget for the line card to 250 W. Doing so frees up 665 W, which then can be used to fulfill the PoE power needs of lower-priority line cards.

The topology used in this example consists of a switch that has a mixture of line cards installed, some of which support PoE and some of which do not.

[Table 14 on page 23](#) details the topology used in this configuration example.

Table 14: Components of the PoE Configuration Topology

Component	Description	Comments
Power supplies	Six 2000 W power supplies with low-line power inputs	1200 W capacity each
Line card 0	EX8200-48T line card (no PoE ports)	Ports 0 through 47—Access ports for non-PoE devices, such as print and file servers or workstations not connected through VoIP phones
Line card 1	EX8200-48PL line card	Ports 0 through 47—Access ports for PoE class 2 VoIP phones

Table 14: Components of the PoE Configuration Topology (*continued*)

Component	Description	Comments
Line card 2	EX8200-48PL line card	Ports 0 through 47—Access ports for PoE class 2 VoIP phones
Line card 3	EX8200-2XS-40P line card	<p>Ports 0 through 11—Access ports for high-priority PoE+ class 4 devices, such as door access control devices, pan-tilt-zoom security cameras, and high-power wireless access points.</p> <p>Ports 12 through 22—Access ports for high-priority PoE class 3 devices, such as static security cameras, executive video VoIP phones, and wireless access points.</p> <p>Ports 22 through 40—Access ports for PoE class 2 devices, such as VoIP phones.</p> <p>SFP+ ports 44 and 45—Uplink ports to the distribution switch, link aggregated with the uplink ports on line card 4.</p>
Line card 4	EX8200-2XS-40P line card	<p>Ports 0 through 11—Access ports for high-priority PoE+ class 4 devices</p> <p>Ports 12 through 40—Access ports for PoE class 2 devices</p> <p>SFP+ ports 44 and 45—Uplinks ports to the distribution switch, link aggregated with the uplink ports on line card 3</p>
Line card 5	EX8200-48T line card (no PoE ports)	Ports 0 through 47—Access ports for non-PoE devices
Line card 6	EX8200-48PL line card	Ports 0 through 47—Access ports for PoE class 2 VoIP phones

The following output from the **show chassis power-budget-statistics** command shows how power is being allocated to the switch components before PoE is configured:

```

user@switch# show chassis power-budget-statistics
PSU 0 (EX8200-AC2K) : 1200 W Online
PSU 1 (EX8200-AC2K) : 1200 W Online
PSU 2 (EX8200-AC2K) : 1200 W Online
PSU 3 (EX8200-AC2K) : 1200 W Online
PSU 4 (EX8200-AC2K) : 1200 W Online
PSU 5 (EX8200-AC2K) : 1200 W Online
Total Power supplied by all Online PSUs : 7200 W
Power Redundancy Configuration : N+1
Power Reserved for the Chassis : 1600 W
FPC Statistics Base power PoE power Priority
FPC 0 (EX8200-48T) : 350 W 0 W 7
FPC 1 (EX8200-48PL) : 267 W 915 W 7
FPC 2 (EX8200-48PL) : 267 W 915 W 7
FPC 3 (EX8200-2XS-40P) : 387 W 792 W 7
FPC 4 (EX8200-2XS-40P) : 387 W 792 W 7
FPC 5 (EX8200-48T) : 350 W 0 W 7

```

```

FPC 6 (EX8200-48PL) : 267 W 96 W 7

Total (non-PoE) Power allocated : 3875 W
Total Power allocated for PoE : 3510 W
Power Available (Redundant case) : 2675 W
Total Power Available : 0 W

```

The **Total Power Available** field shows that all available power is being used. Because there is not enough power, the line card in slot 6 is allocated a PoE power budget of only 96 W, which is insufficient to meet the requirements of the connected VoIP phones.

In addition, the assigned power priorities of the line cards do not align with their actual power priority. Line cards 3 and 4 should have the highest power priorities because they provide PoE power to critical security devices and because they provide the connections to the distribution switch. Because the default configuration gives all line cards the same assigned priority (the lowest priority), the power priority for line cards is determined by their slot numbers. Under the default configuration, line card 0 has the highest power priority, not line card 3.

To solve these issues, this example configures the PoE power budgets and power priorities for the line cards as shown in [Table 15 on page 25](#).

Table 15: Line Card PoE Power Budget and Power Priority

FPC	Power Requirements of Powered Devices	PoE Power Budget for Line Card	Power Priority of Line Card
0	Not applicable	Not applicable	7
1	48 class 2 devices (maximum of 7 W each)	336 W	7
2	48 class 2 devices (maximum of 7 W each)	336 W	7
3	12 class 4 devices (maximum of 30 W each) 10 class 3 devices (maximum of 15.4 W each) 18 class 2 devices (maximum of 7 W each)	640 W	0
4	12 class 4 devices (maximum of 30 W each) 28 class 2 devices (maximum of 7 W each)	556 W	1
5	Not applicable	Not applicable	7
6	48 class 2 devices (maximum of 7 W each)	336 W	7

Other than ensuring that the PoE interfaces are enabled for PoE, this example performs no configuration of the PoE interfaces because the default settings for the PoE interfaces are acceptable in this example. You can, however, configure the PoE interfaces on an EX6200 or EX8200 switch as described in [“Configuring PoE on EX Series Switches \(CLI Procedure\)” on page 31](#) or as shown in [“Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch” on page 17](#).

Configuration

To configure PoE on an EX8200 switch:

CLI Quick Configuration

To quickly configure the PoE power budget for PoE line cards and to set the power priority for high-priority line cards, copy the following commands and paste them into the switch terminal window:

```
[edit]
set poe interface all
set poe fpc 3 maximum-power 640
set poe fpc 4 maximum-power 556
set poe fpc 1 maximum-power 336
set poe fpc 2 maximum-power 336
set poe fpc 6 maximum-power 336
set chassis fpc 3 power-budget-priority 0
set chassis fpc 4 power-budget-priority 1
```

Step-by-Step Procedure

To configure PoE on an EX8200 switch:

1. Verify that PoE is enabled on all PoE interfaces by entering the **[edit poe]** hierarchy and showing the current configuration:

```
[edit]
user@switch# edit poe
```

```
[edit poe]
user@switch# show
interface all;
```

If the **interface all** statement does not appear, enable PoE on all PoE interfaces:

```
[edit poe]
user@switch# set interface all
```

2. Set the PoE power budget for line card 3 to 640 W:

```
[edit poe]
user@switch# set fpc 3 maximum-power 640
```

3. Set the PoE power budget for line card 4 to 556 W:

```
[edit poe]
user@switch# set fpc 4 maximum-power 556
```

4. Set the PoE power budgets to 336 W for the remaining PoE line cards:

```
[edit poe]
user@switch# set fpc 1 maximum-power 336
```

```
[edit poe]
user@switch# set fpc 2 maximum-power 336
```



```
[edit poe]
user@switch# set fpc 6 maximum-power 336
```

5. Enter the [edit chassis] hierarchy and set the line card power priority to 0 and 1 for line cards 3 and 4:

```
[edit poe]
user@switch# top edit chassis
```

```
[edit chassis]
user@switch# set fpc 3 power-budget-priority 0
```

```
[edit chassis]
user@switch# set fpc 4 power-budget-priority 1
```

Results

Check the results of the configuration:

```
[edit]
user@switch# show

chassis {
  fpc 3 {
    power-budget-priority 0;
  }
  fpc 4 {
    power-budget-priority 1;
  }
}
poe {
  fpc 3 {
    maximum-power 640;
  }
  fpc 4 {
    maximum-power 556;
  }
  fpc 1 {
    maximum-power 336;
  }
  fpc 2 {
    maximum-power 336;
  }
  fpc 6 {
    maximum-power 336;
  }
  interface all;
}
```

Verification

To verify that the PoE line cards have been configured correctly and that their PoE power budgets have been fully allocated, perform the following tasks:

- [Verifying the Poe Line Card Configuration and Power Budgets on page 28](#)
- [Verifying the Power Budget for the Switch and Line Card Power Priorities on page 28](#)

Verifying the Poe Line Card Configuration and Power Budgets

Purpose Verify that the line card PoE power budgets have been allocated correctly.

Action Show the PoE controller settings for the line cards:

```
user@switch> show poe controller
```

Controller index	Maximum power	Power consumption	Guard band	Management	Status
1	336.00W	0.00W	0W	Class	AT/AF COMBO
2	336.00W	0.00W	0W	Class	AT/AF COMBO
3	640.00W	0.00W	0W	Class	AT/AF COMBO
4	556.00W	0.00W	0W	Class	AT/AF COMBO
6	336.00W	0.00W	0W	Class	AT/AF COMBO

Meaning As shown by the **Maximum power** field, the PoE power budgets for the PoE line cards have been correctly configured and power management was able to allocate the configured PoE power budgets to the line cards.

Verifying the Power Budget for the Switch and Line Card Power Priorities

Purpose Verify the overall power budget for the switch and the line card power priorities.

Action Show the power budget for the switch:

```
user@switch# show chassis power-budget-statistics
```

PSU 0	(EX8200-AC2K)	:	1200 W	Online
PSU 1	(EX8200-AC2K)	:	1200 W	Online
PSU 2	(EX8200-AC2K)	:	1200 W	Online
PSU 3	(EX8200-AC2K)	:	1200 W	Online
PSU 4	(EX8200-AC2K)	:	1200 W	Online
PSU 5	(EX8200-AC2K)	:	1200 W	Online
Total Power supplied by all Online PSUs			:	7200 W
Power Redundancy Configuration			:	N+1
Power Reserved for the Chassis			:	1600 W
FPC Statistics			Base power	PoE power Priority
FPC 0	(EX8200-48T)	:	350 W	0 W 7
FPC 1	(EX8200-48PL)	:	267 W	336 W 7
FPC 2	(EX8200-48PL)	:	267 W	336 W 7
FPC 3	(EX8200-2XS-40P)	:	387 W	640 W 0
FPC 4	(EX8200-2XS-40P)	:	387 W	556 W 1
FPC 5	(EX8200-48T)	:	350 W	0 W 7
FPC 6	(EX8200-48PL)	:	267 W	336 W 7
Total (non-PoE) Power allocated			:	3875 W
Total Power allocated for PoE			:	2204 W
Power Available (Redundant case)			:	2675 W
Total Power Available			:	1306 W

Meaning After each PoE line card has been allocated its configured PoE power budget, 1306 W remain unallocated on the switch. If one of the 1200 W power supplies fails, the PoE line cards will still receive their configured PoE power budgets.

Line cards 3 and 4 have the highest priorities, priority 0 and 1 respectively. The remaining line cards have the same assigned priority, 7. Within the group of line cards of the same assigned priority, power priority is determined by slot number, with lower-numbered slots having higher priority. Thus PoE line cards are allocated PoE power in this order: line card 3, 4, 1, 2, 6. If two or more power supplies fail, PoE power is removed from the line cards in reverse priority order, starting with line card 6.

**Related
Documentation**

- [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
- [Troubleshooting PoE Interfaces on page 95](#)

CHAPTER 3

Configuration Tasks

- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
- [Configuring PoE \(J-Web Procedure\) on page 38](#)

Configuring PoE on EX Series Switches (CLI Procedure)

Power over Ethernet (PoE) ports on EX Series switches supply electric power over the same ports that are used to connect network devices. These ports enable you to plug in devices that require both network connectivity and electric power, such as VoIP phones, wireless access points, and some IP cameras. This reduces the amount of wiring in a network, and also eliminates the need to position a powered device near an AC power outlet, making network design more flexible and efficient.

This topic describes:

- [PoE Configurable Options on page 32](#)
- [Configuring the PoE Controller on EX2200, EX3200, EX3300, EX4200, and EX4300 Switches on page 34](#)
- [Configuring the PoE Controllers on EX6200 and EX8200 Switches on page 36](#)
- [Configuring PoE Interfaces on page 37](#)

PoE Configurable Options

For EX Series switches that support PoE ports, the factory default configuration enables PoE on the PoE-capable ports, with default settings in effect. You might not have to do any additional configuration if the default settings work for you. [Table 16 on page 32](#) shows the configurable PoE options and their default settings for the PoE controller and for the PoE interfaces.



NOTE: On EX8200 switches, the factory default configuration enables PoE on all interfaces starting at Junos OS Release 11.2. Switches that have been upgraded to Release 11.2 from an earlier release might not have PoE enabled by default. To enable PoE on all PoE-capable ports on a switch, use the `set poe interface all` configuration command.

Table 16: Configurable PoE Options and Default Settings

Option	Default	Description
PoE Controller Options		
<code>guard-band</code>	0 W	Reserves a specified amount of power from the PoE power budget to be used in the case of a spike in PoE power consumption: <ul style="list-style-type: none"> Up to 15 W on EX6200 and EX8200 switches Up to 19 W on all other switches
<code>lldp-priority</code>	Not included in default configuration	When included in the configuration, assigns interfaces the power priority provided by the connected powered device by using Link Layer Discovery Protocol (LLDP) power negotiation rather than the power priority configured on the switch interface. Requires LLDP power negotiation to be enabled.

Table 16: Configurable PoE Options and Default Settings (*continued*)

Option	Default	Description
management	class	<p>Sets the PoE power management mode for the switch or line card. The power management mode determines how power to a PoE interface is allocated:</p> <ul style="list-style-type: none"> • class—In this mode, the power allocated to a PoE interface is determined in one of two ways: <ul style="list-style-type: none"> • If LLDP power negotiation is enabled, the PoE controller allocates PoE power by using LLDP power negotiation, which enables the PoE controller to dynamically allocate power to LLDP-enabled devices based on their power needs. LLDP power negotiation is enabled by default on supported switches when the management option is set to class. For information about configuring LLDP power negotiation, see <i>Configuring LLDP (CLI Procedure)</i>. • If LLDP power negotiation is disabled or not supported on the powered device or the switch, the maximum power delivered by an interface is determined by the class of the connected powered device. If there is no powered device connected, standard 15.4W power is allocated on the interface. • static—The maximum power delivered by an interface is statically configured and is independent of the class of the connected powered device. The maximum power is allocated to the interface even if a powered device is not connected.
maximum-power	<p>792 W for the EX8200-2XS-40P (40-port PoE+ with 4-port SFP and 2-port SFP+) line card</p> <p>915 W for the EX8200-48PL (48-port PoE+ 20 Gbps) line card</p> <p>1440 W for the EX6200-48P (48-port PoE+) line card</p>	<p>(EX6200 and EX8200 switches only) Sets the PoE power budget for the line card:</p> <ul style="list-style-type: none"> • 37 W through 792 W for the EX8200-2XS-40P line card • 37 W through 915 W for the EX8200-48PL line card • 37 W through 1440 W for the EX6200-48P line card
notification-control	Not included in default configuration	When included in the configuration, enables the PoE controller to send PoE SNMP traps.
Interface Options		
af-mode	Not included in default configuration	(EX6200 switches only) When included in the configuration, restricts a PoE interface to supporting IEEE 802.3af only. The maximum power that can be delivered by the PoE interface is 15.4 W.
disable (Power over Ethernet)	Not included in default configuration	When included in the configuration, disables PoE on the interface. The interface maintains network connectivity but no longer supplies power to a connected powered device. Power is not allocated to the interface.

Table 16: Configurable PoE Options and Default Settings (*continued*)

Option	Default	Description
maximum-power (Interface)	<p>30.0 W for interfaces that support PoE+ (IEEE 802.3at)</p> <p>15.4 W for interfaces that support PoE (IEEE 802.3af)</p>	<p>Sets the maximum power that can be delivered by a PoE interface when the power management mode is static:</p> <ul style="list-style-type: none"> Up to 30 W for EX2200, EX3300, EX4200, EX4300, EX6200, and EX8200 switches Up to 18.6 W for EX3200 switches <p>This setting is ignored if the power management mode is class.</p> <p>NOTE: The maximum-power setting permitted by the CLI might be greater than the maximum power a given PoE port can deliver. For example, the CLI permits you to set any port on an EX8200 line card to 30 W; however, only ports 0 through 11 support 30 W. Similarly, the CLI permits you to set any port on an EX4200 switch to 30 W, but some EX4200 models support only 18.6 W per port. If you configure a maximum-power value that is greater than the maximum power supported by a port, the power allocated to the port will be the maximum supported.</p>
priority (Power over Ethernet)	low	<p>Sets an interface's power priority to either low or high. If power is insufficient for all PoE interfaces, the PoE power to low-priority interfaces is shut down before power to high-priority interfaces is shut down. Among interfaces that have the same assigned priority, the power priority is determined by port number, with lower-numbered ports having higher priority.</p> <p>If LLDP power priority is enabled, the switch assigns each interface the power priority provided by the connected LLDP-enabled powered device rather than the interface's configured priority.</p> <p>On EX6200 and EX8200 switches, priority determines the interface's power priority relative to the other interfaces on the line card, not the interfaces on the switch as a whole. If power management cannot provide the line card with its full PoE power budget, PoE power to interfaces with low priority is shut down first.</p>
telemetry	Not included in default configuration	<p>When included in the configuration, enables the logging of power consumption records on an interface. Logging occurs every 5 minutes for 1 hour unless you specify a different value for interval (Power over Ethernet) or duration.</p>

Configuring the PoE Controller on EX2200, EX3200, EX3300, EX4200, and EX4300 Switches

To configure the PoE controller on EX2200, EX3200, EX3300, EX4200, and EX4300 switches:

- To change the management mode or to configure a guard band setting for a standalone switch or for all members of an EX3300 Virtual Chassis, an EX4200 Virtual Chassis, an EX4300 Virtual Chassis, or a mixed EX4200 and EX4500 Virtual Chassis that supports PoE:

```
[edit]
user@switch# set poe management mode guard-band watts
```


For example, to set the management mode to static and to configure a guard band of 15 W:

```
[edit]
user@switch# set poe management static guard-band 15
```



NOTE: If the PoE power budget for the switch is insufficient to provide maximum power to all the PoE ports, we recommend that you do not change the management mode from class to static. If you change the power management mode to static and do not change the other default settings, the PoE controller allocates maximum power to the PoE ports in the order of port number, which means PoE will be disabled on higher-numbered ports when the PoE power budget runs out.

In class mode, on the other hand, the PoE controller does not allocate power to a port until a powered device is connected. The class of the connected device determines the amount of power allocated. Thus in class mode, any PoE port can be used to power a device and all the PoE ports on the switch can be used as long as the combined power demand does not exceed the PoE power budget.



NOTE: On EX3200 and EX4200 switches that support enhanced PoE, you must change the management mode from class to static to take advantage of the higher per-port power limits of enhanced PoE.

- To enable PoE SNMP traps on a standalone switch or on a specific member of a Virtual Chassis:

```
[edit]
user@switch# set poe notification-control fpc number
```

For example, to enable PoE SNMP traps on a standalone switch or on member 0 of a Virtual Chassis:

```
[edit]
user@switch# set poe notification-control fpc 0
```

Configuring the PoE Controllers on EX6200 and EX8200 Switches

On EX6200 and EX8200 switches, each line card that supports PoE has its own PoE controller. This means that the PoE controller options are configured separately for each line card.

In addition, each line card has its own separate, configurable PoE power budget. The default power budget for a line card is the amount of power needed to supply all PoE ports on the line card with their maximum supported power. Because there might not be enough power available in a switch to supply each PoE line card with the default PoE power budget, you can configure smaller power budgets for one or more line cards, freeing power for other line cards.

To configure the line card PoE controllers in an EX6200 or EX8200 switch:

- To configure a guard band setting, to change the management mode, or to configure the PoE power budget for a specific line card:

```
[edit]
user@switch# set poe fpc number guard-band watts management mode
maximum-power watts
```

For example, to configure a PoE budget of 350 W and a guard band of 15 W on line card 1:

```
[edit]
user@switch# set poe fpc 1 guard-band 15 maximum-power 350
```



NOTE: If you configure a PoE power budget for a line card that is smaller than the default power budget, we recommend that you do not change the management mode from class to static. If you change the power management mode to static and do not change the interface default settings, the PoE controller allocates maximum power to the PoE ports in the order of port number. As a result, PoE will be disabled on higher-numbered ports when the PoE power budget runs out.

In class mode, on the other hand, the PoE controller does not allocate power to a port until a powered device is connected. The class of the connected device determines the amount of power allocated. Thus in class mode, any PoE port can be used to power a device and all the PoE ports on the switch can be used as long as the combined power demand does not exceed the PoE power budget.

- To configure the same guard band value, management mode, or PoE power budget for all line cards in a switch:

```
[edit]
user@switch# set poe fpc all guard-band watts management mode maximum-power
watts
```

For example, to configure a PoE budget of 1000 W and static management mode for all line cards in a switch:

```
[edit]
user@switch# set poe fpc all management static maximum-power 1000
```

If you configure different settings for a specific line card, those settings override the settings configured with the **fpc all** statement.

- To enable PoE SNMP traps on a line card:

```
[edit]
user@switch# set poe notification-control fpc number
```

For example, to enable PoE SNMP traps on line card 7:

```
[edit]
user@switch# set poe notification-control fpc 7
```

Configuring PoE Interfaces

To configure the PoE interfaces on a switch that supports PoE:

- To configure all PoE interfaces with the same setting or settings:

```
[edit]
user@switch# set poe interface all options
```

For example, to enable telemetry collection on all interfaces, using the default collection duration and interval:

```
[edit]
user@switch# set poe interface all telemetries
```



NOTE: For PoE to be enabled on all PoE-capable interfaces, the configuration must include the **interface all** statement in the **[edit poe]** hierarchy level. With the exception of EX8200 switches that were shipped from the factory with a Junos OS release earlier than Release 11.2, the factory default configurations of switches that support PoE include this statement.

- To configure individual PoE interfaces with different settings:

```
[edit]
user@switch# set poe interface interface-name options
```

For example:

```
[edit]
user@switch# set poe interface ge-0/0/0 priority high telemetries duration 24
```

```
[edit]
user@switch# set poe interface ge-0/0/1
```

```
[edit]
user@switch# set poe interface ge-0/0/5 maximum-power 18.6
```

```
[edit]
user@switch# set poe interface ge-5/0/7 disable
```

When you configure an individual interface, its configuration overrides any settings you configure with the **set poe interface all** command. For example, ge-0/0/1 in the preceding example retains the default settings, regardless of any settings configured with the **set poe interface all** command.

**Related
Documentation**

- [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
- [Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22](#)
- [Verifying PoE Configuration and Status \(CLI Procedure\) on page 71](#)
- [Understanding PoE on EX Series Switches on page 3](#)

Configuring PoE (J-Web Procedure)



NOTE: This topic applies only to the J-Web Application package.

Power over Ethernet (PoE) ports supply electric power over the same ports that are used to connect network devices to EX Series switches. These ports allow you to plug in devices that require both network connectivity and electric power, such as VoIP phones, wireless access points, and some IP cameras. Using the Power over Ethernet (PoE) Configuration page in the J-Web interface, you can modify the settings of all interfaces that are PoE-enabled.

This topic includes:

- [Configuring PoE on EX2200, EX2200-C, EX3200, EX3300, EX4200, and EX4300 Switches on page 38](#)
- [Configuring PoE on EX6200 Switches on page 39](#)

Configuring PoE on EX2200, EX2200-C, EX3200, EX3300, EX4200, and EX4300 Switches

To configure PoE:

1. Select **Configure > Power over Ethernet**.

The page displays a list of all PoE-capable interfaces except uplink ports. Specific operational details about an interface are displayed in the Details section of the page. The details include the PoE operational status and port class.



NOTE: If you are configuring a Virtual Chassis, the PoE configuring option is displayed if any member of the Virtual Chassis supports PoE, even if the Virtual Chassis master does not support PoE.



NOTE: After you make changes to the configuration on this page, you must commit the changes for them to take effect. To commit all changes to the active configuration, select **Commit Options > Commit**. See [Using the Commit Options to Commit Configuration Changes](#) for details about all commit options.

2. Click one of the following options:

- **Edit**—Changes PoE settings for the selected port as described in [Table 17 on page 39](#).
- **System Settings**—Modifies general PoE settings as described in [Table 18 on page 39](#).

Table 17: PoE Edit Settings

Field	Description	Your Action
Enable PoE	Specifies that PoE is enabled on the interface.	Select this option to enable PoE or PoE+ on the interface.
Priority	Lists the power priority (low or high) configured on the interface enabled for PoE.	Set the priority as High or Low .
Maximum Power	Specifies the maximum PoE wattage available to provision the active PoE interface on the switch.	Select a value in watts. If no value is specified, the default is 15.4 for PoE interfaces and 30.0 for PoE+ interfaces.

Table 18: System Settings

Field	Description	Your Action
PoE Management	Specifies the power management mode. The options are: static and class . NOTE: When the power management mode is set to class , the maximum power value is overridden by the maximum power value of the class of the powered device that is connected to the switch on the PoE port. When the power management mode is set to static , you can specify the maximum power for each PoE interface.	By default, the power management mode is class . Select static to change the power management mode.
Guard Band (watts)	Specifies the amount of power reserved for power spikes from the PoE power budget of the switch.	Enter a value to set the guard band value in watts. The default value is 0.

Configuring PoE on EX6200 Switches

To configure PoE:

1. Select **Configure > Power over Ethernet**.

The page displays a list of all PoE-capable interfaces for each FPC. Specific operational details about an interface are displayed in the Details section of the page. The details include the PoE operational status and port class.



NOTE: After you make changes to the configuration on this page, you must commit the changes for them to take effect. To commit all changes to the active configuration, select **Commit Options > Commit**. See [Using the Commit Options to Commit Configuration Changes](#) for details about all commit options.

2. Click one of the following options:

- **Edit**—Changes PoE settings for the selected port as described in [Table 19 on page 40](#).
- **FPC Settings**—Changes PoE settings of PoE-capable FPCs.

To configure FPC settings, click one of the following options:

- **Add**—Adds a PoE setting for an FPC as described in [Table 20 on page 40](#).
- **Edit**—Modifies a PoE setting for an FPC as described in [Table 20 on page 40](#).
- **Delete**—Deletes an existing PoE settings for an FPC.

Table 19: Edit PoE Settings

Field	Description	Your Action
Enable PoE	Specifies that PoE is enabled on the interface.	Select this option to enable PoE or PoE+ on the interface.
Type	Specifies whether the interface is PoE or PoE+.	Select an option from the list.
Priority	Lists the power priority (low or high) configured on the interface enabled for PoE.	Set the priority as High or Low .
Maximum Power	Specifies the maximum PoE wattage available to provision active PoE ports on the switch.	Select a value in watts. If no value is specified, the default is 15.4 for PoE interfaces and 30.0 for PoE+ interfaces.

Table 20: FPC PoE Settings

Field	Description	Your Action
FPC	Specifies the FPC number.	Select a value from the list.
PoE Management	<p>Specifies the power management mode. The options are static and class.</p> <p>NOTE: When the power management mode is set to class, the maximum power value is overridden by the maximum power value for the interface that is connected to the switch on the PoE port. When the power management mode is set to static, you can specify the maximum power for each PoE interface.</p>	By default, the power management mode is class . Select static to change the power management mode.
Guard Band (watts)	Specifies the amount of power reserved for power spikes from the PoE power budget of the switch.	Enter a value to set the guard band value in watts. The default value is 0.

Table 20: FPC PoE Settings (*continued*)

Field	Description	Your Action
Maximum Power	Specifies the maximum PoE wattage available to provision active PoE ports on the FPC. For example, if you specify 1000 W, the PoE controller is limited to a power budget of 1000 W to distribute to the PoE ports.	Select a value in watts.

**Related
Documentation**

- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
- [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
- [Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22](#)
- [Monitoring PoE on page 67](#)
- [Understanding PoE on EX Series Switches on page 3](#)

CHAPTER 4

Configuration Statements

- [\[edit poe\] Configuration Statement Hierarchy on EX Series Switches on page 43](#)
- [af-mode on page 45](#)
- [disable \(Power over Ethernet\) on page 46](#)
- [duration on page 47](#)
- [fpc \(Line Card\) on page 48](#)
- [fpc \(Notification Control\) on page 49](#)
- [guard-band on page 50](#)
- [interface \(Power over Ethernet\) on page 51](#)
- [interval \(Power over Ethernet\) on page 52](#)
- [management on page 53](#)
- [maximum-power \(Interface\) on page 54](#)
- [maximum-power \(Line Card\) on page 56](#)
- [notification-control on page 57](#)
- [poe on page 58](#)
- [priority \(Power over Ethernet\) on page 59](#)
- [telemetries on page 60](#)

[\[edit poe\] Configuration Statement Hierarchy on EX Series Switches](#)

This topic lists supported configuration statements in the **[edit poe]** hierarchy level on EX Series switches.

- *Supported* statements are those that you can use to configure some aspect of a software feature on the switch.
- Not all features are supported on all switch platforms. For detailed information about feature support on specific EX Series switch platforms, see [Feature Explorer](#).

This topic lists:

- [Supported Statements in the \[edit poe\] Hierarchy Level on page 44](#)

Supported Statements in the [edit poe] Hierarchy Level

The following hierarchy shows the **[edit poe]** configuration statements supported on EX Series switches except for EX6200 and EX8200 switches:

```
poe {  
  guard-band watts;  
  interface (all | interface-name) {  
    disable;  
    maximum-power watts;  
    priority (high | low);  
    telemetries {  
      disable;  
      duration hours;  
      interval minutes;  
    }  
  }  
  lldp-priority;  
  management (class | static);  
  notification-control {  
    fpc slot-number {  
      disable;  
    }  
  }  
}
```

The following hierarchy shows the **[edit poe]** configuration statements supported on EX Series switches for EX6200 and EX8200 switches:

```
poe {  
  fpc (all | slot-number) {  
    guard-band watts;  
    lldp-priority;  
    management (class | static);  
    maximum-power watts;  
  }  
  interface (all | interface-name) {  
    af-mode;  
    disable;  
    maximum-power watts;  
    priority (high | low);  
    telemetries {  
      disable;  
      duration hours;  
      interval minutes;  
    }  
  }  
  notification-control {  
    fpc slot-number {  
      disable;  
    }  
  }  
}
```

- Related Documentation**
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
 - [Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22](#)
 - [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
 - [Understanding PoE on EX Series Switches on page 3](#)

af-mode

Syntax	af-mode;
Hierarchy Level	[edit po e interface (Power over Ethernet) (all <i>interface-name</i>)]
Release Information	Statement introduced in Junos OS Release 11.3 for EX Series switches.
Description	Configure a PoE port on an EX6200 switch to support IEEE 802.3af only. The maximum power the port can deliver in either class or static mode is 15.4 W.
Default	PoE ports on an EX6200 switch support IEEE 802.3at (PoE+) by default.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> • Configuring PoE on EX Series Switches (CLI Procedure) on page 31

disable (Power over Ethernet)

Syntax	disable;
Hierarchy Level	[edit poe interface (all <i>interface-name</i>)], [edit poe interface (all <i>interface-name</i>) telemetries], [edit poe notification-control fpc slot-number]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX2000 Universal Access Routers.
Description	<p>Disable a PoE interface, disable the collection of power consumption data for a PoE interface, or disable the generation of the PoE SNMP traps. The action of the disable statement depends on which statement it is used with:</p> <ul style="list-style-type: none">• When used with interface—Disable the PoE capability of this interface. The interface operates as a standard network access interface, and power is no longer allocated to it from the PoE power budget. Although the PoE capability is disabled, the PoE configuration for the interface is retained. To re-enable the PoE capability of this interface, delete the disable statement from the interface entry in the configuration.• When used with telemetries—Disable the collection of PoE power consumption records for this interface. Any previously collected records are deleted. However, the telemetries configuration is retained, including the values for interval and duration. To re-enable record collection, delete the disable statement from the telemetries entry in the configuration.• When used with notification-control—Disable the generation of PoE SNMP traps. To re-enable PoE traps, delete the disable statement from the notification-control entry in the configuration.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none">• Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17• Configuring PoE on EX Series Switches (CLI Procedure) on page 31

duration

Syntax	<code>duration <i>hours</i>;</code>
Hierarchy Level	[edit poe interface (all <i>interface-name</i>) telemetries]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	Modify the duration over which data is collected when you are monitoring the power consumption of a PoE interface.
Options	<i>hours</i> —Number of hours over which the data is to be collected. Range: 1 through 24 Default: 1
Required Privilege Level	system —To view this statement in the configuration. system-control —To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none">• Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17• Configuring PoE on EX Series Switches (CLI Procedure) on page 31

fpc (Line Card)

Syntax	<pre>fpc (all <i>slot-number</i>) { <i>guard-band</i> watts; <i>management</i> (class static); <i>maximum-power</i> watts; }</pre>
Hierarchy Level	[edit poe]
Release Information	Statement introduced in Junos OS Release 11.2 for EX Series switches.
Description	Configure PoE options for an EX6200 or EX8200 line card.
Options	<p>all—All line cards that support PoE that have not been individually configured for PoE. If a line card has been individually configured for PoE, that configuration overrides any settings specified with all.</p> <p><i>slot-number</i>—The line card slot number.</p> <p>The remaining statements are explained separately.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none">• Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17• Configuring PoE on EX Series Switches (CLI Procedure) on page 31

fpc (Notification Control)

Syntax	<code>fpc slot-number { disable; }</code>
Hierarchy Level	[edit poe notification-control]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	Enable the specified PoE controller to generate PoE traps.
Default	PoE traps are disabled by default.
Options	<p>slot-number—Indicates the PoE controller by FPC slot number, where slot-number is:</p> <ul style="list-style-type: none"> • 0—On an EX2200, EX3200, standalone EX3300, standalone EX4200, or standalone EX4300 switch • Member ID—On an EX3300, EX4200, or EX4300 switch in a Virtual Chassis • Line card slot number—On an EX6200 or EX8200 switch <p>The remaining statement is explained separately.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Configuring PoE on EX Series Switches (CLI Procedure) on page 31

guard-band

Syntax	<code>guard-band <i>watts</i>;</code>
Hierarchy Level	[edit poe], [edit poe (all fpc <i>slot-number</i>)]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX2000 Universal Access Routers.
Description	Reserve a specified amount of power from the PoE power budget for the switch or the line card in case of a spike in PoE consumption.
Options	watts —Amount of power to be reserved in case of a spike in PoE consumption. Range: 0 through 15 for EX6200 and EX8200 switches and 0 through 19 for ACX2000 routers and all other switches. Default: 0
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none">• Configuring PoE on EX Series Switches (CLI Procedure) on page 31

interface (Power over Ethernet)

Syntax	<pre> interface (all <i>interface-name</i>) { af-mode; disable; maximum-power <i>watts</i>; priority (high low); telemetries { disable; duration <i>hours</i>; interval <i>minutes</i>; } } </pre>
Hierarchy Level	[edit poe]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	Specify a PoE interface to be configured.
Options	<p>all—All PoE interfaces on the switch that have not been individually configured for PoE. If a PoE interface has been individually configured, that configuration overrides any settings specified with all.</p> <p><i>interface-name</i>—Name of the specific interface being configured.</p> <p>If you use the interface statement without any substatements, default values are used for the remaining statements.</p> <p>The remaining statements are explained separately.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17 • Configuring PoE on EX Series Switches (CLI Procedure) on page 31

interval (Power over Ethernet)

Syntax	interval <i>minutes</i> ;
Hierarchy Level	[edit poe interface (all <i>interface-name</i>) telemetries]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	Modify the interval at which data is collected when you are monitoring the power consumption of a PoE interface.
Options	<i>minutes</i> —Frequency of data collection. Range: 1 through 30 Default: 5
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none">• Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17• Configuring PoE on EX Series Switches (CLI Procedure) on page 31• Configuring PoE (J-Web Procedure) on page 38

management

Syntax	management (class static high-power);
Hierarchy Level	[edit poe], [edit poe (all fpc slot-number)]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX2000 Universal Access Routers.
Description	Designate how the PoE controller allocates power to the PoE interfaces.
Default	class
Options	<ul style="list-style-type: none"> • class—The amount of power allocated to the interface is determined by the class of the connected powered device. If no powered device is connected, standard 15.4 W power is allocated to the interface. See “Understanding PoE on EX Series Switches” on page 3 for more information about classes of powered devices. • static—The amount of power allocated to the interface is determined by the value of the maximum-power statement, not the class of the connected powered device. This amount is allocated even when a powered device is not connected to the interface, ensuring that power is available when needed. • high-power—(ACX2000 routers only) ACX2000 PoE interfaces support power delivery of up to 65 W per port using all four pairs of Ethernet RJ45 cables. Traditional PoE ports use only two pairs of Ethernet cable for power delivery. According to the IEEE 802.3af standard, each port can deliver a maximum power of up to 32 W. With high-power mode of power delivery over all four pairs, the power sourcing equipment (PSE) has an option to deliver up to 65 W per port, provided the powered devices request this high power over all four pairs of the Ethernet cable. By default, high-power mode is not enabled and has to be explicitly enabled. When the PoE controller is configured for high-power mode, the PoE controller does not deliver power to normal powered devices that request power over two pairs.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> • Configuring PoE on EX Series Switches (CLI Procedure) on page 31 • Understanding PoE on EX Series Switches on page 3

maximum-power (Interface)

Syntax	<code>maximum-power watts;</code>
Hierarchy Level	[edit <code>poe interface</code> (all <i>interface-name</i>)]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX2000 routers.
Description	Set the maximum amount of power that the switch can supply to the PoE port.



NOTE: Although you can set this value when PoE power management is in class mode, it does not establish the maximum power for the port. Instead, the IEEE 802.3af (PoE) or IEEE 802.3at (PoE+) class of the connected device determines the maximum power for the port.

Options	watts —The maximum power in watts that can be supplied to the ports.. For EX2200, EX3300, EX4200, EX4300, EX6200, and EX8200 switches: Range: 0.0 through 30.0 Default: 15.4 W for ports that support IEEE 802.3af and 30 W for ports that support IEEE 802.3at For EX3200 switches: Range: 0.0 through 18.6 Default: 15.4 W For ACX2000 routers: Range: 1 through 65 W Default: 32 W
----------------	---



NOTE: The `maximum-power` setting permitted by the CLI might be greater than the maximum power a given PoE port can deliver. For example, the CLI permits you to set any PoE port on an EX8200 line card to 30 W; however, only ports 0 through 11 support 30 W. Similarly, the CLI permits you to set any PoE port on an EX4200 switch to 30 W, but some models of EX4200 switch support only 18.6 W per port. If you configure a `maximum-power` value that is greater than the maximum power supported by a port, the power allocated to the port will be the maximum supported.

If you use the `all` option to set `maximum-power` to a value greater than 15.4 W on all interfaces on an EX8200 line card, the maximum power allocated to all ports is 15.4 W.



NOTE: Support for a maximum of 18.6 W per port instead of 15.4 W per port on EX3200 switches and P and T models of EX4200 switch requires Junos OS Release 11.1 or later. In addition to requiring an upgrade of Junos OS to Release 11.1 or later, switches that are running an earlier release of Junos OS release require the PoE controller software be upgraded as described in [“Upgrading the PoE Controller Software” on page 63](#). If the controller software is not upgraded and you set maximum-power to a value greater than 15.4 W, the configuration is accepted when you commit it, but the actual power allocated to the port will be 15.4 W.




NOTE: On ACX2000 routers, the power sourcing equipment (PSE) delivers up to 65 W per port, provided the management mode is set to high-power mode, by using the high-power option at the [edit poe management] hierarchy level. By default, the management mode is set to static. In the static mode, the PSE can deliver power up to 32 W.

Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
---------------------------------	---

Related Documentation	<ul style="list-style-type: none"> • Configuring PoE on EX Series Switches (CLI Procedure) on page 31 • management on page 53
------------------------------	---

maximum-power (Line Card)

Syntax	maximum-power <i>watts</i> ;
Hierarchy Level	[edit <i>poe</i> fpc (all <i>slot-number</i>)]
Release Information	Statement introduced in Junos OS Release 11.2 for EX Series switches.
Description	Set the PoE power budget for an EX6200 or an EX8200 line card.
Options	<p>watts—The maximum number of watts that is supplied to the line card for its PoE power budget.</p> <p>For the EX6200-48P (48-port PoE+) line card: Range: 37 through 1440 Default: 1440</p> <p>For the EX8200-2XS-40P (40-port PoE+ with 4-port SFP and 2-port SFP+) line card: Range: 37 through 792 Default: 792</p> <p>For the EX8200-48PL (48-port PoE+ 20 Gbps) line card: Range: 37 through 915 Default: 915</p>
	<div> NOTE: If you configure a value for watts that is greater than the maximum value supported by the line card, the power budget for the line card is set to its supported maximum. If you configure a value for watts that is lower than 37 W, the power budget for the line card is set at 37 W. Because of a hardware constraint, at least 37 W of PoE power must always be allocated to the PoE line cards.</div>
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none">• Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22• Configuring PoE on EX Series Switches (CLI Procedure) on page 31

notification-control

Syntax	notification-control { fpc <i>slot-number</i> { disable; } }
Hierarchy Level	[edit poe]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	<p>Enable or disable the generation of PoE SNMP traps. If PoE SNMP traps are enabled, an SNMP trap is sent whenever a PoE interface is enabled or disabled.</p> <p>The remaining statements are explained separately.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17 • Configuring PoE on EX Series Switches (CLI Procedure) on page 31

poe

Syntax For switches other than EX6200 and EX8200 switches:

```
poe {  
  guard-band watts;  
  interface (all | interface-name) {  
    disable;  
    maximum-power watts;  
    priority (high | low);  
    telemetries {  
      disable;  
      duration hours;  
      interval minutes;  
    }  
  }  
  lldp-priority;  
  management (class | static);  
  notification-control {  
    fpc slot-number {  
      disable;  
    }  
  }  
}
```

For EX6200 and EX8200 switches:

```
poe {  
  fpc (all | slot-number) {  
    guard-band watts;  
    lldp-priority;  
    management (class | static);  
    maximum-power watts;  
  }  
  interface (all | interface-name) {  
    af-mode;  
    disable;  
    maximum-power watts;  
    priority (high | low);  
    telemetries {  
      disable;  
      duration hours;  
      interval minutes;  
    }  
  }  
  notification-control {  
    fpc slot-number {  
      disable;  
    }  
  }  
}
```

Hierarchy Level [\[edit\]](#)

Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	Configure PoE options. The remaining statements are explained separately.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> • Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17 • Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22 • Configuring PoE on EX Series Switches (CLI Procedure) on page 31

priority (Power over Ethernet)

Syntax	priority (low high);
Hierarchy Level	[edit poe interface (all <i>interface-name</i>)]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches.
Description	Set the power priority for individual interfaces when there is insufficient power for all PoE interfaces. If the switch needs to shut down powered devices because PoE demand exceeds the PoE budget, low-priority devices are shut down before high-priority devices. Among interfaces that have the same assigned priority, priority is determined by port number, with lower-numbered ports having higher priority.
Default	low
Options	<p>high—Specifies that this interface is to be treated as high-priority in terms of power allocation. If the switch needs to shut down powered devices because PoE demand exceeds the PoE budget, power is not shut down on this interface until it has been shut down on all the low-priority interfaces.</p> <p>low—Specifies that this interface is to be treated as low-priority in terms of power allocation. If the switch needs to shut down powered devices because PoE demand exceeds the PoE budget, power is shut down on this interface before it is shut down on high-priority interfaces.</p>
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> • Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17 • Configuring PoE on EX Series Switches (CLI Procedure) on page 31

telemetries

Syntax	<pre>telemetries { disable; duration <i>hours</i>; interval <i>minutes</i>; }</pre>
Hierarchy Level	[edit poe interface (all <i>interface-name</i>)]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX2000 Universal Access Routers.
Description	<p>Enable the logging of power consumption of a PoE interface over time.</p> <p>If you want to log the power consumption of a PoE interface, you must explicitly specify the telemetries statement. When you commit the configuration, logging begins, with data being collected at the specified intervals. Logging stops at the end of the specified duration. If you do not specify the duration and interval statements, data is collected at the default interval of five minute intervals every hour.</p> <p>The remaining statements are explained separately.</p>
Default	Logging of power consumption is disabled.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none">• Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17• Configuring PoE on EX Series Switches (CLI Procedure) on page 31• show poe telemetries on page 90

PART 3

Administration

- [Upgrading on page 63](#)
- [Routine Monitoring on page 67](#)
- [Operational Commands on page 77](#)

CHAPTER 5

Upgrading

- [Upgrading the PoE Controller Software on page 63](#)

Upgrading the PoE Controller Software

Each Junos OS image for an EX Series switch that supports PoE contains the most recent version of the PoE controller software at the time the Junos OS image was built. When you upgrade Junos OS on your switch, the new image might contain a more recent version of the PoE controller software than is currently running on the PoE controller. You can upgrade your PoE controller software by requesting that the more recent version of the software contained in the Junos OS image be downloaded to the controller.



NOTE: Powered devices are not guaranteed to receive power while the new software is being downloaded to the PoE controller, a process that can take up to 10 minutes. In addition, during the software download, some PoE operational commands, such as [show poe interface](#), might not show correct output. We recommend that you upgrade your PoE controller software during a regularly scheduled maintenance window.



NOTE: On an EX8200 Virtual Chassis, you cannot execute PoE commands on the XRE200 External Routing Engine. You can execute PoE commands only on the member EX8200 switches. Use the `request session member member-id` command to open a CLI session on a member switch.

This topic covers:

- [Determining Whether the PoE Controller Software Needs Upgrading on page 64](#)
- [Upgrading the PoE Controller Software on page 64](#)
- [Monitoring the Upgrade Progress on page 65](#)

Determining Whether the PoE Controller Software Needs Upgrading

To determine whether the version of the PoE controller software supplied with Junos OS is more recent than the version of the software currently running on the PoE controller, enter the following command:

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index power consumption band
0** 130.00W 0.00W 0W Class AF_MODE Disabled
**New PoE software upgrade available.
Use 'request system firmware upgrade poe fpc-slot <slot>'
This procedure will take around 10 minutes (recommended to be performed during
maintenance)
```

The **New PoE software upgrade available** text in the output indicates that the PoE controller software is out-of-date and needs to be upgraded.

For Virtual Chassis or switches with PoE line cards, the output of the **show poe controller** command indicates which members of a Virtual Chassis or which PoE line cards have out-of-date PoE controller software:

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index power consumption band
2 130.00W 120.34W 0W Class AF_ENHANCE Disabled
4** 410.00W 182.80W 0W Class AF_MODE Disabled
**New PoE software upgrade available.
Use 'request system firmware upgrade poe fpc-slot slot'
This procedure will take around 10 minutes (recommended to be performed during
maintenance)
```

In the preceding example, member 4 of the Virtual Chassis has an out-of-date PoE controller software.



NOTE: We recommend that all member switches of a Virtual Chassis or all line cards in a switch run the same version of the PoE controller software.

Upgrading the PoE Controller Software

To upgrade the PoE controller software for a standalone switch with built-in PoE interfaces, enter:

```
user@switch> request system firmware upgrade poe fpc-slot 0
Firmware upgrade initiated. Poe Upgrade takes about 10 minutes
Use 'show poe controller' to get the download status
```

To upgrade the PoE controller software on a specific Virtual Chassis member or line card on a switch, enter:

```
user@switch> request system firmware upgrade poe fpc-slot 8
Firmware upgrade initiated. Poe Upgrade takes about 10 minutes
Use 'show poe controller' to get the download status
```

To upgrade the PoE controller software on all members of a Virtual Chassis or all line cards on a switch, enter:

```
user@switch> request system firmware upgrade poe fpc-slot all-members
Firmware upgrade initiated. Poe Upgrade takes about 10 minutes
Use 'show poe controller' to get the download status
```

Monitoring the Upgrade Progress

Use the **show poe controller** command to monitor the progress of the controller software upgrade:

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index power consumption band
0** 130.00W 0.00W 0W SW_DOWNLOAD(14%) Disabled
```

**New PoE software upgrade available.
Use 'request system firmware upgrade poe fpc-slot <slot>'
This procedure will take around 10 minutes (recommended to be performed during maintenance)

The **Status** field is updated during the download process to show the following stages of the download:

- DOWNLOAD_INIT
- SW_DOWNLOAD (n%)

When the software upgrade is complete, the **New PoE software upgrade available** text is no longer displayed for the particular FPC.



NOTE: If you are upgrading the PoE controller software to enable enhanced PoE, the Status field for the controller shows AF_ENHANCE after the upgrade completes, indicating that the controller now supports enhanced PoE. The default maximum power per port is not automatically increased as a result of the upgrade—it is still 15.4 W per port. You must explicitly set the maximum power for a port to 18.6 W. Enhanced PoE is supported in Junos OS Release 11.1 or later on EX3200 switches and on EX4200-P or EX4200-T model switches.

Related Documentation

- [Verifying PoE Configuration and Status \(CLI Procedure\) on page 71](#)
- [Understanding PoE on EX Series Switches on page 3](#)

CHAPTER 6

Routine Monitoring

- [Monitoring PoE on page 67](#)
- [Monitoring PoE Power Consumption \(CLI Procedure\) on page 68](#)
- [Verifying PoE Configuration and Status \(CLI Procedure\) on page 71](#)

Monitoring PoE

Purpose



NOTE: This topic applies only to the J-Web Application package.

Use the monitoring functionality to view real-time data of the power consumed by each PoE interface, and to enable and configure telemetry values. When telemetry is enabled, the software measures the power consumed by each interface and stores the data for future reference.



NOTE: If you are configuring a Virtual Chassis, the PoE monitoring option is displayed if any member of the Virtual Chassis supports PoE, even if the Virtual Chassis master does not support PoE.

Action

To monitor PoE using the J-Web interface, select **Monitor > Power over Ethernet**.

To monitor PoE power consumption with CLI commands in the CLI Terminal in the J-Web interface:

1. Select **Troubleshoot > CLI Terminal**.
2. Type a CLI command:
 - `show poe controller`
 - `show poe interface`
 - `show poe telemetries`

For detailed information about using these CLI commands to monitor PoE power consumption, see [Monitoring PoE Power Consumption \(CLI Procedure\)](#) in the EX Series documentation at <http://www.juniper.net/techpubs>.

Meaning In the J-Web interface the PoE Monitoring screen is divided into two parts. The top half of the screen displays real-time data of the power consumed by each PoE-capable interface and a list of ports that utilize maximum power.

Select a particular interface to view a graph of the power consumed by the selected interface.

The bottom half of the screen displays telemetry information for interfaces. The Telemetry Status field displays whether telemetry has been enabled on the interface. Click the **Show Graph** button to view a graph of the telemetries. The graph can be based on power or voltage. To modify telemetry values, click **Edit**. Specify Interval in minutes, Duration in hours, and select **Log Telemetries** to enable telemetry on the selected interface.

- Related Documentation**
- [Configuring PoE on EX Series Switches \(CLI Procedure\)](#) on page 31
 - [Configuring PoE \(J-Web Procedure\)](#) on page 38
 - [Example: Configuring PoE Interfaces on an EX Series Switch](#) on page 15
 - [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch](#) on page 17
 - [Monitoring PoE Power Consumption \(CLI Procedure\)](#) on page 68
 - [Verifying PoE Configuration and Status \(CLI Procedure\)](#) on page 71

Monitoring PoE Power Consumption (CLI Procedure)

You can monitor Power over Ethernet (PoE) power consumption, both for the switch as a whole and for individual PoE interfaces.

This topic describes how to monitor:

- [PoE Power Consumption on a Switch](#) on page 68
- [Current Power Consumption for PoE Interfaces](#) on page 69
- [Power Consumption for PoE Interfaces over Time](#) on page 70

PoE Power Consumption on a Switch

Purpose Determine the current PoE power consumption on a switch.

Action Enter the following command:

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index      power  consumption band   Class      AT_MODE  Priority
0          405.00W 130.00W 0W     Class      AT_MODE  Disabled
```

Meaning At the time the command was executed, the PoE interfaces on the switch were consuming 130 W out of the PoE power budget of 405 W.

Current Power Consumption for PoE Interfaces

Purpose Determine the current power consumption for individual PoE interfaces.

Action To monitor the power consumption of all PoE interfaces on the switch, use the following command:

```
user@switch> show poe interface
```

Interface	Admin status	Oper status	Max power	Priority	Power consumption	Class
ge-0/0/0	Enabled	ON	15.4W	Low	7.4W	0
ge-0/0/1	Enabled	ON	15.4W	High	12.0W	0
ge-0/0/2	Enabled	ON	15.4W	Low	12.4W	0
ge-0/0/3	Enabled	ON	7.0W	Low	5.3W	2
ge-0/0/4	Enabled	ON	4.0W	Low	4.0W	1
ge-0/0/5	Enabled	ON	7.0W	Low	6.1W	2
ge-0/0/6	Enabled	ON	15.4W	Low	12.3W	3
ge-0/0/7	Disabled	Disabled	0.0W	Low	0.0W	not-applicable

To monitor the power consumption of the PoE interfaces on a specific EX6200 or EX8200 line card, use the following command:

```
user@switch> show poe interface fpc-slot 3
```

Interface	Admin status	Oper status	Max power	Priority	Power consumption	Class
ge-3/0/0	Enabled	ON	30.0W	Low	20.3W	4
ge-3/0/1	Enabled	ON	30.0W	Low	17.8W	4
ge-3/0/2	Enabled	ON	30.0W	High	16.3W	4
ge-3/0/3	Enabled	ON	30.0W	High	16.2W	4
ge-3/0/4	Enabled	ON	30.0W	Low	25.9W	4
ge-3/0/5	Enabled	ON	30.0W	Low	10.1W	4
ge-3/0/6	Enabled	ON	30.0W	Low	16.2W	4
ge-3/0/7	Enabled	ON	30.0W	Low	6.4W	4
ge-3/0/8	Enabled	ON	30.0W	Low	5.2W	4
ge-3/0/9	Enabled	ON	30.0W	Low	5.2W	4
ge-3/0/10	Enabled	ON	30.0W	Low	21.5W	4
ge-3/0/11	Enabled	ON	30.0W	Low	21.7W	4
ge-3/0/12	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/13	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/14	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/15	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/16	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/17	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/18	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/19	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/20	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/21	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/22	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/23	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/24	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/25	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/26	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/27	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/28	Enabled	ON	15.4W	Low	7.0W	0
ge-3/0/29	Enabled	ON	15.4W	Low	2.2W	1

ge-3/0/30	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/31	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/32	Enabled	ON	15.4W	Low	2.0W	1
ge-3/0/33	Enabled	ON	15.4W	Low	2.0W	1
ge-3/0/34	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/35	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/36	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/37	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/38	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/39	Enabled	ON	15.4W	Low	2.2W	1

To monitor the power consumption of an individual PoE interface (for example, ge-0/0/3), use the following command:

```
user@switch> show poe interface ge-0/0/3
PoE interface status:
PoE interface           : ge-0/0/3
Administrative status   : Enabled
Operational status      : ON
Power limit on the interface : 7.0W
Priority                 : Low
Power consumed          : 5.3W
Class of power device    : 2
PoE Mode                : 802.3at
```

Meaning At the time the command was executed, the individual PoE ports were consuming the amount of power shown. For example, interface ge-0/0/3 was consuming 5.3 W at the time the command was executed.

Power Consumption for PoE Interfaces over Time

Purpose Monitor the power consumption of a PoE interface over a period of time. The records collected remain available for future viewing.

You can specify the intervals at which power consumption data is collected, from once every minute to once every 30 minutes. The default is once every 5 minutes. You can also specify the duration over which the records are collected, from 1 hour (default) to 24 hours.

Action To collect historical records of PoE interface power consumption and display those records:

1. Add the **telemetries** statement to the PoE interface configuration:

```
[edit]
user@switch# set poe interface ge-0/0/5 telemetries interval 10
When you commit the configuration, record collection begins.
```

2. Display the collected records:

```
user@switch> show poe telemetries interface ge-0/0/5 count all
SI No    Timestamp                Power    Voltage
1       03-19-2010 13:00:07 UTC   3.9W    50.9V
2       03-19-2010 12:50:07 UTC   3.9W    50.9V
3       03-19-2010 12:40:07 UTC   3.9W    50.9V
4       03-19-2010 12:30:07 UTC   3.9W    50.9V
5       03-19-2010 12:20:07 UTC   3.9W    50.9V
6       03-19-2010 12:10:07 UTC   3.9W    50.9V
```

To start another session of record collection on the interface, you must delete the existing telemetries configuration on the interface and then reconfigure telemetries. Deleting the telemetries configuration also clears the power consumption history data.

To clear the history of PoE power consumption without deleting the telemetries configuration, use the command `clear poe telemetries interface`.

Meaning Over the hour in which the PoE power consumption data on ge-0/0/5 was collected, the connected powered device consistently consumed 3.9 W.

- Related Documentation**
- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
 - [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
 - [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
 - [Example: Configuring PoE on an EX6200 or EX8200 Switch on page 22](#)
 - [Verifying PoE Configuration and Status \(CLI Procedure\) on page 71](#)

Verifying PoE Configuration and Status (CLI Procedure)

You can verify the Power over Ethernet (PoE) configuration and status on an EX Series switch.

This topic describes how to verify:

- [PoE Controller Configuration and Status on page 71](#)
- [PoE Interface Configuration and Status on page 72](#)
- [PoE SNMP Trap Generation Status on page 73](#)
- [PoE Line Card Configuration and Status on page 74](#)

PoE Controller Configuration and Status

Purpose Verify the PoE controller configuration and status, such as the PoE power budget, total PoE power consumption, power management mode, and the supported PoE standard.

Action Enter the following command:

```
user@switch> show poe controller
```

Example output for an EX2200 switch:

Controller index	Maximum power	Power consumption	Guard band	Management Class	Status	Lldp Priority
0	405.00W	130.00W	19W	Class	AT_MODE	Disabled

Example output for an EX8200 switch:

Controller index	Maximum power	Power consumption	Guard band	Management Class	Status	Lldp Priority
3	540.00W	435.25W	0W	Static	AT/AF COMBO	Disabled
4	915.00W	627.01W	15W	Class	AT/AF COMBO	Disabled

- Meaning**
- For the EX2200 switch—The switch has a PoE power budget of 405 W, of which 130 W were being used by the PoE ports at the time the command was executed. The **Guard band** field shows that 19 W is reserved out of the PoE power budget to protect against spikes in power demand. The power management mode is class. The PoE ports on the switch support PoE+ (IEEE 802.3at).
 - For the EX8200 switch—Line card 3 has a PoE power budget of 540 W, of which 435.25 W were being used by the PoE ports on the line card at the time the command was executed. The management mode for line card 3 is static and the line card has a mix of PoE (IEEE 802.3af) and PoE+ (IEEE 802.3at) ports.

Line card 4 has a PoE power budget of 915 W, of which 627.01 W were being used by the PoE ports on the line card at the time the command was executed. The **Guard band** field shows that 15 W is reserved out of the PoE power budget to protect against spikes in power demand. The management mode for line card 4 is class and the line card has a mix of PoE (IEEE 802.3af) and PoE+ (IEEE 802.3at) ports.

PoE Interface Configuration and Status

- Purpose** Verify that PoE interfaces are enabled and set to the correct maximum power and priority settings. Also verify current operational status and power consumption.

- Action** To view configuration and status for all PoE interfaces, enter:

```
user@switch> show poe interface
```

Interface	Admin status	Oper status	Max power	Priority	Power consumption	Class
ge-0/0/0	Enabled	ON	15.4W	Low	7.9W	3
ge-0/0/1	Enabled	ON	30.0W	High	4.8W	0
ge-0/0/2	Enabled	ON	30.0W	High	4.8W	0
ge-0/0/3	Enabled	ON	7.0W	High	3.3W	2
ge-0/0/4	Enabled	ON	7.0W	Low	3.3W	2
ge-0/0/5	Enabled	ON	7.0W	Low	3.2W	2
ge-0/0/6	Enabled	ON	7.0W	Low	3.3W	2
ge-0/0/7	Enabled	OFF	30.0W	Low	0.0W	not-applicable

To view the configuration and status for the PoE interfaces on an EX6200 or EX8200 line card:

```
user@switch> show poe interface fpc-slot 3
```

Interface	Admin status	Oper status	Max power	Priority	Power consumption	Class
ge-3/0/0	Enabled	ON	30.0W	Low	20.3W	4
ge-3/0/1	Enabled	ON	30.0W	Low	17.8W	4
ge-3/0/2	Enabled	ON	30.0W	High	16.3W	4
ge-3/0/3	Enabled	ON	30.0W	High	16.2W	4
ge-3/0/4	Enabled	ON	30.0W	Low	25.9W	4
ge-3/0/5	Enabled	ON	30.0W	Low	10.1W	4
ge-3/0/6	Enabled	ON	30.0W	Low	16.2W	4
ge-3/0/7	Enabled	ON	30.0W	Low	6.4W	4
ge-3/0/8	Enabled	ON	30.0W	Low	5.2W	4
ge-3/0/9	Enabled	ON	30.0W	Low	5.2W	4
ge-3/0/10	Enabled	ON	30.0W	Low	21.5W	4
ge-3/0/11	Enabled	ON	30.0W	Low	21.7W	4
ge-3/0/12	Enabled	ON	15.4W	Low	9.4W	0

ge-3/0/13	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/14	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/15	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/16	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/17	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/18	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/19	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/20	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/21	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/22	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/23	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/24	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/25	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/26	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/27	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/28	Enabled	ON	15.4W	Low	7.0W	0
ge-3/0/29	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/30	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/31	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/32	Enabled	ON	15.4W	Low	2.0W	1
ge-3/0/33	Enabled	ON	15.4W	Low	2.0W	1
ge-3/0/34	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/35	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/36	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/37	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/38	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/39	Enabled	ON	15.4W	Low	2.2W	1

To view configuration and status for a single PoE interface, enter:

```
user@switch> show poe interface ge-0/0/3
PoE interface status:
PoE interface           : ge-0/0/3
Administrative status   : Enabled
Operational status      : ON
Power limit on the interface : 7.0W
Priority                 : High
Power consumed          : 3.3W
Class of power device   : 2
PoE Mode                : 802.3at
```

Meaning The command output shows the status and configuration of interfaces. For example, the interface ge-0/0/3 is administratively enabled. Its operational status is **ON**; that is, the interface is currently delivering power to a connected powered device. The maximum power allocated to the interface is 7.0 W. The interface has a high power priority. At the time the command was executed, the powered device was consuming 3.3 W. The IEEE 802.3af class of the powered device is class 2. If the PoE power management mode is class, the class of the powered device determines the maximum power allocated to the interface, which is 7 W in the case of class 2 devices.

The PoE Mode field indicates that the interface supports IEEE 802.3at.

PoE SNMP Trap Generation Status

Purpose Verify the status of the [notification-control](#) option, which determines whether or not PoE SNMP traps are enabled.

Action Enter the following command:

```
user@switch> show poe notification-control
FPC slot      Notification-control-status
0              OFF
```

Meaning PoE SNMP traps are not enabled.

PoE Line Card Configuration and Status

Purpose Verify the PoE configuration and status for line cards on an EX6200 or EX8200 switch, such as the PoE power allocation and priority for each line card.

Action Enter the following command:

```
user@switch> show chassis power-budget-statistics
```

Example output for an EX6200 switch:

```
PSU 0      (EX6200-PWR-AC2500)      : 2500 W Online
PSU 1      (EX6200-PWR-AC2500)      : 2500 W Online
PSU 2      (EX6200-PWR-AC2500)      : 2500 W Online
PSU 3      (EX6200-PWR-AC2500)      : 2500 W Online
Total Power supplied by all Online PSUs : 10000 W
Power Redundancy Configuration       : N+1
Power Reserved for the Chassis       : 500 W

Fan Tray Statistics      Base power  Power Used
FTC 0                   : 300 W      43.04 W
FPC Statistics          Base power  Power Used  PoE power  Priority

FPC 1  (EX6200-48P)      : 220 W      49.47 W      1440 W      1
FPC 2  (EX6200-48P)      : 220 W      47.20 W       800 W      2
FPC 3  (EX6200-48P)      : 220 W     1493.57 W     1440 W      0
FPC 4  (EX6200-SRE64-4XS) : 100 W      51.38 W        0 W      0
FPC 5  (EX6200-SRE64-4XS) : 100 W      50.28 W        0 W      0
FPC 6  (EX6200-48P)      : 220 W      49.38 W       800 W      6
FPC 8  (EX6200-48P)      : 220 W      61.41 W     1440 W      9
FPC 9  (EX6200-48T)      : 150 W      12.49 W        0 W      9

Total (non-PoE) Power allocated      : 1750 W
Total Power allocated for PoE        : 5920 W
Power Available (Redundant case)     : 5750 W
Total Power Available                 : 2515 W
```

Example output for an EX8200 switch:

```
PSU 0      (EX8200-AC2K)      : 2000 W Online
PSU 1      (EX8200-AC2K)      : 2000 W Online
PSU 2      (EX8200-AC2K)      : 2000 W Online
PSU 3      (EX8200-AC2K)      : 2000 W online
PSU 4      (EX8200-AC2K)      : 2000 W Online
Total Power supplied by all Online PSUs : 10000 W
Power Redundancy Configuration       : N+1
Power Reserved for the Chassis       : 2400 W
FPC Statistics          Base power  PoE power  Priority

FPC 1  (EX8200-48T)      : 350 W        0 W      15
FPC 5  (EX8200-2XS-40P)  : 387 W       792 W      0
FPC 9  (EX8200-48PL)     : 267 W       915 W     15
FPC 10 (EX8200-2XS-40T)  : 350 W        0 W      1
FPC 12 (EX8200-48T)      : 350 W        0 W     15
```


Total (non-PoE) Power allocated	:	4104 W
Total Power allocated for PoE	:	1707 W
Power Available (Redundant case)	:	3896 W
Total Power Available	:	4263 W

- Meaning**
- For the EX6200 switch—The total of the PoE power budgets allocated to the line cards in the switch is 5920 W. This figure includes the 37 W of PoE power always included in the base allocation for each line card that supports PoE. For line cards with PoE ports, the **PoE power** field shows the PoE power budget allocated to each line card, along with the line card priority.
 - For the EX8200 switch—The total of the PoE power budgets allocated to the line cards in the switch is 1707 W. This figure includes the 37 W of PoE power always included in the base allocation for each line card that supports PoE. For line cards with PoE ports, the **PoE power** field shows the PoE power budget allocated to each line card, along with the line card priority.

- Related Documentation**
- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)
 - [Example: Configuring PoE Interfaces on an EX Series Switch on page 15](#)
 - [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
 - [Monitoring PoE Power Consumption \(CLI Procedure\) on page 68](#)

CHAPTER 7

Operational Commands

- `clear poe telemetries interface`
- `request system firmware upgrade poe`
- `show poe controller`
- `show poe interface`
- `show poe notification-control`
- `show poe telemetries`

clear poe telemetries interface

Syntax	clear poe telemetries interface <i><interface-name></i>
Release Information	Command introduced in Junos OS Release 12.1 for EX Series switches.
Description	Clear the history of PoE power consumption on the specified interface or on all interfaces. Interfaces that were collecting data will continue to collect.
Options	none —Clear power consumption records for all PoE interfaces. <i>interface-name</i> —(Optional) Clear power consumption records for the specified PoE interface.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show poe telemetries on page 90• show poe interface on page 84• show poe controller on page 81• Monitoring PoE Power Consumption (CLI Procedure) on page 68• Troubleshooting PoE Interfaces on page 95
List of Sample Output	clear poe telemetries interface on page 78 clear poe telemetries interface on page 78

Sample Output

This command has no output.



clear poe telemetries interface

```
user@switch> clear poe telemetries interface
```

clear poe telemetries interface

```
user@switch> clear poe telemetries interface ge-0/0/1
```

request system firmware upgrade poe

Syntax	request system firmware upgrade poe fpc-slot (<i>number</i> all-members)
Release Information	Command introduced in Junos OS Release 12.1 for EX Series switches.
Description	<p>Upgrade the PoE controller software on switches and line cards.</p> <p>The Junos OS image running on the switch contains a copy of the PoE controller software. This command compares the Junos OS version with the version of the software running on the PoE controller. If the Junos OS version is a more recent version, the command downloads the more recent version to the controller.</p> <p>For all Virtual Chassis except EX8200 Virtual Chassis, execute this command on the master. The master itself need not support PoE for this command to work—for example, you can execute this command on the master of a mixed EX4200 and EX4500 Virtual Chassis when the master is an EX4500 switch, which does not support PoE. On an EX8200 Virtual Chassis, you must execute this command on the member switch, not the master XRE200 External Routing Engine.</p> <p>We recommend that all members of a Virtual Chassis run the same version of the PoE controller software.</p> <p>Upgrading the controller software can take up to 10 minutes. Use the show poe controller command to monitor the progress of the software download.</p> <p>You cannot downgrade the PoE controller software.</p> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <p> NOTE: When you enter the <code>request system firmware upgrade poe</code> command, a message advises you that the controller software upgrade has started and that it will take about 10 minutes to complete. This message appears even if the FPC you have specified does not have a PoE controller or if the PoE controller software is up-to-date. To determine whether or not the controller software upgrade has actually started, use the <code>show poe controller</code> command.</p> </div> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <p> NOTE: While the upgrade is in progress, power to the powered devices is not guaranteed. We recommend that you upgrade the controller software during a regularly scheduled maintenance window.</p> </div>
Options	fpc-slot (<i>number</i> all-members)—Upgrade the PoE controller firmware for the Virtual Chassis member or line card specified by <i>number</i> , or for all Virtual Chassis members and line cards, specified by all-members .
Required Privilege Level	maintenance

- Related Documentation**
- [show poe controller on page 81](#)
 - [Upgrading the PoE Controller Software on page 63](#)

List of Sample Output [request system firmware upgrade poe \(Specific FPC Slot\) on page 80](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

[request system firmware upgrade poe \(Specific FPC Slot\)](#)

```
user@switch> request system firmware upgrade poe fpc-slot 8
Firmware upgrade initiated. Poe Upgrade takes about 10 minutes
Use 'show poe controller' to get the download status
```

show poe controller

Syntax	<code>show poe controller</code>
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 12.2 for ACX2000 routers.
Description	Display configuration and status of the PoE controllers.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show poe interface on page 84 • request system firmware upgrade poe on page 79 • Verifying PoE Configuration and Status (CLI Procedure) on page 71 • Monitoring PoE Power Consumption (CLI Procedure) on page 68 • Upgrading the PoE Controller Software on page 63
List of Sample Output	show poe controller (EX3200 Switch) on page 82 show poe controller (EX8200 Switch) on page 82 show poe controller (Controller Software Upgrade in Progress) on page 82 show poe controller (ACX2000 Router) on page 83
Output Fields	Table 21 on page 81 lists the output fields for the <code>show poe controller</code> command. Output fields are listed in the approximate order in which they appear.

Table 21: show poe controller Output Fields

Field Name	Field Description
Controller index	PoE controller number: <ul style="list-style-type: none"> • 0 for EX2200, EX3200, standalone EX3300, standalone EX4200 switches, standalone EX4300 switches, and ACX2000 routers. • Member ID for switches in an EX3300 Virtual Chassis, EX4200 Virtual Chassis, EX4300 Virtual Chassis, a mixed EX4200 and EX4500 Virtual Chassis. • Slot number for line cards with a PoE controller in an EX6200 or EX8200 switch.
Maximum power	The PoE power budget for the switch or line card. The PoE controller allocates power to the PoE ports from this budget.
Power consumption	Total amount of power being used by the PoE ports at the time the command is executed.
Guard Band	Amount of power that has been placed in reserve for power demand spikes and that cannot be allocated to a PoE interface.

Table 21: show poe controller Output Fields (*continued*)

Field Name	Field Description
Management	Power management mode: class or static or high-power . NOTE: The mode high-power is available on only ACX2000 routers.
Status	Status of the PoE controller: <ul style="list-style-type: none"> • AF_ENHANCE—Controller supports enhanced PoE. The maximum power per PoE port is 18.6 W in static mode (15.4 W in class mode). • DEVICE FAIL—Software download to the controller has failed or the PoE controller is not initialized because of a hardware failure. • DOWNLOAD_INIT—Software download to the controller is in the initial phase. • AF_MODE—Controller supports standard IEEE 802.3af. The maximum power per PoE port is 15.4 W. • AT/AF COMBO—Controller supports a mix of standard IEEE 802.3af and IEEE 802.3at (PoE+) ports. The maximum power per port is 30 W for IEEE 802.3at (PoE+) ports and 15.4 W for the IEEE 802.3af ports. • AT_MODE—Controller supports IEEE 802.3at (PoE+). The maximum power per PoE port is 30 W. • SW_DOWNLOAD (n%)—Software download to the controller is in progress.
Lldp Priority	Link Layer Discovery Protocol (LLDP) priority operating state. The state can be Enabled or Disabled . LLDP priority enables the PoE controller to assign interfaces the power priority provided by the connected powered device by using LLDP power negotiation rather than the power priority configured on the switch interface.

Sample Output

show poe controller (EX3200 Switch)

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index      power  consumption band    Priority
0          130.00W  81.20W    10W    Static    AF_ENHANCE Disabled
```

show poe controller (EX8200 Switch)

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index      power  consumption band    Priority
0          792.00W  603.50W    0W     Class    AT/AF COMBO Disabled
4          915.00W  781.00W    0W     Class    AT/AF COMBO Disabled
7          915.00W   0.00W     0W     Class    AT/AF COMBO Disabled
```

show poe controller (Controller Software Upgrade in Progress)

```
user@switch> show poe controller
Controller Maximum Power Guard Management Status Lldp
index      power  consumption band    Priority
0          130.00W   0.00W     0W     Static    AF_ENHANCE Disabled
```



```
8**      130.00W  0.00W      0W    Static    SW_DOWNLOAD(10%) Disabled
```

```
**New PoE software upgrade available.
```

```
Use 'request system firmware upgrade poe fpc-slot <slot>'
```

```
This procedure will take around 10 minutes (recommended to be performed during  
maintenance)
```

show poe controller (ACX2000 Router)

```
user@host> show poe controller
```

Controller index	Maximum power	Power consumption	Guard band	Management	Status	Lldp Priority
0	130.0 W	14.2 W	0 W	high-power	UP	

show poe interface

Syntax	show poe interface <fpc-slot number> <interface-name>
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 12.2 for ACX2000 routers.
Description	Display the status of PoE interfaces.
Options	<p>none—Display status of all PoE interfaces on the switch or router.</p> <p>fpc-slot number—(Optional) (EX6200 or EX8200 switches only) Display the status of the PoE interfaces on the specified line card.</p> <p>interface-name—(Optional) Display the status of a specific PoE interface on the switch.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show poe controller on page 81 • Verifying PoE Configuration and Status (CLI Procedure) on page 71 • Monitoring PoE Power Consumption (CLI Procedure) on page 68 • Troubleshooting PoE Interfaces on page 95
List of Sample Output	show poe interface on page 85 show poe interface (with LLDP Negotiation) on page 85 show poe interface (Specific Interface) on page 86 show poe interface (Specific FPC Slot) on page 86 show poe interface (Specific Interface on ACX2000 Universal Access Routers) on page 87
Output Fields	Table 22 on page 84 lists the output fields for the show poe interface command. Output fields are listed in the approximate order in which they appear.

Table 22: show poe interface Output Fields

Field Name (All Interfaces Output)	Field Name (Single Interface Output)	Field Description
Interface	PoE Interface	Interface name.
Admin status	Administrative status	Administrative state of the PoE interface: Enabled or Disabled . If the PoE interface is disabled, it can provide network connectivity, but it cannot provide power to connected devices.

Table 22: show poe interface Output Fields (*continued*)

Field Name (All Interfaces Output)	Field Name (Single Interface Output)	Field Description
Oper status	Operational status	Operational state of the PoE interface: <ul style="list-style-type: none"> • ON—The interface is currently supplying power to a powered device. • OFF—PoE is enabled on the interface, but the interface is not currently supplying power to a powered device. • Disabled—PoE is disabled on the interface.
Max power	Power limit on the interface	Maximum power that can be provided by the interface. An (L) next to the value indicates that the value on the port was negotiated by LLDP.
Priority	Priority	Interface power priority: either High or Low . An (L) next to the value indicates that the value on the port was negotiated by LLDP.
Power consumption	Power consumed	Amount of power being used by the interface at the time the command is executed.
Class	Class of power device	IEEE 802.3af (PoE) or IEEE 802.3at (PoE+) class of the powered device. Class 0 is the default class and is used when the class of the powered device is unknown. If no powered device is connected, this field contains not applicable .
	PoE Mode	IEEE PoE standard supported by the interface—either 802.3af or 802.3at .

Sample Output

show poe interface

```

user@switch> show poe interface
Interface Admin    Oper    Max    Priority Power    Class
           status    status  power
ge-0/0/0 Enabled    ON      15.4W  Low     7.9W    0
ge-0/0/1 Enabled    ON      15.4W  Low     3.2W    2
ge-0/0/2 Enabled    ON      15.4W  Low     3.2W    2
ge-0/0/3 Enabled    ON      15.4W  Low     3.2W    2
ge-0/0/4 Enabled    ON      15.4W  Low     3.2W    2
ge-0/0/5 Enabled    ON      15.4W  Low     3.2W    2
ge-0/0/6 Enabled    ON      15.4W  Low     3.2W    2
ge-0/0/7 Enabled    ON      15.4W  Low     3.2W    2

```

show poe interface (with LLDP Negotiation)

```

user@switch> show poe interface
Interface Admin    Oper    Max    Priority Power    Class
           status    status  power
ge-0/0/0 Enabled    ON      17.5W(L) Low(L)   16.2W    4
ge-0/0/1 Enabled    ON      17.5W(L) Low(L)   16.0W    4
ge-0/0/2 Enabled    ON      17.5W(L) High(L)  16.0W    4
ge-0/0/3 Enabled    ON      17.5W(L) Low(L)   16.0W    4
ge-0/0/4 Enabled    ON      10.1W(L) Low(L)   10.0W    3

```

```

ge-0/0/5    Enabled    ON    3.5W(L)    High(L)    3.0W    2
(L) LLDP-negotiated value on the port.

```

show poe interface (Specific Interface)

```

user@switch> show poe interface ge-0/0/3
PoE interface status:
PoE interface           : ge-0/0/3
Administrative status   : Enabled
Operational status      : ON
Power limit on the interface : 7.0W
Priority                 : Low
Power consumed          : 5.3W
Class of power device    : 2
PoE Mode                : 802.3af

```

show poe interface (Specific FPC Slot)

```

user@switch> show poe interface fpc-slot 3

```

Interface	Admin status	Oper status	Max power	Priority	Power consumption	Class
ge-3/0/0	Enabled	ON	30.0W	Low	20.3W	4
ge-3/0/1	Enabled	ON	30.0W	Low	17.8W	4
ge-3/0/2	Enabled	ON	30.0W	High	16.3W	4
ge-3/0/3	Enabled	ON	30.0W	High	16.2W	4
ge-3/0/4	Enabled	ON	30.0W	Low	25.9W	4
ge-3/0/5	Enabled	ON	30.0W	Low	10.1W	4
ge-3/0/6	Enabled	ON	30.0W	Low	16.2W	4
ge-3/0/7	Enabled	ON	30.0W	Low	6.4W	4
ge-3/0/8	Enabled	ON	30.0W	Low	5.2W	4
ge-3/0/9	Enabled	ON	30.0W	Low	5.2W	4
ge-3/0/10	Enabled	ON	30.0W	Low	21.5W	4
ge-3/0/11	Enabled	ON	30.0W	Low	21.7W	4
ge-3/0/12	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/13	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/14	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/15	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/16	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/17	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/18	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/19	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/20	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/21	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/22	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/23	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/24	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/25	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/26	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/27	Enabled	ON	15.4W	Low	9.4W	0
ge-3/0/28	Enabled	ON	15.4W	Low	7.0W	0
ge-3/0/29	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/30	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/31	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/32	Enabled	ON	15.4W	Low	2.0W	1
ge-3/0/33	Enabled	ON	15.4W	Low	2.0W	1
ge-3/0/34	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/35	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/36	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/37	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/38	Enabled	ON	15.4W	Low	2.2W	1
ge-3/0/39	Enabled	ON	15.4W	Low	2.2W	1

show poe interface (Specific Interface on ACX2000 Universal Access Routers)

```
user@host> show poe interface ge-0/1/7
PoE interface status:
PoE interface           : ge-0/1/7
Administrative status   : Enabled
Operational status      : Powered-up
Power limit on the interface : 9.0 W
Priority                 : Low
Power consumed           : 14.2 W
Class of power device    : 4
```

show poe notification-control

Syntax	show poe notification-control
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the state of the PoE notification-control option, which enables or disables PoE SNMP traps.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show poe controller on page 81• show poe interface on page 84• Verifying PoE Configuration and Status (CLI Procedure) on page 71
List of Sample Output	show poe notification-control on page 89
Output Fields	Table 23 on page 88 lists the output fields for the show poe notification-control command. Output fields are listed in the approximate order in which they appear.

Table 23: show poe notification-control Output Fields

Field Name	Field Description
FPC slot	FPC slot number: <ul style="list-style-type: none">• 0 for a standalone switch• Member ID for a Virtual Chassis
Notification-control-status	Status of notification control: <ul style="list-style-type: none">• ON—PoE traps are enabled.• OFF—PoE traps are disabled.

Sample Output

show poe notification-control

```
user@switch> show poe notification-control
FPC slot      Notification-control-status
  0              OFF
```

show poe telemetries

Syntax	show poe telemetries <count (all <i>number</i>)> <interface (all <i>interface-name</i>)>
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display a history of power consumption on the specified interface or on all interfaces. Telemetries must be enabled on the interface before you can display a history of power consumption.
Options	<p>none—Displays all records for all interfaces that have power consumption history data.</p> <p>count (all <i>number</i>)—(Optional) Specify the number of power consumption records to display. The most recent records are displayed. If you do not specify the count, all available records are displayed.</p> <p>interface (all <i>interface-name</i>)—(Optional) Display power consumption records for the specified PoE interface or for all PoE interfaces. If you do not specify interfaces, all interfaces are displayed.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show poe interface on page 84 • show poe controller on page 81 • Monitoring PoE Power Consumption (CLI Procedure) on page 68 • Verifying PoE Configuration and Status (CLI Procedure) on page 71 • Troubleshooting PoE Interfaces on page 95
List of Sample Output	show poe telemetries interface all count on page 91 show poe telemetries interface (Specific Interface) count all on page 91
Output Fields	Table 24 on page 90 lists the output fields for the show poe telemetries interface command. Output fields are listed in the approximate order in which they appear.

Table 24: show poe telemetries interface Output Fields

Field Name	Field Description
Interface	Name of the interface.
SI No	Number of the record for the specified interface. Record number 1 is the most recent.
Timestamp	Date and time when the power-consumption data was gathered.

Table 24: show poe telemetries interface Output Fields (*continued*)

Field Name	Field Description
Power	Amount of power provided by the specified interface at the time the data was gathered.
Voltage	Maximum voltage provided by the specified interface at the time the data was gathered.

Sample Output

show poe telemetries interface all count

```

user@switch> show poe telemetries interface all count 2
Interface  S1 No    Timestamp                Power    Voltage
ge-0/0/1   1    03-09-2012 11:52:03 UTC    4.2W    54.9V
            2    03-09-2012 11:47:03 UTC    4.2W    54.8V
ge-0/0/2   1    03-09-2012 11:52:03 UTC    4.2W    54.9V
            2    03-09-2012 11:47:03 UTC    4.1W    54.8V
ge-0/0/3   1    03-09-2012 11:52:03 UTC    4.2W    54.9V
            2    03-09-2012 11:47:03 UTC    4.3W    54.8V
ge-0/0/4   1    03-09-2012 11:52:03 UTC    0.0W    54.9V
            2    03-09-2012 11:47:03 UTC    0.0W    54.8V
ge-0/0/5   1    03-09-2012 11:52:03 UTC    4.2W    54.9V
            2    03-09-2012 11:47:03 UTC    4.2W    54.8V
ge-0/0/6   1    03-09-2012 11:52:03 UTC    4.2W    54.9V
            2    03-09-2012 11:47:03 UTC    4.2W    54.8V
ge-0/0/7   1    03-09-2012 11:52:03 UTC    4.2W    54.9V

```

show poe telemetries interface (Specific Interface) count all

```

user@switch> show poe telemetries interface ge-0/0/0 count all
S1 No    Timestamp                Power    Voltage
1    01-27-2008 18:19:58 UTC    15.4W    51.6V
2    01-27-2008 18:18:58 UTC    15.4W    51.6V
3    01-27-2008 18:17:58 UTC    15.4W    51.6V
4    01-27-2008 18:16:58 UTC    15.4W    51.6V
5    01-27-2008 18:15:58 UTC    15.4W    51.6V
6    01-27-2008 18:14:58 UTC    15.4W    51.6V
7    01-27-2008 18:13:58 UTC    15.4W    51.6V
8    01-27-2008 18:12:57 UTC    15.4W    51.6V
9    01-27-2008 18:11:57 UTC    15.4W    51.6V
10   01-27-2008 18:10:57 UTC    15.4W    51.6V
11   01-27-2008 18:09:57 UTC    15.4W    51.6V
12   01-27-2008 18:08:57 UTC    15.4W    51.6V
13   01-27-2008 18:07:57 UTC    15.4W    51.6V
14   01-27-2008 18:06:57 UTC    15.4W    51.6V
15   01-27-2008 18:05:57 UTC    15.4W    51.6V
16   01-27-2008 18:04:56 UTC    15.4W    51.6V
17   01-27-2008 18:03:56 UTC    15.4W    51.6V
18   01-27-2008 18:02:56 UTC    15.4W    51.6V
19   01-27-2008 18:01:56 UTC    15.4W    51.6V
20   01-27-2008 18:00:56 UTC    15.4W    51.6V
21   01-27-2008 17:59:56 UTC    15.4W    51.6V

```


PART 4

Troubleshooting

- [Troubleshooting Procedures on page 95](#)

CHAPTER 8

Troubleshooting Procedures

- [Troubleshooting PoE Interfaces on page 95](#)

Troubleshooting PoE Interfaces

Problem **Description:** A Power over Ethernet (PoE) interface is not supplying power to the powered device.

Solution Check for the items shown in [Table 25 on page 95](#).

Table 25: Troubleshooting a PoE Interface

Items to Check	Explanation
Is the switch a full PoE model or a partial PoE model?	If you are using a partial PoE model, only interfaces ge-0/0/0 through ge-0/0/7 can function as PoE ports.
Has PoE capability been disabled for that interface?	Use the show poe interface command to check PoE interface status.
Is the cable properly seated in the port socket?	Check the hardware.
Has the PoE power budget been exceeded for the switch?	Use the show poe controller command to check the PoE power budget and consumption for the switch.
Does the powered device require more power than is available on the interface?	Use the show poe interface command to check the maximum power provided by the interface.
If the telemetries option has been enabled for the interface, check the history of power consumption.	Use the show poe telemetries command to display the history of power consumption.

- Related Documentation**
- [Example: Configuring PoE Interfaces with Different Priorities on an EX Series Switch on page 17](#)
 - [Verifying PoE Configuration and Status \(CLI Procedure\) on page 71](#)
 - [Monitoring PoE Power Consumption \(CLI Procedure\) on page 68](#)

- [Configuring PoE on EX Series Switches \(CLI Procedure\) on page 31](#)