

## Configuring the Redirect Server (SRC CLI)

---

The redirect server on a C-series Controller manages IP layer redirection.

To configure the redirect server:

1. Configure general properties for the redirect server.

See [Configuring General Properties for the Redirect Server with the SRC CLI](#) .

2. Configure a connection from the redirect server to the directory.

See [Configuring a Connection Between the Redirect Server and the Directory with the SRC CLI](#) .

3. (Optional) Define traffic to be forwarded to the redirect server. In most cases you can accept the default values—traffic destined for port 80 (Web requests) and forwarded from all interface on a C-series Controller.

See [Defining Traffic to Transmit to the Redirect Server with the SRC CLI](#) .

4. (Optional) Configure the number of requests that the redirect server accepts.

See [Changing the Number of Requests That the Redirect Server Accepts with the SRC CLI](#) .

5. (Optional) Configure the types of files for which the redirect server accepts requests.

See [Specifying Extensions for Files That the Redirect Server Accepts with the SRC CLI](#) .

6. (Optional) For a configuration to support HTTP proxies, configure DNS. You can configure the DNS server included with the redirect server, or another DNS server on your network. If you use another DNS server, you do not need to configure the DNS server included with the redirect server.

For information about configuring the DNS server included with the redirect server, see [Configuring the DNS Server for the Redirect Server with the SRC CLI](#).

7. (Optional) Configure support for HTTP proxies.

See [Verifying Configuration for the Redirect Server with the SRC CLI](#).

8. (Optional) Configure a redundant redirect server.

See [Configuring a Redundant Redirect Server with the SRC CLI](#).

9. Enable the redirect server.

See [Enabling the Redirect Server](#).

- Related Topics**
- [Overview of Traffic Redirection](#)
  - [Redirect Server Redundancy](#)
  - [Configuration Statements for the Redirect Server \(SRC CLI\)](#)

