

Configuring Gigabit Ethernet Interfaces for IPv4 (SRC CLI)

You can configure the Gigabit Ethernet interfaces to use IPv4 or IPv6 to allow remote access to the C Series Controller. You can specify an IP address with mask or a broadcast address with mask for an interface.

Use the following configuration statements to configure Gigabit Ethernet interfaces to use IPv4 and the **[edit]** hierarchy level:

```
interfaces name unit unit-number
interfaces name unit unit-number family inet {
    address address ;
    broadcast broadcast ;
}
```

To configure a Gigabit Ethernet interface to use IPv4:

1. From configuration mode, access the configuration statement that configures the interface.

```
[edit]
user@host# edit interfaces name unit unit-number
```

where *unit-number* is a number that you can assign for a logical interface identifier.

For example:

```
[edit]
user@host# edit interfaces eth0
```

2. Specify the unit, family, and IP address for the interface.

```
[edit interfaces eth0]
user@host# set unit number family inet address address
```

For example, to configure an interface with only an IP address:

```
[edit interfaces eth0]
user@host# set unit 0 family inet address 192.2.0.10/24
```

3. Verify the interface configuration.

```
[edit interfaces eth0]
user@host# show
unit 0 {
    family {
        inet {
            address 192.2.0.10/24;
        }
    }
}
```

- Related Topics**
- Configuring Gigabit Ethernet Interfaces for IPv4 (C-Web Interface)
 - Configuring Gigabit Ethernet Interfaces for IPv6 (SRC CLI)
 - Configuring Tunnel Interfaces (SRC CLI)
 - Overview of External Interfaces on a C Series Controller

Published: 2009-09-25