



Junos[®] OS

System Basics and Services Command Reference

Release
11.2



Published: 2011-05-17

Juniper Networks, Inc.
1194 North Mathilda Avenue
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

Junos® OS System Basics and Services Command Reference

Release 11.2

Copyright © 2011, Juniper Networks, Inc.

All rights reserved.

Revision History

April 2011—R1 Junos OS 11.2

The information in this document is current as of the date listed in the revision history.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. The Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

READ THIS END USER LICENSE AGREEMENT ("AGREEMENT") BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE. BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. **The Parties.** The parties to this Agreement are (i) Juniper Networks, Inc. (if the Customer's principal office is located in the Americas) or Juniper Networks (Cayman) Limited (if the Customer's principal office is located outside the Americas) (such applicable entity being referred to herein as "Juniper"), and (ii) the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software ("Customer") (collectively, the "Parties").

2. **The Software.** In this Agreement, "Software" means the program modules and features of the Juniper or Juniper-supplied software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller, or which was embedded by Juniper in equipment which Customer purchased from Juniper or an authorized Juniper reseller. "Software" also includes updates, upgrades and new releases of such software. "Embedded Software" means Software which Juniper has embedded in or loaded onto the Juniper equipment and any updates, upgrades, additions or replacements which are subsequently embedded in or loaded onto the equipment.

3. **License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

- a. Customer shall use Embedded Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller.
- b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees; provided, however, with respect to the Steel-Belted Radius or Odyssey Access Client software only, Customer shall use such Software on a single computer containing a single physical random access memory space and containing any number of processors. Use of the Steel-Belted Radius or IMS AAA software on multiple computers or virtual machines (e.g., Solaris zones) requires multiple licenses, regardless of whether such computers or virtualizations are physically contained on a single chassis.
- c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer's use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, realms, devices, links, ports or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. In addition, such limits may restrict the use of the Software to managing certain kinds of networks or require the Software to be used only in conjunction with other specific Software. Customer's use of the Software shall be subject to all such limitations and purchase of all applicable licenses.
- d. For any trial copy of the Software, Customer's right to use the Software expires 30 days after download, installation or use of the Software. Customer may operate the Software after the 30-day trial period only if Customer pays for a license to do so. Customer may not extend or create an additional trial period by re-installing the Software after the 30-day trial period.
- e. The Global Enterprise Edition of the Steel-Belted Radius software may be used by Customer only to manage access to Customer's enterprise network. Specifically, service provider customers are expressly prohibited from using the Global Enterprise Edition of the Steel-Belted Radius software to support any commercial network access services.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. **Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any 'locked' or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the

Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use Embedded Software on non-Juniper equipment; (j) use Embedded Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. **Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. **Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. **Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. **Warranty, Limitation of Liability, Disclaimer of Warranty.** The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. **Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. **Taxes.** All license fees payable under this agreement are exclusive of tax. Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software. If applicable, valid exemption documentation for each taxing jurisdiction shall be provided to Juniper prior to invoicing, and Customer shall promptly notify Juniper if their exemption is revoked or modified. All payments made by Customer shall be net of any applicable withholding tax. Customer will provide reasonable assistance to Juniper in connection with such withholding taxes by promptly: providing Juniper with valid tax receipts and other required documentation showing Customer's payment of any withholding taxes; completing appropriate applications that would reduce the amount of withholding tax to be paid; and notifying and assisting Juniper in any audit or tax proceeding related to transactions hereunder. Customer shall comply with all applicable tax laws and regulations, and Customer will promptly pay or reimburse Juniper for all costs and damages related to any liability incurred by Juniper as a result of Customer's non-compliance or delay with its responsibilities herein. Customer's obligations under this Section shall survive termination or expiration of this Agreement.

11. **Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. **Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14 (ALT III) as applicable.

13. **Interface Information.** To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. **Third Party Software.** Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License ("GPL") or the GNU Library General Public License ("LGPL")), Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. **Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).

Abbreviated Table of Contents

	About This Guide	xxiii
Part 1	Monitoring and Testing Tools	
Chapter 1	Connectivity Operational Mode Commands	3
Chapter 2	Interface Diagnostics Operational Mode Commands	33
Chapter 3	RADIUS Diagnostics Operational Mode Commands	53
Chapter 4	Real-Time Performance Monitoring Operational Mode Commands	61
Chapter 5	Real-Time Router Monitoring Operational Mode Commands	77
Part 2	System Management	
Chapter 6	Accounting Operational Mode Commands	137
Chapter 7	Chassis Operational Mode Commands	159
Chapter 8	Command-Line Interface Operational Mode Commands	543
Chapter 9	File Management Operational Mode Commands	565
Chapter 10	Packet Forwarding Engine Operational Mode Commands	587
Chapter 11	Remote System Access Operational Mode Commands	657
Chapter 12	Simple Network Management Protocol Operational Mode Commands ..	663
Chapter 13	System Software Operational Mode Commands	695
Chapter 14	Virtual Chassis Operational Mode Commands	1205
Part 3	Class of Service	
Chapter 15	Class-of-Service Operational Mode Commands	1243
Part 4	Services	
Chapter 16	Generic Services Operational Mode Commands	1303
Chapter 17	Border Signaling Gateway Operational Mode Commands	1313
Chapter 18	Compressed Real-Time Transport Protocol Operational Mode Commands	1355
Chapter 19	CoS Services Operational Mode Commands	1363
Chapter 20	Data Link Switching Operational Mode Commands	1369
Chapter 21	Diameter Base Protocol Operational Mode Commands	1383
Chapter 22	Distributed Denial-of-Service Protection Operational Mode Commands	1425
Chapter 23	Dynamic Application Awareness Operational Mode Commands	1459

Chapter 24	Flow Collection and Monitoring Operational Mode Commands	1479
Chapter 25	Intrusion Detection Service Operational Mode Commands	1543
Chapter 26	IP Security Operational Mode Commands	1557
Chapter 27	Layer 2 Tunneling Protocol Operational Mode Commands	1633
Chapter 28	Link Services Operational Mode Commands	1671
Chapter 29	Mobile IP Operational Mode Commands	1677
Chapter 30	Network Address Translation Operational Mode Commands	1689
Chapter 31	PGCP Operational Mode Commands for the BGF Feature	1695
Chapter 32	PTSP Operational Mode Commands	1747
Chapter 33	Service Sets Operational Mode Commands	1761
Chapter 34	Softwire Operational Mode Commands	1779
Chapter 35	Stateful Firewall Operational Mode Commands	1783
Part 5	Index	
	Index	1821
	Index of Statements and Commands	1843

Table of Contents

	About This Guide	xxiii
	Junos OS Documentation and Release Notes	xxiii
	Objectives	xxiii
	Audience	xxiv
	Supported Platforms	xxv
	Using the Indexes	xxv
	Documentation Conventions	xxv
	Documentation Feedback	xxvii
	Requesting Technical Support	xxvii
	Self-Help Online Tools and Resources	xxviii
	Opening a Case with JTAC	xxviii
Part 1	Monitoring and Testing Tools	
Chapter 1	Connectivity Operational Mode Commands	3
	ping	4
	ping atm	8
	ping clns	10
	ping mpls l2circuit	12
	ping mpls l2vpn	15
	ping mpls l3vpn	18
	ping mpls ldp	20
	ping mpls lsp-end-point	23
	ping mpls rsvp	25
	ping vpls instance	30
Chapter 2	Interface Diagnostics Operational Mode Commands	33
	test interface ds0-bert-start	35
	test interface ds0-bert-stop	36
	test interface e1-bert-start	37
	test interface e1-bert-stop	38
	test interface e3-bert-start	39
	test interface e3-bert-stop	40
	test interface fdl-line-loop	41
	test interface fdl-payload-loop	43
	test interface feac-loop-initiate	44
	test interface feac-loop-terminate	45
	test interface inband-line-loop	46
	test interface inband-payload-loop	47
	test interface restart-auto-negotiation	48
	test interface t1-bert-start	49

	test interface t1-bert-stop	50
	test interface t3-bert-start	51
	test interface t3-bert-stop	52
Chapter 3	RADIUS Diagnostics Operational Mode Commands	53
	test access profile	54
	test access radius-server	58
Chapter 4	Real-Time Performance Monitoring Operational Mode Commands	61
	clear services rpm twamp server connection	62
	show services rpm active-servers	63
	show services rpm history-results	64
	show services rpm probe-results	67
	show services rpm twamp server connection	73
	show services rpm twamp server session	75
Chapter 5	Real-Time Router Monitoring Operational Mode Commands	77
	monitor ethernet delay-measurement	79
	monitor ethernet loss-measurement	84
	monitor interface	89
	monitor label-switched-path	96
	monitor list	99
	monitor start	100
	monitor stop	102
	monitor traffic	103
	mtrace	112
	mtrace from-source	114
	mtrace monitor	117
	mtrace to-gateway	119
	traceroute	122
	traceroute monitor	125
	traceroute mpls ldp	127
	traceroute mpls rsvp	130
Part 2	System Management	
Chapter 6	Accounting Operational Mode Commands	137
	clear lldp neighbor	138
	clear lldp statistics	139
	show lldp	140
	show lldp local-information	142
	show lldp neighbors	144
	show lldp remote-global-statistics	148
	show lldp statistics	150
	show accounting profile	152
	show accounting records	156
Chapter 7	Chassis Operational Mode Commands	159
	clear chassis display message	165
	request chassis cb	167
	request chassis cfeb	169

request chassis cip	170
request chassis fabric plane	171
request chassis feb	172
request chassis fpc	173
request chassis fpm resync	175
request chassis lcc	177
request chassis mcs	178
request chassis pcg	179
request chassis pic	180
request chassis mic	182
request chassis redundancy feb slot	183
request chassis routing-engine master	184
request chassis scg	188
request chassis sfm	189
request chassis sfm master switch	190
request chassis sib	191
request chassis sib f13 train-link-receive slot	193
request chassis sib f13 train-link-transmit slot	194
request chassis sib train-link-receive slot	195
request chassis sib train-link-transmit slot	196
request chassis spmb restart	197
request chassis ssb master switch	198
request chassis synchronization mode	199
request chassis synchronization switch	200
set chassis display message	201
show chassis alarms	204
show chassis cfeb	208
show chassis cip	210
show chassis craft-interface	212
show chassis environment	220
show chassis environment cb	237
show chassis environment cip	248
show chassis environment fpc	250
show chassis environment fpm	260
show chassis environment mcs	264
show chassis environment pcg	266
show chassis environment pem	268
show chassis environment routing-engine	274
show chassis environment scg	277
show chassis environment sfm	281
show chassis environment sib	284
show chassis ethernet-switch	304
show chassis fan	317
show chassis fabric feb	319
show chassis fabric errors	320
show chassis fabric fpcs	323
show chassis fabric map	341
show chassis fabric plane	348
show chassis fabric plane-location	370

	show chassis fabric sibs	373
	show chassis fabric summary	381
	show chassis fabric topology	383
	show chassis feb	395
	show chassis firmware	398
	show chassis forwarding	405
	show chassis fpc	406
	show chassis fpc-feb-connectivity	421
	show chassis hardware	423
	show chassis in-service-upgrade	468
	show chassis lccs	470
	show chassis location	471
	show chassis mac-addresses	474
	show chassis network services	477
	show chassis pic	478
	show chassis power-ratings	485
	show chassis power	488
	show chassis power sequence	493
	show chassis psd	494
	show chassis redundancy feb	495
	show chassis routing-engine	498
	show chassis scb	510
	show chassis sfm	512
	show chassis sibs	515
	show chassis spmb	521
	show chassis spmb sibs	528
	show chassis ssb	532
	show chassis synchronization	534
	show chassis temperature-thresholds	537
Chapter 8	Command-Line Interface Operational Mode Commands	543
	clear cli logical-system	545
	set cli complete-on-space	546
	set cli directory	547
	set cli idle-timeout	548
	set cli logical-system	549
	set cli prompt	550
	set cli restart-on-upgrade	551
	set cli screen-length	552
	set cli screen-width	553
	set cli terminal	554
	set cli timestamp	555
	set date	556
	show cli	557
	show cli authorization	559
	show cli directory	562
	show cli history	563

Chapter 9	File Management Operational Mode Commands	565
	clear log	567
	file archive	568
	file checksum md5	570
	file checksum sha1	571
	file checksum sha-256	572
	file compare	573
	file copy	576
	file delete	578
	file list	579
	file rename	581
	file show	583
	show log	585
Chapter 10	Packet Forwarding Engine Operational Mode Commands	587
	show pfe cfeb	589
	show pfe feb	592
	show pfe fpc	595
	show pfe fwdd	602
	show pfe lcc	605
	show pfe next-hop	608
	show pfe route	612
	show pfe scb	617
	show pfe sfm	619
	show pfe ssb	621
	show pfe statistics dma	624
	show pfe statistics error	628
	show pfe statistics ip	631
	show pfe statistics ip6	634
	show pfe statistics notification	637
	show pfe statistics pio	639
	show pfe statistics traffic	641
	show pfe statistics traffic protocol bfd	644
	show pfe statistics traffic protocol cfm	647
	show pfe statistics traffic protocol lfm	649
	show pfe terse	651
	show pfe resource usage memory	653
	show pfe version	656
Chapter 11	Remote System Access Operational Mode Commands	657
	ssh	658
	telnet	660
Chapter 12	Simple Network Management Protocol Operational Mode Commands . .	663
	clear snmp statistics	664
	request snmp spoof-trap	666
	show snmp health-monitor	672
	show snmp inform-statistics	679
	show snmp mib	681
	show snmp rmon	684

Chapter 13

show snmp statistics	688
show snmp v3	692
System Software Operational Mode Commands	695
clear arp	703
clear dhcp server binding	704
clear dhcp server statistics	706
clear dhcpv6 server binding	708
clear dhcpv6 server statistics	710
clear network-access aaa statistics	711
clear network-access aaa subscriber	712
clear system commit	713
clear system reboot	714
clear system services dhcp binding	717
clear system services dhcp conflict	718
clear system services dhcp statistics	719
configure	720
op	722
request dhcp server reconfigure	724
request dhcpv6 server reconfigure	726
request message	728
request routing-engine login	729
request services static-subscribers login group	731
request services static-subscribers login interface	732
request services static-subscribers logout group	733
request services static-subscribers logout interface	734
request support information	735
request system configuration rescue delete	741
request system configuration rescue save	742
request system firmware	743
request system halt	744
request system license add	749
request system license delete	750
request system license save	751
request system logout	752
request system partition abort	753
request system partition hard-disk	755
request system power-off	757
request system reboot	761
request system scripts convert	765
request system snapshot	766
request system software abort	772
request system software add	775
request system software delete	781
request system software delete-backup	784
request system software in-service-upgrade	785
request system software in-service-upgrade (MX Series 3D Universal Edge Routers)	789
request system software rollback	802

request system software validate	805
request system software validate-in-service-upgrade	808
request system storage cleanup	811
restart	813
show arp	820
show configuration	822
show database-replication statistics	825
show database-replication summary	826
show dhcp server binding	828
show dhcp server statistics	832
show dhcpv6 server binding	835
show dhcpv6 server statistics	839
show host	842
show network-access aaa statistics	843
show network-access aaa subscribers	846
show network-access aaa subscribers session-id	849
show network-access address-assignment pool	852
show ntp associations	853
show ntp status	855
show static-subscribers sessions	856
show subscribers	858
show system alarms	866
show system audit	867
show system autoinstallation status	874
show system boot-messages	875
show system buffers	882
show system commit	888
show system configuration archival	890
show system configuration rescue	891
show system connections	893
show system core-dumps	911
show system directory-usage	917
show system firmware	920
show system license	922
show system name-resolution	925
show system processes	927
show system queues	949
show system reboot	955
show system rollback	958
show system services dhcp binding	960
show system services dhcp conflict	963
show system services dhcp global	964
show system services dhcp pool	966
show system services dhcp statistics	968
show system services service-deployment	970
show system snapshot	971
show system software	974
show system statistics	980
show system statistics arp	1014

show system statistics clns	1020
show system statistics esis	1025
show system statistics icmp	1029
show system statistics icmp6	1033
show system statistics igmp	1038
show system statistics ip	1041
show system statistics ip6	1049
show system statistics mpls	1056
show system statistics rdp	1060
show system statistics tcp	1064
show system statistics tnp	1072
show system statistics tudp	1078
show system statistics udp	1081
show system statistics vpls	1084
show system storage	1089
show system subscriber-management summary	1094
show system switchover	1096
show system uptime	1100
show system users	1104
show system virtual-memory	1108
show task	1164
show task io	1166
show task memory	1168
show task replication	1172
show version	1174
show version invoke-on	1182
start shell	1194
test aaa authd-lite user	1196
test aaa dhcp user	1198
test aaa ppp user	1201
test configuration	1204

Chapter 14

Virtual Chassis Operational Mode Commands	1205
request virtual-chassis member-id delete (MX Series Virtual Chassis)	1207
request virtual-chassis member-id set (MX Series Virtual Chassis)	1208
request virtual-chassis routing-engine master switch (MX Series Virtual Chassis)	1209
request virtual-chassis vc-port delete (MX Series Virtual Chassis)	1211
request virtual-chassis vc-port set (MX Series Virtual Chassis)	1213
show virtual-chassis active-topology (MX Series Virtual Chassis)	1215
show virtual-chassis device-topology (MX Series Virtual Chassis)	1217
show virtual-chassis protocol adjacency (MX Series Virtual Chassis)	1219
show virtual-chassis protocol database (MX Series Virtual Chassis)	1223
show virtual-chassis protocol interface (MX Series Virtual Chassis)	1228
show virtual-chassis protocol route (MX Series Virtual Chassis)	1231
show virtual-chassis protocol statistics (MX Series Virtual Chassis)	1234
show virtual-chassis status (MX Series Virtual Chassis)	1237
show virtual-chassis vc-port (MX Series Virtual Chassis)	1239

Part 3

Class of Service

Chapter 15

Class-of-Service Operational Mode Commands 1243

show class-of-service	1246
show class-of-service adaptive-shaper	1248
show class-of-service classifier	1249
show class-of-service code-point-aliases	1251
show class-of-service drop-profile	1253
show class-of-service fabric scheduler-map	1255
show class-of-service fabric statistics	1257
show class-of-service forwarding-class	1259
show class-of-service forwarding-table	1261
show class-of-service forwarding-table classifier	1264
show class-of-service forwarding-table classifier mapping	1266
show class-of-service forwarding-table drop-profile	1267
show class-of-service forwarding-table fabric scheduler-map	1269
show class-of-service forwarding-table loss-priority-map	1271
show class-of-service forwarding-table loss-priority-map mapping	1273
show class-of-service forwarding-table rewrite-rule	1274
show class-of-service forwarding-table rewrite-rule mapping	1276
show class-of-service forwarding-table scheduler-map	1277
show class-of-service fragmentation-map	1279
show class-of-service interface	1281
show class-of-service interface-set	1284
show class-of-service loss-priority-map	1286
show class-of-service rewrite-rule	1288
show class-of-service routing-instance	1290
show class-of-service scheduler-map	1291
show class-of-service traffic-control-profile	1293
show class-of-service translation-table	1295
show class-of-service virtual-channel	1299
show class-of-service virtual-channel-group	1300

Part 4

Services

Chapter 16

Generic Services Operational Mode Commands 1303

clear services flows	1304
show services flows	1307

Chapter 17

Border Signaling Gateway Operational Mode Commands 1313

clear services border-signaling-gateway denied-messsages	1315
clear services border-signaling-gateway name-resolution-cache	1316
clear services border-signaling-gateway registrations statistics	1317
clear services border-signaling-gateway registrations subscription	1318
clear services border-signaling-gateway statistics	1319
show services border-signaling-gateway address-of-record bindings	1320
show services border-signaling-gateway admission-control	1323
show services border-signaling-gateway by-contact	1325
show services border-signaling-gateway by-request-uri	1327
show services border-signaling-gateway calls by-server	1330

	show services border-signaling-gateway calls by-service-point	1332
	show services border-signaling-gateway calls-duration by-server	1334
	show services border-signaling-gateway calls-duration by-service-point	1337
	show services border-signaling-gateway calls-failed by-server	1340
	show services border-signaling-gateway calls-failed by-service-point	1343
	show services border-signaling-gateway denied-messages	1346
	show services border-signaling-gateway name-resolution-cache	1347
	show services border-signaling-gateway registrations	1349
	show services border-signaling-gateway routing-blacklist	1351
	show services border-signaling-gateway status	1352
Chapter 18	Compressed Real-Time Transport Protocol Operational Mode Commands	1355
	clear services crtp statistics	1356
	show services crtp	1357
	show services crtp flows	1360
Chapter 19	CoS Services Operational Mode Commands	1363
	clear services cos statistics	1364
	show services cos statistics	1365
Chapter 20	Data Link Switching Operational Mode Commands	1369
	clear dlsw reachability	1370
	show dlsw capabilities	1371
	show dlsw circuits	1372
	show dlsw peers	1374
	show dlsw reachability	1376
	show llc2 redundancy	1377
	show llc2 redundancy interface statistics	1379
	show llc2 redundancy mac-translation	1380
	show llc2 redundancy track	1381
Chapter 21	Diameter Base Protocol Operational Mode Commands	1383
	clear diameter function statistics	1385
	clear diameter peer	1386
	clear network-access gx-plus replay	1387
	clear network-access gx-plus statistics	1388
	show diameter	1389
	show diameter function	1395
	show diameter function statistics	1398
	show diameter instance	1401
	show diameter network-element	1403
	show diameter network-element map	1406
	show diameter peer	1409
	show diameter peer map	1413
	show diameter peer statistics	1416
	show diameter route	1420
	show network-access gx-plus	1422

Chapter 22	Distributed Denial-of-Service Protection Operational Mode Commands	1425
	clear ddos-protection protocols	1426
	show ddos-protection protocols	1427
	show ddos-protection protocols parameters	1439
	show ddos-protection protocols statistics	1445
	show ddos-protection protocols violations	1455
	show ddos-protection statistics	1457
	show ddos-protection version	1458
Chapter 23	Dynamic Application Awareness Operational Mode Commands	1459
	clear services application-identification application-system-cache	1461
	clear services application-aware-access-list statistics	1462
	clear services application-identification counter	1463
	clear services flows ip-action	1464
	clear services local-policy-decision-function statistics	1465
	show services application-aware-access-list flows	1466
	show services application-aware-access-list statistics	1468
	show services application-identification application-system-cache	1470
	show services application-identification counter	1472
	show services local-policy-decision-function flows	1474
	show services local-policy-decision-function statistics	1476
Chapter 24	Flow Collection and Monitoring Operational Mode Commands	1479
	clear services dynamic-flow-capture	1482
	clear passive-monitoring statistics	1483
	clear services flow-collector statistics	1484
	request services flow-collector change-destination primary interface	1485
	request services flow-collector change-destination secondary interface	1486
	request services flow-collector test-file-transfer	1487
	show forwarding-options next-hop-group	1488
	show forwarding-options port-mirroring	1491
	show passive-monitoring error	1493
	show passive-monitoring flow	1495
	show passive-monitoring memory	1497
	show passive-monitoring status	1499
	show passive-monitoring usage	1501
	show services accounting aggregation	1503
	show services accounting aggregation template	1507
	show services accounting errors	1508
	show services accounting flow	1510
	show services accounting flow-detail	1513
	show services accounting memory	1518
	show services accounting packet-size-distribution	1520
	show services accounting status	1522
	show services accounting usage	1524
	show services dynamic-flow-capture content-destination	1526
	show services dynamic-flow-capture control-source	1528
	show services dynamic-flow-capture statistics	1530

	show services flow-collector file interface	1533
	show services flow-collector input interface	1535
	show services flow-collector interface	1537
Chapter 25	Intrusion Detection Service Operational Mode Commands	1543
	clear services ids	1544
	clear services ids destination-table	1545
	clear services ids pair-table	1546
	clear services ids source-table	1547
	show services ids	1548
Chapter 26	IP Security Operational Mode Commands	1557
	clear ike security-associations	1561
	clear ipsec security-associations	1562
	clear security pki ca-certificate	1564
	clear security pki certificate-request	1565
	clear security pki crl	1566
	clear security pki key-pair	1567
	clear security pki local-certificate	1568
	clear services ipsec-vpn certificates	1569
	clear services ipsec-vpn ike security-associations	1570
	clear services ipsec-vpn ipsec statistics	1571
	clear services ipsec-vpn ipsec security-associations	1572
	request security certificate (signed)	1573
	request security certificate (unsigned)	1574
	request security key-pair	1575
	request security pki ca-certificate enroll	1576
	request security pki ca-certificate load	1577
	request security pki ca-certificate verify	1578
	request security pki crl load	1579
	request security pki generate-certificate-request	1580
	request security pki generate-key-pair	1582
	request security pki local-certificate enroll	1583
	request security pki local-certificate generate-self-signed	1585
	request security pki local-certificate load	1586
	request security pki local-certificate verify	1587
	request ipsec switch	1588
	request services ipsec-vpn ipsec switch tunnel	1589
	show security keychain	1590
	request system certificate add	1593
	show ike security-associations	1594
	show ipsec certificates	1598
	show ipsec redundancy	1601
	show ipsec security-associations	1603
	show security pki ca-certificate	1606
	show security pki certificate-request	1610
	show security pki crl	1612
	show security pki local-certificate	1614
	show services ipsec-vpn certificates	1617
	show services ipsec-vpn ike security-associations	1620

	show services ipsec-vpn ipsec security-associations	1624
	show services ipsec-vpn ipsec statistics	1627
	show system certificate	1630
Chapter 27	Layer 2 Tunneling Protocol Operational Mode Commands	1633
	clear services l2tp destination	1635
	clear services l2tp multilink	1636
	clear services l2tp session	1637
	clear services l2tp session statistics	1639
	clear services l2tp tunnel	1641
	clear services l2tp tunnel statistics	1643
	show services l2tp destination	1645
	show services l2tp multilink	1648
	show services l2tp radius	1651
	show services l2tp session	1655
	show services l2tp summary	1661
	show services l2tp tunnel	1663
	show services l2tp user	1667
Chapter 28	Link Services Operational Mode Commands	1671
	show services link-services cpu-usage	1672
Chapter 29	Mobile IP Operational Mode Commands	1677
	clear mobile-ip binding	1678
	show mobile-ip home-agent bindings	1679
	show mobile-ip home-agent overview	1682
	show mobile-ip home-agent traffic	1683
	show mobile-ip home-agent virtual-network	1685
	show mobile-ip wimax release	1687
Chapter 30	Network Address Translation Operational Mode Commands	1689
	show services nat mapping	1690
	show services nat pool	1692
Chapter 31	PGCP Operational Mode Commands for the BGF Feature	1695
	clear services pgcp gates	1697
	clear services pgcp statistics	1698
	show services pgcp active-configuration	1699
	show services pgcp gate	1708
	show services pgcp gates	1716
	show services pgcp root-termination	1722
	show services pgcp statistics	1724
	show services pgcp conversations	1731
	show services pgcp flows	1736
	show services pgcp terminations	1741
Chapter 32	PTSP Operational Mode Commands	1747
	clear services subscriber sessions	1748
	show services subscriber bandwidth	1749
	show services subscriber dynamic-policies	1751
	show services subscriber flows	1754

	show services subscriber sessions	1756
	show services subscriber statistics	1758
Chapter 33	Service Sets Operational Mode Commands	1761
	clear services service-sets statistics packet-drops	1763
	clear services service-sets statistics syslog	1764
	show services service-sets cpu-usage	1765
	show services service-sets memory-usage	1767
	show services service-sets plug-ins	1769
	show services service-sets statistics packet-drops	1771
	show services service-sets statistics syslog	1773
	show services service-sets statistics tcp-mss	1776
	show services service-sets summary	1777
Chapter 34	Softwire Operational Mode Commands	1779
	clear services softwire statistics	1780
	show services softwire	1781
Chapter 35	Stateful Firewall Operational Mode Commands	1783
	clear services stateful-firewall flows	1785
	clear services stateful-firewall sip-call	1787
	clear services stateful-firewall sip-register	1790
	clear services stateful-firewall statistics	1793
	show services stateful-firewall conversations	1794
	show services stateful-firewall flows	1798
	show services stateful-firewall sip-call	1803
	show services stateful-firewall sip-register	1808
	show services stateful-firewall statistics	1812
	show services stateful-firewall statistics application-protocol sip	1816
Part 5	Index	
	Index	1821
	Index of Statements and Commands	1843

About This Guide

This preface provides the following guidelines for using the *Junos OS System Basics and Services Command Reference*:

- Junos OS Documentation and Release Notes on page xxiii
- Objectives on page xxiii
- Audience on page xxiv
- Supported Platforms on page xxv
- Using the Indexes on page xxv
- Documentation Conventions on page xxv
- Documentation Feedback on page xxvii
- Requesting Technical Support on page xxvii

Junos OS Documentation and Release Notes

For a list of related Junos OS documentation, see <http://www.juniper.net/techpubs/software/junos/>.

If the information in the latest release notes differs from the information in the documentation, follow the *Junos OS Release Notes*.

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

Juniper Networks supports a technical book program to publish books by Juniper Networks engineers and subject matter experts with book publishers around the world. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration using the Junos operating system (Junos OS) and Juniper Networks devices. In addition, the Juniper Networks Technical Library, published in conjunction with O'Reilly Media, explores improving network security, reliability, and availability using Junos OS configuration techniques. All the books are for sale at technical bookstores and book outlets around the world. The current list can be viewed at <http://www.juniper.net/books>.

Objectives

This guide provides descriptions of the Junos OS commands that you use to monitor and troubleshoot basic system operations and services on the router.

For additional commands, see these references:

- *Junos OS Routing Protocols and Policies Command Reference*
- *Junos OS Interfaces Command Reference*



NOTE: For additional information about the Junos OS—either corrections to or information that might have been omitted from this guide—see the software release notes at <http://www.juniper.net/>.

For information about configuration statements and guidelines related to the commands described in this reference, see the following configuration guides:

- *Junos OS CLI User Guide*—Describes how to use the Junos OS command-line interface (CLI) to configure, monitor, and manage Juniper Networks routers.
- *Junos OS Installation and Upgrade Guide*—Provides a description of Junos OS components and packaging, and includes detailed information about how to initially configure, reinstall, and upgrade the Junos system software.
- *Junos OS System Basics Configuration Guide*—Describes Juniper Networks routers, and provides information about how to configure basic system parameters, supported protocols and software processes, authentication, and a variety of utilities for managing your router on the network.
- *Junos OS Services Interfaces Configuration Guide*—Includes configuration statements and guidelines for real-time performance monitoring (RPM) and all services, such as Compressed Real-Time Transport Protocol (CRTP), Data Link Switching (DLSw), flow collection and monitoring, and stateful firewall filters.
- *Junos OS Class of Service Configuration Guide*—Includes configuration statements and guidelines for class of service (CoS) features.
- *Junos OS Network Interfaces Configuration Guide*—Includes configuration statements and guidelines for bit error rate test (BERT) parameters and Automatic Protection Switching (APS).
- *Junos OS Network Management Configuration Guide*—Includes configuration statements and guidelines for accounting parameters and the Simple Network Management Protocol (SNMP).

For information about related tasks performed by network operations center (NOC) personnel, see the following Network Operations Guides:

- *Junos Hardware Network Operations Guide*
- *Junos Baseline Network Operations Guide*

Audience

This guide is designed for network administrators who are configuring and monitoring a Juniper Networks M Series, MX Series, T Series, EX Series, or J Series router or switch.

To use this guide, you need a broad understanding of networks in general, the Internet in particular, networking principles, and network configuration. You must also be familiar with one or more of the following Internet routing protocols:

- Border Gateway Protocol (BGP)
- Distance Vector Multicast Routing Protocol (DVMRP)
- Intermediate System-to-Intermediate System (IS-IS)
- Internet Control Message Protocol (ICMP) router discovery
- Internet Group Management Protocol (IGMP)
- Multiprotocol Label Switching (MPLS)
- Open Shortest Path First (OSPF)
- Protocol-Independent Multicast (PIM)
- Resource Reservation Protocol (RSVP)
- Routing Information Protocol (RIP)
- Simple Network Management Protocol (SNMP)

Personnel operating the equipment must be trained and competent; must not conduct themselves in a careless, willfully negligent, or hostile manner; and must abide by the instructions provided by the documentation.

Supported Platforms

For the features described in this manual, the Junos OS currently supports the following platforms:

- J Series
- M Series
- MX Series
- T Series
- EX Series

Using the Indexes

This reference contains two indexes: a standard index with topic entries, and an index of commands.

Documentation Conventions

Table 1 on page xxvi defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2 on page xxvi defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: <code>user@host> configure</code>
Fixed-width text like this	Represents output that appears on the terminal screen.	<code>user@host> show chassis alarms</code> <code>No alarms currently active</code>
<i>Italic text like this</i>	<ul style="list-style-type: none"> Introduces important new terms. Identifies book names. Identifies RFC and Internet draft titles. 	<ul style="list-style-type: none"> A policy <i>term</i> is a named structure that defines match conditions and actions. <i>Junos OS System Basics Configuration Guide</i> RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] <code>root@# set system domain-name domain-name</code>
Text like this	Represents names of configuration statements, commands, files, and directories; interface names; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> To configure a stub area, include the stub statement at the [edit protocols ospf area area-id] hierarchy level. The console port is labeled CONSOLE.
< > (angle brackets)	Enclose optional keywords or variables.	<code>stub <default-metric metric>;</code>

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Enclose a variable for which you can substitute one or more values.	community name members [community-ids]
Indentation and braces ({ })	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
J-Web GUI Conventions		
Bold text like this	Represents J-Web graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> In the Logical Interfaces box, select All Interfaces. To cancel the configuration, click Cancel.
> (bold right angle bracket)	Separates levels in a hierarchy of J-Web selections.	In the configuration editor hierarchy, select Protocols>Ospf .

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract,

or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf> .
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/> .
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum: <http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/> .
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html> .

PART 1

Monitoring and Testing Tools

- Connectivity Operational Mode Commands on page 3
- Interface Diagnostics Operational Mode Commands on page 33
- RADIUS Diagnostics Operational Mode Commands on page 53
- Real-Time Performance Monitoring Operational Mode Commands on page 61
- Real-Time Router Monitoring Operational Mode Commands on page 77

CHAPTER 1

Connectivity Operational Mode Commands

Table 3 on page 3 summarizes the command-line interface (CLI) commands you can use to perform and monitor connectivity functions. Commands are listed in alphabetical order.

Table 3: Connectivity Operational Mode Commands

Task	Command
Check host reachability and network connectivity.	ping
Check the reachability of a remote Asynchronous Transfer Mode (ATM) node.	ping atm
Check the operability of a remote Connectionless Network Service (CLNS) node.	ping clns
Check the operability of a Layer 2 circuit.	ping mpls l2circuit
Check the operability of a Layer 2 virtual private network (VPN).	ping mpls l2vpn
Check the operability of a Layer 3 VPN.	ping mpls l3vpn
Check the operability of a MPLS connection.	ping mpls ldp
Check the operability of MPLS label-switched path (LSP) endpoint connections.	ping mpls lsp-end-point
Check the operability of MPLS RSVP-signaled LSP connections.	ping mpls rsvp
Check the operability of virtual private LAN service (VPLS) connections.	ping vpls instance



NOTE: For information about related tasks performed by network operations center (NOC) personnel, see the *Junos Baseline Network Operations Guide*.

ping

Syntax `ping host`
 `<bypass-routing>`
 `<count requests>`
 `<detail>`
 `<do-not-fragment>`
 `<inet | inet6>`
 `<interface source-interface>`
 `<interval seconds>`
 `<logical-system (all | logical-system-name)>`
 `<loose-source value>`
 `<no-resolve>`
 `<pattern string>`
 `<rapid>`
 `<record-route>`
 `<routing-instance routing-instance-name>`
 `<size bytes>`
 `<source source-address>`
 `<strict >`
 `<strict-source value.>`
 `<tos type-of-service>`
 `<ttl value>`
 `<verbose>`
 `<wait seconds>`

Syntax (QFX Series) `ping host`
 `<bypass-routing>`
 `<count requests>`
 `<detail>`
 `<do-not-fragment>`
 `<inet>`
 `<interface source-interface>`
 `<interval seconds>`
 `<loose-source value>`
 `<mac-address mac-address>`
 `<no-resolve>`
 `<pattern string>`
 `<rapid>`
 `<record-route>`
 `<routing-instance routing-instance-name>`
 `<size bytes>`
 `<source source-address>`
 `<strict>`
 `< strict-source value>`
 `<tos type-of-service>`
 `<ttl value>`
 `<verbose>`
 `<vpls instance>>`
 `<wait seconds>`

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 Command introduced in Junos OS Release 11.1 for the QFX Series.

Description Check host reachability and network connectivity. The **ping** command sends Internet Control Message Protocol (ICMP) ECHO_REQUEST messages to elicit ICMP ECHO_RESPONSE messages from the specified host. Type Ctrl+c to interrupt a ping command.

Options *host*—IP address or hostname of the remote system to ping.

bypass-routing—(Optional) Bypass the normal routing tables and send ping requests directly to a system on an attached network. If the system is not on a directly attached network, an error is returned. Use this option to ping a local system through an interface that has no route through it.

count requests—(Optional) Number of ping requests to send. The range of values is 1 through 2,000,000,000. The default value is an unlimited number of requests.

detail—(Optional) Include in the output the interface on which the ping reply was received.

do-not-fragment—(Optional) Set the do-not-fragment (DF) flag in the IP header of the ping packets. For IPv6 packets, this option disables fragmentation.



NOTE: In Junos OS Release 11.1 and later, when issuing the **ping** command for an IPv6 route with the **do-not-fragment** option, the maximum ping packet size is calculated by subtracting 48 bytes (40 bytes for the IPV6 header and 8 bytes for the ICMP header) from the MTU. Therefore, if the ping packet size (including the 48-byte header) is greater than the MTU, the ping operation might fail.

inet—(Optional) Ping Packet Forwarding Engine IPv4 routes.

inet6—(Optional) Ping Packet Forwarding Engine IPv6 routes.

interface source-interface—(Optional) Interface to use to send the ping requests.

interval seconds—(Optional) How often to send ping requests. The range of values, in seconds, is 1 through infinity. The default value is 1.

loose-source value—(Optional) Intermediate loose source route entry (IPv4). Open a set of values.

mac-address mac-address—(Optional) Ping the physical or hardware address of the remote system you are trying to reach.

no-resolve—(Optional) Do not attempt to determine the hostname that corresponds to the IP address.

pattern string—(Optional) Specify a hexadecimal fill pattern to include in the ping packet.

rapid—(Optional) Send ping requests rapidly. The results are reported in a single message, not in individual messages for each ping request. By default, five ping requests are

sent before the results are reported. To change the number of requests, include the count option.

record-route—(Optional) Record and report the packet's path (IPv4).

routing-instance *routing-instance-name*—(Optional) Name of the routing instance for the ping attempt.

size *bytes*—(Optional) Size of ping request packets. The range of values, in bytes, is 0 through 65,468. The default value is 56, which is effectively 64 bytes because 8 bytes of ICMP header data are added to the packet.

source *source-address*—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface (lo.0).

strict—(Optional) Use the strict source route option (IPv4).

strict-source *value*—(Optional) Intermediate strict source route entry (IPv4). Open a set of values.

tos *type-of-service*—(Optional) Set the type-of-service (ToS) field in the IP header of the ping packets. The range of values is 0 through 255.

ttl *value*—(Optional) Time-to-live (TTL) value to include in the ping request (IPv6). The range of values is 0 through 255.

verbose—(Optional) Display detailed output.

vpls *instance-name*—(Optional) Ping the instance to which this VPLS belongs.

wait *seconds*—(Optional) Delay, in seconds, after sending the last packet. If this option is not specified, the default delay is 10 seconds. If this option is used without the count option, a default count of 5 packets is used.

Required Privilege Level

network

Related Documentation

- Configuring the Junos OS ICMPv4 Rate Limit for ICMPv4 Routing Engine Messages

List of Sample Output

ping hostname on page 7
ping hostname size count on page 7
ping hostname rapid on page 7

Output Fields

When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code. These packets are not counted in the received packets count. They are accounted for separately.

Sample Output

```

ping hostname user@host> ping skye
PING skye.net (192.168.169.254): 56 data bytes
64 bytes from 192.168.169.254: icmp_seq=0 ttl=253 time=1.028 ms
64 bytes from 192.168.169.254: icmp_seq=1 ttl=253 time=1.053 ms
64 bytes from 192.168.169.254: icmp_seq=2 ttl=253 time=1.025 ms
64 bytes from 192.168.169.254: icmp_seq=3 ttl=253 time=1.098 ms
64 bytes from 192.168.169.254: icmp_seq=4 ttl=253 time=1.032 ms
64 bytes from 192.168.169.254: icmp_seq=5 ttl=253 time=1.044 ms
^C [abort]

ping hostname user@host> ping skye size 200 count 5
size count PING skye.net (192.168.169.254): 200 data bytes
208 bytes from 192.168.169.254: icmp_seq=0 ttl=253 time=1.759 ms
208 bytes from 192.168.169.254: icmp_seq=1 ttl=253 time=2.075 ms
208 bytes from 192.168.169.254: icmp_seq=2 ttl=253 time=1.843 ms
208 bytes from 192.168.169.254: icmp_seq=3 ttl=253 time=1.803 ms
208 bytes from 192.168.169.254: icmp_seq=4 ttl=253 time=17.898 ms

--- skye.net ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 1.759/5.075/17.898 ms

ping hostname rapid user@host> ping skye rapid
PING skye.net (192.168.169.254): 56 data bytes
!!!!
--- skye.net ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max/stddev = 0.956/0.974/1.025/0.026 ms

```

ping atm

Syntax	<code>ping atm interface <i>interface-name</i> vci <i>vci</i></code> <code><brief></code> <code><count <i>count</i>></code> <code><end-to-end segment></code> <code><interval <i>seconds</i>></code> <code><sequence-number <i>sequence-number</i>></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Check the reachability of a remote Asynchronous Transfer Mode (ATM) node. All packets are 53 bytes. Type Ctrl+c to interrupt a ping atm command.
Options	<p><code>interface <i>interface-name</i></code>—Interface to use to send the ATM ping requests. For ATM 1 and ATM 2 interfaces, you must include a logical unit number in the interface name</p> <p><code>vci <i>vci</i></code>—ATM point-to-point virtual circuit identifier. It can be a virtual circuit identifier (vci) or a virtual private identifier (vpi.vci).</p> <p><code>brief</code>—(Optional) Display only the ATM ping summary statistics. These are displayed after you type Ctrl+c to interrupt the ping atm command.</p> <p><code>count <i>count</i></code>—(Optional) Number of ping requests to send. The range of values is 0 through 10,000. The default value is an unlimited number of requests.</p> <p><code>end-to-end</code>—(Optional) Cells are sent to the end node. This is the default.</p> <p><code>segment</code>—(Optional) Cells are sent only to the intermediate node.</p> <p><code>interval <i>seconds</i></code>—(Optional) How often to send ping requests. The range of values, in seconds, is 1 through 10,000. The default value is 1.</p> <p><code>sequence-number <i>sequence-number</i></code>—(Optional) Starting sequence number (correlation tag). The range of values is 0 through 65,468. The default value is 1.</p>
Required Privilege Level	network
List of Sample Output	ping atm on page 9
Output Fields	When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.

Sample Output

```
ping atm    user@host> ping atm interface at-4/0/1.0 vci 0.33
53 byte oam cell received on (vpi=0 vci=33): seq=1
53 byte oam cell received on (vpi=0 vci=33): seq=2
^C[abort]
--- atmping statistics ---
5 cells transmitted, 5 cells received, 0% cell loss
```

ping clns

Syntax `ping clns host`
 `<brief>`
 `<count requests>`
 `<detail>`
 `<do-not-fragment>`
 `<interval seconds>`
 `<no-resolve>`
 `<pattern string>`
 `<rapid>`
 `<routing-instance routing-instance-name>`
 `<size bytes>`
 `<source source-address>`
 `<ttl value>`
 `<verbose>`
 `<wait seconds>`

Release Information Command introduced before Junos OS Release 7.4.

Description Check the reachability of a remote Connectionless Network Service (CLNS) node. Type Ctrl+c to interrupt a **ping clns** command.

Options *host*—IP address or hostname of the remote system to ping.

brief—(Optional) Display brief information.

count requests—(Optional) Number of ping requests to send. The range of values is 1 through 2,000,000,000. The default is an unlimited number of requests.

detail—(Optional) Include in the output the interface on which the ping reply was received.

do-not-fragment—(Optional) Set the do-not-fragment (DF) bit in the IP header of the ping packets.

interval seconds—(Optional) How often to send ping requests. The range of values, in seconds, is 1 through infinity. The default value is 1.

no-resolve—(Optional) Do not attempt to determine the hostname that corresponds to the IP address.

pattern string—(Optional) Specify a hexadecimal fill pattern to include in the ping packet.

rapid—(Optional) Send ping requests rapidly. The results are reported in a single message, not in individual messages for each ping request. By default, five ping requests are sent before the results are reported. To change the number of request, include the *count* option.

routing-instance routing-instance-name —(Optional) Name of the routing instance for the ping attempt.

size bytes—(Optional) Size of ping request packets. The range of values, in bytes, is **0** through **65,468**. The default value is **56**, which is effectively 64 bytes because 8 bytes of ICMP header data are added to the packet.

source source-address—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface.

ttl value—(Optional) Time-to-live (TTL) value to include in the ping request (IPv6). The range of values is **0** through **255**.

verbose—(Optional) Display detailed output.

wait seconds—(Optional) Delay, in seconds, after sending the last packet. If this option is not specified, the default delay is **10** seconds. If this option is used without the count option, a default count of **5** packets is used.

Required Privilege Level network

List of Sample Output ping clns on page 11

Output Fields When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.

Sample Output

```
ping clns user@host> ping clns 47.0005.9000.f800.0000.0108.0001.1921.6812.4058.00
PING 47.0005.9000.f800.0000.0108.0001.1921.6812.4058.00
(47.0005.9000.f800.0000.0108.0001.1921.6812.4058.00): 55 data bytes
64 bytes from 47.0005.9000.f800.0000.0108.0001.1921.6812.4058.00: seq=0 ttl=30
time=15.051 ms
64 bytes from 47.0005.9000.f800.0000.0108.0001.1921.6812.4058.00: seq=1 ttl=30
time=10.370 ms
64 bytes from 47.0005.9000.f800.0000.0108.0001.1921.6812.4058.00: seq=2 ttl=30
time=10.367 ms
--- ping statistics ---
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max/stddev = 10.367/11.929/15.051/2.207 ms
```

ping mpls l2circuit

Syntax ping mpls l2circuit (interface *interface-name* | virtual-circuit *virtual-circuit-id* neighbor *address*)
 <count *count*>
 <destination *address*>
 <detail>
 <exp *forwarding-class*>
 <logical-system (all | *logical-system-name*)>
 reply-mode (application-level-control-channel | ip-udp | no-reply)
 <size *bytes*>
 <source *source-address*>
 <sweep>
 <v1>

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 The **size** and **sweep** options were introduced in Junos OS Release 9.6.
 The **reply-mode** option and its suboptions are introduced in Junos OS Release 10.4R1.

Description Check the operability of the MPLS Layer 2 circuit connections. Type Ctrl+c to interrupt a ping mpls l2circuit command.

Options count *count*—(Optional) Number of ping requests to send. If **count** is not specified, five ping requests are sent. The range of values is 1 through 1,000,000. The default value is 5.

destination *address*—(Optional) Specify an address other than the default (127.0.0.1/32) for the ping echo requests. The address can be anything within the 127/8 subnet.

detail—(Optional) Display detailed information about the echo requests sent and received.

exp *forwarding-class*—(Optional) Value of the forwarding class for the MPLS ping packets.

interface *interface-name*—Ping an interface configured for the Layer 2 circuit on the egress provider edge (PE) router.

logical-system (all | *logical-system-name*)—(Optional) Perform this operation on all logical systems or on the specified logical system.

reply-mode—(Optional) Reply mode for the ping request. This option has the following suboptions:

application-level-control-channel—Reply using an application level control channel.

ip-udp—Reply using an IPv4 or IPv6 UDP packet.

no-reply—Do not reply to the ping request.



NOTE: The reply-mode option and its suboptions application-level-control-channel, ip-udp, and no-reply are also available in Junos OS Release 10.2R4 and 10.3R2.

size bytes—(Optional) Size of the label-switched path (LSP) ping request packet (96 through 65468 bytes). Packets are 4-byte aligned. For example, If you enter a size of 97, 98, 99, or 100, the router or switch uses a size value of 100 bytes. If you enter a packet size that is smaller than the minimum size, an error message is displayed reminding you of the 96-byte minimum.

source source-address—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface (**lo.0**).

sweep—(Optional) Automatically determine the size of the maximum transmission unit (MTU).

vl—(Optional) Use the type 9 Layer 2 circuit type, length, and value (TLV).

virtual-circuit virtual-circuit-id neighbor address—Ping the virtual circuit identifier on the egress PE router or switch and the specified neighbor, testing the integrity of the Layer 2 circuit between the ingress and egress PE routers or switches.

Additional Information You must configure MPLS at the **[edit protocols mpls]** hierarchy level on the egress PE router or switch (the router or switch receiving the MPLS echo packets) to ping a Layer 2 circuit.

In asymmetric MTU scenarios, the echo response may be dropped. For example, if the MTU from System A to System B is 1000 bytes, the MTU from System B to System A is 500 bytes, and the ping request packet size is 1000 bytes, the echo response is dropped because the PAD TLV is included in the echo response, making it too large.

Required Privilege Level network

List of Sample Output [ping mpls l2circuit interface on page 13](#)
[ping mpls l2circuit virtual-circuit detail on page 13](#)
[ping mpls l2circuit interface <interface-name> reply-mode on page 14](#)

Output Fields When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code. Packets with an error code are not counted in the received packets count. They are accounted for separately.

Sample Output

ping mpls l2circuit interface user@host> ping mpls l2circuit interface so-1/0/0.1
 Request for seq 1, to interface 69, labels <100000, 100208>, packet size 100
 Reply for seq 1, return code: Egress-ok, time: 0.439 ms

ping mpls l2circuit virtual-circuit detail user@host> ping mpls l2circuit virtual-circuit 200 neighbor 10.255.245.122/32 detail
 Request for seq 1, to interface 68, labels <100048, 100128>, packet size 100
 Reply for seq 1, return code: Egress-ok time: 0.539 ms

ping mpls l2circuit	user@host> ping mpls l2circuit interface lt-1/2/0.21 reply-mode application-level-control-channel
interface	!!!!
<interface-name>	--- 1sping statistics ---
reply-mode	5 packets transmitted, 5 packets received, 0% packet loss

ping mpls l2vpn

Syntax	<p>ping mpls l2vpn (instance <i>instance-name</i> local-site-id <i>local-site-id-number</i> remote-site-id <i>remote-site-id-number</i> interface <i>interface-name</i>)</p> <p><bottom-label-ttl></p> <p><count <i>count</i>></p> <p><destination <i>address</i>></p> <p><detail></p> <p><exp <i>forwarding-class</i>></p> <p><logical-system (all <i>logical-system-name</i>)></p> <p>reply-mode (application-level-control-channel ip-udp no-reply)</p> <p><size <i>bytes</i>></p> <p><source <i>source-address</i>></p> <p><sweep></p>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>The size and sweep options were introduced in Junos OS Release 9.6.</p> <p>The reply-mode option and its suboptions are introduced in Junos OS Release 10.4R1.</p>
Description	<p>Check the operability of MPLS Layer 2 virtual private network (VPN) connections. Type Ctrl+c to interrupt a ping mpls l2vpn command.</p>
Options	<p>bottom-label-ttl—(Optional) Display the time-to-live value for the bottom label in the label stack.</p> <p>count <i>count</i>—(Optional) Number of ping requests to send. If count is not specified, five ping requests are sent. The range of values is 1 through 1,000,000. The default value is 5.</p> <p>destination <i>address</i>—(Optional) Specify an address other than the default (127.0.0.1/32) for the ping echo requests. The address can be anything within the 127/8 subnet.</p> <p>detail—(Optional) Display detailed information about the echo requests sent and received.</p> <p>exp <i>forwarding-class</i>—(Optional) Value of the forwarding class for the MPLS ping packets.</p> <p>instance <i>instance-name</i> local-site-id <i>local-site-id-number</i> remote-site-id <i>remote-site-id-number</i>—Ping a combination of the Layer 2 VPN routing instance name, the local site identifier, and the remote site identifier, testing the integrity of the Layer 2 VPN circuit (specified by the identifiers) between the ingress and egress provider edge (PE) routers or switches.</p> <p>interface <i>interface-name</i>—Ping an interface configured for the Layer 2 VPN on the egress PE router or switch.</p> <p>logical-system (all <i>logical-system-name</i>)—(Optional) Perform this operation on all logical systems or on the specified logical system.</p> <p>reply-mode—(Optional) Reply mode for the ping request. This option has the following suboptions:</p> <p>application-level-control-channel—Reply using an application level control channel.</p>

ip-udp—Reply using an IPv4 or IPv6 UDP packet.

no-reply—Do not reply to the ping request.

The **reply-mode** option and its suboptions **application-level-control-channel**, **ip-udp**, and **no-reply** are also available in Junos OS Release 10.2R4 and 10.3R2.

size bytes—(Optional) Size of the label-switched path (LSP) ping request packet (96 through 65468 bytes). Packets are 4-byte aligned. For example, If you enter a size of 97, 98, 99, or 100, the router or switch uses a size value of 100 bytes. If you enter a packet size that is smaller than the minimum size, an error message is displayed reminding you of the 96-byte minimum.

source source-address—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface (**lo.0**).

sweep—(Optional) Automatically determine the size of the maximum transmission unit (MTU).

Additional Information You must configure MPLS at the **[edit protocols mpls]** hierarchy level on the egress PE router or switch (the router or switch receiving the MPLS echo packets) to ping a Layer 2 circuit.

In asymmetric MTU scenarios, the echo response may be dropped. For example, if the MTU from System A to System B is 1000 bytes, the MTU from System B to System A is 500 bytes, and the ping request packet size is 1000 bytes, the echo response is dropped because the PAD TLV is included in the echo response, making it too large.

Required Privilege Level

network

List of Sample Output

ping mpls l2vpn instance on page 16
ping mpls l2vpn instance detail on page 16
ping mpls l2vpn interface <interface-name> reply-mode on page 17

Output Fields

When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.

Sample Output

ping mpls l2vpn instance

```
user@host> ping mpls l2vpn instance vpn1 remote-site-id 1 local-site-id 2
!!!!
--- lsping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
```

ping mpls l2vpn instance detail

```
user@host> ping mpls l2vpn instance vpn1 remote-site-id 1 local-site-id 2 detail
Request for seq 1, to interface 68, labels <800001, 100176>
Reply for seq 1, return code: Egress-ok
Request for seq 2, to interface 68, labels <800001, 100176>
```



```
Reply for seq 2, return code: Egress-ok
Request for seq 3, to interface 68, labels <800001, 100176>
Reply for seq 3, return code: Egress-ok
Request for seq 4, to interface 68, labels <800001, 100176>
Reply for seq 4, return code: Egress-ok
Request for seq 5, to interface 68, labels <800001, 100176>
Reply for seq 5, return code: Egress-ok
```

```
--- lsping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
```

```
ping mpls l2vpn user@host> ping mpls l2vpn interface lt-1/2/0.21 reply-mode ip-udp
interface !!!!!
<interface-name> --- lsping statistics ---
reply-mode 5 packets transmitted, 5 packets received, 0% packet loss
```

ping mpls l3vpn

Syntax	<pre>ping mpls l3vpn prefix <i>prefix-name</i> <l3vpn-name> <bottom-label-ttl> <count <i>count</i>> <destination <i>address</i>> <detail> <exp <i>forwarding-class</i>> <logical-system (all <i>logical-system-name</i>)> <size <i>bytes</i>> <source <i>source-address</i>> <sweep></pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>The size and sweep options were introduced in Junos OS Release 9.6.</p>
Description	<p>Check the operability of a MPLS Layer 3 virtual private network (VPN) connection. Type Ctrl+c to interrupt a ping mpls l3vpn command.</p>
Options	<p>bottom-label-ttl—(Optional) Display the time-to-live value for the bottom label in the label stack.</p> <p>count <i>count</i>—(Optional) Number of ping requests to send. If count is not specified, five ping requests are sent. The range of values is 1 through 1,000,000. The default value is 5.</p> <p>destination <i>address</i>—(Optional) Specify an address other than the default (127.0.0.1/32) for the ping echo requests. The address can be anything within the 127/8 subnet.</p> <p>detail—(Optional) Display detailed information about the echo requests sent and received.</p> <p>exp <i>forwarding-class</i>—(Optional) Value of the forwarding class for the MPLS ping packets.</p> <p>l3vpn-name—(Optional) Layer 3 VPN name.</p> <p>logical-system (all <i>logical-system-name</i>)—(Optional) Perform this operation on all logical systems or on the specified logical system.</p> <p>prefix <i>prefix-name</i>—Ping to test whether a prefix is present in a provider edge (PE) router's or switch's VPN routing and forwarding (VRF) table, by means of a Layer 3 VPN destination prefix. This option does not test the connection between a PE router or switch and a customer edge (CE) router or switch.</p> <p>size <i>bytes</i>—(Optional) Size of the label-switched path (LSP) ping request packet (96 through 65468 bytes). Packets are 4-byte aligned. For example, If you enter a size of 97, 98, 99, or 100, the router or switch uses a size value of 100 bytes. If you enter a packet size that is smaller than the minimum size, an error message is displayed reminding you of the 96-byte minimum.</p>

source source-address—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface (**lo.0**).

sweep—(Optional) Automatically determine the size of the maximum transmission unit (MTU).

Additional Information	<p>You must configure MPLS at the [edit protocols mpls] hierarchy level on the egress PE router or switch (the router or switch receiving the MPLS echo packets) to ping a Layer 2 circuit.</p> <p>In asymmetric MTU scenarios, the echo response may be dropped. For example, if the MTU from System A to System B is 1000 bytes, the MTU from System B to System A is 500 bytes, and the ping request packet size is 1000 bytes, the echo response is dropped because the PAD TLV is included in the echo response, making it too large.</p>
Required Privilege Level	network
List of Sample Output	<p>ping mpls l3vpn on page 19</p> <p>ping mpls l3vpn detail on page 19</p>
Output Fields	<p>When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.</p>

Sample Output

ping mpls l3vpn	<pre>user@host> ping mpls l3vpn vpn1 prefix 10.255.245.122/32 !!!! --- lsping statistics --- 5 packets transmitted, 5 packets received, 0% packet loss</pre>
ping mpls l3vpn detail	<pre>user@host> ping mpls l3vpn vpn1 prefix 10.255.245.122/32 detail Request for seq 1, to interface 68, labels <100128, 100112> Reply for seq 1, return code: Egress-ok Request for seq 2, to interface 68, labels <100128, 100112> Reply for seq 2, return code: Egress-ok Request for seq 3, to interface 68, labels <100128, 100112> Reply for seq 3, return code: Egress-ok Request for seq 4, to interface 68, labels <100128, 100112> Reply for seq 4, return code: Egress-ok Request for seq 5, to interface 68, labels <100128, 100112> Reply for seq 5, return code: Egress-ok --- lsping statistics --- 5 packets transmitted, 5 packets received, 0% packet loss</pre>

ping mpls ldp

Syntax ping mpls ldp *fec*
 <count *count*>
 <destination *address*>
 <detail>
 <exp *forwarding-class*>
 <instance *routing-instance-name*>
 <logical-system (all | *logical-system-name*)>
 <p2mp root-addr *ip-address* lsp-id *identifier*>
 <size *bytes*>
 <source *source-address*>
 <sweep>

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 size and **sweep** options introduced in Junos OS Release 9.6.
 instance option introduced in Junos OS Release 10.0.
 p2mp, **root-address**, and **lsp-id** options introduced in Junos OS Release 11.2.

Description Check the operability of MPLS LDP-signaled label-switched path (LSP) connections.
 Type Ctrl+c to interrupt a **ping mpls** command.

Options count *count*—(Optional) Number of ping requests to send. If **count** is not specified, five ping requests are sent. The range of values is 1 through **1,000,000**. The default value is **5**.

 destination *address*—(Optional) Specify an address other than the default (**127.0.0.1/32**) for the ping echo requests. The address can be anything within the **127/8** subnet.

 detail—(Optional) Display detailed information about the echo requests sent and received.

 exp *forwarding-class*—(Optional) Value of the forwarding class for the MPLS ping packets.

fec—Ping an LDP-signaled LSP using the forwarding equivalence class (FEC) prefix and length.

 instance *routing-instance-name*—(Optional) Allows you to ping a combination of the routing instance and forwarding equivalence class (FEC) associated with an LSP.

 logical-system (all | *logical-system-name*)—(Optional) Perform this operation on all logical systems or on the specified logical system.

 p2mp root-addr *ip-address* lsp-id *identifier*—(Optional) Ping the end points of a point-to-multipoint LSP. Enter the IP address of the point-to-multipoint LSP root and the ID number of the point-to-multipoint LSP.

 size *bytes*—(Optional) Size of the LSP ping request packet (**88** through **65468** bytes). Packets are 4-byte aligned. For example, If you enter a size of 89, 90, 91, or 92, the router or switch uses a size value of 92 bytes. If you enter a packet size that is smaller than the minimum size, an error message is displayed reminding you of the 88-byte minimum.

source *source-address*—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface (**lo.0**).

sweep—(Optional) Automatically determine the size of the maximum transmission unit (MTU).

Additional Information If the LSP changes, the label and interface information displayed when you issued the **ping** command continues to be used. You must configure MPLS at the **[edit protocols mpls]** hierarchy level on the remote router or switch to ping an LSP terminating there. You must configure MPLS even if you intend to ping only LDP forwarding equivalence classes (FECs).

You can configure the ping interval for the **ping mpls ldp** command by specifying a new time in seconds using the **lsp-ping-interval** statement at the **[edit protocols ldp oam]** hierarchy level. For more information, see the [Junos OS MPLS Applications Configuration Guide](#).

In asymmetric MTU scenarios, the echo response may be dropped. For example, if the MTU from System A to System B is 1000 bytes, the MTU from System B to System A is 500 bytes, and the ping request packet size is 1000 bytes, the echo response is dropped because the PAD TLV is included in the echo response, making it too large.

Required Privilege Level network

List of Sample Output **ping mpls ldp fec count** on page 21
ping mpls ldp p2mp root-addr lsp-id on page 21

Output Fields When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code. Packets with error codes are not counted in the received packets count. They are accounted for separately.

Sample Output

ping mpls ldp fec count user@host> ping mpls ldp 10.255.245.222 count 10
!!!xxx...x--- lsping statistics ---10 packets transmitted, 3 packets received,
70% packet loss 4 packets received with error status, not counted as received.

ping mpls ldp p2mp root-addr lsp-id user@host> ping mpls ldp p2mp root-addr 10.1.1.1/32 lsp-id 1 count 1
Request for seq 1, to interface 71, no label stack.
Request for seq 1, to interface 70, label 299786
Reply for seq 1, egress 10.1.1.3, return code: Egress-ok, time: 18.936 ms
Local transmit time: 2009-01-12 03:50:03 PST 407.281 ms
Remote receive time: 2009-01-12 03:50:03 PST 426.217 ms
Reply for seq 1, egress 10.1.1.4, return code: Egress-ok, time: 18.936 ms
Local transmit time: 2009-01-12 03:50:03 PST 407.281 ms
Remote receive time: 2009-01-12 03:50:03 PST 426.217 ms
Reply for seq 1, egress 10.1.1.5, return code: Egress-ok, time: 18.936 ms

Local transmit time: 2009-01-12 03:50:03 PST 407.281 ms
Remote receive time: 2009-01-12 03:50:03 PST 426.217 ms

ping mpls lsp-end-point

Syntax	<pre>ping mpls lsp-end-point <i>prefix-name</i> <count <i>count</i>> <destination <i>address</i>> <detail> <exp <i>forwarding-class</i>> <instance <i>routing-instance-name</i>> <logical-system (all <i>logical-system-name</i>)> <size <i>bytes</i>> <source <i>source-address</i>> <sweep></pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>The size and sweep options were introduced in Junos OS Release 9.6.</p> <p>The instance option was introduced in Junos OS Release 10.0.</p>
Description	<p>Check the operability of MPLS label-switched path (LSP) endpoint connections. Type Ctrl+c to interrupt a ping mpls command.</p>
Options	<p>count <i>count</i>—(Optional) Number of ping requests to send. If count is not specified, five ping requests are sent. The range of values is 1 through 1,000,000. The default value is 5.</p> <p>destination <i>address</i>—(Optional) Specify an address other than the default (127.0.0.1/32) for the ping echo requests. The address can be anything within the 127/8 subnet.</p> <p>detail—(Optional) Display detailed information about the echo requests sent and received.</p> <p>exp <i>forwarding-class</i>—(Optional) Value of the forwarding class for the MPLS ping packets.</p> <p>instance <i>routing-instance-name</i>—(Optional) Ping a combination of the routing instance and forwarding equivalence class (FEC) associated with an LSP connection.</p> <p>logical-system (all <i>logical-system-name</i>)—(Optional) Perform this operation on all logical systems or on the specified logical system.</p> <p>prefix-name—LDP forwarding equivalence class (FEC) prefix or RSVP LSP endpoint address.</p> <p>size <i>bytes</i>—(Optional) Size of the LSP ping request packet. If the endpoint is LDP-based, the minimum size of the packet is 88 bytes. If the endpoint is RSVP-based, the minimum size of the packet is 100 bytes. The maximum size in either case is 65468 bytes.</p> <p>source <i>source-address</i>—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface (lo.0).</p> <p>sweep—(Optional) Automatically determine the size of the maximum transmission unit (MTU).</p>

Additional Information	<p>If the LSP changes, the label and interface information displayed when you issued the ping command continues to be used. You must configure MPLS at the [edit protocols mpls] hierarchy level on the remote router or switch to ping an LSP terminating there. You must configure MPLS even if you intend to ping only LDP forwarding equivalence classes (FECs).</p> <p>In asymmetric MTU scenarios, the echo response may be dropped. For example, if the MTU from System A to System B is 1000 bytes, the MTU from System B to System A is 500 bytes, and the ping request packet size is 1000 bytes, the echo response is dropped because the PAD TLV is included in the echo response, making it too large.</p>
Required Privilege Level	network
List of Sample Output	ping mpls lsp-end-point detail on page 24
Output Fields	When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.

Sample Output

ping mpls lsp-end-point detail	<pre>user@host> ping mpls lsp-end-point 10.255.245.119 detail Route to end point address is via LDP FEC Request for seq 1, to interface 67, label 100032 Reply for seq 1, return code: Egress-ok Request for seq 2, to interface 67, label 100032 Reply for seq 2, return code: Egress-ok Request for seq 3, to interface 67, label 100032 Reply for seq 3, return code: Egress-ok Request for seq 4, to interface 67, label 100032 Reply for seq 4, return code: Egress-ok Request for seq 5, to interface 67, label 100032 Reply for seq 5, return code: Egress-ok --- lsping statistics --- 5 packets transmitted, 5 packets received, 0% packet loss</pre>
---	---

ping mpls rsvp

Syntax ping mpls rsvp
 <lsp-name>
 <count count>
 <destination address>
 <detail>
 <dynamic-bypass>
 <egress egress-address>
 <exp forwarding-class>
 <interface interface-name>
 <logical-system (all | logical-system-name)>
 <manual-bypass>
 <multipoint>
 <size bytes>
 <source source-address>
 <standby standby-path-name>
 <sweep>

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 The **egress** and **multipoint** options were introduced in Junos OS Release 9.2.
 The **size** and **sweep** options were introduced in Junos OS Release 9.6.
 The **dynamic-bypass** and **manual-bypass** options were introduced in Junos OS Release 10.2.

Description Check the operability of MPLS RSVP-signaled label-switched path (LSP) connections. Type Ctrl+c to interrupt a **ping mpls** command.

Options count *count*—(Optional) Number of ping requests to send. If **count** is not specified, five ping requests are sent. The range of values is 1 through 1,000,000. The default value is 5.

destination *address*—(Optional) Specify an address other than the default (127.0.0.1/32) for the ping echo requests. The address can be anything within the 127/8 subnet.

detail—(Optional) Display detailed information about the echo requests sent and received.



NOTE: When using the **detail** option, the reported time is based on the system time configured on the local and remote routers. Differences in these system times can result in inaccurate one way ping trip times being reported.

In practice, it is difficult to synchronize the system times of independent Juniper Networks routers with sufficient accuracy to provide a meaningful time value for the **detail** option (even when synchronized using NTP).

dynamic-bypass—(Optional) Ping dynamically generated bypass LSPs, used for protecting other LSPs.

egress egress-address—(Optional) Only the specified egress router or switch responds to the ping request.

exp forwarding-class—(Optional) Value of the forwarding class for the MPLS ping packets.

interface—(Optional) Specify the name of the interface protected by the manual bypass LSP. This option is only available when you have also used the **manual-bypass** option.

logical-system (all | logical-system-name)—(Optional) Perform this operation on all logical systems or on the specified logical system.

lsp-name—Ping an RSVP-signaled LSP using an LSP name.

manual-bypass—(Optional) Ping manually configured bypass LSPs, used for protecting other LSPs. For this option, you must also specify the interface protected by the manual bypass LSP using the **interface** option.

multipoint—(Optional) Send ping requests to each of the egress routers or switches participating in a point-to-multipoint LSP. You can also include the **egress** option to ping a specific egress router or switch participating in a point-to-multipoint LSP.

size bytes—(Optional) Size of the LSP ping request packet (100 through 65468 bytes). Packets are 4-byte aligned. For example, if you enter a size of 101, 102, 103, or 104, the router or switch uses a size value of 104 bytes. If you enter a packet size that is smaller than the minimum size, an error message is displayed reminding you of the 100-byte minimum.

source source-address—(Optional) IP address of the outgoing interface. This address is sent in the IP source address field of the ping request. If this option is not specified, the default address is usually the loopback interface.

standby standby-path-name—(Optional) Name of the standby path.

sweep —(Optional) Automatically determine the size of the maximum transmission unit (MTU).

Additional Information If the LSP changes, the label and interface information displayed when you issued the **ping** command continues to be used. You must configure MPLS at the **[edit protocols mpls]** hierarchy level on the remote router or switch to ping an LSP terminating there. You must configure MPLS even if you intend to ping only LDP forwarding equivalence classes (FECs).

In asymmetric MTU scenarios, the echo response may be dropped. For example, if the MTU from System A to System B is 1000 bytes, the MTU from System B to System A is 500 bytes, and the ping request packet size is 1000 bytes, the echo response is dropped because the PAD TLV is included in the echo response, making it too large.

Required Privilege Level network

List of Sample Output **ping mpls rsvp (Echo Reply Received) on page 27**
ping mpls rsvp (Echo Reply with Error Code) on page 27

ping mpls rsvp detail on page 27
 ping mpls rsvp multipoint egress detail count on page 27
 ping mpls rsvp multipoint detail count on page 27
 ping mpls rsvp destination detail count size on page 28
 ping mpls rsvp destination detail sweep size on page 28

Output Fields When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.

Sample Output

ping mpls rsvp (Echo Reply Received)	<pre> user@host> ping mpls rsvp test1 !!!!!--- lsping statistics ---5 packets transmitted, 5 packets received, 0% packet loss </pre>
ping mpls rsvp (Echo Reply with Error Code)	<pre> user@host> ping mpls rsvp test2 !!xxx--- lsping statistics ---5 packets transmitted, 2 packets received, 60% packet loss3 packets received with error status, not counted as received. </pre>
ping mpls rsvp detail	<pre> user@host> ping mpls rsvp to-green detail Request for seq 1, to interface 67, labels <100095, 0, 0> Reply for seq 1, return code: Egress-ok Request for seq 2, to interface 67, labels <100095, 0, 0> Reply for seq 2, return code: Egress-ok </pre>
ping mpls rsvp multipoint egress detail count	<pre> user@host>ping mpls rsvp sample-lsp multipoint egress 192.168.1.3 detail count 1 Request for seq 1, to interface 70, label 299952 Request for seq 1, to interface 70, no label stack. Request for seq 1, to interface 67, no label stack. Reply for seq 1, egress 192.168.1.3, return code: Egress-ok, time: 0.242 ms Local transmit time: 1205310695s 215737us Remote receive time: 1205310695s 215979us --- lsping, egress 192.168.1.3 statistics --- 1 packets transmitted, 1 packets received, 0% packet loss </pre>
ping mpls rsvp multipoint detail count	<pre> user@host>ping mpls rsvp sample-lsp multipoint detail count 1 Request for seq 1, to interface 70, label 299952 Request for seq 1, to interface 70, no label stack. Request for seq 1, to interface 67, no label stack. Reply for seq 1, return code: Unknown TLV, time: 9.877 ms Local transmit time: 1205310615s 347317us Remote receive time: 1205310615s 357194us Reply for seq 1, egress 192.168.1.3, return code: Egress-ok, time: 0.351 ms Local transmit time: 1205310615s 347262us Remote receive time: 1205310615s 347613us Reply for seq 1, egress 192.168.1.13, return code: Egress-ok, time: 0.301 ms Local transmit time: 1205310615s 347167us Remote receive time: 1205310615s 347468us Timeout for seq 1, egress 192.168.1.1 Timeout for seq 1, egress 192.168.1.4 Timeout for seq 1, egress 192.168.1.14 </pre>

```

--- lsping, egress 192.168.1.1 statistics ---
1 packets transmitted, 0 packets received, 100% packet loss

--- lsping, egress 192.168.1.3 statistics ---
1 packets transmitted, 1 packets received, 0% packet loss

--- lsping, egress 192.168.1.4 statistics ---
1 packets transmitted, 0 packets received, 100% packet loss

--- lsping, egress 192.168.1.13 statistics ---
1 packets transmitted, 1 packets received, 0% packet loss

--- lsping, egress 192.168.1.14 statistics ---
1 packets transmitted, 0 packets received, 100% packet loss

```

ping mpls rsvp destination detail count size

```

user@host> ping mpls rsvp chaser-access destination 192.168.0.1 detail count 1 size 4468

Request for seq 1, to interface 88, label 299984, packet size 4468
Reply for seq 1, return code: Egress-ok, time: 44.804 ms
    Local transmit time: 2009-03-30 22:05:02 CEST 408.629 ms
    Remote receive time: 2009-03-30 22:05:02 CEST 453.433 ms

--- lsping statistics ---
1 packets transmitted, 1 packets received, 0% packet loss

```

ping mpls rsvp destination detail sweep size

```

user@router> ping mpls rsvp chaser-access destination 192.168.0.1 detail sweep size 4500

Request for seq 1, to interface 86, no label stack., packet size 100
Reply for seq 1, return code: Egress-ok, time: -39.264 ms
    Local transmit time: 2009-04-24 14:05:40 CEST 541.423 ms
    Remote receive time: 2009-04-24 14:05:40 CEST 502.159 ms
Request for seq 2, to interface 86, no label stack., packet size 2300
Reply for seq 2, return code: Egress-ok, time: -38.179 ms
    Local transmit time: 2009-04-24 14:05:41 CEST 544.240 ms
    Remote receive time: 2009-04-24 14:05:41 CEST 506.061 ms
Request for seq 3, to interface 86, no label stack., packet size 4500
Timeout for seq 3
Request for seq 4, to interface 86, no label stack., packet size 3400
Reply for seq 4, return code: Egress-ok, time: -37.545 ms
    Local transmit time: 2009-04-24 14:05:45 CEST 549.953 ms
    Remote receive time: 2009-04-24 14:05:45 CEST 512.408 ms
Request for seq 5, to interface 86, no label stack., packet size 3952
Reply for seq 5, return code: Egress-ok, time: -37.176 ms
    Local transmit time: 2009-04-24 14:05:46 CEST 555.881 ms
    Remote receive time: 2009-04-24 14:05:46 CEST 518.705 ms
Request for seq 6, to interface 86, no label stack., packet size 4228
Reply for seq 6, return code: Egress-ok, time: -36.962 ms
    Local transmit time: 2009-04-24 14:05:47 CEST 561.809 ms
    Remote receive time: 2009-04-24 14:05:47 CEST 524.847 ms
Request for seq 7, to interface 86, no label stack., packet size 4368
Reply for seq 7, return code: Egress-ok, time: -36.922 ms
    Local transmit time: 2009-04-24 14:05:48 CEST 568.738 ms
    Remote receive time: 2009-04-24 14:05:48 CEST 531.816 ms
Request for seq 8, to interface 86, no label stack., packet size 4440
Reply for seq 8, return code: Egress-ok, time: -36.855 ms
    Local transmit time: 2009-04-24 14:05:49 CEST 575.669 ms
    Remote receive time: 2009-04-24 14:05:49 CEST 538.814 ms
Request for seq 9, to interface 86, no label stack., packet size 4476
Timeout for seq 9
Request for seq 10, to interface 86, no label stack., packet size 4460
Reply for seq 10, return code: Egress-ok, time: -36.906 ms

```

```
Local transmit time: 2009-04-24 14:05:53 CEST 584.382 ms
Remote receive time: 2009-04-24 14:05:53 CEST 547.476 ms
Request for seq 11, to interface 86, no label stack., packet size 4480
Timeout for seq 11
Request for seq 12, to interface 86, no label stack., packet size 4472
Timeout for seq 12
Request for seq 13, to interface 86, no label stack., packet size 4468
Reply for seq 13, return code: Egress-ok, time: -36.943 ms
Local transmit time: 2009-04-24 14:06:00 CEST 594.884 ms
Remote receive time: 2009-04-24 14:06:00 CEST 557.941 ms
Request for seq 14, to interface 86, no label stack., packet size 4476
Timeout for seq 14
Request for seq 15, to interface 86, no label stack., packet size 4472
Timeout for seq 15

--- lsp ping sweep result---
Maximum Transmission Unit (MTU) is 4468 bytes
```

ping vpls instance

Syntax ping vpls instance *instance-name* destination-mac *address* source-ip *address*
<bd-name *name*>
<control-plane-response>
<count *number*>
<detail>
<learning-vlan-id *number*>
<logical-system *logical-system-name*>

Release Information Command introduced in Junos OS Release 9.1.

Description Check the operability of virtual private LAN service (VPLS) connections. Type Ctrl+c to interrupt a **ping vpls instance** command.

When you issue a **ping vpls instance** command, a chassis MAC address is drawn from the ingress PE router's pool of MAC addresses and used to create the VPLS ping packet. The ping packet is then forwarded to the egress PE router. When the egress PE router receives the ping packet, it learns the MAC address from the VPLS ping packet. The MAC address is added to the egress PE router's MAC table.

The **ping vpls instance** command relies on the LSP ping and trace infrastructure defined in RFC 4379, *Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures* and further enhancements defined in Internet draft draft-stokes-vkompella-ppvpn-hvpls-oam-02, *Testing Hierarchical Virtual Private LAN Services*.

Options instance *instance-name*—Specify the name of the VPLS routing instance.

destination-mac *address*—Specify a destination MAC address for the ping echo requests.

source ip *address*—IP address of the outgoing interface.

bd-name *name*—(Optional) Name of the bridge domain.

control-plane-response—(Optional) Request VPLS OAM responses using the control plane.

count *number*—(Optional) Number of ping requests to send. If **count** is not specified, five ping requests are sent. The range of values is 1 through 1,000,000. The default value is 5.

detail—(Optional) Display detailed information about the echo requests sent and received.

learning-vlan-id *number*—(Optional) Specify a learning VLAN identifier for the ping echo requests. The range of values is 0 through 4094.

logical-system *logical-system-name*—(Optional) Specify a logical system name for the ping echo requests.

Additional Information This statement is only supported on the MX Series routers, the M120 and M320 routers, and the T1600 router.

Required Privilege Level network

List of Sample Output ping vpls instance on page 31

Output Fields When you enter this command, you are provided feedback on the status of your request. An exclamation point (!) indicates that an echo reply was received. A period (.) indicates that an echo reply was not received within the timeout period. An x indicates that an echo reply was received with an error code these packets are not counted in the received packets count. They are accounted for separately.

Sample Output

```
ping vpls instance user@host> ping vpls instance red destination-mac 00:89:67:1a:23:6f source-ip 10.255.17.138
! -> sample-router:red:ge-4/1/1.0
! -> sample-router:red:ge-4/1/1.0
! -> sample-router:red:ge-4/1/1.0
! -> sample-router:red:ge-4/1/1.0

--- vpls ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
```


CHAPTER 2

Interface Diagnostics Operational Mode Commands

Table 4 on page 33 summarizes the command-line interface (CLI) commands you can use to run diagnostics on router interfaces. Commands are listed in alphabetical order.

Table 4: Interface Diagnostics Operational Mode Commands

Task	Command
Start a bit error rate test (BERT) on a DS0 interface.	test interface ds0-bert-start
Stop a BERT on a DS0 interface.	test interface ds0-bert-stop
Start a BERT on an E1 interface.	test interface e1-bert-start
Stop a BERT on an E1 interface.	test interface e1-bert-stop
Start a BERT on an E3 interface.	test interface e3-bert-start
Stop a BERT on an E3 interface.	test interface e3-bert-stop
Transmit over a facilities data link (FDL) to initiate or terminate a far-end line loopback.	test interface fdl-line-loop
Transmit over an FDL to initiate or terminate a far-end payload loopback.	test interface fdl-payload-loop
Transmit the line loopback activate code word sequence on the interface's far-end alarm and control (FEAC) channel.	test interface feac-loop-initiate
Transmit the line loopback deactivate code word sequence on the interface's FEAC channel.	test interface feac-loop-terminate
Initiate or terminate a far-end line loopback.	test interface inband-line-loop
Initiate or terminate a far-end payload loopback.	test interface inband-payload-loop

Table 4: Interface Diagnostics Operational Mode Commands (*continued*)

Task	Command
Restart auto-negotiation on a Fast Ethernet or Gigabit Ethernet interface.	test interface restart-auto-negotiation
Start a BERT on a T1 interface.	test interface t1-bert-start
Stop a BERT on a T1 interface.	test interface t1-bert-stop
Start a BERT on a T3 interface.	test interface t3-bert-start
Stop a BERT on a T3 interface.	test interface t3-bert-stop



NOTE: For information about how to configure interface test parameters, see the [Junos OS Network Interfaces Configuration Guide](#). For information about related tasks performed by network operations center (NOC) personnel, see the [Junos Interfaces Network Operations Guide](#).

test interface ds0-bert-start

Syntax	test interface ds0-bert-start <i>ds-fpc/pic/port</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Start a bit error rate test (BERT) on a DS0 interface.
Options	<i>ds-fpc/pic/port</i> —DS0 interface name.
Additional Information	Before starting a BERT, you must disable the interface. To do so, include the disable statement at the [edit interfaces <i>interface-name</i>] hierarchy level. You can run a BERT on only one interface per PIC at a time.
Required Privilege Level	view
List of Sample Output	test interface ds0-bert-start on page 35
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

test interface ds0-bert-start	user@host> test interface ds0-bert-start ds-1/0/0
----------------------------------	---

test interface ds0-bert-stop

Syntax	<code>test interface ds0-bert-stop ds-<i>fpc/pic/port</i></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Stop a bit error rate test (BERT) on a DS0 interface.
Options	<i>ds-fpc/pic/port</i> —DS0 interface name.
Required Privilege Level	view
List of Sample Output	test interface ds0-bert-stop on page 36
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

test interface ds0-bert-stop	<code>user@host> test interface ds0-bert-stop ds-1/0/0</code>
---	--

test interface e1-bert-start

Syntax	test interface e1-bert-start <i>interface-name</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Start a bit error rate test (BERT) on an E1 interface.
Options	<i>interface-name</i> —Interface name: e1-<i>fpc/pic/port</i> or ce1-<i>fpc/pic/port</i> <:<i>channel</i>>
Additional Information	Before starting a BERT, you must disable the interface. To do this, include the disable statement at the [edit interfaces <i>interface-name</i>] hierarchy level. You can run a BERT on only one interface per PIC at a time.
Required Privilege Level	view
List of Sample Output	test interface e1-bert-start on page 37
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

```
test interface user@host> test interface e1-bert-start e1-1/0/0
e1-bert-start
```

test interface e1-bert-stop

Syntax	<code>test interface e1-bert-stop <i>interface-name</i></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Stop a bit error rate test (BERT) on an E1 interface.
Options	<i>interface-name</i> —Interface name: <code>e1-<i>fpc/pic/port</i></code> or <code>ce1-<i>fpc/pic/port</i> <:<i>channel</i>></code> .
Required Privilege Level	view
List of Sample Output	test interface e1-bert-stop on page 38
Output Fields	To display the results of the BERT, use the <code>show interfaces extensive</code> command.

Sample Output

```
test interface  user@host> test interface e1-bert-stop e1-1/0/0
e1-bert-stop
```

test interface e3-bert-start

Syntax	test interface e3-bert-start <i>e3-fpc/pic/port</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Start a bit error rate test (BERT) on an E3 interface.
Options	<i>e3-fpc/pic/port</i> —E3 interface name.
Additional Information	Before starting a BERT, you must disable the interface. To do so, include the disable statement at the [edit interfaces <i>interface-name</i>] hierarchy level. You can run a BERT on only one interface per PIC at a time.
Required Privilege Level	view
List of Sample Output	test interface e3-bert-start on page 39
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

test interface e3-bert-start	user@host> test interface e3-bert-start e3-1/0/0
---------------------------------	--

test interface e3-bert-stop

Syntax	<code>test interface e3-bert-stop e3-<i>fpc/pic/port</i></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Stop a bit error rate test (BERT) on an E3 interface.
Options	<i>e3-fpc/pic/port</i> —E3 interface name.
Required Privilege Level	view
List of Sample Output	test interface e3-bert-stop on page 40
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

```
test interface  user@host> test interface e3-bert-stop e3-1/0/0
e3-bert-stop
```


test interface fdl-line-loop

Syntax test interface fdl-line-loop (ansi (initiate | terminate) | bellcore (initiate | terminate))
t1-fpc/pic/port <:channel>

Release Information Command introduced before Junos OS Release 7.4.

Description Send commands over the facilities data link (FDL) on a T1 interface to initiate or terminate a far-end line loopback using either an ANSI or Bellcore FDL command code. If the far end of the connection is in C-bit parity mode and it has been configured to accept line loopback requests from the near end, the far end executes the request. See the ANSI T1.107 specification for more details.



NOTE: The following restrictions apply to this command:

- If you attach a SmartJack network interface unit on the T1 connection between an M Series router with a channelized DS3 IQ, channelized OC3 IQ, or channelized OC12 IQ interface and a standard T1 interface, and you issue the test interface fdl-line-loop bellcore initiate command on the channelized T1 interface, the loopback test might not function correctly.
- On channelized DS3-to-DS1 and multichannel DS3 PICs, this command can only be initiated by T1 interfaces. These types of T1 interfaces cannot accept a request for this test sent by another router.
- This command is not supported on the 4-port T1 PIC.

Options ansi—ANSI FDL command code.

bellcore—Bellcore FDL command code.

initiate—Initiate the far-end line loopback.

terminate—Terminate the far-end line loopback.

t1-fpc/pic/port <:channel>—Name of a T1 interface. The channel number indicates a channelized interface.

Required Privilege Level view

List of Sample Output test interface fdl-line-loop on page 42

Output Fields To display the state and the number of times the interface has placed itself into remote loopback, use the **show interfaces extensive** command.

Sample Output

```
test interface user@host> test interface fdl-line-loop ansi initiate t1-1/0/0
fdl-line-loop
```

test interface fdl-payload-loop

Syntax test interface fdl-payload-loop (ansi (initiate | terminate) | bellcore (initiate | terminate) t1-fpc/pic/port <:channel>)

Release Information Command introduced before Junos OS Release 7.4.

Description Send commands over the facilities data link (FDL) on a T1 interface to initiate or terminate a far-end payload loopback using either an ANSI or Bellcore FDL command code. If the far end of the connection is in C-bit parity mode and has been configured to accept payload loopback requests from the near end, the far end executes the request. See the ANSI T1.107 specification for more details.



NOTE: The following restrictions apply to this command:

- On channelized DS3-to-DS1 and multichannel DS3 PICs, this command can only be initiated by T1 interfaces. These types of T1 interfaces cannot accept a request for this test sent by another router.
- This command is not supported on the 4-port T1 PIC.

Options ansi—ANSI FDL command code.

bellcore—Bellcore FDL command code.

initiate—Initiate the far-end payload loopback.

terminate—Terminate the far-end payload loopback.

t1-fpc/pic/port <:channel>—Name of a T1 interface. The channel number indicates a channelized interface.

Required Privilege Level view

List of Sample Output test interface fdl-payload-loop on page 43

Output Fields To display the state and the number of times the interface has placed itself into remote loopback, use the **show interfaces extensive** command.

Sample Output

```
test interface fdl-payload-loop user@host> test interface fdl-payload-loop ansi initiate t1-1/0/0
```

test interface feac-loop-initiate

Syntax `test interface t3-fpc/pic/port <:channel> feac-loop-initiate`

Release Information Command introduced before Junos OS Release 7.4.

Description Have the interface transmit the word sequence for the line loopback activate code on its far-end alarm and control (FEAC) channel. If the far end of the connection is in C-bit parity mode and has been configured to accept remote loopback requests from the near end, the far end places its interface into remote loopback. See the ANSI T1.107 specification for more details.



NOTE: This command is not supported for T3 interfaces configured on DS3 and channelized OC12 PICs.

Options `t3-fpc/pic/port <:channel>`—Name of a T3 interface. The channel number indicates a channelized interface.

Required Privilege Level view


List of Sample Output [test interface feac-loop-initiate on page 44](#)

Output Fields To display the state and the number of times the interface has placed itself into remote loopback, use the **show interfaces extensive** command.

Sample Output

```
test interface    user@host> test interface feac-loop-initiate t3-1/0/0
feac-loop-initiate
```

test interface feac-loop-terminate

Syntax	test interface t3- <i>fpc/pic/port</i> <: <i>channel</i> > feac-loop-terminate
Release Information	Command introduced before Junos OS Release 7.4.
Description	Have the interface transmit the line loopback deactivate code word sequence on its far-end alarm and control (FEAC) channel. If the far end of the connection is in C-bit parity mode and has been configured to accept remote loopback requests from the near end, the far end clears remote loopback on the interface. See the ANSI T1.107 specification for more details.
	<div>  <p>NOTE: This command is not supported for T3 interfaces configured on DS3 and Channelized OC12 PICs.</p> </div>
Options	t3- <i>fpc/pic/port</i> <: <i>channel</i> >—Name of a T3 interface. The channel number indicates a channelized interface.
Required Privilege Level	view
List of Sample Output	test interface feac-loop-terminate on page 45
Output Fields	To display the state and the number of times the interface has placed itself into remote loopback, use the show interfaces extensive command.

Sample Output

```
test interface  user@host> test interface feac-loop-terminate t3-1/0/0
feac-loop-terminate
```

test interface inband-line-loop

Syntax test interface inband-line-loop (ansi (initiate | terminate) | bellcore (initiate | terminate) t1-fpc/pic/port <:channel>)

Release Information Command introduced before Junos OS Release 7.4.

Description Send commands on a T1 interface to initiate or terminate a far-end line loopback using either an ANSI or Bellcore FDL command code. If the far end of the connection is in C-bit parity mode and it has been configured to accept line loopback requests from the near end, the far end executes the request.



NOTE: The following restrictions apply to this command:

- On channelized DS3-to-DS1 and multichannel DS3 PICs, this command can only be initiated by T1 interfaces. These types of T1 interfaces cannot accept a request for this test sent by another router.
- This command is not supported on the 4-port T1 PIC.

Options ansi—ANSI FDL command code.

bellcore—Bellcore FDL command code.

initiate—Initiate the far-end payload loopback.

terminate—Terminate the far-end payload loopback.

t1-fpc/pic/port <:channel>—Name of a T1 interface. The channel number indicates a channelized interface.

Required Privilege Level view


List of Sample Output test interface inband-line-loop on page 46

Output Fields To display the state and the number of times the interface has placed itself into remote loopback, use the **show interfaces extensive** command.

Sample Output

```
test interface inband-line-loop user@host> test interface inband-line-loop ansi initiate t1-1/0/0
```

test interface inband-payload-loop

Syntax	test interface inband-payload-loop (ansi (initiate terminate) bellcore (initiate terminate) t1-fpc/pic/port <:channel>)
Release Information	Command introduced before Junos OS Release 7.4.
Description	Send commands on a T1 interface to initiate or terminate a far-end payload loopback using either an ANSI or Bellcore FDL command code. If the far end of the connection is in C-bit parity mode and has been configured to accept payload loopback requests from the near end, the far end executes the request.
	<div>  <p>NOTE: The following restrictions apply to this command:</p> <ul style="list-style-type: none"> On channelized DS3-to-DS1 and multichannel DS3 PICs, this command can only be initiated by T1 interfaces. These types of T1 interfaces cannot accept a request for this test sent by another router. This command is not supported on the 4-port T1 PIC. </div>
Options	ansi—ANSI FDL command code. bellcore—Bellcore FDL command code. initiate—Initiate the far-end payload loopback. terminate—Terminate the far-end payload loopback. t1-fpc/pic/port <:channel>—Name of a T1 interface. The channel number indicates a channelized interface.
Additional Information	See the ANSI T1.107 specification for more details.
Required Privilege Level	view
List of Sample Output	test interface inband-payload-loop on page 47
Output Fields	To display the state and the number of times the interface has placed itself into remote loopback, use the show interfaces extensive command.

Sample Output

```
test interface  user@host> test interface inband-payload-loop ansi initiate t1-1/0/0
inband-payload-loop
```

test interface restart-auto-negotiation

Syntax	test interface restart-auto-negotiation <i>interface-name</i>
Release Information	Command introduced in Junos OS Release 7.6. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Restarts auto-negotiation on a Fast Ethernet or Gigabit Ethernet interface.
Options	<i>interface-name</i> —Interface name: fe-fpc/pic/port or ge-fpc/pic/port .
Required Privilege Level	view
List of Sample Output	test interface restart-auto-negotiation on page 48
Output Fields	Use the show interfaces extensive command to see the state for auto-negotiation.

Sample Output

test interface restart-auto-negotiation	user@host> test interface restart-auto-negotiation fe-1/0/0
--	---

test interface t1-bert-start

Syntax	test interface t1-bert-start <i>interface-name</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Start a bit error rate test (BERT) on a T1 interface.
Options	<i>interface-name</i> —Interface name: t1-fpc/pic/port or ct1-fpc/pic/port <:channel> .
Additional Information	Before starting a BERT, you must disable the interface. To do so, include the disable statement at the [edit interfaces <i>interface-name</i>] hierarchy level. You can run a BERT on only one interface per PIC at a time.
Required Privilege Level	view
List of Sample Output	test interface t1-bert-start on page 49
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

```
test interface  user@host> test interface t1-bert-start t1-1/0/0
t1-bert-start
```

test interface t1-bert-stop

Syntax	test interface t1-bert-stop <i>interface-name</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Stop a bit error rate test (BERT) on a T1 interface.
Options	<i>interface-name</i> —Interface name: t1-<i>interface-name</i> fpc/pic/port or ct1-<i>fpc/pic/port</i> <:channel>
Required Privilege Level	view
List of Sample Output	test interface t1-bert-stop on page 50
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

```
test interface  user@host> test interface t1-bert-stop t1-1/0/0
t1-bert-stop
```

test interface t3-bert-start

Syntax	test interface t3-bert-start <i>interface-name</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Start a bit error rate test (BERT) on a T3 interface.
Options	<i>interface-name</i> —Interface name: t3-fpc/pic/port or ct3-fpc/pic/port <:channel> .
Additional Information	Before starting a BERT, you must disable the interface. To do this, include the disable statement at the [edit interfaces <i>interface-name</i>] hierarchy level. You can run a BERT on only one interface per PIC at a time.
Required Privilege Level	view
List of Sample Output	test interface t3-bert-start on page 51
Output Fields	To display the results of the BERT, use the show interfaces extensive command.

Sample Output

```
test interface t3-bert-start user@host> test interface t3-bert-start t3-1/0/0
```

test interface t3-bert-stop

Syntax	<code>test interface t3-bert-stop <i>interface-name</i></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Stop a bit error rate test (BERT) on a T3 interface.
Options	<i>interface-name</i> —Interface name: <code>t3-fpc/pic/port</code> or <code>ct3-fpc/pic/port <:channel></code> .
Required Privilege Level	view
List of Sample Output	test interface t3-bert-stop on page 52
Output Fields	To display the results of the BERT, use the <code>show interfaces extensive</code> command.

Sample Output

```
test interface  user@host> test interface t3-bert-stop t3-1/0/0
t3-bert-stop
```

CHAPTER 3

RADIUS Diagnostics Operational Mode Commands

Table 5 on page 53 summarizes RADIUS diagnostics commands that allow you to test RADIUS authentication by verifying a user, password, IP address, profile, and other RADIUS authentication attributes. Commands are listed in alphabetical order.

Table 5: RADIUS Operational Mode Commands

Task	Command
Test a RADIUS authentication profile	test access profile
Test RADIUS server authentication	test access radius-server

test access profile

Syntax	<code>test access profile <i>profile-name</i> user <i>username</i> password <i>password</i> <detail></code>
Release Information	Command introduced in Junos OS Release 9.1.
Description	Specify a profile to use to get information from a RADIUS server, which includes all the information from the test access radius-server command.
Options	<p>detail—(Optional) Show the RADIUS attributes returned by the server.</p> <p>profile-name—Access profile name configured.</p> <p>password—Password for the username.</p> <p>username—User name to be authenticated to the RADIUS server.</p>
Required Privilege Level	view
List of Sample Output	<p>test access profile on page 55</p> <p>test access profile detail on page 55</p>
Output Fields	Table 6 on page 54 lists the output fields for the test access profile command. Output fields are listed in the approximate order in which they appear.

Table 6: test access profile Output Fields

Field Name	Field Description
Profile Name	Name of the configured access profile.
Client Username	The user name authenticated by the RADIUS server.
Client Password	The user password authenticated by the RADIUS server.
Num Servers	Number of RADIUS servers in the configured access profile.
Server List	List of RADIUS servers in the configure access profile.
IP Address	The IP address of the RADIUS server authenticated.
UDP Port	The RADIUS server port utilized during the authentication test.
Source Address	The source IP address of the client making the RADIUS request. If no address is shown, it defaults to the address of the outgoing interface.
Timeout	The RADIUS server timeout period.
Retry Count	The number of authentication attempts allowed by the RADIUS server.

Table 6: test access profile Output Fields (*continued*)

Field Name	Field Description
Secret	The shared secret used for authentication with the RADIUS server.
Status	The test result status (Accepted or Rejected) and the number of retransmits utilized during authentication.
Attempts	The number of authentication attempts on the RADIUS server.
Attribute List	The list of returned RADIUS attributes, sorted by the attribute name, and including parameter length and value. See your RADIUS server documentation for attribute descriptions.
(Attribute) Name	The name of the attribute.
(Attribute) Length	The attribute length in bytes.
(Attribute) Value	The attribute value.

Sample Output

test access profile The following example uses the **test access profile** command to access and display basic information about the RADIUS server(s) shown in the resulting output:

```

user@host> test access profile alpha user TEST password TEST
user@host> test access profile alpha user TEST password TEST
Test Radius Profile Access
  Profile Name      : alpha
  Client Username   : TEST
  Client Password   : TEST
  Num Servers       : 5
    Server List
      IP Address    UDP   Source   Retry   Status
      Attempts      Port   Address   Timeout Count Secret
1.1.1.1            1812  10.10.10.10  2       1    TEST   Timeout
2
1.2.3.4            1812  Default    1       2    TEST   Timeout
3
192.168.10.10     1812  Default    3       3    TEST   Accepted
1

```

test access profile detail The following example uses the **test access profile detail** command to access and display detailed information about the RADIUS server(s) shown in the resulting output:

```

user@host> test access profile alpha user TEST password TEST detail
user@host> test access profile alpha user TEST password TEST detail
Test Radius Profile Access Detailed
  Profile Name      : alpha
  Client Username   : TEST
  Client Password   : TEST
  Num Servers       : 5
    Radius Server List

```

```

IP Address      : 1.2.3.4
UDP Port       : 1812
Source Address  : 192.168.10.10
Timeout        : 2
Retry Count    : 1
Secret         : TEST
Status        : Timeout
Attempts      : 2

```

```

IP Address      : 1.2.3.5
UDP Port       : 1812
Source Address  : Default
Timeout        : 1
Retry Count    : 2
Secret         : TEST
Status        : Timeout
Attempts      : 3

```

```

IP Address      : 192.168.10.10
UDP Port       : 1812
Source Address  : Default
Timeout        : 3
Retry Count    : 3
Secret         : TEST
Status        : Accepted
Attempts      : 1

```

Attribute List

Name	Length	Value
Class	52	SBR2CLÍ½%¿ð0%¿
Acct-Interim-Interval	4	5
Callback-Id	12	123-456-789
Callback-Number	13	555-555-1212
Class	15	Class information
Filter-Id	4	999
Filter-Id	6	12345
Framed-Compression	4	0
Framed-IP-Address	4	1:2:3:4
Framed-IP-Netmask	4	255:255:255:255
Framed-IPv6-Route	15	1:2:3:4:5:6:7:8
Framed-MTU	4	1024
Framed-Pool	9	pool sbr
Framed-Protocol	4	1
Framed-Route	8	iproute
Framed-Routing	4	0
Vendor-Specific	11	583
Idle-Timeout	4	3
Vendor-Specific	10	a4c
Vendor-Specific	14	a4c
Login-IP-Host	4	10:1:1:1
Login-LAT-Group	10	lat group
Login-LAT-Node	9	lat node
Login-LAT-Port	9	lat port
Login-LAT-Service	12	lat service
Login-Service	4	0
Login-TCP-Port	4	1812
Vendor-Specific	10	137
Vendor-Specific	38	137
Vendor-Specific	10	137
Vendor-Specific	9	137

Vendor-Specific	16	137
Vendor-Specific	10	137
Vendor-Specific	10	137
Vendor-Specific	10	137
Vendor-Specific	9	137
Vendor-Specific	10	137
Vendor-Specific	10	137
Vendor-Specific	10	137
Vendor-Specific	10	137
Password-Retry	4	3
Port-Limit	4	100
Prompt	4	
Reply-Message	18	Radius Server SB
Service-Type	4	2
Session-Timeout	4	10
Termination-Action	4	1
Tunnel-Assignment-ID	4	
Tunnel-Client-Auth-ID	6	
Tunnel-Client-Endpoint	4	
Tunnel-Password	19	
Tunnel-Type	4	12
MS BAP Usage	4	0
MS-CHAP MPPE-Keys	32	-1234567890
MS-CHAP2 Success	3	123456789
MS Filter	10	ms-filter
MS Link Drop Time Limit	4	5
MS Link Utilization Threshold	4	6
MS MPPE Encryption Policy	4	1
MS MPPE Encryption Types	3	-556677889
MS Primary DNS Server	4	1:1:1:1
MS Primary NBNS Server	4	2:2:2:2
MS Secondary DNS Server	4	3:3:3:3
MS Secondary NBNS Server	4	4:4:4:4

test access radius-server

Syntax `test access radius-server address user username password password secret secret
<authentication-port port>
<retry number>
<source-address address>
<timeout number>`

Release Information Command introduced in Junos OS Release 9.1.

Description Verify RADIUS server authentication parameters.

Options *address*—RADIUS server under test IP address.

password—Password for the user.

secret—Secret shared with the RADIUS server.

user—User name to be authenticated to the RADIUS server.

authentication-port—(Optional) RADIUS server authentication port number (1through 65535).

retry—(Optional) Retry attempts (1through 10).

source-address—(Optional) Use an alternate address as the source address.

timeout—(Optional) Request timeout period (1through 90 seconds).

Required Privilege Level view

List of Sample Output `test access radius-server user password secret` on page 59

Output Fields Table 7 on page 58 lists the output fields for the **test access radius-server** command. Output fields are listed in the approximate order in which they appear.

Table 7: test access radius-server Output Fields

Field Name	Field Description
Server	The IP address of the RADIUS server authenticated.
UDP port	The RADIUS server port utilized during the authentication test.
Source IP Address	"Default" is shown if the IP address is the same as that of the RADIUS server. Alternatively, an IP address specified for authentication is shown.
Server timeout	The RADIUS server timeout period.
Sever retry count	The number of authentication attempts allowed by the RADIUS server.

Table 7: test access radius-server Output Fields (*continued*)

Field Name	Field Description
Secret	The shared secret used for authentication with the RADIUS server.
Client Username	The user name authenticated by the RADIUS server.
Client Password	The user password authenticated by the RADIUS server.
Status	The test result status (Accepted or Rejected) and the number of retransmits utilized during authentication.

Sample Output

test access The following example command tests RADIUS authentication with a specific server
radius-server user (172.28.30.95), user (JOHNDOE), secret (No1Knows), and password (JohnPass); and
password secret displays the resulting output:

```
user@host> test access radius-server 172.28.30.95 user JOHNDOE password JohnPass secret
No1Knows
```

```
Test Radius Server Access
  Server           : 172.28.30.95
  UDP port         : 1812
  Source IP Address : Default
  Server timeout   : 3
  Sever retry count : 3
  Secret           : No1Knows
  Client Username   : JOHNDOE
  Client Password   : JohnPass
  Status            : Accepted, retransmits: 0
```


Real-Time Performance Monitoring Operational Mode Commands

Table 8 on page 61 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot real-time performance monitoring (RPM). Commands are listed in alphabetical order.

Table 8: RPM Operational Mode Commands

Task	Command
Clear Two-Way Active Measurement Protocol (TWAMP) connections and associated sessions.	<code>clear services rpm twamp server connection</code>
Show configured probe servers.	<code>show services rpm active-servers</code>
Show the results of the last 50 completed probes for each RPM instance.	<code>show services rpm history-results</code>
Show probe results.	<code>show services rpm probe-results</code>
Show TWAMP connections.	<code>show services rpm twamp server connection</code>
Show TWAMP sessions.	<code>show services rpm twamp server session</code>



NOTE: For information about how to configure RPM, see the *Junos OS Services Interfaces Configuration Guide*.

clear services rpm twamp server connection

Syntax	<code>clear services rpm twamp server connection</code> <code><connection-id></code>
Release Information	Command introduced in Junos OS Release 9.3.
Description	Clear connections established between the real-time performance monitoring (RPM) Two-Way Active Measurement Protocol (TWAMP) server and control clients. By default all established connections are cleared (along with the sessions on those connections). To clear only a specific connection, specify the connection ID when you issue the command.
Options	<code>connection-id</code> —(Optional) Clear only the specified connection.
Required Privilege Level	clear

show services rpm active-servers

Syntax	show services rpm active-servers
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the protocols and corresponding ports for which a router or switch is configured as a real-time performance monitoring (RPM) server.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show services rpm active-servers on page 63
Output Fields	Table 9 on page 63 lists the output fields for the show services rpm active-servers command. Output fields are listed in the approximate order in which they appear.

Table 9: show services rpm active-servers Output Fields

Field Name	Field Description
Protocol	Protocol configured on the receiving probe server. The protocol can be the User Datagram Protocol (UDP) or the Transmission Control Protocol (TCP).
Port	Port configured on the receiving probe server.
Destination interface name	Output interface name for the probes.

Sample Output

```

show services rpm active-servers user@host> show services rpm active-servers
Protocol: TCP, Port: 50000, Destination interface name: lt-0/0/0.0
Protocol: UDP, Port: 50001, Destination interface name: lt-0/0/0.0

```

show services rpm history-results

Syntax	show services rpm history-results <brief detail> <owner <i>owner</i> > <since <i>time</i> > <test <i>name</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display standard information about the results of the last 50 probes for each real-time performance monitoring (RPM) instance.
Options	<p>none—Display the results of the last 50 probes for all RPM instances.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>owner <i>owner</i>—(Optional) Display information for the specified probe owner.</p> <p>since <i>time</i>—(Optional) Display information from the specified time. Specify time as <i>yyyy-mm-dd.hh:mm:ss</i>.</p> <p>test <i>name</i>—(Optional) Display information for the specified test.</p>
Required Privilege Level	view
List of Sample Output	<p>show services rpm history-results on page 65</p> <p>show services rpm history-results detail on page 65</p>
Output Fields	Table 10 on page 64 lists the output fields for the show services rpm history-results command. Output fields are listed in the approximate order in which they appear.

Table 10: show services rpm history-results Output Fields

Field Name	Field Description	Level of Output
Owner	Probe owner.	All levels
Test	Name of a test for a probe instance.	All levels
Probe received	Timestamp when the probe result was determined.	All levels
Round trip time	Average ping round-trip time (RTT), in microseconds.	All levels
Probe results	<p>Result of a particular probe performed by a remote host. The following information is contained in the results:</p> <ul style="list-style-type: none"> Response received—Timestamp when the probe result was determined. Rtt—Average ping round-trip time (RTT), in microseconds. 	detail

Table 10: show services rpm history-results Output Fields (*continued*)

Field Name	Field Description	Level of Output
Results over current test	Displays the results for the current test by probe at the time each probe was completed, as well as the status of the current test at the time the probe was completed.	detail
Probes sent	Number of probes sent with the current test.	detail
Probes received	Number of probe responses received within the current test.	detail
Loss percentage	Percentage of lost probes for the current test.	detail
Measurement	<p>Increment of measurement. Possible values are round-trip time delay and, for the probe type icmp-pin-timestamp, the egress and ingress delay:</p> <ul style="list-style-type: none"> • Minimum—Minimum RTT, ingress delay, or egress delay measured over the course of the current test. • Maximum—Maximum RTT, ingress delay, or egress delay measured over the course of the current test. • Average—Average RTT, ingress delay, or egress delay measured over the course of the current test. • Jitter—Difference, in microseconds, between the maximum and minimum RTT measured over the course of the current test. • Stddev—Standard deviation of the round-trip time, in microseconds, measured over the course of the current test. 	detail

Sample Output

```

show services rpm history-results user@host> show services rpm history-results
Owner, Test                               Probe received                               Round trip time
flintstone, 0                             Tue Dec 28 15:56:22 2004                       158 usec
flintstone, 0                             Tue Dec 28 15:56:23 2004                       218 usec
flintstone, 0                             Tue Dec 28 15:56:24 2004                       161 usec
flintstone, 0                             Tue Dec 28 15:56:25 2004                       184 usec
flintstone, 0                             Tue Dec 28 15:56:30 2004                       332 usec
flintstone, 0                             Tue Dec 28 15:56:31 2004                       132 usec
flintstone, 0                             Tue Dec 28 15:56:32 2004                       226 usec
flintstone, 0                             Tue Dec 28 15:56:33 2004                       191 usec
flintstone, 0                             Tue Dec 28 15:56:34 2004                       179 usec
flintstone, 0                             Tue Dec 28 15:56:39 2004                       217 usec
flintstone, 0                             Tue Dec 28 15:56:40 2004                       141 usec
flintstone, 0                             Tue Dec 28 15:56:41 2004                       230 usec
flintstone, 0                             Tue Dec 28 15:56:42 2004                       248 usec
flintstone, 0                             Tue Dec 28 15:56:43 2004                       234 usec
flintstone, 0                             Tue Dec 28 15:56:48 2004                       251 usec
flintstone, 0                             Tue Dec 28 15:56:49 2004                       134 usec
flintstone, 0                             Tue Dec 28 15:56:50 2004                       272 usec
flintstone, 0                             Tue Dec 28 15:56:51 2004                       181 usec
flintstone, 0                             Tue Dec 28 15:56:52 2004                       216 usec
flintstone, 0                             Tue Dec 28 15:56:57 2004                       227 usec
flintstone, 0                             Tue Dec 28 15:56:58 2004                       133 usec

show services rpm history-results detail user@host> show services rpm history-results detail

```

```
Owner: flintstone, Test: 0
Probe results:
  Response received, Tue Dec 28 15:56:39 2004
  Rtt: 217 usec
Results over current test:
  Probes sent: 1, Probes received: 1, Loss percentage: 0
  Measurement: Round trip time
    Minimum: 217 usec, Maximum: 217 usec, Average: 217 usec,
    Jitter: 0 usec, Stddev: 0 usec

Owner: flintstone, Test: 0
Probe results:
  Response received, Tue Dec 28 15:56:40 2004
  Rtt: 141 usec
Results over current test:
  Probes sent: 2, Probes received: 2, Loss percentage: 0
  Measurement: Round trip time
    Minimum: 141 usec, Maximum: 217 usec, Average: 179 usec,
    Jitter: 76 usec, Stddev: 38 usec

Owner: flintstone, Test: 0
Probe results:
  Response received, Tue Dec 28 15:56:41 2004
  Rtt: 230 usec
Results over current test:
  Probes sent: 3, Probes received: 3, Loss percentage: 0
  Measurement: Round trip time
    Minimum: 141 usec, Maximum: 230 usec, Average: 196 usec,
    Jitter: 89 usec, Stddev: 39 usec

Owner: flintstone, Test: 0
Probe results:
  Response received, Tue Dec 28 15:56:42 2004
  Rtt: 248 usec
Results over current test:
  Probes sent: 4, Probes received: 4, Loss percentage: 0
  Measurement: Round trip time
    Minimum: 141 usec, Maximum: 248 usec, Average: 209 usec,
    Jitter: 107 usec, Stddev: 41 usec
```

show services rpm probe-results

Syntax	show services rpm probe-results <owner <i>owner</i> > <test <i>name</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the results of the most recent real-time performance monitoring (RPM) probes.
Options	none—Display all results of the most recent RPM probes. owner <i>owner</i> —(Optional) Display information for the specified probe owner. test <i>name</i> —(Optional) Display information for the specified test.
Required Privilege Level	view
List of Sample Output	show services rpm probe-results on page 70 show services rpm probe-results (BGP Neighbor Discovery) on page 71
Output Fields	Table 11 on page 67 lists the output fields for the show services rpm probe-results command. Output fields are listed in the approximate order in which they appear.

Table 11: show services rpm probe-results Output Fields

Field Name	Field Description
Owner	Owner name. When you configure the probe owner statement at the [edit services rpm] hierarchy level, this field displays the configured owner name. When you configure BGP neighbor discovery through RPM, the output for this field is Rpm-Bgp-Owner .
Test	Name of a test representing a collection of probes. When you configure the test test-name statement at the [edit services rpm probe owner] hierarchy level, the field displays the configured test name. When you configure BGP neighbor discovery through RPM, the output for this field is Rpm-BGP-Test-n , where <i>n</i> is a cumulative number.
Target address	Destination address used for the probes.
Source address	Source address used for the probes.
Probe type	Protocol configured on the receiving probe server: http-get , http-metadata-get , icmp-ping , icmp-ping-timestamp , tcp-ping , udp-ping , or udp-ping-timestamp .
Test size	Number of probes within a test.

Table 11: show services rpm probe-results Output Fields (*continued*)

Field Name	Field Description
Routing Instance Name	<p>(BGP neighbor discovery) Name of the configured (if any) routing instance, logical system name, or both, in which the probe is configured:</p> <ul style="list-style-type: none"> When a routing instance is defined within a logical system, the logical system name is followed by the routing instance name. A slash (/) is used to separate the two entities. For example, if the routing instance called R1 is configured within the logical system called LS, the name in the output field is LS/R1. When a routing instance is configured but the default logical system is used, the name in the output field is the name of the routing instance. When a logical system is configured but the default routing instance is used, the name in the output field is the name of the logical system followed by default. A slash (/) is used to separate the two entities. For example, LS/default.
Probe results	<p>Raw measurement of a particular probe sample done by a remote host. This data is provided separately from the calculated results. The following information is contained in the raw measurement:</p> <ul style="list-style-type: none"> Response received—Timestamp when the probe result was determined. Client and server hardware timestamps—If timestamps are configured, an entry appears at this point. Rtt—Average ping round-trip time (RTT), in microseconds. Egress jitter—Egress jitter, in microseconds. Ingress jitter—Ingress jitter, in microseconds. Round trip jitter—Round-trip jitter, in microseconds. Egress interarrival jitter—Egress interarrival jitter, in microseconds. Ingress interarrival jitter—Ingress interarrival jitter, in microseconds. Round trip interarrival jitter—Round-trip interarrival jitter, in microseconds.
Results over current test	<p>Probes are grouped into tests, and the statistics are calculated for each test. If a test contains 10 probes, the average, minimum, and maximum results are calculated from the results of those 10 probes. If the command is issued while the test is in progress, the statistics use information from the completed probes.</p> <ul style="list-style-type: none"> Probes sent—Number of probes sent within the current test. Probes received—Number of probe responses received within the current test. Loss percentage—Percentage of lost probes for the current test. Measurement—Measurement type. Possible values are round-trip time, positive round-trip jitter, negative round-trip jitter, egress time, positive egress jitter, negative egress jitter, ingress time, positive ingress jitter, negative ingress jitter, and, for the probe type icmp-ping-timestamp, the egress delay and ingress delay. <p>For each measurement type, the following individual calculated results are provided:</p> <ul style="list-style-type: none"> Samples—Number of probes. Minimum—Minimum RTT, ingress delay, or egress delay measured over the course of the current test. Maximum—Maximum RTT, ingress delay, or egress delay measured over the course of the current test. Average—Average RTT, ingress delay, or egress delay measured over the course of the current test. Peak to peak—Peak-to-peak difference, in microseconds. Stddev—Standard deviation, in microseconds. Sum—Statistical sum.

Table 11: show services rpm probe-results Output Fields (*continued*)

Field Name	Field Description
Results over last test	<p>Results for the most recently completed test. If the command is issued while the first test is in progress, this information is not displayed</p> <ul style="list-style-type: none"> • Probes sent—Number of probes sent for the most recently completed test. • Probes received—Number of probe responses received for the most recently completed test. • Loss percentage—Percentage of lost probes for the most recently completed test. • Test completed—Time the most recent test was completed. • Measurement—Measurement type. Possible values are round-trip time, positive round-trip jitter, negative round-trip jitter, egress time, positive egress jitter, negative egress jitter, ingress time, positive ingress jitter, negative ingress jitter, and, for the probe type icmp-ping-timestamp, the egress delay and ingress delay. <p>For each measurement type, the following individual calculated results are provided:</p> <ul style="list-style-type: none"> • Samples—Number of probes. • Minimum—Minimum RTT, ingress delay, or egress delay measured for the most recently completed test. • Maximum—Maximum RTT, ingress delay, or egress delay measured for the most recently completed test. • Average—Average RTT, ingress delay, or egress delay measured for the most recently completed test. • Peak to peak—Peak-to-peak difference, in microseconds. • Stddev—Standard deviation, in microseconds. • Sum—Statistical sum.
Results over all tests	<p>Displays statistics made for all the probes, independently of the grouping into tests, as well as statistics for the current test.</p> <ul style="list-style-type: none"> • Probes sent—Number of probes sent in all tests. • Probes received—Number of probe responses received in all tests. • Loss percentage—Percentage of lost probes in all tests. • Measurement—Measurement type. Possible values are round-trip time, positive round-trip jitter, negative round-trip jitter, egress time, positive egress jitter, negative egress jitter, ingress time, positive ingress jitter, negative ingress jitter, and, for the probe types icmp-ping-timestamp and udp-ping-timestamp, the egress delay and ingress delay. <p>For each measurement type, the following individual calculated results are provided:</p> <ul style="list-style-type: none"> • Samples—Number of probes. • Minimum—Minimum RTT, ingress delay, or egress delay measured over the course of the current test. • Maximum—Maximum RTT, ingress delay, or egress delay measured over the course of the current test. • Average—Average RTT, ingress delay, or egress delay measured over the course of the current test. • Peak to peak—Peak-to-peak difference, in microseconds. • Stddev—Standard deviation, in microseconds. • Sum—Statistical sum.

Sample Output

```

show services rpm probe-results user@host> show services rpm probe-results
Owner: ADSN-J4300.ADSN-J2300.D2, Test: 75300002
Target address: 172.16.54.172, Source address: 10.206.0.1,
Probe type: udp-ping-timestamp, Test size: 10 probes
Probe results:
  Response received, Tue Feb  6 14:53:15 2007,
  Client and server hardware timestamps
  Rtt: 575 usec, Egress jitter: 5 usec, Ingress jitter: 8 usec,
  Round trip jitter: 12 usec, Egress interarrival jitter: 8 usec,
  Ingress interarrival jitter: 7 usec, Round trip interarrival jitter: 7 usec,

  Round trip interarrival jitter: 669 usec
Results over current test:
  Probes sent: 10, Probes received: 10, Loss percentage: 0
  Measurement: Round trip time
    Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
    Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
  Measurement: Positive round trip jitter
    Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
    Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
  Measurement: Negative round trip jitter
    Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
    Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
  Measurement: Egress time
    Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
    Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
  Measurement: Positive Egress jitter
    Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
    Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
  Measurement: Negative Egress jitter
    Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
    Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
  Measurement: Ingress time
    Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
    Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
  Measurement: Positive Ingress jitter
    Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
    Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
  Measurement: Negative Ingress jitter
    Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
    Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
Results over last test:
  Probes sent: 10, Probes received: 10, Loss percentage: 0
  Test completed on Tue Feb  6 14:53:16 2007
  Measurement: Round trip time
    Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
    Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
  Measurement: Positive round trip jitter
    Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
    Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
  Measurement: Negative round trip jitter
    Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
    Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
  Measurement: Egress time
    Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
    Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
  Measurement: Positive Egress jitter
    Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
    Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec

```

```

Measurement: Negative Egress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
  Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
Measurement: Ingress time
  Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
  Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
Measurement: Positive Ingress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
  Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
Measurement: Negative Ingress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
  Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
Results over all tests:
Probes sent: 560, Probes received: 560, Loss percentage: 0
Measurement: Round trip time
  Samples: 560, Minimum: 805 usec, Maximum: 3114 usec, Average: 1756 usec,

  Peak to peak: 2309 usec, Stddev: 519 usec, Sum: xxxx usec
Measurement: Positive round trip jitter
  Samples: 257, Minimum: 0 usec, Maximum: 2054 usec, Average: 597 usec,
  Peak to peak: 2054 usec, Stddev: 427 usec, Sum: xxxx usec
Measurement: Negative round trip jitter
  Samples: 302, Minimum: 1 usec, Maximum: 1812 usec, Average: 511 usec,
  Peak to peak: 1811 usec, Stddev: 408 usec, Sum: xxxx usec
Measurement: Egress time
  Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
  Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
Measurement: Positive Egress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
  Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
Measurement: Negative Egress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
  Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec
Measurement: Ingress time
  Samples: 10, Minimum: 805 usec, Maximum: 2859 usec, Average: 1644 usec,
  Peak to peak: 2054 usec, Stddev: 738 usec, Sum: xxxx usec
Measurement: Positive Ingress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 2054 usec, Average: 876 usec,
  Peak to peak: 2049 usec, Stddev: 679 usec, Sum: xxxx usec
Measurement: Negative Ingress jitter
  Samples: 5, Minimum: 5 usec, Maximum: 1812 usec, Average: 926 usec,
  Peak to peak: 1807 usec, Stddev: 665 usec, Sum: xxxx usec

```

**show services rpm
probe-results (BGP
Neighbor Discovery)**

```

user@host> show services rpm probe-results
Owner: Rpm-Bgp-Owner, Test: Rpm-Bgp-Test-1
Target address: 10.209.152.37, Probe type: icmp-ping, Test size: 5 probes
Routing Instance Name: LS1/RI1
Probe results:
  Response received, Fri Oct 28 05:20:23 2005
  Rtt: 662 usec
Results over current test:
  Probes sent: 5, Probes received: 5, Loss percentage: 0
  Measurement: Round trip time
    Minimum: 529 usec, Maximum: 662 usec, Average: 585 usec,
    Jitter: 133 usec, Stddev: 53 usec
Results over all tests:
  Probes sent: 5, Probes received: 5, Loss percentage: 0
  Measurement: Round trip time

```

Minimum: 529 usec, Maximum: 662 usec, Average: 585 usec,
Jitter: 133 usec, Stddev: 53 usec

show services rpm twamp server connection

Syntax	show services rpm twamp server connection <i><connection-id></i>
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display information about the connections established between the real-time performance monitoring (RPM) Two-Way Active Measurement Protocol (TWAMP) server and control-clients. By default, all established sessions are displayed, unless you specify a session ID when you issue the command.
Options	<i>connection-id</i> —(Optional) Display only information about the specified connection ID.
Required Privilege Level	view
List of Sample Output	show services rpm twamp server connection on page 73
Output Fields	Table 12 on page 73 lists the output fields for the show services rpm twamp server connection command. Output fields are listed in the approximate order in which they appear.

Table 12: show services rpm twamp server connection Output Fields

Field Name	Field Description
Connection ID	Connection ID that uniquely identifies the connection between the TWAMP server and a particular client.
Client address	Client IP address.
Client port	Client port number.
Server address	Server IP address.
Server port	Server port number.
Session count	Session count.
Auth mode	Authentication mode.

Sample Output

```

show services rpm twamp server connection
user@host> show services rpm twamp server connection

```

Connection ID	Client address	Client port	Server address	Server port	Session count	Auth mode
4	1.1.1.1	12345	192.168.219.203	890	16	none
78	3.22.1.55	345	22.2.2.2	89022	5	none

	234	192.168.219.203	2345	2.2.22.2	3333	16	none
	5	221.4.1.1	82345	2.2.2.2	45909	16	
authenticated	1	192.168.1.1	645	32.2.2.23	2394	16	
encrypted							

show services rpm twamp server session

Syntax `show services rpm twamp server session`
`<session-id>`

Release Information Command introduced in Junos OS Release 9.3.

Description Display information about the sessions established between the real-time performance monitoring (RPM) Two-Way Active Measurement Protocol (TWAMP) server and control clients. By default, all established sessions are displayed, unless you specify a session ID when you issue the command.

Options `session-id`—(Optional) Display only information about the specified session ID.

Required Privilege Level view

List of Sample Output `show services rpm twamp server session` on page 75

Output Fields Table 13 on page 75 lists the output fields for the `show services rpm twamp server session` command. Output fields are listed in the approximate order in which they appear.

Table 13: show services rpm twamp server session Output Fields

Field Name	Field Description
Session ID	Session ID that uniquely identifies the session between the TWAMP server and a particular client.
Connection ID	Connection ID that uniquely identifies the connection between the TWAMP server and a particular client.
Sender address	Sender IP address.
Sender port	Sender port number.
Reflector address	Reflector IP address.
Reflector port	Reflector port number.

Sample Output

```

show services rpm twamp server session
user@host> show services rpm twamp server session
  Session  Connection  Sender  Sender  Reflector  Reflector
   ID      ID         address  port    address    port
   4        44      1.1.1.1  12345   192.168.219.203  890
   78        44      3.22.1.55   345    22.2.2.2    89022
  234       423    192.168.219.203  2345    2.2.22.2    3333
   5        423    221.4.1.1    82345    2.2.2.2    45909
   1        423    192.168.1.1    645    32.2.2.23    2394

```


CHAPTER 5

Real-Time Router Monitoring Operational Mode Commands

Table 14 on page 77 summarizes the command-line interface (CLI) commands you can use to monitor files, interfaces, and traffic in real time. Commands are listed in alphabetical order.

Table 14: Real-Time Router Monitoring Operational Mode Commands

Task	Command
Start an Ethernet frame delay monitoring session. (MX Series, Ethernet Dense Port Concentrators only)	monitor ethernet delay-measurement
Start an Ethernet frame loss monitoring session. (MX Series, Ethernet Dense Port Concentrators only)	monitor ethernet loss-measurement
Monitor statistics for a physical interface.	monitor interface
Monitor a RSVP label-switched path (LSP).	monitor label-switched-path
Display the status of monitored log and trace files.	monitor list
Start displaying the system log or trace file and additional entries being added to those files.	monitor start
Stop displaying the system log or trace file.	monitor stop
Monitor packet headers transmitted through network interfaces sent from or received by the Routing Engine.	monitor traffic
Display trace information about an IP multicast path.	mtrace
Display trace information about a IP multicast path from a source to the router.	mtrace from-source
Listen passively for IP multicast responses.	mtrace monitor
Display trace information about an IP multicast path from the router to a gateway router.	mtrace to-gateway

Table 14: Real-Time Router Monitoring Operational Mode Commands (*continued*)

Task	Command
Determine the route to a network system.	traceroute
Monitor the route to a network system.	traceroute monitor
Monitor the route to a remote host for an MPLS LSP signaled by LDP.	traceroute mpls ldp
Monitor the route to a remote host for an MPLS LSP signaled by RSVP.	traceroute mpls rsvp



NOTE: For information about how to configure interface parameters, see the *Junos OS Network Interfaces Configuration Guide*.

For information about how to configure IP multicast parameters, see the *Junos OS Multicast Protocols Configuration Guide*.

For information about related tasks performed by network operations center (NOC) personnel, see the *Junos Baseline Network Operations Guide*.

monitor ethernet delay-measurement

Syntax monitor ethernet delay-measurement
 maintenance-domain *md-name*
 maintenance-association *ma-name*
 (one-way | two-way)
 (*remote-mac-address* | mep *remote-mep-id*)
 <count *frame-count*>
 <wait *interval-seconds*>
 <priority *802.1p value*>
 <size>
 <no-session-id-tlv>
 <xml>

Release Information Command introduced in Junos OS Release 9.5.

Description (Interfaces on Ethernet Dense Port Concentrators in MX Series routers only) Start an ITU-T Y.1731 Ethernet frame delay measurement session between the specified local connectivity fault management (CFM) maintenance association end point (MEP) and the specified remote MEP, and display a summary of the frames exchanged in the measurement session. Frame delay measurement statistics are stored at one of the MEPs for later retrieval.



NOTE: If you attempt to monitor delays to a nonexistent MAC address, you must type Ctrl +c to explicitly quit the **monitor ethernet delay-measurement** command and return to the CLI command prompt.

To start an Ethernet frame delay measurement session, the router initiates an exchange of frames carrying one-way or two-way frame delay measurement protocol data units (PDUs) between the local and remote MEPs. The frame counts—the types of and number of Ethernet frame delay measurement PDU frames exchanged to measure frame delay times—are displayed as the run-time output of the **monitor ethernet delay-measurement** command and are also stored at both the initiator and receiver MEPs for later retrieval. Ethernet frame delay measurement statistics, described below, are measured and stored at only one of the MEPs:

Frame delay—The difference, in microseconds, between the time a frame is sent and when it is received.

Frame delay variation—The difference, in microseconds, between consecutive frame delay values. Frame delay variation is sometimes called “frame jitter.”

For one-way Ethernet frame delay measurement, only the receiver MEP (on the remote system) collects statistics. For two-way Ethernet frame delay measurement, only the initiator MEP (on the local system) collects statistics.

Options maintenance-domain *md-name*—Name of an existing CFM maintenance domain.
 maintenance-association *ma-name*—Name of an existing CFM maintenance association.

one-way—Measurement type is one-way Ethernet frame delay measurement, which is based on the difference between the time at which the initiator MEP sends a one-way delay measurement request (IDM) frame and the time at which the receiver MEP receives the frame.

two-way—Measurement type is two-way Ethernet frame delay measurement, which is based on the difference between the time at which the initiator MEP sends a two-way delay measurement message (DMM) frame and the time at which the initiator MEP receives an associated two-way delay measurement reply (DMR) frame from the responder MEP, subtracting the time elapsed at the responder MEP.

mep remote-mep-id—Numeric identifier of the peer MEP with which to perform Ethernet frame delay measurement. The discovered MAC address of the peer MEP is used. The range of values is 1 through 8191.

remote-mac-address—Unicast MAC address of the peer MEP with which to perform Ethernet frame delay measurement. Specify the MAC address as six hexadecimal bytes in one of the following formats: *nnnn.nnnn.nnnn* or *nn:nn:nn:nn:nn:nn*. For example, **0011.2233.4455** or **00:11:22:33:44:55**. Multicast MAC addresses are not supported.

count frame-count—(Optional) Number of frames to send to the specified peer MEP. The range of values is 1 through 65,535 frames. The default value is 10 frames.

wait interval-seconds—(Optional) Number of seconds to wait between sending frames. The range of values is from 1 through 255 seconds. The default value is 1 second.

priority 802.1p value—(Optional) Priority of the delay measurement request frame supported by both one-way delay measurement and two-way delay measurement. The range of values is from 0 through 7. The default value is zero.

size—(Optional) Size of the data TLV to be included in the request frame. The range of values is from 1 through 1400 bytes.

no-session-id-tlv—(Optional) Prevent insertion of the session ID TLV in the request frame.

xml—(Optional) Allow the output of the command to be displayed in XML format supported by both one-way delay measurement and two-way delay measurement. Note that the only way to get output in XML format is to use the **xml** argument. The **display xml** command does not work.

Additional Information To display the frame counts collected at an MEP as the result of this command, see the following command descriptions in the [Junos OS Interfaces Command Reference](#):

- **show oam ethernet connectivity-fault-management interfaces detail**
- **show oam ethernet connectivity-fault-management mep-database**
- **show oam ethernet connectivity-fault-management mep-statistics**

To display the statistics collected at an MEP as the result of this command, see the following command descriptions in the [Junos OS Interfaces Command Reference](#).

- **show oam ethernet connectivity-fault-management delay-statistics**
- **show oam ethernet connectivity-fault-management mep-statistics**

To clear both the frame counts and the statistics collected for MEPs, use the **clear oam ethernet connectivity-fault-management statistics** command, described in the [Junos OS Interfaces Command Reference](#).

For a complete description of Ethernet frame delay measurement, see the *ITU-T Y.1731 Ethernet Service OAM* topics in the [Junos OS Network Interfaces Configuration Guide](#).

Required Privilege Level	trace and maintenance
List of Sample Output	monitor ethernet delay-measurement one-way on page 82 monitor ethernet delay-measurement two-way on page 82 monitor ethernet delay-measurement two-way (Invalid DMR Frames Received) on page 83
Output Fields	<p>The monitor ethernet delay-measurement command displays different output at the CLI, depending on whether you start a one-way or two-way frame delay measurement:</p> <ul style="list-style-type: none"> • Table 15 on page 81 lists the run-time output fields for the monitor ethernet delay-measurement one-way command. • Table 16 on page 82 lists the run-time output fields for the monitor ethernet delay-measurement two-way command. <p>Output fields are listed in the approximate order in which they appear.</p>

Table 15: monitor ethernet delay-measurement one-way Output Fields

Output Field Name	Output Field Description
One-way ETH-DM request to	Unicast MAC address of the remote peer MEP.
Interface	Name of the Ethernet physical, logical, or trunk interface to which the local MEP is attached.
IDM Frames sent	PDU frames sent to the remote MEP in this ETH-DM session.
Packets transmitted	Total number of IDM PDU frames sent to the remote MEP during this measurement session.
Average delay	Average two-way frame delay measured in this session.
Average delay variation	Average frame jitter measured in this session.
Best case delay	Lowest two-way frame delay measured in this session.
Worst case delay	Highest two-way frame delay measured in this session.

Table 15: monitor ethernet delay-measurement one-way Output Fields (*continued*)

Output Field Name	Output Field Description
-------------------	--------------------------

NOTE: For one-way delay measurement, these CLI output fields display **NA** ("not applicable") at the initiator MEP because one-way frame delay measurements occur at the receiver MEP.

Table 16: monitor ethernet delay-measurement two-way Output Fields

Output Field Name	Output Field Description
Two-way Ethernet frame delay measurement request to	Unicast MAC address of the remote peer MEP.
Interface	Name of the Ethernet physical, logical, or trunk interface to which the local MEP is attached.
DMR received from	Unicast MAC address of the remote MEP that transmitted this DMR frame in response to a DMM frame.
Delay	Two-way delay, in microseconds, for the initiator-transmitted DMM frame.
Delay variation	Difference, in microseconds, between the current and previous delay values. This is also known as <i>jitter</i> .
Packets transmitted	Total number of DMM PDU frames sent to the remote MEP in this measurement session.
Valid packets received	Total number of DMR PDU frames received from the remote MEP in this measurement session.
Average delay	Average two-way frame delay measured in this session.
Average delay variation	Average frame jitter measured in this session.
Best case delay	Lowest two-way frame delay measured in this session.
Worst case delay	Highest two-way frame delay measured in this session.

Sample Output

**monitor ethernet
delay-measurement
one-way**

```
user@host> monitor ethernet delay-measurement one-way 00:05:85:73:39:4a
maintenance-domain md6 maintenance-association ma6 count 10
One-way ETH-DM request to 00:05:85:73:39:4a, Interface xe-5/0/0.0
1DM Frames sent : 10
--- Delay measurement statistics ---
Packets transmitted: 10
Average delay: NA, Average delay variation: NA
Best case delay: NA, Worst case delay: NA
```

**monitor ethernet
delay-measurement
two-way**

```
user@host> monitor ethernet delay-measurement two-way 00:05:85:73:39:4a
maintenance-domain md6 maintenance-association ma6 count 10
Two-way ETH-DM request to 00:05:85:73:39:4a, Interface xe-5/0/0.0
DMR received from 00:05:85:73:39:4a Delay: 100 usec Delay variation: 0 usec
DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 8 usec
```

```

DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 0 usec
DMR received from 00:05:85:73:39:4a Delay: 111 usec Delay variation: 19 usec
DMR received from 00:05:85:73:39:4a Delay: 110 usec Delay variation: 1 usec
DMR received from 00:05:85:73:39:4a Delay: 119 usec Delay variation: 9 usec
DMR received from 00:05:85:73:39:4a Delay: 122 usec Delay variation: 3 usec
DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 30 usec
DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 0 usec
DMR received from 00:05:85:73:39:4a Delay: 108 usec Delay variation: 16 usec

```

```

--- Delay measurement statistics ---

```

```

Packets transmitted: 10, Valid packets received: 10
Average delay: 103 usec, Average delay variation: 8 usec
Best case delay: 92 usec, Worst case delay: 122 usec

```

**monitor ethernet
delay-measurement
two-way (Invalid DMR
Frames Received)**

```

user@host> monitor ethernet delay-measurement two-way 00:05:85:73:39:4a
maintenance-domain md6 maintenance-association ma6 count 10

```

```

Two-way ETH-DM request to 00:05:85:73:39:4a, Interface xe-5/0/0.0

```

```

DMR received from 00:05:85:73:39:4a Delay: 100 usec Delay variation: 0 usec
DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 8 usec
DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 0 usec
DMR received from 00:05:85:73:39:4a Delay: 111 usec Delay variation: 19 usec
DMR received from 00:05:85:73:39:4a Delay: 110 usec Delay variation: 1 usec
DMR received from 00:05:85:73:39:4a Delay: 119 usec Delay variation: 9 usec
DMR received from 00:05:85:73:39:4a Delay: 122 usec Delay variation: 3 usec
DMR received from 00:05:85:73:39:4a Delay: 92 usec Delay variation: 30 usec
DMR received from 00:05:85:73:39:4a with invalid timestamp(s).
DMR received from 00:05:85:73:39:4a Delay: 108 usec Delay variation: 16 usec

```

```

--- Delay measurement statistics ---

```

```

Packets transmitted: 10, Valid packets received: 9, Invalid packets received: 1
Average delay: 105 usec, Average delay variation: 9 usec
Best case delay: 92 usec, Worst case delay: 122 usec

```

monitor ethernet loss-measurement

Syntax monitor ethernet loss-measurement
 maintenance-domain *md-name*
 maintenance-association *ma-name*
 (*remote-mac-address* | mep *remote-mep-id*)
 <count *frame-count*>
 <wait *interval-seconds*>
 <priority *802.1p value*>
 <no-session-id-tlv>
 <xml>

Release Information Command introduced in Junos OS Release 11.1.

Description (Interfaces on Ethernet Dense Port Concentrators in MX Series routers only) Start an ITU-T Y.1731 Ethernet frame loss measurement session between the specified local connectivity fault management (CFM) maintenance association end point (MEP) and the specified remote MEP, and display a count of transmitted and received data frames between the pair of MEPs. Frame loss measurement statistics are stored at one of the MEPs for later retrieval.



NOTE: If you attempt to monitor loss to a nonexistent MAC address, you must type Ctrl + c to explicitly quit the **monitor ethernet loss-measurement** command and return to the CLI command prompt.

To start an Ethernet frame loss measurement session, the router first sends frames with ETH-LM information to a peer MEP and similarly receives frames with ETH-LM information from the peer MEP. Frame loss is calculated by collecting the counter values applicable for ingress and egress service frames where the counters maintain a count of transmitted and received data frames between a pair of MEPs. The loss measurement statistics are retrieved as the output of the **monitor ethernet loss-measurement** command and are also stored at the initiator. The frames counts are stored at both the initiator and the receiver MEPs for later retrieval.

Options maintenance-domain *md-name*—Name of an existing CFM maintenance domain.

maintenance-association *ma-name*—Name of an existing CFM maintenance association.

mep *remote-mep-id*—Numeric identifier of the peer MEP with which to perform Ethernet frame loss measurement. The discovered MAC address of the peer MEP is used. The range of values is from 1 through 8192.

remote-mac-address—Unicast MAC address of the peer MEP with which to perform Ethernet frame loss measurement. Specify the MAC address as six hexadecimal bytes in one of the following formats: *nnnn.nnnn.nnnn* or *nn:nn:nn:nn:nn:nn* (for example, 0011.2233.4455 or 00:11:22:33:44:55). Multicast MAC addresses are not supported.

count *frame-count*—(Optional) Number of frames to send to the specified peer MEP. The range of values is from 1 through 65535 frames. The default value is 10 frames.

wait *interval-seconds*—(Optional) Number of seconds to wait between sending frames. The range of values is from 1 through 255 seconds. The default value is 1 second.

priority *802.1p value*—(Optional) Priority of the delay measurement request frame. The range of values is from 0 through 7. The default value is 1 second.

no-session-id-tlv—(Optional) Disable the **session id TLV** argument set in the request frame.

xml—(Optional) Allow the output of the command to be displayed in XML format.

Additional Information To display the frame counts collected at an MEP as the result of this command, see the following command descriptions in the [Junos OS Interfaces Command Reference](#):

- **show oam ethernet connectivity-fault-management loss-statistics**
- **show oam ethernet connectivity-fault-management interfaces detail**
- **show oam ethernet connectivity-fault-management mep-database**
- **show oam ethernet connectivity-fault-management mep-statistics**

To display the statistics collected at an MEP as the result of this command, see the following command descriptions in the [Junos OS Interfaces Command Reference](#):

- **show oam ethernet connectivity-fault-management delay-statistics**
- **show oam ethernet connectivity-fault-management mep-statistics**

To clear both the frame counts and the statistics collected for MEPs, use the **clear oam ethernet connectivity-fault-management loss-statistics maintenance-domain *md-name* maintenance-association *ma-name*** command, as described in the [Junos OS Interfaces Command Reference](#).

For a complete description of Ethernet frame loss measurement, see the *ITU-T Y.1731 Ethernet Service OAM* topics in the [Junos OS Network Interfaces Configuration Guide](#).

Required Privilege Level trace and maintenance

List of Sample Output **monitor ethernet loss-measurement (with only CIR counters enabled)** on page 87
monitor ethernet loss-measurement (with CIR and EIR counters enabled) on page 87

Output Fields Table 17 on page 86 lists the output fields for the **monitor ethernet loss-measurement** command and their descriptions. Output fields are listed in the approximate order in which they appear.

Table 17: monitor ethernet loss-measurement output fields

Output Field Name	Output Field Description
Ethernet loss delay measurement request to	Unicast MAC address of the remote peer MEP.
Interface	Name of the Ethernet physical, logical, or trunk interface to which the local MEP is attached.
LMR received from	Unicast MAC address of the remote MEP that transmitted this LMR frame in response to a loss measurement message (LMM) frame.
Near-end frame loss	Count of frame loss associated with ingress data frames.
Far-end frame loss	Count of frame loss associated with egress data frames.
Near-end loss ratio	Ratio, expressed as a percentage, of the number of service frames not delivered divided by the total number of service frames during time interval T at the ingress interface.
Far-end loss ratio	Ratio, expressed as a percentage, of the number of service frames not delivered divided by the total number of service frames during time interval T at the egress interface.
LMM packets transmitted	Total number of LMM PDU frames sent to the remote MEP in this measurement session.
LMR packets received	Total number of LMR PDU frames received from the remote MEP in this measurement session.
Average near-end frame loss	Average frame loss measured in this session associated with ingress data frames.
Average near-end loss ratio	Average frame loss ratio measured in this session associated with ingress data frames.
Average far-end frame loss	Average frame loss measured in this session associated with egress data frames.
Average far-end loss ratio	Average frame loss ratio measured in this session associated with egress data frames.
Near-end best case frame loss	Lowest frame loss measured in this session associated with ingress data frames.
Near-end best case loss ratio	Lowest frame loss ratio measured in this session associated with ingress data frames.
Near-end worst case frame loss	Highest frame loss measured in this session associated with ingress data frames.
Near-end worst case loss ratio	Highest frame loss ratio measured in this session associated with ingress data frames.
Far-end best case frame loss	Lowest frame loss measured in this session associated with egress data frames.
Far-end best case loss ratio	Lowest frame loss ratio measured in this session associated with egress data frames.

Table 17: monitor ethernet loss-measurement output fields (*continued*)

Output Field Name	Output Field Description
Far-end worst case frame loss	Highest frame loss measured in this session associated with egress data frames.
Far-end worst case loss ratio	Highest frame loss ratio measured in this session associated with egress data frames.

Note that in the preceding table, the term *number of service frames not delivered* is the difference between the number of service frames arriving at the ingress Ethernet flow point and the number of service frames delivered at the egress Ethernet flow point in a point-to-point Ethernet connection.

Sample Output

monitor ethernet loss-measurement (with only CIR counters enabled)

```
user@host> monitor ethernet loss-measurement 00:05:85:73:39:4a maintenance-domain md6
maintenance-association ma6 count 5
ETH-LM request to 00:05:85:73:39:4a, Interface ge-5/0/0.0
LMR received from 00:05:85:73:39:4a
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 4 Far-end frame loss (CIR) : 6
Near-end loss ratio (CIR) : 4% Far-end loss ratio (CIR) : 6%
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 6 Far-end frame loss (CIR) : 8
Near-end loss ratio (CIR) : 6% Far-end loss ratio (CIR) : 8%
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 2 Far-end frame loss (CIR) : 2
Near-end loss ratio (CIR) : 2% Far-end loss ratio (CIR) : 2%
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 6 Far-end frame loss (CIR) : 4
Near-end loss ratio (CIR) : 6% Far-end loss ratio (CIR) : 4%
```

```
--- Loss measurement statistics ---
LMM packets transmitted: 5, LMR packets received: 5
Average near-end frame loss (CIR) : 4.5
Average near-end loss ratio (CIR) : 4.5%
Average far-end frame loss (CIR) : 5
Average far-end loss ratio (CIR) : 5%
Near-end best case frame loss (CIR) : 2
Near-end best case loss ratio (CIR) : 2%
Near-end worst case frame loss (CIR) : 6
Near-end worst case loss ratio (CIR) : 6%
Far-end best case frame loss (CIR) : 2
Far-end best case loss ratio (CIR) : 2%
Far-end worst case frame loss (CIR) : 8
Far-end worst case loss ratio (CIR) : 8%
```

monitor ethernet loss-measurement (with CIR and EIR counters enabled)

```
user@host> monitor ethernet loss-measurement 00:05:85:73:39:4a maintenance-domain md6
maintenance-association ma6 count 5
ETH-LM request to 00:05:85:73:39:4a, Interface ge-5/0/0.0
LMR received from 00:05:85:73:39:4a
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 2 Far-end frame loss (CIR) : 4
Near-end loss ratio (CIR) : 2% Far-end loss ratio (CIR) : 4%
Near-end frame loss (EIR) : 0 Far-end frame loss (EIR) : 6
```

```

Near-end loss ratio (EIR) : 0%   Far-end loss ratio (EIR) : 6%
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 8     Far-end frame loss (CIR) : 5
Near-end loss ratio (CIR) : 8%   Far-end loss ratio (CIR) : 5%
Near-end frame loss (EIR) : 4     Far-end frame loss (EIR) : 1
Near-end loss ratio (EIR) : 4%   Far-end loss ratio (EIR) : 1%
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 10    Far-end frame loss (CIR) : 4
Near-end loss ratio (CIR) : 10%  Far-end loss ratio (CIR) : 4%
Near-end frame loss (EIR) : 1     Far-end frame loss (EIR) : 3
Near-end loss ratio (EIR) : 1%   Far-end loss ratio (EIR) : 3%
LMR received from 00:05:85:73:39:4a
Near-end frame loss (CIR) : 6     Far-end frame loss (CIR) : 2
Near-end loss ratio (CIR) : 6%   Far-end loss ratio (CIR) : 2%
Near-end frame loss (EIR) : 8     Far-end frame loss (EIR) : 0
Near-end loss ratio (EIR) : 8%   Far-end loss ratio (EIR) : 0%

```

--- Loss measurement statistics ---

```

LMM packets transmitted: 5,   LMR packets received: 5
Average near-end frame loss (CIR) : 6.5
Average near-end loss ratio (CIR) : 6.5%
Average far-end frame loss (CIR) : 3.75
Average far-end loss ratio (CIR) : 3.75%
Near-end best case frame loss (CIR) : 2
Near-end best case loss ratio (CIR) : 2%
Near-end worst case frame loss (CIR) : 10
Near-end worst case loss ratio (CIR) : 10%
Far-end best case frame loss (CIR) : 2
Far-end best case loss ratio (CIR) : 2%
Far-end worst case frame loss (CIR) : 6
Far-end worst case loss ratio (CIR) : 6%
Average near-end frame loss (EIR) : 3.25
Average near-end loss ratio (EIR) : 3.25%
Average far-end frame loss (EIR) : 2.5
Average far-end loss ratio (EIR) : 2.5%
Near-end best case frame loss (EIR) : 0
Near-end Best case loss ratio (EIR) : 0%
Near-end worst case frame loss (EIR) : 8
Near-end Worst case loss ratio (EIR) : 8%
Far-end best case frame loss (EIR) : 0
Far-end Best case loss ratio (EIR) : 0%
Far-end worst case frame loss (EIR) : 6
Far-end Worst case loss ratio (EIR) : 6%

```


monitor interface

Syntax	monitor interface <interface-name traffic <detail>>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display real-time statistics about interfaces, updating the statistics every second. Check for and display common interface failures, such as SONET/SDH and T3 alarms, loopbacks detected, and increases in framing errors.
Options	<p>none—Display real-time statistics for all interfaces.</p> <p>interface-name—(Optional) Display real-time statistics for the specified interface.</p> <p>traffic—(Optional) Display traffic data for all active interfaces.</p> <p>detail—(Optional) With traffic option only, display detailed output.</p>
Additional Information	The output of this command shows how much each field has changed since you started the command or since you cleared the counters by using the c key. For a description of the statistical information provided in the output of this command, see the show interfaces extensive command for a particular interface type in the Junos OS Interfaces Command Reference . To control the output of the monitor interface interface-name command while it is running, use the keys listed in Table 18 on page 89. The keys are not case-sensitive.

Table 18: Output Control Keys for the monitor interface interface-name Command

Key	Action
c	Clears (returns to zero) the delta counters since monitor interface was started. This does not clear the accumulative counter. To clear the accumulative counter, use the clear interfaces interval command.
f	Freezes the display, halting the display of updated statistics and delta counters.
i	Displays information about a different interface. The command prompts you for the name of a specific interface.
n	Displays information about the next interface. The monitor interface command displays the physical or logical interfaces in the same order as the show interfaces terse command.
q or Esc	Quits the command and returns to the command prompt.
t	Thaws the display, resuming the update of the statistics and delta counters.

To control the output of the **monitor interface traffic** command while it is running, use the keys listed in Table 19 on page 90. The keys are not case-sensitive.

Table 19: Output Control Keys for the monitor interface traffic Command

Key	Action
b	Displays the statistics in units of bytes and bytes per second (bps).
c	Clears (return to 0) the delta counters in the Current Delta column. The statistics counters are not cleared.
d	Displays the Current Delta column (instead of the rate column) in bps or packets per second (pps).
p	Displays the statistics in units of packets and packets per second (pps).
q or Esc	Quits the command and returns to the command prompt.
r	Displays the rate column (instead of the Current Delta column) in bps and pps.

Required Privilege Level trace

List of Sample Output **monitor interface (Physical)** on page 91
monitor interface (OTN Interface) on page 93
monitor interface (Logical) on page 94
monitor interface traffic on page 94
monitor interface traffic detail on page 95

Output Fields Table 20 on page 90 describes the output fields for the **monitor interface** command. Output fields are listed in the approximate order in which they appear.

Table 20: monitor interface Output Fields

Field Name	Field Description	Level of Output
routerl	Hostname of the router.	All levels
Seconds	How long the monitor interface command has been running or how long since you last cleared the counters.	All levels
Time	Current time (UTC).	All levels
Delay x/y/z	Time difference between when the statistics were displayed and the actual clock time. <ul style="list-style-type: none"> x—Time taken for the last polling (in milliseconds). y—Minimum time taken across all pollings (in milliseconds). z—Maximum time taken across all pollings (in milliseconds). 	All levels
Interface	Short description of the interface, including its name, status, and encapsulation.	All levels
Link	State of the link: Up , Down , or Test .	All levels

Table 20: monitor interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
Current delta	Cumulative number for the counter in question since the time shown in the Seconds field, which is the time since you started the command or last cleared the counters.	All levels
Local Statistics	<p>(Logical interfaces only) Number and rate of bytes and packets destined to the router or switch through the specified interface. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.:</p> <ul style="list-style-type: none"> • Input bytes—Number of bytes received on the interface. • Output bytes—Number of bytes transmitted on the interface. • Input packets—Number of packets received on the interface. • Output packets—Number of packets transmitted on the interface. 	All levels
Remote Statistics	<p>(Logical interfaces only) Statistics for traffic transiting the router or switch. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.:</p> <ul style="list-style-type: none"> • Input bytes—Number of bytes received on the interface. • Output bytes—Number of bytes transmitted on the interface. • Input packets—Number of packets received on the interface. • Output packets—Number of packets transmitted on the interface. 	All levels
Traffic statistics	<p>Total number of bytes and packets received and transmitted on the interface. These statistics are the sum of the local and remote statistics. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.</p> <ul style="list-style-type: none"> • Input bytes—Number of bytes received on the interface. • Output bytes—Number of bytes transmitted on the interface. • Input packets—Number of packets received on the interface. • Output packets—Number of packets transmitted on the interface. 	All levels
Description	With the traffic option, displays the interface description configured at the [edit interfaces <i>interface-name</i>] hierarchy level.	detail

Sample Output

```

monitor interface so-0/0/0
(Physical) user@host> monitor interface so-0/0/0
router1 Seconds: 19 Time: 15:46:29

Interface: so-0/0/0, Enabled, Link is Up
Encapsulation: PPP, Keepalives, Speed: 0C48
Traffic statistics:
Input packets: 6045 (0 pps) Current Delta [11]
Input bytes: 6290065 (0 bps) [13882]
Output packets: 10376 (0 pps) [10]
Output bytes: 10365540 (0 bps) [9418]
Encapsulation statistics:

```

Input keepalives:	1901	[2]
Output keepalives:	1901	[2]
NCP state: Opened		
LCP state: Opened		
Error statistics:		
Input errors:	0	[0]
Input drops:	0	[0]
Input framing errors:	0	[0]
Policed discards:	0	[0]
L3 incompletes:	0	[0]
L2 channel errors:	0	[0]
L2 mismatch timeouts:	0	[0]
Carrier transitions:	1	[0]
Output errors:	0	[0]
Output drops:	0	[0]
Aged packets:	0	[0]
Active alarms :	None	
Active defects:	None	
SONET error counts/seconds:		
LOS count	1	[0]
LOF count	1	[0]
SEF count	1	[0]
ES-S	0	[0]
SES-S	0	[0]
SONET statistics:		
BIP-B1	458871	[0]
BIP-B2	460072	[0]
REI-L	465610	[0]
BIP-B3	458978	[0]
REI-P	458773	[0]

```

Received SONET overhead:
  F1      : 0x00  J0      : 0x00  K1      : 0x00
  K2      : 0x00  S1      : 0x00  C2      : 0x00
  C2(cmp) : 0x00  F2      : 0x00  Z3      : 0x00
  Z4      : 0x00  S1(cmp) : 0x00
Transmitted SONET overhead:
  F1      : 0x00  J0      : 0x01  K1      : 0x00
  K2      : 0x00  S1      : 0x00  C2      : 0xcf
  F2      : 0x00  Z3      : 0x00  Z4      : 0x00

```

Next='n', Quit='q' or ESC, Freeze='f', Thaw='t', Clear='c', Interface='i'

monitor interface user@host> **monitor interface ge-7/0/0**
(OTN Interface)

```

Interface: ge-7/0/0, Enabled, Link is Up
Encapsulation: Ethernet, Speed: 10000Mbps
Traffic statistics:
  Input bytes:                0 (0 bps)
  Output bytes:               0 (0 bps)
  Input packets:              0 (0 pps)
  Output packets:             0 (0 pps)
Error statistics:
  Input errors:                0
  Input drops:                 0
  Input framing errors:        0
  Policed discards:            0
  L3 incompletes:              0
  L2 channel errors:           0
  L2 mismatch timeouts:        0
  Carrier transitions:         5
  Output errors:               0
  Output drops:                0
  Aged packets:                0
Active alarms : None
Active defects: None
Input MAC/Filter statistics:
  Unicast packets              0
  Broadcast packets            0
  Multicast packets            0
  Oversized frames             0
  Packet reject count          0
  DA rejects                   0
  SA rejects                   0
Output MAC/Filter Statistics:
  Unicast packets              0
  Broadcast packets            0
  Multicast packets            0
  Packet pad count             0
  Packet error count           0
OTN Link 0
OTN Alarms: OTU_BDI, OTU_TTIM, ODU_BDI
OTN Defects: OTU_BDI, OTU_TTIM, ODU_BDI, ODU_TTIM
OTN OC - Seconds
  LOS                          2
  LOF                          9
OTN OTU - FEC Statistics
  Corr err ratio                N/A
  Corr bytes                    0
  Uncorr words                  0
OTN OTU - Counters

```

```

BIP                                0
BBE                                0
ES                                 0
SES                                0
UAS                                422
OTN ODU - Counters
BIP                                0
BBE                                0
ES                                 0
SES                                0
UAS                                422
OTN ODU - Received Overhead    APSGCC 0-3:          0

```

```

monitor interface user@host> monitor interface so-1/0/0.0
(Logical)          host name                Seconds: 16                Time: 15:33:39
                                                           Delay: 0/0/1

Interface: so-1/0/0.0, Enabled, Link is Down
Flags: Hardware-Down Point-To-Point SNMP-Traps
Encapsulation: PPP
Local statistics:
Input bytes:                0                                Current delta [0]
Output bytes:               0                                [0]
Input packets:              0                                [0]
Output packets:             0                                [0]
Remote statistics:
Input bytes:                0 (0 bps)                        [0]
Output bytes:               0 (0 bps)                        [0]
Input packets:              0 (0 pps)                        [0]
Output packets:             0 (0 pps)                        [0]
Traffic statistics:
Destination address: 192.168.8.193, Local: 192.168.8.21

Next='n', Quit='q' or ESC, Freeze='f', Thaw='t', Clear='c', Interface='i'

```

```

monitor interface user@host> monitor interface traffic
traffic          host name                Seconds: 15                Time: 12:31:09

Interface  Link  Input packets  (pps)  Output packets  (pps)
so-1/0/0   Down    0              (0)    0              (0)
so-1/1/0   Down    0              (0)    0              (0)
so-1/1/1   Down    0              (0)    0              (0)
so-1/1/2   Down    0              (0)    0              (0)
so-1/1/3   Down    0              (0)    0              (0)
t3-1/2/0   Down    0              (0)    0              (0)
t3-1/2/1   Down    0              (0)    0              (0)
t3-1/2/2   Down    0              (0)    0              (0)
t3-1/2/3   Down    0              (0)    0              (0)
so-2/0/0   Up      211035         (1)    36778          (0)
so-2/0/1   Up      192753         (1)    36782          (0)
so-2/0/2   Up      211020         (1)    36779          (0)
so-2/0/3   Up      211029         (1)    36776          (0)
so-2/1/0   Up      189378         (1)    36349          (0)
so-2/1/1   Down    0              (0)    18747          (0)
so-2/1/2   Down    0              (0)    16078          (0)
so-2/1/3   Up      0              (0)    80338          (0)
at-2/3/0   Up      0              (0)    0              (0)
at-2/3/1   Down    0              (0)    0              (0)

Bytes=b, Clear=c, Delta=d, Packets=p, Quit=q or ESC, Rate=r, Up=^U, Down=^D

```

```
monitor interface traffic detail user@host> monitor interface traffic detail
host name                      Seconds: 15                      Time: 12:31:09

Interface    Link  Input packets  (pps)  Output packets  (pps)  Description
-----
t1-0/1/1:0  Up    19769          (0)    0              (0)    To-OSAKA-1
...

Bytes=b, Clear=c, Delta=d, Packets=p, Quit=q or ESC, Rate=r, Up=^U, Down=^D
```

monitor label-switched-path

Syntax `monitor label-switched-path lsp-name`

Release Information Command introduced before Junos OS Release 7.4.

Description Display the real-time status of the specified RSVP label-switched path (LSP).

Options *lsp-name*—Name of the LSP.

Additional Information You can track the amount of traffic traversing an RSVP LSP and observe its essential parameters, such as uptime, ingress and egress addresses, labels, routes, and ports. Values are typically sampled every second. The display also allows you to scroll to other currently running LSPs. You cannot use this command to display information about static LSPs or LDP-signaled LSPs.

The output of this command shows how much each field has changed since you started the command or since you cleared the counters by using the `c` key. To control the output of the **monitor label-switched-path** command while it is running, use the keys listed in Table 21 on page 96. The keys are not case-sensitive.

Table 21: Output Control Keys for the monitor label-switched-path Command

Key	Action
c	Clears the screen and refreshes the display for this LSP.
f	Freezes the display, preventing new information from being displayed.
l	Monitors a different LSP. After you type <code>l</code> , you can type the new LSP name.
n	Displays information about the next LSP (whose name is alphabetically higher than the current LSP name) configured on the router.
p	Goes to the previous LSP (whose name is alphabetically lower than the current LSP name) configured on the router.
q or Esc	Quits the command and returns to the command prompt.
t	Thaws, or restarts, the data display for this LSP.

Required Privilege Level trace

List of Sample Output **monitor label-switched-path on page 97**

Output Fields Table 22 on page 97 describes the output fields for the **monitor label-switched-path** command. Output fields are listed in the approximate order in which they appear.

Table 22: monitor label-switched-path Output Fields

Field Name	Field Description
(1)	Displays the following information: <ul style="list-style-type: none"> • hostname—Name of the router. • Seconds—Time elapsed since this display was started. • Time—Current local time.
(2)	Delay —Length of the time delay, in milliseconds, required to obtain the information in the monitor display. The first number shows the current sampling delay. The second number shows the shortest delay recorded to date. The third number shows the worst delay recorded to date. This delay can vary substantially depending on the system load.
(3)	Displays the following: <ul style="list-style-type: none"> • To—Destination address of the LSP. • From—Originating address of the LSP. • State—Current state of the LSP: Up or Down.
(4)	Displays the following: <ul style="list-style-type: none"> • LSPName—Name of the LSP. • Type—Type of LSP: Ingress, Egress, or Transit.
(5)	Displays the following: <ul style="list-style-type: none"> • Label in—Incoming label of the LSP. • Label out—Outgoing label of the LSP.
(6)	Port number —Port number for the sending router, the port number for the receiving router, and the protocol ID. For MPLS traffic engineering applications, the protocol ID is always 0.
(7/8)	Record route —All intermediate and egress router addresses for this LSP.
(9/10/11)	Displays traffic statistics: <ul style="list-style-type: none"> • Output packets—Number of packets that have traversed this LSP, and the change (delta) in the number since the last sample, typically 1 second ago. • Output bytes—Number of bytes that have traversed this LSP, and the change (delta) in the number since the last sample, typically 1 second ago.
(12)	Displays any errors the router encountered while attempting to retrieve information on the LSP.
(13)	Lists the keyboard commands you can use to navigate to other LSPs. For a description of the keyboard commands, see Table 21 on page 96.

Sample Output

```

monitor user@host> monitor label-switched-path
label-switched-path (1) host                      Seconds: 112           Time: 15:32:22
(2)                                           Delay: 0/0/0
(3) To 10.10.10.16, From 10.10.10.17, state: Up
(4) LSPname: k, type: Ingress

```

```

(5)  Label in: -, Label out: 126000
(6)  Port number: sender 1, receiver 45583, protocol 0
(7)  Record Route: <self> 192.168.224.196
(8)  192.168.224.202 192.168.224.179
(9)  Traffic statistics:
(10) Output packets:                0                      Current delta [0]
(11) Output bytes:                  0                      [0]
(12)
(13) Next='n', Prev='p', Quit='q' or ESC, Freeze='f', Thaw='t', Clear='c',
    LSP=']'

```

monitor list

Syntax	monitor list
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the status of monitored log and trace files.
Options	This command has no options.
Additional Information	Log files are generated by the routing protocol process or by system logging. The log files generated by system logging are configured with the syslog statement at the [edit system] hierarchy level and the options statement at the [edit routing-options] hierarchy level. The trace files generated by the routing protocol process are those configured with traceoptions statements at the [edit routing-options] , [edit interfaces] , and [edit protocols protocol] hierarchy levels.
Required Privilege Level	trace
Related Documentation	<ul style="list-style-type: none"> • monitor start on page 100 • monitor stop on page 102
List of Sample Output	monitor list on page 99
Output Fields	Table 23 on page 99 describes the output fields for the monitor list command. Output fields are listed in the approximate order in which they appear.

Table 23: monitor list Output Fields

Field Name	Field Description
monitor start	Indicates the file is being monitored.
"filename"	Name of the file that is being monitored.
Last changed	Date and time at which the file was last modified.

Sample Output

```

monitor list user@host> monitor list
monitor start "vrrpd" (Last changed Dec 03:11:06 20)
monitor start "cli-commands" (Last changed Nov 07:3)

```

monitor start

Syntax	<code>monitor start <i>filename</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Start displaying the system log or trace file and additional entries being added to those files.
Options	<i>filename</i> —Specific log or trace file.
Additional Information	Log files are generated by the routing protocol process or by system logging. The log files generated by system logging are configured with the syslog statement at the [edit system] hierarchy level and the options statement at the [edit routing-options] hierarchy level. The trace files generated by the routing protocol process are configured with traceoptions statements at the [edit routing-options] , [edit interfaces] , and [edit protocols <i>protocol</i>] hierarchy levels.
Required Privilege Level	trace
Related Documentation	<ul style="list-style-type: none"> monitor list on page 99 monitor stop on page 102
List of Sample Output	monitor start on page 100
Output Fields	Table 24 on page 100 describes the output fields for the monitor start command. Output fields are listed in the approximate order in which they appear.

Table 24: monitor start Output Fields

Field Name	Field Description
<i>filename</i>	Name of the file from which entries are being displayed. This line is displayed initially and when the command switches between log files.
<i>Date and time</i>	Timestamp for the log entry.

Sample Output

```

monitor start user@host> monitor start system-log
*** system-log***
Jul 20 15:07:34 hang sshd[5845]: log: Generating 768 bit RSA key.
Jul 20 15:07:35 hang sshd[5845]: log: RSA key generation complete.
Jul 20 15:07:35 hang sshd[5845]: log: Connection from 204.69.248.180 port 912
Jul 20 15:07:37 hang sshd[5845]: log: RSA authentication for root accepted.

```

```
Jul 20 15:07:37 hang sshd[5845]: log: ROOT LOGIN as 'root' from trip.jcmax.com
Jul 20 15:07:37 hang sshd[5845]: log: Closing connection to 204.69.248.180
```

monitor stop

Syntax	<code>monitor stop <i>filename</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Stop displaying the system log or trace file.
Options	<i>filename</i> —Specific log or trace file.
Additional Information	Log files are generated by the routing protocol process or by system logging. The log files generated by system logging are those configured with the syslog statement at the [edit system] hierarchy level and the options statement at the [edit routing-options] hierarchy level. The trace files generated by the routing protocol process are those configured with traceoptions statements at the [edit routing-options] , [edit interfaces] , and [edit protocols <i>protocol</i>] hierarchy levels.
Required Privilege Level	trace
Related Documentation	<ul style="list-style-type: none">• monitor list on page 99• monitor start on page 100
List of Sample Output	monitor stop on page 102
Output Fields	This command produces no output.

Sample Output

```
monitor stop  user@host> monitor stop
```

monitor traffic

Syntax monitor traffic
 <brief | detail | extensive>
 <absolute-sequence>
 <count *count*>
 <interface *interface-name*>
 <layer2-headers>
 <matching *matching*>
 <no-domain-names>
 <no-promiscuous>
 <no-resolve>
 <no-timestamp>
 <print-ascii>
 <print-hex>
 <resolve-timeout>
 <size *size*>

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 Command introduced in Junos OS Release 11.1 for the QFX Series.

Description Display packet headers or packets received and sent from the Routing Engine.



NOTE:

- Using the **monitor-traffic** command can degrade router or switch performance.
- Delays from DNS resolution can be eliminated by using the **no-resolve** option.

Options none—(Optional) Display packet headers transmitted through **fxp0**. On a TX Matrix Plus router, display packet headers transmitted through **em0**.

brief | detail | extensive—(Optional) Display the specified level of output.

absolute-sequence—(Optional) Display absolute TCP sequence numbers.

count *count*—(Optional) Specify the number of packet headers to display (0 through 1,000,000). The monitor traffic command quits automatically after displaying the number of packets specified.

interface *interface-name*—(Optional) Specify the interface on which the **monitor traffic** command displays packet data. If no interface is specified, the **monitor traffic** command displays packet data arriving on the lowest-numbered interface.

layer2-headers—(Optional) Display the link-level header on each line.

matching *matching*—(Optional) Display packet headers that match a regular expression. Use matching expressions to define the level of detail with which the **monitor traffic** command filters and displays packet data.

no-domain-names—(Optional) Suppress the display of the domain portion of hostnames. With the **no-domain-names** option enabled, the **monitor traffic** command displays only **team** for the hostname **team.company.net**.

no-promiscuous—(Optional) Do not put the interface into promiscuous mode.

no-resolve—(Optional) Suppress reverse lookup of the IP addresses.

no-timestamp—(Optional) Suppress timestamps on displayed packets.

print-ascii—(Optional) Display each packet in ASCII format.

print-hex—(Optional) Display each packet, except the link-level header, in hexadecimal format.

resolve-timeout *timeout*—(Optional) Amount of time the router or switch waits for each reverse lookup before timing out. You can set the timeout for 1 through 4,294,967,295 seconds. The default is 4 seconds. To display each packet, use the **print-ascii**, **print-hex**, or **extensive** option.

size *size*—(Optional) Read but do not display up to the specified number of bytes for each packet. When set to **brief** output, the default packet size is 96 bytes and is adequate for capturing IP, ICMP, UDP, and TCP packet data. When set to **detail** and **extensive** output, the default packet size is 1514. The **monitor traffic** command truncates displayed packets if the matched data exceeds the configured size.

Additional Information In the **monitor traffic** command, you can specify an expression to match by using the **matching** option and including the expression in quotation marks:

```
monitor traffic matching "expression"
```

Replace **expression** with one or more of the match conditions listed in Table 25 on page 105.

Table 25: Match Conditions for the monitor traffic Command

Match Type	Condition	Description
Entity	host [<i>address</i> <i>hostname</i>]	Matches packets that contain the specified address or hostname. The protocol match conditions arp , ip , or rarp , or any of the directional match conditions can be prepended to the host match condition.
	net <i>address</i>	Matches packets with source or destination addresses containing the specified network address.
	net <i>address mask mask</i>	Matches packets containing the specified network address and subnet mask.
	port (<i>port-number</i> <i>port-name</i>)	Matches packets containing the specified source or destination TCP or UDP port number or port name. In place of the numeric port address, you can specify a text synonym, such as bgp (179), dhcp (67), or domain (53) (the port numbers are also listed).
Directional	dst	Matches packets going to the specified destination. This match condition can be prepended to any of the entity type match conditions.
	src	Matches packets from a specified source. This match condition can be prepended to any of the entity type match conditions.
	src and dst	Matches packets that contain the specified source and destination addresses. This match condition can be prepended to any of the entity type match conditions.
	src or dst	Matches packets containing either of the specified addresses. This match condition can be prepended to any of the entity type match conditions.
Packet Length	less <i>value</i>	Matches packets shorter than or equal to the specified value, in bytes.
	greater <i>value</i>	Matches packets longer than or equal to the specified value, in bytes.

Table 25: Match Conditions for the monitor traffic Command (*continued*)

Match Type	Condition	Description
Protocol	amt	Matches all AMT packets. Use the extensive level of output to decode the inner IGMP packets in addition to the AMT outer packet.
	arp	Matches all ARP packets.
	ether	Matches all Ethernet packets.
	ether (broadcast multicast)	Matches broadcast or multicast Ethernet frames. This match condition can be prepended with src and dst .
	ether protocol (address (arp ip rarp))	Matches packets with the specified Ethernet address or Ethernet packets of the specified protocol type. The ether protocol arguments arp , ip , and rarp are also independent match conditions, so they must be preceded by a backslash (\) when used in the ether protocol match condition.
	icmp	Matches all ICMP packets.
	ip	Matches all IP packets.
	ip (broadcast multicast)	Matches broadcast or multicast IP packets.
	ip protocol (address (icmp igmp tcp udp))	Matches packets with the specified address or protocol type. The ip protocol arguments icmp , tcp , and udp are also independent match conditions, so they must be preceded by a backslash (\) when used in the ip protocol match condition.
	isis	Matches all IS-IS routing messages.
	rarp	Matches all RARP packets.
	tcp	Matches all TCP datagrams.
	udp	Matches all UDP datagrams.

To combine expressions, use the logical operators listed in Table 26 on page 106.

Table 26: Logical Operators for the monitor traffic Command

Logical Operator (Highest to Lowest Precedence)	Description
!	Logical NOT. If the first condition does not match, the next condition is evaluated.

Table 26: Logical Operators for the monitor traffic Command (*continued*)

Logical Operator (Highest to Lowest Precedence)	Description
&&	Logical AND. If the first condition matches, the next condition is evaluated. If the first condition does not match, the next condition is skipped.
	Logical OR. If the first condition matches, the next condition is skipped. If the first condition does not match, the next condition is evaluated.
()	Group operators to override default precedence order. Parentheses are special characters, each of which must be preceded by a backslash (\).

You can use relational operators to compare arithmetic expressions composed of integer constants, binary operators, a length operator, and special packet data accessors. The arithmetic expression matching condition uses the following syntax:

```
monitor traffic matching "ether[0] & 1 != 0"arithmetic_expression relational_operator arithmetic_expression
```

The packet data accessor uses the following syntax:

```
protocol [byte-offset <size>]
```

The optional *size* field represents the number of bytes examined in the packet header. The available values are 1, 2, or 4 bytes. The following sample command captures all multicast traffic:

```
user@host> monitor traffic matching "ether[0] & 1 != 0"
```

To specify match conditions that have a numeric value, use the arithmetic and relational operators listed in Table 27 on page 108.



NOTE: Because the Packet Forwarding Engine removes Layer 2 header information before sending packets to the Routing Engine:

- The **monitor traffic** command cannot apply match conditions to inbound traffic.
- The **monitor traffic interface** command also cannot apply match conditions for Layer 3 and Layer 4 packet data, resulting in the match pipe option (**| match**) for this command for Layer 3 and Layer 4 packets not working either. Therefore, ensure that you specify match conditions as described in this command summary. For more information about match conditions, see Table 25 on page 105.
- The 802.1Q VLAN tag information included in the Layer 2 header is removed from all inbound traffic packets. Because the **monitor traffic interface ae[x]** command for aggregated Ethernet interfaces (such as ae0) only shows inbound traffic data, the command does not show VLAN tag information in the output.

Table 27: Arithmetic and Relational Operators for the monitor traffic Command

Arithmetic or Relational Operator	Description
Arithmetic Operator	
+	Addition operator.
-	Subtraction operator.
/	Division operator.
&	Bitwise AND.
*	Bitwise exclusive OR.
	Bitwise inclusive OR.
Relational Operator (Highest to Lowest Precedence)	
<=	If the first expression is less than or equal to the second, the packet matches.
>=	If the first expression is greater than or equal to the second, the packet matches.
<	If the first expression is less than the second, the packet matches.
>	If the first expression is greater than the second, the packet matches.
=	If the compared expressions are equal, the packet matches.
!=	If the compared expressions are unequal, the packet matches.

Required Privilege Level trace
maintenance

List of Sample Output [monitor traffic count on page 109](#)
[monitor traffic detail count on page 109](#)
[monitor traffic extensive \(Absolute Sequence\) on page 109](#)
[monitor traffic extensive \(Relative Sequence\) on page 109](#)
[monitor traffic extensive count on page 109](#)
[monitor traffic interface on page 110](#)
[monitor traffic matching on page 110](#)
[monitor traffic \(TX Matrix Plus Router\) on page 110](#)
[monitor traffic \(QFX3500 Switch\) on page 111](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

monitor traffic count user@host> monitor traffic count 2
 listening on fxp0
 04:35:49.814125 In my-server.home.net.1295 > my-server.work.net.telnet: . ack
 4122529478 win 16798 (DF)
 04:35:49.814185
 Out my-server.work.net.telnet > my-server.home.net.1295: P
 1:38(37) ack 0 win 17680 (DF) [tos 0x10]

**monitor traffic detail
count** user@host> monitor traffic detail count 2
 listening on fxp0
 04:38:16.265864 In my-server.home.net.1295 > my-server.work.net.telnet: . ack
 4122529971 win 17678 (DF) (ttl 121, id 6812)
 04:38:16.265926
 Out my-server.work.net.telnet.telnet > my-server.home.net.1295: P 1:38(37) ack 0
 win 17680 (DF) [tos 0x10] (ttl 6)

**monitor traffic
extensive
(Absolute Sequence)** user@host> monitor traffic extensive no-domain-names no-resolve no-timestamp count 20
 matching "tcp" absolute-sequence
 listening on fxp0
 In 207.17.136.193.179 > 192.168.4.227.1024: . 4042780859:4042780859(0)
 ack 1845421797 win 16384 <nop,nop,timestamp 4935628 965951> [tos 0xc0] (ttl)
 In 207.17.136.193.179 > 192.168.4.227.1024: P 4042780859:4042780912(53)
 ack 1845421797 win 16384
 <nop,nop,timestamp 4935628 965951>:
 BGP [|BGP UPDAT)
 In 192.168.4.227.1024 > 207.17.136.193.179:
 P 1845421797:1845421852(55) ack 4042780912 win 16384 <nop,nop,timestamp 965951
 4935628>: BGP [|BGP UPDAT)
 ...

**monitor traffic
extensive
(Relative Sequence)** user@host> monitor traffic extensive no-domain-names no-resolve no-timestamp count 20
 matching "tcp"
 listening on fxp0
 In 172.24.248.221.1680 > 192.168.4.210.23: . 396159737:396159737(0)
 ack 1664980689 win 17574 (DF) (ttl 121, id 50003)
 Out 192.168.4.210.23 > 172.24.248.221.1680: P 1:40(39)
 ack 0 win 17680 (DF) [tos 0x10] (ttl 64, id 5394)
 In 207.17.136.193.179 > 192.168.4.227.1024: P 4042775817:4042775874(57)
 ack 1845416593 win 16384 <nop,nop,timestamp 4935379 965690>: BGP [|BGP UPDAT)
 ...

**monitor traffic
extensive count** user@host> monitor traffic extensive count 5 no-domain-names no-resolve
 listening on fxp0
 13:18:17.406933
 In 192.168.4.206.2723610880 > 172.17.28.8.2049:
 40 null (ttl 64, id 38367)13:18:17.407577
 In 172.17.28.8.2049 > 192.168.4.206.2723610880:
 reply ok 28 null (ttl 61, id 35495)13:18:17.541140
 In 0:e0:1e:42:9c:e0 0:e0:1e:42:9c:e0 9000 60:
 0000 0100 0000 0000
 0000 0000 0000 0000
 0000 0000 0000 0000
 0000 0000 0000 0000
 0000 0000 0000 0000
 0000 0000 000013:18:17.591513

```

In 172.24.248.156.4139 > 192.168.4.210.23:
3556964918:3556964918(0)
ack 295526518 win 17601 (DF)
(ttl 121, id 14)13:18:17.591568
Out 192.168.4.210.23 >
172.24.248.156.4139: P 1:40(39)
ack 0 win 17680 (DF) [tos 0x10]
(ttl 64, id 52376)

```

monitor traffic interface

```

user@host> monitor traffic interface fxp0
listening on fxp0.0
18:17:28.800650 In server.home.net.723 > host1-0.lab.home.net.log
18:17:28.800733 Out host2-0.lab.home.net.login > server.home.net.7
18:17:28.817813 In host30.lab.home.net.syslog > host40.home0
18:17:28.817846 In host30.lab.home.net.syslog > host40.home0
...

```

monitor traffic matching

```

user@host> monitor traffic matching "net 192.168.1.0/24"
verbose output suppressed, use <detail> or <extensive> for full protocol decode
Address resolution is ON. Use <no-resolve> to avoid any reverse lookup delay.
Address resolution timeout is 4s.
Listening on fxp0, capture size 96 bytes

Reverse lookup for 192.168.1.255 failed (check DNS reachability).
Other reverse lookup failures will not be reported.
Use no-resolve to avoid reverse lookups on IP addresses.

21:55:54.003511 In IP truncated-ip - 18 bytes missing!
192.168.1.17.netbios-ns > 192.168.1.255.netbios-ns: UDP, length 50
21:55:54.003585 Out IP truncated-ip - 18 bytes missing!
192.168.1.17.netbios-ns > 192.168.1.255.netbios-ns: UDP, length 50
21:55:54.003864 In arp who-has 192.168.1.17 tell 192.168.1.9
...

```

monitor traffic (TX Matrix Plus Router)

```

user@host> monitor traffic
verbose output suppressed, use <detail> or <extensive> for full protocol decode
Address resolution is ON. Use <no-resolve> to avoid any reverse lookup delay.
Address resolution timeout is 4s.
Listening on em0, capture size 96 bytes
04:11:59.862121 Out IP truncated-ip - 25 bytes missing!
summit-em0.englab.juniper.net.syslog > sv-log-01.englab.juniper.net.syslog:
SYSLOG kernel.info, length: 57
04:11:59.862303
Out IP truncated-ip - 25 bytes missing!
summit-em0.englab.juniper.net.syslog >
sv-log-02.englab.juniper.net.syslog: SYSLOG kernel.info, length: 57
04:11:59.923948
In IP aj-em0.englab.juniper.net.65235 >
summit-em0.englab.juniper.net.telnet: .
ack 1087492766 win 33304 <nop,nop,timestamp 42366734 993490>
04:11:59.923983 Out IP truncated-ip - 232 bytes missing!
summit-em0.englab.juniper.net.telnet > aj-em0.englab.juniper.net.65235: P
1:241(240) ack 0 win 33304
<nop,nop,timestamp 993590 42366734>
04:12:00.022900
In IP aj-em0.englab.juniper.net.65235 >
summit-em0.englab.juniper.net.telnet: . ack 241 win 33304 <nop,nop,timestamp
42366834 993590>
04:12:00.141204
In IP truncated-ip - 40 bytes missing!

```

```

ipg-lnx-shell11.juniper.net.46182 > summit-em0.englab.juniper.net.telnet: P
2950530356:2950530404(48) ack 485494987 win 63712
<nop,nop,timestamp 1308555294 987086>
04:12:00.141345
Out IP summit-em0.englab.juniper.net.telnet >
ipg-lnx-shell11.juniper.net.46182: P 1:6(5)
ack 48 win 33304
<nop,nop,timestamp 993809 1308555294>
04:12:00.141572
In IP ipg-lnx-shell11.juniper.net.46182 >
summit-em0.englab.juniper.net.telnet: .
ack 6 win 63712
<nop,nop,timestamp 1308555294 993809>
04:12:00.141597
Out IP summit-em0.englab.juniper.net.telnet >
ipg-lnx-shell11.juniper.net.46182: P 6:10(4) ack 48 win 33304
<nop,nop,timestamp 993810 1308555294>
04:12:00.141821
In IP ipg-lnx-shell11.juniper.net.46182 >
summit-em0.englab.juniper.net.telnet: .
ack 10 win 63712 <nop,nop,timestamp 1308555294 993810>
04:12:00.141837 Out IP truncated-ip - 2 bytes missing!
summit-em0.englab.juniper.net.telnet >
ipg-lnx-shell11.juniper.net.46182: P 10:20(10) ack 48 win 33304
<nop,nop,timestamp 993810 1308555294>
04:12:00.142072
In IP ipg-lnx-shell11.juniper.net.46182 >
summit-em0.englab.juniper.net.telnet: . ack 20 win 63712
<nop,nop,timestamp 1308555294 993810>
04:12:00.142089 Out IP summit-em0.englab.juniper.net.telnet >
ipg-lnx-shell11.juniper.net.46182: P 20:28(8) ack 48 win 33304 <nop,nop,timestamp
993810 1308555294>
04:12:00.142321
In IP ipg-lnx-shell11.juniper.net.46182 >
summit-em0.englab.juniper.net.telnet: .
ack 28 win 63712 <nop,nop,timestamp 1308555294 993810>
04:12:00.142337
Out IP truncated-ip - 1 bytes missing!
summit-em0.englab.juniper.net.telnet >
ipg-lnx-shell11.juniper.net.46182: P 28:37(9) ack 48 win 33304 <nop,nop,timestamp
993810 1308555294>
...

```

monitor traffic
(QFX3500 Switch)

```

user@switch> monitor traffic
verbose output suppressed, use <detail> or <extensive> for full protocol decode
Address resolution is ON. Use <no-resolve> to avoid any reverse lookup delay.
Address resolution timeout is 4s.
Listening on me4, capture size 96 bytes
Reverse lookup for 172.22.16.246 failed (check DNS reachability).
Other reverse lookup failures will not be reported.
Use <no-resolve> to avoid reverse lookups on IP addresses.
16:35:32.240873 Out IP truncated-ip - 112 bytes missing!
labqfx-me0.lab4.juniper.net.ssh >
172.22.16.246.telefinder: P 4200727624:4200727756(132) ack 2889954831 win 65535
16:35:32.240900 Out IP truncated-ip - 176 bytes missing!
labqfx-me0.lab4.juniper.net.ssh >
172.22.16.246.telefinder: P 132:328(196) ack 1 win 65535
...

```

mtrace

Syntax	<code>mtrace source</code> <code><routing-instance routing-instance-name></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display trace information about an IP multicast path.
Options	<code>source</code> —Source hostname or address. <code>routing-instance routing-instance-name</code> —(Optional) Trace a particular routing instance.
Additional Information	The mtrace command for multicast traffic is similar to the traceroute command used for unicast traffic. Unlike traceroute , mtrace traces traffic backwards, from the receiver to the source.
Required Privilege Level	view
List of Sample Output	mtrace source on page 113
Output Fields	Table 28 on page 112 describes the output fields for the mtrace command. Output fields are listed in the approximate order in which they appear.

Table 28: mtrace Output Fields

Field Name	Field Description
Mtrace from	IP address of the receiver.
to	IP address of the source.
via group	IP address of the multicast group (if any).
Querying full reverse path	Indicates the full reverse path query has begun.
number-of-hops	Number of hops from the source to the named router or switch.
router-name	Name of the router or switch for this hop.
address	Address of the router or switch for this hop.
protocol	Protocol used (for example, PIM).
Round trip time	Average round-trip time, in milliseconds (ms).
total ttl of	Time-to-live (TTL) threshold.

Sample Output

```
mtrace source user@host> mtrace 192.1.4.2
Mtrace from 192.1.4.2 to 192.1.1.2 via group 0.0.0.0
Querying full reverse path... * *
  0  routerA.lab.mycompany.net (192.1.1.2)
 -1  routerB.lab.mycompany.net (192.1.2.2) PIM thresh^ 1
 -2  routerC.lab.mycompany.net (192.1.3.2) PIM thresh^ 1
 -3  hostA.lab.mycompany.net (192.1.4.2)
Round trip time 2 ms; total ttl of 2 required.
```

mtrace from-source

Syntax mtrace from-source *source source*
 <brief | detail>
 <extra-hops *extra-hops*>
 <group *group*>
 <interval *interval*>
 <loop>
 <max-hops *max-hops*>
 <max-queries *max-queries*>
 <multicast-response | unicast-response>
 <no-resolve>
 <no-router-alert>
 <response *response*>
 <routing-instance *routing-instance-name*>
 <tll *tll*>
 <wait-time *wait-time*>

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.

Description Display trace information about an IP multicast path from a source to this router or switch. If you specify a group address with this command, the Junos OS returns additional information, such as packet rates and losses.

Options brief | detail—(Optional) Display the specified level of output.

extra-hops *extra-hops*—(Optional) Number of hops to take after reaching a nonresponsive router. You can specify a number between **0** and **255**.

group *group*—(Optional) Group address for which to trace the path. The default group address is **0.0.0.0**.

interval *interval*—(Optional) Number of seconds to wait before gathering statistics again. The default value is **10** seconds.

loop—(Optional) Loop indefinitely, displaying rate and loss statistics.

max-hops *max-hops*—(Optional) Maximum hops to trace toward source. The range of values is **0** through **255**. The default value is **32** hops.

max-queries *max-queries*—(Optional) Maximum number of query attempts for any hop. The range of values is **1** through **32**. The default is **3**.

multicast-response—(Optional) Always request the response using multicast.

no-resolve—(Optional) Do not attempt to display addresses symbolically.

no-router-alert—(Optional) Do not use the router-alert IP option.

response *response*—(Optional) Send trace response to a host or multicast address.

routing-instance *routing-instance-name*—(Optional) Trace a particular routing instance.

source *source*—Source hostname or address.

ttl *tvl*—(Optional) IP time-to-live (TTL) value. You can specify a number between 0 and 255. Local queries to the multicast group use a value of 1. Otherwise, the default value is 127.

unicast-response—(Optional) Always request the response using unicast.

wait-time *wait-time*—(Optional) Number of seconds to wait for a response. The default value is 3.

Required Privilege Level view

List of Sample Output mtrace from-source on page 116

Output Fields Table 29 on page 115 describes the output fields for the **mtrace from-source** command. Output fields are listed in the approximate order in which they appear.

Table 29: mtrace from-source Output Fields

Field Name	Field Description
Mtrace from	IP address of the receiver.
to	IP address of the source.
via group	IP address of the multicast group (if any).
Querying full reverse path	Indicates the full reverse path query has begun.
<i>number-of-hops</i>	Number of hops from the source to the named router or switch.
<i>router-name</i>	Name of the router or switch for this hop.
<i>address</i>	Address of the router or switch for this hop.
<i>protocol</i>	Protocol used (for example, PIM).
Round trip time	Average round-trip time, in milliseconds (ms).
total ttl of	Time-to-live (TTL) threshold.
source	Source address.
Response Dest	Response destination address.
Overall	Average packet rate for all traffic at each hop.
Packet Statistics for Traffic From	Number of packets lost, number of packets sent, percentage of packets lost, and average packet rate at each hop.

Table 29: mtrace from-source Output Fields (*continued*)

Field Name	Field Description
Receiver	IP address receiving the multicast.
Query source	IP address sending the mtrace query.

Sample Output

```

mtrace from-source user@host> mtrace from-source source 192.1.4.2 group 225.1.1.1
Mtrace from 192.1.4.2 to 192.1.1.2 via group 225.1.1.1
Querying full reverse path... * *
  0 routerA.lab.mycompany.net (192.1.1.2)
-1 routerB.lab.mycompany.net (192.1.2.2) PIM thresh^ 1
-2 routerC.lab.mycompany.net (192.1.3.2) PIM thresh^ 1
-3 hostA.lab.mycompany.net (192.1.4.2)
Round trip time 2 ms; total ttl of 2 required.

Waiting to accumulate statistics...Results after 10 seconds:

Source      Response Dest Overall Packet Statistics For Traffic From
192.1.4.2 192.1.1.2 Packet 192.1.4.2 To 225.1.1.1
  v    ___/ rtt  2 ms Rate Lost/Sent = Pct Rate
192.1.2.1
192.1.3.2 routerC.lab.mycompany.net
  v    ^    ttl  2 0/0 = -- 0 pps
192.1.4.1
192.1.2.2 routerB.lab.mycompany.net
  v    \__ ttl  3 ?/0 0 pps
192.1.1.2 192.1.1.2
Receiver Query Source

```

mtrace monitor

Syntax	mtrace monitor
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Listen passively for IP multicast responses.To exit mtrace monitor , type Ctrl+c.
Options	none—Trace the master instance.
Required Privilege Level	view
List of Sample Output	mtrace monitor on page 118
Output Fields	Table 30 on page 117 describes the output fields for the mtrace monitor command. Output fields are listed in the approximate order in which they appear.

Table 30: mtrace monitor Output Fields

Field Name	Field Description
Mtrace query at	Date and time of the query.
by	Address of the host issuing the query.
resp to	Response destination.
qid	Query ID number.
packet from...to	IP address of the query source and default group destination.
from...to	IP address of the multicast source and the response address.
via group	IP address of the group to trace.
mxhop	Maximum hop setting.

Sample Output

```
mtrace monitor user@host> mtrace monitor
Mtrace query at Oct 22 13:36:14 by 192.1.3.2, resp to 224.0.1.32, qid 74a5b8
packet from 192.1.3.2 to 224.0.0.2
from 192.1.3.2 to 192.1.3.38 via group 224.1.1.1 (mxhop=60)

Mtrace query at Oct 22 13:36:17 by 192.1.3.2, resp to 224.0.1.32, qid 1d07ba
packet from 192.1.3.2 to 224.0.0.2
from 192.1.3.2 to 192.1.3.38 via group 224.1.1.1 (mxhop=60)

Mtrace query at Oct 22 13:36:20 by 192.1.3.2, resp to same, qid 2fea1d
packet from 192.1.3.2 to 224.0.0.2
from 192.1.3.2 to 192.1.3.38 via group 224.1.1.1 (mxhop=60)

Mtrace query at Oct 22 13:36:30 by 192.1.3.2, resp to same, qid 7c88ad
packet from 192.1.3.2 to 224.0.0.2
from 192.1.3.2 to 192.1.3.38 via group 224.1.1.1 (mxhop=60)
```

mtrace to-gateway

Syntax `mtrace to-gateway gateway gateway`
`<brief | detail>`
`<extra-hops extra-hops>`
`<group group>`
`<interface interface-name>`
`<interval interval>`
`<loop>`
`<max-hops max-hops>`
`<max-queries max-queries>`
`<multicast-response | unicast-response>`
`<no-resolve>`
`<no-router-alert>`
`<response response>`
`<routing-instance routing-instance-name>`
`<tll ttl>`
`<unicast-response>`
`<wait-time wait-time>`

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.

Description Display trace information about a multicast path from this router or switch to a gateway router or switch.

Options `gateway gateway`—Send the trace query to a gateway multicast address.

`brief | detail`—(Optional) Display the specified level of output.

`extra-hops extra-hops`—(Optional) Number of hops to take after reaching a nonresponsive router or switch. You can specify a number between **0** and **255**.

`group group`—(Optional) Group address for which to trace the path. The default group address is **0.0.0.0**.

`interface interface-name`—(Optional) Source address for sending the trace query.

`interval interval`—(Optional) Number of seconds to wait before gathering statistics again. The default value is **10**.

`loop`—(Optional) Loop indefinitely, displaying rate and loss statistics.

`max-hops max-hops`—(Optional) Maximum hops to trace toward the source. You can specify a number between **0** and **255**. The default value is **32**.

`max-queries max-queries`—(Optional) Maximum number of query attempts for any hop. You can specify a number between **0** and **255**. The default value is **3**.

`multicast-response`—(Optional) Always request the response using multicast.

`no-resolve`—(Optional) Do not attempt to display addresses symbolically.

no-router-alert—(Optional) Do not use the router-alert IP option.

response *response*—(Optional) Send trace response to a host or multicast address.

routing-instance *routing-instance-name*—(Optional) Trace a particular routing instance.

ttl *tll*—(Optional) IP time-to-live value. You can specify a number between 0 and 225.
Local queries to the multicast group use TTL 1. Otherwise, the default value is 127.

unicast-response—(Optional) Always request the response using unicast.

wait-time *wait-time*—(Optional) Number of seconds to wait for a response. The default value is 3.

Required Privilege Level view

List of Sample Output mtrace to-gateway on page 120

Output Fields Table 31 on page 120 describes the output fields for the **mtrace to-gateway** command. Output fields are listed in the approximate order in which they appear.

Table 31: mtrace to-gateway Output Fields

Field Name	Field Description
Mtrace from	IP address of the receiver.
to	IP address of the source.
via group	IP address of the multicast group (if any).
Querying full reverse path	Indicates the full reverse path query has begun.
<i>number-of-hops</i>	Number of hops from the source to the named router or switch.
<i>router-name</i>	Name of the router or switch for this hop.
<i>address</i>	Address of the router or switch for this hop.
<i>protocol</i>	Protocol used (for example, PIM).
Round trip time	Average round-trip time, in milliseconds (ms).
total ttl of	Time-to-live (TTL) threshold.

Sample Output

mtrace to-gateway user@host> mtrace to-gateway gateway 192.1.3.2 group 225.1.1.1 interface 192.1.1.73 brief

```
Mtrace from 192.1.1.73 to 192.1.1.2 via group 225.1.1.1
Querying full reverse path... * *
0  routerA.lab.mycompany.net (192.1.1.2)
```



```
-1 routerA.lab.mycompany.net (192.1.1.2) PIM thresh^ 1
-2 routerB.lab.mycompany.net (192.1.2.2) PIM thresh^ 1
-3 routerC.lab.mycompany.net (192.1.3.2) PIM thresh^ 1
Round trip time 2 ms; total ttl of 3 required.
```

traceroute

Syntax	<pre> traceroute <i>host</i> <as-number-lookup> <bypass-routing> <clns> <gateway address> <inet inet6> <interface <i>interface-name</i>> <logical system (all <i>logical-system-name</i>)> <mpls (ldp <i>FEC address</i> rsvp <i>label-switched-path-name</i>)> <no-resolve> <routing-instance <i>routing-instance-name</i>> <source <i>source-address</i>> <tos <i>value</i>> <ttl <i>value</i>> <wait <i>seconds</i>> </pre>
Syntax (QFX Series)	<pre> traceroute <i>host</i> <as-number-lookup> <bypass-routing> <gateway address> <inet> <interface <i>interface-name</i>> <monitor <i>host</i>> <no-resolve> <routing-instance <i>routing-instance-name</i>> <source <i>source-address</i>> <tos <i>value</i>> <ttl <i>value</i>> <wait <i>seconds</i>> </pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>mpls option introduced in Junos OS Release 9.2.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	<p>Display the route that packets take to a specified network host. Use traceroute as a debugging tool to locate points of failure in a network.</p>
Options	<p><i>host</i>—IP address or name of remote host.</p> <p>as-number-lookup—(Optional) Display the autonomous system (AS) number of each intermediate hop on the path from the host to the destination.</p> <p>bypass-routing—(Optional) Bypass the normal routing tables and send requests directly to a system on an attached network. If the system is not on a directly attached network, an error is returned. Use this option to display a route to a local system through an interface that has no route through it.</p> <p>clns—(Optional) Trace the route belonging to Connectionless Network Service (CLNS).</p>

gateway address—(Optional) Address of a router or switch through which the route transits.

inet | *inet6*—(Optional) Trace the route belonging to IPv4 or IPv6, respectively.

interface interface-name—(Optional) Name of the interface over which to send packets.

logical-system (*all* | *logical-system-name*)—(Optional) Perform this operation on all logical systems or on a particular logical system.

monitor host—(Optional) Display real-time monitoring information for the specified host.

mpls (*ldp FEC address* | *rsvp label-switched-path name*)—(Optional) See **traceroute mpls ldp** and **traceroute mpls rsvp**.

no-resolve—(Optional) Do not attempt to determine the hostname that corresponds to the IP address.

routing-instance routing-instance-name—(Optional) Name of the routing instance for the traceroute attempt.

source source-address—(Optional) Source address of the outgoing traceroute packets.

tos value—(Optional) Value to include in the IP type-of-service (ToS) field. The range of values is 0 through 255.

ttl value—(Optional) Maximum time-to-live value to include in the traceroute request. The range of values is 0 through 128.

wait seconds—(Optional) Maximum time to wait for a response to the traceroute request.

Required Privilege Level

network

Related Documentation

- **traceroute monitor** on page 125

List of Sample Output

traceroute on page 124
traceroute as-number-lookup host on page 124
traceroute no-resolve on page 124
traceroute (Between CE Routers, Layer 3 VPN) on page 124
traceroute (Through an MPLS LSP) on page 124

Output Fields

Table 32 on page 123 describes the output fields for the **traceroute** command. Output fields are listed in the approximate order in which they appear.

Table 32: traceroute Output Fields

Field Name	Field Description
traceroute to	IP address of the receiver.
hops max	Maximum number of hops allowed.

Table 32: traceroute Output Fields (*continued*)

Field Name	Field Description
byte packets	Size of packets being sent.
number-of-hops	Number of hops from the source to the named router or switch.
router-name	Name of the router or switch for this hop.
address	Address of the router or switch for this hop.
Round trip time	Average round-trip time, in milliseconds (ms).

Sample Output

```

traceroute      user@host> traceroute santacruz
traceroute to green.company.net (10.156.169.254), 30 hops max, 40 byte packets
 1 blue23 (10.168.1.254)  2.370 ms  2.853 ms  0.367 ms
 2 red14 (10.168.255.250) 0.778 ms  2.937 ms  0.446 ms
 3 yellow (10.156.169.254) 7.737 ms  89.905 ms  0.834 ms

traceroute      user@host> traceroute as-number-lookup 10.100.1.1
as-number-lookup traceroute to 10.100.1.1 (10.100.1.1), 30 hops max, 40 byte packets
host             1 10.39.1.1 (10.39.1.1) 0.779 ms 0.728 ms 0.562 ms
                  2 10.39.1.6 (10.39.1.6) [AS 32] 0.657 ms 0.611 ms 0.617 ms
                  3 10.100.1.1 (10.100.1.1) [AS 10, 40, 50] 0.880 ms 0.808 ms 0.774 ms

traceroute no-resolve user@host> traceroute santacruz no-resolve
traceroute to green.company.net (10.156.169.254), 30 hops max, 40 byte packets
 1 10.168.1.254 0.458 ms 0.370 ms 0.365 ms
 2 10.168.255.250 0.474 ms 0.450 ms 0.444 ms
 3 10.156.169.254 0.931 ms 0.876 ms 0.862 ms

traceroute (Between user@host> traceroute vpn09
CE Routers, Layer 3 traceroute to vpn09.skybank.net (10.255.14.179), 30 hops max, 40
VPN)                byte packets
                  1 10.39.10.21 (10.39.10.21) 0.598 ms 0.500 ms 0.461 ms
                  2 10.39.1.13 (10.39.1.13) 0.796 ms 0.775 ms 0.806 ms
                     MPLS Label=100006 CoS=0 TTL=1 S=1
                  3 vpn09.skybank.net (10.255.14.179) 0.783 ms 0.716 ms 0.686

traceroute      user@host> traceroute mpls1
(Through an MPLS traceroute to 10.168.1.224 (10.168.1.224), 30 hops max, 40 byte packets
LSP)           1 mpls1-sr0.company.net (10.168.200.101) 0.555 ms 0.393 ms 0.367 ms
                     MPLS Label=1024 CoS=0 TTL=1
                  2 mpls5-lo0.company.net (10.168.1.224) 0.420 ms 0.394 ms 0.401 ms

```

traceroute monitor

Syntax	<pre>traceroute monitor <i>host</i> <count <i>value</i>> <inet inet 6> <interval <i>seconds</i>> <no resolve> <size <i>value</i>> <source <i>source-address</i>> <summary></pre>
Syntax (QFX Series)	<pre>traceroute monitor <i>host</i> <count <i>value</i>> <inet> <interval <i>seconds</i>> <no resolve> <size <i>value</i>> <source <i>source-address</i>> <summary></pre>
Release Information	<p>Command introduced in Junos OS Release 8.0</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Display live monitoring of each hop in the route that packets take to a specified network host. Use as a debugging tool to locate points of failure in a network.
Options	<p><i>host</i>—IP address or name of remote host.</p> <p><i>count value</i>—Number of ping requests, in packets, to send in summary mode. The default value is 10.</p> <p><i>inet inet6</i>—(Optional) Trace the route belonging to IPv4 or IPv6, respectively.</p> <p><i>interval seconds</i>—(Optional) Number of seconds to wait before sending ping requests. The default value is 1.</p> <p><i>no resolve</i>—(Optional) Do not attempt to display addresses symbolically.</p> <p><i>size value</i>—(Optional) Receive the specified number of bytes for each packet. The range is 0 through 65468 bytes. The default value is 64.</p> <p><i>source source-address</i>—(Optional) Source address of the outgoing ping packets.</p> <p><i>summary</i>—(Optional) Generate and display a summary of live monitoring of each hop on the route that packets take to a specified network host.</p>
Required Privilege Level	network
List of Sample Output	traceroute monitor on page 126
Output Fields	Table 33 on page 126 describes the output fields for the traceroute monitor command. Output fields are listed in the approximate order in which they appear.

Table 33: traceroute monitor Output Fields

Field Name	Field Description
Host	Hostname or IP address of the router at each hop.
Loss%	Percent of packet loss. The number of ping responses divided by the number of ping requests, specified as a percentage.
Snt	Number of ping requests sent to the router at this hop.
Last	Most recent round-trip time, in milliseconds, to the router at this hop.
Avg	Average round-trip time, in milliseconds, to the router at this hop.
Best	Shortest round-trip time, in milliseconds, to the router at this hop.
Wrst	Longest round-trip time, in milliseconds, to the router at this hop.
StDev	Standard deviation of round-trip times, in milliseconds, to the router at this hop.

Sample Output

```
traceroute monitor user@host> traceroute monitor 10.16.0.1
```

	Loss%	Snt	Last	Avg	Best	Wrst	StDev
Host							
1. 10.17.41.254	0.0%	17	0.7	1.0	0.6	5.4	1.2
2. secret.net	0.0%	17	0.6	1.0	0.6	6.6	1.4
3. top-secret.net	0.0%	17	0.6	0.6	0.6	0.6	0.0

traceroute mpls ldp

Syntax `traceroute mpls <ldp> fec`
`<destination>`
`<detail>`
`<exp>`
`<fanout>`
`<logical-system>`
`<no-resolve>`
`<paths>`
`<retries>`
`<routing-instance>`
`<source>`
`<ttl>`
`<update>`
`<wait>`

Release Information Command introduced in Junos OS Release 8.4.

Description Trace route to a remote host for an MPLS label-switched path signaled by the LDP. Use **traceroute mpls ldp** as a debugging tool to locate MPLS label-switched path forwarding issues in a network. (Currently supported for IPv4 packets only.)

Options *fec*—Specify the IP address and optional prefix of the forwarding equivalence class (FEC).

destination—(Optional) Specify the destination address to use when sending probes.

detail—(Optional) Display detailed output.

exp—(Optional) Specify the class-of-service to use when sending probes. The range of values is **0** through **7**. The default value is **7**.

fanout—(Optional) Specify the maximum number of nexthops to search per node. The range of values is **1** through **16**. The default value is **16**.

logical-system—(Optional) Specify the name of the logical system for the traceroute attempt.

no-resolve—(Optional) Specify not to resolve the hostname that corresponds to the IP address.

paths—(Optional) Specify the number of paths to search. The range of values is **1** through **255**. The default value is **16**.

retries—(Optional) Specify the number of times to resend probe. values. The range of values is **1** through **9**. The default value is **3**.

routing-instance *routing-instance-name*—(Optional) Specify the name of the routing instance for the traceroute attempt.

source *source-address*—(Optional) Specify the source address of the outgoing traceroute packets.

ttn value—(Optional) Specify the maximum time-to-live value to include in the traceroute request, in seconds. The range of values is **1** through **125** and the default value is **64**.

wait seconds—(Optional) Specify the number of seconds to wait before resending a probe. The range of values is **5** through **15** and the default value is **10** seconds.

Required Privilege Level network

List of Sample Output **traceroute mpls ldp** on page 129
traceroute mpls ldp detail on page 129

Output Fields Table 34 on page 128 describes the output fields for the **traceroute mpls ldp fec** command and the **traceroute mpls ldp fec detail** commands. Output fields are listed in the approximate order in which they appear.

Table 34: traceroute mpls ldp Output Fields

Field Name	Field Description	Level of Output
Probe options	Probe options specified in the traceroute mpls ldp fec command.	all levels
ttn	Time to live value of the labeled packet.	none specified
Label	Outgoing label used for forwarding the packet along the label-switched paths.	none specified
Protocol	Signaling protocol used. For this command, it is LDP.	none specified
Address	Address of the next hop.	none specified
Previous Hop	Address of the previous hop. Previous hop address of the first hop is null .	none specified
Probe status	Forwarding status from the first hop to the last-hop label-switching router (egress point in the label-switched paths).	none specified
Hop	Address of the hops in the label-switched path from the first hop to the last hop. Depth indicates the level of the hop.	detail
Parent	Address of the previous hop. Parent value for the first hop is null .	detail
Return Code	Return code for reporting the result of processing the echo request by the receiver.	detail
Response time	Time for the echo request to reach the receiver.	detail
Multipath type	Labels or addresses used by the specified multipath type. If multipaths are not used, the value is none .	detail

Table 34: traceroute mpls ldp Output Fields (*continued*)

Field Name	Field Description	Level of Output
Label Stack	Label stack used to forward the packet.	detail

Sample Output

```

traceroute mpls ldp user@router> traceroute mpls ldp 4.4.4.4

Probe options: ttl 64, retries 3, wait 10, paths 16, exp 7, fanout 16
ttl  Label Protocol Address Previous Hop Probe Status
  1   100016 LDP      24.24.24.1 (null) Success
  2   100000 LDP      20.20.20.2 24.24.24.1 Success
  3         3 LDP      22.22.22.4 20.20.20.2 Egress

Path 1 via fe-0/3/3.101 destination 127.0.0.64

traceroute mpls ldp user@router> traceroute mpls ldp 4.4.4.4 detail
detail

Probe Options: ttl 64, retries 3, wait 10, paths 3, exp 7
Hop 24.24.24.1 Depth 1
  Parent (null)
  Return code: Label switched at stack-depth 1
  Response time 165.93 msec
  Multipath type: IP bitmask
    Address Range 1: 127.0.0.0 ~ 127.0.3.255
  Label Stack:
    Label 1 Value 100032 Protocol LDP

Hop 20.20.20.2 Depth 2
  Parent 24.24.24.1
  Return code: Upstream interface index unknown label-switched at stack-depth
1
  Response time 19.05 msec
  Multipath type: IP bitmask
    Address Range 1: 127.0.0.0 ~ 127.0.3.255
  Label Stack:
    Label 1 Value 100000 Protocol LDP

Hop 22.22.22.4 Depth 3
  Parent 20.20.20.2
  Return code: Egress-ok at stack-depth 1
  Response time 0.79 msec
  Multipath type: None
  Label Stack:
    Label 1 Value 3 Protocol LDP

```

traceroute mpls rsvp

Syntax	<code>traceroute mpls <rsvp> <i>lsp-name</i></code> <code><detail></code> <code><egress></code> <code><exp></code> <code><logical-system></code> <code><multipoint></code> <code><no-resolve></code> <code><retries></code> <code><source <i>source-address</i>></code> <code><ttl></code>
Release Information	Command introduced in Junos OS Release 9.2. egress , multipoint , and ttl options added in Junos OS Release 11.2.
Description	Trace route to a remote host for an MPLS LSP signaled by RSVP. Use traceroute mpls rsvp as a debugging tool to locate MPLS label-switched path (LSP) forwarding issues in a network. (Currently supported for IPv4 packets only.)
Options	<i>lsp-name</i> —Specify the name of the LSP to be traced. detail—(Optional) Display detailed output. egress—(Optional) Request that a specific point-to-multipoint egress node reply to the trace route. The trace route would follow the associated sub-LSP to the egress node. exp—(Optional) Specify the class of service to use when sending probes. The range of values is 0 through 7. The default value is 7. logical-system—(Optional) Specify the name of the logical system for the traceroute attempt. multipoint—(Optional) Perform a trace route on a point-to-multipoint LSP. no-resolve—(Optional) Specify not to resolve the hostname that corresponds to the IP address. retries—(Optional) Specify the number of times to resend probe. The range of values is 1 through 9. The default value is 3. source <i>source-address</i> —(Optional) Specify the source address of the outgoing traceroute packets. ttl—(Optional) Specify the number of hops to follow before forcing the trace route to quit.
Required Privilege Level	network
List of Sample Output	traceroute mpls rsvp on page 132 traceroute mpls rsvp detail on page 132

traceroute mpls rsvp multipoint (branch node for sub-LSPs) on page 133
traceroute mpls rsvp multipoint (single-hop sub-LSPs) on page 133

Output Fields Table 35 on page 131 describes the output fields for the **traceroute mpls rsvp *lsp-name*** and **traceroute mpls rsvp *lsp-name* detail** commands. Output fields are listed in the approximate order in which they appear.

Table 35: traceroute mpls rsvp Output Fields

Field Name	Field Description	Level of Output
Probe options	Probe options specified in the traceroute mpls rsvp <i>lsp-name</i> command.	all levels
ttl	Time-to-live value of the labeled packet.	none specified
Label	MPLS label used to forward the packets along the LSP.	none specified
Protocol	Signaling protocol used. For this command, it is RSVP-TE.	none specified
Address	Address of the next hop.	none specified
Previous Hop	Address of the previous hop. Previous hop address of the first hop is null .	none specified
Probe status	Forwarding status from the first hop to the last-hop label-switching router (egress point in the label-switched paths). Displays Success if the trace to a hop is successful or Egress if the trace has reached the last router on the path.	none specified
Hop	Address of the hops in the label-switched path from the first hop to the last hop. Depth indicates the level of the hop.	detail
Parent	Address of the previous hop. Parent value for the first hop is null .	detail
Return Code	Return code for reporting the result of processing the echo request by the receiver.	detail
Sender timestamp	Displays the timestamp when the MPLS echo request is sent to the next hop.	detail
Receiver timestamp	Timestamp when the echo request from the previous hop is received and acknowledged with an echo response by the next hop.	detail
Response time	Time for the echo request to reach the receiver.	detail
MTU	Size of the largest packet that includes the label stack forwarded to the next hop.	detail

Table 35: traceroute mpls rsvp Output Fields (*continued*)

Field Name	Field Description	Level of Output
Multipath type	Labels or addresses used by the specified multipath type. If multipaths are not used, the value is none .	detail
Label stack	Label stack used to forward the packet.	detail
Path	Displays the sub-lsp path number for this traceroute, the interface used, and the destination address.	all levels

Sample Output

traceroute mpls rsvp user@host> traceroute mpls rsvp lsp-chicago-atlanta

Probe options: retries 3, exp 7

ttl	Label	Protocol	Address	Previous Hop	Probe Status
1	299792	RSVP-TE	192.168.1.2	(null)	Success
2	299803	RSVP-TE	192.168.2.3	192.168.1.2	Success
3	3	RSVP-TE	192.168.3.4	192.168.2.3	Egress

Path 1 via ge-0/0/0.1 destination 127.0.0.64

traceroute mpls rsvp detail user@host> traceroute mpls rsvp lsp-chicago-atlanta detail
Probe options: retries 3, exp 7

Hop 192.168.1.2 Depth 1

Probe status: Success

Parent: (null)

Return code: Label-switched at stack-depth 1

Sender timestamp: 2008-04-17 09:35:27 EDT 400.88 msec

Receiver timestamp: 2008-04-17 09:35:27 EDT 427.87 msec

Response time: 26.99 msec

MTU: Unknown

Multipath type: IP bitmask

Address Range 1: 127.0.0.64 ~ 127.0.0.127

Label Stack:

Label 1 Value 299792 Protocol RSVP-TE

Hop 192.168.2.3 Depth 2

Probe status: Success

Parent: 192.168.1.2

Return code: Upstream interface index unknown label-switched at stack-depth

1

Sender timestamp: 2008-04-17 09:35:27 EDT 522.13 msec

Receiver timestamp: 2008-04-17 09:35:27 EDT 548.69 msec

Response time: 26.55 msec

MTU: 1518

Multipath type: IP bitmask

Address Range 1: 127.0.0.64 ~ 127.0.0.127

Label Stack:

Label 1 Value 299803 Protocol RSVP-TE

**traceroute mpls rsvp
multipoint (branch
node for sub-LSPs)**

The following traceroute output is for a point-to-multipoint LSP where the penultimate node is a branch node for the sub-LSPs.

```
user@host> traceroute mpls rsvp multipoint p2mplsp
Probe options: retries 3, exp 7
```

ttl	Label	Protocol	Address	Previous Hop	Probe Status
1	300000	RSVP-TE	81.1.2.2	(null)	Success
2	299968	RSVP-TE	81.2.3.3	81.1.2.2	Success
3	299952	RSVP-TE	81.3.4.4	81.2.3.3	Success
4	299920	RSVP-TE	81.4.6.6	81.3.4.4	Egress

Path 1 via lt-1/2/0.102 destination 127.0.0.64

ttl	Label	Protocol	Address	Previous Hop	Probe Status
4	299920	RSVP-TE	81.4.5.5	81.3.4.4	Egress

Path 2 via lt-1/2/0.102 destination 127.0.0.64

**traceroute mpls rsvp
multipoint (single-hop
sub-LSPs)**

The following traceroute output is for a point-to-multipoint LSP with multiple single-hop sub-LSPs.

```
user@host> traceroute mpls rsvp multipoint p2mplsp
Probe options: retries 3, exp 7
```

ttl	Label	Protocol	Address	Previous Hop	Probe Status
1	0	RSVP-TE	81.1.2.2	(null)	Egress

Path 1 via lt-1/2/0.102 destination 127.0.0.64

ttl	Label	Protocol	Address	Previous Hop	Probe Status
1	0	RSVP-TE	81.1.8.8	(null)	Egress

Path 2 via lt-1/2/0.108 destination 127.0.0.64

ttl	Label	Protocol	Address	Previous Hop	Probe Status
1	0	RSVP-TE	81.1.9.9	(null)	Egress

Path 3 via lt-1/2/0.109 destination 127.0.0.64

PART 2

System Management

- Accounting Operational Mode Commands on page 137
- Chassis Operational Mode Commands on page 159
- Command-Line Interface Operational Mode Commands on page 543
- File Management Operational Mode Commands on page 565
- Packet Forwarding Engine Operational Mode Commands on page 587
- Remote System Access Operational Mode Commands on page 657
- Simple Network Management Protocol Operational Mode Commands on page 663
- System Software Operational Mode Commands on page 695
- Virtual Chassis Operational Mode Commands on page 1205

CHAPTER 6

Accounting Operational Mode Commands

Table 36 on page 137 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot the Link Layer Discovery Protocol (LLDP) protocol. Commands are listed in alphabetical order.

Table 36: Accounting Operational Mode Commands

Task	Command
Clear LLDP neighbor information.	<code>clear lldp neighbor</code>
Clear LLDP statistics.	<code>clear lldp statistics</code>
Display basic LLDP information.	<code>show lldp</code>
Display LLDP local information.	<code>show lldp local-information</code>
Display LLDP neighbor information.	<code>show lldp neighbors</code>
Display LLDP remote global statistics.	<code>show lldp remote-global-statistics</code>
Display LLDP statistics.	<code>show lldp statistics</code>
Display accounting profile information.	<code>show accounting profile</code>
Display accounting records for the specified accounting profile.	<code>show accounting records</code>

clear lldp neighbor

Syntax	<code>clear lldp neighbor</code> <code><interface <i>interface-name</i>></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, clear information regarding all Link Layer Discovery Protocol (LLDP) neighbors or LLDP neighbors of the specified interface.
Options	<code>interface <i>interface-name</i></code> —(Optional) Clear the LLDP neighbors on the specified interface.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• clear lldp statistics on page 139
List of Sample Output	clear lldp statistics on page 138
Output Fields	When you enter this command, you are provided no feedback on the status of your request. You can enter the show lldp neighbors command before and after clearing the LLDP neighbors to verify the clear operation.

Sample Output

```
clear lldp statistics  user@host> clear lldp statistics
                        user@host> clear lldp statistics interface ge-0/2/0
```

clear lldp statistics

Syntax	<code>clear lldpp neighbor</code> <code><interface <i>interface-name</i>></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, clear all Link Layer Discovery Protocols (LLDP) statistics or LLDP statistics associated with the specified interface.
Options	<code>interface <i>interface-name</i></code> —(Optional) Clear LLDP statistics on the specified interface.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• clear lldp neighbor on page 138
List of Sample Output	clear lldp neighbor on page 139
Output Fields	When you enter this command, you are provided no feedback on the status of your request. You can enter the show lldp statistics command before and after clearing the LLDP statistics to verify the clear operation.

Sample Output

```
clear lldp neighbor  user@host> clear lldp neighbors
                     user@host> clear lldp neighbors interface ge-0/2/2
```

show lldp

Syntax	<code>show lldp</code> <code><detail></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, display information about the Link Layer Discovery Protocol (LLDP).
Options	<code>detail</code> —(Optional) Display the detailed output level.
Required Privilege Level	view
List of Sample Output	<code>show lldp</code> on page 141 <code>show lldp detail</code> on page 141
Output Fields	Table 37 on page 140 describes the output fields for the show lldp command. Output fields are listed in the approximate order in which they appear.

Table 37: show lldp Output Fields

Field Name	Field Description
LLDP	Status of LLDP: Enabled or Disabled .
Advertisement interval	Value of the advertisement interval parameter.
Transmit delay	Value of the transmit delay parameter.
Hold timer	Value of the hold timer parameter.
Notification interval	Value of the notification interval parameter.
Config Trap Interval	Value of the configuration trap parameter.
Connection Hold timer	Value of the connection hold timer parameter.
Interface	List of LLDP interfaces, showing status (Enabled or Disabled) and Neighbor count (detail only).
LLDP basic TLVs supported	List of basic LLDP TLVs supported by this device (detail only).
LLDP 802 TLVs supported	List of IEEE 802.1 LLDP TLVs supported by this device (detail only).

Sample Output

```

user@host> show lldp
LLDP : Enabled
Advertisement interval : 30 Second(s)
Transmit delay : 2 Second(s)
Hold timer : 4 Second(s)
Notification interval : 30 Second(s)
Config Trap Interval : 300 Second(s)
Connection Hold timer : 60 Second(s)

Interface      LLDP
ge-0/0/0       Enabled
ge-0/0/1       Enabled
ge-0/0/4       Enabled

```

Sample Output

```

user@host> show lldp detail
LLDP : Enabled
Advertisement interval : 30 Second(s)
Transmit delay : 2 Second(s)
Hold timer : 4 Second(s)
Notification interval : 30 Second(s)
Config Trap Interval : 300 Second(s)
Connection Hold timer : 60 Second(s)

Interface      LLDP      Neighbor count
ge-0/0/0       Enabled   0
ge-0/0/1       Enabled   0
ge-0/0/4       Enabled   0

LLDP basic TLVs supported:
Chassis identifier, Port identifier, Port description, System name, System
description, System capabilities, Management address.

LLDP 802 TLVs supported:
Link aggregation, Maximum frame size, MAC/PHY Configuration/Status, Port VLAN ID,
Port VLAN name.

```

show lldp local-information

Syntax	show lldp local-information
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, display local Link Layer Discovery Protocol (LLDP) information.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show lldp local-information on page 143
Output Fields	Table 38 on page 142 describes the output fields for the show lldp local-information command. Output fields are listed in the approximate order in which they appear.

Table 38: show lldp local-information Output Fields

Field Name	Field Description
LLDP Local Information details	Information that follows pertains to the local system.
Chassis ID	List of chassis identifiers for local information.
System name	Local system name reported by LLDP.
System descr	Local system description reported by LLDP.
System Capabilities	Capabilities (such as Bridge or Router) that are Supported or Enabled by system on the interface.
Management Information	Listed by Interface Name , Address Subtype (such as ipv4), Address (such as 192.168.168.229), Interface Number , and Interface Numbering Subtype .
Interface Name	List of local interfaces.
Interface ID	List of local interface identifiers.
Interface Description	List of local interface descriptions.
Status	List of interface conditions: UP or DOWN .

Sample Output

```

show lldp local-information user@host> show lldp local-information
LLDP Local Information details

Chassis ID   : 00:90:69:0a:77:c0
System name  : sw-mx-u
System descr : Juniper Networks, Inc. MX 960, Version 9.4IO.1, Build date
                2008-09-04 14:51:50 UTC

System Capabilities
  Supported   : Bridge Router
  Enabled     : Bridge Router

Management Information
  Interface Name : fxp0
  Address Subtype : IPv4(1)
  Address        : 192.168.168.229
  Interface Number : 1
  Interface Numbering Subtype : ifIndex(2)

Interface Name      Interface ID      Interface Description      Status
ge-0/1/0            18              Avaya Port                UP
ge-0/1/1            27              -                          DOWN
ge-0/1/2            13              Port for Hub              UP

```

show lldp neighbors

Syntax	show lldp neighbors <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, display information about LLDP neighbors.
Options	interface <i>interface-name</i> —(Optional) Display the neighbor information about a particular physical interface.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear lldp neighbor on page 138
List of Sample Output	show lldp neighbors on page 146 show lldp neighbors interface ge-0/0/4 on page 146
Output Fields	Table 39 on page 144 describes the output fields for the show lldp neighbors command. Output fields are listed in the approximate order in which they appear.

Table 39: show lldp neighbors Output Fields

Field Name	Field Description
LLDP Remote Devices Information	Information about remote devices.
LocalInterface	List of local interfaces for which neighbor information is available.
ChassisId	List of chassis identifiers for neighbors.
PortInfo	List of port information gathered from neighbors. This could be the port identifier or port description.
SysName	List of system names gathered from neighbors.
LLDP Neighbor Information	Information about both local and neighbor systems on the interface (appears when the interface option is used).
Local Information	Information about local systems on the interface (appears when the interface option is used).
Neighbor Information	Information about both local and neighbor system on the interface (appears when the interface option is used).
Index	Local interface index (appears when the interface option is used).

Table 39: show lldp neighbors Output Fields (*continued*)

Field Name	Field Description
Time Mark	Date and timestamp of information (appears when the interface option is used).
Time To Live	Number of seconds for which this information is valid (appears when the interface option is used).
Local Interface	Name of the local physical interface (appears when the interface option is used).
Local Port ID	Local port identifier (appears when the interface option is used).
Neighbor Information	Information about neighbor systems on the interface (appears when the interface option is used).
Chassis type	Type of chassis identifier supplied, such as MAC address (appears when the interface option is used).
Chassis ID	Chassis identifier of type listed (appears when the interface option is used).
Port type	Type of port identifier supplied, such as local (appears when the interface option is used).
Port ID	Port identifier of type listed (appears when the interface option is used).
Port description	Port description (appears when the interface option is used).
System name	Name supplied by the system on the interface (appears when the interface option is used).
System Description	Description supplied by the system on the interface (appears when the interface option is used).
System Capabilities	Capabilities (such as bridge or router) that are Supported or Enabled by the system on the interface (appears when the interface option is used).
Management address	Details of the management address: Address Type (such as ipv4), Address (such as 10.204.34.35), Interface Number , Interface Subtype , and Organization Identifier (OID) (appears when the interface option is used).
Organization Info	One or more entries listing remote information by Organizationally Unique Identifier (OUI), Subtype , Index , and Info (appears when the interface option is used).

Sample Output

```

show lldp neighbors user@host> show lldp neighbors
LLDP Remote Devices Information

LocalInterface  ChassisId          PortInfo           SysName
ge-0/0/0        10.209.192.12      00 19 bb 20 de 80 AVA4C357D
ge-0/0/1        10.209.192.12      00 19 bb 20 de 80 AVA4C357D
ge-0/0/1        10.209.192.13      00 19 bb 20 de 81 AVA4C357E
ge-0/0/3        00 19 bb 20 de 79 5   apg-hp1
ge-0/0/3        00 19 bb 20 de 80 3   apg-hp1
ge-0/0/4        00 19 bb 20 de 79 5   apg-hp1
ge-0/0/4        00 19 bb 20 de 80 3   apg-hp1
ge-0/0/5        00 19 bb 20 de 81 ge-0/0/3           MX480-1
ge-0/0/6        00 19 bb 20 de 82 ge-0/0/4           MX960-2

```

Sample Output

```

show lldp neighbors user@host> show lldp neighbors interface ge-0/0/4
interface ge-0/0/4 LLDP Neighbor Information:
Local Information:
  Index 6 Time Mark Wed Jun 20 07:34:11 2007 Time To Live 120 seconds
  Local Interface : ge-0/0/4
  Local Port ID   : 4

Neighbor Information:
  Chassis type      : Mac address
  Chassis ID       : 00 19 bb 20 de 80
  Port type        : local
  Port ID          : 3
  Port description  : 3
  System name      : apg-hp1

System Description : ProCurve J9049A Switch 2900-24G, revision
                   T.11.X1, ROM K....

System Capabilities
  Supported : bridge, router
  Enabled   : bridge

Management address
  Address Type : ipv4
  Address      : 10.204.34.35
  Interface Number : 1
  Interface Subtype : ifIndex(2)
  OID          : 1.3.6.1.2.1.31.1.1.1.1.1

Organization Info
  OUI      : 0.18.15
  Subtype  : 1
  Index    : 1
  Info     : 00A0000000

Organization Info
  OUI      : 0.18.15
  Subtype  : 3
  Index    : 2
  Info     : 0100000000

```

Organization Info

OUI : 0.18.15
Subtype : 4
Index : 3
Info : 05EA

show lldp remote-global-statistics

Syntax	show lldp remote-global-statistics
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, display remote Link Layer Discovery Protocol (LLDP) global statistics.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show lldp remote-global-statistics on page 149
Output Fields	Table 40 on page 148 describes the output fields for the show lldp remote-global-statistics command. Output fields are listed in the approximate order in which they appear.

Table 40: show lldp remote-global-statistics Output Fields

Field Name	Field Description
LLDP Remote Database Table Counters	Information about remote database table counters.
LastchangeTime	Time elapsed between LLDP agent startup and the last change to the remote database table information.
Inserts	Number of insertions made in the remote database table.
Deletes	Number of deletions made in the remote database table.
Drops	Number of LLDP frames dropped from the remote database table because of errors.
Ageouts	Number of remote database table entries that have aged out of the table.

Sample Output

```
show lldp remote-global-statistics
user@host> show lldp remote-global-statistics
LLDP Remote Database Table Counters
LastchangeTime      Inserts    Deletes    Drops    Ageouts
00:00:76 (76 sec)   192        0          0        0
```

show lldp statistics

Syntax	show lldp statistics <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 9.6.
Description	On MX Series routers, display information about Link Layer Discovery Protocol (LLDP) statistics.
Options	interface <i>interface-name</i> —(Optional) Display the statistics about a particular physical interface.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear lldp statistics on page 139
List of Sample Output	show lldp statistics on page 151 show lldp statistics interface ge-0/1/1 on page 151
Output Fields	Table 41 on page 150 describes the output fields for the show lldp statistics command. Output fields are listed in the approximate order in which they appear.

Table 41: show lldp statistics Output Fields

Field Name	Field Description
Interface	Interface name.
Received	Number of LLDP frames received on this interface.
Transmitted	Number of LLDP frames sent on this interface.
Unknown-TLVs	Number of LLDP frames with unsupported content received on this interface.
With-Errors	Number of LLDP frames with errors received on this interface.
Discarded	Number of LLDP frames received on this interface that were discarded because of problems.

Sample Output

```
show lldp statistics user@host> show lldp statistics
Interface Received Transmitted Unknown-TLVs With-Errors Discarded
-----
ge-0/1/1 544 540 0 0 0
ge-0/1/2 540 500 0 0 0
ge-0/1/3 544 540 0 0 0
ge-0/1/4 544 540 0 0 0
ge-0/1/5 544 540 0 0 0
ge-0/1/6 544 540 0 0 0
ge-0/1/7 0 0 0 0 0
```

Sample Output

```
show lldp statistics user@host> show lldp statistics interface ge-0/1/1
interface ge-0/1/1 Interface Received Transmitted Unknown-TLVs With-Errors Discarded
-----
ge-0/1/1 544 540 0 0 0
```

show accounting profile

Syntax	<code>show accounting profile <i>profile-name</i></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display accounting profile information.
Options	<i>profile-name</i> —Name of the accounting profile.
Required Privilege Level	view
List of Sample Output	show accounting profile (Interface) on page 153 show accounting profile (Filter) on page 154 show accounting profile (Destination Class) on page 154 show accounting profile (Routing Engine) on page 155
Output Fields	Table 42 on page 152 lists the output fields for the show accounting profile command. Output fields are listed in the approximate order in which they appear.

Table 42: show accounting profile Output Fields

Field Name	Field Description
Profile	Name of the accounting profile.
Sampling interval	Configured interval, in minutes, for statistic collection.
Profile Usage Count	Number of items configured for collecting accounting statistics.
<i>file information</i>	Information about the accounting profile log, including: <ul style="list-style-type: none"> • File—Name of accounting profile log. If no name is explicitly provided, the name of the accounting profile is used. All statistics files are placed in the <code>/var/log</code> directory. • maximum size—Configured size. When the size is exceeded, the log file closes and a new log file opens. • maximum number—Configured maximum number of log files. • bytes written—Number of bytes written to the log file.
Transfer Interval	Length of time (in minutes) the file remains open, receiving statistics before it is closed, transferred, and rotated. When either the time or the file size is exceeded, the file is closed and a new one opened, whether or not a transfer site is specified.
Next Scheduled Transfer	Time at which the next transfer occurs.

Table 42: show accounting profile Output Fields (*continued*)

Field Name	Field Description
Column Labels	<p>Names of sampled statistics. This list varies depending on the configuration:</p> <ul style="list-style-type: none"> profile-layout—List of data fields reported, in the order they appear in the output. epoch-timestamp—Number of seconds since the epoch. interfaces—(For interface, filter, and destination class profiles) Name of the interfaces on which the filter is applied. filter-name—(For filter profiles) Name of the filter. counter-name—(For filter profiles) Name of the counter. packet-count—(For filter and destination class profiles) Number of packets for the counter. byte-count—(For filter and destination class profiles) Number of bytes for the counter. input-bytes—(For interface profiles) Input bytes. input-errors—(For interface profiles) Generic input error packets. input-multicast—(For interface profiles) Input packets arriving by multicast. input-packets—(For interface profiles) Input packets. input-unicast—(For interface profiles) Input unicast packets. output-bytes—(For interface profiles) Output bytes. output-errors—(For interface profiles) Generic output error packets. output-multicast—(For interface profiles) Output packets sent by multicast. output-packets—(For interface profiles) Output packets. output-unicast—(For interface profiles) Output unicast packets. no-proto—(For interface profiles) Packets for unsupported protocol. snmp-index—(For interface profiles) SNMP index. destination-class-name—(For destination class profiles) Configured destination class name. host name—(For Routing Engine profiles) Hostname for the router. date-yyyyymmdd—(For Routing Engine profiles) Date. timeofday-hhmmss—(For Routing Engine profiles) Time of day. uptime—(For Routing Engine profiles) Time since the last reboot, in seconds. cpu1min—(For Routing Engine profiles) Average system load over the last 1 minute. cpu5min—(For Routing Engine profiles) Average system load over the last 5 minutes. cpu15min—(For Routing Engine profiles) Average system load over the last 15 minutes.
Interface name	Name of the interface configured for this accounting profile.
Filter name	Name of the filter configured for this accounting profile.
routing-engine-stats	Routing Engine accounting profile.
Next Scheduled Collection	Time for next collection of statistics for the named interface.

Sample Output

```

show accounting profile (Interface) user@host> show accounting profile if_prof
Profile if_prof
Sampling interval: 1 minute(s), Profile Usage Count: 2
File accounting_profile_stats: maximum size 1048576, maximum number 5, bytes

```

```
written 2196
Transfer Interval: 15 minute(s), Next Scheduled Transfer: 2001-06-17-18:00:45
Column Labels:
  profile-layout
  epoch-timestamp
  interface-name
  snmp-index
  input-bytes
  output-bytes
  input-packets
  output-packets
  input-unicast
  output-unicast
  input-multicast
  output-multicast
  no-proto
  input-errors
  output-errors
```

Interface Name	Next Scheduled Collection
fxp0.0	2001-06-18-18:00:30
fxp0	2001-06-18-18:01:00

**show accounting
profile (Filter)**

```
user@host> show accounting profile filter_profile
Profile filter_profile
Sampling interval: 1 minute(s), Profile Usage Count: 0
File accounting_profile_stats: maximum size 1048576, maximum number 5, bytes
written 822
Transfer Interval: 15 minute(s), Next Scheduled Transfer: 2001-06-17-18:00:46
Column Labels:
  profile-layout
  epoch-timestamp
  interfaces
  filter-name
  counter-name
  packet-count
  byte-count
```

Filter Name	Next Scheduled Collection
myfiltero	2001-06-03-04:32:59

**show accounting
profile (Destination
Class)**

```
user@host> show accounting profile dcu1
Profile dcu1
Sampling interval: 1 minute(s), Profile Usage Count: 0
File accounting_profile_stats: maximum size 1048576, maximum number 5, bytes
written 901
Transfer Interval: 15 minute(s), Next Scheduled Transfer: 2001-06-17-18:00:46
Column Labels:
  profile-layout
  epoch-timestamp
  interface-name
  destination-class-name
  packet-count
  byte-count
```

	Interface Name	Next Scheduled Collection
	so-0/3/3	2001-06-03-04:34:00

show accounting profile (Routing Engine)

```
user@host> show accounting profile rep1
Profile rep1
Sampling interval: 1 minute(s), Profile Usage Count: 1
File accounting_profile_stats: maximum size 1048576, maximum number 5, bytes
written 901
Transfer Interval: 15 minute(s), Next Scheduled Transfer: 2001-06-17-18:00:46
Column Labels:
  profile-layout
  epoch-timestamp
  hostname
  date-yyyymmdd
  timeofday-hhmmss
  uptime
  cpu1min
  cpu5min
  cpu15min
```

	Interface Name	Next Scheduled Collection
	routing-engine-stats	2001-06-18-18:02:31

show accounting records

Syntax	<code>show accounting records <i>profile-name</i></code> <code><since <i>time</i>></code> <code><utc_timestamp></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display accounting records for the specified accounting profile.
Options	<p><i>profile-name</i>—Name of the accounting profile.</p> <p><i>since time</i>—(Optional) Display accounting statistics since the specified time (<i>YYYY-MM-DD-HH:MM:SS</i>)</p> <p><i>utc_timestamp</i>—(Optional) Display the timestamp in Coordinated Universal Time (UTC) format.</p>
Required Privilege Level	view
List of Sample Output	<p><code>show accounting records</code> on page 157</p> <p><code>show accounting records utc-timestamp</code> on page 158</p> <p><code>show accounting records (Since Time)</code> on page 158</p> <p><code>show accounting records (Filter Profile)</code> on page 158</p> <p><code>show accounting records (Destination Class Profile)</code> on page 158</p> <p><code>show accounting records (Routing Engine Profile)</code> on page 158</p>
Output Fields	Table 43 on page 156 lists the output fields for the show accounting records command. Output fields are listed in the approximate order in which they appear.

Table 43: show accounting records Output Fields

Field Name	Field Description
Timestamp	Date and time of sample.
Interface Name	(For interface profiles) Name and SNMP index of the interface for the accounting profile.
Filter name	(For filter profiles) Name of the filter.
Interfaces	(For filter profiles) Name of the interfaces for the accounting profile.
Counter name	(For filter profiles) Name of the counter.
Destination Class	(For destination class profiles) Name of the destination class.
Input Bytes	(For interface profiles) Input bytes.
Output Bytes	(For interface profiles) Output bytes.

Table 43: show accounting records Output Fields (*continued*)

Field Name	Field Description
Input Packets	(For interface profiles) Input packets.
Output Packets	(For interface profiles) Output packets.
Input Unicast Packets	(For interface profiles) Input unicast packets.
Output Unicast Packets	(For interface profiles) Output unicast packets
Input Multicast Packets	(For interface profiles) Input packets arriving by multicast.
Output Multicast Packets	(For interface profiles) Output packets sent by multicast.
Unsupported Protocol Packets	(For interface profiles) Packets for unsupported protocols.
Input Errors	(For interface profiles) Generic input error packets.
Output Errors	(For interface profiles) Generic output error packets.
Host Name	(For Routing Engine profiles) Hostname for the router.
Date	(For Routing Engine profiles) Date, in YYYYMMDD format.
Time of Day	(For Routing Engine profiles) Time of day, in HHMMSS format.
Uptime	(For Routing Engine profiles) Time since the last reboot, in seconds.
Average CPU Load (1 min)	(For Routing Engine profiles) Average system load over the last 1 minute.
Average CPU Load (5 min)	(For Routing Engine profiles) Average system load over the last 5 minutes.
Average CPU Load (15 min)	(For Routing Engine profiles) Average system load over the last 15 minutes.

Sample Output

```

show accounting records user@host> show accounting records if_prof
Timestamp: 2000-10-03-00:30:41, Interface Name: fxp0 (SNMP Index 1)
32663634 Input Bytes
3487515 Output Bytes
158000 Input Packets
33296 Output Packets
158000 Input Unicast Packets
33296 Output Unicast Packets
0 Input Multicast Packets
0 Output Multicast Packets

```

```

0   Unsupported Protocol Packets
0   Input Errors
0   Output Errors

```

```

show accounting      user@host> show accounting records if_prof utc_timestamp
records utc-timestamp  Timestamp: 2001-06-18-18:01:00, Interface Name: fxp0 (SNMP Index 1)
                        32663634   Input Bytes
                        3487515   Output Bytes
                        158000    Input Packets
                        33296    Output Packets
                        158000    Input Unicast Packets
                        33296    Output Unicast Packets
                        0         Input Multicast Packets
                        0         Output Multicast Packets
                        0         Unsupported Protocol Packets
                        0         Input Errors
                        0         Output Errors

show accounting      user@host> show accounting records if_prof since 2000-10-03-00:10:41
records (Since Time)  Timestamp: 2000-10-03-00:30:41, Interface Name: fxp0 (SNMP Index 1)
                        32663634   Input Bytes
                        3487515   Output Bytes
                        158000    Input Packets
                        33296    Output Packets
                        158000    Input Unicast Packets
                        33296    Output Unicast Packets
                        0         Input Multicast Packets
                        0         Output Multicast Packets
                        0         Unsupported Protocol Packets
                        0         Input Errors
                        0         Output Errors

show accounting      user@host> show accounting records filter_profile
records (Filter Profile)  Timestamp: 2000-10-03-00:30:41, Filter Name: ap_filter, Interfaces: fxp0.0
                        Counter Name: c1
                        2440      Packets
                        223509    Bytes

show accounting      user@host> show accounting records dcu1
records (Destination    Timestamp: 2000-10-03-00:30:41, Interface: so-2/0/0.0, Destination Class: gold
Class Profile)         0       Packets
                        0       Bytes

show accounting      user@host> show accounting records rep1
records (Routing        Timestamp: 2000-10-03-00:30:41
Engine Profile)        Host Name:      andro
                        Date:      20010618
                        Time of Day: 183130
                        Uptime:     88260
                        Average CPU Load (1 min): 0.000000
                        Average CPU Load (5 min): 0.000000
                        Average CPU Load (15 min): 0.000000

```

CHAPTER 7

Chassis Operational Mode Commands

Table 44 on page 159 summarizes the command-line interface (CLI) commands you can use to monitor the router chassis. Commands are listed in alphabetical order.

Table 44: Chassis Operational Mode Commands

Task	CLI Command
(T Series and M320 routers only) Clear or stop a text message on the craft interface.	clear chassis display message
(T Series, M120, M320, and MX Series routers only) Change Control Board (CB) status information.	request chassis cb
(M7i and M10i routers only) Control the operation of the Compact Forwarding Engine Board (CFEB).	request chassis cfeb
(TX Matrix Plus routers only) Control the operation of the Connector Interface Panel (CIP).	request chassis cip
(M120 and MX Series routers only) Control the operation of the specified fabric plane.	request chassis fabric plane
(M120 router only) Control the operation of the specified Forwarding Engine Board (FEB).	request chassis feb
(M20, M40, M40e, M120 M160, M320, and MX Series routers, and T Series routers only) Control the operation of the Flexible PIC Concentrator (FPC).	request chassis fpc
(M40e, M120, M160, M320, and MX Series routers, and T Series routers only) Resynchronize the Front Panel Module (FPM) craft interface status	request chassis fpm resync
(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, control the operation of the T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, control the operation of a T1600 router that is connected to the TX Matrix Plus router.	request chassis lcc
(MX Series routers) Control the operation of Modular Interface Cards (MICs)	request chassis mic

Table 44: Chassis Operational Mode Commands *(continued)*

Task	CLI Command
(M40e and M160 routers only) Control the operation of the Miscellaneous Control Subsystem (MCS).	request chassis mcs
(MX Series routers only) Control the operation of a MIC.	request chassis mic
(M40e and M160 routers only) Control the operation of the Packet Forwarding Engine Clock Generator (PCG).	request chassis pcg
Control the operation of a PIC.	request chassis pic
(M120 routers only) Control the operation of a FEB in a redundancy group.	request chassis redundancy feb slot
For routers with multiple Routing Engines, control which Routing Engine is the master.	request chassis routing-engine master
(T Series routers only) Control the operation of the specified SONET Clock Generator (SCG).	request chassis scg
(M40e and M160 routers only) Control which Switching and Forwarding Module (SFM) is master.	request chassis sfm master switch
(M40e and M160 routers only) Control the operation of the specified SFM.	request chassis sfm
(M320 routers and T Series routers only) Control the operation of the specified Switch Interface Board (SIB).	request chassis sib
(TX Matrix Plus routers only) Control the receiving link of the specified Switch Interface Board (SIB) of the SFC.	request chassis sib f13 train-link-receive slot
(TX Matrix Plus routers only) Control the transmission link of the specified Switch Interface Board (SIB) of the SFC.	request chassis sib f13 train-link-transmit slot
(T1600 routers (LCCs) and TX Matrix Plus routing platform only) Control the receiving link of the specified Switch Interface Board (SIB) of the LCC.	request chassis sib train-link-receive slot
(T1600 routers (LCCs) and TX Matrix Plus routing platform only) Control the transmission link of the specified Switch Interface Board (SIB) of the LCC.	request chassis sib train-link-transmit slot
(T Series routers only) Restart the specified Switch Processor Mezzanine Board (SPMB) on the CB.	request chassis spmb restart
(M320 routers only) Change the external clock source used for chassis synchronization.	request chassis synchronization switch
Send a message to the router's craft interface.	set chassis display message

Table 44: Chassis Operational Mode Commands *(continued)*

Task	CLI Command
Display chassis alarm status.	show chassis alarms
(M7i and M10i routers only) Change and display CFEB status information.	show chassis cfeb
(TX Matrix Plus routers only) Display environmental information about the CIP.	show chassis cip
View information that is currently displayed on the craft interface.	show chassis craft-interface
Display environmental information about the router chassis, including the temperature and information about the fans, power supplies, and Routing Engine.	show chassis environment
(T Series, M120, M320, and MX Series routers only) Display CB environmental information.	show chassis environment cb
(M20, M40, M40e, M120, M160, M320, and MX Series routers, and T Series routers only) Display FPC environmental status information.	show chassis environment fpc
(M20, M40, M40e, M120, M160, M320, and MX Series routers, and T Series routers only) Change and display FPM status information.	show chassis environment fpm
(M40e and M160 routers only) Display MCS environmental status information.	show chassis environment mcs
Display generic environmental information.	show chassis environment
(M40e and M160 routers only) Display PCG environmental status information.	show chassis environment pcg
(M40e, M120, M160, M320, and MX Series routers, and T Series routers only) Display Power Entry Module (PEM) environmental status information.	show chassis environment pem
Display Routing Engine environmental status information.	show chassis environment routing-engine
(T Series routers only) Display SCG environmental information.	show chassis environment scg
(M40e and M160 routers only) Display SFM environmental information.	show chassis environment sfm
(M320 routers and T Series router only) Display SIB environmental information.	show chassis environment sib

Table 44: Chassis Operational Mode Commands *(continued)*

Task	CLI Command
(M10i, M40e, M120, M160, M320, and MX Series routers, and T Series routers only) Display information about the ports on the CB Ethernet switch.	show chassis ethernet-switch
(MX Series routers only) Display information about the fan and fan trays.	show chassis fan
(M120 router only) Display the state of the electrical and optical switching fabric link between the FEBs and the fabric planes, as interpreted by the FEB.	show chassis fabric feb
(TX Matrix Plus routers only) Display chassis fabric errors for FPCs and SIBs.	show chassis fabric errors
(M320 and MX Series routers and T Series router only) Display the state of the electrical and optical switch fabric links between the FPCs and the SIBs.	show chassis fabric fpcs
(M120 and MX Series routers only) Display the state of the switching fabric map for connections from the FEBs to the ports on the fabric planes, as interpreted by the fabric plane.	show chassis fabric map
(M120, MX Series, T1600, and TX Matrix Plus routers only) Display the state of all fabric plane connections to the FEBs. On a TX Matrix Plus router and T1600 routers, display the state of the fabric management plane and the logical planes on the SFC and line-card chassis (LCC)	show chassis fabric plane
(M120, MX Series, T1600, and TX Matrix Plus router only) Display the CB location of each plane.	show chassis fabric plane-location
(T Series routers only) Display the state of the electrical and optical switch fabric links: <ul style="list-style-type: none"> • Between the SIBs in the TX Matrix router and the SIBs in the T640 routers. • Between the T640 SIBs and the FPCs in a T640 router. 	show chassis fabric sibs
(T Series routers only) Display the state of the switching fabric topology for the SIB connection between the TX Matrix router and the T640 routers.	show chassis fabric topology
(M5, M10, and M120 routers only). Display FEB status information.	show chassis feb
Display the version levels of the firmware running on the SCB, SFM, SSB, FEB, and FPCs.	show chassis firmware
(J Series Services Routers only) Display status of the forwarding process (fwdd).	show chassis forwarding

Table 44: Chassis Operational Mode Commands *(continued)*

Task	CLI Command
(M20, M40, M40e, M160, and M320 routers, MX Series routers and T Series routers only) Display FPC status information.	show chassis fpc
(M120 router only) Display the FPC and FEB mapping and their respective states.	show chassis fpc-feb-connectivity
Display hardware inventory.	show chassis hardware
Display the status of the most recent unified in-service software upgrade (ISSU).	show chassis in-service-upgrade
(TX Matrix and TX Matrix Plus router only) On a TX Matrix router, display the status of all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display the status of all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.	show chassis lccs
Display chassis location information.	show chassis location
Display MAC address information.	show chassis mac-addresses
Display the network services mode.	show chassis network services
Display PIC status information.	show chassis pic
(J Series routers only) Display PIM power ratings.	show chassis power-ratings
(MX Series 3D Universal Edgerouters only) Display power limits and usage.	show chassis power
(MX Series 3D Universal Edgerouters only) Show power-on sequence for the chassis DPCs.	show chassis power sequence
(Root System Domain [RSD] only) Display information about Protected System Domains (PSDs).	show chassis psd
(M120 routers only) Display status information about configured FEB redundancy groups.	show chassis redundancy feb
Display the information about one or more Routing Engines.	show chassis routing-engine
(M40 router only) Display System Control Board (SCB) status information.	show chassis scb
(M40e and M160 routers only) Change and display SFM status information.	show chassis sfm
(M320 routers and T Series routers only) Display SIB status information.	show chassis sibs

Table 44: Chassis Operational Mode Commands (*continued*)

Task	CLI Command
(T Series routers only) Display SPMB status information.	show chassis spmb
(T Series routers only) Display SPMB Switch Interface Board (SIB) status information.	show chassis spmb sibs
(M320 routers only) Display information about the external clock source currently used for chassis synchronization.	show chassis synchronization
Display chassis temperature threshold settings, in degrees Celsius.	show chassis temperature-thresholds



NOTE: For information about how to configure chassis parameters, such as conditions that activate the alarm LEDs on the router's craft interface, properties for specific PICs, and redundancy, see the *Junos OS System Basics Configuration Guide*.

For information about related tasks performed by network operations center (NOC) personnel, see the *Junos Hardware Network Operations Guide*.

clear chassis display message

Syntax	clear chassis display message
Syntax (TX Matrix Router)	clear chassis display message <fcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	clear chassis display message <fcc <i>number</i> sfc <i>number</i> >
Release Information	<p>Command introduced in Junos OS Release 7.5.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>sfc option for the TX Matrix Plus routers introduced in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	(M40e, M160, M320, T Series routers, EX Series, and QFX Series only) Clear or stop a text message on the craft interface display, which is on the front of the router or switch or on the LCD panel display on the router or switch. The craft interface alternates the display of text messages with standard craft interface messages, switching between messages every 2 seconds. By default, on both the router and the switch, the text message is displayed for 5 minutes. The craft interface display has four 20-character lines. The LCD panel display has two 16-character lines, and text messages appear only on the second line.
Options	<p>none—Clear or stop a text message on the craft interface display.</p> <p>fcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, clear or stop a text message on the craft interface on a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, clear or stop a text message on the craft interface on a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) (Optional) Clear or stop a text message on the craft interface on the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Clear or stop a text message on the craft interface on the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> Configuring the LCD Panel on EX Series Switches (CLI Procedure) set chassis display message on page 201 show chassis craft-interface on page 212
List of Sample Output	clear chassis display message on page 166
Output Fields	See show chassis craft-interface for an explanation of output fields.

Sample Output

clear chassis display message The following example displays and then clears the text message on the craft interface display:

```
user@host> show chassis craft-interface
Red alarm:      LED off, relay off
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host fail LED:  Off
FPCs           0  1  2  3  4  5  6  7
-----
Green  ..  *..  *  *.
Red    .....
LCD screen:
+-----+
|NOC contact Dusty|
|(888) 526-1234   |
+-----+

user@host> clear chassis display message

user@host> show chassis craft-interface
Red alarm:      LED off, relay off
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host fail LED:  Off
FPCs           0  1  2  3  4  5  6  7
-----
Green  ..  *..  *  *.
Red    .....
LCD screen:
+-----+
|host
|Up: 0+17:05:47
|
|Temperature OK
+-----+
```

request chassis cb

Syntax	request chassis cb (offline online) slot <i>slot-number</i>
Syntax (TX Matrix Router)	request chassis cb (offline online) <slot <i>slot-number</i> lcc <i>number</i> slot <i>cb-slot-number</i> scc <i>number</i> slot <i>cb-slot-number</i> >
Syntax (TX Matrix Plus Router)	request chassis cb (offline online) <slot <i>slot-number</i> lcc <i>number</i> slot <i>cb-slot-number</i> sfc <i>number</i> slot <i>cb-slot-number</i> >
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS 9.4 for EX Series switches.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p>
Description	<p>(M120, M320, and MX Series routers and T Series routers and EX8200 switches only)</p> <p>Control the operation of the Control Board (CB). For information about the meaning of "CBs" on the switches, see EX Series Switches Hardware and CLI Terminology Mapping.</p>
Options	<p>offline—Take the CB offline.</p> <p>online—Bring the CB online.</p> <p>slot <i>slot-number</i>—CB slot number:</p> <ul style="list-style-type: none"> (TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, if you specify the number of the T640 router by using the lcc <i>number</i> option (the recommended method), replace <i>cb-slot-number</i> with a value from 0 through 1. Likewise, on a TX Matrix Plus router, if you specify the number of the T1600 router by using the lcc <i>number</i> option (the recommended method), replace <i>cb-slot-number</i> with a value from 0 through 1. M320 router—Replace <i>slot-number</i> with a value from 0 through 1. MX480/MX240 routers—Replace <i>slot-number</i> with a value from 0 through 1. MX960 router—Replace <i>slot-number</i> with a value from 0 through 2. EX8208 switch—Replace <i>slot-number</i> with a value from 0 through 2. EX8216 switch—Replace <i>slot-number</i> with a value from 0 through 1. <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Change the CB status for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Required Privilege Level	maintenance
List of Sample Output	request chassis cb on page 168
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis cb user@host> request chassis cb offline slot 1
Backup CB 1 cannot be set offline, backup RE is online
```


request chassis cfep

Syntax	request chassis cfep (offline online restart)
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M7i and M10i routers only) Control the operation of the Compact Forwarding Engine Board (CFEB).
Options	offline—Take the CFEB offline. online—Bring the CFEB online. restart—Restart the CFEB.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• show chassis cfep on page 208
List of Sample Output	request chassis cfep on page 169
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis cfep	user@host> request chassis cfep offline CFEB Offlined
-----------------------------	--

request chassis cip

Syntax	<code>request chassis cip (offline online) slot <i>slot-number</i></code>
Release Information	Command introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(TX Matrix Plus routers only) Control the operation of the Connector Interface Panel (CIP).
Options	<p>offline—Take the CIP offline.</p> <p>online—Bring the CIP online.</p> <p>slot <i>slot-number</i>—CIP slot number. Replace <i>slot-number</i> with a value ranging from 0 through 1.</p>
Required Privilege Level	maintenance
List of Sample Output	<p>request chassis cip offline slot (TX Matrix Plus Router) on page 170</p> <p>request chassis cip offline slot (TX Matrix Plus Router) on page 170</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis cip offline slot (TX Matrix Plus Router)	<pre>user@host > request chassis cip offline slot 0 CIP 0 offline done</pre>
request chassis cip offline slot (TX Matrix Plus Router)	<pre>user@host > request chassis cip online slot 0 CIP 0 online done</pre>

request chassis fabric plane

Syntax	<code>request chassis fabric plane <i>plane-number</i> (offline online)</code>
Release Information	Command introduced in Junos OS Release 8.0. Command introduced in Junos OS Release 9.4 for EX Series switches.
Description	(M120 and MX Series routers and EX8200 switches only) Control the operation of the specified fabric plane.
Options	<p>offline—Take the fabric plane offline. Use the request chassis fabric plane <i>plane-number</i> offline command to clear a FAULT state on a fabric plane. To bring the fabric plane back online, use the request chassis fabric plane <i>plane-number</i> online command.</p> <p>online—Bring the fabric plane online.</p> <p>plane <i>plane-number</i>—Fabric plane number.</p> <ul style="list-style-type: none"> For the M120 router, replace <i>plane-number</i> with a value from 0 through 3. For the MX480 and MX240 routers, replace <i>plane-number</i> with a value from 0 through 7. For the MX960 router, replace <i>plane-number</i> with a value from 0 through 5. For the EX8208 switch, replace <i>plane-number</i> with a value from 0 through 11. For the EX8216 switch, replace <i>plane-number</i> with a value from 0 through 7.
Required Privilege Level	maintenance
List of Sample Output	request chassis fabric plane 0 online on page 171 request chassis fabric plane 0 offline on page 171 request chassis fabric plane 0 online (EX8200 switch) on page 171
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request chassis fabric plane 0 online  user@host> request chassis fabric plane 0 online
                                       Online initiated, use "show chassis fabric plane" to verify

request chassis fabric plane 0 offline user@host> request chassis fabric plane 0 offline
                                       Offline initiated, use "show chassis fabric plane" to verify

request chassis fabric plane 0 online  user@host> request chassis fabric plane 0 online
plane 0 online                          Plane 0 is already active
(EX8200 switch)

```

request chassis feb

Syntax	<code>request chassis feb (offline online restart) slot <i>slot-number</i></code>
Release Information	Command introduced in Junos OS Release 8.0.
Description	(M120 router only) Control the operation of the specified Forwarding Engine Board (FEB).
Options	<p>offline—Take the specified FEB offline.</p> <p>online—Bring the specified FEB online.</p> <p>restart—Restart the specified FEB.</p> <p>slot <i>slot-number</i>—FEB slot number. Replace <i>slot-number</i> with a value from 0 through 5.</p>
Required Privilege Level	maintenance
List of Sample Output	<p><code>request chassis feb offline slot 0</code> on page 172</p> <p><code>request chassis feb online slot 0</code> on page 172</p> <p><code>request chassis feb restart slot 0</code> on page 172</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>request chassis feb offline slot 0</code>	<code>user@host> request chassis feb offline slot 0</code> Offline initiated, use "show chassis feb" to verify
<code>request chassis feb online slot 0</code>	<code>user@host> request chassis feb online slot 0</code> Online initiated, use "show chassis feb" to verify
<code>request chassis feb restart slot 0</code>	<code>user@host> request chassis feb restart slot 0</code> Restart initiated, use "show chassis feb" to verify

request chassis fpc

Syntax	request chassis fpc (offline online restart) slot <i>slot-number</i>
Syntax (TX Matrix and TX Matrix Plus Router)	request chassis fpc (offline online restart) slot <i>slot-number</i> <lcc <i>number</i> >
Syntax (MX Series Router)	request chassis fpc (offline online restart) slot <i>slot-number</i> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches that have multiple FPCs.
Description	(M20, M40, M40e, M120, M160, M320, MX Series, and T Series routers and EX Series switches only) Control the operation of the Flexible PIC Concentrator (FPC). For information about the meaning of “FPCs” on the switches, see EX Series Switches Hardware and CLI Terminology Mapping.
Options	<p>offline—Take the FPC offline.</p> <p>online—Bring the FPC online.</p> <p>restart—Restart the FPC.</p> <p>slot <i>slot-number</i>—FPC slot number:</p> <ul style="list-style-type: none"> • M20 router—0 through 3. • M120 router—0 through 5. • MX240 router—0 through 2. On the MX240 router, slot-number corresponds to the Dense Port Concentrator (DPC) slot number. If an MPC is installed, slot-number corresponds to the MPC slot number. • MX480 router—0 through 5. On the MX480 router, slot-number corresponds to the Dense Port Concentrator (DPC) slot number. If an MPC is installed, slot-number corresponds to the MPC slot number. • MX960 router—0 through 11. On the MX960 router, slot-number corresponds to the Dense Port Concentrator (DPC) slot number. If an MPC is installed, slot-number corresponds to the MPC slot number. • TX Matrix and TX Matrix Plus routers only—On the TX Matrix router, if you specify the number of the T640 router by using the lcc <i>number</i> option (the recommended method), replace slot-number with a value from 0 through 7. Otherwise, replace slot-number with a value from 0 through 31. <p>Likewise, on a TX Matrix Plus router, if you specify the number of the T1600 router by using the lcc <i>number</i> option (the recommended method), replace slot-number with a value from 0 through 7. Otherwise, replace slot-number with a value from 0 through 31. For example, the following commands have the same result:</p>

```
user@host> request chassis fpc lcc 1 slot 1 offline
user@host> request chassis fpc slot 9 offline
```

- Other routers—0 through 7.
- EX Series switches:
 - EX4200 switches in a Virtual Chassis configuration—Replace **slot-number** with a value from 0 through 9 (switch's member ID).
 - EX8208 switches—Replace **slot-number** with a value from 0 through 7 (line card).
 - EX8216 switches—Replace **slot-number** with a value from 0 through 15 (line card).

all-members—(MX Series routers only) (Optional) Change FPC status of all members of the Virtual Chassis configuration.

local—(MX Series routers only) (Optional) Change FPC status of the local Virtual Chassis member.

member member-id—(MX Series routers only) (Optional) Change FPC status of the specified member of the Virtual Chassis configuration. Replace **member-id** with a value of 0 or 1.

lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, control the FPC in a specified T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, control the FPC in a specified T1600 router that is connected to the TX Matrix Plus router. Replace **number** with a value from 0 through 3.

Required Privilege Level maintenance

Related Documentation

- [show chassis fpc on page 406](#)

List of Sample Output [request chassis fpc on page 174](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis fpc user@host> request chassis fpc online slot 0
FPC 0 already online
```

request chassis fpm resync

Syntax	request chassis fpm resync
Syntax (TX Matrix Router)	request chassis fpm resync (<i>lcc number</i> <i>scc</i>)
Syntax (TX Matrix Plus Router)	request chassis fpm resync (<i>lcc number</i> <i>sfc number</i>)
Syntax (MX Series Router)	request chassis fpm resync <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(M40e, M120, M160, M320, MX Series, and T Series routers only) Resynchronize the craft interface status.
Options	<p>all-members—(MX Series routers only) (Optional) Resynchronize the craft interface status on all members of the Virtual Chassis configuration.</p> <p><i>lcc number</i>—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, resynchronize the craft interface status on a specified T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, resynchronize the craft interface status on a specified T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Resynchronize the craft interface status on the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Resynchronize the craft interface status on the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) Resynchronize the craft interface status on the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) Resynchronize the craft interface status on the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Required Privilege Level	maintenance
List of Sample Output	request chassis fpm resync on page 176
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis fpm    user@host> request chassis fpm resync
resync                Front Panel resynced
```


request chassis lcc

Syntax (TX Matrix and TX Matrix Plus Router)	request chassis lcc (offline online) slot <i>slot-number</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, control the operation of a T640 router (or line-card chassis) that is connected to the TX matrix router. On a TX Matrix Plus router, control the operation of a T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router.
Options	<p>offline—On a routing matrix based on the TX Matrix router (or switch-card chassis), take the T640 router (or line-card chassis) offline. On a routing matrix based on a TX Matrix Plus router (or switch-fabric chassis), take the T1600 router (or line-card chassis) offline.</p> <p>online—On a routing matrix based on the TX Matrix router (or switch-card chassis), bring the T640 router (or line-card chassis) online. On a routing matrix based on a TX Matrix Plus router (or switch-fabric chassis), bring the T1600 router (or line-card chassis) online.</p> <p>slot <i>slot-number</i>—On a TX Matrix router (or switch-card chassis), the slot number of a T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router (or switch-fabric chassis), the slot number of a T1600 router (or line-card chassis) that is connected to the TX Matrix Plus (or switch-fabric chassis) router. Replace <i>slot-number</i> with a value from 0 through 3.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show chassis lccs on page 470
List of Sample Output	request chassis lcc on page 177
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis lcc user@host> request chassis lcc offline slot 0

request chassis mcs

Syntax	<code>request chassis mcs (offline online restart) slot <i>slot-number</i></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Control the operation of the Miscellaneous Control Subsystem (MCS).
Options	<p>offline—Take the MCS offline.</p> <p>online—Bring the MCS online.</p> <p>restart—Restart the MCS.</p> <p>slot <i>slot-number</i>—MCS slot number. Replace <i>slot-number</i> with 0 or 1.</p>
Required Privilege Level	maintenance
List of Sample Output	request chassis mcs on page 178
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis mcs  user@host> request chassis mcs online slot 0
MCS 0 appears to be online already
```



request chassis pcg

Syntax	request chassis pcg (offline online) slot <i>slot-number</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers) Control the operation of the Packet Forwarding Engine (PFE) clock generator (PCG).
Options	offline—Take the PCG offline. online—Bring the PCG online. slot <i>slot-number</i> —PCG slot number. Replace <i>slot-number</i> with 0 or 1.
Required Privilege Level	maintenance
List of Sample Output	request chassis pcg on page 179
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis pcg user@host> request chassis pcg online slot 0
PCG 1 appears to be already online
```

request chassis pic

Syntax	request chassis pic (offline online) fpc-slot <i>slot-number</i> pic-slot <i>slot-number</i>
Syntax (TX Matrix and TX Matrix Plus Router)	request chassis pic (offline online) fpc-slot <i>slot-number</i> pic-slot <i>slot-number</i> <lcc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Control the operation of the PIC.
	<div>  <p>NOTE: The request chassis pic (offline online) fpc-slot <i>slot number</i> pic-slot <i>slot-number</i> command is not supported for built-in PICs on MX Series routers.</p> <p>To view a list of built-in PICs on the router or switch chassis, use the show chassis hardware command.</p> </div>
	<div>  <p>NOTE: T1600 routers and TX Matrix Plus routers with 100-Gigabit Ethernet PICs require two adjacent PIC slots, 0 and 1, for each PIC. Therefore, only online and offline command options to PIC slot 0 are allowed. Use of the online and offline command options for PIC slot 1 with the described router and PIC combination is not allowed.</p> </div>
Options	<p>offline—Take the PIC offline.</p> <p>online—Bring the PIC online.</p> <p>fpc-slot <i>slot-number</i>—Flexible PIC Concentrator (FPC) slot number. Replace <i>slot-number</i> with a value appropriate for your router or switch:</p> <ul style="list-style-type: none"> EX Series switches: <ul style="list-style-type: none"> EX3200 switches and EX4200 standalone switches—0. EX4200 switches in a Virtual Chassis configuration—0 through 9 (switch's member ID). EX8208 switches—0 through 7 (line card). EX8216 switches—0 through 15 (line card). M5, M7i, M10, and M10i routers—0 or 1. M20 routers—0 through 3. M120 routers—0 through 5. MX960 routers—0 through 11.

- M40, M40e, M160, M320, T320, T640, and T1600 routers—0 through 7.
- TX Matrix and TX Matrix Plus routers only—On a TX Matrix router, if you specify the number of the T640 router by using the **lcc number** option (the recommended method), replace **slot-number** with a value from 0 through 7. Otherwise, replace **slot-number** with a value from 0 through 31.

Likewise, on a TX Matrix Plus router, if you specify the **number** of the T1600 router by using the lcc number option (the recommended method), replace **slot-number** with a value from 0 through 7. Otherwise, replace **slot-number** with a value from 0 through 31. For example, the following commands have the same result:

```
user@host> request chassis pic fpc-slot 1 lcc 1 pic-slot 0 offline
user@host> request chassis pic fpc-slot 9 pic-slot 0 offline
```

pic-slot slot-number—PIC slot number. For the M Series router, the T640 router, the T1600 router, and the TX Matrix and TX Matrix Plus routers, it can be 0, 1, 2, or 3. On the MX960 router, **slot-number** corresponds to the slot number of the Packet Forwarding Engine. For the T320 router, it can be 0 or 1. For EX3200 and EX4200 switches, it is 0 for built-in network interfaces and 1 for interfaces on uplink modules. For EX8208 and EX8216 switches, it is 0.

lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, control the PIC in a specified T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, control the PIC in a specified T1600 router that is connected to the TX Matrix Plus router. Replace **number** with a value from 0 through 3.

Required Privilege Level maintenance

Related Documentation

- [show chassis hardware on page 423](#)
- [show chassis pic on page 478](#)

List of Sample Output [request chassis pic on page 181](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis pic user@host> request chassis pic pic-slot 0 online fpc-slot 0
FPC 0, PIC 0 is already online
```

request chassis mic

Syntax	<code>request chassis mic (offline online) fpc-slot <i>slot-number</i> mic-slot <i>slot-number</i></code>
Release Information	Command introduced in Junos OS Release 10.1.
Description	(MX Series routers only) Control the operation of the Modular Interface Cards (MICs) installed on a Modular Port Concentrator (MPC).
Options	<p>offline—Take the MIC offline.</p> <p>online—Bring the MIC online.</p> <p>fpc-slot <i>slot-number</i>—FPC slot number where the MIC is installed:</p> <ul style="list-style-type: none">• MX80 router—Replace <i>fpc-slot</i> with the value 1. This command is not supported on FPC slot 0.• MX240 router—Replace <i>fpc-slot</i> with a value from 0 through 2.• MX480 router—Replace <i>fpc-slot</i> with a value from 0 through 5.• MX-960 router—Replace <i>fpc-slot</i> with a value from 0 through 11. <p>mic-slot <i>slot-number</i>—MIC slot number. Replace <i>slot-number</i> with 0 or 1.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• show chassis hardware on page 423
List of Sample Output	request chassis mic online on page 182
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>request chassis mic online</code>	<code>user@host> request chassis mic online fpc-slot 1 mic-slot 1</code>
---	---

request chassis redundancy feb slot

Syntax	<code>request chassis redundancy feb slot <i>slot-number</i> (switch-to-backup revert-from-backup)</code>
Release Information	Command introduced in Junos OS Release 8.2.
Description	(M120 routers only) Control the operation of the specified Forwarding Engine Board (FEB) in a redundancy group.
Options	<p><i>slot-number</i>—FEB slot number. Replace <i>slot-number</i> with a value from 0 through 5.</p> <p><code>switch-to-backup</code>—Initiate a switchover from the specified active FEB to the backup FEB for the redundancy group.</p> <p><code>revert-from-backup</code>—Initiate a revert to the specified FEB following a switchover to the backup FEB for a redundancy group.</p>
Required Privilege Level	maintenance
List of Sample Output	<p><code>request chassis redundancy feb slot 2 switch-to-backup</code> on page 183</p> <p><code>request chassis redundancy feb slot 3 revert-to-backup</code> on page 183</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request chassis user@host> request chassis redundancy feb slot 2 switch-to-backup
redundancy feb slot 2 Switch initiated, use "show chassis redundancy febs" to verify
switch-to-backup

request chassis user@host> request chassis redundancy feb slot 3 revert-to-backup
redundancy feb slot 3 Revert initiated, use "show chassis redundancy febs" to verify
revert-to-backup

```

request chassis routing-engine master

Syntax	request chassis routing-engine master (acquire release switch) <force> <no-confirm>
Syntax (TX Matrix Router)	request chassis routing-engine master (acquire release switch) (lcc <i>number</i> scc all-chassis) <force> <no-confirm>
Syntax (TX Matrix Plus Router)	request chassis routing-engine master (acquire release switch) (lcc <i>number</i> sfc all-chassis all-lcc) <force> <no-confirm>
Syntax (MX Series Router)	request chassis routing-engine master (acquire release switch) <all-members> <force> <local> <member <i>member-id</i> > <no-confirm>
Release Information	Command introduced before Junos OS Release 7.4. all-chassis option added in Junos OS Release 8.0. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	For routers or switches with multiple Routing Engines, control which Routing Engine is the master.



CAUTION: (Routing matrix based on the TX Matrix or TX Matrix Plus routers only) Within the routing matrix, we recommend that all Routing Engines run the same Junos OS Release. If you run different releases on the Routing Engines and a change in mastership occurs on any backup Routing Engine in the routing matrix, one or all T640 routers (in a routing matrix based on the TX Matrix router) or T1600 routers (in a routing matrix based on a TX Matrix Plus router) might become logically disconnected from the TX Matrix router and cause data loss. For more information, see the [TX Matrix Router Hardware Guide](#) or the [Junos OS High Availability Configuration Guide](#).



NOTE: Successive graceful Routing Engine switchover events must be a minimum of 240 seconds (4 minutes) apart after both Routing Engines have come up.

If the router or switch displays a warning message similar to “Standby Routing Engine is not ready for graceful switchover. Packet Forwarding Engines that are not ready for graceful switchover might be reset,” do not attempt switchover. If you choose to proceed with switchover, only the Packet Forwarding Engines that were not ready for graceful switchover are reset. None of the Flexible PIC concentrators (FPCs) should spontaneously restart. We recommend that you wait until the warning no longer appears and then proceed with the switchover.

Options **acquire**—Attempt to become the master Routing Engine.

release—Request that the other Routing Engine become the master.

switch—Toggle mastership between Routing Engines.

The **acquire**, **release**, and **switch** options have the following suboptions:

all-chassis—(TX Matrix and TX Matrix Plus routers only) On a routing matrix composed of a TX Matrix router and the attached T640 routers, switch mastership on all the Routing Engines in the routing matrix. Likewise, on a routing matrix composed of a TX Matrix Plus router and the attached T1600 routers, switch mastership on all the Routing Engines in the routing matrix.

all-lcc—(TX Matrix Plus routers only) Request to acquire mastership for all line-card chassis (LCC).

all-members—(MX Series routers only) (Optional) Control Routing Engine mastership on the Routing Engines in all member routers of the Virtual Chassis configuration.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, the T640 router (or LCC) that is connected to the TX Matrix router (or switch-card chassis). On a TX Matrix Plus router, the T1600 router (or LCC) that is connected to the TX Matrix Plus router (or switch-fabric chassis). Replace ***number*** with a value from 0 through 3.

local—(MX Series routers only) (Optional) Control Routing Engine mastership on the Routing Engines in the local Virtual Chassis member.

member *member-id*—(MX Series routers only) (Optional) Control Routing Engine mastership on the Routing Engines of the specified member in the Virtual Chassis Configuration. Replace ***member-id*** with a value of 0 or 1.

no-confirm—(Optional) Do not request confirmation for the switch.

scc—(TX Matrix routers only) TX Matrix (or switch-card chassis).

sfc—(TX Matrix Plus routers only) TX Matrix Plus router (or switch-fabric chassis).

force—(Optional) Available only with the acquire option. Force the change to a new master Routing Engine.

Additional Information Because both Routing Engines are always running, the transition from one to the other as the master Routing Engine is immediate. However, the changeover interrupts communication to the System and Switch Board (SSB). The SSB takes several seconds to reinitialize the Flexible PIC Concentrators (FPCs) and restart the PICs. Interior gateway protocol (IGP) and BGP convergence times depend on the specific network environment.

By default, the Routing Engine in slot 0 (RE0) is the master and the Routing Engine in slot 1 (RE1) is the backup. To change the default master Routing Engine, include the **routing-engine** statement at the **[edit chassis redundancy]** hierarchy level in the configuration. For more information, see the [Junos OS System Basics Configuration Guide](#)

To have the backup Routing Engine become the master Routing Engine, use the **request chassis routing-engine master switch** command. If you use this command to change the master and then restart the chassis software for any reason, the master reverts to the default setting.



NOTE: Although the configurations on the two Routing Engines do not have to be the same and are not automatically synchronized, we recommend making both configurations the same.

Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show chassis routing-engine on page 498
List of Sample Output	request chassis routing-engine master acquire on page 186 request chassis routing-engine master switch on page 186
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request chassis routing-engine master acquire
user@host> request chassis routing-engine master acquire

warning: Traffic will be interrupted while the PFE is re-initialized
warning: The other routing engine's file system could be corrupted

Reset other routing engine and become master ? [yes,no] (no)

request chassis routing-engine master switch
user@host> request chassis routing-engine master switch

warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between Routing Engines ? [yes,no] (no) yes

```

Resolving mastership...
Complete. The other Routing Engine becomes the master.

Switch mastership back to the local Routing Engine:

user@host> **request chassis routing-engine master switch**

warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between routing engines ? [yes,no] (no) yes

Resolving mastership...
Complete. The local routing engine becomes the master.

request chassis scg

Syntax	request chassis scg (offline online) slot <i>slot-number</i>
Syntax (TX Matrix and TX Matrix Plus Routers)	request chassis scg lcc <i>number</i> (offline online) slot <i>slot-number</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(T Series routers only) Control the operation of the specified SONET Clock Generator (SCG).
Options	<p><i>lcc number</i>—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix Plus router, change the SCG status on a specified T640 router (or line-card chassis [LCC]) that is connected to the TX Matrix router. On a TX Matrix Plus router, change the SCG status on a specified T1600 router (or LCC) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p><i>offline</i>—Take the SCG offline. When you change the SCG status to offline, the unit is not powered down.</p> <p><i>online</i>—Bring the SCG online.</p> <p><i>slot slot-number</i>—SCG slot number. Replace <i>slot-number</i> with 0 or 1.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• show chassis environment scg on page 277
List of Sample Output	request chassis scg on page 188
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis scg	<pre>user@host> request chassis scg online slot 0 Online initiated, use "show chassis environment scg" to verify</pre>
----------------------------	---

request chassis sfm

Syntax	request chassis sfm (offline online restart) slot <i>slot-number</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Control the operation of the specified Switching and Forwarding Module (SFM).
Options	<p>offline—Take the SFM offline.</p> <p>online—Bring the SFM online.</p> <p>restart—Restart the SFM.</p> <p>slot <i>slot-number</i>—SFM slot number. Replace <i>slot-number</i> with a value from 0 through 3.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show chassis sfm on page 512
List of Sample Output	<p>request chassis sfm (M40e) on page 189</p> <p>request chassis sfm (M160) on page 189</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis sfm (M40e)	<pre>user@host> request chassis sfm slot 1 restart M40e router: error: SFM 0 is transitioning to online state.</pre>
request chassis sfm (M160)	<pre>user@host> request chassis sfm slot 1 restart M160 router: Restart initiated, use "show chassis sfm" to verify</pre>

request chassis sfm master switch

Syntax	request chassis sfm master switch <no-confirm>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Control which Switching and Forwarding Module (SFM) is master.
Options	no-confirm—(Optional) Do not display a switch warning or query.
Additional Information	<p>By default, the SFM in slot 0 (SFM0) is the master and the SFM in slot 1 (SFM1) is the backup. If you use this command to change the master, and then restart the chassis software for any reason, the master reverts to the default setting. To change the default master SFM, include the sfm statement at the [edit chassis redundancy] hierarchy level in the configuration. For more information, see the Junos OS System Basics Configuration Guide.</p> <p>All installed SFMs are always working together to forward packets. If an SFM fails, the other SFMs take over and traffic continues to flow uninterrupted.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• show chassis sfm on page 512
List of Sample Output	request chassis sfm master switch on page 190 request chassis sfm master switch no-confirm on page 190
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis sfm master switch	<pre>user@host> request chassis sfm master switch warning: Traffic will be interrupted while the PFE is re-initialized Toggle mastership between system forwarding module? [yes,no] (no) yes Switch initiated, use "show chassis sfm" to verify</pre>
request chassis sfm master switch no-confirm	<pre>user@host> request chassis sfm master switch no-confirm Switch initiated, use "show chassis sfm" to verify</pre>

request chassis sib

Syntax	request chassis sib (offline online) slot <i>slot-number</i>
Syntax (TX Matrix Router)	request chassis sib (lcc <i>number</i> scc) (offline online) slot <i>slot-number</i> (start-receiver <i>number</i> stop-receiver <i>number</i>)
Syntax (TX Matrix Plus Router)	request chassis sib (all-lcc f13 <i>slot-number</i> f2s <i>sib-slot/sib-f2s-slot-number</i> lcc <i>number</i> (offline online) slot <i>slot-number</i>)
Release Information	Command introduced before Junos OS Release 7.4. f13 and f2s options for the TX Matrix Plus router introduced in Junos OS Release 9.6.
Description	(M320 routers and T Series routers only) Control the operation of the specified Switch Interface Board (SIB).
Options	<p>all-lcc—(TX Matrix Plus routers only) Control the operation of the SIB on all T1600 routers connected to the TX Matrix Plus router.</p> <p>f13 <i>slot-number</i>—Control the operation of F13 SIBs. Replace <i>slot-number</i> with a value 0, 1, 3, 4, 6, 7, 8, 9, 11, or 12.</p> <p>f2s <i>sib-slot/sib-f2s-slot-number</i>—(TX Matrix Plus routers only) (Optional) Control the operation of the SIB F2s. Replace <i>sib-slot</i> with a value from 0 through 4, followed by a <i>sib-f2s-slot-number</i> value 0, 2, 4 or 6.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, the T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, the T1600 router (or line-card chassis) and TX Matrix Plus that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix router only) TX Matrix router (or switch-card chassis) on a routing matrix.</p> <p>offline—Take the SIB offline.</p> <p>online—Bring the SIB online.</p> <p>slot <i>slot-number</i>—SIB slot number. For the T320 router, replace <i>slot-number</i> with a value from 0 through 2. For the T640 router, TX Matrix router, and T1600 router in a routing matrix, replace <i>slot-number</i> with a value from 0 through 4.</p> <p>start-receiver <i>number</i>—(TX Matrix routers only) Start the SIB optical receiver. Replace <i>number</i> with a value from 0 through 3.</p> <p>stop-receiver <i>number</i>—(TX Matrix routers only) Stop the SIB optical receiver. Replace <i>number</i> with a value from 0 through 3.</p>
Required Privilege Level	maintenance

Related Documentation	<ul style="list-style-type: none">• show chassis sibs on page 515
List of Sample Output	request chassis sib on page 192 request chassis sib on page 192
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request chassis sib	<code>user@host> request chassis sib slot 0 online</code> Online initiated, use "show chassis sibs" to verify
request chassis sib	<code>user@host> request chassis sib f13 slot 0 offline</code> Offline initiated, use "show chassis sibs" to verify

request chassis sib f13 train-link-receive slot

Syntax	request chassis sib f13 train-link-receive slot <i>SFC-SIB-F13-slot-num</i>
Syntax (TX Matrix Plus Routing)	request chassis sib f13 train-link-receive slot <i>SFC-SIB-F13-slot-num</i>
Release Information	Command introduced in Junos OS Release 10.1.
Description	(TX Matrix Plus routing platform only) Control the receiving link of the specified Switch Interface Board (SIB) of the SFC.
Options	slot <i>SFC-SIB-F13-slot-num</i> — SFC SIB slot number. Replace it with 0, 3, 6, 8 or 11.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> request chassis sib f13 train-link-transmit slot on page 194
List of Sample Output	request chassis sib f13 train-link-receive slot on page 193
Output Fields	When you enter this command, the SFC is ready to receive traffic from the T1600 router (LCC).

Sample Output

```
request chassis sib f13 train-link-receive slot
user@host> request chassis sib f13 train-link-receive slot 0
```

request chassis sib f13 train-link-transmit slot

Syntax	request chassis sib f13 train-link-transmit slot <i>SFC-SIB-F13-slot-num</i>
Release Information	Command introduced in Junos OS Release 10.1.
Description	(TX Matrix Plus routing platform only) Control the transmission link of the specified Switch Interface Board (SIB) of the SFC.
Options	slot <i>SFC-SIB-F13-slot-num</i> —SFC SIB slot number. Replace it with 0, 3, 6, 8 or 11.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">request chassis sib f13 train-link-receive slot on page 193
List of Sample Output	request chassis sib f13 train-link-transmit slot on page 194
Output Fields	When you enter this command, the SFC is ready to transmit traffic to the T1600 router (LCC).

Sample Output

```
request chassis sib f13 train-link-transmit slot user@host> request chassis sib f13 train-link-transmit slot 0
```

request chassis sib train-link-receive slot

Syntax	request chassis sib train-link-receive slot <i>LCC-SIB-ST-SIB-L-slot-num</i>
Release Information	Command introduced in Junos OS Release 10.1.
Description	(T1600 Router [LCC] and TX Matrix Plus routing platform only) Control the receiving link of the specified Switch Interface Board (SIB) of the LCC.
Options	slot <i>LCC-SIB-ST-SIB-L-slot-num</i> — LCC SIB slot number. Replace it with a value from 0 through 4.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">request chassis sib train-link-transmit slot on page 196
List of Sample Output	request chassis sib train-link-receive slot on page 195
Output Fields	When you enter this command, the LCC is ready to receive traffic from the SFC.

Sample Output

```
request chassis sib  user@host> request chassis sib train-link-receive slot 0
train-link-receive slot
```

request chassis sib train-link-transmit slot

Syntax	<code>request chassis sib train-link-transmit slot <i>LCC-SIB-ST-SIB-L-slot-num</i></code>
Syntax (TX Matrix Plus Routing Platform)	<code>request chassis sib train-link-receive slot <i>LCC-SIB-ST-SIB-L-slot-num</i></code>
Release Information	Command introduced in Junos OS Release 10.1.
Description	(T1600 Router (LCC) and TX Matrix Plus routing platform only) Control the transmission link of the specified Switch Interface Board (SIB) of the LCC.
Options	<code>slot <i>LCC-SIB-ST-SIB-L-slot-num</i></code> — LCC SIB slot number. Replace it with a value from 0 through 4.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• request chassis sib train-link-receive slot on page 195
List of Sample Output	request chassis sib train-link-transmit slot on page 196
Output Fields	When you enter this command, the LCC is ready to transmit traffic to the SFC.

Sample Output

```
request chassis sib train-link-transmit slot user@host> request chassis sib train-link-transmit slot 0
```

request chassis spmb restart

Syntax	<code>request chassis spmb restart slot <i>slot-number</i></code>
Syntax (TX Matrix Router)	<code>request chassis spmb restart (lcc <i>number</i> scc) slot <i>slot-number</i></code>
Syntax (TX Matrix Plus Router)	<code>request chassis spmb restart (lcc <i>number</i> sfc <i>number</i>) slot <i>slot-number</i></code>
Release Information	Command introduced before Junos OS Release 7.4. sfc option for the TX Matrix Plus router introduced in Junos OS Release 9.6.
Description	Restart the specified Switch Processor Mezzanine Board (SPMB) on the Control Board (CB).
Options	<p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, the T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, the T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) TX Matrix router (or switch-card chassis) in the routing matrix.</p> <p>sfc—(TX Matrix Plus routers only) TX Matrix Plus router (or switch-fabric chassis) in the routing matrix.</p> <p>slot <i>slot-number</i>—CB slot number. Replace <i>slot-number</i> with 0 or 1.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show chassis spmb on page 521 • show chassis spmb sibs on page 528
List of Sample Output	request chassis spmb restart on page 197
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request chassis spmb restart user@host> request chassis spmb restart slot 0
```

request chassis ssb master switch

Syntax	request chassis ssb master switch <no-confirm>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M20 router only) Control which System and Switch Board (SSB) is master.
Options	no-confirm—(Optional) Do not request confirmation for the switch.
Additional Information	<p>By default, the SSB in slot 0 (SSB0) is the master and the SSB in slot 1 (SSB1) is the backup. If you use this command to change the master, and then restart the chassis software for any reason, the master reverts to the default setting. To change the default master SSB, include the ssb statement at the [edit chassis redundancy] hierarchy level in the configuration. For more information, see the Junos OS System Basics Configuration Guide.</p> <p>The configurations on the two SSBs do not have to be the same, and they are not automatically synchronized. If you configure both SSBs as masters, when the chassis software restarts for any reason, the SSB in slot 0 becomes the master and the one in slot 1 becomes the backup.</p> <p>The switchover from the primary SSB to the backup SSB is immediate. The SSB takes several seconds to reinitialize the Flexible PIC Concentrators (FPCs) and restart the PICs. The interior gateway protocol (IGP) and BGP convergence times depend on the specific network environment.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show chassis ssb on page 532
List of Sample Output	request chassis ssb master switch on page 198 request chassis ssb master switch no-confirm on page 198
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request chassis ssb master switch
user@host> request chassis ssb master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between system switch boards ? [yes,no] (no) yes

Switch initiated, use "show chassis ssb" to verify

request chassis ssb master switch no-confirm
user@host> request chassis ssb master switch no-confirm
Switch initiated, use "show chassis ssb" to verify
no-confirm

```

request chassis synchronization mode

Syntax	request chassis synchronization mode (free-run holdover auto-select)
Release Information	Command introduced in Junos OS Release 10.4.
Description	(MX80 and MX240 routers only) Change the chassis synchronization source used for synchronized Ethernet (Sync-E) configuration.
Options	<p>freerun—Change chassis synchronization to freerun mode.</p> <p>holdover—Change chassis synchronization to holdover mode.</p> <p>auto-select—Change chassis synchronization to auto-select mode.</p>
Required Privilege Level	maintenance
Related Documentation	
List of Sample Output	<p>request chassis synchronization mode freerun on page 199</p> <p>request chassis synchronization mode holdover on page 199</p> <p>request chassis synchronization mode auto-select on page 199</p>
Output Fields	<p>When you enter this command, you are provided feedback on the status of your request. Not configured indicates that the source is not configured. Present indicates that the source is configured and present. Qualified indicates that the source is being used for synchronization.</p>

Sample Output

```
request chassis user@host> request chassis synchronization mode freerun
mode is freerun, status: qualified
freerun
```

Sample Output

```
request chassis user@host> request chassis synchronization mode holdover
mode is holdover, status: qualified
holdover
```

Sample Output

```
request chassis user@host> request chassis synchronization mode auto-select
mode is auto-select, status: qualified
auto-select
```

request chassis synchronization switch

Syntax	request chassis synchronization switch (external-a external-b)
Release Information	Command introduced in Junos OS Release 7.6. Command introduced in Junos OS Release 8.3 for M40e routers. Command introduced in Junos OS Release 9.3 for M120 routers. Command introduced in Junos OS Release 10.2 for T320, T640, and T1600 routers.
Description	(M320, M40e, M120, T320, T640, and T1600 routers only) Change the external clock source used for chassis synchronization.
Options	external-a—(Routing matrix only) Change the synchronization source to external source A. external-b—(Routing matrix only) Change the synchronization source to external source B.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• show chassis synchronization on page 534
List of Sample Output	request chassis synchronization switch external-a on page 200
Output Fields	When you enter this command, you are provided feedback on the status of your request. Not configured indicates that the source is not configured. Present indicates that the source is configured and present. Qualified indicates that the source is being used for synchronization.

Sample Output

request chassis synchronization switch external-a	user@host> request chassis synchronization switch external-a switching to external-a, status: qualified
---	--

set chassis display message

Syntax	set chassis display message " <i>message</i> " <permanent>
Syntax (TX Matrix Router)	set chassis display message " <i>message</i> " (<i>lcc number</i> <i>scc</i>) <permanent>
Syntax (TX Matrix Plus Router)	set chassis display message " <i>message</i> " (<i>fpc-slot slot-number</i> <i>lcc number</i> <i>sfc number</i>) <permanent>
Syntax (QFX Series)	set chassis display message " <i>message</i> "
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option for TX Matrix Plus router introduced in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display or stop a text message on the craft interface display, which is on the front of the router, or on the LCD panel display on the switch. The craft interface alternates the display of text messages with standard craft interface messages, switching between messages every 2 seconds. By default, on both the router and the switch, the text message is displayed for 5 minutes. The craft interface display has four 20-character lines. The LCD panel display has two 16-character lines, and text messages appear only on the second line.
Options	<p>"message"—Message to display. On the craft interface display, if the message is longer than 20 characters, it wraps onto the next line. If a word does not fit on one line, the entire word moves down to the next line. Any portion of the message that does not fit on the display is truncated. An empty pair of quotation marks (" ") deletes the text message from the craft interface display. On the LCD panel display, the message is limited to 16 characters.</p> <p>fpc-slot <i>slot-number</i>—(TX Matrix Plus routers and EX4200 and QFX Series only) On the router or switch, display the text message on the craft interface for a specific Flexible PIC Concentrator (FPC). Replace <i>slot-number</i> with a value from 0 through 31. On the switch, display the text message for a specific member of a Virtual Chassis, where fpc-slot <i>slot-number</i> corresponds to the member ID. Replace <i>slot-number</i> with a value from 0 through 9. On the QFX Series, the <i>slot-number</i> is always 0.</p> <p>lcc <i>number</i> —(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display the text message on the craft interface display of a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display the text message on the craft interface display of a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>permanent—(Optional) Display a text message on the craft interface display or LCD panel display permanently.</p>

scc—(TX Matrix routers only) Display the text message on the craft interface display of the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) Display the text message on the craft interface display of the TX Matrix Plus router (or switch-fabric chassis).

Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> Configuring the LCD Panel on EX Series Switches (CLI Procedure) clear chassis display message on page 165 show chassis craft-interface on page 212
List of Sample Output	set chassis display message (Creating) on page 202 set chassis display message (Deleting) on page 202 set chassis display message (QFX Series) on page 203
Output Fields	See show chassis craft-interface for an explanation of output fields.

Sample Output

set chassis display message (Creating)

The following example shows how to set the display message and verify the result:

```
user@host> set chassis display message "NOC contact Dusty (888) 555-1234"
message sent

user@host> show chassis craft-interface
Red alarm:      LED off, relay off
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host fail LED:  Off
FPCs           0  1  2  3  4  5  6  7
-----
Green  ..  *..  *  *.
Red    .....
LCD screen:
+-----+
|NOC contact Dusty |
|(888) 555-1234   |
+-----+
```

set chassis display message (Deleting)

The following example shows how to delete the display message and verify that the message is removed:

```
user@host> set chassis display message ""
message sent

user@host> show chassis craft-interface
Red alarm:      LED off, relay off
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host fail LED:  Off
FPCs           0  1  2  3  4  5  6  7
-----
Green  ..  *..  *  *.

```

```

Red      .....
LCD screen:
+-----+
|host    |
|Up: 0+17:05:47|
|        |
|Temperature OK|
+-----+

```

set chassis display message (QFX Series)

```
user@switch> set chassis display message
```

```
Red alarm:      LED off, relay off
```

```
Yellow alarm:   LED off, relay off
```

```
Host OK LED:    On
```

```
Host fail LED:  Off
```

```
FPCs      0  1  2  3  4  5  6  7
```

```
-----
Green  ..  *..  *  *.
```

```
Red      .....
LCD screen:
```

```

+-----+
|host    |
|Up: 0+17:05:47|
|        |
|Temperature OK|
+-----+

```

show chassis alarms

Syntax	show chassis alarms
Syntax (TX Matrix Router)	show chassis alarms <fcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis alarms <fcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis alarms <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option for the TX Matrix Plus router introduced in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display information about the conditions that have been configured to trigger alarms.
Options	<p>none—Display information about the conditions that have been configured to trigger alarms.</p> <p>all-members—(MX Series routers only) (Optional) Display information about alarm conditions for all the member routers of the Virtual Chassis configuration.</p> <p>fcc <i>number</i> — (TX Matrix and TX Matrix Plus routers only) (Optional) On the TX Matrix router, show information about a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On the TX Matrix Plus router, show information about a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display information about alarm conditions for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display information about alarm conditions for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix router only) (Optional) Show information about the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus router only) (Optional) Show information about the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Additional Information	You cannot clear the alarms for chassis components. Instead, you must remedy the cause of the alarm. When a chassis alarm is lit, it indicates that you are running the router or switch in a manner that we do not recommend.

On routers, you can manually silence external devices connected to the alarm relay contacts by pressing the alarm cutoff button, located on the craft interface. Silencing the device does not remove the alarm messages from the display (if present on the router) or extinguish the alarm LEDs. In addition, new alarms that occur after you silence an external device reactivate the external device.

In Junos OS release 11.1 and later, alarms for fans also show the slot number of the fans in the CLI output.

In Junos OS Release 11.2 and later, the command output on EX8200 switches shows the detailed location (**Plane/FPC/PFE**) for link errors in the chassis.

In Junos OS Release 10.2 and later, an alarm is shown on T Series routers for a standby sonic clock generator (SCG) that is offline or absent.

Required Privilege Level view

List of Sample Output **show chassis alarms (Alarms Active)** on page 205
show chassis alarms (No Alarms Active) on page 205
show chassis alarms (Fan Tray) on page 206
show chassis alarms (SCG Absent on a T Series Router) on page 206
show chassis alarms (Alarms Active on a TX Matrix Router) on page 206
show chassis alarms (Backup Routing Engine) on page 206
show chassis alarms (Alarms Active on the QFX Series) on page 206
show chassis alarms (Alarms Active on an EX8200 Switch) on page 206

Output Fields Table 45 on page 205 lists the output fields for the **show chassis alarms** command. Output fields are listed in the approximate order in which they appear.

Table 45: show chassis alarms Output Fields

Field Name	Field Description
Alarm time	Date and time the alarm was first recorded.
Class	Severity class for this alarm: Minor or Major .
Description	Information about the alarm.

Sample Output

```

show chassis alarms      user@host> show chassis alarms
(Alarms Active)         3 alarms are currently active
                          Alarm time      Class  Description
                          2000-02-07 10:12:22 UTC Major fxp0: ethernet link down
                          2000-02-07 10:11:54 UTC Minor YELLOW ALARM - PEM 1 Removed
                          2000-02-07 10:11:03 UTC Minor YELLOW ALARM - Lower Fan Tray Removed

show chassis alarms      user@host> show chassis alarms
(No Alarms Active)       No alarms are currently active

```

```

show chassis alarms      user@host> show chassis alarms
  (Fan Tray)              4 alarms currently active
                          Alarm time      Class  Description
                          2010-11-11 20:27:38 UTC Major  Side Fan Tray 7 Failure
                          2010-11-11 20:27:13 UTC Minor  Side Fan Tray 7 Overspeed
                          2010-11-11 20:27:13 UTC Major  Side Fan Tray 5 Failure
                          2010-11-11 20:27:13 UTC Major  Side Fan Tray 0 Failure

show chassis alarms      user@host> show chassis alarms
  (SCG Absent on a T      4 alarms currently active
   Series Router)         Alarm time      Class  Description
                          2011-01-23 21:42:46 PST Major  SCG 0 NO EXT CLK MEAS-BKUP SCG ABS

show chassis alarms      user@host> show chassis alarms
  (Alarms Active on a TX  scc-re0:
   Matrix Router)         -----
                          8 alarms currently active
                          Alarm time      Class  Description
                          2004-08-05 18:43:53 PDT Minor  LCC 0 Minor Errors
                          2004-08-05 18:43:53 PDT Minor  SIB 3 Not Online
                          2004-08-05 18:43:52 PDT Major  SIB 2 Absent
                          2004-08-05 18:43:52 PDT Major  SIB 1 Absent
                          2004-08-05 18:43:52 PDT Major  SIB 0 Absent
                          2004-08-05 18:43:33 PDT Major  LCC 2 Major Errors
                          2004-08-05 18:43:28 PDT Major  LCC 0 Major Errors
                          2004-08-05 18:43:05 PDT Minor  LCC 2 Minor Errors
                          lcc0-re0:
                          -----
                          5 alarms currently active
                          Alarm time      Class  Description
                          2004-08-05 18:43:53 PDT Minor  SIB 3 Not Online
                          2004-08-05 18:43:49 PDT Major  SIB 2 Absent
                          2004-08-05 18:43:49 PDT Major  SIB 1 Absent
                          2004-08-05 18:43:49 PDT Major  SIB 0 Absent
                          2004-08-05 18:43:28 PDT Major  PEM 0 Not OK
                          lcc2-re0:
                          -----
                          5 alarms currently active
                          Alarm time      Class  Description
                          2004-08-05 18:43:35 PDT Minor  SIB 3 Not Online
                          2004-08-05 18:43:33 PDT Major  SIB 2 Absent
                          2004-08-05 18:43:33 PDT Major  SIB 1 Absent
                          2004-08-05 18:43:33 PDT Major  SIB 0 Absent
                          2004-08-05 18:43:05 PDT Minor  PEM 1 Absent

show chassis alarms      user@host> show chassis alarms
  (Backup Routing         2 alarms are currently active
   Engine)               Alarm time      Class  Description
                          2005-04-07 10:12:22 PDT Minor  Host 1 Boot from alternate media
                          2005-04-07 10:11:54 PDT Major  Host 1 compact-flash missing in Boot List

show chassis alarms      user@switch> show chassis alarms
  (Alarms Active on the   1 alarms currently active
   QFX Series)           Alarm time      Class  Description
                          2011-11-24 07:45:01 PST Major  FPC 0 Fan 1 not spinning

show chassis alarms      user@switch> show chassis alarms
  (Alarms Active on an    6 alarms currently active
   EX8200 Switch)

```

Alarm time	Class	Description
2010-12-02 19:15:22 UTC	Major	Fan Tray Failure
2010-12-02 19:15:22 UTC	Major	Fan Tray Failure
2010-12-02 19:15:14 UTC	Minor	Check CB 0 Fabric Chip 1 on Plane/FPC/PFE: 1/5/0, 1/5/1, 1/5/2, 1/5/3, 1/7/0, 1/7/1, 1/7/2, 1/7/3, 2/5/0, 2/5/1, ...
2010-12-02 19:15:14 UTC	Minor	Check CB 0 Fabric Chip 0 on Plane/FPC/PFE: 1/5/0, 1/5/1, 1/5/2, 1/5/3, 1/7/0, 1/7/1, 1/7/2, 1/7/3, 2/5/0, 2/5/1, ...
2010-12-02 19:14:18 UTC	Major	PSU 1 Output Failure
2010-12-02 19:14:18 UTC	Minor	Loss of communication with Backup RE

show chassis cfeb

Syntax	show chassis cfeb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M7i and M10i routers only) Display status information about the Compact Forwarding Engine Board (CFEB).
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis cfeb on page 169
List of Sample Output	show chassis cfeb (M7i) on page 209 show chassis cfeb (M10i) on page 209
Output Fields	Table 46 on page 208 lists the output fields for the show chassis cfeb command. Output fields are listed in the approximate order in which they appear.

Table 46: show chassis cfeb Output Fields

Field Name	Field Description
State	Status of the CFEB: <ul style="list-style-type: none"> • Online—CFEB is online and running. • Offline—CFEB is powered down.
Intake Temperature	Temperature of the air before flowing past the CFEB.
Exhaust Temperature	Temperature of the air after flowing past the CFEB.
CPU utilization	Percentage of CPU being used by the CFEB processor.
Interrupt utilization	Of the total CPU being used by the CFEB processor, the percentage being used for interrupts
Heap Utilization	Percentage of heap space (dynamic memory) being used by the CFEB processor. If this number exceeds 80 percent, there may be a software problem (memory leak).
Buffer Utilization	Percentage of buffer space being used by the CFEB processor for buffering internal messages
Total CPU DRAM	Amount of DRAM available to the CFEB CPU.
Internet Processor II	Information about the CFEB processor.

Table 46: show chassis cfep Output Fields (*continued*)

Field Name	Field Description
Start time	Time when the Routing Engine detected that the CFEB was running.
Uptime	How long the Routing Engine has been connected to the CFEB and, therefore, how long the Flexible PIC Concentrator (FPC) has been up and running.

Sample Output

```

show chassis cfep user@host> show chassis cfep
(M7i) CFEB status:
      State Online
      Intake Temperature 27 degrees C / 80 degrees F
      Exhaust Temperature 33 degrees C / 91 degrees F
      CPU utilization 3 percent
      Interrupt utilization 0 percent
      Heap utilization 8 percent
      Buffer utilization 21 percent
      Total CPU DRAM 128 MB
      Internet Processor II Version 1, Foundry IBM, Part number 164
      Start time: 2003-06-11 11:41:22 PDT
      Uptime: 1 hour, 39 minutes, 31 seconds

show chassis cfep user@host> show chassis cfep
(M10i) CFEB status:
Slot 0 information:
  StateMaster
  Intake temperature 35 degrees C / 95 degrees F
  Exhaust temperature 43 degrees C / 109 degrees F
  CPU utilization 3 percent
  Interrupt utilization 0 percent
  Heap utilization 10 percent
  Buffer utilization 22 percent
  Total CPU DRAM 128 MB
  Internet Processor II Version 1, Foundry IBM, Part number 164
  Start time: 2004-11-01 03:24:15 PST
  Uptime: 12 hours, 56 minutes, 18 seconds
Slot 1 information:
  State Backup

```

show chassis cip

Syntax (TX Matrix Plus Router)	show chassis cip
Release Information	Command introduced in Junos OS Release 9.6.
Description	(TX Matrix Plus routers only) Display environmental information about the Connector Interface Panel (CIP) that provides Ethernet Control Plane connectivity to line-card chassis (LCCs), switch fabric chassis, and other devices.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis cip on page 170
Output Fields	Table 47 on page 210 lists the output fields for the show chassis cip command. Output fields are listed in the approximate order in which they appear.

Table 47: show chassis cip Output Fields

Field Name	Field Description
Eswitch	Ethernet switch used to connect to the LCC or to a JCS1200: 0 or 1 .
Port	Physical port number of the Ethernet switch: <ul style="list-style-type: none"> Port numbers: 4 to 8 on Ethernet switch 0 can be used to connect up to four (reserved for future use) other SFCs or optional JCS1200s. <p>NOTE: The current configuration of the routing matrix based on a TX Matrix Plus router supports only one SFC.</p> <ul style="list-style-type: none"> Port numbers 0 to 15 on Ethernet switch 1 can be used to connect up to 16 LCCs. <p>NOTE: The current configuration of a routing matrix based on a TX Matrix Plus router supports only up to four LCCs. You can connect the four LCCs to any of the ports (0 to 15) on the Ethernet switch 1.</p>
Type	Type of CIP: <ul style="list-style-type: none"> XE—Ethernet switch 0 ports used for connections to the SFC control plane or other devices such as JCS1200. GE—Ethernet switch 1 ports used for connections to the LCC control plane.
Connected-to	Show control plane connection to a specific LCC or SFC.
Link	State of the connection to an LCC control plane, SFC control plane, or other devices: Up or Down .
Speed	Ethernet link speed.
Duplex	Type of Ethernet link: Full or Half Duplex .

Table 47: show chassis cip Output Fields (*continued*)

Field Name	Field Description
Auto-neg	Status of autonegotiation for the CIP connection to the LCC, SFC, or other devices: On or Off .

show chassis cip (TX Matrix Plus Router)

```

user@host> show chassis cip
sfc0-cip0
Eswitch Port Type Connected-to Link Speed Duplex Auto-Neg
0 4 XE SFC1 Down 0 Full Off
0 5 XE SFC0 Down 0 Full Off
0 6 XE SFC3 Down 0 Full Off
0 7 XE SFC2 Down 0 Full Off
0 8 XE SFC4 Down 0 Full Off
1 0 GE LCC0 Up 1000Mbps Full On
1 1 GE LCC8 Down 0 Half On
1 2 GE LCC1 Up 1000Mbps Full On
1 3 GE LCC9 Down 0 Half On
1 4 GE LCC2 Up 1000Mbps Full On
1 5 GE LCC10 Down 0 Half On
1 6 GE LCC3 Up 1000Mbps Full On
1 7 GE LCC11 Down 0 Half On
1 8 GE LCC4 Down 0 Half On
1 9 GE LCC12 Down 0 Half On
1 10 GE LCC5 Down 0 Half On
1 11 GE LCC13 Down 0 Half On
1 12 GE LCC6 Down 0 Half On
1 13 GE LCC14 Down 0 Half On
1 14 GE LCC7 Down 0 Half On
1 15 GE LCC15 Down 0 Half On
1 16 GE GE17 Up 1000Mbps Full On
1 17 GE GE16 Down 0 Half On

```

show chassis craft-interface

Syntax	show chassis craft-interface
Syntax (TX Matrix Router)	show chassis craft-interface <fcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis craft-interface <fcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before JUNOS Release 7.4. sfc option for the TX Matrix Plus router introduced in JUNOS Release 9.6.
Description	For routers or switches that have a display on the craft interface, show the messages that are currently displayed. On all routers except for the M20 router, you must enter this command on the master Routing Engine.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, show messages that are currently displayed on the craft interface on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, show messages that are currently displayed on the craft interface on the TX Matrix Plus router and its attached T1600 routers.</p> <p>fcc <i>number</i>—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, show messages that are currently displayed on the craft interface for a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, show messages that are currently displayed on the craft interface for a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix router only) (Optional) Show messages that are currently displayed on the craft interface for the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus router only) (Optional) Show messages that are currently displayed on the craft interface for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear chassis display message on page 165 set chassis display message on page 201
List of Sample Output	<p>show chassis craft-interface (M20 Router) on page 213</p> <p>show chassis craft-interface (M40 Router) on page 214</p> <p>show chassis craft-interface (M120 Router) on page 214</p> <p>show chassis craft-interface (M160 Router) on page 215</p> <p>show chassis craft-interface (TX Matrix Routing Matrix) on page 215</p> <p>show chassis craft-interface (TX Matrix Plus Routing Matrix) on page 217</p>

Output Fields Table 48 on page 213 lists the output fields for the **show chassis craft-interface** command. Output fields are listed in the approximate order in which they appear.

Table 48: show chassis craft-interface Output Fields

Field Name	Field Description
LCD screen or FPM Display Contents	Contents of the Front Panel Module display: <ul style="list-style-type: none"> • router-name—Name of the router. • Up—How long the router has been operational, in days, hours, minutes, and seconds. • message—Information about the router traffic load, the power supply status, the fan status, and the temperature status. The display of this information changes every 2 seconds. If a text message has been created with the set chassis display command, this message appears on all four lines of the craft interface display. The display alternates between the text message and the standard system status messages every 2 seconds.
Front Panel System LEDs	Status of the Front Panel System LEDs. A dot (.) indicates the LED is not lit. An asterisk (*) indicates the LED is lit.
Front Panel Alarm Indicators	Status of the Front Panel Alarm indicators. A dot (.) indicates the relay is off. An asterisk (*) indicates the relay is active.
Front Panel FPC LEDs	Status of the Front Panel Flexible PIC Concentrator (FPC) LEDs. A dot (.) indicates the LED is not lit. An asterisk (*) indicates the LED is lit.
CB LEDs	Status of the Control Board (CB) LEDs. A dot (.) indicates the LED is not lit. An asterisk (*) indicates the LED is lit.
MCS and SFM LEDs	Status of the Miscellaneous Control Subsystem (MCS) and Switching and Forwarding Module (SFM) LEDs. A dot (.) indicates the LED is not lit. An asterisk (*) indicates the LED is lit. When neither a dot nor an asterisk is displayed, there is no board in that slot.
SIB LEDs	Status of the Switch Interface Board (SIB) LEDs. A dot (.) indicates the LED is not lit. An asterisk (*) indicates the LED is lit.
SCG LEDs	Status of the SONET Clock Generator (SCG) LEDs. A dot (.) indicates the LED is not lit. An asterisk (*) indicates the LED is lit.

Sample Output

```

show chassis user@host> show chassis craft-interface
craft-interface (M20 Red alarm:      LED off, relay off
Router)          Yellow alarm: LED on, relay on
                  Host OK LED:  On
                  Host fail LED: Off
                  FPCs      0  1  2  3
                  -----
                  Green   .  *  *.
                  Red     ....
                  LCD screen:
                        +-----+
                        |host      |
                        |1 Alarm active|
                        |Y: FERF   |
                        +-----+

```

```

|                                     |
+-----+
show chassis user@host> show chassis craft-interface
craft-interface (M40 Router) Front Panel LCD Display: enabled
Red alarm:      LED off, relay off
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host Fail LED:  Off
NICs    0  1  2  3  4  5  6  7
-----
Green   *.  *.  *.  *.
Red     .....
LCD Screen:
+-----+
| host                                     |
| Up: 27+18:52:37                       |
|                                         |
| 52.649kpps Load                       |
+-----+

```

```

show chassis user@host> show chassis craft-interface
craft-interface (M120 Router) Front Panel System LEDs:
Routing Engine  0  1
-----
OK              *   .
Fail            .   .
Master          *   .

Front Panel Alarm Indicators:
-----
Red LED        *
Yellow LED     .
Major relay    *
Minor relay    .

Front Panel FPC LEDs:
FPC    0  1  2  3  4  5
-----
Red     .  .  .  .  .  .
Green   .  *  .  *  *  *

CB LEDs:
CB      0  1
-----
Amber   .  .
Green   *  *

PS LEDs:
PS      0  1
-----
Red     .  .
Green   *  *

FEB LEDs:
FEB    0  1  2  3  4  5
-----
Red     .  .  .  .  .  .

```

```

Green . . . * * *
Active . . . * * *

show chassis user@host> show chassis craft-interface
craft-interface (M160 Router) FPM Display contents:
+-----+
|hosts      |
|Up: 1+16:46|
|           |
|Fans OK    |
+-----+

Front Panel System LEDs:
Host      0      1
-----
OK         .      *
Fail       .      .
Master     .      *

Front Panel Alarm Indicators:
-----
Red LED    .
Yellow LED .
Major relay.
Minor relay.

Front Panel FPC LEDs:
FPC      0      1      2      3      4      5      6      7
-----
Red       .      .      .      .      .      .      .      .
Green     *      *      .      .      .      .      .      .

MCS and SFM LEDs:
MCS      0      1      SFM      0      1      2      3
-----
Amber     .              .      .
Green     .              .      .
Blue      .      *      .      *      *

```

```

show chassis user@host> show chassis craft-interface
craft-interface (TX scc-re0:
Matrix Routing Matrix)
-----
FPM Display contents:
+-----+
|bradley    |
|8 Alarms active|
|R: SIB 2 Absent|
|R: SIB 1 Absent|
+-----+

```

```

Front Panel System LEDs:
Routing Engine  0      1
-----
OK              *      .
Fail            .      .
Master          *      .

Front Panel Alarm Indicators:
-----
Red LED         *
Yellow LED      *

```

```

Major relay *
Minor relay *

CB LEDs:
  CB  0  1
-----
Amber. .
Green * .
Blue  * .

SIB LEDs:
  SIB 0  1  2  3  4
-----
Fail . . . . .
OK   . . . . *
Active . . . . *

lcc0-re0:
-----
FPM Display contents:
  +-----+
  | hybrid          |
  | 5 Alarms active |
  | R: SIB 2 Absent |
  | R: SIB 1 Absent |
  +-----+

Front Panel System LEDs:
Routing Engine  0  1
-----
OK              * .
Fail            . .
Master          * .

Front Panel Alarm Indicators:
-----
Red LED        *
Yellow LED     *
Major relay    *
Minor relay    *

Front Panel FPC LEDs:
FPC  0  1  2  3  4  5  6  7
-----
Red   . . . . .
Green * * . . . .

CB LEDs:
  CB  0  1
-----
Amber. .
Green * .
Blue  * .

SCG LEDs:
  SCG 0  1
-----
Amber. .
Green * .
Blue  * .

SIB LEDs:

```



```

SIB 0 1 2 3 4
-----
Red . . . . .
Green. . . . *

lcc2-re0:
-----
FPM Display contents:
+-----+
|prius          |
|5 Alarms active |
|R: SIB 2 Absent |
|R: SIB 1 Absent |
+-----+

Front Panel System LEDs:
Routing Engine 0 1
-----
OK              * .
Fail            . .
Master          * .

Front Panel Alarm Indicators:
-----
Red LED        *
Yellow LED     *
Major relay    *
Minor relay    *

Front Panel FPC LEDs:
FPC 0 1 2 3 4 5 6 7
-----
Red . . . . .
Green * * * . . . .

CB LEDs:
CB 0 1
-----
Amber. .
Green * .
Blue  * .

SCG LEDs:
SCG 0 1
-----
Amber. .
Green * .
Blue  * .

SIB LEDs:
SIB 0 1 2 3 4
-----
Red . . . . .
Green. . . . *

```

```

show chassis craft-interface (TX
Matrix Plus
Routing Matrix) user@host> show chassis craft-interface
sfc0-re0:
-----
FPM Display Contents:
+-----+
|finalfive      |

```

```

|22 Alarms active   |
|R: LCC 0 Major Error|
|R: SIB F2S 4/6 Absen|
+-----+

```

Front Panel System LEDs:
Routing Engine 0 1

```

-----
OK          *    *
Fail        .    .
Master      *    .

```

Front Panel Alarm Indicators:

```

-----
Red LED     *
Yellow LED  *
Major relay  *
Minor relay  *

```

Front Panel F13 SIB LEDs:

```

SIB  0  1  2  3  4  5  6  7  8  9 10 11 12 13 14 15
-----
Fail  .  .  .  .  .  .  .  .  .  .  .  .  .  .  .
OK    *  *  .  .  .  .  .  .  .  .  .  .  .  .  .
Active *  *  .  .  .  .  .  .  .  .  .  .  .  .  .

```

PS LEDs:

```

PS  0  1
-----

```

```

Red    .  .
Green  *  .

```

Fan Tray LEDs:

```

FT  0  1  2  3  4  5
-----

```

```

Red    .  .  .  .  .  .
Green  *  *  *  *  *  *

```

CB LEDs:

```

CB  0  1
-----

```

```

Amber  .  .
Green  *  *
Blue   *  .

```

FPM Display contents:

```

+-----+
|tigh   |
|5 Alarms active   |
|R: SIB-L - Fan Rev M|
|Y: Check SIB 0   |
+-----+

```

Front Panel System LEDs:
Routing Engine 0 1

```

-----
OK          *    *
Fail        .    .
Master      *    .

```

Front Panel Alarm Indicators:

```

-----

```

```

Red LED      *
Yellow LED   *
Major relay  *
Minor relay   *

```

Front Panel FPC LEDs:

FPC	0	1	2	3	4	5	6	7
Red
Green	*	*

CB LEDs:

CB	0	1
Amber	.	.
Green	*	*
Blue	*	.

SCG LEDs:

SCG	0	1
Amber	.	.
Green	*	*
Blue	*	.

SIB LEDs:

SIB	0	1	2	3	4
Red
Green	*

show chassis environment

Syntax	show chassis environment
Syntax (TX Matrix Router)	show chassis environment <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis environment <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis environment <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show chassis environment <fpc <i>fpc-slot</i> > <routing-engine>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display environmental information about the router or switch chassis, including the temperature and information about the fans, power supplies, and Routing Engine.
Options	<p>none—Display environmental information about the router or switch chassis. On a TX Matrix router, display environmental information about the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display environmental information about the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display chassis environmental information for all the members of the Virtual Chassis configuration.</p> <p>fpc <i>fpc-slot</i>—(QFX Series only) (Optional) On the QFX Series, display chassis environmental information for a specified Flexible Pic Concentrator. Replace <i>fpc-slot</i> with 0.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display chassis environmental information for a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display chassis environmental information for a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display chassis environmental information for the local Virtual Chassis member.</p>

member member-id—(MX Series routers only) (Optional) Display chassis environmental information for the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

routing-engine—(QFX Series only) (Optional) On the QFX Series, display chassis environmental information for the Routing Engine.

scc—(TX Matrix routers only) (Optional) Display chassis environmental information about the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Display chassis environmental information about the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Required Privilege Level

view

Related Documentation

- [show chassis environment cb on page 237](#)
- [show chassis environment cip on page 248](#)
- [show chassis environment fpc on page 250](#)
- [show chassis environment fpm on page 260](#)
- [show chassis environment mcs on page 264](#)
- [show chassis environment pcg on page 266](#)
- [show chassis environment pem on page 268](#)
- [show chassis environment routing-engine on page 274](#)

List of Sample Output

[show chassis environment \(J2300 Router\) on page 222](#)
[show chassis environment \(J4300 or J6300 Router\) on page 222](#)
[show chassis environment \(M5 Router\) on page 222](#)
[show chassis environment \(M7i Router\) on page 223](#)
[show chassis environment \(M10 Router\) on page 223](#)
[show chassis environment \(M10i Router\) on page 223](#)
[show chassis environment \(M20 Router\) on page 224](#)
[show chassis environment \(M40 Router\) on page 224](#)
[show chassis environment \(M40e Router\) on page 224](#)
[show chassis environment \(M120 Router\) on page 225](#)
[show chassis environment \(M160 Router\) on page 226](#)
[show chassis environment \(M320 Router\) on page 226](#)
[show chassis environment \(MX240 Router\) on page 227](#)
[show chassis environment \(MX480 Router\) on page 228](#)
[show chassis environment \(MX960 Router\) on page 229](#)
[show chassis environment \(T320 Router\) on page 230](#)
[show chassis environment \(T640 Router\) on page 230](#)
[show chassis environment \(TX Matrix Router\) on page 231](#)
[show chassis environment \(T1600 Router\) on page 233](#)
[show chassis environment \(TX Matrix Plus Router\) on page 234](#)

show chassis environment (EX4200 Standalone Switch) on page 236

show chassis environment (QFX Series) on page 236

Output Fields Table 49 on page 222 lists the output fields for the **show chassis environment** command. Output fields are listed in the approximate order in which they appear.

Table 49: show chassis environment Output Fields

Field Name	Field Description
Class	Item, Status, Measurement
Power	Power information: <ul style="list-style-type: none"> (M5, M10, M20, and M40 routers and EX Series switches only) Power supply status: OK, Testing, (during initial power-on), Failed, or Absent. (M7i, M10i, M40e, M120, M160, M320, T Series routers and EX Series switches only) Information about the Power Entry Modules status: OK, Testing, (during initial power-on), Check, Failed, or Absent.
Temp	Temperature of air flowing through the chassis in degrees Celsius (C) and Fahrenheit (F).
Fan	Fan status: OK , Testing (during initial power-on), Failed , or Absent . Measurement indicates if fans are spinning at normal or high speed.
Misc	Information about other components of the chassis: <ul style="list-style-type: none"> On some routers, this field indicates the status of one or more additional components. On the M160 router, Misc includes CIP (Connector Interface Panel). OK indicates the CIP is present. On the T640 router, Misc includes CIP and SPMB (Switch Processor Mezzanine Board). OK indicates the item is present.

Sample Output

```

show chassis environment (J2300 Router) user@host> show chassis environment
Class Item Status Measurement
Temp Routing Engine OK 40 degrees C / 104 degrees F
Fan Fan OK

show chassis environment (J4300 or J6300 Router) user@host> show chassis environment
Class Item Status Measurement
Temp Routing Engine OK 41 degrees C / 105 degrees F
Fan Fan 0 OK
Fan Fan 1 OK

show chassis environment (M5 Router) user@host> show chassis environment
Class Item Status Measurement
Power Power Supply A OK
Power Power Supply B Absent
Temp FPC 0 OK 30 degrees C / 86 degrees F
FEB OK 33 degrees C / 91 degrees F
PS Intake OK 27 degrees C / 80 degrees F
PS Exhaust OK 27 degrees C / 80 degrees F
Routing Engine OK 34 degrees C / 93 degrees F
Fans Left Fan 1 OK Spinning at normal speed
Left Fan 2 OK Spinning at normal speed
Left Fan 3 OK Spinning at normal speed

```

```

Left Fan 4          OK      Spinning at normal speed
Misc Craft Interface OK

```

```

show chassis user@host> show chassis environment
environment (M7i) Class Item          Status      Measurement
Router)          Power Power Supply 0    OK
                  Power Power Supply 1    Absent
                  Temp  Intake          OK          22 degrees C / 71 degrees F
                  FPC 0          OK          23 degrees C / 73 degrees F
                  Power Supplies OK          23 degrees C / 73 degrees F
                  CFEB Intake    OK          24 degrees C / 75 degrees F
                  CFEB Exhaust   OK          29 degrees C / 84 degrees F
                  Routing Engine OK          26 degrees C / 78 degrees F
                  Fans  Fan 1      OK          Spinning at normal speed
                  Fan 2      OK          Spinning at normal speed
                  Fan 3      OK          Spinning at normal speed
                  Fan 4      OK          Spinning at normal speed

```

```

show chassis user@host> show chassis environment
environment (M10) Class Item          Status      Measurement
Router)          Power Power Supply A    OK
                  Power Power Supply B    Failed
                  Temp  FPC 0          OK          36 degrees C / 96 degrees F
                  FPC 1          OK          35 degrees C / 95 degrees F
                  FEB           OK          34 degrees C / 93 degrees F
                  PS Intake      OK          31 degrees C / 87 degrees F
                  PS Exhaust     OK          34 degrees C / 93 degrees F
                  Routing Engine OK          35 degrees C / 95 degrees F
                  Fans  Left Fan 1    OK          Spinning at normal speed
                  Left Fan 2    OK          Spinning at normal speed
                  Left Fan 3    OK          Spinning at normal speed
                  Left Fan 4    OK          Spinning at normal speed
                  Misc  Craft Interface OK

```

```

show chassis user@host> show chassis environment
environment (M10i) Class Item          Status      Measurement
Router)          Power Power Supply 0    OK
                  Power Power Supply 1    OK
                  Power Power Supply 2    Absent
                  Power Power Supply 3    Absent
                  Temp  Intake          OK          26 degrees C / 78 degrees F
                  FPC 0          OK          27 degrees C / 80 degrees F
                  FPC 1          OK          28 degrees C / 82 degrees F
                  Lower Power Supplies OK          29 degrees C / 84 degrees F
                  Upper Power Supplies OK          28 degrees C / 82 degrees F
                  CFEB Intake    OK          27 degrees C / 80 degrees F
                  CFEB Exhaust   OK          36 degrees C / 96 degrees F
                  Routing Engine 0 OK          31 degrees C / 87 degrees F
                  Routing Engine 1 OK          27 degrees C / 80 degrees F
                  Fans  Fan Tray 0 Fan 1 OK          Spinning at normal speed
                  Fan Tray 0 Fan 2 OK          Spinning at normal speed
                  Fan Tray 0 Fan 3 OK          Spinning at normal speed
                  Fan Tray 0 Fan 4 OK          Spinning at normal speed
                  Fan Tray 0 Fan 5 OK          Spinning at normal speed
                  Fan Tray 0 Fan 6 OK          Spinning at normal speed
                  Fan Tray 0 Fan 7 OK          Spinning at normal speed
                  Fan Tray 0 Fan 8 OK          Spinning at normal speed

```

```

Fan Tray 1 Fan 1      Absent
Fan Tray 1 Fan 2      Absent
Fan Tray 1 Fan 3      Absent
Fan Tray 1 Fan 4      Absent
Fan Tray 1 Fan 5      Absent
Fan Tray 1 Fan 6      Absent
Fan Tray 1 Fan 7      Absent
Fan Tray 1 Fan 8      Absent

```

```

show chassis environment (M20 Router) user@host> show chassis environment
Class Item              Status      Measurement
Power Power Supply A     OK
Power Power Supply B     Absent
Temp  FPC 0              OK          28 degrees C / 82 degrees F
      FPC 1              OK          27 degrees C / 80 degrees F
      Power Supply A     OK          22 degrees C / 71 degrees F
      Power Supply B     Absent
      SSB 0              OK          30 degrees C / 86 degrees F
      Backplane          OK          22 degrees C / 71 degrees F
      Routing Engine 0   OK          26 degrees C / 78 degrees F
      Routing Engine 1   Testing
Fans  Rear Fan           OK          Spinning at normal speed
      Front Upper Fan    OK          Spinning at normal speed
      Front Middle Fan   OK          Spinning at normal speed
      Front Bottom Fan   OK          Spinning at normal speed
Misc  Craft Interface     OK

```

```

show chassis environment (M40 Router) user@host> show chassis environment
Class Item              Status      Measurement
Power Power Supply A     OK
Power Power Supply B     Absent
Temp  FPC 3              OK          24 degrees C / 75 degrees F
      FPC 6              OK          26 degrees C / 78 degrees F
      SCB                OK          26 degrees C / 78 degrees F
      Backplane @ A1     OK          28 degrees C / 82 degrees F
      Backplane @ A2     OK          23 degrees C / 73 degrees F
      Routing Engine     OK          26 degrees C / 78 degrees F
Fans  Top Impeller       OK          Spinning at normal speed
      Bottom impeller    OK          Spinning at normal speed
      Rear Left Fan      OK          Spinning at normal speed
      Rear Center Fan    OK          Spinning at normal speed
      Rear Right Fan     OK          Spinning at normal speed
Misc  Craft Interface     OK

```

```

show chassis environment (M40e Router) user@host> show chassis environment
Class Item              Status      Measurement
Power PEM 0              OK
Power PEM 1              Absent
Temp  PCG 0              OK          44 degrees C / 111 degrees F
      PCG 1              OK          47 degrees C / 116 degrees F
      Routing Engine 0   OK          40 degrees C / 104 degrees F
      Routing Engine 1   OK          37 degrees C / 98 degrees F
      MCS 0              OK          45 degrees C / 113 degrees F
      MCS 1              OK          42 degrees C / 107 degrees F
      SFM 0 SPP          OK          40 degrees C / 104 degrees F
      SFM 0 SPR          OK          44 degrees C / 111 degrees F
      SFM 1 SPP          OK          43 degrees C / 109 degrees F

```


SFM 1 SPR	OK	45 degrees C / 113 degrees F
FPC 0	OK	38 degrees C / 100 degrees F
FPC 1	OK	40 degrees C / 104 degrees F
FPC 2	OK	38 degrees C / 100 degrees F
FPC 4	OK	34 degrees C / 93 degrees F
FPC 5	OK	43 degrees C / 109 degrees F
FPC 6	OK	41 degrees C / 105 degrees F
FPC 7	OK	43 degrees C / 109 degrees F
FPM CMB	OK	28 degrees C / 82 degrees F
FPM Display	OK	28 degrees C / 82 degrees F
Fans Rear Bottom Blower	OK	Spinning at normal speed
Rear Top Blower	OK	Spinning at normal speed
Front Top Blower	OK	Spinning at normal speed
Fan Tray Rear Left	OK	Spinning at normal speed
Fan Tray Rear Right	OK	Spinning at normal speed
Fan Tray Front Left	OK	Spinning at normal speed
Fan Tray Front Right	OK	Spinning at normal speed
Misc CIP	OK	

show chassis environment (M120 Router)

```
user@host> show chassis environment
```

Class	Item	Status	Measurement
Temp	PEM 0	OK	
	PEM 1	OK	
	Routing Engine 0	OK	43 degrees C / 109 degrees F
	Routing Engine 1	OK	44 degrees C / 111 degrees F
	CB 0 Intake	OK	33 degrees C / 91 degrees F
	CB 0 Exhaust A	OK	36 degrees C / 96 degrees F
	CB 0 Exhaust B	OK	35 degrees C / 95 degrees F
	CB 1 Intake	OK	34 degrees C / 93 degrees F
	CB 1 Exhaust A	OK	38 degrees C / 100 degrees F
	CB 1 Exhaust B	OK	35 degrees C / 95 degrees F
	FEB 3 Intake	OK	35 degrees C / 95 degrees F
	FEB 3 Exhaust A	OK	37 degrees C / 98 degrees F
	FEB 3 Exhaust B	OK	39 degrees C / 102 degrees F
	FEB 4 Intake	OK	33 degrees C / 91 degrees F
	FEB 4 Exhaust A	OK	39 degrees C / 102 degrees F
	FEB 4 Exhaust B	OK	36 degrees C / 96 degrees F
	FPC 2 Exhaust A	OK	32 degrees C / 89 degrees F
	FPC 2 Exhaust B	OK	31 degrees C / 87 degrees F
	FPC 3 Exhaust A	OK	32 degrees C / 89 degrees F
	FPC 3 Exhaust B	OK	33 degrees C / 91 degrees F
	FPC 4 Exhaust A	OK	32 degrees C / 89 degrees F
	FPC 4 Exhaust B	OK	30 degrees C / 86 degrees F
Fans	Front Top Tray Fan 1	OK	Spinning at normal speed
	Front Top Tray Fan 2	OK	Spinning at normal speed
	Front Top Tray Fan 3	OK	Spinning at normal speed
	Front Top Tray Fan 4	OK	Spinning at normal speed
	Front Top Tray Fan 5	OK	Spinning at normal speed
	Front Top Tray Fan 6	OK	Spinning at normal speed
	Front Top Tray Fan 7	OK	Spinning at normal speed
	Front Top Tray Fan 8	OK	Spinning at normal speed
	Front Bottom Tray Fan 1	OK	Spinning at normal speed
	Front Bottom Tray Fan 2	OK	Spinning at normal speed
	Front Bottom Tray Fan 3	OK	Spinning at normal speed
	Front Bottom Tray Fan 4	OK	Spinning at normal speed
	Front Bottom Tray Fan 5	OK	Spinning at normal speed
	Front Bottom Tray Fan 6	OK	Spinning at normal speed
	Front Bottom Tray Fan 7	OK	Spinning at normal speed
	Front Bottom Tray Fan 8	OK	Spinning at normal speed
	Rear Top Tray Fan 1	OK	Spinning at normal speed

Rear Top Tray Fan 2	OK	Spinning at normal speed
Rear Top Tray Fan 3	OK	Spinning at normal speed
Rear Top Tray Fan 4	OK	Spinning at normal speed
Rear Top Tray Fan 5	OK	Spinning at normal speed
Rear Top Tray Fan 6	OK	Spinning at normal speed
Rear Top Tray Fan 7	OK	Spinning at normal speed
Rear Top Tray Fan 8	OK	Spinning at normal speed
Rear Bottom Tray Fan 1	OK	Spinning at normal speed
Rear Bottom Tray Fan 2	OK	Spinning at normal speed
Rear Bottom Tray Fan 3	OK	Spinning at normal speed
Rear Bottom Tray Fan 4	OK	Spinning at normal speed
Rear Bottom Tray Fan 5	OK	Spinning at normal speed
Rear Bottom Tray Fan 6	OK	Spinning at normal speed
Rear Bottom Tray Fan 7	OK	Spinning at normal speed
Rear Bottom Tray Fan 8	OK	Spinning at normal speed

```

show chassis environment (M160 Router) user@host> show chassis environment
Class Item Status Measurement
Power PEM 0 OK PEM 1 Absent
Temp PCG 0 OK 45 degrees C / 113 degrees F
PCG 1 Absent
Routing Engine 0 OK 35 degrees C / 95 degrees F
Routing Engine 1 Absent
MCS 0 OK 50 degrees C / 122 degrees F
SFM 0 SPP OK 47 degrees C / 116 degrees F
SFM 0 SPR OK 49 degrees C / 120 degrees F
SFM 1 SPP OK 50 degrees C / 122 degrees F
SFM 1 SPR OK 50 degrees C / 122 degrees F
SFM 2 SPP OK 51 degrees C / 123 degrees F
SFM 2 SPR OK 52 degrees C / 125 degrees F
SFM 3 SPP OK 52 degrees C / 125 degrees F
SFM 3 SPR OK 48 degrees C / 118 degrees F
FPC 0 OK 45 degrees C / 113 degrees F
FPC 6 OK 43 degrees C / 109 degrees F
FPM CMB OK 31 degrees C / 87 degrees F
FPM Display OK 33 degrees C / 91 degrees F
Fans Rear Bottom Blower OK Spinning at normal speed
Rear Top Blower OK Spinning at normal speed
Front Top Blower OK Spinning at normal speed
Fan Tray Rear Left OK Spinning at normal speed
Fan Tray Rear Right OK Spinning at normal speed
Fan Tray Front Left OK Spinning at normal speed
Fan Tray Front Right OK Spinning at normal speed
Misc CIP OK

```

```

show chassis environment (M320 Router) user@host> show chassis environment
Class Item Status Measurement
Temp PEM 0 Absent
PEM 1 Absent
PEM 2 OK
PEM 3 OK
Routing Engine 0 OK 33 degrees C / 91 degrees F
Routing Engine 1 OK 32 degrees C / 89 degrees F
CB 0 OK 36 degrees C / 96 degrees F
CB 1 OK 36 degrees C / 96 degrees F
SIB 0 OK 38 degrees C / 100 degrees F
SIB 1 OK 29 degrees C / 84 degrees F
SIB 2 OK 38 degrees C / 100 degrees F
SIB 3 OK 41 degrees C / 105 degrees F
FPC 0 Intake OK 28 degrees C / 82 degrees F

```

	FPC 0 Exhaust	OK	40 degrees C / 104 degrees F
	FPC 1 Intake	OK	29 degrees C / 84 degrees F
	FPC 1 Exhaust	OK	39 degrees C / 102 degrees F
	FPC 2 Intake	OK	28 degrees C / 82 degrees F
	FPC 2 Exhaust	OK	38 degrees C / 100 degrees F
	FPC 3 Intake	OK	28 degrees C / 82 degrees F
	FPC 3 Exhaust	OK	39 degrees C / 102 degrees F
	FPC 6 Intake	OK	27 degrees C / 80 degrees F
	FPC 6 Exhaust	OK	39 degrees C / 102 degrees F
	FPC 7 Intake	OK	27 degrees C / 80 degrees F
	FPC 7 Exhaust	OK	42 degrees C / 107 degrees F
	FPM GBUS	OK	30 degrees C / 86 degrees F
Fan	Top Left Front fan	OK	Spinning at normal speed
	Top Right Rear fan	OK	Spinning at normal speed
	Top Right Front fan	OK	Spinning at normal speed
	Top Left Rear fan	OK	Spinning at normal speed
	Bottom Left Front fan	OK	Spinning at normal speed
	Bottom Right Rear fan	OK	Spinning at normal speed
	Bottom Right Front fan	OK	Spinning at normal speed
	Bottom Left Rear fan	OK	Spinning at normal speed
	Rear Fan 1 (TOP)	OK	Spinning at normal speed
	Rear Fan 2	OK	Spinning at normal speed
	Rear Fan 3	OK	Spinning at normal speed
	Rear Fan 4	OK	Spinning at normal speed
	Rear Fan 5	OK	Spinning at normal speed
	Rear Fan 6	OK	Spinning at normal speed
	Rear Fan 7 (Bottom)	OK	Spinning at normal speed
Misc	CIP	OK	

```

show chassis environment (MX240 Router)
user@host> show chassis environment

```

Class	Item	Status	Measurement
Temp	PEM 0	OK	40 degrees C / 104 degrees F
	PEM 1	OK	45 degrees C / 113 degrees F
	PEM 2	Absent	
	PEM 3	Absent	
	Routing Engine 0	OK	39 degrees C / 102 degrees F
	Routing Engine 1	OK	37 degrees C / 98 degrees F
	CB 0 Intake	OK	36 degrees C / 96 degrees F
	CB 0 Exhaust A	OK	34 degrees C / 93 degrees F
	CB 0 Exhaust B	OK	38 degrees C / 100 degrees F
	CB 0 ACBC	OK	37 degrees C / 98 degrees F
	CB 0 SF A	OK	49 degrees C / 120 degrees F
	CB 0 SF B	OK	41 degrees C / 105 degrees F
	CB 1 Intake	OK	37 degrees C / 98 degrees F
	CB 1 Exhaust A	OK	34 degrees C / 93 degrees F
	CB 1 Exhaust B	OK	39 degrees C / 102 degrees F
	CB 1 ACBC	OK	38 degrees C / 100 degrees F
	CB 1 SF A	OK	47 degrees C / 116 degrees F
	CB 1 SF B	OK	41 degrees C / 105 degrees F
	FPC 1 Intake	OK	33 degrees C / 91 degrees F
	FPC 1 Exhaust A	OK	38 degrees C / 100 degrees F
	FPC 1 Exhaust B	OK	53 degrees C / 127 degrees F
	FPC 1 I3 0 TSensor	OK	50 degrees C / 122 degrees F
	FPC 1 I3 0 Chip	OK	53 degrees C / 127 degrees F
	FPC 1 I3 1 TSensor	OK	49 degrees C / 120 degrees F
	FPC 1 I3 1 Chip	OK	52 degrees C / 125 degrees F
	FPC 1 I3 2 TSensor	OK	47 degrees C / 116 degrees F
	FPC 1 I3 2 Chip	OK	49 degrees C / 120 degrees F
	FPC 1 I3 3 TSensor	OK	44 degrees C / 111 degrees F
	FPC 1 I3 3 Chip	OK	46 degrees C / 114 degrees F

FPC 1 IA 0 TSensor	OK	45 degrees C / 113 degrees F
FPC 1 IA 0 Chip	OK	44 degrees C / 111 degrees F
FPC 1 IA 1 TSensor	OK	44 degrees C / 111 degrees F
FPC 1 IA 1 Chip	OK	48 degrees C / 118 degrees F
FPC 2 Intake	OK	32 degrees C / 89 degrees F
FPC 2 Exhaust A	OK	40 degrees C / 104 degrees F
FPC 2 Exhaust B	OK	52 degrees C / 125 degrees F
FPC 2 I3 0 TSensor	OK	52 degrees C / 125 degrees F
FPC 2 I3 0 Chip	OK	56 degrees C / 132 degrees F
FPC 2 I3 1 TSensor	OK	52 degrees C / 125 degrees F
FPC 2 I3 1 Chip	OK	55 degrees C / 131 degrees F
FPC 2 I3 2 TSensor	OK	49 degrees C / 120 degrees F
FPC 2 I3 2 Chip	OK	52 degrees C / 125 degrees F
FPC 2 I3 3 TSensor	OK	44 degrees C / 111 degrees F
FPC 2 I3 3 Chip	OK	48 degrees C / 118 degrees F
FPC 2 IA 0 TSensor	OK	50 degrees C / 122 degrees F
FPC 2 IA 0 Chip	OK	48 degrees C / 118 degrees F
FPC 2 IA 1 TSensor	OK	47 degrees C / 116 degrees F
FPC 2 IA 1 Chip	OK	53 degrees C / 127 degrees F
Fans Front Fan	OK	Spinning at normal speed
Middle Fan	OK	Spinning at normal speed
Rear Fan	OK	Spinning at normal speed

```

show chassis environment (MX480 Router)
user@host> show chassis environment

```

Class	Item	Status	Measurement
Temp	PEM 0	OK	35 degrees C / 95 degrees F
	PEM 1	OK	40 degrees C / 104 degrees F
	PEM 2	Absent	
	PEM 3	Absent	
	Routing Engine 0	OK	44 degrees C / 111 degrees F
	Routing Engine 1	OK	45 degrees C / 113 degrees F
	CB 0 Intake	OK	36 degrees C / 96 degrees F
	CB 0 Exhaust A	OK	38 degrees C / 100 degrees F
	CB 0 Exhaust B	OK	39 degrees C / 102 degrees F
	CB 0 ACBC	OK	37 degrees C / 98 degrees F
	CB 0 SF A	OK	51 degrees C / 123 degrees F
	CB 0 SF B	OK	44 degrees C / 111 degrees F
	CB 1 Intake	OK	36 degrees C / 96 degrees F
	CB 1 Exhaust A	OK	39 degrees C / 102 degrees F
	CB 1 Exhaust B	OK	40 degrees C / 104 degrees F
	CB 1 ACBC	OK	37 degrees C / 98 degrees F
	CB 1 SF A	OK	50 degrees C / 122 degrees F
	CB 1 SF B	OK	43 degrees C / 109 degrees F
	FPC 0 Intake	OK	36 degrees C / 96 degrees F
	FPC 0 Exhaust A	OK	39 degrees C / 102 degrees F
	FPC 0 Exhaust B	OK	51 degrees C / 123 degrees F
	FPC 0 I3 0 TSensor	OK	49 degrees C / 120 degrees F
	FPC 0 I3 0 Chip	OK	56 degrees C / 132 degrees F
	FPC 0 I3 1 TSensor	OK	47 degrees C / 116 degrees F
	FPC 0 I3 1 Chip	OK	52 degrees C / 125 degrees F
	FPC 0 I3 2 TSensor	OK	46 degrees C / 114 degrees F
	FPC 0 I3 2 Chip	OK	48 degrees C / 118 degrees F
	FPC 0 I3 3 TSensor	OK	42 degrees C / 107 degrees F
	FPC 0 I3 3 Chip	OK	45 degrees C / 113 degrees F
	FPC 0 IA 0 TSensor	OK	45 degrees C / 113 degrees F
	FPC 0 IA 0 Chip	OK	45 degrees C / 113 degrees F
	FPC 0 IA 1 TSensor	OK	44 degrees C / 111 degrees F
	FPC 0 IA 1 Chip	OK	48 degrees C / 118 degrees F
	FPC 1 Intake	OK	37 degrees C / 98 degrees F
	FPC 1 Exhaust A	OK	41 degrees C / 105 degrees F
	FPC 1 Exhaust B	OK	52 degrees C / 125 degrees F

FPC 1 I3 0 TSensor	OK	51 degrees C / 123 degrees F
FPC 1 I3 0 Chip	OK	57 degrees C / 134 degrees F
FPC 1 I3 1 TSensor	OK	48 degrees C / 118 degrees F
FPC 1 I3 1 Chip	OK	52 degrees C / 125 degrees F
FPC 1 I3 2 TSensor	OK	46 degrees C / 114 degrees F
FPC 1 I3 2 Chip	OK	50 degrees C / 122 degrees F
FPC 1 I3 3 TSensor	OK	42 degrees C / 107 degrees F
FPC 1 I3 3 Chip	OK	46 degrees C / 114 degrees F
FPC 1 IA 0 TSensor	OK	49 degrees C / 120 degrees F
FPC 1 IA 0 Chip	OK	48 degrees C / 118 degrees F
FPC 1 IA 1 TSensor	OK	46 degrees C / 114 degrees F
FPC 1 IA 1 Chip	OK	50 degrees C / 122 degrees F
Fans Top Rear Fan	OK	Spinning at normal speed
Bottom Rear Fan	OK	Spinning at normal speed
Top Middle Fan	OK	Spinning at normal speed
Bottom Middle Fan	OK	Spinning at normal speed
Top Front Fan	OK	Spinning at normal speed
Bottom Front Fan	OK	Spinning at normal speed

```

show chassis environment (MX960 Router)
user@host> show chassis environment

```

Class	Item	Status	Measurement
Temp	PEM 0	Absent	
	PEM 1	Absent	
	PEM 2	Check	
	PEM 3	OK	35 degrees C / 95 degrees F
	Routing Engine 0	OK	37 degrees C / 98 degrees F
	Routing Engine 1	Absent	
	CB 0 Intake	OK	24 degrees C / 75 degrees F
	CB 0 Exhaust A	OK	30 degrees C / 86 degrees F
	CB 0 Exhaust B	OK	27 degrees C / 80 degrees F
	CB 1 Intake	Absent	
	CB 1 Exhaust A	Absent	
	CB 1 Exhaust B	Absent	
	CB 1 ACBC	Absent	
	CB 1 SF A	Absent	
	CB 1 SF B	Absent	
	CB 2 Intake	Absent	
	CB 2 Exhaust A	Absent	
	CB 2 Exhaust B	Absent	
	CB 2 ACBC	Absent	
	CB 2 SF A	Absent	
	CB 2 SF B	Absent	
	FPC 4 Intake	OK	24 degrees C / 75 degrees F
	FPC 4 Exhaust A	OK	36 degrees C / 96 degrees F
	FPC 4 Exhaust B	OK	38 degrees C / 100 degrees F
	FPC 7 Intake	OK	24 degrees C / 75 degrees F
	FPC 7 Exhaust A	OK	36 degrees C / 96 degrees F
	FPC 7 Exhaust B	OK	42 degrees C / 107 degrees F
Fans	Top Fan Tray Temp	Failed	
	Top Tray Fan 1	OK	Spinning at normal speed
	Top Tray Fan 2	OK	Spinning at normal speed
	Top Tray Fan 3	OK	Spinning at normal speed
	Top Tray Fan 4	OK	Spinning at normal speed
	Top Tray Fan 5	OK	Spinning at normal speed
	Top Tray Fan 6	OK	Spinning at normal speed
	Bottom Fan Tray Temp	Failed	
	Bottom Tray Fan 1	OK	Spinning at normal speed
	Bottom Tray Fan 2	OK	Spinning at normal speed
	Bottom Tray Fan 3	OK	Spinning at normal speed
	Bottom Tray Fan 4	OK	Spinning at normal speed

```

Bottom Tray Fan 5      OK      Spinning at normal speed
Bottom Tray Fan 6      OK      Spinning at normal speed

```

```

show chassis environment (T320 Router) user@host> show chassis environment
Class Item              Status      Measurement
Power PEM 0             OK
      PEM 1             Absent
Temp  SCG 0             OK          28 degrees C / 82 degrees F
      SCG 1             OK          28 degrees C / 82 degrees F
      Routing Engine 0   OK          31 degrees C / 87 degrees F
      Routing Engine 1   OK          30 degrees C / 86 degrees F
      CB 0               OK          32 degrees C / 89 degrees F
      CB 1               OK          32 degrees C / 89 degrees F
      SIB 0              OK          33 degrees C / 91 degrees F
      SIB 1              OK          33 degrees C / 91 degrees F
      SIB 2              OK          34 degrees C / 93 degrees F
      FPC 0 Top           OK          38 degrees C / 100 degrees F
      FPC 0 Bottom        OK          32 degrees C / 89 degrees F
      FPC 1 Top           OK          38 degrees C / 100 degrees F
      FPC 1 Bottom        OK          33 degrees C / 91 degrees F
      FPC 2 Top           OK          36 degrees C / 96 degrees F
      FPC 2 Bottom        OK          31 degrees C / 87 degrees F
      FPM GBUS            OK          26 degrees C / 78 degrees F
      FPM Display         OK          29 degrees C / 84 degrees F
Fans  Top Left Front fan  OK          Spinning at normal speed
      Top Left Middle fan OK          Spinning at normal speed
      Top Left Rear fan   OK          Spinning at normal speed
      Top Right Front fan  OK          Spinning at normal speed
      Top Right Middle fan OK          Spinning at normal speed
      Top Right Rear fan   OK          Spinning at normal speed
      Bottom Left Front fan OK          Spinning at normal speed
      Bottom Left Middle fan OK          Spinning at normal speed
      Bottom Left Rear fan OK          Spinning at normal speed
      Bottom Right Front fan OK          Spinning at normal speed
      Bottom Right Middle fan OK          Spinning at normal speed
      Bottom Right Rear fan OK          Spinning at normal speed
      Rear Tray Top fan    OK          Spinning at normal speed
      Rear Tray Second fan OK          Spinning at normal speed
      Rear Tray Middle fan OK          Spinning at normal speed
      Rear Tray Fourth fan OK          Spinning at normal speed
      Rear Tray Bottom fan OK          Spinning at normal speed
Misc  CIP                 OK
      SPMB 0             OK
      SPMB 1             OK

```

```

show chassis environment (T640 Router) user@host> show chassis environment
Class Item              Status      Measurement
Temp  PEM 0             Absent
      PEM 1             OK          22 degrees C / 71 degrees F
      SCG 0             OK          30 degrees C / 86 degrees F
      SCG 1             OK          30 degrees C / 86 degrees F
      Routing Engine 0   Present
      Routing Engine 1   OK          27 degrees C / 80 degrees F
      CB 0               Present
      CB 1               OK          33 degrees C / 91 degrees F
      SIB 0              Absent
      SIB 1              Absent
      SIB 2              Absent
      SIB 3              Absent
      SIB 4              Absent

```

	FPC 4 Top	Testing	
	FPC 4 Bottom	Testing	
	FPC 5 Top	Testing	
	FPC 5 Bottom	Testing	
	FPC 6 Top	Testing	
	FPC 6 Bottom	Testing	
	FPM GBUS	OK	23 degrees C / 73 degrees F
	FPM Display	Absent	
Fans	Top Left Front fan	OK	Spinning at normal speed
	Top Left Middle fan	OK	Spinning at normal speed
	Top Left Rear fan	OK	Spinning at normal speed
	Top Right Front fan	OK	Spinning at normal speed
	Top Right Middle fan	OK	Spinning at normal speed
	Top Right Rear fan	OK	Spinning at normal speed
	Bottom Left Front fan	OK	Spinning at normal speed
	Bottom Left Middle fan	OK	Spinning at normal speed
	Bottom Left Rear fan	OK	Spinning at normal speed
	Bottom Right Front fan	OK	Spinning at normal speed
	Bottom Right Middle fan	OK	Spinning at normal speed
	Bottom Right Rear fan	OK	Spinning at normal speed
	Fourth Blower from top	OK	Spinning at normal speed
	Bottom Blower	OK	Spinning at normal speed
	Middle Blower	OK	Spinning at normal speed
	Top Blower	OK	Spinning at normal speed
	Second Blower from top	OK	Spinning at normal speed
Misc	CIP	OK	
	SPMB 0	OK	
	SPMB 1	OK	

show chassis environment (TX Matrix Router)

```
user@host> show chassis environment
scc-re0:
```

Class	Item	Status	Measurement
Temp	PEM 0	Absent	
	PEM 1	OK	29 degrees C / 84 degrees F
	Routing Engine 0	OK	34 degrees C / 93 degrees F
	Routing Engine 1	OK	34 degrees C / 93 degrees F
	CB 0	OK	32 degrees C / 89 degrees F
	CB 1	OK	32 degrees C / 89 degrees F
	SIB 0	OK	44 degrees C / 111 degrees F
	SIB 0 (B)	OK	44 degrees C / 111 degrees F
	FPM GBUS	OK	27 degrees C / 80 degrees F
	FPM Display	OK	32 degrees C / 89 degrees F
Fans	Top Left Front fan	OK	Spinning at normal speed
	Top Left Middle fan	OK	Spinning at normal speed
	Top Left Rear fan	OK	Spinning at normal speed
	Top Right Front fan	OK	Spinning at normal speed
	Top Right Middle fan	OK	Spinning at normal speed
	Top Right Rear fan	OK	Spinning at normal speed
	Bottom Left Front fan	OK	Spinning at normal speed
	Bottom Left Middle fan	OK	Spinning at normal speed
	Bottom Left Rear fan	OK	Spinning at normal speed
	Bottom Right Front fan	OK	Spinning at normal speed
	Bottom Right Middle fan	OK	Spinning at normal speed
	Bottom Right Rear fan	OK	Spinning at normal speed
	Rear Tray Top fan	OK	Spinning at normal speed
	Rear Tray Second fan	OK	Spinning at normal speed
	Rear Tray Third fan	OK	Spinning at normal speed
	Rear Tray Fourth fan	OK	Spinning at normal speed
	Rear Tray Fifth fan	OK	Spinning at normal speed

```

Rear Tray Sixth fan    OK      Spinning at normal speed
Rear Tray Seventh fan  OK      Spinning at normal speed
Rear Tray Bottom fan   OK      Spinning at normal speed
Misc CIP 0              OK
CIP 1                  OK
SPMB 0                 OK
SPMB 1                  OK

```

lcc0-re0:

```

-----
Class Item              Status      Measurement
Temp PEM 0              OK        29 degrees C / 84 degrees F
      PEM 1              Absent
      SCG 0              OK        35 degrees C / 95 degrees F
      SCG 1              Absent
      Routing Engine 0    OK        39 degrees C / 102 degrees F
      Routing Engine 1    OK        36 degrees C / 96 degrees F
      CB 0                OK        32 degrees C / 89 degrees F
      CB 1                OK        32 degrees C / 89 degrees F
      SIB 0               OK        40 degrees C / 104 degrees F
      SIB 0 (B)           OK        51 degrees C / 123 degrees F
      FPC 0 Top            OK        45 degrees C / 113 degrees F
      FPC 0 Bottom        OK        31 degrees C / 87 degrees F
      FPC 1 Top            OK        34 degrees C / 93 degrees F
      FPC 1 Bottom        OK        31 degrees C / 87 degrees F
      FPM GBUS            OK        30 degrees C / 86 degrees F
      FPM Display         OK        34 degrees C / 93 degrees F
Fans  Top Left Front fan  OK        Spinning at normal speed
      Top Left Middle fan OK        Spinning at normal speed
      Top Left Rear fan   OK        Spinning at normal speed
      Top Right Front fan  OK        Spinning at normal speed
      Top Right Middle fan OK        Spinning at normal speed
      Top Right Rear fan   OK        Spinning at normal speed
      Bottom Left Front fan OK        Spinning at normal speed
      Bottom Left Middle fan OK       Spinning at normal speed
      Bottom Left Rear fan  OK        Spinning at normal speed
      Bottom Right Front fan OK       Spinning at normal speed
      Bottom Right Middle fan OK      Spinning at normal speed
      Bottom Right Rear fan  OK        Spinning at normal speed
      Rear Tray Top fan     OK        Spinning at normal speed
      Rear Tray Second fan  OK        Spinning at normal speed
      Rear Tray Third fan   OK        Spinning at normal speed
      Rear Tray Fourth fan  OK        Spinning at normal speed
      Rear Tray Fifth fan   OK        Spinning at normal speed
      Rear Tray Sixth fan   OK        Spinning at normal speed
      Rear Tray Seventh fan  OK        Spinning at normal speed
      Rear Tray Bottom fan  OK        Spinning at normal speed
Misc  CIP                 OK
      SPMB 0              OK
      SPMB 1              OK

```

lcc2-re0:

```

-----
Class Item              Status      Measurement
Temp PEM 0              OK        29 degrees C / 84 degrees F
      PEM 1              Absent
      SCG 0              OK        32 degrees C / 89 degrees F
      SCG 1              Absent
      Routing Engine 0    OK        31 degrees C / 87 degrees F
      Routing Engine 1    OK        32 degrees C / 89 degrees F
      CB 0                OK        30 degrees C / 86 degrees F

```



```

SIB 0                OK          38 degrees C / 100 degrees F
SIB 0 (B)            OK          49 degrees C / 120 degrees F
FPC 0 Top             OK          45 degrees C / 113 degrees F
FPC 0 Bottom          OK          33 degrees C / 91 degrees F
FPC 1 Top             OK          37 degrees C / 98 degrees F
FPC 1 Bottom          OK          33 degrees C / 91 degrees F
FPM GBUS              OK          30 degrees C / 86 degrees F
FPM Display           OK          34 degrees C / 93 degrees F
Fans Top Left Front fan OK        Spinning at normal speed
Top Left Middle fan   OK        Spinning at normal speed
...

```

```

show chassis environment (T1600 Router)
user@host> show chassis environment

Class Item          Status      Measurement
Temp PEM 0          OK          27 degrees C / 80 degrees F
      PEM 1          Absent
      SCG 0          OK          31 degrees C / 87 degrees F
      SCG 1          OK          35 degrees C / 95 degrees F
      Routing Engine 0 OK          30 degrees C / 86 degrees F
      Routing Engine 1 OK          30 degrees C / 86 degrees F
      CB 0           OK          31 degrees C / 87 degrees F
      CB 1           OK          31 degrees C / 87 degrees F
      SIB 0          OK          41 degrees C / 105 degrees F
      SIB 0 (B)      OK          34 degrees C / 93 degrees F
      SIB 1          OK          0 degrees C / 32 degrees F
      SIB 1 (B)      OK          0 degrees C / 32 degrees F
      SIB 2          OK          0 degrees C / 32 degrees F
      SIB 2 (B)      OK          0 degrees C / 32 degrees F
      SIB 3          OK          0 degrees C / 32 degrees F
      SIB 3 (B)      OK          0 degrees C / 32 degrees F
      SIB 4          OK          0 degrees C / 32 degrees F
      SIB 4 (B)      OK          0 degrees C / 32 degrees F
      FPC 0 Top       OK          49 degrees C / 120 degrees F
      FPC 0 Bottom    OK          50 degrees C / 122 degrees F
      FPC 1 Top       OK          48 degrees C / 118 degrees F
      FPC 1 Bottom    OK          49 degrees C / 120 degrees F
      FPM GBUS        OK          27 degrees C / 80 degrees F
      FPM Display     OK          30 degrees C / 86 degrees F
Fans  Top Left Front fan OK        Spinning at normal speed
      Top Left Middle fan OK        Spinning at normal speed
      Top Left Rear fan  OK        Spinning at normal speed
      Top Right Front fan OK        Spinning at normal speed
      Top Right Middle fan OK       Spinning at normal speed
      Top Right Rear fan  OK        Spinning at normal speed
      Bottom Left Front fan OK       Spinning at normal speed
      Bottom Left Middle fan OK      Spinning at normal speed
      Bottom Left Rear fan OK       Spinning at normal speed
      Bottom Right Front fan OK      Spinning at normal speed
      Bottom Right Middle fan OK     Spinning at normal speed
      Bottom Right Rear fan OK      Spinning at normal speed
      Rear Tray Top fan   OK        Spinning at normal speed
      Rear Tray Second fan OK       Spinning at normal speed
      Rear Tray Third fan  OK       Spinning at normal speed
      Rear Tray Fourth fan OK       Spinning at normal speed
      Rear Tray Fifth fan  OK       Spinning at normal speed
      Rear Tray Sixth fan  OK       Spinning at normal speed
      Rear Tray Seventh fan OK      Spinning at normal speed
      Rear Tray Bottom fan OK       Spinning at normal speed
Misc  CIP            OK
      SPMB 0          OK
      SPMB 1          OK

```

show chassis environment (TX Matrix Plus Router)

user@host> show chassis environment
sfc0-re0:

Class	Item	Status	Measurement
Temp	PEM 0	OK	28 degrees C / 82 degrees F
	PEM 1	Absent	
	Routing Engine 0	OK	27 degrees C / 80 degrees F
	Routing Engine 1	OK	29 degrees C / 84 degrees F
	CB 0 Intake	OK	26 degrees C / 78 degrees F
	CB 0 Exhaust A	OK	25 degrees C / 77 degrees F
	CB 0 Exhaust B	OK	25 degrees C / 77 degrees F
	CB 1 Intake	OK	26 degrees C / 78 degrees F
	CB 1 Exhaust A	OK	26 degrees C / 78 degrees F
	CB 1 Exhaust B	OK	26 degrees C / 78 degrees F
	SIB F13 0	OK	47 degrees C / 116 degrees F
	SIB F13 0 (B)	OK	48 degrees C / 118 degrees F
	SIB F13 1	OK	38 degrees C / 100 degrees F
	SIB F13 1 (B)	OK	37 degrees C / 98 degrees F
	SIB F2S 0/0	OK	27 degrees C / 80 degrees F
	SIB F2S 0/2	OK	28 degrees C / 82 degrees F
	SIB F2S 0/4	OK	27 degrees C / 80 degrees F
	SIB F2S 0/6	OK	28 degrees C / 82 degrees F
	SIB F2S 1/0	OK	26 degrees C / 78 degrees F
	SIB F2S 1/2	OK	26 degrees C / 78 degrees F
	SIB F2S 1/4	OK	26 degrees C / 78 degrees F
	SIB F2S 1/6	OK	26 degrees C / 78 degrees F
	SIB F2S 2/0	OK	25 degrees C / 77 degrees F
	SIB F2S 2/2	OK	25 degrees C / 77 degrees F
	SIB F2S 2/4	OK	23 degrees C / 73 degrees F
	CIP 0 Intake	OK	23 degrees C / 73 degrees F
	CIP 0 Exhaust A	OK	24 degrees C / 75 degrees F
	CIP 0 Exhaust B	OK	24 degrees C / 75 degrees F
	CIP 1 Intake	OK	24 degrees C / 75 degrees F
	CIP 1 Exhaust A	OK	25 degrees C / 77 degrees F
	CIP 1 Exhaust B	OK	25 degrees C / 77 degrees F
Fans	Fan Tray 0 Fan 1	OK	Spinning at normal speed
	Fan Tray 0 Fan 2	OK	Spinning at normal speed
	Fan Tray 0 Fan 3	OK	Spinning at normal speed
	Fan Tray 0 Fan 4	OK	Spinning at normal speed
	Fan Tray 0 Fan 5	OK	Spinning at normal speed
	Fan Tray 0 Fan 6	OK	Spinning at normal speed
	Fan Tray 1 Fan 1	OK	Spinning at normal speed
	Fan Tray 1 Fan 2	OK	Spinning at normal speed
	Fan Tray 1 Fan 3	OK	Spinning at normal speed
	Fan Tray 1 Fan 4	OK	Spinning at normal speed
	Fan Tray 1 Fan 5	OK	Spinning at normal speed
	Fan Tray 1 Fan 6	OK	Spinning at normal speed
	Fan Tray 2 Fan 1	OK	Spinning at normal speed
	Fan Tray 2 Fan 2	OK	Spinning at normal speed
	Fan Tray 2 Fan 3	OK	Spinning at normal speed
	Fan Tray 2 Fan 4	OK	Spinning at normal speed
	Fan Tray 2 Fan 5	OK	Spinning at normal speed
	Fan Tray 2 Fan 6	OK	Spinning at normal speed
	Fan Tray 2 Fan 7	OK	Spinning at normal speed
	Fan Tray 2 Fan 8	OK	Spinning at normal speed
	Fan Tray 2 Fan 9	OK	Spinning at normal speed
	Fan Tray 3 Fan 1	OK	Spinning at normal speed
	Fan Tray 3 Fan 2	OK	Spinning at normal speed
	Fan Tray 3 Fan 3	OK	Spinning at normal speed
	Fan Tray 3 Fan 4	OK	Spinning at normal speed
	Fan Tray 3 Fan 5	OK	Spinning at normal speed

Fan Tray 3 Fan 6	OK	Spinning at normal speed
Fan Tray 3 Fan 7	OK	Spinning at normal speed
Fan Tray 3 Fan 8	OK	Spinning at normal speed
Fan Tray 3 Fan 9	OK	Spinning at normal speed
Fan Tray 4 Fan 1	OK	Spinning at normal speed
Fan Tray 4 Fan 2	OK	Spinning at normal speed
Fan Tray 4 Fan 3	OK	Spinning at normal speed
Fan Tray 4 Fan 4	OK	Spinning at normal speed
Fan Tray 4 Fan 5	OK	Spinning at normal speed
Fan Tray 4 Fan 6	OK	Spinning at normal speed
Fan Tray 4 Fan 7	OK	Spinning at normal speed
Fan Tray 4 Fan 8	OK	Spinning at normal speed
Fan Tray 4 Fan 9	OK	Spinning at normal speed
Fan Tray 5 Fan 1	OK	Spinning at normal speed
Fan Tray 5 Fan 2	OK	Spinning at normal speed
Fan Tray 5 Fan 3	OK	Spinning at normal speed
Fan Tray 5 Fan 4	OK	Spinning at normal speed
Fan Tray 5 Fan 5	OK	Spinning at normal speed
Fan Tray 5 Fan 6	OK	Spinning at normal speed
Fan Tray 5 Fan 7	OK	Spinning at normal speed
Fan Tray 5 Fan 8	OK	Spinning at normal speed
Fan Tray 5 Fan 9	OK	Spinning at normal speed
Misc SPMB 0	OK	
SPMB 1	OK	

1cc0-re0:

Class	Item	Status	Measurement
Temp	PEM 0	OK	27 degrees C / 80 degrees F
	PEM 1	Absent	
	SCG 0	OK	31 degrees C / 87 degrees F
	SCG 1	OK	35 degrees C / 95 degrees F
	Routing Engine 0	OK	30 degrees C / 86 degrees F
	Routing Engine 1	OK	30 degrees C / 86 degrees F
	CB 0	OK	31 degrees C / 87 degrees F
	CB 1	OK	31 degrees C / 87 degrees F
	SIB 0	OK	41 degrees C / 105 degrees F
	SIB 0 (B)	OK	34 degrees C / 93 degrees F
	SIB 1	OK	0 degrees C / 32 degrees F
	SIB 1 (B)	OK	0 degrees C / 32 degrees F
	SIB 2	OK	0 degrees C / 32 degrees F
	SIB 2 (B)	OK	0 degrees C / 32 degrees F
	SIB 3	OK	0 degrees C / 32 degrees F
	SIB 3 (B)	OK	0 degrees C / 32 degrees F
	SIB 4	OK	0 degrees C / 32 degrees F
	SIB 4 (B)	OK	0 degrees C / 32 degrees F
	FPC 0 Top	OK	49 degrees C / 120 degrees F
	FPC 0 Bottom	OK	50 degrees C / 122 degrees F
	FPC 1 Top	OK	48 degrees C / 118 degrees F
	FPC 1 Bottom	OK	49 degrees C / 120 degrees F
	FPM GBUS	OK	27 degrees C / 80 degrees F
	FPM Display	OK	30 degrees C / 86 degrees F
Fans	Top Left Front fan	OK	Spinning at normal speed
	Top Left Middle fan	OK	Spinning at normal speed
	Top Left Rear fan	OK	Spinning at normal speed
	Top Right Front fan	OK	Spinning at normal speed
	Top Right Middle fan	OK	Spinning at normal speed
	Top Right Rear fan	OK	Spinning at normal speed
	Bottom Left Front fan	OK	Spinning at normal speed
	Bottom Left Middle fan	OK	Spinning at normal speed
	Bottom Left Rear fan	OK	Spinning at normal speed

```

Bottom Right Front fan      OK      Spinning at normal speed
Bottom Right Middle fan     OK      Spinning at normal speed
Bottom Right Rear fan       OK      Spinning at normal speed
Rear Tray Top fan           OK      Spinning at normal speed
Rear Tray Second fan        OK      Spinning at normal speed
Rear Tray Third fan         OK      Spinning at normal speed
Rear Tray Fourth fan        OK      Spinning at normal speed
Rear Tray Fifth fan         OK      Spinning at normal speed
Rear Tray Sixth fan         OK      Spinning at normal speed
Rear Tray Seventh fan       OK      Spinning at normal speed
Rear Tray Bottom fan        OK      Spinning at normal speed
Misc CIP                    OK
SPMB 0                      OK
SPMB 1                      OK

```

show chassis environment (EX4200 Standalone Switch)

```

user@host> show chassis environment
Class Item                               Status Measurement
Power FPC 0 Power Supply 0              OK
      FPC 0 Power Supply 1              Absent
Temp  FPC 0 CPU                          OK          41 degrees C / 105 degrees F
      FPC 0 EX-PFE1                     OK          42 degrees C / 107 degrees F
      FPC 0 EX-PFE2                     OK          46 degrees C / 114 degrees F
      FPC 0 GEPHY Front Left             OK          25 degrees C / 77 degrees F
      FPC 0 GEPHY Front Right            OK          27 degrees C / 80 degrees F
      FPC 0 Uplink Conn                  OK          29 degrees C / 84 degrees F
Fans  FPC 0 Fan 1                       OK          Spinning at normal speed
      FPC 0 Fan 2                       OK          Spinning at normal speed
      FPC 0 Fan 3                       OK          Spinning at normal speed

```

show chassis environment (QFX Series)

```

user@switch> show chassis environment
Class Item                               Status Measurement
Power FPC 0 Power Supply 0              OK
      FPC 0 Power Supply 1              OK
Temp  FPC 0 Sensor TopLeft I            OK          26 degrees C / 78 degrees F
      FPC 0 Sensor TopRight I           OK          24 degrees C / 75 degrees F
      FPC 0 Sensor TopLeft E            OK          30 degrees C / 86 degrees F
      FPC 0 Sensor TopRight E           OK          30 degrees C / 86 degrees F
      FPC 0 Sensor TopMiddle I          OK          30 degrees C / 86 degrees F
      FPC 0 Sensor TopMiddle E          OK          38 degrees C / 100 degrees F
      FPC 0 Sensor Bottom I             OK          34 degrees C / 93 degrees F
      FPC 0 Sensor Bottom E             OK          38 degrees C / 100 degrees F
      FPC 0 Sensor Die Temp             OK          38 degrees C / 100 degrees F
      FPC 0 Sensor Mgmt Brd I           OK          24 degrees C / 75 degrees F
Fans  FPC 0 Fan 1 (left)                 Failed
      FPC 0 Fan 2 (right)               OK          Spinning at normal speed
      FPC 0 Fan 3 (middle)              OK          Spinning at normal speed

```

show chassis environment cb

Syntax	show chassis environment cb <slot>
Syntax (TX Matrix Routers)	show chassis environment cb <lcc <i>number</i> scc> <slot>
Syntax (TX Matrix Plus Routers)	show chassis environment cb <lcc <i>number</i> sfc <i>number</i> > <slot>
Syntax (MX Series Router)	show chassis environment cb <slot> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos Release 7.4. Command introduced in Junos OS Release 9.4 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos Release 9.6.
Description	(M120, M320, MX Series, and T Series routers and EX8200 switches only) Display environmental information about the Control Boards (CBs). For information about the meaning of “CBs” on the switches, see EX Series Switches Hardware and CLI Terminology Mapping.
Options	<p>none—Display environmental information about all CBs. For a TX Matrix router, display environmental information about all CBs on the TX Matrix router and its attached T640 routers. For a TX Matrix Plus router, display environmental information about all CBs on the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display environmental information about the CBs on all the members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) For a TX Matrix router, display environmental information about the CBs in a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. For a TX Matrix Plus router, display environmental information about the CBs in a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display environmental information about the CBs on the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display environmental information about the CBs on the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p>

`scc`—(TX Matrix router only) (Optional) Display environmental information about the CBs in the TX Matrix router (or switch-card chassis).

`sfc number`—(TX Matrix Plus router only) (Optional) Display environmental information about the CBs in the TX Matrix Plus router (or switch-fabric chassis).

`slot`—(Optional) Display environmental information about the specified CB. On the routers, replace `slot` with `0` or `1`. On the switches, replace `slot` with `0`, `1`, or `2`.

`slot`—(Optional) Display environmental information about the specified CB. On EX8200 switches, replace `slot` with `0` or `1` or `2`.

Required Privilege Level view

List of Sample Output

- `show chassis environment cb` (M120 Router) on page 239
- `show chassis environment cb` (M320 Router) on page 239
- `show chassis environment cb` (MX80 Router) on page 240
- `show chassis environment cb` (MX240 Router) on page 240
- `show chassis environment cb` (MX480 Router) on page 240
- `show chassis environment cb` (MX960 Router) on page 241
- `show chassis environment cb` (TX Matrix Router) on page 241
- `show chassis environment cb` (TX Matrix Plus Router) on page 242
- `show chassis environment cb` (EX8200 Switch) on page 245
- `show chassis environment cb` (EX8208 Switch) on page 246

Output Fields Table 50 on page 238 lists the output fields for the `show chassis environment cb` command. Output fields are listed in the approximate order in which they appear.

Table 50: show chassis environment cb Output Fields

Field Name	Field Description
State	<p>Status of the CB. If two CBs are installed and online, one is functioning as the master, and the other is the standby.</p> <ul style="list-style-type: none"> • Online—CB is online and running. • Offline—CB is powered down. <p>NOTE: On the EX8208 switch, the installation can include three CBs. See EX Series Switches Hardware and CLI Terminology Mapping.</p>
Temperature	<p>Temperature in Celsius (C) and Fahrenheit (F) of the air flowing past the CB.</p> <ul style="list-style-type: none"> • Temperature Intake—Measures the temperature of the air intake to cool the power supplies. • Temperature Exhaust—Measures the temperature of the hot air exhaust.
Power	<p>Power required and measured on the CB. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.</p>
BUS Revision	<p>Revision level of the generic bus device. (Not on switches.)</p>
FPGA Revision	<p>Revision level of the field-programmable gate array (FPGA). (Not on switches.)</p>

Sample Output

```

show chassis environment cb (M120 Router)
user@host> show chassis environment cb
CB 0 status:
  State      Online Master
  Temperature 33 degrees C / 91 degrees F
  Power
    1.2 V      1214 mV
    1.5 V      1495 mV
    2.5 V      2494 mV
    3.3 V      3319 mV
    5.0 V      5085 mV
    3.3 V bias 3296 mV
  Bus Revision 12
  FPGA Revision 17
CB 1 status:
  State      Online Standby
  Temperature 34 degrees C / 93 degrees F
  Power
    1.2 V      1195 mV
    1.5 V      1495 mV
    2.5 V      2504 mV
    3.3 V      3312 mV
    5.0 V      5111 mV
    3.3 V bias 3296 mV
  Bus Revision 12
  FPGA Revision 17

show chassis environment cb (M320 Router)
user@host> show chassis environment cb
CB 0 status:
  State      Online Master
  Temperature 29 degrees C / 84 degrees F
  Power:
    1.8 V      1805 mV
    2.5 V      2501 mV
    3.3 V      3293 mV
    4.6 V      4725 mV
    5.0 V      5032 mV
    12.0 V     11975 mV
    3.3 V bias 3286 mV
    8.0 V bias 7589 mV
  BUS Revision 40
  FPGA Revision 7
CB 1 status:
  State      Online Standby
  Temperature 32 degrees C / 89 degrees F
  Power:
    1.8 V      1802 mV
    2.5 V      2482 mV
    3.3 V      3289 mV
    4.6 V      4720 mV
    5.0 V      5001 mV
    12.0 V     11946 mV
    3.3 V bias 3274 mV
    8.0 V bias 7562 mV
  BUS Revision 40
  FPGA Revision 7

```

```

show chassis environment cb (MX80 Router)
user@host> show chassis environment cb
CB 0 status:
State Online Master
Temperature 36 degrees C / 96 degrees F
Power 1
  1.0 V 1034 mV
  1.0 V MQ 1037 mV
  1.0 V LU 1005 mV
  1.2 V 1218 mV
  1.5 V 1524 mV
  1.8 V 1814 mV
  2.5 V 2558 mV
  3.3 V 3296 mV
  5.0 V 5233 mV
  5.0 V bias 5207 mV
  12.0 V 12162 mV

```

```

show chassis environment cb (MX240 Router)
user@host> show chassis environment cb
CB 0 status:
State Online Standby
Temperature 37 degrees C / 98 degrees F
Power 1
  1.2 V 1208 mV
  1.5 V 1521 mV
  1.8 V 1811 mV
  2.5 V 2513 mV
  3.3 V 3332 mV
  5.0 V 5059 mV
  12.0 V 12162 mV
  1.25 V 1260 mV
  3.3 V SM3 3306 mV
  5.0 V RE 5085 mV
  12.0 V RE 11872 mV
Power 2
  11.3 V bias PEM 11272 mV
  4.6 V bias MidPlane 4827 mV
  11.3 V bias FPD 11272 mV
  11.3 V bias POE 0 11292 mV
  11.3 V bias POE 1 11253 mV
Bus Revision 42
FPGA Revision 1

```

```

show chassis environment cb (MX480 Router)
user@host> show chassis environment cb
CB 0 status:
State Online Master
Temperature 41 degrees C / 105 degrees F
Power 1
  1.2 V 1202 mV
  1.5 V 1511 mV
  1.8 V 1798 mV
  2.5 V 2507 mV
  3.3 V 3312 mV
  5.0 V 5027 mV
  12.0 V 12200 mV
  1.25 V 1260 mV
  3.3 V SM3 3293 mV
  5 V RE 5040 mV
  12 V RE 11910 mV
Power 2
  11.3 V bias PEM 11156 mV

```



```

4.6 V bias MidPlane      4801 mV
11.3 V bias FPD          11214 mV
11.3 V bias POE 0        11098 mV
11.3 V bias POE 1        11330 mV
Bus Revision              42
FPGA Revision             1

```

**show chassis
environment cb
(MX960 Router)**

```

user@host> show chassis environment cb
CB 0 status:
State                Online Master
Temperature           24 degrees C / 75 degrees F
Power 1
  1.2 V               1965 mV
  1.5 V               2465 mV
  1.8 V               2990 mV
  2.5 V               3296 mV
  3.3 V               3296 mV
  5.0 V               6593 mV
  12.0 V              13187 mV
  3.3 V bias          3296 mV
  1.25 V              1994 mV
  3.3 V SM3           3296 mV
  5 V RE              6593 mV
  12 V RE             13174 mV
Power 2              Sensor failure
Bus Revision          4
FPGA Revision         3

```

**show chassis
environment cb
(TX Matrix Router)**

```

user@host> show chassis environment cb
-----
CB 0 status:
State                Online Master
Temperature           32 degrees C / 89 degrees F
Power:
  1.8 V               1797 mV
  2.5 V               2477 mV
  3.3 V               3311 mV
  4.6 V               4727 mV
  5.0 V               5015 mV
  12.0 V              12185 mV
  3.3 V bias          3304 mV
  8.0 V bias          7870 mV
BUS Revision          40
FPGA Revision         1
CB 1 status:
State                Online Standby
...

```

lcc0-re0:

```

-----
CB 0 status:
State                Online Master
Temperature           32 degrees C / 89 degrees F
Power:
  1.8 V               1787 mV
  2.5 V               2473 mV
  3.3 V               3306 mV
  4.6 V               4793 mV
  5.0 V               5025 mV
  12.0 V              12156 mV
  3.3 V bias          3289 mV

```

```

      8.0 V bias          7609 mV
      BUS Revision       40
      FPGA Revision      5
CB 1 status:
  State                  Online Standby
  ....
      BUS Revision       40
      FPGA Revision      5

lcc2-re0:
-----
CB 0 status:
  State                  Online Master
  ...
CB 1 status:
  State                  Online Standby
  ...

show chassis environment cb
(TX Matrix Plus
Router)
user@host> show chassis environment cb
sfc0-re0:
-----
CB 0 status:
  State                  Online Master
  Temperature            38 degrees C / 100 degrees F
  Power 1
    1.0 V                1005 mV
    1.1 V                1108 mV
    1.2 V                1205 mV
    1.25 V               1269 mV
    1.5 V                1508 mV
    1.8 V                1814 mV
    2.5 V                2507 mV
    3.3 V                3306 mV
    3.3 V bias           3300 mV
    9.0 V                9058 mV
    9.0 V RE             9107 mV
  Power 2
    3.9 V                3963 mV
    5.0 V                5020 mV
    9.0 V                9087 mV
  Bus Revision           79
  FPGA Revision          23
CB 1 status:
  State                  Online Standby
  Temperature            39 degrees C / 102 degrees F
  Power 1
    1.0 V                1002 mV
    1.1 V                1105 mV
    1.2 V                1198 mV
    1.25 V               1276 mV
    1.5 V                1504 mV
    1.8 V                1804 mV
    2.5 V                2507 mV
    3.3 V                3300 mV
    3.3 V bias           3293 mV
    9.0 V                9039 mV
    9.0 V RE             9049 mV
  Power 2
    3.9 V                3892 mV
    5.0 V                5040 mV
    9.0 V                9058 mV

```

```

Bus Revision          79
FPGA Revision         23

```

```
lcc0-re0:
```

```
-----
CB 0 status:
```

```

State                Online Master
Temperature           39 degrees C / 102 degrees F
Power 1
  1.8 V              1799 mV
  2.5 V              2499 mV
  3.3 V              3327 mV
  3.3 V bias         3299 mV
  4.6 V              4673 mV
  5.0 V              4918 mV
  8.0 V bias         7308 mV
  12.0 V             11887 mV
Power 2
  1.0 V              996 mV
  1.2 V              1199 mV
  3.3 V RE           3319 mV
Bus Revision          51
FPGA Revision         3

```

```
CB 1 status:
```

```

State                Online Standby
Temperature           40 degrees C / 104 degrees F
Power 1
  1.8 V              1800 mV
  2.5 V              2496 mV
  3.3 V              3322 mV
  3.3 V bias         3284 mV
  4.6 V              4680 mV
  5.0 V              4954 mV
  8.0 V bias         7284 mV
  12.0 V             11902 mV
Power 2
  1.0 V              998 mV
  1.2 V              1205 mV
  3.3 V RE           3327 mV
Bus Revision          51
FPGA Revision         3

```

```
lcc1-re0:
```

```
-----
CB 0 status:
```

```

State                Online Master
Temperature           41 degrees C / 105 degrees F
Power 1
  1.8 V              1804 mV
  2.5 V              2517 mV
  3.3 V              3300 mV
  3.3 V bias         3284 mV
  4.6 V              4681 mV
  5.0 V              4927 mV
  8.0 V bias         7357 mV
  12.0 V             11907 mV
Power 2
  1.0 V              991 mV
  1.2 V              1202 mV
  3.3 V RE           3301 mV
Bus Revision          51

```

```

FPGA Revision          3
CB 1 status:
State                  Online Standby
Temperature             40 degrees C / 104 degrees F
Power 1
  1.8 V                1805 mV
  2.5 V                2528 mV
  3.3 V                3324 mV
  3.3 V bias           3289 mV
  4.6 V                4694 mV
  5.0 V                4959 mV
  8.0 V bias           7311 mV
 12.0 V               11926 mV
Power 2
  1.0 V                998 mV
  1.2 V               1200 mV
  3.3 V RE             3313 mV
Bus Revision           51
FPGA Revision          3

```

```

lcc2-re0:
-----

```

```

CB 0 status:
State                  Online Master
Temperature             41 degrees C / 105 degrees F
Power 1
  1.8 V                1805 mV
  2.5 V                2494 mV
  3.3 V                3333 mV
  3.3 V bias           3296 mV
  4.6 V                4673 mV
  5.0 V                4901 mV
  8.0 V bias           7343 mV
 12.0 V               11916 mV
Power 2
  1.0 V                993 mV
  1.2 V               1213 mV
  3.3 V RE             3328 mV
Bus Revision           51
FPGA Revision          3

```

```

CB 1 status:
State                  Online Standby
Temperature             41 degrees C / 105 degrees F
Power 1
  1.8 V                1804 mV
  2.5 V                2523 mV
  3.3 V                3334 mV
  3.3 V bias           3291 mV
  4.6 V                4697 mV
  5.0 V                4969 mV
  8.0 V bias           7308 mV
 12.0 V               11936 mV
Power 2
  1.0 V                996 mV
  1.2 V               1200 mV
  3.3 V RE             3328 mV
Bus Revision           51
FPGA Revision          3

```

```

lcc3-re0:
-----

```

```

CB 0 status:
State                Online Master
Temperature          37 degrees C / 98 degrees F
Power 1
  1.8 V              1809 mV
  2.5 V              2510 mV
  3.3 V              3296 mV
  3.3 V bias         3291 mV
  4.6 V              4670 mV
  5.0 V              4905 mV
  8.0 V bias         7211 mV
  12.0 V             11882 mV
Power 2
  1.0 V              996 mV
  1.2 V              1188 mV
  3.3 V RE           3326 mV
Bus Revision         51
FPGA Revision        5
CB 1 status:
State                Online Standby
Temperature          38 degrees C / 100 degrees F
Power 1
  1.8 V              1813 mV
  2.5 V              2510 mV
  3.3 V              3322 mV
  3.3 V bias         3289 mV
  4.6 V              4692 mV
  5.0 V              4967 mV
  8.0 V bias         7194 mV
  12.0 V             11916 mV
Power 2
  1.0 V              996 mV
  1.2 V              1205 mV
  3.3 V RE           3273 mV
Bus Revision         51
FPGA Revision        5

```

```

show chassis environment cb
user@host> show chassis environment cb

```

(EX8200 Switch)

```

CB 0 status:
State                Online Master
Temperature Intake    20 degrees C / 68 degrees F
Temperature Exhaust   24 degrees C / 75 degrees F
Power 1
  1.1 V              1086 mV
  1.2 V              1179 mV
  1.2 V *            1182 mV
  1.2 V *            1182 mV
  1.25 V             1211 mV
  1.5 V              1472 mV
  1.8 V              1756 mV
  2.5 V              2449 mV
  3.3 V              3254 mV
  3.3 V bias         3300 mV
  5.0 V              4911 mV
  12.0 V             11891 mV
Power 2
  3.3 V bias *       3615 mV
  3.3 V bias *       3615 mV
  3.3 V bias *       3567 mV
  3.3 V bias *       3664 mV

```

```

4.3 V bias *      4224 mV
4.3 V bias *      4215 mV
4.3 V bias *      4224 mV
4.3 V bias *      4205 mV
4.3 V bias *      4195 mV
4.3 V bias *      4215 mV
5.0 V bias        4920 mV
CB 1 status:
State              Online Standby
Temperature Intake  19 degrees C / 66 degrees F
Temperature Exhaust 23 degrees C / 73 degrees F
Power 1
1.1 V              1082 mV
1.2 V              1169 mV
1.2 V *            1179 mV
1.2 V *            1179 mV
1.25 V             1214 mV
1.5 V              1482 mV
1.8 V              1759 mV
2.5 V              2481 mV
3.3 V              3248 mV
3.3 V bias         3306 mV
5.0 V              4911 mV
12.0 V             11910 mV
Power 2
3.3 V bias *       3644 mV
3.3 V bias *       3664 mV
3.3 V bias *       3586 mV
3.3 V bias *       3654 mV
4.3 V bias *       4224 mV
4.3 V bias *       4215 mV
4.3 V bias *       4224 mV
4.3 V bias *       4205 mV
4.3 V bias *       4244 mV
4.3 V bias *       4215 mV
5.0 V bias         4930 mV
CB 2 status:
State              Online
Temperature Intake  19 degrees C / 66 degrees F
Temperature Exhaust 23 degrees C / 73 degrees F
Power 1
1.2 V              1195 mV
1.5 V              1511 mV
1.8 V              1804 mV
2.5 V              2526 mV
3.3 V              3300 mV
3.3 V bias         3306 mV
12.0 V             12220 mV

```

```

show chassis environment cb
user@host> show chassis environment cb
environment cb
CB 0 status:
(EX8208 Switch)
State              Online Master
Temperature Intake  20 degrees C / 68 degrees F
Temperature Exhaust 24 degrees C / 75 degrees F
Power 1
1.1 V              1086 mV
1.2 V              1179 mV
1.2 V *            1182 mV
1.2 V *            1182 mV
1.25 V             1211 mV
1.5 V              1466 mV

```

```

1.8 V          1759 mV
2.5 V          2455 mV
3.3 V          3261 mV
3.3 V bias     3300 mV
5.0 V          4930 mV
12.0 V         11891 mV
Power 2
3.3 V bias *   3606 mV
3.3 V bias *   3615 mV
3.3 V bias *   3567 mV
3.3 V bias *   3673 mV
4.3 V bias *   4224 mV
4.3 V bias *   4215 mV
4.3 V bias *   4234 mV
4.3 V bias *   4205 mV
4.3 V bias *   4186 mV
4.3 V bias *   4215 mV
5.0 V bias     4940 mV
CB 1 status:
State          Online Standby
Temperature Intake  19 degrees C / 66 degrees F
Temperature Exhaust 23 degrees C / 73 degrees F
Power 1
1.1 V          1086 mV
1.2 V          1169 mV
1.2 V *        1179 mV
1.2 V *        1179 mV
1.25 V         1211 mV
1.5 V          1479 mV
1.8 V          1759 mV
2.5 V          2475 mV
3.3 V          3235 mV
3.3 V bias     3306 mV
5.0 V          4930 mV
12.0 V         11891 mV
Power 2
3.3 V bias *   3644 mV
3.3 V bias *   3664 mV
3.3 V bias *   3586 mV
3.3 V bias *   3654 mV
4.3 V bias *   4215 mV
4.3 V bias *   4224 mV
4.3 V bias *   4215 mV
4.3 V bias *   4215 mV
4.3 V bias *   4234 mV
4.3 V bias *   4224 mV
5.0 V bias     4920 mV
CB 2 status:
State          Online
Temperature Intake  20 degrees C / 68 degrees F
Temperature Exhaust 24 degrees C / 75 degrees F
Power 1
1.2 V          1202 mV
1.5 V          1508 mV
1.8 V          1804 mV
2.5 V          2520 mV
3.3 V          3300 mV
3.3 V bias     3300 mV
12.0 V         12200 mV

```

show chassis environment cip

Syntax (TX Matrix Plus Router)	<code>show chassis environment cip</code> <code><slot-number></code>
Release Information	Command introduced in Junos OS Release 9.6 for the TX Matrix Plus router.
Description	(TX Matrix Plus router only) Display environmental information about the Connector Interface Panel (CIP).
Options	<p><code>none</code>—Display environmental information about all the CIP.</p> <p><code>slot</code>—Display environmental information about a specific CIP. Replace slot with a value from 0 through 1.</p>
Required Privilege Level	view
Output Fields	Table 51 on page 248 lists the output fields for the show chassis environment cip command. Output fields are listed in the approximate order in which they appear.

Table 51: show chassis environment cip Output Fields

Field Name	Field Description
State	<p>State of the CIP:</p> <ul style="list-style-type: none"> • Online Active: CIP is online and there is active control plane data transfer between the SFC and LCCs in the routing matrix. • Online Inactive: CIP is online, but inactive. • Offline: CIP is offline.
Temp	Temperature of the CIP in Celsius (C) and Fahrenheit (F).
Power	Information about the voltage supplied to the CIP. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
Bus Revision	Bus revision number.

show chassis environment cip (TX Matrix Plus Router)

```

user@host> show chassis environment cip
CIP 0 status:
  State                Online Active
  Temperature          23 degrees C / 73 degrees F
  Power 1
    1.0 V              1015 mV
    1.8 V              1817 mV
    2.5 V              2497 mV
    3.3 V              3325 mV
    3.3 V bias         3300 mV
    5.0 V              5001 mV
    9.0 V              9049 mV

```


Bus Revision	74
CIP 1 status:	
State	Online Inactive
Temperature	24 degrees C / 75 degrees F
Power 1	
1.0 V	1008 mV
1.8 V	1820 mV
2.5 V	2504 mV
3.3 V	3325 mV
3.3 V bias	3306 mV
5.0 V	5091 mV
9.0 V	9049 mV
Bus Revision	74

show chassis environment fpc

Syntax	show chassis environment fpc <slot>
Syntax (TX Matrix and TX Matrix Plus Router)	show chassis environment fpc <lcc number> <slot>
Syntax (MX Series Router)	show chassis environment fpc <slot> <all-members> <local> <member member-id>
Syntax (QFX Series)	show chassis environment fpc <fpc-slot>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	(M40e, M120, M160, M320, MX Series, T Series routers, EX Series, and QFX Series switches only) Display environmental information about Flexible PIC Concentrators (FPCs).
Options	<p>none—Display environmental information about all FPCs. On a TX Matrix router, display environmental information about all FPCs on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display environmental information about all FPCs on the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display environmental information for the FPCs in all the members of the Virtual Chassis configuration.</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display environmental information about the FPC in a T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display environmental information about the FPC in a T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace number with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display environmental information for the FPCs in the local Virtual Chassis member.</p> <p>member member-id—(MX Series routers only) (Optional) Display environmental information for the FPCs in the specified member of the Virtual Chassis configuration. Replace member-id with a value of 0 or 1.</p> <p>slot or fpc-slot—(Optional) Display environmental information about an individual FPC:</p> <ul style="list-style-type: none"> (TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, if you specify the number of the T640 router by using only the lcc number option (the recommended method), replace slot with a value from 0 through 7. Similarly, on

a TX Matrix Plus router, if you specify the number of the T1600 router by using only the **lcc number** option (the recommended method), replace **slot** with a value from 0 through 7. Otherwise, replace **slot** with a value from 0 through 31. For example, the following commands have the same result:

```
user@host> show chassis environment fpc 1 lcc 1
user@host> show chassis environment fpc 9
```

- M120 router—Replace **slot** with a value from 0 through 5.
- MX240 router—Replace **slot** with a value from 0 through 2.
- MX480 router—Replace **slot** with a value from 0 through 5.
- MX960 router—Replace **slot** with a value from 0 through 11.
- Other routers—Replace **slot** with a value from 0 through 7.
- EX Series switches:
 - EX3200 switches and EX4200 standalone switches—Replace **slot** with 0.
 - EX4200 switches in a Virtual Chassis configuration—Replace **slot** with a value from 0 through 9 (switch's member ID).
 - EX8208 switches—Replace **slot** with a value from 0 through 7 (line card).
 - EX8216 switches—Replace **slot** with a value from 0 through 15 (line card).
- QFX Series—Replace **fpc-slot** with 0.

Required Privilege Level	view
List of Sample Output	show chassis environment fpc (M120 Router) on page 252 show chassis environment fpc (M160 Router) on page 253 show chassis environment fpc (M320 Router) on page 254 show chassis environment fpc (MX240 Router) on page 254 show chassis environment fpc (MX480 Router) on page 255 show chassis environment fpc (MX960 Router) on page 256 show chassis environment fpc (T Series Core Routers) on page 257 show chassis environment fpc lcc (TX Matrix Router) on page 258 show chassis environment fpc lcc (TX Matrix Plus Router) on page 258 show chassis environment fpc 0 (QFX Series) on page 259
Output Fields	Table 52 on page 252 lists the output fields for the show chassis environment fpc command. Output fields are listed in the approximate order in which they appear.

Table 52: show chassis environment fpc Output Fields

Field Name	Field Description
State	Status of the FPC: <ul style="list-style-type: none"> • Unknown—FPC is not detected by the router. • Empty—No FPC is present. • Present—FPC is detected by the chassis daemon but is either not supported by the current version of the Junos OS, or the FPC is coming up but not yet online. • Ready—FPC is in intermediate or transition state. • Announce online—Intermediate state during which the FPC is coming up but not yet online, and the chassis manager acknowledges the chassisd FPC online initiative. • Online—FPC is online and running. • Offline—FPC is powered down. • Diagnostics—FPC is set to operate in diagnostics mode.
Temperature	(M40e and M160 routers and QFX Series only) Temperature of the air flowing past the FPC.
Temperature Intake	(M320 routers only) Temperature of the air flowing into the chassis.
Temperature Top	(T Series routers only) Temperature of the air flowing past the top of the FPC.
Temperature Exhaust	(M120 and M320 routers only) Temperature of the air flowing out of the chassis.
Temperature Bottom	(T Series routers only) Temperature of the air flowing past the bottom of the FPC.
Temperature MMBO	(T640 router only) Temperature of the air flowing past the type 3 FPC.
Temperature MMB1	(M320 and T Series routers only) Temperature of the air flowing past the type 1, type 2, and type 3 FPC.
Power	Information about the voltage supplied to the FPC. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
CMB Revision or BUS revision	Revision level of the chassis management bus device (M Series router) or bus (T Series routers).

Sample Output

```

show chassis environment fpc (M120 Router)
user@host> show chassis environment fpc
FPC 2 status:
  State      Online
  Temperature Exhaust A  32 degrees C / 89 degrees F
  Temperature Exhaust B  31 degrees C / 87 degrees F
  Power A-Board
    1.2 V      1202 mV
    1.5 V      1508 mV
    1.8 V      1798 mV
    2.5 V      2507 mV
    3.3 V      3351 mV
    5.0 V      4995 mV
    3.3 V bias  3296 mV
    1.2 V Rocket IO 1205 mV

```

```

    1.5 V Rocket IO      1501 mV
    I2C Slave Revision   12
    FPC 3 status:
    State                Online
    Temperature Exhaust A 31 degrees C / 87 degrees F
    Temperature Exhaust B 33 degrees C / 91 degrees F
    Power A-Board
    1.2 V                1211 mV
    1.5 V                1501 mV
    1.8 V                1798 mV
    2.5 V                2471 mV
    3.3 V                3293 mV
    5.0 V                4930 mV
    3.3 V bias           3296 mV
    1.2 V Rocket IO      1205 mV
    1.5 V Rocket IO      1501 mV
    Power B-Board
    1.2 V                1214 mV
    1.5 V                1501 mV
    2.5 V                2471 mV
    3.3 V                3300 mV
    5.0 V                4943 mV
    3.3 V bias           3296 mV
    1.2 V Rocket IO      1205 mV
    1.5 V Rocket IO      1501 mV
    I2C Slave Revision   12
    FPC 4 status:
    State                Online
    Temperature Exhaust A 32 degrees C / 89 degrees F
    Temperature Exhaust B 30 degrees C / 86 degrees F
    Power A-Board
    1.2 V                1195 mV
    1.5 V                1504 mV
    1.8 V                1801 mV
    2.5 V                2504 mV
    3.3 V                3293 mV
    5.0 V                4917 mV
    3.3 V bias           3296 mV
    1.2 V Rocket IO      1202 mV
    1.5 V Rocket IO      1492 mV
    I2C Slave Revision   12

```

**show chassis
environment fpc (M160
Router)**

```

user@host> show chassis environment fpc
FPC 0 status:
State                Online
Temperature          42 degrees C / 107 degrees F
Power:
  1.5 V              1500 mV
  2.5 V              2509 mV
  3.3 V              3308 mV
  5.0 V              4991 mV
  5.0 V bias         4952 mV
  8.0 V bias         8307 mV
CMB Revision         12
FPC 1 status:
State                Online
Temperature          45 degrees C / 113 degrees F
Power:
  1.5 V              1498 mV
  2.5 V              2501 mV
  3.3 V              3319 mV

```

```

5.0 V          5020 mV
5.0 V bias     5025 mV
8.0 V bias     8307 mV
CMB Revision   12

```

**show chassis
environment fpc
(M320 Router)**

```

user@host> show chassis environment fpc
FPC 0 status:
State                Online
Temperature Intake    27 degrees C / 80 degrees F
Temperature Exhaust    38 degrees C / 100 degrees F
Temperature MMB1      31 degrees C / 87 degrees F
Power:
1.5 V                1487 mV
1.5 V *              1494 mV
1.8 V                1821 mV
2.5 V                2533 mV
3.3 V                3323 mV
5.0 V                5028 mV
3.3 V bias           3296 mV
5.0 V bias           4984 mV
CMB Revision         16
FPC 1 status:
State                Online
Temperature Intake    27 degrees C / 80 degrees F
Temperature Exhaust    37 degrees C / 98 degrees F
Temperature MMB1      32 degrees C / 89 degrees F
Power:
1.5 V                1504 mV
1.5 V *              1499 mV
1.8 V                1820 mV
2.5 V                2529 mV
3.3 V                3328 mV
5.0 V                5013 mV
3.3 V bias           3294 mV
5.0 V bias           4984 mV
CMB Revision         16
FPC 2 status:
State                Online
Temperature Intake    28 degrees C / 82 degrees F
Temperature Exhaust    38 degrees C / 100 degrees F
Temperature MMB1      32 degrees C / 89 degrees F
Power:
1.5 V                1498 mV
1.5 V *              1487 mV
1.8 V                1816 mV
2.5 V                2531 mV
3.3 V                3324 mV
5.0 V                5025 mV
3.3 V bias           3277 mV
5.0 V bias           5013 mV
CMB Revision         17
FPC 3 status:
...

```

**show chassis
environment fpc
(MX240 Router)**

```

user@host> show chassis environment fpc
FPC 1 status:
State                Online
Temperature Intake    34 degrees C / 93 degrees F
Temperature Exhaust A  39 degrees C / 102 degrees F
Temperature Exhaust B  53 degrees C / 127 degrees F
Temperature I3 0 TSensor 51 degrees C / 123 degrees F

```

```

Temperature I3 0 Chip      54 degrees C / 129 degrees F
Temperature I3 1 TSensor   50 degrees C / 122 degrees F
Temperature I3 1 Chip      53 degrees C / 127 degrees F
Temperature I3 2 TSensor   48 degrees C / 118 degrees F
Temperature I3 2 Chip      51 degrees C / 123 degrees F
Temperature I3 3 TSensor   45 degrees C / 113 degrees F
Temperature I3 3 Chip      48 degrees C / 118 degrees F
Temperature IA 0 TSensor   45 degrees C / 113 degrees F
Temperature IA 0 Chip      45 degrees C / 113 degrees F
Temperature IA 1 TSensor   45 degrees C / 113 degrees F
Temperature IA 1 Chip      49 degrees C / 120 degrees F
Power
  1.5 V                    1492 mV
  2.5 V                    2507 mV
  3.3 V                    3306 mV
  1.8 V PFE 0              1801 mV
  1.8 V PFE 1              1804 mV
  1.8 V PFE 2              1798 mV
  1.8 V PFE 3              1798 mV
  1.2 V PFE 0              1169 mV
  1.2 V PFE 1              1189 mV
  1.2 V PFE 2              1182 mV
  1.2 V PFE 3              1176 mV
I2C Slave Revision        42
FPC 2 status:
State                      Online
Temperature Intake          33 degrees C / 91 degrees F
Temperature Exhaust A       41 degrees C / 105 degrees F
Temperature Exhaust B       53 degrees C / 127 degrees F
Temperature I3 0 TSensor    53 degrees C / 127 degrees F
Temperature I3 0 Chip       58 degrees C / 136 degrees F
Temperature I3 1 TSensor    52 degrees C / 125 degrees F
Temperature I3 1 Chip       56 degrees C / 132 degrees F
Temperature I3 2 TSensor    50 degrees C / 122 degrees F
Temperature I3 2 Chip       52 degrees C / 125 degrees F
Temperature I3 3 TSensor    46 degrees C / 114 degrees F
Temperature I3 3 Chip       49 degrees C / 120 degrees F
Temperature IA 0 TSensor    51 degrees C / 123 degrees F
Temperature IA 0 Chip       49 degrees C / 120 degrees F
Temperature IA 1 TSensor    48 degrees C / 118 degrees F
Temperature IA 1 Chip       53 degrees C / 127 degrees F
Power
  1.5 V                    1492 mV
  2.5 V                    2445 mV
  3.3 V                    3293 mV
  1.8 V PFE 0              1827 mV
  1.8 V PFE 1              1775 mV
  1.8 V PFE 2              1788 mV
  1.8 V PFE 3              1798 mV
  1.2 V PFE 0              1250 mV
  1.2 V PFE 1              1234 mV
  1.2 V PFE 2              1231 mV
  1.2 V PFE 3              1192 mV
I2C Slave Revision        42

```

```

show chassis environment fpc
(MX480 Router)
user@host> show chassis environment fpc
FPC 1 status:
State                      Online
Temperature Intake          36 degrees C / 96 degrees F
Temperature Exhaust A       41 degrees C / 105 degrees F
Temperature Exhaust B       55 degrees C / 131 degrees F

```

```

Temperature I3 0 TSensor 55 degrees C / 131 degrees F
Temperature I3 0 Chip    57 degrees C / 134 degrees F
Temperature I3 1 TSensor 53 degrees C / 127 degrees F
Temperature I3 1 Chip    53 degrees C / 127 degrees F
Temperature I3 2 TSensor 52 degrees C / 125 degrees F
Temperature I3 2 Chip    49 degrees C / 120 degrees F
Temperature I3 3 TSensor 47 degrees C / 116 degrees F
Temperature I3 3 Chip    47 degrees C / 116 degrees F
Temperature IA 0 TSensor 54 degrees C / 129 degrees F
Temperature IA 0 Chip    58 degrees C / 136 degrees F
Temperature IA 1 TSensor 48 degrees C / 118 degrees F
Temperature IA 1 Chip    53 degrees C / 127 degrees F
Power
  1.5 V      1479 mV
  2.5 V      2542 mV
  3.3 V      3319 mV
  1.8 V PFE 0 1811 mV
  1.8 V PFE 1 1804 mV
  1.8 V PFE 2 1804 mV
  1.8 V PFE 3 1814 mV
  1.2 V PFE 0 1192 mV
  1.2 V PFE 1 1202 mV
  1.2 V PFE 2 1205 mV
  1.2 V PFE 3 1189 mV
I2C Slave Revision 40

```

**show chassis
environment fpc
(MX960 Router)**

```

user@host> show chassis environment fpc
FPC 5 status:
  State Online
  Temperature Intake 27 degrees C / 80 degrees F
  Temperature Exhaust A 34 degrees C / 93 degrees F
  Temperature Exhaust B 40 degrees C / 104 degrees F
  Temperature I3 0 TSensor 39 degrees C / 102 degrees F
  Temperature I3 0 Chip 41 degrees C / 105 degrees F
  Temperature I3 1 TSensor 38 degrees C / 100 degrees F
  Temperature I3 1 Chip 37 degrees C / 98 degrees F
  Temperature I3 2 TSensor 37 degrees C / 98 degrees F
  Temperature I3 2 Chip 34 degrees C / 93 degrees F
  Temperature I3 3 TSensor 32 degrees C / 89 degrees F
  Temperature I3 3 Chip 33 degrees C / 91 degrees F
  Temperature IA 0 TSensor 39 degrees C / 102 degrees F
  Temperature IA 0 Chip 44 degrees C / 111 degrees F
  Temperature IA 1 TSensor 36 degrees C / 96 degrees F
  Temperature IA 1 Chip 44 degrees C / 111 degrees F
  Power
    1.5 V      1479 mV
    2.5 V      2523 mV
    3.3 V      3254 mV
    1.8 V PFE 0 1798 mV
    1.8 V PFE 1 1798 mV
    1.8 V PFE 2 1807 mV
    1.8 V PFE 3 1791 mV
    1.2 V PFE 0 1173 mV
    1.2 V PFE 1 1179 mV
    1.2 V PFE 2 1179 mV
    1.2 V PFE 3 1185 mV
  I2C Slave Revision 6
FPC 6 status:
  State Online
  Temperature Intake 25 degrees C / 77 degrees F
  Temperature Exhaust A 38 degrees C / 100 degrees F

```



```

Temperature Exhaust B      38 degrees C / 100 degrees F
Temperature I3 0 TSensor   40 degrees C / 104 degrees F
Temperature I3 0 Chip      40 degrees C / 104 degrees F
Temperature I3 1 TSensor   40 degrees C / 104 degrees F
Temperature I3 1 Chip      38 degrees C / 100 degrees F
Temperature I3 2 TSensor   37 degrees C / 98 degrees F
Temperature I3 2 Chip      32 degrees C / 89 degrees F
Temperature I3 3 TSensor   34 degrees C / 93 degrees F
Temperature I3 3 Chip      33 degrees C / 91 degrees F
Temperature IA 0 TSensor   45 degrees C / 113 degrees F
Temperature IA 0 Chip      47 degrees C / 116 degrees F
Temperature IA 1 TSensor   37 degrees C / 98 degrees F
Temperature IA 1 Chip      42 degrees C / 107 degrees F
Power
  1.5 V                    1485 mV
  2.5 V                    2510 mV
  3.3 V                    3332 mV
  1.8 V PFE 0             1801 mV
  1.8 V PFE 1             1814 mV
  1.8 V PFE 2             1804 mV
  1.8 V PFE 3             1820 mV
  1.2 V PFE 0             1192 mV
  1.2 V PFE 1             1189 mV
  1.2 V PFE 2             1202 mV
  1.2 V PFE 3             1156 mV
I2C Slave Revision        40

```

**show chassis
environment fpc (T
Series Core Routers)**

```

user@host> show chassis environment fpc
FPC 0 status:
  State                Online
  Temperature Top       42 degrees C / 107 degrees F
  Temperature Bottom    36 degrees C / 96 degrees F
  Temperature MMB1      39 degrees C / 102 degrees F
  Power:
    1.8 V               1959 mV
    2.5 V               2495 mV
    3.3 V               3344 mV
    5.0 V               5047 mV
    1.8 V bias          1787 mV
    3.3 V bias          3291 mV
    5.0 V bias          4998 mV
    8.0 V bias          7343 mV
  BUS Revision          40
FPC 1 status:
  State                Online
  Temperature Top       42 degrees C / 107 degrees F
  Temperature Bottom    39 degrees C / 102 degrees F
  Temperature MMB1      40 degrees C / 104 degrees F
  Power:
    1.8 V               1956 mV
    2.5 V               2498 mV
    3.3 V               3340 mV
    5.0 V               5023 mV
    1.8 V bias          1782 mV
    3.3 V bias          3277 mV
    5.0 V bias          4989 mV
    8.0 V bias          7289 mV
  BUS Revision          40
FPC 2 status:
  State                Online
  Temperature Top       43 degrees C / 109 degrees F

```

```

Temperature Bottom      39 degrees C / 102 degrees F
Temperature MMB1        41 degrees C / 105 degrees F
Power:
  1.8 V                  1963 mV
  2.5 V                  2503 mV
  3.3 V                  3340 mV
  5.0 V                  5042 mV
  1.8 V bias             1797 mV
  3.3 V bias             3311 mV
  5.0 V bias             5013 mV
  8.0 V bias             7221 mV
BUS Revision            40

```

show chassis environment fpc lcc
(TX Matrix Router)

```

user@host> show chassis environment fpc lcc 0
lcc0-re0:
-----

```

```

FPC 1 status:
State                  Online
Temperature Top         30 degrees C / 86 degrees F
Temperature Bottom      25 degrees C / 77 degrees F
Temperature MMB0        Absent
Temperature MMB1        27 degrees C / 80 degrees F
Power:
  1.8 V                  1813 mV
  2.5 V                  2504 mV
  3.3 V                  3338 mV
  5.0 V                  5037 mV
  1.8 V bias             1797 mV
  3.3 V bias             3301 mV
  5.0 V bias             5013 mV
  8.0 V bias             7345 mV
BUS Revision            40
FPC 2 status:
State                  Online
Temperature Top         37 degrees C / 98 degrees F
Temperature Bottom      26 degrees C / 78 degrees F
Temperature MMB0        32 degrees C / 89 degrees F
Temperature MMB1        27 degrees C / 80 degrees F
Power:
  1.8 V                  1791 mV
  2.5 V                  2517 mV
  3.3 V                  3308 mV
  5.0 V                  5052 mV
  1.8 V bias             1797 mV
  3.3 V bias             3289 mV
  5.0 V bias             4991 mV
  8.0 V bias             7477 mV
BUS Revision            40

```

show chassis environment fpc lcc
(TX Matrix Plus Router)

```

user@host> show chassis environment fpc lcc 0
lcc0-re0:
-----

```

```

FPC 1 status:
State                  Online
Temperature Top         46 degrees C / 114 degrees F
Temperature Bottom      47 degrees C / 116 degrees F
Power:
  1.8 V                  1788 mV
  1.8 V bias             1787 mV
  3.3 V                  3321 mV
  3.3 V bias             3306 mV

```

5.0 V bias	5018 mV
5.0 V TOP	5037 mV
8.0 V bias	7223 mV
Power (Base/PMB/MMB)	
1.2 V	1205 mV
1.5 V	1503 mV
5.0 V BOT	5084 mV
12.0 V TOP Base	11775 mV
12.0 V BOT Base	11794 mV
1.1 V PMB	1108 mV
1.2 V PMB	1196 mV
1.5 V PMB	1499 mV
1.8 V PMB	1811 mV
2.5 V PMB	2515 mV
3.3 V PMB	3318 mV
5.0 V PMB	5030 mV
12.0 V PMB	11832 mV
0.75 MMB TOP	752 mV
1.5 V MMB TOP	1489 mV
1.8 V MMB TOP	1782 mV
2.5 V MMB TOP	2498 mV
1.2 V MMB TOP	1155 mV
5.0 V MMB TOP	4902 mV
12.0 V MMB TOP	11721 mV
3.3 V MMB TOP	3316 mV
0.75 MMB BOT	754 mV
1.5 V MMB BOT	1482 mV
1.8 V MMB BOT	1758 mV
2.5 V MMB BOT	2488 mV
1.2 V MMB BOT	1157 mV
5.0 V MMB BOT	4962 mV
12.0 V MMB BOT	11691 mV
3.3 V MMB BOT	3308 mV
APS 00	1484 mV
APS 01	2503 mV
APS 02	3313 mV
5.0 V PIC 0	5025 mV
APS 10	1501 mV
APS 11	2466 mV
APS 12	3311 mV
5.0 V PIC 1	5081 mV
Bus Revision	49

```

show chassis environment fpc 0
user@switch> show chassis environment fpc 0
environment fpc 0
(QFX Series)
FPC 0 status:
State          Online
Temperature    42 degrees C / 107 degrees F

```

show chassis environment fpm

Syntax	show chassis environment fpm
Syntax (TX Matrix Router)	show chassis environment fpm <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis environment fpm <lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(M40e, M120, M160, M320, MX Series, and T Series routers only) Display environmental information about the front panel module in the router.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display environmental information about the front panel modules (craft interfaces) on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display environmental information about the front panel modules (craft interfaces) on the TX Matrix Plus router and its attached T1600 routers.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display environmental information about the front panel module (craft interface) on a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display environmental information about the front panel module (craft interface) on a specified T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix router only) (Optional) Display environmental information about the front panel module (craft interface) on the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus router only) (Optional) Display environmental information about the front panel module (craft interface) on the TX Matrix Plus router (or switch-fabric chassis).</p>
Required Privilege Level	view
List of Sample Output	show chassis environment fpm (M40e and M160 Routers) on page 261 show chassis environment fpm (M320 Router) on page 261 show chassis environment fpm (MX240 Router) on page 262 show chassis environment fpm (MX480 Router) on page 262 show chassis environment fpm (T Series Routers) on page 262 show chassis environment fpm lcc (TX Matrix Router) on page 262 show chassis environment fpm scc (TX Matrix Router) on page 262 show chassis environment fpm sfc (TX Matrix Plus Router) on page 263

Output Fields Table 53 on page 261 lists the output fields for the **show chassis environment fpm** command. Output fields are listed in the approximate order in which they appear.

Table 53: show chassis environment fpm Output Fields

Field Name	Field Description
State	FPM status: <ul style="list-style-type: none"> • Online—FPM is online and running. • Offline—FPM is powered down.
FPM CMB Voltage	(M40e and M160 routers only) Information about the voltage supplied to the FPM chassis management bus (CMB) device. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
FPM GBUS Voltage	(M320 and T Series routers only) Information about the voltage supplied to the FPM generic bus (GBUS) device. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
FPM Display Voltage	Information about the voltage supplied to the FPM display. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
FPM CMB Temperature	(M40e and M160 routers only) Temperature of the air flowing past the FPM CMB device
FPM GBUS Temperature	(M320 and T Series routers only) Temperature of the air flowing past the FPM GBUS device.
FPM Display Temperature	Temperature of the air flowing past the FPM display.
CMB Revision	(M40e and M160 routers only) Revision level of the CMB device.
GBUS Revision	(M320 and T Series routers only) Revision level of the GBUS device.

Sample Output

```

show chassis environment fpm (M40e and M160 Routers)
user@host> show chassis environment fpm
FPM status:
State Online
FPM CMB Voltage:
  5.0 V bias 5030 mV
  8.0 V bias 8083 mV
FPM Display Voltage:
  5.0 V bias 4998 mV
FPM CMB temperature 34 degrees C / 93 degrees F
FPM Display temperature 35 degrees C / 95 degrees F
CMB Revision 12

show chassis environment fpm (M320 Router)
user@host> show chassis environment fpm
FPM status:
State Online
FPM GBUS Voltage:
  5.0 V 5006 mV
  1.8 V bias 1799 mV

```

```

        3.3 V bias           3294 mV
        5.0 V bias           4998 mV
        8.0 V bias           7682 mV
        FPM GBUS temperature 30 degrees C / 86 degrees F
        GBUS Revision        51

show chassis environment fpm (MX240 Router) user@host> show chassis environment fpm
FPM status:
  State           Online
  I2CS Revision   41

show chassis environment fpm (MX480 Router) user@host> show chassis environment fpm
FPM status:
  State           Online
  I2CS Revision   41

show chassis environment fpm (T Series Routers) user@host> show chassis environment fpm
FPM status:
  State           Online
  FPM GBUS Voltage:
    1.8 V bias     1787 mV
    3.3 V bias     3286 mV
    5.0 V bias     4991 mV
    8.0 V bias     7162 mV
  FPM Display Voltage:
    5.0 V          4996 mV
  FPM GBUS temperature 29 degrees C / 84 degrees F
  FPM Display temperature 26 degrees C / 78 degrees F
  GBUS Revision     37

show chassis environment fpm lcc (TX Matrix Router) user@host> show chassis environment fpm lcc 0
lcc0-re0:
-----
FPM status:
  State           Online
  FPM GBUS Voltage:
    1.8 V bias     1797 mV
    3.3 V bias     3294 mV
    5.0 V bias     5015 mV
    8.0 V bias     7470 mV
  FPM Display Voltage:
    5.0 V          5018 mV
  FPM GBUS temperature 25 degrees C / 77 degrees F
  FPM Display temperature 29 degrees C / 84 degrees F
  GBUS Revision     37

show chassis environment fpm scc (TX Matrix Router) user@host> show chassis environment fpm scc
scc-re0:
-----
FPM status:
  State           Online
  FPM GBUS Voltage:
    1.8 V bias     1789 mV
    3.3 V bias     3296 mV
    5.0 V bias     5003 mV
    8.0 V bias     7592 mV
  FPM Display Voltage:
    5.0 V          5010 mV
  FPM GBUS temperature 22 degrees C / 71 degrees F

```

```

FPM Display temperature      27 degrees C / 80 degrees F
GBUS Revision                37

show chassis environment fpm sfc
(TX Matrix Plus
Router) user@host> show chassis environment fpm sfc

sfc0-re0:
-----
FPM status:
State                               Online
FPM I2CS Voltage:
  3.3 V                             3300 mV
  5.0 V                             5001 mV
  9.0 V FPD                         8672 mV
FPM I2CS temperature          33 degrees C / 91 degrees F
I2CS Revision                 69

lcc0-re0:
-----
FPM status:
State                               Online
FPM GBUS Voltage:
  1.8 V bias                        1802 mV
  3.3 V bias                        3301 mV
  5.0 V bias                        4984 mV
  8.0 V bias                        7377 mV
FPM Display Voltage:
  5.0 V                             5015 mV
FPM GBUS temperature          30 degrees C / 86 degrees F
FPM Display temperature       32 degrees C / 89 degrees F
GBUS Revision                 37

lcc1-re0:
-----
FPM status:
State                               Online
FPM GBUS Voltage:
  1.8 V bias                        1789 mV
  3.3 V bias                        3311 mV
  5.0 V bias                        5013 mV
  8.0 V bias                        7467 mV
FPM Display Voltage:
  5.0 V                             5015 mV
FPM GBUS temperature          29 degrees C / 84 degrees F
FPM Display temperature       31 degrees C / 87 degrees F
GBUS Revision                 37

```

show chassis environment mcs

Syntax	<code>show chassis environment mcs</code> <code><slot></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Display environmental information about the Miscellaneous Control Subsystems (MCSs).
Options	<p><code>none</code>—Display environmental information about both MCSs.</p> <p><code>slot</code> —(Optional) Display environmental information about an individual MCS. Replace <code>slot</code> with <code>0</code> or <code>1</code>.</p>
Required Privilege Level	view
List of Sample Output	<p><code>show chassis environment mcs</code> (M40e Router) on page 265</p> <p><code>show chassis environment mcs</code> (M160 Router) on page 265</p>
Output Fields	Table 54 on page 264 lists the output fields for the <code>show chassis environment mcs</code> command. Output fields are listed in the approximate order in which they appear.

Table 54: show chassis environment mcs Output Fields

Field Name	Field Description
State	<p>Status of the MCS:</p> <ul style="list-style-type: none"> • Present—MCS is detected by the chassis daemon but is either not supported by the current version of Junos or MCS is coming up but not yet online. • Online—MCS is online and running. • Offline—MCS is powered down. • Empty—No MCS is present. • Master—MCS is online, operating as master. • Standby—MCS is online, operating as standby.
Temperature	Temperature of the air flowing past the MCS.
Power	Information about the voltage supplied to the MCS. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
BUS Revision	Revision level of the generic bus device.
FPGA Revision	Revision level of the field-programmable gate array (FPGA) revision.

Sample Output

```

show chassis environment mcs user@host> show chassis environment mcs
(M40e Router)
MCS 0 status:
  State Online Master
  Temperature 45 degrees C / 113 degrees F
  Power:
    3.3 V 3283 mV
    5.0 V 5013 mV
    12.0 V 11721 mV
    5.0 V bias 5025 mV
    8.0 V bias 8229 mV
  BUS Revision 12
  FPGA Revision 13
MCS 1 status:
  State Online Standby
  Temperature 42 degrees C / 107 degrees F
  Power:
    3.3 V 3296 mV
    5.0 V 4971 mV
    12.0 V 11814 mV
    5.0 V bias 4976 mV
    8.0 V bias 8241 mV
  BUS Revision 12
  FPGA Revision 13

show chassis environment mcs user@host> show chassis environment mcs
(M160 Router)
MCS 0 status:
  State Online Master
  Temperature 50 degrees C / 122 degrees F
  Power:
    3.3 V 3306 mV
    5.0 V 4993 mV
    12.0 V 11799 mV
    5.0 V bias 4993 mV
    8.0 V bias 8288 mV
  BUS Revision 12
  FPGA Revision 13

```

show chassis environment pcg

Syntax	show chassis environment pcg <slot>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Display environmental information about the Packet Forwarding Engine clock generators (PCGs).
Options	none—Display environmental information about both PCGs. slot—(Optional) Display environmental information about an individual PCG. Replace <i>slot</i> with 0 or 1.
Required Privilege Level	view
List of Sample Output	show chassis environment pcg (M40e Router) on page 267 show chassis environment pcg (M160 Router) on page 267
Output Fields	Table 55 on page 266 lists the output fields for the show chassis environment pcg command. Output fields are listed in the approximate order in which they appear.

Table 55: show chassis environment pcg Output Fields

Field Name	Field Description
PCG slot status	Slot number: 0 or 1.
State	Status of PCG: <ul style="list-style-type: none"> • Present—PCG is detected by the chassis process but is either not supported by the current version of Junos OS or PCG is coming up but is not yet online. • Online—PCG is powered down. If Online, it can be the Master clock or the Standby clock. • Offline—PCG is powered down. • Empty—No PCG is present.
Temperature	Temperature of the air flowing past the PCG.
Frequency	Frequency setting and measurement for the PCG.
Power	Information about the voltage supplied to the PCG. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
BUS Revision	Revision level of the generic bus device.

Sample Output

```

show chassis environment pcg (M40e Router) user@host> show chassis environment pcg
PCG 0 status:
  State                Online - Master clock
  Temperature          44 degrees C / 111 degrees F
  Frequency:
    Setting            125.00 MHz
    Measurement        124.95 MHz
  Power:
    3.3 V              3266 mV
    5.0 V bias         4964 mV
    8.0 V bias         8112 mV
  BUS Revision        12
PCG 1 status:
  State                Online - Standby
  Temperature          47 degrees C / 116 degrees F
  Frequency:
    Setting            125.00 MHz
    Measurement        124.96 MHz
  Power:
    3.3 V              3271 mV
    5.0 V bias         4979 mV
    8.0 V bias         8117 mV
  BUS Revision        12

show chassis environment pcg (M160 Router) user@host> show chassis environment pcg
PCG 0 status:
  State                Online - Master clock
  Temperature          41 degrees C / 105 degrees F
  Frequency:
    Setting            125.00 MHz
    Measurement        125.03 MHz
  Power:
    3.3 V              3286 mV
    5.0 V bias         5010 mV
    8.0 V bias         8183 mV
  BUS Revision        12
PCG 1 status:
  State                Online - Standby
  Temperature          43 degrees C / 109 degrees F
  Frequency:
    Setting            125.00 MHz
    Measurement        125.01 MHz
  Power:
    3.3 V              3288 mV
    5.0 V bias         4993 mV
    8.0 V bias         8197 mV
  BUS Revision        12

```

show chassis environment pem

Syntax	show chassis environment pem <slot>
Syntax (TX Matrix Routers)	show chassis environment pem <lcc <i>number</i> scc> <slot>
Syntax (TX Matrix Plus Routers)	show chassis environment pem <lcc <i>number</i> sfc <i>number</i> > <slot>
Syntax (MX Series Router)	show chassis environment pem <slot> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M120, M160, M320, MX Series, and T Series routers only) Display Power Entry Module (PEM) environmental status information.



NOTE: The new high-capacity (4100W) enhanced DC PEM on MX960 routers includes a new design that can condition the input voltage. This results in the output voltage differing from the input voltage. The earlier generation of DC PEMs coupled the input power directly to the output, thereby making it safe to assume that the output voltage was equal to the input voltage.

- Options** none—Display environmental information about both PEMs. For the TX Matrix router, display environmental information about the PEMs, the TX Matrix router, and its attached T640 routers. For the TX Matrix Plus router, display environmental information about the PEMs, the TX Matrix Plus router, and its attached T1600 routers.
- all-members—(MX Series routers only) (Optional) Display environmental information about the PEMs in all the member routers of the Virtual Chassis configuration.
- lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display environmental information about the PEM in a specified T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display environmental information about the PEM in a specified T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.
- local—(MX Series routers only) (Optional) Display environmental information about the PEM in the local Virtual Chassis member.

member member-id—(MX Series routers only) (Optional) Display environmental information about the PEM in the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display environmental information about the PEM in the TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus routers only) (Optional) Display environmental information about the PEM in the TX Matrix Plus router (or switch-fabric chassis).

slot —(Optional) Display environmental information about an individual PEM. Replace *slot* with 0 or 1.

Required Privilege Level view

List of Sample Output

show chassis environment pem (M40e Router) on page 270
 show chassis environment pem (M120 Router) on page 270
 show chassis environment pem (M160 Router) on page 270
 show chassis environment pem (M320 Router) on page 271
 show chassis environment pem (MX240 Router) on page 271
 show chassis environment pem (MX480 Router) on page 271
 show chassis environment pem (MX960 Router) on page 271
 show chassis environment pem (T320 Router) on page 271
 show chassis environment pem (T640 Router) on page 272
 show chassis environment pem lcc (TX Matrix Routing Matrix) on page 272
 show chassis environment pem scc (TX Matrix Routing Matrix) on page 272
 show chassis environment pem sfc (TX Matrix Plus Routing Matrix) on page 272
 show chassis environment pem lcc (TX Matrix Plus Routing Matrix) on page 273

Output Fields Table 56 on page 269 lists the output fields for the **show chassis environment pem** command. Output fields are listed in the approximate order in which they appear.

Table 56: show chassis environment pem Output Fields

Field Name	Field Description
PEM <i>slot</i> status	Number of the PEM slot.
State	Status of the PEM.
Temperature	Temperature of the air flowing past the PEM.
AC Input	Status of the AC input for the specified component
AC Output	Status of the AC output for the specified component.
DC input	Status of the DC input for the specified component.
DC output	Status of the DC output for the specified component.

Table 56: show chassis environment pem Output Fields (*continued*)

Field Name	Field Description
Load	(Not available on M40e or M160 routers) Information about the load on supply, in percentage of rated current being used.
Voltage	(M120, M160, M320, T640, T1600, TX Matrix, and TX Matrix Plus routers only) Information about voltage supplied to the PEM.
Current	(T640, T1600, TX Matrix, and TX Matrix Plus routers only) Information about the PEM current.
Power	(T640, T1600, TX Matrix, and TX Matrix Plus routers only) Information about the PEM power.
SCG/CB/SIB	(T640, T1600, TX Matrix, and TX Matrix Plus routers only) SONET Clock Generator/Control Board/Switch Interface Board.

Sample Output

```

show chassis environment pem (M40e Router) user@host> show chassis environment pem
PEM 0 status:
  State                Online
  Temperature          OK
  AC input             OK
  DC output            OK

show chassis environment pem (M120 Router) user@host> show chassis environment pem
PEM 0 status:
  State                Online
  Temperature          OK
  DC Input:            OK
  DC Output:           OK
  Load                Less than 20 percent
  Voltage:
    48.0 V input       52864 mV
    48.0 V fan supply  41655 mV
    3.3 V              3399 mV
  PEM 1 status:
    State                Online
    Temperature          OK
    DC Input:            OK
    DC Output:           OK
    Load                Less than 20 percent
    Voltage:
      48.0 V input       54537 mV
      48.0 V fan supply  42910 mV
      3.3 V              3506 mV

show chassis environment pem (M160 Router) user@host> show chassis environment pem
PEM 0 status:
  State                Online
  Temperature          OK
  DC input             OK
  DC output            OK
  Load                Less than 20 percent
  Voltage:
    48.0 V input       54833 mV

```

```

48.0 V fan supply      50549 mV
8.0 V bias              8239 mV
5.0 V bias              5006 mV

```

**show chassis
environment pem
(M320 Router)**

```

user@host> show chassis environment pem
PEM 2 status:
  State                Online
  Temperature           OK
  DC input              OK
  Load                 Less than 40 percent
    48.0 V input        51853 mV
    48.0 V fan supply   48877 mV
    8.0 V bias          8449 mV
    5.0 V bias          4998 mV
PEM 3 status:
  State                Online
  Temperature           OK
  DC input              OK
  Load                 Less than 40 percent
    48.0 V input        51717 mV
    48.0 V fan supply   49076 mV
    8.0 V bias          8442 mV
    5.0 V bias          4998 mV

```

**show chassis
environment pem
(MX240 Router)**

```

user@host> show chassis environment pem
PEM 0 status:
  State                Online
  Temperature           OK
  DC Output:           OK
PEM 1 status:
  State                Online
  Temperature           OK
  DC Output:           OK

```

**show chassis
environment pem
(MX480 Router)**

```

user@host> show chassis environment pem
PEM 0 status:
  State                Online
  Temperature           OK
  DC Input:            OK
  DC Output:           OK
  Voltage:
PEM 1 status:
  State                Online
  Temperature           OK
  DC Input:            OK
  DC Output:           OK
  Voltage:

```

**show chassis
environment pem
(MX960 Router)**

```

user@host> show chassis environment pem
PEM 2 status:
  State                Present
PEM 3 status:
  State                Online
  Temperature           OK
  DC Output:           OK

```

**show chassis
environment pem
(T320 Router)**

```

user@host> show chassis environment pem
PEM 0 status:
  State                Online

```

```

Temperature          OK
DC input:            OK

show chassis environment pem (T640 Router)
user@host> show chassis environment pem
PEM 0 status:
State                Online
Temperature          22 degrees C / 71 degrees F
AC input: OK
DC output:
Voltage      Current      Power      Load
FPC 0        56875        606         34         4
FPC 1        57016        525         29         3
FPC 2         0         0           0          0
FPC 3         0         0           0          0
FPC 4         0         0           0          0
FPC 5         0         0           0          0
FPC 6        57158       1581         90        12
FPC 7         0         0           0          0
SCG/CB/SIB    56750       1125         63         5

show chassis environment pem lcc (TX Matrix Routing Matrix)
user@host> show chassis environment pem 0 lcc 0
lcc0-re0:
-----
PEM 0 status:
State                Present
Temperature          27 degrees C / 80 degrees F
DC input:            Check
DC output:
Voltage      Current      Power      Load
FPC 0         0         0           0          0
FPC 1         0         0           0          0
FPC 2         0         0           0          0
FPC 3         0         0           0          0
FPC 4         0         0           0          0
FPC 5         0         0           0          0
FPC 6         0         0           0          0
FPC 7         0         0           0          0
SCG/CB/SIB     0         0           0          0

show chassis environment pem scc (TX Matrix Routing Matrix)
user@host> show chassis environment pem scc
scc-re0:
-----
PEM 1 status:
State                Online
Temperature          24 degrees C / 75 degrees F
DC input:            OK
DC output:
Voltage      Current      Power      Load
SIB 0         0         0           0          0
SIB 1         0         0           0          0
SIB 2         0         0           0          0
SIB 3        56550         0           0          0
SIB 4        55958       6912        386        51

show chassis environment pem sfc (TX Matrix Plus Routing Matrix)
user@host> show chassis environment pem sfc 0
sfc0-re0:
-----
PEM 0 status:
State                Online
Temperature          35 degrees C / 95 degrees F
DC Input:            OK
DC Output
Channel 0          Voltage      Current      Power      Load
                  53820       14140        761        59

```


Channel 1	53550	12720	681	53
Channel 2	53840	12930	696	54
Channel 3	53690	14990	804	63
Channel 4	53620	15070	808	63
Channel 5	53900	14820	798	62
Channel 6	54120	5020	271	21

show chassis environment pem lcc
(TX Matrix Plus Routing Matrix)

user@host> show chassis environment lcc 0

lcc0-re1:

PEM 0 status:

State	Online			
Temperature	38 degrees C / 100 degrees F			
DC Input:	OK			
DC Output	Voltage	Current	Power	Load
FPC 0	0	0	0	0
FPC 1	0	0	0	0
FPC 2	0	0	0	0
FPC 3	0	0	0	0
FPC 4	56408	7575	427	56
FPC 5	0	0	0	0
FPC 6	56266	7956	447	59
FPC 7	56283	6100	343	45
SCG/CB/SIB	55916	8950	500	41

PEM 1 status:

State	Present			
Temperature	35 degrees C / 95 degrees F			
DC Input:	Check			
DC Output	Voltage	Current	Power	Load
FPC 0	0	0	0	0
FPC 1	0	0	0	0
FPC 2	0	0	0	0
FPC 3	0	0	0	0
FPC 4	0	0	0	0
FPC 5	0	0	0	0
FPC 6	0	0	0	0
FPC 7	0	0	0	0
SCG/CB/SIB	0	0	0	0

show chassis environment routing-engine

Syntax	show chassis environment routing-engine <slot>
Syntax (TX Matrix Routers)	show chassis environment routing-engine <lcc <i>number</i> scc> <slot>
Syntax (TX Matrix Plus Routers)	show chassis environment routing-engine <lcc <i>number</i> sfc <i>number</i> > <slot>
Syntax (MX Series Routers)	show chassis environment routing-engine <slot> <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show chassis environment routing-engine
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display Routing Engine environmental status information.
Options	<p>none—Display environmental information about all Routing Engines. For a TX Matrix router, display environmental information about all Routing Engines on the TX Matrix router and its attached T640 routers. For a TX Matrix Plus router, display environmental information about all Routing Engines on the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display environmental information about the Routing Engines in all member routers in the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix routers only) (Optional) On a TX Matrix router, display environmental information about the Routing Engine in a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display environmental information about the Routing Engine in a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display environmental information about the Routing Engines in the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display environmental information about the Routing Engines in the specified member in the Virtual Chassis configuration. Replace <i>member-id</i> with the value of 0 or 1.</p>

scc—(TX Matrix router only) (Optional) Display environmental information about the Routing Engine in the TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus router only) (Optional) Display environmental information about the Routing Engine in the TX Matrix Plus router (or switch-fabric chassis).

slot—(Optional) Display environmental information about an individual Routing Engine. On M10i, M20, M40e, M120, M160, M320, MX Series, and T Series routers, replace **slot** with **0** or **1**. On M5, M7i, M10, and M40 routers and on the J Series router, replace **slot** with **0**. On EX3200 and EX4200 standalone switches, replace **slot** with **0**. On EX4200 switches in a Virtual Chassis configuration and on EX8208 and EX8216 switches, replace **slot** with **0** or **1**. On the QFX3500 switch, there is only one Routing Engine so you do not need to specify the slot number.

Required Privilege Level view

List of Sample Output **show chassis environment routing-engine (Nonredundant)** on page 275
show chassis environment routing-engine (Redundant) on page 275
show chassis environment routing-engine (TX Matrix Plus Router) on page 276
show chassis environment routing-engine (QFX Series) on page 276

Output Fields Table 57 on page 275 lists the output fields for the **show chassis environment routing-engine** command. Output fields are listed in the approximate order in which they appear.

Table 57: show chassis environment routing-engine Output Fields

Field Name	Field Description
Routing engine slot status	Number of the Routing Engine slot: 0 or 1 .
State	Status of the Routing Engine: <ul style="list-style-type: none"> • Online Master—MCS is online, operating as Master. • Online Standby—MCS is online, operating as Standby.
Temperature	Temperature of the air flowing past the Routing Engine.

Sample Output

```

show chassis environment routing-engine (Nonredundant) user@host> show chassis environment routing-engine
Routing Engine 0 status:
  State          Online Master
  Temperature    27 degrees C / 80 degrees

show chassis environment routing-engine (Redundant) user@host> show chassis environment routing-engine
Route Engine 0 status:
  State          Online Master
  Temperature    26 degrees C / 78 degrees F
Route Engine 1 status:
  State          Online Standby
  Temperature    26 degrees C / 78 degrees F

```

**show chassis
environment
routing-engine (TX
Matrix Plus Router)**

user@host> show chassis environment routing-engine
sfc0-re0:

```
-----
Routing Engine 0 status:
  State           Online Master
  Temperature      26 degrees C / 78 degrees F
Routing Engine 1 status:
  State           Online Standby
  Temperature      28 degrees C / 82 degrees F
```

1cc0-re0:

```
-----
Routing Engine 0 status:
  State           Online Master
  Temperature      30 degrees C / 86 degrees F
Routing Engine 1 status:
  State           Online Standby
  Temperature      29 degrees C / 84 degrees F
```

**show chassis
environment
routing-engine (QFX
Series)**

user@switch> show chassis environment routing-engine

```
Routing Engine 0 status:
  State           Online Master
  Temperature      42 degrees C / 107 degrees F
```

show chassis environment scg

Syntax	show chassis environment scg <slot>
Syntax (TX Matrix and TX Matrix Plus Router)	show chassis environment scg <lcc number> <slot>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display SONET Clock Generator (SCG) environmental information.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) Display environmental information about all SCGs. On a TX Matrix router, display environmental information about all SCGs on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display environmental information about all SCGs on the TX Matrix Plus router and its attached T1600 routers.</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display environmental information about the SCG in a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display environmental information about the SCG in a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>slot—(Optional) Display environmental information about the SCG. Replace <i>slot</i> with 0 or 1.</p>
Required Privilege Level	view
List of Sample Output	<p>show chassis environment scg (T Series Routers) on page 278</p> <p>show chassis environment scg lcc (TX Matrix Router) on page 278</p> <p>show chassis environment scg lcc (TX Matrix Plus Router) on page 279</p> <p>show chassis environment scg (TX Matrix Plus Router) on page 279</p>
Output Fields	Table 58 on page 277 lists the output fields for the show chassis environment scg command. Output fields are listed in the approximate order in which they appear.

Table 58: show chassis environment scg Output Fields

Field Name	Field Description
SCG slot status	Number of the SCG slot: 0 or 1.

Table 58: show chassis environment scg Output Fields (*continued*)

Field Name	Field Description
State	Status of the SCG: <ul style="list-style-type: none"> • Online—SCG is online and running. • Offline—SCG is powered down. <p>If two SCGs are installed and online, one is functioning as the master, and the other is the standby.</p>
Temperature	Temperature of the air flowing past the SCG.
Power	Power on the SCG. The left column displays required power, in volts. The right column displays measured power, in millivolts.
BUS Revision	Revision level of the generic bus device.

Sample Output

**show chassis
environment scg (T
Series Routers)**

```

user@host> show chassis environment scg
SCG 0 status:
  State                Online - Master clock
  Temperature          29 degrees C / 84 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3297 mV
    5.0 V               5050 mV
    5.6 V               5682 mV
    1.8 V bias          1787 mV
    3.3 V bias          3277 mV
    5.0 V bias          4984 mV
    8.0 V bias          8400 mV
  BUS Revision         40
SCG 1 status:
  State                Online - Standby
  Temperature          28 degrees C / 82 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3317 mV
    5.0 V               5057 mV
    5.6 V               5689 mV
    1.8 V bias          1794 mV
    3.3 V bias          3296 mV
    5.0 V bias          4991 mV
    8.0 V bias          8410 mV
  BUS Revision         40

```

**show chassis
environment scg lcc
(TX Matrix Router)**

```

user@host> show chassis environment scg lcc 0 0
lcc0-re0:
-----
SCG 0 status:
  State                Online - Master clock
  Temperature          30 degrees C / 86 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3321 mV

```

5.0 V	5062 mV
5.6 V	5682 mV
1.8 V bias	1789 mV
3.3 V bias	3289 mV
5.0 V bias	4993 mV
8.0 V bias	7807 mV
BUS Revision	40

show chassis environment scg lcc
(TX Matrix Plus Router)

```
user@host> show chassis environment scg lcc 0
lcc0-re0:
```

```
-----
SCG 0 status:
State          Online - Master clock
Temperature    42 degrees C / 107 degrees F
Power
  GROUND              0 mV
  1.8 V bias         1800 mV
  3.3 V              3290 mV
  3.3 V bias         3304 mV
  5.0 V              5042 mV
  5.0 V bias         4979 mV
  5.6 V              5765 mV
  8.0 V bias         7682 mV
Bus Revision    40
```

show chassis environment scg
(TX Matrix Plus Router)

```
user@host> show chassis environment scg
lcc0-re0:
```

```
-----
SCG 0 status:
State          Online - Master clock
Temperature    40 degrees C / 104 degrees F
Power
  GROUND              0 mV
  1.8 V bias         1800 mV
  3.3 V              3291 mV
  3.3 V bias         3304 mV
  5.0 V              5042 mV
  5.0 V bias         4979 mV
  5.6 V              5765 mV
  8.0 V bias         7643 mV
Bus Revision    40
```

```
lcc1-re0:
```

```
-----
SCG 0 status:
State          Online - Master clock
Temperature    37 degrees C / 98 degrees F
Power
  GROUND              0 mV
  1.8 V bias         1788 mV
  3.3 V              3305 mV
  3.3 V bias         3284 mV
  5.0 V              5042 mV
  5.0 V bias         5010 mV
  5.6 V              5748 mV
  8.0 V bias         7692 mV
Bus Revision    40
```

```
lcc2-re0:
```

```
-----
SCG 0 status:
```

State	Online - Master clock
Temperature	39 degrees C / 102 degrees F
Power	
GROUND	0 mV
1.8 V bias	1785 mV
3.3 V	3306 mV
3.3 V bias	3301 mV
5.0 V	5045 mV
5.0 V bias	4993 mV
5.6 V	5765 mV
8.0 V bias	7838 mV
Bus Revision	40

1cc3-re0:

SCG 0 status:

State	Online - Master clock
Temperature	39 degrees C / 102 degrees F
Power	
GROUND	0 mV
1.8 V bias	1800 mV
3.3 V	3290 mV
3.3 V bias	3294 mV
5.0 V	5050 mV
5.0 V bias	4984 mV
5.6 V	5780 mV
8.0 V bias	7716 mV
Bus Revision	40

show chassis environment sfm

Syntax	show chassis environment sfm <slot>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Display Switching and Forwarding Module (SFM) environmental information.
Options	none—Display environmental information about all SFMs. slot—(Optional) Display environmental information about an individual SFM. Replace <i>slot</i> with a value from 0 through 3.
Required Privilege Level	view
List of Sample Output	show chassis environment sfm (M40e Router) on page 282 show chassis environment sfm (M160 Router) on page 282
Output Fields	Table 59 on page 281 lists the output fields for the show chassis environment sfm command. Output fields are listed in the approximate order in which they appear.

Table 59: show chassis environment sfm Output Fields

Field Name	Field Description
SFM slot status	SFM slot number: 0 or 1 on an M40e router, or 0, 1, 2, or 3 on an M160 router.
State	Status of the SFM: <ul style="list-style-type: none"> • Online—SFM is online and running. • Offline—SFM is powered down. <p>If two SFMs are installed and online, one is functioning as the master, and the other is marked as the Standby.</p>
SPP Temperature	Temperature of the air flowing past the Switch Plane Processor card.
SPR Temperature	Temperature of the air flowing past the Switch Plane Router card.
SPP Power	Information about the voltage supplied to the Switch Plane Processor card. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
SPR Power	Information about the voltage supplied to the Switch Plane Router. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.
CMB Revision	Revision level of the Chassis Management Bus (CMB) device.

Sample Output

```

show chassis environment sfm
(M40e Router)
user@host> show chassis environment sfm
SFM 0 status:
  State Online
  SPP temperature 40 degrees C / 104 degrees F
  SPR temperature 44 degrees C / 111 degrees F
  SPP Power:
    1.5 V 1501 mV
    2.5 V 2472 mV
    3.3 V 3293 mV
    5.0 V 5028 mV
    5.0 V bias 4964 mV
  SPR Power:
    1.5 V 1501 mV
    2.5 V 2483 mV
    3.3 V 3308 mV
    5.0 V 5035 mV
    5.0 V bias 4981 mV
    8.0 V bias 8239 mV
  CMB Revision 12
SFM 1 status:
  State Online - Standby
  SPP temperature 43 degrees C / 109 degrees F
  SPR temperature 45 degrees C / 113 degrees F
  SPP Power:
    1.5 V 1503 mV
    2.5 V 2483 mV
    3.3 V 3284 mV
    5.0 V 5045 mV
    5.0 V bias 4993 mV
  SPR Power:
    1.5 V 1498 mV
    2.5 V 2472 mV
    3.3 V 3284 mV
    5.0 V 5035 mV
    5.0 V bias 4991 mV
    8.0 V bias 8231 mV
  CMB Revision 12

show chassis environment sfm
(M160 Router)
user@host> show chassis environment sfm
SFM 0 status:
  State Online
  SPP temperature 43 degrees C / 109 degrees F
  SPR temperature 44 degrees C / 111 degrees F
  SPP Power:
    1.5 V 1504 mV
    2.5 V 2474 mV
    3.3 V 3290 mV
    5.0 V 5015 mV
    5.0 V bias 4962 mV
  SPR Power:
    1.5 V 1498 mV
    2.5 V 2482 mV
    3.3 V 3299 mV
    5.0 V 5020 mV
    5.0 V bias 4971 mV
    8.0 V bias 8229 mV
  CMB Revision 12
SFM 1 status:

```

```

State                               Online
SPP temperature                     47 degrees C / 116 degrees F
SPR temperature                     50 degrees C / 122 degrees F
SPP Power:
  1.5 V                             1499 mV
  2.5 V                             2466 mV
  3.3 V                             3274 mV
  5.0 V                             5025 mV
  5.0 V bias                         4984 mV
SPR Power:
  1.5 V                             1496 mV
  2.5 V                             2470 mV
  3.3 V                             3279 mV
  5.0 V                             5020 mV
  5.0 V bias                         4993 mV
  8.0 V bias                         8222 mV
CMB Revision                         12
SFM 2 status:
State                               Online
SPP temperature                     50 degrees C / 122 degrees F
SPR temperature                     52 degrees C / 125 degrees F
SPP Power:
  1.5 V                             1504 mV
  2.5 V                             2471 mV
  3.3 V                             3294 mV
  5.0 V                             5045 mV
  5.0 V bias                         4981 mV
SPR Power:
  1.5 V                             1496 mV
  2.5 V                             2470 mV
  3.3 V                             3293 mV
  5.0 V                             5028 mV
  5.0 V bias                         4971 mV
  8.0 V bias                         8214 mV
CMB Revision                         12
SFM 3 status:
State                               Online
SPP temperature                     49 degrees C / 120 degrees F
SPR temperature                     48 degrees C / 118 degrees F
SPP Power:
  1.5 V                             1505 mV
  2.5 V                             2484 mV
  3.3 V                             3296 mV
  5.0 V                             5040 mV
  5.0 V bias                         4984 mV
SPR Power:
  1.5 V                             1503 mV
  2.5 V                             2488 mV
  3.3 V                             3302 mV
  5.0 V                             5037 mV
  5.0 V bias                         4993 mV
  8.0 V bias                         8249 mV
CMB Revision                         12

```

show chassis environment sib

Syntax	show chassis environment sib <slot>
Syntax (TX Matrix Router)	show chassis environment sib <lcc number scc> <slot>
Syntax (TX Matrix Plus Router)	show chassis environment sib <lcc number sfc number> <slot> <f13 sib-slot> <f2s sib-slot/sib-f2s-slot-number>
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(M320, T Series routers, TX Matrix and TX Matrix Plus only) Display Switch Interface Boards (SIB) environmental information.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) Display environmental information about all SIBs. On a TX Matrix router, display environmental information about all SIBs on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display environmental information about all SIBs on the TX Matrix Plus router and its attached T1600 routers.</p> <p>f13 sib-slot—(TX Matrix Plus routers only) (Optional) Display SIB F13 environmental information only. Replace sib-slot with one of the following values: 0, 1, 3, 4, 6, 7, 8, 9, 11, or 12.</p> <p>f2s sib-slot/sib-f2s-slot-number—(TX Matrix Plus routers only) (Optional) Display SIB F2s environmental information only. Replace sib-slot with a value from 0 through 4, followed by a sib-f2s-slot-number value of 0, 2, 4 or 6.</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display environmental information about the SIB in a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display environmental information about the SIB in a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace number with a value from 0 through 4.</p> <p>scc—(TX Matrix routers only) (Optional) Display environmental information about the SIB in the TX Matrix router (or switch-card chassis).</p> <p>sfc—(TX Matrix Plus routers only) (Optional) Display environmental information about the SIB in the TX Matrix Plus router (or switch-fabric chassis).</p> <p>slot—(Optional) Display environmental information about the specified SIB. For the M320 router, replace slot with a value from 0 through 3. For the T640, T1600, and TX Matrix routers, replace slot with a value from 0 through 4. For the TX Matrix Plus router,</p>

replace **slot** with a value from 0 through 15. For the T320 router, replace **slot** with a value from 0 through 2.

Required Privilege Level view

List of Sample Output `show chassis environment sib` (M320 Router) on page 285
`show chassis environment sib 1` (T640 Router) on page 286
`show chassis environment sib scc` (TX Matrix Router) on page 287
`show chassis environment sib` (TX Matrix Plus Router) on page 287
`show chassis environment sib sfc` (TX Matrix Plus Router) on page 297
`show chassis environment sib f13` (TX Matrix Plus Router) on page 302
`show chassis environment sib f2s` (TX Matrix Plus Router) on page 303

Output Fields Table 60 on page 285 lists the output fields for the `show chassis environment sib` command. Output fields are listed in the approximate order in which they appear.

Table 60: show chassis environment sib Output Fields

Field Name	Field Description
SIB slot status	<p>SIB slot number:</p> <ul style="list-style-type: none"> 0 through 3 on an M320 router. 0 or 2 on a T320 router. 0 through 4 on a T640 or T1600 router. 0 through 15 on a TX Matrix or TX Matrix Plus router. 0, 1, 3, 4, 6, 7, 8, 9, 11, or 12 for F13 SIBs on a TX Matrix Plus router. 0 through 4, followed by 0, 2, 4, or 6 for an F2S SIB on a TX Matrix Plus router. For example, SIB F2S 0/4.
State	<p>Status of the SIB:</p> <ul style="list-style-type: none"> Online—SIB is online and running. Offline—SIB is powered down. Spare (T640 router only)—SIB is redundant and will move to active state if one of the working SIBs fails. <p>Only four of the five T640 router SIBs are active at any time. The fifth one is marked Spare. It is activated if there is a fault on one of the active SIBs.</p>
Temperature	Temperature of the air flowing past the SIB.
Power	Information about the voltage supplied to the SIB. The left column displays the required power, in volts. The right column displays the measured power, in millivolts.

Sample Output

```

show chassis environment sib (M320 Router)
user@host> show chassis environment sib
SIB 0 status:
  State           Online
  Temperature     34 degrees C / 93 degrees F
  Power:
    GROUND         0 mV

```

```

1.8 V          1805 mV
2.5 V          2498 mV
3.3 V          3306 mV
1.8 V bias     1789 mV
3.3 V bias     3299 mV
5.0 V bias     5003 mV
8.0 V bias     7374 mV
SIB 1 status:
State          Online
Temperature    35 degrees C / 95 degrees F
Power:
GROUND        0 mV
1.8 V         1814 mV
2.5 V         2477 mV
3.3 V         3319 mV
1.8 V bias    1792 mV
3.3 V bias    3291 mV
5.0 V bias    4981 mV
8.0 V bias    7335 mV
SIB 2 status:
State          Online
Temperature    33 degrees C / 91 degrees F
Power:
GROUND        0 mV
1.8 V         1811 mV
2.5 V         2489 mV
3.3 V         3330 mV
1.8 V bias    1797 mV
3.3 V bias    3304 mV
5.0 V bias    5025 mV
8.0 V bias    7330 mV
SIB 3 status:
State          Online
Temperature    37 degrees C / 98 degrees F
Power:
GROUND        0 mV
1.8 V         1798 mV
2.5 V         2481 mV
3.3 V         3328 mV
1.8 V bias    1792 mV
3.3 V bias    3313 mV
5.0 V bias    5013 mV
8.0 V bias    7467 mV

```

```

show chassis environment sib 1
(T640 Router)
user@host> show chassis environment sib 1
SIB 1 status:
State          Online
Temperature    39 degrees C / 102 degrees F
Power:
GROUND        0 mV
1.8 V         1809 mV
2.5 V         2478 mV
3.3 V         3308 mV
1.8 V bias    1794 mV
3.3 V bias    3274 mV
5.0 V bias    4996 mV
8.0 V bias    7247 mV

```

```

show chassis environment sib scc
(TX Matrix Router)
user@host> show chassis environment sib scc
scc-re0:
-----
SIB 3 status:
State                Offline
Reason               Offlined by button press
Temperature           0 degrees C / 32 degrees F
Power:
  GROUND              0 mV
  1.8 V               0 mV
  2.5 V               0 mV
  3.3 V               0 mV
  1.8 V bias          0 mV
  3.3 V bias          0 mV
  5.0 V bias          0 mV
  8.0 V bias          0 mV
SIB 4 status:
State                Online
Temperature           42 degrees C / 107 degrees F
Temperature (B)       41 degrees C / 105 degrees F
Power:
  GROUND              0 mV
  1.8 V               1787 mV
  2.5 V               2488 mV
  3.3 V               3294 mV
  1.8 V bias          1787 mV
  3.3 V bias          3306 mV
  5.0 V bias          5010 mV
  8.0 V bias          7418 mV
Power (B):
  GROUND              0 mV
  1.8 V               1785 mV
  2.5 V               2485 mV
  3.3 V               3289 mV
  1.8 V bias          1799 mV
  3.3 V bias          3284 mV
  5.0 V bias          4979 mV
  8.0 V bias          7882 mV

```

```

show chassis environment sib
(TX Matrix Plus Router)
user@host> show chassis environment sib
sfc0-re0:
-----
SIB F13 0 status:
State                Online - Standby
Temperature           54 degrees C / 129 degrees F
Temperature (B)       50 degrees C / 122 degrees F
Power
  1.2 V_0             1205 mV
  1.2 V_1             1202 mV
  1.2 V_2             1205 mV
  1.2 V_3             1208 mV
  1.5 V_0             1501 mV
  1.5 V_1             1508 mV
  1.8 V               1798 mV
  2.5 V               2510 mV
  3.3 V               3312 mV
  9.0 V               8991 mV
  9.0 V bias          0 mV
Power (B)
  2.5 V               2510 mV
  3.3 V               3318 mV

```

```

9.0 V                                9024 mV
SIB F13 1 status:
State                                Online - Standby
Temperature                          45 degrees C / 113 degrees F
Temperature (B)                      42 degrees C / 107 degrees F
Power
  1.2 V_0                            1202 mV
  1.2 V_1                            1198 mV
  1.2 V_2                            1202 mV
  1.2 V_3                            1202 mV
  1.5 V_0                            1498 mV
  1.5 V_1                            1501 mV
  1.8 V                              1811 mV
  2.5 V                              2504 mV
  3.3 V                              3292 mV
  9.0 V                              8991 mV
  9.0 V bias                          0 mV
Power (B)
  2.5 V                              2507 mV
  3.3 V                              3306 mV
  9.0 V                              8970 mV
SIB F13 3 status:
State                                Online
Temperature                          48 degrees C / 118 degrees F
Temperature (B)                      44 degrees C / 111 degrees F
Power
  1.2 V_0                            1205 mV
  1.2 V_1                            1202 mV
  1.2 V_2                            1202 mV
  1.2 V_3                            1202 mV
  1.5 V_0                            1508 mV
  1.5 V_1                            1504 mV
  1.8 V                              1798 mV
  2.5 V                              2520 mV
  3.3 V                              3300 mV
  9.0 V                              9009 mV
  9.0 V bias                          0 mV
Power (B)
  2.5 V                              2504 mV
  3.3 V                              3312 mV
  9.0 V                              9006 mV
SIB F13 4 status:
State                                Online
Temperature                          44 degrees C / 111 degrees F
Temperature (B)                      40 degrees C / 104 degrees F
Power
  1.2 V_0                            1205 mV
  1.2 V_1                            1205 mV
  1.2 V_2                            1202 mV
  1.2 V_3                            1205 mV
  1.5 V_0                            1508 mV
  1.5 V_1                            1508 mV
  1.8 V                              1811 mV
  2.5 V                              2510 mV
  3.3 V                              3312 mV
  9.0 V                              8970 mV
  9.0 V bias                          0 mV
Power (B)
  2.5 V                              2513 mV
  3.3 V                              3318 mV
  9.0 V                              9048 mV

```



```

SIB F13 6 status:
State                               Online
Temperature                         50 degrees C / 122 degrees F
Temperature (B)                     46 degrees C / 114 degrees F
Power
  1.2 V_0                           1195 mV
  1.2 V_1                           1205 mV
  1.2 V_2                           1202 mV
  1.2 V_3                           1202 mV
  1.5 V_0                           1495 mV
  1.5 V_1                           1495 mV
  1.8 V                             1801 mV
  2.5 V                             2494 mV
  3.3 V                             3300 mV
  9.0 V                             8991 mV
  9.0 V bias                         0 mV
Power (B)
  2.5 V                             2500 mV
  3.3 V                             3300 mV
  9.0 V                             9006 mV
SIB F13 7 status:
State                               Online
Temperature                         52 degrees C / 125 degrees F
Temperature (B)                     49 degrees C / 120 degrees F
Power
  1.2 V_0                           1202 mV
  1.2 V_1                           1202 mV
  1.2 V_2                           1198 mV
  1.2 V_3                           1185 mV
  1.5 V_0                           1501 mV
  1.5 V_1                           1492 mV
  1.8 V                             1795 mV
  2.5 V                             2491 mV
  3.3 V                             3286 mV
  9.0 V                             8892 mV
  9.0 V bias                         0 mV
Power (B)
  2.5 V                             2507 mV
  3.3 V                             3306 mV
  9.0 V                             8952 mV
SIB F13 8 status:
State                               Online
Temperature                         55 degrees C / 131 degrees F
Temperature (B)                     50 degrees C / 122 degrees F
Power
  1.2 V_0                           1208 mV
  1.2 V_1                           1205 mV
  1.2 V_2                           1205 mV
  1.2 V_3                           1211 mV
  1.5 V_0                           1514 mV
  1.5 V_1                           1508 mV
  1.8 V                             1807 mV
  2.5 V                             2516 mV
  3.3 V                             3324 mV
  9.0 V                             9027 mV
  9.0 V bias                         0 mV
Power (B)
  2.5 V                             2520 mV
  3.3 V                             3318 mV
  9.0 V                             9066 mV
SIB F13 9 status:

```

```

State
Temperature
Temperature (B)
Power
  1.2 V_0      1208 mV
  1.2 V_1      1202 mV
  1.2 V_2      1208 mV
  1.2 V_3      1202 mV
  1.5 V_0      1504 mV
  1.5 V_1      1504 mV
  1.8 V        1817 mV
  2.5 V        2516 mV
  3.3 V        3312 mV
  9.0 V        9009 mV
  9.0 V bias   0 mV
Power (B)
  2.5 V        2510 mV
  3.3 V        3312 mV
  9.0 V        9024 mV
SIB F13 11 status:
State
Temperature
Temperature (B)
Power
  1.2 V_0      1202 mV
  1.2 V_1      1205 mV
  1.2 V_2      1202 mV
  1.2 V_3      1202 mV
  1.5 V_0      1501 mV
  1.5 V_1      1501 mV
  1.8 V        1801 mV
  2.5 V        2510 mV
  3.3 V        3312 mV
  9.0 V        8979 mV
  9.0 V bias   0 mV
Power (B)
  2.5 V        2252 mV
  3.3 V        5014 mV
  9.0 V        9954 mV
SIB F13 12 status:
State
Temperature
Temperature (B)
Power
  1.2 V_0      1211 mV
  1.2 V_1      1208 mV
  1.2 V_2      1205 mV
  1.2 V_3      1205 mV
  1.5 V_0      1511 mV
  1.5 V_1      1501 mV
  1.8 V        1817 mV
  2.5 V        2504 mV
  3.3 V        3318 mV
  9.0 V        9027 mV
  9.0 V bias   0 mV
Power (B)
  2.5 V        2520 mV
  3.3 V        3338 mV
  9.0 V        9006 mV
SIB F2S 0/0 status:
State
Online - Standby

```

```

Temperature                                40 degrees C / 104 degrees F
Power
  1.2 V_1                                0 mV
  1.2 V_ASF                             1198 mV
  1.2 V_ASF_B                           1198 mV
  1.2 V_ASF_D                           1202 mV
  1.5 V                                 1498 mV
  1.8 V                                 1814 mV
  3.3 V                                 3300 mV
  3.3 V bias                            3300 mV
  3.3 V ASF                             3286 mV
  9.0 V                                 8250 mV
SIB F2S 0/2 status:
State                                     Online - Standby
Temperature                             40 degrees C / 104 degrees F
Power
  1.2 V_1                                0 mV
  1.2 V_ASF                             1198 mV
  1.2 V_ASF_B                           1195 mV
  1.2 V_ASF_D                           1202 mV
  1.5 V                                 1498 mV
  1.8 V                                 1807 mV
  3.3 V                                 3300 mV
  3.3 V bias                            3300 mV
  3.3 V ASF                             3286 mV
  9.0 V                                 8250 mV
SIB F2S 0/4 status:
State                                     Online - Standby
Temperature                             40 degrees C / 104 degrees F
Power
  1.2 V_1                                0 mV
  1.2 V_ASF                             1202 mV
  1.2 V_ASF_B                           1198 mV
  1.2 V_ASF_D                           1202 mV
  1.5 V                                 1504 mV
  1.8 V                                 1817 mV
  3.3 V                                 3300 mV
  3.3 V bias                            3300 mV
  3.3 V ASF                             3306 mV
  9.0 V                                 8250 mV
SIB F2S 0/6 status:
State                                     Online - Standby
Temperature                             39 degrees C / 102 degrees F
Power
  1.2 V_1                                0 mV
  1.2 V_ASF                             1202 mV
  1.2 V_ASF_B                           1198 mV
  1.2 V_ASF_D                           1202 mV
  1.5 V                                 1495 mV
  1.8 V                                 1814 mV
  3.3 V                                 3300 mV
  3.3 V bias                            3300 mV
  3.3 V ASF                             3280 mV
  9.0 V                                 8250 mV
SIB F2S 1/0 status:
State                                     Online
Temperature                             39 degrees C / 102 degrees F
Power
  1.2 V_1                                0 mV
  1.2 V_ASF                             1195 mV
  1.2 V_ASF_B                           1192 mV

```

```

1.2 V_ASF_D          1195 mV
1.5 V                1488 mV
1.8 V                1798 mV
3.3 V                3300 mV
3.3 V bias           3300 mV
3.3 V ASF            3280 mV
9.0 V                8250 mV
SIB F2S 1/2 status:
State                Online
Temperature          39 degrees C / 102 degrees F
Power
1.2 V_1              0 mV
1.2 V_ASF            1205 mV
1.2 V_ASF_B          1202 mV
1.2 V_ASF_D          1205 mV
1.5 V                1501 mV
1.8 V                1820 mV
3.3 V                3300 mV
3.3 V bias           3300 mV
3.3 V ASF            3306 mV
9.0 V                8250 mV
SIB F2S 1/4 status:
State                Online
Temperature          39 degrees C / 102 degrees F
Power
1.2 V_1              0 mV
1.2 V_ASF            1198 mV
1.2 V_ASF_B          1195 mV
1.2 V_ASF_D          1195 mV
1.5 V                1498 mV
1.8 V                1811 mV
3.3 V                3300 mV
3.3 V bias           3300 mV
3.3 V ASF            3300 mV
9.0 V                8250 mV
SIB F2S 1/6 status:
State                Online
Temperature          39 degrees C / 102 degrees F
Power
1.2 V_1              0 mV
1.2 V_ASF            1195 mV
1.2 V_ASF_B          1195 mV
1.2 V_ASF_D          1198 mV
1.5 V                1498 mV
1.8 V                1807 mV
3.3 V                3306 mV
3.3 V bias           3300 mV
3.3 V ASF            3292 mV
9.0 V                8250 mV
SIB F2S 2/0 status:
State                Online
Temperature          39 degrees C / 102 degrees F
Power
1.2 V_1              0 mV
1.2 V_ASF            1195 mV
1.2 V_ASF_B          1195 mV
1.2 V_ASF_D          1198 mV
1.5 V                1498 mV
1.8 V                1804 mV
3.3 V                3300 mV
3.3 V bias           3300 mV

```

```

3.3 V ASF          3286 mV
9.0 V              8250 mV
SIB F2S 2/2 status:
State              Online
Temperature        38 degrees C / 100 degrees F
Power
  1.2 V_1          0 mV
  1.2 V_ASF        1195 mV
  1.2 V_ASF_B      1195 mV
  1.2 V_ASF_D      1198 mV
  1.5 V            1495 mV
  1.8 V            1807 mV
  3.3 V            3300 mV
  3.3 V bias       3300 mV
  3.3 V ASF        3300 mV
  9.0 V            8250 mV
SIB F2S 2/4 status:
State              Online
Temperature        38 degrees C / 100 degrees F
Power
  1.2 V_1          0 mV
  1.2 V_ASF        1198 mV
  1.2 V_ASF_B      1195 mV
  1.2 V_ASF_D      1198 mV
  1.5 V            1501 mV
  1.8 V            1804 mV
  3.3 V            3286 mV
  3.3 V bias       3292 mV
  3.3 V ASF        3300 mV
  9.0 V            8230 mV
SIB F2S 2/6 status:
State              Online
Temperature        38 degrees C / 100 degrees F
Power
  1.2 V_1          0 mV
  1.2 V_ASF        1202 mV
  1.2 V_ASF_B      1198 mV
  1.2 V_ASF_D      1202 mV
  1.5 V            1501 mV
  1.8 V            1817 mV
  3.3 V            3300 mV
  3.3 V bias       3300 mV
  3.3 V ASF        3318 mV
  9.0 V            8250 mV
SIB F2S 3/0 status:
State              Online
Temperature        38 degrees C / 100 degrees F
Power
  1.2 V_1          0 mV
  1.2 V_ASF        1195 mV
  1.2 V_ASF_B      1195 mV
  1.2 V_ASF_D      1198 mV
  1.5 V            1501 mV
  1.8 V            1814 mV
  3.3 V            3300 mV
  3.3 V bias       3300 mV
  3.3 V ASF        3274 mV
  9.0 V            8250 mV
SIB F2S 3/2 status:
State              Online
Temperature        37 degrees C / 98 degrees F

```

```

Power
  1.2 V_1                0 mV
  1.2 V_ASF              1202 mV
  1.2 V_ASF_B            1195 mV
  1.2 V_ASF_D            1195 mV
  1.5 V                  1495 mV
  1.8 V                  1804 mV
  3.3 V                  3300 mV
  3.3 V bias              3300 mV
  3.3 V ASF               3286 mV
  9.0 V                  8250 mV
SIB F2S 3/4 status:
State                     Online
Temperature               37 degrees C / 98 degrees F
Power
  1.2 V_1                0 mV
  1.2 V_ASF              1205 mV
  1.2 V_ASF_B            1198 mV
  1.2 V_ASF_D            1202 mV
  1.5 V                  1501 mV
  1.8 V                  1811 mV
  3.3 V                  3300 mV
  3.3 V bias              3300 mV
  3.3 V ASF               3318 mV
  9.0 V                  8250 mV
SIB F2S 3/6 status:
State                     Online
Temperature               37 degrees C / 98 degrees F
Power
  1.2 V_1                0 mV
  1.2 V_ASF              1205 mV
  1.2 V_ASF_B            1202 mV
  1.2 V_ASF_D            1202 mV
  1.5 V                  1511 mV
  1.8 V                  1820 mV
  3.3 V                  3306 mV
  3.3 V bias              3306 mV
  3.3 V ASF               3318 mV
  9.0 V                  8265 mV
SIB F2S 4/0 status:
State                     Online
Temperature               36 degrees C / 96 degrees F
Power
  1.2 V_1                0 mV
  1.2 V_ASF              1198 mV
  1.2 V_ASF_B            1198 mV
  1.2 V_ASF_D            1198 mV
  1.5 V                  1501 mV
  1.8 V                  1814 mV
  3.3 V                  3292 mV
  3.3 V bias              3292 mV
  3.3 V ASF               3312 mV
  9.0 V                  8230 mV
SIB F2S 4/2 status:
State                     Online
Temperature               37 degrees C / 98 degrees F
Power
  1.2 V_1                0 mV
  1.2 V_ASF              1198 mV
  1.2 V_ASF_B            1192 mV
  1.2 V_ASF_D            1195 mV

```

```

1.5 V          1495 mV
1.8 V          1807 mV
3.3 V          3300 mV
3.3 V bias     3300 mV
3.3 V ASF      3300 mV
9.0 V          8250 mV
SIB F2S 4/4 status:
State          Online
Temperature     36 degrees C / 96 degrees F
Power
  1.2 V_1       0 mV
  1.2 V_ASF     1202 mV
  1.2 V_ASF_B   1195 mV
  1.2 V_ASF_D   1202 mV
1.5 V          1501 mV
1.8 V          1814 mV
3.3 V          3300 mV
3.3 V bias     3300 mV
3.3 V ASF      3312 mV
9.0 V          8250 mV
SIB F2S 4/6 status:
State          Online
Temperature     36 degrees C / 96 degrees F
Power
  1.2 V_1       0 mV
  1.2 V_ASF     1198 mV
  1.2 V_ASF_B   1195 mV
  1.2 V_ASF_D   1198 mV
1.5 V          1498 mV
1.8 V          1820 mV
3.3 V          3292 mV
3.3 V bias     3292 mV
3.3 V ASF      3286 mV
9.0 V          8230 mV

lcc0-re0:
-----
SIB 0 status:
State          Online - Standby
Temperature     49 degrees C / 120 degrees F
Temperature (B) 42 degrees C / 107 degrees F
Power
  1.2 V          1204 mV
  1.5 V          1484 mV
  2.5 V          2500 mV
  3.3 V          3312 mV
  3.3 V bias     3312 mV
  5.0 V bias     4956 mV
  8.0 V bias     7740 mV
  9.0 V          8880 mV
Power (B)
  1.2 V          1206 mV
  2.5 V          2500 mV
  3.3 V          3316 mV
  9.0 V          8988 mV
SIB 1 status:
State          Online
Temperature     49 degrees C / 120 degrees F
Temperature (B) 42 degrees C / 107 degrees F
Power
  1.2 V          1202 mV

```

1.5 V	1482 mV
2.5 V	2500 mV
3.3 V	3296 mV
3.3 V bias	3288 mV
5.0 V bias	4986 mV
8.0 V bias	7800 mV
9.0 V	8868 mV
Power (B)	
1.2 V	1206 mV
2.5 V	2512 mV
3.3 V	3312 mV
9.0 V	8952 mV
SIB 2 status:	
State	Online
Temperature	49 degrees C / 120 degrees F
Temperature (B)	42 degrees C / 107 degrees F
Power	
1.2 V	1202 mV
1.5 V	1480 mV
2.5 V	2476 mV
3.3 V	3292 mV
3.3 V bias	3308 mV
5.0 V bias	5010 mV
8.0 V bias	7800 mV
9.0 V	8880 mV
Power (B)	
1.2 V	1204 mV
2.5 V	2516 mV
3.3 V	3308 mV
9.0 V	8988 mV
SIB 3 status:	
State	Online
Temperature	48 degrees C / 118 degrees F
Temperature (B)	42 degrees C / 107 degrees F
Power	
1.2 V	1204 mV
1.5 V	1480 mV
2.5 V	2500 mV
3.3 V	3292 mV
3.3 V bias	3292 mV
5.0 V bias	4986 mV
8.0 V bias	7812 mV
9.0 V	8892 mV
Power (B)	
1.2 V	1198 mV
2.5 V	2512 mV
3.3 V	3308 mV
9.0 V	8892 mV
SIB 4 status:	
State	Online
Temperature	48 degrees C / 118 degrees F
Temperature (B)	42 degrees C / 107 degrees F
Power	
1.2 V	1206 mV
1.5 V	1482 mV
2.5 V	2484 mV
3.3 V	3324 mV
3.3 V bias	3340 mV
5.0 V bias	4980 mV
8.0 V bias	7764 mV
9.0 V	8784 mV


```

Power (B)
  1.2 V          1202 mV
  2.5 V          2504 mV
  3.3 V          3308 mV
  9.0 V          8820 mV
lcc1-re0:
-----
SIB 0 status:
State           Online - Standby
Temperature      49 degrees C / 120 degrees F
Temperature (B)  43 degrees C / 109 degrees F
Power
  1.2 V          1206 mV
  1.5 V          1506 mV
  2.5 V          2496 mV
  3.3 V          3308 mV
  3.3 V bias     3296 mV
  5.0 V bias     4974 mV
  8.0 V bias     7884 mV
  9.0 V          8820 mV
Power (B)
  1.2 V          1200 mV
  2.5 V          2508 mV
  3.3 V          3292 mV
  9.0 V          8892 mV
...

```

**show chassis
environment sib sfc
(TX Matrix Plus
Router)**

```

user@host> show chassis environment sib sfc
sfc0-re0:
-----
SIB F13 0 status:
State           Online - Standby
Temperature      54 degrees C / 129 degrees F
Temperature (B)  50 degrees C / 122 degrees F
Power
  1.2 V_0        1205 mV
  1.2 V_1        1205 mV
  1.2 V_2        1208 mV
  1.2 V_3        1208 mV
  1.5 V_0        1501 mV
  1.5 V_1        1508 mV
  1.8 V          1804 mV
  2.5 V          2504 mV
  3.3 V          3312 mV
  9.0 V          8991 mV
  9.0 V bias     0 mV
Power (B)
  2.5 V          2516 mV
  3.3 V          3318 mV
  9.0 V          9048 mV
SIB F13 1 status:
State           Online - Standby
Temperature      45 degrees C / 113 degrees F
Temperature (B)  42 degrees C / 107 degrees F
Power
  1.2 V_0        1202 mV
  1.2 V_1        1205 mV
  1.2 V_2        1198 mV
  1.2 V_3        1205 mV
  1.5 V_0        1498 mV
  1.5 V_1        1495 mV

```

```

1.8 V          1801 mV
2.5 V          2507 mV
3.3 V          3306 mV
9.0 V          8970 mV
9.0 V bias      0 mV
Power (B)
2.5 V          2507 mV
3.3 V          3306 mV
9.0 V          8970 mV
SIB F13 3 status:
State          Online
Temperature     48 degrees C / 118 degrees F
Temperature (B) 43 degrees C / 109 degrees F
Power
1.2 V_0        1208 mV
1.2 V_1        1195 mV
1.2 V_2        1202 mV
1.2 V_3        1198 mV
1.5 V_0        1504 mV
1.5 V_1        1504 mV
1.8 V          1801 mV
2.5 V          2510 mV
3.3 V          3312 mV
9.0 V          8970 mV
9.0 V bias      0 mV
Power (B)
2.5 V          2500 mV
3.3 V          3332 mV
9.0 V          8970 mV
SIB F13 4 status:
State          Online
Temperature     44 degrees C / 111 degrees F
Temperature (B) 40 degrees C / 104 degrees F
Power
1.2 V_0        1205 mV
1.2 V_1        1202 mV
1.2 V_2        1205 mV
1.2 V_3        1202 mV
1.5 V_0        1508 mV
1.5 V_1        1511 mV
1.8 V          1811 mV
2.5 V          2510 mV
3.3 V          3312 mV
9.0 V          8952 mV
9.0 V bias      0 mV
Power (B)
2.5 V          2510 mV
3.3 V          3306 mV
9.0 V          9024 mV
SIB F13 6 status:
State          Online
Temperature     49 degrees C / 120 degrees F
Temperature (B) 46 degrees C / 114 degrees F
Power
1.2 V_0        1195 mV
1.2 V_1        1198 mV
1.2 V_2        1202 mV
1.2 V_3        1202 mV
1.5 V_0        1501 mV
1.5 V_1        1495 mV
1.8 V          1801 mV

```

```

2.5 V          2507 mV
3.3 V          3306 mV
9.0 V          8979 mV
9.0 V bias     0 mV
Power (B)
2.5 V          2497 mV
3.3 V          3318 mV
9.0 V          9006 mV
SIB F13 7 status:
State          Online
Temperature     52 degrees C / 125 degrees F
Temperature (B) 48 degrees C / 118 degrees F
Power
1.2 V_0        1198 mV
1.2 V_1        1198 mV
1.2 V_2        1202 mV
1.2 V_3        1189 mV
1.5 V_0        1498 mV
1.5 V_1        1498 mV
1.8 V          1804 mV
2.5 V          2491 mV
3.3 V          3292 mV
9.0 V          8904 mV
9.0 V bias     0 mV
Power (B)
2.5 V          2500 mV
3.3 V          3306 mV
9.0 V          8952 mV
SIB F13 8 status:
State          Online
Temperature     54 degrees C / 129 degrees F
Temperature (B) 49 degrees C / 120 degrees F
Power
1.2 V_0        1211 mV
1.2 V_1        1208 mV
1.2 V_2        1208 mV
1.2 V_3        1211 mV
1.5 V_0        1508 mV
1.5 V_1        1511 mV
1.8 V          1801 mV
2.5 V          2513 mV
3.3 V          3324 mV
9.0 V          9048 mV
9.0 V bias     0 mV
Power (B)
2.5 V          2516 mV
3.3 V          3318 mV
9.0 V          9102 mV
SIB F13 9 status:
State          Online
Temperature     46 degrees C / 114 degrees F
Temperature (B) 41 degrees C / 105 degrees F
Power
1.2 V_0        1205 mV
1.2 V_1        1202 mV
1.2 V_2        1205 mV
1.2 V_3        1198 mV
1.5 V_0        1504 mV
1.5 V_1        1504 mV
1.8 V          1817 mV
2.5 V          2507 mV

```

```

3.3 V          3306 mV
9.0 V          8991 mV
9.0 V bias     0 mV
Power (B)
2.5 V          2510 mV
3.3 V          3332 mV
9.0 V          9006 mV
SIB F13 11 status:
State          Online
Temperature     47 degrees C / 116 degrees F
Temperature (B) 42 degrees C / 107 degrees F
Power
1.2 V_0        1202 mV
1.2 V_1        1205 mV
1.2 V_2        1202 mV
1.2 V_3        1198 mV
1.5 V_0        1501 mV
1.5 V_1        1504 mV
1.8 V          1807 mV
2.5 V          2510 mV
3.3 V          3306 mV
9.0 V          8991 mV
9.0 V bias     0 mV
Power (B)
2.5 V          2249 mV
3.3 V          4994 mV
9.0 V          9936 mV
SIB F13 12 status:
State          Online
Temperature     44 degrees C / 111 degrees F
Temperature (B) 40 degrees C / 104 degrees F
Power
1.2 V_0        1208 mV
1.2 V_1        1202 mV
1.2 V_2        1208 mV
1.2 V_3        1205 mV
1.5 V_0        1511 mV
1.5 V_1        1508 mV
1.8 V          1814 mV
2.5 V          2507 mV
3.3 V          3318 mV
9.0 V          9039 mV
9.0 V bias     0 mV
Power (B)
2.5 V          2516 mV
3.3 V          3344 mV
9.0 V          9006 mV
SIB F2S 0/0 status:
State          Online - Standby
Temperature     40 degrees C / 104 degrees F
Power
1.2 V_1        0 mV
1.2 V_ASF      1198 mV
1.2 V_ASF_B    1198 mV
1.2 V_ASF_D    1202 mV
1.5 V          1498 mV
1.8 V          1814 mV
3.3 V          3300 mV
3.3 V bias     3300 mV
3.3 V ASF      3286 mV
9.0 V          8250 mV

```

```

SIB F2S 0/2 status:
State           Online - Standby
Temperature     40 degrees C / 104 degrees F
Power
  1.2 V_1       0 mV
  1.2 V_ASF     1198 mV
  1.2 V_ASF_B   1195 mV
  1.2 V_ASF_D   1202 mV
  1.5 V         1498 mV
  1.8 V         1807 mV
  3.3 V         3300 mV
  3.3 V bias    3300 mV
  3.3 V ASF     3292 mV
  9.0 V         8250 mV
SIB F2S 0/4 status:
State           Online - Standby
Temperature     40 degrees C / 104 degrees F
Power
  1.2 V_1       0 mV
  1.2 V_ASF     1198 mV
  1.2 V_ASF_B   1195 mV
  1.2 V_ASF_D   1202 mV
  1.5 V         1501 mV
  1.8 V         1817 mV
  3.3 V         3300 mV
  3.3 V bias    3300 mV
  3.3 V ASF     3306 mV
  9.0 V         8250 mV
SIB F2S 0/6 status:
State           Online - Standby
Temperature     39 degrees C / 102 degrees F
Power
  1.2 V_1       0 mV
  1.2 V_ASF     1202 mV
  1.2 V_ASF_B   1198 mV
  1.2 V_ASF_D   1198 mV
  1.5 V         1495 mV
  1.8 V         1814 mV
  3.3 V         3300 mV
  3.3 V bias    3300 mV
  3.3 V ASF     3280 mV
  9.0 V         8250 mV
SIB F2S 1/0 status:
State           Online
Temperature     39 degrees C / 102 degrees F
Power
  1.2 V_1       0 mV
  1.2 V_ASF     1195 mV
  1.2 V_ASF_B   1192 mV
  1.2 V_ASF_D   1195 mV
  1.5 V         1492 mV
  1.8 V         1798 mV
  3.3 V         3300 mV
  3.3 V bias    3300 mV
  3.3 V ASF     3280 mV
  9.0 V         8250 mV
SIB F2S 1/2 status:
State           Online
Temperature     39 degrees C / 102 degrees F
Power
  1.2 V_1       0 mV

```

```

1.2 V_ASF                1205 mV
1.2 V_ASF_B              1202 mV
1.2 V_ASF_D              1205 mV
1.5 V                    1504 mV
1.8 V                    1820 mV
3.3 V                    3300 mV
3.3 V bias               3300 mV
3.3 V ASF                3306 mV
9.0 V                    8250 mV
SIB F2S 1/4 status:
State                    Online
Temperature              39 degrees C / 102 degrees F
Power
1.2 V_1                  0 mV
1.2 V_ASF                1202 mV
1.2 V_ASF_B              1195 mV
1.2 V_ASF_D              1198 mV
1.5 V                    1498 mV
1.8 V                    1811 mV
3.3 V                    3300 mV
3.3 V bias               3300 mV
3.3 V ASF                3300 mV
9.0 V                    8250 mV
SIB F2S 1/6 status:
State                    Online
Temperature              39 degrees C / 102 degrees F
Power
1.2 V_1                  0 mV
1.2 V_ASF                1195 mV
1.2 V_ASF_B              1192 mV
1.2 V_ASF_D              1198 mV
1.5 V                    1498 mV
1.8 V                    1807 mV
3.3 V                    3306 mV
3.3 V bias               3300 mV
3.3 V ASF                3292 mV
9.0 V                    8250 mV
SIB F2S 2/0 status:
State                    Online
Temperature              38 degrees C / 100 degrees F
Power
1.2 V_1                  0 mV
1.2 V_ASF                1195 mV
1.2 V_ASF_B              1195 mV
1.2 V_ASF_D              1198 mV
1.5 V                    1498 mV
1.8 V                    1804 mV
3.3 V                    3300 mV
3.3 V bias               3300 mV
3.3 V ASF                3292 mV
9.0 V                    8250 mV
...

```

```

show chassis user@host> show chassis environment sib f13 0
environment sib f13 SIB F13 0 status:
(TX Matrix Plus State Online - Standby
Router)           Temperature 54 degrees C / 129 degrees F
                  Temperature (B) 50 degrees C / 122 degrees F
                  Power
                  1.2 V_0        1202 mV
                  1.2 V_1        1202 mV

```

1.2 V_2	1208 mV
1.2 V_3	1208 mV
1.5 V_0	1501 mV
1.5 V_1	1504 mV
1.8 V	1801 mV
2.5 V	2504 mV
3.3 V	3318 mV
9.0 V	8991 mV
9.0 V bias	0 mV
Power (B)	
2.5 V	2510 mV
3.3 V	3318 mV
9.0 V	9024 mV

```

show chassis environment sib f2s
(TX Matrix Plus Router)
user@host> show chassis environment sib f2s 0/2
SIB F2S 0/2 status:
State Online - Standby
Temperature 40 degrees C / 104 degrees F
Power
1.2 V_1 0 mV
1.2 V_ASF 1198 mV
1.2 V_ASF_B 1195 mV
1.2 V_ASF_D 1202 mV
1.5 V 1501 mV
1.8 V 1807 mV
3.3 V 3300 mV
3.3 V bias 3300 mV
3.3 V ASF 3286 mV
9.0 V 8250 mV

```

show chassis ethernet-switch

Syntax	show chassis ethernet-switch <errors <port>>
Syntax (EX8200 Switch)	show chassis ethernet-switch <statistics <port> switch <number>
Syntax (TX Matrix Router)	show chassis ethernet-switch <errors <port> statistics <port>> <lcc <number> scc>
Syntax (TX Matrix Plus Router)	show chassis ethernet-switch <errors <port> switch <number> <lcc number sfc number> <statistics <port> switch <number>
Syntax (MX Series Router)	show chassis ethernet-switch <all-members> <errors <port>> <local> <member member-id>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.4 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(M10i, M40e, M120, M160, M320, MX Series, and T Series routers and EX8200 switches only) Display information about the ports on the Control Board (CB) Ethernet switch.
Options	<p>none—Display information about each connected port on the Ethernet switch. On a TX Matrix router, display information about each connected port on the Ethernet switch on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display information about each connected port on the Ethernet switch on the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display information about the ports on the CB Ethernet switch on all the members of the Virtual Chassis configuration.</p> <p>errors—(Optional) Display the numbers and types of errors accumulated on all ports of the Ethernet switch.</p> <p>errors port—(Optional) Display the numbers and types of errors accumulated on the specified port (0 through 15) of the Ethernet switch. On the TX Matrix router, replace port with a value from 0 through 15. On the TX Matrix Plus router and EX8200 switch, replace port with a value from 0 through 27.</p> <p>errors switch number—(TX Matrix Plus router only) (Optional) Display the numbers and types of errors accumulated on the specified switch. Replace number with a value from 0 through 2.</p>

lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display information about the ports on the CB's Ethernet switch on a specified T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display information about the ports on the CB's Ethernet switch on a specified T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(MX Series routers only) (Optional) Display information about the ports on the CB Ethernet switch on the local Virtual Chassis member.

member member-id—(MX Series routers only) (Optional) Display information about the ports on the CB Ethernet switch on the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

scc—(TX Matrix router only) (Optional) Display information about the ports on the CB's Ethernet switch on the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus router only) (Optional) Display information about the ports on the CB's Ethernet switch on the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

statistics—(Optional) Display traffic statistics for each connected port on the Ethernet switch.

statistics port—(Optional) Display traffic statistics for the specified port on the Ethernet switch. On the TX Matrix router, replace *port* with a value from 0 through 25. On the TX Matrix Plus router or EX8200 switch, replace *port* with a value from 0 through 27.

statistics switch number—(TX Matrix Plus routers and EX8200 switch only) (Optional) Display traffic statistics for the specified Ethernet switch number. On the TX Matrix Plus router and EX8216 switch, replace *number* with a value from 0 through 2. On the EX8208 switch, replace *number* with a value from 0 through 1.

Required Privilege Level view

List of Sample Output **show chassis ethernet-switch on page 307**
show chassis ethernet-switch (TX Matrix Router) on page 307
show chassis ethernet-switch errors on page 309
show chassis ethernet-switch statistics on page 309
show chassis ethernet-switch errors (TX Matrix Plus Router) on page 310
show chassis ethernet-switch sfc errors (TX Matrix Plus Router) on page 311
show chassis ethernet-switch statistics (TX Matrix Plus Router) on page 312

Output Fields Table 61 on page 306 lists the output fields for the **show chassis ethernet-switch** command. Output fields are listed in the approximate order in which they appear.

Table 61: show chassis ethernet-switch Output Fields

Field Name	Field Description
Link is good on port n connected to device or Link is good on FE port n connected to device	Information about the link between each port on the CB's Ethernet switch and one of the following devices: <ul style="list-style-type: none"> • FPC0 (Flexible PIC Concentrator 0) through FPC7 • Local controller • Other RE (on a system with two Routing Engines) • SPMB (Switch Processor Mezzanine Board) • (TX Matrix router only) LCC0 (line-card chassis 0) through LCC3
Speed is	Speed at which the Ethernet link is running: 10 Mb or 100 Mb . When the device is Other RE on the TX Matrix router, the speed is 1000 Mb .
Duplex is	Duplex type of the Ethernet link: full or half .
Auto-negotiate is enabled	By default, both of the built-in Fast Ethernet ports on the M7i router PIC autonegotiate whether to operate at 10 Mbps or 100 Mbps. All other interfaces automatically choose the correct speed based on the PIC type and whether the PIC is configured to operate in multiplexed mode (using the no-concatenate statement at the [edit chassis] hierarchy level, as described in the <i>JUNOS System Basics Configuration Guide</i>).
MLT3	Number of multilevel threshold-3 (MLT-3) Fast Ethernet errors detected.
Accumulated error counts for port n connected to device FPCn: (error output only)	
Lock	Number of lock errors detected.
Xmit	Number of transmission errors detected.
ESD	Number of electrostatic discharge (ESD) errors detected.
False Carrier	Number of false carrier errors detected.
Disconnects	Number of disconnect errors detected.
FX mode	Number of errors detected on an Ethernet link over optical fiber.
Statistics for port n connected to device FPCn (statistics output only)	
TX Unicast packets	Number of unicast packets sent.
TX Multicast packets	Number of multicast packets sent.
TX Broadcast packets	Number of broadcast packets sent.
TX Late collisions	Number of packets aborted during sending because of collisions after 64 bytes.
TX Excessive collisions	Number of packets not sent because of too many collisions.
TX Dropped packets	Number of transmitted packets that were dropped.

Table 61: show chassis ethernet-switch Output Fields (*continued*)

Field Name	Field Description
RX Unicast packets	Number of unicast packets received.
RX Multicast packets	Number of multicast packets received.
RX Broadcast packets	Number of broadcast packets received.
RX FCS Errors	Number of packets discarded because of frame check sequence errors.
RX Alignment Errors	Number of incomplete octets received.
RX Dropped Packets	Number of incoming packets that were dropped.
RX Fragments	Number of fragmented packets received.
RX Symbol Errors	Number of symbols received that the router did not correctly decode.

Sample Output

```

show chassis ethernet-switch user@host> show chassis ethernet-switch
Link is good on port 0 connected to device: FPC0
  Speed is 100Mb
  Duplex is full

Link is good on port 1 connected to device: FPC1
  Speed is 100Mb
  Duplex is full

Link is good on port 2 connected to device: FPC2
  Speed is 100Mb
  Duplex is full

Link is good on port 3 connected to device: FPC3
  Speed is 100Mb
  Duplex is full

Link is good on port 7 connected to device: Local controller
  Speed is 100Mb
  Duplex is full

Link is good on port 9 connected to device: SPMB
  Speed is 100Mb
  Duplex is full

Link is good on port 13 connected to device: FPC5
  Speed is 100Mb
  Duplex is full

show chassis ethernet-switch (TX scc-re0:
Matrix Router) -----
Link is good on FE port 4 connected to device: LCC0

```

Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 6 connected to device: LCC2
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 8 connected to device: SPMB
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

lcc0-re0:

Link is good on FE port 1 connected to device: FPC1
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 2 connected to device: FPC2
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 8 connected to device: SPMB
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 10 connected to device: SCC
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

lcc2-re0:

Link is good on FE port 0 connected to device: FPC0
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 1 connected to device: FPC1
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 2 connected to device: FPC2
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 8 connected to device: SPMB
Speed is 100Mb
Duplex is full
Autonegotiate is Enabled

Link is good on FE port 10 connected to device: SCC
Speed is 100Mb

```

Duplex is full
Autonegotiate is Enabled

show chassis ethernet-switch errors user@host> show chassis ethernet-switch errors
ethernet-switch errors Accumulated error counts for port 0 connected to device FPC0:
MLT3 2
Lock 0
Xmit 0
ESD 0
False carrier 2
Disconnects 0
FX mode 0
Accumulated error counts for port 1 connected to device FPC1:
MLT3 2
Lock 0
Xmit 0
ESD 0
False carrier 2
Disconnects 0
FX mode 0
Accumulated error counts for port 2 connected to device FPC2:
MLT3 2
Lock 0
Xmit 0
ESD 0
False carrier 3
Disconnects 0
FX mode 0
Accumulated error counts for port 3 connected to device FPC3:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
Accumulated error counts for port 4 connected to device Nothing:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
FX mode 0
...

show chassis ethernet-switch statistics user@host> show chassis ethernet-switch statistics
ethernet-switch statistics Statistics for port 0 connected to device FPC0:
TX Unicast packets 68113
TX Multicast packets 0
TX Broadcast packets 20851
TX Late collisions 0
TX Excessive collisions 0
TX Dropped packets 0

RX Unicast packets 67410
RX Multicast packets 0
RX Broadcast packets 20852
RX FCS Errors 0
RX Alignment Errors 0
RX Dropped Packets 0
RX Fragments 0

```

```
RX Symbol Errors          0
```

```
Statistics for port 1 connected to device FPC1:
```

```
TX Unicast packets      66496
TX Multicast packets    0
TX Broadcast packets    20080
TX Late collisions      0
TX Excessive collisions 0
TX Dropped packets      0
```

```
RX Unicast packets      66037
RX Multicast packets    0
RX Broadcast packets    20080
RX FCS Errors           0
RX Alignment Errors     0
RX Dropped Packets      0
RX Fragments            0
RX Symbol Errors        0
```

```
Statistics for port 2 connected to device FPC2:
```

```
TX Unicast packets      64206
TX Multicast packets    0
TX Broadcast packets    21183
TX Late collisions      0
TX Excessive collisions 0
TX Dropped packets      0
```

```
RX Unicast packets      63671
RX Multicast packets    0
RX Broadcast packets    21183
RX FCS Errors           0
RX Alignment Errors     0
RX Dropped Packets      0
RX Fragments            0
RX Symbol Errors        0
```

```
Statistics for port 3 connected to device FPC3:
```

```
...
```

**show chassis
ethernet-switch errors
(TX Matrix Plus
Router)**

```
user@host> show chassis ethernet-switch errors
sfc0-re0:
```

```
-----
Displaying error for switch 0
```

```
Displaying error for switch 1
```

```
Accumulated error counts for port 0 connected to device LCC0:
```

```
MLT3      0
Lock      0
Xmit      0
ESD       0
False carrier 0
Disconnects 0
FX mode   0
```

```
lcc0-re0:
```

```
-----
Displaying error for switch 0
```

```
Accumulated error counts for port 6 connected to device FPC0:
```

```
MLT3      0
Lock      0
Xmit      0
ESD       0
```

```

False carrier 5
Disconnects 0
FX mode 0
Accumulated error counts for port 7 connected to device FPC1:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 7
Disconnects 0
FX mode 0
Accumulated error counts for port 19 connected to device Other RE:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
FX mode 0
Accumulated error counts for port 20 connected to device SFC0:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
FX mode 0

```

**show chassis
ethernet-switch sfc
errors (TX Matrix Plus
Router)**

```

user@host> show chassis ethernet-switch errors switch sfc
sfc0-re0:

```

```

-----
Displaying error for switch 1
Accumulated error counts for port 0 connected to device LCC0:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
FX mode 0
Accumulated error counts for port 2 connected to device LCC1:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
FX mode 0
Accumulated error counts for port 4 connected to device LCC2:
MLT3 0
Lock 0
Xmit 0
ESD 0
False carrier 0
Disconnects 0
FX mode 0
Accumulated error counts for port 6 connected to device LCC3:
MLT3 0
Lock 0
Xmit 0
ESD 0

```

```

False carrier 0
Disconnects   0
FX mode       0

```

```
lcc0-re0:
```

```
-----
error: command is not valid on the t1600
```

```
lcc1-re0:
```

```
-----
error: command is not valid on the t1600
```

```
lcc2-re0:
```

```
-----
error: command is not valid on the t1600
```

```
lcc3-re0:
```

```
-----
error: command is not valid on the t1600
```

**show chassis
ethernet-switch
statistics (TX Matrix
Plus Router)**

```
user@host> show chassis ethernet-switch statistics
```

```
sfc0-re0:
```

```
-----
Displaying port statistics for switch 0
```

```
Statistics for port 1 connected to device 1GSW:
```

```

TX Packets 64 Octets      5183577
TX Packets 65-127 Octets  67820
TX Packets 128-255 Octets 772
TX Packets 256-511 Octets 136
TX Packets 512-1023 Octets 68
TX Packets 1024-1518 Octets 10881
TX Packets 1519-2047 Octets 0
TX Packets 2048-4095 Octets 0
TX Packets 4096-9216 Octets 0
TX Packets 9217-16383 Octets 0
TX Octets                  5263254
TX Multicast Packets       16
TX Broadcast Packets       723403
TX PAUSEMAC Ctrl Frames    0
TX Oversize Packets        0
TX FCS Error Counter       0
TX Fragment Counter        0
TX Byte Counter            349922253
TX Packet OK Counter       5263254
TX Pause Packet Counter    0
TX Unicast Counter         4539835
RX Packets 64 Octets      6513629
RX Packets 65-127 Octets  88761
RX Packets 128-255 Octets 6382
RX Packets 256-511 Octets 22027
RX Packets 512-1023 Octets 4319
RX Packets 1024-1518 Octets 49922
RX Packets 1519-2047 Octets 0
RX Packets 2048-4095 Octets 0
RX Packets 4096-9216 Octets 0
RX Packets 9217-16383 Octets 0
RX Octets                  6685040
RX Multicast Packets       4
RX Broadcast Packets       2137376
RX FCS Errors              0
RX Fragments               0

```



```

RX MAC Control Packets      0
RX Out of Range Length      0
RX Undersize Packets        0
RX Oversize Packets         0
RX Jabbers                  0
RX Control Frame Counter    0
RX Pause Frame Counter      0
RX Byte Counter             509224602
RX Unicast Frame Count      4547660
RX Packet OK Count          6685040
Statistics for port 9 connected to device RE1:
TX Packets 64 Octets        2500318
TX Packets 65-127 Octets    443
TX Packets 128-255 Octets   0
TX Packets 256-511 Octets   0
TX Packets 512-1023 Octets  0
TX Packets 1024-1518 Octets 0
TX Packets 1519-2047 Octets 0
TX Packets 2048-4095 Octets 0
TX Packets 4096-9216 Octets 0
TX Packets 9217-16383 Octets 0
TX Octets                   2500761
TX Multicast Packets        4
TX Broadcast Packets        2500757
TX PAUSEMAC Ctrl Frames    0
TX Oversize Packets         0
TX FCS Error Counter        0
TX Fragment Counter         0
TX Byte Counter             160049670
TX Packet OK Counter        0
TX Pause Packet Counter     0
TX Unicast Counter          0
RX Packets 64 Octets        701191
RX Packets 65-127 Octets    5882
RX Packets 128-255 Octets   2
RX Packets 256-511 Octets   0
RX Packets 512-1023 Octets  17965
RX Packets 1024-1518 Octets  7
RX Packets 1519-2047 Octets 0
RX Packets 2048-4095 Octets 0
RX Packets 4096-9216 Octets 0
RX Packets 9217-16383 Octets 0
RX Octets                   725047
RX Multicast Packets        8
RX Broadcast Packets        2500757
RX FCS Errors               0
RX Fragments                0
RX MAC Control Packets      0
RX Out of Range Length      0
RX Undersize Packets        0
RX Oversize Packets         0
RX Jabbers                  0
RX Control Frame Counter    0
RX Pause Frame Counter      0
RX Byte Counter             62402656
RX Unicast Frame Count      0
RX Packet OK Count          0
Statistics for port 17 connected to device RE0:
TX Packets 64 Octets        7214818
TX Packets 65-127 Octets    94640
TX Packets 128-255 Octets   6384

```

```

TX Packets 256-511 Octets    22027
TX Packets 512-1023 Octets   22284
TX Packets 1024-1518 Octets  49929
TX Packets 1519-2047 Octets  0
TX Packets 2048-4095 Octets  0
TX Packets 4096-9216 Octets  0
TX Packets 9217-16383 Octets 0
TX Octets                    7410082
TX Multicast Packets         12
TX Broadcast Packets         2497247
TX PAUSEMAC Ctrl Frames     0
TX Oversize Packets         0
TX FCS Error Counter         0
TX Fragment Counter         0
TX Byte Counter              571626932
TX Packet OK Counter         0
TX Pause Packet Counter     0
TX Unicast Counter          0
RX Packets 64 Octets         4823701
RX Packets 65-127 Octets     67812
RX Packets 128-255 Octets    772
RX Packets 256-511 Octets    136
RX Packets 512-1023 Octets   68
RX Packets 1024-1518 Octets  10881
RX Packets 1519-2047 Octets  0
RX Packets 2048-4095 Octets  0
RX Packets 4096-9216 Octets  0
RX Packets 9217-16383 Octets 0
RX Octets                    4903370
RX Multicast Packets         8
RX Broadcast Packets         2497247
RX FCS Errors                0
RX Fragments                 0
RX MAC Control Packets       0
RX Out of Range Length       0
RX Undersize Packets         0
RX Oversize Packets         0
RX Jabbers                   0
RX Control Frame Counter     0
RX Pause Frame Counter       0
RX Byte Counter              326889517
RX Unicast Frame Count       0
RX Packet OK Count           0

```

Displaying port statistics for switch 1
 Statistics for port 0 connected to device LCC0:

```

TX Packets 64 Octets         5053443
TX Packets 65-127 Octets     59737
TX Packets 128-255 Octets    768
TX Packets 256-511 Octets    87
TX Packets 512-1023 Octets   68
TX Packets 1024-1518 Octets  85
TX Packets 1519-2047 Octets  0
TX Packets 2048-4095 Octets  0
TX Packets 4096-9216 Octets  0
TX 1519-1522 Good Vlan frms 0
TX Octets                    5114188
TX Multicast Packets         16
TX Broadcast Packets         1125742
TX Single Collision frames   0
TX Mult. Collision frames    0

```

```

TX Late Collisions          0
TX Excessive Collisions    0
TX Collision frames        0
TX PAUSEMAC Ctrl Frames    0
TX MAC ctrl frames         0
TX Frame deferred Xmsns    0
TX Frame excessive deferl  0
TX Oversize Packets        0
TX Jabbers                 0
TX FCS Error Counter       0
TX Fragment Counter        0
TX Byte Counter            329291449
RX Packets 64 Octets       5640175
RX Packets 65-127 Octets   79875
RX Packets 128-255 Octets  6338
RX Packets 256-511 Octets  165
RX Packets 512-1023 Octets 4317
RX Packets 1024-1518 Octets 10
RX Packets 1519-2047 Octets 0
RX Packets 2048-4095 Octets 0
RX Packets 4096-9216 Octets 0
RX Octets                   5730880
RX Multicast Packets       4
RX Broadcast Packets       1735007
RX FCS Errors              0
RX Align Errors            0
RX Fragments               0
RX Symbol errors           0
RX Unsupported opcodes     0
RX Out of Range Length     0
RX False Carrier Errors    0
RX Undersize Packets       0
RX Oversize Packets        0
RX Jabbers                 0
RX 1519-1522 Good Vlan frms 0
RX MTU Exceed Counter      0
RX Control Frame Counter   0
RX Pause Frame Counter     0
RX Byte Counter            371282850
Statistics for port 18 connected to device SPMB:
TX Packets 64 Octets       2990326
TX Packets 65-127 Octets   8572
TX Packets 128-255 Octets  4
TX Packets 256-511 Octets  49
TX Packets 512-1023 Octets 0
TX Packets 1024-1518 Octets 10793
TX Packets 1519-2047 Octets 0
TX Packets 2048-4095 Octets 0
TX Packets 4096-9216 Octets 0
TX 1519-1522 Good Vlan frms 0
TX Octets                   3009744
TX Multicast Packets       20
TX Broadcast Packets       2458322
TX Single Collision frames 0
TX Mult. Collision frames  0
TX Late Collisions         0
TX Excessive Collisions    0
TX Collision frames        0
TX PAUSEMAC Ctrl Frames    0
TX MAC ctrl frames         0
TX Frame deferred Xmsns    0

```

TX Frame excessive deferl	0
TX Oversize Packets	0
TX Jabbers	0
TX FCS Error Counter	0
TX Fragment Counter	0
TX Byte Counter	203712524
RX Packets 64 Octets	873454
RX Packets 65-127 Octets	8886
RX Packets 128-255 Octets	44
RX Packets 256-511 Octets	21862
RX Packets 512-1023 Octets	2
RX Packets 1024-1518 Octets	49912
RX Packets 1519-2047 Octets	0
RX Packets 2048-4095 Octets	0
RX Packets 4096-9216 Octets	0
RX Octets	954160
RX Multicast Packets	0
RX Broadcast Packets	402369
RX FCS Errors	0
RX Align Errors	0
RX Fragments	0
RX Symbol errors	0
RX Unsupported opcodes	0
RX Out of Range Length	0
RX False Carrier Errors	0
RX Undersize Packets	0
RX Oversize Packets	0
RX Jabbers	0
RX 1519-1522 Good Vlan frms	0
RX MTU Exceed Counter	0
RX Control Frame Counter	0
RX Pause Frame Counter	0
RX Byte Counter	137941752
...	

show chassis fan

Syntax	show chassis fan
Release Information	Command introduced in JUNOS Release 10.0.
Description	(MX Series 3D Universal EdgeRouters only) Show information about the fan tray and fans.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chasis fan on page 317
Output Fields	Table 62 on page 317 lists the output fields for the show chassis fan command. Output fields are listed in the approximate order in which they appear.

Table 62: show chassis fan Output Fields

Field Name	Field Description
Item	Fan item identifier.
Status	Status of the fan: <ul style="list-style-type: none"> • OK-Fan is running properly and within the normal range. • Check-Fan is in Check state because of some fault or alarm condition.
RPM	Fan speed in revolutions per minute (RPM).
Measurement	Fan speed status based on different chassis cooling requirements: <ul style="list-style-type: none"> • Spinning at high speed • Spinning at intermediate-speed • Spinning at low speed

Sample Output

```

show chasis fan  user@host> show chassis fan
user@host> show chassis fan
      Item           Status  RPM      Measurement
Top Tray Fan 1      OK      3790    Spinning at normal speed
Top Tray Fan 2      OK      3769    Spinning at normal speed
Top Tray Fan 3      OK      3769    Spinning at normal speed
Top Tray Fan 4      OK      3790    Spinning at normal speed
Top Tray Fan 5      OK      3790    Spinning at normal speed
Top Tray Fan 6      OK      3769    Spinning at normal speed
Top Tray Fan 7      OK      3790    Spinning at normal speed
Top Tray Fan 8      OK      3769    Spinning at normal speed
Top Tray Fan 9      OK      3769    Spinning at normal speed
Top Tray Fan 10     OK      3790    Spinning at normal speed

```

Top Tray Fan 11	OK	3790	Spinning at normal speed
Top Tray Fan 12	OK	3769	Spinning at normal speed
Bottom Tray Fan 1	OK	2880	Spinning at normal speed
Bottom Tray Fan 2	OK	2912	Spinning at normal speed
Bottom Tray Fan 3	OK	2928	Spinning at normal speed
Bottom Tray Fan 4	OK	2896	Spinning at normal speed
Bottom Tray Fan 5	OK	2896	Spinning at normal speed
Bottom Tray Fan 6	OK	2928	Spinning at normal speed

show chassis fabric feb

Syntax	show chassis fabric feb
Release Information	Command introduced in Junos OS Release 8.0.
Description	(M120 router only) Display the state of the electrical and optical switching fabric links between the Forwarding Engine Boards (FEBs) and the fabric planes, as interpreted by the FEB.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis fabric feb on page 319
Output Fields	Table 63 on page 319 lists the output fields for the show chassis fabric feb command.

Table 63: show chassis fabric feb Output Fields

Field Name	Field Description
Fabric management FEB state	State of the switching fabric link between each FEB and fabric plane: desalination error, disabled, enabled, link error, link ok, or unused.

Sample Output

```

show chassis fabric feb
user@host> show chassis fabric feb
Fabric management      FEB state
FEB 0                  Plane 0: Plane enabled
                       Plane 1: Plane enabled
                       Plane 2: Plane enabled
                       Plane 3: Plane enabled
FEB 4                  Plane 0: Plane enabled
                       Plane 1: Plane enabled
                       Plane 2: Plane enabled
                       Plane 3: Plane enabled

```

show chassis fabric errors

Syntax show chassis fabric errors
 <fpc *slot-number* lcc *number*>
 <sib (*slot* | f13 *sib-slot* | f2s *sib-slot/sib-f2s-slot-number* | lcc *number*)>

Release Information Command introduced in Junos OS Release 10.0.

Description (TX Matrix Plus routers only) Display the first ten and last ten fabric errors for the FPC or Switch Interface Boards (SIBs).



NOTE: This command can only be issued on a master Routing Engine.

Options fpc *slot-number*—Show error log of the first ten and last ten errors for the specified FPC. Replace *slot-number* with a value from 0 through 31. This option has the following suboptions:

- **lcc *number***—Show error log of the first ten and last ten errors for the specified FPC on a specific T1600 router (or line-card chassis) that is part of the routing matrix. Replace *number* with a value from 0 through 3.

If you specify the number of the T1600 router by using only the **lcc *number*** option (the recommended method), replace *slot-number* with a value from 0 through 7. Otherwise, replace *slot-number* with a value from 0 through 31. For example, the following commands have the same result:

```
user@host> show chassis fabric errors fpc 1 lcc 1
user@host> show chassis fabric errors fpc 9
```

sib—Show error log of the first ten and last ten errors for the specified SIB. This option has the following suboptions:

- **sib-slot**—Replace *sib-slot* with a value ranging from 0 through 4.
- **f13 *sib-slot***—(Optional) Show SIB F13 errors. Replace *sib-slot* with a valid SIB value number: 0, 1, 3, 4, 6, 7, 8, 9, 11, or 12.
- **f2s *sib-slot/sib-f2s-slot-number***—(Optional) Show SIB F2S errors. Replace *sib-slot* with a value from 0 through 4, followed by a *sib-f2s-slot-number* value 0, 2, 4 or 6.
- **lcc *number***—(Optional) Show error log of the first ten and last ten SIB errors for the specified T1600 router (or line-card chassis). Replace *number* with a value from 0 through 3.



NOTE: The *lcc number* suboption is mandatory when using the following format for the command: `show chassis fabric errors sib lcc number sib slot-number`. For instance, issuing `show chassis fabric errors sib lcc 2 3` displays errors detected on LCC 2, SIB 3.

This suboption is not required when the *f13* or *f2s* suboptions are used with the *sib slot-number* option.

Required Privilege Level view

List of Sample Output `show chassis fabric errors` (F13 SIB Errors on a TX Matrix Plus Router) on page 321
`show chassis fabric errors` (F2S SIB Errors on a TX Matrix Plus Router) on page 321
`show chassis fabric errors` (SIB Errors Specific to an LCC Connected to a TX Matrix Plus Router) on page 321
`show chassis fabric errors` (FPC Errors Specific to an LCC Connected to a TX Matrix Plus Router) on page 322

Output Fields Table 64 on page 321 lists the output fields for the `show chassis fabric errors` command. Output fields are listed in the approximate order in which they appear.

Table 64: show chassis fabric errors Output Fields

Field Name	Field Description
Time	Time the error was logged.
Error log of first 10 errors	List of the first ten errors.
Error log of last 10 errors	List of the last ten errors.

Sample Output

`show chassis fabric errors (F13 SIB Errors on a TX Matrix Plus Router)`

```
user@host> show chassis fabric errors sib f13 11
Time                               Error log of first 10 errors
2009-10-06 02:21:17 PDT            LOS on Cable-D(1,0)
```

`show chassis fabric errors (F2S SIB Errors on a TX Matrix Plus Router)`

```
user@host> show chassis fabric errors sib f2s 0/0
Time                               Error log of first 10 errors
2009-10-06 13:51:42 PDT            Cell drop errors on CLOS F2 SF 0 Port 0 link
```

`show chassis fabric errors (SIB Errors Specific to an LCC Connected to a TX Matrix Plus Router)`

```
user@host> show chassis fabric errors sib 1 lcc 0
lcc0-re0:
-----
Time                               Error log of first 10 errors
```

2009-10-06 02:23:16 PDT Cell drop errors on FPC7_T link

2009-10-06 02:23:16 PDT Cell drop errors on FPC7_B link

**show chassis fabric
errors (FPC Errors
Specific to an LCC
Connected to a TX
Matrix Plus Router)**

user@host> show chassis fabric errors fpc 5 lcc 0
lcc0-re0:

Time	Error log of first 10 errors
2009-10-06 13:56:59 PDT	PFE_T has link error on plane 1

show chassis fabric fpcs

Syntax	show chassis fabric fpcs <fcc <i>number</i> >
Syntax (MX Series Router)	show chassis fabric fpcs <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.4 for EX Series switches.
Description	(M320, MX Series, and T Series routers and EX8200 switches only) Display the state of the electrical and optical switch fabric links between the Flexible PIC Concentrators (FPCs) and the Switch Interface Boards (SIBs).
Options	<p>none—Display the switch fabric link state. On a TX Matrix router, display the switching fabric link states for the FPCs in all T640 routers connected to the TX Matrix router. On a TX Matrix Plus router, display the switching fabric link states for the FPCs in all T1600 routers connected to the TX Matrix Plus router.</p> <p>all-members—(MX Series routers only) (Optional) Display the switching fabric link states for the FPCs in all members of the Virtual Chassis configuration.</p> <p>fcc <i>number</i>—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display the switch fabric link state for the FPCs in the specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display the switch fabric link state for the FPCs in the specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display the switching fabric link states for the FPCs in the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display the switching fabric link states for the FPCs in the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p>
Required Privilege Level	view
List of Sample Output	<p>show chassis fabric fpcs (M320 Router) on page 324</p> <p>show chassis fabric fpcs (MX240 Router) on page 324</p> <p>show chassis fabric fpcs (MX480 Router) on page 325</p> <p>show chassis fabric fpcs (MX960 Router) on page 326</p> <p>show chassis fabric fpcs (T320 Router) on page 327</p> <p>show chassis fabric fpcs (T640 Router) on page 328</p> <p>show chassis fabric fpcs (TX Matrix Router) on page 328</p> <p>show chassis fabric fpcs (T1600 Router) on page 329</p>

show chassis fabric fpcs (TX Matrix Plus Router) on page 331

show chassis fabric fpcs lcc (TX Matrix Plus Router) on page 338

show chassis fabric fpcs (EX8200 Switch) on page 339

Output Fields Table 65 on page 324 lists the output fields for the **show chassis fabric fpcs** command. Output fields are listed in the approximate order in which they appear.

Table 65: show chassis fabric fpcs Output Fields

Field Name	Field Description
Fabric management FPC state	<p>Switching fabric link (link from SIB to FPC) state for each FPC:</p> <ul style="list-style-type: none"> • Unused—FPC is not present. • Destination error on PFEs <i>list of PFE numbers</i>—Destination errors to the listed Packet Forwarding Engines. Indicates that the link is not carrying traffic to the listed Packet Forwarding Engines. <p>NOTE: In Junos OS Release 9.6 and later, the list of Packet Forwarding Engines with destination errors is displayed in the output.</p> <p>In Junos OS Releases before 9.6, the output only indicates that there are destination errors. However, the list of Packet Forwarding Engines with destination errors is not displayed.</p> <ul style="list-style-type: none"> • Links ok—Link between the spare SIB and FPC is eligible to carry traffic. • Link error—Link between the SIB and FPC has CRC errors. However, the link is still eligible to carry traffic. • Plane disabled—Fabric plane has been disabled for the following reasons: <ul style="list-style-type: none"> • Destination errors have exceeded the thresholds. • Run-time link errors have exceeded the thresholds. • Initialization time link errors detected, and link training was unsuccessful. • Plane enabled—Link between the active SIB and FPC is eligible to carry traffic.

Sample Output

show chassis fabric fpcs (M320 Router)

```
user@host> show chassis fabric fpcs
Fabric management FPC state:
FPC #2
  PFE #1
    SIB #0      Plane enabled
    SIB #1      Plane enabled
    SIB #2      Plane enabled
    SIB #3      Plane enabled
```

show chassis fabric fpcs (MX240 Router)

```
user@host> show chassis fabric fpcs
Fabric management FPC state:
FPC 2
  PFE #0
```

```

Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
PFE #1
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
PFE #2
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
PFE #3
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok

```

show chassis fabric fpcs (MX480 Router) user@host> show chassis fabric fpcs

```

FPC 0
PFE #0
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
PFE #1
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
PFE #2
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled

```

```
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
PFE #3
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
FPC 1
PFE #0
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Plane enabled
Plane 5: Plane enabled
Plane 6: Plane enabled
Plane 7: Plane enabled
PFE #1
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Plane enabled
Plane 5: Plane enabled
Plane 6: Plane enabled
Plane 7: Plane enabled
```

show chassis fabric fpcs (MX960 Router) **user@host> show chassis fabric fpcs**

```
FPC 0
PFE #0
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
PFE #1
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
PFE #2
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
PFE #3
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
```

```

        Plane 3: Plane enabled
        Plane 4: Links ok
        Plane 5: Links ok
FPC 1
  PFE #0
    Plane 0: Plane enabled
    Plane 1: Plane enabled
    Plane 2: Plane enabled
    Plane 3: Plane enabled
    Plane 4: Plane enabled
    Plane 5: Plane enabled
  PFE #1
    Plane 0: Plane enabled
    Plane 1: Plane enabled
    Plane 2: Plane enabled
    Plane 3: Plane enabled
    Plane 4: Plane enabled
    Plane 5: Plane enabled
FPC 2
  PFE #0
    Plane 0: Plane enabled
    Plane 1: Plane enabled
    Plane 2: Plane enabled
    Plane 3: Plane enabled
    Plane 4: Links ok
    Plane 5: Links ok
  PFE #1
    Plane 0: Plane enabled
    Plane 1: Plane enabled
    Plane 2: Plane enabled
    Plane 3: Plane enabled
    Plane 4: Links ok
    Plane 5: Links ok
  PFE #2
    Plane 0: Plane enabled
    Plane 1: Plane enabled
    Plane 2: Plane enabled
    Plane 3: Plane enabled
    Plane 4: Links ok
...

```

show chassis fabric fpcs (T320 Router) user@host> show chassis fabric fpcs

```

FPC #3
  PFE #1
    SIB #0
      Links ok
    SIB #1
      Plane enabled
    SIB #2
      Plane enabled
FPC #5
  PFE #1
    SIB #0
      Links ok
    SIB #1
      Plane enabled
    SIB #2
      Plane enabled
FPC #7
  PFE #1
    SIB #0

```

```

        Links ok
SIB #1
        Plane enabled
SIB #2
        Plane enabled

show chassis fabric fpcs (T640 Router) user@host> show chassis fabric fpcs
Fabric management FPC state:

FPC #2
PFE #1
SIB #0
        Links ok
SIB #1
        Plane enabled
SIB #2
        Plane enabled
SIB #3
        Plane enabled
SIB #4
        Plane enabled
FPC #3
PFE #1
SIB #2
        Plane enabled
SIB #3
        Link error
        Destination error on PFES
        8   9   10  11  12  13  14  15  16  17  18  19  20  21
SIB #4
        Destination error on PFES
        8   9   10  11  12  13  14  15  16  17  18  19  20  21
...

show chassis fabric fpcs (TX Matrix Router) user@host> show chassis fabric fpcs
lcc0-re0:
-----
Fabric management FPC state:
FPC #0
PFE #1
SIB #0
        Links ok
SIB #2
        Links ok
SIB #3
        Links ok
SIB #4
        Links ok
FPC #2
PFE #1
SIB #0
        Links ok
SIB #2
        Links ok
SIB #3
        Links ok
SIB #4
        Links ok
FPC #3
PFE #1
SIB #2
        Plane enabled

```



```

SIB #3
  Link error
  Destination error on PFes      0   1   2   3   4   5   6   7
    8   9  10  11  12  13  14  15  16  17  18  19  20  21
SIB #4
  Destination error on PFes      0   1   2   3   4   5   6   7
    8   9  10  11  12  13  14  15  16  17  18  19  20  21
...
FPC #4
  PFE #0
    SIB #4 Links ok
  PFE #1
    SIB #4 Links ok
FPC #5
  PFE #1
    SIB #4 Links ok
FPC #6
  PFE #1
    SIB #4 Links ok

```

```
lcc2-re0:
```

```
-----
Fabric management FPC state:
```

```

FPC #0
  PFE #1
    SIB #4 Links ok
FPC #1
  PFE #1
    SIB #4 Links ok
FPC #2
  PFE #0
    SIB #4 Links ok
  PFE #1
    SIB #4 Links ok
FPC #4
  PFE #0
    SIB #4 Links ok
  PFE #1
    SIB #4 Links ok
FPC #5
  PFE #1
    SIB #4 Links ok

```

show chassis fabric fpcs (T1600 Router)

```

user@host> show chassis fabric fpcs
Fabric management FPC state:
FPC #0
  PFE #0
    SIB #0
      Links ok
    SIB #1
      Plane enabled
    SIB #2
      Plane enabled
    SIB #3
      Plane enabled
    SIB #4
      Plane enabled
  PFE #1
    SIB #0
      Links ok
    SIB #1

```

```

        Plane enabled
    SIB #2
        Plane enabled
    SIB #3
        Plane enabled
    SIB #4
        Plane enabled
FPC #1
  PFE #0
    SIB #0
        Links ok
    SIB #1
        Plane enabled
    SIB #2
        Plane enabled
    SIB #3
        Plane enabled
    SIB #4
        Plane enabled
  PFE #1
    SIB #0
        Links ok
    SIB #1
        Plane enabled
    SIB #2
        Plane enabled
    SIB #3
        Plane enabled
    SIB #4
        Plane enabled
FPC #2
  PFE #0
    SIB #0
        Links ok
    SIB #1
        Plane enabled
    SIB #2
        Plane enabled
    SIB #3
        Plane enabled
    SIB #4
        Plane enabled
FPC #4
  PFE #0
    SIB #0
        Links ok
    SIB #1
        Plane enabled
    SIB #2
        Plane enabled
    SIB #3
        Plane enabled
    SIB #4
        Plane enabled
  PFE #1
    SIB #0
        Links ok
    SIB #1
        Plane enabled
    SIB #2
        Plane enabled
```

```

SIB #3
    Plane enabled
SIB #4
    Plane enabled
FPC #3
  PFE #1
    SIB #2
      Plane enabled
    SIB #3
      Link error
      Destination error on PFEs
        8  9 10 11 12 13 14 15 16 17 18 19 20 21
          0  1  2  3  4  5  6  7
    SIB #4
      Destination error on PFEs
        8  9 10 11 12 13 14 15 16 17 18 19 20 21
          0  1  2  3  4  5  6  7

```

```

show chassis fabric fpcs (TX Matrix Plus Router)
user@host> show chassis fabric fpcs
1cc0-re0:
-----
Fabric management FPC state:

```

```

FPC #0
  PFE #1
    SIB #0
      Unused
    SIB #1
      Links ok
    SIB #2
      Links ok
    SIB #3
      Links ok
    SIB #4
      Links ok
FPC #2
  PFE #0
    SIB #0
      Unused
    SIB #1
      Links ok
    SIB #2
      Links ok
    SIB #3
      Links ok
    SIB #4
      Links ok
  PFE #1
    SIB #0
      Unused
    SIB #1
      Links ok
    SIB #2
      Links ok
    SIB #3
      Links ok
    SIB #4
      Links ok
FPC #3
  PFE #1
    SIB #2
      Plane enabled
    SIB #3
      Link error

```

```

          Destination error on PFes      0   1   2   3   4   5   6   7
          8   9  10  11  12  13  14  15  16  17  18  19  20  21
SIB #4   Destination error on PFes      0   1   2   3   4   5   6   7
          8   9  10  11  12  13  14  15  16  17  18  19  20  21
FPC #4
PFE #0
SIB #0   Unused
SIB #1   Links ok
SIB #2   Links ok
SIB #3   Links ok
SIB #4   Links ok
PFE #1
SIB #0   Unused
SIB #1   Links ok
SIB #2   Links ok
SIB #3   Links ok
SIB #4   Links ok
FPC #6
PFE #0
SIB #0   Unused
SIB #1   Links ok
SIB #2   Links ok
SIB #3   Links ok
SIB #4   Links ok
PFE #1
SIB #0   Unused
SIB #1   Links ok
SIB #2   Links ok
SIB #3   Links ok
SIB #4   Links ok
FPC #7
PFE #0
SIB #0   Unused
SIB #1   Links ok
SIB #2   Links ok
SIB #3   Links ok

```

```

SIB #4
    Links ok

lcc1-re0:
-----
Fabric management FPC state:
FPC #2
    PFE #0
        SIB #0
            Links ok
        SIB #1
            Links ok
        SIB #2
            Links ok
        SIB #3
            Links ok
        SIB #4
            Links ok
    PFE #1
        SIB #0
            Links ok
        SIB #1
            Links ok
        SIB #2
            Links ok
        SIB #3
            Links ok
        SIB #4
            Links ok
FPC #4
    PFE #0
        SIB #0
            Links ok
        SIB #1
            Links ok
        SIB #2
            Links ok
        SIB #3
            Links ok
        SIB #4
            Links ok
    PFE #1
        SIB #0
            Links ok
        SIB #1
            Links ok
        SIB #2
            Links ok
        SIB #3
            Destination error on PFES      1      8      9      29      40      65      72      73
            93 104
        SIB #4
            Links ok
FPC #6
    PFE #0
        SIB #0
            Links ok
        SIB #1
            Links ok
        SIB #2

```

```

        Links ok
    SIB #3
        Links ok
    SIB #4
        Links ok
PFE #1
    SIB #0
        Links ok
    SIB #1
        Links ok
    SIB #2
        Links ok
    SIB #3
        Links ok
    SIB #4
        Links ok
FPC #7
PFE #0
    SIB #0
        Links ok
    SIB #1
        Links ok
    SIB #2
        Links ok
    SIB #3
        Links ok
    SIB #4
        Links ok
```

lcc2-re0:

Fabric management FPC state:

```
FPC #0
PFE #0
    SIB #0
        Links ok
    SIB #1
        Links ok
    SIB #2
        Links ok
    SIB #3
        Links ok
    SIB #4
        Links ok
PFE #1
    SIB #0
        Links ok
    SIB #1
        Links ok
    SIB #2
        Links ok
    SIB #3
        Links ok
    SIB #4
        Links ok
FPC #2
PFE #0
    SIB #0
        Links ok
    SIB #1
        Links ok
```

```
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
PFE #1
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
FPC #4
PFE #0
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
FPC #5
PFE #0
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
PFE #1
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
FPC #6
PFE #0
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
```

```

        SIB #4      Links ok
        SIB #4      Links ok
PFE #1
    SIB #0          Links ok
    SIB #1          Links ok
    SIB #2          Links ok
    SIB #3          Links ok
    SIB #4          Links ok
FPC #7
PFE #0
    SIB #0          Links ok
    SIB #1          Links ok
    SIB #2          Links ok
    SIB #3          Links ok
    SIB #4          Links ok
```

lcc3-re0:

Fabric management FPC state:

```
FPC #0
PFE #0
    SIB #0          Links ok
    SIB #1          Links ok
    SIB #2          Links ok
    SIB #3          Links ok
    SIB #4          Links ok
PFE #1
    SIB #0          Links ok
    SIB #1          Links ok
    SIB #2          Links ok
    SIB #3          Links ok
    SIB #4          Links ok
FPC #2
PFE #0
    SIB #0          Links ok
    SIB #1          Links ok
    SIB #2          Links ok
```



```
SIB #3
Links ok
SIB #4
Links ok
PFE #1
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
FPC #4
PFE #0
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
PFE #1
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
FPC #5
PFE #0
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
PFE #1
SIB #0
Links ok
SIB #1
Links ok
SIB #2
Links ok
SIB #3
Links ok
SIB #4
Links ok
```

```

FPC #6
  PFE #0
    SIB #0
      Links ok
    SIB #1
      Links ok
    SIB #2
      Links ok
    SIB #3
      Links ok
    SIB #4
      Links ok
  PFE #1
    SIB #0
      Links ok
    SIB #1
      Links ok
    SIB #2
      Links ok
    SIB #3
      Links ok
    SIB #4
      Links ok
FPC #7
  PFE #0
    SIB #0
      Links ok
    SIB #1
      Links ok
    SIB #2
      Links ok
    SIB #3
      Links ok
    SIB #4
      Links ok

```

**show chassis fabric
fpcs lcc (TX Matrix
Plus Router)**

```

user@host> show chassis fabric fpcs lcc 0
lcc0-re1:

```

Fabric management FPC state:

```

FPC #3
  PFE #1
    SIB #2
      Plane enabled
    SIB #3
      Link error
      Destination error on PFes
      8   9  10  11  12  13  14  15  16  17  18  19  20  21
      0   1   2   3   4   5   6   7
    SIB #4
      Destination error on PFes
      8   9  10  11  12  13  14  15  16  17  18  19  20  21
      0   1   2   3   4   5   6   7
FPC #4
  PFE #0
    SIB #0 Links ok
    SIB #1 Links ok
    SIB #2 Links ok
    SIB #3 Links ok
    SIB #4 Links ok
  PFE #1
    SIB #0 Links ok
    SIB #1 Links ok

```

```

SIB #2 Links ok
SIB #3 Links ok
SIB #4 Links ok
FPC #6
PFE #0
SIB #0 Links ok
SIB #1 Links ok
SIB #2 Links ok
SIB #3 Links ok
SIB #4 Links ok
PFE #1
SIB #0 Links ok
SIB #1 Links ok
SIB #2 Links ok
SIB #3 Links ok
SIB #4 Links ok
FPC #7
PFE #0
SIB #0 Links ok
SIB #1 Links ok
SIB #2 Links ok
SIB #3 Links ok
SIB #4 Links ok

```

**show chassis fabric
fpcs (EX8200 Switch)**

```

user@host> show chassis fabric fpcs
Fabric management FPC state
FPC 6
PFE #0
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
Plane 8: Plane enabled
Plane 9: Plane enabled
Plane 10: Plane enabled
Plane 11: Plane enabled
PFE #1
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
Plane 8: Plane enabled
Plane 9: Plane enabled
Plane 10: Plane enabled
Plane 11: Plane enabled
FPC 7
PFE #0
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok

```

```
Plane 6: Links ok
Plane 7: Links ok
Plane 8: Plane enabled
Plane 9: Plane enabled
Plane 10: Plane enabled
Plane 11: Plane enabled
PFE #1
Plane 0: Plane enabled
Plane 1: Plane enabled
Plane 2: Plane enabled
Plane 3: Plane enabled
Plane 4: Links ok
Plane 5: Links ok
Plane 6: Links ok
Plane 7: Links ok
Plane 8: Plane enabled
Plane 9: Plane enabled
Plane 10: Plane enabled
Plane 11: Plane enabled
```

show chassis fabric map

Syntax	show chassis fabric map plane <plane-number>
Syntax (MX Series Router)	show chassis fabric map <all-members> <local> <member member-id> <plane plane-number>
Release Information	Command introduced in Junos OS Release 8.0. Command introduced in Junos OS Release 9.4 for EX Series switches.
Description	(M120 and MX Series routers and EX8200 switches only) On the M120 router, display the state of the switching fabric map for connections from the Forwarding Engine Boards (FEBs) to the ports on the fabric planes, as interpreted by the fabric plane. On the MX Series router and the EX8200 switch, display the state of the switching fabric map for connections from each Packet Forwarding Engine on the Dense Port Concentrators (DPCs) to the ports on the fabric planes, as interpreted by the fabric plane. For information about the meaning of “fabric plane”, “DPCs”, and “SIBs” on the switches, see EX Series Switches Hardware and CLI Terminology Mapping.
Options	<p>none—Display the switching fabric map state for the M120 or MX Series router or EX8200 switch.</p> <p>all-members—(MX Series routers only) (Optional) Display the switching fabric map state for all the members of the Virtual Chassis configuration.</p> <p>local—(MX Series routers only) (Optional) Display the switching fabric map state for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display the switching fabric map state for the specified member of the Virtual Chassis configuration. Replace the <i>member-id</i> with a value of 0 or 1.</p> <p>plane <i>plane-number</i>—(Optional) Display the state of the fabric link for the specified plane number.</p> <ul style="list-style-type: none"> For the M120 router, replace <i>plane-number</i> with a value from 0 through 3. For the MX480 and MX240 routers, replace <i>plane-number</i> with a value from 0 through 7. For the MX960 router, replace <i>plane-number</i> with a value from 0 through 5. For the EX8208 switch, replace <i>plane-number</i> with a value from 0 through 11. For the EX8216 switch, replace <i>plane-number</i> with a value from 0 through 7.
Required Privilege Level	view

List of Sample Output **show chassis fabric map (M120 Router) on page 342**
show chassis fabric map (MX Series Routers) on page 342
show chassis fabric map plane 1 (EX8200 Switch) on page 346

Output Fields Table 66 on page 342 lists the output fields for the **show chassis fabric map** command. Output fields are listed in the approximate order in which they appear.

Table 66: show chassis fabric map Output Fields

Field Name	Field Description
in-links	Fabric map for receive side links.
out-links	Fabric map for transmit side links.
state	<p>State of the fabric link:</p> <ul style="list-style-type: none"> • RESET—Link between SIB and FPC/DPC is powered down on purpose. This is done in all non-dual PFE based boards. • UP—Link between SIB and FPC/DPC is up and running. • DOWN—Link between SIB and FPC/DPC is powered down. • FAULT—SIB is in alarmed state where the SIB's plane is not operational for the following reasons: <ul style="list-style-type: none"> • On-board F-chip is not operational. • Fiber optic connector faults. • FPC connector faults. • SIB midplane connector faults.

Sample Output

show chassis fabric map (M120 Router)

```

user@host> show chassis fabric map
FEB0->CB0F0_00 up CB0F0_08->FEB7 Down

FEB1->CB0F0_01 Down CB0F0_09->FEB6 Down

FEB6->CB0F0_02 Down CB0F0_10->FEB1 Down

FEB2->CB0F0_03 Down CB0F0_11->FEB0 up

FEB3->CB0F0_04 Down CB0F0_12->FEB3 Down

FEB4->CB0F0_05 up CB0F0_13->FEB2 Down

FEB7->CB0F0_06 Down CB0F0_14->FEB5 Down

FEB5->CB0F0_07 Down CB0F0_15->FEB4 up:

```

show chassis fabric map (MX Series Routers)

```

user@host> show chassis fabric map
DPC4PFE0->CB0F0_00_0 up CB0F0_00_0->DPC4PFE0 up
DPC4PFE1->CB0F0_00_1 up CB0F0_00_1->DPC4PFE1 up
DPC4PFE2->CB0F0_00_2 up CB0F0_00_2->DPC4PFE2 up
DPC4PFE3->CB0F0_00_3 up CB0F0_00_3->DPC4PFE3 up
DPC7PFE0->CB0F0_01_0 Down CB0F0_01_0->DPC7PFE0 Down
DPC7PFE1->CB0F0_01_1 Down CB0F0_01_1->DPC7PFE1 Down
DPC7PFE2->CB0F0_01_2 Down CB0F0_01_2->DPC7PFE2 Down

```

DPC7PFE3->CB0F0_01_3	Down	CB0F0_01_3->DPC7PFE3	Down
DPC3PFE0->CB0F0_03_0	Down	CB0F0_03_0->DPC3PFE0	Down
DPC3PFE1->CB0F0_03_1	Down	CB0F0_03_1->DPC3PFE1	Down
DPC3PFE2->CB0F0_03_2	Down	CB0F0_03_2->DPC3PFE2	Down
DPC3PFE3->CB0F0_03_3	Down	CB0F0_03_3->DPC3PFE3	Down
DPC8PFE0->CB0F0_05_0	Down	CB0F0_05_0->DPC8PFE0	Down
DPC8PFE1->CB0F0_05_1	Down	CB0F0_05_1->DPC8PFE1	Down
DPC8PFE2->CB0F0_05_2	Down	CB0F0_05_2->DPC8PFE2	Down
DPC8PFE3->CB0F0_05_3	Down	CB0F0_05_3->DPC8PFE3	Down
DPC1PFE0->CB0F0_06_0	Down	CB0F0_06_0->DPC1PFE0	Down
DPC1PFE1->CB0F0_06_1	Down	CB0F0_06_1->DPC1PFE1	Down
DPC1PFE2->CB0F0_06_2	Down	CB0F0_06_2->DPC1PFE2	Down
DPC1PFE3->CB0F0_06_3	Down	CB0F0_06_3->DPC1PFE3	Down
DPC10PFE0->CB0F0_07_0	Down	CB0F0_07_0->DPC10PFE0	Down
DPC10PFE1->CB0F0_07_1	Down	CB0F0_07_1->DPC10PFE1	Down
DPC10PFE2->CB0F0_07_2	Down	CB0F0_07_2->DPC10PFE2	Down
DPC10PFE3->CB0F0_07_3	Down	CB0F0_07_3->DPC10PFE3	Down
DPC11PFE0->CB0F0_08_0	Down	CB0F0_08_0->DPC11PFE0	Down
DPC11PFE1->CB0F0_08_1	Down	CB0F0_08_1->DPC11PFE1	Down
DPC11PFE2->CB0F0_08_2	Down	CB0F0_08_2->DPC11PFE2	Down
DPC11PFE3->CB0F0_08_3	Down	CB0F0_08_3->DPC11PFE3	Down
DPC0PFE0->CB0F0_09_0	Down	CB0F0_09_0->DPC0PFE0	Down
DPC0PFE1->CB0F0_09_1	Down	CB0F0_09_1->DPC0PFE1	Down
DPC0PFE2->CB0F0_09_2	Down	CB0F0_09_2->DPC0PFE2	Down
DPC0PFE3->CB0F0_09_3	Down	CB0F0_09_3->DPC0PFE3	Down
DPC9PFE0->CB0F0_11_0	Down	CB0F0_11_0->DPC9PFE0	Down
DPC9PFE1->CB0F0_11_1	Down	CB0F0_11_1->DPC9PFE1	Down
DPC9PFE2->CB0F0_11_2	Down	CB0F0_11_2->DPC9PFE2	Down
DPC9PFE3->CB0F0_11_3	Down	CB0F0_11_3->DPC9PFE3	Down
DPC2PFE0->CB0F0_13_0	up	CB0F0_13_0->DPC2PFE0	up
DPC2PFE1->CB0F0_13_1	up	CB0F0_13_1->DPC2PFE1	up
DPC2PFE2->CB0F0_13_2	up	CB0F0_13_2->DPC2PFE2	up
DPC2PFE3->CB0F0_13_3	up	CB0F0_13_3->DPC2PFE3	up
DPC6PFE0->CB0F0_14_0	Down	CB0F0_14_0->DPC6PFE0	Down
DPC6PFE1->CB0F0_14_1	Down	CB0F0_14_1->DPC6PFE1	Down
DPC6PFE2->CB0F0_14_2	Down	CB0F0_14_2->DPC6PFE2	Down
DPC6PFE3->CB0F0_14_3	Down	CB0F0_14_3->DPC6PFE3	Down
DPC5PFE0->CB0F0_15_0	Down	CB0F0_15_0->DPC5PFE0	Down
DPC5PFE1->CB0F0_15_1	Down	CB0F0_15_1->DPC5PFE1	Down
DPC5PFE2->CB0F0_15_2	Down	CB0F0_15_2->DPC5PFE2	Down
DPC5PFE3->CB0F0_15_3	Down	CB0F0_15_3->DPC5PFE3	Down
DPC4PFE0->CB0F1_00_0	up	CB0F1_00_0->DPC4PFE0	up
DPC4PFE1->CB0F1_00_1	up	CB0F1_00_1->DPC4PFE1	up
DPC4PFE2->CB0F1_00_2	up	CB0F1_00_2->DPC4PFE2	up
DPC4PFE3->CB0F1_00_3	up	CB0F1_00_3->DPC4PFE3	up
DPC7PFE0->CB0F1_01_0	Down	CB0F1_01_0->DPC7PFE0	Down
DPC7PFE1->CB0F1_01_1	Down	CB0F1_01_1->DPC7PFE1	Down
DPC7PFE2->CB0F1_01_2	Down	CB0F1_01_2->DPC7PFE2	Down
DPC7PFE3->CB0F1_01_3	Down	CB0F1_01_3->DPC7PFE3	Down
DPC3PFE0->CB0F1_03_0	Down	CB0F1_03_0->DPC3PFE0	Down
DPC3PFE1->CB0F1_03_1	Down	CB0F1_03_1->DPC3PFE1	Down
DPC3PFE2->CB0F1_03_2	Down	CB0F1_03_2->DPC3PFE2	Down
DPC3PFE3->CB0F1_03_3	Down	CB0F1_03_3->DPC3PFE3	Down
DPC8PFE0->CB0F1_05_0	Down	CB0F1_05_0->DPC8PFE0	Down
DPC8PFE1->CB0F1_05_1	Down	CB0F1_05_1->DPC8PFE1	Down
DPC8PFE2->CB0F1_05_2	Down	CB0F1_05_2->DPC8PFE2	Down
DPC8PFE3->CB0F1_05_3	Down	CB0F1_05_3->DPC8PFE3	Down
DPC1PFE0->CB0F1_06_0	Down	CB0F1_06_0->DPC1PFE0	Down
DPC1PFE1->CB0F1_06_1	Down	CB0F1_06_1->DPC1PFE1	Down
DPC1PFE2->CB0F1_06_2	Down	CB0F1_06_2->DPC1PFE2	Down
DPC1PFE3->CB0F1_06_3	Down	CB0F1_06_3->DPC1PFE3	Down

DPC10PFE0->CB0F1_07_0	Down	CB0F1_07_0->DPC10PFE0	Down
DPC10PFE1->CB0F1_07_1	Down	CB0F1_07_1->DPC10PFE1	Down
DPC10PFE2->CB0F1_07_2	Down	CB0F1_07_2->DPC10PFE2	Down
DPC10PFE3->CB0F1_07_3	Down	CB0F1_07_3->DPC10PFE3	Down
DPC11PFE0->CB0F1_08_0	Down	CB0F1_08_0->DPC11PFE0	Down
DPC11PFE1->CB0F1_08_1	Down	CB0F1_08_1->DPC11PFE1	Down
DPC11PFE2->CB0F1_08_2	Down	CB0F1_08_2->DPC11PFE2	Down
DPC11PFE3->CB0F1_08_3	Down	CB0F1_08_3->DPC11PFE3	Down
DPC0PFE0->CB0F1_09_0	Down	CB0F1_09_0->DPC0PFE0	Down
DPC0PFE1->CB0F1_09_1	Down	CB0F1_09_1->DPC0PFE1	Down
DPC0PFE2->CB0F1_09_2	Down	CB0F1_09_2->DPC0PFE2	Down
DPC0PFE3->CB0F1_09_3	Down	CB0F1_09_3->DPC0PFE3	Down
DPC9PFE0->CB0F1_11_0	Down	CB0F1_11_0->DPC9PFE0	Down
DPC9PFE1->CB0F1_11_1	Down	CB0F1_11_1->DPC9PFE1	Down
DPC9PFE2->CB0F1_11_2	Down	CB0F1_11_2->DPC9PFE2	Down
DPC9PFE3->CB0F1_11_3	Down	CB0F1_11_3->DPC9PFE3	Down
DPC2PFE0->CB0F1_13_0	up	CB0F1_13_0->DPC2PFE0	up
DPC2PFE1->CB0F1_13_1	up	CB0F1_13_1->DPC2PFE1	up
DPC2PFE2->CB0F1_13_2	up	CB0F1_13_2->DPC2PFE2	up
DPC2PFE3->CB0F1_13_3	up	CB0F1_13_3->DPC2PFE3	up
DPC6PFE0->CB0F1_14_0	Down	CB0F1_14_0->DPC6PFE0	Down
DPC6PFE1->CB0F1_14_1	Down	CB0F1_14_1->DPC6PFE1	Down
DPC6PFE2->CB0F1_14_2	Down	CB0F1_14_2->DPC6PFE2	Down
DPC6PFE3->CB0F1_14_3	Down	CB0F1_14_3->DPC6PFE3	Down
DPC5PFE0->CB0F1_15_0	Down	CB0F1_15_0->DPC5PFE0	Down
DPC5PFE1->CB0F1_15_1	Down	CB0F1_15_1->DPC5PFE1	Down
DPC5PFE2->CB0F1_15_2	Down	CB0F1_15_2->DPC5PFE2	Down
DPC5PFE3->CB0F1_15_3	Down	CB0F1_15_3->DPC5PFE3	Down
DPC4PFE0->CB1F0_00_0	up	CB1F0_00_0->DPC4PFE0	up
DPC4PFE1->CB1F0_00_1	up	CB1F0_00_1->DPC4PFE1	up
DPC4PFE2->CB1F0_00_2	up	CB1F0_00_2->DPC4PFE2	up
DPC4PFE3->CB1F0_00_3	up	CB1F0_00_3->DPC4PFE3	up
DPC7PFE0->CB1F0_01_0	Down	CB1F0_01_0->DPC7PFE0	Down
DPC7PFE1->CB1F0_01_1	Down	CB1F0_01_1->DPC7PFE1	Down
DPC7PFE2->CB1F0_01_2	Down	CB1F0_01_2->DPC7PFE2	Down
DPC7PFE3->CB1F0_01_3	Down	CB1F0_01_3->DPC7PFE3	Down
DPC3PFE0->CB1F0_03_0	Down	CB1F0_03_0->DPC3PFE0	Down
DPC3PFE1->CB1F0_03_1	Down	CB1F0_03_1->DPC3PFE1	Down
DPC3PFE2->CB1F0_03_2	Down	CB1F0_03_2->DPC3PFE2	Down
DPC3PFE3->CB1F0_03_3	Down	CB1F0_03_3->DPC3PFE3	Down
DPC8PFE0->CB1F0_05_0	Down	CB1F0_05_0->DPC8PFE0	Down
DPC8PFE1->CB1F0_05_1	Down	CB1F0_05_1->DPC8PFE1	Down
DPC8PFE2->CB1F0_05_2	Down	CB1F0_05_2->DPC8PFE2	Down
DPC8PFE3->CB1F0_05_3	Down	CB1F0_05_3->DPC8PFE3	Down
DPC1PFE0->CB1F0_06_0	Down	CB1F0_06_0->DPC1PFE0	Down
DPC1PFE1->CB1F0_06_1	Down	CB1F0_06_1->DPC1PFE1	Down
DPC1PFE2->CB1F0_06_2	Down	CB1F0_06_2->DPC1PFE2	Down
DPC1PFE3->CB1F0_06_3	Down	CB1F0_06_3->DPC1PFE3	Down
DPC10PFE0->CB1F0_07_0	Down	CB1F0_07_0->DPC10PFE0	Down
DPC10PFE1->CB1F0_07_1	Down	CB1F0_07_1->DPC10PFE1	Down
DPC10PFE2->CB1F0_07_2	Down	CB1F0_07_2->DPC10PFE2	Down
DPC10PFE3->CB1F0_07_3	Down	CB1F0_07_3->DPC10PFE3	Down
DPC11PFE0->CB1F0_08_0	Down	CB1F0_08_0->DPC11PFE0	Down
DPC11PFE1->CB1F0_08_1	Down	CB1F0_08_1->DPC11PFE1	Down
DPC11PFE2->CB1F0_08_2	Down	CB1F0_08_2->DPC11PFE2	Down
DPC11PFE3->CB1F0_08_3	Down	CB1F0_08_3->DPC11PFE3	Down
DPC0PFE0->CB1F0_09_0	Down	CB1F0_09_0->DPC0PFE0	Down
DPC0PFE1->CB1F0_09_1	Down	CB1F0_09_1->DPC0PFE1	Down
DPC0PFE2->CB1F0_09_2	Down	CB1F0_09_2->DPC0PFE2	Down
DPC0PFE3->CB1F0_09_3	Down	CB1F0_09_3->DPC0PFE3	Down
DPC9PFE0->CB1F0_11_0	Down	CB1F0_11_0->DPC9PFE0	Down

DPC9PFE1->CB1F0_11_1	Down	CB1F0_11_1->DPC9PFE1	Down
DPC9PFE2->CB1F0_11_2	Down	CB1F0_11_2->DPC9PFE2	Down
DPC9PFE3->CB1F0_11_3	Down	CB1F0_11_3->DPC9PFE3	Down
DPC2PFE0->CB1F0_13_0	up	CB1F0_13_0->DPC2PFE0	up
DPC2PFE1->CB1F0_13_1	up	CB1F0_13_1->DPC2PFE1	up
DPC2PFE2->CB1F0_13_2	up	CB1F0_13_2->DPC2PFE2	up
DPC2PFE3->CB1F0_13_3	up	CB1F0_13_3->DPC2PFE3	up
DPC6PFE0->CB1F0_14_0	Down	CB1F0_14_0->DPC6PFE0	Down
DPC6PFE1->CB1F0_14_1	Down	CB1F0_14_1->DPC6PFE1	Down
DPC6PFE2->CB1F0_14_2	Down	CB1F0_14_2->DPC6PFE2	Down
DPC6PFE3->CB1F0_14_3	Down	CB1F0_14_3->DPC6PFE3	Down
DPC5PFE0->CB1F0_15_0	Down	CB1F0_15_0->DPC5PFE0	Down
DPC5PFE1->CB1F0_15_1	Down	CB1F0_15_1->DPC5PFE1	Down
DPC5PFE2->CB1F0_15_2	Down	CB1F0_15_2->DPC5PFE2	Down
DPC5PFE3->CB1F0_15_3	Down	CB1F0_15_3->DPC5PFE3	Down
DPC4PFE0->CB1F1_00_0	up	CB1F1_00_0->DPC4PFE0	up
DPC4PFE1->CB1F1_00_1	up	CB1F1_00_1->DPC4PFE1	up
DPC4PFE2->CB1F1_00_2	up	CB1F1_00_2->DPC4PFE2	up
DPC4PFE3->CB1F1_00_3	up	CB1F1_00_3->DPC4PFE3	up
DPC7PFE0->CB1F1_01_0	Down	CB1F1_01_0->DPC7PFE0	Down
DPC7PFE1->CB1F1_01_1	Down	CB1F1_01_1->DPC7PFE1	Down
DPC7PFE2->CB1F1_01_2	Down	CB1F1_01_2->DPC7PFE2	Down
DPC7PFE3->CB1F1_01_3	Down	CB1F1_01_3->DPC7PFE3	Down
DPC3PFE0->CB1F1_03_0	Down	CB1F1_03_0->DPC3PFE0	Down
DPC3PFE1->CB1F1_03_1	Down	CB1F1_03_1->DPC3PFE1	Down
DPC3PFE2->CB1F1_03_2	Down	CB1F1_03_2->DPC3PFE2	Down
DPC3PFE3->CB1F1_03_3	Down	CB1F1_03_3->DPC3PFE3	Down
DPC8PFE0->CB1F1_05_0	Down	CB1F1_05_0->DPC8PFE0	Down
DPC8PFE1->CB1F1_05_1	Down	CB1F1_05_1->DPC8PFE1	Down
DPC8PFE2->CB1F1_05_2	Down	CB1F1_05_2->DPC8PFE2	Down
DPC8PFE3->CB1F1_05_3	Down	CB1F1_05_3->DPC8PFE3	Down
DPC1PFE0->CB1F1_06_0	Down	CB1F1_06_0->DPC1PFE0	Down
DPC1PFE1->CB1F1_06_1	Down	CB1F1_06_1->DPC1PFE1	Down
DPC1PFE2->CB1F1_06_2	Down	CB1F1_06_2->DPC1PFE2	Down
DPC1PFE3->CB1F1_06_3	Down	CB1F1_06_3->DPC1PFE3	Down
DPC10PFE0->CB1F1_07_0	Down	CB1F1_07_0->DPC10PFE0	Down
DPC10PFE1->CB1F1_07_1	Down	CB1F1_07_1->DPC10PFE1	Down
DPC10PFE2->CB1F1_07_2	Down	CB1F1_07_2->DPC10PFE2	Down
DPC10PFE3->CB1F1_07_3	Down	CB1F1_07_3->DPC10PFE3	Down
DPC11PFE0->CB1F1_08_0	Down	CB1F1_08_0->DPC11PFE0	Down
DPC11PFE1->CB1F1_08_1	Down	CB1F1_08_1->DPC11PFE1	Down
DPC11PFE2->CB1F1_08_2	Down	CB1F1_08_2->DPC11PFE2	Down
DPC11PFE3->CB1F1_08_3	Down	CB1F1_08_3->DPC11PFE3	Down
DPC0PFE0->CB1F1_09_0	Down	CB1F1_09_0->DPC0PFE0	Down
DPC0PFE1->CB1F1_09_1	Down	CB1F1_09_1->DPC0PFE1	Down
DPC0PFE2->CB1F1_09_2	Down	CB1F1_09_2->DPC0PFE2	Down
DPC0PFE3->CB1F1_09_3	Down	CB1F1_09_3->DPC0PFE3	Down
DPC9PFE0->CB1F1_11_0	Down	CB1F1_11_0->DPC9PFE0	Down
DPC9PFE1->CB1F1_11_1	Down	CB1F1_11_1->DPC9PFE1	Down
DPC9PFE2->CB1F1_11_2	Down	CB1F1_11_2->DPC9PFE2	Down
DPC9PFE3->CB1F1_11_3	Down	CB1F1_11_3->DPC9PFE3	Down
DPC2PFE0->CB1F1_13_0	up	CB1F1_13_0->DPC2PFE0	up
DPC2PFE1->CB1F1_13_1	up	CB1F1_13_1->DPC2PFE1	up
DPC2PFE2->CB1F1_13_2	up	CB1F1_13_2->DPC2PFE2	up
DPC2PFE3->CB1F1_13_3	up	CB1F1_13_3->DPC2PFE3	up
DPC6PFE0->CB1F1_14_0	Down	CB1F1_14_0->DPC6PFE0	Down
DPC6PFE1->CB1F1_14_1	Down	CB1F1_14_1->DPC6PFE1	Down
DPC6PFE2->CB1F1_14_2	Down	CB1F1_14_2->DPC6PFE2	Down
DPC6PFE3->CB1F1_14_3	Down	CB1F1_14_3->DPC6PFE3	Down
DPC5PFE0->CB1F1_15_0	Down	CB1F1_15_0->DPC5PFE0	Down
DPC5PFE1->CB1F1_15_1	Down	CB1F1_15_1->DPC5PFE1	Down

```

DPC5PFE2->CB1F1_15_2    Down    CB1F1_15_2->DPC5PFE2    Down
DPC5PFE3->CB1F1_15_3    Down    CB1F1_15_3->DPC5PFE3    Down
plane 4 is not up
plane 5 is not up

```

**show chassis fabric
map plane 1 (EX8200
Switch)**

```

user@host> show chassis fabric map plane 1
regress@tp-grande01> show chassis fabric map plane 1
DPC6PFE0->CB0F0_00_0    Down    CB0F0_00_0->DPC6PFE0    Down
DPC6PFE1->CB0F0_00_1    Down    CB0F0_00_1->DPC6PFE1    Down
DPC6PFE2->CB0F0_00_2    Down    CB0F0_00_2->DPC6PFE2    Down
DPC6PFE3->CB0F0_00_3    Down    CB0F0_00_3->DPC6PFE3    Down
DPC0PFE0->CB0F0_01_0    Down    CB0F0_01_0->DPC0PFE0    Down
DPC0PFE1->CB0F0_01_1    Down    CB0F0_01_1->DPC0PFE1    Down
DPC0PFE2->CB0F0_01_2    Down    CB0F0_01_2->DPC0PFE2    Down
DPC0PFE3->CB0F0_01_3    Down    CB0F0_01_3->DPC0PFE3    Down
DPC5PFE0->CB0F0_02_0    Down    CB0F0_02_0->DPC5PFE0    Down
DPC5PFE1->CB0F0_02_1    Down    CB0F0_02_1->DPC5PFE1    Down
DPC5PFE2->CB0F0_02_2    Down    CB0F0_02_2->DPC5PFE2    Down
DPC5PFE3->CB0F0_02_3    Down    CB0F0_02_3->DPC5PFE3    Down
DPC3PFE0->CB0F0_03_0    Down    CB0F0_03_0->DPC3PFE0    Down
DPC3PFE1->CB0F0_03_1    Down    CB0F0_03_1->DPC3PFE1    Down
DPC3PFE2->CB0F0_03_2    Down    CB0F0_03_2->DPC3PFE2    Down
DPC3PFE3->CB0F0_03_3    Down    CB0F0_03_3->DPC3PFE3    Down
DPC4PFE0->CB0F0_04_0    Down    CB0F0_04_0->DPC4PFE0    Down
DPC4PFE1->CB0F0_04_1    Down    CB0F0_04_1->DPC4PFE1    Down
DPC4PFE2->CB0F0_04_2    Down    CB0F0_04_2->DPC4PFE2    Down
DPC4PFE3->CB0F0_04_3    Down    CB0F0_04_3->DPC4PFE3    Down
DPC2PFE0->CB0F0_05_0    Down    CB0F0_05_0->DPC2PFE0    Down
DPC2PFE1->CB0F0_05_1    Down    CB0F0_05_1->DPC2PFE1    Down
DPC2PFE2->CB0F0_05_2    Down    CB0F0_05_2->DPC2PFE2    Down
DPC2PFE3->CB0F0_05_3    Down    CB0F0_05_3->DPC2PFE3    Down
DPC7PFE0->CB0F0_06_0    Down    CB0F0_06_0->DPC7PFE0    Down
DPC7PFE1->CB0F0_06_1    Down    CB0F0_06_1->DPC7PFE1    Down
DPC7PFE2->CB0F0_06_2    Down    CB0F0_06_2->DPC7PFE2    Down
DPC7PFE3->CB0F0_06_3    Down    CB0F0_06_3->DPC7PFE3    Down
DPC1PFE0->CB0F0_07_0    Down    CB0F0_07_0->DPC1PFE0    Down
DPC1PFE1->CB0F0_07_1    Down    CB0F0_07_1->DPC1PFE1    Down
DPC1PFE2->CB0F0_07_2    Down    CB0F0_07_2->DPC1PFE2    Down
DPC1PFE3->CB0F0_07_3    Down    CB0F0_07_3->DPC1PFE3    Down
DPC0PFE0->CB0F0_08_0    Down    CB0F0_08_0->DPC0PFE0    Down
DPC0PFE1->CB0F0_08_1    Down    CB0F0_08_1->DPC0PFE1    Down
DPC0PFE2->CB0F0_08_2    Down    CB0F0_08_2->DPC0PFE2    Down
DPC0PFE3->CB0F0_08_3    Down    CB0F0_08_3->DPC0PFE3    Down
DPC7PFE0->CB0F0_09_0    Down    CB0F0_09_0->DPC7PFE0    Down
DPC7PFE1->CB0F0_09_1    Down    CB0F0_09_1->DPC7PFE1    Down
DPC7PFE2->CB0F0_09_2    Down    CB0F0_09_2->DPC7PFE2    Down
DPC7PFE3->CB0F0_09_3    Down    CB0F0_09_3->DPC7PFE3    Down
DPC1PFE0->CB0F0_10_0    Down    CB0F0_10_0->DPC1PFE0    Down
DPC1PFE1->CB0F0_10_1    Down    CB0F0_10_1->DPC1PFE1    Down
DPC1PFE2->CB0F0_10_2    Down    CB0F0_10_2->DPC1PFE2    Down
DPC1PFE3->CB0F0_10_3    Down    CB0F0_10_3->DPC1PFE3    Down
DPC4PFE0->CB0F0_11_0    Down    CB0F0_11_0->DPC4PFE0    Down
DPC4PFE1->CB0F0_11_1    Down    CB0F0_11_1->DPC4PFE1    Down
DPC4PFE2->CB0F0_11_2    Down    CB0F0_11_2->DPC4PFE2    Down
DPC4PFE3->CB0F0_11_3    Down    CB0F0_11_3->DPC4PFE3    Down
DPC2PFE0->CB0F0_12_0    Down    CB0F0_12_0->DPC2PFE0    Down
DPC2PFE1->CB0F0_12_1    Down    CB0F0_12_1->DPC2PFE1    Down
DPC2PFE2->CB0F0_12_2    Down    CB0F0_12_2->DPC2PFE2    Down
DPC2PFE3->CB0F0_12_3    Down    CB0F0_12_3->DPC2PFE3    Down
DPC5PFE0->CB0F0_13_0    Down    CB0F0_13_0->DPC5PFE0    Down
DPC5PFE1->CB0F0_13_1    Down    CB0F0_13_1->DPC5PFE1    Down

```

DPC5PFE2->CB0F0_13_2	Down	CB0F0_13_2->DPC5PFE2	Down
DPC5PFE3->CB0F0_13_3	Down	CB0F0_13_3->DPC5PFE3	Down
DPC3PFE0->CB0F0_14_0	Down	CB0F0_14_0->DPC3PFE0	Down
DPC3PFE1->CB0F0_14_1	Down	CB0F0_14_1->DPC3PFE1	Down
DPC3PFE2->CB0F0_14_2	Down	CB0F0_14_2->DPC3PFE2	Down
DPC3PFE3->CB0F0_14_3	Down	CB0F0_14_3->DPC3PFE3	Down
DPC6PFE0->CB0F0_15_0	Down	CB0F0_15_0->DPC6PFE0	Down
DPC6PFE1->CB0F0_15_1	Down	CB0F0_15_1->DPC6PFE1	Down
DPC6PFE2->CB0F0_15_2	Down	CB0F0_15_2->DPC6PFE2	Down
DPC6PFE3->CB0F0_15_3	Down	CB0F0_15_3->DPC6PFE3	Down

show chassis fabric plane

Syntax	show chassis fabric plane
Syntax (TX Matrix Plus Router)	show chassis fabric plane <detail extensive terse> <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis fabric plane <detail extensive terse> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced in Junos OS Release 8.0. Command introduced in Junos OS Release 9.4 for EX Series switches. detail , extensive , lcc , sfc , and terse options introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(TX Matrix Plus, T1600, M120, and MX Series routers and EX8200 switches only) On the M120 router, display the state of all fabric plane connections to the Forwarding Engine Boards (FEBs). On MX Series routers, display the state of all fabric plane connections to the Dense Port Concentrators (DPCs) and Packet Forwarding Engines (PFEs) on the Flexible PIC Concentrators (FPCs). On the TX Matrix Plus router and T1600 routers in a routing matrix, display the state of the fabric management plane and the logical planes on the switch-fabric chassis (SFC) and line-card chassis (LCC). On EX8200 switches, display the state of all fabric planes. This command can be used on the master Routing Engine only.
Options	<p>detail—(TX Matrix Plus and T1600 routers in a routing matrix, and MX Series routers only) (Optional) Display detailed output for the fabric management plane. Show Switch Interface Board (SIB) states for the TXP-F13 SIB and TXP-F2S SIB.</p> <p>extensive—(TX Matrix Plus and T1600 routers in a routing matrix, and MX Series routers only) (Optional) Display extensive output for the fabric management plane, including the state of the optical links between the F13 SIB on the TX Matrix Plus router and the TXP-T1600 SIB (ST-SIB-L) on the T1600 router.</p> <p>terse—(TX Matrix Plus router and MX Series routers only) (Optional) Display terse output for the fabric management plane.</p> <p>all-members—(MX Series routers only) (Optional) Display the state of all fabric plane connections on all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix Plus router only) (Optional) T1600 router (LCC) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display the state of all fabric plane connections on the local Virtual Chassis member.</p>

member *member-id*—(MX Series routers only) (Optional) Display the state of all fabric plane connections on the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

sfc *number*—(TX Matrix Plus router only) (Optional) Show information about the TX Matrix Plus router (SFC). Replace *number* with 0.

Required Privilege Level view

List of Sample Output

- show chassis fabric plane (M120 Router) on page 354
- show chassis fabric plane (MX240 Router) on page 354
- show chassis fabric plane (MX480 Router) on page 356
- show chassis fabric plane (MX960 Router) on page 357
- show chassis fabric plane (TX Matrix Plus Router) on page 358
- show chassis fabric plane detail (TX Matrix Plus Router) on page 358
- show chassis fabric plane extensive (TX Matrix Plus Router) on page 359
- show chassis fabric plane terse (TX Matrix Plus Router) on page 361
- show chassis fabric plane lcc (TX Matrix Plus Router) on page 361
- show chassis fabric plane sfc (TX Matrix Plus Router) on page 362
- show chassis fabric plane (T1600 Router) on page 362
- show chassis fabric plane extensive (T1600 Router) on page 362
- show chassis fabric plane detail (T1600 Router) on page 365
- show chassis fabric plane extensive (TX Matrix Plus Router) on page 365
- show chassis fabric plane (EX8200 Switch) on page 368

Output Fields Table 67 on page 349 lists the output fields for the **show chassis fabric plane** command. Output fields are listed in the approximate order in which they appear.

Table 67: show chassis fabric plane Output Fields

Field Name	Field Description	Level of output
Plane	(TX Matrix Plus, MX Series, and M120 routers and EX8200 switches only) Number of the plane.	none
Plane state	<p>(MX Series and M120 routers and EX8200 switches only) State of each plane:</p> <ul style="list-style-type: none"> • ACTIVE—SIB is operational and running. • FAULTY— SIB is in alarmed state where the SIB's plane is not operational for the following reasons: <ul style="list-style-type: none"> • On-board fabric ASIC is not operational. • Fiber optic connector faults. • FPC connector faults. • SIB midplane connector faults. 	none
FEB	<p>(M120 routers only) FEB number and state of links to each FEB:</p> <ul style="list-style-type: none"> • Link error—Link between SIB and FPC is not operational. • Links ok—Link between SIB and FPC is active. • Unused—No FPC is present. 	none

Table 67: show chassis fabric plane Output Fields (*continued*)

Field Name	Field Description	Level of output
FPC	(MX Series routers only) Slot number of each Dense Port Concentrator (DPC) or Flexible PIC Concentrator (FPC). An FPC occupies two DPC slots on an MX Series router. The interface corresponds to the lowest numbered DPC slot for which the FPC is installed.	none
PFE	<p>(MX Series and M120 routers only) Slot number of each Packet Forwarding Engine and the state of the links to the DCP: Links ok, Link error, or Unused. Each DPC includes four Packet Forwarding Engines.</p> <p>Links ok: Link between SIB and FPC is active. Link error: Link between SIB and FPC is not operational. Unused: No FPC is present.</p>	none
State	<p>(TX Matrix Plus and T1600 routers in a routing matrix only)—State of the fabric plane:</p> <ul style="list-style-type: none"> • Online: Fabric plane is operational and running and links on the SIB are operational. • Offline: Fabric plane state is Offline because the plane does not have four or more F2S and one F13 online. • Empty: Fabric plane state is Empty if all SIBs in the plane are absent. • Spare: Fabric plane is redundant and can be operational if the operational fabric plane encounters an error. • Check: Fabric plane is in alarmed state due to the following reason and the cause of the error must be resolved: <ul style="list-style-type: none"> • One or more SIBs (belonging to the fabric plane) in the Online or Spare states has transitioned to the Check state. Check state of the SIB can be caused by link errors or destination errors. • Fault: Fabric plane is in alarmed state if one or more SIBs belonging to the plane are in the Fault state. A SIB can be in the Fault state because of the following reasons: <ul style="list-style-type: none"> • On-board fabric ASIC is not operational. • Fiber optic connector faults. • FPC connector faults. • SIB midplane connector faults. • Link errors have exceeded the threshold. 	none
Uptime	(TX Matrix Plus and T1600 routers in a routing matrix only)—Time the fabric plane has been up and running.	none

Fabric Management Plane State Output Fields for the show chassis fabric plane extensive Command on a TX Matrix Plus Router

Table 67: show chassis fabric plane Output Fields (*continued*)

Field Name	Field Description	Level of output
PLANE number	<p>State of the fabric plane:</p> <ul style="list-style-type: none"> • Online: Fabric plane is operational and running and links on the SIB are operational. • Offline: Fabric plane state is Offline because the plane does not have 4 or more F2S and 1 F13 online. • Empty: Fabric plane state is Empty if all SIBs in the plane are absent. • Spare: Fabric plane is redundant and can be operational if the operational fabric plane encounters an error. • Check: Fabric plane is in alarmed state due to the following reasons and the cause of the error must be resolved: <ul style="list-style-type: none"> • One or more SIBs (belonging to the fabric plane) in the Online or Spare states has transitioned to the Check state. Check state of the SIB can be caused because of link errors or destination errors. • Fault: Fabric plane is in alarmed state if one or more SIBs belonging to the plane are in the Fault state. A SIB can be in the Fault state because of the following reasons: <ul style="list-style-type: none"> • On-board fabric ASIC is not operational. • Fiber optic connector faults. • FPC connector faults. • SIB midplane connector faults. • Link errors have exceeded the threshold. 	extensive
SIB F13/F2S slot-number	<p>State of the TXP-F13 SIB or TXP-F2S SIB:</p> <ul style="list-style-type: none"> • Activating—Transitional state when the SIB is transitioning to the Online or Spare state. • Deactivating—Transitional state when the SIB is going offline. • Online—SIB is operational and running. • Offline—SIB is powered down. • Spare—SIB is redundant and will move to active state if one of the working SIBs fails to pass traffic. • Empty—No SIB is present. • Fault—SIB is in alarmed state because of the following reasons and the cause of the error must be resolved: <ul style="list-style-type: none"> • On-board fabric ASIC is not operational. • Fiber optic connector faults. • FPC connector faults. • SIB midplane connector faults. • Link errors have exceeded the threshold • Check—SIB is in alarmed state where the SIB is partially operational because of link or destination errors. Only a SIB that is Online or Spare can transition to the Check state. <p>NOTE: If a SIB is not inserted properly, the SIB cannot transition to the Online or Spare state, and therefore cannot transition to the Check state.</p>	extensive

Table 67: show chassis fabric plane Output Fields (*continued*)

Field Name	Field Description	Level of output
SIB F13 slot-number Odd/Even	State of the TXP-F13 SIB even and odd port connection optical links from the TX Matrix Plus router (SFC) to the T1600 router (LCC) in the routing matrix. The left four ports on the SFC are labeled Even and provide connections to one even-numbered LCC—LCC0 or LCC2. The right four ports on the SFC are labeled Odd and provide connections to one odd-numbered LCC—LCC1 or LCC3.	extensive
LCC number, SIB slot-number	State of the SIB on the LCC that is connected to the Even or Odd port on the TXP-F13 SIB faceplate: <ul style="list-style-type: none"> • Links ok—Links between the TXP-F13 SIB on the SFC and the LCC is active. • Link error—Link between the TXP-F13 SIB on the SFC and the LCC is not operational. • Unused—No SIB is present. 	extensive
SG number Port number	State of the SG chip ports on the LCC: <ul style="list-style-type: none"> • Links ok—Link is active. • Link error—Link is not operational. • Unused—Port is not in use. 	extensive
SIB F2S slot-number	State of the intra-chassis links between the TXP-F2S and TXP-F13 SIB.	extensive

Fabric Management SIB State Output Fields for the show chassis fabric plane extensive Command on a TX Matrix Plus Router

Table 67: show chassis fabric plane Output Fields (*continued*)

Field Name	Field Description	Level of output
SIB slot-number	<p>State of the SIBs on the T1600 router (LCC) in the routing matrix:</p> <ul style="list-style-type: none"> • Activating—Transitional state when the SIB is coming online. • Deactivating—Transitional state when the SIB is going offline. • Connected—SIBs on an LCC are connected and trained, but are either not online or are spare, because the plane on the TX Matrix Plus router (SFC) is still offline. The LCC SIB transitions to the Connected state when the F13 SIB to which it connects is online but the SFC plane (to which the LCC SIB connects) is offline for some reason; for instance, when there are insufficient number of F2 SIBs in the plane. • Disconnected—If an F13 SIB on the TX Matrix Plus router (SFC) goes offline, then the SIBs on the LCCs connected to the F13 SIB get disconnected. The Disconnected state is valid only for SIBs on an LCC. An LCC SIB transitions to the Disconnected state when the F13 SIB to which it connects goes Offline, irrespective of the state of the SFC plane. SFC Error—If an F13 SIB on the TX Matrix Plus router (SFC) transitions to the Fault state (because of link errors, for instance), and if an LCC SIB connected to the F13 SIB comes online, the LCC SIB transitions to the SFC Error state. This state indicates that the F13 SIB to which the LCC SIB is connected has errors <p>NOTE: The Connected, Disconnected, and SFC Error states are only applicable to the SIBs on an LCC.</p> <ul style="list-style-type: none"> • Online—SIB is operational and running. • Offline—SIB is powered down. • Spare—SIB is redundant and will move to active state if one of the working SIBs fails to pass traffic. • Empty—No SIB is present. • Fault—SIB is in alarmed state where the SIB's plane is not operational for the following reasons: <ul style="list-style-type: none"> • On-board fabric ASIC is not operational. • Fiber optic connector faults. • FPC connector faults. • SIB midplane connector faults. • Link errors have exceeded the threshold • Check—SIB is in alarmed state where the SIB is partially operational because of link or destination errors. Only a SIB that is Online or Spare can transition to the Check state. <p>NOTE: If a SIB is not inserted properly, the SIB cannot transition to the Online or Spare state, and therefore cannot transition to the Check state.</p>	extensive

Table 67: show chassis fabric plane Output Fields (*continued*)

Field Name	Field Description	Level of output
LCC SIB Link State	State of the LCC SIB link: <ul style="list-style-type: none"> • Links ok—Link is active. • Link error—Link is not operational. • Unused—SIB is not in use. 	extensive
SG number Port number	State of the SG chip ports on the LCC: <ul style="list-style-type: none"> • Links ok—Link is active. • Link error—Link is not operational. • Unused—Port is not in use. 	extensive

Sample Output

show chassis fabric plane (M120 Router)

```

user@host> show chassis fabric plane
Fabric management PLANE state
Plane 0
Plane state: ACTIVE
FEB 0: Links ok
FEB 1: Links ok
FEB 2: Links ok
FEB 3: Links ok
FEB 4: Links ok
FEB 5: Links ok
Plane 1
Plane state: ACTIVE
FEB 0: Links ok
FEB 1: Links ok
FEB 2: Links ok
FEB 3: Links ok
FEB 4: Links ok
FEB 5: Links ok
Plane 2
Plane state: ACTIVE
FEB 0: Links ok
FEB 1: Links ok
FEB 2: Links ok
FEB 3: Links ok
FEB 4: Links ok
FEB 5: Links ok
Plane 3
Plane state: ACTIVE
FEB 0: Links ok
FEB 1: Links ok
FEB 2: Links ok
FEB 3: Links ok
FEB 4: Links ok
FEB 5: Links ok

```

show chassis fabric plane (MX240 Router)

```

user@host> show chassis fabric plane
Plane 0
  Plane state: ACTIVE
    FPC 1
      PFE 0 :Links ok

```

```
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 1
  Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 2
  Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 3
  Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 4
  Plane state: SPARE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 5
  Plane state: SPARE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
```

```
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 6
Plane state: SPARE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 7
Plane state: SPARE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
    FPC 2
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
```

show chassis fabric plane (MX480 Router) **user@host> show chassis fabric plane**
Fabric management PLANE state

```
Plane 0
Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 1
Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 2
Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
        PFE 3 :Links ok
Plane 3
Plane state: ACTIVE
    FPC 1
        PFE 0 :Links ok
        PFE 1 :Links ok
        PFE 2 :Links ok
```

```

        PFE 3 :Links ok
Plane 4
  Plane state: SPARE
    FPC 1
      PFE 0 :Links ok
      PFE 1 :Links ok
      PFE 2 :Links ok
      PFE 3 :Links ok
Plane 5
  Plane state: SPARE
    FPC 1
      PFE 0 :Links ok
      PFE 1 :Links ok
      PFE 2 :Links ok
      PFE 3 :Links ok
Plane 6
  Plane state: SPARE
    FPC 1
      PFE 0 :Links ok
      PFE 1 :Links ok
      PFE 2 :Links ok
      PFE 3 :Links ok
Plane 7
  Plane state: SPARE
    FPC 1
      PFE 0 :Links ok
      PFE 1 :Links ok
      PFE 2 :Links ok
      PFE 3 :Links ok

```

**show chassis fabric
plane (MX960 Router)**

```

user@host> show chassis fabric plane
Plane 0
  Plane state: ACTIVE
    FPC 0
      PFE 0 :Links ok
    FPC 2
      PFE 0 :Links ok
      PFE 1 :Links ok
Plane 1
  Plane state: ACTIVE
    FPC 0
      PFE 0 :Links ok
    FPC 2
      PFE 0 :Links ok
      PFE 1 :Links ok
Plane 2
  Plane state: ACTIVE
    FPC 0
      PFE 0 :Links ok
    FPC 2
      PFE 0 :Links ok
      PFE 1 :Links ok
Plane 3
  Plane state: ACTIVE
    FPC 0
      PFE 0 :Links ok
    FPC 2
      PFE 0 :Links ok
      PFE 1 :Links ok

```

**show chassis fabric
plane (TX Matrix Plus
Router)**

```
user@host> show chassis fabric plane
sfc0-re0:
```

Plane	State	Uptime
0	Spare	
1	Online	1 hour, 11 minutes, 26 seconds
2	Online	1 hour, 11 minutes, 25 seconds
3	Online	1 hour, 11 minutes, 20 seconds
4	Online	1 hour, 11 minutes, 12 seconds

```
1cc0-re0:
```

SIB	State	Uptime
0	Spare	
1	Online	5 hours, 11 minutes, 39 seconds
2	Online	5 hours, 11 minutes, 39 seconds
3	Online	5 hours, 11 minutes, 39 seconds
4	Online	5 hours, 11 minutes, 39 seconds

```
1cc1-re0:
```

SIB	State	Uptime
0	Spare	
1	Online	5 hours, 11 minutes, 40 seconds
2	Online	5 hours, 11 minutes, 40 seconds
3	Online	5 hours, 11 minutes, 40 seconds
4	Online	5 hours, 11 minutes, 40 seconds

**show chassis fabric
plane detail (TX Matrix
Plus Router)**

```
user@host> show chassis fabric plane detail
sfc0-re0:
```

```
Fabric Management PLANE State:
```

```
PLANE 0: Spare
  SIB F13 0 : Spare
  SIB F13 1 : Empty
  SIB F2S 0/0 : Spare
  SIB F2S 0/2 : Spare
  SIB F2S 0/4 : Spare
  SIB F2S 0/6 : Spare
PLANE 1: Online
  SIB F13 3 : Online
  SIB F13 4 : Empty
  SIB F2S 1/0 : Online
  SIB F2S 1/2 : Online
  SIB F2S 1/4 : Online
  SIB F2S 1/6 : Online
PLANE 2: Online
  SIB F13 6 : Online
  SIB F13 7 : Empty
  SIB F2S 2/0 : Online
  SIB F2S 2/2 : Online
  SIB F2S 2/4 : Online
  SIB F2S 2/6 : Online
PLANE 3: Online
  SIB F13 8 : Online
  SIB F13 9 : Online
  SIB F2S 3/0 : Online
  SIB F2S 3/2 : Online
  SIB F2S 3/4 : Online
  SIB F2S 3/6 : Online
PLANE 4: Online
```

```

SIB F13 11 : Online
SIB F13 12 : Online
SIB F2S 4/0 : Online
SIB F2S 4/2 : Online
SIB F2S 4/4 : Online
SIB F2S 4/6 : Online

```

```
lcc0-re0:
```

```
-----
Fabric Management SIB State:
```

```

SIB 0 : Spare
SIB 1 : Online
SIB 2 : Online
SIB 3 : Online
SIB 4 : Online

```

```
lcc1-re0:
```

```
-----
Fabric Management SIB State:
```

```

SIB 0 : Spare
SIB 1 : Online
SIB 2 : Online
SIB 3 : Online
SIB 4 : Online

```

**show chassis fabric
plane extensive (TX
Matrix Plus Router)**

```
user@host> show chassis fabric plane extensive
```

```
sfc0-re0:
```

```
-----
Fabric Management PLANE State:
```

```
PLANE 0: Spare
```

```

SIB F13 0 : Spare
SIB F13 1 : Empty
SIB F2S 0/0 : Spare
SIB F2S 0/2 : Spare
SIB F2S 0/4 : Spare
SIB F2S 0/6 : Spare

```

```
SIB F13 0 Even:
```

```
  LCC 0, SIB 0 : Links ok
```

```
    SG 0
```

```

      Port 0 : Links ok
      Port 1 : Links ok
      Port 2 : Links ok
      Port 3 : Links ok

```

```
    SG 1
```

```

      Port 0 : Links ok
      Port 1 : Links ok
      Port 2 : Links ok
      Port 3 : Links ok

```

```
    SG 2
```

```

      Port 0 : Links ok
      Port 1 : Links ok
      Port 2 : Links ok
      Port 3 : Links ok

```

```
    SG 3
```

```

      Port 0 : Links ok
      Port 1 : Links ok
      Port 2 : Links ok
      Port 3 : Links ok

```

```
SIB F13 0 Odd:
```

```
  LCC 1, SIB 0 : Links ok
```

```
    SG 0
```

```

        Port 0      : Links ok
        Port 1      : Links ok
        Port 2      : Links ok
        Port 3      : Links ok
    SG 1
        Port 0      : Links ok
        Port 1      : Links ok
        Port 2      : Links ok
        Port 3      : Links ok
    SG 2
        Port 0      : Links ok
        Port 1      : Links ok
        Port 2      : Links ok
        Port 3      : Links ok
    SG 3
        Port 0      : Links ok
        Port 1      : Links ok
        Port 2      : Links ok
        Port 3      : Links ok
    SIB F2S 0/0: Links ok
    SIB F2S 0/2: Links ok
    SIB F2S 0/4: Links ok
    SIB F2S 0/6: Links ok
SIB F13 1 Even:
    LCC 2, SIB 0 : Unused
    SG 0
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused
        Port 3      : Unused
    SG 1
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused
        Port 3      : Unused
    SG 2
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused
        Port 3      : Unused
    SG 3
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused
        Port 3      : Unused
SIB F13 1 Odd:
    LCC 3, SIB 0 : Unused
    SG 0
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused
        Port 3      : Unused
    SG 1
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused
        Port 3      : Unused
    SG 2
        Port 0      : Unused
        Port 1      : Unused
        Port 2      : Unused

```



```

          Port 3      : Unused
SG 3
          Port 0      : Unused
          Port 1      : Unused
          Port 2      : Unused
          Port 3      : Unused
SIB F2S 0/0: Unused
SIB F2S 0/2: Unused
SIB F2S 0/4: Unused
SIB F2S 0/6: Unused
PLANE 1:  Online
SIB F13 3   :   Online
SIB F13 4   :   Empty
SIB F2S 1/0 :   Online
SIB F2S 1/2 :   Online
SIB F2S 1/4 :   Online
SIB F2S 1/6 :   Online
SIB F13 3 Even:
...

```

**show chassis fabric
plane terse (TX Matrix
Plus Router)**

```
user@host> show chassis fabric plane terse
sfc0-re0:
```

```

-----
Plane  State                Uptime
0      Spare
1      Online                1 hour, 16 minutes, 14 seconds
2      Online                1 hour, 16 minutes, 13 seconds
3      Online                1 hour, 16 minutes, 8 seconds
4      Online                1 hour, 16 minutes

```

```
lcc0-re0:
```

```

-----
SIB    State                Uptime
0      Spare
1      Online                5 hours, 16 minutes, 27 seconds
2      Online                5 hours, 16 minutes, 27 seconds
3      Online                5 hours, 16 minutes, 27 seconds
4      Online                5 hours, 16 minutes, 27 seconds

```

```
lcc1-re0:
```

```

-----
SIB    State                Uptime
0      Spare
1      Online                5 hours, 16 minutes, 28 seconds
2      Online                5 hours, 16 minutes, 28 seconds
3      Online                5 hours, 16 minutes, 28 seconds
4      Online                5 hours, 16 minutes, 28 seconds

```

**show chassis fabric
plane lcc (TX Matrix
Plus Router)**

```
user@host> show chassis fabric plane lcc 7
lcc1-re0:
```

```

-----
SIB    State                Uptime
0      Spare
1      Online                5 hours, 17 minutes, 52 seconds
2      Online                5 hours, 17 minutes, 52 seconds
3      Online                5 hours, 17 minutes, 52 seconds
4      Online                5 hours, 17 minutes, 52 seconds

```

**show chassis fabric
plane sfc (TX Matrix
Plus Router)**

```
user@host> show chassis fabric plane sfc 0
sfc0-re0:
```

Plane	State	Uptime
0	Spare	
1	Online	1 hour, 4 minutes, 43 seconds
2	Online	1 hour, 4 minutes, 38 seconds
3	Online	1 hour, 4 minutes, 35 seconds
4	Online	1 hour, 4 minutes, 33 seconds

```
1cc0-re0:
```

SIB	State	Uptime
0	Spare	
1	Online	1 hour, 7 minutes, 24 seconds
2	Online	1 hour, 7 minutes, 24 seconds
3	Online	1 hour, 7 minutes, 24 seconds
4	Online	1 hour, 7 minutes, 24 seconds

```
1cc1-re0:
```

SIB	State	Uptime
0	Offline	
1	Online	1 hour, 7 minutes, 22 seconds
2	Online	1 hour, 7 minutes, 22 seconds
3	Online	1 hour, 7 minutes, 22 seconds
4	Online	1 hour, 7 minutes, 22 seconds

**show chassis fabric
plane (T1600 Router)**

```
user@host> show chassis fabric plane
```

Plane	State	Uptime
0	Online	15 hours, 42 minutes, 9 seconds
1	Online	15 hours, 42 minutes, 9 seconds
2	Fault	
3	Online	15 hours, 42 minutes, 9 seconds
4	Online	15 hours, 42 minutes, 9 seconds

**show chassis fabric
plane extensive
(T1600 Router)**

```
user@host> show chassis fabric plane extensive
```

```
Fabric Management PLANE State:
```

```
PLANE 0: Online
```

```
ST-SIB-L 0: Links ok
```

```
SG 0
```

```
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
```

```
SG 1
```

```
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
```

```
SG 2
```

```
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
```

```
SG 3
```

```
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
```

```
ST-SIB-L 0
  FPC 4
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 6
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 7
    PFE 0: Links ok
PLANE 1:  Online
ST-SIB-L 1: Links ok
  SG 0
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
  SG 1
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
  SG 2
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
  SG 3
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
ST-SIB-L 1
  FPC 4
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 6
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 7
    PFE 0: Links ok
PLANE 2:  Online
ST-SIB-L 2: Links ok
  SG 0
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
  SG 1
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
  SG 2
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
  SG 3
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
```

```

    Port 3      : Links ok
ST-SIB-L 2
  FPC 4
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 6
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 7
    PFE 0: Links ok
PLANE 3:   Spare
ST-SIB-L 3: Links ok
  SG 0
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
  SG 1
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
  SG 2
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
  SG 3
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
ST-SIB-L 3
  FPC 4
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 6
    PFE 0: Links ok
    PFE 1: Links ok
  FPC 7
    PFE 0: Links ok
PLANE 4:   Online
ST-SIB-L 4: Links ok
  SG 0
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
  SG 1
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
  SG 2
    Port 0      : Links ok
    Port 1      : Links ok
    Port 2      : Links ok
    Port 3      : Links ok
  SG 3
    Port 0      : Links ok
    Port 1      : Links ok
```

```

Port 2    : Links ok
Port 3    : Links ok
ST-SIB-L 4
FPC 4
PFE 0: Links ok
PFE 1: Links ok
FPC 6
PFE 0: Links ok
PFE 1: Links ok
FPC 7
PFE 0: Links ok

```

**show chassis fabric
plane detail (T1600
Router)**

```

user@host> show chassis fabric plane detail
Fabric Management PLANE State:
PLANE 0:   Online
PLANE 1:   Online
PLANE 2:   Online
PLANE 3:   Spare
PLANE 4:   Online

```

**show chassis fabric
plane extensive (TX
Matrix Plus Router)**

```

user@host> show chassis fabric plane extensive
sfc0-re0:

```

```

-----
Fabric Management PLANE State:
PLANE 0:   Online
SIB F13 0   :   Online
SIB F13 1   :   Empty
SIB F2S 0/0 :   Online
SIB F2S 0/2 :   Online
SIB F2S 0/4 :   Online
SIB F2S 0/6 :   Online
SIB F13 0 Even:
LCC 0, SIB 0 : Unused
SG 0
Port 0      : Unused
Port 1      : Unused
Port 2      : Unused
Port 3      : Unused
SG 1
Port 0      : Unused
Port 1      : Unused
Port 2      : Unused
Port 3      : Unused
SG 2
Port 0      : Unused
Port 1      : Unused
Port 2      : Unused
Port 3      : Unused
SG 3
Port 0      : Unused
Port 1      : Unused
Port 2      : Unused
Port 3      : Unused
SIB F13 0 Odd:
LCC 1, SIB 0 : Links ok
SG 0
Port 0      : Links ok
Port 1      : Links ok
Port 2      : Links ok
Port 3      : Links ok
SG 1

```

```

    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
SG 2
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
SG 3
    Port 0    : Links ok
    Port 1    : Links ok
    Port 2    : Links ok
    Port 3    : Links ok
SIB F2S 0/0: Links ok
SIB F2S 0/2: Links ok
SIB F2S 0/4: Links ok
SIB F2S 0/6: Links ok
SIB F13 1 Even:
LCC 2, SIB 0 : Unused
SG 0
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SG 1
...
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SG 2
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SG 3
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SIB F13 1 Odd:
LCC 3, SIB 0 : Unused
SG 0
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SG 1
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SG 2
    Port 0    : Unused
    Port 1    : Unused
    Port 2    : Unused
    Port 3    : Unused
SG 3
    Port 0    : Unused
    Port 1    : Unused
```

```

        Port 2      : Unused
        Port 3      : Unused
    SIB F2S 0/0: Unused
    SIB F2S 0/2: Unused
    SIB F2S 0/4: Unused
    SIB F2S 0/6: Unused
PLANE 1:  Fault
    SIB F13 3      :  Fault
    SIB F13 4      :  Empty
    SIB F2S 1/0 :  Fault
    SIB F2S 1/2 :  Fault
    SIB F2S 1/4 :  Online
    SIB F2S 1/6 :  Online
    SIB F13 3 Even:
        LCC 0, SIB 1 : Unused
        SG 0
            Port 0      : Unused
            Port 1      : Unused
            Port 2      : Unused
            Port 3      : Unused
        SG 1
            Port 0      : Unused
            Port 1      : Unused
            Port 2      : Unused
            Port 3      : Unused
        SG 2
            Port 0      : Unused
            Port 1      : Unused
            Port 2      : Unused
            Port 3      : Unused
        SG 3
            Port 0      : Unused
...
lcc1-re1:
-----
Fabric Management SIB State:
    SIB      0      :  Online
        LCC SIB Link State : Links ok
        SG 0
            Port 0      : Links ok
            Port 1      : Links ok
            Port 2      : Links ok
            Port 3      : Links ok
        SG 1
            Port 0      : Links ok
            Port 1      : Links ok
            Port 2      : Links ok
            Port 3      : Links ok
        SG 2
            Port 0      : Links ok
            Port 1      : Links ok
            Port 2      : Links ok
            Port 3      : Links ok
        SG 3
            Port 0      : Links ok
            Port 1      : Links ok
            Port 2      : Links ok
            Port 3      : Links ok
    SIB      1      :  Fault
        LCC SIB Link State : Link error
        SG 0

```

```

Port 0 : Link error
Port 1 : Link error
Port 2 : Link error
Port 3 : Link error
SG 1
Port 0 : Link error
Port 1 : Link error
Port 2 : Link error
Port 3 : Link error
SG 2
Port 0 : Link error
Port 1 : Link error
Port 2 : Link error
Port 3 : Link error
SG 3
Port 0 : Link error
Port 1 : Link error
Port 2 : Link error
Port 3 : Link error
SIB 2 : Online
LCC SIB Link State : Links ok
SG 0
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
SG 1
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
SG 2
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
SG 3
Port 0 : Links ok
Port 1 : Links ok
Port 2 : Links ok
Port 3 : Links ok
SIB 3 : Check
LCC SIB Link State : Link error
SG 0
Port 0 : Link error
Port 1 : Link error
Port 2 : Link error

```

```

show chassis fabric plane (EX8200 Switch)

```

```

user@host> show chassis fabric plane
Fabric management PLANE state
Plane 0
Plane state: ACTIVE
Plane 1
Plane state: ACTIVE
Plane 2
Plane state: ACTIVE
Plane 3
Plane state: ACTIVE
Plane 4
Plane state: SPARE
Plane 5

```



```
Plane state: SPARE
Plane 6
Plane state: SPARE
Plane 7
Plane state: SPARE
Plane 8
Plane state: ACTIVE
Plane 9
Plane state: ACTIVE
Plane 10
Plane state: ACTIVE
Plane 11
Plane state: ACTIVE
```

show chassis fabric plane-location

Syntax	show chassis fabric plane-location
Syntax (MX Series Router)	show chassis fabric plane-location <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced in Junos OS Release 8.0. Command introduced in Junos OS Release 9.4 for EX Series switches.
Description	(M120 and MX Series routers and TX Matrix Plus router and EX8200 switches only) Display the Control Board (CB) location of each plane. This command can be used on the master Routing Engine or the backup Routing Engine. For information about the meaning of “CBs” and “fabric plane” on the switches, see EX Series Switches Hardware and CLI Terminology Mapping.
Options	all-members—(MX Series routers only) (Optional) Display the CB location of each fabric plane on the Routing Engines in all member routers in the Virtual Chassis configuration. local—(MX Series routers only) (Optional) Display the CB location of each fabric plane on the Routing Engines in the local Virtual Chassis member. member <i>member-id</i> —(MX Series routers only) (Optional) Display the CB location of each fabric plane on the Routing Engines in the specified member in the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.
Required Privilege Level	view
List of Sample Output	show chassis fabric plane-location (M120 Router) on page 371 show chassis fabric plane-location (MX240 and MX480 Routers) on page 371 show chassis fabric plane-location (MX960 Router) on page 371 show chassis fabric plane-location (TX Matrix Plus Router) on page 371 show chassis fabric plane-location (EX8200 Switch) on page 371
Output Fields	Table 68 on page 370 lists the output fields for the show chassis fabric plane-location command. Output fields are listed in the approximate order in which they appear.

Table 68: show chassis fabric plane-location Output Fields

Field Name	Field Description
Plane <i>n</i>	Plane number.
Control Board <i>n</i>	Control board number.
SFC ABS-SIB-F13	(TX Matrix Plus routers only) Switch Interface Board (SIB) slot number on the F13 SIB.

Table 68: show chassis fabric plane-location Output Fields (*continued*)

Field Name	Field Description
SFC ABS-SIB-F2S	(TX Matrix Plus routers only) SIB slot number on the F2S.
LCC ST-SIB-L	(TX Matrix Plus routers only) Line-card chassis (LCC) SIB slot number.

Sample Output

```

show chassis fabric plane-location (M120 Router)
user@host> show chassis fabric plane-location
-----Fabric Plane Locations-----
Plane 0                      Control Board 0
Plane 1                      Control Board 0
Plane 2                      Control Board 1
Plane 3                      Control Board 1

show chassis fabric plane-location (MX240 and MX480 Routers)
user@host> show chassis fabric plane-location
-----Fabric Plane Locations-----
Plane 0                      Control Board 0
Plane 1                      Control Board 0
Plane 2                      Control Board 0
Plane 3                      Control Board 0
Plane 4                      Control Board 1
Plane 5                      Control Board 1
Plane 6                      Control Board 1
Plane 7                      Control Board 1

show chassis fabric plane-location (MX960 Router)
user@host> show chassis fabric plane-location
-----Fabric Plane Locations-----
Plane 0                      Control Board 0
Plane 1                      Control Board 0
Plane 2                      Control Board 1
Plane 3                      Control Board 1
Plane 4                      Control Board 2
Plane 5                      Control Board 2

show chassis fabric plane-location (TX Matrix Plus Router)
user@host> show chassis fabric plane-location
Fabric Plane Locations :
Plane      SFC ABS-SIB-F13      SFC ABS-SIB-F2      LCC ST-SIB-L
0          0, 1                  0/0, 0/2, 0/4, 0/6      0
1          3, 4                  1/0, 1/2, 1/4, 1/6      1
2          6, 7                  2/0, 2/2, 2/4, 2/6      2
3          8, 9                  3/0, 3/2, 3/4, 3/6      3
4          11, 12                 4/0, 4/2, 4/4, 4/6      4

show chassis fabric plane-location (EX8200 Switch)
user@host> show chassis fabric plane-location
-----Fabric Plane Locations-----
Plane 0                      Control Board 0
Plane 1                      Control Board 0
Plane 2                      Control Board 0
Plane 3                      Control Board 0
Plane 4                      Control Board 1
Plane 5                      Control Board 1
Plane 6                      Control Board 1
Plane 7                      Control Board 1

```

Plane 8	Control Board 2
Plane 9	Control Board 2
Plane 10	Control Board 2
Plane 11	Control Board 2

show chassis fabric sibs

Syntax	show chassis fabric sibs <fcc <i>number</i> scc>
Release Information	Command introduced before Junos OS Release 7.4.
Description	<p>(T Series routers only) Display the state of the electrical and optical switch fabric links:</p> <ul style="list-style-type: none"> Between the Switch Interface Boards (SIBs) in the TX Matrix router (TX SIBs) and the SIBs in the T640 routers (T640 SIBs). Between the T640 SIBs and the Flexible PIC Concentrators (FPCs) in a T640 router.
Options	<p>none—Display the switching fabric link state for the TX SIBs in the TX Matrix router and for the T640 SIBs in all the T640 routers connected to a TX Matrix router.</p> <p>fcc <i>number</i>—(Optional) Display the switching fabric link state for the T640 SIBs in a specified T640 router (or line-card chassis) connected to a TX Matrix router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(Optional) Display the switching fabric link state for the TX SIBs on the TX Matrix router (or switch-card chassis).</p>
Required Privilege Level	view
List of Sample Output	<p>show chassis fabric sibs (T640 Router) on page 374</p> <p>show chassis fabric sibs (T1600 Router) on page 375</p> <p>show chassis fabric sibs (TX Matrix Router) on page 376</p> <p>show chassis fabric sibs fcc (TX Matrix Router) on page 379</p> <p>show chassis fabric sibs scc (TX Matrix Router) on page 379</p>
Output Fields	Table 69 on page 373 lists the output fields for the <code>show chassis fabric sibs</code> command. Output fields are listed in the approximate order in which they appear.

Table 69: show chassis fabric sibs Output Fields

Field Name	Field Description
Fabric management SIB state	<p>Switching fabric link (link from FPC to SIB) state for each SIB:</p> <ul style="list-style-type: none"> Unused—SIB is not present. Links ok—Link between the SIB and the FPC is active. Link error—Link between the SIB and the FPC is not operational.

Table 69: show chassis fabric sibs Output Fields (*continued*)

Field Name	Field Description
Plane state	<p>In a routing matrix composed of the TX Matrix router, state of the TX SIB or T640 SIB:</p> <ul style="list-style-type: none"> • S_ACTIVE—Links on the SIB are operational, and the fabric plane (SIB) is operational and running. • S_SPARE—Links on the SIB are operational and the fabric plane (SIB) is redundant and can be operational if any of the fabric planes in the S_ACTIVE state encounters an error. <p>NOTE: If the plane is unusable by any of the Packet Forwarding Engines, the command output displays an additional string, plane has link errors on # pfes, where, # indicates the total number of links (both from SIB to FPC, and from FPC to SIB) having link errors (detected either during initialization time or runtime) in this particular plane. This does not count links having destination errors.</p>

Sample Output

show chassis fabric
sibs (T640 Router)

```

user@host> show chassis fabric sibs
Fabric management SIB state:
SIB #0
  plane state: S_SPARE
  FPC #0
    PFE #1 : Links ok
  FPC #2
    PFE #1 : Links ok
  FPC #3
    PFE #0 : Links ok
    PFE #1 : Links ok
SIB #1
  plane state: S_ACTIVE
  FPC #0
    PFE #1 : Links ok
  FPC #2
    PFE #1 : Links ok
  FPC #3
    PFE #0 : Links ok
    PFE #1 : Links ok
SIB #2
  plane state: S_ACTIVE
  FPC #0
    PFE #1 : Links ok
  FPC #2
    PFE #1 : Links ok
  FPC #3
    PFE #0 : Links ok
    PFE #1 : Links ok
SIB #3
  plane state: S_ACTIVE
  FPC #0
    PFE #1 : Links ok
  FPC #2
    PFE #1 : Links ok
  FPC #3
    PFE #0 : Links ok

```

```

        PFE #1 : Links ok
SIB #4
  plane state: S_ACTIVE
  FPC #0
    PFE #1 : Links ok
  FPC #2
    PFE #1 : Links ok
  FPC #3
    PFE #0 : Links ok
    PFE #1 : Links ok

show chassis fabric sibs (T1600 Router) user@host> show chassis fabric sibs
SIB #0
  plane state: S_SPARE
  FPC #0
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #1
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #2
    PFE #0 : Links ok
  FPC #4
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #5
    PFE #0 : Links ok
  FPC #6
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #7
    PFE #0 : Links ok
    PFE #1 : Links ok
SIB #1
  plane state: S_ACTIVE , plane has link errors on 2 pfes
  FPC #0
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #1
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #3
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #4
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #5
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #7
    PFE #0 : Links ok
    PFE #1 : Links okSIB #2
  plane state: S_ACTIVE
SIB #2
  plane state: S_ACTIVE
  FPC #0
    PFE #0 : Links ok
    PFE #1 : Links ok
  FPC #1
    PFE #0 : Links ok

```

```

        PFE #1 : Links ok
FPC #2
        PFE #0 : Links ok
FPC #4
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #5
        PFE #0 : Links ok
FPC #6
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #7
        PFE #0 : Links ok
        PFE #1 : Links ok
SIB #3
plane state: S_ACTIVE
FPC #0
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #1
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #2
        PFE #0 : Links ok
FPC #4
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #5
        PFE #0 : Links ok
FPC #6
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #7
        PFE #0 : Links ok
        PFE #1 : Links ok
SIB #4
plane state: S_ACTIVE
FPC #0
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #1
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #2
        PFE #0 : Links ok
FPC #4
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #5
        PFE #0 : Links ok
FPC #6
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #7
        PFE #0 : Links ok
        PFE #1 : Links ok

```

**show chassis fabric
sibs (TX Matrix Router)**

```

user@host> show chassis fabric sibs
scc-re0:

```

```

-----
Fabric management SIB state:

```



```

SIB #1
plane state: S_ACTIVE , plane has link errors on 2 pfes
FPC #0
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #1
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #3
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #4
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #5
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #7
  PFE #0 : Links ok
  PFE #1 : Links ok
SIB #2
plane state: S_ACTIVE
LCC #0 : Links ok
LCC #1 : Links ok
SIB #3
plane state: S_ACTIVE
LCC #0 : Links ok
LCC #1 : Links ok
SIB #4
plane state: S_ACTIVE
LCC #0 : Links ok
LCC #1 : Links ok

```

```
lcc0-re0:
```

```
-----
Fabric management SIB state:
```

```

SIB #1
plane state: S_ACTIVE
FPC #0
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #1
  PFE #1 : Links ok
FPC #2
  PFE #0 : Links ok
  PFE #1 : Links ok
FPC #3
  PFE #1 : Links ok
FPC #4
  PFE #1 : Links ok
FPC #5
  PFE #0 : Links ok
FPC #6
  PFE #1 : Links ok
FPC #7
  PFE #1 : Links ok
SCC : Links ok
SIB #2
plane state: S_ACTIVE
FPC #0
  PFE #0 : Links ok

```

```
        PFE #1 : Links ok
FPC #1
        PFE #1 : Links ok
FPC #2
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #3
        PFE #1 : Links ok
FPC #4
        PFE #1 : Links ok
FPC #5
        PFE #0 : Links ok
FPC #6
        PFE #1 : Links ok
FPC #7
        PFE #1 : Links ok
SCC      : Links ok
SIB #3
plane state: S_ACTIVE
FPC #0
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #1
        PFE #1 : Links ok
FPC #2
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #3
        PFE #1 : Links ok
FPC #4
        PFE #1 : Links ok
FPC #5
        PFE #0 : Links ok
FPC #6
        PFE #1 : Links ok
FPC #7
        PFE #1 : Links ok
SCC      : Links ok
SIB #4
plane state: S_ACTIVE
FPC #0
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #1
        PFE #1 : Links ok
FPC #2
        PFE #0 : Links ok
        PFE #1 : Links ok
FPC #3
        PFE #1 : Links ok
FPC #4
        PFE #1 : Links ok
FPC #5
        PFE #0 : Links ok
FPC #6
        PFE #1 : Links ok
FPC #7
        PFE #1 : Links ok
SCC      : Links o
```

```
show chassis fabric sibs lcc (TX Matrix Router)
user@host> show chassis fabric sibs lcc 0
lcc1-re0:
```

```
-----
Fabric management SIB state:
```

```
SIB #1
```

```
plane state: S_ACTIVE
```

```
FPC #0
```

```
PFE #0 : Links ok
```

```
FPC #2
```

```
PFE #1 : Links ok
```

```
FPC #4
```

```
PFE #0 : Links ok
```

```
FPC #5
```

```
PFE #1 : Links ok
```

```
FPC #7
```

```
PFE #0 : Links ok
```

```
SCC
```

```
: Links ok
```

```
SIB #2
```

```
plane state: S_ACTIVE
```

```
FPC #0
```

```
PFE #0 : Links ok
```

```
FPC #2
```

```
PFE #1 : Links ok
```

```
FPC #4
```

```
PFE #0 : Links ok
```

```
FPC #5
```

```
PFE #1 : Links ok
```

```
FPC #7
```

```
PFE #0 : Links ok
```

```
SCC
```

```
: Links ok
```

```
SIB #3
```

```
plane state: S_ACTIVE
```

```
FPC #0
```

```
PFE #0 : Links ok
```

```
FPC #2
```

```
PFE #1 : Links ok
```

```
FPC #4
```

```
PFE #0 : Links ok
```

```
FPC #5
```

```
PFE #1 : Links ok
```

```
FPC #7
```

```
PFE #0 : Links ok
```

```
SCC
```

```
: Links ok
```

```
SIB #4
```

```
plane state: S_ACTIVE
```

```
FPC #0
```

```
PFE #0 : Links ok
```

```
FPC #2
```

```
PFE #1 : Links ok
```

```
FPC #4
```

```
PFE #0 : Links ok
```

```
FPC #5
```

```
PFE #1 : Links ok
```

```
FPC #7
```

```
PFE #0 : Links ok
```

```
SCC
```

```
: Links ok
```

```
show chassis fabric sibs scc (TX Matrix Router)
user@host> show chassis fabric sibs scc
scc-re0:
```

```
-----
Fabric management SIB state:
```

```
SIB #1
  plane state: S_ACTIVE
  LCC #0      : Links ok
  LCC #1      : Links ok
SIB #2
  plane state: S_ACTIVE
  LCC #0      : Links ok
  LCC #1      : Links ok
SIB #3
  plane state: S_ACTIVE
  LCC #0      : Links ok
  LCC #1      : Links ok
SIB #4
  plane state: S_ACTIVE
  LCC #0      : Links ok
  LCC #1      : Links ok
```

show chassis fabric summary

Syntax	show chassis fabric summary
Release Information	Command introduced in Junos OS Release 8.4. Command introduced in Junos OS Release 9.4 for EX Series switches.
Description	(MX Series routers and EX8200 switches only) Display the state of all fabric planes and the elapsed uptime.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis fabric summary (MX240 Router) on page 382 show chassis fabric summary (MX480 Router) on page 382 show chassis fabric summary (MX960 Router) on page 382 show chassis fabric summary (EX8200 Switch) on page 382
Output Fields	Table 70 on page 381 lists the output fields for the show chassis fabric summary command. Output fields are listed in the approximate order in which they appear.

Table 70: show chassis fabric summary Output Fields

Field Name	Field Description
Plane	Plane number.
State	<p>State of each plane:</p> <ul style="list-style-type: none"> • Online—Switch Interface Board (SIB) is operational and running. • Empty—SIB is powered down. • Check—SIB is in the Check state because of the following reasons: <ul style="list-style-type: none"> • SIB is not inserted properly. • Some destination errors are detected on the SIB. In this case, the Packet Forwarding Engine stops using the SIB to send traffic to the affected destination Packet Forwarding Engine. • Some link errors are detected on the channel between the SIB and a Packet Forwarding Engine. Link errors can be detected at initialization time or runtime: <ul style="list-style-type: none"> • Link errors caused by a link training failure at initialization time—The Packet Forwarding Engine does not use the SIB to send traffic. The show chassis fabric fpcs command shows Plane disabled as status for this link. • Link errors caused by CRC errors detected at runtime—The Packet Forwarding Engine continues to use the SIB to send traffic. The show chassis fabric fpcs command shows Link error as the status for this link. <p>For information about link and destination errors, issue the show chassis fabric fpcs commands.</p> <ul style="list-style-type: none"> • Spare—SIB is redundant and will move to active state if one of the working SIBs fails.

Table 70: show chassis fabric summary Output Fields (*continued*)

Field Name	Field Description
Uptime	Elapsed time the plane has been online.

Sample Output

```

show chassis fabric summary (MX240 Router)
user@host> show chassis fabric summary
Plane  State  Uptime
0      Online 23 hours, 26 minutes, 54 seconds
1      Online 23 hours, 26 minutes, 54 seconds
2      Check 18 hours, 33 minutes, 42 seconds
3      Online 23 hours, 26 minutes, 54 seconds
4      Spare 23 hours, 26 minutes, 54 seconds
5      Spare 23 hours, 26 minutes, 54 seconds
6      Spare 23 hours, 26 minutes, 54 seconds
7      Spare 23 hours, 26 minutes, 54 seconds

```

```

show chassis fabric summary (MX480 Router)
user@host> show chassis fabric summary
Plane  State  Uptime
0      Online 8 hours, 45 minutes, 29 seconds
1      Online 8 hours, 45 minutes, 28 seconds
2      Online 8 hours, 45 minutes, 28 seconds
3      Online 8 hours, 45 minutes, 28 seconds
4      Spare 8 hours, 45 minutes, 28 seconds
5      Spare 8 hours, 45 minutes, 28 seconds
6      Spare 8 hours, 45 minutes, 28 seconds
7      Check 6 hours, 10 minutes, 12 seconds

```

```

show chassis fabric summary (MX960 Router)
user@host> show chassis fabric summary
Plane  State  Uptime
0      Online 3 hours, 7 minutes, 9 seconds
1      Online 3 hours, 7 minutes, 4 seconds
2      Online 3 hours, 6 minutes, 59 seconds
3      Online 3 hours, 6 minutes, 54 seconds
4      Empty
5      Empty

```

```

show chassis fabric summary (EX8200 Switch)
user@host> show chassis fabric summary
Plane  State  Uptime
0      Online 12 days, 50 minutes, 54 seconds
1      Online 12 days, 50 minutes, 53 seconds
2      Online 12 days, 50 minutes, 53 seconds
3      Online 12 days, 50 minutes, 52 seconds
4      Spare 12 days, 50 minutes, 49 seconds
5      Spare 12 days, 50 minutes, 47 seconds
6      Spare 12 days, 50 minutes, 47 seconds
7      Spare 12 days, 50 minutes, 46 seconds
8      Online 12 days, 50 minutes, 52 seconds
9      Online 12 days, 50 minutes, 50 seconds
10     Online 12 days, 50 minutes, 50 seconds
11     Online 12 days, 50 minutes, 49 seconds

```

show chassis fabric topology

Syntax	show chassis fabric topology <lcc <i>number</i> scc> <sib-slot-number>
Syntax (TX Matrix Router)	show chassis fabric topology <lcc <i>number</i> scc> <sib-slot-number>
Syntax (TX Matrix Plus Router)	show chassis fabric topology <lcc <i>number</i> sfc <i>number</i> > <sib-slot-number>
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(TX Matrix, TX Matrix Plus, and T Series routers only) On the TX Matrix router, display the state of the switching fabric topology for the Switch Interface Board (SIB) connection between the TX Matrix router and the T640 routers. On the TX Matrix Plus router, display the state of the switching fabric topology for the SIB connection between the TX Matrix Plus router and the T1600 routers.
Options	<p>none—Display the fabric topology state for the TX Matrix router and for all the T640 routers connected to it.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display the fabric topology state for a specified T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display the fabric topology state for a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) (Optional) Display the fabric topology state for the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display the fabric topology for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p> <p>sib-slot-number—(Optional) Display the fabric topology state for a specified SIB slot. Replace <i>sib-slot-number</i> with a value from 0 through 4. On a TX Matrix Plus router, replace <i>sib-slot-number</i> with a value from 0 through 15.</p>
Required Privilege Level	view
List of Sample Output	<p>show chassis fabric topology scc (TX Matrix Router) on page 386</p> <p>show chassis fabric topology lcc on page 388</p> <p>show chassis fabric topology (TX Matrix Plus Router) on page 390</p> <p>show chassis fabric topology sfc (TX Matrix Plus Router) on page 392</p> <p>show chassis fabric topology lcc (TX Matrix Plus Router) on page 393</p>

Output Fields Table 71 on page 384 lists the output fields for the **show chassis fabric topology** command. Output fields are listed in the approximate order in which they appear.

Table 71: show chassis fabric topology Output Fields

Field Name	Field Description
in-links	Fabric topology for receive side links.
out-links	Fabric topology for transmit side links.
state	State of the fabric link: <ul style="list-style-type: none">• RESET—Link between the SIB and the FPC/DPC is powered down on purpose. This is done in all non-dual Packet Forwarding Engine-based boards.• UP—Link between the SIB and the FPC/DCP is up and running.• DOWN—Link between the SIB and the FPC/DCP is powered down.• FAULT—SIB is in the alarmed state, in which the SIB's plane is not operational for the following reasons:<ul style="list-style-type: none">• On-board F-chip is not operational.• Fiber-optic connector faults.• FPC connector faults.• SIB midplane connector faults.

Table 71: show chassis fabric topology Output Fields (*continued*)

Out-Links: In-Links (TX Matrix Plus router only)	State of the links from the F13 SIB to the LCC or vice-versa. Out-Links indicate Tx links. In-Links indicate an Rx link. The following additional fields are displayed for each SIB:
	<ul style="list-style-type: none"> • VCSEL Status—Optical (VCSEL channel) link status for the corresponding electrical (HSL2) link. The states include: <ul style="list-style-type: none"> • OK—Optical signal power is good. • Error—Internal error. • LOS—Loss of Signal detected. • High Cur—The Tx Bias-current is higher than threshold on this channel. This is applicable only to Tx Channels. • Low Cur—The Tx Bias-current is lower than threshold on this channel. This is applicable only to Tx Channels. • HSL2 Channel—HSL2 is the electrical link used to connect ASICs to the in-link and out-link. The channel number corresponds to the link and varies based on the ASIC or configuration.
	<ul style="list-style-type: none"> • HSL2 Status —The status of the HSL2 Channel. Includes the following states: <ul style="list-style-type: none"> • Up—Channel is up. • Down—Channel is down. • Reset—Channel has been reset. • Fault—Channel has faults.
	The following is a sample output with description of the fields displayed in the output for Out-Links:
	<pre> Out-Links: ===== SF_3_13_FB_A(21,09) -> FPC7_B_SG(3,3,6)_FB_A(18,09) OK 203 Up </pre>

Table 71: show chassis fabric topology Output Fields (*continued*)

- **SF_3_13**—Name of the ASIC, with Fabric F1 or F3 mode. In this case, 3 is the F3 direction and is used in the Tx path. You can also have F1 mode and Rx path instead.
- **FB_A (21, 09)**—Fiber bundle A, with VCSEL unit number 21 within the SIB, and channel number 9 within the unit number.
- **FPC7_B_SG(3,3,6)**—FPC 7.with bottom Packet Forwarding Engine (T for top PFE and B for bottom PFE), SG ASIC, with number 3 and port number 3, with HSL2 link number with the SIB as 6.
- **FB_A(18, 09)**—Fiber Bundle, with VCSEL unit number 18 within the SIB, and VCSEL channel number 9 within the unit number.

The following is a sample output with description of the fields displayed in the output for In-Links:

In-Links:

=====

```
FPC0_T_SG(0,0,0)_FB_D(04,11)  -> SF_1_00_FB_D(01,11)    OK      0
Up
```

- **FPC0**—FPC 0.
- **T**—Top Packet Forwarding Engine.
- **SG (0, 0, 0)**—SG ASIC with port number 0 and link 0.
- **FB_D (04,11)**—Fiber Bundle D with VCSEL 4, channel 11.
- **SF_1**—Indicates F1 mode and Rx path.
- **SF_1_00_FB_D(01,11)** —Indicates F1 mode and Rx path with port 0, fiber bundle D, with VCSEL 1, channel 11.

Sample Output

show chassis fabric
topology scc (TX
Matrix Router)

```
user@host> show chassis fabric topology scc
scc-rel:
```

```
-----
fchip (mode)
```

```
in-links      state  out-links      state
-----
```

Sib #0 :

SIB0_F0 (F2):

LCC0_SIB-L0_F0,03->SIB-S0_F0,00	UP	SIB-S0_F0,00->LCC0_SIB-L0_F1,00	UP
LCC1_SIB-L0_F0,03->SIB-S0_F0,01	UP	SIB-S0_F0,01->LCC1_SIB-L0_F1,08	UP
LCC2_SIB-L0_F0,03->SIB-S0_F0,02	RESET	SIB-S0_F0,02->LCC2_SIB-L0_F1,08	UP
LCC3_SIB-L0_F0,03->SIB-S0_F0,03	RESET	SIB-S0_F0,03->LCC3_SIB-L0_F1,00	UP
LCC0_SIB-L0_F0,02->SIB-S0_F0,04	UP	SIB-S0_F0,04->LCC0_SIB-L0_F1,01	UP
LCC1_SIB-L0_F0,02->SIB-S0_F0,05	UP	SIB-S0_F0,05->LCC1_SIB-L0_F1,09	UP
LCC2_SIB-L0_F0,02->SIB-S0_F0,06	RESET	SIB-S0_F0,06->LCC2_SIB-L0_F1,09	UP
LCC3_SIB-L0_F0,02->SIB-S0_F0,07	RESET	SIB-S0_F0,07->LCC3_SIB-L0_F1,01	UP
LCC0_SIB-L0_F0,07->SIB-S0_F0,08	UP	SIB-S0_F0,08->LCC0_SIB-L0_F1,04	UP
LCC1_SIB-L0_F0,07->SIB-S0_F0,09	UP	SIB-S0_F0,09->LCC1_SIB-L0_F1,12	UP
LCC2_SIB-L0_F0,07->SIB-S0_F0,10	RESET	SIB-S0_F0,10->LCC2_SIB-L0_F1,12	UP
LCC3_SIB-L0_F0,07->SIB-S0_F0,11	RESET	SIB-S0_F0,11->LCC3_SIB-L0_F1,04	UP
LCC0_SIB-L0_F0,06->SIB-S0_F0,12	UP	SIB-S0_F0,12->LCC0_SIB-L0_F1,05	UP
LCC1_SIB-L0_F0,06->SIB-S0_F0,13	UP	SIB-S0_F0,13->LCC1_SIB-L0_F1,13	UP
LCC2_SIB-L0_F0,06->SIB-S0_F0,14	RESET	SIB-S0_F0,14->LCC2_SIB-L0_F1,13	UP
LCC3_SIB-L0_F0,06->SIB-S0_F0,15	RESET	SIB-S0_F0,15->LCC3_SIB-L0_F1,05	UP

SIB0_F1 (F2):

LCC0_SIB-L0_F0,11->SIB-S0_F1,00	UP	SIB-S0_F1,00->LCC0_SIB-L0_F1,08	UP
LCC1_SIB-L0_F0,11->SIB-S0_F1,01	UP	SIB-S0_F1,01->LCC1_SIB-L0_F1,00	UP
LCC2_SIB-L0_F0,11->SIB-S0_F1,02	RESET	SIB-S0_F1,02->LCC2_SIB-L0_F1,00	UP
LCC3_SIB-L0_F0,11->SIB-S0_F1,03	RESET	SIB-S0_F1,03->LCC3_SIB-L0_F1,08	UP
LCC0_SIB-L0_F0,10->SIB-S0_F1,04	UP	SIB-S0_F1,04->LCC0_SIB-L0_F1,09	UP
LCC1_SIB-L0_F0,10->SIB-S0_F1,05	UP	SIB-S0_F1,05->LCC1_SIB-L0_F1,01	UP
LCC2_SIB-L0_F0,10->SIB-S0_F1,06	RESET	SIB-S0_F1,06->LCC2_SIB-L0_F1,01	UP
LCC3_SIB-L0_F0,10->SIB-S0_F1,07	RESET	SIB-S0_F1,07->LCC3_SIB-L0_F1,09	UP
LCC0_SIB-L0_F0,15->SIB-S0_F1,08	UP	SIB-S0_F1,08->LCC0_SIB-L0_F1,12	UP
LCC1_SIB-L0_F0,15->SIB-S0_F1,09	UP	SIB-S0_F1,09->LCC1_SIB-L0_F1,04	UP
LCC2_SIB-L0_F0,15->SIB-S0_F1,10	RESET	SIB-S0_F1,10->LCC2_SIB-L0_F1,04	UP
LCC3_SIB-L0_F0,15->SIB-S0_F1,11	RESET	SIB-S0_F1,11->LCC3_SIB-L0_F1,12	UP
LCC0_SIB-L0_F0,14->SIB-S0_F1,12	UP	SIB-S0_F1,12->LCC0_SIB-L0_F1,13	UP
LCC1_SIB-L0_F0,14->SIB-S0_F1,13	UP	SIB-S0_F1,13->LCC1_SIB-L0_F1,05	UP
LCC2_SIB-L0_F0,14->SIB-S0_F1,14	RESET	SIB-S0_F1,14->LCC2_SIB-L0_F1,05	
UP			
LCC3_SIB-L0_F0,14->SIB-S0_F1,15	RESET	SIB-S0_F1,15->LCC3_SIB-L0_F1,13	
UP			

SIB0_F2 (F2):

LCC3_SIB-L0_F0,13->SIB-S0_F2,00	RESET	SIB-S0_F2,00->LCC3_SIB-L0_F1,14	UP
LCC2_SIB-L0_F0,13->SIB-S0_F2,01	RESET	SIB-S0_F2,01->LCC2_SIB-L0_F1,06	
UP			
LCC1_SIB-L0_F0,13->SIB-S0_F2,02	UP	SIB-S0_F2,02->LCC1_SIB-L0_F1,06	UP
LCC0_SIB-L0_F0,13->SIB-S0_F2,03	UP	SIB-S0_F2,03->LCC0_SIB-L0_F1,14	UP
LCC3_SIB-L0_F0,12->SIB-S0_F2,04	RESET	SIB-S0_F2,04->LCC3_SIB-L0_F1,15	
UP			
LCC2_SIB-L0_F0,12->SIB-S0_F2,05	RESET	SIB-S0_F2,05->LCC2_SIB-L0_F1,07	UP
LCC1_SIB-L0_F0,12->SIB-S0_F2,06	UP	SIB-S0_F2,06->LCC1_SIB-L0_F1,07	UP
LCC0_SIB-L0_F0,12->SIB-S0_F2,07	UP	SIB-S0_F2,07->LCC0_SIB-L0_F1,15	UP
LCC3_SIB-L0_F0,09->SIB-S0_F2,08	RESET	SIB-S0_F2,08->LCC3_SIB-L0_F1,10	
UP			
LCC2_SIB-L0_F0,09->SIB-S0_F2,09	RESET	SIB-S0_F2,09->LCC2_SIB-L0_F1,02	
UP			
LCC1_SIB-L0_F0,09->SIB-S0_F2,10	UP	SIB-S0_F2,10->LCC1_SIB-L0_F1,02	UP
LCC0_SIB-L0_F0,09->SIB-S0_F2,11	UP	SIB-S0_F2,11->LCC0_SIB-L0_F1,10	UP
LCC3_SIB-L0_F0,08->SIB-S0_F2,12	RESET	SIB-S0_F2,12->LCC3_SIB-L0_F1,11	
UP			
LCC2_SIB-L0_F0,08->SIB-S0_F2,13	RESET	SIB-S0_F2,13->LCC2_SIB-L0_F1,03	
UP			
LCC1_SIB-L0_F0,08->SIB-S0_F2,14	UP	SIB-S0_F2,14->LCC1_SIB-L0_F1,03	UP
LCC0_SIB-L0_F0,08->SIB-S0_F2,15	UP	SIB-S0_F2,15->LCC0_SIB-L0_F1,11	UP

SIB0_F3 (F2):

LCC3_SIB-L0_F0,05->SIB-S0_F3,00	RESET	SIB-S0_F3,00->LCC3_SIB-L0_F1,06	
UP			
LCC2_SIB-L0_F0,05->SIB-S0_F3,01	RESET	SIB-S0_F3,01->LCC2_SIB-L0_F1,14	
UP			
LCC1_SIB-L0_F0,05->SIB-S0_F3,02	UP	SIB-S0_F3,02->LCC1_SIB-L0_F1,14	UP
LCC0_SIB-L0_F0,05->SIB-S0_F3,03	UP	SIB-S0_F3,03->LCC0_SIB-L0_F1,06	UP
LCC3_SIB-L0_F0,04->SIB-S0_F3,04	RESET	SIB-S0_F3,04->LCC3_SIB-L0_F1,07	
UP			
LCC2_SIB-L0_F0,04->SIB-S0_F3,05	RESET	SIB-S0_F3,05->LCC2_SIB-L0_F1,15	
UP			
LCC1_SIB-L0_F0,04->SIB-S0_F3,06	UP	SIB-S0_F3,06->LCC1_SIB-L0_F1,15	UP
LCC0_SIB-L0_F0,04->SIB-S0_F3,07	UP	SIB-S0_F3,07->LCC0_SIB-L0_F1,07	UP
LCC3_SIB-L0_F0,01->SIB-S0_F3,08	RESET	SIB-S0_F3,08->LCC3_SIB-L0_F1,02	
UP			
LCC2_SIB-L0_F0,01->SIB-S0_F3,09	RESET	SIB-S0_F3,09->LCC2_SIB-L0_F1,10	
UP			
LCC1_SIB-L0_F0,01->SIB-S0_F3,10	UP	SIB-S0_F3,10->LCC1_SIB-L0_F1,10	UP
LCC0_SIB-L0_F0,01->SIB-S0_F3,11	UP	SIB-S0_F3,11->LCC0_SIB-L0_F1,02	UP

```

LCC3_SIB-L0_F0,00->SIB-S0_F3,12  RESET      SIB-S0_F3,12->LCC3_SIB-L0_F1,03
UP
LCC2_SIB-L0_F0,00->SIB-S0_F3,13  RESET      SIB-S0_F3,13->LCC2_SIB-L0_F1,11
UP
LCC1_SIB-L0_F0,00->SIB-S0_F3,14  UP          SIB-S0_F3,14->LCC1_SIB-L0_F1,11  UP
LCC0_SIB-L0_F0,00->SIB-S0_F3,15  UP          SIB-S0_F3,15->LCC0_SIB-L0_F1,03  UP
Sib #1 :
-----
SIB1_F0 (F2 ):
LCC0_SIB-L1_F0,03->SIB-S1_F0,00  RESET      SIB-S1_F0,00->LCC0_SIB-L1_F1,00  UP
LCC1_SIB-L1_F0,03->SIB-S1_F0,01  RESET      SIB-S1_F0,01->LCC1_SIB-L1_F1,08  UP
LCC2_SIB-L1_F0,03->SIB-S1_F0,02  RESET      SIB-S1_F0,02->LCC2_SIB-L1_F1,08  UP
LCC3_SIB-L1_F0,03->SIB-S1_F0,03  RESET      SIB-S1_F0,03->LCC3_SIB-L1_F1,00  UP
LCC0_SIB-L1_F0,02->SIB-S1_F0,04  RESET      SIB-S1_F0,04->LCC0_SIB-L1_F1,01  UP
LCC1_SIB-L1_F0,02->SIB-S1_F0,05  RESET      SIB-S1_F0,05->LCC1_SIB-L1_F1,09  UP
LCC2_SIB-L1_F0,02->SIB-S1_F0,06  RESET      SIB-S1_F0,06->LCC2_SIB-L1_F1,09  UP
LCC3_SIB-L1_F0,02->SIB-S1_F0,07  RESET      SIB-S1_F0,07->LCC3_SIB-L1_F1,01  UP
LCC0_SIB-L1_F0,07->SIB-S1_F0,08  RESET      SIB-S1_F0,08->LCC0_SIB-L1_F1,04  UP
LCC1_SIB-L1_F0,07->SIB-S1_F0,09  RESET      SIB-S1_F0,09->LCC1_SIB-L1_F1,12  UP
LCC2_SIB-L1_F0,07->SIB-S1_F0,10  RESET      SIB-S1_F0,10->LCC2_SIB-L1_F1,12  UP
LCC3_SIB-L1_F0,07->SIB-S1_F0,11  RESET      SIB-S1_F0,11->LCC3_SIB-L1_F1,04  UP
LCC0_SIB-L1_F0,06->SIB-S1_F0,12  RESET      SIB-S1_F0,12->LCC0_SIB-L1_F1,05  UP
LCC1_SIB-L1_F0,06->SIB-S1_F0,13  RESET      SIB-S1_F0,13->LCC1_SIB-L1_F1,13  UP
LCC2_SIB-L1_F0,06->SIB-S1_F0,14  RESET      SIB-S1_F0,14->LCC2_SIB-L1_F1,13  UP
LCC3_SIB-L1_F0,06->SIB-S1_F0,15  RESET      SIB-S1_F0,15->LCC3_SIB-L1_F1,05  UP
SIB1_F1 (F2 ):
LCC0_SIB-L1_F0,11->SIB-S1_F1,00  RESET      SIB-S1_F1,00->LCC0_SIB-L1_F1,08  UP
LCC1_SIB-L1_F0,11->SIB-S1_F1,01  RESET      SIB-S1_F1,01->LCC1_SIB-L1_F1,00  UP
LCC2_SIB-L1_F0,11->SIB-S1_F1,02  RESET      SIB-S1_F1,02->LCC2_SIB-L1_F1,00  UP
LCC3_SIB-L1_F0,11->SIB-S1_F1,03  RESET      SIB-S1_F1,03->LCC3_SIB-L1_F1,08  UP
LCC0_SIB-L1_F0,10->SIB-S1_F1,04  RESET      SIB-S1_F1,04->LCC0_SIB-L1_F1,09  UP
LCC1_SIB-L1_F0,10->SIB-S1_F1,05  RESET      SIB-S1_F1,05->LCC1_SIB-L1_F1,01  UP
LCC2_SIB-L1_F0,10->SIB-S1_F1,06  RESET      SIB-S1_F1,06->LCC2_SIB-L1_F1,01  UP
LCC3_SIB-L1_F0,10->SIB-S1_F1,07  RESET      SIB-S1_F1,07->LCC3_SIB-L1_F1,09  UP
LCC0_SIB-L1_F0,15->SIB-S1_F1,08  RESET      SIB-S1_F1,08->LCC0_SIB-L1_F1,12  UP
LCC1_SIB-L1_F0,15->SIB-S1_F1,09  RESET      SIB-S1_F1,09->LCC1_SIB-L1_F1,04  UP
LCC2_SIB-L1_F0,15->SIB-S1_F1,10  RESET      SIB-S1_F1,10->LCC2_SIB-L1_F1,04  UP
LCC3_SIB-L1_F0,15->SIB-S1_F1,11  RESET      -S1_F1,11->LCC3_SIB-L1_F1,12,05  UP
LCC0_SIB-L1_F0,14->SIB-S1_F1,12  RESET      SIB-S1_F1,12->LCC0_SIB-L1_F1,13  UP
LCC1_SIB-L1_F0,14->SIB-S1_F1,13  RESET      SIB-S1_F1,13->LCC1_SIB-L1_F1,05  UP
LCC2_SIB-L1_F0,14->SIB-S1_F1,14  RESET      SIB-S1_F1,14->LCC2_SIB-L1_F1,05  UP

```

**show chassis fabric
topology lcc**

```

user@host> show chassis fabric topology lcc 0
lcc0-re0:

```

```

-----
      fchip (mode)
in-links      state      out-links      state
-----
Sib #2 :
-----
SIB2_F0 (F1 ):
FPC0_T->SIB-L2_F0,00  DOWN      SIB-L2_F0,00->SIB-S2_F3,15  DOWN
FPC0_B->SIB-L2_F0,01  UP          SIB-L2_F0,01->SIB-S2_F3,11  DOWN
FPC1_T->SIB-L2_F0,02  DOWN      SIB-L2_F0,02->SIB-S2_F0,04  DOWN
FPC1_B->SIB-L2_F0,03  DOWN      SIB-L2_F0,03->SIB-S2_F0,00  DOWN
FPC2_T->SIB-L2_F0,04  DOWN      SIB-L2_F0,04->SIB-S2_F3,07  DOWN
FPC2_B->SIB-L2_F0,05  DOWN      SIB-L2_F0,05->SIB-S2_F3,03  DOWN
FPC3_T->SIB-L2_F0,06  DOWN      SIB-L2_F0,06->SIB-S2_F0,12  DOWN
FPC3_B->SIB-L2_F0,07  DOWN      SIB-L2_F0,07->SIB-S2_F0,08  DOWN
FPC4_T->SIB-L2_F0,08  DOWN      SIB-L2_F0,08->SIB-S2_F2,15  DOWN
FPC4_B->SIB-L2_F0,09  DOWN      SIB-L2_F0,09->SIB-S2_F2,11  DOWN

```

```

FPC5_T->SIB-L2_F0,10    DOWN
FPC5_B->SIB-L2_F0,11    DOWN
FPC6_T->SIB-L2_F0,12    DOWN
FPC6_B->SIB-L2_F0,13    UP
FPC7_T->SIB-L2_F0,14    DOWN
FPC7_B->SIB-L2_F0,15    DOWN
SIB2_F1 (F3 ):
SIB-S2_F0,00->SIB-L2_F1,00 UP
SIB-S2_F0,04->SIB-L2_F1,01 UP
SIB-S2_F3,11->SIB-L2_F1,02 UP
SIB-S2_F3,15->SIB-L2_F1,03 UP
SIB-S2_F0,08->SIB-L2_F1,04 UP
SIB-S2_F0,12->SIB-L2_F1,05 UP
SIB-S2_F3,03->SIB-L2_F1,06 UP
SIB-S2_F3,07->SIB-L2_F1,07 UP
SIB-S2_F1,00->SIB-L2_F1,08 UP
SIB-S2_F1,04->SIB-L2_F1,09 UP
SIB-S2_F2,11->SIB-L2_F1,10 UP
SIB-S2_F2,15->SIB-L2_F1,11 UP
SIB-S2_F1,08->SIB-L2_F1,12 UP
SIB-S2_F1,12->SIB-L2_F1,13 UP
SIB-S2_F2,03->SIB-L2_F1,14 UP
SIB-S2_F2,07->SIB-L2_F1,15 UP
Sib #4 :
-----
SIB4_F0 (F1 ):
FPC0_T->SIB-L4_F0,00    RESET
FPC0_B->SIB-L4_F0,01    UP
FPC1_T->SIB-L4_F0,02    RESET
FPC1_B->SIB-L4_F0,03    RESET
FPC2_T->SIB-L4_F0,04    RESET
FPC2_B->SIB-L4_F0,05    RESET
FPC3_T->SIB-L4_F0,06    RESET
FPC3_B->SIB-L4_F0,07    RESET
FPC4_T->SIB-L4_F0,08    RESET
FPC4_B->SIB-L4_F0,09    RESET
FPC5_T->SIB-L4_F0,10    RESET
FPC5_B->SIB-L4_F0,11    RESET
FPC6_T->SIB-L4_F0,12    RESET
FPC6_B->SIB-L4_F0,13    UP
FPC7_T->SIB-L4_F0,14    RESET
FPC7_B->SIB-L4_F0,15    RESET
SIB4_F1 (F3 ):
SIB-S4_F0,00->SIB-L4_F1,00 UP
SIB-S4_F0,04->SIB-L4_F1,01 UP
SIB-S4_F3,11->SIB-L4_F1,02 UP
SIB-S4_F3,15->SIB-L4_F1,03 UP
SIB-S4_F0,08->SIB-L4_F1,04 UP
SIB-S4_F0,12->SIB-L4_F1,05 UP
SIB-S4_F3,03->SIB-L4_F1,06 UP
SIB-S4_F3,07->SIB-L4_F1,07 UP
SIB-S4_F1,00->SIB-L4_F1,08 UP
SIB-S4_F1,04->SIB-L4_F1,09 UP
SIB-S4_F2,11->SIB-L4_F1,10 UP
SIB-S4_F2,15->SIB-L4_F1,11 UP
SIB-S4_F1,08->SIB-L4_F1,12 UP
SIB-S4_F1,12->SIB-L4_F1,13 UP
SIB-S4_F2,03->SIB-L4_F1,14 UP
SIB-S4_F2,07->SIB-L4_F1,15 UP
SIB-L2_F0,10->SIB-S2_F1,04 DOWN
SIB-L2_F0,11->SIB-S2_F1,00 DOWN
SIB-L2_F0,12->SIB-S2_F2,07 DOWN
SIB-L2_F0,13->SIB-S2_F2,03 DOWN
SIB-L2_F0,14->SIB-S2_F1,12 DOWN
SIB-L2_F0,15->SIB-S2_F1,08 DOWN
SIB-L2_F1,00->FPC7_B    DOWN
SIB-L2_F1,01->FPC7_T    DOWN
SIB-L2_F1,02->FPC6_B    DOWN
SIB-L2_F1,03->FPC6_T    DOWN
SIB-L2_F1,04->FPC5_B    DOWN
SIB-L2_F1,05->FPC5_T    DOWN
SIB-L2_F1,06->FPC4_B    DOWN
SIB-L2_F1,07->FPC4_T    DOWN
SIB-L2_F1,08->FPC3_B    DOWN
SIB-L2_F1,09->FPC3_T    DOWN
SIB-L2_F1,10->FPC2_B    DOWN
SIB-L2_F1,11->FPC2_T    DOWN
SIB-L2_F1,12->FPC1_B    DOWN
SIB-L2_F1,13->FPC1_T    DOWN
SIB-L2_F1,14->FPC0_B    DOWN
SIB-L2_F1,15->FPC0_T    DOWN
SIB-L4_F0,00->SIB-S4_F3,15 UP
SIB-L4_F0,01->SIB-S4_F3,11 UP
SIB-L4_F0,02->SIB-S4_F0,04 UP
SIB-L4_F0,03->SIB-S4_F0,00 UP
SIB-L4_F0,04->SIB-S4_F3,07 UP
SIB-L4_F0,05->SIB-S4_F3,03 UP
SIB-L4_F0,06->SIB-S4_F0,12 UP
SIB-L4_F0,07->SIB-S4_F0,08 UP
SIB-L4_F0,08->SIB-S4_F2,15 UP
SIB-L4_F0,09->SIB-S4_F2,11 UP
SIB-L4_F0,10->SIB-S4_F1,04 UP
SIB-L4_F0,11->SIB-S4_F1,00 UP
SIB-L4_F0,12->SIB-S4_F2,07 UP
SIB-L4_F0,13->SIB-S4_F2,03 UP
SIB-L4_F0,14->SIB-S4_F1,12 UP
SIB-L4_F0,15->SIB-S4_F1,08 UP
SIB-L4_F1,00->FPC7_B    UP
SIB-L4_F1,01->FPC7_T    UP
SIB-L4_F1,02->FPC6_B    UP
SIB-L4_F1,03->FPC6_T    UP
SIB-L4_F1,04->FPC5_B    UP
SIB-L4_F1,05->FPC5_T    UP
SIB-L4_F1,06->FPC4_B    UP
SIB-L4_F1,07->FPC4_T    UP
SIB-L4_F1,08->FPC3_B    UP
SIB-L4_F1,09->FPC3_T    UP
SIB-L4_F1,10->FPC2_B    UP
SIB-L4_F1,11->FPC2_T    UP
SIB-L4_F1,12->FPC1_B    UP
SIB-L4_F1,13->FPC1_T    UP
SIB-L4_F1,14->FPC0_B    UP
SIB-L4_F1,15->FPC0_T    UP

```

**show chassis fabric
topology (TX Matrix
Plus Router)**

```
user@host> show chassis fabric topology
sfc0-re0:
```

```
-----
1cc0-re0:
```

```
-----
SIB0
```

```
=====
```

```
Out-Links:
```

```
=====
```

LCC00_ST_SIB_L00	-> SFC0_F13_SIB_00	VCSEL Status	HSL2 Channel	HSL2 Status
=====				
FPC0_T_SG(0,0,0)_FB_D(04,11)	-> SF_1_00_FB_D(01,11)	OK	12	Up
FPC0_T_SG(0,0,1)_FB_D(04,10)	-> SF_1_00_FB_D(01,10)	OK	12	Up
FPC0_T_SG(0,0,2)_FB_D(04,09)	-> SF_1_00_FB_D(01,09)	OK	12	Up
FPC0_T_SG(0,0,3)_FB_D(04,08)	-> SF_1_00_FB_D(01,08)	OK	12	Up
FPC0_T_SG(0,0,4)_FB_D(04,07)	-> SF_1_00_FB_D(01,07)	OK	12	Up
FPC0_T_SG(0,0,5)_FB_D(04,06)	-> SF_1_00_FB_D(01,06)	OK	12	Up
FPC0_T_SG(0,0,6)_FB_D(04,05)	-> SF_1_00_FB_D(01,05)	OK	12	Up
FPC0_T_SG(0,0,7)_FB_D(04,04)	-> SF_1_00_FB_D(01,04)	OK	12	Up
FPC0_B_SG(0,1,0)_FB_D(03,07)	-> SF_1_10_FB_D(00,07)	OK	15	Up
FPC0_B_SG(0,1,1)_FB_D(03,06)	-> SF_1_10_FB_D(00,06)	OK	15	Up
FPC0_B_SG(0,1,2)_FB_D(03,05)	-> SF_1_10_FB_D(00,05)	OK	15	Up
FPC0_B_SG(0,1,3)_FB_D(03,04)	-> SF_1_10_FB_D(00,04)	OK	15	Up
FPC0_B_SG(0,1,4)_FB_D(03,03)	-> SF_1_10_FB_D(00,03)	OK	15	Up
FPC0_B_SG(0,1,5)_FB_D(03,02)	-> SF_1_10_FB_D(00,02)	OK	15	Up
FPC0_B_SG(0,1,6)_FB_D(03,01)	-> SF_1_10_FB_D(00,01)	OK	15	Up
FPC0_B_SG(0,1,7)_FB_D(03,00)	-> SF_1_10_FB_D(00,00)	OK	15	Up
FPC1_T_SG(0,2,0)_FB_D(05,08)	-> SF_1_02_FB_D(02,08)	OK	18	Up
FPC1_T_SG(0,2,1)_FB_D(05,07)	-> SF_1_02_FB_D(02,07)	OK	18	Up
FPC1_T_SG(0,2,2)_FB_D(05,06)	-> SF_1_02_FB_D(02,06)	OK	18	Up
FPC1_T_SG(0,2,3)_FB_D(05,05)	-> SF_1_02_FB_D(02,05)	OK	18	Up
FPC1_T_SG(0,2,4)_FB_D(05,03)	-> SF_1_02_FB_D(02,03)	OK	18	Up
FPC1_T_SG(0,2,5)_FB_D(05,02)	-> SF_1_02_FB_D(02,02)	OK	18	Up
FPC1_T_SG(0,2,6)_FB_D(05,01)	-> SF_1_02_FB_D(02,01)	HIGH	CUR	18
FPC1_T_SG(0,2,7)_FB_D(05,00)	-> SF_1_02_FB_D(02,00)	OK	18	Up
FPC1_B_SG(0,3,0)_FB_D(04,03)	-> SF_1_11_FB_D(01,03)	OK	21	Up
FPC1_B_SG(0,3,1)_FB_D(04,02)	-> SF_1_11_FB_D(01,02)	OK	21	Up
FPC1_B_SG(0,3,2)_FB_D(04,01)	-> SF_1_11_FB_D(01,01)	OK	21	Up
FPC1_B_SG(0,3,3)_FB_D(04,00)	-> SF_1_11_FB_D(01,00)	OK	21	Up
FPC1_B_SG(0,3,4)_FB_D(03,11)	-> SF_1_11_FB_D(00,11)	OK	21	Up
FPC1_B_SG(0,3,5)_FB_D(03,10)	-> SF_1_11_FB_D(00,10)	OK	21	Up
FPC1_B_SG(0,3,6)_FB_D(03,09)	-> SF_1_11_FB_D(00,09)	OK	21	Up
FPC1_B_SG(0,3,7)_FB_D(03,08)	-> SF_1_11_FB_D(00,08)	OK	21	Up
FPC2_T_SG(1,0,0)_FB_C(10,11)	-> SF_1_04_FB_C(07,11)	OK	12	Up
FPC2_T_SG(1,0,1)_FB_C(10,10)	-> SF_1_04_FB_C(07,10)	OK	12	Up
FPC2_T_SG(1,0,2)_FB_C(10,09)	-> SF_1_04_FB_C(07,09)	OK	12	Up
FPC2_T_SG(1,0,3)_FB_C(10,08)	-> SF_1_04_FB_C(07,08)	OK	12	Up
FPC2_T_SG(1,0,4)_FB_C(10,07)	-> SF_1_04_FB_C(07,07)	OK	12	Up
FPC2_T_SG(1,0,5)_FB_C(10,06)	-> SF_1_04_FB_C(07,06)	OK	12	Up
FPC2_T_SG(1,0,6)_FB_C(10,05)	-> SF_1_04_FB_C(07,05)	OK	12	Up
FPC2_T_SG(1,0,7)_FB_C(10,04)	-> SF_1_04_FB_C(07,04)	OK	12	Up
FPC2_B_SG(1,1,0)_FB_C(09,07)	-> SF_1_14_FB_C(06,07)	OK	15	Up
FPC2_B_SG(1,1,1)_FB_C(09,06)	-> SF_1_14_FB_C(06,06)	OK	15	Up
FPC2_B_SG(1,1,2)_FB_C(09,05)	-> SF_1_14_FB_C(06,05)	OK	15	Up
FPC2_B_SG(1,1,3)_FB_C(09,04)	-> SF_1_14_FB_C(06,04)	OK	15	Up
FPC2_B_SG(1,1,4)_FB_C(09,03)	-> SF_1_14_FB_C(06,03)	OK	15	Up
FPC2_B_SG(1,1,5)_FB_C(09,02)	-> SF_1_14_FB_C(06,02)	OK	15	Up

FPC2_B_SG(1,1,6)_FB_C(09,01)	-> SF_1_14_FB_C(06,01)	OK	15	Up
FPC2_B_SG(1,1,7)_FB_C(09,00)	-> SF_1_14_FB_C(06,00)	OK	15	Up
FPC3_T_SG(1,2,0)_FB_C(11,08)	-> SF_1_06_FB_C(08,08)	OK	18	Up
FPC3_T_SG(1,2,1)_FB_C(11,07)	-> SF_1_06_FB_C(08,07)	OK	18	Up
FPC3_T_SG(1,2,2)_FB_C(11,06)	-> SF_1_06_FB_C(08,06)	OK	18	Up
FPC3_T_SG(1,2,3)_FB_C(11,05)	-> SF_1_06_FB_C(08,05)	OK	18	Up
FPC3_T_SG(1,2,4)_FB_C(11,03)	-> SF_1_06_FB_C(08,03)	OK	18	Up
FPC3_T_SG(1,2,5)_FB_C(11,02)	-> SF_1_06_FB_C(08,02)	OK	18	Up
FPC3_T_SG(1,2,6)_FB_C(11,01)	-> SF_1_06_FB_C(08,01)	OK	18	Up
FPC3_T_SG(1,2,7)_FB_C(11,00)	-> SF_1_06_FB_C(08,00)	OK	18	Up
FPC3_B_SG(1,3,0)_FB_C(10,03)	-> SF_1_15_FB_C(07,03)	OK	21	Up
FPC3_B_SG(1,3,1)_FB_C(10,02)	-> SF_1_15_FB_C(07,02)	OK	21	Up
FPC3_B_SG(1,3,2)_FB_C(10,01)	-> SF_1_15_FB_C(07,01)	HIGH	CUR	21
FPC3_B_SG(1,3,3)_FB_C(10,00)	-> SF_1_15_FB_C(07,00)	OK	21	Up
FPC3_B_SG(1,3,4)_FB_C(09,11)	-> SF_1_15_FB_C(06,11)	OK	21	Up
FPC3_B_SG(1,3,5)_FB_C(09,10)	-> SF_1_15_FB_C(06,10)	OK	21	Up
FPC3_B_SG(1,3,6)_FB_C(09,09)	-> SF_1_15_FB_C(06,09)	OK	21	Up
FPC3_B_SG(1,3,7)_FB_C(09,08)	-> SF_1_15_FB_C(06,08)	OK	21	Up
FPC4_T_SG(2,0,0)_FB_B(16,11)	-> SF_1_01_FB_B(13,11)	OK	12	Up
FPC4_T_SG(2,0,1)_FB_B(16,10)	-> SF_1_01_FB_B(13,10)	OK	12	Up
FPC4_T_SG(2,0,2)_FB_B(16,09)	-> SF_1_01_FB_B(13,09)	OK	12	Up
FPC4_T_SG(2,0,3)_FB_B(16,08)	-> SF_1_01_FB_B(13,08)	OK	12	Up
FPC4_T_SG(2,0,4)_FB_B(16,07)	-> SF_1_01_FB_B(13,07)	OK	12	Up
FPC4_T_SG(2,0,5)_FB_B(16,06)	-> SF_1_01_FB_B(13,06)	OK	12	Up
FPC4_T_SG(2,0,6)_FB_B(16,05)	-> SF_1_01_FB_B(13,05)	OK	12	Up
FPC4_T_SG(2,0,7)_FB_B(16,04)	-> SF_1_01_FB_B(13,04)	OK	12	Up
FPC4_B_SG(2,1,0)_FB_B(15,07)	-> SF_1_08_FB_B(12,07)	OK	15	Up
FPC4_B_SG(2,1,1)_FB_B(15,06)	-> SF_1_08_FB_B(12,06)	OK	15	Up
FPC4_B_SG(2,1,2)_FB_B(15,05)	-> SF_1_08_FB_B(12,05)	OK	15	Up
FPC4_B_SG(2,1,3)_FB_B(15,04)	-> SF_1_08_FB_B(12,04)	OK	15	Up
FPC4_B_SG(2,1,4)_FB_B(15,03)	-> SF_1_08_FB_B(12,03)	OK	15	Up
FPC4_B_SG(2,1,5)_FB_B(15,02)	-> SF_1_08_FB_B(12,02)	OK	15	Up
FPC4_B_SG(2,1,6)_FB_B(15,01)	-> SF_1_08_FB_B(12,01)	OK	15	Up
FPC4_B_SG(2,1,7)_FB_B(15,00)	-> SF_1_08_FB_B(12,00)	OK	15	Up
FPC5_T_SG(2,2,0)_FB_B(17,08)	-> SF_1_03_FB_B(14,08)	OK	18	Up
FPC5_T_SG(2,2,1)_FB_B(17,07)	-> SF_1_03_FB_B(14,07)	OK	18	Up
FPC5_T_SG(2,2,2)_FB_B(17,06)	-> SF_1_03_FB_B(14,06)	OK	18	Up
FPC5_T_SG(2,2,3)_FB_B(17,05)	-> SF_1_03_FB_B(14,05)	OK	18	Up
FPC5_T_SG(2,2,4)_FB_B(17,03)	-> SF_1_03_FB_B(14,03)	OK	18	Up
FPC5_T_SG(2,2,5)_FB_B(17,02)	-> SF_1_03_FB_B(14,02)	OK	18	Up
FPC5_T_SG(2,2,6)_FB_B(17,01)	-> SF_1_03_FB_B(14,01)	OK	18	Up
FPC5_T_SG(2,2,7)_FB_B(17,00)	-> SF_1_03_FB_B(14,00)	OK	18	Up
FPC5_B_SG(2,3,0)_FB_B(16,03)	-> SF_1_09_FB_B(13,03)	OK	21	Up
FPC5_B_SG(2,3,1)_FB_B(16,02)	-> SF_1_09_FB_B(13,02)	OK	21	Up
FPC5_B_SG(2,3,2)_FB_B(16,01)	-> SF_1_09_FB_B(13,01)	OK	21	Up
FPC5_B_SG(2,3,3)_FB_B(16,00)	-> SF_1_09_FB_B(13,00)	OK	21	Up
FPC5_B_SG(2,3,4)_FB_B(15,11)	-> SF_1_09_FB_B(12,11)	OK	21	Up
FPC5_B_SG(2,3,5)_FB_B(15,10)	-> SF_1_09_FB_B(12,10)	OK	21	Up
FPC5_B_SG(2,3,6)_FB_B(15,09)	-> SF_1_09_FB_B(12,09)	OK	21	Up
FPC5_B_SG(2,3,7)_FB_B(15,08)	-> SF_1_09_FB_B(12,08)	OK	21	Up
FPC6_T_SG(3,0,0)_FB_A(22,11)	-> SF_1_05_FB_A(19,11)	OK	12	Up
FPC6_T_SG(3,0,1)_FB_A(22,10)	-> SF_1_05_FB_A(19,10)	OK	12	Up
FPC6_T_SG(3,0,2)_FB_A(22,09)	-> SF_1_05_FB_A(19,09)	OK	12	Up
FPC6_T_SG(3,0,3)_FB_A(22,08)	-> SF_1_05_FB_A(19,08)	OK	12	Up
FPC6_T_SG(3,0,4)_FB_A(22,07)	-> SF_1_05_FB_A(19,07)	OK	12	Up
FPC6_T_SG(3,0,5)_FB_A(22,06)	-> SF_1_05_FB_A(19,06)	OK	12	Up
FPC6_T_SG(3,0,6)_FB_A(22,05)	-> SF_1_05_FB_A(19,05)	OK	12	Up
FPC6_T_SG(3,0,7)_FB_A(22,04)	-> SF_1_05_FB_A(19,04)	OK	12	Up
FPC6_B_SG(3,1,0)_FB_A(21,07)	-> SF_1_12_FB_A(18,07)	OK	15	Up
FPC6_B_SG(3,1,1)_FB_A(21,06)	-> SF_1_12_FB_A(18,06)	OK	15	Up
...				

```
show chassis fabric topology sfc (TX
Matrix Plus Router)
```

```
user@host> show chassis fabric topology sfc 0
sfc0-re0:
```

```
F13_SIB0
```

```
=====
```

```
Out-Links:
```

```
=====
```

SFC0_F13_SIB_00	-> LCC00_ST_SIB_L00	VCSEL Status	HSL2 Channel	HSL2 Status
=====				
SF_3_00_FB_D(04,11)	-> FPC0_T_SG(0,0,0)_FB_D(01,11)	OK	112	Up
SF_3_00_FB_D(04,10)	-> FPC0_T_SG(0,0,1)_FB_D(01,10)	OK	112	Up
SF_3_00_FB_D(04,09)	-> FPC0_T_SG(0,0,2)_FB_D(01,09)	OK	112	Up
SF_3_00_FB_D(04,08)	-> FPC0_T_SG(0,0,3)_FB_D(01,08)	OK	112	Up
SF_3_00_FB_D(04,07)	-> FPC0_T_SG(0,0,4)_FB_D(01,07)	OK	112	Up
SF_3_00_FB_D(04,06)	-> FPC0_T_SG(0,0,5)_FB_D(01,06)	OK	112	Up
SF_3_00_FB_D(04,05)	-> FPC0_T_SG(0,0,6)_FB_D(01,05)	OK	112	Up
SF_3_00_FB_D(04,04)	-> FPC0_T_SG(0,0,7)_FB_D(01,04)	OK	112	Up
SF_3_01_FB_B(16,11)	-> FPC4_T_SG(2,0,0)_FB_B(13,11)	OK	119	Up
SF_3_01_FB_B(16,10)	-> FPC4_T_SG(2,0,1)_FB_B(13,10)	OK	119	Up
SF_3_01_FB_B(16,09)	-> FPC4_T_SG(2,0,2)_FB_B(13,09)	OK	119	Up
SF_3_01_FB_B(16,08)	-> FPC4_T_SG(2,0,3)_FB_B(13,08)	OK	119	Up
SF_3_01_FB_B(16,07)	-> FPC4_T_SG(2,0,4)_FB_B(13,07)	OK	119	Up
SF_3_01_FB_B(16,06)	-> FPC4_T_SG(2,0,5)_FB_B(13,06)	OK	119	Up
SF_3_01_FB_B(16,05)	-> FPC4_T_SG(2,0,6)_FB_B(13,05)	OK	119	Up
SF_3_01_FB_B(16,04)	-> FPC4_T_SG(2,0,7)_FB_B(13,04)	OK	119	Up
SF_3_02_FB_D(05,08)	-> FPC1_T_SG(0,2,0)_FB_D(02,08)	OK	126	Up
SF_3_02_FB_D(05,07)	-> FPC1_T_SG(0,2,1)_FB_D(02,07)	OK	126	Up
SF_3_02_FB_D(05,06)	-> FPC1_T_SG(0,2,2)_FB_D(02,06)	OK	126	Up
SF_3_02_FB_D(05,05)	-> FPC1_T_SG(0,2,3)_FB_D(02,05)	OK	126	Up
SF_3_02_FB_D(05,03)	-> FPC1_T_SG(0,2,4)_FB_D(02,03)	OK	126	Up
SF_3_02_FB_D(05,02)	-> FPC1_T_SG(0,2,5)_FB_D(02,02)	OK	126	Up
SF_3_02_FB_D(05,01)	-> FPC1_T_SG(0,2,6)_FB_D(02,01)	OK	126	Up
SF_3_02_FB_D(05,00)	-> FPC1_T_SG(0,2,7)_FB_D(02,00)	OK	126	Up
SF_3_03_FB_B(17,08)	-> FPC5_T_SG(2,2,0)_FB_B(14,08)	OK	133	Up
SF_3_03_FB_B(17,07)	-> FPC5_T_SG(2,2,1)_FB_B(14,07)	OK	133	Up
SF_3_03_FB_B(17,06)	-> FPC5_T_SG(2,2,2)_FB_B(14,06)	OK	133	Up
SF_3_03_FB_B(17,05)	-> FPC5_T_SG(2,2,3)_FB_B(14,05)	OK	133	Up
SF_3_03_FB_B(17,03)	-> FPC5_T_SG(2,2,4)_FB_B(14,03)	OK	133	Up
SF_3_03_FB_B(17,02)	-> FPC5_T_SG(2,2,5)_FB_B(14,02)	OK	133	Up
SF_3_03_FB_B(17,01)	-> FPC5_T_SG(2,2,6)_FB_B(14,01)	OK	133	Up
SF_3_03_FB_B(17,00)	-> FPC5_T_SG(2,2,7)_FB_B(14,00)	OK	133	Up
SF_3_04_FB_C(10,11)	-> FPC2_T_SG(1,0,0)_FB_C(07,11)	OK	140	Up
SF_3_04_FB_C(10,10)	-> FPC2_T_SG(1,0,1)_FB_C(07,10)	OK	140	Up
SF_3_04_FB_C(10,09)	-> FPC2_T_SG(1,0,2)_FB_C(07,09)	OK	140	Up
SF_3_04_FB_C(10,08)	-> FPC2_T_SG(1,0,3)_FB_C(07,08)	OK	140	Up
SF_3_04_FB_C(10,07)	-> FPC2_T_SG(1,0,4)_FB_C(07,07)	OK	140	Up
SF_3_04_FB_C(10,06)	-> FPC2_T_SG(1,0,5)_FB_C(07,06)	OK	140	Up
SF_3_04_FB_C(10,05)	-> FPC2_T_SG(1,0,6)_FB_C(07,05)	OK	140	Up
SF_3_04_FB_C(10,04)	-> FPC2_T_SG(1,0,7)_FB_C(07,04)	OK	140	Up
SF_3_05_FB_A(22,11)	-> FPC6_T_SG(3,0,0)_FB_A(19,11)	OK	147	Up
SF_3_05_FB_A(22,10)	-> FPC6_T_SG(3,0,1)_FB_A(19,10)	OK	147	Up
SF_3_05_FB_A(22,09)	-> FPC6_T_SG(3,0,2)_FB_A(19,09)	OK	147	Up
SF_3_05_FB_A(22,08)	-> FPC6_T_SG(3,0,3)_FB_A(19,08)	OK	147	Up
SF_3_05_FB_A(22,07)	-> FPC6_T_SG(3,0,4)_FB_A(19,07)	OK	147	Up
SF_3_05_FB_A(22,06)	-> FPC6_T_SG(3,0,5)_FB_A(19,06)	OK	147	Up
SF_3_05_FB_A(22,05)	-> FPC6_T_SG(3,0,6)_FB_A(19,05)	HIGH	CUR	147
SF_3_05_FB_A(22,04)	-> FPC6_T_SG(3,0,7)_FB_A(19,04)	OK	147	Up
SF_3_06_FB_C(11,08)	-> FPC3_T_SG(1,2,0)_FB_C(08,08)	OK	154	Up


```

SF_3_06_FB_C(11,07) -> FPC3_T_SG(1,2,1)_FB_C(08,07)    OK      154    Up
SF_3_06_FB_C(11,06) -> FPC3_T_SG(1,2,2)_FB_C(08,06)    OK      154    Up
SF_3_06_FB_C(11,05) -> FPC3_T_SG(1,2,3)_FB_C(08,05)    OK      154    Up
SF_3_06_FB_C(11,03) -> FPC3_T_SG(1,2,4)_FB_C(08,03)    OK      154    Up
SF_3_06_FB_C(11,02) -> FPC3_T_SG(1,2,5)_FB_C(08,02)    OK      154    Up
SF_3_06_FB_C(11,01) -> FPC3_T_SG(1,2,6)_FB_C(08,01)    OK      154    Up
...

```

show chassis fabric
topology lcc (TX Matrix
Plus Router)

```

user@host> show chassis fabric topology lcc 0
lcc0-re0:

```

SIB0

=====

Out-Links:

=====

LCC00_ST_SIB_L00	-> SFC0_F13_SIB_00	VCSEL Status	HSL2 Channel	HSL2 Status
=====				
FPC0_T_SG(0,0,0)_FB_D(04,11)	-> SF_1_00_FB_D(01,11)	OK	12	Up
FPC0_T_SG(0,0,1)_FB_D(04,10)	-> SF_1_00_FB_D(01,10)	OK	12	Up
FPC0_T_SG(0,0,2)_FB_D(04,09)	-> SF_1_00_FB_D(01,09)	OK	12	Up
FPC0_T_SG(0,0,3)_FB_D(04,08)	-> SF_1_00_FB_D(01,08)	OK	12	Up
FPC0_T_SG(0,0,4)_FB_D(04,07)	-> SF_1_00_FB_D(01,07)	OK	12	Up
FPC0_T_SG(0,0,5)_FB_D(04,06)	-> SF_1_00_FB_D(01,06)	OK	12	Up
FPC0_T_SG(0,0,6)_FB_D(04,05)	-> SF_1_00_FB_D(01,05)	OK	12	Up
FPC0_T_SG(0,0,7)_FB_D(04,04)	-> SF_1_00_FB_D(01,04)	OK	12	Up
FPC0_B_SG(0,1,0)_FB_D(03,07)	-> SF_1_10_FB_D(00,07)	OK	15	Up
FPC0_B_SG(0,1,1)_FB_D(03,06)	-> SF_1_10_FB_D(00,06)	OK	15	Up
FPC0_B_SG(0,1,2)_FB_D(03,05)	-> SF_1_10_FB_D(00,05)	OK	15	Up
FPC0_B_SG(0,1,3)_FB_D(03,04)	-> SF_1_10_FB_D(00,04)	OK	15	Up
FPC0_B_SG(0,1,4)_FB_D(03,03)	-> SF_1_10_FB_D(00,03)	OK	15	Up
FPC0_B_SG(0,1,5)_FB_D(03,02)	-> SF_1_10_FB_D(00,02)	OK	15	Up
FPC0_B_SG(0,1,6)_FB_D(03,01)	-> SF_1_10_FB_D(00,01)	OK	15	Up
FPC0_B_SG(0,1,7)_FB_D(03,00)	-> SF_1_10_FB_D(00,00)	OK	15	Up
FPC1_T_SG(0,2,0)_FB_D(05,08)	-> SF_1_02_FB_D(02,08)	OK	18	Up
FPC1_T_SG(0,2,1)_FB_D(05,07)	-> SF_1_02_FB_D(02,07)	OK	18	Up
FPC1_T_SG(0,2,2)_FB_D(05,06)	-> SF_1_02_FB_D(02,06)	OK	18	Up
FPC1_T_SG(0,2,3)_FB_D(05,05)	-> SF_1_02_FB_D(02,05)	OK	18	Up
FPC1_T_SG(0,2,4)_FB_D(05,03)	-> SF_1_02_FB_D(02,03)	OK	18	Up
FPC1_T_SG(0,2,5)_FB_D(05,02)	-> SF_1_02_FB_D(02,02)	OK	18	Up
FPC1_T_SG(0,2,6)_FB_D(05,01)	-> SF_1_02_FB_D(02,01)	HIGH	CUR	18
FPC1_T_SG(0,2,7)_FB_D(05,00)	-> SF_1_02_FB_D(02,00)	OK	18	Up
FPC1_B_SG(0,3,0)_FB_D(04,03)	-> SF_1_11_FB_D(01,03)	OK	21	Up
FPC1_B_SG(0,3,1)_FB_D(04,02)	-> SF_1_11_FB_D(01,02)	OK	21	Up
FPC1_B_SG(0,3,2)_FB_D(04,01)	-> SF_1_11_FB_D(01,01)	OK	21	Up
FPC1_B_SG(0,3,3)_FB_D(04,00)	-> SF_1_11_FB_D(01,00)	OK	21	Up
FPC1_B_SG(0,3,4)_FB_D(03,11)	-> SF_1_11_FB_D(00,11)	OK	21	Up
FPC1_B_SG(0,3,5)_FB_D(03,10)	-> SF_1_11_FB_D(00,10)	OK	21	Up
FPC1_B_SG(0,3,6)_FB_D(03,09)	-> SF_1_11_FB_D(00,09)	OK	21	Up
FPC1_B_SG(0,3,7)_FB_D(03,08)	-> SF_1_11_FB_D(00,08)	OK	21	Up
FPC2_T_SG(1,0,0)_FB_C(10,11)	-> SF_1_04_FB_C(07,11)	OK	12	Up
FPC2_T_SG(1,0,1)_FB_C(10,10)	-> SF_1_04_FB_C(07,10)	OK	12	Up
FPC2_T_SG(1,0,2)_FB_C(10,09)	-> SF_1_04_FB_C(07,09)	OK	12	Up
FPC2_T_SG(1,0,3)_FB_C(10,08)	-> SF_1_04_FB_C(07,08)	OK	12	Up
FPC2_T_SG(1,0,4)_FB_C(10,07)	-> SF_1_04_FB_C(07,07)	OK	12	Up
FPC2_T_SG(1,0,5)_FB_C(10,06)	-> SF_1_04_FB_C(07,06)	OK	12	Up
FPC2_T_SG(1,0,6)_FB_C(10,05)	-> SF_1_04_FB_C(07,05)	OK	12	Up
FPC2_T_SG(1,0,7)_FB_C(10,04)	-> SF_1_04_FB_C(07,04)	OK	12	Up
FPC2_B_SG(1,1,0)_FB_C(09,07)	-> SF_1_14_FB_C(06,07)	OK	15	Up

FPC2_B_SG(1,1,1)_FB_C(09,06)	-> SF_1_14_FB_C(06,06)	OK	15	Up
FPC2_B_SG(1,1,2)_FB_C(09,05)	-> SF_1_14_FB_C(06,05)	OK	15	Up
FPC2_B_SG(1,1,3)_FB_C(09,04)	-> SF_1_14_FB_C(06,04)	OK	15	Up
FPC2_B_SG(1,1,4)_FB_C(09,03)	-> SF_1_14_FB_C(06,03)	OK	15	Up
FPC2_B_SG(1,1,5)_FB_C(09,02)	-> SF_1_14_FB_C(06,02)	OK	15	Up
FPC2_B_SG(1,1,6)_FB_C(09,01)	-> SF_1_14_FB_C(06,01)	OK	15	Up
FPC2_B_SG(1,1,7)_FB_C(09,00)	-> SF_1_14_FB_C(06,00)	OK	15	Up
FPC3_T_SG(1,2,0)_FB_C(11,08)	-> SF_1_06_FB_C(08,08)	OK	18	Up
FPC3_T_SG(1,2,1)_FB_C(11,07)	-> SF_1_06_FB_C(08,07)	OK	18	Up
FPC3_T_SG(1,2,2)_FB_C(11,06)	-> SF_1_06_FB_C(08,06)	OK	18	Up
FPC3_T_SG(1,2,3)_FB_C(11,05)	-> SF_1_06_FB_C(08,05)	OK	18	Up
FPC3_T_SG(1,2,4)_FB_C(11,03)	-> SF_1_06_FB_C(08,03)	OK	18	Up
FPC3_T_SG(1,2,5)_FB_C(11,02)	-> SF_1_06_FB_C(08,02)	OK	18	Up
FPC3_T_SG(1,2,6)_FB_C(11,01)	-> SF_1_06_FB_C(08,01)	OK	18	Up
...				

show chassis feb

Syntax	show chassis feb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M5, M10, and M120 routers only) Display Forwarding Engine Board (FEB) status information.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis feb (M10 Router) on page 396 show chassis feb (M120 Router) on page 396 show chassis feb detail (M120 Router) on page 396
Output Fields	Table 72 on page 395 lists the output fields for the show chassis feb command. Output fields are listed in the approximate order in which they appear.

Table 72: show chassis feb

Field Name	Field Description
State	State of the FEB: <ul style="list-style-type: none"> • Offline—FEB is powered down. • Online—FEB is operational and running. • Check—FEB is in alarmed state where the Switch Interface Board (SIB) plane is partially operational for the following reasons: <ul style="list-style-type: none"> • FEB is not inserted properly. • Two or more links between the FEB and Packet Forwarding Engine fail.
Temp (C) or Intake temperature	Temperature of the air passing by the FEB, in degrees Celsius or in both degrees Celsius and degrees Fahrenheit.
CPU Utilization (%)	Percentage of CPU being used: <ul style="list-style-type: none"> • Total—Total percentage of CPU being used by the FEB processor. • Interrupt—Of the total CPU being used by the FEB processor, the percentage being used for interrupts.
Memory DRAM (MB)	Total DRAM, in megabytes, available to the FEB processor.
Utilization (%)	Percentage of memory utilization: <ul style="list-style-type: none"> • Heap—Percentage of heap space (dynamic memory) being used by the FEB processor. If this number exceeds 80 percent, you might experience a software problem (memory leak). • Buffer—Percentage of buffer space being used by the FPC processor for buffering internal messages.
Exhaust A temperature	Temperature of the air flowing past Exhaust A.

Table 72: show chassis feb (continued)

Field Name	Field Description
Exhaust B temperature	Temperature of the air flowing past Exhaust B.
Total DDR DRAM	Amount of double data rate dynamic random access memory (DDR DRAM) available to the FEB CPU.
Total RLD RAM	Amount of reduced latency dynamic random access memory (RLDRAM) available to the FEB CPU.
Start time (Detail output only)	Time when the Routing Engine detected that the FEB was running.
Uptime (Detail output only)	How long the Routing Engine has been connected to the FEB, and therefore, how long the Flexible PIC Concentrator (PIC) has been up and running.

Sample Output

```

show chassis feb (M10 Router)  user@host> show chassis feb
                                FEB status:
                                Temperature          27 degrees C / 80 degrees F
                                CPU utilization         3 percent
                                Interrupt utilization   0 percent
                                Heap utilization        26 percent
                                Buffer utilization       50 percent
                                Total CPU DRAM         64 MB
                                Internet Processor II   Version 1, Foundry IBM, Part number 9
                                Start time:            2010-05-23 13:59:51 PDT
                                Uptime:                6 hours, 33 minutes, 11 seconds

```

```

show chassis feb (M120 Router) user@host> show chassis feb
                                Temp  CPU Utilization (%)  Memory  Utilization (%)
                                (C)   Total  Interrupt  DRAM (MB) Heap      Buffer
Slot State
0  Online      47      4      0      512      7      60
1  Online      54      3      0      512      7      59
2  Online      50      4      0      512      7      59
3  Online      49      4      0      512      7      59
4  Online      46      3      0      512      7      59
5  Online      35      3      0      512      7      59

```

```

show chassis feb detail (M120 Router) user@host> show chassis feb detail
Slot 0 information:
State                Online
Intake temperature   48 degrees C / 118 degrees F
Exhaust A temperature 51 degrees C / 123 degrees F
Exhaust B temperature 52 degrees C / 125 degrees F
Total DDR DRAM       512 MB
Total RLD RAM        32 MB
Start time:          2006-06-28 15:00:40 PDT
Uptime:              10 minutes, 21 seconds
Slot 1 information:
State                Online
Intake temperature   55 degrees C / 131 degrees F
Exhaust A temperature 46 degrees C / 114 degrees F
Exhaust B temperature 45 degrees C / 113 degrees F
Total DDR DRAM       512 MB
Total RLD RAM        32 MB

```

```
Start time:                2006-06-28 15:00:33 PDT
Uptime:                    10 minutes, 28 seconds
Slot 2 information:
  State                     Online
  Intake temperature        50 degrees C / 122 degrees F
  Exhaust A temperature     47 degrees C / 116 degrees F
  Exhaust B temperature     47 degrees C / 116 degrees F
  Total DDR DRAM            512 MB
  Total RLD RAM             32 MB
  Start time:               2006-06-28 15:00:35 PDT
  Uptime:                    10 minutes, 26 seconds
Slot 3 information:
  State                     Online
  Intake temperature        49 degrees C / 120 degrees F
  Exhaust A temperature     47 degrees C / 116 degrees F
  Exhaust B temperature     49 degrees C / 120 degrees F
  Total DDR DRAM            512 MB
  Total RLD RAM             32 MB
  Start time:               2006-06-28 15:00:43 PDT
  Uptime:                    10 minutes, 18 seconds
Slot 4 information:
  State                     Online
  Intake temperature        45 degrees C / 113 degrees F
  Exhaust A temperature     42 degrees C / 107 degrees F
  Exhaust B temperature     42 degrees C / 107 degrees F
  Total DDR DRAM            512 MB
  Total RLD RAM             32 MB
  Start time:               2006-06-28 15:00:29 PDT
  Uptime:                    10 minutes, 32 seconds
Slot 5 information:
  State                     Online
  Intake temperature        35 degrees C / 95 degrees F
  Exhaust A temperature     33 degrees C / 91 degrees F
  Exhaust B temperature     40 degrees C / 104 degrees F
  Total DDR DRAM            512 MB
  Total RLD RAM             32 MB
  Start time:               2006-06-28 15:00:27 PDT
  Uptime:                    10 minutes, 34 seconds
```

show chassis firmware

Syntax	show chassis firmware
Syntax (TX Matrix Router)	show chassis firmware <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis firmware <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis firmware <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show chassis firmware
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.4 for EX Series switches.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p> <p>Command introduced for EX8200 switches in Junos OS Release 10.2 for EX Series switches.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	<p>On the routers and switches, display the version levels of the firmware running on the System Control Board (SCB), Switching and Forwarding Module (SFM), System and Switch Board (SSB), Forwarding Engine Board (FEB), Flexible PIC Concentrators (FPCs), and Routing Engines. On a TX Matrix Plus router, display the version levels of the firmware running on the FPCs and the Switch Processor Mezzanine Board (SPMBs).</p> <p>On EX2200, EX3200, EX4200, and the QFX Series, display the version levels of the firmware running on the switch. On an EX8208 switch, display the version levels of the firmware running on the Switch Fabric and Routing Engine (SRE) modules and on the line cards (shown as FPCs). On an EX8216 switch, display the version levels of the firmware running on the Routing Engine (RE) modules and on the line cards (shown as FPCs).</p>
Options	<p>none—Display the version levels of the firmware running. For an EX4200 switch that is a member of a Virtual Chassis, display version levels for all members. For a TX Matrix router, display version levels for the firmware on the TX Matrix router and on all the T640 routers connected to the TX Matrix router. For a TX Matrix Plus router, display version levels for the firmware on the TX Matrix Plus router and on all the T1600 routers connected to the TX Matrix Plus router.</p> <p>all-members—(MX Series routers only) (Optional) Display the version levels of the firmware running for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display version levels for the firmware on a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display</p>

the version levels for the firmware on a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace **number** with a value from **0** through **3**.

local—(MX Series routers only) (Optional) Display the version levels of the firmware running for the local Virtual Chassis member.

member member-id—(MX Series routers only) (Optional) Display the version levels of the firmware running for the specified member of the Virtual Chassis configuration. Replace **member-id** with a value of 0 or 1.

scc—(TX Matrix router only) (Optional) Display version levels for the firmware on the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus router only) (Optional) Display version levels for the firmware on the TX Matrix Plus router (or switch-fabric chassis). Replace **number** with **0**.

Required Privilege Level view

List of Sample Output

```
show chassis firmware (M10 Router) on page 400
show chassis firmware (M20 Router) on page 400
show chassis firmware (M40 Router) on page 400
show chassis firmware (M120 Router) on page 400
show chassis firmware (M160 Router) on page 400
show chassis firmware (MX240 Router) on page 400
show chassis firmware (MX480 Router) on page 400
show chassis firmware (MX960 Router) on page 401
show chassis firmware (EX4200 Switch) on page 401
show chassis firmware (EX8200 Switch) on page 401
show chassis firmware lcc (TX Matrix Router) on page 401
show chassis firmware scc (TX Matrix Router) on page 401
show chassis firmware (TX Matrix Plus Router) on page 402
show chassis firmware lcc (TX Matrix Plus Router) on page 403
show chassis firmware sfc (TX Matrix Plus Router) on page 403
show chassis firmware (QFX Series) on page 404
```

Output Fields Table 73 on page 399 lists the output fields for the **show chassis firmware** command. Output fields are listed in the approximate order in which they appear.

Table 73: show chassis firmware Output Fields

Field Name	Field Description
Part	Chassis part name.
Type	Type of firmware: On routers: ROM or O/S . On switches: uboot or loader .
Version	Version of firmware running on the chassis part.

Sample Output

```

show chassis firmware user@host> show chassis firmware
(M10 Router)          Part      Type      Version
                     Forwarding engine board ROM      Juniper ROM Monitor Version 4.1b2
                     O/S          Version 4.1I1 by tlim on 2000-04-24 11:27

show chassis firmware user@host> show chassis firmware
(M20 Router)          Part      Type      Version
                     System switch board ROM      Juniper ROM Monitor Version 3.4b26
                     O/S          Version 3.4I16 by smackie on 2000-02-29 2
                     FPC 1          ROM      Juniper ROM Monitor Version 3.0b1
                     O/S          Version 3.4I4 by smackie on 2000-02-25 21
                     FPC 2          ROM      Juniper ROM Monitor Version 3.0b1
                     O/S          Version 3.4I4 by smackie on 2000-02-25 21

show chassis firmware user@host> show chassis firmware
(M40 Router)          Part      Type      Version
                     System control board ROM      Juniper ROM Monitor Version 2.0i126Copyri
                     O/S          Version 2.0i1 by root on Thu Jul 23 00:51
                     FPC 5          ROM      Juniper ROM Monitor Version 2.0i49Copyrig
                     O/S          Version 2.0i1 by root on Thu Jul 23 00:59

show chassis firmware user@host> show chassis firmware
(M120 Router)         FPC 2      ROM      Juniper ROM Monitor Version 8.0b29
                     O/S          Version 8.2B1 by builder on 2006-10-18 16:2
                     FPC 3          ROM      Juniper ROM Monitor Version 8.0b29
                     O/S          Version 8.2B1 by builder on 2006-10-18 16:2
                     FPC 4          ROM      Juniper ROM Monitor Version 8.0b29
                     O/S          Version 8.2B1 by builder on 2006-10-18 16:2
                     FEB 3          ROM      Juniper ROM Monitor Version 8.0b29
                     O/S          Version 8.2B1 by builder on 2006-10-18 16:1
                     FEB 4          ROM      Juniper ROM Monitor Version 8.0b29
                     O/S          Version 8.2B1 by builder on 2006-10-18 16:1

show chassis firmware user@host> show chassis firmware
(M160 Router)         Part      Type      Version
                     SFM 0          ROM      Juniper ROM Monitor Version 4.0b2
                     O/S          Version 4.0I1 by tlim on 2000-02-29 11:50
                     SFM 1          ROM      Juniper ROM Monitor Version 4.0b2
                     O/S          Version 4.0I1 by tlim on 2000-02-29 11:50
                     FPC 0          ROM      Juniper ROM Monitor Version 4.0b2
                     O/S          Version 4.0I1 by tlim on 2000-02-29 11:56
                     FPC 1          ROM      Juniper ROM Monitor Version 4.0b2
                     O/S          Version 4.0I1 by tlim on 2000-02-29 11:56
                     FPC 2          ROM      Juniper ROM Monitor Version 4.0b3
                     O/S          Version 4.0I1 by tlim on 2000-02-29 11:56

show chassis firmware user@host> show chassis firmware
(MX240 Router)        Part      Type      Version
                     FPC 1          ROM      Juniper ROM Monitor Version 8.3b1
                     O/S          Version 9.0-20080103.0 by builder on 2008-0
                     FPC 2          ROM      Juniper ROM Monitor Version 8.3b1
                     O/S          Version 9.0-20080103.0 by builder on 2008-0

show chassis firmware user@host> show chassis firmware
(MX480 Router)

```



```

Part                Type                Version
FPC 1               ROM                Juniper ROM Monitor Version 8.3b1
                   O/S                Version 9.0-20070916.3 by builder on 2007-0

show chassis firmware user@host> show chassis firmware
(MX960 Router)
Part                Type                Version
FPC 4               ROM                Juniper ROM Monitor Version 8.0b8
                   O/S                Version 8.2I59 by artem on 2006-10-31 19:22
FPC 7               ROM                Juniper ROM Monitor Version 8.2b1
                   O/S                Version 8.2-20061026.1 by builder on 2006-1

show chassis firmware user@host> show chassis firmware
(EX4200 Switch)
Part                Type                Version
FPC 0               uboot              U-Boot 1.1.6 (Feb  6 2008 - 11:27:42)
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.1
FPC 1               uboot              U-Boot 1.1.6 (Feb  6 2008 - 11:27:42)
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.1
FPC 2               uboot              U-Boot 1.1.6 (Feb  6 2008 - 11:27:42)
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.1

show chassis firmware user@host> show chassis firmware
(EX8200 Switch)
Part                Type                Version
FPC 0               U-Boot            U-Boot 1.1.6 (Mar 25 2009 - 06:13:12) 2.4.0
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.2
FPC 3               U-Boot            U-Boot 1.1.6 (Dec  4 2009 - 13:17:34) 3.1.0
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.2
FPC 5               U-Boot            U-Boot 1.1.6 (Mar 25 2009 - 06:13:12) 2.4.0
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.2
FPC 7               U-Boot            U-Boot 1.1.6 (Feb  6 2009 - 05:31:46) 2.4.0
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.2
Routing Engine 0    U-Boot            U-Boot 1.1.6 (Mar 25 2009 - 06:13:12) 2.4.0
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.2
Routing Engine 1    U-Boot            U-Boot 1.1.6 (Mar 25 2009 - 06:13:12) 2.4.0
                   loader              FreeBSD/PowerPC U-Boot bootstrap loader 2.2

show chassis firmware user@host> show chassis firmware lcc 0
lcc (TX Matrix Router) lcc0-re0:
-----
Part                Type                Version
FPC 1               ROM                Juniper ROM Monitor Version 6.4b18
                   O/S                Version 7.0-20040804.0 by builder on 2004-0
FPC 2               ROM                Juniper ROM Monitor Version 6.4b20
                   O/S                Version 7.0-20040804.0 by builder on 2004-0
SPMB 0              ROM                Juniper ROM Monitor Version 6.4b18
                   O/S                Version 7.0-20040804.0 by builder on 2004-0

show chassis firmware user@host> show chassis firmware scc
scc (TX Matrix Router) scc-re0:
-----
Part                Type                Version
SPMB 0              ROM                Juniper ROM Monitor Version 6.4b18
                   O/S                Version 7.0-20040804.0 by builder on 2004-0

```

show chassis firmware
(TX Matrix Plus
Router)

user@host> show chassis firmware
sfc0-re0:

Part	Type	Version
Global FPC 4		
Global FPC 6		
Global FPC 7		
Global FPC 12		
Global FPC 14		
Global FPC 15		
Global FPC 20		
Global FPC 21		
Global FPC 22		
Global FPC 23		
Global FPC 24		
Global FPC 25		
Global FPC 26		
Global FPC 28		
Global FPC 29		
Global FPC 31		
SPMB 0	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0
SPMB 1	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0

lcc0-re1:

Part	Type	Version
FPC 4	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
FPC 6	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
FPC 7	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
SPMB 0	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0
SPMB 1	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0

lcc1-re1:

Part	Type	Version
FPC 4	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
FPC 6	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
FPC 7	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
SPMB 0	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0
SPMB 1	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0

lcc2-re1:

Part	Type	Version
FPC 4	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
FPC 5	ROM	Juniper ROM Monitor Version 9.0b2
	O/S	Version 9.6-20090507.0 by builder on 2009-0
FPC 6	ROM	Juniper ROM Monitor Version 9.0b2

```

FPC 7          O/S      Version 9.6-20090507.0 by builder on 2009-0
              ROM      Juniper ROM Monitor Version 7.5b4
SPMB 0          O/S      Version 9.6-20090507.0 by builder on 2009-0
              ROM      Juniper ROM Monitor Version 9.5b1
SPMB 1          O/S      Version 9.6-20090507.0 by builder on 2009-0
              ROM      Juniper ROM Monitor Version 9.5b1
              O/S      Version 9.6-20090507.0 by builder on 2009-0

```

lcc3-re1:

```

-----
Part          Type      Version
FPC 0          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 1          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 2          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 4          ROM      Juniper ROM Monitor Version 7.5b4
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 5          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 7          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
SPMB 0          ROM      Juniper ROM Monitor Version 9.5b1
              O/S      Version 9.6-20090507.0 by builder on 2009-0
SPMB 1          ROM      Juniper ROM Monitor Version 9.5b1
              O/S      Version 9.6-20090507.0 by builder on 2009-0

```

show chassis firmware user@host> **show chassis firmware lcc 0**
lcc (TX Matrix Plus lcc0-re1:
Router)

```

-----
Part          Type      Version
FPC 4          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 6          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
FPC 7          ROM      Juniper ROM Monitor Version 9.0b2
              O/S      Version 9.6-20090507.0 by builder on 2009-0
SPMB 0          ROM      Juniper ROM Monitor Version 9.5b1
              O/S      Version 9.6-20090507.0 by builder on 2009-0
SPMB 1          ROM      Juniper ROM Monitor Version 9.5b1
              O/S      Version 9.6-20090507.0 by builder on 2009-0

```

show chassis firmware user@host> **show chassis firmware sfc 0**
sfc (TX Matrix Plus sfc0-re0:
Router)

```

-----
Part          Type      Version
Global FPC 4
Global FPC 6
Global FPC 7
Global FPC 12
Global FPC 14
Global FPC 15
Global FPC 20
Global FPC 21
Global FPC 22
Global FPC 23
Global FPC 24
Global FPC 25
Global FPC 26
Global FPC 28

```

Global FPC 29		
Global FPC 31		
SPMB 0	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0
SPMB 1	ROM	Juniper ROM Monitor Version 9.5b1
	O/S	Version 9.6-20090507.0 by builder on 2009-0

show chassis firmware (QFX Series)	user@switch> show chassis firmware		
Part	Type	Version	
FPC 0			
Routing Engine 0	U-Boot loader	U-Boot 1.1.6 (Sep 15 2010 - 02:11:11) 1.0.5	FreeBSD/MIPS U-Boot bootstrap loader 0.1

show chassis forwarding

Syntax	show chassis forwarding
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series Services Routers only) Display status of the forwarding process (fwdd).
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis forwarding on page 405
Output Fields	Table 74 on page 405 lists the output fields for the show chassis forwarding command. Output fields are listed in the approximate order in which they appear.

Table 74: show chassis forwarding Output Fields

Field Name	Field Description
FWDD status	<p>Forwarding status:</p> <ul style="list-style-type: none"> • State: <ul style="list-style-type: none"> • Online—FWDD is operational and running. • Offline—FWDD is not running. • Microkernel CPU utilization—Percentage of microkernel CPU being used by the forwarding process. • Real-time threads CPU utilization—Percentage of CPU being used by the forwarding process. • Heap utilization—Percentage of heap space (dynamic memory) being used by the forwarding process. If this number exceeds 80 percent, there may be a software problem (memory leak). • Buffer utilization—Percentage of buffer space being used by the forwarding process for buffering internal messages. • Uptime—How long the forwarding process has been up and running.

Sample Output

```

show chassis forwarding user@host> show chassis forwarding
FWDD status:
  State                               Online
  Microkernel CPU utilization         10 percent
  Real-time threads CPU utilization    4 percent
  Heap utilization                     26 percent
  Buffer utilization                    0 percent
  Uptime:                             1 day, 1 hour, 30 minutes, 11 seconds

```

show chassis fpc

Syntax	show chassis fpc <detail <slot>> <pic-status <slot>>
Syntax (TX Matrix and TX Matrix Plus Router)	show chassis fpc <detail <fpc-slot>> <pic-status <fpc-slot>> <slot>
Syntax (MX Series Router)	show chassis fpc <detail <slot>> <pic-status <slot>> <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show chassis fpc <detail <fpc-slot>> <pic-status <fpc-slot>> <fpc-slot>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display status information about the installed Flexible PIC Concentrators (FPCs) and PICs.
Options	<p>none—Display status information for all FPCs. On a TX Matrix router, display status information for all FPCs on the attached T640 routers in the routing matrix. On a TX Matrix Plus router, display status information for all FPCs on the attached T1600 routers in the routing matrix.</p> <p>detail—(Optional) Display detailed status information for all FPCs or for the FPC in the specified slot (see <i>fpc-slot</i> or <i>slot</i>).</p> <p>all-members—(MX Series routers only) (Optional) Display status information for all FPCs on all members of the Virtual Chassis configuration.</p> <p><i>fpc-slot</i>—(Optional) FPC slot number:</p> <ul style="list-style-type: none"> (TX Matrix and TX Matrix Plus router only)—On a TX Matrix router, if you specify the number of the T640 router (or line-card chassis) by using the <i>lcc number</i> option (the recommended method), replace <i>fpc-slot</i> with a value from 0 through 7. Otherwise, replace <i>fpc-slot</i> with a value from 0 through 31. Likewise, on a TX Matrix Plus router, if you specify the number of the T1600 router (or line-card chassis) by using the <i>lcc number</i> option (the recommended method), replace <i>fpc-slot</i> with a value from 0 through 7. Otherwise, replace <i>fpc-slot</i> with a value from 0 through 31. For example, the following commands have the same result: <pre> user@host> show chassis fpc detail 1 lcc 1 user@host> show chassis fpc detail 9 </pre> M120 router—Replace <i>fpc-slot</i> with a value from 0 through 5.

- MX80 router—Replace *fpc-slot* with a value from 0 through 1.
- MX240 router—Replace *fpc-slot* with a value from 0 through 2.
- MX480 router—Replace *fpc-slot* with a value from 0 through 5.
- MX-960 router—Replace *fpc-slot* with a value from 0 through 11.
- Other routers—Replace *fpc-slot* with a value from 0 through 7.
- EX Series switches:
 - EX3200 switches and EX4200 standalone switches—Replace *fpc-slot* with 0.
 - EX4200 switches in a Virtual Chassis configuration—Replace *fpc-slot* with a value from 0 through 9 (switch's member ID).
 - EX8208 switches—Replace *fpc-slot* with a value from 0 through 7 (line card).
 - EX8216 switches—Replace *fpc-slot* with a value from 0 through 15 (line card).
- QFX Series:
 - QFX3500 switches—Replace *fpc-slot* with 0.

local—(MX Series routers only) (Optional) Display status information for all FPCs on the local Virtual Chassis member.

member member-id—(MX Series routers only) (Optional) Display status information for all FPCs on the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

pic-status—(Optional) Display status information for all PICs or for the PIC in the specified slot (see *fpc-slot*).



NOTE: On T1600 routers, Type 4 FPCs with ASICs based on the SL2.0 chipset do not support the 10-Gigabit Ethernet LAN/WAN PIC with SFP+ (10x10GE [LAN/WAN] SFPP). If you issue the `show chassis fpc` command with the `pic-status` option, the CLI displays the string “Not Supported” for 10x10GE (LAN/WAN) SFPP PICs installed on such FPCs. The following is a sample output:

```
user@host> show chassis fpc pic-status
Slot 0  Online      E2-FPC Type 1
  PIC 0  Online      1x G/E SFP, 1000 BASE
  PIC 1  Online      Adaptive Services-II
  PIC 2  Online      1x G/E IQ, 1000 BASE
  PIC 3  Online      1x G/E IQ, 1000 BASE
Slot 1  Online      FPC Type 3-ES
  PIC 0  Present     UNUSED- Not Supported
Slot 2  Online      FPC Type 4-ES
  PIC 0  Offline     4x OC-192 SONET XFP
  PIC 1  Present     10x10GE (LAN/WAN) SFPP- Not Supported
<<<<<<
Slot 4  Offline     FPC Type 1-ES
Slot 5  Offline     FPC Type 2-ES
Slot 6  Online      E2-FPC Type 3
  PIC 0  Online      1x OC-192 SONET XFP
  PIC 1  Online      4x OC-48 SONET
  PIC 2  Online      4x OC-48 SONET
  PIC 3  Online      MultiServices 500
Slot 7  Online      FPC Type 4-ES
  PIC 0  Online      4x 10GE (LAN/WAN) XFP
  PIC 1  Online      4x 10GE (LAN/WAN) XFP
```

In addition, an entry is logged in the system log messages (/var/log/messages) that the PIC is not supported. The following is a sample message logged in the system log:

```
Apr  5 08:47:36  router1 chassisd[2770]: CHASSISD_UNSUPPORTED_PIC:
PIC 1 in FPC 2 (type 763, version 257) is not supported
```

lcc number—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display status information for a T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display status information for a T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace **number** with a value from 0 through 3.

Required Privilege Level view

Related Documentation

- request chassis fpc on page 173

List of Sample Output

- show chassis fpc (M10 Router) on page 410
- show chassis fpc (M20 Router) on page 410
- show chassis fpc detail (M Series Routers) on page 411
- show chassis fpc detail (MX80 Router) on page 411

show chassis fpc (MX240 Router) on page 411
 show chassis fpc (MX480 Router) on page 411
 show chassis fpc (MX960 Router) on page 411
 show chassis fpc detail (MX Series Routers) on page 412
 show chassis fpc (Hardware Not Supported) on page 412
 show chassis fpc detail (Hardware Not Supported) on page 412
 show chassis fpc pic-status on page 413
 show chassis fpc pic-status (M Series Routers) on page 413
 show chassis fpc pic-status (M120 Router) on page 413
 show chassis fpc lcc (TX Matrix Router) on page 413
 show chassis fpc pic-status (TX Matrix Router) on page 414
 show chassis fpc pic-status lcc (TX Matrix Router) on page 414
 show chassis fpc (TX Matrix Plus Router) on page 414
 show chassis fpc lcc (TX Matrix Plus Router) on page 415
 show chassis fpc detail (TX Matrix Plus Router) on page 415
 show chassis fpc pic-status (TX Matrix Plus Router) on page 417
 show chassis fpc (T1600 Router) on page 418
 show chassis fpc detail (T1600 Router) on page 418
 show chassis fpc [Warning: element unresolved in stylesheets: <change> (in <title>). This is probably a new element that is not yet supported in the stylesheets.]slot (T1600 Router) on page 419
 show chassis fpc pic-status (T1600 Router) on page 419
 show chassis fpc (QFX Series) on page 420
 show chassis fpc detail (QFX Series) on page 420
 show chassis fpc pic-status (QFX Series) on page 420

Output Fields Table 75 on page 409 lists the output fields for the **show chassis fpc** command. Output fields are listed in the approximate order in which they appear.

Table 75: show chassis fpc Output Fields

Field Name	Field Description	Level of Output
Slot or Slot State	Slot number and state. The state can be one of the following conditions: <ul style="list-style-type: none"> • Dead—Held in reset because of errors. • Diag—Slot is being ignored while the FPC is running diagnostics. • Dormant—Held in reset. • Empty—No FPC is present. • Online—FPC is online and running. • Present—FPC is detected by the chassis daemon but either is not supported by the current version of Junos OS or is inserted in the wrong slot. The output also states either Hardware Not Supported or Hardware Not In Right Slot. The FPC is coming up but not yet online. • Probed—Probe is complete; awaiting restart of the Packet Forwarding Engine (PFE). • Probe-wait—Waiting to be probed. 	all levels
Logical slot	Slot number.	all levels
Temp (C) or Temperature	Temperature of the air passing by the FPC, in degrees Celsius or in both Celsius and Fahrenheit.	all levels

Table 75: show chassis fpc Output Fields (*continued*)

Field Name	Field Description	Level of Output
Total CPU Utilization (%)	Total percentage of CPU being used by the FPC's processor.	all levels
Interrupt CPU Utilization (%)	Of the total CPU being used by the FPC's processor, the percentage being used for interrupts.	none specified
Memory DRAM (MB)	Total DRAM, in megabytes, available to the FPC's processor.	none specified
Heap Utilization (%)	Percentage of heap space (dynamic memory) being used by the FPC's processor. If this number exceeds 80 percent, there may be a software problem (memory leak).	none specified
Buffer Utilization (%)	Percentage of buffer space being used by the FPC's processor for buffering internal messages.	none specified
Total CPU DRAM	Amount of DRAM available to the FPC's CPU.	detail
Total RLDRAM	Amount of reduced latency dynamic random access memory (RLDRAM) available to the FPC CPU.	detail
Total DDR DRAM	Amount of double data rate dynamic random access memory (DDR DRAM) available to the FPC CPU.	detail
Total SRAM	Amount of static RAM (SRAM) used by the FPC's CPU.	detail
Total SDRAM	Total amount of memory used for storing packets and notifications.	detail
I/O Manager ASICs information	I/O Manager version number, manufacturer, and part number.	detail
Start time	Time when the Routing Engine detected that the FPC was running.	detail
Uptime	How long the Routing Engine has been connected to the FPC and, therefore, how long the FPC has been up and running.	detail
PIC type	(pic-status output only) Type of PIC.	none specified

Sample Output

```

show chassis fpc (M10 Router)  user@host> show chassis fpc
                                FPC status:
                                Temp
                                Slot State (C)
                                0  Online  27
                                1  Online  28

```

```

show chassis fpc (M20 Router)  user@host> show chassis fpc

```

FPC status:

Slot	State	Temp	CPU Utilization (%)		Memory	Utilization (%)	
		(C)	Total	Interrupt	DRAM (MB)	Heap	Buffer
0	Empty	0	0	0	0	0	0
1	Online	38	0	0	8	0	4
2	Online	35	0	0	8	0	3
3	Empty	0	0	0	0	0	0

show chassis fpc detail
(M Series Routers)

user@host> show chassis fpc detail 1

Slot 1 information:

```

State                               Online
Temperature                         48 degrees C
Total CPU DRAM                      32 Mbytes
Total SRAM                          4 Mbytes
Total SDRAM                         256 Mbytes
I/O Manager ASICs information       Version 2.0, Foundry IBM, Part number 0
I/O Manager ASICs information       Version 2.0, Foundry IBM, Part number 0
Start time                          2000-02-08 02:18:49 UTC
Uptime                              14 hours, 41 minutes, 41 seconds

```

show chassis fpc detail
(MX80 Router)

user@host> show chassis fpc detail

Slot 0 information:

```

State                               Online
Temperature                         47 degrees C / 116 degrees F
Total CPU DRAM                      1024 MB
Total SRAM                          331 MB
Total SDRAM                         1280 MB
Start time                          2010-02-08 12:25:33 PST
Uptime                              2 hours, 13 minutes, 19 seconds

```

Slot 1 information:

```

State                               Online
Temperature                         47 degrees C / 116 degrees F
Total CPU DRAM                      1024 MB
Total SRAM                          331 MB
Total SDRAM                         1280 MB
Start time                          2010-02-08 12:25:33 PST
Uptime                              2 hours, 13 minutes, 19 seconds

```

show chassis fpc
(MX240 Router)

user@host> show chassis fpc

Slot	State	Temp	CPU Utilization (%)		Memory	Utilization (%)	
		(C)	Total	Interrupt	DRAM (MB)	Heap	Buffer
0	Empty						
1	Online	34	6	0	1024	18	30
2	Online	33	9	0	1024	24	30

show chassis fpc
(MX480 Router)

user@host> show chassis fpc

Slot	State	Temp	CPU Utilization (%)		Memory	Utilization (%)	
		(C)	Total	Interrupt	DRAM (MB)	Heap	Buffer
0	Empty						
1	Online	36	9	0	1024	17	57
2	Empty						
3	Empty						
4	Empty						
5	Empty						

show chassis fpc
(MX960 Router)

user@host> show chassis fpc

Slot	State	Temp	CPU Utilization (%)		Memory	Utilization (%)	
		(C)	Total	Interrupt	DRAM (MB)	Heap	Buffer
0	Empty						
1	Empty						

```

2 Empty
3 Online      25    19      0    1024    15    57
4 Empty
5 Online      26    27      0    1024    15    57
6 Empty
7 Empty
8 Empty
9 Empty
10 Empty
11 Empty

```

show chassis fpc detail
(MX Series Routers)

```

user@host> show chassis fpc detail 2
Slot 0 information:
  State                Online
  Temperature          36 degrees C / 96 degrees F
  Total CPU DRAM       1024 MB
  Total RLDRAM         256 MB
  Total DDR DRAM       4096 MB
  Start time:          2009-08-11 21:20:30 PDT
  Uptime:               2 hours, 8 minutes, 50 seconds
  Max Power Consumption 335 Watts

```

show chassis fpc
(Hardware Not
Supported)

```

user@host> show chassis fpc
show chassis fpc

```

Slot	State	Temp (C)	CPU Utilization (%)	Memory Utilization (%)
			Total Interrupt	DRAM (MB) Heap Buffer
0	Online			
1	Present			
2	Online			
3	Present			
4	Empty			
5	Empty			
6	Online			

show chassis fpc detail
(Hardware Not
Supported)

```

user@host> show chassis fpc detail
Slot 0 information:
  State                Online
  Total CPU DRAM       ---- CPU less FPC ----
  Start time           2006-07-07 03:21:00 UTC
  Uptime                27 minutes, 51 seconds
Slot 1 information:
  State                Present
  Reason              --- Hardware Not In Right Slot ---
Slot 2 information:
  State                Online
  Total CPU DRAM       32 MB
  Start time           2006-07-07 03:20:59 UTC
  Uptime                27 minutes, 52 seconds
Slot 3 information:
  State                Present
  Reason              --- Hardware Not Supported ---
  Total CPU DRAM       0 MB
Slot 6 information:
  State                Online
  Total CPU DRAM       32 MB
  Start time           2006-07-07 03:21:01 UTC
  Uptime                27 minutes, 50 seconds

```

```

show chassis fpc pic-status user@host> show chassis fpc pic-status
                               Slot 0 Online
                               PIC 1    1x OC-12 ATM, MM
                               PIC 2    1x OC-12 ATM, MM
                               PIC 3    1x OC-12 ATM, MM
                               Slot 1 Online
                               PIC 0    1x OC-48 SONET, SMIR
                               Slot 2 Online
                               PIC 0    1x OC-192 SONET, SMSR

show chassis fpc pic-status (M Series Routers) user@host> show chassis fpc pic-status
Slot 1  Online      FPC Type 1
PIC 0   Present    2x OC-3 ATM, MM- Hardware Error
PIC 1   Online     4x OC-3 SONET, SMIR
Slot 2  Online     E-FPC Type 2
PIC 0   Online     4x G/E, 1000 BASE-SX
PIC 1   Online     2x G/E SFP, 1000 BASE
PIC 3   Online     1x Tunnel
Slot 3  Online     E-FPC Type 1
PIC 0   Online     1x G/E IQ, 1000 BASE
PIC 2   Online     1x G/E SFP, 1000 BASE
Slot 4  Online     E-FPC Type 2
PIC 0   Online     4x G/E SFP, 1000 BASE
PIC 1   Online     4x G/E SFP, 1000 BASE
PIC 2   Online     4x G/E SFP, 1000 BASE
PIC 3   Online     4x G/E SFP, 1000 BASE
Slot 5  Online     FPC Type 2
...

show chassis fpc pic-status (M120 Router) user@host> show chassis fpc pic-status
Slot 1  Online     M120 CFPC 10GE
PIC 0   Online     1x 10GE(LAN/WAN) XFP
Slot 3  Online     M120 FPC Type 2 (proto)
PIC 0   Online     2x G/E IQ, 1000 BASE
PIC 1   Online     4x OC-3 SONET, SMIR
PIC 2   Online     2x G/E IQ, 1000 BASE
PIC 3   Online     8x 1GE(LAN), IQ2
Slot 4  Online     M120 FPC Type 3 (proto)
PIC 0   Online     10x 1GE(LAN), 1000 BASE
Slot 5  Online     M120 FPC Type 1 (proto)
PIC 0   Present    1x G/E, 1000 BASE-LX- Not Supported
PIC 1   Online     1x CHOC3 IQ SONET, SMLR
PIC 2   Online     4x CHDS3 IQ
PIC 3   Online     1x G/E SFP, 1000 BASE

show chassis fpc lcc (TX Matrix Router) user@host> show chassis fpc lcc 0
lcc0-re0:
-----
Slot State      Temp  CPU      Utilization (%)  Memory  Utilization (%)
              (C)  Total  Interrupt      DRAM (MB)  Heap    Buffer
0  Empty
1  Online      27     2         0        256      8       44
2  Online      27     3         0        256     15       44
3  Empty
4  Empty
5  Empty
6  Empty
7  Empty

```

show chassis fpc
pic-status (TX Matrix
Router)

user@host> show chassis fpc pic-status
 lcc0-re0:

```

-----
Slot 0  Online      FPC Type 3
  PIC 0  Online      1x OC-192 SM SR1
  PIC 1  Online      1x OC-192 SM SR2
  PIC 2  Online      1x OC-192 SM SR1
  PIC 3  Online      1x Tunnel
Slot 1  Online      FPC Type 2
  PIC 0  Online      1x OC-48 SONET, SMSR
  PIC 1  Online      1x OC-48 SONET, SMSR

```

lcc1-re0:

lcc2-re0:

```

-----
Slot 1  Online      FPC Type 3
  PIC 0  Online      1x OC-192 SM SR1
Slot 5  Online      FPC Type 2
  PIC 0  Online      1x OC-48 SONET, SMSR
  PIC 1  Online      2x G/E, 1000 BASE-LX
  PIC 2  Online      2x G/E, 1000 BASE-LX
  PIC 3  Online      1x OC-48 SONET, SMSR

```

lcc3-re0:

show chassis fpc
pic-status lcc (TX
Matrix Router)

user@host> show chassis fpc pic-status lcc 0
 lcc0-re0:

```

-----
Slot 0  Online      FPC Type 3
  PIC 0  Online      1x OC-192 SM SR2
Slot 1  Online      FPC Type 2
  PIC 0  Online      2x OC-12 ATM2 IQ, MM
  PIC 1  Online      1x OC-48 SONET, SMSR
  PIC 2  Online      1x OC-48 SONET, SMSR
  PIC 3  Online      4x G/E, 1000 BASE-SX

```

show chassis fpc (TX
Matrix Plus Router)

user@host> show chassis fpc
 lcc0-re0:

```

-----
Slot State      Temp  CPU Utilization (%)  Memory  Utilization (%)
              (C)  Total  Interrupt          DRAM (MB) Heap      Buffer
0  Empty
1  Online        38    4          0        2048      3        24
2  Online        43    8          0        2048      6        24
3  Empty
4  Online        43    6          0        2048      6        24
5  Empty
6  Online        42   13          0        2048      6        24
7  Online        45    7          0        2048      3        24

```

lcc2-re0:

```

-----
Slot State      Temp  CPU Utilization (%)  Memory  Utilization (%)
              (C)  Total  Interrupt          DRAM (MB) Heap      Buffer
0  Online        42   10          0        2048      6        24
1  Empty
2  Online        42   11          0        2048      6        24

```

3	Online	40	5	0	2048	3	24
4	Online	33	26	0	1024	8	49
5	Empty						
6	Online	43	8	0	2048	6	24
7	Online	46	6	0	2048	3	24

lcc3-re0:

Slot	State	Temp (C)	CPU Utilization (%) Total Interrupt	Memory DRAM (MB)	Utilization (%) Heap Buffer
0	Empty				
1	Empty				
2	Online	39	30 0	2048	7 24
3	Empty				
4	Online	41	8 0	2048	6 24
5	Online	41	12 0	2048	6 24
6	Online	40	8 0	2048	6 24
7	Online	42	4 0	2048	3 24

show chassis fpc lcc
(TX Matrix Plus
Router)

```
user@host> show chassis fpc lcc 0
lcc0-re0:
```

Slot	State	Temp (C)	CPU Utilization (%) Total Interrupt	Memory DRAM (MB)	Utilization (%) Heap Buffer
0	Empty				
1	Online	38	4 0	2048	3 24
2	Online	43	8 0	2048	6 24
3	Empty				
4	Online	43	6 0	2048	6 24
5	Empty				
6	Online	42	14 0	2048	6 24
7	Online	45	6 0	2048	3 24

show chassis fpc detail
(TX Matrix Plus
Router)

```
user@host> show chassis fpc details
```

lcc0-re0:

Slot 1 information:

```
State Online
Temperature 38 degrees C / 100 degrees F
Total CPU DRAM 2048 MB
Total SRAM 64 MB
Total SDRAM 1280 MB
Start time 2010-10-04 20:06:22 PDT
Uptime 1 hour, 32 minutes, 51 seconds
```

Slot 2 information:

```
State Online
Temperature 43 degrees C / 109 degrees F
Total CPU DRAM 2048 MB
Total SRAM 128 MB
Total SDRAM 2560 MB
Start time 2010-10-04 20:06:37 PDT
Uptime 1 hour, 32 minutes, 36 seconds
```

Slot 4 information:

```
State Online
Temperature 43 degrees C / 109 degrees F
Total CPU DRAM 2048 MB
Total SRAM 128 MB
Total SDRAM 2560 MB
Start time 2010-10-04 20:06:40 PDT
Uptime 1 hour, 32 minutes, 33 seconds
```

```

Slot 6 information:
  State                Online
  Temperature          42 degrees C / 107 degrees F
  Total CPU DRAM       2048 MB
  Total SRAM           128 MB
  Total SDRAM          2560 MB
  Start time           2010-10-04 20:06:42 PDT
  Uptime               1 hour, 32 minutes, 31 seconds

```

```

Slot 7 information:
  State                Online
  Temperature          45 degrees C / 113 degrees F
  Total CPU DRAM       2048 MB
  Total SRAM           64 MB
  Total SDRAM          1280 MB
  Start time           2010-10-04 20:06:43 PDT
  Uptime               1 hour, 32 minutes, 30 seconds

```

```
lcc2-re0:
```

```

-----
Slot 0 information:
  State                Online
  Temperature          42 degrees C / 107 degrees F
  Total CPU DRAM       2048 MB
  Total SRAM           128 MB
  Total SDRAM          2560 MB
  Start time           2010-10-04 20:06:35 PDT
  Uptime               1 hour, 32 minutes, 38 seconds

```

```

Slot 2 information:
  State                Online
  Temperature          42 degrees C / 107 degrees F
  Total CPU DRAM       2048 MB
  Total SRAM           128 MB
  Total SDRAM          2560 MB
  Start time           2010-10-04 20:06:37 PDT
  Uptime               1 hour, 32 minutes, 36 seconds

```

```

Slot 3 information:
  State                Online
  Temperature          40 degrees C / 104 degrees F
  Total CPU DRAM       2048 MB
  Total SRAM           64 MB
  Total SDRAM          1280 MB
  Start time           2010-10-04 20:06:28 PDT
  Uptime               1 hour, 32 minutes, 45 seconds

```

```

Slot 4 information:
  State                Online
  Temperature          33 degrees C / 91 degrees F
  Total CPU DRAM       1024 MB
  Total SRAM           64 MB
  Total SDRAM          1280 MB
  Start time           2010-10-04 20:08:03 PDT
  Uptime               1 hour, 31 minutes, 10 seconds

```

```

Slot 6 information:
  State                Online
  Temperature          43 degrees C / 109 degrees F
  Total CPU DRAM       2048 MB
  Total SRAM           128 MB
  Total SDRAM          2560 MB
  Start time           2010-10-04 20:06:44 PDT
  Uptime               1 hour, 32 minutes, 29 seconds

```

```

Slot 7 information:
  State                Online

```



```

Temperature                46 degrees C / 114 degrees F
Total CPU DRAM              2048 MB
Total SRAM                  64 MB
Total SDRAM                 1280 MB
Start time                  2010-10-04 20:06:46 PDT
Uptime                      1 hour, 32 minutes, 27 seconds

```

```
lcc3-re0:
```

```
-----
Slot 2 information:
```

```

State                      Online
Temperature                 38 degrees C / 100 degrees F
Total CPU DRAM              2048 MB
Total SRAM                  128 MB
Total SDRAM                 2560 MB
Start time                  2010-10-04 20:17:31 PDT
Uptime                      1 hour, 21 minutes, 42 seconds

```

```
Slot 4 information:
```

```

State                      Online
Temperature                 41 degrees C / 105 degrees F
Total CPU DRAM              2048 MB
Total SRAM                  128 MB
Total SDRAM                 2560 MB
Start time                  2010-10-04 20:17:34 PDT
Uptime                      1 hour, 21 minutes, 39 seconds

```

```
Slot 5 information:
```

```

State                      Online
Temperature                 41 degrees C / 105 degrees F
Total CPU DRAM              2048 MB
Total SRAM                  128 MB
Total SDRAM                 2560 MB
Start time                  2010-10-04 20:17:36 PDT
Uptime                      1 hour, 21 minutes, 37 seconds

```

```
Slot 6 information:
```

```

State                      Online
Temperature                 40 degrees C / 104 degrees F
Total CPU DRAM              2048 MB
Total SRAM                  128 MB
Total SDRAM                 2560 MB
Start time                  2010-10-04 20:17:39 PDT
Uptime                      1 hour, 21 minutes, 34 seconds

```

```
Slot 7 information:
```

```

State                      Online
Temperature                 42 degrees C / 107 degrees F
Total CPU DRAM              2048 MB
Total SRAM                  64 MB
Total SDRAM                 1280 MB
Start time                  2010-10-04 20:17:41 PDT
Uptime                      1 hour, 21 minutes, 32 seconds

```

```

show chassis fpc
pic-status (TX Matrix
Plus Router)

```

```
user@host> show chassis fpc pic-status
```

```
lcc0-re0:
```

```

-----
Slot 1  Online      FPC Type 2-ES
PIC 0   Online      8x 1GE(LAN), IQ2
Slot 2  Online      FPC Type 4-ES
PIC 0   Online      4x 10GE (LAN/WAN) XFP
Slot 4  Online      FPC Type 4-ES
PIC 0   Online      4x 10GE (LAN/WAN) XFP
Slot 6  Online      FPC Type 4-ES

```

```

PIC 0 Online 4x 10GE (LAN/WAN) XFP
PIC 1 Online 4x 10GE (LAN/WAN) XFP
Slot 7 Online FPC Type 3-ES
PIC 0 Online 10x 1GE(LAN), 1000 BASE
PIC 2 Online 1x OC-192 SM SR2
PIC 3 Online 10x 1GE(LAN), 1000 BASE

```

lcc2-re0:

```

-----
Slot 0 Online FPC Type 4-ES
PIC 0 Online 4x 10GE (LAN/WAN) XFP
Slot 2 Online FPC Type 4-ES
PIC 0 Online 4x 10GE (LAN/WAN) XFP
PIC 1 Online 4x 10GE (LAN/WAN) XFP
Slot 3 Online FPC Type 2-ES
PIC 0 Online 8x 1GE(LAN), IQ2
Slot 4 Online FPC Type 4
PIC 0 Online 10x10GE(LAN/WAN) SFPP
Slot 6 Online FPC Type 4-ES
PIC 0 Online 4x OC-192 SONET XFP
Slot 7 Online FPC Type 3-ES
PIC 0 Online 10x 1GE(LAN), 1000 BASE
PIC 1 Offline 1x 10GE(LAN/WAN) IQ2E
PIC 2 Online 1x OC-192 SM SR2
PIC 3 Online 1x Tunnel

```

lcc3-re0:

```

-----
Slot 2 Online FPC Type 4-ES
PIC 0 Online 10x10GE(LAN/WAN) SFPP
Slot 4 Online FPC Type 4-ES
PIC 0 Online 4x OC-192 SONET XFP
Slot 5 Online FPC Type 4-ES
PIC 0 Online 4x OC-192 SONET XFP
PIC 1 Online 4x 10GE (LAN/WAN) XFP
Slot 6 Online FPC Type 4-ES
PIC 1 Online 4x 10GE (LAN/WAN) XFP
Slot 7 Online FPC Type 3-ES
PIC 0 Online 10x 1GE(LAN), 1000 BASE
PIC 1 Online 8x 1GE(TYPE3), IQ2E
PIC 2 Online 4x OC-48 SONET

```

show chassis fpc
(T1600 Router)

```

user@host> show chassis fpc

```

Slot	State	Temp (C)	CPU Utilization (%) Total Interrupt	Memory DRAM (MB)	Utilization (%) Heap Buffer
0	Empty				
1	Empty				
2	Online	49	3 0	2048	3 24
3	Online	46	6 0	2048	6 24
4	Empty				
5	Online	46	5 0	2048	3 24
6	Empty				
7	Online	44	8 0	1024	7 49

show chassis fpc detail
(T1600 Router)

```

user@host> show chassis fpc detail
show chassis fpc detail
Slot 2 information:
State Online
Temperature 49 degrees C / 120 degrees F
Total CPU DRAM 2048 MB

```

```

Total SRAM                64 MB
Total SDRAM                1280 MB
Start time                2010-10-04 21:12:52 PDT
Uptime                    32 minutes, 9 seconds
Slot 3 information:
State                     Online
Temperature               47 degrees C / 116 degrees F
Total CPU DRAM            2048 MB
Total SRAM                128 MB
Total SDRAM                2560 MB
Start time                2010-10-04 21:13:06 PDT
Uptime                    31 minutes, 55 seconds
Slot 5 information:
State                     Online
Temperature               46 degrees C / 114 degrees F
Total CPU DRAM            2048 MB
Total SRAM                64 MB
Total SDRAM                1280 MB
Start time                2010-10-04 21:12:56 PDT
Uptime                    32 minutes, 5 seconds
Slot 7 information:
State                     Online
Temperature               44 degrees C / 111 degrees F
Total CPU DRAM            1024 MB
Total SRAM                64 MB
Total SDRAM                1280 MB
Start time                2010-10-04 21:14:34 PDT
Uptime                    30 minutes, 27 seconds

```

```

show chassis fpc          user@host> show chassis fpc 2
[Warning: element
unresolved in
stylesheets: <change>
(in <title>). This is
probably a new
element that is not yet
supported in the
stylesheets.]
slot
(T1600 Router)

```

Slot	State	Temp (C)	CPU Utilization (%)	Memory DRAM (MB)	Utilization (%)
			Total Interrupt	Heap	Buffer
2	Online	49	3 0	2048	3 24

```

show chassis fpc          user@host> show chassis fpc pic-status
pic-status (T1600
Router)
Slot 2   Online          FPC Type 1-ES
PIC 0    Online          Load Type 1
PIC 1    Online          4x 1GE(LAN), IQ2E
PIC 3    Online          1x OC-12-3 SFP
Slot 3   Online          FPC Type 4-ES
PIC 0    Online          4x 10GE (LAN/WAN) XFP
PIC 1    Online          4x OC-192 SONET XFP
Slot 5   Online          FPC Type 2-ES
PIC 0    Online          Load Type 2
PIC 1    Online          8x 1GE(LAN), IQ2E
PIC 2    Online          8x 1GE(LAN), IQ2E
PIC 3    Online          1x OC-48-12-3 SFP
Slot 7   Online          FPC Type 4
PIC 0    Online          4x 10GE (LAN/WAN) XFP

```

```

show chassis fpc (QFX Series) user@switch> show chassis fpc
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Online 26 2 0 2820 0 49

show chassis fpc detail (QFX Series) user@switch> show chassis fpc detail
Slot 0 information:
State Online
Temperature 28 degrees C / 82 degrees F
Total CPU DRAM 2820 MB
Total SRAM 0 MB
Total SDRAM 0 MB
Start time 2010-09-20 01:34:13 PDT
Uptime 3 days, 3 hours, 31 minutes, 48 seconds

show chassis fpc pic-status (QFX Series) user@switch> show chassis fpc pic-status
Slot 0 Online QFX 48x10G 4x40G Switch
PIC 0 Online 48x 10G-SFP+
PIC 1 Online 15x 10G-SFP+

```

show chassis fpc-feb-connectivity

Syntax	show chassis fpc-feb-connectivity
Release Information	Command introduced in Junos OS Release 8.0.
Description	(M120 router only) Display the Flexible PIC Concentrator (FPC) and Forwarding Engine Board (FEB) mapping and their respective states.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis fpc-feb-connectivity on page 422
Output Fields	Table 76 on page 421 lists the output fields for the show chassis fpc-feb-connectivity command. Output fields are listed in the approximate order in which they appear.

Table 76: show chassis fpc-feb-connectivity Output Fields

Field Name	Field Description
FPC	Slot number of the Flexible PIC Concentrator (FPC).
FPC type	Type of FPC: Type 1 , Type 2 , Type 3 , or cFPC .
FPC state	State of the FPC. State can be any of the following: <ul style="list-style-type: none"> • Announce offline—Intermediate state where FPC is going down but is not offline and the Chassis manager acknowledges that the FPC is in the process of going offline. • Announce online—Intermediate state where FPC is coming up but is not online and the Chassis manager acknowledges that the FPC is in the process of coming online. • Empty—No FPC is present. • Offline—FPC is powered down. • Online—FPC is online and running. • Present—The chassis process has detected the FPC, but the FPC is either not supported by the current version of the Junos OS or FPC is coming up but is not online. • Ready—FPC is in transition state.
Connected FEB	Slot number of the Forwarding Engine Board (FEB) connected to the FPC or None if the FPC is not connected to a FEB.

Table 76: show chassis fpc-feb-connectivity Output Fields (*continued*)

Field Name	Field Description
FEB state	<p>State of the FEB. State can be any of the following:</p> <ul style="list-style-type: none"> • Announce offline—Intermediate state where FEB is going down but is not offline and the Chassis manager acknowledges that the FEB is in the process of going offline. • Announce online—Intermediate state where FEB is coming up but is not online and the Chassis manager acknowledges that the FEB is in the process of coming online. • Empty—No FEB is present. • Offline—FEB is powered down. • Online—FEB is online and running. • Present—The chassis process has detected the FEB, but the FEB is either not supported by the current version of the Junos OS or FEB is coming up but is not online. • Ready—FEB is in transition state.
Link status	<p>Status of the link connecting the R-FEB and R-FPC:</p> <ul style="list-style-type: none"> • Error • Misconfiguration—Configuration between the R-FEB and the F-FPC is incorrect. • OK

Sample Output

```

show chassis fpc-feb-connectivity user@host> show chassis fpc-feb-connectivity
FPC  FPC type  FPC state  Connected FEB  FEB state  Link status
0    cFPC      Online    0              Empty
1    cFPC      Online    1              Online    OK
2    Type 3   Online    3              Online    OK
3    Type 2   Online    None
4    Type 1   Online    4              Online    OK
5    Type 3   Online    None

FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Egress queues: 8 supported, 8 in use
Queue counters:      Queued packets  Transmitted packets      Dropped packets

  0 best-effort              0              0              0
  1 expedited-fo             0              0              0
  2 assured-forw             0              0              0
  3 network-cont             0              0              0

Active alarms : PLL, LOS, LINK
Active defects : PLL, LOF, LOS, SEF, LOP, BERR-SF, PLM-P, LINK
PCS statistics      Seconds
  Bit errors        0
  Errored blocks    3
MAC statistics:      Receive      Transmit
  Total octets      0              0
  Total packets     0              0

```

show chassis hardware

Syntax	show chassis hardware <clei-models detail extensive models>
Syntax (EX and QFX Series)	show chassis hardware <clei-models> <detail extensive> <models>
Syntax (TX Matrix Router)	show chassis hardware <clei-models> <detail extensive> <models> <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis hardware <clei-models> <detail extensive> <models> <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis hardware <clei-models detail extensive models> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. models option introduced in Junos OS Release 8.2. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display a list of all Flexible PIC Concentrators (FPCs) and PICs installed in the router or switch chassis, including the hardware version level and serial number. In EX Series switch command output, FPC refers to the following: <ul style="list-style-type: none"> On EX2200 switches, EX3200 switches, EX4200 standalone switches, and EX4500 switches—Refers to the switch; FPC number is always 0. On EX4200 switches in a Virtual Chassis configuration—Refers to the member of a Virtual Chassis; FPC number equals the member ID, from 0 through 9. On EX8208 and EX8216 switches—Refers to a line card; FPC number equals the slot number for the line card. In QFX Series command output, FPC refers to a line card; FPC number equals the slot number for the line card. Both the FPC and FPC number are always 0.

- Options**
- none**—Display information about hardware. For a TX Matrix router, display information about the TX Matrix router and its attached T640 routers. For a TX Matrix Plus router, display information about the TX Matrix Plus router and its attached T1600 routers.
 - clei-models**—(Optional) Display Common Language Equipment Identifier (CLEI) bar code and model number for orderable field-replaceable units (FRUs).
 - detail**—(Optional) Include RAM and disk information in output.
 - extensive**—(Optional) Display ID EEPROM information.
 - all-members**—(MX Series routers only) (Optional) Display hardware-specific information for all the members of the Virtual Chassis configuration.
 - lcc *number***—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display hardware information for a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display hardware information for a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.
 - local**—(MX Series routers only) (Optional) Display hardware-specific information for the local Virtual Chassis members.
 - member *member-id***—(MX Series routers only) (Optional) Display hardware-specific information for the specified member of the Virtual Chassis configuration. Replace ***member-id*** with a value of 0 or 1.
 - models**—(Optional) Display model numbers and part numbers for orderable FRUs and, for components that use ID EEPROM format v2, the CLEI code.
 - scc**—(TX Matrix router only) (Optional) Display hardware information for the TX Matrix router (or switch-card chassis).
 - sfc *number***—(TX Matrix Plus router only) (Optional) Display hardware information for the TX Matrix Plus router (or switch-fabric chassis). Replace ***number*** with 0.

Additional Information The **show chassis hardware detail** command now displays DIMM information for the following Routing Engines:

Table 77: Routing Engines Displaying DIMM Information

Routing Engines	Routers
RE-S-1800x2 and RE-S-1800x4	MX240, MX480, and MX960 routers
RE-A-1800x2	M120 and M320 routers

Required Privilege Level view

List of Sample Output

- show chassis hardware (EX8216 Switch) on page 428**
- show chassis hardware clei-models (EX8216 Switch) on page 429**
- show chassis hardware clei-models (T1600 Router) on page 429**

show chassis hardware detail (EX4200 Switch) on page 430
show chassis hardware models (EX4500 Switch) on page 430
show chassis hardware (J6350 Router) on page 430
show chassis hardware (J6300 Router) on page 431
show chassis hardware (M7i Router) on page 431
show chassis hardware (M10 Router) on page 432
show chassis hardware models (M10 Router) on page 432
show chassis hardware (M20 Router) on page 432
show chassis hardware models (M20 Router) on page 433
show chassis hardware (M40 Router) on page 433
show chassis hardware (M40e Router) on page 434
show chassis hardware (M120 Router) on page 435
show chassis hardware detail (M120 Router) on page 435
show chassis hardware models (M120 Router) on page 436
show chassis hardware (M160 Router) on page 437
show chassis hardware models (M160 Router) on page 437
show chassis hardware detail (M160 Router) on page 438
show chassis hardware (M320 Router) on page 439
show chassis hardware models (M320 Router) on page 440
show chassis hardware (Fixed MX80 Router) on page 440
show chassis hardware (Modular MX80 Router) on page 441
show chassis hardware (MX240 Router) on page 441
show chassis hardware detail (MX 240 Router with Routing Engine Displaying DIMM information) on page 442
show chassis hardware (MX480 Router) on page 442
show chassis hardware (MX960 Router) on page 443
show chassis hardware (MX960 Router with Bidirectional Optics) on page 443
show chassis hardware detail (MX960 Router) on page 444
show chassis hardware (T320 Router) on page 444
show chassis hardware (T640 Router) on page 445
show chassis hardware models (T640 Router) on page 446
show chassis hardware extensive (T640 Router) on page 447
show chassis hardware lcc (TX Matrix Router) on page 447
show chassis hardware scc (TX Matrix Router) on page 448
show chassis hardware (T1600 Router) on page 448
show chassis hardware (TX Matrix Plus Router) on page 451
show chassis hardware sfc (TX Matrix Plus Router) on page 456
show chassis hardware extensive (TX Matrix Plus Router) on page 457
show chassis hardware clei-models (TX Matrix Plus Router) on page 458
show chassis hardware detail (TX Matrix Plus Router) on page 460
show chassis hardware models (TX Matrix Plus Router) on page 462
show chassis hardware (16-Port 10-Gigabit Ethernet MPC with SFP+ Optics [MX Series Routers]) on page 465
show chassis hardware (QFX Series) on page 465
show chassis hardware detail (QFX Series) on page 466
show chassis hardware models (QFX Series) on page 467
show chassis hardware clei-models (QFX Series) on page 467

Output Fields Table 78 on page 426 lists the output fields for the **show chassis hardware** command. Output fields are listed in the approximate order in which they appear.

Table 78: show chassis hardware Output Fields

Field Name	Field Description	Level of Output
Item	Chassis component: <ul style="list-style-type: none"> (EX Series switches)—Information about the chassis, Routing Engine (SRE and RE modules in EX8200 switches), power supplies, fan trays, and LCD panel. Also displays information about Flexible PIC Concentrators (FPCs) and associated Physical Interface Cards (PICs). Information about the backplane, midplane, and SIBs (SF modules) is displayed for EX8200 switches. See EX Series Switches Hardware and CLI Terminology Mapping . (MX Series routers)—Information about the backplane, Routing Engine, Power Entry Modules (PEMs), and fan trays. Also displays information about Flexible PIC Concentrators (FPCs) and associated Physical Interface Cards (PICs), Modular Port Concentrators (MPCs) and associated Modular Interface Cards (MICs), or Dense Port Concentrators (DPCs). MX80 routers have a single Routing Engine and a built-in Packet Forwarding Engine (PFE) that attaches directly to MICs. The PFE has two “pseudo” FPCs (FPC 0 and FPC1). MX80 routers also have a Forwarding Engine Board (FEB). (M Series routers, except for the M320 router)—Information about the backplane; power supplies; fan trays; Routing Engine; maxicab (the connection between the Routing Engine and the backplane, for the M40 router only); SCB, SSB, SFM, or FEB; MCS and PCG (for the M160 router only); each FPC and PIC; and each fan, blower, and impeller. (M120, M320, and T Series routers)—Information about the backplane, power supplies, fan trays, midplane, FPM (craft interface), CIP, PEM, SCG, CB, FPC, PIC, SFP, SPMB, and SIB. (QFX Series)—Information about the chassis, Routing Engine, power supplies, and fan trays. Also displays information about Flexible PIC Concentrators (FPCs) and associated Physical Interface Cards (PICs). 	All levels
Version	Revision level of the chassis component.	All levels
Part number	Part number of the chassis component.	All levels
Serial number	Serial number of the chassis component. The serial number of the backplane is also the serial number of the router or switch chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.	All levels
Assb ID or Assembly ID	(extensive keyword only) Identification number that describes the FRU hardware.	extensive
Assembly Version	(extensive keyword only) Version number of the FRU hardware.	extensive
Assembly Flags	(extensive keyword only) Flags.	extensive
FRU model number	(clei-models , extensive , and models keyword only) Model number of FRU hardware component.	none specified

Table 78: show chassis hardware Output Fields (*continued*)

Field Name	Field Description	Level of Output
CLEI code	(clei-models and extensive keyword only) Common Language Equipment Identifier code. This value is displayed only for hardware components that use ID EEPROM format v2. This value is not displayed for components that use ID EEPROM format v1.	none specified
EEPROM Version	ID EEPROM version used by hardware component: 0x00 (version 0), 0x01 (version 1), or 0x02 (version 2).	extensive
Description	<p>Brief description of the hardware item:</p> <ul style="list-style-type: none"> Type of power supply. Type of PIC. If the PIC type is not supported on the current software release, the output states Hardware Not Supported. Type of FPC: FPC Type 1, FPC Type 2, FPC Type 3, FPC Type 4, or FPC Type OC192. On EX Series switches, a brief description of the FPC. On the J Series routers, the FPC type corresponds to the Physical Interface Module (PIM). The following list shows the PIM abbreviation in the output and the corresponding PIM name. <ul style="list-style-type: none"> 2x FE—Either two built-in Fast Ethernet interfaces (fixed PIM) or dual-port Fast Ethernet PIM 4x FE—4-port Fast Ethernet ePIM 1x GE Copper—Copper Gigabit Ethernet ePIM (one 10-Mbps, 100-Mbps, or 1000-Mbps port) 1x GE SFP—SFP Gigabit Ethernet ePIM (one fiber port) 4x GE Base PIC—Four built-in Gigabit Ethernet ports on a J4350 or J6350 chassis (fixed PIM) 2x Serial—Dual-port serial PIM 2x T1—Dual-port T1 PIM 2x E1—Dual-port E1 PIM 2x CTIE1—Dual-port channelized T1/E1 PIM 1x T3—T3 PIM (one port) 1x E3—E3 PIM (one port) 4x BRI S/T—4-port ISDN BRI S/T PIM 4x BRI U—4-port ISDN BRI U PIM 1x ADSL Annex A—ADSL 2/2+ Annex A PIM (one port, for POTS) 1x ADSL Annex B—ADSL 2/2+ Annex B PIM (one port, for ISDN) 2x SHDSL (ATM)—G SHDSL PIM (2-port two-wire module or 1-port four-wire module) 1x TGM550—TGM550 Telephony Gateway Module (Avaya VoIP Gateway Module with one console port, two analog LINE ports, and two analog TRUNK ports) 1x DS1 TIM510—TIM510 E1/T1 Telephony Interface Module (Avaya VoIP media module with one E1 or T1 trunk termination port and ISDN PRI backup) 4x FXS, 4x FXO, TIM514—TIM514 Analog Telephony Interface Module (Avaya VoIP media module with four analog LINE ports and four analog TRUNK ports) 	All levels

Table 78: show chassis hardware Output Fields (*continued*)

Field Name	Field Description	Level of Output
	<ul style="list-style-type: none"> • 4x BRI TIM521—TIM521 BRI Telephony Interface Module (Avaya VoIP media module with four ISDN BRI ports) • Crypto Accelerator Module—For enhanced performance of cryptographic algorithms used in IP Security (IPsec) services • MPC M 16x 10GE—16-port 10-Gigabit Module Port Concentrator that supports SFP+ optical transceivers. (Not on EX Series switches.) • For hosts, the Routing Engine type. • For small form-factor pluggable transceiver (SFP) modules, the type of fiber: LX, SX, LH, or T. • LCD description for EX Series switches (except EX2200 switches). 	

Sample Output

```

show chassis hardware user@host> show chassis hardware
(EX8216 Switch)      Hardware inventory:
Item                 Version  Part number  Serial number  Description
Chassis              REV 06
Midplane              REV 06      710-016845   BA0909120112   EX8216-MP
CB 0                  REV 22      710-020771   AX0109197723   EX8216-RE320
CB 1                  REV 22      710-020771   AX0109197726   EX8216-RE320
  Routing Engine 1    BUILTIN     BUILTIN      RE-EX8216
FPC 3                 REV 19      710-020683   BC0109083125   EX8200-48F
  CPU                 REV 13      710-020598   BF0109144549   EX8200-CPU
FPC 4                 REV 17      710-020683   BC0108500127   EX8200-48F
  CPU                 REV 10      710-020598   BF0108460510   EX8200-CPU
  PIC 0               BUILTIN     BUILTIN      48x 100 Base-QFX/1000
Base-X
  Xcvr 1              REV 01      740-011613   PE70V89         SFP-SX
  Xcvr 11             REV 01      740-011613   PE70YCE         SFP-SX
  Xcvr 12             REV 01      740-011613   PE70VSH         SFP-SX
  Xcvr 13             REV 01      740-011613   E08C02063       SFP-SX
  Xcvr 14             REV 01      740-011613   PE70VKU         SFP-SX
  Xcvr 15             REV 01      740-011613   E08E03372       SFP-SX
  Xcvr 21             REV 01      740-011613   PE70VAD         SFP-SX
  Xcvr 22             REV 01      740-011613   E08E01228       SFP-SX
  Xcvr 23             REV 01      740-011613   PE70VSL         SFP-SX
  Xcvr 24             REV 01      740-011613   E08E03409       SFP-SX
  Xcvr 25             REV 01      740-011613   PE70VL4         SFP-SX
  Xcvr 26             REV 01      740-011613   PDQ4L2Z         SFP-SX
  Xcvr 27             REV 01      740-011613   PE70WFK         SFP-SX
  Xcvr 28             REV 01      740-011782   PBD2B5U         SFP-SX
  Xcvr 29             REV 01      740-011613   PE70UQX         SFP-SX
  Xcvr 30             REV 01      740-011613   PE70VL5         SFP-SX
  Xcvr 31             REV 01      740-011613   PE70V0F         SFP-SX
  Xcvr 32             REV 01      740-011613   E08C02052       SFP-SX
  Xcvr 33             REV 01      740-011613   E08C02197       SFP-SX
  Xcvr 34             REV 01      740-011613   PE70V0L         SFP-SX
  Xcvr 35             REV 01      740-011613   E08E03390       SFP-SX
  Xcvr 36             REV 01      740-011613   PDQ4VL9         SFP-SX
  Xcvr 37             REV 01      740-011613   E08E03370       SFP-SX
  Xcvr 38             REV 01      740-011613   E08E03362       SFP-SX
  Xcvr 39             REV 01      740-011613   E08C02065       SFP-SX
  Xcvr 40             REV 01      740-011613   E08E03405       SFP-SX
  Xcvr 41             REV 01      740-011613   E08E03411       SFP-SX

```

Xcvr 43	REV 01	740-011613	E08C02171	SFP-SX
Xcvr 45	REV 01	740-011613	E08E03410	SFP-SX
FPC 13	REV 16	710-016837	BB0109051344	EX8200-8XS
CPU				
SIB 0	REV 10	710-021613	AY0109166244	EX8216-SF320
SIB 1	REV 10	710-021613	AY0109166357	EX8216-SF320
SIB 2	REV 10	710-021613	AY0109166362	EX8216-SF320
SIB 3	REV 10	710-021613	AY0109166338	EX8216-SF320
SIB 4	REV 10	710-021613	AY0109166350	EX8216-SF320
SIB 5	REV 10	710-021613	AY0109166365	EX8216-SF320
SIB 6	REV 10	710-021613	AY0109166361	EX8216-SF320
SIB 7	REV 10	710-021613	AY0109166399	EX8216-SF320
PSU 0	REV 17	740-021466	BG0709170003	EX8200-AC2K
PSU 1	REV 17	740-021466	BG0709170004	EX8200-AC2K
PSU 2	REV 17	740-021466	BG0709170020	EX8200-AC2K
PSU 3	REV 17	740-021466	BG0709170017	EX8200-AC2K
PSU 4	REV 17	740-021466	BG0709170008	EX8200-AC2K
PSU 5	REV 17	740-021466	BG0709170018	EX8200-AC2K
Top Fan Tray				
FTC 0	REV 4	760-022620	CX1209140212	EX8216-FT
FTC 1	REV 4	760-022620	CX1209140212	EX8216-FT
Bottom Fan Tray				
FTC 0	REV 4	760-022620	CX1209140211	EX8216-FT
FTC 1	REV 4	760-022620	CX1209140211	EX8216-FT
LCD 0	REV 04	710-025742	CE0109186919	EX8200 LCD

show chassis hardware user@host> **show chassis hardware clei-models**

clei-models (EX8216 Switch)

Hardware inventory:

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 08	710-016845		
PSU 0	REV 05	740-023002	COUPAEAEAA	EX8200-PWR-AC3KR
PSU 1	REV 05	740-023002	COUPAEAEAA	EX8200-PWR-AC3KR
PSU 2	REV 05	740-023002	COUPAEAEAA	EX8200-PWR-AC3KR
PSU 3	REV 05	740-023002	COUPAEAEAA	EX8200-PWR-AC3KR
PSU 4	REV 05	740-023002	COUPAEAEAA	EX8200-PWR-AC3KR
PSU 5	REV 05	740-023002	COUPAEAEAA	EX8200-PWR-AC3KR
Top Fan Tray				
Bottom Fan Tray				

show chassis hardware user@host> **show chassis hardware clei-models**

clei-models (T1600 Router)

Hardware inventory:

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 03	710-005608		CHAS-BP-T640-S
FPM Display	REV 05	710-002897		CRAFT-T640-S
CIP	REV 06	710-002895		CIP-L-T640-S
PEM 0	Rev 07	740-017906	IPUPAC7KTA	PWR-T1600-3-80-DC-S
PEM 1	Rev 18	740-002595		PWR-T-DC-S
SCG 0	REV 15	710-003423		SCG-T-S
Routing Engine 0	REV 08	740-014082		RE-A-2000-4096-S
Routing Engine 1	REV 07	740-014082		RE-A-2000-4096-S
CB 0	REV 05	710-007655		CB-T-S
CB 1	REV 03	710-017707		CB-T-S
FPC 0	REV 07	710-013558		T640-FPC2-E2
PIC 0	REV 01	750-010618		PB-4GE-SFP
PIC 1	REV 06	750-001900		PB-10C48-SON-SMSR
PIC 2	REV 14	750-001901		PB-40C12-SON-SMIR
PIC 3	REV 07	750-001900		PB-10C48-SON-SMSR
FPC 1	REV 06	710-013553		T640-FPC1-E2
PIC 0	REV 08	750-001072		P-1GE-SX
PIC 1	REV 10	750-012266		PB-4GE-TYPE1-SFP-IQ2
PIC 2	REV 22	750-005634		PB-1CHOC12SMIR-QPP

FPC 2				
PIC 0	REV 16	750-007141		PC-10GE-SFP
PIC 1	REV 06	750-015217		PC-8GE-TYPE3-SFP-IQ2
PIC 2	REV 05	750-004695		PC-TUNNEL
PIC 3	REV 17	750-009553		PC-40C48-SON-SFP
FPC 3	REV 01	710-010154		T640-FPC3-E
PIC 0	REV 07	750-012793		PC-1XGE-TYPE3-XFP-IQ2
PIC 1	REV 25	750-007141		PC-10GE-SFP
PIC 2	REV 17	750-009553		PC-40C48-SON-SFP
PIC 3	REV 32	750-003700		PC-10C192-SON-VSR
FPC 4	REV 16	710-013037		T1600-FPC4-ES
PIC 1	REV 06	750-034781		PD-1CE-CFP
FPC 5	REV 02	710-013037		T1600-FPC4-ES
PIC 0	REV 16	750-012518		PD-40C192-SON-XFP
PIC 1	REV 01	750-010850		PD-10C768-SON-SR
FPC 6	REV 14	710-013037		T1600-FPC4-ES
PIC 0	REV 11	750-017405		PD-4XGE-XFP
PIC 1	REV 13	750-017405		PD-4XGE-XFP
FPC 7	REV 09	710-007529		T640-FPC3
PIC 0	REV 10	750-012793		PC-1XGE-TYPE3-XFP-IQ2
PIC 1	REV 01	750-015217		PC-8GE-TYPE3-SFP-IQ2
PIC 2	REV 01	750-015217		PC-8GE-TYPE3-SFP-IQ2
PIC 3	REV 15	750-009450		PC-10C192-SON-SR2
SIB 0	REV 07	710-013074		SIB-I-T1600-S
SIB 1	REV 07	710-013074		SIB-I-T1600-S
SIB 2	REV 07	710-013074		SIB-I-T1600-S
SIB 3	REV 07	710-013074		SIB-I-T1600-S
SIB 4	REV 07	710-013074		SIB-I-T1600-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FAN-REAR-TX-T640-S

show chassis hardware user@host> **show chassis hardware detail**detail (EX4200
Switch)

Hardware inventory:				
Item	Version	Part number	Serial number	Description
Chassis			BM0208327733	EX4200-24T
Routing Engine 0	REV 11	750-021256	BM0208327733	EX4200-24T, 8 POE
Routing Engine 0			BM0208327733	EX4200-24T, 8 POE
FPC 0	REV 11	750-021256	BM0208327733	EX4200-24T, 8 POE
CPU		BUILTIN	BUILTIN	FPC CPU
PIC 0		BUILTIN	BUILTIN	24x 10/100/1000 Base-T
PIC 1	REV 03B	711-021270	AR0208162285	4x GE SFP
BRD	REV 08	711-021264	AK0208328289	EX4200-24T, 8 POE
Power Supply 0	REV 03	740-020957	AT0508346354	PS 320W AC
Fan Tray				Fan Tray

show chassis hardware user@host> **show chassis hardware models**models (EX4500
Switch)

Hardware inventory:				
Item	Version	Part number	Serial number	FRU model number
Routing Engine 0	REV 01	750-035700	GG0210271867	EX4500-40F-FB-C
FPC 0	REV 01	750-035700	GG0210271867	EX4500-40F-FB-C
PIC 0		BUILTIN	BUILTIN	EX4500-40F-FB-C
Power Supply 1	REV 01	740-029654	H884FS00JC09	EX4500-PWR1-AC-FB

show chassis hardware user@host> **show chassis hardware**

(J6350 Router)

Hardware inventory:				
Item	Version	Part number	Serial number	Description
Chassis			JN1090E07ADB	JSR6350
Midplane	REV 03	710-014593	NP1265	
System IO	REV 01	710-016210	NN9950	JX350 System IO

```

Crypto Module
Routing Engine  REV 08  710-015273  NM6509  Crypto Acceleration
ad0      248 MB  256MB  CKS      00102006C24A00000039 Compact
Flash
FPC 0
  PIC 0
FPC 1      REV 06  750-010355  AI07030023  FPC
  PIC 0      2x T1
FPC 3      REV 06  750-011148  AJ06520151  FPC
  PIC 0      2x E1
FPC 6      REV 06  750-013492  NC4170      FPC
  PIC 0      4x FE
Power Supply 0

```

**show chassis hardware
(J6300 Router)**

```

user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               JN000164AB     J6300
Midplane      REV 02.04 710-010001  CORE99570
System IO     REV 02.00 710-010003  CORE100848    System IO board
Routing Engine RevX2.6   750-010006  IWGS40735390  RE-J.3
FPC 0
  PIC 0
FPC 1      RevX2.0 750-011380  N3960005      FPC
  PIC 0      1xADSL pic Annex A
FPC 2      RevX2.0 750-011380  N3960002      FPC
  PIC 0      1xADSL pic Annex B
FPC 3      REV 03  750-010354  N0780028      FPC
  PIC 0      1x T3

```

**show chassis hardware
(M7i Router)**

```

user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               31959          M7i
Midplane      REV 02  710-008761  CA0209         M7i Midplane
Power Supply 0 Rev 04  740-008537  PD10272        AC Power Supply
Routing Engine REV 01  740-008846  1000396803     RE-5.0
CFEB          REV 02  750-009492  CA0166         Internet Processor IIv1
FPC 0
  PIC 0      REV 04  750-003163  HJ6416         1x G/E, 1000 BASE-SX
  PIC 1      REV 04  750-003163  HJ6423         1x G/E, 1000 BASE-SX
  PIC 2      REV 04  750-003163  HJ6421         1x G/E, 1000 BASE-SX
  PIC 3      REV 02  750-003163  HJ0425         1x G/E, 1000 BASE-SX
FPC 1
  PIC 2      REV 01  750-009487  HM2275         ASP - Integrated
  PIC 3      REV 01  750-009098  CA0142         2x F/E, 100 BASE-TX

Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               B1157          M7i
Midplane      REV 05  710-008761  DM0840         M7i Midplane
Power Supply 0 Rev 08  740-008537  TE53755        AC Power Supply
Routing Engine REV 07  740-011202  1000736567     RE-850
CFEB          REV 09  750-010463  DK6952         Internet Processor II
FPC 0
  PIC 0      REV 12  750-012838  DL7993         4x 1GE(LAN), IQ2
    Xcvr 0    REV 01  740-011614  PD94TDJ        SFP-LX10
    Xcvr 1    REV 01  740-011615  PAD5EER        UNKNOWN
    Xcvr 2    REV 01  740-011614  PD94THU        SFP-LX10
    Xcvr 3    NON-JNPR  PDC2E7A       SFP-LX10
  PIC 1      REV 03  750-023116  JT0203         4x CHSTM1 SDH CE SFP

```

Xcvr 0	REV 01	740-012434	AGT063832PS	SFP-SR
Xcvr 1	REV 01	740-012434	AGT063832LY	SFP-SR
Xcvr 3	REV 01	740-016064	C06J19018	SFP-LR
PIC 2	REV 15	750-014895	DM5757	MultiServices 100
PIC 3	REV 01	750-025390	JW9448	12x T1/E1 CE
FPC 1				E-FPC
PIC 2		BUILTIN	BUILTIN	1x Tunnel
PIC 3	REV 09	750-009099	DM0899	1x G/E, 1000 BASE
Xcvr 0	REV 01	740-012434	AGT07150HGJ	UNKNOWN
Fan Tray				Rear Fan Tray

show chassis hardware
(M10 Router)

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               1122          M10
Midplane      REV 1.1  710-001950   S/N AC6626
Power supply A Rev 01    740-002497   S/N LC36095    AC
Power supply B Rev 01    740-002497   S/N LC36100    AC
Display       REV 1.2  710-001995   S/N AC6656
Host          18000005dfb3fb01  teknor
FEB           REV 01    710-001948   S/N AC6632     Internet Processor II
FPC 0
  PIC 0        REV 08    750-001072   S/N AB2485     1x G/E, 1000 BASE-SX
  PIC 1        REV 01    750-000613   S/N AA1048     1x OC-12 SONET, SMIR
FPC 1
Fan Tray 0
Fan Tray 1      FANTRAY-M10I-S
                  FANTRAY-M10I-S
```

show chassis hardware
models (M10 Router)

```
user@host> show chassis hardware models
Hardware inventory:
Item          Version  Part number  CLEI code  FRU model number
Midplane      REV 04    710-008920
Power Supply 0 Rev 06    740-008537  PWR-M10i-M7i-AC-S
Power Supply 1 Rev 06    740-008537  PWR-M10i-M7i-AC-S
HCM 0         REV 03    710-010580  HCM-M10i-S
HCM 1         REV 03    710-010580  HCM-M10i-S
Routing Engine 0 REV 09    740-009459  RE-400-256-S
CFEB 0        REV 05    750-010465  FEB-M10i-M7i-S
FPC 0
  PIC 0        REV 10    750-002971  PE-40C3-SON-MM
  PIC 1        REV 11    750-002992  PE-4FE-TX
  PIC 2        REV 03    750-002977  PE-20C3-ATM-MM
  PIC 3        REV 08    750-005724  PE-20C3-ATM2-MM
FPC 1
  PIC 2        REV 12    750-008425  PE-AS
  PIC 3        REV 13    750-005636  PE-4CHDS3-QPP
Fan Tray 0    FANTRAY-M10I-S
Fan Tray 1    FANTRAY-M10I-S
```

show chassis hardware
(M20 Router)

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               20033        M20
Backplane      REV 07    710-001517   S/N AA7940
Power supply B Rev 01    740-001465   S/N 000001    AC
Display       REV 02    710-001519   S/N AA9704
Host 0        980000004f8f27501  teknor
SSB slot 0    REV 01    710-001951   S/N AD5905     Internet Processor II
  SSRAM bank 0 REV 01    710-001385   S00480         2 Mbytes
  SSRAM bank 1 REV 01    710-001385   S00490         2 Mbytes
```


SSRAM bank 2	REV 01	710-001385	S001:?	2 Mbytes
SSRAM bank 3	REV 01	710-001385	S00483	2 Mbytes
SSB slot 1	N/A	N/A	N/A	Backup
FPC 1	REV 01	710-001292	S/N AB7528	
SSRAM	REV 01	710-000077	S/N 304209	1 Mbyte
SDRAM bank 0	REV 01	710-000099	S/N 000603	64 Mbytes
SDRAM bank 1	REV 01	710-000099	S/N 000414	64 Mbytes
PIC 0	REV 03	750-000612	S/N AB8433	2x OC-3 ATM, MM
PIC 1	REV 01	750-000616	S/N AA1168	1x OC-12 ATM, MM
PIC 2	REV 01	750-000613	S/N AA1008	1x OC-12 SONET, SMIR
PIC 3	REV 01	750-002501	S/N AD5810	4x E3
FPC 2	REV 01	710-001292	S/N AC0119	
SSRAM	REV 01	710-000077	S/N 503241	1 Mbyte
SDRAM bank 0	REV 01	710-000099	S/N 306835	64 Mbytes
SDRAM bank 1	REV 01	710-000099	S/N 306832	64 Mbytes
Fan Tray 0				Front Upper Fan Tray
Fan Tray 1				Front Middle Fan Tray
Fan Tray 2				Front Bottom Fan Tray
Fan Tray 3				Rear Fan Tray

show chassis hardware models (M20 Router) user@host> show chassis hardware models
Hardware inventory:

Item	Version	Part number	CLEI code	FRU model number
Backplane	REV 03	710-002334		CHAS-MP-M20-S
Power Supply A	REV 06	740-001465		PWR-M20-AC-S
Display	REV 04	710-001519		CRAFT-M20-S
Routing Engine 0	REV 06	740-003239		RE-333-768-S
Routing Engine 1	REV 06	740-003239		RE-333-768-S
SSB 0	REV 02	710-001951		SSB-E-M20
SSB 1	N/A	N/A		
FPC 0	REV 03	710-003308		FPC-E
PIC 0	REV 08	750-002303		P-4FE-TX
PIC 1	REV 07	750-004745		P-2MCD53
PIC 2	REV 03	750-002965		PE-4CHDS3
FPC 1	REV 03	710-003308		FPC-E
PIC 0	REV 03	750-002914		P-20C3-ATM-MM
Fan Tray 0				FANTRAY-F-M20-S
Fan Tray 1				FANTRAY-F-M20-S
Fan Tray 2				FANTRAY-F-M20-S
Fan Tray 3				FANTRAY-R-M20-S

show chassis hardware (M40 Router) user@host> show chassis hardware
Hardware inventory:

Item	Version	Part number	Serial number	Description
Backplane	REV 02	710-000073	S/N AA0053	
Power supply A	Rev 2	740-000235	S/N 000042	DC
Maxicab	REV X1	710-000229	S/N AA0139	
Minicab	REV X1	710-000482	S/N AA0201	
Display	REV 06	710-000150	S/N AA0905	
Host				cpv5000
SCB	REV X1	710-000075	S/N AA0158	Internet Processor I
SSRAM bank 0	REV 02	710-000077	S/N AA2267	1 Mbyte
SSRAM bank 1	REV 02	710-000077	S/N AA2270	1 Mbyte
SSRAM bank 2	REV 02	710-000077	S/N AA2269	1 Mbyte
SSRAM bank 3	REV 02	710-000077	S/N AA2268	1 Mbyte
FPC 0	REV 01	710-000175	S/N AA0048	
SSRAM	REV 01	710-000077	S/N AA2333	1 Mbyte
SDRAM bank 0	REV 01	710-000099	S/N AA2332	64 Mbytes
SDRAM bank 1	REV X1	710-000099	S/N AA2337	64 Mbytes
PIC 0	REV 04	750-000613	S/N aa0343	1x OC-12 SONET, SMIR
PIC 1	REV 04	750-000613	S/N AA0379	1x OC-12 SONET, SMIR

PIC 2	REV 04	750-000613	S/N AA0377	1x OC-12 SONET, SMIR
PIC 3	REV 04	750-000613	S/N AA0378	1x Tunnel
FPC 2	REV 01	710-000175	S/N AA0042	
SSRAM	REV 02	710-000077	S/N AA2288	1 Mbyte
SDRAM bank 0	REV 01	710-000099	S/N AA2331	64 Mbytes
SDRAM bank 1	REV 01	710-000099	S/N AA2330	64 Mbytes
PIC 0	REV X1	750-000603	S/N AA0143	4x OC-3 SONET, SMIR
PIC 1	REV X1	750-000615	S/N AA0149	4x OC-3 SONET, MM
PIC 2	REV X1	750-000611	S/N AA0148	4x OC-3 SONET, MM
PIC 3	REV 04	750-000613	S/N AA0330	1x OC-12 SONET, SMIR
FPC 4	REV 01	710-000175	S/N AA0050	
SSRAM	REV 01	710-000077	S/N AA2327	1 Mbyte
SDRAM bank 0	REV 01	710-000099	S/N AA2329	64 Mbytes
SDRAM bank 1	REV 01	710-000099	S/N AA2328	64 Mbytes
PIC 0	REV 04	750-000613	S/N AA0320	1x OC-12 SONET, SMIR
PIC 2	REV 05	750-000616	S/N AA1341	1x OC-12 ATM, MM
PIC 3	REV 08	750-001072	S/N AB2462	1x G/E, 1000 BASE-SX
FPC 5	REV 10	710-000175	S/N AA7663	
SSRAM	REV 01	710-000077	S/N 501590	1 Mbyte
SDRAM bank 0	REV 01	710-000099	S/N 300949	64 Mbytes
SDRAM bank 1	REV 01	710-000099	S/N 300868	64 Mbytes
PIC 1	REV 01	750-001323	S/N AB1670	1x Tunnel

show chassis hardware
(M40e Router)

user@host> show chassis hardware

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis				m40e
Midplane	REV 01	710-005071	AX3671	
FPM CMB	REV 03	710-001642	AR9074	
FPM Display	REV 03	710-001647	AR7331	
CIP	REV 04	710-002649	BB4449	
PEM 0	Rev 01	740-003787	MC12364	Power Entry Module
PEM 1	Rev 01	740-003787	MC12383	Power Entry Module
PCG 0	REV 07	710-001568	AG1332	
PCG 1	REV 07	710-001568	AR3789	
Host 0			3e000007c8176601	Present
MCS 0	REV 11	710-001226	AN5813	
SFM 0 SPP	REV 07	710-001228	AG4676	
SFM 0 SPR	REV 05	710-002189	AE4735	Internet Processor II
SFM 1 SPP	REV 07	710-001228	AP1347	
SFM 1 SPR	REV 05	710-002189	BE0063	Internet Processor II
FPC 0	REV 01	710-011725	BE0669	M40e-EP-FPC Type 1
CPU	REV 01	710-004600	BD9504	
PIC 0	REV 03	750-003737	AY3991	4x G/E, 1000 BASE-SX
FPC 1	REV 01	710-005197	BD9842	M40e-FPC Type 2
CPU	REV 01	710-004600	BB4869	
PIC 0	REV 07	750-001900	AR8278	1x OC-48 SONET, SMSR
FPC 2	REV 02	710-005197	BD9824	M40e-FPC Type 2
CPU	REV 01	710-004600	BD9531	
PIC 0	REV 03	750-003737	AY3986	4x G/E, 1000 BASE-SX
FPC 4	REV 02	710-005078	BE0664	M40e-FPC Type 1
CPU	REV 01	710-004600	BD9559	
PIC 0	REV 03	750-001894	AG7963	1x G/E, 1000 BASE-SX
PIC 2	REV 01	750-002575	AF2472	4x OC-3 SONET, SMIR
FPC 6	REV 02	710-005078	BE0652	M40e-FPC Type 1
CPU	REV 01	710-004600	BD9607	
PIC 0	REV 02	750-002911	AN2286	4x F/E, 100 BASE-TX
PIC 2	REV 01	750-002577	AP6345	4x OC-3 SONET, MM

show chassis hardware user@host> **show chassis hardware**
(M120 Router) Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN000054AC	M120
Midplane	REV 01	710-013667	RB4170	M120 Midplane
FPM Board	REV 02	710-011407	CJ9186	M120 FPM Board
FPM Display	REV 02	710-011405	CJ9173	M120 FPM Display
FPM CIP	REV 02	710-011410	CJ9221	M120 FPM CIP
PEM 0	Rev 05	740-011936	RM28320	AC Power Entry Module
PEM 1	Rev 05	740-011936	RM28321	AC Power Entry Module
Routing Engine 0	REV 03	740-014080	1000642883	RE-A-1000
CB 0	REV 03	710-011403	CM8346	M120 Control Board
CB 1	REV 06	710-011403	CP6728	M120 Control Board
FPC 1	REV 02	710-015908	CP6925	M120 CFPC 10GE
PIC 0		BUILTIN	BUILTIN	1x 10GE(LAN/WAN) XFP
Xcvr 0	REV 01	740-014279	62E204N00007	XFP-10G-LR
FPC 3	REV 03	710-011393	CJ9234	M120 FPC Type 2
PIC 0	REV 16	750-008155	NB5229	2x G/E IQ, 1000 BASE
Xcvr 0	REV 01	740-011613	P9F15JB	SFP-SX
Xcvr 1	REV 01	740-007326	P4Q0R9G	SFP-SX
PIC 1	REV 09	750-007745	CG4360	4x OC-3 SONET, SMIR
PIC 2	REV 16	750-008155	ND7787	2x G/E IQ, 1000 BASE
Xcvr 0	REV 01	740-011613	P9F12AS	SFP-SX
Xcvr 1	REV 01	740-011613	P9F1ALU	SFP-SX
PIC 3	REV 07	750-011800	JW1284	8x 1GE(LAN), IQ2
Xcvr 0	REV 01	740-011613	P9F1AM6	SFP-SX
Xcvr 6	REV 01	740-011613	P9F16NN	SFP-SX
Xcvr 7	REV 01	740-011782	P8C29Y7	SFP-SX
Board B	REV 02	710-011395	CN3754	M120 FPC Mezz
FPC 4	REV 02	710-011398	CP6741	M120 FPC Type 3
PIC 0	REV 16	750-007141	NB2855	10x 1GE(LAN), 1000 BASE
Xcvr 0	REV 01	740-011782	P922A1F	SFP-SX
Xcvr 1	REV 01	740-011782	P922A16	SFP-SX
Xcvr 2	REV 01	740-011782	P922A0U	SFP-SX
Xcvr 3	REV 01	740-011782	P9229UZ	SFP-SX
Xcvr 4	REV 01	740-009029	P11JXWP	SFP-LX
Xcvr 6	REV 01	740-011613	P9F1ALW	SFP-SX
FPC 5	REV 01	710-011388	CJ9088	M120 FPC Type 1
PIC 0	*** Hardware Not Supported ***			
PIC 1	REV 05	750-012052	NB0410	1x CHOC3 IQ SONET, SMLR
PIC 2	REV 01	750-013167	CM3824	4x CHDS3 IQ
PIC 3	REV 01	750-010240	CB5366	1x G/E SFP, 1000 BASE
Board B	REV 01	710-011390	CJ9103	M120 FPC Mezz Board
FEB 3	REV 04	710-011663	CP6673	M120 FEB
FEB 4	REV 04	710-011663	CJ9368	M120 FEB
FEB 5	REV 04	710-011663	CJ9386	M120 FEB
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Top Fan Tray
Fan Tray 3				Rear Bottom Fan Tray

show chassis hardware user@host> **show chassis hardware detail**
detail (M120 Router) Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN000054AC	M120
Midplane	REV 01	710-013667	RB4170	M120 Midplane
FPM Board	REV 02	710-011407	CJ9186	M120 FPM Board
FPM Display	REV 02	710-011405	CJ9173	M120 FPM Display
FPM CIP	REV 02	710-011410	CJ9221	M120 FPM CIP

PEM 0	Rev 05	740-011936	RM28320	AC Power Entry Module
PEM 1	Rev 05	740-011936	RM28321	AC Power Entry Module
Routing Engine 0	REV 03	740-014080	1000642883	RE-A-1000
ad0 248 MB	SILICONSYSTEMS INC	256M 126CT505S0763SC00110		Compact Flash
ad2 38154 MB	HTE541040G9SA00	MPBBT0X2HS2E3M		Hard Disk
CB 0	REV 03	710-011403	CM8346	M120 Control Board
CB 1	REV 06	710-011403	CP6728	M120 Control Board
FPC 1	REV 02	710-015908	CP6925	M120 CFPC 10GE
PIC 0		BUILTIN	BUILTIN	1x 10GE(LAN/WAN) XFP
Xcvr 0	REV 01	740-014279	62E204N00007	XFP-10G-LR
FPC 3	REV 03	710-011393	CJ9234	M120 FPC Type 2
PIC 0	REV 16	750-008155	NB5229	2x G/E IQ, 1000 BASE
Xcvr 0	REV 01	740-011613	P9F15JB	SFP-SX
Xcvr 1	REV 01	740-007326	P4Q0R9G	SFP-SX
PIC 1	REV 09	750-007745	CG4360	4x OC-3 SONET, SMIR
PIC 2	REV 16	750-008155	ND7787	2x G/E IQ, 1000 BASE
Xcvr 0	REV 01	740-011613	P9F12AS	SFP-SX
Xcvr 1	REV 01	740-011613	P9F1ALU	SFP-SX
PIC 3	REV 07	750-011800	JW1284	8x 1GE(LAN), IQ2
Xcvr 0	REV 01	740-011613	P9F1AM6	SFP-SX
Xcvr 6	REV 01	740-011613	P9F16NN	SFP-SX
Xcvr 7	REV 01	740-011782	P8C29Y7	SFP-SX
Board B	REV 02	710-011395	CN3754	M120 FPC Mezz
FPC 4	REV 02	710-011398	CP6741	M120 FPC Type 3
PIC 0	REV 16	750-007141	NB2855	10x 1GE(LAN), 1000 BASE
Xcvr 0	REV 01	740-011782	P922A1F	SFP-SX
Xcvr 1	REV 01	740-011782	P922A16	SFP-SX
Xcvr 2	REV 01	740-011782	P922A0U	SFP-SX
Xcvr 3	REV 01	740-011782	P9229UZ	SFP-SX
Xcvr 4	REV 01	740-009029	P11JXWP	SFP-LX
Xcvr 6	REV 01	740-011613	P9F1ALW	SFP-SX
FPC 5	REV 01	710-011388	CJ9088	M120 FPC Type 1
PIC 0	*** Hardware Not Supported ***			
PIC 1	REV 05	750-012052	NB0410	1x CHOC3 IQ SONET, SMLR
PIC 2	REV 01	750-013167	CM3824	4x CHDS3 IQ
PIC 3	REV 01	750-010240	CB5366	1x G/E SFP, 1000 BASE
Board B	REV 01	710-011390	CJ9103	M120 FPC Mezz Board
FEB 3	REV 04	710-011663	CP6673	M120 FEB
FEB 4	REV 04	710-011663	CJ9368	M120 FEB
FEB 5	REV 04	710-011663	CJ9386	M120 FEB
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Top Fan Tray
Fan Tray 3				Rear Bottom Fan Tray

show chassis hardware models (M120 Router)

```
user@host> show chassis hardware models
```

```
Hardware inventory:
```

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 01	710-013667		
FPM CIP	REV 02	710-011410		CRAFT-M120-S
PEM 0	Rev 05	740-011936		PWR-M120-AC-S
PEM 1	Rev 05	740-011936		PWR-M120-AC-S
Routing Engine 0	REV 03	740-014080		RE-A-1000-2048-S
CB 0	REV 03	710-011403		CB-M120-S
CB 1	REV 06	710-011403		CB-M120-S
FPC 1	REV 02	710-015908		M120-cFPC-1XGE-XFP
FPC 3				
PIC 0	REV 16	750-008155		PB-2GE-SFP-QPP
PIC 1	REV 09	750-007745		PC-40C3-SON-SMIR

PIC 2	REV 16	750-008155	PB-2GE-SFP-QPP
PIC 3	REV 07	750-011800	PB-8GE-TYPE2-SFP-IQ2
FPC 4			
PIC 0	REV 16	750-007141	PC-10GE-SFP
FPC 5			
PIC 1	REV 05	750-012052	PB-1CHOC3-SMIR-QPP
PIC 2	REV 01	750-013167	PE-4CHDS3-QPP
PIC 3	REV 01	750-010240	PB-1GE-SFP
Fan Tray 0			FFANTRAY-M120-S
Fan Tray 1			FFANTRAY-M120-S
Fan Tray 2			RFANTRAY-M120-S
Fan Tray 3			RFANTRAY-M120-S

show chassis hardware (M160 Router)

```
user@host> show chassis hardware
```

Item	Version	Part number	Serial number	Description
Chassis			101	M160
Midplane	REV 02	710-001245	S/N AB4107	
FPM CMB	REV 01	710-001642	S/N AA2911	
FPM Display	REV 01	710-001647	S/N AA2999	
CIP	REV 02	710-001593	S/N AA9563	
PEM 0	Rev 01	740-001243	S/N KJ35769	DC
PEM 1	Rev 01	740-001243	S/N KJ35765	DC
PCG 0	REV 01	710-001568	S/N AA9794	
PCG 1	REV 01	710-001568	S/N AA9804	
Host 1			da000004f8d57001	teknor
MCS 1	REV 03	710-001226	S/N AA9777	
SFM 0 SPP	REV 04	710-001228	S/N AA2975	
SFM 0 SPR	REV 02	710-001224	S/N AA9838	Internet Processor I
SFM 1 SPP	REV 04	710-001228	S/N AA2860	
SFM 1 SPR	REV 01	710-001224	S/N AB0139	Internet Processor I
FPC 0	REV 03	710-001255	S/N AA9806	FPC Type 1
CPU	REV 02	710-001217	S/N AA9590	
PIC 1	REV 05	750-000616	S/N AA1527	1x OC-12 ATM, MM
PIC 2	REV 05	750-000616	S/N AA1535	1x OC-12 ATM, MM
PIC 3	REV 01	750-000616	S/N AA1519	1x OC-12 ATM, MM
FPC 1	REV 02	710-001611	S/N AA9523	FPC Type 2
CPU	REV 02	710-001217	S/N AA9571	
PIC 0	REV 03	750-001900	S/N AA9626	1x STM-16 SDH, SMIR
PIC 1	REV 01	710-002381	S/N AD3633	2x G/E, 1000 BASE-SX
FPC 2				FPC Type OC192
CPU	REV 03	710-001217	S/N AB3329	
PIC 0	REV 01			1x OC-192 SM SR-2
Fan Tray 0				Rear Bottom Blower
Fan Tray 1				Rear Top Blower
Fan Tray 2				Front Top Blower
Fan Tray 3				Front Fan Tray

show chassis hardware models (M160 Router)

```
user@host> show chassis hardware models
```

Hardware inventory:

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 03	710-009120		CHAS-BP-M320-S
FPM Display	REV 02	710-009351		CRAFT-M320-S
CIP	REV 03	710-005926		CIP-M320-S
PEM 2	Rev X4	740-009148		PWR-M-DC-S
PEM 3	Rev X4	740-009148		PWR-M-DC-S
Routing Engine 0	REV 02	740-008883		RE-1600-2048-S
Routing Engine 1	REV 02	740-008883		RE-1600-2048-S
FPC 0	REV 02	710-010419		M320-FPC1
PIC 0	REV 01	750-001323		P-TUNNEL
PIC 1	REV 02	750-002987		PE-10C12-SON-SMIR
PIC 2	REV 04	750-001894		PB-1GE-SX

PIC 3	REV 04	750-001896	PB-10C12-SON-SMIR
FPC 1	REV 02	710-010419	M320-FPC1
PIC 0	REV 04	750-001894	PB-1GE-SX
PIC 1	REV 04	750-001894	PB-1GE-SX
PIC 3	REV 03	750-001894	PB-1GE-SX
FPC 2	REV 02	710-010419	M320-FPC1
PIC 0	REV 10	750-005634	PB-1CHOC12SMIR-QPP
PIC 1	REV 10	750-005634	PB-1CHOC12SMIR-QPP
PIC 2	REV 07	750-005634	PB-1CHOC12SMIR-QPP
PIC 3	REV 07	750-005634	PB-1CHOC12SMIR-QPP
PIC 1	REV 10	750-005634	PB-1CHOC12SMIR-QPP
PIC 2	REV 07	750-005634	PB-1CHOC12SMIR-QPP
PIC 3	REV 07	750-005634	PB-1CHOC12SMIR-QPP
FPC 3			
PIC 0	REV 03	750-001895	PB-10C12-SON-MM
PIC 1	REV 04	750-001894	PB-1GE-SX
PIC 3	REV 04	750-003141	PB-1GE-SX-B
FPC 4	REV 02	710-010419	M320-FPC1
FPC 5	REV 02	710-010419	M320-FPC1
FPC 6	REV 02	710-010419	M320-FPC1
FPC 7			
PIC 0	REV 15	750-001901	PB-40C12-SON-SMIR
PIC 1	REV 06	750-001900	PB-10C48-SON-SMSR
PIC 2	REV 07	750-001900	PB-10C48-SON-SMSR
PIC 3	REV 05	750-003737	PB-4GE-SX
SIB 0	REV 03	710-009184	SIB-M-S
SIB 1	REV 03	710-009184	SIB-M-S
SIB 2	REV 03	710-009184	SIB-M-S
SIB 3	REV 03	710-009184	SIB-M-S
Fan Tray 0			FFANTRAY-M320-S
Fan Tray 1			FFANTRAY-M320-S
Fan Tray 2			RFANTRAY-M320-S

show chassis hardware detail (M160 Router)

```
user@host> show chassis hardware detail
```

```
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis			101	M160
Midplane	REV 02	710-001245	S/N AB4107	
FPM CMB	REV 01	710-001642	S/N AA2911	
FPM Display	REV 01	710-001647	S/N AA2999	
CIP	REV 02	710-001593	S/N AA9563	
PEM 0	Rev 01	740-001243	S/N KJ35769	DC
PEM 1	Rev 01	740-001243	S/N KJ35765	DC
PCG 0	REV 01	710-001568	S/N AA9794	
PCG 1	REV 01	710-001568	S/N AA9804	
Host 1			da000004f8d57001	teknor
MCS 1	REV 03	710-001226	S/N AA9777	
SFM 0 SPP	REV 04	710-001228	S/N AA2975	
SFM 0 SPR	REV 02	710-001224	S/N AA9838	Internet Processor I
SSRAM bank 0	REV 01	710-000077	S/N 306456	1 Mbyte
SSRAM bank 1	REV 01	710-000077	S/N 306474	1 Mbyte
SSRAM bank 2	REV 01	710-000077	S/N 306388	1 Mbyte
SSRAM bank 3	REV 01	710-000077	S/N 306392	1 Mbyte
SFM 1 SPP	REV 04	710-001228	S/N AA2860	
SFM 1 SPR	REV 01	710-001224	S/N AB0139	Internet Processor I
SSRAM bank 0	REV 01	710-000077	S/N 302917	1 Mbyte
SSRAM bank 1	REV 01	710-000077	S/N 302662	1 Mbyte
SSRAM bank 2	REV 01	710-000077	S/N 302593	1 Mbyte
SSRAM bank 3	REV 01	710-000077	S/N 100160	1 Mbyte
FPC 0	REV 03	710-001255	S/N AA9806	FPC Type 1
CPU	REV 02	710-001217	S/N AA9590	

SSRAM	REV 01	710-000077	S/N 302836	1 Mbyte
SDRAM 0	REV 01	710-001196	S00141	32 Mbytes
SDRAM 1	REV 01	710-001196	S0010;	32 Mbytes
SSRAM	REV 01	710-000077	S/N 302633	1 Mbyte
SDRAM 0	REV 01	710-001196	S00143	32 Mbytes
SDRAM 1	REV 01	710-001196	S00115	32 Mbytes
SSRAM	REV 01	710-000077	S/N 302952	1 Mbyte
SDRAM 0	REV 01	710-001196	S00135	32 Mbytes
SDRAM 1	REV 01	710-001196	S001=3	32 Mbytes
SSRAM	REV 01	710-000077	S/N 302892	1 Mbyte
SDRAM 0	REV 01	710-001196	S000?6	32 Mbytes
SDRAM 1	REV 01	710-001196	S001=5	32 Mbytes
PIC 1	REV 05	750-000616	S/N AA1527	1x OC-12 ATM, MM
PIC 2	REV 05	750-000616	S/N AA1535	1x OC-12 ATM, MM
PIC 3	REV 01	750-000616	S/N AA1519	1x OC-12 ATM, MM
FPC 1	REV 02	710-001611	S/N AA9523	FPC Type 2
CPU	REV 02	710-001217	S/N AA9571	
SSRAM	REV 01	710-000077	S/N 306340	1 Mbyte
SDRAM 0	REV 01	710-001196	S00012	32 Mbytes
SDRAM 1	REV 01	710-001196	S0001?	32 Mbytes
SSRAM	REV 01	710-000077	S/N 306454	1 Mbyte
SDRAM 0	REV 01	710-001196	S00028	32 Mbytes
SDRAM 1	REV 01	710-001196	S0002?	32 Mbytes
SSRAM	REV 01	710-000077	S/N 306492	1 Mbyte
SDRAM 0	REV 01	710-001196	S00015	32 Mbytes
SDRAM 1	REV 01	710-001196	S00031	32 Mbytes
SSRAM	REV 01	710-000077	S/N 306363	1 Mbyte
SDRAM 0	REV 01	710-001196	S00013	32 Mbytes
SDRAM 1	REV 01	710-001196	S00032	32 Mbytes
PIC 0	REV 03	750-001900	S/N AA9626	1x STM-16 SDH, SMIR
PIC 1	REV 01	710-002381	S/N AD3633	2x G/E, 1000 BASE-SX
FPC 2				FPC Type OC192
... SSRAM	REV 01	710-000077	S/N 306466	1 Mbyte

show chassis hardware
(M320 Router)

```
user@host> show chassis hardware
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis			67245	M320
Midplane	REV 05	710-009120	RB1202	M320 Midplane
FPM GBUS	REV 04	710-005928	HZ5697	M320 Board
FPM Display	REV 05	710-009351	HR1464	M320 FPM Display
CIP	REV 04	710-005926	HT8672	M320 CIP
PEM 0	Rev 05	740-009148	QK34208	DC Power Entry Module
PEM 1	Rev 05	740-009148	QK34262	DC Power Entry Module
PEM 2	Rev 05	740-009148	QF10449	DC Power Entry Module
PEM 3	Rev 05	740-009148	QJ18257	DC Power Entry Module
Routing Engine 0	REV 06	740-008883	P11123901185	RE-4.0
CB 0	REV 07	710-009115	JB2382	M320 Control Board
FPC 0	REV 02	710-005017	CD9926	M320 FPC Type 2
CPU	REV 01	710-011659	CJ6940	M320 PCA SCPU
PIC 0	REV 07	750-001900	AT1594	1x OC-48 SONET, SMSR
PIC 1	REV 03	750-001850	HS2746	1x Tunnel
PIC 2	REV 05	750-010618	JE7117	4x G/E SFP, 1000 BASE
PIC 3	REV 06	750-001900	HE6083	1x OC-48 SONET, SMSR
FPC 2	REV 02	710-005017	CH0319	M320 FPC Type 1
CPU	REV 01	710-011659	CJ6942	M320 PCA SCPU
PIC 0	REV 05	750-003034	BD8705	4x OC-3 SONET, SMIR
FPC 5	REV 02	710-005017	CD9938	M320 FPC Type 2
CPU				
FPC 7	REV 02	710-005017	CD9934	M320 FPC Type 2
CPU				

SIB 0	REV 09	710-009184	JA6540	M320 SIB
SIB 1	REV 09	710-009184	HV9511	M320 SIB
SIB 2	REV 09	710-009184	HW2057	M320 SIB
SIB 3	REV 09	710-009184	JA6687	M320 SIB
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Fan Tray

show chassis hardware models (M320 Router)

```
user@host> show chassis hardware models
```

```
Hardware inventory:
```

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 03	710-009120		CHAS-BP-M320-S
FPM Display	REV 02	710-009351		CRAFT-M320-S
CIP	REV 03	710-005926		CIP-M320-S
PEM 2	Rev X4	740-009148		PWR-M-DC-S
PEM 3	Rev X4	740-009148		PWR-M-DC-S
Routing Engine 0	REV 02	740-008883		RE-1600-2048-S
Routing Engine 1	REV 02	740-008883		RE-1600-2048-S
FPC 0	REV 02	710-010419		M320-FPC1
PIC 0	REV 01	750-001323		P-TUNNEL
PIC 1	REV 02	750-002987		PE-10C12-SON-SMIR
PIC 2	REV 04	750-001894		PB-1GE-SX
PIC 3	REV 04	750-001896		PB-10C12-SON-SMIR
FPC 1	REV 02	710-010419		M320-FPC1
PIC 0	REV 04	750-001894		PB-1GE-SX
PIC 1	REV 04	750-001894		PB-1GE-SX
PIC 3	REV 03	750-001894		PB-1GE-SX
FPC 2	REV 02	710-010419		M320-FPC1
PIC 0	REV 10	750-005634		PB-1CHOC12SMIR-QPP
PIC 1	REV 10	750-005634		PB-1CHOC12SMIR-QPP
PIC 2	REV 07	750-005634		PB-1CHOC12SMIR-QPP
PIC 3	REV 07	750-005634		PB-1CHOC12SMIR-QPP
PIC 1	REV 10	750-005634		PB-1CHOC12SMIR-QPP
PIC 2	REV 07	750-005634		PB-1CHOC12SMIR-QPP
PIC 3	REV 07	750-005634		PB-1CHOC12SMIR-QPP
FPC 3				
PIC 0	REV 03	750-001895		PB-10C12-SON-MM
PIC 1	REV 04	750-001894		PB-1GE-SX
PIC 3	REV 04	750-003141		PB-1GE-SX-B
FPC 4	REV 02	710-010419		M320-FPC1
FPC 5	REV 02	710-010419		M320-FPC1
FPC 6	REV 02	710-010419		M320-FPC1
FPC 7				
PIC 0	REV 15	750-001901		PB-40C12-SON-SMIR
PIC 1	REV 06	750-001900		PB-10C48-SON-SMSR
PIC 2	REV 07	750-001900		PB-10C48-SON-SMSR
PIC 3	REV 05	750-003737		PB-4GE-SX
SIB 0	REV 03	710-009184		SIB-M-S
SIB 1	REV 03	710-009184		SIB-M-S
SIB 2	REV 03	710-009184		SIB-M-S
SIB 3	REV 03	710-009184		SIB-M-S
Fan Tray 0				FFANTRAY-M320-S
Fan Tray 1				FFANTRAY-M320-S
Fan Tray 2				RFANTRAY-M320-S

show chassis hardware (Fixed MX80 Router)

```
user@host> show chassis hardware
```

```
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis				MX80-48T
Midplane	REV 01	711-031603	KF9250	MX80-48T
Routing Engine		BUILTIN	BUILTIN	Routing Engine

FEB 0		BUILTIN	BUILTIN	Forwarding Engine Board
FPC 0		BUILTIN	BUILTIN	MPC BUILTIN
MIC 0		BUILTIN	BUILTIN	4x 10GE XFP
PIC 0		BUILTIN	BUILTIN	4x 10GE XFP
Xcvr 0		NON-JNPR	M6439D41	XFP-10G-LR
Xcvr 1	REV 01	740-014279	6XE931N00202	XFP-10G-LR
Xcvr 2	REV 01	740-014289	C715XU05F	XFP-10G-SR
Xcvr 3	REV 01	740-014289	C650XU0EP	XFP-10G-SR
FPC 1		BUILTIN	BUILTIN	MPC BUILTIN
MIC 0	REV 01	711-029399	JR6981	12x 1GE(LAN) RJ45
PIC 0		BUILTIN	BUILTIN	12x 1GE(LAN) RJ45
PIC 1		BUILTIN	BUILTIN	12x 1GE(LAN) RJ45
MIC 1	REV 01	BUILTIN	BUILTIN	12x 1GE(LAN) RJ45
PIC 2		BUILTIN	BUILTIN	12x 1GE(LAN) RJ45
PIC 3		BUILTIN	BUILTIN	12x 1GE(LAN) RJ45
Fan Tray				Fan Tray

show chassis hardware user@host> show chassis hardware

(Modular MX80
Router)

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis				MX80
Midplane	REV 02	711-031594	JR7084	MX80
PEM 0	Rev 01	740-028288	000018	AC Power Entry Module
Routing Engine		BUILTIN	BUILTIN	Routing Engine
FEB 0		BUILTIN	BUILTIN	Forwarding Engine Board
QXM 0	REV 05	711-028408	JR7041	MPC QXM
FPC 0		BUILTIN	BUILTIN	MPC BUILTIN
MIC 0		BUILTIN	BUILTIN	4x 10GE XFP
PIC 0		BUILTIN	BUILTIN	4x 10GE XFP
FPC 1		BUILTIN	BUILTIN	MPC BUILTIN
MIC 0	REV 02	750-028380	JR6598	3D 2x 10GE XFP
PIC 0		BUILTIN	BUILTIN	1x 10GE XFP
Xcvr 0	REV 01	740-014289	T07M86365	XFP-10G-SR
PIC 1		BUILTIN	BUILTIN	1x 10GE XFP
Xcvr 0	REV 01	740-014289	T07M71094	XFP-10G-SR
MIC 1	REV 02	750-028380	JG8548	3D 2x 10GE XFP
PIC 2		BUILTIN	BUILTIN	1x 10GE XFP
Xcvr 0	REV 02	740-014289	T08L86302	XFP-10G-SR
PIC 3		BUILTIN	BUILTIN	1x 10GE XFP
Xcvr 0	REV 02	740-014289	C810XU0BA	XFP-10G-SR
Fan Tray				Fan Tray

show chassis hardware user@host> show chassis hardware

(MX240 Router)

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN10C7F7EAF	MX240
Midplane	REV 01	710-021041	TR1502	MX240 Backplane
FPM Board	REV 01	710-017254	KD4017	Front Panel Display
PEM 0	Rev 02	740-017330	000332	PS 1.2-1.7kW; 100-240V
AC in				
PEM 1	Rev 02	740-017330	000226	PS 1.2-1.7kW; 100-240V
AC in				
Routing Engine 0	REV 06	740-013063	1000703522	RE-S-2000
Routing Engine 1	REV 06	740-015113	1000687625	RE-S-1300
CB 0	REV 07	710-013385	KC9057	MX SCB
CB 1	REV 05	710-013385	JY4760	MX SCB
FPC 1	REV 01	750-021679	KC7340	DPCE 40x 1GE R
CPU	REV 06	710-013713	KD4078	DPC PMB
PIC 0		BUILTIN	BUILTIN	10x 1GE(LAN)

Xcvr 0	REV 01	740-011613	P9F18ME	SFP-SX
PIC 1		BUILTIN	BUILTIN	10x 1GE(LAN)
PIC 2		BUILTIN	BUILTIN	10x 1GE(LAN)
PIC 3		BUILTIN	BUILTIN	10x 1GE(LAN)
FPC 2	REV 04	710-016669	JS4529	DPCE 40x 1GE R EQ
CPU	REV 06	710-013713	KB3969	DPC PMB
PIC 0		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
Xcvr 0	REV 01	740-011613	PBG3Y79	SFP-SX
Xcvr 1	REV 01	740-011613	PBG3XU8	SFP-SX
Xcvr 2	REV 01	740-011613	PBG3YG6	SFP-SX
Xcvr 3	REV 01	740-011613	PBG3XUG	SFP-SX
Xcvr 4	REV 01	740-011613	PBG3XTJ	SFP-SX
PIC 1		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
Xcvr 0	REV 01	740-011613	PBG3ZUM	SFP-SX
Xcvr 1	REV 01	740-011613	PBG3Y5H	SFP-SX
Xcvr 2	REV 01	740-011613	PBG3UZT	SFP-SX
Xcvr 3	REV 01	740-011613	PBG3US1	SFP-SX
PIC 2		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
Xcvr 0	REV 01	740-011613	PBG3YG7	SFP-SX
Xcvr 1	REV 01	740-011613	PBG3XZ9	SFP-SX
Xcvr 2	REV 01	740-011613	PBG3XTY	SFP-SX
Xcvr 3	REV 01	740-011613	PBG3UZG	SFP-SX
PIC 3		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
Xcvr 0	REV 01	740-011613	PBG3Y8W	SFP-SX
Xcvr 1	REV 01	740-011613	PBG3YVX	SFP-SX
Xcvr 2	REV 01	740-011613	PBG3YB3	SFP-SX
Xcvr 3	REV 01	740-011613	PBG43VQ	SFP-SX
Fan Tray 0	REV 01	710-021113	JS4642	MX240 Fan Tray

show chassis hardware user@host> show chassis hardware detail

detail (MX 240 Router
with Routing Engine
Displaying DIMM
information)

Item	Version	Part number	Serial number	Description
Chassis			JN11279B4AFC	MX240 Backplane
Midplane	REV 07	760-021404	TS2474	MX240 Backplane
FPM Board	REV 03	760-021392	XC2643	Front Panel Display
PEM 0	Rev 03	740-017343	QCS0908A068	DC Power Entry Module
Routing Engine 0	REV 01	740-031117	AARCH00	RE-S-1800x4
ad0 3764 MB	STEC M2+	CF 9.0.2	STIM2Q3209239145303	Removable Compact Flash
ad1 28626 MB	WDC SSD-F0030S-5000		C933Z036237215548S00	Compact Flash
usb0 (addr 1)	EHCI root hub 0		Intel	uhub0
usb0 (addr 2)	product 0x0020 32		vendor 0x8087	uhub1
DIMM 0	VL31B5263E-F8S DIE REV-0	PCB REV-0		MFR ID-ce80
DIMM 1	VL31B5263E-F8S DIE REV-0	PCB REV-0		MFR ID-ce80
DIMM 2	VL31B5263E-F8S DIE REV-0	PCB REV-0		MFR ID-ce80
DIMM 3	SL31B5263E-F8S DIE REV-0	PCB REV-0		MFR ID-ce80
CB 0	REV 03	710-021523	XD7225	MX SCB
Fan Tray 0	REV 01	710-021113	WZ4986	MX240 Fan Tray

show chassis hardware user@host> show chassis hardware

(MX480 Router)

Hardware inventory:				
Item	Version	Part number	Serial number	Description
Chassis			JN10C7F7FAFB	MX480
Midplane	REV 04	710-017414	TR2071	MX480 Midplane
FPM Board	REV 02	710-017254	KB8459	Front Panel Display
PEM 0	Rev 02	740-017330	QCS07519029	PS 1.2-1.7kW; 100-240V
AC in				
PEM 1	Rev 02	740-017330	QCS07519041	PS 1.2-1.7kW; 100-240V
AC in				
PEM 2	Rev 02	740-017330	QCS07519097	PS 1.2-1.7kW; 100-240V
AC in				

Routing Engine 0	REV 07	740-013063	1000733381	RE-S-2000
Routing Engine 1	REV 07	740-013063	1000733540	RE-S-2000
CB 0	REV 07	710-013385	KA8022	MX SCB
CB 1	REV 07	710-013385	KA8303	MX SCB
FPC 0	REV 09	750-020452	KA8660	DPCE 40x 1GE X EQ
CPU	REV 06	710-013713	KA8185	DPC PMB
PIC 0		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
PIC 1		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
PIC 2		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
PIC 3		BUILTIN	BUILTIN	10x 1GE(LAN) EQ
Fan Tray				Left Fan Tray

show chassis hardware (MX960 Router)

```
user@host> show chassis hardware
```

```
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis				MX960
Midplane	REV 01	710-013698	AA6082	MX960 Midplane
PIM	Rev 01	740-013110	000008	Power Inlet Module
PEM 2				
PEM 3	Rev 01	740-013682	000038	PS 1.7kW; 200-240VAC in
Routing Engine 0	REV 00	740-015113	1000617944	RE-S-1300
CB 0	REV 05	710-013725	JK6947	MX960 Test SCB
FPC 4	REV 01	710-013305	JM7617	MX960 Test DPC
CPU				
PIC 0		BUILTIN	BUILTIN	1x 10GE(LAN/WAN)
PIC 1		BUILTIN	BUILTIN	10x 1GE
FPC 7	REV 01	710-013305	JL9634	MX960 Test DPC
CPU				
PIC 0		BUILTIN	BUILTIN	1x 10GE(LAN/WAN)
Xcvr 0		NON-JNPR	MYBG65I82C	XFP-10G-SR
PIC 1		BUILTIN	BUILTIN	10x 1GE
Xcvr 1	REV 01	740-011782	P7N0368	SFP-SX
Xcvr 4	REV 01	740-011782	P8J1W27	SFP-SX
Xcvr 6	REV 01	740-011782	P8J1VSD	SFP-SX
Xcvr 9	REV 01	740-011782	P8J1W25	SFP-SX
Fan Tray 0				
Fan Tray 1				

show chassis hardware (MX960 Router with Bidirectional Optics)

```
user@host> show chassis hardware
```

```
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis			JN10BA5B9AFA	MX960
Midplane	REV 03	710-013698	TR0234	MX960 Backplane
FPM Board	REV 03	710-014974	JA0878	Front Panel Display
PDM	Rev 03	740-013110	QCS11135028	Power Distribution Module
PEM 0	Rev 03	740-013682	QCS11154036	PS 1.7kW; 200-240VAC in
PEM 1	Rev 03	740-013682	QCS11154010	PS 1.7kW; 200-240VAC in
PEM 2	Rev 03	740-013682	QCS11154022	PS 1.7kW; 200-240VAC in
Routing Engine 0	REV 06	740-013063	1000691458	RE-S-2000
CB 0	REV 07	710-013385	KA2190	MX SCB
CB 1	REV 07	710-013385	KA0837	MX SCB
FPC 3	REV 02	750-018122	KB3890	DPCE 40x 1GE R
CPU				
FPC 4	REV 01	750-018122	KB3889	DPCE 40x 1GE R
CPU	REV 06	710-013713	KB3976	DPC PMB
PIC 0		BUILTIN	BUILTIN	10x 1GE(LAN)
Xcvr 1	REV 01	740-020426	4910549	SFP-1000BASE-BX40-D
Xcvr 2	REV 01	740-020426	4910551	SFP-1000BASE-BX40-D
Xcvr 5	REV 01	740-021340	77E245N00006	SFP-1000BASE-BX10-U
Xcvr 6	REV 01	740-020425	4882821	SFP-1000BASE-BX40-U
Xcvr 8	REV 01	740-020425	4882820	SFP-1000BASE-BX40-U

PIC 1			BUILTIN	BUILTIN	10x 1GE(LAN)
Xcvr 0	REV 01	740-020465	77E555N00894	SFP-1000BASE-BX10-D	
Xcvr 1	REV 01	740-020465	75E467X00818	SFP-1000BASE-BX10-D	
Xcvr 2	REV 01	740-020465	75E467X00573	SFP-1000BASE-BX10-D	
Xcvr 3	REV 01	740-020465	4888227	SFP-1000BASE-BX10-D	
Xcvr 4	REV 01	740-020465	4888241	SFP-1000BASE-BX10-D	
Xcvr 5	REV 01	740-021340	77E245N00005	SFP-1000BASE-BX10-U	
Xcvr 6	REV 01	740-021340	76E245X00487	SFP-1000BASE-BX10-U	
Xcvr 7	REV 01	740-021341	5255889	SFP-1000BASE-BX10-U	
Xcvr 8	REV 01	740-021341	5255887	SFP-1000BASE-BX10-U	
Xcvr 9	REV 01	740-021340	77E245N00004	SFP-1000BASE-BX10-U	
PIC 2			BUILTIN	BUILTIN	10x 1GE(LAN)
Xcvr 0	REV 01	740-020424	5007582	SFP-1000BASE-BX10-D	
Xcvr 1	REV 01	740-020424	4888187	SFP-1000BASE-BX10-D	
Xcvr 2	REV 01	740-020424	4656500	SFP-1000BASE-BX10-D	
Xcvr 5	REV 01	740-021341	5255886	SFP-1000BASE-BX10-U	
Xcvr 7	REV 01	740-021340	77E245N00003	SFP-1000BASE-BX10-U	
Xcvr 8	REV 01	740-021341	5255888	SFP-1000BASE-BX10-U	
PIC 3			BUILTIN	BUILTIN	10x 1GE(LAN)
Xcvr 0	REV 01	740-017726	74S184H30341	SFP-LH	
Xcvr 1	REV 01	740-017726	4814061	SFP-LH	
Xcvr 5	REV 01	740-017726	6ZS184H31108	SFP-LH	
Xcvr 9	REV 01	740-021340	76E245X00486	SFP-1000BASE-BX10-U	
Fan Tray 0					
Fan Tray 1	REV 03	740-014971	TP0850	Fan Tray	

show chassis hardware detail (MX960 Router)

```
user@host> show chassis hardware detail
```

Hardware inventory:					
Item	Version	Part number	Serial number	Description	
Chassis				MX960	
Midplane	REV 01	710-013698	AA6082	MX960 Midplane	
PIM	Rev 01	740-013110	000008	Power Inlet Module	
PEM 2					
PEM 3	Rev 01	740-013682	000038	PS 1.7kW; 200-240VAC in	
Routing Engine 0	REV 00	740-015113	1000617944	RE-S-1300	
ad0	245 MB	SanDisk	SDCFB-256	111419E1805T1141	Compact Flash
ad2	38154 MB	FUJITSU	MHT2040BH	NROWT5925N77	Hard Disk
CB 0	REV 05	710-013725	JK6947	MX960 Test SCB	
FPC 4	REV 01	710-013305	JM7617	MX960 Test DPC	
CPU					
PIC 0		BUILTIN	BUILTIN	1x 10GE(LAN/WAN)	
PIC 1		BUILTIN	BUILTIN	10x 1GE	
FPC 7	REV 01	710-013305	JL9634	MX960 Test DPC	
CPU					
PIC 0		BUILTIN	BUILTIN	1x 10GE(LAN/WAN)	
Xcvr 0		NON-JNPR	MYBG65I82C	XFP-10G-SR	
PIC 1		BUILTIN	BUILTIN	10x 1GE	
Xcvr 1	REV 01	740-011782	P7N0368	SFP-SX	
Xcvr 4	REV 01	740-011782	P8J1W27	SFP-SX	
Xcvr 6	REV 01	740-011782	P8J1VSD	SFP-SX	
Xcvr 9	REV 01	740-011782	P8J1W25	SFP-SX	
Fan Tray 0					
Fan Tray 1					

show chassis hardware (T320 Router)

```
user@host> show chassis hardware
```

Hardware inventory:					
Item	Version	Part number	Serial number	Description	
Chassis			19093	T320	
Midplane	REV 04	710-004339	BC1436	T320 Backplane	
FPM GBUS	REV 03	710-004461	BC1407	T320 FPM Board	
FPM Display	REV 04	710-002897	BE0763	FPM Display	

CIP	REV 05	710-002895	BB2311	T Series CIP
PEM 0	Rev 01	740-004359	NB12546	Power Entry Module
SCG 0	REV 06	710-004455	AY4522	T320 Sonet
Clock Gen.				
Routing Engine 0				
CB 0	REV 13	710-002728	BC1577	unknown
Control Board				T Series
CB 1	REV 13	710-002728	BC1595	T Series
Control Board				
FPC 1	REV 09	710-007531	HS1572	FPC Type 2
CPU	REV 15	710-001726	HR8763	FPC CPU
PIC 0	REV 01	750-010618	CB5579	4x G/E SFP,
1000 BASE				
SFP 0	REV 01	740-007326	P5809Z1	SFP-SX
SFP 1	REV 01	740-007326	P4Q10XU	SFP-SX
SFP 2		NON-JNPR	RA45020031	SFP-SX
SFP 3		NON-JNPR	RA45020032	SFP-SX
PIC 1	REV 01	750-010618	CD9587	4x G/E SFP,
1000 BASE				
SFP 0		NON-JNPR	P5A08QZ	SFP-T
SFP 1	REV 01	740-007326	P4Q133K	SFP-SX
SFP 2	REV 01	740-007326	P5809YY	SFP-SX
SFP 3	REV 01	740-007327	4C81704	SFP-LX
MMB 1	REV 03	710-005555	HR9401	MMB-288mbit
PPB 0	REV 04	710-003758	HR2886	PPB Type 2
FPC 2	REV 07	710-005860	HP2392	FPC Type 1
CPU	REV 14	710-001726	HP7797	FPC CPU
PIC 0	REV 02	750-007643	HM0853	1x G/E QPP,
1000 BASE				
SFP 0	REV 01	740-007326	P11E9JJ	SFP-SX
MMB 1	REV 02	710-005555	HN2379	MMB-288mbit
PPB 0	REV 04	710-003758	HP8092	PPB Type 2
FPC 3	REV 07	710-005860	HP2393	FPC Type 1
CPU	REV 14	710-001726	HP0968	FPC CPU
PIC 0	REV 01	750-010240	CB5363	1x G/E SFP,
1000 BASE				
SFP 0	REV 01	740-007326	P4R0PNH	SFP-SX
PIC 1	REV 03	750-003034	HD2832	4x OC-3 SONET,
SMIR				
MMB 1	REV 02	710-005555	HN6307	MMB-288mbit
PPB 0	REV 04	710-003758	HP5051	PPB Type 2
FPC 4	REV 01	710-010845	JD3872	FPC Type 4
CPU	REV 02	710-011481	JB6042	FPC CPU
5	REV 01	710-005802	BC1566	FPC Type 2
CPU	REV 09	710-001726	AY4922	FPC CPU
PIC 0	REV 02	750-008155	BE2114	2x G/E QPP,
1000 BASE				
SFP 0	REV 01	740-007326	P4R0PMQ	SFP-SX
SFP 1	REV 01	740-007326	P4R0PN9	SFP-SX
PIC 1	REV 01	750-008155	BE2116	2x G/E QPP,
1000 BASE				
SFP 0	REV 01	740-007326	P4R0PNZ	SFP-SX
SFP 1		NON-JNPR	2908	SFP-T
MMB 1	REV 01	710-005555	AZ2246	MMB-288mbit
PPB 0	REV 03	710-003758	AY4839	PPB Type 2
FPC 7	REV 01	710-005803	AZ2123	FPC Type 3
...				

show chassis hardware user@host> **show chassis hardware**

(T640 Router)

Hardware inventory:

Item	Version	Part number	Serial number	Description
------	---------	-------------	---------------	-------------

Chassis			19182	T640
Midplane	REV 04	710-002726	AX5608	T640 Backplane
FPM GBUS	REV 02	710-002901	HE3064	T640 FPM Board
FPM Display	REV 02	710-002897	HE7864	FPM Display
CIP	REV 05	710-002895	HA5024	T Series CIP
PEM 0	Rev 02	740-029522	VH26235	AC PEM 10kW US
PEM 1	Rev 02	740-029522	VH26230	AC PEM 10kW US
SCG 0	REV 03	710-003423	HA4508	T640 Sonet Clock Gen.
Routing Engine 0	REV 02	740-005022	210865700483	RE-3.0 (RE-600)
CB 0	REV 01	710-002728	HD3044	T Series Control Board
FPC 2	REV 04	710-001721	HD5572	FPC Type 3
CPU	REV 06	710-001726	HA4712	FPC CPU
PIC 1	REV 03	750-009567	HV2331	1x 10GE(LAN),XENPAK
SFP 0	REV 01	740-009898	USC202R103	XENPAK-SR
PIC 2	REV 03	750-009567	HV2332	1x 10GE(LAN),XENPAK
SFP 0	REV 01	740-011268	USC202R112	XENPAK-ZR
PIC 3	REV 03	750-009567	HX4416	1x 10GE(LAN),XENPAK
SFP 0	REV 01	740-012056	434TC004	XENPAK-CX4
PIC 4	REV 03	750-009567	HX4420	1x 10GE(LAN),XENPAK
SFP 0	REV 01	740-012058	434TC124	XENPAK-LX4
FPC 5	REV 01	710-013553	JE4839	E2-FPC Type 1
CPU	REV 01	710-013569	JW9163	FPC CPU
PIC 0	REV 01	750-009567	HX4419	1x 10GE(LAN),XENPAK
SFP 0	REV 01	740-009898	USC202RT05	XENPAK-LR
PIC 1	REV 03	750-009567	HN7426	1x 10GE(LAN),XENPAK
SFP 0	REV 01	740-009550	03L90051	XENPAK-ER
PIC 2	REV 03	750-009467	HT7423	1x 10GE(LAN),XENPAK
SFP 0		NON-JNPR		UNKNOWN
PIC 3	REV 04	750-005100	AY4850	1x 10GE(LAN),DWDM
FPC 4	REV 01	710-010845	JD3872	FPC Type 4
CPU	REV 02	710-011481	JB6042	FPC CPU
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Fan Tray

show chassis hardware models (T640 Router)

```
user@host> show chassis hardware models
```

```
Hardware inventory:
```

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 04	710-002726		CHAS-BP-T640-S
FPM Display	REV 02	710-002897		CRAFT-T640-S
CIP	REV 05	710-002895		CIP-L-T640-S
PEM 0	Rev 01	740-002595		PWR-T-DC-S
SCG 0	REV 04	710-003423		SCG-T-S
SCG 1	REV 04	710-003423		SCG-T-S
Routing Engine 0	REV 01	740-005022		RE-600-2048-S
Routing Engine 1	REV 07	740-005022		RE-600-2048-S
CB 0	REV 06	710-002726		CHAS-BP-T640-S
CB 1	REV 06	710-002728		CB-L-T-S
FPC 5	REV 05	710-007527		T640-FPC2
PIC 0	REV 05	750-002510		PB-2GE-SX
PIC 1	REV 05	750-001901		PB-40C12-SON-SMIR
FPC 6	REV 03	710-001721		T640-FPC3
PIC 1	REV 01	750-009553		PC-40C48-SON-SFP
SIB 4	REV 02	750-005486		SIB-I-T640-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FAN-REAR-TX-T640-S

```

show chassis hardware extensive (T640 Router)
user@host> show chassis hardware extensive
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis
Jedec Code:   0x7fb0          EEPROM Version: 0x01
P/N:          .....         S/N:           .....
Assembly ID:  0x0507          Assembly Version: 00.00
Date:         00-00-0000      Assembly Flags:  0x00
Version:      .....
ID: Gibson LCC Chassis
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 01 ff 05 07 00 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x20: ff ff ff ff ff ff ff ff ff ff ff ff ff 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Midplane
REV 04      710-002726  AX5633
Jedec Code:  0x7fb0          EEPROM Version: 0x01
P/N:         710-002726.     S/N:           S/N AX5633.
Assembly ID:  0x0127          Assembly Version: 01.04
Date:         06-27-2001      Assembly Flags:  0x00
Version:      REV 04.....
ID: Gibson Backplane
Board Information Record:
Address 0x00: ad 01 08 00 00 90 69 0e f8 00 ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 01 ff 01 27 01 04 52 45 56 20 30 34 00 00
Address 0x10: 00 00 00 00 37 31 30 2d 30 30 32 37 32 36 00 00
Address 0x20: 53 2f 4e 20 41 58 35 36 33 33 00 00 00 00 1b 06 07
Address 0x30: d1 ff ff ff ad 01 08 00 00 90 69 0e f8 00 ff ff
Address 0x40: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
FPM GBUS      REV 02      710-002901  HE3245
...
FPM Display   REV 02      710-002897  HA4873
...
CIP           REV 05      710-002895  HA4729
...
PEM 1         RevX02     740-002595  MD21815      Power Entry Module
...
SCG 0         REV 04      710-003423  HF6023
...
SCG 1         REV 04      710-003423  HF6061
...
Routing Engine 0 REV 01      740-005022  210865700292 RE-3.0
...
CB 0          REV 06      710-002728  HE3614
...
FPC 1         REV 01      710-002385  HE3009      FPC Type 1
...
              REV 06      710-001726  HC0010

show chassis hardware lcc (TX Matrix Router)
user@host> show chassis hardware lcc 0
lcc0-re0:
-----
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis
Midplane      REV 03      710-005608  RA1408        T640 Backplane
FPM GBUS      REV 09      710-002901  RA2784        T640 FPM Board
FPM Display   REV 05      710-002897  RA2825        FPM Display

```

CIP	REV 06	710-002895	HT0684	T Series CIP
PEM 0	Rev 11	740-002595	PM18483	Power Entry Module
PEM 1	Rev 11	740-002595	qb13984	Power Entry Module
SCG 0	REV 11	710-003423	HT0022	T640 Sonet Clock Gen.
Routing Engine 0	REV 13	740-005022	210865700363	RE-3.0 (RE-600)
CB 0	REV 03	710-007655	HW1195	Control Board (CB-T)
FPC 1	REV 05	710-007527	HM3245	FPC Type 2
CPU	REV 14	710-001726	HM1084	FPC CPU
PIC 0	REV 02	750-007218	AZ1112	2x OC-12 ATM2 IQ, SMIR
PIC 1	REV 02	750-007745	HG3462	4x OC-3 SONET, SMIR
PIC 2	REV 14	750-001901	BA5390	4x OC-12 SONET, SMIR
PIC 3	REV 09	750-008155	HS3012	2x G/E IQ, 1000 BASE
SFP 0		NON-JNPR	P1186TY	SFP-S
SFP 1	REV 01	740-007326	P11WLTf	SFP-SX
MMB 1	REV 02	710-005555	HL7514	MMB-288mbit
PPB 0	REV 04	710-003758	HM4405	PPB Type 2
PPB 1	REV 04	710-003758	AV1960	PPB Type 2
FPC 2	REV 08	710-010154	HZ3578	E-FPC Type 3
CPU	REV 05	710-010169	HZ3219	FPC CPU-Enhanced
PIC 0	REV 02	750-009567	HX2882	1x 10GE(LAN), XENPAK
SFP 0	REV 01	740-009898	USC202U709	XENPAK-LR
PIC 1	REV 03	750-003336	HJ9954	4x OC-48 SONET, SMSR
PIC 2	REV 01	750-004535	HC0235	1x OC-192 SM SR1
PIC 3	REV 07	750-007141	HX1699	10x 1GE(LAN), 1000 BASE
SFP 0	REV 01	740-007326	2441042	SFP-SX
SFP 1	REV 01	740-007326	2441027	SFP-SX
MMB 0	REV 03	710-010171	HV2365	MMB-5M3-288mbit
MMB 1	REV 03	710-010171	HZ3888	MMB-5M3-288mbit
SPMB 0	REV 09	710-003229	HW5245	T Series Switch CPU
SIB 3	REV 07	710-005781	HR5927	SIB-L8-F16
B Board	REV 06	710-005782	HR5971	SIB-L8-F16 (B)
SIB 4	REV 07	710-005781	HR5903	SIB-L8-F16
B Board	REV 06	710-005782	HZ5275	SIB-L8-F16 (B)

show chassis hardware user@host> **show chassis hardware scc**
scc (TX Matrix Router) scc-re0:

```
-----
```

Hardware inventory:				
Item	Version	Part number	Serial number	Description
Chassis				TX Matrix
Midplane	REV 04	710-004396	RB0014	SCC Midplane
FPM GBUS	REV 04	710-004617	HW9141	SCC FPM Board
FPM Display	REV 04	710-004619	HS5950	SCC FPM
CIP 0	REV 01	710-010218	HV9151	SCC CIP
CIP 1	REV 01	710-010218	HV9152	SCC CIP
PEM 1	Rev 11	740-002595	QB13977	Power Entry Module
Routing Engine 0	REV 05	740-008883	P11123900153	RE-4.0 (RE-1600)
CB 0	REV 01	710-011709	HR5964	Control Board (CB-TX)
SPMB 0	REV 09	710-003229	HW5293	T Series Switch CPU
SIB 3				
SIB 4	REV 01	710-005839	HW1177	SIB-S8-F16
B Board	REV 01	710-005840	HW1202	SIB-S8-F16 (B)

show chassis hardware user@host> **show chassis hardware**
(T1600 Router) Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			B2703	T1600
Midplane	REV 03	710-005608	RC4137	T640 Backplane
FPM GBUS	REV 10	710-002901	DT7062	T640 FPM Board
FPM Display	REV 05	710-002897	DS3067	FPM Display

CIP	REV 06	710-002895	DT3386	T-series CIP
PEM 0	Rev 07	740-017906	UA26344	Power Entry Module 3x80
PEM 1	Rev 18	740-002595	UF38441	Power Entry Module
SCG 0	REV 15	710-003423	DV0941	T640 Sonet Clock Gen.
Routing Engine 0	REV 08	740-014082	9009014502	RE-A-2000
Routing Engine 1	REV 07	740-014082	9009009591	RE-A-2000
CB 0	REV 05	710-007655	JA9360	Control Board (CB-T)
CB 1	REV 03	710-017707	DT3251	Control Board (CB-T)
FPC 0	REV 07	710-013558	DR4253	E2-FPC Type 2
CPU	REV 05	710-013563	DS3902	FPC CPU-Enhanced
PIC 0	REV 01	750-010618	CB5446	4x G/E SFP, 1000 BASE
Xcvr 0	REV 01	740-011613	P9F11CW	SFP-SX
Xcvr 1	REV 01	740-011613	P9F15C2	SFP-SX
Xcvr 2	REV 01	740-011782	PB94K0L	SFP-SX
PIC 1	REV 06	750-001900	HB6399	1x OC-48 SONET, SMSR
PIC 2	REV 14	750-001901	AP1092	4x OC-12 SONET, SMIR
PIC 3	REV 07	750-001900	AR8275	1x OC-48 SONET, SMSR
MMB 1	REV 07	710-010171	DS1524	MMB-5M3-288mbit
FPC 1	REV 06	710-013553	DL9067	E2-FPC Type 1
CPU	REV 04	710-013563	DM1685	FPC CPU-Enhanced
PIC 0	REV 08	750-001072	AB1688	1x G/E, 1000 BASE-SX
PIC 1	REV 10	750-012266	JX5519	4x 1GE(LAN), IQ2
Xcvr 0	REV 01	740-011613	AM0812S8UK6	SFP-SX
Xcvr 2	REV 01	740-011613	AM0812S8UK1	SFP-SX
Xcvr 3	REV 01	740-011782	P8N1YHG	SFP-SX
PIC 2	REV 22	750-005634	DP0083	1x CHOC12 IQ SONET, SMIR
MMB 1	REV 07	710-008923	DN1862	MMB 3M 288-bit
FPC 2	REV 01	710-005548	HJ9899	FPC Type 3
CPU	REV 06	710-001726	HC0586	FPC CPU
PIC 0	REV 16	750-007141	NC9660	10x 1GE(LAN), 1000 BASE
Xcvr 0	REV 01	740-011613	AM0812S8XAR	SFP-SX
Xcvr 1	REV 01	740-011782	P920E7B	SFP-SX
Xcvr 2	REV 01	740-011613	AM0812S8XAU	SFP-SX
Xcvr 4	REV 01	740-011613	AM0812S8XAK	SFP-SX
Xcvr 5	REV 01	740-011613	AM0812S8XAA	SFP-SX
Xcvr 6	REV 01	740-011613	PAJ4NKY	SFP-SX
Xcvr 7	REV 01	740-011613	AM0812S8UJW	SFP-SX
Xcvr 8	REV 01	740-011782	PB81X89	SFP-SX
Xcvr 9	REV 01	740-011613	AM0812S8UJX	SFP-SX
PIC 1	REV 06	750-015217	DK3280	8x 1GE(TYPE3), IQ2
Xcvr 0	REV 01	740-011782	P8POA3T	SFP-SX
Xcvr 1	REV 01	740-013111	5090002	SFP-T
Xcvr 2	REV 01	740-011613	AM0814S93BQ	SFP-SX
Xcvr 4		NON-JNPR	PDE0FAN	SFP-SX
Xcvr 5	REV 01	740-011782	P8Q20XY	SFP-SX
Xcvr 6	REV 01	740-011613	AM0812S8UJV	SFP-SX
Xcvr 7	REV 01	740-011613	AM0812S8UP7	SFP-SX
PIC 2	REV 05	750-004695	HT4383	1x Tunnel
PIC 3	REV 17	750-009553	RL0204	4x OC-48 SONET
Xcvr 0	REV 01	740-011785	PDS3T23	SFP-SR
Xcvr 1	REV 01	740-011785	P6Q0F3E	SFP-SR
MMB 0	REV 03	710-004047	HD5843	MMB-288mbit
MMB 1	REV 03	710-004047	HE3208	MMB-288mbit
PPB 0	REV 02	710-002845	HA4524	PPB Type 3
PPB 1	REV 02	710-002845	HA4766	PPB Type 3
FPC 3	REV 01	710-010154	HR0863	E-FPC Type 3
CPU	REV 01	710-010169	HN3422	FPC CPU-Enhanced
PIC 0	REV 07	750-012793	WF5096	1x 10GE(LAN/WAN) IQ2
Xcvr 0		NON-JNPR	M64294TP	XFP-10G-LR

PIC 1	REV 25	750-007141	DV2127	10x 1GE(LAN), 1000 BASE
Xcvr 0	REV 01	740-011613	PFA6LTJ	SFP-SX
Xcvr 1	REV 01	740-011782	P9P0XV4	SFP-SX
Xcvr 2	REV 01	740-011782	P9M0TNX	SFP-SX
Xcvr 4	REV 01	740-011782	P9B0TTP	SFP-SX
Xcvr 5		NON-JNPR	PBS4LED	SFP-SX
PIC 2	REV 17	750-009553	RL0212	4x OC-48 SONET
Xcvr 0	REV 01	740-011785	PDS3T8G	SFP-SR
PIC 3	REV 32	750-003700	DL1279	1x OC-192 12xMM VSR
MMB 0	REV 01	710-010171	HR0821	MMB-288mbit
MMB 1	REV 01	710-010171	HR0818	MMB-288mbit
FPC 4	REV 16	710-013037	EB4919	FPC Type 4-ES
CPU	REV 09	710-016744	BBAA4382	ST-PMB2
PIC 0	REV 03	711-029996	EB1569	100GE
PIC 1	REV 05	711-029999	EB9983	100GE CFP
Xcvr 0	REV 0	740-032210	J10G80746	CFP-100G-LR4
BRIDGE 0	REV 02	711-029995	EB2235	100GE Bridge Board
MMB 0	REV 04	710-025563	BBAA7112	ST-MMB2
MMB 1	REV 04	710-025563	BBAA7149	ST-MMB2
FPC 5	REV 02	710-013037	DE3407	FPC Type 4-ES
CPU	REV 04	710-016744	DA2124	ST-PMB2
PIC 0	REV 16	750-012518	DF2554	4x OC-192 SONET XFP
Xcvr 0	REV 01	740-014279	AA0745N1FX8	XFP-OC192-SR
Xcvr 1	REV 01	740-014279	AA0748N1HN5	XFP-OC192-SR
Xcvr 2	REV 01	740-014279	AA0748N1HT6	XFP-OC192-SR
Xcvr 3	REV 01	740-014279	AA0744N1EC9	XFP-OC192-SR
PIC 1	REV 01	750-010850	JA0329	1x OC-768 SONET SR
MMB 0	REV 04	710-016036	DE9577	ST-MMB2
MMB 1	REV 04	710-016036	DK4060	ST-MMB2
FPC 6	REV 14	710-013037	DV1431	FPC Type 4-ES
CPU	REV 09	710-016744	DT9020	ST-PMB2
PIC 0	REV 11	750-017405	DM6261	4x 10GE (LAN/WAN) XFP
Xcvr 0	REV 01	740-014289	C701XU05Q	XFP-10G-SR
Xcvr 1	REV 01	740-014279	AA0748N1HPT	XFP-10G-LR
Xcvr 2	REV 01	740-014289	T08E19189	XFP-10G-SR
Xcvr 3	REV 01	740-014289	C715XU058	XFP-10G-SR
PIC 1	REV 13	750-017405	DP8772	4x 10GE (LAN/WAN) XFP
Xcvr 0	REV 02	740-011571	C850XJ037	XFP-10G-SR
Xcvr 1	REV 02	740-014289	C839XU0L9	XFP-10G-SR
Xcvr 2	REV 02	740-014289	C834XU05A	XFP-10G-SR
Xcvr 3	REV 02	740-014289	C810XU0CE	XFP-10G-SR
MMB 0	REV 01	710-025563	DT8454	ST-MMB2
MMB 1	REV 01	710-025563	DT8366	ST-MMB2
FPC 7	REV 09	710-007529	HZ7624	FPC Type 3
CPU	REV 15	710-001726	HZ1413	FPC CPU
PIC 0	REV 10	750-012793	DM5627	1x 10GE(LAN/WAN) IQ2
Xcvr 0	REV 02	740-011571	C831XJ062	XFP-10G-SR
PIC 1	REV 01	750-015217	JT6762	8x 1GE(TYPE3), IQ2
Xcvr 0	REV 01	740-011782	P8Q25JU	SFP-SX
Xcvr 1	REV 01	740-011782	P9B0U0K	SFP-SX
PIC 2	REV 01	750-015217	JS4268	8x 1GE(TYPE3), IQ2
Xcvr 0	REV 01	740-011613	AM0812S8XBZ	SFP-SX
Xcvr 1	REV 01	740-011613	AM0812S8XAP	SFP-SX
Xcvr 2	REV 01	740-011613	AM0812S8XBY	SFP-SX
Xcvr 3	REV 01	740-011613	AM0812S8XBX	SFP-SX
Xcvr 4	REV 01	740-011613	P9F1652	SFP-SX
Xcvr 5	REV 01	740-011782	P8Q21YC	SFP-SX
Xcvr 6	REV 01	740-011782	P8Q27HQ	SFP-SX
Xcvr 7	REV 01	740-011613	P8E2SSU	SFP-SX
PIC 3	REV 15	750-009450	NB6790	1x OC-192 SM SR2

MMB 0	REV 03	710-005555	HZ3450	MMB-288mbit
MMB 1	REV 03	710-005555	HZ3415	MMB-288mbit
PPB 0	REV 04	710-002845	HP0887	PPB Type 3
PPB 1	REV 04	710-002845	HW5255	PPB Type 3
SPMB 0	REV 10	710-003229	HX3699	T-series Switch CPU
SPMB 1	REV 12	710-003229	DT3091	T-series Switch CPU
SIB 0	REV 07	710-013074	DS4747	SIB-I8-SF
SIB 1	REV 07	710-013074	DS4942	SIB-I8-SF
SIB 2	REV 07	710-013074	DS4965	SIB-I8-SF
SIB 3	REV 07	710-013074	DS4990	SIB-I8-SF
SIB 4	REV 07	710-013074	DS4944	SIB-I8-SF
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Fan Tray -- Rev 2

show chassis hardware (TX Matrix Plus Router)

user@host> show chassis hardware
sfc0-re0:

```
-----
Hardware inventory:
Item                Version  Part number  Serial number  Description
Chassis              REV 05    710-022574   TS3822         TXP
Midplane              REV 03    710-024027   DW4701         SFC Midplane
FPM Display           REV 05    710-023792   DW7998         TXP FPM Display
CIP 0                 REV 05    710-023792   DW7999         TXP CIP
CIP 1                 REV 05    710-023792   DW7999         TXP CIP
PEM 0                 Rev 04    740-027463   UM26367        Power Entry Module
PEM 1                 Rev 04    740-027463   UM26346        Power Entry Module
Routing Engine 0      REV 06    740-026942   737A-1081      RE-DUO-2600
Routing Engine 1      REV 06    740-026942   737A-1043      RE-DUO-2600
CB 0                  REV 05    710-022606   DW4435         SFC Control Board
CB 1                  REV 09    710-022606   DW6100         SFC Control Board
SPMB 0                BUILTIN                                     SFC Switch CPU
SPMB 1                BUILTIN                                     SFC Switch CPU
SIB F13 0             REV 04    750-024564   DW5764         F13 SIB
  B Board              REV 03    710-023431   DW9053         F13 SIB Mezz
SIB F13 3             REV 04    750-024564   DW5785         F13 SIB
  B Board              REV 03    710-023431   DW9030         F13 SIB Mezz
SIB F13 6
SIB F13 8             REV 04    750-024564   DW5752         F13 SIB
  B Board              REV 03    710-023431   DW9051         F13 SIB Mezz
SIB F13 11            REV 04    750-024564   DW5782         F13 SIB
  B Board              REV 03    710-023431   DW9058         F13 SIB Mezz
SIB F13 12            REV 03    750-024564   DT9466         F13 SIB
  B Board              REV 02    710-023431   DT6556         F13 SIB Mezz
SIB F2S 0/0           REV 05    710-022603   DW7898         F2S SIB
  B Board              REV 05    710-023787   DW7625         F2S SIB Mezz
SIB F2S 0/2           REV 05    710-022603   DW7811         F2S SIB
  B Board              REV 05    710-023787   DW7550         F2S SIB Mezz
SIB F2S 0/4           REV 04    710-022603   DW4873         F2S SIB
  B Board              REV 05    710-023787   DW8509         F2S SIB Mezz
SIB F2S 0/6           REV 04    710-022603   DW4867         F2S SIB
  B Board              REV 05    710-023787   DW8472         F2S SIB Mezz
SIB F2S 1/0           REV 04    710-022603   DW4871         F2S SIB
  B Board              REV 05    710-023787   DW8497         F2S SIB Mezz
SIB F2S 1/2           REV 05    710-022603   DW7868         F2S SIB
  B Board              REV 05    710-023787   DW7551         F2S SIB Mezz
SIB F2S 1/4           REV 04    710-022603   DW4854         F2S SIB
  B Board              REV 05    710-023787   DW8496         F2S SIB Mezz
SIB F2S 1/6           REV 05    710-022603   DW7889         F2S SIB
  B Board              REV 05    710-023787   DW7496         F2S SIB Mezz
SIB F2S 2/0           REV 04    710-022603   DW4852         F2S SIB
```

B Board	REV 05	710-023787	DW8498	F2S SIB Mezz
SIB F2S 2/2	REV 04	710-022603	DW4845	F2S SIB
B Board	REV 05	710-023787	DW8457	F2S SIB Mezz
SIB F2S 2/4	REV 05	710-022603	DW7802	F2S SIB
B Board	REV 05	710-023787	DW7562	F2S SIB Mezz
SIB F2S 2/6	REV 04	710-022603	DW4822	F2S SIB
B Board	REV 05	710-023787	DW8467	F2S SIB Mezz
SIB F2S 3/0	REV 05	710-022603	DW7815	F2S SIB
B Board	REV 05	710-023787	DW7518	F2S SIB Mezz
SIB F2S 3/2	REV 03	710-022603	DV0068	F2S SIB
B Board	REV 03	710-023787	DT9974	F2S SIB Mezz
SIB F2S 3/4	REV 05	710-022603	DW7874	F2S SIB
B Board	REV 05	710-023787	DW7601	F2S SIB Mezz
SIB F2S 3/6	REV 03	710-022603	DV0033	F2S SIB
B Board	REV 03	710-023787	DT9969	F2S SIB Mezz
SIB F2S 4/0	REV 03	710-022603	DV0043	F2S SIB
B Board	REV 03	710-023787	DT9948	F2S SIB Mezz
SIB F2S 4/2	REV 05	710-022603	DW5446	F2S SIB
B Board	REV 05	710-023787	DW7611	F2S SIB Mezz
SIB F2S 4/4	REV 04	710-022603	DW4826	F2S SIB
B Board	REV 05	710-023787	DW8458	F2S SIB Mezz
SIB F2S 4/6	REV 03	710-022603	DV0026	F2S SIB
B Board	REV 03	710-023787	DT9963	F2S SIB Mezz
Fan Tray 0	REV 02	760-024497	DR8290	Front Fan Tray
Fan Tray 1	REV 02	760-024497	DR8293	Front Fan Tray
Fan Tray 2	REV 05	760-024502	DR8280	Rear Fan Tray
Fan Tray 3				
Fan Tray 4	REV 05	760-024502	DR8276	Rear Fan Tray
Fan Tray 5	REV 02	760-024502	DP5643	Rear Fan Tray

lcc0-re0:

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN11036F8AHA	T1600
Midplane	REV 03	710-017247	RC3799	T-series Backplane
FPM GBUS	REV 10	710-002901	DP7009	T640 FPM Board
FPM Display	REV 01	710-021387	DN7026	T1600 FPM Display
CIP	REV 06	710-002895	DP6024	T-series CIP
PEM 1	Rev 02	740-023211	WA50019	Power Entry Module 4x60A
SCG 0	REV 15	710-003423	DR6757	T640 Sonet Clock Gen.
SCG 1	REV 15	710-003423	DS2225	T640 Sonet Clock Gen.
Routing Engine 0	REV 01	740-026941	737F-1040	RE-DUO-1800
Routing Engine 1	REV 01	740-026941	737F-1016	RE-DUO-1800
CB 0	REV 06	710-022597	DX4011	LCC Control Board
CB 1	REV 06	710-022597	DX4017	LCC Control Board
FPC 1	REV 07	710-013035	DN5847	FPC Type 3-ES
CPU	REV 08	710-016744	DP2570	ST-PMB2
PIC 0	REV 05	750-015217	DB0418	8x 1GE(TYPE3), IQ2
Xcvr 0	REV 01	740-011782	P8Q27ZG	SFP-SX
Xcvr 1		NON-JNPR	PDA1U0D	SFP-SX
Xcvr 2	REV 01	740-011613	P9F1ALW	SFP-SX
Xcvr 3	REV 01	740-011782	PBA403V	SFP-SX
Xcvr 4		NON-JNPR	PDE09DP	SFP-SX
Xcvr 5	REV 01	740-011782	PCH2P4K	SFP-SX
Xcvr 6	REV 01	740-011782	PB94K0F	SFP-SX
Xcvr 7	REV 01	740-011782	PBA2R2A	SFP-SX
PIC 1	REV 03	750-004424	HJ4020	1x 10GE(LAN),DWDM
PIC 2	REV 01	750-003336	HG6073	4x OC-48 SONET, SMSR
MMB 0	REV 04	710-016036	DP3401	ST-MMB2
FPC 3	REV 12	710-013037	DR1169	FPC Type 4-ES

CPU	REV 08	710-016744	DP9429	ST-PMB2
PIC 0	REV 02	750-010850	JA0332	1x OC-768 SONET SR
MMB 0	REV 04	710-016036	DR0628	ST-MMB2
MMB 1	REV 04	710-016036	DR0592	ST-MMB2
FPC 4	REV 05	710-021534	DR7350	FPC Type 1-ES
CPU	REV 08	710-016744	DP8096	ST-PMB2
PIC 0	REV 04	750-014627	DP9171	4x OC-3 1x OC-12 SFP
Xcvr 0	REV 02	740-011615	PDE2RVR	SFP-SR
PIC 1	REV 22	750-005634	DS5815	1x CHOC12 IQ SONET, SMIR
PIC 2	REV 09	750-002911	CF4539	4x F/E, 100 BASE-TX
PIC 3	REV 08	750-021652	DR2827	1x CHOC12 IQE SONET
Xcvr 0		NON-JNPR	8	UNKNOWN
MMB 0	REV 04	710-016036	DR0809	ST-MMB2
FPC 5	REV 07	710-007529	HS5608	FPC Type 3
CPU	REV 15	710-001726	HX4351	FPC CPU
PIC 0	REV 14	750-009567	WJ8961	1x 10GE(LAN), XENPAK
Xcvr 0	REV 01	740-013170	J05K05961	XENPAK-LR
PIC 1	REV 16	750-007141	JJ8146	10x 1GE(LAN), 1000 BASE
Xcvr 1	REV 01	740-011613	P9F117T	SFP-SX
Xcvr 2	REV 01	740-011782	PBA2VCL	SFP-SX
Xcvr 3	REV 01	740-011782	PB83DRB	SFP-SX
Xcvr 4	REV 01	740-011613	AM0812S8UP8	SFP-SX
PIC 2	REV 12	750-009567	WF3566	1x 10GE(LAN), XENPAK
Xcvr 0	REV 02	740-013170	T07C94489	XENPAK-LR
MMB 0	REV 03	710-005555	HZ1907	MMB-288mbit
MMB 1	REV 03	710-005555	HW5283	MMB-288mbit
PPB 0	REV 04	710-002845	HZ7717	PPB Type 3
PPB 1	REV 04	710-002845	HS0110	PPB Type 3
FPC 6	REV 07	710-013035	DP7486	FPC Type 3-ES
CPU	REV 08	710-016744	DP2545	ST-PMB2
PIC 0	REV 09	750-009567	NE6323	1x 10GE(LAN), XENPAK
Xcvr 0	REV 02	740-013170	T09C71959	XENPAK-LR
PIC 1	REV 06	750-015217	DN4775	8x 1GE(TYPE3), IQ2
Xcvr 0	REV 01	740-011782	P7E0T6M	SFP-SX
Xcvr 1	REV 01	740-011613	AM0812S8XAY	SFP-SX
Xcvr 2	REV 01	740-011782	P7E0T6J	SFP-SX
Xcvr 3	REV 01	740-011782	PCH2P7D	SFP-SX
Xcvr 4	REV 01	740-011782	P9B0QYT	SFP-SX
Xcvr 5	REV 01	740-011613	AM0812S8WQJ	SFP-SX
Xcvr 6	REV 02	740-013111	9301220	SFP-T
Xcvr 7	REV 01	740-011782	P9B0TZ5	SFP-SX
PIC 2	REV 06	750-015217	DM6747	8x 1GE(TYPE3), IQ2
Xcvr 0	REV 01	740-011613	PAP0ZB2	SFP-SX
Xcvr 1	REV 01	740-013111	70191002	SFP-T
Xcvr 6	REV 01	740-011782	PBA29H8	SFP-SX
Xcvr 7	REV 01	740-011613	AM0812S8WQG	SFP-SX
MMB 0	REV 04	710-016036	DP3238	ST-MMB2
FPC 7	REV 03	710-021540	DV3154	FPC Type 2-ES
CPU	REV 09	710-016744	DT9053	ST-PMB2
PIC 0	REV 13	750-001901	HB4225	4x OC-12 SONET, SMIR
PIC 1	REV 05	750-001900	AD3644	1x OC-48 SONET, SMSR
PIC 2	REV 10	750-008155	HV0335	2x G/E IQ, 1000 BASE
Xcvr 0	REV 01	740-011782	PCH2UKF	SFP-SX
Xcvr 1	REV 01	740-011782	PCH2V19	SFP-SX
PIC 3	REV 03	750-014638	JS9493	1x OC-48-12-3 SFP
Xcvr 0	REV 01	740-011785	P6Q0ENK	SFP-SR
MMB 0	REV 05	710-016036	DP3323	ST-MMB2
SPMB 0	REV 04	710-023321	DX3004	LCC Switch CPU
SPMB 1	REV 04	710-023321	DX3009	LCC Switch CPU

SIB 0	REV 07	710-022594	DW4195	LCC SIB
B Board	REV 07	710-023185	DW3930	LCC SIB Mezz
SIB 1	REV 07	710-022594	DW4179	LCC SIB
B Board	REV 07	710-023185	DW3919	LCC SIB Mezz
SIB 2				
SIB 3	REV 06	710-022594	DT8251	LCC SIB
B Board	REV 06	710-023185	DT5792	LCC SIB Mezz
SIB 4	REV 08	710-022594	DW8014	LCC SIB
B Board	REV 07	710-023185	DW3917	LCC SIB Mezz
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Fan Tray -- Rev 3

lcc1-re0:

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN1102270AHA	T1600
Midplane	REV 04	710-017247	RC5358	T-series Backplane
FPM GBUS	REV 10	710-002901	DS3443	T640 FPM Board
FPM Display	REV 01	710-021387	DS6411	T1600 FPM Display
CIP	REV 06	710-002895	DS4235	T-series CIP
PEM 0	Rev 02	740-023211	VM82438	Power Entry Module 4x60A
SCG 0	REV 15	710-003423	DS6649	T640 Sonet Clock Gen.
SCG 1	REV 15	710-003423	DR6775	T640 Sonet Clock Gen.
Routing Engine 0	REV 01	740-026941	737F-1083	RE-DUO-1800
Routing Engine 1	REV 01	740-026941	737F-1104	RE-DUO-1800
CB 0	REV 06	710-022597	DW8542	LCC Control Board
CB 1	REV 06	710-022597	DW8530	LCC Control Board
FPC 0	REV 02	710-010845	JE2392	FPC Type 4
CPU	REV 02	710-011481	JF6820	FPC CPU-Enhanced
PIC 0	REV 11	750-017405	DP7259	4x 10GE (LAN/WAN) XFP
Xcvr 0	REV 01	740-014279	AA0741N1C8T	XFP-10G-LR
Xcvr 1	REV 01	740-014279	AA0746N1GAM	XFP-10G-LR
Xcvr 2	REV 01	740-014279	AA0747N1H0B	XFP-10G-LR
Xcvr 3	REV 01	740-014279	AA0748N1HZ5	XFP-10G-LR
MMB 0	REV 03	710-010842	HY7601	ST-MMB
FPC 1	REV 16	710-013037	BBAA7398	FPC Type 4-ES
CPU	REV 09	710-016744	BBAA2329	ST-PMB2
PIC 0	REV 03	711-029996	EB1575	100GE
PIC 1	REV 06	750-034781	EB9980	100GE CFP
MMB 0	REV 04	710-025563	BBAA5325	ST-MMB2
MMB 1	REV 04	710-025563	BBAA5444	ST-MMB2
FPC 2	REV 16	710-013037	BBAA7185	FPC Type 4-ES
CPU	REV 09	710-016744	BBAA3522	ST-PMB2
PIC 0	REV 03	711-029996	EB1557	100GE
PIC 1	REV 05	750-034781	EB4660	100GE CFP
Xcvr 0	REV 0	740-032210	J10F73666	CFP-100G-LR4
BRIDGE 0	REV 02	711-029995	EB2237	100GE Bridge Board
MMB 0	REV 04	710-025563	BBAA5347	ST-MMB2
MMB 1	REV 04	710-025563	BBAA5401	ST-MMB2
FPC 3	REV 10	710-021534	DZ0941	FPC Type 1-ES
CPU	REV 09	710-016744	DY6364	ST-PMB2
PIC 0	REV 13	750-012266	DK9192	4x 1GE(LAN), IQ2
Xcvr 0	REV 01	740-011613	AM0812S8WVD	SFP-SX
Xcvr 1		NON-JNPR	PDD63Q4	SFP-SX
Xcvr 2		NON-JNPR	PDE4G54	SFP-SX
Xcvr 3		NON-JNPR	PD40MAG	SFP-SX
PIC 1	REV 01	750-007641	HJ2003	1x G/E IQ, 1000 BASE
Xcvr 0	REV 01	740-011613	AM0812S8WVG	SFP-SX
PIC 3	REV 17	750-007444	JB6873	1x CHSTM1 IQ SDH, SMIR

MMB 0	REV 04	710-025563	DZ0281	ST-MMB2
FPC 4	REV 06	710-013035	DK0614	FPC Type 3-ES
CPU	REV 07	710-016744	DK1616	ST-PMB2
PIC 0	REV 22	750-007141	DM1870	10x 1GE(LAN), 1000 BASE
Xcvr 0	REV 01	740-011782	PCL3UKW	SFP-SX
Xcvr 1	REV 01	740-011782	P7E0T73	SFP-SX
Xcvr 2	REV 01	740-007326	P4TOWLR	SFP-SX
Xcvr 3	REV 01	740-011782	PAR1LRL	SFP-SX
Xcvr 4	REV 01	740-011782	P9MOU3Z	SFP-SX
Xcvr 5	REV 01	740-011782	P9MOU0C	SFP-SX
Xcvr 6	REV 01	740-011782	P9M0TLG	SFP-SX
Xcvr 7	REV 01	740-011782	P9MOU0F	SFP-SX
Xcvr 8	REV 01	740-011613	PFA6LAP	SFP-SX
Xcvr 9	REV 01	740-011782	PCH2POU	SFP-SX
PIC 1	REV 16	750-009450	CV2565	1x OC-192 SM SR2
PIC 2	REV 05	750-004424	HH3057	1x 10GE(LAN),10GBASE-LR
PIC 3	REV 12	750-013423	DP0403	MultiServices 500
MMB 0	REV 04	710-016036	DK1988	ST-MMB2
FPC 5	REV 07	710-013560	DR0004	E2-FPC Type 3
CPU	REV 05	710-013563	DR0089	FPC CPU-Enhanced
PIC 0	REV 11	750-012793	DR6107	1x 10GE(LAN/WAN) IQ2
Xcvr 0	REV 01	740-014289	C743XU074	XFP-10G-SR
PIC 1	REV 01	750-004695	HD5980	1x Tunnel
PIC 2	REV 32	750-003700	DL3770	1x OC-192 12xMM VSR
PIC 3	REV 12	750-009553	WB8901	4x OC-48 SONET
Xcvr 0	REV 01	740-011785	P9D1GTQ	SFP-SR
Xcvr 1	REV 01	740-011785	PDSOMMB	SFP-SR
Xcvr 3	REV 01	740-011785	PDE1KXP	SFP-SR
MMB 0	REV 07	710-010171	DP7374	MMB-5M3-288mbit
MMB 1	REV 07	710-010171	DP7404	MMB-5M3-288mbit
FPC 6	REV 07	710-013035	DM0994	FPC Type 3-ES
CPU	REV 07	710-016744	DM3651	ST-PMB2
PIC 0	REV 07	750-015217	DN4743	8x 1GE(TYPE3), IQ2
Xcvr 3	REV 01	740-011613	AM0812S8XB0	SFP-SX
Xcvr 4	REV 01	740-011782	PB829RB	SFP-SX
Xcvr 5	REV 01	740-011782	P8J1SYX	SFP-SX
PIC 1	REV 03	750-003336	HJ9954	4x OC-48 SONET, SMSR
PIC 3	REV 02	750-012793	JM7665	1x 10GE(LAN/WAN) IQ2
MMB 0	REV 04	710-016036	DN6913	ST-MMB2
FPC 7	REV 08	710-010845	JM3958	FPC Type 4
CPU	REV 04	710-011481	JK3669	FPC CPU-Enhanced
PIC 0	REV 11	750-017405	DP8837	4x 10GE (LAN/WAN) XFP
Xcvr 1	REV 01	740-014279	753019A00277	XFP-10G-LR
Xcvr 2	REV 02	740-011571	C850XJ00P	XFP-10G-SR
Xcvr 3	REV 01	740-014279	AA0813N1RTG	XFP-10G-LR
MMB 0	REV 04	710-010842	JN1971	ST-MMB
SPMB 0	REV 04	710-023321	DW3629	LCC Switch CPU
SPMB 1	REV 04	710-023321	DW3621	LCC Switch CPU
SIB 0	REV 07	710-022594	DW4200	LCC SIB
B Board	REV 07	710-023185	DW3932	LCC SIB Mezz
SIB 1	REV 07	710-022594	DW4193	LCC SIB
B Board	REV 07	710-023185	DW3904	LCC SIB Mezz
SIB 2				
SIB 3	REV 07	710-022594	DW4210	LCC SIB
B Board	REV 06	710-023185	DT5780	LCC SIB Mezz
SIB 4	REV 08	710-022594	DW8019	LCC SIB
B Board	REV 06	710-023185	DT5795	LCC SIB Mezz
Fan Tray 0				Front Top Fan Tray

Fan Tray 1
Fan Tray 2

Front Bottom Fan Tray
Rear Fan Tray -- Rev 3

show chassis hardware
sfc (TX Matrix Plus

Router)

user@host> show chassis hardware sfc 0
sfc0-re0:

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN112F007AHB	TXP
Midplane	REV 05	710-022574	TS4027	SFC Midplane
FPM Display	REV 03	710-024027	DX0282	TXP FPM Display
CIP 0	REV 04	710-023792	DW4889	TXP CIP
CIP 1	REV 04	710-023792	DW4887	TXP CIP
PEM 0	Rev 07	740-027463	UM26368	Power Entry Module
Routing Engine 0	REV 01	740-026942	737A-1064	SFC RE
Routing Engine 1	REV 01	740-026942	737A-1082	SFC RE
CB 0	REV 09	710-022606	DW6099	SFC Control Board
CB 1	REV 09	710-022606	DW6096	SFC Control Board
SPMB 0		BUILTIN		SFC Switch CPU
SPMB 1		BUILTIN		SFC Switch CPU
SIB F13 0	REV 04	710-022600	DX0841	F13 SIB
B Board	REV 03	710-023431	DX0966	F13 SIB Mezz
SIB F13 1	REV 04	750-024564	DW5776	F13 SIB
B Board	REV 03	710-023431	DW9028	F13 SIB
SIB F13 3	REV 04	750-024564	DW5762	F13 SIB
B Board	REV 03	710-023431	DW9059	F13 SIB
SIB F13 4	REV 04	750-024564	DW5797	F13 SIB
B Board	REV 03	710-023431	DW9041	F13 SIB
SIB F13 6	REV 04	750-024564	DW5770	F13 SIB
B Board	REV 03	710-023431	DW9079	F13 SIB Mezz
SIB F13 7	REV 04	750-024564	DW5758	F13 SIB
B Board	REV 03	710-023431	DW9047	F13 SIB
SIB F13 8	REV 04	750-024564	DW5761	F13 SIB
B Board	REV 03	710-023431	DW9043	F13 SIB Mezz
SIB F13 9	REV 04	750-024564	DW5754	F13 SIB
B Board	REV 03	710-023431	DW9078	F13 SIB Mezz
SIB F13 11	REV 04	710-022600	DX0826	F13 SIB
B Board	REV 03	710-023431	DX0967	F13 SIB Mezz
SIB F13 12	REV 04	750-024564	DW5794	F13 SIB
B Board	REV 03	710-023431	DW9044	F13 SIB Mezz
SIB F2S 0/0	REV 05	710-022603	DW7897	F2S SIB
B Board	REV 05	710-023787	DW7657	NEO PMB
SIB F2S 0/2	REV 05	710-022603	DW7833	F2S SIB
B Board	REV 05	710-023787	DW7526	NEO PMB
SIB F2S 0/4	REV 05	710-022603	DW7875	F2S SIB
B Board	REV 05	710-023787	DW7588	NEO PMB
SIB F2S 0/6	REV 05	710-022603	DW7860	F2S SIB
B Board	REV 05	710-023787	DW7589	NEO PMB
SIB F2S 1/0	REV 04	710-022603	DW4820	F2S SIB
B Board	REV 05	710-023787	DW8510	NEO PMB
SIB F2S 1/2	REV 05	710-022603	DW7849	F2S SIB
B Board	REV 05	710-023787	DW7525	NEO PMB
SIB F2S 1/4	REV 05	710-022603	DW7927	F2S SIB
B Board	REV 05	710-023787	DW7556	F2S SIB Mezz
SIB F2S 1/6	REV 05	710-022603	DW7866	F2S SIB
B Board	REV 05	710-023787	DW7651	NEO PMB
SIB F2S 2/0	REV 05	710-022603	DW7880	F2S SIB
B Board	REV 05	710-023787	DW7523	NEO PMB
SIB F2S 2/2	REV 05	710-022603	DW7895	F2S SIB
B Board	REV 05	710-023787	DW7591	NEO PMB
SIB F2S 2/4	REV 05	710-022603	DW7907	F2S SIB

B Board	REV 05	710-023787	DW7590	NEO PMB
SIB F2S 2/6	REV 05	710-022603	DW7785	F2S SIB
B Board	REV 05	710-023787	DW7524	NEO PMB
SIB F2S 3/0	REV 05	710-022603	DW7782	F2S SIB
B Board	REV 05	710-023787	DW7634	NEO PMB
SIB F2S 3/2	REV 05	710-022603	DW7793	F2S SIB
B Board	REV 05	710-023787	DW7548	NEO PMB
SIB F2S 3/4	REV 05	710-022603	DW7779	F2S SIB
B Board	REV 05	710-023787	DW7587	NEO PMB
SIB F2S 3/6	REV 05	710-022603	DW7930	F2S SIB
B Board	REV 05	710-023787	DW7505	NEO PMB
SIB F2S 4/0	REV 05	710-022603	DW7867	F2S SIB
B Board	REV 05	710-023787	DW7656	NEO PMB
SIB F2S 4/2	REV 05	710-022603	DW7917	F2S SIB
B Board	REV 05	710-023787	DW7640	NEO PMB
SIB F2S 4/4	REV 05	710-022603	DW7929	F2S SIB
B Board	REV 05	710-023787	DW7643	NEO PMB
SIB F2S 4/6	REV 05	710-022603	DW7870	F2S SIB
B Board	REV 05	710-023787	DW7635	NEO PMB
Fan Tray 0	REV 06	760-024497	DV7831	Front Fan Tray
Fan Tray 1	REV 06	760-024497	DV9614	Front Fan Tray
Fan Tray 2	REV 06	760-024502	DV9618	Rear Fan Tray
Fan Tray 3	REV 06	760-024502	DV9616	Rear Fan Tray
Fan Tray 4	REV 06	760-024502	DV7807	Rear Fan Tray
Fan Tray 5	REV 06	760-024502	DV7828	Rear Fan Tray

show chassis hardware
extensive (TX Matrix
Plus Router)

user@host> show chassis hardware extensive
sfc0-re0:

```
-----
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis
Jedec Code:   0x7fb0          EEPROM Version: 0x02
S/N:          JN112F007AHB
Assembly ID:  0x052c          Assembly Version: 00.00
Date:         00-00-0000      Assembly Flags:  0x00
ID: TXP
Board Information Record:
Address 0x00: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
I2C Hex Data:
Address 0x00: 7f b0 02 ff 05 2c 00 00 00 00 00 00 00 00 00 00
Address 0x10: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x20: 4a 4e 31 31 32 46 30 30 37 41 48 42 00 00 00 00
Address 0x30: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x40: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Address 0x70: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Midplane      REV 05      710-022574      TS4027      SFC Midplane
Jedec Code:   0x7fb0          EEPROM Version: 0x01
P/N:          710-022574      S/N:          S/N TS4027
Assembly ID:  0x0962          Assembly Version: 01.05
Date:         03-23-2009      Assembly Flags:  0x00
Version:      REV 05
ID: SFC Midplane
Board Information Record:
Address 0x00: ad 01 ff ff 00 1d b5 14 00 00 ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 01 ff 09 62 01 05 52 45 56 20 30 35 00 00
Address 0x10: 00 00 00 00 37 31 30 2d 30 32 32 35 37 34 00 00
Address 0x20: 53 2f 4e 20 54 53 34 30 32 37 00 00 00 17 03 07
```

```

Address 0x30: d9 ff ff ff ad 01 ff ff 00 1d b5 14 00 00 ff ff
Address 0x40: ff ff ff ff 00 ff ff ff ff ff ff ff ff ff ff
Address 0x50: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x60: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
FPM Display      REV 03      710-024027      DX0282      TXP FPM Display
Jedec Code:      0x7fb0      EEPROM Version: 0x01
P/N:             710-024027   S/N:           S/N DX0282
Assembly ID:     0x096c      Assembly Version: 01.03
Date:           02-10-2009   Assembly Flags: 0x00
Version:         REV 03
ID: TXP FPM Display      FRU Model Number: CRAFT-TXP
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
I2C Hex Data:
Address 0x00: 7f b0 01 ff 09 6c 01 03 52 45 56 20 30 33 00 00
Address 0x10: 00 00 00 00 37 31 30 2d 30 32 34 30 32 37 00 00
Address 0x20: 53 2f 4e 20 44 58 30 32 38 32 00 00 00 0a 02 07
Address 0x30: d9 ff ff ff ff ff ff ff ff ff ff ff ff ff ff
Address 0x40: ff ff ff ff 01 00 00 00 00 00 00 00 00 00 00 43
Address 0x50: 52 41 46 54 2d 54 58 50 00 00 00 00 00 00 00 00
Address 0x60: 00 00 00 00 00 00 ff ff ff ff ff ff ff ff ff ff
Address 0x70: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
CIP 0            REV 04      710-023792      DW4889      TXP CIP
Jedec Code:      0x7fb0      EEPROM Version: 0x01
P/N:             710-023792   S/N:           S/N DW4889
Assembly ID:     0x0969      Assembly Version: 01.04
Date:           01-26-2009   Assembly Flags: 0x00
Version:         REV 04
ID: TXP CIP      FRU Model Number: CIP-TXP
Board Information Record:
Address 0x00: ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff

```

**show chassis hardware
clei-models (TX Matrix
Plus Router)**

```

user@host> show chassis hardware clei-models
sfc0-re0:

```

```

-----
Hardware inventory:

```

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 05	710-022574		CHAS-BP-TXP-S
FPM Display	REV 03	710-024027		CRAFT-TXP-S
CIP 0	REV 05	710-023792		CIP-TXP-S
CIP 1	REV 05	710-023792		CIP-TXP-S
PEM 0	Rev 04	740-027463	IPUPAFGKTA	PWR-TXP-7-60-DC
PEM 1	Rev 04	740-027463	IPUPAFGKTA	PWR-TXP-7-60-DC
Routing Engine 0	REV 06	740-026942		RE-DUO-C2600-16G-S
Routing Engine 1	REV 06	740-026942		RE-DUO-C2600-16G-S
CB 0	REV 05	710-022606		CB-TXP-S
CB 1	REV 09	710-022606		CB-TXP-S
SIB F13 0	REV 04	750-024564		SIB-TXP-F13
SIB F13 3	REV 04	750-024564		SIB-TXP-F13
SIB F13 8	REV 04	750-024564		SIB-TXP-F13
SIB F13 11	REV 04	750-024564		SIB-TXP-F13
SIB F13 12	REV 03	750-024564		SIB-TXP-F13
SIB F2S 0/0	REV 05	710-022603		SIB-TXP-F2S-S
SIB F2S 0/2	REV 05	710-022603		SIB-TXP-F2S-S
SIB F2S 0/4	REV 04	710-022603		SIB-TXP-F2S-S
SIB F2S 0/6	REV 04	710-022603		SIB-TXP-F2S-S
SIB F2S 1/0	REV 04	710-022603		SIB-TXP-F2S-S
SIB F2S 1/2	REV 05	710-022603		SIB-TXP-F2S-S
SIB F2S 1/4	REV 04	710-022603		SIB-TXP-F2S-S
SIB F2S 1/6	REV 05	710-022603		SIB-TXP-F2S-S

SIB F2S 2/0	REV 04	710-022603	SIB-TXP-F2S-S
SIB F2S 2/2	REV 04	710-022603	SIB-TXP-F2S-S
SIB F2S 2/4	REV 05	710-022603	SIB-TXP-F2S-S
SIB F2S 2/6	REV 04	710-022603	SIB-TXP-F2S-S
SIB F2S 3/0	REV 05	710-022603	SIB-TXP-F2S-S
SIB F2S 3/2	REV 03	710-022603	SIB-TXP-F2S-S
SIB F2S 3/4	REV 05	710-022603	SIB-TXP-F2S-S
SIB F2S 3/6	REV 03	710-022603	SIB-TXP-F2S-S
SIB F2S 4/0	REV 03	710-022603	SIB-TXP-F2S-S
SIB F2S 4/2	REV 05	710-022603	SIB-TXP-F2S-S
SIB F2S 4/4	REV 04	710-022603	SIB-TXP-F2S-S
SIB F2S 4/6	REV 03	710-022603	SIB-TXP-F2S-S
Fan Tray 0	REV 02	760-024497	FANTRAY-TXP-H-S
Fan Tray 1	REV 02	760-024497	FANTRAY-TXP-H-S
Fan Tray 2	REV 05	760-024502	FANTRAY-TXP-V-S
Fan Tray 3			
Fan Tray 4	REV 05	760-024502	FANTRAY-TXP-V-S
Fan Tray 5	REV 02	760-024502	FANTRAY-TXP-V-S

1cc0-re0:

Hardware inventory:

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 03	710-017247		CHAS-BP-T1600-S
FPM Display	REV 01	710-021387		CRAFT-T1600-S
CIP	REV 06	710-002895		CIP-L-T640-S
PEM 1	Rev 02	740-023211	IPUPAC8KTA	PWR-T1600-4-60-DC-S
SCG 0	REV 15	710-003423		SCG-T-S
SCG 1	REV 15	710-003423		SCG-T-S
Routing Engine 0	REV 01	740-026941		RE-DUO-C1800-8G-S
Routing Engine 1	REV 01	740-026941		RE-DUO-C1800-8G-S
CB 0	REV 06	710-022597		CB-LCC-S
CB 1	REV 06	710-022597		CB-LCC-S
FPC 1	REV 07	710-013035		T640-FPC3-ES
PIC 0	REV 05	750-015217		PC-8GE-TYPE3-SFP-IQ2
PIC 1	REV 03	750-004424		PC-1XGE-LR
PIC 2	REV 01	750-003336		PC-40C48-SON-SMSR
FPC 3	REV 12	710-013037		T1600-FPC4-ES
PIC 0	REV 02	750-010850		PD-10C768-SON-SR
FPC 4	REV 05	710-021534		T640-FPC1-ES
PIC 0	REV 04	750-014627		PB-40C3-10C12-SON-SFP
PIC 1	REV 22	750-005634		PB-1CHOC12SMIR-QPP
PIC 2	REV 09	750-002911		PB-4FE-TX
PIC 3	REV 08	750-021652		PB-1CHOC12-STM4-IQE-SFP
FPC 5	REV 07	710-007529		T640-FPC3
PIC 0	REV 14	750-009567		PC-1XGE-XENPAK
PIC 1	REV 16	750-007141		PC-10GE-SFP
PIC 2	REV 12	750-009567		PC-1XGE-XENPAK
FPC 6	REV 07	710-013035		T640-FPC3-ES
PIC 0	REV 09	750-009567		PC-1XGE-XENPAK
PIC 1	REV 06	750-015217		PC-8GE-TYPE3-SFP-IQ2
PIC 2	REV 06	750-015217		PC-8GE-TYPE3-SFP-IQ2
FPC 7	REV 03	710-021540		T640-FPC2-ES
PIC 0	REV 13	750-001901		PB-40C12-SON-SMIR
PIC 1	REV 05	750-001900		PB-10C48-SON-SMSR
PIC 2	REV 10	750-008155		PB-2GE-SFP-QPP
PIC 3	REV 03	750-014638		PB-10C48-SON-B-SFP
SIB 0	REV 07	710-022594		SIB-TXP-T1600-S
SIB 1	REV 07	710-022594		SIB-TXP-T1600-S
SIB 3	REV 06	710-022594		SIB-TXP-T1600-S
SIB 4	REV 08	710-022594		SIB-TXP-T1600-S

```

Fan Tray 0
Fan Tray 1
Fan Tray 2

```

FANTRAY-T-S
FANTRAY-T-S
FANTRAY-TXP-R-S

```
lcc1-re0:
```

```
-----
Hardware inventory:
```

Item	Version	Part number	CLEI code	FRU model number
Midplane	REV 04	710-017247		CHAS-BP-T1600-S
FPM Display	REV 01	710-021387		CRAFT-T1600-S
CIP	REV 06	710-002895		CIP-L-T640-S
PEM 0	Rev 02	740-023211	IPUPAC8KTA	PWR-T1600-4-60-DC-S
SCG 0	REV 15	710-003423		SCG-T-S
SCG 1	REV 15	710-003423		SCG-T-S
Routing Engine 0	REV 01	740-026941		RE-DUO-C1800-8G-S
Routing Engine 1	REV 01	740-026941		RE-DUO-C1800-8G-S
CB 0	REV 06	710-022597		CB-LCC-S
CB 1	REV 06	710-022597		CB-LCC-S
FPC 0	REV 02	710-010845		T640-FPC4-ES
PIC 0	REV 11	750-017405		PD-4XGE-XFP
FPC 1	REV 16	710-013037		T1600-FPC4-ES
PIC 1	REV 06	750-034781		PD-1CE-CFP
FPC 2	REV 16	710-013037		T1600-FPC4-ES
PIC 1	REV 05	750-034781		PD-1CE-CFP
FPC 3	REV 10	710-021534		T640-FPC1-ES
PIC 0	REV 13	750-012266		PB-4GE-TYPE1-SFP-IQ2
PIC 1	REV 01	750-007641		PE-1GE-SFP-QPP
PIC 3	REV 17	750-007444		PB-1CHSTM1-SMIR-QPP
FPC 4	REV 06	710-013035		T640-FPC3-ES
PIC 0	REV 22	750-007141		PC-10GE-SFP
PIC 1	REV 16	750-009450		PC-10C192-SON-SR2
PIC 2	REV 05	750-004424		PC-1XGE-LR
PIC 3	REV 12	750-013423		PC-MS-500-3
FPC 5	REV 07	710-013560		T640-FPC3-E2
PIC 0	REV 11	750-012793		PC-1XGE-TYPE3-XFP-IQ2
PIC 1	REV 01	750-004695		PC-TUNNEL
PIC 2	REV 32	750-003700		PC-10C192-SON-VSR
PIC 3	REV 12	750-009553		PC-40C48-SON-SFP
FPC 6	REV 07	710-013035		T640-FPC3-ES
PIC 0	REV 07	750-015217		PC-8GE-TYPE3-SFP-IQ2
PIC 1	REV 03	750-003336		PC-40C48-SON-SMSR
PIC 3	REV 02	750-012793		PC-1XGE-TYPE3-XFP-IQ2
FPC 7	REV 08	710-010845		T640-FPC4-ES
PIC 0	REV 11	750-017405		PD-4XGE-XFP
SIB 0	REV 07	710-022594		SIB-TXP-T1600-S
SIB 1	REV 07	710-022594		SIB-TXP-T1600-S
SIB 3	REV 07	710-022594		SIB-TXP-T1600-S
SIB 4	REV 08	710-022594		SIB-TXP-T1600-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FANTRAY-TXP-R-S

```

show chassis hardware
detail (TX Matrix Plus
Router)

```

```

user@host> show chassis hardware detail
sfc0-re0:

```

```
-----
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis			JN111B023AHB	TXP
Midplane	REV 01	710-022574	TR7990	SFC Midplane
FPM Display	REV 03	710-024027	DW4699	TXP FPM Display
CIP 0	REV 01	710-023792	DR1437	TXP CIP

CIP 1	REV 02	710-023792	DS4564	TXP CIP
PEM 0	Rev 07	740-027463	UM26360	Power Entry Module
Routing Engine 0	REV 01	740-026942	737A-1024	SFC RE
ad0 3887 MB	SMART CF		200811050193CEB1	Compact Flash
ad1 30533 MB	SAMSUNG	MCBQE32G8MPP-0V	SY814A0762	Disk 1
Routing Engine 1	REV 01	740-026942	737A-1024	SFC RE
ad0 3887 MB	SMART CF		20081105004C19A019A0	Compact Flash
ad1 30533 MB	SAMSUNG	MCBQE32G8MPP-0V	SY814A0794	Disk 1
CB 0	REV 03	710-022606	DR7134	SFC Control Board
CB 1	REV 01	710-022606	DP8890	SFC Control Board
SPMB 0		BUILTIN		SFC Switch CPU
SPMB 1		BUILTIN		SFC Switch CPU
SIB F13 0	REV 03	750-024564	DT9478	F13 SIB
B Board	REV 02	710-023431	DT6554	F13 SIB
SIB F13 1	REV 03	750-024564	DT9454	F13 SIB
B Board	REV 02	710-023431	DT6551	F13 SIB
SIB F2S 0/0	REV 02	710-022603	DT2838	F2S SIB
B Board	REV 02	710-023787	DT1725	NEO PMB
SIB F2S 0/2	REV 02	710-022603	DT2824	F2S SIB
B Board	REV 02	710-023787	DT1706	NEO PMB
SIB F2S 0/4	REV 02	710-022603	DT2822	F2S SIB
B Board	REV 02	710-023787	DT1696	NEO PMB
SIB F2S 0/6	REV 02	710-022603	DT2823	F2S SIB
B Board	REV 02	710-023787	DT1717	NEO PMB
SIB F2S 1/0	REV 03	710-022603	DV0059	F2S SIB
B Board	REV 03	710-023787	DT9942	NEO PMB
SIB F2S 1/2	REV 02	710-022603	DT2826	F2S SIB
B Board	REV 02	710-023787	DT1713	NEO PMB
SIB F2S 1/4	REV 03	710-022603	DV0092	F2S SIB
B Board	REV 03	710-023787	DV0000	NEO PMB
SIB F2S 1/6	REV 03	710-022603	DV0079	F2S SIB
B Board	REV 03	710-023787	DT9972	NEO PMB
SIB F2S 2/0	REV 03	710-022603	DV0100	F2S SIB
B Board	REV 03	710-023787	DT9925	NEO PMB
SIB F2S 2/2	REV 03	710-022603	DV0050	F2S SIB
B Board	REV 03	710-023787	DV0005	NEO PMB
SIB F2S 2/4	REV 03	710-022603	DV0097	F2S SIB
B Board	REV 03	710-023787	DT9936	NEO PMB
Fan Tray 0	REV 02	760-024497	DR8286	Front Fan Tray
Fan Tray 1	REV 06	760-024497	DV9624	Front Fan Tray
Fan Tray 2	REV 02	760-024502	DR8259	Rear Fan Tray
Fan Tray 3	REV 02	760-024502	DR8270	Rear Fan Tray
Fan Tray 4	REV 02	760-024502	DR8284	Rear Fan Tray
Fan Tray 5	REV 06	760-024502	DV7813	Rear Fan Tray

```
lcc0-re0:
```

```
-----
Hardware inventory:
```

Item	Version	Part number	Serial number	Description
Chassis			JN1101F27AHA	T1600
Midplane	REV 04	710-017247	RC5317	T Series Backplane
FPM GBUS	REV 10	710-002901	DS8197	T640 FPM Board
FPM Display	REV 01	710-021387	DS6433	T1600 FPM Display
CIP	REV 06	710-002895	DS1493	T Series CIP
PEM 0	Rev 08	740-017906	UD26601	Power Entry Module 3x80
SCG 0	REV 15	710-003423	DP5847	T640 Sonet Clock Gen.
SCG 1	REV 15	710-003423	DR0924	T640 Sonet Clock Gen.
Routing Engine 0	REV 01	740-026942	737F-1024	LCC RE
ad0 3887 MB	SMART CF		2008110502B63E513E51	Compact Flash
ad1 30533 MB	SAMSUNG	MCBQE32G8MPP-0V	SY814A1208	Disk 1
Routing Engine 1	REV 01	740-026942	737F-1024	LCC RE

ad0	3887 MB	SMART CF	2008110500F9A8A8A8A8	Compact Flash
ad1	30533 MB	SAMSUNG MCBQE32G8MPP-0V	SY814A1076	Disk 1
CB 0	REV 05	710-022597	DV4264	LCC Control Board
CB 1	REV 03	710-022597	DP8558	LCC Control Board
FPC 0	REV 14	710-013037	DS9967	FPC Type 4-ES
CPU	REV 08	710-016744	DS3989	ST-PMB2
PIC 0	REV 12	750-013198	DL7506	1x Tunnel
PIC 1	REV 12	750-013198	DL7505	1x Tunnel
MMB 0	REV 01	710-025563	DS8524	ST-MMB2
MMB 1	REV 01	710-025563	DS8373	ST-MMB2
FPC 1	REV 14	710-013037	DT0027	FPC Type 4-ES
CPU	REV 09	710-016744	DS7684	ST-PMB2
PIC 0	REV 12	750-013198	DL7512	1x Tunnel
PIC 1	REV 12	750-013198	DL7498	1x Tunnel
MMB 0	REV 01	710-025563	DS8494	ST-MMB2
MMB 1	REV 01	710-025563	DS8436	ST-MMB2
SPMB 0	REV 04	710-023321	DV3867	LCC Switch CPU
SPMB 1	REV 02	710-023321	DP0238	LCC Switch CPU
SIB 0	REV 06	710-022594	DT8268	LCC SIB
B Board	REV 06	710-023185	DT5791	LCC SIB Mezz
SIB 1	REV 06	710-022594	DT8261	LCC SIB
B Board	REV 06	710-023185	DT5769	LCC SIB Mezz
SIB 2	REV 04	710-022594	DS2315	LCC SIB
B Board	REV 06	710-023185	DT5788	LCC SIB Mezz
SIB 3	REV 06	710-022594	DT8253	LCC SIB
B Board	REV 06	710-023185	DT5811	LCC SIB Mezz
SIB 4	REV 06	710-022594	DT8248	LCC SIB
B Board	REV 06	710-023185	DT5812	LCC SIB Mezz
Fan Tray 0				Front Top Fan Tray
Fan Tray 1				Front Bottom Fan Tray
Fan Tray 2				Rear Fan Tray

show chassis hardware
models (TX Matrix
Plus Router)

```

user@host> show chassis hardware models
sfc0-re0:
-----
Hardware inventory:
Item          Version  Part number  Serial number  FRU model number
FPM Display   REV 03   710-024027   DX0282         CRAFT-TXP
CIP 0         REV 04   710-023792   DW4889         CIP-TXP
CIP 1         REV 04   710-023792   DW4887         CIP-TXP
PEM 0         Rev 07   740-027463   UM26368        yyyyyyyyyyyyyyyyyyyyyyy
Routing Engine 0 REV 01   740-026942   737A-1064      RE-TXP-SFC-DUO-2600-16G
Routing Engine 1 REV 01   740-026942   737A-1082      RE-TXP-SFC-DUO-2600-16G
CB 0          REV 09   710-022606   DW6099         CB-TXP
CB 1          REV 09   710-022606   DW6096         CB-TXP
SIB F13 1     REV 04   750-024564   DW5776         SIB-TXP-F13
SIB F13 3     REV 04   750-024564   DW5762         SIB-TXP-F13
SIB F13 4     REV 04   750-024564   DW5797         SIB-TXP-F13
SIB F13 6     REV 04   750-024564   DW5770         SIB-TXP-F13
SIB F13 7     REV 04   750-024564   DW5758         SIB-TXP-F13
SIB F13 8     REV 04   750-024564   DW5761         SIB-TXP-F13
SIB F13 9     REV 04   750-024564   DW5754         SIB-TXP-F13
SIB F13 12    REV 04   750-024564   DW5794         SIB-TXP-F13
SIB F2S 0/0   REV 05   710-022603   DW7897
SIB F2S 0/2   REV 05   710-022603   DW7833
SIB F2S 0/4   REV 05   710-022603   DW7875
SIB F2S 0/6   REV 05   710-022603   DW7860
SIB F2S 1/0   REV 04   710-022603   DW4820
SIB F2S 1/2   REV 05   710-022603   DW7849
SIB F2S 1/4   REV 05   710-022603   DW7927         SIB-TXP-F2S
SIB F2S 1/6   REV 05   710-022603   DW7866

```

SIB F2S 2/0	REV 05	710-022603	DW7880	
SIB F2S 2/2	REV 05	710-022603	DW7895	
SIB F2S 2/4	REV 05	710-022603	DW7907	
SIB F2S 2/6	REV 05	710-022603	DW7785	
SIB F2S 3/0	REV 05	710-022603	DW7782	
SIB F2S 3/2	REV 05	710-022603	DW7793	
SIB F2S 3/4	REV 05	710-022603	DW7779	
SIB F2S 3/6	REV 05	710-022603	DW7930	
SIB F2S 4/0	REV 05	710-022603	DW7867	
SIB F2S 4/2	REV 05	710-022603	DW7917	
SIB F2S 4/4	REV 05	710-022603	DW7929	
SIB F2S 4/6	REV 05	710-022603	DW7870	
Fan Tray 0	REV 06	760-024497	DV7831	FANTRAY-TXP-F
Fan Tray 1	REV 06	760-024497	DV9614	FANTRAY-TXP-F
Fan Tray 2	REV 06	760-024502	DV9618	FANTRAY-TXP-R
Fan Tray 3	REV 06	760-024502	DV9616	FANTRAY-TXP-R
Fan Tray 4	REV 06	760-024502	DV7807	FANTRAY-TXP-R
Fan Tray 5	REV 06	760-024502	DV7828	FANTRAY-TXP-R

lcc0-re0:

Hardware inventory:

Item	Version	Part number	Serial number	FRU model number
Midplane	REV 03	710-017247	RC3765	CHAS-BP-T1600-S
FPM Display	REV 01	710-021387	DN5441	CRAFT-T1600-S
CIP	REV 06	710-002895	DP6021	CIP-L-T640-S
PEM 0	Rev 07	740-017906	UA26384	PWR-T1600-3-80-DC-S
PEM 1	Rev 07	740-017906	UA26296	PWR-T1600-3-80-DC-S
SCG 0	REV 15	710-003423	DR0875	SCG-T-S
CB 0	REV 06	710-022597	DW8534	CB-LCC
CB 1	REV 06	710-022597	DW8527	CB-LCC
FPC 4	REV 12	710-013037	DJ8717	T1600-FPC4-ES
PIC 0	REV 11	750-017405	DP8795	PD-4XGE-XFP
PIC 1	REV 11	750-017405	DP8794	PD-4XGE-XFP
FPC 6	REV 14	710-013037	DS5335	T1600-FPC4-ES
PIC 0	REV 13	750-017405	DS7634	PD-4XGE-XFP
PIC 1	REV 13	750-017405	DS7637	PD-4XGE-XFP
FPC 7	REV 07	710-013035	DM0990	T1600-FPC3-ES
PIC 0	REV 16	750-007141	JJ8067	PC-10GE-SFP
PIC 1	REV 08	750-015749	WE9598	PC-10C192-SON-XFP
PIC 2	REV 10	750-009450	HX6466	PC-10C192-SON-SR2
SIB 0	REV 08	710-022594	DW8033	SIB-TXP-T1600-S
SIB 1	REV 08	710-022594	DW8044	SIB-TXP-T1600-S
SIB 2	REV 08	710-022594	DW8020	SIB-TXP-T1600-S
SIB 3	REV 08	710-022594	DW8063	SIB-TXP-T1600-S
SIB 4	REV 08	710-022594	DW8064	SIB-TXP-T1600-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FANTRAY-TXP-R-S

lcc1-re0:

Hardware inventory:

Item	Version	Part number	Serial number	FRU model number
Midplane	REV 04	710-017247	RC5361	CHAS-BP-T1600-S
FPM Display	REV 01	710-021387	DS6430	CRAFT-T1600-S
CIP	REV 06	710-002895	DS4239	CIP-L-T640-S
PEM 0	Rev 08	740-017906	UD26649	PWR-T1600-3-80-DC-S
SCG 0	REV 15	710-003423	DP5820	SCG-T-S
CB 0	REV 06	710-022597	DW8523	CB-LCC
CB 1	REV 06	710-022597	DW8528	CB-LCC

FPC 4	REV 12	710-013037	DP8509	T1600-FPC4-ES
PIC 0	REV 11	750-017405	DP8808	PD-4XGE-XFP
PIC 1	REV 11	750-017405	DP7263	PD-4XGE-XFP
FPC 6	REV 14	710-013037	DS9961	T1600-FPC4-ES
PIC 0	REV 13	750-017405	DS5532	PD-4XGE-XFP
PIC 1	REV 13	750-017405	DS7639	PD-4XGE-XFP
FPC 7	REV 03	710-013035	DF5564	T1600-FPC3-ES
PIC 0	REV 16	750-007141	JJ8063	PC-10GE-SFP
SIB 0	REV 08	710-022594	DW8035	SIB-TXP-T1600-S
SIB 1	REV 10	710-022594	DX7672	SIB-TXP-T1600-S
SIB 2	REV 08	710-022594	DW8060	SIB-TXP-T1600-S
SIB 3	REV 08	710-022594	DW8072	SIB-TXP-T1600-S
SIB 4	REV 08	710-022594	DW8043	SIB-TXP-T1600-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FANTRAY-TXP-R-S

```
lcc2-re0:
```

```
-----
Hardware inventory:
```

Item	Version	Part number	Serial number	FRU model number
Midplane	REV 03	710-017247	RC3956	CHAS-BP-T1600-S
FPM Display	REV 01	710-021387	DN7030	CRAFT-T1600-S
CIP	REV 06	710-002895	DM3962	CIP-L-T640-S
PEM 0	Rev 08	740-017906	UD26519	PWR-T1600-3-80-DC-S
PEM 1	Rev 07	740-017906	UC26601	PWR-T1600-3-80-DC-S
SCG 0	REV 15	710-003423	DP0277	SCG-T-S
CB 0	REV 06	710-022597	DW8524	CB-LCC
CB 1	REV 06	710-022597	DW8536	CB-LCC
FPC 4	REV 12	710-013037	DR1194	T1600-FPC4-ES
PIC 0	REV 11	750-017405	DP8811	PD-4XGE-XFP
PIC 1	REV 11	750-017405	DP8823	PD-4XGE-XFP
FPC 5	REV 12	710-013037	DR1184	T1600-FPC4-ES
PIC 1	REV 11	750-017405	DP4744	PD-4XGE-XFP
FPC 6	REV 12	710-013037	DN8622	T1600-FPC4-ES
PIC 0	REV 14	750-012518	JY9924	PD-40C192-SON-XFP
PIC 1	REV 11	750-017405	DP8776	PD-4XGE-XFP
FPC 7	REV 04	710-013560	JR3968	T640-FPC3-E2
PIC 0	REV 16	750-007141	NC9330	PC-10GE-SFP
SIB 0	REV 07	710-022594	DW4217	SIB-TXP-T1600-S
SIB 1	REV 07	710-022594	DW4213	SIB-TXP-T1600-S
SIB 2	REV 07	710-022594	DW4189	SIB-TXP-T1600-S
SIB 3	REV 07	710-022594	DW4173	SIB-TXP-T1600-S
SIB 4	REV 07	710-022594	DW4201	SIB-TXP-T1600-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FANTRAY-TXP-R-S

```
lcc3-re0:
```

```
-----
Hardware inventory:
```

Item	Version	Part number	Serial number	FRU model number
Midplane	REV 04	710-017247	RC5319	CHAS-BP-T1600-S
FPM Display	REV 01	710-021387	DS6402	CRAFT-T1600-S
CIP	REV 06	710-002895	DR9973	CIP-L-T640-S
PEM 0	Rev 07	740-017906	UC26496	PWR-T1600-3-80-DC-S
PEM 1	Rev 07	740-017906	UC26599	PWR-T1600-3-80-DC-S
SCG 0	REV 15	710-003423	DP5831	SCG-T-S
CB 0	REV 06	710-022597	DW8533	CB-LCC
CB 1	REV 06	710-022597	DW8538	CB-LCC
FPC 0	REV 14	710-013037	DS5345	T1600-FPC4-ES

PIC 0	REV 13	750-017405	DS7641	PD-4XGE-XFP
PIC 1	REV 13	750-017405	DS5479	PD-4XGE-XFP
FPC 1	REV 14	710-013037	DS7338	T1600-FPC4-ES
PIC 0	REV 13	750-017405	DS7631	PD-4XGE-XFP
PIC 1	REV 13	750-017405	DS7632	PD-4XGE-XFP
FPC 2	REV 14	710-013037	DS9962	T1600-FPC4-ES
PIC 0	REV 13	750-017405	DS7581	PD-4XGE-XFP
PIC 1	REV 13	750-017405	DS7627	PD-4XGE-XFP
FPC 4	REV 10	710-010845	JZ6573	T640-FPC4-ES
PIC 0	REV 14	750-012518	JT5124	PD-40C192-SON-XFP
FPC 5	REV 14	710-013037	DT0016	T1600-FPC4-ES
PIC 0	REV 14	750-012518	JY9918	PD-40C192-SON-XFP
FPC 7	REV 07	710-013035	DM0967	T1600-FPC3-ES
PIC 0	REV 16	750-007141	JJ8059	PC-10GE-SFP
PIC 1	REV 13	750-004695	DM5712	PC-TUNNEL
SIB 0	REV 07	710-022594	DW4174	SIB-TXP-T1600-S
SIB 1	REV 07	710-022594	DW4207	SIB-TXP-T1600-S
SIB 2	REV 06	710-022594	DT8231	SIB-TXP-T1600-S
SIB 3	REV 07	710-022594	DW4175	SIB-TXP-T1600-S
SIB 4	REV 07	710-022594	DW4209	SIB-TXP-T1600-S
Fan Tray 0				FANTRAY-T-S
Fan Tray 1				FANTRAY-T-S
Fan Tray 2				FANTRAY-TXP-R-S

show chassis hardware
(16-Port 10-Gigabit
Ethernet MPC with
SFP+ Optics [MX
Series Routers])

user@host> show chassis hardware

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN112D865AFA	MX960
Midplane	REV 03	710-013698	TS3339	MX960 Backplane
FPM Board	REV 03	710-014974	WW6267	Front Panel Display
PDM	Rev 03	740-013110	QCS12485026	Power Distribution
Module				
PEM 0	Rev 04	740-013682	QCS12434086	PS 1.7kW; 200-240VAC
in				
PEM 1	Rev 04	740-013682	QCS1243408Z	PS 1.7kW; 200-240VAC
in				
PEM 2	Rev 04	740-013682	QCS1243407X	PS 1.7kW; 200-240VAC
in				
Routing Engine 0	REV 07	740-015113	9009009677	RE-S-1300
Routing Engine 1	REV 07	740-015113	9009011510	RE-S-1300
CB 0	REV 03	710-021523	XF0394	MX SCB
CB 1	REV 03	710-021523	XF0550	MX SCB
CB 2	REV 03	710-021523	XD7455	MX SCB
FPC 4	REV 02	750-028467	JR6127	MPC M 16x 10GE
CPU	REV 02	711-029089	JX0129	AS PMB
PIC 0		BUILTIN	BUILTIN	4x 10GE(LAN) SFP+
PIC 1		BUILTIN	BUILTIN	4x 10GE(LAN) SFP+
PIC 2		BUILTIN	BUILTIN	4x 10GE(LAN) SFP+
PIC 3		BUILTIN	BUILTIN	4x 10GE(LAN) SFP+
Fan Tray 0	REV 05	740-014971	TP9990	Fan Tray
Fan Tray 1	REV 05	740-014971	VS1709	Fan Tray

show chassis hardware
(QFX Series)

user@switch> show chassis hardware

Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis				QFX3500
Routing Engine 0		BUILTIN	BUILTIN	QFX Routing Engine
FPC 0	REV 02	711-032234	EC4074	QFX 48x10G 4x40G Switch
CPU		BUILTIN	BUILTIN	FPC CPU

PIC 0		BUILTIN	BUILTIN	48x 10G-SFP+
PIC 1		BUILTIN	BUILTIN	15x 10G-SFP+
Power Supply 0	PSMI 2C	11-d65800	--	QFX PS 650W AC
Fan Tray				

show chassis hardware detail (QFX Series) user@switch> **show chassis hardware detail**
Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			JN000TEST5	QFX3500
Routing Engine 0		BUILTIN	BUILTIN	QFX Routing Engine
FPC 0	REV 05	750-036931	EE0823	QFX 48x10G 4x40G Switch

CPU		BUILTIN	BUILTIN	FPC CPU
PIC 0		BUILTIN	BUILTIN	48x 10G-SFP+
Xcvr 0	REV 01	740-030589	S99E270079	SFP+-10G-LPBK
Xcvr 1	REV 01	740-030589	S9AK450099	SFP+-10G-LPBK
Xcvr 2	REV 01	740-030589	S99E270078	SFP+-10G-LPBK
Xcvr 3	REV 01	740-030589	S9AK450098	SFP+-10G-LPBK
Xcvr 4	REV 01	740-030589	S99E270075	SFP+-10G-LPBK
Xcvr 5	REV 01	740-030589	S9AK450093	SFP+-10G-LPBK
Xcvr 6	REV 01	740-030589	S9AK450097	SFP+-10G-LPBK
Xcvr 7	REV 01	740-030589	S9AK450095	SFP+-10G-LPBK
Xcvr 8	REV 01	740-030589	S99E270072	SFP+-10G-LPBK
Xcvr 9	REV 01	740-030589	S99E270073	SFP+-10G-LPBK
Xcvr 10	REV 01	740-030589	S99E270080	SFP+-10G-LPBK
Xcvr 11	REV 01	740-030589	S9AK450169	SFP+-10G-LPBK
Xcvr 12	REV 01	740-030589	S99E270076	SFP+-10G-LPBK
Xcvr 13	REV 01	740-030589	S9AK450167	SFP+-10G-LPBK
Xcvr 14	REV 01	740-030589	S9AK450170	SFP+-10G-LPBK
Xcvr 15	REV 01	740-030589	S9AK450166	SFP+-10G-LPBK
Xcvr 16	REV 01	740-030589	S9AK450092	SFP+-10G-LPBK
Xcvr 17	REV 01	740-030589	S9AK450163	SFP+-10G-LPBK
Xcvr 18	REV 01	740-030589	S9AK450094	SFP+-10G-LPBK
Xcvr 19	REV 01	740-030589	S9AK450100	SFP+-10G-LPBK
Xcvr 20	REV 01	740-030589	S9AK450168	SFP+-10G-LPBK
Xcvr 21	REV 01	740-030589	S9AK450165	SFP+-10G-LPBK
Xcvr 22	REV 01	740-030589	S9AK450073	SFP+-10G-LPBK
Xcvr 23	REV 01	740-030589	S9AK450164	SFP+-10G-LPBK
Xcvr 24	REV 01	740-030589	S9AK450074	SFP+-10G-LPBK
Xcvr 25	REV 01	740-030589	SA62270195	SFP+-10G-LPBK
Xcvr 26	REV 01	740-030589	S9AK450078	SFP+-10G-LPBK
Xcvr 27	REV 01	740-030589	S9AK450024	SFP+-10G-LPBK
Xcvr 28	REV 01	740-030589	S9AK450027	SFP+-10G-LPBK
Xcvr 29	REV 01	740-030589	S9AK450080	SFP+-10G-LPBK
Xcvr 30	REV 01	740-030589	S9AK450030	SFP+-10G-LPBK
Xcvr 31	REV 01	740-030589	S9AK450025	SFP+-10G-LPBK
Xcvr 32	REV 01	740-030589	S9AK450023	SFP+-10G-LPBK
Xcvr 33	REV 01	740-030589	S9AK450075	SFP+-10G-LPBK
Xcvr 34	REV 01	740-030589	S9AK450161	SFP+-10G-LPBK
Xcvr 35	REV 01	740-030589	S9AK450071	SFP+-10G-LPBK
Xcvr 36	REV 01	740-030589	S9AK450072	SFP+-10G-LPBK
Xcvr 37	REV 01	740-030589	S9AK450022	SFP+-10G-LPBK
Xcvr 38	REV 01	740-030589	S9AK450021	SFP+-10G-LPBK
Xcvr 39	REV 01	740-030589	S9AK450175	SFP+-10G-LPBK
Xcvr 40	REV 01	740-030589	S9AK450162	SFP+-10G-LPBK
Xcvr 41	REV 01	740-030589	S99E270074	SFP+-10G-LPBK
Xcvr 42	REV 01	740-030589	S9AK450174	SFP+-10G-LPBK
Xcvr 43	REV 01	740-030589	S9AK450077	SFP+-10G-LPBK
Xcvr 44	REV 01	740-030589	S9AK450076	SFP+-10G-LPBK
Xcvr 45	REV 01	740-030589	S9AK450026	SFP+-10G-LPBK
Xcvr 46	REV 01	740-030589	S9AK450079	SFP+-10G-LPBK

Xcvr 47	REV 01	740-030589	S9AK450029	SFP+-10G-LPBK
PIC 1		BUILTIN	BUILTIN	15x 10G-SFP+
Xcvr 1	REV 01	740-032986	QA170087	QSFP+-40G-SR4
Xcvr 4	REV 01	740-032986	QA360442	QSFP+-40G-SR4
Xcvr 8	REV 01	740-032986	QA170091	QSFP+-40G-SR4
Xcvr 12	REV 01	740-032986	QA170042	QSFP+-40G-SR4
MGMT BRD	REV 08	750-036946	EE0731	QFX3500-MB
Power Supply 0	Rev 04	740-032091	UI00690	QFX PS 650W AC
Power Supply 1	Rev 04	740-032091	UI00679	QFX PS 650W AC
Fan Tray 0				QFX Fan Tray
Fan Tray 1				QFX Fan Tray

**show chassis hardware
models (QFX Series)**

user@switch> show chassis hardware models

Hardware inventory:

Item	Version	Part number	Serial number	FRU model number
Routing Engine 0		BUILTIN	BUILTIN	
FPC 0	REV 02	711-032234	EC4074	
Power Supply 0	PSMI 2C	11-d65800	--	

**show chassis hardware
clei-models (QFX
Series)**

user@switch> show chassis hardware clei-models

Hardware inventory:

Item	Version	Part number	CLEI code	FRU model number
Routing Engine 0		BUILTIN		
FPC 0	REV 02	711-032234		
Power Supply 0	PSMI 2C	11-d65800		

show chassis in-service-upgrade

Syntax `show chassis in-service-upgrade`

Release Information Command introduced in Junos OS Release 9.0.

Description Display the status of Flexible PIC Concentrators (FPCs) and their corresponding PICs after the most recent unified in-service software upgrade (ISSU). This command must be issued on the master Routing Engine.



NOTE: Only Intelligent Queuing (IQ) PICs are displayed by this command output. Unified ISSU status for other PIC types is controlled internally by the FPC.

Options This command has no options.

Required Privilege Level view

Related Documentation

- [request system software abort on page 772](#)
- [request system software in-service-upgrade on page 785](#)

List of Sample Output [show chassis in-service-upgrade on page 468](#)

Output Fields Table 79 on page 468 lists the output fields for the `show chassis in-service-upgrade` command. Output fields are listed in the approximate order in which they appear.

Table 79: show chassis in-service-upgrade Output Fields

Field Name	Field Description
Item	Flexible PIC Concentrator (FPC) slot number.
Status	FPC and corresponding PIC state. State can be either of the following: <ul style="list-style-type: none"> • Online—FPC is online and running. • Offline—FPC is powered down.
Reason	Reason for the state (if offline).

Sample Output

```

show chassis in-service-upgrade user@host> show chassis in-service-upgrade
  Item      Status      Reason
  FPC 0     Online
  FPC 1     Online
  FPC 2     Online
  PIC 0     Online

```

PIC 1	Online	
FPC 3	Offline	Offlined by CLI command
FPC 4	Online	
PIC 1	Online	
FPC 5	Online	
PIC 0	Online	
FPC 6	Online	
PIC 3	Online	
FPC 7	Online	

show chassis lccs

Syntax	show chassis lccs
Release Information	Command introduced before Junos OS Release 7.4.
Description	(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display the status of all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display the status of all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis lcc on page 177
List of Sample Output	show chassis lccs on page 470
Output Fields	Table 80 on page 470 lists the output fields for the show chassis lccs command. Output fields are listed in the approximate order in which they appear.

Table 80: show chassis lccs Output Fields

Field Name	Field Description
Slot	LCC slot number.
State	LCC status: <ul style="list-style-type: none"> • Online—LCC is online and running. • Offline—LCC is powered down. • Empty—No LCC is present.
Uptime	How long the LCC has been up and running.

Sample Output

```

show chassis lccs user@host> show chassis lccs
Slot  State                Uptime
0     Online                 3 minutes, 17 seconds
1     Empty
2     Online                 3 minutes, 23 seconds
3     Empty

```

show chassis location

Syntax	show chassis location
Syntax (TX Matrix Router)	show chassis location <fpc interface (by-name <i>name</i> by-slot fpc number lcc number) lcc number scc>
Syntax (TX Matrix Plus Router)	show chassis location <fpc interface (by-name <i>name</i> by-slot fpc number lcc number) lcc number sfc number>
Syntax (MX Series Router)	show chassis location <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the physical location of the chassis. This command can only be used on the master Routing Engine.
Options	<p>none—Display all information about the physical location of the chassis. On a TX Matrix router, display all information about the physical location of the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display all information about the physical location of the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display the physical location of the chassis for all the member routers in the Virtual Chassis configuration.</p> <p>fpc—(TX Matrix and TX Matrix Plus routers only) (Optional) Display the physical location of all Flexible PIC Concentrators (FPCs).</p> <p>interface by-name <i>name</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) Display the physical location of a specified interface name. On a TX Matrix router, this option displays the FPC number and T640 router (or line-card chassis) number associated with the specified interface. On a TX Matrix Plus router, this option displays the FPC number and T1600 router (or line-card chassis) number associated with the specified interface.</p> <p>interface by-slot fpc number lcc number—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display the global FPC number of an interface by specifying its local FPC number and T640 router (or line-card chassis) number. On a TX Matrix Plus router, display the global FPC number of an interface by specifying its local FPC number and T1600 router (or line-card chassis) number.</p> <ul style="list-style-type: none"> The global FPC number is the FPC slot number when all the FPC slots in the routing matrix are considered: 0 through 31. The local FPC number is the FPC slot number on a particular T640 router.

- For **fpc**, replace *number* with a value from 0 through 7.
- For **lcc**, replace *number* with a value from 0 through 3.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display the physical location of a specified T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display the physical location of a specified T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(MX Series routers only) (Optional) Display the physical location of the chassis for the local Virtual Chassis member.

member *member-id*—(MX Series routers only) (Optional) Display the physical location of the chassis for the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display the physical location of the TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus routers only) (Optional) Display the physical location of the TX Matrix Plus router (or switch-fabric chassis).

Required Privilege Level view

List of Sample Output [show chassis location on page 473](#)
[show chassis location fpc \(TX Matrix Router\) on page 473](#)
[show chassis location interface by-slot \(TX Matrix Router\) on page 473](#)
[show chassis location fpc \(TX Matrix Plus Router\) on page 473](#)
[show chassis location interface by-slot \(TX Matrix Plus Router\) on page 473](#)
[show chassis location \(QFX Series\) on page 473](#)

Output Fields Table 81 on page 472 lists the output fields for the **show chassis location** command. Output fields are listed in the approximate order in which they appear.

Table 81: show chassis location Output Fields

Field Name	Field Description
country-code	Country code information.
postal-code	Postal code information.
Building	Building information.
Floor	Floor information.
Global FPC	Global FPC number. The FPC slot number, when all FPC slots in the Routing Matrix are considered. The range of values is 0 through 31.

Table 81: show chassis location Output Fields (*continued*)

Field Name	Field Description
LCC	Line-card chassis number. On a TX Matrix router, the number of a particular T640 router connected to the TX Matrix router. On a TX Matrix Plus router, the number of a particular T1600 router connected to the TX Matrix Plus router.
Local FPC	Local FPC number. On a TX Matrix router, the FPC slot number on a particular T640 router. On a TX Matrix Plus router, the FPC slot number on a particular T1600 router.

Sample Output

```

show chassis location user@host> show chassis location
country-code: US
postal-code: 94404
Building: Building 2, Floor: 2

show chassis location user@host> show chassis location fpc
fpc (TX Matrix Router) Global FPC    LCC    Local FPC
                        17          2      1
                        21          2      5

show chassis location user@host> show chassis location interface by-slot fpc 1 lcc 1
interface by-slot      Global FPC: 9
(TX Matrix Router)

show chassis location user@host> show chassis location fpc
fpc (TX Matrix Plus   Global FPC    LCC    Local FPC
Router)               0          0      0
                        1          0      1

show chassis location user@host> show chassis location interface by-slot fpc 2 lcc 1
interface by-slot      Global FPC: 10
(TX Matrix Plus
Router)

show chassis location user@switch> show chassis location
(QFX Series)          Global FPC: 10

```

show chassis mac-addresses

Syntax	show chassis mac-addresses
Syntax (TX Matrix Router)	show chassis mac-addresses <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis mac-addresses <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis mac-addresses <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show chassis mac-addresses
Release Information	Command introduced before JUNOS Release 7.4. Command introduced in JUNOS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6. Command introduced in JUNOS Release 11.1 for the QFX Series.
Description	Display the media access control (MAC) addresses for the router, switch chassis, or switch.
Options	<p>none—(TX Matrix, TX Matrix Plus routers, and the QFX Series) Display the MAC addresses for the router chassis or switch. On a TX Matrix router, display MAC addresses on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display MAC addresses on the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display the MAC addresses for all the member routers of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display MAC addresses for a specified T640 router (or line-card chassis) that is connected to the TX Matrix Plus router. On a TX Matrix Plus router, display MAC addresses for a specified T640 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display the MAC addresses for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display the MAC addresses for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) (Optional) Display MAC addresses for the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display MAC addresses for the TX Matrix Plus router (or switch-fabric chassis).</p>

Required Privilege Level view

List of Sample Output `show chassis mac-addresses` on page 475
`show chassis mac-addresses (TX Matrix Router)` on page 475
`show chassis mac-addresses (TX Matrix Plus Router)` on page 476
`show chassis mac-addresses (QFX Series)` on page 476

Output Fields Table 82 on page 475 lists the output fields for the `show chassis mac-addresses` command. Output fields are listed in the approximate order in which they appear.

Table 82: show chassis mac-addresses Output Fields

Field Name	Field Description
MAC address information	
Public base address	Base address of the MAC addresses allocated to this router or switch.
Public count	Number of allocated public addresses.
Private base address	Base address of the private MAC addresses allocated to this router or switch.
Private count	Number of allocated private addresses.

Sample Output

```

show chassis mac-addresses user@host> show chassis mac-addresses
MAC address information
  Public base address  0:90:69:0:4:0
  Public count         1008
  Private base address 0:90:69:0:7:f0
  Private count        16

```

```

show chassis mac-addresses (TX user@host> show chassis mac-addresses
Matrix Router) scc-re0:
-----
MAC address information:
  Public base address  00:05:85:9e:cc:00
  Public count         8064
  Private base address 00:05:85:9e:eb:80
  Private count        128
lcc0-re0:
-----
MAC address information:
  Public base address  00:05:85:68:98:00
  Public count         2032
  Private base address 00:05:85:68:9f:f0
  Private count        16
lcc2-re0:
-----
MAC address information:
  Public base address  00:05:85:68:78:00
  Public count         2032

```

```

Private base address  00:05:85:68:7f:f0
Private count        16

```

**show chassis
mac-addresses (TX
Matrix Plus Router)**

```

user@host> show chassis mac-addresses
sfc0-re0:

```

```

-----
MAC address information:
Public base address  00:1d:b5:14:00:00
Public count        65023
Private base address 00:1d:b5:14:fd:ff
Private count        512

```

```

lcc0-re0:

```

```

-----
MAC address information:
Public base address  00:1f:12:7a:84:00
Public count        2032
Private base address 00:1f:12:7a:8b:f0
Private count        16

```

```

lcc1-re0:

```

```

-----
MAC address information:
Public base address  00:22:83:42:48:00
Public count        2032
Private base address 00:22:83:42:4f:f0
Private count        16

```

```

lcc2-re0:

```

```

-----
MAC address information:
Public base address  00:1f:12:c3:58:00
Public count        2032
Private base address 00:1f:12:c3:5f:f0
Private count        16

```

```

lcc3-re0:

```

```

-----
MAC address information:
Public base address  00:21:59:ef:b8:00
Public count        2032
Private base address 00:21:59:ef:bf:f0
Private count        16

```

**show chassis
mac-addresses (QFX
Series)**

```

user@switch> show chassis mac-addresses
MAC address information:
Public base address 02:00:08:00:00:00
Public count 512
Private base address 02:00:00:00:00:00
Private count 64

```

show chassis network services

Syntax	show chassis network services
Release Information	Command introduced in Junos OS Release 9.4.
Description	(MX Series routers only) Display the network services mode that the router is configured to run in—IP Services mode or Ethernet Services mode.
Options	This command has no options.
Required Privilege Level	view
Output Fields	Table 83 on page 477 lists the output fields for the show chassis network services command. Output fields are listed in the approximate order in which they appear.

Table 83: show chassis network services Output Fields

Field Name	Field Description
Network services mode	Network services mode configured for the MX Series router: <ul style="list-style-type: none">• IP—IP Services mode.• Ethernet—Ethernet Services mode.

show chassis network services

```
user@host> show chassis network services
Network Services Mode: IP
```

show chassis pic

Syntax	<code>show chassis pic fpc-slot <i>slot-number</i> pic-slot <i>slot-number</i></code>
Syntax (TX Matrix and TX Matrix Plus Routers)	<code>show chassis pic fpc-slot <i>slot-number</i> pic-slot <i>slot-number</i> <<i>lcc number</i>></code>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Display status information about the PIC installed in the specified Flexible PIC Concentrator (FPC) and PIC slot.
Options	<p><code>fpc-slot <i>slot-number</i></code>—Display information about the PIC in this particular FPC slot:</p> <ul style="list-style-type: none">On a TX Matrix router, if you specify the number of the T640 router by using the <i>lcc number</i> option (the recommended method), replace <i>slot-number</i> with a value from 0 through 7. Otherwise, replace <i>slot-number</i> with a value from 0 through 31. For example, the following commands have the same result: <p>Likewise, on a TX Matrix Plus router, if you specify the number of the T1600 router by using the <i>lcc number</i> option (the recommended method), replace <i>slot-number</i> with a value from 0 through 7. Otherwise, replace <i>slot-number</i> with a value from 0 through 31. For example, the following commands have the same result:</p> <pre>user@host> show chassis pic fpc-slot 1 lcc 1 pic-slot 1 user@host> show chassis pic fpc-slot 9 pic-slot 1</pre> <ul style="list-style-type: none">M120 routers only—Replace <i>slot-number</i> with a value from 0 through 5.MX80 routers only—Replace <i>slot-number</i> with a value from 0 through 1.MX240 routers only—Replace <i>slot-number</i> with a value from 0 through 2.MX480 routers only—Replace <i>slot-number</i> with a value from 0 through 5.MX960 routers only—Replace <i>slot-number</i> with a value from 0 through 11.Other routers—Replace <i>slot-number</i> with a value from 0 through 7.EX Series switches:<ul style="list-style-type: none">EX3200 switches and EX4200 standalone switches—Replace <i>slot-number</i> with 0.EX4200 switches in a Virtual Chassis configuration—Replace <i>slot-number</i> with a value from 0 through 9 (switch's member ID).

- EX8208 switches—Replace *slot-number* with a value from 0 through 7 (line card).
- EX8216 switches—Replace *slot-number* with a value from 0 through 15 (line card).
- QFX Series:
 - QFX3500 switches—Replace *slot-number* with 0. In QFX3500 switch command output, FPC refers to a line card. The FPC number equals the slot number for the line card. Both the FPC and PIC slot numbers are always 0.

lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display PIC information for a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display PIC information for a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

pic-slot slot-number—Display information about the PIC in this particular PIC slot. For routers, replace *slot-number* with a value from 0 through 3. For EX3200 and EX4200 switches, replace *slot-number* with 0 for built-in network interfaces and 1 for interfaces on uplink modules. For EX8208, EX8216, and QFX3500 switches, replace *slot-number* with 0.

Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • request chassis pic on page 180
List of Sample Output	<p>show chassis pic fpc-slot pic-slot on page 481</p> <p>show chassis pic fpc-slot pic-slot (PIC Offline) on page 481</p> <p>show chassis pic fpc-slot pic-slot (FPC Offline) on page 481</p> <p>show chassis pic fpc-slot pic-slot (FPC Not Present) on page 481</p> <p>show chassis pic fpc-slot pic-slot (PIC Not Present) on page 481</p> <p>show chassis pic fpc-slot 3 pic-slot 0 (M120 Router) on page 481</p> <p>show chassis pic fpc-slot pic-slot (MX960 Router Bidirectional Optics) on page 481</p> <p>show chassis pic fpc-slot pic-slot (T1600 Router with 100-Gigabit Ethernet PIC) on page 482</p> <p>show chassis pic fpc-slot pic-slot lcc (TX Matrix Router) on page 482</p> <p>show chassis pic fpc-slot pic-slot lcc (TX Matrix Plus Router) on page 482</p> <p>show chassis pic fpc-slot pic-slot (Next-Generation SONET/SDH SFP) on page 482</p> <p>show chassis pic fpc-slot pic-slot (12-port T1/E1) on page 483</p> <p>show chassis pic fpc-slot 0 pic-slot 1 (4x CHOC3 SONET CE SFP) on page 483</p> <p>show chassis pic fpc-slot 0 pic-slot 0 (SONET/SDH OC3/STM1 [Multi-Rate] MIC with SFP) on page 483</p> <p>show chassis pic fpc-slot pic-slot (OTN) on page 483</p> <p>show chassis pic fpc-slot pic-slot (QFX Series) on page 484</p>
Output Fields	Table 84 on page 480 lists the output fields for the show chassis pic command. Output fields are listed in the approximate order in which they appear.

Table 84: show chassis pic Output Fields

Field Name	Field Description
Type	PIC type.
ASIC type	Type of ASIC on the PIC.
State	Status of the PIC. State is displayed only when a PIC is in the slot. <ul style="list-style-type: none"> • Online— PIC is online and running. • Offline—PIC is powered down.
PIC version	PIC hardware version.
Uptime	How long the PIC has been online.
Package	(Multiservices PICs only) Services package supported: Layer-2 or Layer-3 .
PIC Port Information	Port-level information for the PIC.
Port Number	Port number for the PIC.
Cable Type	Type of cable connected to the port: LH , LX , or SX
PIC Port Information (MX960 Router Bidirectional Optics)	Port-level information for the PIC. <ul style="list-style-type: none"> • Port—Port number • Cable type—Type of small form-factor pluggable (SFP) optical transceiver installed. Uplink interfaces display -U. Down link interfaces display -D. • Fiber type—Type of fiber. SM is single-mode. • Xcvr vendor—Transceiver vendor name. • Xcvr vendor part number—Transceiver vendor part number. <ul style="list-style-type: none"> • BX10-10-km bidirectional optics. • BX40-40-km bidirectional optics. • SFP-LX-40-km SFP optics. • Wavelength—Wavelength of the transmitted signal. Uplinks are always 1310 nm. Downlinks are either 1490 nm or 1550 nm.
PIC Port Information (next-generation SONET/SDH SFP)	Port-level information for the next-generation SONET/SDH SFP PIC. <ul style="list-style-type: none"> • Port—Port number • Cable type—Type of small form-factor pluggable (SFP) optical transceiver installed. • Fiber type—Type of fiber: SM (single-mode) or MM (multimode). • Xcvr vendor—Transceiver vendor name. • Xcvr vendor part number—Transceiver vendor part number. • Wavelength—Wavelength of the transmitted signal. Next-generation SONET/SDH SFPs use 1310 nm.

Sample Output

```

show chassis pic fpc-slot pic-slot user@host> show chassis pic fpc-slot 2 pic-slot 0
PIC fpc slot 2 pic slot 0 information:
  Type          10x 1GE(LAN), 1000 BASE
  ASIC type      H chip
  State          Online
  PIC version    1.1
  Uptime        1 day, 50 minutes, 58 seconds
PIC Port Information:
  Port          Cable
  Number        Type
  0             GIGE 1000LX
  6             GIGE 1000LX

show chassis pic fpc-slot pic-slot user@host> show chassis pic fpc-slot 1 pic-slot 0
(PIC Offline)                       PIC fpc slot 1 pic slot 0 information:
                                   State          Offline

show chassis pic fpc-slot pic-slot user@host> show chassis pic fpc-slot 1 pic-slot 0
(PFC Offline)                       FPC 1 is not online

show chassis pic fpc-slot pic-slot user@host> show chassis pic fpc-slot 4 pic-slot 0
(PFC Not Present)                   FPC slot 4 is empty

show chassis pic fpc-slot pic-slot user@host> show chassis pic fpc-slot 5 pic-slot 2
(PIC Not Present)                   FPC 5, PIC 2 is empty

show chassis pic fpc-slot 3 pic-slot user@host> show chassis pic fpc-slot 3 pic-slot 0
(M120 Router)                       PC slot 3, PIC slot 0 information:
  Type          2x G/E IQ, 1000 BASE
  ASIC type      IQ GE 2 VLAN-TAG FPGA
  State          Online
  PIC version    1.16
  Uptime        3 hours, 3 minutes
PIC Port Information:
  Port          Cable          Xcvr          Xcvr Vendor
  Number        Type          Vendor Name   Part Number
  0             GIGE 1000SX    FINISAR CORP. FTRJ8519P1BNL-J3
  1             GIGE 1000SX    FINISAR CORP. FTRJ-8519-7D-JUN

show chassis pic fpc-slot 4 pic-slot user@host> show chassis pic fpc-slot 4 pic-slot 1
(MX960 Router Bidirectional Optics) FPC slot 4, PIC slot 1 information:
  Type          10x 1GE(LAN)
  State          Online
  PIC version    0.0
  Uptime        18 days, 5 hours, 41 minutes, 54 seconds
PIC port information:
  Port          Cable type      Fiber          Xcvr vendor
  Number        type            type           part number    Wavelength
  0             SFP-1000BASE-BX10-D SM SumitomoElectric SBP6H44-J3-BW-49 1490 nm
  1             SFP-1000BASE-BX10-D SM SumitomoElectric SBP6H44-J3-BW-49 1490 nm
  2             SFP-1000BASE-BX10-D SM SumitomoElectric SBP6H44-J3-BW-49 1490 nm

```

```

3      SFP-1000BASE-BX10-D SM OCP          TRXBG1LXDBVM2-JW 1490 nm
4      SFP-1000BASE-BX10-D SM OCP          TRXBG1LXDBVM2-JW 1490 nm
5      SFP-1000BASE-BX10-U SM SumitomoElectric SBP6H44-J3-BW-31 1310 nm
6      SFP-1000BASE-BX10-U SM SumitomoElectric SBP6H44-J3-BW-31 1310 nm
7      SFP-1000BASE-BX10-U SM OCP          TRXBG1LXDBBMH-J1 1310 nm
8      SFP-1000BASE-BX10-U SM OCP          TRXBG1LXDBBMH-J1 1310 nm
9      SFP-1000BASE-BX10-U SM SumitomoElectric SBP6H44-J3-BW-31 1310 nm

```

**show chassis pic
fpc-slot pic-slot
(T1600 Router with
100-Gigabit Ethernet
PIC)**

```
user@host> run show chassis pic fpc-slot 3 pic-slot 1
```

FPC slot 3, PIC slot 1 information:

```

Type          100GE SLOT1
ASIC type     Brooklyn 100GE FPGA
State         Online
PIC version   1.3
Uptime        10 minutes, 44 seconds

```

PIC port information:

Port	Cable type	Fiber type	Xcvr vendor	Xcvr vendor part number	Wavelength
0	100GBASE LR4	SM	Opnext Inc.	TRC5E20ENFSF000F	1310 nm

**show chassis pic
fpc-slot pic-slot lcc
(TX Matrix Router)**

```
user@host> show chassis pic fpc-slot 1 pic-slot 1 lcc 0
lcc0-re0:
```

PIC fpc slot 1 pic slot 1 information:

```

Type          4x OC-3 SONET, SMIR
ASIC type     D chip
State         Online
PIC version   1.2
Uptime        5 days, 2 hours, 12 minutes, 8 seconds

```

**show chassis pic
fpc-slot pic-slot lcc
(TX Matrix Plus
Router)**

```
user@host> show chassis pic fpc-slot 0 pic-slot 0 lcc 0
lcc0-re0:
```

FPC slot 0, PIC slot 0 information:

```

Type          4x OC-192 SONET XFP
ASIC type     D16 chip
State         Online
PIC version   1.16
Uptime        1 hour, 40 minutes, 17 seconds

```

PIC port information:

Port	Cable type	Fiber type	Xcvr vendor	Xcvr vendor part number	Wavelength
0	OC192 short reach	n/a	SumitomoElectric	SXP3101NV-J3	1310 nm
1	OC192 short reach	n/a	SumitomoElectric	SXP3101NV-J3	1310 nm
2	OC192 short reach	n/a	AVAGO	HFCT-711XPD-JU1	1310 nm
3	OC192 short reach	n/a	AVAGO	HFCT-711XPD-JU1	1310 nm

**show chassis pic
fpc-slot pic-slot
(Next-Generation
SONET/SDH SFP)**

```
user@host> show chassis pic fpc-slot 4 pic-slot 0
```

FPC slot 4, PIC slot 0 information:

```

Type          4x OC-3 1x OC-12 SFP
ASIC type     D FPGA
State         Online
PIC version   1.3
Uptime        1 day, 50 minutes, 4 seconds

```

PIC port information:

Port	Cable type	Fiber type	Xcvr vendor	Xcvr vendor part number	Wavelength
------	------------	------------	-------------	-------------------------	------------

0	OC48 short reach	SM	FINISAR CORP.	FTRJ1321P1BTL-J2	1310 nm
1	OC3 short reach	MM	OCP	TRPA03MM3BAS-JE	1310 nm
2	OC3 short reach	MM	OCP	TRXA03MM3BAS-JW	1310 nm
3	OC12 inter reach	SM	FINISAR CORP.	FTLF1322P1BTR	1310 nm

**show chassis pic
fpc-slot pic-slot
(12-port T1/E1)**

```
user@host> show chassis pic fpc-slot 0 pic-slot 3
FPC slot 0, PIC slot 3 information:
  Type                12x T1/E1 CE
  State                Online
  PIC version          1.1
  CPU load average     1 percent
  Interrupt load average 0 percent
  Total DRAM size      128 MB
  Memory buffer utilization 100 percent
  Memory heap utilization 4 percent
  Uptime               1 day, 22 hours, 28 minutes, 12 seconds
  Internal Clock Synchronization Normal
```

**show chassis pic
fpc-slot 0 pic-slot 1 (4x
CHOC3 SONET CE
SFP)**

```
user@host> show chassis pic fpc-slot 0 pic-slot 1
FPC slot 0, PIC slot 1 information:
  Type                4x CHOC3 SONET CE SFP
  State                Online
  PIC version          1.3
  CPU load average     1 percent
  Interrupt load average 0 percent
  Total DRAM size      128 MB
  Memory buffer utilization 99 percent
  Memory heap utilization 4 percent
  Uptime               1 day, 22 hours, 55 minutes, 37 seconds
  Internal Clock Synchronization Normal
```

PIC port information:

Port	Cable type	Fiber type	Xcvr vendor	Xcvr vendor part number	Wavelength
0	OC3 short reach	MM	AVAGO	HFBR-57E0P-JU2	n/a
1	OC3 short reach	MM	AVAGO	HFBR-57E0P-JU2	n/a
3	OC3 long reach	SM	OPNEX INC	TRF5456AVLB314	1310 nm

**show chassis pic
fpc-slot 0 pic-slot 0
(SONET/SDH
OC3/STM1
[Multi-Rate] MIC with
SFP)**

```
user@host> show chassis pic fpc-slot 0 pic-slot 0
FPC slot 0, PIC slot 0 information:
  Type                MIC-3D-80C30C12-40C48
  State                Online
  PIC version          1.8
  Uptime               3 days, 22 hours, 3 minutes, 50 seconds
```

PIC port information:

Port	Cable type	Fiber type	Xcvr vendor	Xcvr vendor part number	Wavelength
1	OC12 inter reach	SM	FINISAR CORP	FTRJ1322P1BTR-J3	1310 nm
7	OC12 inter reach	SM	FINISAR CORP	FTRJ1322P1BTR-J3	1310 nm

Multirate Mode Enabled

**show chassis pic
fpc-slot pic-slot (OTN)**

```
user@host> show chassis pic fpc-slot 5 pic-slot 0
PIC fpc slot 5 pic slot 0 information:
  Type                1x10GE(LAN),OTN
  ASIC type            H chip
  State                Online
```

PIC version	1.0
Uptime	5 minutes, 50 seconds

```

show chassis pic user@switch> show chassis pic fpc-slot 0 pic-slot 0
fpc-slot pic-slot (QFX FPC slot 0, PIC slot 0 information:
Series) Type 48x 10G-SFP+ Builtin
State Online
Uptime 3 days, 3 hours, 5 minutes, 20 seconds
    
```

show chassis power-ratings

Syntax	show chassis power-ratings
Release Information	Command introduced in Junos OS Release 8.4.
Description	(J Series routers only) Display the low-power consumption, high-power consumption, and heat dissipation ratings of the router. Low-power consumption, high-power consumption, and heat dissipation values are represented in nondimensional tokens.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis power-ratings on page 487 show chassis power-ratings (Power Management Disabled) on page 487
Output Fields	Table 85 on page 485 lists the output fields for the show chassis power-ratings command. Output fields are listed in the approximate order in which they appear.

Table 85: show chassis power-ratings Output Fields

Field Name	Field Description
Device	Physical Interface Module (PIM) slot. (PIM slot numbers appear as FPC numbers in the output.)
Total Tokens	Maximum number of low-power, high-power, and heat tokens available for the router: <ul style="list-style-type: none"> • Low Power—Maximum number of low-power consumption tokens available for the router. • High Power—Maximum number of high-power consumption tokens available for the router. • Heat—Maximum number of heat tokens available for the router.

Table 85: show chassis power-ratings Output Fields (*continued*)

Field Name	Field Description
FPC number	<p>PIM slot number and power and heat information for the PIM in this slot:</p> <ul style="list-style-type: none"> • Low Power—PIM low-power consumption. The number of low-power tokens used by the PIM. • High Power—PIM high-power consumption. The number of high-power tokens used by the PIM. • Heat—The number of PIM heat dissipation tokens used by this PIM. • Ratings—Status of the PIM slot. The status of the slot is based on either the configuration of the slot or the power use and heat dissipation of the PIM in that slot: <p>NOTE: The request chassis fpc command has no effect on the status of the PIM slot.</p> <ul style="list-style-type: none"> • OK—The PIM in this PIM slot can be brought online. • Exceeded—The PIM cannot be brought online because the PIM slot has been disabled by J Series power management. The PIM in this PIM slot exceeds the maximum number of low-power tokens, high-power tokens, or heat tokens. • Empty—No PIM is installed in the PIM slot. • Cfg offline—The PIM cannot be brought online because the PIM slot has been disabled by the set chassis fpc offline command.
Tokens Used	<p>Total number of low-power, high-power, and heat tokens used by the router:</p> <ul style="list-style-type: none"> • Low Power—The total number of low-power tokens used by the router. • High Power—The total number of high-power tokens used by the router. • Heat—Number of heat tokens used by the router. • Ratings—If blank, J Series power management is enabled. No Power Mgmt indicates that J Series power management has been disabled by the set chassis disable_power_management command. <p>NOTE: Use extreme caution when disabling J Series power management. To prevent equipment damage, do not install a combination of PIMs that exceeds the power and heat capacity of the router when J Series power management is disabled.</p>

Sample Output

```

show chassis power-ratings user@host> show chassis power-ratings
Device          Low      High      Heat      Ratings
                  Power      Power
Total Tokens    83       83       83       -
FPC 1           6        27       21       OK
FPC 2           3        27       18       OK
FPC 3           0         0         0       Empty
FPC 4           0         0         0       Empty
FPC 5           2         0         2       Exceeded
Tokens Used     11       54       41       -

show chassis power-ratings (Power user@host> show chassis power-ratings
Management Disabled) Device          Low      High      Heat      Ratings
                  Power      Power
Total Tokens    83       83       83       -
FPC 1           6        27       21       OK
FPC 2           3        27       18       OK
FPC 3           0         0         0       Empty
FPC 4           0         0         0       Empty
FPC 5           2         0         2       Exceeded
Tokens Used     11       54       41       No Power Mgmt

```

show chassis power

Syntax show chassis power

Release Information Command introduced in Junos OS Release 10.0

Description (MX Series 3D Universal EdgeRouters only) Display power limits and usage information for the AC or DC Power Entry Modules (PEMs).



.....
NOTE: The new high-capacity (4100W) enhanced DC PEM on MX960 routers includes a new design that can condition the input voltage. This results in the output voltage differing from the input voltage. The earlier generation of DC PEMs coupled the input power directly to the output, thereby making it safe to assume that the output voltage was equal to the input voltage.
.....

Options This command has no options.

Required Privilege Level view

Related Documentation • show chassis power sequence on page 493

List of Sample Output show chassis power (MX960 Router with DC PEM) on page 489
 show chassis power (MX960 Router with AC PEM) on page 490
 show chassis power (MX480 Router with AC PEM) on page 491
 show chassis power (MX240 Router with DC PEM) on page 491

Output Fields Table 86 on page 489 lists the output fields for the **show chassis power** command. Output fields are listed in the approximate order in which they appear.

Table 86: show chassis power Output Fields

Field Name	Field Description
PEM number	<p>AC or DC PEM number on the chassis. The following output fields are displayed for the PEM:</p> <ul style="list-style-type: none"> • State—State of the PEM: <ul style="list-style-type: none"> • Online—PEM is present in the slot and online. • Empty—PEM is not present in the slot. • Present—PEM is present in the slot, but not online. • AC/DC Input—OK or Check—State of the AC or DC input power feed with the number of active and expected feeds (one or two). For a DC input power feed, this output field also displays the reference voltage input with maximum input voltage displayed in mV (in parentheses) for the AC or DC PEM. • Capacity—Actual power input capacity with maximum capacity displayed (in parentheses) in watts. <p>NOTE: The maximum capacity for AC and DC PEMs is:</p> <ul style="list-style-type: none"> • MX960 AC PEM—4100 W if two feeds are connected. 1700 W if one feed is connected. • MX960 DC PEM—4100 W if two feeds are connected. 1700 W if one feed is connected. • MX480 AC PEM—2520 W if it is high-line. 1450 W if it is low-line. • MX480 DC PEM—2400 W if the DIP switch is off. 2600 W if the DIP switch is on. • MX240 AC PEM—2520 W if it is high-line. 1450 W if it is low-line. • MX240 DC PEM—2400 W if the DIP switch is off. 2600 W if the DIP switch is on. • DC Output—DC power output in Watts for the specified zone, at the specified amps and voltage (A @ V), and load and percentage utilization of the maximum capacity) for the zone.
System	<p>Overall power statistics for the system zone-wise:</p> <ul style="list-style-type: none"> • Zone number: <ul style="list-style-type: none"> • Capacity—Maximum power capacity applicable for the zone, in watts. • Allocated power—Actual capacity allocated for the zone, in watts, with remaining power displayed in parentheses. • Actual usage—Actual power usage for the zone, in watts. • Total system capacity—Cumulative power capacity of all the zones, in watts. • Total remaining capacity—Difference between the Total system capacity and cumulative Allocated power of all the zones, in watts.

Sample Output

```

show chassis power user@host> show chassis power
(MX960 Router with PEM 0:
DC PEM)           State:      Online
                  DC input:  OK (2 feed expected, 2 feed connected)
                  DC input:  48.0 V input (57000 mV)
                  Capacity:  4100 W (maximum 4100 W)
                  DC output:  513 W (zone 0, 9 A at 57 V, 12% of capacity)

                  PEM 1:
                  State:      Online
                  DC input:  OK (2 feed expected, 2 feed connected)
                  DC input:  48.0 V input (57000 mV)
                  Capacity:  4100 W (maximum 4100 W)
                  DC output:  228 W (zone 1, 4 A at 57 V, 5% of capacity)

```

```

PEM 2:
  State:      Online
  DC input:   OK (2 feed expected, 2 feed connected)
  DC input:   48.0 V input (57000 mV)
  Capacity:   4100 W (maximum 4100 W)
  DC output:  513 W (zone 0, 9 A at 57 V, 12% of capacity)

```

```

PEM 3:
  State:      Online
  DC input:   OK (2 feed expected, 2 feed connected)
  DC input:   48.0 V input (57000 mV)
  Capacity:   4100 W (maximum 4100 W)
  DC output:  342 W (zone 1, 6 A at 57 V, 8% of capacity)

```

```

System:
  Zone 0:
    Capacity:      4100 W (maximum 4100 W)
    Allocated power: 1680 W (2420 W remaining)
    Actual usage:   1026 W
  Zone 1:
    Capacity:      4100 W (maximum 4100 W)
    Allocated power: 1263 W (2837 W remaining)
    Actual usage:   570 W
  Total system capacity: 8200 W (maximum 8200 W)
  Total remaining power: 5257 W

```

show chassis power
(MX960 Router with
AC PEM)

```

user@host> show chassis power
PEM 0:
  State:      Online
  AC input:   OK (2 feed expected, 2 feed connected)
  Capacity:   4100 W (maximum 4100 W)
  DC output:  0 W (zone 0, 0 A at 56 V, 0% of capacity)

```

```

PEM 1:
  State:      Present
  AC input:   Check (2 feed expected, 1 feed connected)
  Capacity:   1700 W (maximum 4100 W)

```

```

PEM 2:
  State:      Empty
  Input:      Absent

```

```

PEM 3:
  State:      Online
  AC input:   OK (1 feed expected, 1 feed connected)
  Capacity:   1700 W (maximum 1700 W)

```

```

System:
  Zone 0:
    Capacity:      4100 W (maximum 4100 W)
    Allocated power: 540 W (3560 W remaining)
    Actual usage:   0 W
  Zone 1:
    Capacity:      0 W (maximum 0 W)
    Allocated power: 0 W (0 W remaining)
    Actual usage:   0 W
  Total system capacity: 4100 W (maximum 4100 W)
  Total remaining power: 3560 W

```

```

show chassis power user@host> show chassis power
(MX480 Router with PEM 0:
AC PEM)          State:      Online
                  AC input:   OK (1 feed expected, 1 feed connected)
                  Capacity:   2520 W (maximum 2520 W)
                  DC output:  472 W (zone 0, 8 A at 59 V, 18% of capacity)

PEM 1:
                  State:      Online
                  AC input:   OK (1 feed expected, 1 feed connected)
                  Capacity:   2520 W (maximum 2520 W)
                  DC output:  472 W (zone 0, 8 A at 59 V, 18% of capacity)

PEM 2:
                  State:      Online
                  AC input:   OK (1 feed expected, 1 feed connected)
                  Capacity:   2520 W (maximum 2520 W)
                  DC output:  118 W (zone 0, 2 A at 59 V, 4% of capacity)

PEM 3:
                  State:      Empty
                  Input:       Absent

System:
Maximum capacity: 5040 W
Allocated capacity: 1675 W (33% of maximum)
Remaining capacity: 3365 W
Actual usage:     1062 W

```

```

show chassis power user@host> show chassis power
(MX240 Router with PEM 0:
DC PEM)          State:      Online
                  DC input:   OK (1 feed expected, 1 feed connected)
                  DC input:   48.0 V input (53500 mV)
                  Capacity:   2400 W (maximum 2400 W)
                  DC output:  318 W (zone 0, 6 A at 53 V, 13% of capacity)

PEM 1:
                  State:      Online
                  DC input:   OK (1 feed expected, 1 feed connected)
                  DC input:   48.0 V input (54000 mV)
                  Capacity:   2400 W (maximum 2400 W)
                  DC output:  0 W (zone 0, 0 A at 54 V, 0% of capacity)

PEM 2:
                  State:      Online
                  DC input:   OK (1 feed expected, 1 feed connected)
                  DC input:   48.0 V input (52500 mV)
                  Capacity:   2400 W (maximum 2400 W)
                  DC output:  312 W (zone 0, 6 A at 52 V, 13% of capacity)

PEM 3:
                  State:      Online
                  DC input:   OK (1 feed expected, 1 feed connected)
                  DC input:   48.0 V input (55000 mV)
                  Capacity:   2400 W (maximum 2400 W)
                  DC output:  0 W (zone 0, 0 A at 55 V, 0% of capacity)

System:
Maximum capacity: 2400 W
Allocated capacity: 1270 W (52% of maximum)

```

Remaining capacity: 1130 W
Actual usage: 630 W

show chassis power sequence

Syntax	show chassis power sequence
Release Information	Command introduced in Junos OS Release 10.0
Description	(MX Series 3D Universal EdgeRouters only) Show power-on sequence for the chassis Dense Port Concentrators (DPCs).
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show chassis power on page 488
List of Sample Output	show chassis power sequence on page 493
Output Fields	Table 87 on page 493 lists the output fields for the show chassis power sequence command. Output fields are listed in the approximate order in which they appear.

Table 87: show chassis power sequence Output Fields

Field Name	Field Description
Chassis FRU Power Sequence	Power-on sequence for the DPCs in the chassis. The numbers indicate the slot number of the DPCs.

Sample Output

```

show chassis power sequence user@host> show chassis power sequence
sequence Chassis FRU Power Sequence: 3 4 5 6 7 8 9 10 11 0 1 2

```

show chassis psd

Syntax	show chassis psd
Release Information	Command introduced in Junos OS Release 9.1.
Description	(Root System Domain [RSD] only) Display information about Protected System Domains (PSDs). A PSD is initially created by the RSD configuration. An RSD and PSDs are supported on a T320 or T640 router, or a T1600 routing node that is interconnected with the JCS1200 platform.
Options	This command has no options
Additional Information	For more information about PSDs, RSDs, and the JCS1200 platform, see the <i>Junos OS Protected System Domain Configuration Guide</i> .
Required Privilege Level	view
List of Sample Output	show chassis psd on page 494
Output Fields	Table 88 on page 494 lists the output fields for the show chassis psd command. Output fields are listed in the approximate order in which they appear.

Table 88: show chassis psd Output Fields

Field Name	Field Description
Slot Description	PSD identification.
State	PSD status: <ul style="list-style-type: none"> • Online—PSD is online and running. • Offline—PSD is powered down.
Uptime	Length of time that the PSD has been up and running.

Sample Output

```

show chassis psd {master}
user@host> show chassis psd
Slot Description      State      Uptime
1                    Online    12 hours, 19 minutes, 51 seconds
2                    Online    2 hours, 18 minutes, 17 seconds
3                    Online    12 hours, 19 minutes, 51 seconds

```

show chassis redundancy feb

Syntax	show chassis redundancy feb <errors> <redundancy-group <i>group-name</i> >
Release Information	Command introduced in Junos OS Release 8.2.
Description	(M120 routers only) Display information about the status of configured Forwarding Engine Board (FEB) redundancy groups.
Options	<p>none—Display information about the status of all configured FEB redundancy groups.</p> <p>redundancy-group <i>group-name</i>—(Optional) Display information about the specified configured redundancy group.</p> <p>errors—(Optional) Display information about any errors encountered on the components in configured redundancy groups or on links between a FEB and a Flexible PIC Concentrator (FPC).</p>
Required Privilege Level	view
List of Sample Output	<p>show chassis redundancy feb on page 496</p> <p>show chassis redundancy feb redundancy-group grp1 on page 496</p> <p>show chassis redundancy feb redundancy-group grp0 errors on page 496</p>
Output Fields	Table 89 on page 495 lists the output fields for the show chassis redundancy feb command. Output fields are listed in the approximate order in which they appear.

Table 89: show chassis redundancy feb Output Fields

Field name	Field Description
Group	Name of configured redundancy group.
FEB	Slot number of each FEB included in redundancy groups.
State	State of each FEB: <ul style="list-style-type: none"> • Online—FEB is online and running. • Offline—FEB is powered down.
Priority	(Standard and redundancy-group option) Status of FEB in the redundancy group: Backup , Primary , or null.
Connected FPCs	(Standard and redundancy-group option) Slot number of each FPC connected to the FEB. The status Check is displayed when an error might have occurred.

Table 89: show chassis redundancy feb Output Fields (*continued*)

Field name	Field Description
Redundancy State	(Standard and redundancy-group option) Status of the FEB: <ul style="list-style-type: none"> • Active—FEB is currently active. • Ready—Backup FEB is ready for a switchover • Not Ready—Backup FEB is not ready for a switchover.
Auto-failover	(Standard and redundancy-group option) Automatic failover status of redundancy group: Enabled or Disabled .
Switch-reason	(Standard and redundancy-group option) Reason a switchover occurred to the backup FEB in the redundancy group.
Hard error: Yes	(errors option only) Displayed when a hard error occurs on a FEB.
FPC	(errors option only) Slot number and status of FPC: link ok or link error .
Fabric plane	(errors option only) Slot number and status of fabric plane.

Sample Output

```

show chassis redundancy feb user@host> show chassis redundancy feb
Group:          cfpc
FEB  State      Priority  Connected FPCs  Redundancy state
0    Offline    Backup
1    Online      5        Active
Auto-failover:  Enabled
Group:          grp0
FEB  State      Priority  Connected FPCs  Redundancy state
3    Offline    Backup
5    Online      Primary   0        Active
Auto-failover:  Enabled

show chassis redundancy feb user@host> show chassis redundancy feb redundancy-group grp1
redundancy-group grp1 Group: grp1
FEB  State      Priority  Connected FPC(s)  Redundancy state
0    Online      Backup    5                Active
3    Online      3        Active
5    Online      Primary   3                Ready
Auto-failover:  Enabled
Switch-reason:  Switchover from CLI

show chassis redundancy feb user@host> show chassis redundancy feb redundancy-group grp0 errors
redundancy-group grp0 errors Group: grp0
FEB: 0    State: Online
FPC 0 link OK
Fabric plane 0 OK
Fabric plane 1 OK
Fabric plane 2 OK
Fabric plane 3 OK
FEB: 1    State: Online
FPC 0 link OK
Fabric plane 0 OK

```



```
Fabric plane 1 OK
Fabric plane 2 OK
Fabric plane 3 OK
FEB: 2    State: Online
FPC 2 link OK
Fabric plane 0 OK
Fabric plane 1 OK
Fabric plane 2 OK
Fabric plane 3 OK
FEB: 3    State: Online
FPC 3 link OK
Fabric plane 0 OK
Fabric plane 1 OK
Fabric plane 2 OK
Fabric plane 3 OK
FEB: 4    State: Online
FPC 4 link OK
Fabric plane 0 OK
Fabric plane 1 OK
Fabric plane 2 OK
Fabric plane 3 OK
FEB: 5    State: Online
FPC 5 link OK
Fabric plane 0 OK
Fabric plane 1 OK
Fabric plane 2 OK
Fabric plane 3 OK
```

show chassis routing-engine

Syntax	show chassis routing-engine <bios <i>slot</i> >
Syntax (EX Series Switch)	show chassis routing-engine < <i>slot</i> >
Syntax (TX Matrix Router)	show chassis routing-engine <bios <i>slot</i> > < <i>lcc number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis routing-engine <bios <i>slot</i> > < <i>lcc number</i> <i>sfc number</i> >
Syntax (QFX Series)	show chassis routing-engine
Syntax (MX Series Router)	show chassis routing-engine <bios <i>slot</i> > <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release in 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the status of the Routing Engine.
Options	<p>none—Display information about one or more Routing Engines. On a TX Matrix router, display information about all Routing Engines on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display information about all Routing Engines on the TX Matrix Plus router and its attached T1600 routers.</p> <p>all-members—(MX Series routers only) (Optional) Display Routing Engine information for all members of the Virtual Chassis configuration.</p> <p>bios—(Optional) Display the basic input/output system (BIOS) firmware version.</p> <p><i>lcc number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display Routing Engine information for a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display Routing Engine information for a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display Routing Engine information for the local Virtual Chassis member.</p>

member member-id—(MX Series routers only) (Optional) Display Routing Engine information for the specified member of the Virtual Chassis configuration. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display Routing Engine information for the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Display Routing Engine information for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

slot—(Systems with multiple Routing Engines) (Optional) Display information for an individual Routing Engine. Replace *slot* with 0 or 1. For QFX3500 switches, there is only one Routing Engine, so you do not need to specify the slot number.

Required Privilege Level view

Related Documentation • request chassis routing-engine master on page 184

List of Sample Output

- show chassis routing-engine (M5 Router) on page 500
- show chassis routing-engine (M10 Router) on page 501
- show chassis routing-engine (M20 Router) on page 501
- show chassis routing-engine (M40 Router) on page 502
- show chassis routing-engine (M120 Router) on page 502
- show chassis routing-engine (M160 Router) on page 503
- show chassis routing-engine (MX240 Router) on page 503
- show chassis routing-engine (MX480 Router) on page 504
- show chassis routing-engine (MX960 Router) on page 504
- show chassis routing-engine (TX Matrix Router) on page 504
- show chassis routing-engine lcc (TX Matrix Router) on page 506
- show chassis routing-engine bios (TX Matrix Router) on page 506
- show chassis routing-engine (TX Matrix Plus Router) on page 506
- show chassis routing-engine lcc (TX Matrix Plus Router) on page 508
- show chassis routing-engine bios (TX Matrix Plus Router) on page 508
- show chassis routing-engine (QFX Series) on page 509

Output Fields Table 90 on page 499 lists the output fields for the `show chassis routing-engine` command. Output fields are listed in the approximate order in which they appear.

Table 90: show chassis routing-engine Output Fields

Field Name	Field Description
Slot	(Systems with single and multiple Routing Engines) Slot number.
Current state	(Systems with multiple Routing Engines) Current state of the Routing Engine: Master , Backup , or Disabled .
Election priority	(Systems with multiple Routing Engines) Election priority for the Routing Engine: Master or Backup .
Temperature	Temperature of the air flowing past the Routing Engine.

Table 90: show chassis routing-engine Output Fields (*continued*)

Field Name	Field Description
DRAM	Total DRAM available to the Routing Engine's processor.
Memory utilization	Percentage of Routing Engine memory being used.
CPU utilization	Information about the Routing Engine's CPU utilization: <ul style="list-style-type: none"> • User—Percentage of CPU time being used by user processes. • Background—Percentage of CPU time being used by background processes. • Kernel—Percentage of CPU time being used by kernel processes. • Interrupt—Percentage of CPU time being used by interrupts. • Idle—Percentage of CPU time that is idle.
Model	Routing Engine model number.
Serial ID	(Systems with multiple Routing Engines) Identification number of the Routing Engine in this slot.
Start time	Time at which the Routing Engine started running.
Uptime	How long the Routing Engine has been running.
Last reboot reason	Reason for last reboot, including: <ul style="list-style-type: none"> • power cycle/failure—Reboot due to the switching off of the power button behind the Routing Engine, not the power button on the chassis. • watchdog—Reboot due to a hardware watchdog. • reset-button reset—(Not available on the J Series router or EX Series switch) Reboot due to pressing of the reset button on the Routing Engine. • power-button hard power off—Reboot due to pressing of the power button. • misc hardware reason—Reboot due to miscellaneous hardware reasons. • thermal shutdown—Reboot due to the router reaching a critical temperature point at which it is unsafe to continue operations. • hard disk failure—Reboot due to a hard disk failure. • reset from debugger—Reboot due to reset from the debugger. • chassis control reset—Reboot due to a chassis control reset. • bios auto recovery reset—Reboot due to a BIOS auto-recovery reset. • could not be determined—Reboot due to an undetermined reason. • Router rebooted after a normal shutdown—Reboot due to a normal shutdown.
Load averages	Routing Engine load averages for the last 1, 5, and 15 minutes.

Sample Output

```

show chassis routing-engine (M5 Router)
user@host> show chassis routing-engine
Routing Engine status:
  Temperature          25 degrees C / 77 degrees F
  DRAM                  768 MB
  Memory utilization    21 percent
  CPU utilization:

```

```

User                0 percent
Background          0 percent
Kernel              0 percent
Interrupt            0 percent
Idle                100 percent
Model               RE-2.0
Serial ID            31000007349bf701
Start time           2003-12-04 09:42:17 PST
Uptime               26 days, 1 hour, 12 minutes, 27 seconds
Last reboot reason   Router rebooted after a normal shutdown
Load averages:       1 minute   5 minute   15 minute
                     0.00       0.01       0.00

```

```

show chassis routing-engine
routing-engine (M10 Router) user@host> show chassis routing-engine
Routing Engine status:
  Temperature          25 degrees C / 77 degrees F
  DRAM                  768 MB
  Memory utilization    21 percent
  CPU utilization:
    User                0 percent
    Background          0 percent
    Kernel              0 percent
    Interrupt            0 percent
    Idle                100 percent
  Model               RE-2.0
  Serial ID            31000007349bf701
  Start time           2003-12-04 09:42:17 PST
  Uptime               26 days, 1 hour, 12 minutes, 27 seconds
  Last reboot reason   Router rebooted after a normal shutdown
  Load averages:       1 minute   5 minute   15 minute
                     0.00       0.01       0.00

```

```

show chassis routing-engine
routing-engine (M20 Router) user@host> show chassis routing-engine
Routing Engine status:
  Slot 0:
    Current state       Master
    Election priority    Master (default)
    Temperature          29 degrees C / 84 degrees F
    DRAM                  768 MB
    Memory utilization    20 percent
    CPU utilization:
      User                1 percent
      Background          0 percent
      Kernel              2 percent
      Interrupt            0 percent
      Idle                97 percent
    Model               RE-2.0
    Serial ID            58000007348d9a01
    Start time           2003-12-30 07:05:47 PST
    Uptime               3 hours, 41 minutes, 14 seconds
    Last reboot reason   Router rebooted after a normal shutdown
    Load averages:       1 minute   5 minute   15 minute
                     0.00       0.02       0.00

  Routing Engine status:
    Slot 1:
      Current state       Backup
      Election priority    Backup (default)
      Temperature          29 degrees C / 84 degrees F
      DRAM                  768 MB
      Memory utilization    0 percent
      CPU utilization:

```

```

User                0 percent
Background          0 percent
Kernel              1 percent
Interrupt           0 percent
Idle                99 percent
Model               RE-2.0
Serial ID            d800000734745701
Start time           2003-06-17 16:37:33 PDT
Uptime               195 days, 18 hours, 47 minutes, 9 seconds
Last reboot reason   Router rebooted after a normal shutdown

```

```

show chassis routing-engine
routing-engine (M40 Router)
user@host> show chassis routing-engine
Routing Engine status:
  Temperature        25 degrees C / 77 degrees F
  DRAM                768 MB
  Memory utilization  21 percent
  CPU utilization:
    User              0 percent
    Background        0 percent
    Kernel             0 percent
    Interrupt         0 percent
    Idle              100 percent
  Model               RE-2.0
  Serial ID            31000007349bf701
  Start time           2003-12-04 09:42:17 PST
  Uptime               26 days, 1 hour, 12 minutes, 27 seconds
  Last reboot reason   Router rebooted after a normal shutdown
  Load averages:      1 minute   5 minute   15 minute
                      0.00       0.01       0.00

```

```

show chassis routing-engine
routing-engine (M120 Router)
user@host> show chassis routing-engine
Routing Engine status:
  Slot 0:
    Current state      Master
    Election priority   Master (default)
    Temperature         46 degrees C / 114 degrees F
    CPU temperature     44 degrees C / 111 degrees F
    DRAM                2048 MB
    Memory utilization  18 percent
    CPU utilization:
      User              0 percent
      Background        0 percent
      Kernel             5 percent
      Interrupt         0 percent
      Idle              95 percent
    Model               RE-A-1000
    Serial ID            1000621154
    Start time           2006-10-31 17:10:05 PST
    Uptime               14 minutes, 31 seconds
    Last reboot reason   Router rebooted after a normal shutdown
    Load averages:      1 minute   5 minute   15 minute
                      0.02       0.07       0.07
  Routing Engine status:
    Slot 1:
      Current state      Backup
      Election priority   Backup (default)
      Temperature         45 degrees C / 113 degrees F
      CPU temperature     42 degrees C / 107 degrees F
      DRAM                2048 MB
      Memory utilization  15 percent
      CPU utilization:

```

```

User                0 percent
Background           0 percent
Kernel              0 percent
Interrupt            0 percent
Idle                100 percent
Model               RE-A-1000
Serial ID            1000621151
Start time           2006-10-31 17:10:04 PST
Uptime               14 minutes, 30 seconds
Last reboot reason   Router rebooted after a normal shutdown

```

```

show chassis routing-engine
routing-engine (M160 Router)

user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             43 degrees C / 109 degrees F
  DRAM                    2048 MB
  Memory utilization      11 percent
  CPU utilization:
    User                  1 percent
    Background            0 percent
    Kernel                2 percent
    Interrupt             0 percent
    Idle                  97 percent
  Model                   RE-3.0
  Serial ID               210865700403
  Start time              2003-12-23 12:25:55 PST
  Uptime                  6 days, 22 hours, 33 minutes, 24 seconds
  Last reboot reason      Router rebooted after a normal shutdown
  Load averages:         1 minute   5 minute   15 minute
                        0.24       0.13       0.04

Routing Engine status:
Slot 1:
  Current state           Backup
  Election priority       Backup (default)
  Temperature             40 degrees C / 104 degrees F
  DRAM                    2048 MB
  Memory utilization      9 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                0 percent
    Interrupt             0 percent
    Idle                  100 percent
  Model                   RE-3.0
  Serial ID               210865700332
  Start time              2003-12-23 12:25:55 PST
  Uptime                  6 days, 22 hours, 33 minutes, 21 seconds
  Last reboot reason      Router rebooted after a normal shutdown

```

```

show chassis routing-engine
routing-engine (MX240 Router)

user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Backup
  Election priority       Master (default)
  Temperature             40 degrees C / 104 degrees F
  CPU temperature         47 degrees C / 116 degrees F
  DRAM                    3584 MB
  Memory utilization      7 percent
  CPU utilization:

```

```

User                0 percent
Background          0 percent
Kernel              0 percent
Interrupt            0 percent
Idle                100 percent
Model               RE-S-2000
Serial ID            1000703522
Start time           2007-12-19 10:35:40 PST
Uptime               16 days, 3 hours, 15 minutes, 23 seconds
Last reboot reason   Router rebooted after a normal shutdown

```

**show chassis
routing-engine
(MX480 Router)**

```

user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature              41 degrees C / 105 degrees F
  CPU temperature          38 degrees C / 100 degrees F
  DRAM                     2048 MB
  Memory utilization       13 percent
  CPU utilization:
    User                   0 percent
    Background             0 percent
    Kernel                  2 percent
    Interrupt              0 percent
    Idle                   98 percent
  Model                   RE-S-1300
  Serial ID                1000697044
  Start time               2008-01-04 06:46:08 PST
  Uptime                   8 hours, 17 minutes, 16 seconds
  Last reboot reason       Router rebooted after a normal shutdown

```

**show chassis
routing-engine
(MX960 Router)**

```

user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature              37 degrees C / 98 degrees F
  CPU temperature          37 degrees C / 98 degrees F
  DRAM                     2048 MB
  Memory utilization       18 percent
  CPU utilization:
    User                   0 percent
    Background             0 percent
    Kernel                  4 percent
    Interrupt              0 percent
    Idle                   96 percent
  Model                   RE-S-1300
  Serial ID                1000617944
  Start time               2006-10-26 12:37:13 PDT
  Uptime                   6 days, 4 hours, 59 minutes, 40 seconds
  Last reboot reason       Router rebooted after a normal shutdown
  Load averages:          1 minute   5 minute  15 minute
                           0.16        0.08      0.02

```

**show chassis
routing-engine (TX
Matrix Router)**

```

user@host> show chassis routing-engine
scc-re0:
-----
Routing Engine status:
Slot 0:

```



```

Current state           Master
Election priority       Master (default)
Temperature             34 degrees C / 93 degrees F
CPU temperature         33 degrees C / 91 degrees F
DRAM                   2048 MB
Memory utilization      12 percent
CPU utilization:
  User                  0 percent
  Background            0 percent
  Kernel                2 percent
  Interrupt             0 percent
  Idle                  98 percent
Model                  RE-4.0
Serial ID               P11123900153
Start time              2004-08-05 18:42:05 PDT
Uptime                  9 days, 22 hours, 49 minutes, 50 seconds
Last reboot reason      Router rebooted after a normal shutdown
Load averages:          1 minute   5 minute  15 minute
                        0.00        0.08    0.07

```

lcc0-re0:

Routing Engine status:

Slot 0:

```

Current state           Master
Election priority       Master (default)
Temperature             33 degrees C / 91 degrees F
CPU temperature         30 degrees C / 86 degrees F
DRAM                   2048 MB
Memory utilization      12 percent
CPU utilization:
  User                  0 percent
  Background            0 percent
  Kernel                1 percent
  Interrupt             0 percent
  Idle                  98 percent
Model                  RE-3.0
Serial ID               210865700363
Start time              2004-08-05 18:42:05 PDT
Uptime                  9 days, 22 hours, 48 minutes, 20 seconds
Last reboot reason      Router rebooted after a normal shutdown
Load averages:          1 minute   5 minute  15 minute
                        0.00        0.02    0.00

```

lcc2-re0:

Routing Engine status:

Slot 0:

```

Current state           Master
Election priority       Master (default)
Temperature             34 degrees C / 93 degrees F
CPU temperature         35 degrees C / 95 degrees F
DRAM                   2048 MB
Memory utilization      12 percent
CPU utilization:
  User                  0 percent
  Background            0 percent
  Kernel                2 percent
  Interrupt             0 percent
  Idle                  98 percent
Model                  RE-4.0

```

```

Serial ID                P11123900126
Start time               2004-08-05 18:42:05 PDT
Uptime                  9 days, 22 hours, 49 minutes, 4 seconds
Last reboot reason      Router rebooted after a normal shutdown
Load averages:          1 minute   5 minute   15 minute
                        0.01       0.01       0.0

```

show chassis routing-engine lcc (TX Matrix Router)

```

user@host> show chassis routing-engine 0 lcc 0
lcc0-re0:

```

```

-----
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             33 degrees C / 91 degrees F
  CPU temperature         30 degrees C / 86 degrees F
  DRAM                    2048 MB
  Memory utilization      12 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                1 percent
    Interrupt             0 percent
    Idle                  98 percent
  Model                   RE-3.0
  Serial ID               210865700363
  Start time              2004-08-05 18:42:05 PDT
  Uptime                  7 days, 22 hours, 49 minutes, 6 seconds
  Last reboot reason      Router rebooted after a normal shutdown
  Load averages:         1 minute   5 minute   15 minute
                        0.00       0.00       0.00

```

show chassis routing-engine bios (TX Matrix Router)

```

user@host> show chassis routing-engine bios
scc-re0:

```

```

-----
Routing Engine BIOS Version: V1.0.0
lcc0-re0:
-----
Routing Engine BIOS Version: V1.0.17
lcc2-re0:
-----
Routing Engine BIOS Version: V1.0.0

```

show chassis routing-engine (TX Matrix Plus Router)

```

user@host> show chassis routing-engine
sfc0-re0:

```

```

-----
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             27 degrees C / 80 degrees F
  CPU temperature         42 degrees C / 107 degrees F
  DRAM                    3327 MB
  Memory utilization      12 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                2 percent
    Interrupt             0 percent
    Idle                  98 percent

```

```

Model RE-TXP-SFC
Serial ID 737A-1024
Start time 2009-05-11 17:39:49 PDT
Uptime 3 hours, 45 minutes, 25 seconds
Last reboot reason Router rebooted after a normal shutdown.
Load averages: 1 minute 5 minute 15 minute
                0.00      0.00      0.00

Routing Engine status:
Slot 1:
  Current state Backup
  Election priority Backup (default)
  Temperature 29 degrees C / 84 degrees F
  CPU temperature 43 degrees C / 109 degrees F
  DRAM 3327 MB
  Memory utilization 11 percent
  CPU utilization:
    User 0 percent
    Background 0 percent
    Kernel 0 percent
    Interrupt 0 percent
    Idle 100 percent
  Model RE-TXP-SFC
  Serial ID 737A-1024
  Start time 2009-05-11 17:08:54 PDT
  Uptime 4 hours, 16 minutes, 52 seconds
  Last reboot reason 0x1:power cycle/failure

```

```
1cc0-re0:
```

```

-----
Routing Engine status:
Slot 0:
  Current state Master
  Election priority Master (default)
  Temperature 30 degrees C / 86 degrees F
  CPU temperature 43 degrees C / 109 degrees F
  DRAM 3327 MB
  Memory utilization 9 percent
  CPU utilization:
    User 0 percent
    Background 0 percent
    Kernel 2 percent
    Interrupt 0 percent
    Idle 98 percent
  Model RE-TXP-LCC
  Serial ID 737F-1024
  Start time 2009-05-11 17:40:32 PDT
  Uptime 3 hours, 44 minutes, 51 seconds
  Last reboot reason Router rebooted after a normal shutdown.
  Load averages: 1 minute 5 minute 15 minute
                  0.00      0.00      0.00

Routing Engine status:
Slot 1:
  Current state Backup
  Election priority Backup (default)
  Temperature 30 degrees C / 86 degrees F
  CPU temperature 43 degrees C / 109 degrees F
  DRAM 3327 MB
  Memory utilization 9 percent
  CPU utilization:
    User 0 percent
    Background 0 percent

```

```

Kernel                0 percent
Interrupt              0 percent
Idle                  100 percent
Model                 RE-TXP-LCC
Serial ID              737F-1024
Start time             2009-05-06 17:31:32 PDT
Uptime                 5 days, 3 hours, 54 minutes, 19 seconds
Last reboot reason     Router rebooted after a normal shutdown.

```

**show chassis
routing-engine lcc (TX
Matrix Plus Router)**

```

user@host> show chassis routing-engine 0 lcc 0
lcc0-re0:

```

```

-----
Routing Engine status:

```

```

Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature              30 degrees C / 86 degrees F
  CPU temperature          43 degrees C / 109 degrees F
  DRAM                     3327 MB
  Memory utilization       9 percent
  CPU utilization:
    User                   0 percent
    Background              0 percent
    Kernel                  2 percent
    Interrupt               0 percent
    Idle                    98 percent
  Model                   RE-TXP-LCC
  Serial ID                737F-1024
  Start time               2009-05-11 17:40:32 PDT
  Uptime                   3 hours, 45 minutes, 26 seconds
  Last reboot reason       Router rebooted after a normal shutdown.
  Load averages:          1 minute 5 minute 15 minute
                           0.00      0.00      0.00

```

```

Routing Engine status:

```

```

Slot 1:
  Current state           Backup
  Election priority       Backup (default)
  Temperature              30 degrees C / 86 degrees F
  CPU temperature          43 degrees C / 109 degrees F
  DRAM                     3327 MB
  Memory utilization       9 percent
  CPU utilization:
    User                   0 percent
    Background              0 percent
    Kernel                  0 percent
    Interrupt               0 percent
    Idle                    100 percent
  Model                   RE-TXP-LCC
  Serial ID                737F-1024
  Start time               2009-05-06 17:31:32 PDT
  Uptime                   5 days, 3 hours, 54 minutes, 59 seconds
  Last reboot reason       Router rebooted after a normal shutdown.

```

**show chassis
routing-engine bios
(TX Matrix Plus
Router)**

```

user@host> show chassis routing-engine bios
sfc0-re0:

```

```

-----
Routing Engine BIOS Version: V0.0.Z

```

```

lcc0-re0:

```

```

-----
Routing Engine BIOS Version: V0.0.N

```

```
show chassis routing-engine (QFX Series) user@switch> show chassis routing-engine
Routing Engine status:
Slot 0:
Current state Master
Election priority Master (default)
DRAM 2820 MB
Memory utilization 49 percent
CPU utilization:
User 1 percent
Background 0 percent
Kernel 1 percent
Interrupt 0 percent
Idle 97 percent
Model QFX3500-48S4Q
Serial ID S/N ED3709
Uptime 3 days, 4 hours, 29 minutes, 42 seconds
Last reboot reason 0x200:chassis control reset
Load averages: 1 minute 5 minute 15 minute
0.37 0.26 0.19
```

show chassis scb

Syntax	show chassis scb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40 router only) Display System Control Board (SCB) status information.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show chassis scb on page 511
Output Fields	Table 91 on page 510 lists the output fields for the show chassis scb command. Output fields are listed in the approximate order in which they appear.

Table 91: show chassis scb Output Fields

Field Name	Field Description
Temperature	Temperature of the air passing by the SCB, in degrees Celsius.
CPU utilization	Total percentage of CPU being used by the SCB's processor.
Interrupt utilization	Of the total CPU being used by the SCB's processor, the percentage being used for interrupts.
Heap utilization	Percentage of heap space being used by the SCB's processor.
Buffer utilization	Percentage of buffer space being used by the SCB's processor.
DRAM	Total DRAM available to the SCB's processor.
Start time	Time when the SCB started running.
Uptime	How long the SCB has been running.
Internet Processor memory	Information about the memory of the Internet Processor ASIC on the SCB: <ul style="list-style-type: none"> • IP routes—Number of IP routes known to the Internet Processor. • MPLS routes—Number of MPLS routes known to the Internet Processor. • SRAM banks enabled—Which SRAM banks are enabled. • SRAM size—Size of SCB SRAM, in bytes. • SRAM used—Amount of SRAM used, in bytes. • SRAM utilization—Percentage of SRAM used.

Sample Output

```
show chassis scb  user@host> show chassis scb
SCB status:
  Temperature:          30 Centigrade
  CPU utilization:      5 percent
  Interrupt utilization: 0 percent
  Heap utilization:     0 percent
  Buffer utilization:    2 percent
  DRAM:                 64 Mbytes
  Start time:           1998-10-28 18:35:46 UTC
  Uptime:               6 minutes, 16 seconds
  Internet Processor memory:
    IP routes:          16
    MPLS routes:        1
    SRAM banks enabled: [ 1 1 1 1 ]
    SRAM size:          4 Mbytes
    SRAM used:          256 bytes
    SRAM utilization:    0 percent
```

show chassis sfm

Syntax	show chassis sfm <detail < <i>sfm-slot</i> >>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Display Switching and Forwarding Module (SFM) status information.
Options	<p>none—Display standard status information about all SFMs.</p> <p>detail—(Optional) Display detailed SFM status information.</p> <p><i>sfm-slot</i>—(Optional) Display status information about the SFM in the specified slot only. For the M40e router, replace <i>sfm-slot</i> with 0 or 1. For the M160 router, replace <i>sfm-slot</i> with a value from 0 through 3.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis sfm on page 189 request chassis sfm master switch on page 190
List of Sample Output	<p>show chassis sfm (M160 Router) on page 513</p> <p>show chassis sfm detail (M40e Router) on page 513</p> <p>show chassis sfm detail (M160 Router) on page 514</p>
Output Fields	Table 92 on page 512 lists the output fields for the show chassis sfm command. Output fields are listed in the approximate order in which they appear.

Table 92: show chassis sfm Output Fields

Field Name	Field Description	Level of Output
Slot	Slot number.	All levels
State	<p>Status of the SFM. State can be any of the following:</p> <ul style="list-style-type: none"> Online—SFM is online and running. Online-Standby (M40e router only)—SFM is online, operating as Standby. Offline—SFM is powered down. Empty—No SFM is present. 	All levels
Reason	If the status is Offline , reason for this state.	All levels
Temp	Temperature of air passing by the SFM, in degrees Celsius.	none specified
CPU Utilization (%)	Information about CPU usage.	none specified

Table 92: show chassis sfm Output Fields (*continued*)

Field Name	Field Description	Level of Output
Total	Total percentage of the CPU being used by the SFM's processor.	All levels
Interrupt	Of the total CPU being used by the SFM's processor, the percentage being used for interrupts.	All levels
Memory Utilization	Information about memory usage.	none specified
DRAM	Total DRAM available to the SFM's processor, in megabytes (MB).	All levels
Heap	Percentage of heap space (dynamic memory) being used by the SFM's processor. If this number exceeds 80 percent, it might indicate a software problem (memory leak).	All levels
Buffer	Percentage of buffer space being used by the SFM's processor for buffering internal messages.	All levels
SPP Temperature	Temperature of air passing by the Switch Plane Processor card, in degrees Celsius and Fahrenheit	detail
SPR Temperature	Temperature of air passing by the Switch Plane Router card, in degrees Celsius and Fahrenheit.	detail
Total CPU DRAM	Total amount of CPU DRAM being used by the SFM's processor.	detail
Total SSRAM	Total amount of SSRAM being used by the SFM's processor.	detail
Internet processor II	(M160 router only) Processor type.	detail
Start time	Time this SFM became active.	detail
Uptime	How long the SFM has been up and running.	detail
Packet scheduling mode	(M160 router only) Enabled or disabled.	detail

Sample Output

show chassis sfm
(M160 Router)

```
user@host> show chassis sfm
SFM status:
```

Slot	State	Temp (C)	CPU Total	Utilization (%) Interrupt	Memory DRAM (MB)	Utilization (%) Heap	Utilization (%) Buffer
0	Online	39	0	0	64	0	6
1	Online	43	0	0	64	0	6
2	Empty	0	0	0	0	0	0
3	Empty	0	0	0	0	0	0

show chassis sfm
detail (M40e Router)

```
user@host> show chassis sfm detail
```

```

Slot 0 information:
  State                               Offline
  Reason:                             - power configured off
Slot 1 information:
  State                               Present
  SPP temperature                     0 degrees C / 32 degrees F
  SPR temperature                     0 degrees C / 32 degrees F
  Total CPU DRAM                      0 MB
  Total SSRAM                         0 MB

show chassis sfm    user@host> show chassis sfm detail
detail (M160 Router)
Slot 0 information:
  State                               Online
  SPP temperature                     37 degrees C / 98 degrees F
  SPR temperature                     39 degrees C / 102 degrees F
  Total CPU DRAM                      64 MB
  Total SSRAM                         8 MB
  Internet Processor II               Version 1, Foundry IBM, Part number 9
  Start time:                         2004-08-17 09:23:08 PDT
  Uptime:                             72 days, 1 hour, 15 minutes, 57 seconds
Slot 1 information:
  State                               Online
  SPP temperature                     36 degrees C / 96 degrees F
  SPR temperature                     37 degrees C / 98 degrees F
  Total CPU DRAM                      64 MB
  Total SSRAM                         8 MB
  Internet Processor II               Version 1, Foundry IBM, Part number 9
  Start time:                         2004-08-17 09:23:08 PDT
  Uptime:                             72 days, 1 hour, 15 minutes, 57 seconds
Slot 2 information:
  ....
Packet scheduling mode : Disabled

```

show chassis sibs

Syntax	show chassis sibs
Syntax (TX Matrix Router)	show chassis sibs <fcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis sibs <fcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(M320 and T Series routers only) Display Switch Interface Boards (SIBs) status information.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display the SIB status for the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display the SIB status for the TX Matrix Plus router and its attached T1600 routers.</p> <p>fcc <i>number</i>—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display SIB status information for a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display SIB status information for a specified T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) (Optional) Display SIB status information for the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display SIB status information for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis sib on page 191 show chassis spmb sibs on page 528
List of Sample Output	<p>show chassis sibs (T640 Router) on page 517</p> <p>show chassis sibs (TX Matrix Router) on page 517</p> <p>show chassis sibs (T1600 Router) on page 518</p> <p>show chassis sibs (TX Matrix Plus Router) on page 518</p> <p>show chassis sibs sfc (TX Matrix Plus Router) on page 519</p> <p>show chassis sibs fcc (TX Matrix Plus Router) on page 520</p> <p>show chassis sibs (M320 Router) on page 520</p>
Output Fields	Table 93 on page 516 lists the output fields for the show chassis sibs command. Output fields are listed in the approximate order in which they appear.

Table 93: show chassis sibs Output Fields

Field Name	Field Description
Slot	SIB slot number.
Type	(TX Matrix Plus router only) SIB type.
Uptime	How long the SIB has been up and running.
State	<p>SIB status:</p> <ul style="list-style-type: none"> • Activating—SIB is coming online; this is a transitional state. • Deactivating—SIB is going offline; this is a transitional state. • Connected—SIBs on a T1600 router are connected and trained but are either not online or are spare, because the plane on the TX Matrix Plus router (or switch-fabric chassis) is still offline. • Disconnected—SIBs on all T640 routers on the TX Matrix router (or switch-card chassis) are in the Disconnected state, because a SIB on the SCC has gone offline. Likewise, SIBs on all T1600 routers on the TX Matrix Plus router (or switch-fabric chassis) are in the Disconnected state, because a SIB on the SFC has gone offline. • Online—SIB is operational and running. • Offline—SIB is powered down. <p>NOTE: If a SIB transitions to the Offline state, the command displays an appropriate reason in the output. For instance, if the SIB is taken offline using the request chassis sib command, the show chassis sibs command displays --- Offlined by cli command --- in the output.</p> <ul style="list-style-type: none"> • Spare—SIB is redundant and will move to active state if one of the working SIBs fails to pass traffic. • Empty—No SIB is present. • Fault—SIB is in an alarmed state in which the SIB's plane is not operational for one of the following reasons: <ul style="list-style-type: none"> • Onboard fabric ASIC is not operational. • Fiber-optic connector faults. • FPC connector faults. • SIB midplane connector faults. • Check—SIB is in the Check state because of the following reasons: <ul style="list-style-type: none"> • SIB is not inserted properly. • Destination errors are detected on the SIB. In this case, the Packet Forwarding Engine stops using the SIB to send traffic to the affected destination Packet Forwarding Engine. • Link errors are detected on the channel between the SIB and a Packet Forwarding Engine. Link errors can be detected at initialization time or runtime: <ul style="list-style-type: none"> • Link errors caused by a link training failure at initialization time—The Packet Forwarding Engine does not use the SIB to send traffic. The show chassis fabric fpcs command shows Plane disabled as status for this link.

Table 93: show chassis sibs Output Fields (*continued*)

Field Name	Field Description
	<ul style="list-style-type: none"> Link errors caused by CRC errors detected at runtime—The Packet Forwarding Engine continues to use the SIB to send traffic. The show chassis fabric fpcs command shows Link error as the status for this link. <p>NOTE: For SIBs in the Check state, the output displays some additional information:</p> <ul style="list-style-type: none"> In Junos OS Release 9.6 and later, the Check state message shows the number of Packet Forwarding Engines in the plane having destination errors. For example, Check (10 destination errors) indicates 10 Packet Forwarding Engines having destination errors. If there are no destination errors, and if the SIB transitions to the Check state because of link errors only, the Check state message shows Check (0 destination errors). In Junos OS Release 9.5 and earlier, the Check state message shows Check (destination errors) if there are Packet Forwarding Engines with destination errors in this plane. However, it does not show the number of Packet Forwarding Engines having destination errors. If there are no destination errors and if the SIB transitions to the Check state because of link errors only, the Check state message shows Check (no destination errors). <p>If the SIB is in a Check state, because of destination errors, the CLI displays an additional line in the output, use "show chassis fabric fpcs" and "show chassis fabric sibs" for more details.</p> <ul style="list-style-type: none"> SFC Error—If an F13 SIB on the TX Matrix Plus router (SFC) transitions to the Fault state (for instance, because of link errors), and then if an LCC SIB (connected to the F13 SIB) comes online, the LCC SIB transitions to the SFC Error state. This state indicates that the F13 SIB to which the LCC SIB is connected has errors. <p>NOTE: The Connected, Disconnected, and SFC Error states are only applicable to the SIBs on an LCC.</p>

Sample Output

show chassis sibs
(T640 Router)

```
user@host> show chassis sibs
Slot  State                      Uptime
0      Empty
1      Offline                    --- Offlined by cli command ---
2      Check (21 destination errors) 1 day, 1 hour, 32 minutes, 55 seconds
3      Check (0 destination errors)  1 day, 1 hour, 32 minutes, 45 seconds
4      Empty

use "show chassis fabric fpcs" and "show chassis fabric sibs" for more details
```

show chassis sibs (TX
Matrix Router)

```
user@host> show chassis sibs
scc-re0:
-----
Slot  State                      Uptime
0      Empty
1      Empty
```

```

2    Offline          --- Offlined by cli command ---
3    Offline
4    Online           7 days, 21 hours, 50 minutes, 4 seconds
lcc0-re0:

```

```

-----
Slot  State                      Uptime
0    Offline                    --- Offlined by cli command ---
1    Empty
2    Check (21 destination errors) 1 day, 1 hour, 32 minutes, 55 seconds
3    Check (0 destination errors)  1 day, 1 hour, 32 minutes, 45 seconds
4    Empty

```

use "show chassis fabric fpcs" and "show chassis fabric sibs" for more details

show chassis sibs (T1600 Router)

```

user@host> show chassis sibs
Slot
Slot  State                      Uptime
0    Check (destination errors)  2 hours, 23 minutes, 2 seconds
1    Offline                    --- Offlined by cli command ---
2    Check (destination errors)  2 hours, 23 minutes, 3 seconds
3    Check (destination errors)  2 hours, 23 minutes, 3 seconds
4    Check (destination errors)  2 hours, 23 minutes, 3 seconds

```

use "show chassis fabric fpcs" and "show chassis fabric sibs" for more details

show chassis sibs (TX Matrix Plus Router)

```

user@host> show chassis sibs
sfc0-re0:
-----
Slot  State                      Type          Uptime
0    Offline                    SIB F13      --- Offlined by cli command ---
1    Online                     SIB F13      4 hours, 1 minute, 39 seconds
2    Invalid
3    Empty
4    Empty
5    Invalid
6    Empty
7    Empty
8    Empty
9    Empty
10   Invalid
11   Empty
12   Empty
13   Invalid
14   Invalid
15   Invalid
0/0  Online                       SIB F2S      4 hours, 2 minutes, 17 seconds
0/2  Online                       SIB F2S      4 hours, 2 minutes, 15 seconds
0/4  Online                       SIB F2S      4 hours, 2 minutes, 14 seconds
0/6  Online                       SIB F2S      4 hours, 2 minutes, 13 seconds
1/0  Online                       SIB F2S      4 hours, 2 minutes, 25 seconds
1/2  Online                       SIB F2S      4 hours, 2 minutes, 24 seconds
1/4  Online                       SIB F2S      4 hours, 2 minutes, 23 seconds
1/6  Online                       SIB F2S      4 hours, 2 minutes, 22 seconds
2/0  Online                       SIB F2S      4 hours, 2 minutes, 20 seconds
2/2  Online                       SIB F2S      4 hours, 2 minutes, 19 seconds
2/4  Online                       SIB F2S      4 hours, 2 minutes, 18 seconds
2/6  Empty
3/0  Empty
3/2  Empty
3/4  Empty

```

```

3/6 Empty
4/0 Empty
4/2 Empty
4/4 Empty
4/6 Empty

```

```
lcc0-re0:
```

```

-----
Slot  State                               Uptime
  0    Check (destination errors)         2 hours, 23 minutes, 2 seconds
  1    Offline                           --- Offlined by cli command ---
  2    Check (destination errors)         2 hours, 23 minutes, 3 seconds
  3    Check (destination errors)         2 hours, 23 minutes, 3 seconds
  4    Check (destination errors)         2 hours, 23 minutes, 3 seconds

```

use "show chassis fabric fpcs" and "show chassis fabric sibs" for more details

show chassis sibs sfc
(TX Matrix Plus
Router)

```
user@host> show chassis sibs sfc 0
```

```
sfc0-re0:
```

```

-----
Slot  State                               Type          Uptime
  0    Online                             SIB F13        4 hours, 15 minutes, 29 seconds
  1    Offline                           --- Offlined by cli command ---
  2    Invalid
  3    Empty
  4    Empty
  5    Invalid
  6    Empty
  7    Empty
  8    Empty
  9    Empty
 10    Invalid
 11    Empty
 12    Empty
 13    Invalid
 14    Invalid
 15    Invalid
0/0    Online                             SIB F2S        4 hours, 15 minutes, 50 seconds
0/2    Online                             SIB F2S        4 hours, 15 minutes, 48 seconds
0/4    Online                             SIB F2S        4 hours, 15 minutes, 47 seconds
0/6    Online                             SIB F2S        4 hours, 15 minutes, 46 seconds
1/0    Online                             SIB F2S        4 hours, 15 minutes, 58 seconds
1/2    Online                             SIB F2S        4 hours, 15 minutes, 57 seconds
1/4    Online                             SIB F2S        4 hours, 15 minutes, 56 seconds
1/6    Online                             SIB F2S        4 hours, 15 minutes, 55 seconds
2/0    Online                             SIB F2S        4 hours, 15 minutes, 53 seconds
2/2    Online                             SIB F2S        4 hours, 15 minutes, 52 seconds
2/4    Online                             SIB F2S        4 hours, 15 minutes, 51 seconds
2/6    Empty
3/0    Empty
3/2    Empty
3/4    Empty
3/6    Empty
4/0    Empty
4/2    Empty
4/4    Empty
4/6    Empty

```

show chassis sibs lcc user@host> **show chassis sibs lcc 0**
(TX Matrix Plus lcc0-re0:
Router)

Slot	State	Uptime
0	SFC error	3 seconds
1	Offline	--- Offlined by cli command ---
2	Empty	
3	Online	1 hour, 18 minutes, 18 seconds
4	Online	1 hour, 18 minutes, 3 seconds

show chassis sibs user@host> **show chassis sibs**
(M320 Router)

0	Online	1 hour, 18 minutes, 3 seconds
1	Offline	--- Offlined by cli command ---
2	Online	1 hour, 18 minutes, 18 seconds
3	Online	1 hour, 18 minutes, 3 seconds

show chassis spmb

Syntax	show chassis spmb
Syntax (TX Matrix Routers)	show chassis spmb <sibs> <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Routers)	show chassis spmb <sibs> <lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. sibs option introduced for the T1600 and TX Matrix Plus routers in Junos OS Release 9.6.
Description	(T Series routers only) Display Switch Processor Mezzanine Board (SPMB) status information.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display SPMB status for the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display SPMB status for the TX Matrix Plus router and its attached T1600 routers.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display information about the SPMB on a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display information about the SPMB on a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) (Optional) Display information about the SPMB on the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display information about the SPMB on the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p> <p>sibs—(TX Matrix and TX Matrix Plus routers only) (Optional) Display information about the SIBS on the TX Matrix router (or switch-card chassis) or TX Matrix Plus routers (or switch-fabric chassis). The sibs option has the following sub-options:</p> <p>lcc <i>number</i> (TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display information about the SIBs on a specified T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display information about the SIBs on a specified T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc <i>number</i>—(TX Matrix routers only) (Optional) Display information about the SIBs on the TX Matrix router (or switch-card chassis). Replace <i>number</i> with 0.</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display information about the SIBs on the TX Matrix Plus router (or switch-fabric chassis). Replace **number** with 0.

Required Privilege Level view

Related Documentation

- request chassis sib on page 191
- show chassis spmb sibs on page 528

List of Sample Output

- show chassis spmb on page 523
- show chassis spmb lcc (TX Matrix Router) on page 523
- show chassis spmb scc (TX Matrix Router) on page 523
- show chassis spmb (T1600 Router) on page 523
- show chassis spmb sibs (T1600 Router) on page 523
- show chassis spmb (TX Matrix Plus Router) on page 524
- show chassis spmb lcc (TX Matrix Plus Router) on page 525
- show chassis spmb scc (TX Matrix Plus Router) on page 526
- show chassis spmb sibs (TX Matrix Plus Router) on page 526

Output Fields Table 94 on page 522 lists the output fields for the **show chassis spmb** command. Output fields are listed in the approximate order in which they appear.

Table 94: show chassis spmb Output Fields

Field Name	Field Description
Slot	SPMB slot number: 0 or 1.
State	SPMB status: <ul style="list-style-type: none"> • Online—SPMB is operational and running. • Offline—SPMB is powered down.
Total CPU Utilization (%)	Total percentage of CPU being used by the SPMB processor.
Interrupt CPU Utilization (%)	Of the total CPU being used by the SPMB processor, the percentage being used for interrupts.
Memory Heap Utilization (%)	Percentage of heap space (dynamic memory) being used by the FPC processor. If this number exceeds 80 percent, there may be a software problem (memory leak).
Buffer Utilization (%)	Percentage of buffer space being used by the SPMB processor for buffering internal messages.
Start time	Time at which the SPMB last came online.
Uptime	How long the SPMB has been up and running.

Sample Output

```

show chassis spmb user@host> show chassis spmb
Slot 0 information:
  State                               Online
  Total CPU Utilization                1%
  Interrupt CPU Utilization             0%
  Memory Heap Utilization              0%
  Buffer Utilization                   40%
  Start time:                          2001-08-27 14:05:04 PDT
  Uptime:                              46 minutes, 36 seconds

```

```

show chassis spmb lcc user@host> show chassis spmb lcc 0
(TX Matrix Router) lcc0-re0:
-----
Slot 0 information:
  State                               Online
  Total CPU Utilization                0%
  Interrupt CPU Utilization             0%
  Memory Heap Utilization              0%
  Buffer Utilization                   42%
  Start time:                          2004-08-05 18:43:38 PDT
  Uptime:                              8 days, 55 minutes, 52 seconds

```

```

show chassis spmb scc user@host> show chassis spmb scc
(TX Matrix Router) scc-re0:
-----
Slot 0 information:
  State                               Online
  Total CPU Utilization                1%
  Interrupt CPU Utilization             0%
  Memory Heap Utilization              0%
  Buffer Utilization                   42%
  Start time:                          2004-08-05 18:43:37 PDT
  Uptime:                              8 days, 1 hour, 6 minutes, 51 seconds

```

```

show chassis spmb user@host> show chassis spmb
(T1600 Router) Slot 0 information:
  State                               Online
  Total CPU Utilization                2%
  Interrupt CPU Utilization             0%
  Memory Heap Utilization              0%
  Buffer Utilization                   24%
  Start time:                          2009-05-07 22:34:03 PDT
  Uptime:                              3 days, 4 hours, 14 minutes, 33 seconds
Slot 1 information:
  State                               Online - Standby
  Total CPU Utilization                0%
  Interrupt CPU Utilization             0%
  Memory Heap Utilization              0%
  Buffer Utilization                   24%
  Start time:                          2009-05-07 22:34:02 PDT
  Uptime:                              3 days, 4 hours, 14 minutes, 34 seconds

```

```

show chassis spmb user@host> show chassis spmb sibs
sibs (T1600 Router) Slot State      Uptime
0    Check      3 days, 4 hours, 11 minutes, 59 seconds
1    Disconnected 3 days, 4 hours, 12 minutes, 36 seconds
2    Disconnected 3 days, 4 hours, 12 minutes, 26 seconds

```

```

3    Disconnected      3 days, 4 hours, 12 minutes, 17 seconds
4    Disconnected      3 days, 4 hours, 12 minutes, 8 seconds

```

show chassis spmb
(TX Matrix Plus
Router)

```

user@host> show chassis spmb
sfc0-re0:

```

```

-----
Slot 0 information:
State                Online
Total CPU Utilization 84%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:20 PDT
Uptime:               46 minutes, 6 seconds

```

```

Slot 1 information:
State                Online - Standby
Total CPU Utilization 0%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:20 PDT
Uptime:               46 minutes, 6 seconds

```

```

lcc0-re1:

```

```

-----
Slot 0 information:
State                Online - Standby
Total CPU Utilization 0%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:09 PDT
Uptime:               46 minutes, 24 seconds

```

```

Slot 1 information:
State                Online
Total CPU Utilization 5%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:08 PDT
Uptime:               46 minutes, 25 seconds

```

```

lcc1-re1:

```

```

-----
Slot 0 information:
State                Online - Standby
Total CPU Utilization 1%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:09 PDT
Uptime:               46 minutes, 24 seconds

```

```

Slot 1 information:
State                Online
Total CPU Utilization 5%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:10 PDT
Uptime:               46 minutes, 23 seconds

```

```
lcc2-re1:
```

```
-----
Slot 0 information:
```

```
State                Online - Standby
Total CPU Utilization 0%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:08 PDT
Uptime:               46 minutes, 25 seconds
```

```
Slot 1 information:
```

```
State                Online
Total CPU Utilization 5%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:10 PDT
Uptime:               46 minutes, 23 seconds
```

```
lcc3-re1:
```

```
-----
Slot 0 information:
```

```
State                Online - Standby
Total CPU Utilization 1%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:10 PDT
Uptime:               46 minutes, 23 seconds
```

```
Slot 1 information:
```

```
State                Online
Total CPU Utilization 5%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:09 PDT
Uptime:               46 minutes, 24 seconds
```

```
show chassis spmb lcc user@host> show chassis spmb lcc 2
(TX Matrix Plus      lcc2-re1:
Router)
```

```
-----
Slot 0 information:
```

```
State                Online - Standby
Total CPU Utilization 0%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:08 PDT
Uptime:               45 minutes, 18 seconds
```

```
Slot 1 information:
```

```
State                Online
Total CPU Utilization 6%
Interrupt CPU Utilization 0%
Memory Heap Utilization 0%
Buffer Utilization    24%
Start time:           2009-05-11 01:25:10 PDT
Uptime:               45 minutes, 16 seconds
```

show chassis spmb scc user@host> **show chassis spmb sfc 0**
(TX Matrix Plus sfc0-re0:

Router)

```
-----
Slot 0 information:
  State                               Online
  Total CPU Utilization               87%
  Interrupt CPU Utilization           0%
  Memory Heap Utilization             0%
  Buffer Utilization                  24%
  Start time:                        2009-05-11 01:25:20 PDT
  Uptime:                            43 minutes, 32 seconds

Slot 1 information:
  State                               Online - Standby
  Total CPU Utilization               0%
  Interrupt CPU Utilization           0%
  Memory Heap Utilization             0%
  Buffer Utilization                  24%
  Start time:                        2009-05-11 01:25:20 PDT
  Uptime:                            43 minutes, 32 seconds
```

show chassis spmb user@host> **show chassis spmb sibs**
sibs (TX Matrix Plus sfc0-re0:

Router)

```
-----
Slot  State          Type          Uptime
0      Online         SIB F13      1 hour, 18 minutes, 54 seconds
1      Online         SIB F13      1 hour, 18 minutes, 45 seconds
2      Invalid
3      Online         SIB F13      1 hour, 20 minutes, 21 seconds
4      Online         SIB F13      1 hour, 20 minutes, 18 seconds
5      Invalid
6      Online         SIB F13      1 hour, 19 minutes, 51 seconds
7      Fault          SIB F13
8      Online         SIB F13      1 hour, 19 minutes, 17 seconds
9      Online         SIB F13      1 hour, 19 minutes, 13 seconds
10     Invalid
11     Online         SIB F13      1 hour, 17 minutes, 54 seconds
12     Online         SIB F13      1 hour, 17 minutes, 51 seconds
13     Invalid
14     Invalid
15     Invalid
0/0    Online         SIB F2S      1 hour, 18 minutes, 52 seconds
0/2    Online         SIB F2S      1 hour, 18 minutes, 51 seconds
0/4    Online         SIB F2S      1 hour, 18 minutes, 49 seconds
0/6    Online         SIB F2S      1 hour, 18 minutes, 48 seconds
1/0    Online         SIB F2S      1 hour, 20 minutes, 16 seconds
1/2    Online         SIB F2S      1 hour, 20 minutes, 15 seconds
1/4    Online         SIB F2S      1 hour, 20 minutes, 14 seconds
1/6    Online         SIB F2S      1 hour, 20 minutes, 13 seconds
2/0    Online         SIB F2S      1 hour, 19 minutes, 48 seconds
2/2    Online         SIB F2S      1 hour, 19 minutes, 47 seconds
2/4    Online         SIB F2S      1 hour, 19 minutes, 46 seconds
2/6    Online         SIB F2S      1 hour, 19 minutes, 44 seconds
3/0    Online         SIB F2S      1 hour, 19 minutes, 24 seconds
3/2    Online         SIB F2S      1 hour, 19 minutes, 22 seconds
3/4    Online         SIB F2S      1 hour, 19 minutes, 21 seconds
3/6    Online         SIB F2S      1 hour, 19 minutes, 20 seconds
4/0    Online         SIB F2S      1 hour, 18 minutes, 2 seconds
4/2    Online         SIB F2S      1 hour, 18 minutes
4/4    Online         SIB F2S      1 hour, 17 minutes, 58 seconds
4/6    Online         SIB F2S      1 hour, 17 minutes, 58 seconds
```

lcc0-re1:

Slot	State	Uptime
0	Online	1 hour, 18 minutes, 58 seconds
1	Online	1 hour, 20 minutes, 25 seconds
2	Fault	
3	Online	1 hour, 18 minutes, 30 seconds
4	Online	1 hour, 18 minutes, 28 seconds

lcc1-re1:

Slot	State	Uptime
0	Online	1 hour, 18 minutes, 58 seconds
1	Online	1 hour, 20 minutes, 26 seconds
2	Fault	
3	Online	1 hour, 18 minutes, 22 seconds
4	Online	1 hour, 18 minutes, 20 seconds

lcc2-re1:

Slot	State	Uptime
0	Online	1 hour, 18 minutes, 19 seconds
1	Online	1 hour, 20 minutes, 25 seconds
2	Fault	
3	Online	1 hour, 18 minutes, 17 seconds
4	Online	1 hour, 18 minutes, 15 seconds

lcc3-re1:

Slot	State	Uptime
0	Online	1 hour, 18 minutes, 27 seconds
1	Online	1 hour, 20 minutes, 24 seconds
2	Fault	
3	Online	1 hour, 18 minutes, 25 seconds
4	Online	1 hour, 18 minutes, 23 seconds

show chassis spmb sibs

Syntax	show chassis spmb sibs
Syntax (TX Matrix Router)	show chassis spmb sibs <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis spmb sibs <lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	(T Series routers only) Display Switch Processor Mezzanine Board (SPMB) Switch Interface Board (SIB) status information.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display the SIB status for the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display the SIB status for the TX Matrix Plus router and its attached T1600 routers.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display SIB status information for a specified T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display SIB status information for a specified T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix router only) (Optional) Display SIB status information for the TX Matrix router (or switch-card chassis).</p> <p>sfc—(TX Matrix Plus router only) (Optional) Display SIB status information for the TX Matrix Plus router (or switch-fabric chassis).</p>
Additional Information	On a T Series router, you can use either this command or the show chassis sibs command to produce the same output. The show chassis sibs command is supported on the M320 router and on the T Series routers.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis spmb restart on page 197
List of Sample Output	<p>show chassis spmb sibs (T320 Router) on page 529</p> <p>show chassis-spmb-sibs (T1600 Router) on page 529</p> <p>show chassis spmb sibs (TX Matrix Router) on page 530</p> <p>show chassis spmb sibs lcc (TX Matrix Router) on page 530</p> <p>show chassis spmb sibs scc (TX Matrix Router) on page 530</p> <p>show chassis spmb sibs (TX Matrix Plus Router) on page 530</p> <p>show chassis spmb sibs sfc (TX Matrix Plus Router) on page 531</p>

Output Fields Table 95 on page 529 lists the output fields for the **show chassis spmb sibs** command. Output fields are listed in the approximate order in which they appear.

Table 95: show chassis spmb sibs Output Fields

Field Name	Field Description
Slot	<p>SIB slot number:</p> <ul style="list-style-type: none"> T640 router, T1600 router or TX Matrix router, and TX Matrix Plus router—0 through 4 T320 router—0 through 2
State	<p>SIB status:</p> <ul style="list-style-type: none"> Disconnected—SIBs on all T640 routers on the TX Matrix router (or switch-card chassis) are in the Disconnected state, because a SIB on the SCC has gone offline. Likewise, SIBs on all T1600 routers on the TX Matrix Plus router (or switch-fabric chassis) are in the Disconnected state, because a SIB on the SFC has gone offline. Online—SPMB is operational and running. Offline—SPMB is powered down. Spare—SIB is redundant and will move to active state if one of the working SIBs fail to pass traffic. Empty—No SPMB is present. Fault—SIB is in alarmed state where the SIB's plane is not operational for the following reasons: <ul style="list-style-type: none"> On-board F-chip is not operational. Fiber optic connector faults. FPC connector faults. SIB midplane connector faults. Check—SIB is in alarmed state where the SIB's plane is partially operational for the following reasons: <ul style="list-style-type: none"> SIB is not inserted properly. Two or more links between the SIB and PFE fails.
Uptime	How long the SIB has been up and running.

Sample Output

```

show chassis spmb sibs (T320 Router) user@host> show chassis spmb sibs
Slot State
0 Spare
1 Online
2 Online

show chassis-spmb-sibs (T1600 Router) user@host> show chassis spmb sibs
Slot State
0 Spare
1 Online
2 Empty

```

```

3    Online
4    Offline

```

show chassis spmb sibs (TX Matrix Router) user@host> show chassis spmb sibs

```

Slot  State
0     Online
1     Online
2     Empty
3     Online
4     Offline

```

show chassis spmb sibs lcc (TX Matrix Router) user@host> show chassis spmb sibs lcc 0
lcc0-re0:

```

-----
Slot  State          Uptime
0     Empty
1     Empty
2     Empty
3     Disconnected    8 days, 48 minutes, 58 seconds
4     Online           8 days, 48 minutes, 57 seconds

```

show chassis spmb sibs scc (TX Matrix Router) user@host> show chassis spmb sibs scc
scc-re0:

```

-----
Slot  State          Uptime
0     Empty
1     Empty
2     Empty
3     Offline
4     Online           8 days, 54 minutes, 1 second

```

show chassis spmb sibs (TX Matrix Plus Router) user@host> show chassis spmb sibs
sfc0-re0:

```

-----
Slot  State          Type          Uptime
0     Online          SIB F13      1 hour, 52 minutes, 55 seconds
1     Empty
2     Invalid
3     Online          SIB F13      1 hour, 53 minutes, 3 seconds
4     Empty
5     Invalid
6     Empty
7     Empty
8     Empty
9     Empty
10    Invalid
11    Empty
12    Empty
13    Invalid
14    Invalid
15    Invalid
0/0   Online          SIB F2S      1 hour, 53 minutes, 2 seconds
0/2   Online          SIB F2S      1 hour, 53 minutes, 1 second
0/4   Online          SIB F2S      1 hour, 52 minutes, 59 seconds
0/6   Online          SIB F2S      1 hour, 52 minutes, 58 seconds
1/0   Online          SIB F2S      1 hour, 53 minutes, 10 seconds
1/2   Online          SIB F2S      1 hour, 53 minutes, 8 seconds
1/4   Online          SIB F2S      1 hour, 53 minutes, 7 seconds
1/6   Online          SIB F2S      1 hour, 53 minutes, 6 seconds
2/0   Empty

```

```

2/2 Empty
2/4 Empty
2/6 Empty
3/0 Empty
3/2 Empty
3/4 Empty
3/6 Empty
4/0 Empty
4/2 Empty
4/4 Empty
4/6 Empty

```

lcc0-re0:

```

-----
Slot  State          Uptime
0      Online         1 hour, 53 minutes, 1 second
1      Online         1 hour, 53 minutes, 3 seconds
2      Empty
3      Empty
4      Empty

```

lcc1-re1:

```

-----
Slot  State          Uptime
0      Online         1 hour, 47 minutes, 13 seconds
1      Online         1 hour, 47 minutes, 15 seconds
2      Empty
3      Empty
4      Empty

```

**show chassis spmb
sibs sfc (TX Matrix
Plus Router)**

```

user@host> show chassis spmb sibs sfc 0
sfc0-re0:

```

```

-----
Slot 0 information:
State                               Online
Total CPU Utilization               16%
Interrupt CPU Utilization            0%
Memory Heap Utilization              0%
Buffer Utilization                   24%
Start time:                          2009-06-17 20:59:47 PDT
Uptime:                             1 hour, 56 minutes, 30 seconds

Slot 1 information:
State                               Online - Standby
Total CPU Utilization               0%
Interrupt CPU Utilization            0%
Memory Heap Utilization              0%
Buffer Utilization                   24%
Start time:                          2009-06-17 20:59:48 PDT
Uptime:                             1 hour, 56 minutes, 29 seconds

```

show chassis ssb

Syntax	<code>show chassis ssb</code> <code><slot></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M20 routers only) Display status information about the System and Switch Board (SSB).
Options	<p><code>none</code>—Display information about all SSBs.</p> <p><code>slot</code>—(Optional) Display information about the SSB in the specified slot. Replace slot with 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request chassis ssb master switch on page 198
List of Sample Output	show chassis ssb on page 533
Output Fields	Table 96 on page 532 lists the output fields for the <code>show chassis ssb</code> command. Output fields are listed in the approximate order in which they appear.

Table 96: show chassis ssb Output Fields

Field Name	Field Description
Failover	Number of times mastership has changed.
Slot	SSB slot number.
State	<p>Current state of the SSB in this slot. State can be any one of the following:</p> <ul style="list-style-type: none"> Master—SSB is online, operating as master. Backup—SSB running as backup. Empty—No SSB is present.
Temperature	Temperature of the air passing by the SSB, in degrees Celsius.
CPU utilization	Total percentage of the CPU being used by the SSB's processor.
Interrupt utilization	Of the total CPU being used by the SSB's processor, the percentage being used for interrupts.
Heap utilization	Percentage of heap space being used by the SSB's processor.
Buffer utilization	Percentage of buffer space being used by the SSB's processor.
DRAM	Total DRAM available to the SSB's processor.

Table 96: show chassis ssb Output Fields (*continued*)

Field Name	Field Description
Start time	Time when the SSB started running.
Uptime	How long the SSB has been up and running.

Sample Output

```

show chassis ssb user@host> show chassis ssb
SSB status:
  Failover:                0 time
  Slot 0:
    State:                  Master
    Temperature:            33 Centigrade
    CPU utilization:        0 percent
    Interrupt utilization:   0 percent
    Heap utilization:       0 percent
    Buffer utilization:      6 percent
    DRAM:                   64 Mbytes
    Start time:             1999-01-15 22:05:36 UTC
    Uptime:                 21 hours, 21 minutes, 22 seconds
...

```

show chassis synchronization

Syntax	show chassis synchronization <extensive> <backup master>
Release Information	Command introduced in Junos OS Release 7.6 for M320 routers. Command introduced in Junos OS Release 8.3 for M40e routers. Command introduced in Junos OS Release 9.3 for M120 routers. Command introduced in Junos OS Release 10.2 for T320, T640, and T1600 routers.
Description	(M320, M40e, M120, T320, T640, and T1600 routers only) Display information about the external clock source currently used for chassis synchronization.
Options	extensive—(Optional) Display clock synchronization information in detail. backup—(Optional) Display clock synchronization information about the backup clock. master— (Optional) Display clock synchronization information about the master clock.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> request chassis synchronization switch on page 200
List of Sample Output	show chassis synchronization on page 535 show chassis synchronization master on page 535 show chassis synchronization backup on page 536 show chassis synchronization extensive on page 536 show chassis synchronization (T320, T640, and T1600 Routers) on page 536
Output Fields	Table 97 on page 534 lists the output fields for the <code>show chassis synchronization</code> command. Output fields are listed in the approximate order in which they appear.

Table 97: show chassis synchronization Output Fields

Field Name	Field Description
Current state	Indicates current status of external clock sources: <ul style="list-style-type: none"> backup—Source is currently the backup clock source. master—Source is currently the master clock source.
Current clock state	Indicates current source of external synchronization: <ul style="list-style-type: none"> internal—Source is providing its own clocking. locked to master CB—(M320, M40e, and M120 routers) Source is locked to master clock source. locked to master SCG—(T320, T640, and T1600 routers) Source is locked to master clock source.
Selected for	Number of seconds this clock has been the master or backup clock source.

Table 97: show chassis synchronization Output Fields (*continued*)

Field Name	Field Description
Selected since	Time stamp for establishment as master or backup clock source.
Deviation (in ppm)	Difference in clock timing, in parts per million (ppm).
Last deviation (in ppm)	Previous difference in clock timing, if any, in ppm.
Configured sources	Information of clock sources eligible for selection as master clock.
Source	Information following concerns external source A or B.
Priority	Indicates priority of external clock sources: <ul style="list-style-type: none"> • primary—Source is a primary reference. • secondary—Source is a secondary reference.
Deviation (in ppm)	Current difference in clock timing, in ppm: <ul style="list-style-type: none"> • measuring—Establishing source deviation. • number—Deviation in ppm.
Last deviation (in ppm)	Previous difference in clock timing, in ppm: <ul style="list-style-type: none"> • number—Deviation in ppm.
Status	Indicates status of external sources: <ul style="list-style-type: none"> • present—Source is configured and present. • qualified—Source is eligible for synchronization source.

Sample Output

```

show chassis synchronization user@host> show chassis synchronization
Clock Synchronization Status :
  Clock module on CB 0
    Current state           : master
    Current clock state     : internal
    Selected for            : 18 hours, 12 minutes, 43 seconds
    Selected since         : 2008-09-10 03:27:47 PDT
    Deviation (in ppm)     : +0.00
    Last deviation (in ppm): +0.00
  Clock Synchronization Status :
  Clock module on CB 1
    Current state           : backup
    Current clock state     : locked to master CB
    Selected for            : 1 day, 12 hours, 49 minutes, 20 seconds
    Selected since         : 2008-09-09 08:51:10 PDT

show chassis synchronization master user@host> show chassis synchronization master
Clock Synchronization Status :
  Clock module on CB 0
    Current state           : master
    Current clock state     : internal

```

```

Selected for           : 8 days, 21 minutes, 12 seconds
Selected since        : 2008-08-27 21:05:40 PDT
Deviation (in ppm)    : +0.00
Last deviation (in ppm): +0.00

show chassis user@host> show chassis synchronization backup
synchronization Clock Synchronization Status :
backup         Clock module on CB 1
               Current state           : backup
               Current clock state      : locked to master CB
               Selected for             : 34 days, 20 hours, 17 minutes, 8 seconds
               Selected since          : 2008-08-01 01:22:16 PDT

show chassis user@host> show chassis synchronization extensive
synchronization Clock Synchronization Status :
extensive       Clock module on CB 0
               Current state           : master
               Current clock state      : internal
               Selected for             : 8 days, 36 minutes, 29 seconds
               Selected since          : 2008-08-27 21:05:40 PDT
               Deviation (in ppm)      : +0.00
               Last deviation (in ppm) : +0.00
Clock Synchronization Status :
Clock module on CB 1
Current state           : backup
Current clock state      : locked to master CB
Selected for             : 34 days, 20 hours, 19 minutes, 53 seconds
Selected since          : 2008-08-01 01:22:16 PDT

show chassis user@host> show chassis synchronization
synchronization (T320, Clock Synchronization Status :
T640, and T1600      Clock module on SCG 0
Routers)             Current state           : master
                     Current clock state      : locked to external-a
                     Selected for             : 2 hours, 28 minutes, 4 seconds
                     Selected since          : 2006-02-17 01:12:58 PST
                     Configured sources
                     Source      Priority  Deviation    Last deviation  Status
                                   (in ppm)  (in ppm)
                     external-a primary  measuring    -0.10           in-use
                     external-b secondary -0.10        -0.10           qualified
Clock Synchronization Status :
Clock module on SCG 1
Current state           : backup
Current clock state      : locked to master SCG
Selected for             : 19 hours, 49 minutes, 14 seconds
Selected since          : 2006-02-16 07:51:48 PST
Configured sources
Source      Priority  Deviation    Last deviation  Status
                                   (in ppm)  (in ppm)
external-a primary  -0.25        -0.25           qualified
external-b secondary -0.25        -0.25           qualified

```


show chassis temperature-thresholds

Syntax	show chassis temperature-thresholds
Syntax (TX Matrix Router)	show chassis temperature-thresholds <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show chassis temperature-thresholds <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show chassis temperature-thresholds <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced in Junos OS Release 8.0. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc command introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display chassis temperature threshold settings, in degrees Celsius.
Options	<p>none—(QFX Series) Display the temperature threshold details of a QFX Series product.</p> <p>all-members—(MX Series routers only) (Optional) Display the chassis temperature threshold settings of all member routers in the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display the temperature threshold details of a specified T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display the temperature threshold details of a specified T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display the chassis temperature threshold settings of the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display the chassis temperature threshold settings of the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) (Optional) Display the temperature threshold details of the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display the temperature threshold details of the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Required Privilege Level	view

List of Sample Output **show chassis temperature-thresholds** on page 538
 show chassis temperature-thresholds (TX Matrix Plus Router) on page 539
 show chassis temperature-thresholds lcc (TX Matrix Plus Router) on page 540
 show chassis temperature-thresholds sfc (TX Matrix Plus Router) on page 540
 show chassis temperature-thresholds (QFX Series) on page 541

Output Fields Table 98 on page 538 lists the output fields for the **show chassis temperature-thresholds** command. Output fields are listed in the approximate order in which they appear.

Table 98: show chassis temperature-thresholds Output Fields

Field name	Field Description
Item	Chassis component. If per FRU per slot thresholds are configured, the components about which information is displayed include the chassis, the Routing Engines, FPCs, and FEBs. If per FRU per slot thresholds are not configured, the components about which information is displayed include the chassis and the Routing Engines.
Fan speed	<p>Temperature threshold settings, in degrees Celsius, for the fans to operate at normal and high speeds.</p> <ul style="list-style-type: none"> • Normal—The fans operate at normal speed if the component is at or below this temperature and all the fans are present and functioning normally. • High—The fans operate at high speed if the component has exceeded this temperature or a fan has failed or is missing. <p>An alarm is not triggered until the temperature exceeds the threshold settings for a yellow alarm or a red alarm.</p>
Yellow alarm	<p>Temperature threshold settings, in degrees Celsius, that trigger a yellow alarm.</p> <ul style="list-style-type: none"> • Normal—The temperature that must be exceeded on the component to trigger a yellow alarm when the fans are running at full speed. • Bad fan—The temperature that must be exceeded on the component to trigger a yellow alarm when one or more fans have failed or are missing.
Red alarm	<p>Temperature threshold settings, in degrees Celsius, that trigger a red alarm.</p> <ul style="list-style-type: none"> • Normal—The temperature that must be exceeded on the component to trigger a red alarm when the fans are running at full speed. • Bad fan—The temperature that must be exceeded on the component to trigger a red alarm when one or more fans have failed or are missing.

Sample Output

```

show chassis temperature-thresholds user@host> show chassis temperature-thresholds
                                     Fan speed      Yellow alarm      Red alarm
                                     (degrees C)      (degrees C)      (degrees C)
Item                                Normal    High    Normal    Bad fan    Normal    Bad fan
Chassis default                    48       54      65       55       75       65
Routing Engine 0                    70       80      95       95      110      110
Routing Engine 1                    70       80      95       95      110      110
FPC 0                              55       60      75       65       90       80
FPC 1                              55       60      75       65       90       80
FPC 2                              55       60      75       65       90       80
FPC 3                              55       60      75       65       90       80
FPC 4                              55       60      75       65       90       80
FPC 5                              55       60      75       65       90       80

```

FPC 6	55	60	75	65	90	80
FPC 7	55	60	75	65	90	80
FPC 8	55	60	75	65	90	80
FPC 9	55	60	75	65	90	80
FPC 10	55	60	75	65	90	80
FPC 11	55	60	75	65	90	80

show chassis temperature-thresholds
 user@host> show chassis temperature-thresholds
 sfc0-re0:

(TX Matrix Plus
 Router)

Item	Fan speed (degrees C)		Yellow alarm (degrees C)		Red alarm (degrees C)	
	Normal	High	Normal	Bad fan	Normal	Bad fan
Chassis default	48	54	65	55	75	65
Routing Engine 0	55	65	85	85	100	100
Routing Engine 1	55	65	85	85	100	100
SIB F13 0	64	70	76	72	90	84
SIB F13 3	64	70	76	72	90	84
SIB F13 6	64	70	76	72	90	84
SIB F13 8	64	70	76	72	90	84
SIB F13 11	64	70	76	72	90	84
SIB F13 12	64	70	76	72	90	84
SIB F2S 16	64	70	76	72	90	84
SIB F2S 17	64	70	76	72	90	84
SIB F2S 18	64	70	76	72	90	84
SIB F2S 19	64	70	76	72	90	84
SIB F2S 20	64	70	76	72	90	84
SIB F2S 21	64	70	76	72	90	84
SIB F2S 22	64	70	76	72	90	84
SIB F2S 23	64	70	76	72	90	84
SIB F2S 24	64	70	76	72	90	84
SIB F2S 25	64	70	76	72	90	84
SIB F2S 26	64	70	76	72	90	84
SIB F2S 27	64	70	76	72	90	84
SIB F2S 28	64	70	76	72	90	84
SIB F2S 29	64	70	76	72	90	84
SIB F2S 30	64	70	76	72	90	84
SIB F2S 31	64	70	76	72	90	84
SIB F2S 32	64	70	76	72	90	84
SIB F2S 33	64	70	76	72	90	84
SIB F2S 34	64	70	76	72	90	84
SIB F2S 35	64	70	76	72	90	84

lcc0-re0:

Item	Fan speed (degrees C)		Yellow alarm (degrees C)		Red alarm (degrees C)	
	Normal	High	Normal	Bad fan	Normal	Bad fan
Chassis default	48	54	65	55	75	65
Routing Engine 0	55	65	85	85	100	100
Routing Engine 1	55	65	85	85	100	100
FPC 1	56	62	75	63	83	76
FPC 3	56	62	75	63	83	76
FPC 4	56	62	75	63	83	76
FPC 6	56	62	75	63	83	76
FPC 7	56	62	75	63	83	76
SIB 0	48	54	65	60	80	75
SIB 1	48	54	65	60	80	75
SIB 2	48	54	65	60	80	75
SIB 3	48	54	65	60	80	75
SIB 4	48	54	65	60	80	75

```
lcc1-re0:
```

Item	Fan speed (degrees C)		Yellow alarm (degrees C)		Red alarm (degrees C)	
	Normal	High	Normal	Bad fan	Normal	Bad fan
Chassis default	48	54	65	55	75	65
Routing Engine 0	55	65	85	85	100	100
Routing Engine 1	55	65	85	85	100	100
FPC 1	56	62	75	63	83	76
FPC 3	56	62	75	63	83	76
FPC 4	56	62	75	63	83	76
FPC 6	56	62	75	63	83	76
...						

```
show chassis temperature-thresholds lcc (TX Matrix Plus Router)
user@host> show chassis temperature-thresholds lcc 1
lcc1-re0:
```

Item	Fan speed (degrees C)		Yellow alarm (degrees C)		Red alarm (degrees C)	
	Normal	High	Normal	Bad fan	Normal	Bad fan
Chassis default	48	54	65	55	75	65
Routing Engine 0	55	65	85	85	100	100
Routing Engine 1	55	65	85	85	100	100
FPC 1	56	62	75	63	83	76
FPC 3	56	62	75	63	83	76
FPC 4	56	62	75	63	83	76
FPC 6	56	62	75	63	83	76
SIB 0	48	54	65	60	80	75
SIB 1	48	54	65	60	80	75
SIB 2	48	54	65	60	80	75
SIB 3	48	54	65	60	80	75
SIB 4	48	54	65	60	80	75

```
show chassis temperature-thresholds sfc (TX Matrix Plus Router)
user@host> show chassis temperature-thresholds sfc 0
sfc0-re0:
```

Item	Fan speed (degrees C)		Yellow alarm (degrees C)		Red alarm (degrees C)	
	Normal	High	Normal	Bad fan	Normal	Bad fan
Chassis default	48	54	65	55	75	65
Routing Engine 0	55	65	85	85	100	100
Routing Engine 1	55	65	85	85	100	100
SIB F13 0	64	70	76	72	90	84
SIB F13 3	64	70	76	72	90	84
SIB F13 6	64	70	76	72	90	84
SIB F13 8	64	70	76	72	90	84
SIB F13 11	64	70	76	72	90	84
SIB F13 12	64	70	76	72	90	84
SIB F2S 16	64	70	76	72	90	84
SIB F2S 17	64	70	76	72	90	84
SIB F2S 18	64	70	76	72	90	84
SIB F2S 19	64	70	76	72	90	84
SIB F2S 20	64	70	76	72	90	84
SIB F2S 21	64	70	76	72	90	84
SIB F2S 22	64	70	76	72	90	84
SIB F2S 23	64	70	76	72	90	84
SIB F2S 24	64	70	76	72	90	84
SIB F2S 25	64	70	76	72	90	84
SIB F2S 26	64	70	76	72	90	84
SIB F2S 27	64	70	76	72	90	84

SIB F2S 28	64	70	76	72	90	84
SIB F2S 29	64	70	76	72	90	84
SIB F2S 30	64	70	76	72	90	84
SIB F2S 31	64	70	76	72	90	84
SIB F2S 32	64	70	76	72	90	84
SIB F2S 33	64	70	76	72	90	84
SIB F2S 34	64	70	76	72	90	84
SIB F2S 35	64	70	76	72	90	84

```

show chassis temperature-thresholds (QFX Series)
user@switch> show chassis temperature-thresholds

```

	Fan speed (degrees C)		Yellow alarm (degrees C)		Red alarm (degrees C)	
Item	Normal	High	Normal	Bad fan	Normal	Bad fan
FPC Sensor TopLeft I	30	65	55	45	60	50
FPC Sensor TopRight I	30	65	55	45	60	50
FPC Sensor TopLeft E	30	65	55	45	60	50
FPC Sensor TopRight E	30	65	55	45	60	50
FPC Sensor TopMiddle I	30	65	55	45	60	50
FPC Sensor TopMiddle E	30	65	55	45	60	50
FPC Sensor Bottom I	30	65	55	45	60	50
FPC Sensor Bottom E	30	65	55	45	60	50
FPC Sensor Die Temp	30	65	55	45	60	50
FPC Sensor Mgmt Brd I	30	65	55	45	60	50

CHAPTER 8

Command-Line Interface Operational Mode Commands

Table 99 on page 543 summarizes the command-line interface (CLI) commands you can use to perform and monitor CLI management functions. Commands are listed in alphabetical order.

Table 99: CLI Operational Mode Commands

Task	Command
Clear the logical system view and return to a full router view.	clear cli logical-system
Set the CLI to complete partial command entries.	set cli complete-on-space
Set the current working directory.	set cli directory
Set the maximum time that an individual session can be idle before the user is logged off the router.	set cli idle-timeout
Set the CLI to the specified logical routing instance.	set cli logical-system
Set the CLI prompt.	set cli prompt
Set the CLI to prompt you to restart the router after a software upgrade.	set cli restart-on-upgrade
Set the number of lines on the screen.	set cli screen-length
Set the number of characters on a line.	set cli screen-width
Set the terminal type.	set cli terminal
Timestamp CLI output.	set cli timestamp
Set the system date and time.	set date
Display all CLI settings.	show cli

Table 99: CLI Operational Mode Commands (*continued*)

Task	Command
Display login permissions for the current user.	show cli authorization
Display the current working directory.	show cli directory
Display a list of previous CLI commands.	show cli history



NOTE: For information about how to configure CLI parameters, see the *Junos OS CLI User Guide*.

For information about related tasks performed by network operations center (NOC) personnel, see the *Junos Baseline Network Operations Guide*.

clear cli logical-system

Syntax	clear cli logical-system
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear the logical system view and return to a full router view. In a logical system view, the output of the command displays information related to the logical system only.
Options	This command has no options.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• set cli logical-system on page 549
List of Sample Output	clear cli logical-system on page 545
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear cli logical-system  user@host:1r1> clear cli logical-system
                           Cleared default logical system
                           user@host>
```

set cli complete-on-space

Syntax	set cli complete-on-space (off on)
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the command-line interface (CLI) to complete a partial command entry when you type a space or a tab. This is the default behavior of the CLI.
Options	off—Turn off command completion. on—Allow either a space or a tab to be used for command completion.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• show cli on page 557
List of Sample Output	set cli complete-on-space on page 546
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli complete-on-space	<p>In the following example, pressing the Spacebar changes the partial command entry from com to complete-on-space. The example shows how adding the keyword off at the end of the command disables command completion.</p> <pre>user@host> set cli com<Space> user@host>set cli complete-on-space off Disabling complete-on-space</pre>
----------------------------------	---

set cli directory

Syntax	set cli directory <i>directory</i>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the current working directory.
Options	<i>directory</i> —Pathname of the working directory.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• show cli directory on page 562
List of Sample Output	set cli directory on page 547
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli directory	user@host> set cli directory /var/home/regress Current directory: /var/home/regress
--------------------------	--

set cli idle-timeout

Syntax	set cli idle-timeout <minutes>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the maximum time that an individual session can be idle before the user is logged off the router or switch.
Options	<i>minutes</i> —(Optional) Maximum idle time. The range of values, in minutes, is 0 through 100,000. If you do not issue this command, and the user's login class does not specify this value, the user is never forced off the system after extended idle times. Setting the value to 0 disables the timeout.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• show cli on page 557
List of Sample Output	set cli idle-timeout on page 548
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli idle-timeout	user@host> set cli idle-timeout 60 Idle timeout set to 60 minutes
-----------------------------	--

set cli logical-system

Syntax	set cli logical-system <i>logical-system</i>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Set the CLI to the specified logical system view.
Options	<i>logical-system</i> —logical system name.
Required Privilege Level	view
List of Sample Output	set cli logical-system on page 549
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
set cli logical-system  user@host> set cli logical-system log-router-A
                        logical system: log-router-A
                        user@host:log-router-A>
```

set cli prompt

Syntax	set cli prompt <i>string</i>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the prompt so that it is displayed within the CLI.
Options	<i>string</i> —CLI prompt string. To include spaces in the prompt, enclose the string in quotation marks. By default, the string is <i>username@hostname</i> .
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• show cli on page 557
List of Sample Output	set cli prompt on page 550
Output Fields	When you enter this command, the new CLI prompt is displayed.

Sample Output

set cli prompt	user@host> set cli prompt lab1-router> lab1-router>
----------------	--

set cli restart-on-upgrade

Syntax	set cli restart-on-upgrade string (off on)
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	For an individual session, set the CLI to prompt you to restart the router or switch after upgrading the software.
Options	off—Disables the prompt. on—Enables the prompt.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• show cli on page 557
List of Sample Output	set cli restart-on-upgrade on page 551
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli restart-on-upgrade	user@host> set cli restart-on-upgrade on Enabling restart-on-upgrade
---------------------------------------	---

set cli screen-length

Syntax	set cli screen-length <i>length</i>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set terminal screen length.
Options	<i>length</i> —Number of lines of text that the terminal screen displays (0 through 10,000). The default is 24.
Additional Information	The point at which the ---(more)--- prompt appears on the screen is a function of this setting and the settings for the set cli screen-width and set cli terminal commands.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• set cli screen-width on page 553• set cli terminal on page 554• show cli on page 557
List of Sample Output	set cli screen-length on page 552
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli screen-length	user@host> set cli screen-length 75 Screen length set to 75
------------------------------	--

set cli screen-width

Syntax	set cli screen-width <i>width</i>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the terminal screen width.
Options	<i>width</i> —Number of characters (0 through 1024) in a line. The default is 80.
Additional Information	The point at which the ---(more)--- prompt appears on the screen is a function of this setting and the settings for the set cli screen-length and set cli terminal commands.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• set cli screen-length on page 552• set cli terminal on page 554• show cli on page 557
List of Sample Output	set cli screen-width on page 553
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli screen-width	user@host> set cli screen-width Screen width set to 132
-----------------------------	--

set cli terminal

Syntax	set cli terminal <i>terminal-type</i>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the terminal type.
Options	<i>terminal-type</i> —Type of terminal that is connected to the Ethernet management port: <ul style="list-style-type: none">• ansi—ANSI-compatible terminal (80 characters by 24 lines)• small-xterm—Small xterm window (80 characters by 24 lines)• vt100—VT100-compatible terminal (80 characters by 24 lines)• xterm—Large xterm window (80 characters by 65 lines)
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• set cli screen-length on page 552• set cli screen-width on page 553• show cli on page 557
List of Sample Output	set cli terminal on page 554
Output Fields	This command provides no output.

Sample Output

```
set cli terminal  user@host> set cli terminal xterm
```

set cli timestamp

Syntax	set cli timestamp (format <i>timestamp-format</i> disable)
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set a timestamp for CLI output.
Options	<p>format <i>timestamp-format</i>—Set the date and time format for the timestamp. The timestamp format you specify can include the following placeholders in any order:</p> <ul style="list-style-type: none">• %m—Two-digit month• %d—Two-digit date• %T—Six-digit hour, minute, and seconds <p>disable—Remove the timestamp from the CLI.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• CLI User Interface Overview• show cli on page 557
List of Sample Output	set cli timestamp on page 555
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

set cli timestamp	user@host> set cli timestamp format '%m-%d-%T' '04-21-17:39:13' CLI timestamp set to: '%m-%d-%T'
--------------------------	--

set date

Syntax	<code>set date (<i>date-time</i> ntp <<i>servers</i>> <<i>source-address source-address</i>>)</code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Set the date and time.
Options	<i>date-time</i> —Date and time. Enter this string inside quotation marks. ntp—Use a Network Time Protocol (NTP) server to synchronize the current date and time setting on the router or switch. <i>servers</i> —(Optional) Specify the IP address of one or more NTP servers. <i>source-address source-address</i> —Specify the source address that the router or switch uses to contact the remote NTP server.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">Setting the Date and Time
List of Sample Output	set date on page 556
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
set date user@host> set date ntp
21 Apr 17:22:02 ntpdate[3867]: step time server 172.17.27.46 offset 8.759252 sec
```

show cli

Syntax	show cli
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display configured CLI settings.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show cli on page 557
Output Fields	Table 100 on page 557 lists the output fields for the show cli command. Output fields are listed in the approximate order in which they appear.

Table 100: show cli Output Fields

Field Name	Field Description
CLI complete-on-space	Capability to complete a partial command entry when you type a space or a tab: on or off .
CLI idle-timeout	Maximum time that an individual session can be idle before the user is logged off the router or switch. When this feature is enabled, the number of minutes is displayed. Otherwise, the state is disabled .
CLI restart-on-upgrade	CLI is set to prompt you to restart the router or switch after upgrading the software: on or off .
CLI screen-length	Number of lines of text that the terminal screen displays.
CLI screen-width	Number of characters in a line on the terminal screen.
CLI terminal	Terminal type.
CLI is operating in	Mode: enhanced .
CLI timestamp	Date and time format for the timestamp. If the timestamp is not set, the state is disabled .
CLI working directory	Pathname of the working directory.

Sample Output

```
show cli  user@host> show cli
          CLI complete-on-space set to on
          CLI idle-timeout disabled
          CLI restart-on-upgrade set to on
          CLI screen-length set to 47
          CLI screen-width set to 132
          CLI terminal is 'vt100'
```

```
CLI is operating in enhanced mode
CLI timestamp disabled
CLI working directory is '/var/home/regress'
```

show cli authorization

Syntax	show cli authorization
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the permissions for the current user.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show cli authorization on page 561
Output Fields	Table 101 on page 559 lists the output fields for the show cli authorization command. In the table, all possible permissions are displayed and output fields are listed in alphabetical order.

Table 101: show cli authorization Output Fields

Field Name	Field Description
access	Can view access configuration information.
access-control	Can modify access configuration.
admin	Can view user account information.
admin-control	Can modify user account information.
clear	Can clear learned network information.
configure	Can enter configuration mode.
control	Can modify any configuration.
edit	Can edit configuration files.
field	Reserved for field (debugging) support.
firewall	Can view firewall configuration information.
firewall-control	Can modify firewall configuration information.
floppy	Can read from and write to removable media.
flow-tap	Can view flow-tap configuration information.

Table 101: show cli authorization Output Fields (*continued*)

Field Name	Field Description
flow-tap-control	Can configure flow-tap configuration information.
idp-profiler-operation	Can configure Profiler data.
interface	Can view interface configuration information.
interface-control	Can modify interface configuration information.
maintenance	Can perform system maintenance.
network	Can access the network by entering the ping , ssh , telnet , and traceroute commands.
pgcp-session-mirroring	Can view pgcp session mirroring configuration.
pgcp-session-mirroring-control	Can modify pgcp session mirroring configuration all-control.
reset	Can reset or restart interfaces and system processes.
rollback	Can rollback to previous configurations.
routing	Can view routing configuration information.
routing-control	Can modify routing configuration information.
secret	Can view passwords and authentication keys in the configuration.
secret-control	Can modify passwords and authentication keys in the configuration.
security	Can view security configuration information.
security-control	Can modify security configuration information.
shell	Can start a local shell.
snmp	Can view SNMP configuration information.
snmp-control	Can modify SNMP configuration information.
system	Can view system configuration information.
system-control	Can modify system configuration information.
trace	Can view trace file settings information.
trace-control	Can modify trace file settings information.

Table 101: show cli authorization Output Fields (*continued*)

Field Name	Field Description
view	Can view current values and statistics.
view-configuration	Can view all configuration information (not including secrets).

Sample Output

```

show cli authorization user@host> show cli authorization
Current user: 'remote' login: 'user' class ''
Permissions:
  admin      -- Can view user accounts
  admin-control-- Can modify user accounts
  clear      -- Can clear learned network information
  configure  -- Can enter configuration mode
  control    -- Can modify any configuration
  edit       -- Can edit full files
  field      -- Special for field (debug) support
  floppy     -- Can read and write from the floppy
  interface  -- Can view interface configuration
  interface-control-- Can modify interface configuration
  network    -- Can access the network
  reset      -- Can reset/restart interfaces and daemons
  routing    -- Can view routing configuration
  routing-control-- Can modify routing configuration
  shell      -- Can start a local shell
  snmp       -- Can view SNMP configuration
  snmp-control-- Can modify SNMP configuration
  system     -- Can view system configuration
  system-control-- Can modify system configuration
  trace      -- Can view trace file settings
  trace-control-- Can modify trace file settings
  view       -- Can view current values and statistics
  maintenance -- Can become the super-user
  firewall   -- Can view firewall configuration
  firewall-control-- Can modify firewall configuration
  secret     -- Can view secret configuration
  secret-control-- Can modify secret configuration
  rollback   -- Can rollback to previous configurations
  security   -- Can view security configuration
  security-control-- Can modify security configuration
  access     -- Can view access configuration
  access-control-- Can modify access configuration
  view-configuration-- Can view all configuration (not including secrets)
  flow-tap   -- Can view flow-tap configuration
  flow-tap-control-- Can configure flow-tap service
Individual command authorization:
  Allow regular expression: none
  Deny regular expression: none
  Allow configuration regular expression: none
  Deny configuration regular expression: none

```

show cli directory

Syntax	show cli directory
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the current working directory.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show cli directory on page 562
Output Fields	Table 102 on page 562 lists the output fields for the show cli directory command. Output fields are listed in the approximate order in which they appear.

Table 102: show cli directory Output Fields

Field Name	Field Description
Current directory	Pathname of the current working directory.

Sample Output

```
show cli directory  user@host> show cli directory
Current directory: /var/home/regress
```

show cli history

Syntax	show cli history <count>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display a list of previous CLI commands.
Options	none—Display all previous CLI commands. count—(Optional) Maximum number of commands to display.
Required Privilege Level	view
List of Sample Output	show cli history on page 563
Output Fields	Table 103 on page 563 lists the output fields for the show cli history command. Output fields are listed in the approximate order in which they appear.

Table 103: show cli history Output Fields

Field Name	Field Description
<i>timestamp</i>	Time at which the command was entered.
<i>command-syntax</i>	Command that was entered.

Sample Output

```
show cli history user@host> show cli history
11:14:14 -- show arp
11:22:10 -- show cli authorization
11:27:12 -- show cli history
```


CHAPTER 9

File Management Operational Mode Commands

Table 104 on page 565 summarizes the command-line interface (CLI) commands you can use to perform and monitor file management functions. Commands are listed in alphabetical order.

Table 104: File Management Operational Mode Commands

Task	Command
Remove contents of a log file.	clear log
Archive files or archive and compress files.	file archive
Calculate checksum using MD5 has algorithm.	file checksum md5
Calculate checksum using Secure Hash Algorithm SHA1.	file checksum sha1
Calculate checksum using Secure Hash Algorithm SHA-256.	file checksum sha-256
Compare two files.	file compare
Copy files.	file copy
Delete files.	file delete
List files and directories on the router.	file list
Rename files.	file rename
Display the contents of a file.	file show
List log files, display log file contents, and display information about users who have logged in to the router.	show log



.....

NOTE: See also the `monitor list`, `monitor start`, and `monitor stop` commands, which are documented in *Real-Time Router Monitoring Operational Mode Commands*.

For information about how to configure file parameters, see the *Junos OS System Basics Configuration Guide*.

For information about related tasks performed by network operations center (NOC) personnel, see the *Junos Baseline Network Operations Guide*.

.....

clear log

Syntax	<code>clear log <i>filename</i></code> <code><all></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Remove contents of a log file.
Options	<i>filename</i> —Name of the specific log file. all—(Optional) Delete the specified log file and all archived versions of it.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • show log on page 585
List of Sample Output	clear log on page 567
Output Fields	See file list for an explanation of output fields.

Sample Output

clear log The following sample commands list log file information, clear the contents of a log file, and then display the updated log file information:

```
user@host> file list lcc0-re0:/var/log/sampled detail
lcc0-re0:
-----
-rw-r----- 1 root  wheel      26450 Jun 23 18:47 /var/log/sampled
total 1

user@host> clear log lcc0-re0:sampled
lcc0-re0:
-----

user@host> file list lcc0-re0:/var/log/sampled detail
lcc0-re0:
-----
-rw-r----- 1 root  wheel      57 Sep 15 03:44 /var/log/sampled
total 1
```

file archive

Syntax	<code>file archive destination <i>destination</i> source <i>source</i> <compress></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Archive, and optionally compress, one or multiple local system files as a single file, locally or at a remote location.
Options	<p><code>destination <i>destination</i></code>—Destination of the archived file or files. Specify the destination as a URL or filename. The Junos OS adds one of the following suffixes if the destination filename does not already have it:</p> <ul style="list-style-type: none">• For archived files—The suffix .tar• For archived and compressed files—The suffix .tgz <p><code>source <i>source</i></code>—Source of the original file or files. Specify the source as a URL or filename.</p> <p><code>compress</code>—(Optional) Compress the archived file with the GNU zip (gzip) compression utility. The compressed files have the suffix .tgz.</p>
Required Privilege Level	maintenance
List of Sample Output	<code>file archive (Multiple Files)</code> on page 568 <code>file archive (Single File)</code> on page 568 <code>file archive (with Compression)</code> on page 568
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

file archive (Multiple Files)	<p>The following sample command archives all message files in the local directory <code>/var/log/messages</code> as the single file messages-archive.tar.</p> <pre>user@host> file archive source /var/log/messages* destination /var/log/messages-archive.tar /usr/bin/tar: Removing leading / from absolute path names in the archive. user@host></pre>
file archive (Single File)	<p>The following sample command archives one message file in the local directory <code>/var/log/messages</code> as the single file messages-archive.tar.</p> <pre>user@host> file archive source /var/log/messages destination /var/log/messages-archive.tar /usr/bin/tar: Removing leading / from absolute path names in the archive. user@host></pre>
file archive (with Compression)	<p>The following sample command archives and compresses all message files in the local directory <code>/var/log/messages</code> as the single file messages-archive.tgz.</p>


```
user@host> file archive compress source /var/log/messages* destination  
/var/log/messages-archive.tgz  
/usr/bin/tar: Removing leading / from absolute path names in the archive.
```

file checksum md5

Syntax	<code>file checksum md5 <pathname> filename</code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Calculate the Message Digest 5 (MD5) checksum of a file.
Options	<i>pathname</i> —(Optional) Path to a filename. <i>filename</i> —Name of a local file for which to calculate the MD5 checksum.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• Configuring Checksum Hashes for a Commit Script in the <i>Junos OS Configuration and Operations Automation Guide</i>• Configuring Checksum Hashes for an Event Script in the <i>Junos OS Configuration and Operations Automation Guide</i>• Configuring Checksum Hashes for an Op Script in the <i>Junos OS Configuration and Operations Automation Guide</i>• Executing an Op Script from a Remote Site in the <i>Junos OS Configuration and Operations Automation Guide</i>• file checksum sha-256 on page 572• file checksum sha1 on page 571• op on page 722
List of Sample Output	file checksum md5 on page 570
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
file checksum md5  user@host> file checksum md5 jbundle-5.3R2.4-export-signed.tgz
MD5 (jbundle-5.3R2.4-export-signed.tgz) = 2a3b69e43f9bd4893729cc16f505a0f5
```

file checksum sha1

Syntax	<code>file checksum sha1 <pathname> filename</code>
Release Information	<p>Command introduced in Junos OS Release 9.5.</p> <p>Command introduced in Junos OS Release 9.5 for EX Series switches.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Calculate the Secure Hash Algorithm (SHA-1) checksum of a file.
Options	<p><i>pathname</i>—(Optional) Path to a filename.</p> <p><i>filename</i>—Name of a local file for which to calculate the SHA-1 checksum.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> Configuring Checksum Hashes for a Commit Script in the <i>Junos OS Configuration and Operations Automation Guide</i> Configuring Checksum Hashes for an Event Script in the <i>Junos OS Configuration and Operations Automation Guide</i> Configuring Checksum Hashes for an Op Script in the <i>Junos OS Configuration and Operations Automation Guide</i> Executing an Op Script from a Remote Site in the <i>Junos OS Configuration and Operations Automation Guide</i> file checksum md5 on page 570 file checksum sha-256 on page 572 op on page 722
List of Sample Output	file checksum sha1 on page 571
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

file checksum sha1  user@host> file checksum sha1 /var/db/scripts/opscript.slax

SHA1 (/var/db/scripts/commitscript.slax) = ba9e47120c7ce55cff29afd73eacd370e162c676

```

file checksum sha-256

Syntax	<code>file checksum sha-256 <pathname> filename</code>
Release Information	Command introduced in Junos OS Release 9.5. Command introduced in Junos OS Release 9.5 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Calculate the Secure Hash Algorithm 2 family (SHA-256) checksum of a file.
Options	<i>pathname</i> —(Optional) Path to a filename. <i>filename</i> —Name of a local file for which to calculate the SHA-256 checksum.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• Configuring Checksum Hashes for a Commit Script in the <i>Junos OS Configuration and Operations Automation Guide</i>• Configuring Checksum Hashes for an Event Script in the <i>Junos OS Configuration and Operations Automation Guide</i>• Configuring Checksum Hashes for an Op Script in the <i>Junos OS Configuration and Operations Automation Guide</i>• Executing an Op Script from a Remote Site in the <i>Junos OS Configuration and Operations Automation Guide</i>• file checksum md5 on page 570• file checksum sha1 on page 571• op on page 722
List of Sample Output	file checksum sha-256 on page 572
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
file checksum sha-256  user@host> file checksum sha-256 /var/db/scripts/commitscript.slax

SHA256 (/var/db/scripts/commitscript.slax) =
94c2b061fb55399e15babd2529453815601a602b5c98e5c12ed929c9d343dd71
```

file compare

Syntax	file compare (files <i>filename filename</i>) <context unified> <ignore-white-space>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	<p>Compare two local files and describe the differences between them in default, context, or unified output styles:</p> <ul style="list-style-type: none"> • Default—In the first line of output, c means lines were changed between the two files, d means lines were deleted between the two files, and a means lines were added between the two files. The numbers preceding this alphabetical marker represent the first file, and the lines after the alphabetical marker represent the second file. A left angle bracket (<) in front of output lines refers to the first file. A right angle bracket (>) in front of output lines refers to the second file. • Context—The display is divided into two parts. The first part is the first file; the second part is the second file. Output lines preceded by an exclamation point (!) have changed. Additions are marked with a plus sign (+), and deletions are marked with a minus sign (-). • Unified—The display is preceded by the line number from the first and the second file (xx,xxx,x). Before the line number, additions to the file are marked with a plus sign (+), and deletions to the file are marked with a minus sign (-). The body of the output contains the affected lines. Changes are viewed as additions plus deletions.
Options	<p>files <i>filename</i>—Names of two local files to compare.</p> <p>context—(Optional) Display output in context format.</p> <p>ignore-white-space—(Optional) Ignore changes in the amount of white space.</p> <p>unified—(Optional) Display output in unified format.</p>
Required Privilege Level	none
List of Sample Output	<p>file compare files on page 574</p> <p>file compare files context on page 574</p> <p>file compare files unified on page 574</p> <p>file compare files unified ignore-white-space on page 574</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

file compare files user@host> file compare files /tmp/one /tmp/two
100c100
<          full-name "File 1";
---
>          full-name "File 2";
102c102
<          class foo; # 'foo' is not defined
---
>          class super-user;

```

```

file compare files user@host> file compare files /tmp/one /tmp/two context
context
*** /tmp/one   Wed Dec  3 17:12:50 2003
--- /tmp/two   Wed Dec  3 09:13:14 2003
*****
*** 97,104 ***
    }
  }
  user bill {
!    full-name "Bill Smith";
!    class foo; # 'foo' is not defined
    authentication {
        encrypted-password SECRET;
    }
--- 97,105 ----
    }
  }
  user bill {
!    full-name "Bill Smith";
!    uid 1089;
!    class super-user;
    authentication {
        encrypted-password SECRET;
    }

```

```

file compare files user@host> file compare files /tmp/one /tmp/two unified
unified
--- /tmp/one   Wed Dec  3 17:12:50 2003
+++ /tmp/two   Wed Dec  3 09:13:14 2003
@@ -97,8 +97,9 @@
    }
  }
  user bill {
-    full-name "Bill Smith";
-    class foo; # 'foo' is not defined
+    full-name "Bill Smith";
+    uid 1089;
+    class super-user;
    authentication {
        encrypted-passwordSECRET;
    }

```

```

file compare files user@host> file compare files /tmp/one /tmp/two unified ignore-white-space
unified ignore-white-space
--- /tmp/one   Wed Dec  3 09:13:10 2003
+++ /tmp/two   Wed Dec  3 09:13:14 2003
@@ -99,7 +99,7 @@
  user bill {
    full-name "Bill Smith";
    uid 1089;

```

```
-      class foo; # 'foo' is not defined
+      class super-user;
      authentication {
          encrypted-password <SECRET>; # SECRET-DATA
      }
```

file copy

Syntax	<code>file copy <i>source destination</i></code> <code><source-address <i>address</i>></code>
Release Information	Command introduced before Junos OS Release 7.4. source-address option added in Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for QFX Series switches.
Description	Copy files from one place to another on the local router or switch or between the local router or switch and a remote system.
Options	<i>source</i> —Source of the original file. Specify this as a URL or filename. <i>destination</i> —Destination of the copied file. Specify this as a URL or filename. If you are copying a file to the current directory (your home directory on the local router or switch) and are not renaming the file, specify the destination with a period (.). <i>source-address <i>address</i></i> —(Optional) Source IP host address. This option is useful for specifying the source address of a secure copy (scp) file transfer.
Required Privilege Level	maintenance
List of Sample Output	file copy (A File from the Router or Switch to a PC) on page 576 file copy (A Configuration File Between Routing Engines) on page 576 file copy (A Log File Between Routing Engines) on page 576 file copy (A File from the TX Matrix Plus Router to a T1600 Router Connected to the TX Matrix Plus Router) on page 576
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

file copy (A File from the Router or Switch to a PC)	<pre>user@host> file copy /var/tmp/rpd.core.4 berry:/c/junipero/tmp</pre> <pre>...transferring.file..... 0 KB 0.3 kB/s ETA: 00:00:00 100%</pre>
file copy (A Configuration File Between Routing Engines)	<p>The following sample command copies a configuration file from Routing Engine 0 to Routing Engine 1:</p> <pre>user@host> file copy /config/juniper.conf re1:/var/tmp/copied-juniper.conf</pre>
file copy (A Log File Between Routing Engines)	<p>The following sample command copies a log file from Routing Engine 0 to Routing Engine 1:</p> <pre>user@host> file copy lcc0-re0:/var/log/chassisd lcc0-re1:/var/tmp</pre>
file copy (A File from the TX Matrix Plus Router to a T1600 Router)	<p>The following sample command copies a text file from Routing Engine 1 on the switch-fabric chassis sfc0 to Routing Engine 1 on the line-card chassis lcc0:</p>

Router Connected to the TX Matrix Plus Router)

```
user@host> file copy sfc0-re1:/tmp/sample.txt lcc0-re1:/var/tmp
```

file delete

Syntax	<code>file delete <i>filename</i></code> <code><purge></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Delete a file on the local router or switch.
Options	<i>filename</i> —Name of the file to delete. For a routing matrix, include chassis information in the filename if the file to be deleted is not local to the Routing Engine from which the command is issued. <code>purge</code> —(Optional) Overwrite regular files before deleting them.
Required Privilege Level	maintenance
List of Sample Output	file delete on page 578 file delete (Routing Matrix) on page 578
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

file delete	<pre>user@host> file list /var/tmp dcd.core rpd.core snmpd.core user@host> file delete /var/tmp/snmpd.core user@host> file list /var/tmp dcd.core rpd.core</pre>
file delete (Routing Matrix)	<pre>user@host> file list lcc0-re0:/var/tmp dcd.core rpd.core snmpd.core user@host> file delete lcc0-re0:/var/tmp/snmpd.core user@host> file list /var/tmp dcd.core rpd.core</pre>

file list

Syntax	file list <detail recursive> <filename>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display a list of files on the local router or switch.
Options	<p>none—Display a list of all files for the current directory.</p> <p>detail recursive—(Optional) Display detailed output or descend recursively through the directory hierarchy, respectively.</p> <p>filename—(Optional) Display a list of files. For a routing matrix, the filename must include the chassis information.</p>
Additional Information	The default directory is the home directory of the user logged in to the router or switch. To view available directories, enter a space and then a backslash (/) after the file list command. To view files within a specific directory, include a backslash followed by the directory and, optionally, subdirectory name after the file list command.
Required Privilege Level	maintenance
List of Sample Output	file list on page 579 file list (Routing Matrix) on page 579
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

file list      user@host> file list /var/tmp
               dcd.core
               rpd.core
               snmpd.core

file list (Routing Matrix) user@host> file list lcc0-re0:var/tmp
                           lcc0-re0:
                           -----
                           /var/tmp/:
                           .gdbinit
                           .pccardd
                           Test/
                           chassisd*
                           chassisd.nathan*
                           check_time*
                           cores/
                           diagTestPrep*
                           diagtest*

```

diagtest.regress*
do_switchovers*
dump_test*
err.manoj.log
esw_clearstats*
esw_counter*
esw_debug*
esw_debug_ge*
esw_filt_test*
esw_filter_tnp_addr*
esw_getstats*
esw_phy*
esw_stats*

file rename

Syntax	<code>file rename <i>source destination</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Rename a file on the local router or switch.
Options	<i>destination</i> —New name for the file. <i>source</i> —Original name of the file. For a routing matrix, the filename must include the chassis information.
Required Privilege Level	maintenance
List of Sample Output	file rename on page 581 file rename (Routing Matrix) on page 581
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

file rename	<p>The following example lists the files in <code>/var/tmp</code>, renames one of the files, and then displays the list of files again to reveal the newly named file.</p> <pre> user@host> file list /var/tmp dcd.core rpd.core snmpd.core user@host> file rename /var/tmp/dcd.core /var/tmp/dcd.core.990413 user@host> file list /var/tmp dcd.core.990413 rpd.core snmpd.core </pre>
file rename (Routing Matrix)	<p>The following example lists the files in <code>/var/tmp</code>, renames one of the files, and then displays the list of files again to reveal the newly named file.</p> <pre> user@host> file list lcc0-re1:/var/tmp lcc0-re1: ----- /var/tmp: .pccardd sartre.conf snmpd syslogd.core-tarball.0.tgz user@host> file rename lcc0-re0:/var/tmp/snmpd /var/tmp/snmpd.rr user@host> file list lcc0-re1:/var/tmp lcc0-re1: ----- </pre>

```
/var/tmp:  
.pccardd  
sartre.conf  
snmpd.rr  
syslogd.core-tarball.0.tgz
```

file show

Syntax	<code>file show <i>filename</i></code> <code><encoding (base64 raw)></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the contents of a file.
Options	<i>filename</i> —Name of a file. For a routing matrix, the filename must include the chassis information. encoding (base64 raw)—(Optional) Encode file contents with base64 encoding or show raw text.
Required Privilege Level	maintenance
List of Sample Output	file show on page 583 file show (Routing Matrix) on page 583
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

file show user@host> file show /var/log/messages
Apr 13 21:00:08 romney /kernel: so-1/1/2: loopback suspected; going to standby.
Apr 13 21:00:40 romney /kernel: so-1/1/2: loopback suspected; going to standby.
Apr 13 21:02:48 romney last message repeated 4 times
Apr 13 21:07:04 romney last message repeated 8 times
Apr 13 21:07:13 romney /kernel: so-1/1/0: Clearing SONET alarm(s) RDI-P
Apr 13 21:07:29 romney /kernel: so-1/1/0: Asserting SONET alarm(s) RDI-P
...

file show user@host> file show lcc0-re0:/var/tmp/gdbinit
(Routing Matrix) lcc0-re0:
-----
#####
# Settings
#####

set print pretty

#####
# Basic stuff
#####

define msgbuf
    printf "%s", msgbufp->msg_ptr
end
# hex dump of a block of memory
# usage: dump address length
define dump

```

```
p $arg0, $arg1
set $ch = $arg0
set $j = 0
set $n = $arg1
while ($j < $n)
    #printf "%x %x ",&$ch[$j],$ch[$j]
    printf "%x ",$ch[$j]
    set $j = $j + 1
    if (!($j % 16))
        printf "\n"
    end
end
end
end
```


show log

Syntax	show log <filename user <username>>
Syntax (TX Matrix Router)	show log <all-lcc lcc <i>number</i> scc> <filename user <username>>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	List log files, display log file contents, or display information about users who have logged in to the router or switch.
Options	<p>none—List all log files.</p> <p><all-lcc lcc <i>number</i> scc>—(Routing matrix only)(Optional) Display logging information about all T640 routers (or line-card chassis) or a specific T640 router (replace <i>number</i> with a value from 0 through 3) connected to a TX Matrix router. Or, display logging information about the TX Matrix router (or switch-card chassis).</p> <p><i>filename</i>—(Optional) Display the log messages in the specified log file. For the routing matrix, the filename must include the chassis information.</p> <p>user <username>—(Optional) Display logging information about users who have recently logged in to the router or switch. If you include <i>username</i>, display logging information about the specified user.</p>
Required Privilege Level	trace
List of Sample Output	<p>show log on page 585</p> <p>show log filename on page 586</p> <p>show log user on page 586</p>

Sample Output

```

user@host> show log
total 57518
-rw-r--r--  1 root  bin      211663 Oct  1 19:44 dcd
-rw-r--r--  1 root  bin      999947 Oct  1 19:41 dcd.0
-rw-r--r--  1 root  bin      999994 Oct  1 17:48 dcd.1
-rw-r--r--  1 root  bin      238815 Oct  1 19:44 rpd
-rw-r--r--  1 root  bin     1049098 Oct  1 18:00 rpd.0
-rw-r--r--  1 root  bin     1061095 Oct  1 12:13 rpd.1
-rw-r--r--  1 root  bin     1052026 Oct  1 06:08 rpd.2
-rw-r--r--  1 root  bin     1056309 Sep 30 18:21 rpd.3
-rw-r--r--  1 root  bin     1056371 Sep 30 14:36 rpd.4
-rw-r--r--  1 root  bin     1056301 Sep 30 10:50 rpd.5
-rw-r--r--  1 root  bin     1056350 Sep 30 07:04 rpd.6

```

```
-rw-r--r-- 1 root bin      1048876 Sep 30 03:21 rpd.7
-rw-rw-r-- 1 root bin      19656 Oct  1 19:37 wtmp
```

```
show log filename user@host> show log rpd
Oct  1 18:00:18 trace_on: Tracing to ?/var/log/rpd? started
Oct  1 18:00:18 EVENT <MTU> ds-5/2/0.0 index 24 <Broadcast PointToPoint Multicast
Oct  1 18:00:18
Oct  1 18:00:19 KRT recv len 56 V9 seq 148 op add Type route/if af 2 addr
13.13.13.21 nhop type local nhop 13.13.13.21
Oct  1 18:00:19 KRT recv len 56 V9 seq 149 op add Type route/if af 2 addr
13.13.13.22 nhop type unicast nhop 13.13.13.22
Oct  1 18:00:19 KRT recv len 48 V9 seq 150 op add Type ifaddr index 24 devindex
43
Oct  1 18:00:19 KRT recv len 144 V9 seq 151 op chnge Type ifdev devindex 44
Oct  1 18:00:19 KRT recv len 144 V9 seq 152 op chnge Type ifdev devindex 45
Oct  1 18:00:19 KRT recv len 144 V9 seq 153 op chnge Type ifdev devindex 46
Oct  1 18:00:19 KRT recv len 1272 V9 seq 154 op chnge Type ifdev devindex 47
...
```

```
show log user user@host> show log user
darius mg2546 Thu Oct  1 19:37 still logged in
darius mg2529 Thu Oct  1 19:08 - 19:36 (00:28)
darius mg2518 Thu Oct  1 18:53 - 18:58 (00:04)
root mg1575 Wed Sep 30 18:39 - 18:41 (00:02)
root ttyt2 jun.site.per Wed Sep 30 18:39 - 18:41 (00:02)
alex ttyt1 192.168.1.2 Wed Sep 30 01:03 - 01:22 (00:19)
```

Packet Forwarding Engine Operational Mode Commands

Table 105 on page 587 summarizes the command-line interface (CLI) commands you can use to perform and monitor Packet Forwarding Engine management functions. Commands are listed in alphabetical order.

Table 105: Packet Forwarding Engine Operational Mode Commands

Task	Command
Display Packet Forwarding Engine Compact Forwarding Engine Board (CFEB) status and statistics information.	show pfe cfeb
Display Packet Forwarding Engine Forwarding Engine Board (FEB) status and statistics information.	show pfe feb
Display Packet Forwarding Engine statistics for the specified Flexible PIC Concentrator (FPC).	show pfe fpc
(J Series router only) Display Packet Forwarding Engine forwarding process (fwdd) status and statistics information.	show pfe fwdd
(Routing matrix only) Display Packet Forwarding Engine information for the specified T640 router (or line-card chassis).	show pfe lcc
Display Packet Forwarding Engine next-hop information.	show pfe next-hop
Display IPv4 Packet Forwarding Engine statistics.	show pfe statistics ip
(M320 and T320 routers, and T-640 only) Display Packet Forwarding Engine resource and L-chip SRAM memory usage statistics.	show pfe resource usage memory
Display the routes in the Packet Forwarding Engine forwarding table.	show pfe route
(M40 routers only) Display Packet Forwarding Engine System Control Board (SCB) status and statistics information.	show pfe scb

Table 105: Packet Forwarding Engine Operational Mode Commands (*continued*)

Task	Command
(M40e and M160 routers only) Display Packet Forwarding Engine Switching and Forwarding Module (SFM) status and statistics information.	show pfe sfm
(M20 routers only) Display Packet Forwarding Engine System and Switch Board (SSB) status and statistics information.	show pfe ssb
Display Packet Forwarding Engine direct memory access (DMA) statistics.	show pfe statistics dma
Display Packet Forwarding Engine error statistics.	show pfe statistics error
Display Packet Forwarding Engine IPv6 statistics.	show pfe statistics ip6
Display Packet Forwarding Engine notification statistics.	show pfe statistics notification
Display Packet Forwarding Engine polled I/O (PIO) statistics.	show pfe statistics pio
Display Packet Forwarding Engine traffic statistics.	show pfe statistics traffic
Display Packet Forwarding Engine traffic statistics for Bidirectional Forwarding Detection (BFD).	show pfe statistics traffic protocol bfd
Display Packet Forwarding Engine traffic statistics for connectivity fault management (CFM).	show pfe statistics traffic protocol cfm
Display Packet Forwarding Engine traffic statistics for link fault management (LFM).	show pfe statistics traffic protocol lfm
Display Packet Forwarding Engine status information.	show pfe terse
(M320 and T320 routers, and T-640 only) Display Packet Forwarding Engine resource and L-chip SRAM memory usage statistics.	show pfe resource usage memory
Display Packet Forwarding Engine version information.	show pfe version



NOTE: For information about how to configure PFE parameters, see the *Junos OS System Basics Configuration Guide*.

show pfe cfeb

Syntax	show pfe cfeb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M7i routers only) Display Packet Forwarding Engine Compact Forwarding Engine Board (CFEB) status and statistics information.
Options	This command has no options.
Required Privilege Level	admin
List of Sample Output	show pfe cfeb on page 589

Sample Output

```

user@host> show pfe cfeb
CFEB status:
  Slot:                Present
  State:                Online
  Last State Change:   2005-03-10 09:01:25 PST
  Uptime (total):      2d 00:44
  Failures:            0
  Pending:             0

Peer message type receive qualifiers:
Message Type      Receive Qualifier
-----
          TTP      All
          IFD      All
          IFL      All
        Nexthop    All
          COS      All
          Route    All
        SW Firewall All
        HW Firewall All
      PFE Statistics All
      PIC Statistics All
        Sampling    All
        Monitoring  None
          ASP       None
          L2TP      None
        Collector   None
PIC Configuration  All
Queue Statistics   All
      (null)       None

PFE listener statistics:
  Open:             1
  Close:            0
  Sleep:            0
  Wakeup:           0
  Resync Request:   0
  Resync Done:      1
  Resync Fail:      0
  Resync Time:      0

```

PFE IPC statistics:

type	TX Messages	RX messages
Header	0	0
Test	0	0
Interface	562	14582
Chassis	0	0
Boot	0	0
Next-hop	104	0
Jtree	0	0
Cprod	0	0
Route	103	1
Pfe	3770	2925
Dfw	10	0
Mastership	0	0
Sampling	0	0
GUCP	0	0
CoS	50	0
GCCP	0	0
GHCP	0	0
IRSD	0	0
Monitoring	0	0
RE	0	0
PIC	0	0
ASP cfg	0	0
ASP cmd	0	0
L2TP cfg	0	0
Collector	0	0
PIC state	0	0
Aggregator	0	0
Empty	0	0

PFE socket-buffer mbuf depth:

bucket	count
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

PFE socket-buffer bytes pending transmit:

bucket	count
--------	-------

-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

show pfe feb

Syntax	show pfe feb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M5 and M10 routers only) Display Packet Forwarding Engine Forwarding Engine Board (FEB) status and statistics information.
Options	This command has no options.
Required Privilege Level	admin
List of Sample Output	show pfe feb on page 592

Sample Output

```

user@host> show pfe feb
FEB status:
  Slot:                Present
  State:                Online
  Last State Change:    2005-03-11 00:33:57 PST
  Uptime (total):       1d 09:14
  Failures:             0
  Pending:              0

Peer message type receive qualifiers:
Message Type      Receive Qualifier
-----
          TTP      All
          IFD      All
          IFL      All
        Nexthop    All
          COS      All
          Route     All
        SW Firewall All
        HW Firewall All
      PFE Statistics All
      PIC Statistics All
        Sampling    All
        Monitoring  None
          ASP       None
          L2TP      None
        Collector   None
PIC Configuration All
Queue Statistics   All
      (null)        None

PFE listener statistics:
  Open:            1
  Close:           0
  Sleep:           0
  Wakeup:          0
  Resync Request:  0
  Resync Done:     1
  Resync Fail:     0
  Resync Time:     0

```


PFE IPC statistics:

type	TX Messages	RX messages
Header	0	0
Test	0	0
Interface	639	11889
Chassis	0	0
Boot	0	0
Next-hop	104	0
Jtree	0	0
Cprod	0	0
Route	940	0
Pfe	3008	1995
Dfw	9	0
Mastership	0	0
Sampling	0	0
GUCP	0	0
CoS	35	0
GCCP	0	0
GHCP	0	0
IRSD	0	0
Monitoring	0	0
RE	0	0
PIC	0	0
ASP cfg	0	0
ASP cmd	0	0
L2TP cfg	0	0
Collector	0	0
PIC state	0	0
Aggregator	0	0
Empty	0	0

PFE socket-buffer mbuf depth:

bucket	count
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

PFE socket-buffer bytes pending transmit:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

show pfe fpc

Syntax	show pfe fpc <i>slot</i> <detail extensive>
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe fpc <lcc <i>number</i> >
Syntax (MX Series Router)	show pfe fpc <i>slot</i> <detail extensive> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Packet Forwarding Engine statistics for the specified Flexible PIC Concentrator (FPC).
Options	<p><i>slot</i>—FPC slot number. Replace <i>slot</i> with a value from 0 through 2.</p> <p>detail extensive—(Optional) Display the specified level of detail.</p> <p>all-members—(MX Series routers only) (Optional) Display Packet Forwarding Engine statistics for the specified FPC in all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, the slot number of the T640 router (or line-card chassis) that houses the FPC. On a TX Matrix Plus router, lcc <i>number</i> represents the slot number of the T1600 router (or line-card chassis) that houses the FPC. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display Packet Forwarding Engine statistics for the specified FPC in the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display Packet Forwarding Engine statistics for the specified FPC in the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe fpc on page 595</p> <p>show pfe fpc lcc on page 596</p> <p>show pfe fpc 0 detail on page 598</p>

Sample Output

```

user@host> show pfe fpc 1
FPC 1 status:
  Slot:                Present
  State:                Online
  Last State Change:    2000-01-10 18:12:27 UTC

```

```

Uptime:                1d 03:31
Failures:              0
Pending:               0
Route Memory Enhanced: 0
PFE listener statistics:
Open:                  1
Close:                 0
Sleep:                 0
Wakeup:                0
Resync Request:        0
Resync Done:           0
Resync Fail:           0
Resync Time:           0

PFE IPC statistics:
type      TX Messages  RX messages
-----
Header    0            0
Test      0            0
Interface 2251          2219
Chassis   0            0
Boot      0            0
Next-hop  0            0
Jtree     0            0
Cprod     0            0
Route     0            0
Pfe       0            1
Dfw

```

show pfe fpc lcc user@host> show pfe fpc 0 lcc 0
lcc0-re0:

```

-----
GFPC 0 status:
Slot:                Present
State:               Online
Last State Change:   2009-06-17 21:00:35 PDT
Uptime (total):      02:31:45
Failures:            0
Pending:             0

```

Peer message type receive qualifiers [non-NONE(s) only]:
IPC Msg Type (subtype) Receive Qualifier

```

-----
Interface (0)    A11
Interface (1)    A11
Interface (2)    A11
Interface (3)    A11
Interface (4)    A11
Interface (5)    A11
Interface (6)    A11
Interface (7)    A11
Interface (8)    A11
Interface (9)    A11
Interface (10)   A11
Interface (11)   A11
Interface (12)   A11
Interface (13)   A11
Interface (14)   A11
Interface (15)   A11
Interface (16)   A11
Interface (17)   A11

```

```

Interface      (18)      All
Interface      (19)      All
Interface      (20)      Slot only
Interface      (21)      All
...
Next-hop       (0)       All
Next-hop       (1)       All
Next-hop       (2)       All
Next-hop       (3)       All
Next-hop       (4)       All
Next-hop       (5)       Always TRUE
...
Route          (0)       All
Route          (1)       All
Route          (2)       All
Route          (3)       All
Route          (4)       All
Route          (5)       All
Route          (6)       All
Route          (7)       All
Route          (8)       All
...
Pfe            (1)       Always TRUE
Pfe            (3)       Always TRUE
Pfe            (5)       Always TRUE
...
Dfw            (0)       All
Dfw            (1)       All
Dfw            (2)       All
Dfw            (3)       All
...
Sampling       (1)       All
Sampling       (2)       All
Sampling       (3)       All
CoS            (0)       All
CoS            (1)       All
CoS            (2)       All
CoS            (3)       All
...
PIC            (1)       Always TRUE
PIC            (3)       Always TRUE
...
GenCfg         (8)       All
GenCfg         (15)      All
...
IFSTATE BITS SET:
-----
IFD
IFL
IFF
IFA
RTTABLE
ROUTE
NEXTHOP
FIREWALL
NAME TABLE
COS_FABRIC
COS_POLICY
COS_RED

```

```

COS_REWRT_TABLE
COS_REWRT_IFLMAP
COS_CLASS_TABLE
COS_CLASS_IFLMAP
COS_POLICER
COS_SHAPER
SAMPLE
RTCOS
SYSCONF
IFVP
SADB
IFVC
COS_FC_QUEUE
COS_FRAGMAP_TABLE
COS_FRAGMAP_IFLMAP
Generic config
Mesh group

```

PFE listener statistics:

```

Open:          1
Close:         0
Sleep:         0
Wakeup:        0
Resync Request: 0
Resync Done:   1
Resync Fail:   0
Resync Time:   0

```

PFE IPC statistics:

Type (subtype)	TX Messages	RX messages
Interface (3)	165	0
Interface (4)	81	0
Interface (5)	0	190
Interface (8)	145	0
Interface (9)	425	0
Interface (10)	24	0

...

PFE socket-buffer mbuf depth:

bucket	count
0	0
1	0
2	0

PFE socket-buffer bytes pending transmit:

bucket	count
0	0
1	0

...

show pfe fpc 0 detail user@host> show pfe fpc 0 detail

GFPC 2 status:

```

Slot:          Present
State:         Online
Last State Change: 2010-11-16 03:55:25 PST
Uptime (total): 00:11:06
Failures:      1
Pending:       0

```

Route Memory Enhanced: 0

Filter Memory Enhanced: 1

Peer message type receive qualifiers [non-NONE(s) only]:

IPC Msg Type (subtype)	Receive Qualifier
Interface (0)	All
Interface (1)	All
Interface (2)	All
Interface (3)	All
Interface (4)	All
Interface (5)	All
Interface (6)	All
Interface (7)	All
Interface (8)	All
Interface (9)	All
Interface (10)	All
Interface (11)	All
...	
Next-hop (0)	All
Next-hop (1)	All
Next-hop (2)	All
Next-hop (3)	All
Next-hop (4)	All
Next-hop (5)	All
...	
Route (0)	All
Route (1)	All
Route (2)	All
Route (3)	All
Route (4)	All
Route (5)	All
...	
Pfe (1)	Always TRUE
Pfe (3)	Always TRUE
Pfe (5)	Always TRUE
...	
Dfw (0)	All
Dfw (1)	All
Dfw (2)	All
Dfw (3)	All
...	
Sampling (1)	All
Sampling (2)	All
Sampling (3)	All
CoS (0)	All
CoS (1)	All
CoS (2)	All
CoS (3)	All
CoS (4)	All
...	
PIC (1)	Always TRUE
PIC (3)	Always TRUE
...	
GenCfg (8)	All
GenCfg (15)	All
...	

IFSTATE BITS SET:

IFD
IFL

```

IFF
IFA
RTTABLE
ROUTE
NEXTHOP
FIREWALL
NAME TABLE
COS_FABRIC
COS_POLICY
COS_RED
COS_REWRT_TABLE
COS_REWRT_IFLMAP
COS_CLASS_TABLE
COS_CLASS_IFLMAP
COS_POLICER
COS_SHAPER
SAMPLE
RTCOS
SYSCONF
IFVP
SADB
IFVC
COS_FC_QUEUE
COS_FRAGMAP_TABLE
COS_FRAGMAP_IFLMAP
Generic config
Mesh group

```

PFE listener statistics:

```

Open:                2
Close:               1
Sleep:               0
Wakeup:              0
Resync Request:      0
Resync Done:         2
Resync Fail:         0
Resync Time:         0

```

PFE IPC statistics:

Type (subtype)	TX Messages	RX messages
-----	-----	-----
Interface (3)	104	0
Interface (5)	0	8
Interface (8)	85	0
Interface (9)	67	0
Interface (10)	4	0
...		
Next-hop (1)	364	0
Next-hop (3)	12	0
Next-hop (11)	33	0
Next-hop (23)	39	0
Route (1)	331	0
Route (2)	34	0
Route (3)	1	0
Route (6)	1	0
Route (9)	48	0
Pfe (1)	0	1
Pfe (3)	1	0
Pfe (4)	0	1
Pfe (5)	1	0
...		

Dfw	(1)	20	0
Dfw	(18)	1	0
GenCfg	(8)	45	0
GenCfg	(15)	1	0

show pfe fwdd

Syntax	show pfe fwdd
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series routers only) Display Packet Forwarding Engine forwarding process (fwdd) status and statistics information.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show pfe fwdd on page 602

Sample Output

```

user@host> show pfe fwdd
FWDD status:
  Slot:                Present
  State:                Online
  Last State Change:   2004-09-15 16:00:36 PDT
  Uptime (total):      1d 01:16
  Failures:            0
  Pending:             0

Peer message type receive qualifiers:
Message Type      Receive Qualifier
-----
          TTP      Slot only
          IFD      All
          IFL      All
        Nexthop    All
          COS      All
          Route    All
        SW Firewall All
        HW Firewall All
      PFE Statistics All
      PIC Statistics All
        Sampling   All
        Monitoring All
          ASP      Slot only
          L2TP     None
        Collector  None

PFE listener statistics:
  Open:            1
  Close:           0
  Sleep:           0
  Wakeup:          0
  Resync Request:  0
  Resync Done:     1
  Resync Fail:     0
  Resync Time:     0

PFE IPC statistics:
type              TX Messages  RX messages

```

Header	0	0
Test	0	0
Interface	221	3189
Chassis	0	0
Boot	0	0
Next-hop	40	0
Jtree	0	0
Cprod	0	0
Route	45	0
Pfe	1907	1520
Dfw	16	0
Mastership	0	0
Sampling	0	0
GUCP	0	0
CoS	20	0
GCCP	0	0
GHCP	0	0
IRSD	0	0
Monitoring	0	0
RE	0	0
PIC	0	0
ASP cfg	0	0
ASP cmd	0	0
L2TP cfg	0	0
Collector	0	0
PIC state	0	0

PFE socket-buffer mbuf depth:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

PFE socket-buffer bytes pending transmit:

bucket	count
-----	-----
0	0
1	0
2	0
3	0

4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

show pfe lcc

Syntax (TX Matrix and TX Matrix Plus Router) `show pfe lcc number`

Release Information Command introduced before Junos OS Release 7.4.

Description (TX Matrix and TX Matrix Plus router only) On a TX Matrix router, display Packet Forwarding Engine status and statistics for the specified T640 router (or line-card chassis). On a TX Matrix Plus router, display Packet Forwarding Engine status and statistics for the specified T1600 router (or line-card chassis).

Options *lcc number*—On a TX Matrix router, the slot number of the T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, the slot number of the T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

Required Privilege Level admin

List of Sample Output `show pfe lcc` on page 605

Sample Output

```
user@host> show pfe lcc 0
LCC 0 status:
  Slot:                Present
  State:               Online
  Last State Change:   2005-03-10 19:31:50 PST
  Uptime (total):      1d 14:20
  Failures:            23
  Pending:             0

Peer message type receive qualifiers:
Message Type      Receive Qualifier
-----
                TTP All detail
                IFD All detail
                IFL All detail
                Nexthop All
                COS All
                Route All
                SW Firewall All
                HW Firewall All
                PFE Statistics All
                PIC Statistics All
                Sampling All detail
                Monitoring All detail
                ASP All detail
                L2TP All detail
                Collector All detail

PFE listener statistics:
  Open:              25
  Close:             23
  Sleep:             0
  Wakeup:            0
```

```

Resync Request:    0
Resync Done:       2
Resync Fail:       0
Resync Time:       0

```

PFE IPC statistics:

type	TX Messages	RX messages
-----	-----	-----
Header	0	0
Test	0	0
Interface	163	2923
Chassis	0	0
Boot	0	0
Next-hop	15	0
Jtree	0	0
Cprod	0	0
Route	100	0
Pfe	5369	3072
Dfw	11	0
Mastership	0	0
Sampling	0	0
GUCP	0	0
CoS	20	0
GCCP	0	0
GHCP	0	0
IRSD	0	0
Monitoring	0	0
RE	3	6930
PIC	0	0
ASP cfg	0	0
ASP cmd	0	0
L2TP cfg	0	0
Collector	0	0
PIC state	4	0

PFE socket-buffer mbuf depth:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

PFE socket-buffer bytes pending transmit:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

show pfe next-hop

Syntax	show pfe next-hop <interface <i>interface-name</i> >
Syntax (TX Matrix and TX Matrix Plus router)	show pfe next-hop <fpc <i>slot</i> > <interface <i>interface-name</i> > <lcc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display Packet Forwarding Engine next-hop information.
Options	<p>none—Display all Packet Forwarding Engine next-hop information.</p> <p>fpc <i>slot</i>—(TX Matrix and TX Matrix Plus router only) (Optional) Show the next hops for a Flexible PIC Concentrator (FPC) slot. On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. For example, the following commands have the same result:</p> <pre>user@host> show pfe next-hop fpc 1 lcc 1 user@host> show pfe next-hop fpc 9</pre> <p>interface <i>interface-name</i>—(Optional) Display the Packet Forwarding Engine next-hop interface.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, the slot number of the T640 router (or line-card chassis) that houses the FPC. On a TX Matrix Plus router, the slot number of the T1600 router (or line-card chassis) that houses the FPC. Replace number with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	show pfe next-hop on page 609 show pfe next-hop fpc (TX Matrix Router) on page 609 show pfe next-hop fpc (TX Matrix Plus Router) on page 609

Sample Output

show pfe next-hop

user@host> show pfe next-hop

NextHop Info:

ID	Type	Interface	Protocol	Encap	Next Hop Addr	MTU
4	Mcast	-	IPv4	-	0.0.0.0	0
5	Bcast	-	IPv4	-	-	0
7	Discard	-	IPv4	-	-	0
8	MDiscard	-	IPv4	-	-	0
9	Reject	-	IPv4	-	-	0
13	Local	-	IPv4	-	192.168.4.60	0
14	Resolve	fxp0.0	IPv4	Unspecified	-	0
17	Local	-	IPv4	-	127.0.0.1	0
18	Unicast	fxp0.0	IPv4	Unspecified	192.168.4.254	0
21	Local	-	IPv4	-	11.1.0.1	0
22	Unicast	at-0/1/0.0	IPv4	ATM SNAP	11.1.0.2	4482
...						

**show pfe next-hop fpc
(TX Matrix Router)**

user@host> show pfe next-hop fpc 1

Slot 1

NextHop Info:

ID	Type	Interface	Next Hop Addr	Protocol	Encap	MTU
5	Mcast	-	default	IPv4	-	0
6	Bcast	-	-	IPv4	-	0
8	Discard	-	-	IPv4	-	0
9	MDiscard	-	-	IPv4	-	0
13	Mcast	-	default	IPv6	-	0
17	MDiscard	-	-	IPv6	-	0
18	Reject	-	-	IPv6	-	0
24	Discard	-	-	None	-	0
68	Local	-	192.168.66.113	IPv4	-	0
69	Resolve	fxp0.0	-	IPv4	Unspecified	0
70	Unicast	fxp0.0	192.168.71.254	IPv4	Unspecified	0
256	Local	-	10.71.71.1	IPv4	-	0
257	Local	-	127.0.0.1	IPv4	-	0
258	Mcast.local..1	default	-	IPv4	Unspecified	0
259	Bcast.local..1	-	-	IPv4	Unspecified	0
261	Discard.local..1	-	-	IPv4	Unspecified	0
262	MDiscard.local..1	-	-	IPv4	Unspecified	0
269	Mcast.local..1	default	-	IPv6	Unspecified	0
271	Discard.local..1	-	-	IPv6	Unspecified	0
...						

**show pfe next-hop fpc
(TX Matrix Plus
Router)**

user@host> show pfe next-hop fpc 0

Slot 0

ID	Type	Interface	Next Hop Addr	Protocol	Encap	MTU
31	Mcast	-	default	IPv4	-	0
32	Bcast	-	-	IPv4	-	0
34	Discard	-	-	IPv4	-	0
35	MDiscard	-	-	IPv4	-	0
36	Reject	-	-	IPv4	-	0
39	Mcast	-	default	IPv6	-	0
42	Discard	-	-	IPv6	-	0
43	MDiscard	-	-	IPv6	-	0
44	Reject	-	-	IPv6	-	0

49	Receive	-	-	MPLS	-	0
50	Discard	-	-	MPLS	-	0
111	Mcast	.local..1	default	IPv4	Unspecified	0
112	Bcast	.local..1	-	IPv4	Unspecified	0
114	Discard	.local..1	-	IPv4	Unspecified	0
115	MDiscard	.local..1	-	IPv4	Unspecified	0
116	Reject	.local..1	-	IPv4	Unspecified	0
119	Mcast	.local..1	default	IPv6	Unspecified	0
122	Discard	.local..1	-	IPv6	Unspecified	0
123	MDiscard	.local..1	-	IPv6	Unspecified	0
124	Reject	.local..1	-	IPv6	Unspecified	0
191	Mcast	.local..2	default	IPv4	Unspecified	0
192	Bcast	.local..2	-	IPv4	Unspecified	0
194	Discard	.local..2	-	IPv4	Unspecified	0
195	MDiscard	.local..2	-	IPv4	Unspecified	0
196	Reject	.local..2	-	IPv4	Unspecified	0
322	Local	-	10.1.0.5	IPv4	-	0
323	Resolve	bcm0.0	-	IPv4	Unspecified	0
326	Local	-	129.0.0.5	IPv4	-	0
327	Resolve	bcm0.0	-	IPv4	Unspecified	0
328	Local	-	fe80::201:ff:fe01:5	IPv6	-	0
329	Receive	bcm0.0	ff02::1:ff01:5	IPv6	Unspecified	0
330	Receive	bcm0.0	fe80::	IPv6	Unspecified	0
331	Resolve	bcm0.0	-	IPv6	Unspecified	0
332	Local	-	fec0::a:1:0:5	IPv6	-	0
333	Receive	bcm0.0	ff02::1:ff00:5	IPv6	Unspecified	0
334	Receive	bcm0.0	fec0::	IPv6	Unspecified	0
335	Resolve	bcm0.0	-	IPv6	Unspecified	0
348	Local	-	192.168.178.4	IPv4	-	0
349	Resolve	em0.0	-	IPv4	Unspecified	0
350	Unicast	em0.0	192.168.178.126	IPv4	Unspecified	0
357	Local	-	fe80::201:1ff:fe01:5	IPv6	-	0
512	Local	-	10.255.178.11	IPv4	-	0
513	Local	-	127.0.0.1	IPv4	-	0
515	Local	-	abcd::10:255:178:11	IPv6	-	0
516	Local	-	fe80::200:ff:fe00:0	IPv6	-	0
517	Local	-	127.0.0.1	IPv4	-	0
518	Mcast	.local..3	default	IPv4	Unspecified	0
519	Bcast	.local..3	-	IPv4	Unspecified	0
521	Discard	.local..3	-	IPv4	Unspecified	0
522	MDiscard	.local..3	-	IPv4	Unspecified	0
523	Reject	.local..3	-	IPv4	Unspecified	0
531	Mcast	.local..3	default	IPv6	Unspecified	0
533	Discard	.local..3	-	IPv6	Unspecified	0
534	MDiscard	.local..3	-	IPv6	Unspecified	0
535	Reject	.local..3	-	IPv6	Unspecified	0
539	Mgroup	-	-	IPv4	-	0
540	Bcast	ge-15/0/3.0	-	IPv4	Ethernet	0
541	Receive	ge-15/0/3.0	14.2.1.0	IPv4	Ethernet	0
542	Local	-	14.2.1.1	IPv4	-	0
543	Resolve	ge-15/0/3.0	-	IPv4	Ethernet	0
544	Bcast	ge-31/0/4.0	-	IPv4	Ethernet	0
545	Receive	ge-31/0/4.0	14.1.1.0	IPv4	Ethernet	0
546	Local	-	14.1.1.1	IPv4	-	0
547	Resolve	ge-31/0/4.0	-	IPv4	Ethernet	0
548	Unicast	ge-31/0/4.0	14.1.1.2	IPv4	Ethernet	0
549	Unicast	ge-15/0/3.0	14.2.1.2	IPv4	Ethernet	0

550	Bcast	ae1.0	-	IPv4	Ethernet	0
551	Receive	ae1.0	11.1.1.0	IPv4	Ethernet	0
552	Local	-	11.1.1.1	IPv4	-	0
553	Resolve	ae1.0	-	IPv4	Ethernet	0
554	Aggreg.	ae1.0	-	IPv4	Ethernet	0
555	Unicast	ge-23/0/8.0	11.1.1.2	IPv4	Ethernet	0
556	Unicast	ge-7/0/9.0	11.1.1.2	IPv4	Ethernet	0
557	Aggreg.	ae1.0	-	MPLS	Ethernet	0
558	Unicast	ge-23/0/8.0	-	MPLS	Ethernet	0
559	Unicast	ge-7/0/9.0	-	MPLS	Ethernet	0
560	Aggreg.	ae1.0	-	MPLS	Ethernet	0
561	Unicast	ge-23/0/8.0	-	MPLS	Ethernet	0
562	Unicast	ge-7/0/9.0	-	MPLS	Ethernet	0

show pfe route

Syntax	<pre>show pfe route <<inet6 ip iso> <prefix prefix> <table <table-name> <index index> <prefix prefix>>> <mpls> <summary></pre>
Syntax (EX Series Switch and QFX Series)	<pre>show pfe route <<inet6 ip> <prefix prefix> <table <table-name> <index index> <prefix prefix>>> <mpls> <summary></pre>
Syntax (TX Matrix and TX Matrix Plus Router)	<pre>show pfe route <fpc slot> <<inet6 ip iso> <prefix prefix> <table <table-name> <index index> <prefix prefix>>> <lcc number> <mpls> <summary></pre>

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 Command introduced in Junos OS Release 11.1 for the QFX Series.

Description Display the routes in the Packet Forwarding Engine forwarding table. The Packet Forwarding Engine forwards packets between input and output interfaces.



NOTE: The Routing Engine maintains a master copy of the forwarding table. It copies the forwarding table to the Packet Forwarding Engine, which is the part of the router or switch responsible for forwarding packets. To display the routes in the Routing Engine forwarding table, use the `show route forwarding table` command. For more information, see the [Junos OS Routing Protocols and Policies Command Reference](#).

Options none—Display all Packet Forwarding Engine forwarding table information.

`fpc slot`—(TX Matrix and TX Matrix Plus router only) (Optional) Show the next hops for a Flexible PIC Concentrator (FPC) slot.

On a TX Matrix router, if you specify the number of a T640 router by using the `lcc number` option (the recommended method), replace `slot` with a value from 0 through 7. Otherwise, replace `slot` with a value from 0 through 31. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the `lcc number` option (the recommended method), replace `slot` with a value from 0 through 7. Otherwise, replace `slot` with a value from 0 through 31. For example, the following commands have the same result:

```
user@host> show pfe route fpc 1 lcc 1
user@host> show pfe route fpc 9
```

inet6—(Optional) Display Packet Forwarding Engine IPv6 routes.

ip—(Optional) Display Packet Forwarding Engine IPv4 routes.

iso —(Optional) Display ISO version routing tables.

lcc *number*—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, the slot number of the T640 router (or line-card chassis) that houses the FPC. On a TX Matrix Plus router, the slot number of the T1600 router (or line-card chassis) that houses the FPC. Replace *number* with a value from 0 through 3.

mpls—(Optional) Display Packet Forwarding Engine Multiprotocol Label Switching (MPLS) information.

prefix *prefix*—(Optional) IPv4 or IPv6 prefix for which to show table entries.

summary—(Optional) Display summary of Packet Forwarding Engine information.

table <table-name> <index *index*> <prefix *prefix*>—(Optional) Display table information. Optionally, specify the table name, index, or prefix.

Required Privilege Level admin

List of Sample Output show pfe route ip on page 613
show pfe route iso on page 613
show pfe route lcc summary (TX Matrix Router) on page 614
show pfe route lcc summary (TX Matrix Plus Router) on page 615

Sample Output

show pfe route ip user@host> show pfe route ip

```
IPv4 Route Table 0, default.0, 0x0:
Destination                NH IP Addr      Type      NH ID Interface
-----
default
127.0.0.1                  127.0.0.1      Local     256
172.16/12                  192.168.71.254 Unicast   68 fxp0.0
192.168.0/18               192.168.71.254 Unicast   68 fxp0.0
192.168.40/22              192.168.71.254 Unicast   68 fxp0.0
192.168.64/18              192.168.71.254 Unicast   68 fxp0.0
192.168.64/21              192.168.71.254 Resolve   67 fxp0.0
192.168.71.249             192.168.71.249 Local     66
192.168.220.0/30           192.168.71.249 Resolve   303 fe-0/0/0.0
192.168.220.0              192.168.220.0 Receive   301 fe-0/0/0.0
224.0.0.1                  Mcast          5
255.255.255.255           Bcast          6

...
```

show pfe route iso user@host# show pfe route iso

```
CLNS Route Table 0, CLNP.0, 0x0:
Destination                Type      NH ID Interface
-----
default                    Reject    60
```

```

47.0005.80ff.f800.0000.0108.0001.0102.5508.2159/152    Local  514
49.0001.00a0.c96b.c491/72                               Local  536

```

**show pfe route lcc
summary (TX Matrix
Router)**

```
user@host> show pfe route lcc 2 summary
```

Slot 0

IPv4 Route Tables:

Index	Routes	Size(b)
Default	43	3081
1	4	281

MPLS Route Tables:

Index	Routes	Size(b)
Default	1	68

IPv6 Route Tables:

Index	Routes	Size(b)
Default	9	717
1	5	389

Slot 1

IPv4 Route Tables:

Index	Routes	Size(b)
Default	43	3081
1	4	281

MPLS Route Tables:

Index	Routes	Size(b)
Default	1	68

IPv6 Route Tables:

Index	Routes	Size(b)
Default	9	717
1	5	389

Slot 16

IPv4 Route Tables:

Index	Routes	Size(b)
Default	41	2938
1	4	281

MPLS Route Tables:

Index	Routes	Size(b)
Default	1	68

IPv6 Route Tables:

Index	Routes	Size(b)
-------	--------	---------

Default	9	717
1	5	389

Slot 17

IPv4 Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	41	2938
1	4	281

MPLS Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	1	68

IPv6 Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	9	717
1	5	389

**show pfe route lcc
summary (TX Matrix
Plus Router)**

user@host> show pfe route lcc 2 summary

Slot 0

IPv4 Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	25	2266
1	9	815
2	6	545
3	5	453
4	15	1371
5	5	453
6	13	1187

MPLS Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	1	88
4	5	452

IPv6 Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	7	697
1	13	1305
3	4	385
4	4	385
5	4	385
6	18	1833

Slot 6

IPv4 Route Tables:

Index	Routes	Size(b)
-----	-----	-----

Default	25	2266
1	9	815
2	6	545
3	5	453
4	15	1371
5	5	453
6	13	1187

MPLS Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	1	88
4	5	452

IPv6 Route Tables:

Index	Routes	Size(b)
-----	-----	-----
Default	7	697
1	13	1305
3	4	385
4	4	385
5	4	385
6	18	1833
...		

show pfe scb

Syntax	show pfe scb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40 routers only) Display Packet Forwarding Engine System Control Board (SCB) status and statistics information.
Options	This command has no options.
Required Privilege Level	admin
List of Sample Output	show pfe scb on page 617

Sample Output

```

user@host> show pfe scb
SCB status:
  Slot:           Present
  State:          Online
  Last State Change: 1999-02-05 11:02:36 UTC
  Uptime:         1d 02:31
  Failures:       0
  Pending:        0

PFE listener statistics:
  Open:           1
  Close:          0
  Sleep:          1
  Wakeup:         0
  Resync Request: 1
  Resync Done:    1
  Resync Fail:    0
  Resync Time:    0

PFE IPC statistics:
type            TX Messages  RX messages
-----
  Header         0             0
  Test           0             0
  Interface     10715          10594
  Chassis        0             0
  Boot           0             0
  Next-hop       8             0
  Jtree          0             0
  Cprod          0             0
  Route         11             0
  PFe           1592          1593
  Dfw            0             0
  Mastership     0             0
  Empty          0             0

PFE socket-buffer mbuf depth:
bucket          count
-----
  0              5298

```

1	0
2	0
3	0
4	0
5	0
6	0
7	0
...	

PFE socket-buffer bytes pending transmit:

bucket	count
-----	-----
0	5298
1	0
2	0
3	0
4	2
5	3
6	1
7	1
...	

show pfe sfm

Syntax	<code>show pfe sfm slot</code> <detail extensive>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e and M160 routers only) Display Packet Forwarding Engine Switching and Forwarding Module (SFM) status and statistics information.
Options	<p><i>slot</i>—Display statistics from the specified SFM slot. Replace <i>slot</i> with a value from 0 through 3.</p> <p>detail extensive—(Optional) Display the specified level of detail.</p>
Additional Information	This command applies only to systems with multiple SFMs.
Required Privilege Level	admin
List of Sample Output	show pfe sfm on page 619

Sample Output

```

user@host> show pfe sfm 1
SFM 1 status:
  Slot:                Offline
  State:                Init
  Last State Change:    2000-03-01 07:45:55 UTC
  Downtime:             17:47:29
  Failures:             167
  Pending:              0

PFE listener statistics:
  Open:                 167
  Close:                167
  Sleep:                2
  Wakeup:               1
  Resync Request:       2
  Resync Done:          2
  Resync Fail:          0
  Resync Time:          1

PFE IPC statistics:
type          TX Messages  RX messages
-----
  Header      0           0
  Test        0           0
  Interface   0           0
  Chassis     0           0
  Boot        0           0
  Next-hop    0           0
  Jtree       0           0
  Cprod       0           0
  Route       0           0
  Pfe         0           0

```

Dfw	0	0
Mastership	0	0
Empty	0	0

PFE socket-buffer mbuf depth:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

PFE socket-buffer bytes pending transmit:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

show pfe ssb

Syntax	show pfe ssb
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M20 routers only) Display Packet Forwarding Engine System and Switch Board (SSB) status and statistics information.
Options	This command has no options.
Required Privilege Level	admin
List of Sample Output	show pfe ssb on page 621

Sample Output

```

user@host> show pfe ssb
SSB status:
  Slot:          Present
  State:         Online
  Last State Change: 2005-03-06 03:10:28 PST
  Uptime (total):  11:23:27
  Failures:       0
  Pending:        0

Peer message type receive qualifiers:
Message Type      Receive Qualifier
-----
                TTP Slot only
                IFD All
                IFL All
                Nexthop All
                COS All
                Route All
                SW Firewall All
                HW Firewall All
                PFE Statistics All
                PIC Statistics None
                Sampling All
                Monitoring None
                ASP None
                L2TP None
                Collector None
                PIC Configuration None
                Queue Statistics None
                (null) None

PFE listener statistics:
  Open:          1
  Close:         0
  Sleep:         0
  Wakeup:        0
  Resync Request: 0
  Resync Done:   1
  Resync Fail:   0

```

Resync Time: 0

PFE IPC statistics:

type	TX Messages	RX messages
-----	-----	-----
Header	0	0
Test	0	0
Interface	737	9911
Chassis	0	0
Boot	0	0
Next-hop	48	0
Jtree	0	0
Cprod	0	0
Route	94	0
Pfe	2034	683
Dfw	8	0
Mastership	0	0
Sampling	0	0
GUCP	0	0
CoS	73	0
GCCP	0	0
GHCP	0	0
IRSD	0	0
Monitoring	0	0
RE	0	0
PIC	0	0
ASP cfg	0	0
ASP cmd	0	0
L2TP cfg	0	0
Collector	0	0
PIC state	0	0
Aggregator	0	0
Empty	0	0

PFE socket-buffer mbuf depth:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

PFE socket-buffer bytes pending transmit:

bucket	count
-----	-----
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0

show pfe statistics dma

Syntax	show pfe statistics dma
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics dma <fpc slot> <lcc number>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Packet Forwarding Engine direct memory access (DMA) statistics.
Options	<p>none—Display all Packet Forwarding Engine direct memory access statistics.</p> <p>fpc slot—(TX Matrix and TX Matrix Plus routers only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot.</p> <p>On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. For example, the following commands have the same result:</p> <pre> user@host> show pfe statistics dma fpc 1 lcc 1 user@host> show pfe statistics dma fpc 9 </pre> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display statistics for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix router. Replace number with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe statistics dma on page 624</p> <p>show pfe statistics dma lcc (Routing Matrix) on page 625</p>

Sample Output

```

show pfe statistics dma user@host> show pfe statistics dma
DMA Statistics:
      Name      Requests      Completed      Failed
-----
Packet Read    905119      905119          0
Packet Write   943761      943761          0
Physical Read      0          0          0
Physical Write     0          0          0

DMA Errors:
      Name      Write 0      Write 1      Read 0      Read 1
-----

```


Illegal Bank	0	0	0	0
Address Range	0	0	0	0
ECC Error	0	0	0	0
PCI Retries	0	0	0	0
PCI Error	0	0	0	0

DMA Requests:

Requests available: 256, Requests used: 0

show pfe statistics dma lcc (Routing Matrix)

user@host> show pfe statistics dma lcc 2

Slot 0

DMA Statistics:

Name	Requests	Completed	Failed
Packet Read	10718	10718	0
Packet Write	9935	9935	0

DMA Errors:

Name	Write 0	Write 1	Read 0	Read 1
Illegal Bank	0	0		
Address Range	0	0		
ECC Error	0	0		

DMA Requests:

Requests available: 768, Requests used: 0

DMA Statistics:

Name	Requests	Completed	Failed
Packet Read	0	0	0
Packet Write	0	0	0

DMA Errors:

Name	Write 0	Write 1	Read 0	Read 1
Illegal Bank	0	0		
Address Range	0	0		
ECC Error	0	0		

DMA Requests:

Requests available: 768, Requests used: 0

Slot 1

DMA Statistics:

Name	Requests	Completed	Failed
Packet Read	2	2	0
Packet Write	10154	10154	0

DMA Errors:

Name	Write 0	Write 1	Read 0	Read 1

Illegal Bank	0	0
Address Range	0	0
ECC Error	0	0

DMA Requests:
Requests available: 768, Requests used: 0

Slot 16

DMA Statistics:

Name	Requests	Completed	Failed
-----	-----	-----	-----
Packet Read	0	0	0
Packet Write	0	0	0

DMA Errors:

Name	Write 0	Write 1	Read 0	Read 1
-----	-----	-----	-----	-----
Illegal Bank	0	0		
Address Range	0	0		
ECC Error	0	0		

DMA Requests:
Requests available: 768, Requests used: 0

DMA Statistics:

Name	Requests	Completed	Failed
-----	-----	-----	-----
Packet Read	0	0	0
Packet Write	0	0	0

DMA Errors:

Name	Write 0	Write 1	Read 0	Read 1
-----	-----	-----	-----	-----
Illegal Bank	0	0		
Address Range	0	0		
ECC Error	0	0		

DMA Requests:
Requests available: 768, Requests used: 0

Slot 17

DMA Statistics:

Name	Requests	Completed	Failed
-----	-----	-----	-----
Packet Read	0	0	0
Packet Write	0	0	0

DMA Errors:

Name	Write 0	Write 1	Read 0	Read 1
-----	-----	-----	-----	-----
Illegal Bank	0	0		
Address Range	0	0		
ECC Error	0	0		

DMA Requests:
Requests available: 768, Requests used: 0

show pfe statistics error

Syntax	show pfe statistics error
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics error <fpc slot> <lcc number>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Packet Forwarding Engine error statistics.
Options	<p>none—Display all Packet Forwarding Engine error statistics.</p> <p>fpc slot—(TX Matrix and TX Matrix Plus routers only) (Optional) Display error statistics for a Flexible PIC Concentrator (FPC) slot. On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. For example, the following commands have the same result:</p> <pre>user@host> show pfe statistics error fpc 1 lcc 1 user@host> show pfe statistics error fpc 9</pre> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display error statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix. On a TX Matrix Plus router, display error statistics for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace number with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe statistics error on page 628</p> <p>show pfe statistics error lcc (Routing Matrix) on page 629</p> <p>show pfe statistics error on page 630</p>

Sample Output

```

show pfe statistics error
error
user@host> show pfe statistics error
PFE error statistics:
      C chip    A1 chip    A2 chip
-----
          0          0          0  scan fail
          0          0         N/A  A1<->C FCS error
          0         N/A          0  A2<->C FCS error
         N/A          0          0  A<->B FCS error
B chip slots:
          0          1          2          3
-----
          0          0          0          0  scan fail
          0          0          0          0  A1->B FCS error

```

0	0	0	0	A2->B FCS error
0	0	0	0	correctable ECC error
0	0	0	0	uncorrectable ECC error
0	0	0	0	multiple ECC errors
0	0	0	0	B->HS link error
0	0	0	0	A1->Bm error
0	0	0	0	A2->Bo error
0	0	0	0	write buffer overflow
0	0	0	0	Bo FIFO sync error
0	0	0	0	Bo FIFO size error
0	0	0	0	Bo stream stuck error
0	0	0	0	Bo SRAM parity error
4	5	6	7	

0	0	0	0	scan fail
0	0	0	0	A1->B FCS error
0	0	0	0	A2->B FCS error
0	0	0	0	correctable ECC error
0	0	0	0	uncorrectable ECC error
0	0	0	0	multiple ECC errors
0	0	0	0	B->HS link error
0	0	0	0	A1->Bm error
0	0	0	0	A2->Bo error
0	0	0	0	write buffer overflow
0	0	0	0	Bo FIFO sync error
0	0	0	0	Bo FIFO size error
0	0	0	0	Bo stream stuck error
0	0	0	0	Bo SRAM parity error

show pfe statistics user@host> **show pfe statistics error lcc 2**
error lcc
(Routing Matrix) Slot 0

LCHIP Error statistics:

LCHIP	0	1	2	3

Lin PIF:	0	0	0	0
Lin SRCTL:	0	0	0	0
Lout NLIF:	0	0	0	0
Lout DESRD:	0	0	0	0
Lout HDRF:	0	0	0	0

HSL Map for PFE complex 0 (Top):

Index	HST Name	----	Index	HSR Name	Errors
=====	=====		=====	=====	=====
***** No errors on this PFE *****					

HSL Map for PFE complex 1 (Bottom):

Index	HST Name	----	Index	HSR Name	Errors
=====	=====		=====	=====	=====
***** No errors on this PFE *****					

Slot 1

LCHIP Error statistics:

LCHIP	0	1	2	3

Lin PIF:	0	0	0	0
Lin SRCTL:	0	0	0	0
Lout NLIF:	0	0	0	0
Lout DESRD:	0	0	0	0
Lout HDRF:	0	0	0	0

HSL Map for PFE complex 1 (Bottom):

Index	HST Name	---->	Index	HSR Name	Errors
=====	=====		=====	=====	=====

***** No errors on this PFE *****

show pfe statistics error
error

user@host> show pfe statistics error

Slot 1

ICHIP Error statistics:

ICHIP	0	1	2	3

SPI4 Sink(Rx):	0	0	0	0
SPI4 Src(Tx):	0	0	0	0
Iwi SPI Total:	0	0	0	0
Iwi PIF:	0	0	0	0
Iwo DESRD:	0	0	0	0
Iwo HDRF:	0	0	0	0
Ipktwr Drops:	0	0	0	0
f_burst_fc Drops:	0	0	0	0
f_burst_nfc Drops:	0	0	0	0
f_rord_fc Drops:	0	0	0	0
f_rord_nfc Drops:	0	0	0	0
HSL2 Errors:				

***** No errors on this PFE *****

show pfe statistics ip

Syntax	show pfe statistics ip <icmp options>
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics ip <fpc slot> <icmp options> <lcc number>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display IPv4 Packet Forwarding Engine statistics.
Options	<p>none—Display all IPv4 Packet Forward Engine statistics.</p> <p>fpc slot—(TX Matrix and TX Matrix Plus routers only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot. On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. For example, the following commands have the same result:</p> <pre>user@host> show pfe statistics ip fpc 1 lcc 1 user@host> show pfe statistics ip fpc 9</pre> <p>icmp—(Optional) Display Packet Forwarding Engine IP ICMP statistics.</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display error statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display error statistics for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace number with a value from 0 through 3.</p> <p>options—(Optional) Display Packet Forwarding Engine IP options statistics.</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe statistics ip icmp on page 632</p> <p>show pfe statistics ip options on page 633</p>
Output Fields	Table 106 on page 632 lists the output fields for the show pfe statistics ip command. Output fields are listed in the approximate order in which they appear.

Table 106: show pfe statistics ip Output Fields

Field Name	Field Description
ICMP Statistics	<p>ICMP statistics, including the following:</p> <ul style="list-style-type: none"> • requests—Number of ICMP notifications sent to the PFE. If a throttler is configured, the number of notifications might not reflect all requests made. (See the throttled icmps field description.) • network unreachable—When route lookups fail, ICMP packets are sent to the source. These packets are ICMP TypeDestination Unreachable (3) and ICMP Code=Network Unreachable (0). • ttl expired—Number of notifications processed as a result of time-to-live (TTL) expiration packets. • ttl captured—Number of TTL expired packets sent by PFE interfaces to the Routing Engine. • redirects—Number of ICMP errors sent with Type=Redirect (5). • mtu exceeded—Number of ICMP errors sent with Type=Source Quench (4). • icmp/option handoffs—Number of packets that the PFE hardware requests the PFE software to process.
ICMP errors	<p>ICMP errors, including the following:</p> <ul style="list-style-type: none"> • unknown unreachable—Unknown code (greater than 16) found for an unknown unreachable type ICMP error. • unsupported ICMP type—Any ICMP type other than UNREACH, REDIRECT, TIME_EXCEED, and PARAM_PROB. • unprocessed redirects—When trying to find the neighbor to send redirects to, the PFE could not find the next-hop information. • invalid ICMP type—Any ICMP type other than UNREACH, REDIRECT, TIME_EXCEED, and PARAM_PROB. • invalid protocol—An incorrect protocol was detected by the ICMP processor. • bad input interface ifl—The PFE software cannot map the interface index supplied by the chips to a proper data structure in the microkernel. • throttled icmps—Number of requests dropped because of rate limiting by the PFE. • runts—Number of packets for which the IP header length is less than the minimum length that is supported.
ICMP Discards	<p>ICMP discard statistics, including the following:</p> <ul style="list-style-type: none"> • multicasts—ICMP packets are not sent for link-layer multicast packets. These are counted as invalid source addresses (not a unicast address or all zeros). • bad source addresses—ICMP packets were received from an invalid source address (not a unicast address or all zeros). • bad dest addresses—ICMP packets were sent to an invalid destination address (not a unicast address or all zeros). • IP fragments—ICMP responses are sent only for the first fragments. The rest do not receive a response. This is the count for ICMP requests that receive no response. • ICMP errors—Number of ICMP error packets.

Sample Output

```

show pfe statistics ip icmp  user@host> show pfe statistics ip icmp
                             ICMP Statistics:
                             0 requests
                             0 network unreachable
                             0 ttl expired
                             0 ttl captured

```



```

0 redirects
0 mtu exceeded
0 icmp/option handoffs
ICMP Errors:
0 unknown unreachable
0 unsupported ICMP type
0 unprocessed redirects
0 invalid ICMP type
0 invalid protocol
0 bad input interface
0 throttled icmps
0 runts
ICMP Discards:
0 multicasts
0 bad source addresses
0 bad dest addresses
0 IP fragments
0 ICMP errors

```

```

show pfe statistics ip options user@host> show pfe statistics ip options
options IP Option Values:
LSRR/SSRR forwarding enabled
IP Option Statistics:
0 loose source routes
0 strict source routes
0 record routes
889382 router alerts
0 other options
IP Option Errors:
0 runts
2 bad versions
0 runt header lengths
0 giant header lengths
0 null frames
0 bad option lengths
0 duplicate options
0 bad option pointers
0 source route frames dropped
188 frames queued
1126 frames dropped

```

show pfe statistics ip6

Syntax	show pfe statistics ip6 <icmp>
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics ip6 <fpc slot> <icmp> < lcc number>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display Packet Forwarding Engine IPv6 statistics.
Options	<p>none—Display all Packet Forwarding Engine IPv6 statistics.</p> <p>fpc slot—(TX Matrix and TX Matrix Plus router only) (Optional) Display statistics for a Flexible PIC Concentrator slot. On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. Likewise, on a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. For example, the following commands have the same result:</p> <pre> user@host> show pfe statistics ip6 fpc 1 lcc 1 user@host> show pfe statistics ip6 fpc 9 </pre> <p>icmp—(Optional) Display Packet Forwarding Engine IP ICMP statistics.</p> <p>lcc number—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display statistics for a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display statistics for a specific T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace number with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe statistics ip6 icmp on page 635</p> <p>show pfe statistics ip6 lcc on page 636</p>
Output Fields	Table 107 on page 635 lists the output fields for the show pfe statistics ip6 command. Output fields are listed in the approximate order in which they appear.

Table 107: show pfe statistics ip6 Output Fields

Field Name	Field Description
ICMP6 Statistics	<p>ICMP6 statistics, including the following:</p> <ul style="list-style-type: none"> requests—Number of ICMP notifications sent to the PFE. If a throttler is configured, the number of notifications might not reflect all requests made. (See the throttled icmps field description.) network unreachable—When route lookups fail, ICMP packets are sent to the source. These packets are ICMP Type= Destination Unreachable (3) and ICMP Code= Network Unreachable (0). ttl expired—Number of notifications processed as a result of time-to-live (TTL) expiration packets. ttl captured—Number of TTL expired packets sent by PFE interfaces to the Routing Engine. redirects—Number of ICMP errors sent with Type=Redirect (5). mtu exceeded—Number of ICMP errors sent with Type=Source Quench (4). icmp/option handoffs—Number of packets that the PFE hardware requests the PFE software to process.
ICMP6 errors	<p>ICMP6 errors, including the following:</p> <ul style="list-style-type: none"> unknown unreachable—Unknown code (greater than 16) found for an unknown unreachable type ICMP error. unsupported ICMP type—Any ICMP type other than UNREACH, REDIRECT, TIME_EXCEED, and PARAM_PROB. unprocessed redirects—When trying to find the neighbor to send redirects to, the PFE could not find the next-hop information. invalid ICMP type—Any ICMP type other than UNREACH, REDIRECT, TIME_EXCEED, and PARAM_PROB. invalid protocol—An incorrect protocol was detected by the ICMP processor. bad input interface ifl—The PFE software cannot map the interface index supplied by the chips to a proper data structure in the microkernel. throttled icmps—Number of requests dropped because of rate limiting by the PFE. runs—Number of packets for which the IP header length is less than the minimum length that is supported.
ICMP6 Discards	<p>ICMP6 discard statistics, including the following:</p> <ul style="list-style-type: none"> multicasts—ICMP packets are not sent for link-layer multicast packets. These are counted as invalid source addresses (not a unicast address or all zeros). bad source addresses—ICMP packets were received from an invalid source address (not a unicast address or all zeros). bad dest addresses—ICMP packets were sent to an invalid destination address (not a unicast address or all zeros). IP fragments—ICMP responses are sent only for the first fragments. The rest do not receive a response. This is the count for ICMP requests that receive no response. ICMP errors—Number of ICMP error packets.

Sample Output

```

show pfe statistics ip6 icmp  user@host> show pfe statistics ip6 icmp
                                ICMP6 Statistics:
                                0 requests
                                0 network unreachable
                                0 ttl expired
                                0 ttl captured

```

```
0 redirects
0 mtu exceeded
0 icmp/option handoffs
ICMP6 Errors:
0 unknown unreachable
0 unsupported ICMP type
0 unprocessed redirects
0 invalid ICMP type
0 invalid protocol
0 bad input interface
0 throttled icmps
0 runts
ICMP6 Discards:
0 multicasts
0 bad source addresses
0 bad dest addresses
0 IP fragments
0 ICMP errors
```

```
show pfe statistics ip6 user@host> show pfe statistics ip6 lcc 0 fpc 0
lcc sfc0-re0:
```

```
-----
ICMP Statistics:
0 requests
0 network unreachable
0 ttl expired
0 ttl captured
0 redirects
0 mtu exceeded
0 icmp/option handoffs

ICMP Errors:
0 unknown unreachable
0 unsupported ICMP type
0 unprocessed redirects
0 invalid ICMP type
0 invalid protocol
0 bad input interface
0 throttled icmps
0 runts

ICMP Discards:
0 multicasts
0 bad source addresses
0 bad dest addresses
0 IP fragments
0 ICMP errors
```

show pfe statistics notification

Syntax	show pfe statistics notification
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics notification <fpc slot> <lcc number>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Packet Forwarding Engine notification statistics.
Options	<p>none—(TX Matrix and TX Matrix Plus routers only) On a TX Matrix router, display statistics about the Packet Forwarding Engine notification on the TX Matrix router and its attached T640 routers. On a TX Matrix Plus router, display statistics about the Packet Forwarding Engine notification on the TX Matrix Plus router and its attached T1600 routers.</p> <p>fpc slot—(TX Matrix and TX Matrix Plus routers only) (Optional) Display notification for a Flexible PIC Concentrator (FPC) slot. On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace <i>slot</i> with a value from 0 through 7. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace <i>slot</i> with a value from 0 through 7. Otherwise, replace <i>slot</i> with a value from 0 through 31. For example, the following commands have the same result:</p> <pre> user@host> show pfe statistics notification fpc 1 lcc 1 user@host> show pfe statistics notification fpc 9 </pre> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display notification for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display notification for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace number with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	show pfe statistics notification on page 637 show pfe statistics notification lcc (Routing Matrix) on page 638

Sample Output

```

show pfe statistics notification
notification
user@host> show pfe statistics notification
PFE Notification statistics:
  2453 parsed
    0 aged
    0 corrupt
    0 illegal
    0 sample
    0 giants
    0 transit options/ttl-exceeded

```

```

PFE Notification Type statistics:
  Parsed      Input      Failed      Ignored
  Illegal      0          0          0          0
  Unclass     1733        1733        0          0
  Option       0          0          0          0
  Next-Hop    720         720         0          0
  Discard      0          0          0          0
  Sample       0          0          0          0
  Redirect     0          0          0          0
  DontFrag     0          0          0          0
  CfDF         0          0          0          0

```

```

show pfe statistics notification lcc 0
notification lcc
(Routing Matrix) Slot 0

```

```

PFE Notification statistics:
  1252 parsed
  0 aged
  0 corrupt
  0 illegal
  0 sample
  0 giants
  0 transit options/ttl-exceeded
  0 transit options/ttl-exceeded errors
  0 svc options sent to ASP
  0 svc options sent to RE
  0 post svc options sent out
  121 options or ttl expired (not RE-destined)

```

```

PFE Notification Type statistics:
  Parsed      Input      Failed      Ignored
  Illegal      0          0          0          0
  Unclass     695        695        0          0
  Option      30         30         0          0
  Next-Hop    527        527        0          0
  Discard      0          0          0          0
  Sample       0          0          0          0
  Redirect     0          0          0          0
  DontFrag     0          0          0          0
  CfDF         0          0          0          0
  Poison       0          0          0          0

```

Slot 1

```

PFE Notification statistics:
  0 parsed
  0 aged
  ...

```

show pfe statistics pio

Syntax	show pfe statistics pio
Syntax (TX Matrix Router)	show pfe statistics pio <fpc slot> < lcc number>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Packet Forwarding Engine polled I/O (PIO) statistics.
Options	<p>none—(TX Matrix routers only) Display statistics about the Packet Forwarding Engine polled I/O on the TX Matrix routers and its attached T640 routers.</p> <p>fpc slot—(TX Matrix routers only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot. If you specify the number of a T640 router by using the lcc number option (the recommended method), replace slot with a value from 0 through 7. Otherwise, replace slot with a value from 0 through 31. For example, the following commands have the same result:</p> <pre> user@host> show pfe statistics pio fpc 1 lcc 1 user@host> show pfe statistics pio fpc 9 </pre> <p>lcc number—(TX Matrix routers only) (Optional) Display statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. Replace number with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe statistics pio on page 639</p> <p>show pfe statistics pio lcc (Routing Matrix) on page 639</p>

Sample Output

show pfe statistics pio	<pre> user@host> show pfe statistics pio PIO Statistics: 8542732 PIO read requests 8542732 PIO read replies 586193 PIO write requests 586191 PIO write replies 0 PIO error replies 0 PIO bad requests 0 PIO bad replies 0 PIO bad address 0 PIO extra replies 0 PIO timeouts </pre>
show pfe statistics pio lcc (Routing Matrix)	<pre> user@host> show pfe statistics pio lcc 0 Slot 0 PIO Statistics (chip 0): 425582 PIO reads 120303 PIO writes PIO Statistics (chip 1): </pre>

```
406993 PIO reads
    117769 PIO writes
...
```


show pfe statistics traffic

Syntax	show pfe statistics traffic <fpc slot>
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics traffic <fpc slot> < lcc number>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Packet Forwarding Engine traffic statistics.
Options	<p>none—Display statistics about PFE traffic. On the TX Matrix router, display statistics about PFE traffic for all its attached T640 routers. On the TX Matrix Plus router, display statistics about PFE traffic for all its attached T1600 routers</p> <p>fpc slot—(T Series and M320 router only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot. On a TX Matrix router, if you specify the number of a T640 router by using the lcc number option (the recommended method), replace <i>slot</i> with a value from 0 through 7. Otherwise, replace <i>slot</i> with a value from 0 through 31. On a TX Matrix Plus router, if you specify the number of a T1600 router by using the lcc number option (the recommended method), replace <i>slot</i> with a value from 0 through 7. Otherwise, replace <i>slot</i> with a value from 0 through 31. For example, the following commands have the same result:</p> <pre>user@host> show pfe statistics traffic fpc 1 lcc 1 user@host> show pfe statistics traffic fpc 9</pre> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display statistics for a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display statistics for a specific T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p>
Required Privilege Level	admin
List of Sample Output	show pfe statistics traffic on page 643
Output Fields	Table 108 on page 641 lists the output fields for the show pfe statistics traffic command. Output fields are listed in the approximate order in which they appear.

Table 108: show pfe statistics traffic Output Fields

Field Name	Field Description
Packet Forwarding Engine Traffic statistics	<p>Information about Packet Forwarding Engine traffic:</p> <ul style="list-style-type: none"> Input Packets—Number and rate of input packets. Output Packets—Number and rate of output packets.

Table 108: show pfe statistics traffic Output Fields (*continued*)

Field Name	Field Description
Packet Forwarding Engine Local Traffic statistics	<p>Information about Packet Forwarding Engine local traffic:</p> <ul style="list-style-type: none"> • Local packets input—Number of local input packets. • Local packets output—Number of local output packets. • Software input high drops—Number of software input high-priority drops. • Software input medium drops—Number of software input medium-priority drops. • Software input low drops—Number of software input low-priority drops. • Software output drops—Number of software output drops. • Hardware input drops—Number of hardware input drops.
Packet Forwarding Engine Local Protocol statistics	<p>Information about the Packet Forwarding Engine Local Protocol:</p> <ul style="list-style-type: none"> • HDLC keepalives—Number of HDLC keepalive packets. • ATM OAM—Number of Asynchronous Transfer Mode (ATM) Operation, Administration, and Maintenance (OAM) packets. • Frame Relay LMI—Number of Frame Relay Local Management Interface (LMI) packets. • PPP LCP/NCP—Number of Point-to-Point Protocol (PPP) Link Control Protocol (LCP) or Network Control Protocol (NCP) packets. • OSPF hello—Number of Open Shortest Path First (OSPF) hello packets. • OSPF3 hello—Number of Open Shortest Path First version 3 (OSPFv3) hello packets. • RSVP hello—Number of Reservation Setup Protocol (RSVP) hello packets. • LDP hello—Number of Label Distribution Protocol (LDP) hello packets. • BFD—Number of Bidirectional Forwarding Detection Protocol (BFD) hello packets. • IS-IS IIH—Number of Intermediate System-to-Intermediate System Hello (IIH) packets. • LACP—Number of Link Aggregation Control Protocol (LACP) packets. • ARP—Number of Address Resolution Protocol (ARP) packets. • ETHER OAM—Number of Ethernet Operations, Administration, and Management (OAM) packets. • Unknown—Number of unknown packets not matching any of the packet types listed above.
Packet Forwarding Engine Hardware Discard statistics	<p>Information about Packet Forwarding Engine hardware discards:</p> <ul style="list-style-type: none"> • Timeout—Number of packets discarded because of timeouts. • Truncated key—Number of packets discarded because of truncated keys. • Bits to test—Number of bits to test. • Data error—Number of packets discarded because of data errors. • Stack underflow—Number of packets discarded because of stack underflows. • Stack overflow—Number of packets discarded because of stack overflows. • Normal discard—Number of packets discarded because of discard routes. • Extended discard—Number of packets discarded because of illegal next hops. • Invalid interface—Number of packets discarded because of invalid incoming interfaces. • Info cell drops—Number of information cell drops. • Fabric drops—Number of fabric drops.

Sample Output

```

show pfe statistics user@host> show pfe statistics traffic
traffic
Packet Forwarding Engine traffic statistics:
  Input  packets:          102682          5 pps
  Output packets:           58033          4 pps
Packet Forwarding Engine local traffic statistics:
  Local packets input      :          44628
  Local packets output     :          46146
  Software input control plane drops :           0
  Software input high drops :           0
  Software input medium drops :           0
  Software input low drops  :           0
  Software output drops     :           0
  Hardware input drops      :           0
Packet Forwarding Engine local protocol statistics:
  HDLC keepalives          :           0
  ATM OAM                   :           0
  Frame Relay LMI          :           0
  PPP LCP/NCP              :          5597
  OSPF hello               :          3195
  OSPF3 hello              :           0
  RSVP hello               :           0
  LDP hello                :          7478
  BFD                      :           0
  IS-IS IIH                :           0
  LACP                     :           0
  ARP                      :           0
  ETHER OAM                 :           0
  Unknown                  :           8
Packet Forwarding Engine hardware discard statistics:
  Timeout                  :           0
  Truncated key            :           0
  Bits to test             :           0
  Data error               :           0
  Stack underflow          :           0
  Stack overflow           :           0
  Normal discard           :           0
  Extended discard         :           0
  Invalid interface        :           0
  Info cell drops          :           39
  Fabric drops             :           0
Packet Forwarding Engine Input IPv4 Header Checksum Error and Output MTU Error
statistics:
  Input Checksum           :           0
  Output MTU               :           0

```

show pfe statistics traffic protocol bfd

Syntax	show pfe statistics traffic protocol bfd <fpc slot>
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics traffic protocol bfd <fpc slot> <lcc number>
Release Information	Command introduced in Junos OS Release 8.4.
Description	Display Packet Forwarding Engine traffic protocol statistics for Bidirectional Forwarding Detection hello packets.
Options	<p>None—Display all Packet Forwarding Engine traffic protocol BFD statistics.</p> <p>fpc slot—(M320 and MX960 routers, and T Series routers only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot.</p> <p>user@host> show pfe statistics traffic protocol bfd fpc 1</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display statistics for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>user@host> show pfe statistics traffic protocol bfd fpc 1 lcc 1</p>
Required Privilege Level	admin
List of Sample Output	show pfe statistics traffic protocol bfd on page 645
Output Fields	Table 109 on page 644 lists the output fields for the show pfe statistics traffic protocol bfd command. Output fields are listed in the approximate order in which they appear.

Table 109: show pfe statistics traffic protocol bfd Output Fields

Field Name	Field Description
Packets with invalid interface	Number of packets discarded because of invalid interface.
Packets with invalid address family	Number of packets discarded because of invalid address family.
Packets with bad IP checksum	Number of packets discarded because of bad IP checksum.
Packets with bad IP options	Number of packets discarded because of bad IP options.

Table 109: show pfe statistics traffic protocol bfd Output Fields (*continued*)

Field Name	Field Description
Packets with bad IP length	Number of packets discarded because of bad IP length.
Packets with bad udp checksum	Number of packets discarded because of bad UDP checksum.
Packets with bad udp length	Number of packets discarded because of bad UDP length.
Packets with bad udp ports	Number of packets discarded because of bad UDP ports.
Packets with no logical interface	(T640 and M20 routers only) Number of packets discarded because of nonavailability of logical interface.
Packets with prefix length mismatch	(T640 and M20 routers only) Number of packets discarded because of prefix length mismatch.
Packets received	Number of packets received.
Packets absorbed	Number of packets absorbed.
Packets failed to transmit	Number of packets discarded because of transmission failure.
Packets receive failures	Number of packet receive failures.
Packets allocation failures	Number of packet allocation failures.

Sample Output

```
show pfe statistics traffic protocol bfd
user@host> show pfe statistics traffic protocol bfd
```

```
BFD protocol statistics:
Packets with invalid interface      : 0
Packets with invalid address family : 0
Packets with bad IP checksum        : 0
Packets with bad IP options         : 0
Packets with bad IP length          : 0
Packets with bad udp checksum       : 0
Packets with bad udp length         : 0
Packets with bad udp ports          : 0
Packets with no logical interface    : 0
Packets with prefix length mismatch : 0
Packets received                    : 0
Packets absorbed                    : 0
Packets failed to transmit          : 0
Packets receive failures             : 0
Packets allocation failures          : 0
```


show pfe statistics traffic protocol cfm

Syntax	show pfe statistics traffic protocol cfm <fpc slot >
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics traffic protocol cfm <fpc slot > <lcc number>
Release Information	Command introduced in Junos OS Release 8.5.
Description	Display Packet Forwarding Engine traffic protocol statistics for connectivity fault management (CFM).
Options	<p>None—Display all PFE traffic protocol CFM statistics.</p> <p>fpc slot—(M320 and MX960 routers, and T Series routers only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot.</p> <p>user@host> show pfe statistics traffic protocol cfm fpc 1</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix routers. On a TX Matrix Plus router, display statistics for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>user@host> show pfe statistics traffic protocol cfm fpc 1 lcc 1</p>
Required Privilege Level	admin
List of Sample Output	show pfe statistics traffic protocol cfm on page 648
Output Fields	Table 110 on page 647 lists the output fields for the show pfe statistics traffic protocol cfm command. Output fields are listed in the approximate order in which they appear.

Table 110: show pfe statistics traffic protocol cfm Output Fields

Field Name	Field Description
Packets transmitted	Number of packets transmitted.
Packets failed to transmit	Number of packets that were not transmitted.
Packets received	Number of packets received.
Packets sent to RE	Number of packets sent to the Routing Engine.
Packets absorbed	Number of packets absorbed.

Table 110: show pfe statistics traffic protocol cfm Output Fields (*continued*)

Field Name	Field Description
Packets with invalid length	Number of packets with invalid length.
Packets with sequence number	Number of packets with a sequence number.
Packets dropped (Invalid)	Number of invalid packets dropped.

Sample Output

**show pfe statistics
traffic protocol cfm**

```
user@host> show pfe statistics traffic protocol cfm
```

```
CFM protocol statistics:
Packets transmitted      : 0
Packets failed to transmit : 0
Packets received         : 0
Packets send to RE       : 0
Packets absorbed         : 0
Packets with invalid length : 0
Packets with sequence number : 0
Packets dropped (Invalid) : 0
```


show pfe statistics traffic protocol lfm

Syntax	show pfe statistics traffic protocol lfm <fpc slot >
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe statistics traffic protocol lfm <fpc slot> <lcc number>
Release Information	Command introduced in Junos OS Release 8.5
Description	Display Packet Forwarding Engine traffic protocol link fault management (LFM) statistics.
Options	<p>none—Display all PFE traffic protocol LFM statistics.</p> <p>fpc slot—(M320 and MX960 routers, and T Series routers only) (Optional) Display statistics for a Flexible PIC Concentrator (FPC) slot.</p> <p>user@host> show pfe statistics traffic protocol lfm fpc 1</p> <p>lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display statistics for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display statistics for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>user@host> show pfe statistics traffic protocol lfm fpc 1 lcc 1</p>
Required Privilege Level	admin
List of Sample Output	show pfe statistics traffic protocol lfm on page 650
Output Fields	Table 111 on page 649 lists the output fields for the show pfe statistics traffic protocol lfm command. Output fields are listed in the approximate order in which they appear.

Table 111: show pfe statistics traffic protocol lfm Output Fields

Field Name	Field Description
Packets transmitted	Number of packets transmitted.
Packets failed to transmit	Number of packets that were not transmitted.
Packets received	Number of packets received.
Packets send to RE	Number of packets sent to the Routing Engine.
Packets absorbed	Number of packets absorbed.
Packets dropped (Invalid)	Number of invalid packets dropped.

Sample Output

```
show pfe statistics user@host> show pfe statistics traffic protocol lfm
traffic protocol lfm user@host> show pfe statistics traffic protocol lfm

LFM protocol statistics:
Packets transmitted      : 0
Packets failed to transmit : 0
Packets received         : 0
Packets send to RE       : 0
Packets absorbed         : 0
Packets dropped (Invalid) : 0
```

show pfe terse

Syntax	show pfe terse
Syntax (TX Matrix and TX Matrix Plus Router)	show pfe terse <fcc <i>number</i> scc>
Syntax (MX Series Router)	show pfe terse <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display Packet Forwarding Engine status information.
Options	<p>none—Display brief information about the Packet Forwarding Engine.</p> <p>all-members—(MX Series routers only) (Optional) Display Packet Forwarding Engine status information for all members in the Virtual Chassis configuration.</p> <p>fcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix, display Packet Forwarding Engine information for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, display Packet Forwarding Engine information for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display Packet Forwarding Engine status information for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display Packet Forwarding Engine status information for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) (Optional) Display Packet Forwarding Engine information for the TX Matrix router (or switch-card chassis).</p> <p>sfc—(TX Matrix Plus routers only) (Optional) Display Packet Forwarding Engine information for the TX Matrix Plus router (or switch-fabric chassis).</p>
Required Privilege Level	admin
List of Sample Output	<p>show pfe terse (TX Matrix Router) on page 652</p> <p>show pfe terse (TX Matrix Plus Router) on page 652</p> <p>show pfe terse sfc (TX Matrix Plus Router) on page 652</p>

Sample Output

```
show pfe terse (TX Matrix Router) user@host> show pfe terse
Slot Type Slot State Flags Uptime
0 SFM Present Online 0x0bf 01:25:42
2 SFM Present Online 0x0bf 01:25:40
0 FPC Present Online 0x102 01:25:57
1 FPC Present Online 0x102 01:25:55
2 FPC Present Online 0x102 01:25:53
```

```
show pfe terse (TX Matrix Plus Router) user@host> show pfe terse
sfc0-re0:
-----
Slot Type Slot State Uptime
0 LCC Present Online 2d 05:26

lcc0-re0:
-----
Slot Type Slot State Uptime
0 GFPC Present Online 2d 05:25
1 GFPC Present Online 2d 05:25
```

```
show pfe terse sfc (TX Matrix Plus Router) user@host> show pfe terse sfc 0
sfc0-re0:
-----
Slot Type Slot State Uptime
0 LCC Present Online 2d 05:25
```

show pfe resource usage memory

Syntax show pfe resource usage memory
<extensive | brief>
<fpc <0..n>>

Release Information Command introduced in Junos OS Release 9.3.

Description (M320 and T320 routers, and T-640 only) Display Packet Forwarding Engine resource and L-chip SRAM memory usage statistics.



NOTE: On M320 routers, this command is not supported for the following FPCs:

- M320 E3-FPC Type 1
- M320 E3-FPC Type 2
- M320 E3-FPC Type 3

Options brief | extensive—(Optional) Display the specified level of output.

fpc slot—(Optional) Display L-chip-based FPC SRAM usage statistics for a Flexible PIC Concentrator (FPC) slot.

user@host> show pfe resource usage memory fpc 1

Required Privilege Level admin

List of Sample Output show pfe resource usage memory on page 654

Output Fields Table 112 on page 653 lists the output fields for the **show pfe resource usage memory** command. Output fields are listed in the approximate order in which they appear.

Table 112: show pfe resource usage memory Output Fields

Field Name	Field Description
Resource Name	Name of the resource, including: <ul style="list-style-type: none"> • FPC • Pfe
Free	Free L-chip SRAM memory.
Inuse	L-chip SRAM memory that is currently in use.
Total	Total of Free and Inuse memory.
%Use	Percentage of Total L-chip memory that is in use.

Sample Output

```

user@host> show pfe resource usage memory
show pfe resource usage memory
Resource Name      Free      Inuse      Total      %Use

Pfc 0
(* - resource 80% used)

Pfe 1  Lin  2

SRAM Pages (Page = 4096 bytes)  510      2      512      0.39

Pfe 1  Lout 2

L2rw Zones (Bytes)
Multicast List Table      16384      0      16384      0.00
L2 Descriptor Table      2080744      24      2080768      0.00
L2 Tag Table              488      24      512      4.69

Pfe 1  Lin  3

SRAM Pages (Page = 4096 bytes)  511      1      512      0.20

Pfe 1  Lout 3

L2rw Zones (Bytes)
Multicast List Table      16384      0      16384      0.00
L2 Descriptor Table      2080768      0      2080768      0.00
L2 Tag Table              504      8      512      1.56

Resource Name      Free      Inuse      Total      %Use

Pfc 1
(* - resource 80% used)

Pfe 1  Lin  2

SRAM Pages (Page = 4096 bytes)  511      1      512      0.20

Pfe 1  Lout 2

L2rw Zones (Bytes)
Multicast List Table      16384      0      16384      0.00
L2 Descriptor Table      2080768      0      2080768      0.00
L2 Tag Table              504      8      512      1.56

Pfe 1  Lin  3

SRAM Pages (Page = 4096 bytes)  511      1      512      0.20

Pfe 1  Lout 3

L2rw Zones (Bytes)
Multicast List Table      16384      0      16384      0.00
L2 Descriptor Table      2080696      72      2080768      0.00
L2 Tag Table              496      16      512      3.12

Resource Name      Free      Inuse      Total      %Use

Pfc 3
(* - resource 80% used)

```

Fpc 5 (* - resource 80% used)

user@host> show pfe resource usage memory fpc 0 extensive

Resource Name	Free	Inuse	Total	%Use
---------------	------	-------	-------	------

Fpc 0 (* - resource 80% used)

Pfe 2 Lin 3

SRAM Pages (Page = 4096 bytes)	510	3	512	0.59
Channel Table Pages		1		
Accounting Pages		1		

Pfe 2 Lout 3

L2rw Zones (Bytes)				
Multicast List Table	16384	0	16384	0.00
L2 Descriptor Table	2080748	20	2080768	0.00
L2 Tag Table	488	24	512	4.69

Pfe 2 Lin 4

SRAM Pages (Page = 4096 bytes)	511	33	512	6.45
Channel Table Pages		0		
Accounting Pages		1		

Pfe 2 Lout 4

L2rw Zones (Bytes)				
Multicast List Table	16384	0	16384	0.00
L2 Descriptor Table	2080768	0	2080768	0.00
L2 Tag Table	504	8	512	1.56

show pfe version

Syntax	show pfe version <brief detail>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display Packet Forwarding Engine version information.
Options	brief detail—Display the specified level of output.
Required Privilege Level	admin
List of Sample Output	show pfe version brief on page 656 show pfe version detail on page 656

Sample Output

show pfe version brief user@host> show pfe version brief
PFED release 11.1D0 built by builder on 2010-11-11 05:16:11 UTC

show pfe version detail user@host> show pfe version detail
PFED release 11.1D0 built by builder on 2010-11-11 05:16:11 UTC

junos-core01.juniper.net:/volume/build/junos/rpd_feb11/11.1/development/20101111.0/dbj-i386/junos/usr/sbin/pfed

Remote System Access Operational Mode Commands

Table 113 on page 657 summarizes the command-line interface (CLI) commands you can use to access remote systems. Commands are listed in alphabetical order.

Table 113: Remote System Access Operational Mode Commands

Task	Command
Open an SSH connection to a remote system.	ssh
Open a telnet session to a remote system.	telnet



NOTE: To configure SSH and Telnet parameters, see the *Junos OS System Basics Configuration Guide*.

ssh

Syntax	<code>ssh host</code> <code><bypass-routing></code> <code><inet inet6></code> <code><interface <i>interface-name</i>></code> <code><logical-system <i>logical-system-name</i>></code> <code><routing-instance <i>routing-instance-name</i>></code> <code><source <i>address</i>></code> <code><v1 v2></code>
Syntax (EX Series and QFX Series)	<code>ssh host</code> <code><bypass-routing></code> <code><inet inet6></code> <code><interface <i>interface-name</i>></code> <code><routing-instance <i>routing-instance-name</i>></code> <code><source <i>address</i>></code> <code><v1 v2></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	<p>Use the SSH program to open a connection between a local router or switch and a remote system and execute commands on the remote system. You can issue the ssh command from the Junos OS CLI to log in to a remote system or from a remote system to log in to the local router or switch. When executing this command, you include one or more CLI commands by enclosing them in quotation marks and separating the commands with semicolons:</p> <pre>ssh address '<i>cli-command1</i> ; <i>cli-command2</i> '</pre>
Options	<p><i>host</i>—Name or address of the remote system.</p> <p><i>bypass-routing</i>—(Optional) Bypass the normal routing tables and send ping requests directly to a system on an attached network. If the system is not on a directly attached network, an error is returned. Use this option to ping a local system through an interface that has no route through it.</p> <p><i>inet inet6</i>—(Optional) Create an IPv4 or IPv6 connection, respectively.</p> <p><i>interface interface-name</i>—(Optional) Interface name for the SSH session. (This option does not work when default-address-selection is configured at the [edit system] hierarchy level, because this configuration uses the loopback interface as the source address for all locally generated IP packets.)</p> <p><i>logical-system logical-system-name</i>—(Optional) Name of a particular logical system for the SSH attempt.</p> <p><i>routing-instance routing-instance-name</i>—(Optional) Name of the routing instance for the SSH attempt.</p>

source address—(Optional) Source address of the SSH connection.

v1 | v2—(Optional) Use SSH version 1 or 2, respectively, when connecting to a remote host.

Additional Information To configure an SSH (version 1) key for your user account, include the **authentication ssh-rsa** statement at the **[edit system login user *user-name*]** hierarchy level. To configure an SSH (version 2) key for your user account, include the **authentication dsa-rsa** statement at the **[edit system login user *user-name*]** hierarchy level. For details, see the .

You can limit the number of times a user can attempt to enter a password while logging in through SSH. To specify the number of times a user can attempt to enter a password to log in through SSH, include the **retry-options** statement at the **[edit system login]** hierarchy level. For details, see the .

Required Privilege Level network

Related Documentation

- Configuring SSH Host Keys for Secure Copying of Data

List of Sample Output **ssh** on page 659

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
ssh user@switch> ssh cree
Host key not found from the list of known hosts.
Are you sure you want to continue connecting (yes/no)? yes

Host ?cree' added to the list of known hosts.
boojun@cree's password:
Last login: Sun Jun 21 10:43:42 1998 from junos-router
% ...
```

telnet

Syntax	<pre>telnet <i>host</i> <8bit> <bypass-routing> <inet inet6> <interface <i>interface-name</i>> <logical-system <i>logical-system-name</i>> <no-resolve> <port <i>port-number</i>> <routing-instance <i>routing-instance-name</i>> <source <i>source-address</i>></pre>
Syntax (EX Series Switch)	<pre>telnet <i>host</i> <8bit> <bypass-routing> <inet inet6> <interface <i>interface-name</i>> <no-resolve> <port <i>port-number</i>> <routing-instance <i>routing-instance-name</i>> <source <i>source-address</i>></pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p>
Description	<p>Open a telnet session to a remote system. Type Ctrl+] to escape from the telnet session to the telnet command level, and then type quit to exit from telnet.</p>
Options	<p><i>host</i>—Name or address of the remote system.</p> <p>8bit—(Optional) Use an 8-bit data path.</p> <p>bypass-routing—(Optional) Bypass the normal routing tables and send ping requests directly to a system on an attached network. If the system is not on a directly attached network, an error is returned. Use this option to ping a local system through an interface that has no route through it.</p> <p>inet inet6—(Optional) Open an IPv4 or IPv6 session, respectively.</p> <p>interface <i>interface-name</i>—(Optional) Interface name for the telnet session. (This option does not work when default-address-selection is configured at the [edit system] hierarchy level, because this configuration uses the loopback interface as the source address for all locally generated IP packets.)</p> <p>logical-system <i>logical-system-name</i>—(Optional) Name of a particular logical system for the telnet attempt.</p> <p>no-resolve—(Optional) Do not attempt to determine the hostname that corresponds to the IP address.</p> <p>port <i>port-number</i>—(Optional) Port number or service name on the remote system.</p>

routing-instance *routing-instance-name*—(Optional) Name of the routing instance for the telnet attempt.

source *source-address*—(Optional) Source address of the telnet connection.

Additional Information You can limit the number of times a user can attempt to enter a password while logging in through telnet. To specify the number of times a user can attempt to enter a password to log in through telnet, include the **retry-options** statement at the [edit system login] hierarchy level. For details, see the [Junos OS System Basics Configuration Guide](#).

Required Privilege Level network

List of Sample Output telnet on page 661

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
telnet user@host> telnet 192.154.1.254
Trying 192.154.169.254...
Connected to level5.company.net.
Escape character is '^]'.
ttypa
login:
```


Simple Network Management Protocol Operational Mode Commands

Table 114 on page 663 summarizes the command-line interface (CLI) commands that allow you to monitor the Simple Network Management Protocol (SNMP). Commands are listed in alphabetical order.

Table 114: SNMP Operational Commands

Task	Command
Clear SNMP statistics.	clear snmp statistics
Spoof (mimic) the behavior of an SNMP trap.	request snmp spoof-trap
Display information about health monitor alarms.	show snmp health-monitor
Display statistics about SNMP informs.	show snmp inform-statistics
Display local Management Information Base (MIB) object values through the command-line interface (CLI).	show snmp mib
Display information about Remote Monitoring (RMON) alarms and events.	show snmp rmon
Display statistics about SNMP packets sent and received.	show snmp statistics
Display SNMP version 3 statistics.	show snmp v3



NOTE: For information about how to configure SNMP, see the *Junos OS Network Management Configuration Guide*.

clear snmp statistics

Syntax	clear snmp statistics
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Clear Simple Network Management Protocol (SNMP) statistics.
Options	This command has no options.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show snmp statistics on page 688
List of Sample Output	clear snmp statistics on page 664
Output Fields	See show snmp statistics for an explanation of output fields.

Sample Output

clear snmp statistics In the following example, SNMP statistics are displayed before and after the **clear snmp statistics** command is issued:

```
user@host> show snmp statistics
SNMP statistics:
  Input:
    Packets: 8, Bad versions: 0, Bad community names: 0,
    Bad community uses: 0, ASN parse errors: 0,
    Too bigs: 0, No such names: 0, Bad values: 0,
    Read onlys: 0, General errors: 0,
    Total request varbinds: 8, Total set varbinds: 0,
    Get requests: 0, Get nexts: 8, Set requests: 0,
    Get responses: 0, Traps: 0,
    Silent drops: 0, Proxy drops 0
  Output:
    Packets: 2298, Too bigs: 0, No such names: 0,
    Bad values: 0, General errors: 0,
    Get requests: 0, Get nexts: 0, Set requests: 0,
    Get responses: 8, Traps: 2290
```

```
user@host> clear snmp statistics
```

```
user@host> show snmp statistics
SNMP statistics:
  Input:
    Packets: 0, Bad versions: 0, Bad community names: 0,
    Bad community uses: 0, ASN parse errors: 0,
    Too bigs: 0, No such names: 0, Bad values: 0,
    Read onlys: 0, General errors: 0,
    Total request varbinds: 0, Total set varbinds: 0,
```



```
Get requests: 0, Get nexts: 0, Set requests: 0,  
Get responses: 0, Traps: 0,  
Silent drops: 0, Proxy drops 0  
Output:  
Packets: 0, Too bigs: 0, No such names: 0,  
Bad values: 0, General errors: 0,  
Get requests: 0, Get nexts: 0, Set requests: 0,  
Get responses: 0, Traps: 0
```

request snmp spoof-trap

Syntax	request snmp spoof-trap <trap> variable-bindings <object> <instance> <value>
Release Information	Command introduced in Junos OS Release 8.2. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Spoof (mimic) the behavior of a Simple Network Management Protocol (SNMP) trap.
Options	<p><trap>—Name of the trap to spoof.</p> <p>variable-bindings <object> <instance> <value>—(Optional) List of variables and values to include in the trap. Each variable binding is specified as an object name, the object instance, and the value (for example, ifIndex[14] = 14). Enclose the list of variable bindings in quotation marks (" ") and use a comma to separate each object name, instance, and value definition (for example, variable-bindings "ifIndex[14] = 14, ifAdminStatus[14] = 1, ifOperStatus[14] = 2"). Objects included in the trap definition that do not have instances and values specified as part of the command are included in the trap and spoofed with automatically generated instances and values.</p> <p><dummy name>—A dummy trap name to display the list of available traps.</p> <p>Question mark (?)—Question mark? to display possible completions.</p>
Required Privilege Level	request
List of Sample Output	<p>request snmp spoof-trap (with Variable Bindings) on page 666</p> <p>request snmp spoof-trap (Illegal Trap Name) on page 666</p> <p>request snmp spoof-trap (Question Mark ?) on page 670</p>

Sample Output

request snmp spoof-trap (with Variable Bindings)	<pre>user@host> request snmp spoof-trap linkUp variable-bindings "ifIndex[14] = 14, ifAdminStatus[14] = 1, ifOperStatus[14] = 2" Spoof trap request result: trap sent successfully</pre>
request snmp spoof-trap (Illegal Trap Name)	<pre>user@host> request snmp spoof-trap xx Spoof trap request result: trap not found</pre> <p>Allowed Traps:</p> <pre>adslAtucInitFailureTrap adslAtucPerfESsThreshTrap adslAtucPerfLofsThreshTrap adslAtucPerfLossThreshTrap adslAtucPerfLprsThreshTrap adslAtucRateChangeTrap adslAturPerfESsThreshTrap adslAturPerfLofsThreshTrap adslAturPerfLossThreshTrap adslAturPerfLprsThreshTrap</pre>

ads1AturRateChangeTrap
apsEventChannelMismatch
apsEventFEPLF
apsEventModeMismatch
apsEventPSBF
apsEventSwitchover
authenticationFailure
bfdSessDown
bfdSessUp
bgpBackwardTransition
bgpEstablished
coldStart
dlsWTrapCircuitDown
dlsWTrapCircuitUp
dlsWTrapTConnDown
dlsWTrapTConnPartnerReject
dlsWTrapTConnProtViolation
dlsWTrapTConnUp
dsx1LineStatusChange
dsx3LineStatusChange
entConfigChange
fallingAlarm
frDLCIStatusChange
ggsnTrapChanged
ggsnTrapCleared
ggsnTrapNew
gmp1sTunnelDown
ifMauJabberTrap
ipv6IfStateChange
isisAreaMismatch
isisAttemptToExceedMaxSequence
isisAuthenticationFailure
isisAuthenticationTypeFailure
isisCorruptedLSPDetected
isisDatabaseOverload
isisIDLenMismatch
isisLSPTooLargeToPropagate
isisManualAddressDrops
isisMaxAreaAddressesMismatch
isisOriginatingLSPBufferSizeMismatch
isisOwnLSPPurge
isisProtocolsSupportedMismatch
isisRejectedAdjacency
isisSequenceNumberSkip
isisVersionSkew
jnxAccessAuthServerDisabled
jnxAccessAuthServerEnabled
jnxAccessAuthServiceDown
jnxAccessAuthServiceUp
jnxBfdSessDetectionTimeHigh
jnxBfdSessTxIntervalHigh
jnxBgpM2BackwardTransition
jnxBgpM2Established
jnxCmCfgChange
jnxCmRescueChange
jnxCollFlowOverload
jnxCollFlowOverloadCleared
jnxCollFtpSwitchover
jnxCollMemoryAvailable
jnxCollMemoryUnavailable
jnxCollUnavailableDest

jnxCollUnavailableDestCleared
jnxCollUnsuccessfulTransfer
jnxDfcHardMemThresholdExceeded
jnxDfcHardMemUnderThreshold
jnxDfcHardPpsThresholdExceeded
jnxDfcHardPpsUnderThreshold
jnxDfcSoftMemThresholdExceeded
jnxDfcSoftMemUnderThreshold
jnxDfcSoftPpsThresholdExceeded
jnxDfcSoftPpsUnderThreshold
jnxEventTrap
jnxExampleStartup
jnxFEBSwitchover
jnxFanFailure
jnxFanOK
jnxFruCheck
jnxFruFailed
jnxFruInsertion
jnxFruOK
jnxFruOffline
jnxFruOnline
jnxFruPowerOff
jnxFruPowerOn
jnxFruRemoval
jnxHardDiskFailed
jnxHardDiskMissing
jnxJsAvPatternUpdateTrap
jnxJsChassisClusterSwitchover
jnxJsFwAuthCapacityExceeded
jnxJsFwAuthFailure
jnxJsFwAuthServiceDown
jnxJsFwAuthServiceUp
jnxJsNatAddrPoolThresholdStatus
jnxJsScreenAttack
jnxJsScreenCfgChange
jnxLdpLspDown
jnxLdpLspUp
jnxLdpSesDown
jnxLdpSesUp
jnxMIMstCistPortLoopProtectStateChangeTrap
jnxMIMstCistPortRootProtectStateChangeTrap
jnxMIMstErrTrap
jnxMIMstGenTrap
jnxMIMstInvalidBpduRxdTrap
jnxMIMstMstiPortLoopProtectStateChangeTrap
jnxMIMstMstiPortRootProtectStateChangeTrap
jnxMIMstNewRootTrap
jnxMIMstProtocolMigrationTrap
jnxMIMstRegionConfigChangeTrap
jnxMIMstTopologyChgTrap
jnxMacChangedNotification
jnxMplsLdpInitSesThresholdExceeded
jnxMplsLdpPathVectorLimitMismatch
jnxMplsLdpSessionDown
jnxMplsLdpSessionUp
jnxOspfV3IfConfigError
jnxOspfV3IfRxBadPacket
jnxOspfV3IfStateChange
jnxOspfV3LsdbApproachingOverflow
jnxOspfV3LsdbOverflow
jnxOspfV3NbrRestartHelperStatusChange

jnxOspfV3NbrStateChange
jnxOspfV3NssaTranslatorStatusChange
jnxOspfV3RestartStatusChange
jnxOspfV3VirtIfConfigError
jnxOspfV3VirtIfRxBadPacket
jnxOspfV3VirtIfStateChange
jnxOspfV3VirtNbrRestartHelperStatusChange
jnxOspfV3VirtNbrStateChange
jnxOtnAlarmCleared
jnxOtnAlarmSet
jnxOverTemperature
jnxPMonOverloadCleared
jnxPMonOverloadSet
jnxPingEgressJitterThresholdExceeded
jnxPingEgressStdDevThresholdExceeded
jnxPingEgressThresholdExceeded
jnxPingIngressJitterThresholdExceeded
jnxPingIngressStdDevThresholdExceeded
jnxPingIngressThresholdExceeded
jnxPingRttJitterThresholdExceeded
jnxPingRttStdDevThresholdExceeded
jnxPingRttThresholdExceeded
jnxPortBpduErrorStatusChangeTrap
jnxPortLoopProtectStateChangeTrap
jnxPortRootProtectStateChangeTrap
jnxPowerSupplyFailure
jnxPowerSupplyOK
jnxRedundancySwitchover
jnxRmonAlarmGetFailure
jnxRmonGetOk
jnxSecAccessIfMacLimitExceeded
jnxSecAccessSdsRateLimitCrossed
jnxSonetAlarmCleared
jnxSonetAlarmSet
jnxSpSvcSetCpuExceeded
jnxSpSvcSetCpuOk
jnxSpSvcSetZoneEntered
jnxSpSvcSetZoneExited
jnxStormEventNotification
jnxSyslogTrap
jnxTemperatureOK
jnxVccpPortDown
jnxVccpPortUp
jnxVpnIfDown
jnxVpnIfUp
jnxVpnPwDown
jnxVpnPwUp
jnxl2aldGlobalMacLimit
jnxl2aldInterfaceMacLimit
jnxl2aldRoutingInstMacLimit
linkDown
linkUp
lldpRemTablesChange
mfrMibTrapBundleLinkMismatch
mplsLspChange
mplsLspDown
mplsLspInfoChange
mplsLspInfoDown
mplsLspInfoPathDown
mplsLspInfoPathUp
mplsLspInfoUp

mplsLspPathDown
mplsLspPathUp
mplsLspUp
mplsNumVrfRouteMaxThreshExceeded
mplsNumVrfRouteMidThreshExceeded
mplsNumVrfSecIllglLb1ThrshExcd
mplsTunnelDown
mplsTunnelReoptimized
mplsTunnelRerouted
mplsTunnelUp
mplsVrfIfDown
mplsVrfIfUp
mplsXCDown
mplsXCUp
msdpBackwardTransition
msdpEstablished
newRoot
ospfIfAuthFailure
ospfIfConfigError
ospfIfRxBadPacket
ospfIfStateChange
ospfLsdbApproachingOverflow
ospfLsdbOverflow
ospfMaxAgeLsa
ospfNbrStateChange
ospfOriginateLsa
ospfTxRetransmit
ospfVirtIfAuthFailure
ospfVirtIfConfigError
ospfVirtIfRxBadPacket
ospfVirtIfStateChange
ospfVirtIfTxRetransmit
ospfVirtNbrStateChange
pethMainPowerUsageOffNotification
pethMainPowerUsageOnNotification
pethPsePortOnOffNotification
pingProbeFailed
pingTestCompleted
pingTestFailed
ptopoConfigChange
risingAlarm
rpMauJabberTrap
sdlcLSStatusChange
sdlcPortStatusChange
topologyChange
traceRoutePathChange
traceRouteTestCompleted
traceRouteTestFailed
vrrpTrapAuthFailure
vrrpTrapNewMaster
warmStart

**request snmp
spoof-trap (Question
Mark ?)**

user@host> request snmp spoof-trap ?
Possible completions:
<trap> The name of the trap to spoof
adslAtucInitFailureTrap
adslAtucPerfESsThreshTrap
adslAtucPerfLofsThreshTrap
adslAtucPerfLolsThreshTrap
adslAtucPerfLossThreshTrap
adslAtucPerfLprsThreshTrap

```
adslAtucRateChangeTrap
adslAturPerfESsThreshTrap
adslAturPerfLofsThreshTrap
adslAturPerfLossThreshTrap
adslAturPerfLprsThreshTrap
adslAturRateChangeTrap
apsEventChannelMismatch
apsEventFEPLF
apsEventModeMismatch
apsEventPSBF
apsEventSwitchover
authenticationFailure
bfdSessDown
bfdSessUp
bgpBackwardTransition
bgpEstablished
coldStart
dlsWTrapCircuitDown
dlsWTrapCircuitUp
---(more 10%)---
```

show snmp health-monitor

Syntax	show snmp health-monitor <alarms <detail>> <logs>
Release Information	Command introduced in Junos OS Release 8.0. Command introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display information about Simple Network Management Protocol (SNMP) health monitor alarms and logs.
Options	none—Display information about all health monitor alarms and logs. alarms <detail>—(Optional) Display detailed information about health monitor alarms. logs—(Optional) Display information about health monitor logs.
Required Privilege Level	view
List of Sample Output	show snmp health-monitor on page 674 show snmp health-monitor alarms detail on page 676
Output Fields	Table 115 on page 672 describes the output fields for the show snmp health-monitor command. Output fields are listed in the approximate order in which they appear.

Table 115: show snmp health-monitor Output Fields

Field Name	Field Description	Level of Output
Alarm Index	Alarm identifier.	All levels
Variable description	Description of the health monitor object instance being monitored.	All levels
Variable name	Name of the health monitor object instance being monitored.	All levels
Value	Current value of the monitored variable in the most recent sample interval.	All levels

Table 115: show snmp health-monitor Output Fields (*continued*)

Field Name	Field Description	Level of Output
State	<p>State of the alarm or event entry:</p> <ul style="list-style-type: none"> Alarms: <ul style="list-style-type: none"> active—Entry is fully configured and activated. falling threshold crossed—Value of the variable has crossed the lower threshold limit. rising threshold crossed—Value of the variable has crossed the upper threshold limit. under creation—Entry is being configured and is not yet activated. startup—Alarm is waiting for the first sample of the monitored variable. object not available—Monitored variable of that type is not available to the health monitor agent. instance not available—Monitored variable's instance is not available to the health monitor agent. object type invalid—Monitored variable is not a numeric value. object processing errored—An error occurred when the monitored variable was processed. unknown—State is not one of the above. 	All levels
Variable OID	Object ID to which the variable name is resolved. The format is x.x.x.x.	detail
Sample type	Method of sampling the monitored variable and calculating the value to compare against the upper and lower thresholds. It can have the value of absolute value or delta value .	detail
Startup alarm	<p>Alarm that might be sent when this entry is first activated, depending on the following criteria:</p> <ul style="list-style-type: none"> Alarm is sent when one of the following situations exists: <ul style="list-style-type: none"> Value of the alarm is above or equal to the rising threshold and the startup type is either rising alarm or rising or falling alarm. Value of the alarm is below or equal to the falling threshold and the startup type is either falling alarm or rising or falling alarm. Alarm is <i>not</i> sent when one of the following situations exists: <ul style="list-style-type: none"> Value of the alarm is above or equal to the rising threshold and the startup type is falling alarm. Value of the alarm is below or equal to the falling threshold and the startup type is rising alarm. Value of the alarm is between the thresholds. 	detail
Owner	Name of the entry configured by the user. If the entry was created through the CLI, the owner has monitor prepended to it.	detail
Creator	Mechanism by which the entry was configured (Health Monitor).	detail
Sample interval	Time period between samples (in seconds).	detail
Rising threshold	Upper limit threshold value as a percentage of the maximum possible value.	detail

Table 115: show snmp health-monitor Output Fields (*continued*)

Field Name	Field Description	Level of Output
Falling threshold	Lower limit threshold value as a percentage of the maximum possible value.	detail
Rising event index	Event triggered when the rising threshold is crossed.	detail
Falling event index	Event triggered when the falling threshold is crossed.	detail

Sample Output

```

show snmp health-monitor user@host> show snmp health-monitor

Alarm
Index  Variable description                                Value State
-----
32768 Health Monitor: root file system utilization
      jnxHrStoragePercentUsed.1                        58 active
32769 Health Monitor: /config file system utilization
      jnxHrStoragePercentUsed.2                        0 active
32770 Health Monitor: RE 0 CPU utilization
      jnxOperatingCPU.9.1.0.0                          0 active
32773 Health Monitor: RE 0 Memory utilization
      jnxOperatingBuffer.9.1.0.0                      35 active
32775 Health Monitor: jkernel daemon CPU utilization
      Init daemon                                       0 active
      Chassis daemon                                   50 active
      Firewall daemon                                  0 active
      Interface daemon                                 5 active
      SNMP daemon                                       11 active
      MIB2 daemon                                       42 active
      Sonet APS daemon                                 0 active
      VRRP daemon                                       0 active
      Alarm daemon                                      3 active
      PFE daemon                                        0 active
      CRAFT daemon                                     0 active
      Traffic sampling control daemon                  0 active
      Ilmi daemon                                       0 active
      Remote operations daemon                         0 active
      CoS daemon                                        0 active
      Pic Services Logging daemon                      0 active
      Internal Routing Service Daemon                  3 active
      Network Access Service daemon                   0 active
      Forwarding UDP daemon                           0 active
      Routing socket proxy daemon                      0 active
      Disk Monitoring daemon                           1 active
      Inet daemon                                       0 active
      Syslog daemon                                    0 active
      Adaptive Services PIC daemon                    0 active
      ECC parity errors logging Daemon                 0 active
      Layer 2 Tunneling Protocol daemon                0 active
      PPPoE daemon                                     3 active
      Redundancy device daemon                        0 active

```

```

PPP daemon                                0 active
Dynamic Flow Capture Daemon               0 active

32776 Health Monitor: jroute daemon CPU utilization
Routing protocol daemon                   1 active
Management daemon                        0 active
Management daemon                        0 active
Command line interface                   4 active
Periodic Packet Management daemon         0 active
Link Management daemon                   0 active
Pragmatic General Multicast daemon        0 active
Bidirectional Forwarding Detection daemon 0 active
SRC daemon                              0 active
audit daemon                             0 active
Event daemon                             0 active

32777 Health Monitor: jcrypto daemon CPU utilization
IPSec Key Management daemon               0 active

32779 Health Monitor: jkernel daemon Memory utilization
Init daemon                             47384 active
Chassis daemon                           20204 active
Firewall daemon                          1956 active
Interface daemon                         3340 active
SNMP daemon                              4540 active
MIB2 daemon                              3880 active
Sonet APS daemon                         2632 active
VRRP daemon                              2672 active
Alarm daemon                             1856 active
PFE daemon                               2600 active
CRAFT daemon                             2000 active
Traffic sampling control daemon           3164 active
Ilmi daemon                              2132 active
Remote operations daemon                  2964 active
CoS daemon                               3044 active
Pic Services Logging daemon               1944 active
Internal Routing Service Daemon           1392 active
Network Access Service daemon             1992 active
Forwarding UDP daemon                     1876 active
Routing socket proxy daemon               1296 active
Disk Monitoring daemon                    1180 active
Inet daemon                              1296 active
Syslog daemon                             1180 active
Adaptive Services PIC daemon              3220 active
ECC parity errors logging Daemon          1100 active
Layer 2 Tunneling Protocol daemon         3372 active
PPPoE daemon                             1424 active
Redundancy device daemon                  1820 active
PPP daemon                               2060 active
Dynamic Flow Capture Daemon               10740 active

32780 Health Monitor: jroute daemon Memory utilization
Routing protocol daemon                   8104 active
Management daemon                        13360 active
Management daemon                        19252 active
Command line interface                   9912 active
Periodic Packet Management daemon         1484 active
Link Management daemon                   2016 active
Pragmatic General Multicast daemon        1968 active
Bidirectional Forwarding Detection daemon 1956 active
SRC daemon                              1772 active
audit daemon                             1772 active

```

Event daemon 1808 active

32781 Health Monitor: jcrypto daemon Memory utilization
IPSec Key Management daemon 5600 active

show snmp user@host> **show snmp health-monitor alarms detail**
health-monitor alarms
detail

```
Alarm Index 32768:
Variable name          jnxHrStoragePercentUsed.1
Variable OID           1.3.6.1.4.1.2636.3.31.1.1.1.1.1
Sample type            absolute value
Startup alarm          rising alarm
Owner                  Health Monitor: root file system
                       utilization
Creator                Health Monitor
State                  active
Sample interval        300 seconds
Rising threshold       80
Falling threshold      70
Rising event index     32768
Falling event index    32768
Instance Value: 58
Instance State: active

Alarm Index 32769:
Variable name          jnxHrStoragePercentUsed.2
Variable OID           1.3.6.1.4.1.2636.3.31.1.1.1.1.2
Sample type            absolute value
Startup alarm          rising alarm
Owner                  Health Monitor: /config file system
                       utilization
Creator                Health Monitor
State                  active
Sample interval        300 seconds
Rising threshold       80
Falling threshold      70
Rising event index     32768
Falling event index    32768
Instance Value: 0
Instance State: active

Alarm Index 32770:
Variable name          jnxOperatingCPU.9.1.0.0
Variable OID           1.3.6.1.4.1.2636.3.1.13.1.8.9.1.0.0
Sample type            absolute value
Startup alarm          rising alarm
Owner                  Health Monitor: RE 0 CPU utilization

Creator                Health Monitor
State                  active
Sample interval        300 seconds
Rising threshold       80
Falling threshold      70
Rising event index     32768
Falling event index    32768
Instance Value: 0
Instance State: active

Alarm Index 32773:
Variable name          jnxOperatingBuffer.9.1.0.0
```

Variable OID	1.3.6.1.4.1.2636.3.1.13.1.11.9.1.0.0
Sample type	absolute value
Startup alarm	rising alarm
Owner	Health Monitor: RE 0 Memory utilization

Creator	Health Monitor
State	active
Sample interval	300 seconds
Rising threshold	80
Falling threshold	70
Rising event index	32768
Falling event index	32768
Instance Value:	35
Instance State:	active

Alarm Index 32775:

Variable name	sysAppElmtRunCPU.3
Variable OID	1.3.6.1.2.1.54.1.2.3.1.9.3
Sample type	delta value
Startup alarm	rising alarm
Owner	Health Monitor: jkernel daemon CPU utilization

Creator	Health Monitor
State	active
Sample interval	300 seconds
Rising threshold	24000
Falling threshold	21000
Rising event index	32768
Falling event index	32768
Instance Name:	sysAppElmtRunCPU.3.1.1
Instance Description:	Init daemon
Instance Value:	0
Instance State:	active

Instance Name:	sysAppElmtRunCPU.3.2.2786
Instance Description:	Chassis daemon
Instance Value:	50
Instance State:	active

Instance Name:	sysAppElmtRunCPU.3.3.2938
Instance Description:	Firewall daemon
Instance Value:	0
Instance State:	active

Instance Name:	sysAppElmtRunCPU.3.4.2942
Instance Description:	Interface daemon
Instance Value:	5
Instance State:	active

Instance Name:	sysAppElmtRunCPU.3.7.7332
Instance Description:	SNMP daemon
Instance Value:	11
Instance State:	active

Instance Name:	sysAppElmtRunCPU.3.9.2914
Instance Description:	MIB2 daemon
Instance Value:	42
Instance State:	active

Instance Name:	sysAppElmtRunCPU.3.12.2916
----------------	----------------------------

Instance Description: Sonet APS daemon
Instance Value: 0
Instance State: active

Instance Name: sysAppElemRunCPU.3.13.2917
Instance Description: VRRP daemon
Instance Value: 0
Instance State: active

Instance Name: sysAppElemRunCPU.3.14.2787
Instance Description: Alarm daemon
Instance Value: 3
Instance State: active

Instance Name: sysAppElemRunCPU.3.15.2940
Instance Description: PFE daemon
Instance Value: 0
Instance State: active

Instance Name: sysAppElemRunCPU.3.16.2788
Instance Description: CRAFT daemon
Instance Value: 0
Instance State: active

Instance Name: sysAppElemRunCPU.3.17.2918
Instance Description: Traffic sampling control daemon
---(more 23%)---

show snmp inform-statistics

Syntax	show snmp inform-statistics
Release Information	Command introduced in Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display information about Simple Network Management Protocol (SNMP) inform requests.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show snmp inform-statistics on page 679
Output Fields	Table 116 on page 679 describes the output fields for the show snmp inform-statistics command. Output fields are listed in the approximate order in which they appear.

Table 116: show snmp inform-statistics Output Fields

Field Name	Field Description
Target Name	Name of the device configured to receive and respond to SNMP informs.
Address	IP address of the target device.
Sent	Number of informs sent to the target device and acknowledged by the target device.
Pending	Number of informs held in memory pending a response from the target device.
Discarded	Number of informs discarded after the specified number of retransmissions to the target device were attempted.
Timeouts	Number of informs that did not receive an acknowledgement from the target device within the timeout specified.
Probe Failures	Connection failures that occurred (for example, when the target server returned invalid content or you incorrectly configured the target address).

Sample Output

```

user@host> show snmp inform-statistics
Inform Request Statistics:
Target Name: TA1_v3_md5_none Address: 172.17.20.184
Sent: 176, Pending: 0
Discarded: 0, Timeouts: 0, Probe Failures: 0
Target Name: TA2_v3_sha_none Address: 192.168.110.59
Sent: 0, Pending: 4
Discarded: 84, Timeouts: 0, Probe Failures: 258

```

Target Name: TA5_v2_none Address: 172.17.20.184
Sent: 0, Pending: 0
Discarded: 2, Timeouts: 10, Probe Failures: 0

show snmp mib

Syntax	<code>show snmp mib (get get-next walk) (ascii decimal) <i>object-id</i></code>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>ascii and decimal options introduced in Junos OS Release 9.6.</p> <p>ascii and decimal options introduced in Junos OS Release 9.6 for EX Series switches.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Display local Simple Network Management Protocol (SNMP) Management Information Base (MIB) object values.
Options	<p>get—Retrieve and display one or more SNMP object values.</p> <p>get-next—Retrieve and display the next SNMP object values.</p> <p>walk—Retrieve and display the SNMP object values that are associated with the requested object identifier (OID). When you use this option, the Junos OS displays the objects below the subtree that you specify.</p> <p>ascii—Display the SNMP object's string indices as an ASCII-key representation.</p> <p>decimal—Display the SNMP object values in the decimal (default) format. The decimal option is the default option for this command. Therefore, issuing the show snmp mib (get get-next walk) decimal object-id and the show snmp mib (get get-next walk) object-id commands display the same output.</p> <p>object-id—The object can be represented by a sequence of dotted integers (such as 1.3.6.1.2.1.2) or by its subtree name (such as interfaces). When entering multiple objects, enclose the objects in quotation marks.</p>
Required Privilege Level	snmp—To view this statement in the configuration.
List of Sample Output	<p><code>show snmp mib get</code> on page 682</p> <p><code>show snmp mib get (Multiple Objects)</code> on page 682</p> <p><code>show snmp mib get-next</code> on page 682</p> <p><code>show snmp mib get-next (Specify an OID)</code> on page 682</p> <p><code>show snmp mib walk</code> on page 682</p> <p><code>show snmp mib walk (QFX Series)</code> on page 682</p> <p><code>show snmp mib walk decimal</code> on page 682</p> <p><code>show snmp mib walk (ASCII)</code> on page 682</p> <p><code>show snmp mib walk (Multiple Indices)</code> on page 682</p> <p><code>show snmp mib walk decimal (Multiple Indices)</code> on page 683</p>
Output Fields	Table 117 on page 682 describes the output fields for the show snmp mib command. Output fields are listed in the approximate order in which they appear.

Table 117: show snmp mib Output Fields

Field Name	Field Description
<i>name</i>	Object name and numeric instance value.
<i>object value</i>	Object value. The Junos OS translates OIDs into the corresponding object names.

Sample Output

```

show snmp mib get      user@host> show snmp mib get sysObjectID.0
                        sysObjectID.0 = jnxProductNameM20

show snmp mib get      user@host> show snmp mib get ?sysObjectID.0 sysUpTime.0?
(Multiple Objects)    sysObjectID.0 = jnxProductNameM20
                        sysUpTime.0 = 1640992

show snmp mib          user@host> show snmp mib get-next jnxMibs
get-next              jnxBoxClass.0 = jnxProductLineM20.0

show snmp mib          user@host> show snmp mib get-next 1.3.6.1
get-next (Specify an  sysDescr.0 = Juniper Networks, Inc. m20 internet router, kernel
OID)                  Junos OS Release: 2004-1 Build date: build date UTC Copyright (c) 1996-2004 Juniper
                        Networks, Inc.

show snmp mib walk     user@host> show snmp mib walk system
                        sysDescr.0 = Juniper Networks, Inc. m20 internet router, kernel
                        Junos OS Release #0: 2004-1 Build date: build date UTC Copyright (c) 1996-2004
                        Juniper Networks, Inc.
                        sysObjectID.0 = jnxProductNameM20
                        sysUpTime.0 = 1640992
                        sysContact.0 = Your contact
                        sysName.0 = my router
                        sysLocation.0 = building 1
                        sysServices.0 = 4

show snmp mib walk     user@switch> show snmp mib walk system
(QFX Series)          sysDescr.0 = Juniper Networks, Inc. qfx3500s internet router, kernel JUNOS
                        11.1-20100926.0 #0: 2010-09-26 06:17:38 UTC Build date: 2010-09-26 06:00:10
                        sysObjectID.0 = jnxProductQFX3500
                        sysUpTime.0 = 138980301
                        sysContact.0 = System Contact
                        sysName.0 = LabQFX3500
                        sysLocation.0 = Lab
                        sysServices.0 = 4

show snmp mib walk     user@host> show snmp mib walk decimal jnxUtilData
decimal                jnxUtilCounter32Value.102.114.101.100 = 100

show snmp mib walk     show snmp mib walk ascii jnxUtilData
(ASCII)                jnxUtilCounter32Value."fred" = 100

show snmp mib walk     show snmp mib walk ascii jnxFWCounterByteCount
(Multiple Indices)    jnxFWCounterByteCount."fe-1/3/0.0-i"."CLASS_BE-fe-1/3/0.0-i".2 = 0
                        jnxFWCounterByteCount."fe-1/3/0.0-i"."CLASS_CC-fe-1/3/0.0-i".2 = 0

```

```
jnxFWCounterByteCount."fe-1/3/0.0-i"."CLASS_RT-fe-1/3/0.0-i".2 = 0
.....
```

show snmp mib walk
decimal (Multiple
Indices)

```
show snmp mib walk ascii jnxFWCounterByteCount
jnxFWCounterByteCount."fe-1/3/0.0-i"."CLASS_BE-fe-1/3/0.0-i".2 = 0
jnxFWCounterByteCount."fe-1/3/0.0-i"."CLASS_CC-fe-1/3/0.0-i".2 = 0
jnxFWCounterByteCount."fe-1/3/0.0-i"."CLASS_RT-fe-1/3/0.0-i".2 = 0
.....
```

show snmp rmon

Syntax	show snmp rmon <alarms <brief detail> events <brief detail> logs>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display information about Simple Network Management Protocol (SNMP) Remote Monitoring (RMON) alarms and events.
Options	<p>none—Display information about all RMON alarms and events.</p> <p>alarms—(Optional) Display information about RMON alarms.</p> <p>brief detail—(Optional) Display brief or detailed information about RMON alarms or events.</p> <p>events—(Optional) Display information about RMON events.</p> <p>logs—(Optional) Display information about RMON monitoring logs.</p>
Required Privilege Level	view
List of Sample Output	<p>show snmp rmon on page 686</p> <p>show snmp rmon alarms detail on page 686</p> <p>show snmp rmon events detail on page 687</p>
Output Fields	Table 118 on page 684 describes the output fields for the show snmp rmon command. Output fields are listed in the approximate order in which they appear.

Table 118: show snmp rmon Output Fields

Field Name	Field Description	Level of Output
Alarm Index	Alarm identifier.	All levels

Table 118: show snmp rmon Output Fields (*continued*)

Field Name	Field Description	Level of Output
State	<p>State of the alarm or event entry:</p> <p>Alarms:</p> <ul style="list-style-type: none"> • active—Entry is fully configured and activated. • falling threshold crossed—Value of the variable has crossed the lower threshold limit. • rising threshold crossed—Value of the variable has crossed the upper threshold limit. • under creation—Entry is being configured and is not yet activated. • startup—Alarm is waiting for the first sample of the monitored variable. • object not available—Monitored variable of that type is not available to the SNMP agent. • instance not available—Monitored variable's instance is not available to the SNMP agent. • object type invalid—Monitored variable is not a numeric value. • object processing errored—An error occurred when the monitored variable was processed. • unknown—State is not one of the above. <p>Events:</p> <ul style="list-style-type: none"> • active—Entry has been fully configured and activated. • under creation—Entry is being configured and is not yet activated. • unknown—State is not one of the above. 	All levels
Variable name	Name of the SNMP object instance being monitored.	All levels
Event Index	Event identifier.	All levels
Type	<p>Type of notification made when an event is triggered. It can be one of the following:</p> <ul style="list-style-type: none"> • log—A system log message is generated and an entry is made to the log table. • snmptrap—An SNMP trap is sent to the configured destination. • log and trap—A system log message is generated, an entry is made to the log table, and an SNMP trap is sent to the configured destination. • none—Neither log nor trap will be sent. 	detail
Last Event	Date and time of the last event. It has the format <i>yyyy-mm-dd hh:mm:ss timezone</i> .	brief
Community	Identifies the trap group used for sending the SNMP trap.	detail
Variable OID	Object ID to which the variable name is resolved. The format is x.x.x.x.	detail
Sample type	Method of sampling the monitored variable and calculating the value to compare against the upper and lower thresholds. It can have the value of absolute value or delta value .	detail

Table 118: show snmp rmon Output Fields (*continued*)

Field Name	Field Description	Level of Output
Startup alarm	Alarm that might be sent when this entry is first activated, depending on the following criteria: <ul style="list-style-type: none"> Alarm is sent when one of the following situations exists: <ul style="list-style-type: none"> Value of the alarm is above or equal to the rising threshold and the startup type is either rising alarm or rising or falling alarm. Value of the alarm is below or equal to the falling threshold and the startup type is either falling alarm or rising or falling alarm. Alarm is <i>not</i> sent when one of the following situations exists: <ul style="list-style-type: none"> Value of the alarm is above or equal to the rising threshold and the startup type is falling alarm. Value of the alarm is below or equal to the falling threshold and the startup type is rising alarm. Value of the alarm is between the thresholds. 	detail
Owner	Name of the entry configured by the user. If the entry was created through the CLI, the owner has monitor prepended to it.	detail
Creator	Mechanism by which the entry was configured (CLI or SNMP).	detail
Sample interval	Time period between samples (in seconds).	detail
Rising threshold	Upper limit threshold value configured by the user.	detail
Falling threshold	Lower limit threshold value configured by the user.	detail
Rising event index	Event triggered when the rising threshold is crossed.	detail
Falling event index	Event triggered when the falling threshold is crossed.	detail
Current value	Current value of the monitored variable in the most recent sample interval.	detail

Sample Output

```

show snmp rmon      user@host> show snmp rmon
                    Alarm
                    Index  State                      Variable name
                      1  falling threshold crossed  ifInOctets.1

                    Event
                    Index  Type                      Last Event
                      1  log and trap                2002-01-30 01:13:01 PST

show snmp rmon      user@host> show snmp rmon alarms detail
alarms detail
Alarm Index 1:
Variable name                      ifInOctets.1
Variable OID                        1.3.6.1.2.1.2.2.1.10.1

```

Sample type		delta value
Startup alarm		rising or falling alarm
Owner		monitor
Creator		CLI
State		falling threshold crossed
Sample interval	60	seconds
Rising threshold	100000	
Falling threshold	80000	
Rising event index	1	
Falling event index	1	
Current value	0	

```
show snmp rmon events detail user@host> show snmp rmon events detail
Event Index 1:
  Type          log and trap
  Community     boy-elroy
  Last event    2002-01-30 01:13:01 PST
  Creator       CLI
  State         active
```

show snmp statistics

Syntax	show snmp statistics
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display statistics about Simple Network Management Protocol (SNMP) packets sent and received by the router or switch.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear snmp statistics on page 664
List of Sample Output	show snmp statistics on page 691
Output Fields	Table 119 on page 688 describes the output fields for the show snmp statistics command. Output fields are listed in the approximate order in which they appear.

Table 119: show snmp statistics Output Fields

Field Name	Field Description
Input	<p>Information about received packets:</p> <ul style="list-style-type: none"> Packets(snmplnPkts)—Total number of messages delivered to the SNMP entity from the transport service. Bad versions—(snmplnBadVersions) Total number of messages delivered to the SNMP entity that were for an unsupported SNMP version. Bad community names—(snmplnBadCommunityNames) Total number of messages delivered to the SNMP entity that used an SNMP community name not known to the entity. Bad community uses—(snmplnBadCommunityUses) Total number of messages delivered to the SNMP entity that represented an SNMP operation that was not allowed by the SNMP community named in the message. ASN parse errors—(snmplnASNParseErrs) Total number of ASN.1 or BER errors encountered by the SNMP entity when decoding received SNMP messages. Too big—(snmplnTooBig) Total number of SNMP PDUs delivered to the SNMP entity with an error status field of tooBig. No such names—(snmplnNoSuchNames) Total number of SNMP PDUs delivered to the SNMP entity with an error status field of noSuchName. Bad values—(snmplnBadValues) Total number of SNMP PDUs delivered to the SNMP entity with an error status field of badValue. Read only—(snmplnReadOnly) Total number of valid SNMP PDUs delivered to the SNMP entity with an error status field of readOnly. Only incorrect implementations of SNMP generate this error.

Table 119: show snmp statistics Output Fields (*continued*)

Field Name	Field Description
Input (continued)	<ul style="list-style-type: none"> • General errors—(snmpInGenErrs) Total number of SNMP PDUs delivered to the SNMP entity with an error status field of genErr. • Total requests varbinds—(snmpInTotalReqVars) Total number of MIB objects retrieved successfully by the SNMP entity as a result of receiving valid SNMP GetRequest and GetNext PDUs. • Total set varbinds—(snmpInSetVars) Total number of MIB objects modified successfully by the SNMP entity as a result of receiving valid SNMP SetRequest PDUs. • Get requests—(snmpInGetRequests) Total number of SNMP GetRequest PDUs that have been accepted and processed by the SNMP entity. • Get nexts—(snmpInGetNexts) Total number of SNMP GetNext PDUs that have been accepted and processed by the SNMP entity. • Set requests—(snmpInSetRequests) Total number of SNMP SetRequest PDUs that have been accepted and processed by the SNMP entity. • Get responses—(snmpInGetResponses) Total number of SNMP GetResponse PDUs that have been accepted and processed by the SNMP entity. • Traps—(snmpInTraps) Total number of SNMP traps generated by the SNMP entity. • Silent drops—(snmpSilentDrops) Total number of GetRequest, GetNextRequest, GetBulkRequest, SetRequests, and InformRequest PDUs delivered to the SNMP entity that were silently dropped because the size of a reply containing an alternate response PDU with an empty variable-bindings field was greater than either a local constraint or the maximum message size associated with the originator of the requests. • Proxy drops—(snmpProxyDrops) Total number of GetRequest, GetNextRequest, GetBulkRequest, SetRequests, and InformRequest PDUs delivered to the SNMP entity that were silently dropped because the transmission of the message to a proxy target failed in such a way (other than a timeout) that no response PDU could be returned. • Commit pending drops—Number of SNMP packets for Set requests dropped because of a previous pending SNMP Set request on the committed configuration. • Throttle drops—Number of SNMP packets for any requests dropped reaching the throttle limit.

Table 119: show snmp statistics Output Fields (*continued*)

Field Name	Field Description
V3 Input	<p>Information about SNMP version 3 packets:</p> <ul style="list-style-type: none"> • Unknown security models—(snmpUnknownSecurityModels) Total number of packets received by the SNMP engine that were dropped because they referenced a security model that was not known to or supported by the SNMP engine. • Invalid messages—(snmpInvalidMsgs) Number of packets received by the SNMP engine that were dropped because there were invalid or inconsistent components in the SNMP message. • Unknown pdu handlers—(snmpUnknownPDUHandlers) Number of packets received by the SNMP engine that were dropped because the PDU contained in the packet could not be passed to an application responsible for handling the PDU type. • Unavailable contexts—(snmpUnavailableContexts) Number of requests received for a context that is known to the SNMP engine, but is currently unavailable. • Unknown contexts—(snmpUnknownContexts) Total number of requests received for a context that is unknown to the SNMP engine. • Unsupported security levels—(usmStatsUnsupportedSecLevels) Total number of packets received by the SNMP engine that were dropped because they requested a security level unknown to the SNMP engine (or otherwise unavailable). • Not in time windows—(usmStatsNotInTimeWindows) Total number of packets received by the SNMP engine that were dropped because they appeared outside the authoritative SNMP engine's window. • Unknown user names—(usmStatsUnknownUserNames) Total number of packets received by the SNMP engine that were dropped because they referenced a user that was not known to the SNMP engine. • Unknown engine ids—(usmStatsUnknownEngineIDs) Total number of packets received by the SNMP engine that were dropped because they referenced an SNMP engine ID that was not known to the SNMP engine. • Wrong digests—(usmStatsWrongDigests) Total number of packets received by the SNMP engine that were dropped because they did not contain the expected digest value. • Decryption errors—(usmStatsDecryptionErrors) Total number of packets received by the SNMP engine that were dropped because they could not be decrypted.

Table 119: show snmp statistics Output Fields (*continued*)

Field Name	Field Description
Output	<p>Information about transmitted packets:</p> <ul style="list-style-type: none"> • Packets—(snmpOutPkts) Total number of messages passed from the SNMP entity to the transport service. • Too big—(snmpOutTooBig) Total number of SNMP PDUs generated by the SNMP entity with an error status field of tooBig. • No such names—(snmpOutNoSuchNames) Total number of SNMP PDUs delivered to the SNMP entity with an error status field of noSuchName. • Bad values—(snmpOutBadValues) Total number of SNMP PDUs generated by the SNMP entity with an error status field of badValue. • General errors—(snmpOutGenErrs) Total number of SNMP PDUs generated the SNMP entity with an error status field of genErr. • Get requests—(snmpOutGetRequests) Total number of SNMP GetRequest PDUs generated by the SNMP entity. • Get nexts—(snmpOutGetNexts) Total number of SNMP GetNext PDUs generated by the SNMP entity. • Set requests—(snmpOutSetRequests) Total number of SNMP SetRequest PDUs generated by the SNMP entity. • Get responses—(snmpOutGetResponses) Total number of SNMP GetResponse PDUs generated by the SNMP entity. • Traps—(snmpOutTraps) Total number of SNMP traps generated by the SNMP entity.

Sample Output

```

show snmp statistics  user@host> show snmp statistics
SNMP statistics:
  Input:
    Packets: 246213, Bad versions: 12, Bad community names: 12,
    Bad community uses: 0, ASN parse errors: 96,
    Too big: 0, No such names: 0, Bad values: 0,
    Read only: 0, General errors: 0,
    Total request varbinds: 227084, Total set varbinds: 67,
    Get requests: 44942, Get nexts: 190371, Set requests: 10712,
    Get responses: 0, Traps: 0,
    Silent drops: 0, Proxy drops: 0, Commit pending drops: 0,
    Throttle drops: 0,
  V3 Input:
    Unknown security models: 0, Invalid messages: 0
    Unknown pdu handlers: 0, Unavailable contexts: 0
    Unknown contexts: 0, Unsupported security levels: 1
    Not in time windows: 0, Unknown user names: 0
    Unknown engine ids: 44, Wrong digests: 23, Decryption errors: 0
  Output:
    Packets: 246093, Too big: 0, No such names: 31561,
    Bad values: 0, General errors: 2,
    Get requests: 0, Get nexts: 0, Set requests: 0,
    Get responses: 246025, Traps: 0

```

show snmp v3

Syntax	<code>show snmp v3</code> <code><access <brief detail> community general groups notify <filter> target <address parameters> users></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the Simple Network Management Protocol version 3 (SNMPv3) operating configuration.
Options	<p><code>none</code>—Display all of the SNMPv3 operating configuration.</p> <p><code>access</code>—(Optional) Display SNMPv3 access information.</p> <p><code>brief detail</code>—(Optional) Display brief or detailed information about SNMPv3 access information.</p> <p><code>community</code>—(Optional) Display SNMPv3 community information.</p> <p><code>general</code>—(Optional) Display SNMPv3 general information.</p> <p><code>groups</code>—(Optional) Display SNMPv3 security-to-group information.</p> <p><code>notify <filter></code>—(Optional) Display SNMPv3 notify and, optionally, notify filter information.</p> <p><code>target <address parameters></code>—(Optional) Display SNMPv3 target and, optionally, either target address or target parameter information.</p> <p><code>users</code>—(Optional) Display SNMPv3 user information.</p>
Additional Information	To edit the default display of the show snmp v3 command, specify options in the show statement at the [edit snmp v3] hierarchy level.
Required Privilege Level	view
List of Sample Output	show snmp v3 on page 694
Output Fields	Table 120 on page 693 describes the output fields for the show snmp v3 command. Output fields are listed in the approximate order in which they appear.

Table 120: show snmp v3 Output Fields

Field Name	Field Description
Access control	<p>Information about access control:</p> <ul style="list-style-type: none"> • Group—Group name for which the configured access privileges apply. The group, together with the context prefix and the security model and security level, forms the index for this table. • Context prefix—SNMPv3 context for which the configured access privileges apply. • Security model/level—Security model and security level for which the configuration access privileges apply. • Read view—Identifies the MIB view applied to SNMPv3 read operations. • Write view—Identifies the MIB view applied to SNMPv3 write operations. • Notify view—Identifies the MIB view applied to outbound SNMP notifications.
Engine	<p>Information about local engine configuration:</p> <ul style="list-style-type: none"> • Local engine ID—Identifier that uniquely and unambiguously identifies the local SNMPv3 engine. • Engine boots—Number of times the local SNMPv3 engine has rebooted or reinitialized since the engine ID was last changed. • Engine time—Number of seconds since the local SNMPv3 engine was last rebooted or reinitialized. • Max msg size—Maximum message size the sender can accommodate.
Engine ID	<p>Information about engine ID:</p> <ul style="list-style-type: none"> • Local engine ID—Identifier that uniquely and unambiguously identifies the local SNMPv3 engine. • Engine boots—Number of times the local SNMPv3 engine has rebooted or reinitialized since the engine ID was last changed. • Engine time—Number of seconds since the local SNMPv3 engine was last rebooted or reinitialized. • Max msg size—Maximum message size the sender can accommodate. • Engine ID—SNMPv3 engine ID associated with each user. • User—SNMPv3 user. • Auth/Priv—Authentication and encryption algorithm available for use by each user. • Storage—Indicates whether a user is saved to the configuration file (nonvolatile) or not (volatile). Applies only to users with active status. • Status—Status of the conceptual row. Only rows with an active status are used by the SNMPv3 engine.
Group name	Name of the group to which this entry belongs.
Security model	Identifies the security model context for the security name.
Security name	Used with the security model; identifies a specific security name instance. Each security model/security name combination can be assigned to a specific group.
Storage type	Indicates whether a user is saved to the configuration file (nonvolatile) or not (volatile). Applies only to users with active status.
Status	Status of the conceptual row. Only rows with active status are used by the SNMPv3 engine.

Sample Output

```

user@host> show snmp v3
show snmp v3
Local engine ID: 80 00 0a 4c e04 31 32 33 34
Engine boots:      38
Engine time:       64583 seconds
Max msg size:      2048 bytes

Engine ID: local
  User          Auth/Priv  Storage  Status
  user1         md5/des   nonvolatile active
  user2         sha/none  nonvolatile active
  user3         none/none nonvolatile active

Engine ID: 81 00 0a 4c 04 64 64 64 64
  User          Auth/Priv  Storage  Status
  UNEW         md5/none  nonvolatile active

Group name      Security model  Security name  Storage type  Status
g1              usm             user1          nonvolatile   active
g2              usm             user2          nonvolatile   active
g3              usm             user3          nonvolatile   active

Access control:
Group           Context prefix  Security model/level  Read view  Write view  Notify view
g1              usm/privacy  v1                  v1
g2              usm/authent  v1                  v1
g3              usm/none     v1                  v1

```

System Software Operational Mode Commands

Table 121 on page 695 summarizes the command-line interface (CLI) commands you can use to perform and monitor system software management functions. Commands are listed in alphabetical order.

Table 121: System Software Operational Mode Commands

Task	Command
Clear the Address Resolution Protocol (ARP) table.	clear arp
Clear the binding state of a Dynamic Host Configuration Protocol (DHCP) client from the client table on the extended DHCP local server.	clear dhcp server binding
Clear all extended DHCP local server statistics.	clear dhcp server statistics
Clear the binding state from the client table on the DHCPv6 local server.	clear dhcpv6 server binding
Clear all DHCPv6 local server statistics.	clear dhcpv6 server statistics
Clear AAA statistics.	clear network-access aaa statistics
Log out AAA subscribers and clear the AAA subscriber statistics.	clear network-access aaa subscriber
Clear a pending commit operation.	clear system commit
Clear a pending system halt or reboot.	clear system reboot
(J Series routers only) Remove obsolete IP address bindings on a Dynamic Host Configuration Protocol (DHCP) server.	clear system services dhcp binding
(J Series routers only) Clear IP addresses from the DHCP server conflicts list.	clear system services dhcp conflict

Table 121: System Software Operational Mode Commands (*continued*)

Task	Command
(J Series routing routers only) Clear DHCP server statistics.	clear system services dhcp statistics
Enter configuration mode.	configure
Execute an operation (op) script.	op
Force lease renewal for DHCPv4 clients.	request dhcp server reconfigure
Initiate reconfiguration processing for DHCPv6 clients.	request dhcpv6 server reconfigure
Send messages to users currently logged in to the router.	request message
On a router with two Routing Engines, specify a tty connection for login.	request routing-engine login
Resets the state of an interface group on which static subscribers were forcibly logged out.	request services static-subscribers login group
Forces static subscribers on the interfaces in the group to be logged out.	request services static-subscribers login interface
Resets the state of an interface on which a static subscriber was forcibly logged out.	request services static-subscribers logout group
Forces static subscriber on the interface to be logged out.	request services static-subscribers logout interface
Collect information for customer support.	request support information
Delete an existing rescue configuration.	request system configuration rescue delete
Save the most recently committed configuration as the rescue configuration.	request system configuration rescue save
(J Series routers only) Upgrade or downgrade firmware.	request system firmware
Stop the routing software.	request system halt
Add a license key.	request system license add
Delete a license key.	request system license delete
(J Series routers only) Save installed license keys to a file or URL.	request system license save

Table 121: System Software Operational Mode Commands (*continued*)

Task	Command
Log out a user from the configuration database.	request system logout
Abort a previously scheduled partition request.	request system partition abort
Schedule the hard disk for partitioning.	request system partition hard-disk
Power off the routing software.	request system power-off
Reboot the routing software.	request system reboot
Convert an Extensible Stylesheet Language Transformations (XSLT) script to Stylesheet Language, Alternative syntax (SLAX), or convert a SLAX script to XSLT.	request system scripts convert
Back up the file systems on the router.	request system snapshot
(M320 router, T320 router, and T640 router only) Abort a unified in-service software upgrade (ISSU).	request system software abort
Install software bundles or packages onto the router.	request system software add
Remove software bundles or packages from the router.	request system software delete
(J Series routers only) Delete the backup Junos OS file (if it exists) to free up compact flash drive space.	request system software delete-backup
(M320 router, T320 router, and T640 router only) Perform a unified ISSU.	request system software in-service-upgrade
MX Series 3D Universal Edge Routers	request system software in-service-upgrade (MX Series 3D Universal Edge Routers)
Roll back to a previously installed version.	request system software rollback
Check candidate software compatibility against the current configuration.	request system software validate
Free storage space on the router by rotating log files and deleting unnecessary files.	request system storage cleanup
Restart a Junos OS process.	restart
Display the contents of the ARP table.	show arp

Table 121: System Software Operational Mode Commands (*continued*)

Task	Command
Display the current running system configuration.	show configuration
Display the address bindings in the client table on the extended DHCP local server.	show dhcp server binding
Display extended DHCP local server statistics.	show dhcp server statistics
Display the address bindings in the client table on the extended DHCPv6 local server.	show dhcpv6 server binding
Display extended DHCPv6 local server statistics.	show dhcpv6 server statistics
Display Domain Name System (DNS) hostname information.	show host
Display AAA statistics.	show network-access aaa statistics
Display information about AAA subscribers.	show network-access aaa subscribers
Display information about AAA subscriber sessions.	show network-access aaa subscribers session-id
Display state information for address-assignment pools.	show network-access address-assignment pool
Display information for domain maps.	show network-access domain-map
Display Network Time Protocol (NTP) peers.	show ntp associations
Display variables returned by NTP peers.	show ntp status
Display Information about static subscriber sessions.	show static-subscribers sessions
Display information about active subscribers	show subscribers
Show system alarms.	show system alarms
Display state and checksum values for files in a file system.	show system audit
(J Series routers only) Display autoinstallation status information.	show system autoinstallation status
Display boot messages.	show system boot-messages
Display system memory and buffer usage information.	show system buffers

Table 121: System Software Operational Mode Commands (*continued*)

Task	Command
Display information about a pending commit operation.	show system commit
Display directory and number of files queued for archival transfer.	show system configuration archival
Display information about the rescue configuration.	show system configuration rescue
Display information about active IP sockets on the Routing Engine.	show system connections
Display directory usage information.	show system directory-usage
(J Series routers only) Display system firmware information.	show system firmware
Display a list of installed licenses.	show system license
Display dynamic hostname to IP address mappings.	show system name-resolution
Display software processes running on the router.	show system processes
Display statistics about queues on interfaces.	show system queues
Display any pending system reboots or halts.	show system reboot
View or compare previous configurations.	show system rollback
(J Series routers only) Display client binding information.	show system services dhcp binding
(J Series routers only) Display DHCP client-detected conflicts for IP addresses.	show system services dhcp conflict
(J Series routers only) Display global configuration settings for a DHCP server.	show system services dhcp global
(J Series routers only) Display IP address pools defined for a DHCP server.	show system services dhcp pool
(J Series routers only) Display statistics associated with a DHCP server.	show system services dhcp statistics
Display information about a Session and Resource Control (SRC) client.	show system services service-deployment

Table 121: System Software Operational Mode Commands (*continued*)

Task	Command
Display information about the backup software that located in the /altroot and /altconfig file systems.	show system snapshot
Display Junos OS extensions.	show system software
Display system-wide protocol-related statistics.	show system statistics
Display system-wide Address Resolution Protocol (ARP) statistics.	show system statistics arp
Display system-wide Connectionless Network Service (CLNS) statistics.	show system statistics clns
Display system-wide End System-to-Intermediate System (ES-IS) statistics.	show system statistics esis
Display system-wide Internet Control Message Protocol (ICMP) statistics.	show system statistics icmp
Display system-wide ICMP version 6 statistics.	show system statistics icmp6
Display system-wide Internet Group Management Protocol (IGMP) statistics.	show system statistics igmp
Display system-wide IPv4 statistics.	show system statistics ip
Display system-wide IPv6 statistics.	show system statistics ip6
Display system-wide Multiprotocol Label Switching (MPLS) statistics.	show system statistics mpls
Display system-wide Reliable Datagram Protocol (RDP) statistics.	show system statistics rdp
Display system-wide Transmission Control Protocol (TCP) statistics.	show system statistics tcp
Display system-wide Trivial Network Protocol (TNP) statistics.	show system statistics tnp
Display system-wide Trivial User Datagram Protocol (TUDP) statistics.	show system statistics tudp
Display system-wide User Datagram Protocol (UDP) statistics.	show system statistics udp

Table 121: System Software Operational Mode Commands (*continued*)

Task	Command
Display system-wide Virtual Private LAN Services (VPLS) statistics.	show system statistics vpls
Display statistics about the amount of free disk space in the router's file systems.	show system storage
View configurations of the primary and secondary Routing Engines.	show system switchover
Display the current time and information about how long the router, router software, and routing protocols have been running.	show system uptime
Display complete subscriber management database summary information.	show system subscriber-management summary
Display users currently logged in to the router.	show system users
Display Junos kernel memory usage.	show system virtual-memory
Display routing protocol tasks on the Routing Engine.	show task
Display I/O statistics for routing protocol tasks on the Routing Engine.	show task io
Display memory utilization for routing protocol tasks on the Routing Engine.	show task memory
Display whether or not graceful Routing Engine switchover (GRES) and nonstop active routing (NSR) are configured on the router.	show task replication
Display the hostname and version information about the software running on the router.	show version
Display the hostname and version information about the software running on the master and backup Routing Engines.	show version invoke-on
Create a UNIX-level shell.	start shell
Verify authd-lite subscriber AAA configuration.	test aaa authd-lite user
Verify DHCP subscriber AAA configuration.	test aaa dhcp user
Verify PPP subscriber AAA configuration.	test aaa ppp user
Verify the syntax of a configuration file.	test configuration



.....

NOTE: For information about the request system certificate add and show system certificate commands, see IP Security Operational Mode Commands.

.....



.....

NOTE: For information about how to configure system software parameters, see the *Junos OS System Basics Configuration Guide*.

.....

For information about related tasks performed by network operations center (NOC) personnel, see the *Junos Baseline Network Operations Guide*.

.....

clear arp

Syntax	clear arp <hostname <i>hostname</i> > <logical-system <i>logical-system-name</i> > <vpn <i>vpn</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Remove entries from the Address Resolution Protocol (ARP) table for the current CLI view. To clear entries for a specific logical system, you must first enter the set cli logical-system <i>logical-system-name</i> command, and then issue the clear arp command.
Options	<p>none—Clear all entries from the ARP table.</p> <p>hostname <i>hostname</i>—(Optional) Clear the specified host entry only.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Clear entries for the specified logical system; only available in main router context.</p> <p>vpn <i>vpn</i>—(Optional) Clear entries from the ARP table for the specified virtual private network (VPN).</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • set cli logical-system on page 549 • show arp on page 820
List of Sample Output	<p>clear arp on page 703</p> <p>clear arp logical-system ls1 on page 703</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output


```

clear arp  user@host> clear arp
           192.168.71.254    deleted
           192.168.65.46    deleted
           192.168.64.10    deleted
           10.0.12.14       deleted
           10.0.17.14       deleted

clear arp  user@host> clear arp logical-system ls1
logical-system ls1 192.168.71.254    deleted
                   192.168.65.46    deleted
                   192.168.64.10    deleted
                   10.0.12.14       deleted
                   10.0.17.14       deleted

```

clear dhcp server binding

Syntax	<pre>clear dhcp server binding <all <i>ip-address</i> <i>mac-address</i>> <interface <i>interface-name</i>> <logical-system <i>logical-system-name</i>> <routing-instance <i>routing-instance-name</i>></pre>
Release Information	Command introduced in Junos OS Release 9.0.
Description	Clear the binding state of a Dynamic Host Configuration Protocol (DHCP) client from the client table on the extended DHCP local server.
Options	<p>all—(Optional) Clear the binding state for all DHCP clients.</p> <p><i>ip-address</i>—(Optional) Clear the binding state for the DHCP client with the specified IP address.</p> <p><i>mac-address</i>—(Optional) Clear the binding state for the DHCP client with the specified MAC address.</p> <p>interface <i>interface-name</i>—(Optional) Clear the binding state for DHCP clients on the specified interface.</p> <div style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;">  <p>NOTE: This option clears all bindings whose initial login requests were received over the specified interface. Dynamic demux login requests are not received over the dynamic demux interface, but rather the underlying interface of the dynamic demux interface. To clear a specific dynamic demux interface, use the <i>ip-address</i> or <i>mac-address</i> options.</p> </div> <p>logical-system <i>logical-system-name</i>—(Optional) Clear the binding state for DHCP clients on the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Clear the binding state for DHCP clients on the specified routing instance.</p>
Required Privilege Level	view
List of Sample Output	<pre>clear dhcp server binding on page 705 clear dhcp server binding all on page 705 clear dhcp server binding interface on page 705</pre>
Output Fields	See show dhcp server binding for an explanation of output fields.

Sample Output

clear dhcp server binding The following sample output displays the address bindings in the DHCP client table on the extended DHCP local server before and after the **clear dhcp server binding** command is issued.

```
user@host> show dhcp server binding
```

```
2 clients, (0 bound, 0 selecting, 0 renewing, 0 rebinding)
```

IP address	Hardware address	Type	Lease expires at
100.20.32.1	90:00:00:01:00:01	active	2007-01-17 11:38:47 PST
100.20.32.3	90:00:00:02:00:01	active	2007-01-17 11:38:41 PST

```
user@host> clear dhcp server binding 10.20.32.1
```

```
user@host> show dhcp server binding
```

```
1 clients, (0 bound, 0 selecting, 0 renewing, 0 rebinding)
```

IP address	Hardware address	Type	Lease expires at
100.20.32.3	90:00:00:02:00:01	active	2007-01-17 11:38:41 PST

clear dhcp server binding all user@host> clear dhcp server binding all

clear dhcp server binding interface user@host> clear dhcp server binding interface fe-0/0/2

clear dhcp server statistics

Syntax	clear dhcp server statistics <interface <i>interface-name</i> > <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.0.
Description	Clear all extended Dynamic Host Configuration Protocol (DHCP) local server statistics.
Options	<p>interface <i>interface-name</i>—(Optional) Clear the statistics for DHCP clients on the specified interface. If you do not specify an interface, statistics are cleared for the default interface.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Clear the statistics for DHCP clients on the specified logical system. If you do not specify a logical system, statistics are cleared for the default logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Clear the statistics for DHCP clients on the specified routing instance. If you do not specify a routing instance, statistics are cleared for the default routing instance.</p>
Required Privilege Level	view
List of Sample Output	clear dhcp server statistics on page 706
Output Fields	See show dhcp server statistics for an explanation of output fields.

Sample Output

clear dhcp server statistics The following sample output displays the extended DHCP local server statistics before and after the **clear dhcp server statistics** command is issued.

```

user@host> show dhcp server statistics
Packets dropped:
  Total                      0

Messages received:
  BOOTREQUEST                89163
  DHCPDECLINE                 0
  DHCPDISCOVER                8110
  DHCPINFORM                  0
  DHCPRELEASE                 0
  DHCPREQUEST                 81053

Messages sent:
  BOOTREPLY                   32420
  DHCPOFFER                   8110
  DHCPACK                     8110
  DHCPNAK                     8100

user@host> clear dhcp server statistics

```

```
user@host> show dhcp server statistics
```

```
Packets dropped:
```

Total	0
-------	---

```
Messages received:
```

BOOTREQUEST	0
DHCPDECLINE	0
DHCPDISCOVER	0
DHCPINFORM	0
DHCPRELEASE	0
DHCPREQUEST	0

```
Messages sent:
```

BOOTREPLY	0
DHCPOFFER	0
DHCPACK	0
DHCPNAK	0

clear dhcpv6 server binding

Syntax	<code>clear dhcpv6 server binding</code> <code><all <i>client-id</i> <i>ip-address</i> <i>session-id</i>></code> <code><interface <i>interface-name</i>></code> <code><logical-system <i>logical-system-name</i>></code> <code><routing-instance <i>routing-instance-name</i>></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Clear the binding state of a Dynamic Host Configuration Protocol for IPv6 (DHCPv6) client from the client table on the extended DHCPv6 local server.
Options	<p><code>all</code>—(Optional) Clear the binding state for all DHCPv6 clients.</p> <p><code>client-id</code>—(Optional) Clear the binding state for the DHCPv6 client with the specified client ID (option 1).</p> <p><code>ip-address</code>—(Optional) Clear the binding state for the DHCPv6 client with the specified address.</p> <p><code>session-id</code>—(Optional) Clear the binding state for the DHCPv6 client with the specified subscriber session ID.</p> <p><code>interface <i>interface-name</i></code>—(Optional) Clear the binding state for DHCPv6 clients on the specified interface.</p> <p><code>logical-system <i>logical-system-name</i></code>—(Optional) Clear the binding state for DHCPv6 clients on the specified logical system.</p> <p><code>routing-instance <i>routing-instance-name</i></code>—(Optional) Clear the binding state for DHCPv6 clients on the specified routing instance.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show dhcpv6 server binding on page 835
List of Sample Output	clear dhcpv6 server binding on page 708 clear dhcpv6 server binding all on page 708 clear dhcpv6 server binding prefix on page 709
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>clear dhcpv6 server binding</code>	<code>user@host> clear dhcpv6 server binding</code>
<code>clear dhcpv6 server binding all</code>	<code>user@host> clear dhcpv6 server binding all</code>

```
clear dhcpv6 server binding prefix user@host> clear dhcpv6 server binding 14/0x00010001/0x02b3be8f/0x00109400/0x0005
```

clear dhcpv6 server statistics

Syntax	<code>clear dhcpv6 server statistics</code> <code><interface <i>interface-name</i>></code> <code><logical-system <i>logical-system-name</i>></code> <code><routing-instance <i>routing-instance-name</i>></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Clear all extended Dynamic Host Configuration Protocol for IPv6 (DHCPv6) local server statistics.
Options	<p><code>interface <i>interface-name</i></code>—(Optional) Clear the statistics for DHCPv6 clients on the specified interface. If you do not specify an interface, statistics are cleared for the default interface.</p> <p><code>logical-system <i>logical-system-name</i></code>—(Optional) Clear the statistics for DHCPv6 clients on the specified logical system. If you do not specify a logical system, statistics are cleared for the default logical system.</p> <p><code>routing-instance <i>routing-instance-name</i></code>—(Optional) Clear the statistics for DHCPv6 clients on the specified routing instance. If you do not specify a routing instance, statistics are cleared for the default routing instance.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show dhcpv6 server statistics on page 839
List of Sample Output	clear dhcpv6 server statistics on page 710
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>clear dhcpv6 server statistics</code>	<code>user@host> clear dhcpv6 server statistics</code>
---	---

clear network-access aaa statistics

Syntax	clear network-access aaa statistics <accounting> <address-assignment (client pool <i>pool-name</i>)> <authentication> <dynamic-requests> <re-authentication>
Release Information	Command introduced in Junos OS Release 10.0.
Description	Clear AAA statistics.
Options	<p>accounting—Clear AAA accounting statistics.</p> <p>address-assignment client—Clear AAA address-assignment statistics for the client.</p> <p>address-assignment pool <i>pool-name</i>—Clear AAA address-assignment pool statistics.</p> <p>authentication—Clear AAA authentication statistics.</p> <p>dynamic-requests—Clear AAA dynamic-request statistics.</p> <p>re-authentication—Clear AAA reauthentication statistics.</p>
Required Privilege Level	maintenance
List of Sample Output	<p>clear network-access aaa statistics accounting on page 711</p> <p>clear network-access aaa statistics address-assignment pool on page 711</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear network-access user@host> clear network-access aaa statistics accounting
aaa statistics
accounting

clear network-access user@host> clear network-access aaa statistics address-assignment pool isp_1
aaa statistics
address-assignment
pool
```

clear network-access aaa subscriber

Syntax	<code>clear network-access aaa subscriber</code> <code><statistics username <i>username</i>></code> <code><username <i>username</i>></code>
Release Information	Command introduced in Junos OS Release 9.1.
Description	Clear AAA subscriber statistics and log out subscribers.
Options	<code>statistics username <i>username</i></code> —Clear AAA subscriber statistics and log out the subscriber. <code>username <i>username</i></code> —Log out the AAA subscriber.
Required Privilege Level	maintenance
List of Sample Output	<code>clear network-access aaa subscriber statistics username</code> on page 712 <code>clear network-access aaa subscriber username</code> on page 712
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear network-access  user@host> clear network-access aaa subscriber statistics username dsmith@isp5555.com
aaa subscriber
statistics username

clear network-access  user@host> clear network-access aaa subscriber username dsmith@isp5555.com
aaa subscriber
username
```


clear system commit

Syntax	clear system commit
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Clear any pending commit operation.
Options	This command has no options.
Required Privilege Level	maintenance (or the actual user who scheduled the commit)
Related Documentation	<ul style="list-style-type: none"> • show system commit on page 888
List of Sample Output	clear system commit on page 713 clear system commit (None Pending) on page 713 clear system commit (User Does Not Have Required Privilege Level) on page 713
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear system commit	user@host> clear system commit Pending commit cleared.
clear system commit (None Pending)	user@host> clear system commit No commit scheduled.
clear system commit (User Does Not Have Required Privilege Level)	user@host> clear system commit error: Permission denied

clear system reboot

Syntax	clear system reboot <both-routing-engines>
Syntax (EX Series Switch)	clear system reboot <all-members> <both-routing-engines> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	clear system reboot <both-routing-engines> <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	clear system reboot <both-routing-engines> <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (QFX Series)	clear system reboot
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Clear any pending system software reboots or halts. When issued on a TX Matrix router without any options, the default behavior clears all pending system software reboots or halts on all T640 routers connected to the TX Matrix router. When issued on a TX Matrix Plus router without any options, the default behavior clears all pending system software reboots or halts on all T1600 routers connected to the TX Matrix Plus router.
Options	none—Clear all pending system software reboots or halts. all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Clear all halt or reboot requests for all the Routing Engines in the chassis. all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, clear all halt or reboot requests for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, clear all halt or reboot requests for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router. all-members—(EX4200 switches only) (Optional) Clear all halt or reboot requests on all members of the Virtual Chassis configuration. both-routing-engines—(Systems with multiple Routing Engines) (Optional) Clear all halt or reboot requests on both Routing Engines. On a TX Matrix router, clear both Routing Engines on all chassis connected to the TX Matrix router. Likewise, on a TX Matrix Plus router, clear both Routing Engines on all chassis connected to the TX Matrix Plus router.

lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, clear all halt or reboot requests for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, clear all halt or reboot requests for a specific T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(EX4200 switches only) (Optional) Clear all halt or reboot requests on the local Virtual Chassis member.

member member-id—(EX4200 switches only) (Optional) Clear all halt or reboot requests on the specified member of the Virtual Chassis configuration. Replace *member-id* with a value from 0 through 9.

scc—(TX Matrix routers only) (Optional) Clear all halt or reboot requests for the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Clear all halt or reboot requests for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Required Privilege Level maintenance

Related Documentation

- [request system reboot on page 761](#)
- [request system reboot](#)
- [Rebooting and Halting a QFX Series Product](#)

List of Sample Output

[clear system reboot on page 716](#)
[clear system reboot \(TX Matrix Router\) on page 716](#)
[clear system reboot \(QFX Series\) on page 716](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear system reboot user@host> clear system reboot
reboot requested by root at Sat Dec 12 19:37:34 1998
[process id 17855]
Terminating...

clear system reboot user@host> clear system reboot
(TX Matrix Router) scc-re0:

No shutdown/reboot scheduled.
lcc0-re0:

No shutdown/reboot scheduled.
lcc2-re0:

No shutdown/reboot scheduled.

clear system reboot user@switch> clear system reboot
(QFX Series) No shutdown/reboot scheduled.

clear system services dhcp binding

Syntax	clear system services dhcp binding <address>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Remove obsolete IP address bindings on a Dynamic Host Configuration Protocol (DHCP) server and return them to the IP address pool.
Options	<i>address</i> —(Optional) Remove a specific IP address binding and return it to the address pool.
Required Privilege Level	view and system
Related Documentation	<ul style="list-style-type: none">• show system services dhcp binding on page 960
List of Sample Output	clear system services dhcp binding on page 717
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear system services dhcp binding	user@host> clear system services dhcp binding
---------------------------------------	---

clear system services dhcp conflict

Syntax	clear system services dhcp conflict <address>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Remove IP addresses from the Dynamic Host Configuration Protocol (DHCP) server conflict list and return them to the IP address pool.
Options	<i>address</i> —(Optional) Remove a specific IP address from the conflict list and return it to the address pool.
Required Privilege Level	view and system
Related Documentation	<ul style="list-style-type: none">• show system services dhcp conflict on page 963
List of Sample Output	clear system services dhcp conflict on page 718
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear system services dhcp conflict	user@host> clear system services dhcp conflict
--	--

clear system services dhcp statistics

Syntax	clear system services dhcp statistics
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Clear Dynamic Host Configuration Protocol (DHCP) server statistics.
Options	This command has no options.
Required Privilege Level	view and system
Related Documentation	<ul style="list-style-type: none">• show system services dhcp statistics on page 968
List of Sample Output	clear system services dhcp statistics on page 719
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear system services dhcp statistics	user@host> clear system services dhcp statistics
--	--

configure

Syntax	<code>configure</code> <code><dynamic></code> <code><exclusive></code> <code><private></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Enter configuration mode. When this command is entered without any optional keywords, everyone can make configuration changes and commit all changes made to the configuration.
Options	<p><code>none</code>—Enter configuration mode.</p> <p><code>dynamic</code>—(Optional) Configure routing policies and certain routing policy objects in a dynamic database that is not subject to the same verification required in the standard configuration database. As a result, the time it takes to commit changes to the dynamic database is much shorter than for the standard configuration database. You can then reference these policies and policy objects in routing policies you configure in the standard database.</p> <p><code>exclusive</code>—(Optional) Lock the candidate configuration for as long as you remain in configuration mode, allowing you to make changes without interference from other users. Other users can enter and exit configuration mode, but they cannot change the configuration.</p> <p><code>private</code>—(Optional) Allow multiple users to edit different parts of the configuration at the same time and to commit only their own changes, or to roll back without interfering with one another's changes. You cannot commit changes in configure private mode when another user is in configure exclusive mode.</p>
Additional Information	For more information about the different methods of entering configuration mode and the restrictions that apply, see the Junos OS System Basics Configuration Guide .
Required Privilege Level	<code>configure</code>
Related Documentation	<ul style="list-style-type: none">• show configuration on page 822
List of Sample Output	configure on page 720
Output Fields	When you enter this command, you are placed in configuration mode and the system prompt changes from <code>hostname></code> to <code>hostname#</code> .

Sample Output

```
configure  user@host> configure
```



```
Entering configuration mode  
[edit]  
user@host#
```

op

Syntax	<code>op filename</code> <code><detail></code> <code><argument-name argument-value></code> <code><key (md5 sha-256 sha1) key-value</code> <code><url url></code>
Release Information	Command introduced in Junos OS Release 7.6. Command introduced in Junos OS Release 9.0 for EX Series switches. key option introduced in Junos OS Release 10.0. url option introduced in Junos OS Release 10.0.
Description	Execute an op script stored in one of the following locations: <ul style="list-style-type: none">• On the router or switch in the <code>/var/db/scripts/op</code> directory• At a remote URL
Options	detail —(Optional) Display detailed output. argument-name argument-value —(Optional) Specify one or more arguments to the script. For each argument you include on the command line, you must specify a corresponding value for the argument. key (md5 sha-256 sha1) key-value —(Optional) With the <code><url></code> option, specify a checksum hash to verify the integrity of the script. You can include the <code><key></code> option if the checksum statement is included at the <code>[edit system scripts op file filename]</code> hierarchy level. url url —(Optional) Specify a URL where the script is located.
Additional Information	For more information about Junos op scripts, see the Junos OS Configuration and Operations Automation Guide .
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• Executing an Op Script in the Junos OS Configuration and Operations Automation Guide• Executing an Op Script from a Remote Site in the Junos OS Configuration and Operations Automation Guide• checksum• file checksum md5 on page 570• file checksum sha-256 on page 572• file checksum sha1 on page 571
List of Sample Output	op on page 723


op url on page 723

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
op    user@host> op script1 interface ge-0/2/0.0 protocol inet
op url user@host> op url https://www.juniper.net/fa/2009-04-01.01.slax key md5
      8de24d09e1d90b2581bb937d2a5ad590 interface ge-0/2/0.0 protocol inet
```

request dhcp server reconfigure

Syntax	<code>request dhcp server reconfigure (all <i>address</i> interface <i>interface-name</i> logical-system <i>logical-system-name</i> routing-instance <i>routing-instance-name</i>)</code>
Release Information	Command introduced in JUNOS Release 10.0.
Description	<p>Initiate reconfiguration processing for the specified DHCP clients if they are in the bound state. If the clients are in the reconfiguring state, this command has no effect. If the clients are in any state other than bound or reconfiguring, this command has the same effect as the clear dhcp server binding command.</p> <p>When the local server state machine starts the reconfiguration process on a bound client, the client transitions to the reconfiguring state and the local server sends a forcerenew message to the client. Because the client was in the bound state before entering the reconfiguring state, all subscriber services, such as forwarding and statistics, continue to work. An exponential back-off timer determines the interval at which the forcerenew message is sent. If the final attempt is unsuccessful, the client is returned to its original state by default. You can optionally include the clear-on-abort statement to configure the client to be cleared when reconfiguration fails.</p>
Options	<p>all—Initiate reconfiguration for all DHCP clients.</p> <p><i>address</i>—Initiate reconfiguration for DHCP client with the specified IP address or MAC address.</p> <p>interface <i>interface-name</i>—Initiate reconfiguration for all DHCP clients on this logical interface (clients whose initial login requests were received over the specified interface).</p> <div style="margin-top: 10px;">  <p>NOTE: You cannot use the interface <i>interface-name</i> option with the request dhcp server reconfigure command for DHCP passive clients (clients that are added as a result of DHCP snooped packets). For passive clients, the interface is not guaranteed to be the next-hop interface to the client, as is the case for active clients.</p> </div> <p>logical-system <i>logical-system-name</i>—Initiate reconfiguration for all DHCP clients on the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—Initiate reconfiguration reconfigured for all DHCP clients in the specified routing instance.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Configuring Extended DHCP Local Server Dynamic Client Reconfiguration

List of Sample Output [request dhcp server reconfigure on page 725](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request dhcp server    user@host> request dhcp server reconfigure interface fe-0/0/0.100
reconfigure
```

request dhcpv6 server reconfigure

Syntax	<code>request dhcpv6 server reconfigure (all address client-id interface interface-name logical-system logical-system-name routing-instance routing-instance-name session-id)</code>
Release Information	Command introduced in Junos OS Release 10.4.
Description	<p>Initiate reconfiguration processing for the specified DHCPv6 clients if they are in the bound state. If the clients are in the reconfiguring state, this command has no effect. If the clients are in any state other than bound or reconfiguring, this command has the same effect as the clear dhcpv6 server binding command.</p> <p>When the local server state machine starts the reconfiguration process on a bound client, the client transitions to the reconfigure state and the local server sends a reconfigure message to the client. Because the client was in the bound state before entering the reconfiguring state, all subscriber services, such as forwarding and statistics, continue to work. An exponential back-off timer determines the interval at which the reconfigure message is sent. If the final attempt is unsuccessful, the client is returned to its original state by default. You can optionally include the clear-on-abort statement to configure the client to be cleared when reconfiguration fails.</p>
Options	<p>all—Initiate reconfiguration for all DHCPv6 clients.</p> <p>address—Initiate reconfiguration for DHCPv6 client with the specified IPv6 address.</p> <p>client-id—Initiate reconfiguration for DHCPv6 client with the specified client ID.</p> <p>interface interface-name—Initiate reconfiguration for all DHCPv6 clients on this logical interface (clients whose initial login requests were received over the specified interface).</p> <p>logical-system logical-system-name—Initiate reconfiguration for all DHCPv6 clients on the specified logical system.</p> <p>routing-instance routing-instance-name—Initiate reconfiguration reconfigured for all DHCPv6 clients in the specified routing instance.</p> <p>session-id—Initiate reconfiguration for DHCPv6 client with the specified session ID.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">Configuring Extended DHCP Local Server Dynamic Client Reconfiguration
List of Sample Output	request dhcpv6 server reconfigure on page 727
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request dhcpv6 server user@host> request dhcpv6 server reconfigure 2001::2/16
reconfigure
```

request message

Syntax	<code>request message all message "text"</code> <code>request message message "text" (terminal <i>terminal-name</i> user <i>user-name</i>)</code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display a message on the screens of all users who are logged in to the router or switch or on specific screens.
Options	<code>all</code> —Display a message on the terminal of all users who are currently logged in. <code>message "text"</code> —Message to display. <code>terminal <i>terminal-name</i></code> —Name of the terminal on which to display the message. <code>user <i>user-name</i></code> —Name of the user to whom to direct the message.
Required Privilege Level	maintenance
List of Sample Output	request message message on page 728
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request message	<code>user@host> request message message "Maintenance window in 10 minutes" user maria</code>
message	Message from user@host on tty0 at 20:27 ... Maintenance window in 10 minutes EOF

request routing-engine login

Syntax	request routing-engine login (backup master other-routing-engine re0 re1)
Syntax (Root System Domain)	request routing-engine login (backup (psd <i>n</i> rsd) master (psd <i>n</i> rsd) other-routing-engine re0 (psd <i>n</i> rsd) re1 (psd <i>n</i> rsd))
Syntax (TX Matrix Router)	request routing-engine login (backup master other-routing-engine re0 re1) <fcc <i>number</i> > <scc <i>number</i> >
Syntax (TX Matrix Plus Router)	request routing-engine login (backup master other-routing-engine re0 re1) <fcc <i>number</i> > <sfc <i>number</i> >
Syntax (MX Series Router)	request routing-engine login (backup master other-routing-engine re0 re1) <all-members> <local> <member <i>member-id</i> >
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>psd and rsd options added in Junos OS Release 9.1. These options are available from the Root System Domain (RSD). An RSD is supported on a T320 router or T640 or T1600 router that is interconnected with the JCS1200 platform.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p>
Description	On a router with two Routing Engines, specify a tty connection for login.
Options	<p>backup—Log in to the backup Routing Engine.</p> <p>fcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, log in to a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, log in to a specific T1600 router (or line-card chassis) that is connected to the TX Matrix router. Replace <i>number</i> with a value from 0 through 3.</p> <p>master—Log in to the master Routing Engine.</p> <p>other-routing-engine—Log in to the other Routing Engine.</p> <p>psd <i>n</i>—(RSD only) Log in to the specified Protected System Domain (PSD). Replace <i>n</i> with a value from 1 to 31. A PSD is accessible from a T320 router or a T640 or T1600 router that is interconnected with the JCS1200 platform. When you log in to a PSD, you are required to provide user authentication.</p> <p>re0—Log in to the Routing Engine in slot 0.</p> <p>re1—Log in to the Routing Engine in slot 1.</p> <p>all-members—(MX Series routers only) (Optional) Log in to all members of the Virtual Chassis configuration.</p>

local—(MX Series routers only) (Optional) Log in to the local Virtual Chassis member.

member *member-id*—(MX Series routers only) (Optional) Log in to the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

rsd—(RSD only) Log in to the RSD (as opposed to a PSD). A T320 router or a T640 or T1600 router that is interconnected with the JCS1200 platform can be configured as an RSD.

sfc number—(TX Matrix Plus routers only) Log in to the specified Routing Engine on the TX Matrix Plus router (or switch-fabric chassis):

- **backup**—Log in to the backup Routing Engine.
- **master**—Log in to the master Routing Engine.
- **re0**—Log in to the Routing Engine in slot 0.
- **re1**—Log in to the Routing Engine in slot 1.

Additional Information	For more information about PSDs, RSDs, and the JCS1200 platform, see the <i>Junos OS Protected System Domain Configuration Guide</i> .
Required Privilege Level	maintenance
List of Sample Output	request routing-engine login other-routing-engine on page 730 request routing-engine login psd on page 730
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request routing-engine login other-routing-engine
user@host> request routing-engine login other-routing-engine
--- JUNOS 7.2-20050217.0 built 2005-02-17 08:12:50 UTC

request routing-engine login psd
{master}
user@host> request routing-engine login psd 1 re0
€login: regress
Password:

--- JUNOS 9.1-20080321.0 built 2008-03-21 05:43:06 UTC
% cli
user@psd1>

```

request services static-subscribers login group

Syntax	request services static-subscribers login group <i>group-name</i>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Resets the state of an interface group on which static subscribers were forcibly logged out by the request services static-subscribers logout group command. This action enables static subscriber to login on the interfaces in the group.
Options	<i>group group-name</i> —Group of static subscriber interfaces on which static subscribers have been created.
Required Privilege Level	view
List of Sample Output	request services static-subscribers login group on page 731
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request services static-subscribers login group	<pre>user@host> request services static-subscribers login group boston</pre>
--	---

request services static-subscribers login interface

Syntax	request services static-subscribers login interface <i>interface-name</i>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Resets the state of an interface on which a static subscriber was forcibly logged out by the request services static-subscribers logout interface command. This action enables a static subscriber to login on the interface.
Options	interface <i>interface-name</i> —Static interface on which a static subscriber has been created.
Required Privilege Level	view
List of Sample Output	request services static-subscribers login interface on page 732
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request services static-subscribers login interface	user@host> request services static-subscribers login interface ge-2/0/1.5
--	---

request services static-subscribers logout group

Syntax	request services static-subscribers logout group <i>igroup-name</i>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Force static subscribers on the interfaces in the group to be logged out. No subscriber can subsequently log in on the interface group until the interface state is reset by a router reset or the request services static-subscribers login group command.
Options	<i>group group-name</i> —Group of static subscriber interfaces on which static subscribers have been created.
Required Privilege Level	view
List of Sample Output	request services static-subscribers logout group on page 733
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request services static-subscribers logout group	user@host> request services static-subscribers logout group boston
---	--

request services static-subscribers logout interface

Syntax	<code>request services static-subscribers logout interface <i>interface-name</i></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Force static subscriber on the interface to be logged out. No subscriber can subsequently log in on the interface until the interface state is reset by a router reset or the request services static-subscribers login interface command.
Options	interface <i>interface-name</i> —Static interface on which a static subscriber has been created.
Required Privilege Level	view
List of Sample Output	request services static-subscribers logout interface on page 734
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>request services static-subscribers logout interface</code>	<code>user@host> request services static-subscribers logout interface ge-2/0/1.5</code>
---	--

request support information

Syntax	request support information
Syntax (TX Matrix Router)	request support information <all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	request support information <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	request support information <all-members> <local> <member <i>member-id</i> >
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>show chassis alarms added to output in Junos OS Release 8.0.</p> <p>show route summary added to output in Junos OS Release 8.5.</p> <p>show krt queue added to output in Junos OS Release 8.5.</p> <p>show krt state added to output in Junos OS Release 8.5.</p> <p>show pfe statistics traffic added to output in Junos OS Release 11.2.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p>
Description	Display information about the system. Issue this command before contacting customer support, and then include the command output in your support request.
Options	<p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system information for all chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system information for all chassis for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(MX Series routers only) (Optional) Display system information for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system information for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system storage information for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display system information for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display system information for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p>

scc—(TX Matrix routers only) (Optional) Display system information for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Display system information for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information The output of this command can be lengthy. We recommend that you redirect the output to a file. This command is a combination of the following commands:

- show chassis alarms
- show chassis environment
- show chassis firmware
- show chassis fpc detail
- show chassis hardware detail
- show chassis hardware extensive
- show chassis routing-engine
- show configuration | except SECRET DATA
- show configuration chassis network-services
- show interfaces extensive
- show krt queue
- show krt state
- show pfe statistics error
- show pfe statistics traffic
- show route summary
- show system boot messages
- show system core-dumps
- show system processes extensive
- show system queues
- show system statistics
- show system storage
- show system uptime
- show system virtual memory
- show version
- show version invoke-on

Required Privilege Level maintenance


```
request support information | save goose
user@host> request support information | save goose
Wrote 1143 lines of output to 'goose'
user@host>
```

```
request support information scc (TX Matrix Router)
```

```
user@host> show system uptime
```

scc-re0:

```
Current time: 2004-09-15 00:49:06 PDT
System booted: 2004-09-14 12:53:26 PDT (11:55:40 ago)
Protocols started: 2004-09-14 12:54:19 PDT (11:54:47 ago)
Last configured: 2004-09-14 13:07:47 PDT (11:41:19 ago) by regress
12:49AM PDT up 11:56, 3 users, load averages: 0.00, 0.02, 0.03
```

1cc0-re0:

```
Current time: 2004-09-15 00:49:06 PDT
System booted: 2004-09-14 15:36:41 PDT (09:12:25 ago)
Last configured: 2004-09-14 15:38:06 PDT (09:11:00 ago) by root
12:49AM PDT up 9:12, 0 users, load averages: 0.13, 0.05, 0.02
```

1cc2-re0:

```
Current time: 2004-09-15 00:49:06 PDT
System booted: 2004-09-14 15:36:47 PDT (09:12:19 ago)
Last configured: 2004-09-14 15:38:09 PDT (09:10:57 ago) by root
12:49AM PDT up 9:12, 0 users, load averages: 0.00, 0.00, 0.00
```

```
user@host> show version
```

scc-re0:

```

Hostname: hostA
Model: TX Matrix
JUNOS Base OS boot [7.0I20040914_1707_mapte]
JUNOS Base OS Software Suite [7.0I20040907_1922_rtuplur]
JUNOS Kernel Software Suite [7.0I20040914_1707_mapte]
JUNOS Packet Forwarding Engine Support (T Series) [7.0I20040914_1707_mapte]
JUNOS Routing Software Suite [7.0I20040914_1707_mapte]
JUNOS Online Documentation [7.0I20040914_1707_mapte]
JUNOS Crypto Software Suite [7.0I20040914_1707_mapte]
JUNOS Support Tools Package [7.0-20040908.0]

```

1cc0-re0:

```
Hostname: hostB
```

```

Model: t640
JUNOS Base OS boot [7.0I20040914_1707_mapte]
JUNOS Base OS Software Suite [7.0I20040907_1922_rtuplur]
JUNOS Kernel Software Suite [7.0I20040914_1707_mapte]
JUNOS Packet Forwarding Engine Support (T-Series) [7.0I20040914_1707_mapte]
JUNOS Routing Software Suite [7.0I20040914_1707_mapte]
JUNOS Online Documentation [7.0I20040914_1707_mapte]
JUNOS Crypto Software Suite [7.0I20040914_1707_mapte]

lcc2-re0:
-----
Hostname: dewey
Model: t640
JUNOS Base OS boot [7.0I20040914_1707_mapte]
JUNOS Base OS Software Suite [7.0I20040907_1922_rtuplur]
JUNOS Kernel Software Suite [7.0I20040914_1707_mapte]
JUNOS Packet Forwarding Engine Support (T-Series) [7.0I20040914_1707_mapte]
JUNOS Routing Software Suite [7.0I20040914_1707_mapte]
JUNOS Online Documentation [7.0I20040914_1707_mapte]
JUNOS Crypto Software Suite [7.0I20040914_1707_mapte]
...

request support information sfc (TX Matrix Plus Router)
user@host> request support information sfc 0
sfc0-re0:
-----

root@host> show system uptime no-forwarding

Current time: 2009-05-25 03:43:28 PDT
System booted: 2009-05-25 01:15:04 PDT (02:28:24 ago)
Protocols started: 2009-05-25 01:16:01 PDT (02:27:27 ago)
Last configured: 2009-05-25 03:03:42 PDT (00:39:46 ago) by regress
3:43AM up 2:28, 7 users, load averages: 0.00, 0.00, 0.00

root@host> show version detail no-forwarding

Hostname: aj
Model: txp
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
...
root@host> show system core-dumps no-forwarding

-rw----- 1 root wheel 152223744 May 25 03:10 /var/crash/vmcore.0
-rw-r--r-- 1 bdeleon field 139417 May 22 10:17
/var/tmp/aj-core-apps-config-n-gres.txt
...
root@host> show chassis alarms no-forwarding

9 alarms currently active
Alarm time          Class Description
2009-05-25 01:27:08 PDT Minor LCC 0 Minor Errors
2009-05-25 01:27:08 PDT Minor Spare SIB F13 6 Fault
...
root@host> show chassis hardware detail no-forwarding

Hardware inventory:
Item          Version Part number Serial number Description
Chassis                               JN112F007AHB TXP

```

```

Midplane      REV 05   710-022574   TS4027          SFC Midplane
FPM Display   REV 03   710-024027   DX0282          TXP FPM Display
...
root@host> show system processes extensive no-forwarding

last pid: 6639;  load averages:  0.00,  0.00,  0.00  up 0+02:28:54   03:43:28
161 processes: 5 running, 138 sleeping, 18 waiting

Mem: 236M Active, 227M Inact, 104M Wired, 392M Cache, 69M Buf, 2296M Free
Swap: 2048M Total, 2048M Free

```

```

      PID USERNAME      THR PRI NICE   SIZE   RES STATE   TIME  WCPU COMMAND
      11 root           1  171  52     0K    12K RUN    143:00 96.78% idle
     1530 root           1   96   0 38160K 24812K select   2:54  1.12% chassisd
     1343 root           1   76   0     0K    12K      0:18  0.00% bcmLINK.0
     1345 root           1   76   0     0K    12K      0:15  0.00% brq17: uhci1
uhci*
...
root@host> show pfe statistics error

```

Slot 4

SLCHIP Error statistics:

```

SLCHIP              0          1
-----
Lin XIF      :          0          0
Lin SRCTL    :          0          0
...

```

root@host>show pfe statistics traffic

```

Packet Forwarding Engine traffic statistics:
  Input  packets:          2590754          0 pps
  Output packets:          2640010          0 pps
Packet Forwarding Engine local traffic statistics:
  Local packets input      :          2064527
  Local packets output     :          2115925
  Software input control plane drops :          0
  Software input high drops :          0
  Software input medium drops :          0
  Software input low drops  :          0
  Software output drops     :          0
  Hardware input drops      :          0
Packet Forwarding Engine local protocol statistics:
  HDLC keepalives          :          0
  ATM OAM                   :          0
  Frame Relay LMI           :          0
  PPP LCP/NCP               :          0
  OSPF hello                :          20048
  OSPF3 hello               :          109
  RSVP hello                :          3485
  LDP hello                 :          7191
  BFD                       :          0
  IS-IS IIH                 :          11318
  LACP                      :          0
  ARP                       :          629
  ETHER OAM                 :          930
  Unknown                   :          13212
Packet Forwarding Engine hardware discard statistics:

```

```

Timeout : 0
Truncated key : 0
Bits to test : 0
Data error : 0
Stack underflow : 0
Stack overflow : 0
Normal discard : 18060
Extended discard : 0
Invalid interface : 0
Info cell drops : 0
Fabric drops : 0
Packet Forwarding Engine Input IPv4 Header Checksum Error and Output MTU Error
statistics:
  Input Checksum : 0
  Output MTU : 0

root@host> show chassis routing-engine no-forwarding

Routing Engine status:
Slot 0:
  Current state Master
  Election priority Master (default)
  Temperature 32 degrees C / 89 degrees F
  CPU temperature 46 degrees C / 114 degrees F
  DRAM 3327 MB
...
root@host> show chassis environment no-forwarding

Class Item Status Measurement
Temp PEM 0 OK 30 degrees C / 86 degrees F
...
root@host> show chassis firmware no-forwarding

Part Type Version
Global FPC 4
Global FPC 6
Global FPC 7
...
root@host> show system boot-messages no-forwarding
...

```

request system configuration rescue delete

Syntax	request system configuration rescue delete
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Delete an existing rescue configuration.
Options	This command has no options.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• request system configuration rescue save on page 742• request system software rollback on page 802• show system commit on page 888
List of Sample Output	request system configuration rescue delete on page 741
Output Fields	This command produces no output.

Sample Output

request system configuration rescue delete	user@host> request system configuration rescue delete
--	---

request system configuration rescue save

Syntax	request system configuration rescue save
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Save the most recently committed configuration as the rescue configuration so that you can return to it at any time by using the rollback command.
Options	This command has no options.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• request system software delete on page 781• request system software rollback on page 802• show system commit on page 888
List of Sample Output	request system configuration rescue save on page 742
Output Fields	This command produces no output.

Sample Output

request system configuration rescue save	user@host> request system configuration rescue save
--	---

request system firmware

Syntax	request system firmware (<i>upgrade</i> <i>downgrade</i>) (<i>fpc</i> < <i>slot slot-number</i> > <i>pic</i> < <i>assembly-id assembly-id</i> > < <i>fpc-slot fpc-slot-number</i> > < <i>partnumber partnumber</i> > < <i>pic-slot pic-slot-number</i> > < <i>tag tag</i> >)
Release Information	Command introduced in Junos OS Release 7.4.
Description	(J Series routers only) Upgrade or downgrade firmware on a Physical Interface Modules (PIM).
Options	<p><i>fpc</i>—Flexible PIM concentrator (FPC).</p> <p><i>slot slot-number</i>—(Optional) Location of the FPC to upgrade or downgrade.</p> <p><i>pic</i>—Physical interface card (PIC).</p> <p><i>assembly-id assembly-id</i>—(Optional) Component assembly identifier.</p> <p><i>fpc-slot fpc-slot-number</i>—(Optional) Physical location of the PIC to upgrade or downgrade.</p> <p><i>partnumber partnumber</i>—(Optional) Part number of the component to upgrade or downgrade.</p> <p><i>pic-slot pic-slot-number</i>—(Optional) Location of the PIC to upgrade or downgrade.</p> <p><i>tag tag</i>—(Optional) Firmware release number.</p>
Required Privilege Level	maintenance
List of Sample Output	request system firmware upgrade on page 743
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system  user@host> request system configuration firmware upgrade fpc
firmware upgrade
```

request system halt

Syntax	request system halt <at <i>time</i> > <both-routing-engines> <other-routing-engine> <in <i>minutes</i> > <media (compact-flash disk removable-compact-flash usb)> <message " <i>text</i> ">
Syntax (EX Series Switch)	request system halt <all-members> <at <i>time</i> > <both-routing-engines> <in <i>minutes</i> > <local> <media (external internal)> <member <i>member-id</i> > <message " <i>text</i> "> <other-routing-engine> <slice <i>slice</i> >
Syntax (TX Matrix Router)	request system halt <all-lcc lcc <i>number</i> scc> <at <i>time</i> > <both-routing-engines> <other-routing-engine> <in <i>minutes</i> > <media (compact-flash disk)> <message " <i>text</i> ">
Syntax (TX Matrix Plus Router)	request system halt <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <at <i>time</i> > <both-routing-engines> <other-routing-engine> <in <i>minutes</i> > <media (compact-flash disk)> <message " <i>text</i> ">
Syntax (MX Series Router)	request system halt <all-members> <at <i>time</i> > <both-routing-engines> <in <i>minutes</i> > <local> <media (external internal)> <member <i>member-id</i> > <message " <i>text</i> "> <other-routing-engine>
Syntax (QFX Series)	request system halt <at <i>time</i> >


```
<in minutes>
<media >
<message "text">
```

Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>other-routing-engine option introduced in Junos OS Release 8.0.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Stop the router or switch software.
Options	<p>none—Stop the router or switch software immediately.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Halt all chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, halt all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, halt all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Halt all members of the Virtual Chassis configuration.</p> <p>at <i>time</i> —(Optional) Time at which to stop the software, specified in one of the following ways:</p> <ul style="list-style-type: none"> • now—Stop the software immediately. This is the default. • +<i>minutes</i>—Number of minutes from now to stop the software. • <i>yymmddhhmm</i>—Absolute time at which to stop the software, specified as year, month, day, hour, and minute. • <i>hh:mm</i>—Absolute time on the current day at which to stop the software. <p>both-routing-engines—(Optional) Halt both Routing Engines at the same time.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, halt a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, halt a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches and MX Series routers only) (Optional) Halt the local Virtual Chassis member.</p> <p>in <i>minutes</i>—(Optional) Number of minutes from now to stop the software. This option is an alias for the at +<i>minutes</i> option.</p> <p>media (compact-flash disk removable-compact-flash usb)—(Optional) Boot medium for next boot. (The options removable-compact-flash and usb pertain to J Series routers only.)</p>

media (external | internal)—(EX Series switches and MX Series routers only) (Optional)

Halt the boot media:

- **external**—Halt the external mass storage device.
- **internal**—Halt the internal flash device.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Halt the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

message "*text*"—(Optional) Message to display to all system users before stopping the software.

other-routing-engine—(Optional) Halt the other Routing Engine from which the command is issued. For example, if you issue the command from the master Routing Engine, the backup Routing Engine is halted. Similarly, if you issue the command from the backup Routing Engine, the master Routing Engine is halted.

scc—(TX Matrix routers only) (Optional) Halt the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Halt the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

slice *slice*—(EX Series switches only) (Optional) Halt a partition on the boot media. This option has the following suboptions:

- 1—Halt partition 1.
- 2—Halt partition 2.
- **alternate**—Reboot from the alternate partition.

Additional Information On the M7i router, the **request system halt** command does not immediately power down the Packet Forwarding Engine. The power-down process can take as long as 5 minutes.

On a TX Matrix or TX Matrix Plus router, if you issue the **request system halt** command on the master Routing Engine, all the master Routing Engines connected to the routing matrix are halted. If you issue this command on the backup Routing Engine, all the backup Routing Engines connected to the routing matrix are halted. If you issue the **request system halt both-routing-engines** command on the TX Matrix or TX Matrix Plus router, all the Routing Engines on the routing matrix are halted.



NOTE: If you have a router or switch with two Routing Engines and you want to shut the power off to the router or switch or remove a Routing Engine, you must first halt the backup Routing Engine (if it has been upgraded), then halt the master Routing Engine. To halt a Routing Engine, issue the **request system halt** command. You can also halt both Routing Engines at the same time by issuing the **request system halt both-routing-engines** command.

Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• clear system reboot on page 714• Rebooting and Halting a QFX Series Product
List of Sample Output	request system halt on page 748 request system halt (in 2 Hours) on page 748 request system halt (Immediately) on page 748 request system halt (at 1:20 AM) on page 748
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system halt	<pre>user@host> request system halt Halt the system ? [yes,no] (no) yes *** FINAL System shutdown message from root@section2 *** System going down IMMEDIATELY Terminated ... syncing disks... 11 8 done The operating system has halted. Please press any key to reboot.</pre>
request system halt (in 2 Hours)	<p>The following example, which assumes that the time is 5 PM (1700), illustrates three different ways to request that the system stop 2 hours from now:</p> <pre>user@host> request system halt at +120 user@host> request system halt in 120 user@host> request system halt at 19:00</pre>
request system halt (Immediately)	<pre>user@host> request system halt at now</pre>
request system halt (at 1:20 AM)	<p>To stop the system at 1:20 AM, enter the following command. Because 1:20 AM is the next day, you must specify the absolute time.</p> <pre>user@host> request system halt at yymmdd120 request system halt at 120 Halt the system at 120? [yes,no] (no) yes</pre>

request system license add

Syntax	<code>request system license add (<i>filename</i> terminal)</code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Add a license key.
Options	<i>filename</i> —License key from a file or URL. Specify the filename or the URL where the key is located. terminal—License key from the terminal.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• Adding New Licenses
List of Sample Output	request system license add on page 749
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system license user@host> request system license add terminal
add
```

request system license delete

Syntax	<code>request system license delete <i>license-id</i></code>
Syntax (QFX Series)	<code>request system license delete <i>license-identifier</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Delete a license key. You can delete only one license at a time.
Options	<i>license-id</i> —License ID that uniquely identifies a license key. <i>license-identification</i> —(QFX Series) License ID that uniquely identifies a license key.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">Deleting a License
List of Sample Output	request system license delete on page 750
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system license delete  user@host> request system license delete G03000002223
```

request system license save

Syntax	<code>request system license save (<i>filename</i> terminal)</code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Save installed license keys to a file or URL.
Options	<i>filename</i> —License key from a file or URL. Specify the filename or the URL where the key is located. terminal—License key from the terminal.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• Saving License Keys
List of Sample Output	request system license save on page 751
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system license save  user@host> request system license save ftp://user@host/license.conf
```

request system logout

Syntax	<code>request system logout (pid <i>pid</i> terminal <i>terminal</i> user <i>username</i>) <all></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Log out users from the router or switch and the configuration database. If a user held the configure exclusive lock, this command clears the exclusive lock.
Options	<p><code>all</code>—(Optional) Log out all sessions owned by a particular PID, terminal session, or user. (On a TX Matrix or TX Matrix Plus router, this command is broadcast to all chassis.)</p> <p><code>pid <i>pid</i></code>—Log out the user session using the specified management process identifier (PID). The PID type must be management process.</p> <p><code>terminal <i>terminal</i></code>—Log out the user for the specified terminal session.</p> <p><code>user <i>username</i></code>—Log out the specified user.</p>
Required Privilege Level	configure
Related Documentation	<ul style="list-style-type: none">• Junos OS System Basics Configuration Guide
List of Sample Output	request system logout on page 752
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system logout	<pre>user@host> request system logout user tammy all Connection closed by foreign host.</pre>
------------------------------	--

request system partition abort

Syntax	request system partition abort
Syntax (TX Matrix Router)	request system partition abort <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	request system partition abort <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	request system partition abort <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Terminate a previously scheduled storage media partition operation. If the command is issued between the time of a partition request and a reboot, the partition request is aborted and the storage media is not affected.
Options	<p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Abort a previously scheduled partition operation for all chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, abort a previously scheduled partition operation on all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, abort a previously scheduled partition operation on all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(MX Series routers only) (Optional) Abort a previously scheduled partition operation for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix Plus router, abort a previously scheduled partition operation on a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, abort a previously scheduled partition operation on a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Abort a previously scheduled partition operation for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Abort a previously scheduled partition operation for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) (Optional) Abort a previously scheduled partition operation on the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Abort a previously scheduled partition operation on the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Required Privilege Level maintenance

Related Documentation

- [request system partition hard-disk on page 755](#)

List of Sample Output [request system partition abort on page 754](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system partition abort	user@host> request partition abort The hard disk is no longer scheduled to be partitioned.
---------------------------------------	---

request system partition hard-disk

Syntax	request system partition hard-disk
Syntax (TX Matrix Router)	request system partition hard-disk <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	request system partition hard-disk <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	request system partition hard-disk <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Set up the hard disk for partitioning. After this command is issued, the hard disk is partitioned the next time the system is rebooted. When the hard disk is partitioned, the contents of /altroot and /altconfig are saved and restored. All other data on the hard disk is at risk of being lost.
Options	<p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Schedule a partition of the hard disk for all routers in the chassis at its next reboot.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, schedule a partition of the hard disk on all T640 routers (or line-card chassis) connected to the TX Matrix router at their next reboot. On a TX Matrix Plus router, schedule a partition of the hard disk on all T1600 routers (or line-card connected to the TX Matrix Plus router).</p> <p>all-members—(MX Series routers only) (Optional) Schedule a partition of the hard disk for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix Plus router, schedule a partition of the hard disk on a specific T640 router connected to the TX Matrix router. On a TX Matrix Plus router, schedule a partition of the hard disk on a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Schedule a partition of the hard disk for the local member of the Virtual Chassis.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Schedule a partition of the hard disk for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) (Optional) Schedule a partition of the hard disk on the T640 router connected to the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Schedule a partition of the hard disk on the T1600 router connected to the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information To immediately partition the hard disk, use the **request system reboot** command. To cancel the partition request, use the **request system partition abort** command.

Required Privilege Level maintenance

Related Documentation

- [request system partition abort on page 753](#)

List of Sample Output [request system partition hard-disk on page 756](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system user@host> request partition hard-disk
partition hard-disk
```

request system power-off

Syntax	request system power-off <both-routing-engines> <other-routing-engine> <at <i>time</i> > <in <i>minutes</i> > <media (compact-flash disk removable-compact-flash usb)> <message " <i>text</i> ">
Syntax (EX Series Switch)	request system power-off <all-members> <at <i>time</i> > <both-routing-engines> <in <i>minutes</i> > <local> <media (external internal)> <member <i>member-id</i> > <message " <i>text</i> "> <other-routing-engine> <slice <i>slice</i> >
Syntax (TX Matrix Router)	request system power-off <all-chassis all-lcc lcc <i>number</i> scc> <both-routing-engines> <other-routing-engine> <at <i>time</i> > <in <i>minutes</i> > <media (compact-flash disk)> <message " <i>text</i> ">
Syntax (TX Matrix Plus Router)	request system power-off <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <both-routing-engines> <other-routing-engine> <at <i>time</i> > <in <i>minutes</i> > <media (compact-flash disk)> <message " <i>text</i> ">
Syntax (MX Series Router)	request system power-off <all-members> <at <i>time</i> > <both-routing-engines> <in <i>minutes</i> > <local> <media (external internal)> <member <i>member-id</i> > <message " <i>text</i> "> <other-routing-engine>
Syntax (QFX Series)	request system power-off <at <i>time</i> >

<in *minutes*>
<message "*text*">

Release Information Command introduced in Junos OS Release 8.0.
Command introduced in Junos OS Release 9.0 for EX Series switches.
Command introduced in Junos OS Release 11.1 for the QFX Series.

Description Power off the software.

Options none—Power off the router or switch software immediately.

all-chassis—(Optional) (TX Matrix and TX Matrix Plus router only) Power off all Routing Engines in the chassis.

all-lcc—(Optional) (TX Matrix and TX Matrix Plus router only) On a TX Matrix router, power off all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, power off all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.

all-members—(EX4200 switches and MX Series routers only) (Optional) Power off all members of the Virtual Chassis configuration.

at *time*—(Optional) Time at which to power off the software, specified in one of the following ways:

- **now**—Power off the software immediately. This is the default.
- **+minutes**—Number of minutes from now to power off the software.
- **yymmddhhmm**—Absolute time at which to power off the software, specified as year, month, day, hour, and minute.
- **hh:mm**—Absolute time on the current day at which to power off the software.

both-routing-engines—(Optional) Power off both Routing Engines at the same time.

in *minutes*—(Optional) Number of minutes from now to power off the software. This option is an alias for the **at +minutes** option.

lcc *number*—(Optional) (TX Matrix and TX Matrix Plus router only) On a TX Matrix router, power off a T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, power off a T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Power off the local Virtual Chassis member.

media (compact-flash | disk | removable-compact-flash | usb)—(Optional) Boot medium for next boot. (The options **removable-compact-flash** and **usb** pertain to the J Series routers only.)

media (external | internal)—(EX Series switches and MX Series routers only) (Optional) Power off the boot media:

- **external**—Power off the external mass storage device.
- **internal**—Power off the internal flash device.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Power off the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

message "*text*"—(Optional) Message to display to all system users before powering off the software.

other-routing-engine—(Optional) Power off the other Routing Engine from which the command is issued. For example, if you issue the command from the master Routing Engine, the backup Routing Engine is halted. Similarly, if you issue the command from the backup Routing Engine, the master Routing Engine is halted.

scc—(Optional) (TX Matrix router only) Power off only the master Routing Engine or the backup Routing Engine on the TX Matrix router (or switch-card chassis). If you issue the command from the master Routing Engine, the master SCC is powered off. If you issue the command from the backup Routing Engine, the backup SCC is powered off.

sfc *number*—(Optional) (TX Matrix Plus router only) Power off only the master Routing Engine or the backup Routing Engine on the TX Matrix Plus router (or switch-fabric chassis). If you issue the command from the master Routing Engine, the master SFC is powered off. If you issue the command from the backup Routing Engine, the backup SFC is powered off. Replace *number* with zero.

slice *slice*—(EX-series switches only) (Optional) Power off a partition on the boot media. This option has the following suboptions:

- **1**—Power off partition 1.
- **2**—Power off partition 2.
- **alternate**—Reboot from the alternate partition.

Additional Information On a routing matrix composed of a TX Matrix router and T640 routers, if you issue the **request system power-off** command on the TX Matrix master Routing Engine, all the master Routing Engines connected to the routing matrix are powered off. If you issue this command on the backup Routing Engine, all the backup Routing Engines connected to the routing matrix are powered off.

Likewise, on a routing matrix composed of a TX Matrix Plus router and T1600 routers, if you issue the **request system power-off** command on the TX Matrix Plus master Routing Engine, all the master Routing Engines connected to the routing matrix are powered off. If you issue this command on the backup Routing Engine, all the backup Routing Engines connected to the routing matrix are powered off.

If you issue the **request system power-off both-routing-engines** command on the TX Matrix or TX Matrix Plus router, all the Routing Engines on the routing matrix are powered off.

Required Privilege Level	maintenance
List of Sample Output	request system power-off on page 760 request system power-off (QFX Series) on page 760
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system power-off	<pre>user@host> request system power-off message "This router will be powered off in 30 minutes. Please save your data and log out immediately." warning: This command will not halt the other routing-engine. If planning to switch off power, use the both-routing-engines option. Power Off the system ? [yes,no] (no) yes *** FINAL System shutdown message from remote@nutmeg *** System going down IMMEDIATELY This router will be powered off in 30 minutes. Please save your data and log out immediately. Shutdown NOW! [pid 5177]</pre>
request system power-off (QFX Series)	<pre>user@switch> request system power-off message "This switch will be powered off in 30 minutes. Please save your data and log out immediately." warning: This command will not halt the other routing-engine. If planning to switch off power, use the both-routing-engines option. Power Off the system ? [yes,no] (no) yes *** FINAL System shutdown message from remote@nutmeg *** System going down IMMEDIATELY This router will be powered off in 30 minutes. Please save your data and log out immediately. Shutdown NOW! [pid 5177]</pre>

request system reboot

Syntax	request system reboot <other-routing-engine> <at <i>time</i> > <in <i>minutes</i> > <media (compact-flash disk removable-compact-flash usb)> <message " <i>text</i> ">
Syntax (EX Series Switch)	request system reboot <all-members> <at <i>time</i> > <in <i>minutes</i> > <local> <media (external internal)> <member <i>member-id</i> > <message " <i>text</i> "> <other-routing-engine> <slice <i>slice</i> >
Syntax (TX Matrix Router)	request system reboot <all-chassis all-lcc lcc <i>number</i> scc> <other-routing-engine> <at <i>time</i> > <in <i>minutes</i> > <media (compact-flash disk)> <message " <i>text</i> ">
Syntax (TX Matrix Plus Router)	request system reboot <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <other-routing-engine> <partition (1 2 alternate)> <at <i>time</i> > <in <i>minutes</i> > <media (compact-flash disk)> <message " <i>text</i> ">
Syntax (MX Series Router)	request system reboot <all-members> <at <i>time</i> > <in <i>minutes</i> > <local> <media (external internal)> <member <i>member-id</i> > <message " <i>text</i> "> <other-routing-engine>
Release Information	Command introduced before Junos OS Release 7.4. other-routing-engine option added in Junos OS Release 8.0. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Reboot the software.

Options none—Reboot the software immediately.

all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, reboot all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, reboot all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.

all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, reboot all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, reboot all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.

all-members—(EX4200 switches and MX Series routers only) (Optional) Reboot the software on all members of the Virtual Chassis configuration.

at *time*—(Optional) Time at which to reboot the software, specified in one of the following ways:

- **now**—Stop or reboot the software immediately. This is the default.
- **+minutes**—Number of minutes from now to reboot the software.
- **yymmddhhmm**—Absolute time at which to reboot the software, specified as year, month, day, hour, and minute.
- **hh:mm**—Absolute time on the current day at which to stop the software, specified in 24-hour time.

in *minutes*—(Optional) Number of minutes from now to reboot the software. This option is an alias for the **at +minutes** option.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, the number of a T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, the number of a T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Reboot the software on the local Virtual Chassis member.

media (compact-flash | disk | removable-compact-flash | usb)—(Optional) Boot medium for next boot. (The options **removable-compact-flash** and **usb** pertain to the J Series routers only.)

media (external | internal)—(EX Series switches and MX Series routers only) (Optional) Reboot the boot media:

- **external**—Reboot the external mass storage device.
- **internal**—Reboot the internal flash device.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Reboot the software on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

message "text"—(Optional) Message to display to all system users before stopping or rebooting the software.

other-routing-engine—(Optional) Reboot the other Routing Engine from which the command is issued. For example, if you issue the command from the master Routing Engine, the backup Routing Engine is rebooted. Similarly, if you issue the command from the backup Routing Engine, the master Routing Engine is rebooted.

partition—(TX Matrix Plus routers only) (Optional) Reboot using the specified partition on the boot media. This option has the following suboptions:

- **1**—Reboot from partition 1.
- **2**—Reboot from partition 2.
- **alternate**—Reboot from the alternate partition.

scc—(TX Matrix routers only) (Optional) Reboot the Routing Engine on the TX Matrix router (or switch-card chassis). If you issue the command from **re0**, **re0** is rebooted. If you issue the command from **re1**, **re1** is rebooted.

sfc number—(TX Matrix Plus routers only) (Optional) Reboot the Routing Engine on the TX Matrix Plus router (or switch-fabric chassis). If you issue the command from **re0**, **re0** is rebooted. If you issue the command from **re1**, **re1** is rebooted. Replace *number* with **0**.

slice slice—(EX-series switches only) (Optional) Reboot a partition on the boot media. This option has the following suboptions:

- **1**—Power off partition 1.
- **2**—Power off partition 2.
- **alternate**—Reboot from the alternate partition.

Additional Information Reboot requests are recorded in the system log files, which you can view with the **show log** command (see **show log**). Also, the names of any running processes that are scheduled to be shut down are changed. You can view the process names with the **show system processes** command (see **show system processes**).

On a TX Matrix or TX Matrix Plus router, if you issue the **request system reboot** command on the master Routing Engine, all the master Routing Engines connected to the routing matrix are rebooted. If you issue this command on the backup Routing Engine, all the backup Routing Engines connected to the routing matrix are rebooted.



NOTE: To reboot a router that has two Routing Engines, reboot the backup Routing Engine (if you have upgraded it) first, and then reboot the master Routing Engine.

Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• clear system reboot on page 714• request system halt on page 744• request system reboot• Rebooting and Halting a QFX Series Product
List of Sample Output	request system reboot on page 764 request system reboot (at 2300) on page 764 request system reboot (in 2 Hours) on page 764 request system reboot (Immediately) on page 764 request system reboot (at 1:20 AM) on page 764
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system reboot	<pre>user@host> request system reboot Reboot the system ? [yes,no] (no)</pre>
request system reboot (at 2300)	<pre>user@host> request system reboot at 2300 message ?Maintenance time!? Reboot the system ? [yes,no] (no) yes shutdown: [pid 186] *** System shutdown message from root@berry.network.net *** System going down at 23:00</pre>
request system reboot (in 2 Hours)	<p>The following example, which assumes that the time is 5 PM (17:00), illustrates three different ways to request the system to reboot in two hours:</p> <pre>user@host> request system reboot at +120 user@host> request system reboot in 120 user@host> request system reboot at 19:00</pre>
request system reboot (Immediately)	<pre>user@host> request system reboot at now</pre>
request system reboot (at 1:20 AM)	<p>To reboot the system at 1:20 AM, enter the following command. Because 1:20 AM is the next day, you must specify the absolute time.</p> <pre>user@host> request system reboot at 06060120 request system reboot at 120 Reboot the system at 120? [yes,no] (no) yes</pre>

request system scripts convert

Syntax	request system scripts convert (slax-to-xslt xslt-to-slax) source <i>source/filename</i> destination <i>destination/<filename></i>
Release Information	Command introduced in Junos OS Release 8.2. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Convert an Extensible Stylesheet Language Transformations (XSLT) script to Stylesheet Language, Alternative syntax (SLAX), or convert a SLAX script to XSLT.
Options	<p><i>destination destination/<filename></i>—Specify a destination for the converted file.</p> <p>Optionally, you can specify a filename for the converted file. If you do not specify a filename, the software assigns one automatically. The default destination filename is the same as the source filename, except the file extension is altered. For example, the software converts a source file called test.xml to test.slax. The software converts a source file called test1.slax to test1.xml.</p> <p><i>slax-to-xslt</i>—Convert a SLAX script to XSLT.</p> <p><i>source source/filename</i>—Specify a source file that you want to convert.</p> <p><i>xslt-to-slax</i>—Convert an XSLT script to SLAX.</p>
Required Privilege Level	maintenance
List of Sample Output	<p>request system scripts convert slax-to-xslt on page 765</p> <p>request system scripts convert xslt-to-slax on page 765</p>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system scripts convert slax-to-xslt	<pre>user@host> request system scripts convert slax-to-xslt source /var/db/scripts/op/script1.slax destination /var/db/scripts/op conversion complete</pre>
request system scripts convert xslt-to-slax	<pre>user@host> request system scripts convert xslt-to-slax source /var/db/scripts/commit/script1.xml destination /var/db/scripts/commit conversion complete</pre>

request system snapshot

	Syntax	request system snapshot <partition>
	Syntax (EX Series Switch)	request system snapshot <all-members local member <i>member-id</i> > <media <i>type</i> > <partition> <re0 re1 routing-engine <i>routing-engine-id</i> > <slice (1 2 alternate)>
	Syntax (J Series Routers)	request system snapshot <as-primary> <config-size <i>size</i> > <data-size <i>size</i> > <factory> <media <i>type</i> > <partition> <root-size <i>size</i> > <swap-size <i>size</i> >
	Syntax (MX Series Router)	request system snapshot <all-members> <local> <member <i>member-id</i> > <partition>
	Syntax (TX Matrix Router)	request system snapshot <all-chassis all-lcc lcc <i>number</i> scc> <partition>
	Syntax (TX Matrix Plus Router)	request system snapshot <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <partition>
	Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 10.0 for EX Series switches.
	Description	<ul style="list-style-type: none">On the router, back up the currently running and active file system partitions to standby partitions that are not running. Specifically, the root file system (/) is backed up to /altroot, and /config is backed up to /altconfig. The root and /config file systems are on the router's flash drive, and the /altroot and /altconfig file systems are on the router's hard drive.On the switch, take a snapshot of the files currently used to run the switch—the complete contents of the root (/) , /config, and /var directories, which include the running Junos OS, the active configuration, and log files.



CAUTION: After you run the **request system snapshot** command, you cannot return to the previous version of the software, because the running and backup copies of the software are identical.

Options The specific options available depend upon the router or switch:

none—Back up the currently running software as follows:

- On the router, back up the currently running and active file system partitions to standby partitions that are not running. Specifically, the root file system (/) is backed up to **/altroot**, and **/config** is backed up to **/altconfig**. The root and **/config** file systems are on the router's flash drive, and the **/altroot** and **/altconfig** file systems are on the router's hard drive.
- On the switch, take a snapshot of the files currently used to run the switch—the complete contents of the root file system /, **/config** directory, and **/var** directory, which include the running Junos OS, the active configuration, and log files—and copy all these files onto an external drive. (If a USB flash drive is not connected, an error message is displayed.)

all-chassis | all-lcc | lcc number —(TX Matrix and TX Matrix Plus router only) (Optional)

- **all-chassis**—On a TX Matrix router, archive data and executable areas for all Routing Engines in the chassis. On a TX Matrix Plus router, archive data and executable areas for all Routing Engines in the chassis.
- **all-lcc**—On a TX Matrix router, archive data and executable areas for all T640 routers (or line-card chassis) connected to a TX Matrix router. On a TX Matrix Plus router, archive data and executable areas for all T1600 routers (or line-card chassis) connected to a TX Matrix Plus router.
- **lcc number**—On a TX Matrix router, archive data and executable areas for a specific T640 router (or line-card chassis) that is connected to a TX Matrix router. On a TX Matrix Plus router, archive data and executable areas for a specific T1600 router (or line-card chassis) that is connected to a TX Matrix Plus router. Replace **number** with a value from 0 through 3.

all-members | local | member member-id—(EX4200, EX4500, and EX8200 Virtual Chassis and MX Series routers only) (Optional) Specify where to place the snapshot (archive data and executable areas) in a Virtual Chassis:

- **all-members**—Create a snapshot (archive data and executable areas) for all members of the Virtual Chassis.
- **local**—Create a snapshot (archive data and executable areas) on the member of the Virtual Chassis that you are currently logged into.
- **member member-id**—Create a snapshot (archive data and executable areas) for the specified member of the Virtual Chassis.

as-primary—(J Series routers only) (Optional) Create a snapshot that can be used to replace the medium in the primary compact flash drive. This option can be used on the removable compact flash only. The option copies the default files that were loaded on the primary compact flash drive when it was shipped from the factory, plus the rescue configuration if one has been set. This option is useful if you have multiple routers and want to use the same software and configuration on each router. After a boot device is created as a primary compact flash drive, it can operate in only a primary compact flash drive slot. This option causes the boot medium to be partitioned.

config-size size—(J Series routers only) (Optional) Specify the size of the config partition, in megabytes. The default value is **10** percent of physical memory on the boot partition. The config partition is mounted on **/config**, and the configuration files are stored in this partition. This option causes the boot medium to be partitioned.

data-size size—(J Series routers only) (Optional) Specify the size of the data partition, in megabytes. The default value is **0** MB. The data partition is mounted on **/data**. This space is not used by the router, and can be used for extra storage. This option causes the boot medium to be partitioned.

factory—(J Series routers only) (Optional) Copy only default files that were loaded on the primary compact flash drive when it was shipped from the factory, plus the rescue configuration if one has been set. After the boot medium is created with the factory option, it can operate in only the primary compact flash drive.

media type—(J Series routers and EX Series switches only)(Optional) Specify the boot device the software is copied to:

- **compact-flash**—Copy software to the primary compact flash drive.
- **external**—(Switches only) Copy software to an external mass storage device, such as a USB flash drive. If the media option is not specified, this is the default. If a USB drive is not connected, the switch displays an error message.
- **internal**—(Switches only) Copy software to an internal flash drive.
- **removable-compact-flash**—Copy software to the removable compact flash drive.
- **usb**—(M320, T640, MX960, and J Series routers only) Copy software to the device connected to the USB port.

partition—(Optional) Repartition the flash drive before a snapshot occurs. If the partition table on the flash drive is corrupted, the request system snapshot command fails and reports errors. The partition option is only supported for restoring the software image from the hard drive to the flash drive.

(Routers only) You cannot issue the request system snapshot command when you enable flash disk mirroring. We recommend that you disable flash disk mirroring when you upgrade or downgrade the software. For more information, see the [Junos OS System Basics Configuration Guide](#).

re0 | re1 | routing-engine routing-engine-id—(EX8200 switch only) Specify where to place the snapshot in a redundant Routing Engine configuration.

- **re0**—Create a snapshot on Routing Engine 0.
- **re1**—Create a snapshot on Routing Engine 1.
- **routing-engine *routing-engine-id***—Create a snapshot on the specified Routing Engine.

root-size *size*—(J Series routers only) (Optional) Specify the size of the root partition, in megabytes. The default value is one-third of the physical memory minus the config, data, and swap partitions. The root partition is mounted on / and does not include configuration files. This option causes the boot medium to be partitioned.

slice (1 | 2 | *alternate*)—(EX Series switches only) (Optional) Take a snapshot of the active root partition and copy it to the selected slice on the boot media.

scc—(TX Matrix router only) (Optional) Archive data and executable areas for a TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus router only) (Optional) Archive data and executable areas for a TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

swap-size *size*—(J Series router only) (Optional) Specify the size of the swap partition, in megabytes. The default value is one-third of the physical memory on a boot medium larger than 128 MB, or 0 MB on a smaller boot device. The swap partition is used for swap files and software failure memory snapshots. Software failure memory snapshots are saved to the boot medium only if it is specified as the dump device in the system dump-device configuration hierarchy. This option causes the boot medium to be partitioned.

Additional Information

- (Routers only) Before upgrading the software on the router, when you have a known stable system, issue the **request system snapshot** command to back up the software, including the configuration, to the **/altroot** and **/altconfig** file systems. After you have upgraded the software on the router and are satisfied that the new packages are successfully installed and running, issue the **request system snapshot** command again to back up the new software to the **/altroot** and **/altconfig** file systems.
- (Routers only) You cannot issue the **request system snapshot** command when you enable flash disk mirroring. We recommend that you disable flash disk mirroring when you upgrade or downgrade the software. For more information, see the [Junos OS System Basics Configuration Guide](#).
- (TX Matrix and TX Matrix Plus router only) On a routing matrix, if you issue the **request system snapshot** command on the master Routing Engine, all the master Routing Engines connected to the routing matrix are backed up. If you issue this command on the backup Routing Engine, all the backup Routing Engines connected to the routing matrix are backed up.

Required Privilege Level maintenance

Related Documentation	<ul style="list-style-type: none"> • show system snapshot on page 971
List of Sample Output	request system snapshot (Routers) on page 770 request system snapshot (EX Series Switches) on page 770 request system snapshot (When Partition Flag Is On) on page 770 request system snapshot (When Mirroring Is Enabled) on page 770 request system snapshot all-lcc (Routing Matrix) on page 770 request system snapshot all-members (Virtual Chassis) on page 771
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system snapshot (Routers)	<pre> user@host> request system snapshot umount: /altroot: not currently mounted Copying / to /altroot.. (this may take a few minutes) umount: /altconfig: not currently mounted Copying /config to /altconfig.. (this may take a few minutes) The following filesystems were archived: / /config </pre>
request system snapshot (EX Series Switches)	<pre> user@switch> request system snapshot fpc0: ----- Verifying compatibility of destination media partitions... Running newfs (345MB) on external media / partition ... Running newfs (235MB) on external media /config partition ... The following filesystems were archived: / /config /var </pre>
request system snapshot (When Partition Flag Is On)	<pre> user@host> request system snapshot partition Performing preliminary partition checks ... Partitioning ad0 ... umount: /altroot: not currently mounted Copying / to /altroot.. (this may take a few minutes) The following filesystems were archived: / /config </pre>
request system snapshot (When Mirroring Is Enabled)	<pre> user@host> request system snapshot Snapshot is not possible since mirror-flash-on-disk is configured. </pre>
request system snapshot all-lcc (Routing Matrix)	<pre> user@host> request system snapshot all-lcc lcc0-re0: ----- Copying '/' to '/altroot' .. (this may take a few minutes) Copying '/config' to '/altconfig' .. (this may take a few minutes) The following filesystems were archived: / /config lcc2-re0: ----- Copying '/' to '/altroot' .. (this may take a few minutes) Copying '/config' to '/altconfig' .. (this may take a few minutes) The following filesystems were archived: / /config </pre>

```
request system snapshot all-members  
(Virtual Chassis) user@switch> request system snapshot all-members media internal  
fpc0:  
-----  
Copying '/dev/da0s2a' to '/dev/da0s1a' .. (this may take a few minutes)  
The following filesystems were archived: /  
  
fpc1:  
-----  
Copying '/dev/da0s2a' to '/dev/da0s1a' .. (this may take a few minutes)  
The following filesystems were archived: /  
  
fpc2:  
-----  
Copying '/dev/da0s2a' to '/dev/da0s1a' .. (this may take a few minutes)  
The following filesystems were archived: /  
  
fpc3:  
-----  
Copying '/dev/da0s2a' to '/dev/da0s1a' .. (this may take a few minutes)  
The following filesystems were archived: /  
  
fpc4:  
-----  
Copying '/dev/da0s2a' to '/dev/da0s1a' .. (this may take a few minutes)  
The following filesystems were archived: /  
  
fpc5:  
-----  
Copying '/dev/da0s2a' to '/dev/da0s1a' .. (this may take a few minutes)  
The following filesystems were archived: /
```

request system software abort

Syntax	request system software abort in-service-upgrade
Release Information	Command introduced in JUNOS Release 9.0. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Abort a unified in-service software upgrade (ISSU). The unified ISSU must be in progress and you must issue this command from a router session other than the one on which you issued the request system in-service-upgrade command that launched the unified ISSU.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • request system software in-service-upgrade on page 785 • show chassis in-service-upgrade on page 468
List of Sample Output	request system software abort (New Router Session) on page 772 request system software in-service-upgrade (Unified ISSU Session) on page 772 request system software abort (New Router Session) on page 773 request system software in-service-upgrade (Unified ISSU Session) on page 773
Output Fields	When you enter the request system software abort command on a new router session, you are provided feedback on the status of your request in the router session on which you issued the request system software in-service-upgrade command.

Sample Output

request system software abort (New Router Session)	user@host> request system software abort
request system software in-service-upgrade (Unified ISSU Session)	<pre> user@host> request system software in-service-upgrade /var/tmp/jinstall-9.0-20080117.0-domestic-signed.tgz ISSU: Preparing Backup RE Pushing bundle to re1 Checking compatibility with configuration Initializing... Using jbase-9.0-20080116.2 Verified manifest signed by PackageProduction_9_0_0 Using /var/tmp/jinstall-9.0-20080117.0-domestic-signed.tgz Verified jinstall-9.0-20080117.0-domestic.tgz signed by PackageProduction_9_0_0 Using jinstall-9.0-20080117.0-domestic.tgz Using jbundle-9.0-20080117.0-domestic.tgz Checking jbundle requirements on / Using jbase-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0 Using jkernel-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0 Using jcrypto-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0 Using jpfe-9.0-20080117.0.tgz Using jdocs-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0 Using jroute-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0 </pre>

```

Hardware Database regeneration succeeded Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
Installing package '/var/tmp/jinstall-9.0-20080117.0-domestic-signed.tgz'
...
Verified jinstall-9.0-20080117.0-domestic.tgz signed by PackageProduction_9_0_0
Adding jinstall...
Verified manifest signed by PackageProduction_9_0_0

WARNING: This package will load JUNOS 9.0-20080117.0 software.
WARNING: It will save JUNOS configuration files, and SSH keys
WARNING: (if configured), but erase all other files and information
WARNING: stored on this machine. It will attempt to preserve dumps
WARNING: and log files, but this can not be guaranteed. This is the
WARNING: pre-installation stage and all the software is loaded when
WARNING: you reboot the system.

Saving the config files ...
NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Installing the bootstrap installer ...

WARNING: A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING: 'request system reboot' command when software installation is
WARNING: complete. To abort the installation, do not reboot your system,
WARNING: instead use the 'request system software delete jinstall'
WARNING: command as soon as this operation completes.

Saving package file in
/var/sw/pkg/jinstall-9.0-20080117.0-domestic-signed.tgz ...
Saving state for rollback ...
Backup upgrade done
Rebooting Backup RE

Rebooting re1
error: ISSU Aborted! Backup RE maybe in inconsistent state, Please restore backup
RE
ISSU: IDLE

{master}
user@host>

```

Sample Output

```

request system software abort (New Router Session) user@switch> request system software abort

request system software in-service-upgrade (Unified ISSU Session) user@host> request system software in-service-upgrade
/var/tmp/jinstall-9.0-20080117.0-domestic-signed.tgz
ISSU: Preparing Backup RE
Pushing bundle to re1
Checking compatibility with configuration Initializing...
Using jbase-9.0-20080116.2
Verified manifest signed by PackageProduction_9_0_0 Using
/var/tmp/jinstall-9.0-20080117.0-domestic-signed.tgz
Verified jinstall-9.0-20080117.0-domestic.tgz signed by PackageProduction_9_0_0
Using jinstall-9.0-20080117.0-domestic.tgz
Using jbundle-9.0-20080117.0-domestic.tgz
Checking jbundle requirements on /
Using jbase-9.0-20080117.0.tgz

```

```
Verified manifest signed by PackageProduction_9_0_0 Using
jkernel-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0
Using jcrypto-9.0-20080117.0.tgz Verified manifest signed by
PackageProduction_9_0_0 Using jpfe-9.0-20080117.0.tgz Using
jdocs-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0 Using
jroute-9.0-20080117.0.tgz Verified manifest signed by PackageProduction_9_0_0
Hardware Database regeneration succeeded Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
Installing package '/var/tmp/jinstall-9.0-20080117.0-domestic-signed.tgz'
...
Verified jinstall-9.0-20080117.0-domestic.tgz signed by PackageProduction_9_0_0
Adding jinstall...
Verified manifest signed by PackageProduction_9_0_0

WARNING:      This package will load JUNOS 9.0-20080117.0 software.
WARNING:      It will save JUNOS configuration files, and SSH keys
WARNING:      (if configured), but erase all other files and information
WARNING:      stored on this machine. It will attempt to preserve dumps
WARNING:      and log files, but this can not be guaranteed. This is the
WARNING:      pre-installation stage and all the software is loaded when
WARNING:      you reboot the system.

Saving the config files ...
NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Installing the bootstrap installer ...

WARNING:      A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING:      'request system reboot' command when software installation is
WARNING:      complete. To abort the installation, do not reboot your system,
WARNING:      instead use the 'request system software delete jinstall'
WARNING:      command as soon as this operation completes.

Saving package file in
/var/sw/pkg/jinstall-9.0-20080117.0-domestic-signed.tgz ...
Saving state for rollback ...
Backup upgrade done
Rebooting Backup RE

Rebooting re1
error: ISSU Aborted! Backup RE maybe in inconsistent state, Please restore backup
RE
ISSU: IDLE

{master}
user@host>
```

request system software add

Syntax	request system software add <i>package-name</i> <best-effort-load> <delay-restart> <force> <no-copy> <no-validate> <re0 re1> <reboot> <unlink> <validate>
Syntax (EX Series Switches)	request system software add <i>package-name</i> <best-effort-load> <delay-restart> <force> <no-copy> <no-validate> <re0 re1> <reboot> <set [<i>package-name package-name</i>]> <unlink> <validate>
Syntax (TX Matrix Router)	request system software add <i>package-name</i> <best-effort-load> <delay-restart> <force> <lcc <i>number</i> scc> <no-copy> <no-validate> <re0 re1> <reboot> <unlink> <validate>
Syntax (TX Matrix Plus Router)	request system software add <i>package-name</i> <best-effort-load> <delay-restart> <force> <lcc <i>number</i> sfc <i>number</i> > <no-copy> <no-validate> <re0 re1> <reboot> <unlink> <validate>
Syntax (MX Series Router)	request system software add <i>package-name</i> <best-effort-load> <delay-restart> <force> <member <i>member-id</i> >

	<div><div><no-copy></div><div><no-validate></div><div><re0 re1></div><div><reboot></div><div><unlink></div><div><validate></div></div>
Syntax (QFX Series)	<div>request system software add <i>package-name</i></div> <div><best-effort-load></div> <div><delay-restart></div> <div><force></div> <div><no-copy></div> <div><no-validate></div> <div><reboot></div> <div><unlink></div> <div><validate></div>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>best-effort-load and unlink options added in Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p> <p>The set [<i>package-name package-name</i>] option added in Junos OS Release 11.1 for EX Series switches.</p>
Description	Install a software package or bundle on the router or switch.
Options	<div><i>package-name</i>—Location from which the software package or bundle is to be installed.</div> <div>For example:</div> <ul style="list-style-type: none">• /var/tmp/package-name—For a software package or bundle that is being installed from a local directory on the router or switch.• protocol://hostname/pathname/package-name—For a software package or bundle that is to be downloaded and installed from a remote location. Replace protocol with one of the following:<ul style="list-style-type: none">• ftp—File Transfer Protocol. Use ftp://hostname/pathname/package-name. To specify authentication credentials, use ftp://<username>:<password>@hostname/pathname/package-name. To have the system prompt you for the password, specify prompt in place of the password. If a password is required, and you do not specify the password or prompt, an error message is displayed.• http—Hypertext Transfer Protocol. Use http://hostname/pathname/package-name. To specify authentication credentials, use http://<username>:<password>@hostname/pathname/package-name. If a password is required and you omit it, you are prompted for it.• scp—Secure copy (available only for Canada and U.S. version).

Use `scp://hostname/pathname/package-name`. To specify authentication credentials, use

`scp://<username>:<password>@hostname/pathname/package-name`.



NOTE:

- The *pathname* in the protocol is the relative path to the user's home directory on the remote system and not the root directory.
- Do not use the `scp` protocol in the `request system software add` command to download and install a software package or bundle from a remote location. The software upgrade is handled by the MGD process which does not support `scp`.
Use the file copy command to copy the software package or bundle from the remote location to the `/var/tmp` directory on the hard disk:
`file copy scp://source/package-name /var/tmp`
Then install the software package or bundle using the `request system software add` command:
`request system software add /var/tmp/package-name`
- On a J Series Services Router, when you install the software from a remote location, the package is removed at the earliest opportunity in order to make room for the installation to be completed. If you copy the software to a local directory on the router and then install the new package, use the `unlink` option to achieve the same effect and allow the installation to be completed.

`best-effort-load`—(Optional) Activate a partial load and treat parsing errors as warnings instead of errors.

`delay-restart`—(Optional) Install software package or bundle, but do not restart software processes.

`force`—(Optional) Force the addition of the software package or bundle (ignore warnings).

`lcc number`—(TX Matrix and TX Matrix Plus routers only) (Optional) In a routing matrix based on the TX Matrix router, install a software package or bundle on a T640 router (or line-card chassis) that is connected to the TX Matrix router. In a routing matrix based on the TX Matrix Plus router, install a software package or bundle on a T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

`member member-id`—(MX Series routers only) (Optional) Install a software package on the specified Virtual Chassis member. Replace *member-id* with a value of 0 or 1.

`scc`—(TX Matrix routers only) (Optional) Install a software package or bundle on a Routing Engine on a TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Install a software package or bundle on a Routing Engine on a TX Matrix Plus router (or switch-fabric chassis). Replace *number* with **0**.

no-copy—(Optional) Install a software package or bundle, but do not save copies of package or bundle files.

no-validate—(Optional) When loading a software package or bundle with a different release, suppress the default behavior of the **validate** option.

re0 | re1—(Optional) On routers that support dual or redundant Routing Engines, load a software package or bundle on the Routing Engine in slot 0 (**re0**) or Routing Engine in slot 1 (**re1**).

reboot—(Optional) After adding the software package or bundle, reboot the system.

set [package-name package-name]—(Mixed EX4200 and EX4500 Virtual Chassis only) (Optional) Install two software packages—a package for an EX4200 switch and the same release of the package for an EX4500 switch—to upgrade all member switches in a mixed EX4200 and EX4500 Virtual Chassis.

unlink—(Optional) On J Series Services Routers, this option ensures that the software package is removed at the earliest opportunity in order to make room for the installation to be completed. On M Series, T Series, and MX Series routers, use the **unlink** option to remove the software package from this directory after a successful upgrade is completed.

validate—(Optional) Validate the software package or bundle against the current configuration as a prerequisite to adding the software package or bundle. This is the default behavior when the software package or bundle being added is a different release.

Additional Information

Before upgrading the software on the router or switch, when you have a known stable system, issue the **request system snapshot** command to back up the software, including the configuration, to the **/altroot** and **/altconfig** file systems. After you have upgraded the software on the router or switch and are satisfied that the new package or bundle is successfully installed and running, issue the **request system snapshot** command again to back up the new software to the **/altroot** and **/altconfig** file systems.

After you run the **request system snapshot** command, you cannot return to the previous version of the software, because the running and backup copies of the software are identical.

If you are upgrading more than one package at the same time, delete the operating system package, **jkernel**, last. Add the operating system package, **jkernel**, first and the routing software package, **jroute**, last. If you are upgrading all packages at once, delete and add them in the following order:

```
user@host> request system software add /var/tmp/jbase
user@host> request system software add /var/tmp/jkernel
user@host> request system software add /var/tmp/jpfe
user@host> request system software add /var/tmp/jdocs
```

```
user@host> request system software add /var/tmp/jroute
user@host> request system software add /var/tmp/jcrypto
```

By default, when you issue the **request system software add *package-name*** command on a TX Matrix master Routing Engine, all the T640 master Routing Engines that are connected to it are upgraded to the same version of software. If you issue the same command on the TX Matrix backup Routing Engine, all the T640 backup Routing Engines that are connected to it are upgraded to the same version of software.

Likewise, when you issue the **request system software add *package-name*** command on a TX Matrix Plus master Routing Engine, all the T1600 master Routing Engines that are connected to it are upgraded to the same version of software. If you issue the same command on the TX Matrix Plus backup Routing Engine, all the T1600 backup Routing Engines that are connected to it are upgraded to the same version of software.

Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • request system software delete on page 781 • request system software rollback on page 802 • request system storage cleanup on page 811 • Upgrading Software
List of Sample Output	request system software add validate on page 779 request system software add (Mixed EX4200 and EX4500 Virtual Chassis) on page 780
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system software add validate user@host> request system software add validate /var/tmp/jinstall-7.2R1.7-domestic-signed.tgz
Checking compatibility with configuration
Initializing...
Using jbase-7.1R2.2
Using /var/tmp/jinstall-7.2R1.7-domestic-signed.tgz
Verified jinstall-7.2R1.7-domestic.tgz signed by PackageProduction_7_2_0
Using /var/validate/tmp/jinstall-signed/jinstall-7.2R1.7-domestic.tgz
Using /var/validate/tmp/jinstall/jbundle-7.2R1.7-domestic.tgz
Checking jbundle requirements on /
Using /var/validate/tmp/jbundle/jbase-7.2R1.7.tgz
Using /var/validate/tmp/jbundle/jkernel-7.2R1.7.tgz
Using /var/validate/tmp/jbundle/jcrypto-7.2R1.7.tgz
Using /var/validate/tmp/jbundle/jpfe-7.2R1.7.tgz
Using /var/validate/tmp/jbundle/jdocs-7.2R1.7.tgz
Using /var/validate/tmp/jbundle/jroute-7.2R1.7.tgz
Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
Validating against /config/rescue.conf.gz
mgd: commit complete
Validation succeeded
Installing package '/var/tmp/jinstall-7.2R1.7-domestic-signed.tgz' ...
Verified jinstall-7.2R1.7-domestic.tgz signed by PackageProduction_7_2_0
Adding jinstall...
```

```
WARNING: This package will load JUNOS 7.2R1.7 software.
WARNING: It will save JUNOS configuration files, and SSH keys
WARNING: (if configured), but erase all other files and information
WARNING: stored on this machine. It will attempt to preserve dumps
WARNING: and log files, but this can not be guaranteed. This is the
WARNING: pre-installation stage and all the software is loaded when
WARNING: you reboot the system.

Saving the config files ...
Installing the bootstrap installer ...

WARNING: A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING: 'request system reboot' command when software installation is
WARNING: complete. To abort the installation, do not reboot your system,
WARNING: instead use the 'request system software delete jinstall'
WARNING: command as soon as this operation completes.

Saving package file in /var/sw/pkg/jinstall-7.2R1.7-domestic-signed.tgz ...
Saving state for rollback ...
```

Sample Output

```
request system user@switch> request system software add set
software add (Mixed [/var/tmp/jinstall-ex-4200-11.1R1.1-domestic-signed.tgz
EX4200 and EX4500 /var/tmp/jinstall-ex-4500-11.1R1.1-domestic-signed.tgz]
Virtual Chassis) ...
```

request system software delete

Syntax	request system software delete <i>software-package</i> <force>
Syntax (TX Matrix Router)	request system software delete <i>software-package</i> <force> <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	request system software delete <i>software-package</i> <force> <lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Remove a software package or bundle from the router or switch.



CAUTION: Before removing a software package or bundle, make sure that you have already placed the new software package or bundle that you intend to load onto the router or switch.

Options *software-package*—Software package or bundle name. You can delete any or all of the following software bundles or packages:

- **jbase**—(Optional) Junos base software suite
- **jcrypto**—(Optional, in domestic version only) Junos security software
- **jdocs**—(Optional) Junos online documentation file
- **jkernel**—(Optional) Junos kernel software suite
- **jpfe**—(Optional) Junos Packet Forwarding Engine support
- **jroute**—(Optional) Junos routing software suite
- **junos**—(Optional) Junos base software

force—(Optional) Ignore warnings and force removal of the software.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, remove an extension or upgrade package from a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, remove an extension or upgrade package from a specific T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.

scc—(TX Matrix routers only) (Optional) Remove an extension or upgrade package from the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Remove an extension or upgrade package from the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information Before upgrading the software on the router or switch, when you have a known stable system, issue the **request system snapshot** command to back up the software, including the configuration, to the **/altroot** and **/altconfig** file systems. After you have upgraded the software on the router or switch and are satisfied that the new packages are successfully installed and running, issue the **request system snapshot** command again to back up the new software to the **/altroot** and **/altconfig** file systems. After you run the **request system snapshot** command, you cannot return to the previous version of the software, because the running and backup copies of the software are identical.

Required Privilege Level maintenance

Related Documentation

- [request system software add on page 775](#)
- [request system software rollback on page 802](#)
- [request system software validate on page 805](#)

List of Sample Output [request system software delete jdocs on page 782](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system software delete jdocs The following example displays the system software packages before and after the **jdocs** package is deleted through the **request system software delete** command:

```
user@host> show system software
Information for jbase:
```

```
Comment:
JUNOS Base OS Software Suite [7.2R1.7]
```

```
Information for jcrypto:
```

```
Comment:
JUNOS Crypto Software Suite [7.2R1.7]
```

```
Information for jdocs:
```

```
Comment:
JUNOS Online Documentation [7.2R1.7]
```

```
Information for jkernel:
```

```
Comment:
JUNOS Kernel Software Suite [7.2R1.7]

...

user@host> request system software delete jdocs
Removing package 'jdocs' ...

user@host> show system software
Information for jbase:

Comment:
JUNOS Base OS Software Suite [7.2R1.7]

Information for jcrypto:

Comment:
JUNOS Crypto Software Suite [7.2R1.7]

Information for jkernel:

Comment:
JUNOS Kernel Software Suite [7.2R1.7]

...
```

request system software delete-backup

Syntax	request system software delete-backup
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series router only) Delete the backup Junos OS file (if it exists) to free up CompactFlash card space. After running this command, you can no longer use the request system software rollback command to revert to the earlier version of the Junos OS.
Options	This command has no options.
Required Privilege Level	maintenance
List of Sample Output	request system software delete-backup on page 784
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system	user@host> request system software delete-backup
software	Delete backup system software package [yes,no] (no) yes
delete-backup	

request system software in-service-upgrade

Syntax	request system software in-service-upgrade <i>package-name</i> <no-old-master-upgrade> <reboot>
Release Information	Command introduced in Junos OS Release 9.0.
Description	Perform a unified in-service software upgrade (ISSU). A unified ISSU enables you to upgrade from one Junos OS Release to another with no disruption on the control plane and with minimal disruption of traffic. A unified ISSU is only supported by dual Routing Engine platforms. In addition, graceful Routing Engine switchover (GRES) and nonstop active routing (NSR) must be enabled.
Options	<p><i>package-name</i>—Location from which the software package or bundle is to be installed. For example:</p> <ul style="list-style-type: none"> • <i>/var/tmp/package-name</i>—For a software package or bundle that is being installed from a local directory on the router. • <i>protocol://hostname/pathname/package-name</i>—For a software package or bundle that is to be downloaded and installed from a remote location. Replace protocol with one of the following: <ul style="list-style-type: none"> • ftp—File Transfer Protocol • http—Hypertext Transfer Protocol • scp—Secure copy (available only for Canada and U.S. version) <p>no-old-master-upgrade—(Optional) When the no-old-master-upgrade option is included, after the backup Routing Engine is rebooted with the new software package and a switchover occurs to make it the new master Routing Engine, the former master (new backup) Routing Engine will not be upgraded to the new software. In this case, you must manually upgrade the former master (new backup) Routing Engine. If you do not include the no-old-master-upgrade option, the system will automatically upgrade the former master Routing Engine.</p> <p>reboot—(Optional) When the reboot option is included, the former master (new backup) Routing Engine is automatically rebooted after being upgraded to the new software. When the reboot option is not included, you must manually reboot the former master (new backup) Routing Engine using the request system reboot command.</p>
Additional Information	<p>The following conditions apply to unified ISSUs:</p> <ul style="list-style-type: none"> • Unified ISSUs are supported on M320 and T320 routers and on T640 routers only. • Unsupported PICs are restarted during a unified ISSU. For information about supported PICs, see the Junos OS High Availability Configuration Guide.

- Unsupported protocols will experience packet loss during a unified ISSU. For information about supported protocols, see the [Junos OS High Availability Configuration Guide](#).
- During a unified ISSU, you cannot bring any PICs online or offline.

For more information, see the [Junos OS High Availability Configuration Guide](#).

Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • request system software abort on page 772 • show chassis in-service-upgrade on page 468
List of Sample Output	request system software-in-service upgrade reboot on page 786
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system software-in-service upgrade reboot
{master}
user@host> request system software in-service-upgrade
/var/tmp/jinstall-9.0-20080114.2-domestic-signed.tgz reboot
ISSU: Validating Image
PIC 0/3 will be offlined (In-Service-Upgrade not supported)
Do you want to continue with these actions being taken ? [yes,no] (no) yes

ISSU: Preparing Backup RE
Pushing bundle to re1
Checking compatibility with configuration
Initializing...
Using jbase-9.0-20080114.2
Verified manifest signed by PackageProduction_9_0_0
Using /var/tmp/jinstall-9.0-20080114.2-domestic-signed.tgz
Verified jinstall-9.0-20080114.2-domestic.tgz signed by PackageProduction_9_0_0
Using jinstall-9.0-20080114.2-domestic.tgz
Using jbundle-9.0-20080114.2-domestic.tgz
Checking jbundle requirements on /
Using jbase-9.0-20080114.2.tgz
Verified manifest signed by PackageProduction_9_0_0
Using jkernel-9.0-20080114.2.tgz
Verified manifest signed by PackageProduction_9_0_0
Using jcrypto-9.0-20080114.2.tgz
Verified manifest signed by PackageProduction_9_0_0
Using jpfe-9.0-20080114.2.tgz
Using jdocs-9.0-20080114.2.tgz
Verified manifest signed by PackageProduction_9_0_0
Using jroute-9.0-20080114.2.tgz
Verified manifest signed by PackageProduction_9_0_0
Hardware Database regeneration succeeded
Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
Installing package '/var/tmp/jinstall-9.0-20080114.2-domestic-signed.tgz' ...
Verified jinstall-9.0-20080114.2-domestic.tgz signed by PackageProduction_9_0_0
Adding jinstall...
Verified manifest signed by PackageProduction_9_0_0
```

```

WARNING: This package will load JUNOS 9.0-20080114.2 software.
WARNING: It will save JUNOS configuration files, and SSH keys
WARNING: (if configured), but erase all other files and information
WARNING: stored on this machine. It will attempt to preserve dumps
WARNING: and log files, but this can not be guaranteed. This is the
WARNING: pre-installation stage and all the software is loaded when
WARNING: you reboot the system.

```

Saving the config files ...

```

NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Installing the bootstrap installer ...

```

```

WARNING: A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING: 'request system reboot' command when software installation is
WARNING: complete. To abort the installation, do not reboot your system,
WARNING: instead use the 'request system software delete jinstall'
WARNING: command as soon as this operation completes.

```

```

Saving package file in /var/sw/pkg/jinstall-9.0-20080114.2-domestic-signed.tgz
...

```

Saving state for rollback ...

```

Backup upgrade done
Rebooting Backup RE

```

Rebooting re1

```

ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot
GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU started
ISSU: Backup RE Prepare Done
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover

```

Checking In-Service-Upgrade status

Item	Status	Reason
FPC 0	Online (ISSU)	
FPC 1	Online (ISSU)	
FPC 2	Online (ISSU)	
FPC 6	Online (ISSU)	
FPC 7	Online (ISSU)	

Resolving mastership...

Complete. The other routing engine becomes the master.

ISSU: RE switchover Done

ISSU: Upgrading Old Master RE

Installing package '/var/tmp/paKEuy' ...

Verified jinstall-9.0-20080114.2-domestic.tgz signed by PackageProduction_9_0_0

Adding jinstall...

Verified manifest signed by PackageProduction_9_0_0

```

WARNING: This package will load JUNOS 9.0-20080114.2 software.
WARNING: It will save JUNOS configuration files, and SSH keys
WARNING: (if configured), but erase all other files and information
WARNING: stored on this machine. It will attempt to preserve dumps
WARNING: and log files, but this can not be guaranteed. This is the
WARNING: pre-installation stage and all the software is loaded when
WARNING: you reboot the system.

```

```
Saving the config files ...
NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Installing the bootstrap installer ...

WARNING:      A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING:      'request system reboot' command when software installation is
WARNING:      complete. To abort the installation, do not reboot your system,
WARNING:      instead use the 'request system software delete jinstall'
WARNING:      command as soon as this operation completes.

Saving package file in /var/sw/pkg/jinstall-9.0-20080114.2-domestic-signed.tgz
...
cp: /var/tmp/paKEuy is a directory (not copied).
Saving state for rollback ...
ISSU: Old Master Upgrade Done
ISSU: IDLE
Shutdown NOW!
Reboot consistency check bypassed - jinstall 9.0-20080114.2 will complete
installation upon reboot
[pid 30227]

*** FINAL System shutdown message from root@host ***

System going down IMMEDIATELY

Connection to host closed.
```

request system software in-service-upgrade (MX Series 3D Universal Edge Routers)

Syntax request system software in-service-upgrade *package-name*
 <no-copy>
 <no-old-master-upgrade>
 <reboot>
 <unlink>

Release Information Command introduced in Junos OS Release 11.2.

Description Perform a unified in-service software upgrade (unified ISSU). Unified ISSU enables you to upgrade from one Junos OS release to another with no disruption on the control plane and with minimal disruption of traffic. Unified ISSU is supported only by dual Routing Engine platforms. In addition, graceful Routing Engine switchover (GRES) and nonstop active routing (NSR) must be enabled.

Options *package-name*—Location from which the software package or bundle is to be installed. For example:

- */var/tmp/package-name*— For a software package or bundle that is being installed from a local directory on the router.
- *protocol://hostname/pathname/package-name*—For a software package or bundle that is to be downloaded and installed from a remote location. Replace *protocol* with one of the following:
 - **ftp**—File Transfer Protocol
 - **http**—Hypertext Transfer Protocol
 - **scp**—Secure copy (available only for Canada and U.S. version)

no-copy—(Optional) When the **no-copy** option is included, copies of package files are not saved on the Packet Forwarding Engine.

no-old-master-upgrade—(Optional) When the **no-old-master-upgrade** option is included, after the backup Routing Engine is rebooted with the new software package and a switchover occurs to make it the new master Routing Engine, the former master (new backup) Routing Engine is not upgraded to the new software. In this case, you must manually upgrade the former master (new backup) Routing Engine. If you do not include the **no-old-master-upgrade** option, the system automatically upgrades the former master Routing Engine.

reboot—(Optional) When the **reboot** option is included, the former master (new backup) Routing Engine is automatically rebooted after being upgraded to the new software. When the **reboot** option is not included, you must manually reboot the former master (new backup) Routing Engine using the **request system reboot** command.

unlink—(Optional) When the **unlink** option is included, the package is removed after a successful installation.

Additional Information	<p>The following conditions apply to unified ISSUs:</p> <ul style="list-style-type: none"> Unified ISSUs are supported on MX Series 3D Universal Edge Routers. Unsupported PICs are restarted during a unified ISSU. For information about supported PICs, see the Junos OS High Availability Configuration Guide. Unsupported protocols will experience packet loss during a unified ISSU. For information about supported protocols, see the Junos OS High Availability Configuration Guide. During a unified ISSU, you cannot bring any PICs online or offline. <p>For more information, see the Junos OS High Availability Configuration Guide.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request system software abort on page 772 show chassis in-service-upgrade on page 468
List of Sample Output	request system software in-service-upgrade reboot on page 790
Output Fields	When you enter this command, you are provided feedback about the status of your request.

Sample Output

```

request system software in-service-upgrade reboot
{master}
user@host> request system software in-service-upgrade
/var/tmp/jinstall-11.2B2.1-domestic-signed.tgz reboot
Chassis ISSU Check Done
ISSU: Validating Image
Checking compatibility with configuration
Initializing...
Using jbase-11.2B1.5
Verified manifest signed by PackageProduction_11_2_0
Verified jbase-11.2B1.5 signed by PackageProduction_11_2_0
Using /var/tmp/jinstall-11.2B2.1-domestic-signed.tgz
Verified jinstall-11.2B2.1-domestic.tgz signed by PackageProduction_11_2_0
Using jinstall-11.2B2.1-domestic.tgz
Using jbundle-11.2B2.1-domestic.tgz
Checking jbundle requirements on /
Using jbase-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jbase-11.2B2.1 signed by PackageProduction_11_2_0
Using /var/validate/chroot/tmp/jbundle/jboot-11.2B2.1.tgz
Using jcrypto-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jcrypto-11.2B2.1 signed by PackageProduction_11_2_0
Using jdocs-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jdocs-11.2B2.1 signed by PackageProduction_11_2_0
Using jkernel-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jkernel-11.2B2.1 signed by PackageProduction_11_2_0
Using jpfe-11.2B2.1.tgz

```

```

Using jroute-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jroute-11.2B2.1 signed by PackageProduction_11_2_0
Using jruntime-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jruntime-11.2B2.1 signed by PackageProduction_11_2_0
Using jservices-11.2B2.1.tgz
Auto-deleting old jservices-voice ...
Removing /opt/sdk/service-packages/jservices-voice ...
Removing jservices-voice-bsg-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-voice ...
Verified jservices-voice-bsg-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /var/sw/pkg ...
Creating /opt/sdk/service-packages/jservices-voice ...
Storing jservices-voice-bsg-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-voice/jservices-voice-bsg ->
/var/sw/pkg/jservices-voice-bsg-11.2B2.1.tgz...
Auto-deleting old jservices-bgf ...
Removing /opt/sdk/service-packages/jservices-bgf ...
Removing jservices-bgf-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-bgf ...
Verified jservices-bgf-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-bgf ...
Storing jservices-bgf-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-bgf/jservices-bgf-pic ->
/var/sw/pkg/jservices-bgf-pic-11.2B2.1.tgz...
Auto-deleting old jservices-aac1 ...
Removing /opt/sdk/service-packages/jservices-aac1 ...
Removing jservices-aac1-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-aac1 ...
Verified jservices-aac1-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-aac1 ...
Storing jservices-aac1-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-aac1/jservices-aac1-pic ->
/var/sw/pkg/jservices-aac1-pic-11.2B2.1.tgz...
Auto-deleting old jservices-llpdf ...
Removing /opt/sdk/service-packages/jservices-llpdf ...
Removing jservices-llpdf-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-llpdf ...
Verified jservices-llpdf-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-llpdf ...
Storing jservices-llpdf-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-llpdf/jservices-llpdf-pic ->
/var/sw/pkg/jservices-llpdf-pic-11.2B2.1.tgz...
Auto-deleting old jservices-ptsp ...
Removing /opt/sdk/service-packages/jservices-ptsp ...
Removing jservices-ptsp-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-ptsp ...
Verified jservices-ptsp-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-ptsp ...
Storing jservices-ptsp-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-ptsp/jservices-ptsp-pic ->
/var/sw/pkg/jservices-ptsp-pic-11.2B2.1.tgz...
Auto-deleting old jservices-sfw ...
Removing /opt/sdk/service-packages/jservices-sfw ...
Removing jservices-sfw-pic-11.2B1.5.tgz from /var/sw/pkg ...

```

```
Notifying mspd ...
Installing new jservices-sfw ...
Verified jservices-sfw-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-sfw ...
Storing jservices-sfw-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-sfw/jservices-sfw-pic ->
/var/sw/pkg/jservices-sfw-pic-11.2B2.1.tgz...
Auto-deleting old jservices-nat ...
Removing /opt/sdk/service-packages/jservices-nat ...
Removing jservices-nat-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-nat ...
Verified jservices-nat-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-nat ...
Storing jservices-nat-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-nat/jservices-nat-pic ->
/var/sw/pkg/jservices-nat-pic-11.2B2.1.tgz...
Auto-deleting old jservices-alg ...
Removing /opt/sdk/service-packages/jservices-alg ...
Removing jservices-alg-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-alg ...
Verified jservices-alg-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-alg ...
Storing jservices-alg-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-alg/jservices-alg-pic ->
/var/sw/pkg/jservices-alg-pic-11.2B2.1.tgz...
Auto-deleting old jservices-cpcd ...
Removing /opt/sdk/service-packages/jservices-cpcd ...
Removing jservices-cpcd-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-cpcd ...
Verified jservices-cpcd-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-cpcd ...
Storing jservices-cpcd-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-cpcd/jservices-cpcd-pic ->
/var/sw/pkg/jservices-cpcd-pic-11.2B2.1.tgz...
Auto-deleting old jservices-rpm ...
Removing /opt/sdk/service-packages/jservices-rpm ...
Removing jservices-rpm-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-rpm ...
Verified jservices-rpm-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-rpm ...
Storing jservices-rpm-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-rpm/jservices-rpm-pic ->
/var/sw/pkg/jservices-rpm-pic-11.2B2.1.tgz...
Auto-deleting old jservices-hcm ...
Removing /opt/sdk/service-packages/jservices-hcm ...
Removing jservices-hcm-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-hcm ...
Verified jservices-hcm-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-hcm ...
Storing jservices-hcm-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-hcm/jservices-hcm-pic ->
/var/sw/pkg/jservices-hcm-pic-11.2B2.1.tgz...
Auto-deleting old jservices-appid ...
Removing /opt/sdk/service-packages/jservices-appid ...
Removing jservices-appid-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
```



```

Installing new jservices-appid ...
Verified jservices-appid-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-appid ...
Storing jservices-appid-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-appid/jservices-appid-pic ->
/var/sw/pkg/jservices-appid-pic-11.2B2.1.tgz...
Auto-deleting old jservices-idp ...
Removing /opt/sdk/service-packages/jservices-idp ...
Removing jservices-idp-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-idp ...
Verified jservices-idp-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-idp ...
Storing jservices-idp-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-idp/jservices-idp-pic ->
/var/sw/pkg/jservices-idp-pic-11.2B2.1.tgz...
Using jservices-crypto-11.2B2.1.tgz
Auto-deleting old jservices-crypto-base ...
Removing /opt/sdk/service-packages/jservices-crypto-base ...
Removing jservices-crypto-base-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-crypto-base ...
Verified jservices-crypto-base-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-crypto-base ...
Storing jservices-crypto-base-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-crypto-base/jservices-crypto-base-pic
-> /var/sw/pkg/jservices-crypto-base-pic-11.2B2.1.tgz...
Auto-deleting old jservices-ssl ...
Removing /opt/sdk/service-packages/jservices-ssl ...
Removing jservices-ssl-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-ssl ...
Verified jservices-ssl-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-ssl ...
Storing jservices-ssl-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-ssl/jservices-ssl-pic ->
/var/sw/pkg/jservices-ssl-pic-11.2B2.1.tgz...
Hardware Database regeneration succeeded
Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
ISSU: Preparing Backup RE
Pushing bundle to rel
NOTICE: Validating configuration against jinstall-11.2B2.1-domestic-signed.tgz.
NOTICE: Use the 'no-validate' option to skip this if desired.
Checking compatibility with configuration
Initializing...
Using jbase-11.2B1.5
Verified manifest signed by PackageProduction_11_2_0
Verified jbase-11.2B1.5 signed by PackageProduction_11_2_0
Using /var/tmp/jinstall-11.2B2.1-domestic-signed.tgz
Verified jinstall-11.2B2.1-domestic.tgz signed by PackageProduction_11_2_0
Using jinstall-11.2B2.1-domestic.tgz
Using jbundle-11.2B2.1-domestic.tgz
Checking jbundle requirements on /
Using jbase-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jbase-11.2B2.1 signed by PackageProduction_11_2_0
Using /var/validate/chroot/tmp/jbundle/jboot-11.2B2.1.tgz
Using jcrypto-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0

```

```
Verified jcrypto-11.2B2.1 signed by PackageProduction_11_2_0
Using jdocs-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jdocs-11.2B2.1 signed by PackageProduction_11_2_0
Using jkernel-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jkernel-11.2B2.1 signed by PackageProduction_11_2_0
Using jpfe-11.2B2.1.tgz
Using jroute-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jroute-11.2B2.1 signed by PackageProduction_11_2_0
Using jruntime-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jruntime-11.2B2.1 signed by PackageProduction_11_2_0
Using jservices-11.2B2.1.tgz
Auto-deleting old jservices-voice ...
Removing /opt/sdk/service-packages/jservices-voice ...
Removing jservices-voice-bsg-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-voice ...
Verified jservices-voice-bsg-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /var/sw/pkg ...
Creating /opt/sdk/service-packages/jservices-voice ...
Storing jservices-voice-bsg-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-voice/jservices-voice-bsg ->
/var/sw/pkg/jservices-voice-bsg-11.2B2.1.tgz...
Auto-deleting old jservices-bgf ...
Removing /opt/sdk/service-packages/jservices-bgf ...
Removing jservices-bgf-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-bgf ...
Verified jservices-bgf-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-bgf ...
Storing jservices-bgf-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-bgf/jservices-bgf-pic ->
/var/sw/pkg/jservices-bgf-pic-11.2B2.1.tgz...
Auto-deleting old jservices-aacl ...
Removing /opt/sdk/service-packages/jservices-aacl ...
Removing jservices-aacl-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-aacl ...
Verified jservices-aacl-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-aacl ...
Storing jservices-aacl-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-aacl/jservices-aacl-pic ->
/var/sw/pkg/jservices-aacl-pic-11.2B2.1.tgz...
Auto-deleting old jservices-llpdf ...
Removing /opt/sdk/service-packages/jservices-llpdf ...
Removing jservices-llpdf-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-llpdf ...
Verified jservices-llpdf-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-llpdf ...
Storing jservices-llpdf-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-llpdf/jservices-llpdf-pic ->
/var/sw/pkg/jservices-llpdf-pic-11.2B2.1.tgz...
Auto-deleting old jservices-ptsp ...
Removing /opt/sdk/service-packages/jservices-ptsp ...
Removing jservices-ptsp-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-ptsp ...
```

```

Verified jservices-ptsp-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-ptsp ...
Storing jservices-ptsp-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-ptsp/jservices-ptsp-pic ->
/var/sw/pkg/jservices-ptsp-pic-11.2B2.1.tgz...
Auto-deleting old jservices-sfw ...
Removing /opt/sdk/service-packages/jservices-sfw ...
Removing jservices-sfw-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-sfw ...
Verified jservices-sfw-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-sfw ...
Storing jservices-sfw-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-sfw/jservices-sfw-pic ->
/var/sw/pkg/jservices-sfw-pic-11.2B2.1.tgz...
Auto-deleting old jservices-nat ...
Removing /opt/sdk/service-packages/jservices-nat ...
Removing jservices-nat-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-nat ...
Verified jservices-nat-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-nat ...
Storing jservices-nat-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-nat/jservices-nat-pic ->
/var/sw/pkg/jservices-nat-pic-11.2B2.1.tgz...
Auto-deleting old jservices-alg ...
Removing /opt/sdk/service-packages/jservices-alg ...
Removing jservices-alg-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-alg ...
Verified jservices-alg-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-alg ...
Storing jservices-alg-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-alg/jservices-alg-pic ->
/var/sw/pkg/jservices-alg-pic-11.2B2.1.tgz...
Auto-deleting old jservices-cpcd ...
Removing /opt/sdk/service-packages/jservices-cpcd ...
Removing jservices-cpcd-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-cpcd ...
Verified jservices-cpcd-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-cpcd ...
Storing jservices-cpcd-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-cpcd/jservices-cpcd-pic ->
/var/sw/pkg/jservices-cpcd-pic-11.2B2.1.tgz...
Auto-deleting old jservices-rpm ...
Removing /opt/sdk/service-packages/jservices-rpm ...
Removing jservices-rpm-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-rpm ...
Verified jservices-rpm-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-rpm ...
Storing jservices-rpm-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-rpm/jservices-rpm-pic ->
/var/sw/pkg/jservices-rpm-pic-11.2B2.1.tgz...
Auto-deleting old jservices-hcm ...
Removing /opt/sdk/service-packages/jservices-hcm ...
Removing jservices-hcm-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-hcm ...
Verified jservices-hcm-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0

```

```

Creating /opt/sdk/service-packages/jservices-hcm ...
Storing jservices-hcm-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-hcm/jservices-hcm-pic ->
/var/sw/pkg/jservices-hcm-pic-11.2B2.1.tgz...
Auto-deleting old jservices-appid ...
Removing /opt/sdk/service-packages/jservices-appid ...
Removing jservices-appid-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-appid ...
Verified jservices-appid-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-appid ...
Storing jservices-appid-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-appid/jservices-appid-pic ->
/var/sw/pkg/jservices-appid-pic-11.2B2.1.tgz...
Auto-deleting old jservices-idp ...
Removing /opt/sdk/service-packages/jservices-idp ...
Removing jservices-idp-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-idp ...
Verified jservices-idp-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-idp ...
Storing jservices-idp-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-idp/jservices-idp-pic ->
/var/sw/pkg/jservices-idp-pic-11.2B2.1.tgz...
Using jservices-crypto-11.2B2.1.tgz
Auto-deleting old jservices-crypto-base ...
Removing /opt/sdk/service-packages/jservices-crypto-base ...
Removing jservices-crypto-base-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-crypto-base ...
Verified jservices-crypto-base-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-crypto-base ...
Storing jservices-crypto-base-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-crypto-base/jservices-crypto-base-pic
-> /var/sw/pkg/jservices-crypto-base-pic-11.2B2.1.tgz...
Auto-deleting old jservices-ssl ...
Removing /opt/sdk/service-packages/jservices-ssl ...
Removing jservices-ssl-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-ssl ...
Verified jservices-ssl-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-ssl ...
Storing jservices-ssl-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-ssl/jservices-ssl-pic ->
/var/sw/pkg/jservices-ssl-pic-11.2B2.1.tgz...
Hardware Database regeneration succeeded
Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
Installing package '/var/tmp/jinstall-11.2B2.1-domestic-signed.tgz' ...
Verified jinstall-11.2B2.1-domestic.tgz signed by PackageProduction_11_2_0
Adding jinstall...
Verified manifest signed by PackageProduction_11_2_0

WARNING: This package will load JUNOS 11.2B2.1 software.
WARNING: It will save JUNOS configuration files, and SSH keys
WARNING: (if configured), but erase all other files and information
WARNING: stored on this machine. It will attempt to preserve dumps
WARNING: and log files, but this can not be guaranteed. This is the
WARNING: pre-installation stage and all the software is loaded when
WARNING: you reboot the system.

```

```

Saving the config files ...
NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Installing the bootstrap installer ...

WARNING:      A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING:      'request system reboot' command when software installation is
WARNING:      complete. To abort the installation, do not reboot your system,
WARNING:      instead use the 'request system software delete jinstall'
WARNING:      command as soon as this operation completes.

Saving package file in /var/sw/pkg/jinstall-11.2B2.1-domestic-signed.tgz ...
Saving state for rollback ...
Backup upgrade done
Rebooting Backup RE

Rebooting re1
ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot
GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking In-Service-Upgrade status
  Item          Status          Reason
  FPC 1         Online (ISSU)
  FPC 4         Online (ISSU)
  FPC 8         Online (ISSU)
  FPC 10        Online (ISSU)
Resolving mastership...
Complete. The other routing engine becomes the master.
ISSU: RE switchover Done
ISSU: Upgrading Old Master RE
NOTICE: Validating configuration against jinstall-11.2B2.1-domestic-signed.tgz.
NOTICE: Use the 'no-validate' option to skip this if desired.
Checking compatibility with configuration
Initializing...
Using jbase-11.2B1.5
Verified manifest signed by PackageProduction_11_2_0
Verified jbase-11.2B1.5 signed by PackageProduction_11_2_0
Using /var/tmp/jinstall-11.2B2.1-domestic-signed.tgz
Verified jinstall-11.2B2.1-domestic.tgz signed by PackageProduction_11_2_0
Using jinstall-11.2B2.1-domestic.tgz
Using jbundle-11.2B2.1-domestic.tgz
Checking jbundle requirements on /
Using jbase-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jbase-11.2B2.1 signed by PackageProduction_11_2_0
Using /var/validate/chroot/tmp/jbundle/jboot-11.2B2.1.tgz
Using jcrypto-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jcrypto-11.2B2.1 signed by PackageProduction_11_2_0
Using jdocs-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jdocs-11.2B2.1 signed by PackageProduction_11_2_0
Using jkernel-11.2B2.1.tgz

```

```
Verified manifest signed by PackageProduction_11_2_0
Verified jkernel-11.2B2.1 signed by PackageProduction_11_2_0
Using jpfe-11.2B2.1.tgz
Using jroute-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jroute-11.2B2.1 signed by PackageProduction_11_2_0
Using jruntime-11.2B2.1.tgz
Verified manifest signed by PackageProduction_11_2_0
Verified jruntime-11.2B2.1 signed by PackageProduction_11_2_0
Using jservices-11.2B2.1.tgz
Auto-deleting old jservices-voice ...
Removing /opt/sdk/service-packages/jservices-voice ...
Removing jservices-voice-bsg-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-voice ...
Verified jservices-voice-bsg-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /var/sw/pkg ...
Creating /opt/sdk/service-packages/jservices-voice ...
Storing jservices-voice-bsg-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-voice/jservices-voice-bsg ->
/var/sw/pkg/jservices-voice-bsg-11.2B2.1.tgz...
Auto-deleting old jservices-bgf ...
Removing /opt/sdk/service-packages/jservices-bgf ...
Removing jservices-bgf-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-bgf ...
Verified jservices-bgf-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-bgf ...
Storing jservices-bgf-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-bgf/jservices-bgf-pic ->
/var/sw/pkg/jservices-bgf-pic-11.2B2.1.tgz...
Auto-deleting old jservices-aac1 ...
Removing /opt/sdk/service-packages/jservices-aac1 ...
Removing jservices-aac1-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-aac1 ...
Verified jservices-aac1-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-aac1 ...
Storing jservices-aac1-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-aac1/jservices-aac1-pic ->
/var/sw/pkg/jservices-aac1-pic-11.2B2.1.tgz...
Auto-deleting old jservices-llpdf ...
Removing /opt/sdk/service-packages/jservices-llpdf ...
Removing jservices-llpdf-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-llpdf ...
Verified jservices-llpdf-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-llpdf ...
Storing jservices-llpdf-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-llpdf/jservices-llpdf-pic ->
/var/sw/pkg/jservices-llpdf-pic-11.2B2.1.tgz...
Auto-deleting old jservices-ptsp ...
Removing /opt/sdk/service-packages/jservices-ptsp ...
Removing jservices-ptsp-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-ptsp ...
Verified jservices-ptsp-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-ptsp ...
Storing jservices-ptsp-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-ptsp/jservices-ptsp-pic ->
/var/sw/pkg/jservices-ptsp-pic-11.2B2.1.tgz...
```

```
Auto-deleting old jservices-sfw ...
Removing /opt/sdk/service-packages/jservices-sfw ...
Removing jservices-sfw-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-sfw ...
Verified jservices-sfw-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-sfw ...
Storing jservices-sfw-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-sfw/jservices-sfw-pic ->
/var/sw/pkg/jservices-sfw-pic-11.2B2.1.tgz...
Auto-deleting old jservices-nat ...
Removing /opt/sdk/service-packages/jservices-nat ...
Removing jservices-nat-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-nat ...
Verified jservices-nat-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-nat ...
Storing jservices-nat-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-nat/jservices-nat-pic ->
/var/sw/pkg/jservices-nat-pic-11.2B2.1.tgz...
Auto-deleting old jservices-alg ...
Removing /opt/sdk/service-packages/jservices-alg ...
Removing jservices-alg-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-alg ...
Verified jservices-alg-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-alg ...
Storing jservices-alg-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-alg/jservices-alg-pic ->
/var/sw/pkg/jservices-alg-pic-11.2B2.1.tgz...
Auto-deleting old jservices-cpcd ...
Removing /opt/sdk/service-packages/jservices-cpcd ...
Removing jservices-cpcd-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-cpcd ...
Verified jservices-cpcd-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-cpcd ...
Storing jservices-cpcd-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-cpcd/jservices-cpcd-pic ->
/var/sw/pkg/jservices-cpcd-pic-11.2B2.1.tgz...
Auto-deleting old jservices-rpm ...
Removing /opt/sdk/service-packages/jservices-rpm ...
Removing jservices-rpm-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-rpm ...
Verified jservices-rpm-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-rpm ...
Storing jservices-rpm-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-rpm/jservices-rpm-pic ->
/var/sw/pkg/jservices-rpm-pic-11.2B2.1.tgz...
Auto-deleting old jservices-hcm ...
Removing /opt/sdk/service-packages/jservices-hcm ...
Removing jservices-hcm-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-hcm ...
Verified jservices-hcm-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-hcm ...
Storing jservices-hcm-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-hcm/jservices-hcm-pic ->
/var/sw/pkg/jservices-hcm-pic-11.2B2.1.tgz...
Auto-deleting old jservices-appid ...
```

```

Removing /opt/sdk/service-packages/jservices-appid ...
Removing jservices-appid-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-appid ...
Verified jservices-appid-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-appid ...
Storing jservices-appid-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-appid/jservices-appid-pic ->
/var/sw/pkg/jservices-appid-pic-11.2B2.1.tgz...
Auto-deleting old jservices-idp ...
Removing /opt/sdk/service-packages/jservices-idp ...
Removing jservices-idp-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-idp ...
Verified jservices-idp-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-idp ...
Storing jservices-idp-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-idp/jservices-idp-pic ->
/var/sw/pkg/jservices-idp-pic-11.2B2.1.tgz...
Using jservices-crypto-11.2B2.1.tgz
Auto-deleting old jservices-crypto-base ...
Removing /opt/sdk/service-packages/jservices-crypto-base ...
Removing jservices-crypto-base-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-crypto-base ...
Verified jservices-crypto-base-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-crypto-base ...
Storing jservices-crypto-base-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-crypto-base/jservices-crypto-base-pic
-> /var/sw/pkg/jservices-crypto-base-pic-11.2B2.1.tgz...
Auto-deleting old jservices-ssl ...
Removing /opt/sdk/service-packages/jservices-ssl ...
Removing jservices-ssl-pic-11.2B1.5.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-ssl ...
Verified jservices-ssl-pic-11.2B2.1.tgz signed by PackageProduction_11_2_0
Creating /opt/sdk/service-packages/jservices-ssl ...
Storing jservices-ssl-pic-11.2B2.1.tgz in /var/sw/pkg ...
Link: /opt/sdk/service-packages/jservices-ssl/jservices-ssl-pic ->
/var/sw/pkg/jservices-ssl-pic-11.2B2.1.tgz...
Hardware Database regeneration succeeded
Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
Installing package '/var/tmp/jinstall-11.2B2.1-domestic-signed.tgz' ...
Verified jinstall-11.2B2.1-domestic.tgz signed by PackageProduction_11_2_0
Adding jinstall...
Verified manifest signed by PackageProduction_11_2_0

WARNING: This package will load JUNOS 11.2B2.1 software.
WARNING: It will save JUNOS configuration files, and SSH keys
WARNING: (if configured), but erase all other files and information
WARNING: stored on this machine. It will attempt to preserve dumps
WARNING: and log files, but this can not be guaranteed. This is the
WARNING: pre-installation stage and all the software is loaded when
WARNING: you reboot the system.

Saving the config files ...
NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Installing the bootstrap installer ...

```



```
WARNING:    A REBOOT IS REQUIRED TO LOAD THIS SOFTWARE CORRECTLY. Use the
WARNING:    'request system reboot' command when software installation is
WARNING:    complete. To abort the installation, do not reboot your system,
WARNING:    instead use the 'request system software delete jinstall'
WARNING:    command as soon as this operation completes.
```

```
Saving package file in /var/sw/pkg/jinstall-11.2B2.1-domestic-signed.tgz ...
```

```
Saving state for rollback ...
```

```
ISSU: Old Master Upgrade Done
```

```
ISSU: IDLE
```

```
Shutdown NOW!
```

```
Reboot consistency check bypassed - jinstall 11.2B2.1 will complete installation
upon reboot
[pid 66780]
```

```
*** FINAL System shutdown message from user@host> ***
System going down IMMEDIATELY
```

request system software rollback

Syntax	request system software rollback
Syntax (EX Series Switch)	request system software rollback <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	request system software rollback <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	request system software rollback <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	request system software rollback <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Revert to the software that was loaded at the last successful request system software add command.
Options	<p>none—Revert to the set of software as of the last successful request system software add.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Attempt to roll back to the previous set of packages on all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, attempt to roll back to the previous set of packages on a T640 router (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, attempt to roll back to the previous set of packages on a T1600 router (or line-card chassis) connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches and MX Series routers only) (Optional) Attempt to roll back to the previous set of packages on the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches and MX Series routers only) (Optional) Attempt to roll back to the previous set of packages on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace <i>member-id</i> with a value from 0 through 9. For an MX Series Virtual Chassis, replace <i>member-id</i> with a value of 0 or 1.</p>

scc—(TX Matrix routers only) (Optional) Attempt to roll back to the previous set of packages on the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Attempt to roll back to the previous set of packages on the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with **0**.

Additional Information On the J Series router, you can use this command to roll back to a previous software package when the current upgrade has been successful or has failed. On M Series and T Series routers, use this command only to recover from a failed software upgrade—you cannot issue this command to return to the previously installed software after using a **jinstall** package. To return to the previously installed software, use the corresponding **jinstall** package.

A software rollback fails if any required package (or a **jbundle** package containing the required package) cannot be found in **/var/sw/pkg**.

Required Privilege Level maintenance

Related Documentation

- request system software abort on page 772
- request system software add on page 775
- request system software delete on page 781
- request system software validate on page 805
- request system configuration rescue delete on page 741
- request system configuration rescue save on page 742

List of Sample Output request system software rollback on page 804

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request system software rollback user@host> request system software rollback
Verified SHA1 checksum of ./jbase-7.2R1.7.tgz
Verified SHA1 checksum of ./jdocs-7.2R1.7.tgz
Verified SHA1 checksum of ./jroute-7.2R1.7.tgz
Installing package './jbase-7.2R1.7.tgz' ...
Available space: 35495 require: 7335
Installing package './jdocs-7.2R1.7.tgz' ...
Available space: 35339 require: 3497
Installing package './jroute-7.2R1.7.tgz' ...
Available space: 35238 require: 6976
NOTICE: uncommitted changes have been saved in
/var/db/config/juniper.conf.pre-install
Reloading /config/juniper.conf.gz ...
Activating /config/juniper.conf.gz ...
mgd: commit complete
Restarting mgd ...
Restarting aprobed ...
Restarting apsd ...
Restarting cosd ...
Restarting fsad ...
Restarting fud ...
Restarting gcdrd ...
Restarting ilmid ...
Restarting irsd ...
Restarting l2tpd ...
Restarting mib2d ...
Restarting nasd ...
Restarting pppoe ...
Restarting rdd ...
Restarting rmopd ...
Restarting rtspd ...
Restarting sampled ...
Restarting serviced ...
Restarting snmpd ...
Restarting spd ...
Restarting vrrpd ...

WARNING: cli has been replaced by an updated version:
CLI release 7.2R1.7 built by builder on 2005-04-22 02:03:44 UTC
Restart cli using the new version ? [yes,no] (yes) yes

Restarting cli ...
user@host
```

request system software validate

Syntax	request system software validate <i>package-name</i>
Syntax (EX Series Switch)	request system software validate <member <i>member-id</i> >
Syntax (TX Matrix Router)	request system software validate <i>package-name</i> <lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	request system software validate <i>package-name</i> <lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	request system software validate <i>package-name</i> <member <i>member-id</i> >
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Validate candidate software against the current configuration of the router or switch.
Options	<p><i>lcc number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, validate the software bundle or package on a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, validate the software bundle or package on a specific T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace number with a value from 0 through 3.</p> <p><i>member member-id</i>—(EX4200 switches and MX Series routers only) (Optional) Validate the software bundle or package on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace member-id with a value from 0 through 9. For an MX Series Virtual Chassis, replace member-id with a value of 0 or 1.</p> <p><i>package-name</i>—Name of the software bundle or package to test.</p> <p><i>scc</i>—(TX Matrix routers only) (Optional) Validate the software bundle or package for the TX Matrix router (or switch-card chassis).</p> <p><i>sfc number</i>—(TX Matrix Plus routers only) (Optional) Validate the software bundle or package for the TX Matrix Plus router (or switch-fabric chassis).</p>
Additional Information	By default, when you issue the request system software validate command on a TX Matrix master Routing Engine, all the T640 master Routing Engines that are connected to it are validated. If you issue the same command on the TX Matrix backup Routing Engine, all the T640 backup Routing Engines that are connected to it are upgraded to the same version of software.

Likewise, if you issue the **request system software validate** command on a TX Matrix Plus master Routing Engine, all the T1600 master Routing Engines that are connected to it are validated. If you issue the same command on a TX Matrix Plus backup Routing Engine, all the T1600 backup Routing Engines that are connected to it are upgraded to the same version of software.

Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• request system software abort on page 772• request system software add on page 775• request system software delete on page 781• request system software rollback on page 802
List of Sample Output	request system software validate (Successful Case) on page 807 request system software validate (Failure Case) on page 807
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request system software validate (Successful Case) user@host> request system software validate /var/sw/pkg/jbundle-5.3I20020124_0520_sjg.tgz
Checking compatibility with configuration
Initializing...
Using /packages/jbase-5.3I20020122_1901_sjg
Using /var/sw/pkg/jbundle-5.3I20020124_0520_sjg.tgz
Using /var/chroot/var/tmp/jbundle/jbase-5.3I20020124_0520_sjg.tgz
Using /var/chroot/var/tmp/jbundle/jkernel-5.3I20020124_0520_sjg.tgz
Using /var/chroot/var/tmp/jbundle/jcrypto-5.3I20020124_0520_sjg.tgz
Using /var/chroot/var/tmp/jbundle/jpfe-5.3I20020124_0520_sjg.tgz
Using /var/chroot/var/tmp/jbundle/jdocs-5.3I20020124_0520_sjg.tgz
Using /var/chroot/var/tmp/jbundle/jroute-5.3I20020124_0520_sjg.tgz
Validating against /config/juniper.conf.gz
mgd: commit complete

WARNING: cli has been replaced by an updated version:
CLI release 5.3I0 built by sjg on 2002-01-24 05:23:53 UTC
Restart cli using the new version ? [yes,no] (yes)

request system software validate (Failure Case) user@host> request system software validate 6.3/
Pushing bundle to lcc0-re0
error: Failed to transfer package to lcc0-re0

user@host> request system software validate test
Pushing bundle to lcc0-re0
Pushing bundle to lcc2-re0

lcc0-re0:
gzip: stdin: not in gzip format
tar: child returned status 1
ERROR: Not a valid package: /var/tmp/test

```

request system software validate-in-service-upgrade

Syntax	<code>request system software validate in-service-upgrade <i>package-name</i></code>
Release Information	Command introduced in Junos OS Release 9.6
Description	Perform a compatibility check to ensure that the software and hardware components and the configuration on the device support unified ISSU. The request system software validate in-service-upgrade command enables you to detect any compatibility issues before actually issuing the request system software in-service upgrade command to initiate unified ISSU.
Options	<p><i>package-name</i>—Location from which the software package or bundle is to be installed. For example:</p> <ul style="list-style-type: none">• <code>/var/tmp/<i>package-name</i></code>—For a software package or bundle that is being installed from a local directory on the router.• <code><i>protocol</i>://<i>hostname</i>/<i>pathname</i>/<i>package-name</i></code>—For a software package or bundle that is to be downloaded and installed from a remote location. Replace <i>protocol</i> with one of the following:<ul style="list-style-type: none">• ftp—File Transfer Protocol• http—Hypertext Transfer Protocol• scp—Secure copy (available only for Canada and U.S. version)
Additional Information	<p>Unified ISSU is supported on M320, M10i (with Enhanced Compact Forwarding Engine Board), MX Series, T320, T640, T1600, and TX Matrix routers only.</p> <p>For more information, see the Junos OS High Availability Configuration Guide.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• request system software in-service-upgrade on page 785• request system software abort on page 772• request system software abort on page 772• show chassis in-service-upgrade on page 468
List of Sample Output	request system software-validate in-service upgrade on page 809
Output Fields	When you enter this command, Junos OS displays the status of your request.

Sample Output

```

request system {master}
software-validate user@host> request system software validate in-service-upgrade
in-service upgrade /var/tmp/jinstall-9.0-20080114.2-domestic-signed.tgz reboot
Checking compatibility with configuration
Initializing...
Using jbase-9.5-20090127.0
Verified manifest signed by PackageProduction_9_5_0
Using /var/tmp/jinstall-9.6-daily-domestic-signed.tgz
Verified jinstall-9.6-20090706.0-domestic.tgz signed by PackageProduction_9_6_0
Using jinstall-9.6-20090706.0-domestic.tgz
Using jbundle-9.6-20090706.0-domestic.tgz
Checking jbundle requirements on /
Using jbase-9.6-20090706.0.tgz
Verified manifest signed by PackageProduction_9_6_0
Using jkernel-9.6-20090706.0.tgz
Verified manifest signed by PackageProduction_9_6_0
Using jcrypto-9.6-20090706.0.tgz
Verified manifest signed by PackageProduction_9_6_0
Using jpfe-9.6-20090706.0.tgz
Using jdocs-9.6-20090706.0.tgz
Verified manifest signed by PackageProduction_9_6_0
Using jroute-9.6-20090706.0.tgz
Verified manifest signed by PackageProduction_9_6_0
Using jservices-9.6-20090706.0.tgz
[: /var/validate/chroot/tmp/jservices/packages/jservices-voice-9.6-20090706.0.tgz:
  unexpected operator
Auto-deleting old jservices-voice ...
Removing /opt/sdk/jservices-voice ...
Removing jservices-voice-bsg-9.5-20090127.0.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-voice ...
Verified jservices-voice-bsg-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /var/sw/pkg ...
Creating /opt/sdk/jservices-voice ...
Storing jservices-voice-bsg-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-voice/jservices-voice-bsg ->
/var/sw/pkg/jservices-voice-bsg-9.6-20090706.0.tgz...
Installing new jservices-bgf ...
Verified jservices-bgf-pic-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /opt/sdk/jservices-bgf ...
Storing jservices-bgf-pic-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-bgf/jservices-bgf-pic ->
/var/sw/pkg/jservices-bgf-pic-9.6-20090706.0.tgz...
Auto-deleting old jservices-aac1 ...
Removing /opt/sdk/jservices-aac1 ...
Removing jservices-aac1-pic-9.5-20090127.0.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-aac1 ...
Verified jservices-aac1-pic-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /opt/sdk/jservices-aac1 ...
Storing jservices-aac1-pic-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-aac1/jservices-aac1-pic ->
/var/sw/pkg/jservices-aac1-pic-9.6-20090706.0.tgz...
Auto-deleting old jservices-llpdf ...
Removing /opt/sdk/jservices-llpdf ...
Removing jservices-llpdf-pic-9.5-20090127.0.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-llpdf ...

```

```
Verified jservices-llpdf-pic-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /opt/sdk/jservices-llpdf ...
Storing jservices-llpdf-pic-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-llpdf/jservices-llpdf-pic ->
/var/sw/pkg/jservices-llpdf-pic-9.6-20090706.0.tgz...
Auto-deleting old jservices-sfw ...
Removing /opt/sdk/jservices-sfw ...
Removing jservices-sfw-pic-9.5-20090127.0.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-sfw ...
Verified jservices-sfw-pic-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /opt/sdk/jservices-sfw ...
Storing jservices-sfw-pic-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-sfw/jservices-sfw-pic ->
/var/sw/pkg/jservices-sfw-pic-9.6-20090706.0.tgz...
Auto-deleting old jservices-appid ...
Removing /opt/sdk/jservices-appid ...
Removing jservices-appid-pic-9.5-20090127.0.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-appid ...
Verified jservices-appid-pic-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /opt/sdk/jservices-appid ...
Storing jservices-appid-pic-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-appid/jservices-appid-pic ->
/var/sw/pkg/jservices-appid-pic-9.6-20090706.0.tgz...
Auto-deleting old jservices-idp ...
Removing /opt/sdk/jservices-idp ...
Removing jservices-idp-pic-9.5-20090127.0.tgz from /var/sw/pkg ...
Notifying mspd ...
Installing new jservices-idp ...
Verified jservices-idp-pic-9.6-20090706.0.tgz signed by PackageProduction_9_6_0
Creating /opt/sdk/jservices-idp ...
Storing jservices-idp-pic-9.6-20090706.0.tgz in /var/sw/pkg ...
Link: /opt/sdk/jservices-idp/jservices-idp-pic ->
/var/sw/pkg/jservices-idp-pic-9.6-20090706.0.tgz...
Hardware Database regeneration succeeded
Validating against /config/juniper.conf.gz
mgd: commit complete
Validation succeeded
PIC 7/0 will be offlined (In-Service-Upgrade not supported)
PIC 7/1 will be offlined (In-Service-Upgrade not supported)
PIC 4/2 will be offlined (In-Service-Upgrade not supported)
PIC 4/3 will be offlined (In-Service-Upgrade not supported)
```

request system storage cleanup

Syntax	request system storage cleanup <dry-run>
Syntax (EX Series Switch)	request system storage cleanup <all-members> <dry-run> <local> <member <i>member-id</i> >
Release Information	Command introduced in Junos OS Release 7.4. dry-run option introduced in Junos OS Release 7.6. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Free storage space on the router or switch by rotating log files and proposing a list of files for deletion. User input is required for file deletion.
Options	all-members—(EX4200 switches only) (Optional) Delete files on all members of the Virtual Chassis configuration. dry-run—(Optional) List files proposed for deletion (without deleting them). local—(EX4200 switches only) (Optional) Delete files on the local Virtual Chassis member. member <i>member-id</i> —(EX4200 switches only) (Optional) Delete files on the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.
Additional Information	If logging is configured and being used, the dry-run option will rotate the log files. In that case, the output displays the message “Currently rotating log files, please wait.” If no logging is currently underway, the output displays only a list of files to delete.
Required Privilege Level	maintenance
List of Sample Output	request system storage cleanup dry-run on page 811 request system storage cleanup on page 812
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request system user@host> request system storage cleanup dry-run
storage cleanup Currently rotating log files, please wait.
dry-run         This operation can take up to a minute.

List of files to delete:

      Size Date      Name
-----
11.4K Mar  8 15:00 /var/log/messages.1.gz
7245B Feb  5 15:00 /var/log/messages.3.gz
11.8K Feb 22 13:00 /var/log/messages.2.gz

```

```

3926B Mar 16 13:57 /var/log/messages.0.gz
3962B Feb 22 12:47 /var/log/sampled.1.gz
4146B Mar 8 12:20 /var/log/sampled.0.gz
4708B Dec 21 11:39 /var/log/sampled.2.gz
7068B Jan 16 18:00 /var/log/messages.4.gz
13.7K Dec 27 22:00 /var/log/messages.5.gz
890B Feb 22 17:22 /var/tmp/sampled.pkts
65.8M Oct 26 09:10 /var/sw/pkg/jinstall-7.4R1.7-export-signed.tgz
63.1M Oct 26 09:13 /var/sw/pkg/jbundle-7.4R1.7.tgz

```

```

request system user@host> request system storage cleanup
storage cleanup Currently rotating log files, please wait.
                  This operation can take up to a minute.

```


List of files to delete:

	Size	Date	Name
11.4K	Mar 8	15:00	/var/log/messages.1.gz
7245B	Feb 5	15:00	/var/log/messages.3.gz
11.8K	Feb 22	13:00	/var/log/messages.2.gz
3926B	Mar 16	13:57	/var/log/messages.0.gz
11.6K	Mar 8	15:00	/var/log/messages.5.gz
7254B	Feb 5	15:00	/var/log/messages.6.gz
12.9K	Feb 22	13:00	/var/log/messages.8.gz
3726B	Mar 16	13:57	/var/log/messages.7.gz
3962B	Feb 22	12:47	/var/log/sampled.1.gz
4146B	Mar 8	12:20	/var/log/sampled.0.gz
4708B	Dec 21	11:39	/var/log/sampled.2.gz
7068B	Jan 16	18:00	/var/log/messages.4.gz
13.7K	Dec 27	22:00	/var/log/messages.5.gz
890B	Feb 22	17:22	/var/tmp/sampled.pkts
65.8M	Oct 26	09:10	/var/sw/pkg/jinstall-7.4R1.7-export-signed.tgz
63.1M	Oct 26	09:13	/var/sw/pkg/jbundle-7.4R1.7.tgz

Delete these files ? [yes,no] (yes)

restart

Syntax	restart <adaptive-services audit-process chassis-control class-of-service dhcp-service diameter-service disk-monitoring dynamic-flow-capture ecc-error-logging event-processing firewall interface-control ipsec-key-management kernel-replication l2-learning l2tp-universal-edge l2tp-service lacp mib-process pgcp-service pgm pic-services-logging ppp pppoe protected-system-domain-service redundancy-interface-process remote-operations root-system-domain-service routing <logical-system <i>logical-system-name</i> > sampling service-deployment services pgcp gateway <i>gateway-name</i> sbc-configuration-process snmp usb-control web-management> <gracefully immediately soft>
Syntax (EX Series Switch)	restart <autoinstallation chassis-control class-of-service database-replication dhcp dhcp-service diameter-service dot1x-protocol ethernet-link-fault-management ethernet-switching event-processing firewall general-authentication-service interface-control kernel-replication l2-learning lacp license-service link-management lldpd-service mib-process mounstd-service multicast-snooping pgm redundancy-interface-process remote-operations routing secure-neighbor-discovery service-deployment sflow-service snmp vrrp web-management> <gracefully immediately soft>
Syntax (TX Matrix Router)	restart <adaptive-services audit-process chassis-control class-of-service dhcp-service diameter-service disk-monitoring dynamic-flow-capture ecc-error-logging event-processing firewall interface-control ipsec-key-management kernel-replication l2-learning l2tp-service lacp link-management mib-process pgm pic-services-logging ppp pppoe redundancy-interface-process remote-operations routing <logical-system <i>logical-system-name</i> > sampling service-deployment snmp> <all-chassis all-lcc lcc <i>number</i> scc> <gracefully immediately soft>
Syntax (TX Matrix Plus Router)	restart <adaptive-services audit-process chassis-control class-of-service dhcp-service diameter-service disk-monitoring dynamic-flow-capture ecc-error-logging event-processing firewall interface-control ipsec-key-management kernel-replication l2-learning l2tp-service lacp link-management mib-process pgm pic-services-logging ppp pppoe redundancy-interface-process remote-operations routing <logical-system <i>logical-system-name</i> > sampling service-deployment snmp> <all-chassis all-lcc all-sfc lcc <i>number</i> sfc <i>number</i> > <gracefully immediately soft>
Syntax (MX Series Router)	restart <adaptive-services audit-process chassis-control class-of-service dhcp-service diameter-service disk-monitoring dynamic-flow-capture ecc-error-logging event-processing firewall interface-control ipsec-key-management kernel-replication l2-learning l2tp-service l2tp-universal-edge lacp mib-process pgcp-service pgm pic-services-logging ppp pppoe protected-system-domain-service redundancy-interface-process remote-operations root-system-domain-service routing <logical-system <i>logical-system-name</i> > sampling service-deployment services pgcp gateway <i>gateway-name</i> sbc-configuration-process snmp usb-control web-management>

	<code><gracefully immediately soft></code> <code><all-members></code> <code><local></code> <code><member <i>member-id</i>></code>
Syntax (J Series Router)	<code>restart</code> <code><adaptive-services audit-process chassis-control class-of-service dhcp dhcp-service dialer-services diameter-services dlsf event-processing firewall interface-control ipsec-key-management isdn-signaling l2ald l2-learning l2tp-service mib-process network-access-service pgm ppp pppoe remote-operations routing <logical-system <i>logical-system-name</i>> sampling service-deployment snmp usb-control web-management></code> <code><gracefully immediately soft></code>
Syntax (QFX Series)	<code>restart</code> <code><adaptive-services audit-process chassis-control class-of-service dialer-services diameter-services dlsf event-processing fibre-channel firewall interface-control ipsec-key-management isdn-signaling l2ald l2-learning l2tp-service mib-process network-access-service pgm ppp pppoe remote-operations <logical-system <i>logical-system-name</i>> sampling service-deployment snmp usb-control web-management></code> <code><gracefully immediately soft></code>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>dynamic-flow-capture option added in Junos OS Release 7.4.</p> <p>dlsf option added in Junos OS Release 7.5.</p> <p>event-processing option added in Junos OS Release 7.5.</p> <p>ppp option added in Junos OS Release 7.5.</p> <p>l2ald option added in Junos OS Release 8.0.</p> <p>link-management option added in Release 8.0.</p> <p>pgcp-service option added in Junos OS Release 8.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>sbc-configuration-process option added in Junos OS Release 9.5.</p> <p>services pgcp gateway option added in Junos OS Release 9.6.</p> <p>sfc and all-sfc options introduced for the TX Matrix Router in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	Restart a Junos OS process.
	<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;"> <p>CAUTION: Never restart a software process unless instructed to do so by a customer support engineer. A restart might cause the router or switch to drop calls and interrupt transmission, resulting in possible loss of data.</p> </div> </div>
Options	<p>none—Same as gracefully.</p> <p>adaptive-services—(Optional) Restart the configuration management process that manages the configuration for stateful firewall, Network Address Translation (NAT), intrusion detection services (IDS), and IP Security (IPsec) services on the Adaptive Services PIC.</p>

all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Restart the software process on all chassis.

all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) For a TX Matrix router, restart the software process on all T640 routers connected to the TX Matrix router. For a TX Matrix Plus router, restart the software process on all T1600 routers connected to the TX Matrix Plus router.

all-members—(MX Series routers only) (Optional) Restart the software process for all members of the Virtual Chassis configuration.

all-sfc—(TX Matrix Plus routers only) (Optional) For a TX Matrix Plus router, restart the software processes for the TX Matrix Plus router (or switch-fabric chassis).

audit-process—(Optional) Restart the RADIUS accounting process.

autoinstallation—(EX Series switch only) (Optional) Restart the autoinstallation process.

chassis-control—(Optional) Restart the chassis management process.

class-of-service—(Optional) Restart the class-of-service (CoS) process, which controls the router's or switch's CoS configuration.

database-replication—(EX Series switch only) (Optional) Restart the database replication process.

dhcp—(J Series router and EX Series switch only) (Optional) Restart the software process for a Dynamic Host Configuration Protocol (DHCP) server. A DHCP server allocates network IP addresses and delivers configuration settings to client hosts without user intervention.

dhcp-service—(EX Series switch and MX Series routers only) (Optional) Restart the Dynamic Host Configuration Protocol process.

dialer-services—(J Series router only) (Optional) Restart the ISDN dial-out process.

diameter-service—(Optional) Restart the diameter process.

disk-monitoring—(Optional) Restart disk monitoring, which checks the health of the hard disk drive on the Routing Engine.

dls—(J Series router only) (Optional) Restart the data link switching (DLSw) service.

dot1x-protocol—(EX Series switch only) (Optional) Restart the port-based network access control process.

dynamic-flow-capture—(Optional) Restart the dynamic flow capture (DFC) process, which controls DFC configurations on Monitoring Services III PICs.

ecc-error-logging—(Optional) Restart the error checking and correcting (ECC) process, which logs ECC parity errors in memory on the Routing Engine.

ethernet-link-fault-management—(EX Series switch only) (Optional) Restart the Ethernet OAM link fault management process.

ethernet-switching—(EX Series switch only) (Optional) Restart the Ethernet switching process.

event-processing—(Optional) Restart the event process (eventd).

fibre-channel—(QFX Series only) (Optional) Restart the Fibre Channel process.

firewall—(Optional) Restart the firewall management process, which manages firewall configuration.

general-authentication-service—(EX Series switch only) (Optional) Restart the general authentication process.

gracefully—(Optional) Restart the software process.

immediately—(Optional) Immediately restart the software process.

interface-control—(Optional) Restart the interface process, which controls the router's or switch's physical interface devices and logical interfaces.

ipsec-key-management—(Optional) Restart the IPsec key management process.

isdn-signaling—(J Series router only) (Optional) Restart the ISDN signaling process, which initiates ISDN connections.

kernel-replication—(Optional) Restart the kernel replication process, which replicates the state of the backup Routing Engine when graceful Routing Engine switchover is configured.

l2-learning—(Optional) Restart the Layer 2 address flooding and learning process.

l2tp-service—(Optional) (M10, M10i, M7i, and MX Series routers only) Restart the Layer 2 Tunneling Protocol (L2TP) process, which establishes L2TP tunnels and Point-to-Point Protocol (PPP) sessions through L2TP tunnels.

l2tp-universal-edge—(MX Series routers only) (Optional) Restart the Layer 2 Tunneling Protocol (L2TP) process, which establishes L2TP tunnels and Point-to-Point Protocol (PPP) sessions through L2TP tunnels.

lacp—(Optional) Restart the Link Aggregation Control Protocol process.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) For a TX Matrix router, restart the software process for a specific T640 router that is connected to the TX Matrix router. For a TX Matrix Plus router, restart the software process for a specific T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

license-service—(EX Series switch only) (Optional) Restart the feature license management process.

link-management— (TX Matrix and TX Matrix Plus routers and EX Series switches only) (Optional) Restart the Link Management Protocol (LMP) process, which establishes and maintains LMP control channels.

lldpd-service—(EX Series switch only) (Optional) Restart the Link Layer Discovery Protocol process.

local—(MX Series routers only) (Optional) Restart the software process for the local Virtual Chassis member.

member *member-id*—(MX Series routers only) (Optional) Restart the software process for a specific member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

mib-process—(Optional) Restart the Management Information Base (MIB) II process, which provides the router's MIB II agent.

mountd-service—(EX Series switch only) (Optional) Restart the service for NFS mounts requests.

multicast-snooping—(EX Series switch only) (Optional) Restart the multicast snooping process.

network-access-service—(J Series router only) (Optional) Restart the network access process, which provides the router's Challenge Handshake Authentication Protocol (CHAP) authentication service.

pgcp-service—(Optional) Restart the pgcpd service process running on the Routing Engine. This option does not restart pgcpd processes running on mobile station PICs. To restart pgcpd processes running on mobile station PICs, use the **services pgcp gateway** option.

pgm—(Optional) Restart the process that implements the Pragmatic General Multicast (PGM) protocol for assisting in the reliable delivery of multicast packets.

pic-services-logging—(Optional) Restart the logging process for some PICs. With this process, also known as fsad (the file system access daemon), PICs send special logging information to the Routing Engine for archiving on the hard disk.

ppp—(Optional) Restart the Point-to-Point Protocol (PPP) process.

pppoe—(Optional) Restart the Point-to-Point Protocol over Ethernet (PPPoE) process.

protected-system-domain-service—(Optional) Restart the Protected System Domain (PSD) process.

redundancy-interface-process—(Optional) Restart the ASP redundancy process.

remote-operations—(Optional) Restart the remote operations process, which provides the ping and traceroute MIBs.

root-system-domain-service—(Optional) Restart the Root System Domain (RSD) service.

routing—(EX Series switch only) (Optional) Restart the routing protocol process.

routing <logical-system *logical-system-name*>—(Optional) Restart the routing protocol process, which controls the routing protocols that run on the router or switch and

maintains the routing tables. Optionally, restart the routing protocol process for the specified logical system only.

sampling—(Optional) Restart the sampling process, which performs packet sampling and cflowd export.

scc—(TX Matrix routers only) Restart the software process on the TX Matrix router (or switch-card chassis).

secure-neighbor-discovery—(EX Series switch only) (Optional) Restart the secure Neighbor Discovery Protocol process.

sfc *number*—(TX Matrix Plus routers only) Restart the software process on the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

service-deployment—(Optional) Restart the service deployment service process.

services pgcp gateway *gateway-name*—(Optional) Restart the pgcpd process for a specific BGP running on an MS-PIC. This option does not restart the pgcpd process running on the Routing Engine. To restart the pgcpd process on the Routing Engine, use the **pgcp-service** option.

sflow-service—(EX Series switch only) (Optional) Restart the flow sampling (sFlow technology) process.

snmp—(Optional) Restart the SNMP process, which provides the router's or switch's SNMP master agent.

soft—(Optional) Reread and reactivate the configuration without completely restarting the software processes. For example, BGP peers stay up and the routing table stays constant. Omitting this option results in a graceful restart of the software process.

usb-control—(J Series router and MX Series routers only) (Optional) Restart the USB control process.

vrrp—(EX Series switch only) (Optional) Restart the Virtual Router Redundancy Protocol process.

web-management—(J Series router, EX Series switch, and MX Series routers only) (Optional) Restart the Web management process.

Required Privilege Level

reset

Related Documentation

- Overview of Junos OS CLI Operational Mode Commands

List of Sample Output **restart interfaces on page 819**

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
restart interfaces  user@host> restart interfaces
                   interfaces process terminated
                   interfaces process restarted
```

show arp

Syntax	<pre>show arp <expiration-time> <logical-system <i>logical-system-name</i>> <no-resolve> <vpn <i>vpn-name</i>></pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>expiration-time option added in Junos OS Release 8.1.</p> <p>logical-system and vpn options added in Junos OS Release 10.1.</p>
Description	<p>Display all entries in the Address Resolution Protocol (ARP) table. To display entries for a particular logical system only, first enter the set cli logical-system <i>logical-system-name</i> command, and then enter the show arp command.</p>
Options	<p>none—Display the entries in the ARP table.</p> <p>expiration-time—(Optional) Display the amount of time, in seconds, until each ARP entry is set to expire.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Display ARP entries for the specified logical system; only available on the main router context.</p> <p>no-resolve—(Optional) Do not attempt to determine the hostname that corresponds to the IP address.</p> <p>vpn <i>vpn-name</i>—(Optional) Display entries in the ARP table for the specified virtual private network's (VPN) routing table.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear arp on page 703 set cli logical-system on page 549
List of Sample Output	<p>show arp on page 821</p> <p>show arp no-resolve on page 821</p> <p>show arp expiration-time on page 821</p>
Output Fields	<p>Table 122 on page 820 describes the output fields for the show arp command. Output fields are listed in the approximate order in which they appear.</p>

Table 122: show arp Output Fields

Field Name	Field Description
MAC Address	Media access control (MAC) address that corresponds to the IP address.
Address	IP address that corresponds to the hostname.

Table 122: show arp Output Fields (*continued*)

Field Name	Field Description
Name	Hostname.
Interface	Interface name.
Flags	(no-resolve option only) Indicates how mappings between IP and MAC addresses are defined: <ul style="list-style-type: none"> • Permanent—Static mapping. • Permanent and published—Static mapping that is published. • None—Dynamic mapping.
TTE	(expiration-time option only) Amount of time, in seconds, until ARP entry is set to expire.

Sample Output

```

show arp user@host> show arp
MAC Address      Address      Name          Interface
00:e0:81:22:fd:74 192.168.64.10 firewall.my.net fxp0.0
00:04:5a:65:78:e1 192.168.65.13 lab.my net     fxp0.0

```

```

show arp no-resolve user@host> show arp no-resolve
MAC Address      Address      Interface      Flags
00:90:69:96:00:01 10.10.45.5   fe-0/0/1.0    none
00:00:00:00:00:01 200.200.200.1 fe-0/0/0.0    permanent published
00:00:00:00:00:02 200.200.200.2 fe-0/0/0.0    permanent
00:90:69:91:b0:00 200.200.200.3 fe-0/0/0.0    none
Total entries: 4

```

```

show arp expiration-time user@host> show arp expiration-time
MAC Address      Address      Name          Interface      Flags TTE
00:a0:a5:12:3e:d4 10.0.0.5     10.0.0.5      fxp1.0         none
00:e0:81:22:fd:74 192.168.64.10 supernova.englab.juniper. fxp0.0 none 1491
00:30:48:84:03:56 192.168.65.46 kgb.englab.juniper.net   fxp0.0 none 1279
00:03:ba:12:f7:5e 192.168.65.226 nmssun1-eri0.englab.junip fxp0.0 none 452
00:90:69:8e:b0:fc 192.168.71.254 stonewall-ge-200.englab.j fxp0.0 none 1421
Total entries: 5

```

show configuration

Syntax	<code>show configuration</code> <code><statement-path></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the configuration that currently is running on the router or switch, which is the last committed configuration.
Options	<p><code>none</code>—Display the entire configuration.</p> <p><code>statement-path</code>—(Optional) Display one of the following hierarchies in a configuration. (Each <i>statement-path</i> option has additional suboptions not described here. See the appropriate configuration guide or EX Series switch documentation for more information.)</p> <ul style="list-style-type: none">• <code>access</code>—Network access configuration.• <code>access-profile</code>—Access profile configuration.• <code>accounting-options</code>—Accounting data configuration.• <code>applications</code>—Applications defined by protocol characteristics.• <code>apply-groups</code>—Groups from which configuration data is inherited.• <code>chassis</code>—Chassis configuration.• <code>chassis network-services</code>—Current running mode.• <code>class-of-service</code>—Class-of-service configuration.• <code>diameter</code>—Diameter base protocol layer configuration.• <code>ethernet-switching-options</code>—(EX Series switch only) Ethernet switching configuration.• <code>event-options</code>—Event processing configuration.• <code>firewall</code>—Firewall configuration.• <code>forwarding-options</code>—Options that control packet sampling.• <code>groups</code>—Configuration groups.• <code>interfaces</code>—Interface configuration.• <code>jsrc</code>—JSRC partition configuration.• <code>jsrc-partition</code>—JSRC partition configuration.• <code>logical-systems</code>—Logical system configuration.• <code>poe</code>—(EX Series switch only) Power over Ethernet configuration.• <code>policy-options</code>—Routing policy option configuration.• <code>protocols</code>—Routing protocol configuration.

- **routing-instances**—Routing instance configuration.
- **routing-options**—Protocol-independent routing option configuration.
- **security**—Security configuration.
- **services**—Service PIC applications configuration.
- **snmp**—Simple Network Management Protocol configuration.
- **system**—System parameters configuration.
- **virtual-chassis**—(EX Series switch only) Virtual Chassis configuration.
- **vlan**—(EX Series switch only) VLAN configuration.

Additional Information	The portions of the configuration that you can view depend on the user class that you belong to and the corresponding permissions. If you do not have permission to view a portion of the configuration, the text ACCESS-DENIED is substituted for that portion of the configuration. If you do not have permission to view authentication keys and passwords in the configuration, because the secret permission bit is not set for your user account, the text SECRET-DATA is substituted for that portion of the configuration. If an identifier in the configuration contains a space, the identifier is displayed in quotation marks.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • Displaying the Current Junos OS Configuration • Overview of Junos OS CLI Operational Mode Commands
List of Sample Output	show configuration on page 823 show configuration policy-options on page 824
Output Fields	This command displays information about the current running configuration.

Sample Output

```

show configuration user@host> show configuration
## Last commit: 2006-10-31 14:13:00 PST by alant version "8.2I0 [builder]"; ##
last changed: 2006-10-31 14:05:53 PST
system {
    host-name nestor;
    domain-name east.net;
    backup-router 192.1.1.254;
    time-zone America/Los_Angeles;
    default-address-selection;
    name-server {
        192.154.169.254;
        192.154.169.249;
        192.154.169.176;
    }
    services {
        telnet;
    }
    tacplus-server {

```

```
        1.2.3.4 {
            secret /* SECRET-DATA */;
            ...
        }
    }
}
interfaces {
    ...
}
protocols {
    isis {
        export "direct routes";
    }
}
policy-options {
    policy-statement "direct routes" {
        from protocol direct;
        then accept;
    }
}
```

```
show configuration user@host> show configuration policy-options
policy-options    policy-options {
                    policy-statement "direct routes" {
                        from protocol direct;
                        then accept;
                    }
                }
```


show database-replication statistics

Syntax	show database-replication statistics
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display statistics regarding the replication of the subscriber management session database.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show database-replication statistics on page 825
Output Fields	Table 123 on page 825 lists the output fields for the show database-replication statistics command. Output fields are listed in the approximate order in which they appear.

Table 123: show database-replication statistics Output Fields

Field Name	Field Description
General	Number of dropped connections and the maximum buffer count.
Message Received	Total size of messages received and the number of received messages that have been processed.
Message Sent	Total size of messages sent and the number of sent messages that have been processed.
Message Queue	Number of messages in the queue and the maximum size of the queue.

Sample Output

```

show database-replication statistics user@host> show database-replication statistics
General:
  Dropped connections      0
  Max buffer count        0
Message received:
  Size (bytes)            0
  Processed               0
Message sent:
  Size (bytes)            0
  Processed               0
Message queue:
  Queue full              0
  Max queue size          0

```

show database-replication summary

Syntax	show database-replication summary
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display summary information regarding database replication for the subscriber management session database.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show database-replication summary on page 827
Output Fields	Table 124 on page 826 lists the output fields for the show database-replication summary command. Output fields are listed in the approximate order in which they appear.

Table 124: show database-replication summary Output Fields

Field Name	Field Description
Graceful Restart	State of graceful Routing Engine switchover (GRES): <ul style="list-style-type: none">• Enabled• Disabled
Mastership	State of the Routing Engine: <ul style="list-style-type: none">• Master• Standby
Connection	State of the connection: <ul style="list-style-type: none">• Up• Down
Database	State of the subscriber management database: <ul style="list-style-type: none">• Available• Unavailable• Synchronized
Message Queue	State of the message queue: <ul style="list-style-type: none">• Full• Init• Not Ready• Ready

Sample Output

```
show database-replication summary
user@host> show database-replication summary
General:
  Graceful Restart      Enabled
  Mastership            Standby
  Connection            Up
  Database              Available
  Message Queue         Ready
```

show dhcp server binding

Syntax	<code>show dhcp server binding</code> <code><brief detail summary></code> <code><interface <i>interface-name</i>></code> <code><ip-address mac-address></code> <code><logical-system <i>logical-system-name</i>></code> <code><routing-instance <i>routing-instance-name</i>></code>
Release Information	Command introduced in Junos OS Release 9.0.
Description	Display the address bindings in the client table on the extended Dynamic Host Configuration Protocol (DHCP) local server.
Options	<p><code>brief detail summary</code>—(Optional) Display the specified level of output about active client bindings. The default is brief, which produces the same output as show dhcp server binding.</p> <p><code>interface <i>interface-name</i></code>—(Optional) Display information about active client bindings on the specified interface. You can optionally filter on VLAN ID and SVLAN ID.</p> <p><code>ip-address</code>—(Optional) IP address of the DHCP client.</p> <p><code>mac-address</code>—(Optional) MAC address of the DHCP client.</p> <p><code>logical-system <i>logical-system-name</i></code>—(Optional) Display information about active client bindings for DHCP clients on the specified logical system.</p> <p><code>routing-instance <i>routing-instance-name</i></code>—(Optional) Display information about active client bindings for DHCP clients on the specified routing instance.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• clear dhcp server binding on page 704
List of Sample Output	show dhcp server binding on page 830 show dhcp server binding detail on page 830 show dhcp server binding interface vlan-id on page 830 show dhcp server binding interface svlan-id on page 830 show dhcp server binding ip-address on page 830 show dhcp server binding session-id on page 831 show dhcp server binding summary on page 831
Output Fields	Table 125 on page 829 lists the output fields for the show dhcp server binding command. Output fields are listed in the approximate order in which they appear.

Table 125: show dhcp server binding Output Fields

Field Name	Field Description	Level of Output
<i>number</i> clients, (<i>number</i> init, <i>number</i> bound, <i>number</i> selecting, <i>number</i> requesting, <i>number</i> renewing, <i>number</i> releasing)	Summary counts of the total number of DHCP clients and the number of DHCP clients in each state.	summary
IP address	IP address of the DHCP client.	brief detail
Session Id	Session ID of the subscriber session.	brief detail
Hardware address	Hardware address of the DHCP client.	brief detail
Expires	Number of seconds in which lease expires.	brief detail
State	State of the address binding table on the extended DHCP local server: <ul style="list-style-type: none"> • BOUND—Client has active IP address lease. • FORCERENEW—Client has received forcerenew message from server. • INIT—Initial state. • RELEASE—Client is releasing IP address lease. • RENEWING—Client sending request to renew IP address lease. • REQUESTING—Client requesting a DHCP server. • SELECTING—Client receiving offers from DHCP servers. 	brief detail
Interface	Interface on which the request was received.	brief
Lease Expires	Date and time at which the client's IP address lease expires.	detail
Lease Expires in	Number of seconds in which lease expires.	detail
Lease Start	Date and time at which the client's IP address lease started.	detail
Incoming Client Interface	Client's incoming interface.	detail
Server IP Address	IP address of DHCP server.	detail
Server Interface	Interface of DHCP server.	detail
Client Pool Name	Name of address pool used to assign client IP address lease.	detail

Sample Output

```

show dhcp server binding user@host> show dhcp server binding
IP address      Session Id  Hardware address  Expires  State  Interface
100.20.20.15    6          00:10:94:00:00:01 86180    BOUND  ge-1/0/0.0
100.20.20.16    7          00:10:94:00:00:02 86180    BOUND  ge-1/0/0.0
100.20.20.17    8          00:10:94:00:00:03 86180    BOUND  ge-1/0/0.0
100.20.20.18    9          00:10:94:00:00:04 86180    BOUND  ge-1/0/0.0
100.20.20.19    10         00:10:94:00:00:05 86180    BOUND  ge-1/0/0.0

```

```

show dhcp server binding detail user@host> show dhcp server binding detail
Client IP Address: 100.20.20.15
  Hardware Address:      00:10:94:00:00:01
  State:                 BOUND(LOCAL_SERVER_STATE_BOUND_ON_INTF_DELETE)

  Lease Expires:        2009-07-21 10:10:25 PDT
  Lease Expires in:     86151 seconds
  Lease Start:          2009-07-20 10:10:25 PDT
  Incoming Client Interface: ge-1/0/0.0
  Server Ip Address:    100.20.20.9
  Server Interface:     none
  Session Id:           6
  Client Pool Name:     6
Client IP Address: 100.20.20.16
  Hardware Address:      00:10:94:00:00:02
  State:                 BOUND(LOCAL_SERVER_STATE_BOUND_ON_INTF_DELETE)

  Lease Expires:        2009-07-21 10:10:25 PDT
  Lease Expires in:     86151 seconds
  Lease Start:          2009-07-20 10:10:25 PDT
  Incoming Client Interface: ge-1/0/0.0
  Server Ip Address:    100.20.20.9
  Server Interface:     none
  Session Id:           7
  Client Pool Name:     7

```

```

show dhcp server binding interface user@host> show dhcp server binding interface ge-1/1/0:100
vlan-id
IP address      Session Id  Hardware address  Expires  State  Interface
200.20.20.15    6          00:10:94:00:00:01 86124    BOUND  ge-1/1/0:100

```

```

show dhcp server binding interface user@host> show dhcp server binding interface ge-1/1/0:10-100
svlan-id
IP address      Session Id  Hardware address  Expires  State  Interface
200.20.20.16    7          00:10:94:00:00:02 86124    BOUND  ge-1/1/0:10-100

```

```

show dhcp server binding ip-address user@host> show dhcp server binding 100.20.20.19
IP address      Session Id  Hardware address  Expires  State  Interface
100.20.20.19    10         00:10:94:00:00:05 86081    BOUND  ge-1/0/0.0

```

```
show dhcp server user@host> show dhcp server binding 6
binding session-id IP address      Session Id  Hardware address  Expires    State    Interface
200.20.20.15      6           00:10:94:00:00:01 86124          BOUND      ge-1/0/0.0
```

```
show dhcp server user@host> show dhcp server binding summary
binding summary 3 clients, (2 init, 1 bound, 0 selecting, 0 requesting, 0 renewing, 0 releasing)
```

show dhcp server statistics

Syntax	show dhcp server statistics <interface <i>interface-name</i>> <logical-system <i>logical-system-name</i>> <routing-instance <i>routing-instance-name</i>>
Release Information	Command introduced in Junos OS Release 9.0.
Description	Display extended Dynamic Host Configuration Protocol (DHCP) local server statistics.
Options	<p>interface <i>interface-name</i>—(Optional) Display information about extended DHCP local server statistics on the specified interface. If you do not specify an interface, statistics are displayed for the default logical system.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Display information about extended DHCP local server statistics on the specified logical system. If you do not specify a logical system, statistics are displayed for the default logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Display information about extended DHCP local server statistics on the specified routing instance. If you do not specify a routing instance, statistics are displayed for the default routing instance.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• clear dhcp server statistics on page 706
List of Sample Output	show dhcp server statistics on page 833
Output Fields	Table 126 on page 833 lists the output fields for the show dhcp server statistics command. Output fields are listed in the approximate order in which they appear.

Table 126: show dhcp server statistics Output Fields

Field Name	Field Description
Packets dropped	<p>Number of packets discarded by the extended DHCP local server because of errors. Only nonzero statistics appear in the Packets dropped output. When all of the Packets dropped statistics are 0 (zero), only the Total field appears.</p> <ul style="list-style-type: none"> • Total—Total number of packets discarded by the extended DHCP local server • Bad hardware address—Number of packets discarded because an invalid hardware address was specified • Bad opcode—Number of packets discarded because an invalid operation code was specified • Bad options—Number of packets discarded because invalid options were specified • Invalid server address—Number of packets discarded because an invalid server address was specified • No available addresses—Number of packets discarded because there were no addresses available for assignment • No interface match—Number of packets discarded because they did not belong to a configured interface • No routing instance match—Number of packets discarded because they did not belong to a configured routing instance • No valid local address—Number of packets discarded because there was no valid local address • Packet too short—Number of packets discarded because they were too short • Read error—Number of packets discarded because of a system read error • Send error—Number of packets that the extended DHCP local server could not send
Messages received	<p>Number of DHCP messages received.</p> <ul style="list-style-type: none"> • BOOTREQUEST—Number of BOOTP protocol data units (PDUs) received • DHCPDECLINE—Number of DHCP PDUs of type DECLINE received • DHCPDISCOVER—Number of DHCP PDUs of type DISCOVER received • DHCPINFORM—Number of DHCP PDUs of type INFORM received • DHCPRELEASE—Number of DHCP PDUs of type RELEASE received • DHCPREQUEST—Number of DHCP PDUs of type REQUEST received
Messages sent	<p>Number of DHCP messages sent.</p> <ul style="list-style-type: none"> • BOOTREPLY—Number of BOOTP PDUs transmitted • DHCPOFFER—Number of DHCP OFFER PDUs transmitted • DHCPACK—Number of DHCP ACK PDUs transmitted • DHCPNACK—Number of DHCP NACK PDUs transmitted • DHCPFORCERENEW—Number of DHCP FORCERENEW PDUs transmitted

Sample Output

```

show dhcp server statistics  user@host> show dhcp server statistics
Packets dropped:
    Total                  0

Messages received:
    BOOTREQUEST            25
    DHCPDECLINE             0
    DHCPDISCOVER           10
    DHCPINFORM              0

```

DHCPRELEASE	4
DHCPREQUEST	10
Messages sent:	
BOOTREPLY	20
DHCPOFFER	10
DHCPACK	10
DHCPNAK	0
DHCPFORCERENEW	0

show dhcpv6 server binding

Syntax	<pre>show dhcpv6 server binding <brief detail summary> <interface <i>interface-name</i>> <<i>ip-address</i>> <logical-system <i>logical-system-name</i>> <routing-instance <i>routing-instance-name</i>></pre>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display the address bindings in the client table on the extended Dynamic Host Configuration Protocol for IPv6 (DHCPv6) local server.
Options	<p>brief detail summary—(Optional) Display the specified level of output about active client bindings. The default is brief, which produces the same output as show dhcpv6 server binding.</p> <p>interface <i>interface-name</i>—(Optional) Display information about active client bindings on the specified interface. You can optionally filter on VLAN ID and SVLAN ID.</p> <p><i>ip-address</i>—(Optional) IP address of the DHCPv6 client, or client ID of the DHCPv6 client, or session ID associated with the DHCPv6 client.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Display information about active client bindings for DHCPv6 clients on the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Display information about active client bindings for DHCPv6 clients on the specified routing instance.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear dhcpv6 server binding on page 708
List of Sample Output	<pre>show dhcpv6 server binding on page 837 show dhcpv6 server binding detail on page 837 show dhcpv6 server binding interface on page 837 show dhcpv6 server binding interface detail on page 837 show dhcpv6 server binding prefix on page 838 show dhcpv6 server binding session-id on page 838 show dhcpv6 server binding summary on page 838</pre>
Output Fields	Table 127 on page 836 lists the output fields for the show dhcpv6 server binding command. Output fields are listed in the approximate order in which they appear.

Table 127: show dhcpv6 server binding Output Fields

Field Name	Field Description	Level of Output
<i>number clients</i> , (<i>number init</i> , <i>number bound</i> , <i>number selecting</i> , <i>number requesting</i> , <i>number renewing</i> , <i>number releasing</i>)	Summary counts of the total number of DHCPv6 clients and the number of DHCPv6 clients in each state.	summary
Prefix	Client's DHCPv6 prefix.	brief detail
Session Id	Session ID of the subscriber session.	brief detail
Expires	Number of seconds in which lease expires.	brief detail
State	State of the address binding table on the extended DHCPv6 local server: <ul style="list-style-type: none"> • BOUND—Client has active IP address lease. • INIT—Initial state. • RECONFIGURE—Server has sent reconfigure message to client. • RELEASE—Client is releasing IP address lease. • RENEWING—Client sending request to renew IP address lease. • REQUESTING—Client requesting a DHCPv6 server. • SELECTING—Client receiving offers from DHCPv6 servers. 	brief detail
Interface	Interface on which the DHCPv6 request was received.	brief
Client DUID	Client's DHCP Unique Identifier (DUID).	brief detail
Lease expires	Date and time at which the client's IP address lease expires.	detail
Lease expires in	Number of seconds in which lease expires.	detail
Lease Start	Date and time at which the client's address lease was obtained.	detail
Incoming Client Interface	Client's incoming interface.	detail
Server IP Address	IP address of DHCPv6 server.	detail
Server Interface	Interface of DHCPv6 server.	detail
Client Id length	Length of the DHCPv6 client ID, in bytes.	detail
Client Id	ID of the DHCPv6 client.	detail

Sample Output

```

show dhcpv6 server binding  user@host> show dhcpv6 server binding

Prefix          Session Id Expires State Interface Client DUID
2001:bd8:1111:2222::/64 6      86321  BOUND ge-1/0/0.0
LL_TIME0x1-0x2e159c0-00:10:94:00:00:01
2001:bd8:1111:2222::/64 7      86321  BOUND ge-1/0/0.0
LL_TIME0x1-0x2e159c0-00:10:94:00:00:02
2001:bd8:1111:2222::/64 8      86321  BOUND ge-1/0/0.0
LL_TIME0x1-0x2e159c0-00:10:94:00:00:03
2001:bd8:1111:2222::/64 9      86321  BOUND ge-1/0/0.0
LL_TIME0x1-0x2e159c1-00:10:94:00:00:04
2001:bd8:1111:2222::/64 10     86321  BOUND ge-1/0/0.0
LL_TIME0x1-0x2e159c1-00:10:94:00:00:05

show dhcpv6 server binding detail user@host> show dhcpv6 server binding detail
Session Id: 6
Client IPv6 Prefix:          2001:bd8:1111:2222::/64
Client DUID:                  LL_TIME0x1-0x2e159c0-00:10:94:00:00:01

State:
BOUND(LOCAL_SERVER_STATE_BOUND_ON_INTF_DELETE)
Lease Expires:                2009-07-21 10:41:15 PDT
Lease Expires in:              86308 seconds
Lease Start:                   2009-07-20 10:41:15 PDT
Incoming Client Interface:     ge-1/0/0.0
Server Ip Address:              0.0.0.0
Server Interface:               none
Client Id Length:               14
Client Id:                      /0x00010001/0x02e159c0/0x00109400/0x0001

Session Id: 7
Client IPv6 Prefix:          2001:bd8:1111:2222::/64
Client DUID:                  LL_TIME0x1-0x2e159c0-00:10:94:00:00:02

State:
BOUND(LOCAL_SERVER_STATE_BOUND_ON_INTF_DELETE)
Lease Expires:                2009-07-21 10:41:15 PDT
Lease Expires in:              86308 seconds
Lease Start:                   2009-07-20 10:41:15 PDT
Incoming Client Interface:     ge-1/0/0.0
Server Ip Address:              0.0.0.0
Server Interface:               none
Client Id Length:               14
Client Id:                      /0x00010001/0x02e159c0/0x00109400/0x0002

show dhcpv6 server binding interface user@host> show dhcpv6 server binding interface ge-1/0/0:10-101
Prefix          Session Id Expires State Interface Client DUID
2001:bd8:1111:2222::/64 1      86055  BOUND ge-1/0/0.100
LL_TIME0x1-0x4b0a53b9-00:10:94:00:00:01

show dhcpv6 server binding interface detail user@host> show dhcpv6 server binding interface ge-1/0/0:10-101 detail
Session Id: 7

```

```

Client IPv6 Prefix:      2001:bd8:1111:2222::/64
Client DUID:             LL_TIME0x1-0x2e159c0-00:10:94:00:00:02

State:                   BOUND(bound)
Lease Expires:           2009-07-21 10:41:15 PDT
Lease Expires in:        86136 seconds
Lease Start:             2009-07-20 10:41:15 PDT
Incoming Client Interface: ge-1/0/0.0
Server Ip Address:        0.0.0.0
Server Interface:         none
Client Id Length:         14
Client Id:                /0x00010001/0x02e159c0/0x00109400/0x0002

show dhcpv6 server binding prefix
user@host> show dhcpv6 server binding 14/0x00010001/0x02b3be8f/0x00109400/0x0005
detail
Session Id: 7
Client IPv6 Prefix:      2001:bd8:1111:2222::/64
Client DUID:             LL_TIME0x1-0x2e159c0-00:10:94:00:00:02

State:                   BOUND(bound)
Lease Expires:           2009-07-21 10:41:15 PDT
Lease Expires in:        86136 seconds
Lease Start:             2009-07-20 10:41:15 PDT
Incoming Client Interface: ge-1/0/0.0
Server Ip Address:        0.0.0.0
Server Interface:         none
Client Id Length:         14
Client Id:                /0x00010001/0x02e159c0/0x00109400/0x0002

show dhcpv6 server binding session-id
user@host> show dhcpv6 server binding 8
Prefix      Session Id Expires State Interface Client DUID
2001:bd8:1111:2222::/64 8 86235 BOUND ge-1/0/0.0
LL_TIME0x1-0x2e159c0-00:10:94:00:00:03

show dhcpv6 server binding summary
user@host> show dhcpv6 server binding summary
5 clients, (0 init, 5 bound, 0 selecting, 0 requesting, 0 renewing, 0 releasing)

```

show dhcpv6 server statistics

Syntax	<pre>show dhcpv6 server statistics <interface <i>interface-name</i>> <logical-system <i>logical-system-name</i>> <routing-instance <i>routing-instance-name</i>></pre>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display extended Dynamic Host Configuration Protocol for IPv6 (DHCPv6) local server statistics.
Options	<p><i>interface interface-name</i>—(Optional) Display information about extended DHCPv6 local server statistics on the specified interface. If you do not specify an interface, statistics are displayed for the default logical system.</p> <p><i>logical-system logical-system-name</i>—(Optional) Display information about extended DHCPv6 local server statistics on the specified logical system. If you do not specify a logical system, statistics are displayed for the default logical system.</p> <p><i>routing-instance routing-instance-name</i>—(Optional) Display information about extended DHCPv6 local server statistics on the specified routing instance. If you do not specify a routing instance, statistics are displayed for the default routing instance.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear dhcpv6 server statistics on page 710
List of Sample Output	show dhcpv6 server statistics on page 840
Output Fields	Table 128 on page 840 lists the output fields for the show dhcpv6 server statistics command. Output fields are listed in the approximate order in which they appear.

Table 128: show dhcpv6 server statistics Output Fields

Field Name	Field Description
Packets dropped	<p>Number of packets discarded by the extended DHCPv6 local server because of errors. Only nonzero statistics appear in the Packets dropped output. When all of the Packets dropped statistics are 0 (zero), only the Total field appears.</p> <ul style="list-style-type: none"> • Total—Total number of packets discarded by the extended DHCPv6 local server • Strict Reconfigure—Number of solicit messages discarded because the client does not support reconfiguration • Bad hardware address—Number of packets discarded because an invalid hardware address was specified • Bad opcode—Number of packets discarded because an invalid operation code was specified • Bad options—Number of packets discarded because invalid options were specified • Invalid server address—Number of packets discarded because an invalid server address was specified • No available addresses—Number of packets discarded because there were no addresses available for assignment • No interface match—Number of packets discarded because they did not belong to a configured interface • No routing instance match—Number of packets discarded because they did not belong to a configured routing instance • No valid local address—Number of packets discarded because there was no valid local address • Packet too short—Number of packets discarded because they were too short • Read error—Number of packets discarded because of a system read error • Send error—Number of packets that the extended DHCPv6 local server could not send
Messages received	<p>Number of DHCPv6 messages received.</p> <ul style="list-style-type: none"> • DHCPV6_CONFIRM—Number of DHCPv6 CONFIRM PDUs received. • DHCPV6_DECLINE—Number of DHCPv6 DECLINE PDUs received. • DHCPV6_INFORMATION_REQUEST—Number of DHCPv6 INFORMATION-REQUEST PDUs received. • DHCPV6_REBIND—Number of DHCPv6 REBIND PDUs received. • DHCPV6_RELAY_FORW—Number of DHCPv6 RELAY-FORW PDUs received. • DHCPV6_RELAY_REPL—Number of DHCPv6 RELAY-REPL PDUs received. • DHCPV6_RELEASE—Number of DHCPv6 RELEASE PDUs received. • DHCPV6_RENEW—Number of DHCPv6 RENEW PDUs received. • DHCPV6_REQUEST—Number of DHCPv6 REQUEST PDUs received. • DHCPV6_SOLICIT—Number of DHCPv6 SOLICIT PDUs received.
Messages sent	<p>Number of DHCPv6 messages sent.</p> <ul style="list-style-type: none"> • DHCPV6_ADVERTISE—Number of DHCPv6 ADVERTISE PDUs transmitted. • DHCPV6_REPLY—Number of DHCPv6 ADVERTISE PDUs transmitted. • DHC6_RECONFIGURE—Number of DHCPv6 RECONFIGURE PDUs transmitted.

Sample Output

```

show dhcpv6 server statistics  user@host> show dhcpv6 server statistics
                               Dhcpv6 Packets dropped:
                               Total                  0

```



```
Messages received:
  DHCPV6_DECLINE          0
  DHCPV6_SOLICIT          9
  DHCPV6_INFORMATION_REQUEST 0
  DHCPV6_RELEASE          0
  DHCPV6_REQUEST          5
  DHCPV6_CONFIRM          0
  DHCPV6_RENEW            0
  DHCPV6_REBIND           0
  DHCPV6_RELAY_FORW       0
  DHCPV6_RELAY_REPL       0

Messages sent:
  DHCPV6_ADVERTISE        9
  DHCPV6_REPLY            5
  DHCPV6_RECONFIGURE      0
```

show host

Syntax	<code>show host <i>hostname</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display Domain Name System (DNS) hostname information.
Options	<i>hostname</i> —Hostname or address.
Additional Information	The show host command displays the raw data received from the DNS server.
Required Privilege Level	view
List of Sample Output	show host on page 842

Sample Output

```
show host user@host> show host snark
snark.boojum.net has address 192.168.1.254

user@host> show host 192.168.1.254
Name: snark.boojum.net
Address: 192.168.1.254
Aliases:
```

show network-access aaa statistics

Syntax	<pre>show network-access aaa statistics <accounting> <address-assignment (client pool <i>pool-name</i>)> <authentication> <dynamic-requests></pre>
Release Information	<p>Command introduced in Junos OS Release 9.1.</p> <p>address-assignment option introduced in Junos OS Release 10.0.</p>
Description	Display AAA accounting, authentication, address-assignment, and dynamic request statistics.
Options	<p>accounting—(Optional) Display AAA accounting statistics.</p> <p>address-assignment (client pool <i>pool-name</i>)—(Optional) Display AAA address-assignment client and pool statistics.</p> <p>authentication—(Optional) Display AAA authentication statistics.</p> <p>dynamic-requests—(Optional) Display AAA dynamic requests.</p>
Required Privilege Level	view
List of Sample Output	<p>show network-access aaa statistics accounting on page 844</p> <p>show network-access aaa statistics address-assignment client on page 844</p> <p>show network-access aaa statistics address-assignment pool on page 845</p> <p>show network-access aaa statistics authentication on page 845</p> <p>show network-access aaa statistics dynamic-requests on page 845</p>
Output Fields	Table 129 on page 843 lists the output fields for the show network-access aaa statistics command. Output fields are listed in the approximate order in which they appear.

Table 129: show network-access aaa statistics Output Fields

Field Name	Field Description
Requests received	<ul style="list-style-type: none"> Number of authentication requests received from clients. Number of accounting requests generated by the AAA framework. Number of dynamic requests received from the external server.
Accounting Response failures	Number of accounting requests not acknowledged (NAK) by the accounting server.
Accounting Response Success	Number of accounting requests acknowledged by the accounting server.
Requests timedout	Number of accounting requests to the accounting server that timed out.

Table 129: show network-access aaa statistics Output Fields (*continued*)

Field Name	Field Description
Client	Client type; for example, DHCP, Mobile IP, PPP.
Out of Memory	Number of times an address was not given to the client due to memory issues.
No Matches	Number of times there were no network matches for the pool.
Pool Name	Name of the address-assignment pool for this client.
Out of Addresses	Number of times there were no available addresses in the pool.
Address total	Number of addresses in the pool.
Addresses in use	Number of addresses in use.
Address Usage	Percentage of total addresses in use.
Accepts	Number of authentication requests accepted by the authentication server.
Rejects	Number of authentication requests rejected by the authentication server.
Challenges	Number of authentication requests challenged by the authentication server.
processed successfully	Number of dynamic requests processed successfully by the AAA framework.
errors during processing	Number of dynamic requests that resulted in processing errors by the AAA framework.
Link Name	Name of the secondary address-assignment pool to which the primary pool is linked.
Pool Usage	Percentage of allocated addresses in the specified address pool.
silently dropped	Number of dynamic requests dropped by the AAA framework due to multiple back-to-back or duplicate requests.

Sample Output

```

show network-access user@host> show network-access aaa statistics accounting
aaa statistics      Accounting module statistics
accounting          Requests received: 0
                   Accounting Response failures: 0
                   Accounting Response Success: 0
                   Requests timedout: 0

show network-access user@host> show network-access aaa statistics address-assignment client
aaa statistics      Address-assignment statistics
address-assignment Client: jdhcpd
client             Out of Memory: 0
                   No Matches: 2

```

```
show network-access user@host> show network-access aaa statistics address-assignment pool isp_1
  aaa statistics      Address-assignment statistics
address-assignment    Pool Name: isp_1
  pool                Pool Name: (all pools in chain)
                      Out of Memory: 0
                      Out of Addresses: 9
                      Address total: 47
                      Addresses in use: 47
                      Address Usage (percent): 100

show network-access user@host> show network-access aaa statistics authentication
  aaa statistics      Requests received: 0
authentication        Accepts: 0
                      Rejects: 0
                      Challenges: 0

show network-access user@host> show network-access aaa statistics dynamic-requests
  aaa statistics      requests received: 0
dynamic-requests      processed successfully: 0
                      errors during processing: 0
                      silently dropped: 0
```

show network-access aaa subscribers

Syntax	<code>show network-access aaa subscribers</code> <code><logical-system <i>logical-system-name</i>></code> <code><routing-instance <i>routing-instance-name</i>></code> <code><statistics></code> <code><username></code>
Release Information	Command introduced in Junos OS Release 9.1.
Description	Display subscriber-specific AAA statistics.
Options	<p><code>logical-system <i>logical-system-name</i></code>—(Optional) List subscribers in the specific logical system.</p> <p><code>routing-instance <i>routing-instance-name</i></code>—(Optional) List subscribers for the specific routing instance. If you do not specify a routing instance name, the default routing instance is assumed.</p> <p><code>statistics</code>—(Optional) Display statistics for the subscriber events.</p> <p><code>username</code>—(Optional) Display information for the specified subscriber.</p>
Required Privilege Level	view
List of Sample Output	<p><code>show network-access aaa subscribers logical-system</code> on page 847</p> <p><code>show network-access aaa subscribers logical-system routing-instance</code> on page 847</p> <p><code>show network-access aaa subscribers statistics username</code> on page 847</p> <p><code>show network-access aaa subscribers username</code> on page 848</p>
Output Fields	Table 130 on page 846 lists the output fields for the show network-access aaa subscribers command. Output fields are listed in the approximate order in which they appear.

Table 130: show network-access aaa subscribers Output Fields

Field Name	Field Description
Challenge requests	Number of authentication requests challenged by the authentication server for this subscriber.
Challenge responses	Number of challenge responses sent by the subscriber to the authentication server.
START sent successfully	Number of accounting start requests generated by the AAA framework for this subscriber.
START send failures	Number of accounting start requests that failed to make it to the accounting server for this subscriber.
START ack received	Number of accounting start requests acknowledged by the accounting server for this subscriber.
INTERIM sent successfully	Number of accounting interim requests generated by the AAA framework for this subscriber.

Table 130: show network-access aaa subscribers Output Fields (*continued*)

Field Name	Field Description
INTERIM send failures	Number of accounting interim requests that failed to make it to the accounting server for this subscriber.
INTERIM ack received	Number of accounting interim requests acknowledged by the accounting server for this subscriber.
Requests received	Number of reauthentication requests received by the authentication server.
Successful responses	Number of successful reauthentication requests granted by the authentication server.
Aborts handled	Number of reauthentication requests aborted by the authentication server.
Service name	Name of the subscriber service.
Creation requests	Number of requests to create the service.
Deletion requests	Number of requests to delete the service.
Request timeouts	Number of times the service request was timed out.

Sample Output

```

show network-access user@host> show network-access aaa subscribers logical-system
aaa subscribers      Username      Client type  Logical system/Routing instance
logical-system      cbenson@addr.net  ppp          default
                    00010e020304.1231 dhcp          isp-bos-metro-12:isp-cmborg-12
                    conley@isp3.com   dhcp          default:isp-gtown-r3-00
                    0020df980102.2334 dhcp          isp-bos-metro-16:isp-cmborg-12

show network-access user@host> show network-access aaa subscribers logical-system isp-bos-metro-16
aaa subscribers      routing-instance isp-cmborg-12-32
logical-system      Username      Client type  Logical system/Routing instance
routing-instance    00010e020304.1231 dhcp          isp-bos-metro-12:isp-cmborg-12
                    conley@isp3.com   dhcp          default:isp-gtown-r3-00
                    0020df980102.2334 dhcp          isp-bos-metro-16:isp-cmborg-12

show network-access user@host> show network-access aaa subscribers statistics username 00010e020304.1231
aaa subscribers      Authentication statistics
statistics username  Challenge requests: 0
                    Challenge responses: 0
                    Accounting statistics
                        START sent successfully: 1
                        START send failures: 0
                        START ack received: 1
                        INTERIM sent successfully: 0
                        INTERIM send failures: 0
                        INTERIM ack received: 0
                    Re-authentication statistics
                        Requests received: 0
                        Successful responses: 0
                        Aborts handled: 0
                    Service statistics
                        Service name: filter-serv

```

```
Creation requests: 1
Deletion requests: 0
Request timeouts: 0
Service name: filter-serv2
Creation requests: 144
Deletion requests: 0
Request timeouts: 144
```

```
show network-access user@host> show network-access aaa subscribers username fred@isp5.net
aaa subscribers Logical system/Routing instance Client type Session uptime Accounting
username isp-bos-metro-16:isp-cmbrg-12 dhcp 01:12:56 on/volume
Service name Service type Quota Accounting
I-Cast volume 1200 Mbps on/volume+time
Voip on/volume
GamingBurst time 6000 secs on/volume
```


show network-access aaa subscribers session-id

Syntax	show network-access aaa subscribers session-id <i>session-id</i> <brief detail>
Release Information	Command introduced in Junos OS Release 10.0.
Description	Display information about the specified subscriber session.
Options	<i>session-id</i> —ID of the subscriber session. brief detail—(Optional) Display the specified level of information.
Required Privilege Level	view
List of Sample Output	show network-access aaa subscribers session-id brief on page 850 show network-access aaa subscribers session-id detail on page 850
Output Fields	Table 131 on page 849 lists the output fields for the show network-access aaa subscribers session-id command. Output fields are listed in the approximate order in which they appear.

Table 131: show network-access aaa subscribers session-id Output Fields

Field Name	Field Description
Type and Client type	Type of client.
Username	Name of the user logged in to the session.
Stripped username	The username after the domain has been removed.
AAA Logical system/Routing instance	Name of the routing instance, logical system name, or both used for the session.
Target Logical system/Routing instance	Logical system/routing instance to which the session is mapped.
Access-profile	Access profile used for AAA services for the session.
Session ID	ID of the subscriber session. The session ID value displayed under Service name is the service session ID.
Accounting Session ID	ID of the accounting session (RADIUS attribute 44). The ID appears in decimal or description format, as specified by the accounting-session-id-format statement.
Multi Accounting Session ID	Bundle ID for MLPPP sessions. Acct-Multi-Session-Id (RADIUS attribute 50) uses the value of the session database bundle session ID to enable RADIUS to link together multiple related sessions. The value of this field is zero when no MLPPP sessions exist.

Table 131: show network-access aaa subscribers session-id Output Fields (*continued*)

Field Name	Field Description
IP Address	IP address of the subscriber.
Authentication State	State of the subscriber authentication session: AuthInit , AuthStart , AuthChallenge , AuthRedirect , AuthClntRespWait , AuthAcctVolStatsAckWait , AuthAcctStopAckWait , AuthServCreateRespWait , AuthLogoutStart , AuthStateActive , AuthClntLogoutRespWait , AuthProfileUpdateWait , AuthProvisionRespWait , AuthProvisionServiceCreationWait
Gx-Plus Provisioning State	State of Gx-Plus provisioning: <ul style="list-style-type: none"> ignored—Subscriber has no IPv4 address or NAS-Port-ID. in-progress—Provisioning is in progress. logout—Subscriber logout is in progress. logout-done—Logout response has been received. response-received—Provisioning response has been received.
Accounting State	State of the subscriber accounting session: Acc-Init , Acc-Start-Sent , Imm-Update-Stats-Pending , Acc-Interim-Sent , Acc-Stop-Stats-Pending , Acc-Stop-Sent , Acc-Stop-On-Fail-Deny-Sent , Acc-Stop-Ackd
Service name	Name of the attached service or policy. For RADIUS-activated services, this field displays the actual service name. For JSRC-activated policies, this field displays the policy name.
Service State	State of the service provided in the subscriber session.
Session ID	Subscriber session ID.
Session uptime	How long the session has been up, in <i>HH:MM:SS</i> .

Sample Output

```

show network-access aaa subscribers session-id brief
user@host> show network-access aaa subscribers session-id 6 brief
Logical system/Routing instance  Client type  Session uptime  Accounting
default:default                 dhcp      00:01:29       on/time
Service name                    Service type  Quota           Accounting
filter-service                  -na-         -na-            off
1337994190863204450            -na-         -na-            off

```

```

show network-access aaa subscribers session-id detail
user@host> show network-access aaa subscribers session-id 5 detail
Type: dhcp
Username: larry@isp5.net
Stripped username: larry
AAA Logical system/Routing instance: default:default
Target Logical system/Routing instance: default:retail-onlinecompany-ca
Access-profile:retailer-onlinecompany-sjc
Session ID: 5
Accounting Session ID: jnpr ge-1/0/0.101:1
Multi Accounting Session ID: 0
IP Address: 192.168.44.104
Authentication State: AuthStateActive
Gx-Plus Provisioning State: response-received

```

Accounting State: Acc-Interim-Sent
Service name: filter-service-1
Service State: SvcActive
Session ID: 7
Session uptime: 00:01:33
Service name: 1337994190863204450
Service State: SvcActive
Session ID: 8
Session uptime: 00:01:33

show network-access address-assignment pool

Syntax	show network-access address-assignment pool <i>pool-name</i> <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.0.
Description	Display state information for each address-assignment pool.
Options	<p>none—Display information about clients that have obtained addresses from the address-assignment pool.</p> <p><i>pool pool-name</i>—Display information about the specified address-assignment pool.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Perform this operation on the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Perform this operation on the specified routing instance.</p>
Required Privilege Level	view and system
List of Sample Output	show network-access address-assignment pool on page 852
Output Fields	Table 132 on page 852 lists the output fields for the show address-assignment pool command. Output fields are listed in the approximate order in which they appear.

Table 132: show network-access address-assignment pool Output Fields

Field Name	Field Description
IP address	IP address of the client.
Hardware address	MAC address of the client.
Type	Type of client.

Sample Output

```

show network-access address-assignment pool
user@host> show network-access address-assignment pool sunnywest logical-system ls1
routing-instance routinst2
IP address      Hardware address  Type
192.168.2.1     00:05:1b:00:b9:01 DHCP
192.168.2.2     00:05:1b:00:b9:02 DHCP
192.168.2.3     00:05:1b:00:b9:03 DHCP
192.168.2.4     00:05:1b:00:b9:04 DHCP

```

show ntp associations

Syntax	<code>show ntp associations</code> <code><no-resolve></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display Network Time Protocol (NTP) peers and their state.
Options	<code>none</code> —Display NTP peers and their state. <code>no-resolve</code> —(Optional) Suppress symbolic addressing.
Required Privilege Level	<code>view</code>
Related Documentation	<ul style="list-style-type: none"> • show ntp status on page 855
List of Sample Output	show ntp associations on page 854 show ntp associations (QFX Series) on page 854
Output Fields	Table 133 on page 853 describes the output fields for the show ntp associations command. Output fields are listed in the approximate order in which they appear.

Table 133: show ntp associations Output Fields

Field Name	Field Description
remote	Address or name of the remote NTP peer.
refid	Reference identifier of the remote peer. If the reference identifier is not known, this field shows a value of 0.0.0.0 .
st	Stratum of the remote peer.
t	Type of peer: b (broadcast), l (local), m (multicast), or u (unicast).
when	When the last packet from the peer was received.
poll	Polling interval, in seconds.
reach	Reachability register, in octal.
delay	Current estimated delay of the peer, in milliseconds.
offset	Current estimated offset of the peer, in milliseconds.
disp	Current estimated dispersion of the peer, in milliseconds.

Table 133: show ntp associations Output Fields (*continued*)

Field Name	Field Description
<i>peer-name</i>	<p>Peer name and status of the peer in the clock selection process:</p> <ul style="list-style-type: none"> • space—Discarded because of a high stratum value or failed sanity checks. • x—Designated "falseticker" by the intersection algorithm. • .—Culled from the end of the candidate list. • — —Discarded by the clustering algorithm. • +—Included in the final selection set. • #—Selected for synchronization, but the distance exceeds the maximum. • *—Selected for synchronization. • o—Selected for synchronization, but the packets-per-second (pps) signal is in use.

Sample Output

```

show ntp associations user@host> show ntp associations
      remote          refid      st t when poll reach  delay  offset  disp
=====
*wolfe-gw.junipe tick.ucla.edu    2 u  43   64  377    1.86   0.319   0.08

show ntp associations user@switch> show ntp associations
(QFX Series)         remote          refid      st t when poll reach  delay  offset  disp
=====
*wolfe-gw.junipe tick.ucla.edu    2 u  43   64  377    1.86   0.319   0.08

```

show ntp status

Syntax	show ntp status <no-resolve>
Release Information	Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the values of internal variables returned by Network Time Protocol (NTP) peers.
Options	none—Display the values of internal variables returned by NTP peers. no-resolve—(Optional) Suppress symbolic addressing.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show ntp associations on page 853
List of Sample Output	show ntp status on page 855

Sample Output

```

show ntp status  user@host> show ntp status
                  status=0644 leap_none, sync_ntp, 4 events, event_peer/strat_chg,
                  version="ntpd 4.1.0-a Fri Jun 24 06:40:56 GMT 2005 (1)",
                  processor="i386", system="JUNOS7.4-20050624.0", leap=00, stratum=2,
                  precision=-28, rootdelay=6.849, rootdispersion=10.615, peer=38788,
                  refid=ntp-server.company-a.net,
                  reftime=c66705d9.06ee0f3c Fri, Jun 24 2005 15:21:13.027, poll=6,
                  clock=c6670602.cf6db940 Fri, Jun 24 2005 15:21:54.810, state=4,
                  offset=0.205, frequency=75.911, jitter=0.396, stability=0.005

```

show static-subscribers sessions

Syntax	show static-subscribers sessions <group <i>group-name</i> > <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display information about the subscriber sessions for all static subscribers, all static subscribers on an interface group, or a single subscriber on an interface.
Options	<i>group-name</i> —(Optional) Display session information for static subscribers on all interfaces in the specified group. <i>interface-name</i> —(Optional) Display session information for the static subscriber on the specified in the specified group.
Required Privilege Level	view
List of Sample Output	show static-subscribers sessions on page 857 show static-subscribers sessions group on page 857 show static-subscribers sessions interface on page 857
Output Fields	Table 134 on page 856 lists the output fields for the show static-subscribers sessions command. Output fields are listed in the approximate order in which they appear.

Table 134: show static-subscribers sessions Output Fields

Field Name	Field Description	Level of Output
Interface	Name of the interface.	None specified
State	State of the static subscriber session: <ul style="list-style-type: none"> • authenticating—Subscriber is being authenticated. • activating client—Client is being activated. • activating services—Subscriber services are being activated. • deactivating client—Client is being deactivated. • deactivating services—Subscriber services are being deactivated. • initializing—Process is initializing. • logged in—Subscriber is logged in to the interface. • logged out—Subscriber is logged out of the interface. • processing statistics—Session statistics are being processed. • terminating session—Subscriber session is being terminated. 	None specified
Group	Name of the interface group to which the interface belongs.	None specified
User Name	Username used for the static subscriber. Can be the interface name.	None specified

Sample Output

```

show static-subscribers sessions user@host> show static-subscribers sessions
Static subscriber information:
Interface      State      Group      User Name
ge-9/1/0.1     logged out SS1         ge-9-1-0.1
ge-9/1/0.10    logged out SS1         ge-9-1-0.10
ge-9/1/0.100   logged out SS1         ge-9-1-0.100
ge-9/1/0.11    logged out SS1         ge-9-1-0.11
ge-9/1/0.12    logged out SS1         ge-9-1-0.12
ge-9/1/0.13    logged out SS1         ge-9-1-0.13
ge-9/1/0.14    logged out SS1         ge-9-1-0.14
ge-9/1/0.15    logged out SS1         ge-9-1-0.15
ge-9/1/0.16    logged out SS1         ge-9-1-0.16
ge-9/1/0.17    logged out SS1         ge-9-1-0.17
ge-9/1/0.18    logged out SS1         ge-9-1-0.18
ge-9/1/0.19    logged out SS1         ge-9-1-0.19
ge-9/1/0.2     logged out SS1         ge-9-1-0.2
ge-9/1/0.20    logged out SS1         ge-9-1-0.20
ge-9/1/0.21    logged out SS1         ge-9-1-0.21

show static-subscribers sessions group boston user@host> show static-subscribers sessions group boston
Interface      State      Group      User Name
ge-0/0/1.1     logged in  boston     ge-0/0/1.1
ge-0/0/1.2     logged in  boston     ge-0/0/1.2

show static-subscribers sessions interface ge-0/0/1.1 user@host> show static-subscribers sessions interface ge-0/0/1.1
Interface      State      Group      User Name
ge-0/0/1.1     logged in  foo        ge-0/0/1.1

```

show subscribers

Syntax `show subscribers`
 `<address address>`
 `<client-type client-type>`
 `<interface interface>`
 `<logical-system logical-system>`
 `<mac-address mac-address>`
 `<profile-name profile-name>`
 `<routing-instance routing-instance>`
 `<stacked-vlan-id stacked-vlan-id>`
 `<subscriber-state subscriber-state>`
 `<vlan-id vlan-id>`
 `<count | detail | extensive | summary (all | logical-system logical-system | routing-instance routing-instance) | terse>`

Release Information Command introduced in Junos OS Release 9.3.
 Command introduced in Junos OS Release 9.3 for EX Series switches.
 client-type, **mac-address**, **subscriber-state**, **extensive**, and **summary** options introduced in Junos OS Release 10.2.
 count option usage with other options introduced in Junos OS Release 10.2.
 Command introduced in Junos OS Release 11.1 for the QFX Series.

Description Display information for active subscribers.

Options *address*—(Optional) Display subscribers whose IP address matches the specified address.

client-type—(Optional) Display subscribers whose client type matches the specified client type (DHCP, L2TP, PPP, PPPOE, or VLAN).

count—(Optional) Display the count of total subscribers and active subscribers for any specified option. You can use the count option alone or with the **address**, **client-type**, **interface**, **logical-system**, **mac-address**, **profile-name**, **routing-instance**, **stacked-vlan-id**, **subscriber-state**, and **vlan-id** options.

interface—(Optional) Display subscribers whose interface matches the specified interface.

logical system—(Optional) Display subscribers whose logical system matches the specified logical system.

mac-address—(Optional) Display subscribers whose MAC address matches the specified MAC address.

profile name—(Optional) Display subscribers whose dynamic profile matches the specified profile name.

routing instance—(Optional) Display subscribers whose routing instance matches the specified routing instance.

subscriber-state—(Optional) Display subscribers whose subscriber state matches the specified subscriber state (ACTIVE, CONFIGURED, INIT, TERMINATED, or TERMINATING).

vlan-id—(Optional) Display subscribers whose VLAN ID matches the specified VLAN ID.

stacked-vlan-id—(Optional) Display subscribers whose stacked VLAN ID matches the specified stacked VLAN ID.

detail | extensive | terse—(Optional) Display the specified level of output.

summary—(Optional) Display summary output.



NOTE: Due to display limitations, logical system and routing instance output values are truncated when necessary.

Required Privilege Level view

List of Sample Output

- show subscribers on page 861
- show subscribers detail (IPv4) on page 861
- show subscribers detail (IPv6) on page 862
- show subscribers detail (IPv6 Static Demux Interface) on page 862
- show subscribers detail (Tunneled Subscriber) on page 862
- show subscribers logical-system on page 862
- show subscribers count on page 862
- show subscribers routing-instance inst1 count on page 862
- show subscribers vlan-id on page 862
- show subscribers vlan-id detail on page 863
- show subscribers stacked-vlan-id detail on page 863
- show subscribers stacked-vlan-id vlan-id detail (Combined Output) on page 863
- show subscribers stacked-vlan-id vlan-id interface detail (Combined Output for a Specific Interface) on page 863
- show subscribers client-type dhcp detail on page 863
- show subscribers extensive on page 864
- show subscribers summary on page 864
- show subscribers summary all on page 864
- show subscribers terse on page 865

Output Fields Table 135 on page 859 lists the output fields for the **show subscribers** command. Output fields are listed in the approximate order in which they appear.

Table 135: show subscribers Output Fields

Field Name	Field Description
User Name	Name of subscriber.
Type	Subscriber client type (DHCP, L2TP, PPP, PPPoE, STATIC-INTERFACE, VLAN).
IP Address	Subscriber IPv4 address.
IP Netmask	Subscriber IP netmask.

Table 135: show subscribers Output Fields (*continued*)

Field Name	Field Description
IPv6 Address	Subscriber IPv6 address.
IPv6 Prefix	Subscriber IPv6 prefix.
IPv6 Prefix Length	Length of the subscriber IPv6 prefix.
Logical System	Logical system associated with the subscriber.
Routing Instance	Routing instance associated with the subscriber.
Interface	Interface associated with the subscriber. The router displays subscribers whose interface matches or begins with the specified interface.
Interface Type	Whether the subscriber interface is static or dynamic.
Dynamic Profile Name	Dynamic profile used for the subscriber.
MAC Address	MAC address associated with the subscriber.
State	Current state of the subscriber session (Init, Configured, Active, Terminating, Terminated, Tunneled).
VLAN Id	VLAN ID associated with the subscriber in the form <i>tpid.vlan-id</i> .
Stacked VLAN Id	Stacked VLAN ID associated with the subscriber in the form <i>tpid.vlan-id</i> .
RADIUS Accounting ID	RADIUS accounting ID associated with the subscriber.
Agent Circuit ID	Option 82 agent circuit ID associated with the subscriber.
Agent Remote ID	Option 82 agent remote ID associated with the subscriber.
DHCP Relay IP Address	IP address used by the DHCP relay agent.
Login Time	Date and time at which the subscriber logged in.
Session ID	ID number for a subscriber service session.
Service Sessions	Number of service sessions (that is, a service activated using RADIUS CoA) associated with the subscribers.
Service Session Name	Service session profile name.
Session Timeout (seconds)	Number of seconds of access provided to the subscriber before the session is automatically terminated.
Idle Timeout (seconds)	Number of seconds subscriber can be idle before the session is automatically terminated.

Table 135: show subscribers Output Fields (*continued*)

Field Name	Field Description
IPv4 Input Filter Name	Name assigned to the IPv4 input filter (client or service session).
IPv4 Output Filter Name	Name assigned to the IPv4 output filter (client or service session).
IPv6 Input Filter Name	Name assigned to the IPv6 input filter (client or service session).
IPv6 Output Filter Name	Name assigned to the IPv6 output filter (client or service session).
IFL Input Filter Name	Name assigned to the logical interface input filter (client or service session).
IFL Output Filter Name	Name assigned to the logical interface output filter (client or service session).
Subscribers by State	<p>Number of subscribers summarized by state. The summary information includes the following:</p> <ul style="list-style-type: none"> • Init—Number of subscriber currently in the initialization state. • Configured—Number of configured subscribers. • Active—Number of active subscribers. • Terminating—Number of subscribers currently terminating. • Terminated—Number of terminated subscribers. <p>Summary information includes subscriber counts per state and the total number of subscribers.</p>
Subscribers by Client Type	Number of subscribers summarized by client type. Client types can include DHCP, VLAN, PPP, PPPOE, and L2TP. Summary information includes subscriber counts per client type and the total number of subscribers.
Subscribers by LS:RI	Number of subscribers summarized by logical system:routing instance (LS:RI) combination. Summary information includes subscriber counts per LS:RI and the total number of subscribers.

Sample Output

```

show subscribers user@host> show subscribers
Interface      IP Address/VLAN ID  User Name      LS:RI
ge-1/3/0.1073741824  100                WHOLESALER-CLIENT default:default
demux0.1073741824    100.0.0.10         RETAILER1-CLIENT test1:retailer1
demux0.1073741825    101.0.0.3          RETAILER2-CLIENT test1:retailer2
demux0.1073741826    102.0.0.3          RETAILER2-CLIENT test1:retailer2

show subscribers user@host> show subscribers detail
detail (IPv4)   Type: DHCP
                IP Address: 100.20.9.7
                IP Netmask: 255.255.0.0
                Logical System: default
                Routing Instance: default
                Interface: demux0.1073744127
                Interface type: Dynamic
                Dynamic Profile Name: dhcp-demux-prof
                MAC Address: 00:10:95:00:00:98
                State: Active
                Radius Accounting ID: jnpr :2304
                Session Timeout (seconds): 3600

```

```

Idle Timeout (seconds): 600
Login Time: 2009-08-25 14:43:52 PDT
Service Sessions: 2

show subscribers detail (IPv6) user@host> show subscribers detail
Type: DHCP
IPv6 Address: 1080:0:0:0:8:800:200C:417A
IPv6 Prefix: fec0:1:1:1::/128
Logical System: default1
Routing Instance: default
Interface: demux0.1073744127
Interface type: Dynamic
Dynamic Profile Name: dhcp-demux-prof
MAC Address: 00:10:95:00:00:98
State: Active
Radius Accounting ID: jnpr :2304
Login Time: 2009-08-25 14:43:52 PDT
Service Sessions: 2

show subscribers detail (IPv6 Static Demux Interface) user@host> show subscribers detail
Type: STATIC-INTERFACE
User Name: demux0.1@jnpr.net
IPv6 Prefix: 1:2:3:4:5:6:7:aa/128
Logical System: default
Routing Instance: default
Interface: demux0.1
Interface type: Static
Dynamic Profile Name: junos-default-profile
State: Active
Radius Accounting ID: 185
Login Time: 2010-05-18 14:33:56 EDT

show subscribers detail (Tunneled Subscriber) user@host> show subscribers detail
Type: PPPoE
User Name: user1@example.com
Logical System: default
Routing Instance: default
Interface: pp0.1
State: Active, Tunneled
Radius Accounting ID: 512

show subscribers logical-system user@host> show subscribers logical-system test1 terse
Interface      IP Address/VLAN ID  User Name      LS:RI
demux0.1073741825  101.0.0.3          RETAILER1-CLIENT test1:retailer1
demux0.1073741826  102.0.0.3          RETAILER2-CLIENT test1:retailer2

show subscribers count user@host> show subscribers count
Total Subscribers: 188, Active Subscribers: 188

show subscribers routing-instance inst1 count user@host> show subscribers routing-instance inst1 count
Total Subscribers: 188, Active Subscribers: 183

show subscribers vlan-id user@host> show subscribers vlan-id 100
Interface      IP Address      User Name
ge-1/0/0.1073741824
ge-1/2/0.1073741825

```

```

show subscribers      user@host> show subscribers vlan-id 100 detail
vlan-id detail      Type: VLAN
                      Interface: ge-1/0/0.1073741824
                      Interface type: Dynamic
                      Dynamic Profile Name: vlan-prof-tpid
                      State: Active
                      VLAN Id: 100
                      Login Time: 2009-03-11 06:48:54 PDT

                      Type: VLAN
                      Interface: ge-1/2/0.1073741825
                      Interface type: Dynamic
                      Dynamic Profile Name: vlan-prof-tpid
                      State: Active
                      VLAN Id: 100
                      Login Time: 2009-03-11 06:48:54 PDT

show subscribers      user@host> show subscribers stacked-vlan-id 101 detail
stacked-vlan-id detail Type: VLAN
                      Interface: ge-1/2/0.1073741824
                      Interface type: Dynamic
                      Dynamic Profile Name: svlan-prof
                      State: Active
                      Stacked VLAN Id: 0x8100.101
                      VLAN Id: 0x8100.100
                      Login Time: 2009-03-27 11:57:19 PDT

show subscribers      user@host> show subscribers stacked-vlan-id 101 vlan-id 100 detail
stacked-vlan-id vlan-id Type: VLAN
detail (Combined      Interface: ge-1/2/0.1073741824
Output)              Interface type: Dynamic
                      Dynamic Profile Name: svlan-prof
                      State: Active
                      Stacked VLAN Id: 0x8100.101
                      VLAN Id: 0x8100.100
                      Login Time: 2009-03-27 11:57:19 PDT

show subscribers      user@host> show subscribers stacked-vlan-id 101 vlan-id 100 interface ge-1/2/0.* detail
stacked-vlan-id vlan-id Type: VLAN
interface detail      Interface: ge-1/2/0.1073741824
(Combined Output for Interface type: Dynamic
a Specific Interface) Dynamic Profile Name: svlan-prof
                      State: Active
                      Stacked VLAN Id: 0x8100.101
                      VLAN Id: 0x8100.100
                      Login Time: 2009-03-27 11:57:19 PDT

show subscribers      user@host> show subscribers client-type dhcp detail
client-type dhcp detail Type: DHCP
                      IP Address: 100.20.9.7
                      IP Netmask: 255.255.0.0
                      Logical System: default
                      Routing Instance: default
                      Interface: demux0.1073744127
                      Interface type: Dynamic
                      Dynamic Profile Name: dhcp-demux-prof
                      MAC Address: 00:10:95:00:00:98
                      State: Active
                      Radius Accounting ID: jnpr :2304
                      Login Time: 2009-08-25 14:43:52 PDT

```

```
Type: DHCP
IP Address: 100.20.10.7
IP Netmask: 255.255.0.0
Logical System: default
Routing Instance: default
Interface: demux0.1073744383
Interface type: Dynamic
Dynamic Profile Name: dhcp-demux-prof
MAC Address: 00:10:94:00:01:f3
State: Active
Radius Accounting ID: jnpr :2560
Login Time: 2009-08-25 14:43:56 PDT
```

**show subscribers
extensive**

```
user@host> show subscribers extensive
Type: DHCP
IPv6 Prefix: 2001::40:0:0:0/74
IPv6 Prefix Length: 64
Logical System: default
Routing Instance: default
Interface: demux0.1073741825
Interface type: Dynamic
Dynamic Profile Name: dhcp-demux-prof
State: Active
Radius Accounting ID: jnpr :2
Agent Circuit ID: abc
Remote Circuit ID: xyz
Login Time: 2010-03-31 14:27:19 PDT
Service Sessions: 1
IPv6 Input Filter Name: demux0-inet6-in
Session ID: 213
Service Session Name: service-profile
IPv6 Input Filter Name: dfwd1-demux.1073741825-in
```

**show subscribers
summary**

```
user@host> show subscribers summary

Subscribers by State
Init          3
Configured    2
Active       183
Terminating   2
Terminated    1

TOTAL        191

Subscribers by Client Type
DHCP         107
PPP           76
VLAN          8

TOTAL        191
```

**show subscribers
summary all**

```
user@host> show subscribers summary all

Subscribers by State
Init          3
Configured    2
Active       183
Terminating   2
Terminated    1
```


TOTAL 191

Subscribers by Client Type

DHCP 107
PPP 76
VLAN 8

TOTAL 191

Subscribers by LS:RI

default:default 1
default:ri1 28
default:ri2 16
ls1:default 22
ls1:riA 38
ls1:riB 44
logsysX:routinstY 42

TOTAL 191

show subscribers terse

user@host> **show subscribers summary terse**

Interface	IP Address/VLAN ID	User Name	LS:RI
ge-1/3/0.1073741824	100		default:default
demux0.1073741824	100.0.0.10	WHOLESALE-CLIENT	default:default
demux0.1073741825	101.0.0.3	RETAILER1-CLIENT	test1:retailer1
demux0.1073741826	102.0.0.3	RETAILER2-CLIENT	test1:retailer2

show system alarms

Syntax	show system alarms
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display active system alarms.
Options	This command has no options.
Additional Information	System alarms are preset. They include a configuration alarm that appears when no rescue configuration alarm is set and a license alarm that appears when a software feature is configured and no valid license is configured for the feature. For more information about system alarms, see the Junos OS System Basics Configuration Guide . In Junos OS release 11.1 and later, alarms for fans also show the slot number of the fans in the CLI output.
Required Privilege Level	admin
List of Sample Output	show system alarms on page 866 show system alarms (Fan Tray) on page 866 show system alarms (QFX Series) on page 866

Sample Output

show system alarms	<pre> user@host> show system alarms 2 alarms currently active Alarm time Class Description 2005-02-24 17:29:34 UTC Minor IPsec VPN tunneling usage requires a license 2005-02-24 17:29:34 UTC Minor Rescue configuration is not sent </pre>
show system alarms (Fan Tray)	<pre> user@host> show system alarms 4 alarms currently active Alarm time Class Description 2010-11-11 20:27:38 UTC Major Side Fan Tray 7 Failure 2010-11-11 20:27:13 UTC Minor Side Fan Tray 7 Overspeed 2010-11-11 20:27:13 UTC Major Side Fan Tray 5 Failure 2010-11-11 20:27:13 UTC Major Side Fan Tray 0 Failure </pre>
show system alarms (QFX Series)	<pre> user@switches> show system alarms 2 alarms currently active Alarm time Class Description 2005-02-24 17:29:34 UTC Minor Rescue configuration is not sent </pre>

show system audit

Syntax	show system audit <root-only>
Syntax (EX Series, QFX Series and MX Series)	show system audit <all-members> <local> <member <i>member-id</i> > <root-only>
Syntax (TX Matrix Router)	show system audit <all-lcc lcc <i>number</i> scc> <root-only>
Syntax (TX Matrix Plus Router)	show system audit <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <root-only>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the state and checksum values for file systems.
Options	<p>none—Display the state and checksum values for all file systems.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display file system MD5 hash and permissions information for all of the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display file system MD5 hash and permissions information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display file system MD5 hash and permissions information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200, QFX Series, and MX Series routers only) (Optional) Display file system MD5 hash and permissions information on all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display file system MD5 hash and permissions information for a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, display file system MD5 hash and permissions information for a specific T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200, QFX Series, and MX Series routers only) (Optional) Display file system MD5 hash and permissions information on the local Virtual Chassis member.</p>

member member-id—(EX4200, QFX Series, and MX Series routers only) (Optional) Display file system MD5 hash and permissions information on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

root-only—(Optional) Check only the root (/) file system.

scc—(TX Matrix routers only) (Optional) Display file system MD5 hash and permissions information for the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Display file system MD5 hash and permissions information for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information To redirect the output to a file, issue the following command:

```
ssh device-name 'show system audit root-only' > output-file
```

If you save the output of the **show system audit root-only** command to a file, you can compare it to subsequent output from the command to determine whether anything has changed.

By default, when you issue the **show system audit** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. If you issue the command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level admin

List of Sample Output [show system audit root-only on page 868](#)
[show system audit lcc \(TX Matrix Router\) on page 869](#)
[show system audit lcc \(TX Matrix Plus Router\) on page 871](#)
[show system audit root-only \(QFX Series\) on page 872](#)

Sample Output

```
show system audit root-only
user@host> show system audit root-only
#          user: root
#          machine: my-host
#          tree: /
date: Fri Feb 11 21:21:46 2000

# .
/set type=file uid=0 gid=0 mode=0755 nlink=1
.          type=dir nlink=23 size=1024 time=950252640.0
.cshrc     uid=3 gid=7 mode=0644 size=177 time=939182975.0 \
md5digest=f414e06fea6bd646244b98e13d6e6226
.kernel.jkernel.backup \
mode=0744 size=1934552 time=944688902.0 \
md5digest=2c343cf0bd9fea8f04f78604feed7aa4
```

```
.profile      uid=3 gid=7 mode=0644 nlink=2 size=173 time=939182975.0 \
              md5digest=55a1e3c6c67789c9d3a1cce1ea39f670
COPYRIGHT    uid=3 gid=7 mode=0444 size=3425 time=939182975.0 \
              md5digest=7df8bc77dcee71382ea73eb0ec6a9243
boot.config  mode=0644 size=3 time=945902618.0 \
              md5digest=93d722493ed38477338a1405d7dcbb40
boot.help    uid=3 gid=7 mode=0444 size=411 time=939182876.0 \
              md5digest=9b7126385734bcae753f4179ab59d8e5
compat       type=link mode=0777 size=11 time=915149058.0 \
              link=/usr/compat
kernel       mode=0444 size=1947607 time=950230892.0 \
              md5digest=1a2a8aff2fec678a918ba0d6bf063980
kernel.avr   uid=1112 size=1947642 time=950252597.0 \
              md5digest=82e1637682d58ec28964dfee7fccb62e
kernel.config \
              mode=0644 size=0 time=915149058.0 \
              md5digest=d41d8cd98f00b204e9800998ecf8427e
sys          type=link mode=0777 size=11 time=915149029.0 \
              link=usr/src/sys
```

show system audit lcc
(TX Matrix Router)

```
user@host> show system audit lcc 2
lcc2-re0:
```

```
-----
#          user: root
#          machine: rodin-lcc2
#          tree: /
#          date: Mon Sep 13 11:55:33 2004

# .
/set type=file uid=0 gid=0 mode=0555 nlink=1 flags=none
.      type=dir nlink=20 size=512 time=1094982121.0
COPYRIGHT mode=0644 size=4735 time=986012708.0 \
          md5digest=78396df1404ad742e6eb1be28f0cd63b
kernel    type=link mode=0700 size=17 time=1090266262.0 \
          link=/packages/jkernel

# ./altconfig
altconfig type=dir nlink=2 size=512 time=1089801320.0
# ./altconfig
..

# ./altroot
altroot   type=dir nlink=2 size=512 time=1089801320.0
# ./altroot
..

# ./b
b         type=dir mode=0755 nlink=2 size=512 time=1093961429.0
# ./b
..

# ./bin
/set type=file uid=0 gid=0 mode=0700 nlink=1 flags=none
bin      type=dir mode=0755 nlink=2 size=512 time=1089843059.0
[        type=link size=28 time=1090266270.0 \
          link=/packages/mnt/jbase/bin/test
cat      type=link size=27 time=1090266270.0 \
          link=/packages/mnt/jbase/bin/cat
chmod    type=link size=29 time=1090266270.0 \
```

```

        link=/packages/mnt/jbase/bin/chmod
cp      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/cp
csch    type=link size=27 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/csh
date    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/date
dd      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/dd
df      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/df
echo    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/echo
ed      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/ed
expr    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/expr
hostname type=link size=32 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/hostname
kill    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/kill
ln      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/ln
ls      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/ls
mkdir   type=link size=29 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/mkdir
mv      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/mv
ps      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/ps
pwd     type=link size=27 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/pwd
rcp     type=link size=27 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/rcp
red     type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/ed
rm      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/rm
rmdir   type=link size=29 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/rmdir
sh      type=link size=26 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/sh
sleep   type=link size=29 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/sleep
stty    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/stty
sync    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/sync
tcsh    type=link size=27 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/csh
test    type=link size=28 time=1090266270.0 \
        link=/packages/mnt/jbase/bin/test
# ./bin
..

# ./boot
/set type=file uid=0 gid=0 mode=0444 nlink=1 flags=none
boot    type=dir mode=0555 nlink=3 size=512 time=1095069935.0
        boot0    size=512 time=1094978286.0 \

```

```

boot1      md5digest=6f780822dd4ae482a20462b66e542cca
           mode=0555 size=512 time=1094978294.0 \
boot2      md5digest=8d112b09df342cd0b60fdb9bdcde8e07
           mode=0555 size=7680 time=1094978294.0 \
           md5digest=28eb58c4068c6b85717e1484f9e028e4
cdboot     mode=0555 size=165888 time=1094978298.0 \
           md5digest=1474c6b800dfc82ba552d7c36116d07d
kgzldr.o   size=5996 time=1094982121.0 \
           md5digest=c53dc948eb07e2ea4eb0413e4c4634a3
loader     mode=0555 size=163840 time=1094978298.0 \
           md5digest=82d9dc2d31033476bfb61bb7264c4fed
loader.4th size=9237 time=986013631.0 \
           md5digest=43144391465ad50267d31e0a320be1de
...

```

show system audit lcc
(TX Matrix Plus
Router)

```

user@host> show system audit all-chassis

sfc0-re0:
-----
#          user: root
#          machine: finalfive
#          tree: /
#          date: Mon May 18 00:13:16 2009

# .
/set type=file uid=0 gid=0 mode=0755 nlink=1 flags=none
.
  COPYRIGHT  type=dir nlink=23 size=512 time=1242347096.0
             mode=0644 size=6196 time=1168587741.0 \
             md5digest=bbad415e1c29bbdd9b383537100412c
  kernel     type=link size=17 time=1242347011.0 link=/packages/jkernel
  staging     type=link mode=0777 size=8 time=1242346935.0 link=/var/tmp

# ./snap
.snap       type=dir mode=0775 nlink=2 size=512 time=1242346922.0
# ./snap
..

# ./altconfig
altconfig   type=dir mode=0500 nlink=2 size=512 time=1242319843.0
# ./altconfig
..

# ./altroot
altroot     type=dir mode=0500 nlink=2 size=512 time=1242319843.0
# ./altroot
..

# ./bin
bin         type=dir nlink=2 size=512 time=1242346944.0
  \133      type=link size=28 time=1242346942.0 \
            link=/packages/mnt/jbase/bin/test
  cat       type=link size=27 time=1242346941.0 \
            link=/packages/mnt/jbase/bin/cat
  chflags   type=link size=31 time=1242346941.0 \
            link=/packages/mnt/jbase/bin/chflags
  chmod     type=link size=29 time=1242346941.0 \
            link=/packages/mnt/jbase/bin/chmod
  cp        type=link size=26 time=1242346941.0 \

```

```

csh          link=/packages/mnt/jbase/bin/cp
             type=link size=27 time=1242346941.0 \
date         link=/packages/mnt/jbase/bin/csh
             type=link size=28 time=1242346941.0 \
dd          link=/packages/mnt/jbase/bin/date
             type=link size=26 time=1242346941.0 \
df          link=/packages/mnt/jbase/bin/dd
             type=link size=26 time=1242346941.0 \
echo        link=/packages/mnt/jbase/bin/df
             type=link size=28 time=1242346941.0 \
ed          link=/packages/mnt/jbase/bin/echo
             type=link size=26 time=1242346941.0 \
expr        link=/packages/mnt/jbase/bin/ed
             type=link size=28 time=1242346941.0 \
hostname    link=/packages/mnt/jbase/bin/expr
             type=link size=32 time=1242346941.0 \
kill        link=/packages/mnt/jbase/bin/hostname
             type=link size=28 time=1242346941.0 \
ln          link=/packages/mnt/jbase/bin/kill
             type=link size=26 time=1242346941.0 \
ls          link=/packages/mnt/jbase/bin/ln
             type=link size=26 time=1242346941.0 \
mkdir       link=/packages/mnt/jbase/bin/ls
             type=link size=29 time=1242346941.0 \
mv          link=/packages/mnt/jbase/bin/mkdir
             type=link size=26 time=1242346941.0 \
pax         link=/packages/mnt/jbase/bin/mv
             type=link size=27 time=1242346944.0 \
ps          link=/packages/mnt/jbase/bin/pax
             type=link size=26 time=1242346941.0 \
pwd         link=/packages/mnt/jbase/bin/ps
             type=link size=27 time=1242346941.0 \
rcp         link=/packages/mnt/jbase/bin/pwd
             type=link size=27 time=1242346942.0 \
red         link=/packages/mnt/jbase/bin/rcp
             type=link size=26 time=1242346941.0 \
rm          link=/packages/mnt/jbase/bin/red
             type=link size=26 time=1242346942.0 \
rmdir       link=/packages/mnt/jbase/bin/ed
             type=link size=29 time=1242346942.0 \
sh          link=/packages/mnt/jbase/bin/rmdir
             type=link size=26 time=1242346942.0 \
sleep       link=/packages/mnt/jbase/bin/sh
             type=link size=29 time=1242346942.0 \
stty        link=/packages/mnt/jbase/bin/sleep
             type=link size=28 time=1242346942.0 \
sync        link=/packages/mnt/jbase/bin/stty
             type=link size=28 time=1242346942.0 \
tcsh        link=/packages/mnt/jbase/bin/sync
             type=link size=27 time=1242346941.0 \
test        link=/packages/mnt/jbase/bin/tcsh
             type=link size=28 time=1242346942.0 \
# ./bin     link=/packages/mnt/jbase/bin/test
...

```

```

show system audit user@switch> show system audit root-only
root-only (QFX Series)

```

```

#      user: root
#      machine: my-host
#      tree: /
date: Fri Feb 11 21:21:46 2000

```



```

# .
/set type=file uid=0 gid=0 mode=0755 nlink=1
.      type=dir nlink=23 size=1024 time=950252640.0
.cshrc  uid=3 gid=7 mode=0644 size=177 time=939182975.0 \
        md5digest=f414e06fea6bd646244b98e13d6e6226
.kernel.jkernel.backup \
        mode=0744 size=1934552 time=944688902.0 \
        md5digest=2c343cf0bd9fea8f04f78604feed7aa4
.profile uid=3 gid=7 mode=0644 nlink=2 size=173 time=939182975.0 \
        md5digest=55a1e3c6c67789c9d3a1cce1ea39f670
COPYRIGHT uid=3 gid=7 mode=0444 size=3425 time=939182975.0 \
        md5digest=7df8bc77dcee71382ea73eb0ec6a9243
boot.config mode=0644 size=3 time=945902618.0 \
        md5digest=93d722493ed38477338a1405d7dcbb40
boot.help uid=3 gid=7 mode=0444 size=411 time=939182876.0 \
        md5digest=9b7126385734bcae753f4179ab59d8e5
compat   type=link mode=0777 size=11 time=915149058.0 \
        link=/usr/compat
kernel   mode=0444 size=1947607 time=950230892.0 \
        md5digest=1a2a8aff2fec678a918ba0d6bf063980
kernel.avr uid=1112 size=1947642 time=950252597.0 \
        md5digest=82e1637682d58ec28964dfee7fccb62e
kernel.config \
        mode=0644 size=0 time=915149058.0 \
        md5digest=d41d8cd98f00b204e9800998ecf8427e
sys      type=link mode=0777 size=11 time=915149029.0 \
        link=/usr/src/sys

```

show system autoinstallation status

Syntax	show system autoinstallation status
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Display autoinstallation status information.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show system autoinstallation status on page 874
Output Fields	Table 136 on page 874 describes the output fields for the show system autoinstallation status command. Output fields are listed in the approximate order in which they appear.

Table 136: show system autoinstallation status Output Fields

Field Name	Field Description
Autoinstallation status	<p>Display autoinstallation status information:</p> <ul style="list-style-type: none"> • Last committed file—File last committed for autoinstallation configuration. • Configuration server of last committed file—IP address or URL of server configured to retrieve configuration information for the last committed configuration file. • Interface—Interface configured for autoinstallation. <ul style="list-style-type: none"> • Name—Name of interface. • State—Interface state. • Address acquisition—Display IP address acquired and protocol used for acquisition upon bootup. <ul style="list-style-type: none"> • Protocol—Protocol used for acquisition: BOOTP/DHCP or RARP. • Acquired address—IP address acquired from the DHCPserver.

Sample Output

```

show system autoinstallation status user@host> show system autoinstallation status
Autoinstallation status:
Master state: Active
Last committed file: None
Configuration server of last committed file: 0.0.0.0
Interface:
  Name: fe-0/0/1
  State: None
Address acquisition:
  Protocol: DHCP Client
  Acquired address: None
  Protocol: RARP Client
  Acquired address: None

```

show system boot-messages

Syntax	show system boot-messages
Syntax (EX Series Switch)	show system boot-messages <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system boot-messages <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system boot-messages <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system boot-messages <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display initial messages generated by the system kernel upon startup. These messages are the contents of <code>/var/run/dmesg.boot</code> .
Options	<p>none—Display all boot time messages.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display boot time messages for all of the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display boot time messages for all T640 routers (or line-card chassis) connected to a TX Matrix router. On a TX Matrix Plus router, display boot time messages for all T1600 routers (or line-card chassis) connected to a TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Display boot time messages on all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display boot time messages for a specific T640 router connected to a TX Matrix router. On a TX Matrix Plus router, display boot time messages for a specific T1600 router connected to a TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches and MX Series routers only) (Optional) Display boot time messages on the local Virtual Chassis member.</p>

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display boot time messages on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display boot time messages for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Display boot time messages for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system boot-messages** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) master Routing Engines or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) backup Routing Engines or T1600 (routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system boot-messages (TX Matrix Router) on page 876**
show system boot-messages lcc (TX Matrix Router) on page 877
show system boot-messages (TX Matrix Plus Router) on page 878
show system boot-messages (QFX Series) on page 879

Sample Output

```

show system boot-messages (TX Matrix Router)
user@host> show system boot-messages
Copyright (c) 1992-1998 FreeBSD Inc.
Copyright (c) 1996-2000 Juniper Networks, Inc.
All rights reserved.
Copyright (c) 1982, 1986, 1989, 1991, 1993
    The Regents of the University of California. All rights reserved.

JUNOS 4.1-20000216-Zf8469 #0: 2000-02-16 12:57:28 UTC
    tlim@single.juniper.net:/p/build/20000216-0905/4.1/release_kernel/sys/compile/GENERIC
CPU: Pentium Pro (332.55-MHz 686-class CPU)
    Origin = "GenuineIntel" Id = 0x66a Stepping=10
    Features=0x183f9ff<FPU,VME,DE,PSE,TSC,MSR,PAE,MCE,CX8,SEP,MTRR,PGE,MCA,CMOV,<b16>,<b17>,MMX,<b24>>
Teknor CPU Card Recognized
real memory = 805306368 (786432K bytes)
avail memory = 786280448 (767852K bytes)
Probing for devices on PCI bus 0:
chip0 <generic PCI bridge (vendor=8086 device=7192 subclass=0)> rev 3 class 6000
0 on pci0:0:0
chip1 <Intel 82371AB PCI-ISA bridge> rev 1 class 60100 on pci0:7:0
chip2 <Intel 82371AB IDE interface> rev 1 class 10180 on pci0:7:1
chip3 <Intel 82371AB USB interface> rev 1 class c0300 int d irq 11 on pci0:7:2
smb0 <Intel 82371AB SMB controller> rev 1 class 68000 on pci0:7:3
pcic0 <TI PCI-1131 PCI-CardBus Bridge> rev 1 class 60700 int a irq 15 on pci0:13:0

```

```

TI1131 PCI Config Reg: [pci only][FUNC0 pci int]
pcic1 <TI PCI-1131 PCI-CardBus Bridge> rev 1 class 60700 int b irq 12 on pci0:13:1
TI1131 PCI Config Reg: [pci only][FUNC1 pci int]
fxp0 <Intel EtherExpress Pro 10/100B Ethernet> rev 8 class 20000 int a irq 12 on

pci0:16:0
chip4 <generic PCI bridge (vendor=1011 device=0022 subclass=4)> rev 4 class 6040
0 on pci0:17:0
fxp1 <Intel EtherExpress Pro 10/100B Ethernet> rev 8 class 20000 int a irq 10 on

pci0:19:0
Probing for devices on PCI bus 1:
mcs0 <Miscellaneous Control Subsystem> rev 12 class ff0000 int a irq 12 on pci1:
13:0
fxp2 <Intel EtherExpress Pro 10/100B Ethernet> rev 8 class 20000 int a irq 10 on

pci1:14:0
Probing for devices on the ISA bus:
sc0 at 0x60-0x6f irq 1 on motherboard
sc0: EGA color <16 virtual consoles, flags=0x0>
ed0 not found at 0x300
ed1 not found at 0x280
ed2 not found at 0x340
psm0 not found at 0x60
sio0 at 0x3f8-0x3ff irq 4 flags 0x20010 on isa
sio0: type 16550A, console
sio1 at 0x3e8-0x3ef irq 5 flags 0x20000 on isa
sio1: type 16550A
sio2 at 0x2f8-0x2ff irq 3 flags 0x20000 on isa
sio2: type 16550A
pcic0 at 0x3e0-0x3e1 on isa
PC-Card ctlr(0) TI PCI-1131 [CardBus bridge mode] (5 mem & 2 I/O windows)
pcic0: slot 0 controller I/O address 0x3e0
npx0 flags 0x1 on motherboard
npx0: INT 16 interface
fdc0: direction bit not set
fdc0: cmd 3 failed at out byte 1 of 3
fdc0 not found at 0x3f0
wdc0 at 0x1f0-0x1f7 irq 14 on isa
wdc0: unit 0 (wd0): <SunDisk SQFXB-80>, single-sector-i/o
wd0: 76MB (156672 sectors), 612 cyls, 8 heads, 32 S/T, 512 B/S
wdc0: unit 1 (wd1): <IBM-DCXA-210000>
wd1: 8063MB (16514064 sectors), 16383 cyls, 16 heads, 63 S/T, 512 B/S
wdc1 not found at 0x170
wdc2 not found at 0x180
ep0 not found at 0x300
fxp0: Ethernet address 00:a0:a5:12:05:5a
fxp1: Ethernet address 00:a0:a5:12:05:59
fxp2: Ethernet address 02:00:00:00:00:01
swapon: adding /dev/wd1s1b as swap device
Automatic reboot in progress...
/dev/rwd0s1a: clean, 16599 free (95 frags, 2063 blocks, 0.1% fragmentation)
/dev/rwd0s1e: clean, 9233 free (9 frags, 1153 blocks, 0.1% fragmentation)
/dev/rwd0s1a: clean, 16599 free (95 frags, 2063 blocks, 0.1% fragmentation)
/dev/rwd1s1f: clean, 4301055 free (335 frags, 537590 blocks, 0.0% fragmentation)

```

show system
boot-messages lcc (TX
Matrix Router)

```

user@host> show system boot-messages lcc 2
lcc2-re0:

```

 Copyright (c) 1996-2001, Juniper Networks, Inc.

```

All rights reserved.
Copyright (c) 1992-2001 The FreeBSD Project.
Copyright (c) 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994
    The Regents of the University of California. All rights reserved.
JUNOS 7.0-20040912.0 #0: 2004-09-12 09:16:32 UTC

builder@benten.juniper.net:/build/benten-b/7.0/20040912.0/obj-i386/sys/compile/JUNIPER
Timecounter "i8254" frequency 1193182 Hz
Timecounter "TSC" frequency 601368936 Hz
CPU: Pentium III/Pentium III Xeon/Celeron (601.37-MHz 686-class CPU)
    Origin = "GenuineIntel" Id = 0x68a Stepping = 10

Features=0x387f9ff<FPU,WE,DE,PSE,TSC,MSR,PAE,MCE,CX8,SEP,MTRR,PGE,MCA,CMOV,PAT,PSE36,PN,MMX,FXSR,SSE>
real memory = 2147467264 (2097136K bytes)
sio0: gdb debugging port
avail memory = 2084040704 (2035196K bytes)
Preloaded elf kernel "kernel" at 0xc06d9000.
DEVFS: ready for devices
Pentium Pro MTRR support enabled
md0: Malloc disk
DRAM Data Integrity Mode: ECC Mode with h/w scrubbing
npx0: <math processor> on motherboard
npx0: INT 16 interface
pcib0: <ServerWorks NB6635 3.0LE host to PCI bridge> on motherboard
pci0: <PCI bus> on pcib0
pcic-pci0: <TI PCI-1410 PCI-CardBus Bridge> irq 15 at device 1.0 on pci0
pcic-pci0: TI12XX PCI Config Reg: [pwr save][pci only]
fxp0: <Intel Embedded 10/100 Ethernet> port 0x1000-0x103f mem
0xfb800000-0xfb81ffff,0xfb820000-0xfb820fff irq 9 at device 3.0 on pci0
fxp1: <Intel Embedded 10/100 Ethernet> port 0x1040-0x107f mem
0xfb840000-0xfb85ffff,0xfb821000-0xfb821fff irq 11 at device 4.0 on pci0
...

```

**show system
boot-messages (TX
Matrix Plus Router)**

```

user@host> show system boot-messages
sfc0-re0:
-----
Copyright (c) 1996-2009, Juniper Networks, Inc.
All rights reserved.
Copyright (c) 1992-2006 The FreeBSD Project.
Copyright (c) 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994
    The Regents of the University of California. All rights reserved.
JUNOS 9.6B3.3 #0: 2009-06-17 19:52:08 UTC

builder@lanath.juniper.net:/volume/build/junos/9.6/release/9.6B3.3/obj-i386/bsd/sys/compile/JUNIPER
MPTable: Timecounter "i8254" frequency 1193182 Hz quality 0 CPU: Intel(R) Xeon(R)
    CPU          L5238 @ 2.66GHz (2660.01-MHz 686-class CPU) Origin =
"GenuineIntel" Id = 0x1067a Stepping = 10 Features=0xbfebfbff
...
lcc1-re0:
-----
Copyright (c) 1996-2009, Juniper Networks, Inc.
All rights reserved.
Copyright (c) 1992-2006 The FreeBSD Project.
Copyright (c) 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994
    The Regents of the University of California. All rights reserved.
JUNOS 9.6-20090617.0 #0: 2009-06-17 04:15:14 UTC

builder@lanath.juniper.net:/volume/build/junos/9.6/production/20090617.0/obj-i386/bsd/sys/compile/JUNIPER
Timecounter "i8254" frequency 1193182 Hz quality 0
CPU: Intel(R) Xeon(R) CPU          @ 1.86GHz (1862.01-MHz 686-class CPU)

```

```

Origin = "GenuineIntel" Id = 0x1067a Stepping = 10
Features=0xbfebfbff
...

show system user@switch> show system boot-messages
boot-messages (QFX getmemsize: msgbufp[size=32768] = 0x81d07fe4
Series)

System physical memory distribution:
-----
Total physical memory: 4160749568 (3968 MB)
Physical memory used: 3472883712 (3312 MB)
Physical memory allocated to kernel: 2130706432 (2032 MB)
Physical memory allocated to user BTLB: 1342177280 (1280 MB)
-----

Copyright (c) 1996-2010, Juniper Networks, Inc.
All rights reserved.
Copyright (c) 1992-2006 The FreeBSD Project.
Copyright (c) 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994
The Regents of the University of California. All rights reserved.
JUNOS 11.1I #0: 2010-09-17 19:18:07 UTC

ssiano@svl-junos-pool125.juniper.net:/c/ssiano/DEV_QFX_SI_BRANCH/03/20100917.399988/
obj-xlr/bsd/sys/compile/JUNIPER-DCTOR
WARNING: debug.mpsafenet forced to 0 as ipsec requires Giant
JUNOS 11.1I #0: 2010-09-17 19:18:07 UTC

ssiano@svl-junos-pool125.juniper.net:/c/ssiano/DEV_QFX_SI_BRANCH/03/20100917.399988/
obj-xlr/bsd/sys/compile/JUNIPER-DCTOR
real memory = 3472883712 (3312MB)
avail memory = 1708171264 (1629MB)
cpuid: 0, btlb_cpumap:0xffffffff8
FreeBSD/SMP: Multiprocessor System Detected: 12 CPUs
ETHERNET SOCKET BRIDGE initialising
Initializing QFX platform properties ..
cpu0 on motherboard
: RMI's XLR CPU Rev. 0.3 with no FPU implemented
L1 Cache: I size 32kb(32 line), D size 32kb(32 line), eight way.
L2 Cache: Size 1024kb, eight way
pic_lbus0: <XLR Local Bus>
pic_lbus0: <XLR Local Bus> on motherboard
Enter qfx control ethernet probe addr:0xc5eeec00
gmac4: <XLR GMAC GE Ethernet> on pic_lbus0
me0: Ethernet address 00:1d:b5:f7:68:40
Enter qfx control ethernet probe addr:0xc5eeeb40
gmac5: <XLR GMAC GE Ethernet> on pic_lbus0
me1: Ethernet address 00:1d:b5:f7:68:41
Enter qfx control ethernet probe addr:0xc5eeea80
gmac6: <XLR GMAC GE Ethernet> on pic_lbus0
me1: Ethernet address 00:1d:b5:f7:68:42
sio0 on pic_lbus0
Entering sioattach
sio0: type 16550A, console
xls_setup_intr: skip irq 3, xlr regs are set up somewhere else.
gblmem0 on pic_lbus0
ehci0: <RMI XLS USB 2.0 controller> on pic_lbus0
ehci_bus_attach: allocated resource. tag=1, base=bef24000
xls_ehci_init: endian hardware swapping NOT enabled.
usb0: EHCI version 1.0
usb0 on ehci0
usb0: USB revision 2.0

```

```
uhub0: vendor 0x0000 EHCI root hub, class 9/0, rev 2.00/1.00, addr 1
uhub0: 2 ports with 2 removable, self powered
umass0: USB USBFlashDrive, rev 2.00/11.00, addr 2
pcib0: PCIe link 0 up
pcib0: PCIe link 2 up
pcib0: PCIe link 3 up
pcib0: <XLS PCI Host Controller> on pic_lbus0
pci0: <PCI bus> on pcib0
pcib1: <PCI-PCI bridge> at device 0.0 on pci0
pci1: <PCI bus> on pcib1
pci1: <network, ethernet> at device 0.0 (no driver attached)
pcib2: <PCI-PCI bridge> at device 1.0 on pci0
pcib3: <PCI-PCI bridge> at device 2.0 on pci0
pci2: <PCI bus> on pcib3
pci2: <network, ethernet> at device 0.0 (no driver attached)
pcib4: <PCI-PCI bridge> at device 3.0 on pci0
pci3: <PCI bus> on pcib4
pci3: <network, ethernet> at device 0.0 (no driver attached)
cfi device address space at 0xbc000000
cfi0: <AMD/Fujitsu - 8MB> on pic_lbus0
cfi device address space at 0xbc000000
i2c0: <I2C bus controller> on pic_lbus0
i2c1: <I2C bus controller> on pic_lbus0
qfx_fmn0 on pic_lbus0
pool offset 1503776768
xlr_lbus0: <XLR Local Bus Controller> on motherboard
qfx_bcpld_probe[124]
qfx_bcpld_probe[138]: dev_type=0x0
qfx_bcpld_probe[124]
qfx_bcpld0: QFX BCPLD probe success
qfx_bcpld0qfx_bcpld_attach[174]
qfx_bcpld_attach[207] : bus_space_tag=0x0, bus_space_handle=0xbd900000
qfx_bcpld_probe[124]
qfx_bcpld1: QFX BCPLD probe success
qfx_bcpld1qfx_bcpld_attach[174]
tor_bcpld_slave_attach[1245] : bus_space_tag=0x0, bus_space_handle=0xbda00000
Initializing product: 96 ..
bmeb: bmeb_lib_init done 0xc60a5000, addr 0x809c99a0
bme0:Virtual BME driver initializing
Timecounter "mips" frequency 1200000000 Hz quality 0
Timecounter "xlr_pic_timer" frequency 66666666 Hz quality 1
Timecounters tick every 1.000 msec
Loading the NETPFE fc module
IPsec: Initialized Security Association Processing.
SMP: AP CPU #3 Launched!
SMP: AP CPU #1 Launched!
SMP: AP CPU #2 Launched!
SMP: AP CPU #4 Launched!
SMP: AP CPU #5 Launched!
SMP: AP CPU #7 Launched!
SMP: AP CPU #6 Launched!
SMP: AP CPU #11 Launched!
SMP: AP CPU #10 Launched!
SMP: AP CPU #9 Launched!
SMP: AP CPU #8 Launched!
da0 at umass-sim0 bus 0 target 0 lun 0
da0: <USB USBFlashDrive 1100> Removable Direct Access SCSI-0 device
da0: 40.000MB/s transfers
da0: 3920MB (8028160 512 byte sectors: 255H 63S/T 499C)
Trying to mount root from ufs:/dev/da0s1a
```


show system buffers

Syntax	show system buffers
Syntax (EX Series)	show system buffers <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system buffers <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system buffers <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system buffers <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display information about the buffer pool that the Routing Engine uses for local traffic. Local traffic is the routing and management traffic that is exchanged between the Routing Engine and the Packet Forwarding Engine within the router or switch, as well as the routing and management traffic from IP (that is, from OSPF, BGP, SNMP, ping operations, and so on).
Options	none—Show all buffer statistics. all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show buffer statistics for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, show buffer statistics for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router. all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Show buffer statistics for all of the chassis. all-members—(EX4200 switches and MX Series routers only) (Optional) Show buffer statistics for all members of the Virtual Chassis configuration. lcc <i>number</i> —(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show buffer statistics for a specific T640 router (or line-card chassis) that is connected to the TX Matrix router. On a TX Matrix Plus router, show buffer statistics for a specific T1600 router (or line-card chassis) that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Show buffer statistics for the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Show buffer statistics for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

sfc—(TX Matrix Plus routers only) (Optional) Show buffer statistics for the TX Matrix Plus router (or switch-fabric chassis). Replace ***number*** with 0.

Additional Information By default, when you issue the **show system buffers** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) master Routing Engines or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) backup Routing Engines or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

A special type of memory buffer called a *cluster* is 2 KB in size. For more information, see *The Design and Implementation of the 4.4BSD Operation System* by McKusic, Bostic, Karels, and Quarterman.

Required Privilege Level view

List of Sample Output **show system buffers** on page 884
show system buffers scc (TX Matrix Router) on page 885
show system buffers sfc (TX Matrix Plus Router) on page 885
show system buffers all-chassis (TX Matrix Plus Router) on page 885
show system buffers (QFX Series) on page 886

Output Fields Table 137 on page 884 describes the output fields for the **show system buffers** command. Output fields are listed in the approximate order in which they appear.

Table 137: show system buffers Output Fields

Field Name	Field Description
mbufs in use	Memory buffers (mbufs) are 128-byte buffers that are used for various purposes inside the kernel. Each memory buffer has a type, and the output itemizes the amount allocated for each type. Types with no memory buffers allocated are not displayed.
mbufs allocated to packet headers	Number of memory buffers currently holding packet headers
mbufs allocated to control blocks	Number of memory buffers currently holding the state for sockets.
mbufs allocated to send data	Number of memory buffers currently holding socket send data.
mbufs allocated to pfe refill data	Number of memory buffers currently holding Packet Forwarding Engine refill data.
mbufs allocated to fxp data	Number of memory buffers currently holding fxp data.
mbufs allocated to socket names and addresses	Number of memory buffers currently holding addresses for sockets.
mbuf clusters in use	Allocation statistics for mbuf clusters.
allocated to network	Total amount of memory in use by the networking and interprocess communication (IPC) code.
requests for memory denied	Number of times a memory allocation request within the IPC and networking code failed.
requests for memory delayed	Number of times a memory allocation request within the IPC and networking code was postponed.
calls to protocol drain routines	Number of times a memory allocation request within the IPC and networking code triggered a memory reclamation attempt.

Sample Output

```

show system buffers  user@host> show system buffers
                        853 mbufs in use:
                        2 mbufs allocated to packet headers
                        37 mbufs allocated to protocol control blocks
                        28 mbufs allocated to socket names and addresses
                        2 mbufs allocated to socket send data
                        400 mbufs allocated to pfe refill data
                        384 mbufs allocated to fxp data
                        784/944 mbuf clusters in use
                        1994 Kbytes allocated to network (83% in use)
                        0 requests for memory denied

```

```

0 requests for memory delayed
0 calls to protocol drain routines

show system buffers scc (TX Matrix Router) user@host> show system buffers scc
213 mbufs in use:
    11 mbufs allocated to packet headers
    26 mbufs allocated to socket names and addresses
    2 mbufs allocated to socket options
    17 mbufs allocated to socket send data
    2 mbufs allocated to pfe data
    155 mbufs allocated to fxp data (rx)
    511 mbufs allocated to <mbuf type 86>
    256 mbufs allocated to <mbuf type 92>
924/1162 mbuf clusters in use
2788 Kbytes allocated to network (75% in use)
0 requests for memory denied
0 requests for memory delayed
0 calls to protocol drain routines

show system buffers sfc (TX Matrix Plus Router) user@host> show system buffers sfc 0
sfc0-re0:
-----
4363/2807/7170 mbufs in use (current/cache/total)
4358/1968/6326/30000 mbuf clusters in use (current/cache/total/max)
256/128 mbuf+clusters out of packet secondary zone in use (current/cache)
0/0/0/0 4k (page size) jumbo clusters in use (current/cache/total/max)
0/0/0/0 9k jumbo clusters in use (current/cache/total/max)
0/0/0/0 16k jumbo clusters in use (current/cache/total/max)
9806K/4637K/14444K bytes allocated to network (current/cache/total)
0/0/0 requests for mbufs denied (mbufs/clusters/mbuf+clusters)
0/0/0 requests for jumbo clusters denied (4k/9k/16k)
0/10/1024 sfbufs in use (current/peak/max)
0 requests for sfbufs denied
0 requests for sfbufs delayed
0 requests for I/O initiated by sendfile
0 calls to protocol drain routines

show system buffers all-chassis (TX Matrix Plus Router) user@host> show system buffers all-chassis
sfc0-re0:
-----
4363/2807/7170 mbufs in use (current/cache/total)
4358/1968/6326/30000 mbuf clusters in use (current/cache/total/max)
256/128 mbuf+clusters out of packet secondary zone in use (current/cache)
0/0/0/0 4k (page size) jumbo clusters in use (current/cache/total/max)
0/0/0/0 9k jumbo clusters in use (current/cache/total/max)
0/0/0/0 16k jumbo clusters in use (current/cache/total/max)
9806K/4637K/14444K bytes allocated to network (current/cache/total)
0/0/0 requests for mbufs denied (mbufs/clusters/mbuf+clusters)
0/0/0 requests for jumbo clusters denied (4k/9k/16k)
0/10/1024 sfbufs in use (current/peak/max)
0 requests for sfbufs denied
0 requests for sfbufs delayed
0 requests for I/O initiated by sendfile
0 calls to protocol drain routines

lcc0-re0:
-----
772/2558/3330 mbufs in use (current/cache/total)

```

```

772/598/1370/30000 mbuf clusters in use (current/cache/total/max)
768/512 mbuf+clusters out of packet secondary zone in use (current/cache)
0/0/0/0 4k (page size) jumbo clusters in use (current/cache/total/max)
0/0/0/0 9k jumbo clusters in use (current/cache/total/max)
0/0/0/0 16k jumbo clusters in use (current/cache/total/max)
1737K/1835K/3572K bytes allocated to network (current/cache/total)
0/0/0 requests for mbufs denied (mbufs/clusters/mbuf+clusters)
0/0/0 requests for jumbo clusters denied (4k/9k/16k)
0/4/1024 sbufs in use (current/peak/max)
0 requests for sbufs denied
0 requests for sbufs delayed
0 requests for I/O initiated by sendfile
0 calls to protocol drain routines

```

```
lcc1-re0:
```

```

-----
773/2437/3210 mbufs in use (current/cache/total)
773/453/1226/30000 mbuf clusters in use (current/cache/total/max)
768/384 mbuf+clusters out of packet secondary zone in use (current/cache)
0/0/0/0 4k (page size) jumbo clusters in use (current/cache/total/max)
0/0/0/0 9k jumbo clusters in use (current/cache/total/max)
0/0/0/0 16k jumbo clusters in use (current/cache/total/max)
1739K/1515K/3254K bytes allocated to network (current/cache/total)
0/0/0 requests for mbufs denied (mbufs/clusters/mbuf+clusters)
0/0/0 requests for jumbo clusters denied (4k/9k/16k)
0/7/1024 sbufs in use (current/peak/max)
0 requests for sbufs denied
0 requests for sbufs delayed
0 requests for I/O initiated by sendfile
0 calls to protocol drain routines

```

```
lcc2-re0:
```

```

-----
816/2514/3330 mbufs in use (current/cache/total)
816/554/1370/30000 mbuf clusters in use (current/cache/total/max)
768/512 mbuf+clusters out of packet secondary zone in use (current/cache)
0/0/0/0 4k (page size) jumbo clusters in use (current/cache/total/max)
0/0/0/0 9k jumbo clusters in use (current/cache/total/max)
0/0/0/0 16k jumbo clusters in use (current/cache/total/max)
1836K/1736K/3572K bytes allocated to network (current/cache/total)
0/0/0 requests for mbufs denied (mbufs/clusters/mbuf+clusters)
0/0/0 requests for jumbo clusters denied (4k/9k/16k)
0/4/1024 sbufs in use (current/peak/max)
0 requests for sbufs denied
0 requests for sbufs delayed
0 requests for I/O initiated by sendfile

```

show system buffers
(QFX Series)

```

user@switch> show system buffers
6/1794/1800 mbufs in use (current/cache/total)
5/917/922/30000 mbuf clusters in use (current/cache/total/max)
0/640 mbuf+clusters out of packet secondary zone in use (current/cache)
0/0/0/0 4k (page size) jumbo clusters in use (current/cache/total/max)
0/0/0/0 9k jumbo clusters in use (current/cache/total/max)
0/0/0/0 16k jumbo clusters in use (current/cache/total/max)
11K/2282K/2294K bytes allocated to network (current/cache/total)
0/0/0 requests for mbufs denied (mbufs/clusters/mbuf+clusters)
0/0/0 requests for jumbo clusters denied (4k/9k/16k)
0/17/6656 sbufs in use (current/peak/max)
0 requests for sbufs denied
0 requests for sbufs delayed

```

0 requests for I/O initiated by sendfile
0 calls to protocol drain routines

show system commit

Syntax	show system commit
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the pending commit operation (if any) and the commit history.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear system commit on page 713
List of Sample Output	show system commit on page 889 show system commit (At a Particular Time) on page 889 show system commit (At the Next Reboot) on page 889 show system commit (Rollback Pending) on page 889 show system commit (QFX Series) on page 889
Output Fields	Table 138 on page 888 describes the output fields for the show system commit command. Output fields are listed in the approximate order in which they appear.

Table 138: show system commit Output Fields

Field Name	Field Description
Commit history	Displays the last 50 commit operations listed, most recent to first. The identifier rescue designates a configuration created for recovery using the request system configuration rescue save command.
Timestamp	Date and time of the commit operation.
Username	User who executed the commit operation.
Commit method	Method used to execute the commit operation: <ul style="list-style-type: none"> cli—CLI interactive user performed the commit operation. Junos XML protocol—Junos XML protocol client performed the commit operation. synchronize—The commit synchronize command was performed on the other Routing Engine. snmp—An SNMP SET request caused the commit operation. button—A button on the router or switch was pressed to commit a rescue configuration for recovery. autoinstall—A configuration obtained through autoinstallation was committed. other—A method other than those identified was used to perform the commit operation.

Sample Output

```

show system commit      user@host> show system commit
0   2003-07-28 19:14:04 PDT by root via other
1   2003-07-25 22:01:36 PDT by regress via cli
2   2003-07-25 22:01:32 PDT by regress via cli
3   2003-07-25 21:30:13 PDT by root via button
4   2003-07-25 13:46:48 PDT by regress via cli
5   2003-07-25 05:33:21 PDT by root via autoinstall
...
rescue 2002-05-10 15:32:03 PDT by root via other

show system commit      user@host> show system commit
(At a Particular Time)  commit requested by root via cli at Tue May  7 15:59:00 2002

show system commit      user@host> show system commit
(At the Next Reboot)    commit requested by root via cli at reboot

show system commit      user@host> show system commit
(Rollback Pending)      0 2005-01-05 15:00:37 PST by root via cli commit confirmed, rollback in 3mins

show system commit      user@switch> show system commit
(QFX Series)            0 2011-11-25 19:17:49 PST by root via cli

```

show system configuration archival

Syntax	show system configuration archival
Release Information	Introduced in Junos OS Release 7.6. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display directory and number of files queued for archival transfer.
Options	This command has no options.
Required Privilege Level	maintenance
List of Sample Output	show system configuration archival on page 890

Sample Output

```
show system configuration archival  user@host> show system configuration archival
/var/transfer/config/:
total 8
```

show system configuration rescue

Syntax	show system configuration rescue
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display a rescue configuration, if one exists.
Options	This command has no options.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show system configuration archival on page 890
List of Sample Output	show system configuration rescue on page 891

Sample Output

```

user@host> show system configuration rescue
version "7.3"; groups {
  global {
    system {
      host-name router1;
      domain-name customer.net;
      domain-search [ customer.net ];
      backup-router 192.168.124.254;
      name-server {
        172.17.28.11;
        172.17.28.101;
        172.17.28.100;
        172.17.28.10;
      }
      login {
        user regress {
          uid 928;
          class ;
          shell csh;
          authentication {
            encrypted-password "$1$kPU..$w.4FGRAGanJ8U4Yq6sbj7."; ##
SECRET-DATA
          }
        }
      }
    }
  }
  services {
    ftp;
    rlogin;
    rsh;
    telnet;
  }
}

```

```
    }  
    ....
```

show system connections

Syntax	<pre>show system connections <extensive> <all-chassis all-lcc lcc <i>number</i> scc> <inet inet6> <show-routing-instances></pre>
Syntax (EX Series)	<pre>show system connections <extensive> <all-members> <inet inet6> <local> <member <i>member-id</i>> <show-routing-instances></pre>
Syntax (TX Matrix Router)	<pre>show system connections <extensive> <all-chassis all-lcc lcc <i>number</i> scc> <inet inet6> <show-routing-instances></pre>
Syntax (TX Matrix Plus Router)	<pre>show system connections <extensive> <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i>> <inet inet6> <show-routing-instances></pre>
Syntax (MX Series Router)	<pre>show system connections <extensive> <all-members> <inet inet6> <local> <member <i>member-id</i>> <show-routing-instances></pre>
Syntax (QFX Series)	<pre>show system connections <extensive> <inet> <show-routing-instances></pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p>
Description	<p>Display information about the active IP sockets on the Routing Engine. Use this command to verify which servers are active on a system and what connections are currently in progress.</p>
Options	<p>none—Display information about all active IP sockets on the Routing Engine.</p>

extensive—(Optional) Display exhaustive system process information, which, for TCP connections, includes the TCP control block. This option is useful for debugging TCP connections.

all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system connection activity for all the routers in the chassis.

all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system connection activity for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system connection activity for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router

all-members—(EX4200 switches and MX Series routers only) (Optional) Display system connection activity for all members of the Virtual Chassis configuration.

inet | inet6—(Optional) Display IPv4 connections or IPv6 connections, respectively.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system connection activity for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system connection activity for a specific T1600 router that is connected to the TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display system connection activity for the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display system connection activity for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display system connection activity for the TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus routers only) (Optional) Display system connection activity for the TX Matrix Plus router (or switch-fabric chassis).

show-routing-instances—(Optional) Display routing instances.

Additional Information By default, when you issue the **show system connections** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) master Routing Engines or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

- List of Sample Output**
- `show system connections` on page 895
 - `show system connections extensive` on page 896
 - `show system connections lcc` (TX Matrix Router) on page 896
 - `show system connections show-routing-instances` on page 897
 - `show system connections` (TX Matrix Plus Router) on page 898
 - `show system connections sfc` (TX Matrix Plus Router) on page 901
 - `show system connections show-routing-instances` (TX Matrix Plus Router) on page 903
 - `show system connections` (QFX Series) on page 908

Output Fields Table 139 on page 895 describes the output fields for the `show system connections` command. Output fields are listed in the approximate order in which they appear.

Table 139: show system connections Output Fields

Field Name	Field Description
Proto	Protocol of the socket: IP , TCP , or UDP for IPv4 or IPv6.
Recv-Q	Number of input packets received by the protocol and waiting to be processed by the application.
Send-Q	Number of output packets sent by the application and waiting to be processed by the protocol.
Local Address	Local address and port of the socket, separated by a period. An asterisk (*) indicates that the bound address is the wildcard address. Server sockets typically have the wildcard address and a well-known port bound to them.
Foreign Address	Foreign address and port of the socket, separated by a period. An asterisk (*) indicates that the address or port is a wildcard.
Routing Instance (Displayed only when the <code>show-routing-instance</code> option is used.)	Routing instances associated with active IP sockets on the Routing Engine.
(state)	For TCP, the protocol state of the socket.

Sample Output

```

show system connections user@host> show system connections
connections             Active Internet connections (including servers)
Proto Recv-Q Send-Q Local Address          Foreign Address         (state)
tcp      0      2 192.168.4.16.513       208.197.169.254.894    ESTABLISHED
tcp      0      0 192.168.4.16.513       208.197.169.195.945    ESTABLISHED
tcp      0      0 *.23                   *.*                     LISTEN
tcp      0      0 *.22                   *.*                     LISTEN
tcp      0      0 *.513                  *.*                     LISTEN
tcp00 *.514      *.*                     LISTEN
tcp 0 0*.21      *.*                     LISTEN
tcp00 *.79      *.*                     LISTEN
tcp 00 *.1023    *.*                     LISTEN
tcp 00 *.111     *.*                     LISTEN
udp00192.168.4.16.1634    208.197.169.249.2049

```

```

udp00192.168.4.16.1627      208.197.169.254.2049
udp00192.168.4.16.1371      208.197.169.195.2049
udp00*. *                    *. *
udp00*.9999                  *. *
udp00 *.161                  *. *
udp00192.168.4.16.1039      192.168.4.16.1023
udp00192.168.4.16.1038      192.168.4.16.1023
udp 00 192.168.4.16.1037      192.168.4.16.1023
udp00192.168.4.16.1036      192.168.4.16.1023
udp00*.1022                  *. *
udp00*.1023                  *. *
udp00*.111                   *. *
udp00*. *                    *. *

```

show system connections extensive

```

user@host> show system connections extensive
Active Internet connections (including servers)
Proto Recv-Q Send-Q Local Address          Foreign Address         (state)
tcp      0      2 192.168.4.16.513       208.197.169.254.894    ESTABLISHED
    iss: 3972677059      sndup: 3972693435      sndcc: 10
    snduna: 3972693435    sndnxt: 3972693437    sndwnd: 17376
    sndmax: 3972693437    sndcwnd: 65535      sndssthresh: 1073725440
    irs: 484187869      rcvup: 484188060      rcvcc: 98357
    rcvnxt: 484188070    rcvadv: 484205446    rcvwnd: 17376
    rtt: 1              srtt: 7              rttv: 5
    rxtcur: 120          rxtshift: 0          rtseq: 1103707591
    rttmin: 2            duration: 5011        mss: 1448
    flags: REQ_SCALE RCVD_SCALE REQ_TSTMP RCVD_TSTMP RCVD_CC [0x41e0]
tcp      0      0 192.168.4.16.513       208.197.169.195.945    ESTABLISHED
    iss: 1057609890      sndup: 1057790796      sndcc: 2
    snduna: 1057790810    sndnxt: 1057790810    sndwnd: 17376
    sndmax: 1057790810    sndcwnd: 39096      sndssthresh: 1073725440
    irs: 3551947312      rcvup: 3551947422      rcvcc: 0
    rcvnxt: 3551947422    rcvadv: 3551964798    rcvwnd: 17376
    rtt: 0              srtt: 17             rttv: 11
    rxtcur: 300          rxtshift: 0          rtseq: 0
    rttmin: 2            duration: 125814      mss: 1448
    flags: REQ_SCALE RCVD_SCALE REQ_TSTMP RCVD_TSTMP [0x1e0]
udp0     0192.168.4.16.1634208.197.169.249.2049
udp0     0192.168.4.16.1627208.197.169.254.2049
udp0     0192.168.4.16.1371208.197.169.195.2049
udp 0     0*. * *. *
udp0     0*.9999*. *
udp 0     0*.161*. *
udp0     0192.168.4.16.1039192.168.4.16.1023
udp0     0192.168.4.16.1038192.168.4.16.1023
udp0     0192.168.4.16.1037192.168.4.16.1023
udp0     0192.168.4.16.1036192.168.4.16.1023
udp0     0*.1022*. *
udp 0     0*.1023 *. *
udp0     0 *.111*. *
udp0     0*. **.*

```

show system connections lcc (TX Matrix Router)

```

user@host> show system connections lcc 2
lcc2-re0:
-----
Active Internet connections (including servers)
Proto Recv-Q Send-Q Local Address          Foreign Address         (state)
tcp4     0      0 192.168.66.131.1342    192.168.66.130.23      ESTABLISHED
tcp4     0      0 192.168.66.131.2059    192.168.66.130.23      ESTABLISHED
tcp4     0      0 192.168.66.131.4571    192.168.66.130.23      ESTABLISHED

```



```

tcp4      0      0 192.168.66.131.2496 192.168.66.130.23 ESTABLISHED
tcp4      0      0 *.3221      *.*          LISTEN
tcp4      0      0 *.23        *.*          LISTEN
tcp4      0      0 *.22        *.*          LISTEN
tcp4      0      0 *.514       *.*          LISTEN
tcp4      0      0 *.513       *.*          LISTEN
tcp4      0      0 *.21        *.*          LISTEN
tcp4      0      0 *.79        *.*          LISTEN
tcp4      0      0 *.6234      *.*          LISTEN
udp4      0      0 *.514       *.*
udp4      0      0 *.6333      *.*

```

```

show system connections user@host> show system connections show-routing-instances
show-routing-instances Active Internet connections (including servers) (including routing-instances)
Proto Recv-Q Send-Q Local Address Foreign Address Routing Instance
(state)
tcp4      0      0 192.168.69.204.23 172.17.28.19.4267 default
ESTABLISHED
tcp4      0      0 192.168.69.204.58540 10.209.7.138.23 default
ESTABLISHED
tcp4      0      0 192.168.69.204.23 172.17.28.19.1098 default
ESTABLISHED
tcp4      0      0 192.168.7.1.57668 192.168.9.1.179 default
ESTABLISHED
tcp4      0      0 192.168.7.1.179 192.168.8.1.49209 default
ESTABLISHED
tcp4      0      0 128.0.0.1.6234 128.0.3.17.1024
__juniper_private1__ ESTABLISHED
tcp4      0      0 128.0.0.4.9000 128.0.0.4.59103
__juniper_private1__ ESTABLISHED
tcp4      0      0 128.0.0.4.59103 128.0.0.4.9000
__juniper_private1__ ESTABLISHED
tcp4      0      0 *.32012      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.9000      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.33007      *.*
__juniper_private2__ LISTEN
tcp46     0      0 *.179        *.*          default
LISTEN
tcp4      0      0 *.179        *.*          default
LISTEN
tcp4      0      0 *.6154      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.6153      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.7000      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.6152      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.6156      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.33005      *.*
__juniper_private2__ LISTEN
tcp4      0      0 *.31343      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.31341      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.32003      *.*
__juniper_private2__ LISTEN
tcp4      0      0 *.666        *.*

```

```

__juniper_private1__ LISTEN
tcp4      0      0 *.38      *.*
__juniper_private1__ LISTEN
tcp4      0      0 *.3221    *.*      default
LISTEN

```

**show system
connections (TX Matrix
Plus Router)**

```

user@host> show system connections
sfc0-re0:

```

```

-----
Active Internet connections (including servers)
Proto Recv-Q Send-Q Local Address Foreign Address
      (state)
tcp4      0      3 192.168.178.11.23
172.17.28.19.3565 ESTABLISHED
tcp4      0      0 192.168.178.11.23
172.17.28.204.62719 ESTABLISHED
tcp4      0      0 192.168.178.11.23
192.168.69.199.51255 ESTABLISHED
tcp4      0      0 192.168.178.11.23
172.24.26.227.42860 ESTABLISHED
tcp4      0      0 *.6156    *.*
LISTEN
tcp4      0      0 162.0.0.4.32012 162.0.0.5.58935
ESTABLISHED
tcp4      0      0 *.32012   *.*
LISTEN
tcp4      0      0 *.33007   *.*
LISTEN
tcp4      0      0 *.666     *.*
LISTEN
tcp4      0      0 162.0.0.4.6161 162.0.0.5.62026
ESTABLISHED
tcp4      0      0 *.33005   *.*
LISTEN
tcp4      0      0 162.0.0.4.9000 162.0.0.4.51611
ESTABLISHED
tcp4      0      0 162.0.0.4.51611 162.0.0.4.9000
ESTABLISHED
tcp4      0      0 *.6151    *.*
LISTEN
tcp4      0      0 *.6154    *.*
LISTEN
tcp4      0      0 *.6153    *.*
LISTEN
tcp4      0      0 *.31343   *.*
LISTEN
tcp4      0      0 *.31341   *.*
LISTEN
tcp4      0      0 *.9000    *.*
LISTEN
tcp4      0      0 *.6152    *.*
LISTEN
tcp4      0      0 *.32003   *.*
LISTEN
tcp4      0      0 *.33009   *.*
LISTEN
tcp4      0      0 *.3221    *.*
LISTEN
tcp4      0      0 *.23      *.*
LISTEN
tcp4      0      0 *.22      *.*

```

```

tcp4      0      0 *.514      LISTEN      *.
tcp4      0      0 *.513      LISTEN      *.
tcp4      0      0 *.21       LISTEN      *.
tcp4      0      0 *.79       LISTEN      *.
tcp4      0      0 *.514      LISTEN      *.
tcp4      0      0 *.513      LISTEN      *.
tcp4      0      0 *.6234     LISTEN      *.
udp4      0      0 127.0.0.1.123 LISTEN      *.
udp4      0      0 10.255.178.11.123 LISTEN      *.
udp4      0      0 *.123      LISTEN      *.
udp46     0      0 *.514      LISTEN      *.
udp4      0      0 *.514      LISTEN      *.
udp46     0      0 *.62027    LISTEN      *.
udp4      0      0 *.59363    LISTEN      *.
udp4      0      0 *.31342    LISTEN      *.
udp46     0      0 *.161      LISTEN      *.
udp4      0      0 *.161      LISTEN      *.
udp4      0      0 *.31340    LISTEN      *.
udp4      0      0 *.31340    LISTEN      *.
udp46     0      0 *.49152    LISTEN      *.
udp46     0      0 *.4784     LISTEN      *.
udp46     0      0 *.3784     LISTEN      *.
udp4      0      0 *.49152    LISTEN      *.
udp4      0      0 *.4784     LISTEN      *.
udp4      0      0 *.3784     LISTEN      *.
udp4      0      0 *.6333     LISTEN      *.
ip4       0      0 *.         LISTEN      *.
ip4       0      0 *.         LISTEN      *.

```

lcc0-re0:

Active Internet connections (including servers)

Proto	Recv-Q	Send-Q	Local Address		Foreign Address
			(state)		
tcp4	0	0	192.168.178.3.23		
	172.24.26.227.50399			ESTABLISHED	
tcp4	0	0	*.6234		*. *
			LISTEN		
tcp4	0	0	*.7000		*. *
			LISTEN		
tcp4	0	0	*.9000		*. *
			LISTEN		
tcp4	0	0	*.33009		*. *
			LISTEN		
tcp4	0	0	*.3221		*. *
			LISTEN		
tcp4	0	0	*.23		*. *
			LISTEN		
tcp4	0	0	*.22		*. *
			LISTEN		
tcp4	0	0	*.514		*. *
			LISTEN		
tcp4	0	0	*.513		*. *

```

tcp4      0      0 *.21      LISTEN      *.
tcp4      0      0 *.79      LISTEN      *.
tcp4      0      0 *.514     LISTEN      *.
tcp4      0      0 *.513     LISTEN      *.
udp46     0      0 *.514     LISTEN      *.
udp4      0      0 *.514     LISTEN      *.
udp46     0      0 *.59924   LISTEN      *.
udp4      0      0 *.59412   LISTEN      *.
udp46     0      0 *.161     LISTEN      *.
udp4      0      0 *.161     LISTEN      *.
udp4      0      0 *.31342   LISTEN      *.
udp4      0      0 *.6333    LISTEN      *.

```

lcc1-re0:

```

-----
Active Internet connections (including servers)
Proto Recv-Q Send-Q Local Address           Foreign Address
      (state)
tcp4      0      0 *.6234     LISTEN      *.
tcp4      0      0 *.7000     LISTEN      *.
tcp4      0      0 *.9000     LISTEN      *.
tcp4      0      0 *.3221     LISTEN      *.
tcp4      0      0 *.23       LISTEN      *.
tcp4      0      0 *.22       LISTEN      *.
tcp4      0      0 *.514      LISTEN      *.
tcp4      0      0 *.513      LISTEN      *.
tcp4      0      0 *.21       LISTEN      *.
tcp4      0      0 *.79       LISTEN      *.
tcp4      0      0 *.514      LISTEN      *.
tcp4      0      0 *.513      LISTEN      *.
tcp4      0      0 *.33009    LISTEN      *.
udp46     0      0 *.514      LISTEN      *.
udp4      0      0 *.514      LISTEN      *.
udp46     0      0 *.59924    LISTEN      *.
udp4      0      0 *.59412    LISTEN      *.
udp4      0      0 *.31342    LISTEN      *.
udp46     0      0 *.161      LISTEN      *.
udp4      0      0 *.161      LISTEN      *.
udp4      0      0 *.6333     LISTEN      *.

```

lcc2-re0:

```

-----
Active Internet connections (including servers)

```

Proto	Recv-Q	Send-Q	Local Address (state)	Foreign Address
tcp4	0	0	*.6234 LISTEN	*.*
tcp4	0	0	*.7000 LISTEN	*.*
tcp4	0	0	*.9000 LISTEN	*.*
tcp4	0	0	*.33009 LISTEN	*.*
tcp4	0	0	*.3221 LISTEN	*.*
tcp4	0	0	*.23 LISTEN	*.*
tcp4	0	0	*.22 LISTEN	*.*
tcp4	0	0	*.514	*.*
...				

**show system
connections sfc (TX
Matrix Plus Router)**

user@host> show system connections sfc 0
sfc0-re0:

Active Internet connections (including servers)

Proto	Recv-Q	Send-Q	Local Address (state)	Foreign Address
tcp4	0	0	162.0.0.4.514 TIME_WAIT	132.0.0.4.952
tcp4	0	0	162.0.0.4.514 TIME_WAIT	131.0.0.4.694
tcp4	0	0	162.0.0.4.514 TIME_WAIT	130.0.0.4.860
tcp4	0	0	162.0.0.4.514 TIME_WAIT	129.0.0.4.716
tcp4	0	0	162.0.0.4.996 TIME_WAIT	132.0.0.4.514
tcp4	0	0	162.0.0.4.798 TIME_WAIT	131.0.0.4.514
tcp4	0	0	162.0.0.4.995 TIME_WAIT	130.0.0.4.514
tcp4	0	0	162.0.0.4.895 TIME_WAIT	129.0.0.4.514
tcp4	0	0	192.168.178.11.21 172.17.28.204.64662 TIME_WAIT	
tcp4	0	0	192.168.178.11.21 172.17.28.204.51612 TIME_WAIT	
tcp4	0	0	*.6156 LISTEN	*.*
tcp4	0	0	*.9000 LISTEN	*.*
tcp4	0	0	*.666 LISTEN	*.*
tcp4	0	2	192.168.178.11.23 172.17.28.19.3565 ESTABLISHED	
tcp4	0	0	192.168.178.11.23 172.17.28.204.62719 ESTABLISHED	
tcp4	0	0	192.168.178.11.23 192.168.69.199.51255 ESTABLISHED	
tcp4	0	0	192.168.178.11.23 172.24.26.227.42860 ESTABLISHED	
tcp4	0	0	162.0.0.4.32012 ESTABLISHED	162.0.0.5.58935

tcp4	0	0	*.32012		*.*
				LISTEN	
tcp4	0	0	*.33007		*.*
				LISTEN	
tcp4	0	1432	162.0.0.4.6161		162.0.0.5.62026
				ESTABLISHED	
tcp4	0	0	*.33005		*.*
				LISTEN	
tcp4	0	0	162.0.0.4.9000		162.0.0.4.51611
				FIN_WAIT_2	
tcp4	0	0	162.0.0.4.51611		162.0.0.4.9000
				CLOSE_WAIT	
tcp4	0	0	*.6151		*.*
				LISTEN	
tcp4	0	0	*.6154		*.*
				LISTEN	
tcp4	0	0	*.6153		*.*
				LISTEN	
tcp4	0	0	*.31343		*.*
				LISTEN	
tcp4	0	0	*.31341		*.*
				LISTEN	
tcp4	0	0	*.6152		*.*
				LISTEN	
tcp4	0	0	*.32003		*.*
				LISTEN	
tcp4	0	0	*.33009		*.*
				LISTEN	
tcp4	0	0	*.3221		*.*
				LISTEN	
tcp4	0	0	*.23		*.*
				LISTEN	
tcp4	0	0	*.22		*.*
				LISTEN	
tcp4	0	0	*.514		*.*
				LISTEN	
tcp4	0	0	*.513		*.*
				LISTEN	
tcp4	0	0	*.21		*.*
				LISTEN	
tcp4	0	0	*.79		*.*
				LISTEN	
tcp4	0	0	*.514		*.*
				LISTEN	
tcp4	0	0	*.513		*.*
				LISTEN	
tcp4	0	0	*.6234		*.*
				LISTEN	
udp4	0	0	127.0.0.1.123		*.*
udp4	0	0	10.255.178.11.123		*.*
udp4	0	0	*.123		*.*
udp46	0	0	*.514		*.*
udp4	0	0	*.514		*.*
udp46	0	0	*.50895		*.*
udp4	0	0	*.50794		*.*
udp4	0	0	*.31342		*.*
udp46	0	0	*.161		*.*
udp4	0	0	*.161		*.*
udp4	0	0	*.31340		*.*
udp4	0	0	*.31340		*.*
udp46	0	0	*.49152		*.*

```

udp46      0      0 *.4784      *.*
udp46      0      0 *.3784      *.*
udp4       0      0 *.49152     *.*
udp4       0      0 *.4784      *.*
udp4       0      0 *.3784      *.*
udp4       0      0 *.6333      *.*
ip4        104     0 *.*         *.*
ip4         0      0 *.*         *.*
ip4         0      0 *.*         *.*

```

```

show system connections
show-routing-instances (TX Matrix Plus Router)

user@host> show system connections show-routing-instances
sfc0-re0:
-----
Active Internet connections (including servers) (including routing-instances)
Proto Recv-Q Send-Q Local Address           Foreign Address          (state)
tcp4      0      0 *.6156                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.9000                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.666                 *.*                      LISTEN
      __juniper_private1__
tcp4      0      2 192.168.178.11.23      172.17.28.19.3565      default ESTABLISHED
tcp4      0      0 192.168.178.11.23      172.17.28.204.62719    default ESTABLISHED
tcp4      0      0 192.168.178.11.23      192.168.69.199.51255   default ESTABLISHED
tcp4      0      0 192.168.178.11.23      172.24.26.227.42860    default ESTABLISHED
tcp4      0      0 162.0.0.4.32012        162.0.0.5.58935        ESTABLISHED
      __juniper_private1__
tcp4      0      0 *.32012                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.33007                *.*                      LISTEN
      __juniper_private2__
tcp4      0      0 162.0.0.4.6161         162.0.0.5.62026        ESTABLISHED
      __juniper_private1__
tcp4      0      0 *.33005                *.*                      LISTEN
      __juniper_private2__
tcp4      0      0 162.0.0.4.9000         162.0.0.4.51611        FIN_WAIT_2
      __juniper_private1__
tcp4      0      0 162.0.0.4.51611        162.0.0.4.9000        CLOSE_WAIT
      __juniper_private1__
tcp4      0      0 *.6151                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.6154                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.6153                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.31343                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.31341                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.6152                *.*                      LISTEN
      __juniper_private1__
tcp4      0      0 *.32003                *.*                      LISTEN
      __juniper_private2__
tcp4      0      0 *.33009                *.*                      LISTEN
      __juniper_private2__
tcp4      0      0 *.3221                *.*

```

tcp4	0	0 *.23	default	LISTEN	*,*
tcp4	0	0 *.22	default	LISTEN	*,*
tcp4	0	0 *.514	default	LISTEN	*,*
tcp4	0	0 *.513	default	LISTEN	*,*
tcp4	0	0 *.21	default	LISTEN	*,*
tcp4	0	0 *.79	default	LISTEN	*,*
tcp4	0	0 *.514	default	LISTEN	*,*
tcp4	0	0 *.513	__juniper_private1__	LISTEN	*,*
tcp4	0	0 *.6234	__juniper_private1__	LISTEN	*,*
tcp4	0	0 *.6234	__juniper_private1__	LISTEN	*,*
udp4	0	0 127.0.0.1.123	default		*,*
udp4	0	0 10.255.178.11.123	default		*,*
udp4	0	0 *.123	default		*,*
udp46	0	0 *.514	default		*,*
udp4	0	0 *.514	default		*,*
udp46	0	0 *.50895	default		*,*
udp4	0	0 *.50794	default		*,*
udp4	0	0 *.31342	default		*,*
udp46	0	0 *.161	__juniper_private1__		*,*
udp4	0	0 *.161	default		*,*
udp4	0	0 *.31340	default		*,*
udp4	0	0 *.31340	__juniper_private2__		*,*
udp46	0	0 *.49152	__juniper_private1__		*,*
udp46	0	0 *.4784	default		*,*
udp46	0	0 *.3784	default		*,*
udp4	0	0 *.49152	default		*,*
udp4	0	0 *.4784	default		*,*
udp4	0	0 *.3784	default		*,*
udp4	0	0 *.6333	default		*,*
ip4	0	0 *,*	__juniper_private1__		*,*
ip4	0	0 *,*	default		*,*
ip4	0	0 *,*	default		*,*


```

ip4      0      0  *.*
                                     default

lcc0-re0:
-----
Active Internet connections (including servers) (including routing-instances)
Proto Recv-Q Send-Q Local Address           Foreign Address
      Routing Instance      (state)
tcp4      0      0  *.7000                  *.*
                                     __juniper_private1__ LISTEN
tcp4      0      0  192.168.178.3.23        default ESTABLISHED
172.24.26.227.50399
tcp4      0      0  *.6234                  *.*
                                     __juniper_private1__ LISTEN
tcp4      0      0  *.9000                  *.*
                                     __juniper_private1__ LISTEN
tcp4      0      0  *.33009                 __juniper_private2__ LISTEN
tcp4      0      0  *.3221                  default LISTEN
tcp4      0      0  *.23                    default LISTEN
tcp4      0      0  *.22                    default LISTEN
tcp4      0      0  *.514                   default LISTEN
tcp4      0      0  *.513                   default LISTEN
tcp4      0      0  *.21                    default LISTEN
tcp4      0      0  *.79                    default LISTEN
tcp4      0      0  *.514                   __juniper_private1__ LISTEN
tcp4      0      0  *.513                   __juniper_private1__ LISTEN
udp46     0      0  *.514                   default
udp4      0      0  *.514                   default
udp46     0      0  *.59924                 default
udp4      0      0  *.59412                 default
udp46     0      0  *.161                   default
udp4      0      0  *.161                   default
udp4      0      0  *.31342                 __juniper_private1__
udp4      0      0  *.6333                  __juniper_private1__

lcc1-re0:
-----
Active Internet connections (including servers) (including routing-instances)
Proto Recv-Q Send-Q Local Address           Foreign Address
      Routing Instance      (state)
tcp4      0      0  *.7000                  *.*
                                     __juniper_private1__ LISTEN
tcp4      0      0  *.6234                  *.*

```

tcp4	0	0	*.9000	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.3221	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.23	default	LISTEN	*.*
tcp4	0	0	*.22	default	LISTEN	*.*
tcp4	0	0	*.514	default	LISTEN	*.*
tcp4	0	0	*.513	default	LISTEN	*.*
tcp4	0	0	*.21	default	LISTEN	*.*
tcp4	0	0	*.79	default	LISTEN	*.*
tcp4	0	0	*.514	default	LISTEN	*.*
tcp4	0	0	*.513	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.33009	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.33009	__juniper_private2__	LISTEN	*.*
udp46	0	0	*.514	default		*.*
udp4	0	0	*.514	default		*.*
udp46	0	0	*.59924	default		*.*
udp4	0	0	*.59412	default		*.*
udp4	0	0	*.31342	default		*.*
udp46	0	0	*.161	__juniper_private1__		*.*
udp4	0	0	*.161	default		*.*
udp4	0	0	*.6333	default		*.*
udp4	0	0	*.6333	__juniper_private1__		*.*

lcc2-re0:

Active Internet connections (including servers) (including routing-instances)

Proto	Recv-Q	Send-Q	Local Address	Foreign Address
			Routing Instance	(state)
tcp4	0	0	*.7000	*.*
tcp4	0	0	*.6234	__juniper_private1__ LISTEN *.*
tcp4	0	0	*.9000	__juniper_private1__ LISTEN *.*
tcp4	0	0	*.33009	__juniper_private1__ LISTEN *.*
tcp4	0	0	*.3221	__juniper_private2__ LISTEN *.*
tcp4	0	0	*.23	default LISTEN *.*
tcp4	0	0	*.22	default LISTEN *.*
tcp4	0	0	*.514	default LISTEN *.*

tcp4	0	0	*.513	default	LISTEN	*.*
tcp4	0	0	*.21	default	LISTEN	*.*
tcp4	0	0	*.79	default	LISTEN	*.*
tcp4	0	0	*.514	default	LISTEN	*.*
tcp4	0	0	*.513	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.513	__juniper_private1__	LISTEN	*.*
udp46	0	0	*.514	default		*.*
udp4	0	0	*.514	default		*.*
udp4	0	0	*.31342	__juniper_private1__		*.*
udp46	0	0	*.62103	default		*.*
udp4	0	0	*.59924	default		*.*
udp46	0	0	*.161	default		*.*
udp4	0	0	*.161	default		*.*
udp4	0	0	*.6333	__juniper_private1__		*.*

```
lcc3-re0:
```

```
-----
Active Internet connections (including servers) (including routing-instances)
Proto Recv-Q Send-Q Local Address           Foreign Address
Routing Instance         (state)
```

tcp4	0	0	*.7000	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.6234	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.9000	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.33009	__juniper_private2__	LISTEN	*.*
tcp4	0	0	*.3221	default	LISTEN	*.*
tcp4	0	0	*.23	default	LISTEN	*.*
tcp4	0	0	*.22	default	LISTEN	*.*
tcp4	0	0	*.514	default	LISTEN	*.*
tcp4	0	0	*.513	default	LISTEN	*.*
tcp4	0	0	*.21	default	LISTEN	*.*
tcp4	0	0	*.79	default	LISTEN	*.*
tcp4	0	0	*.514	__juniper_private1__	LISTEN	*.*
tcp4	0	0	*.513	__juniper_private1__	LISTEN	*.*
udp46	0	0	*.514	default		*.*
udp4	0	0	*.514			*.*

```

      udp46      0      0  *.62103      default      *.
      udp4       0      0  *.59924      default      *.
      udp4       0      0  *.31342      default      *.
      udp46      0      0  *.161        __juniper_private1__  *.
      udp4       0      0  *.161        default      *.
      udp4       0      0  *.6333       default      *.
      udp4       0      0              __juniper_private1__

```

**show system
connections (QFX
Series)**

```

user@switch> show system connections
Active Internet connections (including servers)
Proto Recv-Q Send-Q Local Address           Foreign Address
      (state)
tcp4      0      0  10.94.204.110.23       128.0.0.1.65142
172.17.28.19.1308      ESTABLISHED
tcp4      0      0  128.0.0.1.6234        128.0.0.1.65142
ESTABLISHED
tcp4      0      0  128.0.0.1.65142        128.0.0.1.6234
ESTABLISHED
tcp4      0      0  128.0.0.1.33003        128.0.0.1.61441
ESTABLISHED
tcp4      0      0  128.0.0.1.61441        128.0.0.1.33003
ESTABLISHED
tcp46     0      0  *.179                *.
LISTEN
tcp4      0      0  *.179                *.
LISTEN
tcp4      0      0  128.0.0.16.9000        128.0.0.16.50970
ESTABLISHED
tcp4      0      0  128.0.0.16.50970        128.0.0.16.9000
ESTABLISHED
tcp4      0      0  *.38                  *.
LISTEN
tcp4      0      0  *.3491                *.
LISTEN
tcp4      0      0  *.6156                *.
LISTEN
tcp4      0      0  128.0.0.1.33001        128.0.0.1.59437
ESTABLISHED
tcp4      0      0  128.0.0.1.59437        128.0.0.1.33001
ESTABLISHED
tcp4      0      0  128.0.0.1.33023        128.0.0.1.63605
ESTABLISHED
tcp4      0      0  128.0.0.1.63605        128.0.0.1.33023
ESTABLISHED
tcp4      0      0  128.0.0.1.33001        128.0.0.1.63830
ESTABLISHED
tcp4      0      0  128.0.0.1.63830        128.0.0.1.33001
ESTABLISHED
tcp4      0      0  *.667                 *.
LISTEN
tcp4      0      0  *.6156                *.
LISTEN
tcp4      0      0  128.0.0.1.7000         128.0.0.1.51580
ESTABLISHED
tcp4      0      0  128.0.0.1.51580        128.0.0.1.7000

```

			ESTABLISHED	
tcp4	0	0	128.0.0.1.6234	128.0.0.1.53646
			ESTABLISHED	
tcp4	0	0	*.33001	*.*
			LISTEN	
tcp4	0	0	*.33003	*.*
			LISTEN	
tcp4	0	0	128.0.0.1.53646	128.0.0.1.6234
			ESTABLISHED	
tcp4	0	0	128.0.0.16.9000	128.0.0.16.63454
			ESTABLISHED	
tcp4	0	0	128.0.0.16.63454	128.0.0.16.9000
			ESTABLISHED	
tcp4	0	0	*.666	*.*
			LISTEN	
tcp4	0	0	*.7000	*.*
			LISTEN	
tcp4	0	0	*.51627	*.*
			LISTEN	
tcp4	0	0	*.3492	*.*
			LISTEN	
tcp4	0	0	*.33023	*.*
			LISTEN	
tcp4	0	0	*.33013	*.*
			LISTEN	
tcp4	0	0	*.7202	*.*
			LISTEN	
tcp4	0	0	*.6151	*.*
			LISTEN	
tcp4	0	0	*.9000	*.*
			LISTEN	
tcp4	0	0	*.6161	*.*
			LISTEN	
tcp4	0	0	*.6011	*.*
			LISTEN	
tcp4	0	0	*.3221	*.*
			LISTEN	
tcp4	0	0	*.23	*.*
			LISTEN	
tcp4	0	0	*.22	*.*
			LISTEN	
tcp4	0	0	*.514	*.*
			LISTEN	
tcp4	0	0	*.513	*.*
			LISTEN	
tcp4	0	0	*.21	*.*
			LISTEN	
tcp4	0	0	*.79	*.*
			LISTEN	
tcp4	0	0	*.514	*.*
			LISTEN	
tcp4	0	0	*.513	*.*
			LISTEN	
tcp4	0	0	*.1127	*.*
			LISTEN	
tcp4	0	0	*.1129	*.*
			LISTEN	
tcp4	0	0	*.1128	*.*
			LISTEN	
tcp4	0	0	*.6234	*.*
			LISTEN	

udp46	0	0	*.514	*.*
udp4	0	0	*.514	*.*
udp4	0	0	128.0.0.1.123	*.*
udp46	0	0	*.53344	*.*
udp4	0	0	*.54261	*.*
udp46	0	0	*.161	*.*
udp4	0	0	*.161	*.*
udp4	0	0	*.31342	*.*
udp4	0	0	*.59137	*.*
udp4	0	0	*.*	*.*
udp46	0	0	*.49152	*.*
udp46	0	0	*.4784	*.*
udp46	0	0	*.3784	*.*
udp4	0	0	*.49152	*.*
udp4	0	0	*.4784	*.*
udp4	0	0	*.3784	*.*
udp4	0	0	10.255.204.110.123	*.*
udp4	0	0	*.123	*.*
udp4	0	0	*.67	*.*
udp4	0	0	*.6333	*.*
udp4	0	0	*.2293	*.*
ip4	0	0	*.*	*.*
ip4	0	0	*.*	*.*
ip4	0	0	*.*	*.*

show system core-dumps

Syntax	show system core-dumps <brief detail> <core-filename> <core-file-info>
Syntax (EX Series Switches)	show system core-dumps <all-members> <brief detail> <core-filename> <core-file-info> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system core-dumps <all-chassis all-lcc lcc <i>number</i> scc> <brief detail> <core-filename> <core-file-info>
Syntax (TX Matrix Plus Router)	show system core-dumps <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <brief detail> <core-filename> <core-file-info>
Syntax (QFX Series)	show system core-dumps <core-filename> <core-file-info>
Release Information	Command introduced before Junos OS Release 8.5. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	<p>Show core files on all routers or switches running Junos OS. You can use the show system core-dumps command to show a list of system core files created when the router or switch has failed. This command can be useful for diagnostic purposes. Each list item includes the file permissions, number of links, owner, group, size, modification date, and path and filename.</p> <p>You can use the option core-filename and its options core-file-info, brief, and detail to display more information about the specified core-dump files.</p>
Options	<p>none—Display a list of all existing core-dump files.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) On a routing matrix based on a TX Matrix router, display system core files for the TX Matrix router (switch-card chassis (SCC)) and all the T640 routers (LCCs) connected to the TX Matrix router.</p>

On a routing matrix based on a TX Matrix Plus router, display system core files for the TX Matrix Plus router (switch-fabric chassis (SFC)) and all the T1600 routers (LCCs) connected to the TX Matrix Plus router.

`<all-lcc | lcc number>`—(TX Matrix and TX Matrix Plus routers only) (Optional) On a routing matrix based on the TX Matrix router, display core dump files for all T640 routers (line-card chassis (LCCs)) or a specific T640 router (LCC) connected to the TX Matrix router.

On a routing matrix based on the TX Matrix Plus router, display logging information for all T1600 routers (line-card chassis (LCCs)) or a specific T1600 router (LCC) connected to the TX Matrix Plus router. When using the `lcc number` option, replace *number* with a value from 0 through 3.



NOTE: The `all-chassis` option displays system core files for the SCC or SFC and the LCCs connected to the SCC or SFC in the routing matrix while the `all-lcc` option only displays system core files for the LCCs in the routing matrix.

`all-members`—(EX4200 switches only) (Optional) Display system core files on all members of the Virtual Chassis configuration.

`brief`—(Optional) View details of binary.

`core-file-info`—(Optional) Display the stack trace of a core file.

`core-filename`—(Optional) Name of a specific core file to display.

`detail`—(Optional) View stack trace with details of the binary file.

`local`—(EX4200 switches only) (Optional) Display system core files on the local Virtual Chassis member.

`member member-id`—(EX4200 switches only) (Optional) Display system core files on the specified member of the Virtual Chassis configuration. Replace *member-id* with a value from 0 through 9.

`scc`—(TX Matrix routers only) (Optional) Display system core files on the TX Matrix router (or switch-card chassis).

`sfc`—(TX Matrix Plus routers only) (Optional) Display system core files on the TX Matrix Plus router (or switch-fabric chassis).

Required Privilege Level

view

List of Sample Output

`show system core-dumps` on page 913

`show system core-dumps` on page 913

`show system core-dumps (TX Matrix Plus Router)` on page 913

`show system core-dumps (QFX Series)` on page 915

Output Fields Table 140 on page 913 describes the output fields for the **show system core-dumps** command. Output fields are listed in the approximate order in which they appear.

Table 140: show system core-dumps Output Fields

Field Name	Field Description
<i>Permissions</i>	Read/write permissions for the file named.
<i>Links</i>	Number of links to the file.
<i>Owner</i>	Name of the file owner.
<i>Group</i>	Name of the group with file access.
<i>File size</i>	File size in bytes.
<i>Modified</i>	Last file modification date and time.
<i>Path/filename</i>	File path where the file resides and the filename.

Sample Output

show system core-dumps This example shows the command output if core files exist.

```
user@switcht> show system core-dumps
-rw----- 1 root wheel 268369920 Jun 18 17:59 /var/crash/vmcore.0
-rw-rw---- 1 root field 3371008 Jun 18 17:53 /var/tmp/rpd.core.0
-rw-r--r-- 1 root wheel 27775914 Jun 18 17:59 /var/crash/kernel.0
```

show system core-dumps This example shows the command output if core files do not exist.

```
user@host> show system core-dumps
/var/crash/*core*: No such file or directory
/var/tmp/*core*: No such file or directory
/var/crash/kernel.*: No such file or directory
```

show system core-dumps (TX Matrix Plus Router)

```
user@host> show system core-dumps
sfc0-re0:
-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

/var/crash/cores:
total 8

/var/tmp/cores:
total 1627592
-rw-r--r-- 1 root field 535346090 May 15 07:36
rpd.core-tarball.0.090515.0736.tgz
-rw-r--r-- 1 root field 105632057 May 15 07:37
rpd.core-tarball.1.090515.0737.tgz
-rw-r--r-- 1 root field 101981681 May 15 07:38
rpd.core-tarball.2.090515.0738.tgz
-rw-r--r-- 1 root field 85854573 May 15 07:40
rpd.core-tarball.3.090515.0740.tgz
```

```

-rw-r--r-- 1 root field 4157845 May 15 08:18
rpd.core-tarball.4.090515.0818.tgz

lcc0-re0:
-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

/var/crash/cores:
total 8

/var/tmp/cores:
total 12

lcc1-re0:
-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

/var/crash/cores:
total 8

/var/tmp/cores:
total 10024
-rw-r--r-- 1 root field 1875794 Apr 22 15:47
chassisd.core-tarball.0.090422.1547.tgz
-rw-r--r-- 1 root field 1894183 Apr 22 19:02
chassisd.core-tarball.0.090422.1902.tgz
-rw-r--r-- 1 root field 1290240 Apr 26 16:01 ksyncd_1558.core.0.090426.1601

lcc2-re0:
-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

/var/crash/cores:
total 21124008
-rw-r--r-- 1 root wheel 1022376528 May 2 06:43
core-LCC2-EGFPC7.core.0.090502.0643
-rw-r--r-- 1 root wheel 1022376528 May 2 08:13
core-LCC2-EGFPC7.core.0.090502.0813
-rw-r--r-- 1 root wheel 1022376544 May 5 06:15
core-LCC2-EGFPC7.core.0.090505.0615
-rw-r--r-- 1 root wheel 1022376544 May 6 10:59
core-LCC2-EGFPC7.core.0.090506.1059
-rw-r--r-- 1 root wheel 1022376528 May 2 06:58
core-LCC2-EGFPC7.core.1.090502.0658
-rw-r--r-- 1 root wheel 754271232 May 5 06:33
core-LCC2-EGFPC7.core.1.090505.0633
-rw-r--r-- 1 root wheel 264897536 May 6 11:12
core-LCC2-EGFPC7.core.1.090506.1112
-rw-r--r-- 1 root wheel 1022376528 May 2 07:22
core-LCC2-EGFPC7.core.2.090502.0722
-rw-r--r-- 1 root wheel 163633152 May 5 06:52
core-LCC2-EGFPC7.core.2.090505.0652
-rw-r--r-- 1 root wheel 171312128 May 6 12:13
core-LCC2-EGFPC7.core.2.090506.1213
-rw-r--r-- 1 root wheel 1022376528 May 2 07:39
core-LCC2-EGFPC7.core.3.090502.0739
-rw-r--r-- 1 root wheel 1022376528 May 2 07:55
core-LCC2-EGFPC7.core.4.090502.0755

```

```

-rw-r--r-- 1 root wheel 427277312 May 7 04:47
core-LCC2-STFPC4.core.0.090507.0447
-rw-r--r-- 1 root wheel 419609600 May 7 04:47
core-LCC2-STFPC5.core.0.090507.0447
-rw-r--r-- 1 root wheel 432356352 May 7 04:47
core-LCC2-STFPC6.core.0.090507.0447

/var/tmp/cores:
total 2568
-rw-r--r-- 1 root field 1290240 May 14 14:26 ksyncd_1540.core.0.090514.1426
...

```

**show system
core-dumps (QFX
Series)**

```
user@switch> show system core-dumps
```

```

-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

```

```

/var/crash/cores:
total 8

```

```

/var/tmp/cores:
total 1627592
-rw-r--r-- 1 root field 535346090 May 15 07:36
rpd.core-tarball.0.090515.0736.tgz
-rw-r--r-- 1 root field 105632057 May 15 07:37
rpd.core-tarball.1.090515.0737.tgz
-rw-r--r-- 1 root field 101981681 May 15 07:38
rpd.core-tarball.2.090515.0738.tgz
-rw-r--r-- 1 root field 85854573 May 15 07:40
rpd.core-tarball.3.090515.0740.tgz
-rw-r--r-- 1 root field 4157845 May 15 08:18
rpd.core-tarball.4.090515.0818.tgz

```

```
lcc0-re0:
```

```

-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

```

```

/var/crash/cores:
total 8

```

```

/var/tmp/cores:
total 12

```

```
lcc1-re0:
```

```

-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

```

```

/var/crash/cores:
total 8

```

```

/var/tmp/cores:
total 10024

```

```

-rw-r--r-- 1 root field 1875794 Apr 22 15:47
chassisd.core-tarball.0.090422.1547.tgz
-rw-r--r-- 1 root field 1894183 Apr 22 19:02
chassisd.core-tarball.0.090422.1902.tgz
-rw-r--r-- 1 root field 1290240 Apr 26 16:01 ksyncd_1558.core.0.090426.1601

```

```
lcc2-re0:
```

```

-----
/var/crash/kernel.*: No such file or directory
/tftpboot/corefiles/*core*: No such file or directory

/var/crash/cores:
total 21124008
-rw-r--r--  1 root  wheel  1022376528 May  2  06:43
core-LCC2-EGFPC7.core.0.090502.0643
-rw-r--r--  1 root  wheel  1022376528 May  2  08:13
core-LCC2-EGFPC7.core.0.090502.0813
-rw-r--r--  1 root  wheel  1022376544 May  5  06:15
core-LCC2-EGFPC7.core.0.090505.0615
-rw-r--r--  1 root  wheel  1022376544 May  6  10:59
core-LCC2-EGFPC7.core.0.090506.1059
-rw-r--r--  1 root  wheel  1022376528 May  2  06:58
core-LCC2-EGFPC7.core.1.090502.0658
-rw-r--r--  1 root  wheel  754271232 May  5  06:33
core-LCC2-EGFPC7.core.1.090505.0633
-rw-r--r--  1 root  wheel  264897536 May  6  11:12
core-LCC2-EGFPC7.core.1.090506.1112
-rw-r--r--  1 root  wheel  1022376528 May  2  07:22
core-LCC2-EGFPC7.core.2.090502.0722
-rw-r--r--  1 root  wheel  163633152 May  5  06:52
core-LCC2-EGFPC7.core.2.090505.0652
-rw-r--r--  1 root  wheel  171312128 May  6  12:13
core-LCC2-EGFPC7.core.2.090506.1213
-rw-r--r--  1 root  wheel  1022376528 May  2  07:39
core-LCC2-EGFPC7.core.3.090502.0739
-rw-r--r--  1 root  wheel  1022376528 May  2  07:55
core-LCC2-EGFPC7.core.4.090502.0755
-rw-r--r--  1 root  wheel  427277312 May  7  04:47
core-LCC2-STFPC4.core.0.090507.0447
-rw-r--r--  1 root  wheel  419609600 May  7  04:47
core-LCC2-STFPC5.core.0.090507.0447
-rw-r--r--  1 root  wheel  432356352 May  7  04:47
core-LCC2-STFPC6.core.0.090507.0447

/var/tmp/cores:
total 2568
-rw-r--r--  1 root  field    1290240 May 14 14:26 ksyncd_1540.core.0.090514.1426
...

```

show system directory-usage

Syntax	show system directory-usage <depth <i>number</i> > <path>
Syntax (EX Series)	show system directory-usage <all-members> <depth <i>number</i> > <local> <member <i>member-id</i> > <path>
Syntax (TX Matrix Router)	show system directory-usage <all-chassis all-lcc lcc <i>number</i> scc> <depth <i>number</i> > <path>
Syntax (TX Matrix Plus Router)	show system directory-usage <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <depth <i>number</i> > <path>
Syntax (MX Series Router)	show system directory-usage <all-members> <depth <i>number</i> > <local> <member <i>member-id</i> > <path>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display directory usage information.
Options	<p>none—Display all directory usage information.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display directory usage information about all the T640 routers (in a routing matrix based on a TX Matrix router) or T1600 routers (in a routing matrix based on a TX Matrix Plus router) in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display directory information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display directory information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Display directory information for all members of the Virtual Chassis configuration.</p>

depth number—(Optional) Depth of the directory to traverse. This option is useful when you want to limit the output shown for a large file system.

lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display directory information for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display directory information for a specific T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display directory information for the local Virtual Chassis member.

member member-id—(EX4200 switches and MX Series routers only) (Optional) Display directory information for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

path—(Optional) Path or root directory to traverse.

scc—(TX Matrix router only) (Optional) Display directory information for the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus router only) (Optional) Display directory information for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Required Privilege Level

view

List of Sample Output

show system directory-usage scc (TX Matrix Router) on page 919
show system directory-usage sfc (TX Matrix Plus Router) on page 919
show system directory-usage (QFX Series) on page 919

Output Fields

Table 141 on page 918 describes the output fields for the **show system directory-usage** command. Output fields are listed in the approximate order in which they appear.

Table 141: show system directory-usage Output Fields

Field Name	Field Description
<i>bytes</i>	Number of bytes used by files in a directory.
<i>directory-name</i>	Name of the directory.

Sample Output

```

show system user@host> show system directory-usage /var/tmp scc
directory-usage scc
(TX Matrix Router)
1.0K      /var/tmp
2.0K      /var/tmp/vi.recover
1.0K      /var/tmp/install
          /var/tmp/instmp.GUMpur
4.8M      /var/tmp/instmp.GUMpur/packages
6.4M      /var/tmp/troy1
297M      /var/tmp/dsw
          /var/tmp/pkg_tmp.2073
83K       /var/tmp/pkg_tmp.2073/bin
          /var/tmp/instmp.oMIDb1
89K       /var/tmp/instmp.oMIDb1/bin
          /var/tmp/instmp.byhMjR
4.6M      /var/tmp/instmp.byhMjR/packages
          /var/tmp/instmp.6fqHF3
1.7M      /var/tmp/instmp.6fqHF3/packages
          /var/tmp/instmp.mljECe
4.6M      /var/tmp/instmp.mljECe/packages

```

```

show system user@switch> show system directory-usage /var/tmp sfc 0
directory-usage sfc
(TX Matrix Plus Router)
sfc0-re0:
-----
          /var/tmp
46K       /var/tmp/gres-tp
          /var/tmp/sec-download
2.0K      /var/tmp/sec-download/sub-download
2.0K      /var/tmp/vi.recover
2.0K      /var/tmp/install
795M      /var/tmp/cores
766K      /var/tmp/pr440594

```

```

show system user@switch> show system directory-usage
directory-usage (QFX 10.0K      /root
Series)

```

show system firmware

Syntax	show system firmware <compatibility>
Release Information	Command introduced in Junos OS Release 7.4. Command introduced in Junos OS Release 9.4 for EX Series switches.
Description	(J Series routers and EX8200 switches only) Display firmware information.
Options	compatibility—(Optional) Display firmware compatibility information.
Required Privilege Level	view
List of Sample Output	show system firmware on page 920 show system firmware compatibility on page 920
Output Fields	Table 142 on page 920 lists the output fields for the show system firmware command. Output fields are listed in the approximate order in which they appear.

Table 142: show system firmware Output Fields

Field Name	Field Description
Part	Physical part on the router or switch affected by the firmware.
Type	Type of firmware on the router or switch.
Tag	Location of the firmware on the interface.
Current version	Firmware version on the affected router or switch parts.
Available version	New versions of firmware for upgrading or downgrading.
Status	Firmware condition on the router or switch.
Action	Whether you can upgrade or downgrade, or if no action is available (none).

Sample Output

show system firmware	<pre> user@host> show system firmware Part Type Tag Current version Available Status Type Tag Current version version FPC 0 ROM Monitor 0 0 6.4.10 Routing Engine 0 RE BIOS 0 0 </pre>
show system firmware compatibility	<pre> user@host> show system firmware compatibility Part Type Tag Current version Available Action Type Tag Current version version </pre>

FPC 0	ROM Monitor 0	0	6.4.10	None
Routing Engine 0	RE BIOS	0	0	None

show system license

Syntax	show system license <installed keys usage>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display licenses and information about how they are used.
Options	<p>none—Display all license information.</p> <p>installed—(Optional) Display installed licenses only.</p> <p>keys—(Optional) Display a list of license keys. Use this information to verify that each expected license key is present.</p> <p>usage—(Optional) Display the state of licensed features.</p>
Required Privilege Level	maintenance
List of Sample Output	<p>show system license on page 923</p> <p>show system license installed on page 923</p> <p>show system license keys on page 924</p> <p>show system license usage on page 924</p>
Output Fields	Table 143 on page 922 lists the output fields for the show system license command. Output fields are listed in the approximate order in which they appear.

Table 143: show system license Output Fields

Field Name	Field Description
Feature name	Name assigned to the configured feature. You use this information to verify that all the features for which you installed licenses are present.
Licenses used	<p>Number of licenses used by a router or switch. You use this information to verify that the number of licenses used matches the number configured. If a licensed feature is configured, the feature is considered used.</p> <p>NOTE: In Junos OS Release 10.1 and later, the Licenses used column displays the actual usage count based on the number of active sessions or connections as reported by the corresponding feature daemons. This is applicable for scalable license-based features such as Subscriber Access (scale-subscriber), L2TP (scale-l2tp), Mobile IP (scale-mobile-ip), and so on.</p>

Table 143: show system license Output Fields (*continued*)

Field Name	Field Description
Licenses installed	Information about the installed license key: <ul style="list-style-type: none"> License identifier—Identifier associated with a license key. State—State of the license key:valid or invalid. An invalid state indicates that the key was entered incorrectly or is not valid for the specific device. License version—Version of a license. The version indicates how the license is validated, the type of signature, and the signer of the license key. Valid for device—Device that can use a license key. Group defined—Group membership of a device. Features—Feature associated with a license, such as data link switching (DLSw).
Licenses needed	Number of licenses required for features being used but not yet properly licensed.
Expiry	Amount of time left within the grace period before a license is required for a feature being used.

Sample Output

show system license user@host> show system license

License usage:

Feature name	Licenses used	Licenses installed	Licenses needed	Expiry
subscriber-accounting	2	2	0	permanent
subscriber-authentication	1	2	0	permanent
subscriber-address-assignment	2	2	0	permanent
subscriber-vlan	2	2	0	permanent
subscriber-ip	0	2	0	permanent
scale-subscriber	2	3	0	permanent
scale-l2tp	4	5	0	permanent
scale-mobile-ip	1	2	0	permanent

Licenses installed:

License identifier: XXXXXXXXXX

License version: 2

Features:

subscriber-accounting - Per Subscriber Radius Accounting
permanent

subscriber-authentication - Per Subscriber Radius Authentication
permanent

subscriber-address-assignment - Radius/SRC Address Pool Assignment
permanent

subscriber-vlan - Dynamic Auto-sensed Vlan
permanent

subscriber-ip - Dynamic and Static IP
permanent

show system license installed user@host> show system license installed

License identifier: XXXXXXXXXX

License version: 2

Features:

subscriber-accounting - Per Subscriber Radius Accounting
permanent

subscriber-authentication - Per Subscriber Radius Authentication

```

    permanent
subscriber-address-assignment - Radius/SRC Address Pool Assignment
    permanent
subscriber-vlan - Dynamic Auto-sensed Vlan
    permanent
subscriber-ip - Dynamic and Static IP
    permanent

```

```

show system license keys user@host> show system license keys
XXXXXXXXXX XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX
XXXXXXXX XXXXXX XXXXXX XXXXXX XXXXXX XXXXXX
XXXXXXXX XXXXXX XXX

```

```

show system license usage user@host> show system license usage
License usage:

```

Feature name	Licenses used	Licenses installed	Licenses needed	Expiry
subscriber-accounting	2	2	0	permanent
subscriber-authentication	1	2	0	permanent
subscriber-address-assignment	2	2	0	permanent
subscriber-vlan	2	2	0	permanent
subscriber-ip	0	2	0	permanent
scale-subscriber	2	3	0	permanent
scale-l2tp	4	5	0	permanent
scale-mobile-ip	1	2	0	permanent

show system name-resolution

Syntax	show system name-resolution
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display hostname-to-IP-address mappings.
Options	This command has no options.
Required Privilege Level	view
Output Fields	Table 144 on page 925 lists the output fields for the show system name-resolution command. Output fields are listed in the approximate order in which they appear.

Table 144: show system name-resolution Output Fields

Field Name	Field Description
Last update	Date and time when the hostname-to-IP address mapping were last resolved.
Refresh interval	Interval for refreshing the cache with the updated hostname-to-IP address mappings.
Addresses	Resolved IP addresses based on the hostname-to-IP address mappings.
Error	Error message displayed if there is a DNS hostname lookup failure.
Last change	Timestamp for the last change in the hostname-to-IP address mappings.

show system name-resolution

```

user@host> show system name-resolution

Hostname to IP-address mappings:
-----
Last update: Mon Sep 29 18:42:21 2008
Refresh interval: 600 secs
Host: ntp1
  Addresses:
    3.3.3.11
  Last change: Mon Sep 29 18:42:20 2008
Host: radauth1
  Error: Host name lookup failure
Last change: Mon Sep 29 18:42:20 2008
Host: radacct1
  Error: Host name lookup failure
Host: snmp1
  Addresses:
    4.4.4.1
    4.4.4.2
  Last change: Mon Sep 29 18:45:20 2008
Host: sys1
  Addresses:

```

192.168.68.69
Last change: Mon Sep 29 18:42:21 2008

show system processes

Syntax	show system processes <brief detail extensive summary> <health (pid <i>process-identifier</i> process-name <i>process-name</i>)> <providers> <resource-limits (brief detail) <i>process-name</i> > <wide>
Syntax (EX Series Switch)	show system processes <all-members> <brief detail extensive summary> <health (pid <i>process-identifier</i> process-name <i>process-name</i>)> <local> <member <i>member-id</i> > <providers> <resource-limits (brief detail) <i>process-name</i> > <wide>
Syntax (TX Matrix Router)	show system processes <brief detail extensive summary> <all-chassis all-lcc lcc <i>number</i> scc> <wide>
Syntax (TX Matrix Plus Router)	show system processes <brief detail extensive summary> <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <wide>
Syntax (MX Series Router)	show system processes <brief detail extensive summary> <all-members> <health (pid <i>process-identifier</i> process-name <i>process-name</i>)> <local> <member <i>member-id</i> > <providers> <resource-limits (brief detail) <i>process-name</i> > <wide>
Syntax (QFX Series)	show system processes <brief detail extensive summary > <health (pid <i>process-identifier</i> process-name <i>process-name</i>)> <providers> <resource-limits> <wide>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in JUNOS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display information about software processes that are running on the router or switch and that have controlling terminals.

- Options** **none**—Display standard information about system processes.
- brief | detail | extensive | summary**—(Optional) Display the specified level of detail.
- all-chassis**—(TX Matrix and TX Matrix Plus routers only) (Optional) Display standard system process information about all the T640 routers (in a routing matrix based on the TX Matrix router) or all the T1600 routers (in a routing matrix based on the TX Matrix Plus router) in the chassis.
- all-lcc**—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display standard system process information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display standard system process information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.
- all-members**—(EX4200 switches and MX Series routers only) (Optional) Display standard system process information for all members of the Virtual Chassis configuration.
- health** (*pid process-identifier* | *process-name process-name*)—(Optional) Display process health information.
- lcc number**—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display standard system process information for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display standard system process information for a specific T1600 router that is connected to the TX Matrix Plus router. Replace **number** with a value from 0 through 3.
- local**—(EX4200 switches and MX Series routers only) (Optional) Display standard system process information for the local Virtual Chassis member.
- member member-id**—(EX4200 switches and MX Series routers only) (Optional) Display standard system process information for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace **member-id** with a value from 0 through 9. For an MX Series Virtual Chassis, replace **member-id** with a value of 0 or 1.
- providers**—(Optional) Display provider processes.
- resource-limits** (**brief | detail**) *process-name*—(Optional) Display process resource limits.
- scc**—(TX Matrix routers only) (Optional) Display standard system process information for the TX Matrix router (or switch-card chassis).
- sfc number**—(TX Matrix Plus routers only) (Optional) Display system process information for the TX Matrix Plus router (or switch-fabric chassis). Replace **number** with 0.
- wide**—(Optional) Display process information that might be wider than 80 columns.

Additional Information By default, when you issue the **show system processes** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command

is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output

- show system processes on page 931
- show system processes brief on page 931
- show system processes detail on page 931
- show system processes extensive on page 932
- show system processes lcc wide (TX Matrix Routing Matrix) on page 933
- show system processes summary on page 933
- show system processes (TX Matrix Plus Router) on page 934
- show system processes sfc (TX Matrix Plus Router) on page 941
- show system processes lcc wide (TX Matrix Plus Routing Matrix) on page 943
- show system processes (QFX Series) on page 945

Output Fields Table 145 on page 929 describes the output fields for the **show system processes** command. Output fields are listed in the approximate order in which they appear.

Table 145: show system processes Output Fields

Field Name	Field Description	Level of Output
last PID	Last process identifier assigned to the process.	brief extensive summary
load averages	Three load averages followed by the current time.	brief extensive summary
processes	Number of existing processes and the number of processes in each state (sleeping, running, starting, zombies, and stopped).	brief extensive summary
Mem	Information about physical and virtual memory allocation.	brief extensive summary
Swap	Information about physical and virtual memory allocation.	brief extensive summary
PID	Process identifier.	detail extensive summary
TT	Control terminal name.	none detail

Table 145: show system processes Output Fields (*continued*)

Field Name	Field Description	Level of Output
STAT	<p>Symbolic process state. The state is given by a sequence of letters. The first letter indicates the run state of the process:</p> <ul style="list-style-type: none"> • D—In disk or other short-term, uninterruptible wait • I—Idle (sleeping longer than about 20 seconds) • R—Runnable • S—Sleeping for less than 20 seconds • T—Stopped • Z—Dead (zombie) • + —The process is in the foreground process group of its control terminal. • < —The process has raised CPU scheduling priority. • > —The process has specified a soft limit on memory requirements and is currently exceeding that limit; such a process is not swapped. • A—The process requested random page replacement. • E—The process is trying to exit. • L—The process has pages locked in core. • N—The process has reduced CPU scheduling priority. • S—The process requested first-in, first-out (FIFO) page replacement. • s—The process is a session leader. • V—The process is temporarily suspended. • W—The process is swapped out. • X—The process is being traced or debugged. 	none detail
UID	User identifier.	detail
USERNAME	Process owner.	extensive summary
PPID	Parent process identifier.	detail
CPU	<p>(D)—Short-term CPU usage.</p> <p>(E and S)—Raw (unweighted) CPU usage. The value of this field is used to sort the processes in the output.</p>	detail extensive summary
RSS	Resident set size.	detail
WCHAN	Symbolic name of the wait channel.	detail
STARTED	Local time when the process started running.	detail
PRI	Current priority of the process. A lower number indicates a higher priority.	detail extensive summary
NI or NICE	UNIX "niceness" value. A lower number indicates a higher priority.	detail extensive summary
SIZE	Total size of the process (text, data, and stack), in kilobytes.	extensive summary

Table 145: show system processes Output Fields (*continued*)

Field Name	Field Description	Level of Output
RES	Current amount of resident memory, in kilobytes.	extensive summary
STATE	Current state of the process (for example, sleep , wait , run , idle , zombie , or stop).	extensive summary
TIME	(S)—Number of system and user CPU seconds that the process has used. (None, D, and E)—Total amount of time that the command has been running.	detail extensive summary
WCPU	Weighted CPU usage.	extensive summary
COMMAND	Command that is currently running.	detail extensive summary

Sample Output

```

show system processes user@host> show system processes
PID  TT  STAT  TIME  COMMAND
  0  ??  DLs   0:00.70  (swapper)
  1  ??  Is    0:00.35  /sbin/init --
  2  ??  DL    0:00.00  (pagedaemon)
  3  ??  DL    0:00.00  (vmdaemon)
  4  ??  DL    0:42.37  (update)
  5  ??  DL    0:00.00  (if_jnx)
 80  ??  Ss    0:14.66  syslogd -s
 96  ??  Is    0:00.01  portmap
128  ??  Is    0:02.70  cron
173  ??  Is    0:02.24  /usr/local/sbin/sshd (sshd1)
189  ??  S     0:03.80  /sbin/watchdog -t180
190  ??  I     0:00.03  /usr/sbin/tnetd -N
191  ??  S     2:24.76  /sbin/ifd -N
192  ??  S<    0:55.44  /usr/sbin/xntpd -N
195  ??  S     0:53.11  /usr/sbin/snmpd -N
196  ??  S     1:15.73  /usr/sbin/mib2d -N
198  ??  I     0:00.75  /usr/sbin/inetd -N
2677 ??  I     0:00.01  /usr/sbin/mgd -N
2712 ??  Ss    0:00.24  rlogind
2735 ??  R     0:00.00  /bin/ps -ax
1985 p0- S   0:07.41  ./rpd -N
2713 p0  Is   0:00.24  -tcsh (tcsh)
2726 p0  S+   0:00.07  cli

show system processes brief user@host> show system processes brief
last pid:  543;  load averages:  0.00,  0.00,  0.00   18:29:47
37 processes:  1 running, 36 sleeping

Mem: 25M Active, 3976K Inact, 19M Wired, 8346K Buf, 202M Free
Swap: 528M Total, 64K Used, 528M Free

show system processes detail user@host> show system processes detail
PID  UID  PPID CPU PRI NI  RSS WCHAN  STARTED  TT  STAT  TIME  COMMAND
3151 1049 3129  2  28  0  672 -        1:13PM  p0  R+    0:00.00  ps -ax -r
  1   0   0   0  10  0  376 wait    1:51PM  ??  Is    0:00.29  /sbin/ini
  2   0   0   0 -18  0  12  psleep    1:51PM  ??  DL    0:00.00  (pagedae

```

```

 3    0    0    0 28    0    12 psleep 1:51PM ?? DL 0:00.00 (vmdaemo
 4    0    0    0 28    0    12 update 1:51PM ?? DL 0:07.15 (update)
 5    0    0    0 2    0    12 pfesel 1:51PM ?? IL 0:02.90 (if_pfe)
27    0    1    0 10    0 17936 mfsidl 1:51PM ?? Is 0:00.46 mfs /dev/
81    0    1    0 2    0    496 select 1:52PM ?? Ss 0:31.21 syslogd -
119   1    1    0 2    0    492 select 1:52PM ?? Is 0:00.00 portmap
134   0    1    0 2    0    580 select 1:52PM ?? S 0:02.95 amd -p -a
151   0    1    0 18    0    532 pause 1:52PM ?? Is 0:00.34 cron
183   0    1    0 2    0    420 select 1:52PM ?? Ss 0:00.07 /usr/loca
206   0    1    0 18    0    72 pause 1:52PM ?? S 0:00.51 /sbin/wat
207   0    1    0 2    0    520 select 1:52PM ?? I 0:00.16 /usr/sbin
208   0    1    0 2    0    536 select 1:52PM ?? S 0:08.21 /sbin/dcd
210   0    1 255 2 -12 740 select 1:52PM ?? S< 0:05.83 /usr/sbin
211   0    1    0 2    0    376 select 1:52PM ?? S 0:00.03 /usr/sbin
215   0    1    0 2    0    548 select 1:52PM ?? I 0:00.50 /usr/sbin
219   0    1    0 3    0    540 ttyin 1:52PM v0 Is+ 0:00.02 /usr/libe
220   0    1    0 3    0    540 ttyin 1:52PM v1 Is+ 0:00.01 /usr/libe
221   0    1    0 3    0    540 ttyin 1:52PM v2 Is+ 0:00.01 /usr/libe
222   0    1    0 3    0    540 ttyin 1:52PM v3 Is+ 0:00.01 /usr/libe
735   0    1    0 2    0    468 select 2:47PM ?? S 0:19.14 /usr/sbin
736   0    1    0 2    0    212 select 2:47PM ?? S 0:14.13 /usr/sbin
1380  0    1    0 3    0    888 ttyin 7:32PM d0 Is+ 0:00.46 bash
3019  0    207  0 2    0    636 select 10:49AM ?? Ss 0:02.93 tnp.chass
3122  0    1380 0 2    0 1764 select 12:33PM d0 S 0:00.77 ./rpd -N
3128  0    215 0 2    0    580 select 12:45PM ?? Ss 0:00.12 rlogind
3129 1049 3128 0 18    0    944 pause 12:45PM p0 Ss 0:00.14 -tcsh (tc
 0    0    0    0 -18 0 0 sched 1:51PM ?? DLs 0:00.10 (swapper

```

```

show system user@host> show system processes extensive
processes extensive last pid: 544; load averages: 0.00, 0.00, 0.00 18:30:33
37 processes: 1 running, 36 sleeping

```

Mem: 25M Active, 3968K Inact, 19M Wired, 8346K Buf, 202M Free

Swap: 528M Total, 64K Used, 528M Free

PID	USERNAME	PRI	NICE	SIZE	RES	STATE	TIME	WCPU	CPU	COMMAND
544	root	30	0	604K	768K	RUN	0:00	0.00%	0.00%	top
3	root	28	0	0K	12K	psleep	0:00	0.00%	0.00%	vmdaemon
4	root	28	0	0K	12K	update	0:03	0.00%	0.00%	update
528	aviva	18	0	660K	948K	pause	0:00	0.00%	0.00%	tcsh
204	root	18	0	300K	544K	pause	0:00	0.00%	0.00%	csh
131	root	18	0	332K	532K	pause	0:00	0.00%	0.00%	cron
186	root	18	0	196K	68K	pause	0:00	0.00%	0.00%	watchdog
27	root	10	0	512M	16288K	mfsidl	0:00	0.00%	0.00%	mount_mfs
1	root	10	0	620K	344K	wait	0:00	0.00%	0.00%	init
304	root	3	0	884K	900K	ttyin	0:00	0.00%	0.00%	bash
200	root	3	0	180K	540K	ttyin	0:00	0.00%	0.00%	getty
203	root	3	0	180K	540K	ttyin	0:00	0.00%	0.00%	getty
202	root	3	0	180K	540K	ttyin	0:00	0.00%	0.00%	getty
201	root	3	0	180K	540K	ttyin	0:00	0.00%	0.00%	getty
194	root	2	0	2248K	1640K	select	0:11	0.00%	0.00%	rpdp
205	root	2	0	964K	800K	select	0:12	0.00%	0.00%	tnp.chassisd
189	root	2	-12	352K	740K	select	0:03	0.00%	0.00%	xntpd
114	root	2	0	296K	612K	select	0:00	0.00%	0.00%	amd
188	root	2	0	780K	600K	select	0:00	0.00%	0.00%	dcd
527	root	2	0	176K	580K	select	0:00	0.00%	0.00%	rlogind
195	root	2	0	212K	552K	select	0:00	0.00%	0.00%	inetd
187	root	2	0	192K	532K	select	0:00	0.00%	0.00%	tnetd
83	root	2	0	188K	520K	select	0:00	0.00%	0.00%	syslogd
538	root	2	0	1324K	516K	select	0:00	0.00%	0.00%	mgd
99	daemon	2	0	176K	492K	select	0:00	0.00%	0.00%	portmap
163	root	2	0	572K	420K	select	0:00	0.00%	0.00%	nsrexecd

```

192 root      2   0   560K   400K select  0:10  0.00%  0.00% snmpd
191 root      2   0  1284K   376K select  0:00  0.00%  0.00% mgd
537 aviva     2   0   636K   364K select  0:00  0.00%  0.00% cli
193 root      2   0   312K   204K select  0:07  0.00%  0.00% mib2d
  5 root      2   0      0K    12K pfesel  0:00  0.00%  0.00% if_pfe
  2 root     -18   0      0K    12K psleep  0:00  0.00%  0.00% pagedaemon
  0 root     -18   0      0K      0K sched  0:00  0.00%  0.00% swapper

```

show system processes lcc wide (TX Matrix Routing Matrix)

```

user@host> show system processes lcc 2 wide
lcc2-re0:

```

```

-----
PID  TT  STAT      TIME COMMAND
  0  ??  DLs      0:00.00 (swapper)
  1  ??  ILs      0:00.10 /sbin/preinit -- (init)
  2  ??  DL       0:00.00 (pagedaemon)
  3  ??  DL       0:00.00 (vmdaemon)
  4  ??  DL       0:00.00 (bufdaemon)
  5  ??  DL       0:00.04 (syncer)
  6  ??  DL       0:00.00 (netdaemon)
  7  ??  IL       0:00.00 (if_pic_listen)
  8  ??  IL       0:00.00 (scs_housekeeping)
  9  ??  IL       0:00.00 (if_pfe_listen)
 10  ??  DL       0:00.00 (vmuncachedaemon)
 11  ??  SL       0:00.02 (cb_poll)
 172 ??  ILs      0:00.21 mfs -o noauto /dev/ad1s1b /tmp (newfs)
2909 ??  Is       0:00.00 pccardd
2932 ??  Ss       0:00.07 syslogd -r -s
3039 ??  Is       0:00.00 cron
3217 ??  I        0:00.00 /sbin/watchdog -d
3218 ??  I        0:00.02 /usr/sbin/tnetd -N
3221 ??  S        0:00.11 /usr/sbin/alarmd -N
3222 ??  S        0:00.85 /usr/sbin/craftd -N
3223 ??  S        0:00.05 /usr/sbin/mgd -N
3224 ??  I        0:00.02 /usr/sbin/inetd -N
3225 ??  I        0:00.00 /usr/sbin/tnp.sntpd -N
3226 ??  I        0:00.01 /usr/sbin/tnp.sntpc -N
3228 ??  I        0:00.01 /usr/sbin/smartd -N
3231 ??  I        0:00.01 /usr/sbin/eccd -N
3425 ??  S        0:00.09 /usr/sbin/dfwd -N
3426 ??  S        0:00.19 /sbin/dcd -N
3427 ??  I        0:00.04 /usr/sbin/pfed -N
3430 ??  S        0:00.10 /usr/sbin/ksyncd -N
3482 ??  S        1:53.63 /usr/sbin/chassisd -N
4285 ??  SL       0:00.01 (peer proxy)
4286 ??  SL       0:00.00 (peer proxy)
4303 ??  Ss       0:00.00 mgd: (mgd) (root) (mgd)
4304 ??  R        0:00.00 /bin/ps -ax -ww
3270 d0  Is+      0:00.00 /usr/libexec/getty std.9600 ttyd0

```

show system processes summary

```

user@host> show system processes summary
last pid: 543; load averages: 0.00, 0.00, 0.00 18:29:47
37 processes: 1 running, 36 sleeping

```

```

Mem: 25M Active, 3976K Inact, 19M Wired, 8346K Buf, 202M Free
Swap: 528M Total, 64K Used, 528M Free

```

```

PID USERNAME PRI NICE SIZE   RES STATE  TIME  WCPU   CPU COMMAND
527 root      2   0   176K   580K select  0:00  0.04%  0.04% rlogind
543 root     30   0   604K   768K RUN     0:00  0.00%  0.00% top

```

**show system
processes (TX Matrix
Plus Router)**

user@host> show system processes
sfc0-re0:

```

-----
PID  TT  STAT      TIME COMMAND
 0  ??  WLS      0:00.00 [swapper]
 1  ??  ILs      0:00.18 /packages/mnt/jbase/sbin/init --
 2  ??  DL       0:00.20 [g_event]
 3  ??  DL       0:00.39 [g_up]
 4  ??  DL       0:00.32 [g_down]
 5  ??  DL       0:00.00 [thread taskq]
 6  ??  DL       0:00.09 [kqueue taskq]
 7  ??  DL       0:00.01 [pagedaemon]
 8  ??  DL       0:00.00 [vmdaemon]
 9  ??  DL       0:06.63 [pagezero]
10  ??  DL       0:00.00 [ktrace]
11  ??  RL      310:52.98 [idle]
12  ??  WL       0:11.03 [swi2: net]
13  ??  WL       0:27.58 [swi7: clock sio]
14  ??  WL       0:00.00 [swi6: vm]
15  ??  DL       0:03.02 [yarrow]
16  ??  WL       0:00.00 [swi9: +]
17  ??  WL       0:00.00 [swi8: +]
18  ??  WL       0:00.00 [swi5: cambio]
19  ??  WL       0:00.00 [swi9: task queue]
20  ??  WL       0:11.41 [irq16: uhci0 uhci*]
21  ??  DL       0:00.00 [usb0]
22  ??  DL       0:00.00 [usbtask]
23  ??  WL       0:39.51 [irq17: uhci1 uhci*]
24  ??  DL       0:00.00 [usb1]
25  ??  WL       0:00.00 [irq18: uhci2 uhci*]
26  ??  DL       0:00.83 [usb2]
27  ??  DL       0:00.00 [usb3]
28  ??  DL       0:00.00 [usb4]
29  ??  DL       0:00.00 [usb5]
30  ??  DL       0:00.73 [usb6]
31  ??  DL       0:00.00 [usb7]
32  ??  WL       0:00.00 [irq14: ata0]
33  ??  WL       0:00.00 [irq15: ata1]
34  ??  WL       0:00.00 [irq1: atkbd0]
35  ??  WL       0:00.00 [swi0: sio]
36  ??  WL       0:00.00 [irq11: isab0]
37  ??  WL       0:00.00 [swi3: ip6opt ipopt]
38  ??  WL       0:00.00 [swi4: ip6mismatch+]
39  ??  WL       0:00.00 [swi1: ipfwd]
40  ??  DL       0:00.02 [bufdaemon]
41  ??  DL       0:00.02 [vnlr]
42  ??  DL       0:00.39 [syncer]
43  ??  DL       0:00.05 [softdepflush]
44  ??  DL       0:00.00 [netdaemon]
45  ??  DL       0:00.02 [vmuncachedaemon]
46  ??  DL       0:00.00 [if_pic_listen]
47  ??  DL       0:00.35 [vmkmemdaemon]
48  ??  DL       0:00.00 [cb_poll]
49  ??  DL       0:00.06 [if_pfe_listen]
50  ??  DL       0:00.00 [scs_housekeeping]
51  ??  IL       0:00.00 [kern_dump_proc]
52  ??  IL       0:00.00 [nfsiod 0]
53  ??  IL       0:00.00 [nfsiod 1]
54  ??  IL       0:00.00 [nfsiod 2]
55  ??  IL       0:00.00 [nfsiod 3]
56  ??  DL       0:00.37 [schedcpu]

```

```

57 ?? DL 0:00.56 [md0]
79 ?? DL 0:02.58 [md1]
100 ?? DL 0:00.03 [md2]
118 ?? DL 0:00.01 [md3]
139 ?? DL 0:00.95 [md4]
160 ?? DL 0:00.12 [md5]
181 ?? DL 0:00.00 [md6]
217 ?? DL 0:00.02 [md7]
227 ?? DL 0:00.05 [md8]
1341 ?? SL 0:01.34 [bcmTX]
1342 ?? SL 0:01.68 [bcmXGS3AsyncTX]
1343 ?? SL 0:41.40 [bcmLINK.0]
1345 ?? SL 0:33.83 [bcmLINK.1]
1350 ?? Is 0:00.01 /usr/sbin/cron
1502 ?? S 0:00.01 /sbin/watchdog -t-1
1503 ?? S 0:00.86 /usr/libexec/bslockd -mp -N
1504 ?? S 0:00.01 /usr/sbin/tnetd -N
1507 ?? S 0:01.32 /usr/sbin/alarmd -N
1508 ?? S 0:14.54 /usr/sbin/craftd -N
1509 ?? S 0:01.19 /usr/sbin/mgd -N
1512 ?? I 0:00.05 /usr/sbin/inetd -N
1513 ?? S 0:00.10 /usr/sbin/tnp.sntpd -N
1517 ?? S 0:00.11 /usr/sbin/smartd -N
1525 ?? S 0:01.10 /usr/sbin/idpd -N
1526 ?? S 0:01.43 /usr/sbin/license-check -U -M -p 10 -i 10
1527 ?? I 0:00.01 /usr/libexec/getty Pc ttyv0
1616 ?? DL 0:00.30 [peer proxy]
1617 ?? DL 0:00.32 [peer proxy]
1618 ?? DL 0:00.34 [peer proxy]
1619 ?? DL 0:00.30 [peer proxy]
2391 ?? Is 0:00.01 telnetd
7331 ?? Ss 0:00.03 telnetd
9538 ?? DL 0:01.16 [jsr_kkcm]
9613 ?? DL 0:00.18 [peer proxy]
23781 ?? Ss 0:00.01 telnetd
23926 ?? Ss 0:00.01 mgd: (mgd) (regress)/dev/tty2 (mgd)
36867 ?? S 0:03.14 /usr/sbin/rpd -N
36874 ?? S 0:00.08 /usr/sbin/lmpd
36876 ?? S 0:00.17 /usr/sbin/lacpd -N
36877 ?? S 0:00.15 /usr/sbin/bfdd -N
36878 ?? S 0:05.05 /usr/sbin/ppmd -N
36907 ?? S 0:25.07 /usr/sbin/chassisd -N
37775 ?? S 0:00.01 /usr/sbin/bdbrepd -N
45727 ?? S 0:00.02 /usr/sbin/xntpd -j -N -g (ntpd)
45729 ?? S 0:00.38 /usr/sbin/l2ald -N
45730 ?? S< 0:00.12 /usr/sbin/apspd -N
45731 ?? SN 0:00.10 /usr/sbin/sampled -N
45732 ?? S 0:00.03 /usr/sbin/ilmid -N
45733 ?? S 0:00.09 /usr/sbin/rmopd -N
45734 ?? S 0:00.30 /usr/sbin/cosd
45735 ?? I 0:00.00 /usr/sbin/rtspd -N
45736 ?? S 0:00.06 /usr/sbin/fsad -N
45737 ?? S 0:00.05 /usr/sbin/rdd -N
45738 ?? S 0:00.10 /usr/sbin/pppd -N
45739 ?? S 0:00.05 /usr/sbin/dfcd -N
45740 ?? S 0:00.07 /usr/sbin/lfmd -N
45741 ?? S 0:00.01 /usr/sbin/mplsoamd -N
45742 ?? I 0:00.01 /usr/sbin/sendd -N
45743 ?? S 0:00.08 /usr/sbin/appidd -N
45744 ?? S 0:00.05 /usr/sbin/mspd -N
45745 ?? S 0:00.25 /usr/sbin/jdiameterd -N

```

```

45746 ?? S      0:00.10 /usr/sbin/pfed -N
45747 ?? S      0:00.19 /usr/sbin/lpdfd -N
45748 ?? S      0:00.63 /sbin/dcd -N
45750 ?? S      0:00.45 /usr/sbin/mib2d -N
45751 ?? S      0:00.15 /usr/sbin/dfwd -N
45752 ?? S      0:00.15 /usr/sbin/irsd -N
45764 ?? S      0:20.59 /usr/sbin/snmpd -N
56479 ?? Ss     0:00.00 mgd: (mgd) (root) (mgd)
56480 ?? R      0:00.00 /bin/ps -ax
1142 d0- I      0:00.01 /usr/sbin/usbd -N
1160 d0- S      0:29.17 /usr/sbin/eventd -N -r -s -A
6527 d0 Is+    0:00.00 /usr/libexec/getty std.9600 ttyd0
2392 p1 Is      0:00.00 login [pam] (login)
2393 p1 I       0:00.00 -csh (csh)
2394 p1 I       0:00.00 su -
2395 p1 I+      0:00.01 -su (csh)
23782 p2 Is      0:00.00 login [pam] (login)
23881 p2 I       0:00.00 -csh (csh)
23925 p2 S+     0:00.03 cli
7332 p3 Is      0:00.00 login [pam] (login)
7333 p3 I       0:00.00 -csh (csh)
23780 p3 S+     0:00.02 telnet aj

```

lcc0-re0:

```

-----
PID TT  STAT    TIME COMMAND
  0 ??  Wls    0:00.00 [swapper]
  1 ??  ILs    0:00.16 /packages/mnt/jbase/sbin/init --
  2 ??  DL     0:00.01 [g_event]
  3 ??  DL     0:00.16 [g_up]
  4 ??  DL     0:00.11 [g_down]
  5 ??  DL     0:00.00 [thread taskq]
  6 ??  DL     0:00.00 [kqueue taskq]
  7 ??  DL     0:00.00 [pagedaemon]
  8 ??  DL     0:00.00 [vmdaemon]
  9 ??  DL     0:01.77 [pagezero]
 10 ??  DL     0:00.00 [ktrace]
 11 ??  RL    17:22.31 [idle]
 12 ??  WL     0:00.32 [swi2: net]
 13 ??  WL     0:01.21 [swi7: clock sio]
 14 ??  WL     0:00.00 [swi6: vm]
 15 ??  DL     0:00.10 [yarrow]
 16 ??  WL     0:00.00 [swi9: +]
 17 ??  WL     0:00.00 [swi8: +]
 18 ??  WL     0:00.00 [swi5: cambio]
 19 ??  WL     0:00.00 [swi9: task queue]
 20 ??  WL     0:02.73 [irq10: bcm0 uhci1*]
 21 ??  WL     0:00.02 [irq11: cb0 uhci0+*]
 22 ??  DL     0:00.00 [usb0]
 23 ??  DL     0:00.00 [usbtask]
 24 ??  DL     0:00.00 [usb1]
 25 ??  DL     0:00.05 [usb2]
 26 ??  DL     0:00.00 [usb3]
 27 ??  DL     0:00.00 [usb4]
 28 ??  DL     0:00.00 [usb5]
 29 ??  DL     0:00.04 [usb6]
 30 ??  DL     0:00.00 [usb7]
 31 ??  WL     0:00.00 [irq14: ata0]
 32 ??  WL     0:00.00 [irq15: ata1]
 33 ??  WL     0:00.00 [irq1: atkbd0]
 34 ??  WL     0:00.00 [swi0: sio]

```



```

35 ?? WL 0:00.00 [swi3: ip6opt ipopt]
36 ?? WL 0:00.00 [swi4: ip6mismatch+]
37 ?? WL 0:00.00 [swi1: ipfwd]
38 ?? DL 0:00.00 [bufdaemon]
39 ?? DL 0:00.00 [vnlru]
40 ?? DL 0:00.01 [syncer]
41 ?? DL 0:00.00 [softdepflush]
42 ?? DL 0:00.00 [netdaemon]
43 ?? DL 0:00.00 [vmuncachedaemon]
44 ?? DL 0:00.00 [if_pic_listen]
45 ?? DL 0:00.02 [vmkmemdaemon]
46 ?? DL 0:00.01 [cb_poll]
47 ?? DL 0:00.00 [if_pfe_listen]
48 ?? DL 0:00.00 [scs_housekeeping]
49 ?? IL 0:00.00 [kern_dump_proc]
50 ?? IL 0:00.00 [nfsiod 0]
51 ?? IL 0:00.00 [nfsiod 1]
52 ?? IL 0:00.00 [nfsiod 2]
53 ?? IL 0:00.00 [nfsiod 3]
54 ?? DL 0:00.01 [schedcpu]
55 ?? DL 0:00.73 [md0]
77 ?? DL 0:03.54 [md1]
98 ?? DL 0:00.37 [md2]
116 ?? DL 0:00.02 [md3]
137 ?? DL 0:00.56 [md4]
158 ?? DL 0:00.15 [md5]
179 ?? DL 0:00.00 [md6]
215 ?? DL 0:00.03 [md7]
225 ?? DL 0:00.03 [md8]
1078 ?? DL 0:00.00 [jsr_kkcm]
1363 ?? SL 0:00.09 [bcmTX]
1364 ?? SL 0:00.10 [bcmXGS3AsyncTX]
1365 ?? SL 0:03.08 [bcmLINK.0]
1370 ?? Is 0:00.00 /usr/sbin/cron
1522 ?? S 0:00.00 /sbin/watchdog -t-1
1523 ?? S 0:00.05 /usr/libexec/bslockd -mp -N
1524 ?? I 0:00.01 /usr/sbin/tnetd -N
1526 ?? S 0:04.98 /usr/sbin/chassisd -N
1527 ?? S 0:00.04 /usr/sbin/alarmd -N
1528 ?? I 0:00.40 /usr/sbin/craftd -N
1529 ?? S 0:00.08 /usr/sbin/mgd -N
1532 ?? I 0:00.04 /usr/sbin/inetd -N
1533 ?? I 0:00.00 /usr/sbin/tnp.sntpd -N
1534 ?? I 0:00.00 /usr/sbin/tnp.sntpc -N
1536 ?? S 0:00.01 /usr/sbin/smartd -N
1540 ?? I 0:00.07 /usr/sbin/jcsd -N
1541 ?? S 0:00.11 /usr/sbin/idpd -N
1542 ?? I 0:00.00 /usr/libexec/getty Pc ttyv0
2089 ?? DL 0:00.01 [peer proxy]
2090 ?? DL 0:00.01 [peer proxy]
2091 ?? DL 0:00.01 [peer proxy]
2657 ?? S 0:00.02 /usr/sbin/dfwd -N
2658 ?? S 0:00.02 /sbin/dcd -N
2659 ?? S 0:00.05 /usr/sbin/snmpd -N
2660 ?? S 0:00.01 /usr/sbin/mib2d -N
2661 ?? S 0:00.01 /usr/sbin/pfed -N
2662 ?? S 0:00.01 /usr/sbin/irsd -N
2667 ?? S 0:00.13 /usr/sbin/ksyncd -N
2690 ?? Ss 0:00.00 mgd: (mgd) (root) (mgd)
2691 ?? R 0:00.00 /bin/ps -ax
1164 d0- S 0:00.00 /usr/sbin/usbd -N

```

```

1182 d0- S      0:00.34 /usr/sbin/eventd -N -r -s -A
1543 d0 Is+    0:00.00 /usr/libexec/getty std.9600 ttyd0

```

```
lcc1-re0:
```

```

-----
PID TT  STAT      TIME COMMAND
  0 ??  Wls      0:00.00 [swapper]
  1 ??  ILs      0:00.17 /packages/mnt/jbase/sbin/init --
  2 ??  DL       0:00.01 [g_event]
  3 ??  DL       0:00.16 [g_up]
  4 ??  DL       0:00.11 [g_down]
  5 ??  DL       0:00.00 [thread taskq]
  6 ??  DL       0:00.00 [kqueue taskq]
  7 ??  DL       0:00.00 [pagedaemon]
  8 ??  DL       0:00.00 [vmdaemon]
  9 ??  DL       0:01.77 [pagezero]
 10 ??  DL       0:00.00 [ktrace]
 11 ??  RL      17:22.83 [idle]
 12 ??  WL       0:00.35 [swi2: net]
 13 ??  WL       0:01.20 [swi7: clock sio]
 14 ??  WL       0:00.00 [swi6: vm]
 15 ??  DL       0:00.10 [yarrow]
 16 ??  WL       0:00.00 [swi9: +]
 17 ??  WL       0:00.00 [swi8: +]
 18 ??  WL       0:00.00 [swi5: cambio]
 19 ??  WL       0:00.00 [swi9: task queue]
 20 ??  WL       0:02.87 [irq10: bcm0 uhci1*]
 21 ??  WL       0:00.02 [irq11: cb0 uhci0+*]
 22 ??  DL       0:00.00 [usb0]
 23 ??  DL       0:00.00 [usbtask]
 24 ??  DL       0:00.00 [usb1]
 25 ??  DL       0:00.05 [usb2]
 26 ??  DL       0:00.00 [usb3]
 27 ??  DL       0:00.00 [usb4]
 28 ??  DL       0:00.00 [usb5]
 29 ??  DL       0:00.04 [usb6]
 30 ??  DL       0:00.00 [usb7]
 31 ??  WL       0:00.00 [irq14: ata0]
 32 ??  WL       0:00.00 [irq15: ata1]
 33 ??  WL       0:00.00 [irq1: atkbd0]
 34 ??  WL       0:00.00 [swi0: sio]
 35 ??  WL       0:00.00 [swi3: ip6opt ipopt]
 36 ??  WL       0:00.00 [swi4: ip6mismatch+]
 37 ??  WL       0:00.00 [swi1: ipfwd]
 38 ??  DL       0:00.00 [bufdaemon]
 39 ??  DL       0:00.00 [vn1ru]
 40 ??  DL       0:00.01 [syncer]
 41 ??  DL       0:00.00 [softdepflush]
 42 ??  DL       0:00.00 [netdaemon]
 43 ??  DL       0:00.00 [vmuncachedaemon]
 44 ??  DL       0:00.00 [if_pic_listen]
 45 ??  DL       0:00.02 [vmkmemdaemon]
 46 ??  DL       0:00.01 [cb_poll]
 47 ??  DL       0:00.00 [if_pfe_listen]
 48 ??  DL       0:00.00 [scs_housekeeping]
 49 ??  IL       0:00.00 [kern_dump_proc]
 50 ??  IL       0:00.00 [nfsiod 0]
 51 ??  IL       0:00.00 [nfsiod 1]
 52 ??  IL       0:00.00 [nfsiod 2]
 53 ??  IL       0:00.00 [nfsiod 3]
 54 ??  DL       0:00.02 [schedcpu]

```

```

55 ?? DL 0:00.75 [md0]
77 ?? DL 0:03.40 [md1]
98 ?? DL 0:00.37 [md2]
116 ?? DL 0:00.02 [md3]
137 ?? DL 0:00.56 [md4]
158 ?? DL 0:00.15 [md5]
179 ?? DL 0:00.00 [md6]
215 ?? DL 0:00.03 [md7]
225 ?? DL 0:00.03 [md8]
1052 ?? DL 0:00.00 [jsr_kkcm]
1337 ?? SL 0:00.09 [bcmTX]
1338 ?? SL 0:00.10 [bcmXGS3AsyncTX]
1339 ?? SL 0:03.10 [bcmLINK.0]
1344 ?? Is 0:00.00 /usr/sbin/cron
1496 ?? S 0:00.00 /sbin/watchdog -t-1
1497 ?? S 0:00.05 /usr/libexec/bslockd -mp -N
1498 ?? I 0:00.01 /usr/sbin/tnetd -N
1500 ?? S 0:04.97 /usr/sbin/chassisd -N
1501 ?? S 0:00.04 /usr/sbin/alarmd -N
1502 ?? I 0:00.40 /usr/sbin/craftd -N
1503 ?? S 0:00.08 /usr/sbin/mgd -N
1506 ?? I 0:00.04 /usr/sbin/inetd -N
1507 ?? I 0:00.00 /usr/sbin/tnp.sntpd -N
1508 ?? I 0:00.00 /usr/sbin/tnp.sntpc -N
1510 ?? S 0:00.01 /usr/sbin/smartd -N
1514 ?? I 0:00.07 /usr/sbin/jcsd -N
1515 ?? S 0:00.18 /usr/sbin/idpd -N
1516 ?? I 0:00.00 /usr/libexec/getty Pc ttyv0
2068 ?? DL 0:00.01 [peer proxy]
2069 ?? DL 0:00.01 [peer proxy]
2070 ?? DL 0:00.01 [peer proxy]
2666 ?? S 0:00.02 /sbin/dcd -N
2667 ?? S 0:00.01 /usr/sbin/irsd -N
2668 ?? S 0:00.01 /usr/sbin/pfed -N
2669 ?? S 0:00.05 /usr/sbin/snmpd -N
2670 ?? S 0:00.01 /usr/sbin/mib2d -N
2671 ?? S 0:00.02 /usr/sbin/dfwd -N
2675 ?? S 0:00.13 /usr/sbin/ksyncd -N
2699 ?? Ss 0:00.00 mgd: (mgd) (root) (mgd)
2700 ?? R 0:00.00 /bin/ps -ax
1138 d0- S 0:00.00 /usr/sbin/usbd -N
1156 d0- S 0:00.37 /usr/sbin/eventd -N -r -s -A
1517 d0 Is+ 0:00.00 /usr/libexec/getty std.9600 ttyd0

```

```
lcc2-re0:
```

```

-----
PID TT STAT TIME COMMAND
0 ?? Wls 0:00.00 [swapper]
1 ?? ILs 0:00.18 /packages/mnt/jbase/sbin/init --
2 ?? DL 0:00.01 [g_event]
3 ?? DL 0:00.17 [g_up]
4 ?? DL 0:00.12 [g_down]
5 ?? DL 0:00.00 [thread taskq]
6 ?? DL 0:00.00 [kqueue taskq]
7 ?? DL 0:00.00 [pagedaemon]
8 ?? DL 0:00.00 [vmdaemon]
9 ?? DL 0:01.77 [pagezero]
10 ?? DL 0:00.00 [ktrace]
11 ?? RL 17:19.13 [idle]
12 ?? WL 0:00.36 [swi2: net]
13 ?? WL 0:01.20 [swi7: clock sio]

```

```

14 ?? WL 0:00.00 [swi6: vm]
15 ?? DL 0:00.13 [yarrow]
16 ?? WL 0:00.00 [swi9: +]
17 ?? WL 0:00.00 [swi8: +]
18 ?? WL 0:00.00 [swi5: cambio]
19 ?? WL 0:00.00 [swi9: task queue]
20 ?? WL 0:03.03 [irq10: bcm0 uhci1*]
21 ?? WL 0:00.02 [irq11: cb0 uhci0+*]
22 ?? DL 0:00.00 [usb0]
23 ?? DL 0:00.00 [usbtask]
24 ?? DL 0:00.00 [usb1]
25 ?? DL 0:00.05 [usb2]
26 ?? DL 0:00.00 [usb3]
27 ?? DL 0:00.00 [usb4]
28 ?? DL 0:00.00 [usb5]
29 ?? DL 0:00.04 [usb6]
30 ?? DL 0:00.00 [usb7]
31 ?? WL 0:00.00 [irq14: ata0]
32 ?? WL 0:00.00 [irq15: ata1]
33 ?? WL 0:00.00 [irq1: atkbd0]
34 ?? WL 0:00.00 [swi0: sio]
35 ?? WL 0:00.00 [swi3: ip6opt ipopt]
36 ?? WL 0:00.00 [swi4: ip6mismatch+]
37 ?? WL 0:00.00 [swi1: ipfwd]
38 ?? DL 0:00.00 [bufdaemon]
39 ?? DL 0:00.00 [vnlru]
40 ?? DL 0:00.01 [syncer]
41 ?? DL 0:00.00 [softdepflush]
42 ?? DL 0:00.00 [netdaemon]
43 ?? DL 0:00.00 [vmuncachedaemon]
44 ?? DL 0:00.00 [if_pic_listen]
45 ?? DL 0:00.02 [vmkmemdaemon]
46 ?? DL 0:00.01 [cb_poll]
47 ?? DL 0:00.00 [if_pfe_listen]
48 ?? DL 0:00.00 [scs_housekeeping]
49 ?? IL 0:00.00 [kern_dump_proc]
50 ?? IL 0:00.00 [nfsiod 0]
51 ?? IL 0:00.00 [nfsiod 1]
52 ?? IL 0:00.00 [nfsiod 2]
53 ?? IL 0:00.00 [nfsiod 3]
54 ?? DL 0:00.02 [schedcpu]
55 ?? DL 0:00.75 [md0]
77 ?? DL 0:03.48 [md1]
98 ?? DL 0:00.59 [md2]
116 ?? DL 0:00.02 [md3]
137 ?? DL 0:00.56 [md4]
158 ?? DL 0:00.15 [md5]
179 ?? DL 0:00.00 [md6]
215 ?? DL 0:00.03 [md7]
225 ?? DL 0:00.03 [md8]
1052 ?? DL 0:00.00 [jsr_kkcm]
1337 ?? SL 0:00.09 [bcmTX]
1338 ?? SL 0:00.10 [bcmXGS3AsyncTX]
1339 ?? SL 0:03.22 [bcmLINK.0]
1344 ?? Is 0:00.00 /usr/sbin/cron
1496 ?? S 0:00.00 /sbin/watchdog -t-1
1497 ?? S 0:00.05 /usr/libexec/bslockd -mp -N
1498 ?? S 0:00.01 /usr/sbin/tnetd -N
1500 ?? R 0:05.17 /usr/sbin/chassisd -N
1501 ?? S 0:00.04 /usr/sbin/alarmd -N
1502 ?? I 0:00.39 /usr/sbin/craftd -N

```

```

1503 ?? S      0:00.08 /usr/sbin/mgd -N
1506 ?? I      0:00.05 /usr/sbin/inetd -N
1507 ?? I      0:00.00 /usr/sbin/tnp.sntpd -N
1508 ?? I      0:00.00 /usr/sbin/tnp.sntpc -N
1510 ?? S      0:00.01 /usr/sbin/smartd -N
1514 ?? I      0:00.07 /usr/sbin/jcsd -N
1515 ?? S      0:00.17 /usr/sbin/idpd -N
1516 ?? I      0:00.00 /usr/libexec/getty Pc ttyv0
2591 ?? DL     0:00.01 [peer proxy]
2592 ?? DL     0:00.01 [peer proxy]
2593 ?? DL     0:00.01 [peer proxy]
2597 ?? DL     0:00.00 [peer proxy]
3192 ?? S      0:00.01 /usr/sbin/irsd -N
3193 ?? S      0:00.05 /usr/sbin/snmpd -N
3194 ?? S      0:00.02 /sbin/dcd -N
3195 ?? S      0:00.01 /usr/sbin/pfed -N
3196 ?? S      0:00.01 /usr/sbin/mib2d -N
3197 ?? S      0:00.02 /usr/sbin/dfwd -N
3198 ?? S      0:00.13 /usr/sbin/ksyncd -N
3228 ?? Ss     0:00.00 mgd: (mgd) (root) (mgd)
3229 ?? R      0:00.00 /bin/ps -ax
1138 d0- S     0:00.00 /usr/sbin/usbd -N
1156 d0- S     0:00.42 /usr/sbin/eventd -N -r -s -A
1517 d0 Is+    0:00.00 /usr/libexec/getty std.9600 ttyd0
...

```

show system
processes sfc (TX
Matrix Plus Router)

user@host> show system processes sfc 0
sfc0-re0:

PID	TT	STAT	TIME	COMMAND
0	??	Wls	0:00.00	[swapper]
1	??	SLs	0:00.18	/packages/mnt/jbase/sbin/init --
2	??	DL	0:00.20	[g_event]
3	??	DL	0:00.39	[g_up]
4	??	DL	0:00.32	[g_down]
5	??	DL	0:00.00	[thread taskq]
6	??	DL	0:00.09	[kqueue taskq]
7	??	DL	0:00.01	[pagedaemon]
8	??	DL	0:00.00	[vmdaemon]
9	??	DL	0:06.63	[pagezero]
10	??	DL	0:00.00	[ktrace]
11	??	RL	312:09.00	[idle]
12	??	WL	0:11.07	[swi2: net]
13	??	WL	0:27.70	[swi7: clock sio]
14	??	WL	0:00.00	[swi6: vm]
15	??	DL	0:03.03	[yarrow]
16	??	WL	0:00.00	[swi9: +]
17	??	WL	0:00.00	[swi8: +]
18	??	WL	0:00.00	[swi5: cambio]
19	??	WL	0:00.00	[swi9: task queue]
20	??	WL	0:11.46	[irq16: uhci0 uhci*]
21	??	DL	0:00.00	[usb0]
22	??	DL	0:00.00	[usbtask]
23	??	WL	0:39.63	[irq17: uhci1 uhci*]
24	??	DL	0:00.00	[usb1]
25	??	WL	0:00.00	[irq18: uhci2 uhci*]
26	??	DL	0:00.84	[usb2]
27	??	DL	0:00.00	[usb3]
28	??	DL	0:00.00	[usb4]
29	??	DL	0:00.00	[usb5]
30	??	DL	0:00.73	[usb6]

```

31 ?? DL 0:00.00 [usb7]
32 ?? WL 0:00.00 [irq14: ata0]
33 ?? WL 0:00.00 [irq15: ata1]
34 ?? WL 0:00.00 [irq1: atkbd0]
35 ?? WL 0:00.00 [swi0: sio]
36 ?? WL 0:00.00 [irq11: isab0]
37 ?? WL 0:00.00 [swi3: ip6opt ipopt]
38 ?? WL 0:00.00 [swi4: ip6mismatch+]
39 ?? WL 0:00.00 [swi1: ipfwd]
40 ?? DL 0:00.02 [bufdaemon]
41 ?? DL 0:00.02 [vn1ru]
42 ?? DL 0:00.39 [syncer]
43 ?? DL 0:00.05 [softdepflush]
44 ?? DL 0:00.00 [netdaemon]
45 ?? DL 0:00.02 [vmuncachedaemon]
46 ?? DL 0:00.00 [if_pic_listen]
47 ?? DL 0:00.35 [vmkmemdaemon]
48 ?? DL 0:00.00 [cb_poll]
49 ?? DL 0:00.06 [if_pfe_listen]
50 ?? DL 0:00.00 [scs_housekeeping]
51 ?? IL 0:00.00 [kern_dump_proc]
52 ?? IL 0:00.00 [nfsiod 0]
53 ?? IL 0:00.00 [nfsiod 1]
54 ?? IL 0:00.00 [nfsiod 2]
55 ?? IL 0:00.00 [nfsiod 3]
56 ?? DL 0:00.37 [schedcpu]
57 ?? DL 0:00.56 [md0]
79 ?? DL 0:02.58 [md1]
100 ?? DL 0:00.03 [md2]
118 ?? DL 0:00.01 [md3]
139 ?? DL 0:00.95 [md4]
160 ?? DL 0:00.12 [md5]
181 ?? DL 0:00.00 [md6]
217 ?? DL 0:00.02 [md7]
227 ?? DL 0:00.05 [md8]
1341 ?? SL 0:01.35 [bcmTX]
1342 ?? SL 0:01.69 [bcmXGS3AsyncTX]
1343 ?? SL 0:41.57 [bcmLINK.0]
1345 ?? SL 0:33.97 [bcmLINK.1]
1350 ?? Is 0:00.01 /usr/sbin/cron
1502 ?? S 0:00.01 /sbin/watchdog -t-1
1503 ?? S 0:00.86 /usr/libexec/bslockd -mp -N
1504 ?? I 0:00.01 /usr/sbin/tnetd -N
1507 ?? S 0:01.32 /usr/sbin/alarmd -N
1508 ?? S 0:14.54 /usr/sbin/craftd -N
1509 ?? S 0:01.20 /usr/sbin/mgd -N
1512 ?? S 0:00.05 /usr/sbin/inetd -N
1513 ?? S 0:00.10 /usr/sbin/tnp.snptd -N
1517 ?? S 0:00.11 /usr/sbin/smartd -N
1525 ?? S 0:01.11 /usr/sbin/idpd -N
1526 ?? S 0:01.43 /usr/sbin/license-check -U -M -p 10 -i 10
1527 ?? I 0:00.01 /usr/libexec/getty Pc ttyv0
1616 ?? DL 0:00.30 [peer proxy]
1617 ?? DL 0:00.32 [peer proxy]
1618 ?? DL 0:00.34 [peer proxy]
1619 ?? DL 0:00.30 [peer proxy]
2391 ?? Is 0:00.01 telnetd
7331 ?? Ss 0:00.03 telnetd
9538 ?? DL 0:01.16 [jsr_kkcm]
9613 ?? DL 0:00.18 [peer proxy]
23781 ?? Ss 0:00.01 telnetd

```

```

23926 ?? Ss 0:00.03 mgd: (mgd) (regress)/dev/tty2 (mgd)
36867 ?? S 0:03.14 /usr/sbin/rpd -N
36874 ?? S 0:00.08 /usr/sbin/lmpd
36876 ?? S 0:00.17 /usr/sbin/lacpd -N
36877 ?? S 0:00.15 /usr/sbin/bfdd -N
36878 ?? S 0:05.05 /usr/sbin/ppmd -N
36907 ?? S 0:26.63 /usr/sbin/chassisd -N
37775 ?? S 0:00.01 /usr/sbin/bdbrepd -N
45727 ?? S 0:00.02 /usr/sbin/xntpd -j -N -g (ntpd)
45729 ?? S 0:00.40 /usr/sbin/l2ald -N
45730 ?? S< 0:00.13 /usr/sbin/apspd -N
45731 ?? SN 0:00.10 /usr/sbin/sampled -N
45732 ?? S 0:00.03 /usr/sbin/ilmid -N
45733 ?? S 0:00.09 /usr/sbin/rmopd -N
45734 ?? S 0:00.31 /usr/sbin/cosd
45735 ?? I 0:00.00 /usr/sbin/rtspd -N
45736 ?? S 0:00.06 /usr/sbin/fsad -N
45737 ?? S 0:00.05 /usr/sbin/rdd -N
45738 ?? S 0:00.10 /usr/sbin/pppd -N
45739 ?? S 0:00.05 /usr/sbin/dfcd -N
45740 ?? S 0:00.08 /usr/sbin/lfmd -N
45741 ?? S 0:00.01 /usr/sbin/mpiisoamd -N
45742 ?? I 0:00.01 /usr/sbin/sendd -N
45743 ?? S 0:00.08 /usr/sbin/appidd -N
45744 ?? S 0:00.05 /usr/sbin/mspd -N
45745 ?? S 0:00.27 /usr/sbin/jdiameterd -N
45746 ?? S 0:00.10 /usr/sbin/pfed -N
45747 ?? S 0:00.19 /usr/sbin/lpdfd -N
45748 ?? S 0:00.64 /sbin/dcd -N
45750 ?? S 0:00.46 /usr/sbin/mib2d -N
45751 ?? S 0:00.16 /usr/sbin/dfwd -N
45752 ?? S 0:00.15 /usr/sbin/irsd -N
45764 ?? S 0:20.60 /usr/sbin/snmpd -N
56481 ?? Ss 0:00.02 telnetd
56548 ?? Rs 0:00.19 mgd: (mgd) (regress)/dev/tty0 (mgd)
56577 ?? Ss 0:00.00 mgd: (mgd) (root) (mgd)
56578 ?? R 0:00.00 /bin/ps -ax
1142 d0- S 0:00.01 /usr/sbin/usbd -N
1160 d0- S 0:29.71 /usr/sbin/eventd -N -r -s -A
6527 d0 Is+ 0:00.00 /usr/libexec/getty std.9600 ttyd0
56482 p0 Is 0:00.00 login [pam] (login)
56483 p0 S 0:00.01 -csh (csh)
56547 p0 S+ 0:00.02 cli
2392 p1 Is 0:00.00 login [pam] (login)
2393 p1 I 0:00.00 -csh (csh)
2394 p1 I 0:00.00 su -
2395 p1 I+ 0:00.01 -su (csh)
23782 p2 Is 0:00.00 login [pam] (login)
23881 p2 I 0:00.00 -csh (csh)
23925 p2 S+ 0:00.03 cli
7332 p3 Is 0:00.00 login [pam] (login)
7333 p3 I 0:00.00 -csh (csh)
23780 p3 S+ 0:00.02 telnet aj

```

```

show system user@host> show system processes lcc 2 wide
processes lcc wide (TX lcc2-re0:

```

**Matrix Plus
Routing Matrix)**

```

-----
PID TT STAT TIME PROVIDER COMMAND
0 ?? WLS 0:00.00 (null) [swapper]
1 ?? ILS 0:00.19 /packages/mnt/jbase/sbin/init --
2 ?? DL 0:00.02 [g_event]

```

3	??	DL	0:00.19	[g_up]
4	??	DL	0:00.13	[g_down]
5	??	DL	0:00.00	[thread taskq]
6	??	DL	0:00.00	[kqueue taskq]
7	??	DL	0:00.00	[pagedaemon]
8	??	DL	0:00.00	[vmdaemon]
9	??	DL	0:01.77	[pagezero]
10	??	DL	0:00.00	[ktrace]
11	??	RL	20:33.81	[idle]
12	??	WL	0:00.38	[swi2: net]
13	??	WL	0:01.43	[swi7: clock sio]
14	??	WL	0:00.00	[swi6: vm]
15	??	DL	0:00.14	[yarrow]
16	??	WL	0:00.00	[swi9: +]
17	??	WL	0:00.00	[swi8: +]
18	??	WL	0:00.00	[swi5: cambio]
19	??	WL	0:00.00	[swi9: task queue]
20	??	WL	0:03.18	[irq10: bcm0 uhci1*]
21	??	WL	0:00.03	[irq11: cb0 uhci0+*]
22	??	DL	0:00.00	[usb0]
23	??	DL	0:00.00	[usbtask]
24	??	DL	0:00.00	[usb1]
25	??	DL	0:00.06	[usb2]
26	??	DL	0:00.00	[usb3]
27	??	DL	0:00.00	[usb4]
28	??	DL	0:00.00	[usb5]
29	??	DL	0:00.05	[usb6]
30	??	DL	0:00.00	[usb7]
31	??	WL	0:00.00	[irq14: ata0]
32	??	WL	0:00.00	[irq15: ata1]
33	??	WL	0:00.00	[irq1: atkbd0]
34	??	WL	0:00.00	[swi0: sio]
35	??	WL	0:00.00	[swi3: ip6opt ipopt]
36	??	WL	0:00.00	[swi4: ip6mismatch+]
37	??	WL	0:00.00	[swi1: ipfwd]
38	??	DL	0:00.00	[bufdaemon]
39	??	DL	0:00.00	[vnlru]
40	??	DL	0:00.02	[syncer]
41	??	DL	0:00.01	[softdepflush]
42	??	DL	0:00.00	[netdaemon]
43	??	DL	0:00.00	[vmuncachedaemon]
44	??	DL	0:00.00	[if_pic_listen]
45	??	DL	0:00.03	[vmkmemdaemon]
46	??	DL	0:00.01	[cb_poll]
47	??	DL	0:00.00	[if_pfe_listen]
48	??	DL	0:00.00	[scs_housekeeping]
49	??	IL	0:00.00	[kern_dump_proc]
50	??	IL	0:00.00	[nfsiod 0]
51	??	IL	0:00.00	[nfsiod 1]
52	??	IL	0:00.00	[nfsiod 2]
53	??	IL	0:00.00	[nfsiod 3]
54	??	DL	0:00.02	[schedcpu]
55	??	DL	0:00.75	[md0]
77	??	DL	0:03.84	[md1]
98	??	DL	0:00.59	[md2]
116	??	DL	0:00.02	[md3]
137	??	DL	0:00.72	[md4]
158	??	DL	0:00.15	[md5]
179	??	DL	0:00.00	[md6]
215	??	DL	0:00.03	[md7]
225	??	DL	0:00.03	[md8]


```

1052 ?? DL 0:00.00 [jsr_kkcm]
1337 ?? SL 0:00.11 [bcmTX]
1338 ?? SL 0:00.12 [bcmXGS3AsyncTX]
1339 ?? SL 0:03.82 [bcmLINK.0]
1344 ?? Is 0:00.00 /usr/sbin/cron
1496 ?? I 0:00.00 /sbin/watchdog -t-1
1497 ?? S 0:00.06 /usr/libexec/bslockd -mp -N
1498 ?? I 0:00.01 /usr/sbin/tnetd -N
1500 ?? S 0:09.93 /usr/sbin/chassisd -N
1501 ?? S 0:00.05 /usr/sbin/alarmd -N
1502 ?? I 0:00.39 /usr/sbin/craftd -N
1503 ?? S 0:00.09 /usr/sbin/mgd -N
1506 ?? I 0:00.05 /usr/sbin/inetd -N
1507 ?? I 0:00.00 /usr/sbin/tnp.sntpd -N
1508 ?? I 0:00.00 /usr/sbin/tnp.sntpc -N
1510 ?? S 0:00.01 /usr/sbin/smartd -N
1514 ?? I 0:00.07 /usr/sbin/jcsd -N
1515 ?? S 0:00.17 /usr/sbin/idpd -N
1516 ?? I 0:00.00 /usr/libexec/getty Pc ttyv0
2591 ?? DL 0:00.01 [peer proxy]
2592 ?? DL 0:00.01 [peer proxy]
2593 ?? DL 0:00.01 [peer proxy]
2597 ?? DL 0:00.01 [peer proxy]
3192 ?? S 0:00.02 /usr/sbin/irsd -N
3193 ?? S 0:00.05 /usr/sbin/snmpd -N
3194 ?? S 0:00.04 /sbin/dcd -N
3195 ?? I 0:00.01 /usr/sbin/pfed -N
3196 ?? S 0:00.02 /usr/sbin/mib2d -N
3197 ?? I 0:00.03 /usr/sbin/dfwd -N
3198 ?? S 0:00.15 /usr/sbin/ksyncd -N
3559 ?? Ss 0:00.00 mgd: (mgd) (root) (mgd)
3560 ?? R 0:00.00 /bin/ps -ax -jpw
1138 d0- S 0:00.00 /usr/sbin/usbd -N
1156 d0- S 0:00.50 /usr/sbin/eventd -N -r -s -A
1517 d0 Is+ 0:00.00 /usr/libexec/getty std.9600 ttyd0

```

**show system
processes (QFX
Series)**

user@switch> show system processes

```

PID TT STAT TIME COMMAND
0 ?? Wls -2341043:-31.01 [swapper]
1 ?? SLs 0:01.34 /packages/mnt/jbase/sbin/init --
2 ?? DL 2:48.31 [g_event]
3 ?? DL 1:47.44 [g_up]
4 ?? DL 1:37.82 [g_down]
5 ?? DL 0:00.00 [kdm_tcp_poller]
6 ?? DL 0:00.00 [thread taskq]
7 ?? DL 0:04.86 [kqueue taskq]
9 ?? DL 0:03.94 [pagedaemon]
10 ?? DL 0:00.00 [ktrace]
11 ?? RL 0:00.00 [idle: cpu31]
12 ?? RL 0:00.00 [idle: cpu30]
13 ?? RL 0:00.00 [idle: cpu29]
14 ?? RL 0:00.00 [idle: cpu28]
15 ?? RL 0:00.00 [idle: cpu27]
16 ?? RL 0:00.00 [idle: cpu26]
17 ?? RL 0:00.00 [idle: cpu25]
18 ?? RL 0:00.00 [idle: cpu24]
19 ?? RL 0:00.00 [idle: cpu23]
20 ?? RL 0:00.00 [idle: cpu22]
21 ?? RL 0:00.00 [idle: cpu21]
22 ?? RL 0:00.00 [idle: cpu20]
23 ?? RL 0:00.00 [idle: cpu19]

```

```

24 ?? RL      0:00.00 [idle: cpu18]
25 ?? RL      0:00.00 [idle: cpu17]
26 ?? RL      0:00.00 [idle: cpu16]
27 ?? RL      0:00.00 [idle: cpu15]
28 ?? RL      0:00.00 [idle: cpu14]
29 ?? RL      0:00.00 [idle: cpu13]
30 ?? RL      0:00.00 [idle: cpu12]
31 ?? RL      0:00.00 [idle: cpu11]
32 ?? RL      0:00.00 [idle: cpu10]
33 ?? RL      0:00.00 [idle: cpu9]
34 ?? RL      18184:07.25 [idle: cpu8]
35 ?? RL      0:00.00 [idle: cpu7]
36 ?? RL      17862:11.31 [idle: cpu6]
37 ?? RL      19343:45.16 [idle: cpu5]
38 ?? RL      5192:38.30 [idle: cpu4]
39 ?? RL      0:00.00 [idle: cpu3]
40 ?? RL      19278:02.24 [idle: cpu2]
41 ?? RL      19291:00.72 [idle: cpu1]
42 ?? RL      18910:31.21 [idle: cpu0]
43 ?? WL      19:03.74 [swi2: net]
44 ?? WL      261:43.82 [swi7: clock sio]
45 ?? WL      0:00.00 [swi6: vm]
46 ?? DL      2:18.57 [yarrow]
47 ?? WL      0:00.00 [swi9: +]
48 ?? WL      0:00.00 [swi8: +]
49 ?? WL      0:12.36 [swi5: cambio]
50 ?? WL      0:00.00 [swi9: task queue]
51 ?? WL      0:00.00 [swi0: sio]
52 ?? WL      0:32.40 [irq39: ehci0]
53 ?? DL      0:00.21 [usb0]
54 ?? DL      0:00.00 [usbtask]
55 ?? WL      0:00.00 [irq22: xlr_lbus0]
56 ?? WL      0:00.00 [irq38: xlr_lbus0]
57 ?? WL      0:00.00 [swi3: ip6opt ipopt]
58 ?? WL      0:00.00 [swi4: ip6mismatch+]
59 ?? WL      0:00.00 [swi1: ipfwd]
60 ?? DL      0:18.65 [pagezero]
61 ?? DL      0:18.59 [bufdaemon]
62 ?? DL      1:10.44 [vnlr_u_mem]
63 ?? DL      1:51.66 [syncer]
64 ?? DL      0:20.22 [vnlr_u]
65 ?? DL      0:40.48 [softdepflush]
66 ?? DL      0:00.00 [netdaemon]
67 ?? DL      20:47.67 [vmkmemdaemon]
68 ?? DL      0:00.00 [if_pfe_listen]
69 ?? SL      0:02.80 [kdm_checkkcore]
70 ?? SL      0:03.34 [kdm_savekcore]
71 ?? SL      0:04.31 [kdm_livekcore]
72 ?? SL      0:06.14 [kdm_logger]
73 ?? SL      0:04.31 [kdm_kdb]
74 ?? SL      0:00.02 [devrt_kernel_thread]
75 ?? DL      0:21.54 [vmuncachedaemon]
76 ?? DL      0:00.00 [if_pic_listen0]
77 ?? SL      0:00.00 [nfsiod 0]
78 ?? SL      0:00.00 [nfsiod 1]
79 ?? SL      0:00.00 [nfsiod 2]
80 ?? SL      0:00.00 [nfsiod 3]
81 ?? WL      5:59.98 [irq13: +]
82 ?? RL      105:06.81 [pkt_sender: cpu0]
83 ?? DL      0:03.62 [md0]
95 ?? DL      0:37.04 [md1]

```

```

115 ?? DL      0:06.01 [md2]
135 ?? DL      0:00.75 [md3]
155 ?? DL      0:21.17 [md4]
175 ?? DL      0:01.90 [md5]
195 ?? DL      0:06.26 [md6]
231 ?? DL      0:00.01 [md7]
755 ?? Ss      0:04.17 /usr/sbin/cron
847 ?? S        0:00.10 /usr/sbin/tnetd -N
849 ?? S        0:06.82 /usr/sbin/mgd -N
850 ?? S        0:00.32 /usr/sbin/inetd -N
852 ?? S        1:05.34 /usr/sbin/dhcpd -N
853 ?? S        0:00.18 /usr/sbin/inetd -p /var/run/inetd_4.pid -N -JU __juni
855 ?? L      1181:02.21 /usr/sbin/dc-pfe -N (pafxpc)
857 ?? S        17:55.86 /usr/sbin/vccpd -N
896 ?? S        93:43.45 /usr/sbin/chassism -N
953 ?? S        0:02.89 /sbin/watchdog -t-1
954 ?? S        3:34.00 /sbin/dcd -N
955 ?? S       10:30.13 /usr/sbin/chassisd -N
956 ?? DL      0:00.21 [peer proxy]
957 ?? S        4:07.43 /usr/sbin/alarmd -N
958 ?? S        0:31.69 /usr/sbin/craftd -N
959 ?? S        0:55.16 /usr/sbin/mib2d -N
960 ?? S        3:40.64 /usr/sbin/rpd -N
961 ?? S        0:00.03 /usr/sbin/tnp.snmpd -N
962 ?? S        0:51.94 /usr/sbin/pfed -N
963 ?? S        0:47.31 /usr/sbin/rmopd -N
964 ?? S        0:33.65 /usr/sbin/cosd
965 ?? S        1:48.41 /usr/sbin/ppmd -N
966 ?? S        0:07.18 /usr/sbin/dfwd -N
967 ?? S        1:02.56 /usr/sbin/bfdd -N
968 ?? S        0:00.63 /usr/sbin/rdd -N
969 ?? S        0:40.61 /usr/sbin/dfcd -N
971 ?? S        0:07.81 /usr/sbin/bdbrepd -N
972 ?? S        0:00.28 /usr/sbin/sendd -N
973 ?? S        1:37.69 /usr/sbin/xntpd -j -N -g -JU __juniper_private4__ (nt
974 ?? S        5:56.28 /usr/sbin/snmpd -N -JU __juniper_private4__
975 ?? S       16:46.82 /usr/sbin/jdiameterd -N
976 ?? S        2:34.13 /usr/sbin/eswd -N
977 ?? S        1:03.05 /usr/sbin/sflowd -N
978 ?? S        0:22.30 /usr/sbin/fcd -N
979 ?? S        1:07.01 /usr/sbin/vccpdf -N
982 ?? S        0:25.25 /usr/sbin/mcsnoopd -N
983 ?? S        3:45.68 /usr/sbin/rpdf -N
1043 ?? S       0:37.87 /usr/sbin/lacpd -N
1048 ?? DL      0:01.29 [peer proxy]
1111 ?? WL      0:00.00 [swi2: FMNITHRD+]
1112 ?? DL      0:00.03 [peer proxy]
12816 ?? S     15:35.32 /usr/sbin/sfid -N
30893 ?? Ss     0:00.65 sshd: tlewis@tty0 (sshd)
30897 ?? Ss     0:00.15 mgd: (mgd) (tlewis)/dev/tty0 (mgd)
30905 ?? Ss     0:00.64 sshd: tlewis@tty1 (sshd)
30909 ?? Ss     0:00.15 mgd: (mgd) (tlewis)/dev/tty1 (mgd)
30910 ?? Ss     0:01.26 sshd: tcheng@tty2 (sshd)
30914 ?? Ss     0:00.80 mgd: (mgd) (tcheng)/dev/tty2 (mgd)
30937 ?? R       0:00.03 /bin/ps -ax
661 d0- S       0:21.24 /usr/sbin/eventd -N -r -s -A
860 d0 Ss+      0:00.07 /usr/libexec/getty std.9600 ttyd0
30896 p0 Ss+    0:00.55 -cli (cli)
30908 p1 Ss+    0:00.50 -cli (cli)
30913 p2 Ss+    0:00.85 -cli (cli)

```


show system queues

Syntax	show system queues
Syntax (TX Matrix Router)	show system queues <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system queues <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system queues <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display queue statistics.
Options	<p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system queue statistics for all the T640 routers in the chassis that are connected to the TX Matrix router. On a TX Matrix Plus router, display system queue statistics for all the T1600 routers in the chassis that are connected the TX Matrix Plus router.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system queue statistics for all LCC chassis attached to the TX Matrix or TX Matrix Plus routers.</p> <p>all-members—(MX Series routers only) (Optional) Display system queue statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system queue statistics for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system queue statistics for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(MX Series routers only) (Optional) Display system queue statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display system queue statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1.</p> <p>scc—(TX Matrix routers only) (Optional) Display queue statistics for the TX Matrix router.</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display system queue statistics for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>

Additional Information By default, when you issue the **show system queues** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix router) backup Routing Engines that are connected to it.

Required Privilege Level maintenance

List of Sample Output **show system queues** on page 950
show system queues scc (TX Matrix Router) on page 950
show system queues sfc (TX Matrix Router) on page 951

Output Fields Table 146 on page 950 lists the output fields for the **show system queues** command. Output fields are listed in the approximate order in which they appear.

Table 146: show system queues Output Fields

Field Name	Field Description
Output interface	Interface on the router on which the queue exists: <ul style="list-style-type: none"> fxp0—Management Ethernet interface fxp1—Internal Ethernet interface lsi—Internally generated interface and not configurable dsc—Discard interface
bytes	Number of bytes in the queue.
max	Maximum number of bytes allowed in the queue.
packets	Number of packets in the queue.
max	Maximum number of packets allowed in the queue.
drops	Number of packets dropped from the queue.

Sample Output

```

user@host> show system queues
output interface      bytes      max  packets      max  drops
fxp0                  0    1250000      0    4166        6
fxp1                  0    1250000      0    4166       19
lsi                   0      12500      0      41         0
dsc                   0         0      0         0         0

```

```

user@host> show system queues scc
output interface      bytes      max  packets      max  drops
fxp0                  0    1250000      0    4166         5
lsi                   0      12500      0      41         0

```

dsc	0	0	0	0	0
lo0	0	0	0	0	0
bcm0	0	12500000	0	30000	0
em0	0	12500000	0	30000	0
gre	0	12500	0	41	0
ipip	0	12500	0	41	0
tap	0	0	0	0	0
pime	0	12500	0	41	0
pimd	0	12500	0	41	0
mtun	0	12500	0	41	0
so-1/0/0	0	125000	0	416	0
so-1/1/0	0	125000	0	416	0
so-21/0/0	0	125000	0	416	0
ge-21/1/0	0	1250000	0	4166	0
ge-21/1/1	0	1250000	0	4166	3
ge-21/2/0	0	1250000	0	4166	0
ge-21/2/1	0	1250000	0	4166	3
so-21/3/0	0	125000	0	416	0
so-0/0/0	0	125000	0	416	0
so-0/1/0	0	125000	0	416	0
so-0/2/0	0	125000	0	416	0
pd-0/3/0	0	12500	0	41	0
pe-0/3/0	0	12500	0	41	0
gr-0/3/0	0	12500	0	41	0
ip-0/3/0	0	12500	0	41	0
vt-0/3/0	0	12500	0	41	0
mt-0/3/0	0	12500	0	41	0
lt-0/3/0	0	12500	0	41	0
so-17/0/0	0	125000	0	416	0
input protocol	bytes	max	packets	max	drops
splfwdq	0	1000000	0	1000	0
splnetq	0	1000000	0	1000	0
arpintrq	0	1000	0	50	0
optionq	0	200000	0	200	0
icmpq	0	50000	0	50	0
frlmiq	0	0	0	0	0
spppintrq	0	25000	0	250	0
clnlintrq	0	200000	0	200	0
tnpintrq	0	1250000	0	4166	0
tagintrq	0	200000	0	200	0
tagfragq	0	200000	0	200	0

show system queues user@host> show system queues sfc 0
sfc0-re0:

output interface	bytes	max	packets	max	drops
ixgbe1	0	125000000	0	45000	4384
ixgbe0	0	125000000	0	45000	0
lsi	0	12500	0	41	0
dsc	0	0	0	0	0
lo0	0	0	0	0	0
em0	0	12500000	0	41666	1
gre	0	12500	0	41	0
ipip	0	12500	0	41	0
tap	0	0	0	0	0
pime	0	12500	0	41	0
pimd	0	12500	0	41	0
mtun	0	12500	0	41	0
xe-12/0/0	0	1250000	0	4166	0
xe-12/0/1	0	1250000	0	4166	0
xe-12/0/2	0	1250000	0	4166	0

xe-12/0/3	0	1250000	0	4166	0
xe-12/1/0	0	1250000	0	4166	0
xe-12/1/1	0	1250000	0	4166	0
xe-12/1/2	0	1250000	0	4166	0
xe-12/1/3	0	1250000	0	4166	0
xe-20/0/0	0	1250000	0	4166	0
xe-20/0/1	0	1250000	0	4166	0
xe-20/0/2	0	1250000	0	4166	0
xe-20/0/3	0	1250000	0	4166	0
xe-20/1/0	0	1250000	0	4166	0
xe-20/1/1	0	1250000	0	4166	0
xe-20/1/2	0	1250000	0	4166	0
xe-20/1/3	0	1250000	0	4166	0
ge-15/0/0	0	1250000	0	4166	75
ge-15/0/1	0	1250000	0	4166	0
ge-15/0/2	0	1250000	0	4166	75
ge-15/0/3	0	1250000	0	4166	75
ge-15/0/4	0	1250000	0	4166	0
ge-15/0/5	0	1250000	0	4166	0
ge-15/0/6	0	1250000	0	4166	0
ge-15/0/7	0	1250000	0	4166	0
ge-15/0/8	0	1250000	0	4166	0
ge-15/0/9	0	1250000	0	4166	0
xe-4/0/0	0	1250000	0	4166	0
xe-4/0/1	0	1250000	0	4166	0
xe-4/0/2	0	1250000	0	4166	0
xe-4/0/3	0	1250000	0	4166	0
xe-4/1/0	0	1250000	0	4166	0
xe-4/1/1	0	1250000	0	4166	0
xe-4/1/2	0	1250000	0	4166	0
xe-4/1/3	0	1250000	0	4166	0
xe-24/0/0	0	1250000	0	4166	0
xe-24/0/1	0	1250000	0	4166	0
xe-24/0/2	0	1250000	0	4166	0
xe-24/0/3	0	1250000	0	4166	0
xe-24/1/0	0	1250000	0	4166	0
xe-24/1/1	0	1250000	0	4166	0
xe-24/1/2	0	1250000	0	4166	0
xe-24/1/3	0	1250000	0	4166	0
ge-7/0/0	0	1250000	0	4166	0
ge-7/0/1	0	1250000	0	4166	0
ge-7/0/2	0	1250000	0	4166	0
ge-7/0/3	0	1250000	0	4166	75
ge-7/0/4	0	1250000	0	4166	0
ge-7/0/5	0	1250000	0	4166	0
ge-7/0/6	0	1250000	0	4166	0
ge-7/0/7	0	1250000	0	4166	0
ge-7/0/8	0	1250000	0	4166	0
ge-7/0/9	0	1250000	0	4166	0
so-7/1/0	0	125000	0	416	0
so-7/2/0	0	125000	0	416	0
xe-21/0/0	0	1250000	0	4166	0
xe-21/0/1	0	1250000	0	4166	0
xe-21/0/2	0	1250000	0	4166	0
xe-21/0/3	0	1250000	0	4166	0
xe-21/1/0	0	1250000	0	4166	0
xe-21/1/1	0	1250000	0	4166	0
xe-21/1/2	0	1250000	0	4166	0
xe-21/1/3	0	1250000	0	4166	0
xe-14/0/0	0	1250000	0	4166	0
xe-14/0/1	0	1250000	0	4166	0

xe-14/0/2	0	1250000	0	4166	0
xe-14/0/3	0	1250000	0	4166	0
xe-14/1/0	0	1250000	0	4166	0
xe-14/1/1	0	1250000	0	4166	0
xe-14/1/2	0	1250000	0	4166	0
xe-14/1/3	0	1250000	0	4166	0
xe-25/0/0	0	1250000	0	4166	0
xe-25/0/1	0	1250000	0	4166	0
xe-25/0/2	0	1250000	0	4166	0
xe-25/0/3	0	1250000	0	4166	0
xe-25/1/0	0	1250000	0	4166	0
xe-25/1/1	0	1250000	0	4166	0
xe-25/1/2	0	1250000	0	4166	0
xe-25/1/3	0	1250000	0	4166	0
so-22/0/0	0	125000	0	416	0
so-22/0/1	0	125000	0	416	0
so-22/0/2	0	125000	0	416	0
so-22/0/3	0	125000	0	416	0
xe-22/1/0	0	1250000	0	4166	0
xe-22/1/1	0	1250000	0	4166	0
xe-22/1/2	0	1250000	0	4166	0
xe-22/1/3	0	1250000	0	4166	0
xe-6/0/0	0	1250000	0	4166	0
xe-6/0/1	0	1250000	0	4166	0
xe-6/0/2	0	1250000	0	4166	0
xe-6/0/3	0	1250000	0	4166	0
xe-6/1/0	0	1250000	0	4166	0
xe-6/1/1	0	1250000	0	4166	0
xe-6/1/2	0	1250000	0	4166	0
xe-6/1/3	0	1250000	0	4166	0
xe-26/0/0	0	1250000	0	4166	0
xe-26/0/1	0	1250000	0	4166	0
xe-26/0/2	0	1250000	0	4166	0
xe-26/0/3	0	1250000	0	4166	0
xe-26/1/0	0	1250000	0	4166	0
xe-26/1/1	0	1250000	0	4166	0
xe-26/1/2	0	1250000	0	4166	0
xe-26/1/3	0	1250000	0	4166	0
ge-31/0/0	0	1250000	0	4166	0
ge-31/0/1	0	1250000	0	4166	0
ge-31/0/2	0	1250000	0	4166	0
ge-31/0/3	0	1250000	0	4166	0
ge-31/0/4	0	1250000	0	4166	75
ge-31/0/5	0	1250000	0	4166	0
ge-31/0/6	0	1250000	0	4166	75
ge-31/0/7	0	1250000	0	4166	0
ge-31/0/8	0	1250000	0	4166	0
ge-31/0/9	0	1250000	0	4166	0
pd-31/1/0	0	12500	0	41	0
pe-31/1/0	0	12500	0	41	0
gr-31/1/0	0	12500	0	41	0
ip-31/1/0	0	12500	0	41	0
vt-31/1/0	0	12500	0	41	0
mt-31/1/0	0	12500	0	41	0
lt-31/1/0	0	12500	0	41	0
so-29/0/0	0	125000	0	416	0
so-29/0/1	0	125000	0	416	0
so-29/0/2	0	125000	0	416	0
so-29/0/3	0	125000	0	416	0
xe-29/1/0	0	1250000	0	4166	0
xe-29/1/1	0	1250000	0	4166	0

xe-29/1/2	0	1250000	0	4166	0
xe-29/1/3	0	1250000	0	4166	0
so-28/0/0	0	125000	0	416	0
so-28/0/1	0	125000	0	416	0
so-28/0/2	0	125000	0	416	0
so-28/0/3	0	125000	0	416	0
ge-23/0/0	0	1250000	0	4166	0
ge-23/0/1	0	1250000	0	4166	0
ge-23/0/2	0	1250000	0	4166	0
ge-23/0/3	0	1250000	0	4166	0
ge-23/0/4	0	1250000	0	4166	0
ge-23/0/5	0	1250000	0	4166	0
ge-23/0/6	0	1250000	0	4166	0
ge-23/0/7	0	1250000	0	4166	0
ge-23/0/8	0	1250000	0	4166	0
ge-23/0/9	0	1250000	0	4166	0
input protocol	bytes	max	packets	max	drops
sp1fwdq	0	1000000	0	1000	0
sp1netq	0	1000000	0	1000	0
arpintrq	0	1000	0	50	0
optionq	0	200000	0	200	0
icmpq	0	50000	0	50	0
fr1miq	0	0	0	0	0
spppintrq	0	25000	0	250	0
atmctlpktq	0	0	0	0	0
atmoamq	0	0	0	0	0
tnpintrq	0	1250000	0	4166	0
tagintrq	0	200000	0	200	0
tagfragq	0	200000	0	200	0

show system reboot

Syntax	show system reboot <both-routing-engines>
Syntax (EX Series Switch)	show system reboot <all-members> <both-routing-engines> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system reboot <all-chassis all-lcc lcc <i>number</i> scc> <both-routing-engines>
Syntax (TX Matrix Plus Router)	show system reboot <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <both-routing-engines>
Syntax (MX Series Router)	show system reboot <all-members> <both-routing-engines> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show system reboot
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display pending system reboots or halts.
Options	<p>none—Display pending reboots or halts on the active Routing Engine.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display halt or reboot request information for all the T640 routers in the chassis that are connected to the TX Matrix router. On a TX Matrix Plus router, display halt or reboot request information for all the T1600 routers in the chassis that are connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Display halt or reboot request information for all members of the Virtual Chassis configuration.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system halt or reboot request information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display halt or reboot request information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p>

both-routing-engines—(Systems with multiple Routing Engines) (Optional) Display halt or reboot request information on both Routing Engines.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display halt or reboot request information for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display halt or reboot request information for a specific T1600 router that is connected to the TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display halt or reboot request information for the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display halt or reboot request information for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

scc—(TX Matrix router only) (Optional) Display halt or reboot request information for the TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus router only) (Optional) Display halt or reboot request information for the TX Matrix Plus router (or switch-fabric chassis).

Additional Information By default, when you issue the **show system reboot** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level maintenance

List of Sample Output **show system reboot** on page 956
show system reboot all-lcc (TX Matrix Router) on page 956
show system reboot sfc (TX Matrix Plus Router) on page 957
show system reboot (QFX Series) on page 957

Sample Output

show system reboot user@host> show system reboot
 reboot requested by root at Wed Feb 10 17:40:46 1999
 [process id 17885]

show system reboot all-lcc (TX Matrix Router) user@host> show system reboot all-lcc
 lcc0-re0:

 No shutdown/reboot scheduled.
 lcc2-re0:

No shutdown/reboot scheduled.

show system reboot	user@host> show system sfc 0
sfc (TX Matrix Plus	No shutdown/reboot scheduled.
Router)	
show system reboot	user@switch> show system reboot
(QFX Series)	No shutdown/reboot scheduled.

show system rollback

Syntax `show system rollback number`
`<compare number>`

Release Information Command introduced before Junos OS Release 7.4.
 Command introduced in Junos OS Release 9.0 for EX Series switches.
 Command introduced in Junos OS Release 11.1 for the QFX Series.

Description Display the contents of a previously committed configuration, or the differences between two previously committed configurations.



NOTE: The `show system rollback` command is a purely operational mode command and cannot be issued with `run` from the configuration mode.

Options `number`—Number of a configuration to view. The output displays the configuration. The range of values is 0 through 49.

`compare number` —(Optional) Number of another previously committed (rollback) configuration to compare to rollback `number`. The output displays the differences between the two configurations. The range of values is 0 through 49.

Required Privilege Level view

List of Sample Output `show system rollback compare` on page 958

Sample Output

```
show system rollback compare user@host> show system rollback 3 compare 1
[edit]
+ interfaces {
+   ge-1/1/1 {
+     unit 0 {
+       family inet {
+         filter {
+           input mf_plp;
+         }
+         address 14.1.1.1/30;
+       }
+     }
+   }
+   ge-1/2/1 {
+     unit 0 {
+       family inet {
+         filter {
+           input mf_plp;
+         }
+         address 13.1.1.1/30;
+       }
+     }
+   }
+ }
```

```
+   ge-1/3/0 {  
+       unit 0 {  
+           family inet {  
+               filter {  
+                   input mf_plp;  
+               }  
+               address 12.1.1.1/30;  
+           }  
+       }  
+   }  
+}
```

show system services dhcp binding

Syntax	show system services dhcp binding <detail> <address>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers only) Display Dynamic Host Configuration Protocol (DHCP) server client binding information.
Options	none—Display brief information about all active client bindings. detail—(Optional) Display detailed information about all active client bindings. address—(Optional) Display detailed client binding information for the specified IP address only.
Required Privilege Level	view and system
Related Documentation	<ul style="list-style-type: none"> clear system services dhcp binding on page 717
List of Sample Output	show system services dhcp binding on page 961 show system services dhcp binding address on page 961 show system services dhcp binding address detail on page 961
Output Fields	Table 147 on page 960 describes the output fields for the show system services dhcp binding command. Output fields are listed in the approximate order in which they appear.

Table 147: show system services dhcp binding Output Fields

Field Name	Field Description	Level of Output
Allocated address	List of IP addresses the DHCP server has assigned to clients.	All levels
MAC address	Corresponding media access control (MAC) hardware address of the client.	All levels
Client identifier	(address option only) Client's unique identifier (represented by an ASCII string or hexadecimal digits). This identifier is used by the DHCP server to index its database of address bindings.	All levels
Binding Type	Type of binding assigned to the client. DHCP servers can assign a dynamic binding from a pool of IP addresses or a static binding to one or more specific IP addresses.	All levels
Lease Expires at	Time the lease expires or never for leases that do not expire.	All levels
Lease Obtained at	(address option only) Time the client obtained the lease from the DHCP server.	detail

Table 147: show system services dhcp binding Output Fields (*continued*)

Field Name	Field Description	Level of Output
State	Status of the binding. Bindings can be active or expired.	detail
Pool	Address pool that contains the IP address assigned to the client.	detail
Request received on	Interface on which the DHCP message exchange occurs. The IP address pool is configured based on the interface's IP address. If a relay agent is used, its IP address is also displayed.	detail
DHCP options	User-defined options created for the DHCP server. If no options have been defined, this field is blank.	detail

Sample Output

```
show system services dhcp binding  user@host> show system services dhcp binding
Allocated address  MAC address      Binding Type  Lease expires at
192.168.1.2        00:a0:12:00:12:ab  static       never
192.168.1.3        00:a0:12:00:13:02  dynamic      2004-05-03 13:01:42 PDT
```

```
show system services dhcp binding address  user@host> show system services dhcp binding 192.168.1.3
DHCP binding information:
Allocated address: 192.168.1.3
Mac address: 00:a0:12:00:12:ab
Client identifier
61 63 65 64 2d 30 30 3a 61 30 3a 31 32 3a 30 30aced-00:a0:12:00
3a 31 33 3a 30 32:13:02

Lease information:
  Binding Type dynamic
  Obtained at 2004-05-02 13:01:42 PDT
  Expires at 2004-05-03 13:01:42 PDT
```

```
show system services dhcp binding address detail  user@host> show system services dhcp binding 192.168.1.3 detail
DHCP binding information:
Allocated address      192.168.1.3
MAC address 00:a0:12:00:12:ab
Pool      192.168.1.0/24
Request received on fe-0/0/0, relayed by 192.168.4.254

Lease information:
  Type      DHCP
  Obtained at      2004-05-02 13:01:42 PDT
  Expires at      2004-05-03 13:01:42 PDT
  State active

DHCP options:
  Name: name-server, Value: { 6.6.6.6, 6.6.6.7 }
  Name: domain-name, Value: mydomain.tld
  Code: 19, Type: flag, Value: off
```

Code: 40, Type: string, Value: domain.tld
Code: 32, Type: ip-address, Value: 3.3.3.33

show system services dhcp conflict

Syntax	show system services dhcp conflict
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers only and EX Series switches) Display Dynamic Host Configuration Protocol (DHCP) client-detected conflicts for IP addresses. When a conflict is detected, the DHCP server removes the address from the address pool.
Options	This command has no options.
Required Privilege Level	view and system
Related Documentation	<ul style="list-style-type: none"> clear system services dhcp conflict on page 718
List of Sample Output	show system services dhcp conflict on page 963
Output Fields	Table 148 on page 963 describes the output fields for the show system services dhcp conflict command. Output fields are listed in the approximate order in which they appear.

Table 148: show system services dhcp conflict Output Fields

Field Name	Field Description
Detection time	Date and time the client detected the conflict.
Detection method	How the conflict was detected.
Address	IP address where the conflict occurs. The addresses in the conflicts list remain excluded from the pool until you use a clear system services dhcp conflict command to manually clear the list.

Sample Output

```

user@host> show system services dhcp conflict
Detection time      Detection method  Address
2004-08-03 19:04:00 PDT  ARP              3.3.3.5
2004-08-04 04:23:12 PDT  Ping             4.4.4.8
2004-08-05 21:06:44 PDT  Client           3.3.3.10

```

show system services dhcp global

Syntax	show system services dhcp global
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Display Dynamic Host Configuration Protocol (DHCP) global configuration options. Global options apply to all scopes and clients served by the DHCP server. Global options are overridden if specified otherwise in scope or client options. Scope options apply to specific subnets or ranges of addresses. Client options apply to specific clients.
Options	This command has no options.
Required Privilege Level	view and system
List of Sample Output	show system services dhcp global on page 965
Output Fields	Table 149 on page 964 describes the output fields for the show system services dhcp global command. Output fields are listed in the approximate order in which they appear.

Table 149: show system services dhcp global Output Fields

Field Name	Field Description
BOOTP lease length	Length of lease time assigned to BOOTP clients.
Default lease time	Lease time assigned to clients that do not request a specific lease time.
Minimum lease time	Minimum time a client retains an IP address lease on the server.
Maximum lease time	Maximum time a client can retain an IP address lease on the server.
DHCP options	User-defined options created for the DHCP server. If no options have been defined, this field is blank.

Sample Output

```
show system services  user@host> show system services dhcp global
dhcp global
Global settings:
  BOOTP lease length      infinite

DHCP lease times:
  Default lease time      1 hour
  Minimum lease time      2 hours
  Maximum lease time      infinite

DHCP options:
  Name: name-server, Value: { 6.6.6.6, 6.6.6.7 }
  Name: domain-name, Value: mydomain.tld
  Code: 19, Type: flag, Value: off
  Code: 40, Type: string, Value: domain.tld
  Code: 32, Type: ip-address, Value: 3.3.3.33
```

show system services dhcp pool

Syntax	show system services dhcp pool <detail> <subnet-address>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Display Dynamic Host Configuration Protocol (DHCP) server IP address pools.
Options	none—Display brief information about all IP address pools. detail—(Optional) Display detailed information. subnet-address—(Optional) Display information for the specified subnet address.
Required Privilege Level	view and system
List of Sample Output	show system services dhcp pool on page 967 show system services dhcp pool subnet-address on page 967 show system services dhcp pool subnet-address detail on page 967
Output Fields	Table 150 on page 966 describes the output fields for the show system services dhcp pool command. Output fields are listed in the approximate order in which they appear.

Table 150: show system services dhcp pool Output Fields

Field Name	Field Description	Level of Output
Pool name	Subnet on which the IP address pool is defined.	None specified
Low address	Lowest address in the IP address pool.	None specified
High address	Highest address in the IP address pool.	None specified
Excluded addresses	Addresses excluded from the address pool.	None specified
Subnet	(<i>subnet-address</i> option only) Subnet to which the specified address pool belongs.	None specified
Address range	(<i>subnet-address</i> option only) Range of IP addresses in the address pool.	None specified
Addresses assigned	Number of IP addresses in the pool that are assigned to DHCP clients and the total number of IP addresses in the pool.	detail
Active	Number of assigned IP addresses in the pool that are active.	detail
Excluded	Number of assigned IP addresses in the pool that are excluded.	detail
Default lease time	Lease time assigned to clients that do not request a specific lease time.	detail

Table 150: show system services dhcp pool Output Fields (*continued*)

Field Name	Field Description	Level of Output
Minimum lease time	Minimum time a client can retain an IP address lease on the server.	detail
Maximum lease time	Maximum time a client can retain an IP address lease on the server.	detail
DHCP options	User-defined options created for the DHCP server. If no options have been defined, this field is blank.	detail

Sample Output

```

show system services dhcp pool      user@host> show system services dhcp pool
                                     Pool name      Low address   High address   Excluded addresses
                                     3.3.3.0/24    3.3.3.2       3.3.3.254     3.3.3.1

show system services dhcp pool      user@host> show system services dhcp pool 3.3.3.0/24
subnet-address                      Pool information:
                                     Subnet                3.3.3.0/24
                                     Address range         3.3.3.2 - 3.3.3.254
                                     Addresses assigned    2/253

show system services dhcp pool      user@host> show system services dhcp pool 3.3.3.0/24 detail
subnet-address detail              Pool information:
                                     Subnet                3.3.3.0/24
                                     Address range         3.3.3.2 - 3.3.3.254
                                     Addresses assigned    2/253
                                     Active: 1, Excluded: 1

                                     DHCP lease times:
                                     Default lease time    1 hour
                                     Minimum lease time    2 hours
                                     Maximum lease time    infinite

                                     DHCP options:
                                     Name: name-server, Value: { 6.6.6.6, 6.6.6.7 }
                                     Name: domain-name, Value: mydomain.tld
                                     Name: router, Value: { 3.3.3.1 }
                                     Name: server-identifier, Value: 3.3.3.1
                                     Code: 19, Type: flag, Value: off
                                     Code: 40, Type: string, Value: domain.tld
                                     Code: 32, Type: ip-address, Value: 3.3.3.333.3.3.254 3.3.3.1

```

show system services dhcp statistics

Syntax	show system services dhcp statistics
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(J Series routers and EX Series switches only) Display Dynamic Host Configuration Protocol (DHCP) server statistics.
Options	This command has no options.
Required Privilege Level	view and system
Related Documentation	<ul style="list-style-type: none"> clear system services dhcp statistics on page 719
List of Sample Output	show system services dhcp statistics on page 969
Output Fields	Table 151 on page 968 describes the output fields for the show system services dhcp statistics command. Output fields are listed in the approximate order in which they appear.

Table 151: show system services dhcp statistics Output Fields

Field Name	Field Description
Default lease time	Lease time assigned to clients that do not request a specific lease time.
Minimum lease time	Minimum time a client can retain an IP address lease on the server.
Maximum lease time	Maximum time a client can retain an IP address lease on the server.
Packets dropped	Total number of packets dropped and number of packets dropped because of: <ul style="list-style-type: none"> Invalid hardware address Invalid opcode Invalid server address No available address No interface match No routing instance match No valid local addresses Packet too short Read error Send error

Table 151: show system services dhcp statistics Output Fields (*continued*)

Field Name	Field Description
Messages received	Number of the following message types sent from DHCP clients and received by the DHCP server: <ul style="list-style-type: none"> • BOOTREQUEST • DHCPDECLINE • DHCPDISCOVER • DHCPINFORM • DHCPRELEASE • DHCPREQUEST
Messages sent	Number of the following message types sent from the DHCP server to DHCP clients: <ul style="list-style-type: none"> • BOOTREPLY • DHCPACK • DHCPOFFER • DHCPNAK

Sample Output

```

show system services dhcp statistics  user@host> show system services dhcp statistics

DHCP lease times:
  Default lease time      1 hour
  Minimum lease time     2 hours
  Maximum lease time     infinite

Packets dropped:
  Total                   0
  Bad hardware address    0
  Bad opcode              0
  Invalid server address  0
  No available addresses  0
  No interface match      0
  No routing instance match 0
  No valid local address  0
  Packet too short        0
  Read error              0
  Send error              0

Messages received:
  BOOTREQUEST            0
  DHCPDECLINE            0
  DHCPDISCOVER           0
  DHCPINFORM             0
  DHCPRELEASE            0
  DHCPREQUEST            0

Messages sent:
  BOOTREPLY              0
  DHCPACK                0
  DHCPOFFER              0
  DHCPNAK                0

```

show system services service-deployment

Syntax	show system services service-deployment
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display information about a Session and Resource Control (SRC) client.
Options	This command has no options.
Required Privilege Level	view system
List of Sample Output	show system services service-deployment on page 970
Output Fields	Table 152 on page 970 lists the output fields for the show system services service-deployment command. Output fields are listed in the approximate order in which they appear.

Table 152: show system services service-deployment Output Fields

Field Name	Field Description
PDT Keepalive settings	Configured PDT Keepalive interval, in seconds.
Keepalives sent	Number of Keepalives sent.
Notifications sent	Number of notifications sent.
Last update from peer	Time at which the last update from peer was received.

Sample Output

```

show system services service-deployment  user@host> show system services service-deployment
Connected to 192.4.4.4 port 10288 since 2004-05-03 11:04:34 PDT Keepalive settings:
Interval 15 seconds Keepalives sent: 750 Notifications sent: 0 Last update from
peer: 00:00:06 ago

```

show system snapshot

Syntax	show system snapshot
Syntax (EX Series Switch)	show system snapshot <all-members local member <i>member-id</i> > <media (external internal)> <slice (1 2 alternate)>
Release Information	Command introduced in Junos OS Release 7.6. Command introduced in Junos OS Release 10.0 for EX Series switches.
Description	Display information about the backup software: <ul style="list-style-type: none"> On the routers, display information about the backup software, which is located in the /altroot, and /altconfig file systems or on the alternate media. On the switches, display information about the backup of the root file system /, /config directory, and /var directory, which are located either on an external USB flash drive or in internal flash memory.



NOTE: To back up software, use the **request system snapshot** command.

Options	<p>none—Display information about the backup software.</p> <p>all-members local member <i>member-id</i>—(EX4200 switch and EX4200, EX4500, and EX8200 Virtual Chassis only) (Optional) Display the snapshot in a Virtual Chassis:</p> <ul style="list-style-type: none"> all-members—Display the snapshot for all members of the Virtual Chassis. local—Display the snapshot on the member of the Virtual Chassis that you are currently logged into. member <i>member-id</i>—Display the snapshot for the specified member of the Virtual Chassis. <p>media (external internal)—(EX Series switch only) (Optional) Display the destination media location for the snapshot. The external option specifies the snapshot on an external mass storage device, such as a USB flash drive. The internal option specifies the snapshot on an internal memory source, such as internal flash memory. If no additional options are specified, the command displays the snapshot stored in both slices.</p> <p>slice (1 2 alternate)—(EX Series switch only) Display the snapshot in a specific partition:</p> <ul style="list-style-type: none"> 1—Display the snapshot in partition 1. 2—Display the snapshot in partition 2. alternate—Display the snapshot in the alternate partition, which is the partition that did not boot the switch at the last bootup.
----------------	--

Required Privilege Level view

Related Documentation • request system snapshot on page 766

List of Sample Output show system snapshot (Router) on page 972
 show system snapshot media external (Switch) on page 972
 show system snapshot media internal (Switch) on page 972
 show system snapshot media internal slice 2 (Switch) on page 973

Output Fields Table 153 on page 972 lists the output fields for the **show system snapshot** command. Output fields are listed in the approximate order in which they appear.

Table 153: show system snapshot Output Fields

Field Name	Field Description
Creation date	Date and time of the last snapshot.
JUNOS version on snapshot	Junos OS release number of individual software packages.

Sample Output

```

show system snapshot (Router) user@host> show system snapshot
Information for snapshot on hard-disk
Creation date: Oct 5 13:53:29 2005
JUNOS version on snapshot:
  jbase : 7.3R2.5
  jcrypto: 7.3R2.5
  jdocs : 7.3R2.5
  jkernel: 7.3R2.5
  jpfe : M40-7.3R2.5
  jroute : 7.3R2.5

show system snapshot media external (Switch) user@switch> show system snapshot media external
Information for snapshot on external (da1s1)
Creation date: Oct 13 20:23:23 2009
JUNOS version on snapshot:
  jbase : 10.0I20090726_0011_user
  jcrypto-ex: 10.0I20090726_0011_user
  jdocs-ex: 10.0I20090726_0011_user
  jkernel-ex: 10.0I20090726_0011_user
  jroute-ex: 10.0I20090726_0011_user
  jswitch-ex: 10.0I20090726_0011_user
  jweb-ex: 10.0I20090726_0011_user
  jpfe-ex42x: 10.0I20090726_0011_user

show system snapshot media internal (Switch) user@switch> show system snapshot media internal
Information for snapshot on internal (/dev/da0s1a) (backup)
Creation date: Mar 14 05:01:02 2011
JUNOS version on snapshot:
  jbase : 11.1R1.9
  jcrypto-ex: 11.1R1.9
  jdocs-ex: 11.1R1.9

```

```

jkernel-ex: 11.1R1.9
jroute-ex: 11.1R1.9
jswitch-ex: 11.1R1.9
jweb-ex: 11.1R1.9
jpfe-ex42x: 11.1R1.9
Information for snapshot on internal (/dev/da0s2a) (primary)
Creation date: Mar 30 08:46:27 2011
JUNOS version on snapshot:
jbase : 11.2-20110330.0
jcrypto-ex: 11.2-20110330.0
jdocs-ex: 11.2-20110330.0
jkernel-ex: 11.2-20110330.0
jroute-ex: 11.2-20110330.0
jswitch-ex: 11.2-20110330.0
jweb-ex: 11.2-20110330.0
jpfe-ex42x: 11.2-20110330.0

```

```

show system snapshot user@switch> show system snapshot media internal slice 2
media internal slice 2 Information for snapshot on internal (/dev/da0s2a) (primary)
(Switch) Creation date: Mar 30 08:46:27 2011
JUNOS version on snapshot:
jbase : 11.2-20110330.0
jcrypto-ex: 11.2-20110330.0
jdocs-ex: 11.2-20110330.0
jkernel-ex: 11.2-20110330.0
jroute-ex: 11.2-20110330.0
jswitch-ex: 11.2-20110330.0
jweb-ex: 11.2-20110330.0
jpfe-ex42x: 11.2-20110330.0

```

show system software

Syntax	show system software <detail>
Syntax (EX Series Switch)	show system software <all-members> <detail> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system software <all-chassis all-lcc lcc <i>number</i> scc> <detail>
Syntax (TX Matrix Plus Router)	show system software <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <detail>
Syntax (J Series Routers)	show system software <backup> <detail>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display the Junos OS extensions loaded on your router or switch.
Options	none—Display standard information about all loaded Junos OS extensions. all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system software information for all the T640 routers (TX Matrix Router) or all the T1600 routers (TX Matrix Plus Router) in the chassis. all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system software information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system software information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router all-members—(EX4200 switches only) (Optional) Display the system software running on all members of the Virtual Chassis configuration. backup—(J Series routers only) (Optional) Display the status of old system software packages only. detail—(Optional) Display detailed information about available Junos OS extensions. lcc <i>number</i> —(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system software information for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system software information

for a specific T1600 router that is connected to the TX Matrix Plus router. Replace **number** with a value from 0 through 3.

local—(EX4200 switches only) (Optional) Display the system software running on the local Virtual Chassis member.

member *member-id*—(EX4200 switches only) (Optional) Display the system software running on the specified member of the Virtual Chassis configuration. Replace **member-id** with a value from 0 through 9.

scc—(Routing matrix only) (Optional) Display the system software running on a TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus routers only) (Optional) Display system software information for the TX Matrix Plus router (or switch-fabric chassis).

Required Privilege Level maintenance

List of Sample Output [show system software on page 975](#)
[show system software \(TX Matrix Plus Router\) on page 976](#)

Output Fields When you enter this command, you are provided a list of Junos OS packages installed on the router and their corresponding Junos OS release number.

Sample Output

```
show system software user@host> show system software
Information for jbase:

Comment:
JUNOS Base OS Software Suite [7.2R1.7]

Information for jcrypto:

Comment:
JUNOS Crypto Software Suite [7.2R1.7]
Information for jdocs:

Comment:
JUNOS Online Documentation [7.2R1.7]

Information for jkernel:

Comment:
JUNOS Kernel Software Suite [7.2R1.7]

Information for jpfe:

Comment:
JUNOS Packet Forwarding Engine Support (M20/M40) [7.2R1.7]

Information for jroute:
```

```

Comment:
JUNOS Routing Software Suite [7.2R1.7]

Information for junos:

Comment:
JUNOS Base OS boot [7.2R1.7]

show system software user@host> show system software
(TX Matrix Plus sfc0-re0:
Router) -----
Information for jbase:

Comment:
JUNOS Base OS Software Suite [9.6-20090515.0]

Information for jcrypto:

Comment:
JUNOS Crypto Software Suite [9.6-20090515.0]

Information for jdocs:

Comment:
JUNOS Online Documentation [9.6-20090515.0]
Information for jkernel:

Comment:
JUNOS Kernel Software Suite [9.6-20090515.0]

Information for jpfe:

Comment:
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090515.0]

Information for jpfe-common:

Comment:
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090515.0]

Information for jroute:Comment:
JUNOS Routing Software Suite [9.6-20090515.0]

Information for jservices-aacl:

Comment:
JUNOS Services ACL Container package [9.6-20090515.0]

```


Information for jservices-appid:

Comment:
JUNOS AppId Services [9.6-20090515.0]

Information for jservices-bgf:

Comment:
JUNOS Border Gateway Function package [9.6-20090515.0]
Information for jservices-idp:

Comment:
JUNOS IDP Services [9.6-20090515.0]

Information for jservices-llpdf:

Comment:
JUNOS Services LL-PDF Container package [9.6-20090515.0]

Information for jservices-sfw:

Comment:
JUNOS Services Stateful Firewall [9.6-20090515.0]
Information for jservices-voice:

Comment:
JUNOS Voice Services Container package [9.6-20090515.0]

Information for junos:

Comment:
JUNOS Base OS boot [9.6-20090515.0]
...
lcc0-re0:

Information for jbase:

Comment:
JUNOS Base OS Software Suite [9.6-20090515.0]

Information for jcrypto:

Comment:
JUNOS Crypto Software Suite [9.6-20090515.0]

Information for jdocs:

Comment:
JUNOS Online Documentation [9.6-20090515.0]

Information for jkernel:

Comment:
JUNOS Kernel Software Suite [9.6-20090515.0]

Information for jpfe:

Comment:
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090515.0]

Information for jpfe-common:

Comment:
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090515.0]

Information for jroute:

Comment:
JUNOS Routing Software Suite [9.6-20090515.0]

Information for jservices-aacl:

Comment:
JUNOS Services ACL Container package [9.6-20090515.0]

Information for jservices-appid:

Comment:
JUNOS AppId Services [9.6-20090515.0]

Information for jservices-bgf:

Comment:
JUNOS Border Gateway Function package [9.6-20090515.0]

Information for jservices-idp:

Comment:
JUNOS IDP Services [9.6-20090515.0]

Information for jservices-llpdf:

Comment:

JUNOS Services LL-PDF Container package [9.6-20090515.0]

Information for jservices-sfw:

Comment:

JUNOS Services Stateful Firewall [9.6-20090515.0]

Information for jservices-voice:

Comment:

JUNOS Voice Services Container package [9.6-20090515.0]

Information for junos:

Comment:

JUNOS Base OS boot [9.6-20090515.0]

lcc1-re0:

Information for jbase:

Comment:

JUNOS Base OS Software Suite [9.6-20090515.0]

Information for jcrypto:

Comment:

JUNOS Crypto Software Suite [9.6-20090515.0]

...

show system statistics

Syntax	show system statistics
Syntax (EX Series Switch)	show system statistics <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system statistics <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show system statistics
Release Information	Command introduced before JUNOS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display system-wide protocol-related statistics.
Options	none—Display system statistics for all the following protocols: <ul style="list-style-type: none">• arp—Address Resolution Protocol• bridge—IEEE 802.1 Bridging• clns—Connectionless Network Service• esis—End System-to-Intermediate System• ethoamcfm—Ethernet OAM protocol for connectivity fault management• ethoamlfm—Ethernet OAM protocol for link fault management• icmp—Internet Control Message Protocol• icmp6—Internet Control Message Protocol version 6• igmp—Internet Group Management Protocol• ip—Internet Protocol version 4• ip6—Internet Protocol version 6• mpls—Multiprotocol Label Switching• rdp—Reliable Datagram Protocol

- **tcp**—Transmission Control Protocol
- **tnp**—Trivial Network Protocol
- **ttp**—TNP Tunneling Protocol
- **tudp**—Trivial User Datagram Protocol
- **udp**—User Datagram Protocol
- **vpls**—Virtual Private LAN Service

all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for a protocol for all the routers in the chassis.

all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for a protocol for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for a protocol for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router

all-members—(EX4200 switches and MX Series routers only) (Optional) Display system statistics for a protocol for all members of the Virtual Chassis configuration.

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for a protocol for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for a protocol for a specific T1600 router that is connected to the TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display system statistics for a protocol for the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display system statistics for a protocol for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display system statistics for a protocol for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Display system statistics for a protocol for the TX Matrix Plus router (or switch-fabric chassis). Replace ***number*** with 0.

Additional Information By default, when you issue the **show system statistics** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output show system statistics on page 982
 show system statistics (EX Series Switch) on page 989
 show system statistics (TX Matrix Router) on page 998
 show system statistics (QFX Series) on page 1004

Sample Output

```
show system statistics    user@host> show system statistics
ip:
    3682087 total packets received
    0 bad header checksums
    0 with size smaller than minimum
    0 with data size < data length
    0 with header length < data size
    0 with data length < header length
    0 with incorrect version number
    0 packets destined to dead next hop
    0 fragments received
    0 fragments dropped (dup or out of space)
    0 fragments dropped (queue overflow)
    0 fragments dropped after timeout
    0 fragments dropped due to over limit
    0 packets reassembled ok
    3664774 packets for this host
    17316 packets for unknown/unsupported protocol
    0 packets forwarded
    0 packets not forwardable
    0 redirects sent
    6528 packets sent from this host
    0 packets sent with fabricated ip header
    0 output packets dropped due to no bufs
    0 output packets discarded due to no route
    0 output datagrams fragmented
    0 fragments created
    0 datagrams that can't be fragmented
    0 packets with bad options
    1123 packets with options handled without error
    0 strict source and record route options
    0 loose source and record route options
    0 record route options
    0 timestamp options
    0 timestamp and address options
    0 timestamp and prespecified address options
    0 option packets dropped due to rate limit
    1123 router alert options
    0 multicast packets dropped (no iflist)
    0 packets dropped (src and int don't match)
icmp:
    0 drops due to rate limit
    0 calls to icmp_error
    0 errors not generated because old message was icmp
Output histogram:
    echo reply: 75
    0 messages with bad code fields
    0 messages less than the minimum length
    0 messages with bad checksum
    0 messages with bad source address
```

```

0 messages with bad length
0 echo drops with broadcast or multicast destination address
0 timestamp drops with broadcast or multicast destination address
Input histogram:
    echo: 75
    router advertisement: 130
75 message responses generated
tcp:
3844 packets sent
    3618 data packets (1055596 bytes)
    0 data packets (0 bytes) retransmitted
    0 resends initiated by MTU discovery
    205 ack-only packets (148 packets delayed)
    0 URG only packets
    0 window probe packets
    0 window update packets
    1079 control packets
5815 packets received
    3377 acks (for 1055657 bytes)
    24 duplicate acks
    0 acks for unsent data
    2655 packets (15004 bytes) received in-sequence
    1 completely duplicate packet (0 bytes)
    0 old duplicate packets
    0 packets with some dup. data (0 bytes duped)
    0 out-of-order packets (0 bytes)
    0 packets (0 bytes) of data after window
    0 window probes
    7 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
1 connection request
32 connection accepts
0 bad connection attempts
0 listen queue overflows
33 connections established (including accepts)
30 connections closed (including 0 drops)
    27 connections updated cached RTT on close
    27 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
3374 segments updated rtt (of 3220 attempts)
0 retransmit timeouts
    0 connections dropped by rexmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
344 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
1096 correct ACK header predictions
1314 correct data packet header predictions
32 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    32 completed
    0 bucket overflow
    0 cache overflow
    0 reset

```

```
0 stale
0 aborted
0 badack
0 unreach
0 zone failures
0 cookies sent
0 cookies received
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
1058 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
udp:
3658884 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
3657342 dropped due to no socket
3657342 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
0 not for hashed pcb
4291311496 delivered
1551 datagrams output
ipsec:
0 inbound packets processed successfully
0 inbound packets violated process security policy
0 inbound packets with no SA available
0 invalid inbound packets
0 inbound packets failed due to insufficient memory
0 inbound packets failed getting SPI
0 inbound packets failed on AH replay check
0 inbound packets failed on ESP replay check
0 inbound AH packets considered authentic
0 inbound AH packets failed on authentication
0 inbound ESP packets considered authentic
0 inbound ESP packets failed on authentication
0 outbound packets processed successfully
0 outbound packets violated process security policy
0 outbound packets with no SA available
0 invalid outbound packets
0 outbound packets failed due to insufficient memory
0 outbound packets with no route
igmp:
17186 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid field(s)
0 membership reports received
0 membership reports received with invalid field(s)
0 membership reports received for groups to which we belong
0 membership reports sent
arp:
44181302 datagrams received
2 ARP requests received
2028 ARP replies received
3156 resolution requests received
0 unrestricted proxy requests
```



```

0 received proxy requests
0 proxy requests not proxied
0 with bogus interface
787 with incorrect length
712 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
7611 with multicast target address
0 with my own hardware address
14241699 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
29929250 which were not for me
0 packets discarded waiting for resolution
6 packets sent after waiting for resolution
17812 ARP requests sent
2 ARP replies sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry

ip6:
0 total packets received
0 with size smaller than minimum
0 with data size < data length
0 with bad options
0 with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
Mbuf statistics:
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too many headers
0 failures of source address selection
0 forward cache hit
0 forward cache miss
0 packets destined to dead next hop
0 option packets dropped due to rate limit
0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol

icmp6:
0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation

```

```
0 messages with bad code fields
0 messages < minimum length
0 bad checksums
0 messages with bad length
Histogram of error messages to be generated:
    0 no route
    0 administratively prohibited
    0 beyond scope
    0 address unreachable
    0 port unreachable
    0 packet too big
    0 time exceed transit
    0 time exceed reassembly
    0 erroneous header field
    0 unrecognized next header
    0 unrecognized option
    0 redirect
    0 unknown
0 message responses generated
0 messages with too many ND options
ipsec6:
0 inbound packets processed successfully
0 inbound packets violated process security policy
0 inbound packets with no SA available
0 invalid inbound packets
0 inbound packets failed due to insufficient memory
0 inbound packets failed getting SPI
0 inbound packets failed on AH replay check
0 inbound packets failed on ESP replay check
0 inbound AH packets considered authentic
0 inbound AH packets failed on authentication
0 inbound ESP packets considered authentic
0 inbound ESP packets failed on authentication
0 outbound packets processed successfully
0 outbound packets violated process security policy
0 outbound packets with no SA available
0 invalid outbound packets
0 outbound packets failed due to insufficient memory
0 outbound packets with no route
c1n1:
0 total packets received
0 packets delivered
0 too small
0 bad header length
0 bad checksum
0 bad version
0 unknown or unsupported protocol
0 bogus sdl size
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 address fields were not reasonable
0 segment information forgotten
0 forwarded packets
0 total packets sent
0 output packets discarded
0 non-forwarded packets
0 packets fragmented
0 fragments sent
0 fragments discarded
```

```

0 fragments timed out
0 fragmentation prohibited
0 packets reconstructed
0 packets destined to dead nexthop
0 packets discarded due to no route
0 Error pdu rate drops
0 ER pdu generation failure
esis:
0 total pkts received
0 total packets consumed by protocol
0 pdus received with bad checksum
0 pdus received with bad version number
0 pdus received with bad type field
0 short pdus received
0 bogus sdl size
0 bad header length
0 unknown or unsupported protocol
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 ISO family not configured
tnp:
146776365 unicast packets received
0 broadcast packets received
0 fragmented packets received
0 hello packets dropped
0 fragments dropped
0 fragment reassembly queue flushes
0 hello packets received
0 control packets received
49681642 rdp packets received
337175 udp packets received
96757548 tunnel packets received
0 input packets discarded with no protocol
98397591 unicast packets sent
0 broadcast packets sent
0 fragmented packets sent
0 hello packets dropped
0 fragments dropped
0 hello packets sent
0 control packets sent
49681642 rdp packets sent
337175 udp packets sent
48378774 tunnel packets sent
0 packets sent with unknown protocol
rdp:
49681642 input packets
0 discards for bad checksum
0 discards bad sequence number
0 refused connections
2031964 acks received
0 dropped due to full socket buffers
49692 retransmits
49681642 output packets
24815968 acks sent
28 connects
0 closes
22783990 keepalives received
22783990 keepalives sent
tudp:

```

```
337175 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
0 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
337175 delivered
337175 datagrams output

ttp:
398749 packets sent
0 packets sent while unconnected
0 packets sent while interface down
0 packets sent couldn't get buffer
0 packets sent couldn't find neighbor
44696687 L2 packets received
0 unknown L3 packets received
3682087 IPv4 L3 packets received
0 MPLS L3 packets received
0 MPLS->IPv4 L3 packets received
0 IPv4->MPLS L3 packets received
0 IPv6 L3 packets received
0 ARP L3 packets received
0 CLNP L3 packets received
0 TNP L3 packets received
0 NULL L3 packets received
0 cyclotron cycle L3 packets received
0 cyclotron send L3 packets received
0 packets received while unconnected
0 packets received from unknown ifl
0 input packets couldn't get buffer
0 input packets with bad type
0 input packets with discard type
0 input packets for which rt lookup is bypassed

mpls:
0 total mpls packets received
0 packets forwarded
0 packets dropped
0 with header too small
0 after tagging, can't fit link MTU
0 with IPv4 explicit NULL tag
0 with IPv4 explicit NULL cksum errors
0 with router alert tag
0 lsp ping packets (ttl-expired/router alert)
0 with ttl expired
0 with tag encoding error
0 packets discarded, no route

vpls:
0 total packets received
0 with size smaller than minimum
0 with incorrect version number
0 packets for this host
0 packets with no logical interface
0 packets with no family
0 packets with no route table
0 packets with no auxiliary table
0 packets with no corefacing entry
0 packets with no CE-facing entry
0 mac route learning requests
0 mac routes learnt
0 requests to learn an existing route
```

```

0 learning requests while learning disabled on interface
0 learning requests over capacity
0 mac routes moved
0 requests to move static route
0 mac route aging requests
0 mac routes aged
0 bogus address in aging requests
0 requests to age static route
0 requests to re-ageout aged route
0 requests involving multiple peer FEs
0 aging acks from PFE
0 aging non-acks from PFE
0 aging requests timed out waiting on FEs
0 aging requests over max-rate
0 errors finding peer FEs

```

show system statistics user@host> **show system statistics**
(EX Series Switch) Tcp:

```

571779 packets sent
    21517 data packets (1797102 bytes)
    2 data packets retransmitted (20 bytes)
    0 resends initiated by MTU discovery
    3708 ack only packets (531 packets delayed)
    0 URG only packets
    1 window probe packets
    1 window update packets
    1093063 control packets
1132541 packets received
    20961 acks(for 1796102 bytes)
    5861 duplicate acks
    0 acks for unsent data
    19556 packets received in-sequence(232079 bytes)
    3018 completely duplicate packets(0 bytes)
    0 old duplicate packets
    4 packets with some duplicate data(4 bytes duped)
    2 out-of-order packets(2 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    39 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
546519 connection requests
78 connection accepts
0 bad connection attempts
0 listen queue overflows
100 connections established (including accepts)
546596 connections closed (including 6 drops)
    47 connections updated cached RTT on close
    47 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
546497 embryonic connections dropped
20453 segments updated rtt(of 566914 attempts)
2 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
3028 keepalive timeouts
    3027 keepalive probes sent
    1 connections dropped by keepalive

```

```
7515 correct ACK header predictions
12258 correct data packet header predictions
78 syncache entries added
    0 retransmitted
    0 dupsyn
    4 dropped
    78 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
1 SACK recovery episodes
1 segment retransmits in SACK recovery episodes
1 byte retransmits in SACK recovery episodes
71 SACK options (SACK blocks) received
1 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
546544 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

udp:
147 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
9 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
0 not for hashed pcb
138 delivered
0 datagrams output

ip:
73704 total packets received
0 bad header checksums
0 with size smaller than minimum
0 with data size < data length
0 with header length < data size
0 with data length < header length
0 with incorrect version number
0 packets destined to dead next hop
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
1133057 packets for this host
0 packets for unknown/unsupported protocol
40146 packets forwarded
```

```

0 packets not forwardable
40146 redirects sent
1121700 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
0 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
0 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent
0 outgoing TTPoIP packets dropped
icmp:
0 drops due to rate limit
9 calls to icmp_error
0 errors not generated because old message was icmp
Output histogram:
    295 echo reply
    9 destination unreachable
0 messages with bad code fields
0 messages less than the minimum length
0 messages with bad checksum
0 messages with bad source address
0 messages with bad length
0 echo drops with broadcast or multicast destination address
0 timestamp drops with broadcast or multicast destination address
Input histogram:
    295 echo
295 message responses generated
igmp:
0 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid fields
0 membership reports received
0 membership reports received with invalid fields
0 membership reports received for groups to which we belong
0 Membership reports sent
raw_if:
0 RAW packets transmitted
0 PPPOE packets transmitted
0 ISDN packets transmitted
0 DIALER packets transmitted
0 PPP packets transmitted to pppd
0 PPP packets transmitted to jppd

```

```
0 IGMPv2 packets transmitted
13 output drops due to tx error
0 MPU packets transmitted
0 PPPoE packets received
0 ISDN packets received
0 DIALER packets received
0 PPP packets received from pppd
0 MPU packets received
0 PPP packets received from jppd
0 IGMPv2 packets received
0 Input drops due to bogus protocol
0 input drops due to no mbufs available
0 input drops due to no space in socket
0 input drops due to no socket

arp:
186413 datagrams received
88 ARP requests received
88 ARP replies received
0 resolution request received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requests not proxied
0 restricted proxy requests not proxied
0 datagrams with bogus interface
0 datagrams with incorrect length
0 datagrams for non-IP protocol
0 datagrams with unsupported op code
0 datagrams with bad protocol address length
0 datagrams with bad hardware address length
0 datagrams with multicast source address
0 datagrams with multicast source address
0 datagrams with my own hardware address
164 datagrams for an address not on the interface
0 datagrams with a broadcast source address
0 datagrams with source address duplicate to mine
186065 datagrams which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
50 ARP requests sent
88 ARP replies sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor

ip6:
0 total packets received
0 packets with size smaller than minimum
0 packets with data size < data length
0 packets with bad options
0 packets with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
```



```

0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too may headers
0 failures of source address selection
0 forward cache hit
0 forward cache miss
0 Packets destined to dead next hop
0 option packets dropped due to rate limit
0 Packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f

icmp6:
0 Calls to icmp_error
0 Errors not generated because old message was icmp error
0 Errors not generated because rate limitation
0 Messages with bad code fields
0 Messages < minimum length
0 Bad checksums
0 Messages with bad length
    0 No route
    0 Administratively prohibited
    0 Beyond scope
    0 Address unreachable
    0 Port unreachable
    0 packet too big
    0 Time exceed transit
    0 Time exceed reassembly
    0 Erroneous header field
    0 Unrecognized next header
    0 Unrecognized option
    0 redirect
    0 Unknown
0 Message responses generated
0 Messages with too many ND options

pfkey:
0 Requests sent from userland
0 Bytes sent from userland
histogram by message type:
    0 reserved
    0 dump
0 Messages with invalid length field
0 Messages with invalid version field
0 Messages with invalid message type field
0 Messages too short
0 Messages with memory allocation failure
0 Messages with duplicate extension
0 Messages with invalid extension type
0 Messages with invalid sa type
0 Messages with invalid address extension

```

```
0 Requests sent to userland
0 Bytes sent to userland
histogram by message type:
    0 reserved
    0 dump
0 Messages toward single socket
0 Messages toward all sockets
0 Messages toward registered sockets
0 Messages with memory allocation failure
c1nl:
0 Total packets received
0 Packets delivered
0 Too small packets
0 Packets with bad header length
0 Packets with bad checksum
0 Bad version packets
0 Unknown or unsupported protocol packets
0 Packets with bogus sdl size
0 No free memory in socket buffer
0 Send packets discarded
0 Sbappend failure
0 Mcopy failure
0 Address fields were not reasonable
0 Segment information forgotten
0 Forwarded packets
0 Total packets sent
0 Output packets discarded
0 Non-forwarded packets
0 Packets fragmented
0 Fragments sent
0 Fragments discarded
0 Fragments timed out
0 Fragmentation prohibited
0 Packets reconstructed
0 Packets destined to dead nexthop
0 Packets discarded due to no route
0 Error pdu rate drops
    0 ER pdu generation failure
esis:
0 Total pkts received
0 Total packets consumed by protocol
0 Pdus received with bad checksum
0 Pdus received with bad version number
0 Pdus received with bad type field
0 Short pdus received
0 Pdus with bogus sdl size
0 Pdus with bad header length
0 Pdus with unknown or unsupported protocol
0 No free memory in socket buffer
0 Send packets discarded
0 Sbappend failure
0 Mcopy failure
0 ISO family not configured
tnp:
0 Unicast packets received
0 Broadcast packets received
0 Fragmented packets received
0 Hello packets dropped
0 Fragments dropped
0 Fragment reassembly queue flushes
0 Packets with tnp src address collision received
```

```

0 Hello packets received
0 Control packets received
0 Rdp packets received
0 Udp packets received
0 Tunnel packets received
0 Input packets discarded with no protocol
0 Packets of version unspecified received
0 Packets of version 1 received
0 Packets of version 2 received
0 Packets of version 3 received
0 Unicast packets sent
0 Broadcast packets sent
0 Fragmented packets sent
0 Hello packets dropped
0 Fragments dropped
0 Hello packets sent
0 Control packets sent
0 Rdp packets sent
0 Udp packets sent
0 Tunnel packets sent
0 Packets sent with unknown protocol
0 Packets of version unspecified sent
0 Packets of version 1 sent
0 Packets of version 2 sent
0 Packets of version 3 sent
rdp:
0 Input packets
0 Packets discarded for bad checksum
0 Packets discarded due to bad sequence number
0 Refused connections
0 Acks received
0 Packets dropped due to full socket buffers
0 Retransmits
0 Output packets
0 Acks sent
0 Connects
0 Closes
0 Keepalives received
0 Keepalives sent
tudp:
67 Datagrams received
0 Datagrams with incomplete header
0 Datagrams with bad data length field
0 Datagrams with bad checksum
0 Datagrams dropped due to no socket
0 Broadcast/multicast datagrams dropped due to no socket
0 Datagrams dropped due to full socket buffers
67 Delivered
68 Datagrams output
ttp:
0 Packets sent
0 Packets sent while unconnected
0 Packets sent while interface down
0 Packets sent couldn't get buffer
0 Packets sent couldn't find neighbor
0 L2 packets received
0 Unknown L3 packets received
0 IPv4 L3 packets received
0 MPLS L3 packets received
0 MPLS->IPv4 L3 packets received
0 IPv4->MPLS L3 packets received

```

```

0 IPv6 L3 packets received
0 ARP L3 packets received
0 CLNP L3 packets received
0 TNP L3 packets received
0 NULL L3 packets received
0 Cyclotron cycle L3 packets received
0 Cyclotron send L3 packets received
0 Packets received while unconnected
0 Packets received from unknown ifl
0 Input packets couldn't get buffer
0 Input packets with bad type
0 Input packets with discard type
0 Input packets for which rt lookup is bypassed

mpls:
0 Total MPLS packets received
0 Packets forwarded
0 Packets dropped
0 Packets with header too small
0 After tagging, packets can't fit link MTU
0 Packets with IPv4 explicit NULL tag
0 Packets with IPv4 explicit NULL cksum errors
0 Packets with router alert tag
0 LSP ping packets (ttl-expired/router alert)
0 Packets with ttl expired
0 Packets with tag encoding error
0 Packets discarded due to no route
0 Packets used first nexthop in ecmp unilist

vpls:
0 Total packets received
0 Packets with size smaller than minimum
0 Packets with incorrect version number
0 Packets for this host
0 Packets with no logical interface
0 Packets with no family
0 Packets with no route table
0 Packets with no auxiliary table
0 Packets with no corefacing entry
0 packets with no CE-facing entry
0 MAC route learning requests
0 MAC routes learnt
0 Requests to learn an existing route
0 Learning requests while learning disabled on interface
0 Learning requests over capacity
0 MAC routes moved
0 Requests to move static route
0 MAC route aging requests
0 MAC routes aged
0 Bogus address in aging requests
0 Requests to age static route
0 Requests to re-ageout aged route
0 Requests involving multiple peer FEs
0 Aging acks from PFE
0 Aging non-acks from PFE
0 Aging requests timed out waiting on FEs
0 Aging requests over max-rate
0 Errors finding peer FEs
0 Unsupported platform
0 Packets dropped due to no l3 route table
0 Packets dropped due to no local ifl
0 Packets punted
0 Packets dropped due to no socket

```

bridge:

Input:

- 0 packets received
- 0 packets forwarded
- 0 packets failed to forward
- 0 packets dropped
- 0 packets with vmember lookup failures
- 0 packets with vlan lookup failures
- 0 packets with stp state lookup failures
- 0 packets dropped due to stp blocked/listening
- 0 packets dropped due to stp learning
- 0 packets with src MAC learning failures
- 0 packets with input control processing failures

Forward:

- 0 packets sent successfully
- 0 packets with send failures
- 0 packets forwarded to l3 interface
- 0 packets with l3 send failures
- 0 packets discarded
- 0 packets with l2ifl store failures
- 0 packets with ifl mismatch failures
- 0 packets with packet duplication failures
- 0 packets with tag lookup failures
- 0 packets with no route for DMAC
- 0 packets with no route table
- 0 packets with no nexthop
- 0 packets with dead nexthop
- 0 packets with eof reached error

Learning:

- 0 MACs learned
- 0 packets sent to l3 interface
- 0 packets with l3 send failures
- 0 packets hit holdq while learning
- 0 MAC moves
- 0 packets discarded
- 0 packets with no route for SMAC
- 0 packets with no nexthop
- 0 packets with dead nexthop
- 0 packets dropped due to no resolve route
- 0 packets with l3 ifd lookup failures
- 0 packets with l3 ifl lookup failures
- 0 packets with l3 invalid rnh
- 0 packets with no route for SMAC in clone learning
- 0 packets with no nexthop in clone learning
- 0 packets with dead nexthop in clone learning
- 0 packets dropped due to no resolve nh in clone learning

Output:

- 0 packets forwarded
- 0 packets failed to forward
- 0 packets with vmember lookup failures
- 0 packets with vlan lookup failures
- 0 packets with input control processing failures

Send:

- 0 packets sent successfully
- 0 packets with send failures
- 0 packets dropped due to interface down
- 0 packets with dev output failures
- 0 blocked ifl discards
- 0 packets with tag lookup failures
- 0 packets with stp state lookup failures
- 0 packets with tag insertion failures

```

0 packets with tag removal failures
Flood:
0 packets flooded
0 flood failures
IGMP:
0 packets sent successfully
0 packets with send failures
0 packets forwarded
0 packets failed to forward
0 packets with mpull failures
0 packets with vmember lookup failures
0 packets with vlan lookup failures
0 packets with ifl lookup failures
0 packets with tag lookup failures
Misc:
0 packets with size smaller than minimum
0 packets with double tags
0 packets with no ifl
0 packets with no family
0 packets with no route table

```

show system statistics user@host> **show system statistics**
(TX Matrix Router) sfc0-re0:

```

-----
Tcp:
361694 packets sent
    326507 data packets (103237236 bytes)
    2343 data packets retransmitted (2673324 bytes)
    0 resends initiated by MTU discovery
    33857 ack only packets (31613 packets delayed)
    0 URG only packets
    14 window probe packets
    387 window update packets
    1108 control packets
345879 packets received
    298207 acks(for 103141728 bytes)
    438 duplicate acks
    0 acks for unsent data
    204578 packets received in-sequence(13820995 bytes)
    6 completely duplicate packets(18 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    899 window update packets
    166 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
406 connection requests
233 connection accepts
0 bad connection attempts
0 listen queue overflows
616 connections established (including accepts)
911 connections closed (including 41 drops)
    346 connections updated cached RTT on close
    346 connections updated cached RTT variance on close
    200 connections updated cached ssthresh on close
23 embryonic connections dropped
298155 segments updated rtt(of 287216 attempts)

```

```

1163 retransmit timeouts
    27 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
5 keepalive timeouts
    5 keepalive probes sent
    0 connections dropped by keepalive
69922 correct ACK header predictions
34993 correct data packet header predictions
233 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    233 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
23 SACK recovery episodes
68 segment retransmits in SACK recovery episodes
71542 byte retransmits in SACK recovery episodes
158 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
259 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

```

1cc0-re0:

 Tcp:

```

346 packets sent
    222 data packets (22894 bytes)
    0 data packets retransmitted (0 bytes)
    0 resends initiated by MTU discovery
    80 ack only packets (12 packets delayed)
    0 URG only packets
    0 window probe packets
    5 window update packets
    42 control packets
358 packets received
    268 acks(for 22939 bytes)
    9 duplicate acks
    0 acks for unsent data
    203 packets received in-sequence(33820 bytes)
    0 completely duplicate packets(0 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)

```

```

        0 packets of data after window(0 bytes)
        0 window probes
        6 window update packets
        0 packets received after close
        0 discarded for bad checksums
        0 discarded for bad header offset fields
        0 discarded because packet too short
13 connection requests
18 connection accepts
0 bad connection attempts
0 listen queue overflows
31 connections established (including accepts)
35 connections closed (including 2 drops)
    3 connections updated cached RTT on close
    3 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
268 segments updated rtt(of 247 attempts)
0 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
0 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
0 correct ACK header predictions
42 correct data packet header predictions
18 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    18 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 SACK recovery episodes
0 segment retransmits in SACK recovery episodes
0 byte retransmits in SACK recovery episodes
0 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
5 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

```

1cc1-re0:

 Tcp:


```

348 packets sent
    223 data packets (22895 bytes)
    0 data packets retransmitted (0 bytes)
    0 resends initiated by MTU discovery
    81 ack only packets (13 packets delayed)
    0 URG only packets
    0 window probe packets
    5 window update packets
    42 control packets
360 packets received
    269 acks(for 22940 bytes)
    9 duplicate acks
    0 acks for unsent data
    203 packets received in-sequence(33820 bytes)
    0 completely duplicate packets(0 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    6 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
13 connection requests
18 connection accepts
0 bad connection attempts
0 listen queue overflows
31 connections established (including accepts)
36 connections closed (including 2 drops)
    3 connections updated cached RTT on close
    3 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
269 segments updated rtt(of 248 attempts)
0 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
0 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
0 correct ACK header predictions
43 correct data packet header predictions
18 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    18 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 SACK recovery episodes

```

```

0 segment retransmits in SACK recovery episodes
0 byte retransmits in SACK recovery episodes
0 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
5 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

```

lcc2-re0:

 Tcp:

```

405 packets sent
    271 data packets (23926 bytes)
    0 data packets retransmitted (0 bytes)
    0 resends initiated by MTU discovery
    86 ack only packets (13 packets delayed)
    0 URG only packets
    0 window probe packets
    5 window update packets
    46 control packets
418 packets received
    321 acks(for 23975 bytes)
    9 duplicate acks
    0 acks for unsent data
    234 packets received in-sequence(34403 bytes)
    0 completely duplicate packets(0 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    7 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
15 connection requests
19 connection accepts
0 bad connection attempts
0 listen queue overflows
34 connections established (including accepts)
39 connections closed (including 2 drops)
    4 connections updated cached RTT on close
    4 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
321 segments updated rtt(of 299 attempts)
0 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
0 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive

```

```

0 correct ACK header predictions
48 correct data packet header predictions
19 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    19 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 SACK recovery episodes
0 segment retransmits in SACK recovery episodes
0 byte retransmits in SACK recovery episodes
0 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
5 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

```

1cc3-re0:

Tcp:

```

346 packets sent
    221 data packets (22895 bytes)
    0 data packets retransmitted (0 bytes)
    0 resends initiated by MTU discovery
    81 ack only packets (13 packets delayed)
    0 URG only packets
    0 window probe packets
    5 window update packets
    42 control packets
360 packets received
    267 acks(for 22940 bytes)
    9 duplicate acks
    0 acks for unsent data
    203 packets received in-sequence(33820 bytes)
    0 completely duplicate packets(0 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    6 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short

```

```
13 connection requests
18 connection accepts
0 bad connection attempts
0 listen queue overflows
31 connections established (including accepts)
35 connections closed (including 2 drops)
    3 connections updated cached RTT on close
    3 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
267 segments updated rtt(of 246 attempts)
0 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
0 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
0 correct ACK header predictions
43 correct data packet header predictions
18 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    18 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 SACK recovery episodes
0 segment retransmits in SACK recovery episodes
0 byte retransmits in SACK recovery episodes
0 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
5 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing
```

```
show system statistics user@switch> show system statistics
(QFX Series) Tcp:
571779 packets sent
21517 data packets (1797102 bytes)
2 data packets retransmitted (20 bytes)
0 resends initiated by MTU discovery
3708 ack only packets (531 packets delayed)
0 URG only packets
1 window probe packets
1 window update packets
```

1093063 control packets
1132541 packets received
20961 acks(for 1796102 bytes)
5861 duplicate acks
0 acks for unsent data
19556 packets received in-sequence(232079 bytes)
3018 completely duplicate packets(0 bytes)
0 old duplicate packets
4 packets with some duplicate data(4 bytes duped)
2 out-of-order packets(2 bytes)
0 packets of data after window(0 bytes)
0 window probes
39 window update packets
0 packets received after close
0 discarded for bad checksums
0 discarded for bad header offset fields
0 discarded because packet too short
546519 connection requests
78 connection accepts
0 bad connection attempts
0 listen queue overflows
100 connections established (including accepts)
546596 connections closed (including 6 drops)
47 connections updated cached RTT on close
47 connections updated cached RTT variance on close
0 connections updated cached ssthresh on close
546497 embryonic connections dropped
20453 segments updated rtt(of 566914 attempts)
2 retransmit timeouts
0 connections dropped by retransmit timeout
0 persist timeouts
0 connections dropped by persist timeout
3028 keepalive timeouts
3027 keepalive probes sent
1 connections dropped by keepalive
7515 correct ACK header predictions
12258 correct data packet header predictions
78 syncache entries added
0 retransmitted
0 dupsyn
4 dropped
78 completed
0 bucket overflow
0 cache overflow
0 reset
0 stale
0 aborted
0 badack
0 unreach
0 zone failures
0 cookies sent
0 cookies received
1 SACK recovery episodes
1 segment retransmits in SACK recovery episodes
1 byte retransmits in SACK recovery episodes
71 SACK options (SACK blocks) received
1 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address

```
0 out-of-sequence segment drops due to insufficient memory
546544 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing
udp:
147 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
9 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
0 not for hashed pcb
138 delivered
0 datagrams output
ip:
73704 total packets received
0 bad header checksums
0 with size smaller than minimum
0 with data size < data length
0 with header length < data size
0 with data length < header length
0 with incorrect version number
0 packets destined to dead next hop
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
1133057 packets for this host
0 packets for unknown/unsupported protocol
40146 packets forwarded
0 packets not forwardable
40146 redirects sent
1121700 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
0 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
0 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent
```

```
0 outgoing TTPoIP packets dropped
icmp:
0 drops due to rate limit
9 calls to icmp_error
0 errors not generated because old message was icmp
Output histogram:
295 echo reply
9 destination unreachable
0 messages with bad code fields
0 messages less than the minimum length
0 messages with bad checksum
0 messages with bad source address
0 messages with bad length
0 echo drops with broadcast or multicast destination address
0 timestamp drops with broadcast or multicast destination address
Input histogram:
295 echo
295 message responses generated
igmp:
0 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid fields
0 membership reports received
0 membership reports received with invalid fields
0 membership reports received for groups to which we belong
0 Membership reports sent
raw_if:
0 RAW packets transmitted
0 PPPOE packets transmitted
0 ISDN packets transmitted
0 DIALER packets transmitted
0 PPP packets transmitted to pppd
0 PPP packets transmitted to jppd
0 IGMPv2 packets transmitted
13 output drops due to tx error
0 MPU packets transmitted
0 PPPOE packets received
0 ISDN packets received
0 DIALER packets received
0 PPP packets received from pppd
0 MPU packets received
0 PPP packets received from jppd
0 IGMPv2 packets received
0 Input drops due to bogus protocol
0 input drops due to no mbufs available
0 input drops due to no space in socket
0 input drops due to no socket
arp:
186413 datagrams received
88 ARP requests received
88 ARP replies received
0 resolution request received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requests not proxied
0 restricted proxy requests not proxied
0 datagrams with bogus interface
0 datagrams with incorrect length
```

```
0 datagrams for non-IP protocol
0 datagrams with unsupported op code
0 datagrams with bad protocol address length
0 datagrams with bad hardware address length
0 datagrams with multicast source address
0 datagrams with multicast source address
0 datagrams with my own hardware address
164 datagrams for an address not on the interface
0 datagrams with a broadcast source address
0 datagrams with source address duplicate to mine
186065 datagrams which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
50 ARP requests sent
88 ARP replies sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor
ip6:
0 total packets received
0 packets with size smaller than minimum
0 packets with data size < data length
0 packets with bad options
0 packets with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too many headers
0 failures of source address selection
0 forward cache hit
0 forward cache miss
0 Packets destined to dead next hop
0 option packets dropped due to rate limit
0 Packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f
icmp6:
0 Calls to icmp_error
0 Errors not generated because old message was icmp error
```



```

0 Errors not generated because rate limitation
0 Messages with bad code fields
0 Messages < minimum length
0 Bad checksums
0 Messages with bad length
0 No route
0 Administratively prohibited
0 Beyond scope
0 Address unreachable
0 Port unreachable
0 packet too big
0 Time exceed transit
0 Time exceed reassembly
0 Erroneous header field
0 Unrecognized next header
0 Unrecognized option
0 redirect
0 Unknown
0 Message responses generated
0 Messages with too many ND options
pfkey:
0 Requests sent from userland
0 Bytes sent from userland
histogram by message type:
0 reserved
0 dump
0 Messages with invalid length field
0 Messages with invalid version field
0 Messages with invalid message type field
0 Messages too short
0 Messages with memory allocation failure
0 Messages with duplicate extension
0 Messages with invalid extension type
0 Messages with invalid sa type
0 Messages with invalid address extension
0 Requests sent to userland
0 Bytes sent to userland
histogram by message type:
0 reserved
0 dump
0 Messages toward single socket
0 Messages toward all sockets
0 Messages toward registered sockets
0 Messages with memory allocation failure
c1n1:
0 Total packets received
0 Packets delivered
0 Too small packets
0 Packets with bad header length
0 Packets with bad checksum
0 Bad version packets
0 Unknown or unsupported protocol packets
0 Packets with bogus sdl size
0 No free memory in socket buffer
0 Send packets discarded
0 Sbappend failure
0 Mcopy failure
0 Address fields were not reasonable
0 Segment information forgotten
0 Forwarded packets
0 Total packets sent

```

```
0 Output packets discarded
0 Non-forwarded packets
0 Packets fragmented
0 Fragments sent
0 Fragments discarded
0 Fragments timed out
0 Fragmentation prohibited
0 Packets reconstructed
0 Packets destined to dead nexthop
0 Packets discarded due to no route
0 Error pdu rate drops
0 ER pdu generation failure
esis:
0 Total pkts received
0 Total packets consumed by protocol
0 Pdus received with bad checksum
0 Pdus received with bad version number
0 Pdus received with bad type field
0 Short pdus received
0 Pdus with bogus sdl size
0 Pdus with bad header length
0 Pdus with unknown or unsupported protocol
0 No free memory in socket buffer
0 Send packets discarded
0 Sbappend failure
0 Mcopy failure
0 ISO family not configured
tnp:
0 Unicast packets received
0 Broadcast packets received
0 Fragmented packets received
0 Hello packets dropped
0 Fragments dropped
0 Fragment reassembly queue flushes
0 Packets with tnp src address collision received
0 Hello packets received
0 Control packets received
0 Rdp packets received
0 Udp packets received
0 Tunnel packets received
0 Input packets discarded with no protocol
0 Packets of version unspecified received
0 Packets of version 1 received
0 Packets of version 2 received
0 Packets of version 3 received
0 Unicast packets sent
0 Broadcast packets sent
0 Fragmented packets sent
0 Hello packets dropped
0 Fragments dropped
0 Hello packets sent
0 Control packets sent
0 Rdp packets sent
0 Udp packets sent
0 Tunnel packets sent
0 Packets sent with unknown protocol
0 Packets of version unspecified sent
0 Packets of version 1 sent
0 Packets of version 2 sent
0 Packets of version 3 sent
rdp:
```

```

0 Input packets
0 Packets discarded for bad checksum
0 Packets discarded due to bad sequence number
0 Refused connections
0 Acks received
0 Packets dropped due to full socket buffers
0 Retransmits
0 Output packets
0 Acks sent
0 Connects
0 Closes
0 Keepalives received
0 Keepalives sent
tudp:
67 Datagrams received
0 Datagrams with incomplete header
0 Datagrams with bad data length field
0 Datagrams with bad checksum
0 Datagrams dropped due to no socket
0 Broadcast/multicast datagrams dropped due to no socket
0 Datagrams dropped due to full socket buffers
67 Delivered
68 Datagrams output
ttp:
0 Packets sent
0 Packets sent while unconnected
0 Packets sent while interface down
0 Packets sent couldn't get buffer
0 Packets sent couldn't find neighbor
0 L2 packets received
0 Unknown L3 packets received
0 IPv4 L3 packets received
0 MPLS L3 packets received
0 MPLS->IPv4 L3 packets received
0 IPv4->MPLS L3 packets received
0 IPv6 L3 packets received
0 ARP L3 packets received
0 CLNP L3 packets received
0 TNP L3 packets received
0 NULL L3 packets received
0 Cyclotron cycle L3 packets received
0 Cyclotron send L3 packets received
0 Packets received while unconnected
0 Packets received from unknown ifl
0 Input packets couldn't get buffer
0 Input packets with bad type
0 Input packets with discard type
0 Input packets for which rt lookup is bypassed
mpls:
0 Total MPLS packets received
0 Packets forwarded
0 Packets dropped
0 Packets with header too small
0 After tagging, packets can't fit link MTU
0 Packets with IPv4 explicit NULL tag
0 Packets with IPv4 explicit NULL cksum errors
0 Packets with router alert tag
0 LSP ping packets (ttl-expired/router alert)
0 Packets with ttl expired
0 Packets with tag encoding error
0 Packets discarded due to no route

```

```
0 Packets used first nexthop in ecmp unilist
vpls:
0 Total packets received
0 Packets with size smaller than minimum
0 Packets with incorrect version number
0 Packets for this host
0 Packets with no logical interface
0 Packets with no family
0 Packets with no route table
582 Copyright © 2010, Juniper Networks, Inc.
0 Packets with no auxiliary table
0 Packets with no corefacing entry
0 packets with no CE-facing entry
0 MAC route learning requests
0 MAC routes learnt
0 Requests to learn an existing route
0 Learning requests while learning disabled on interface
0 Learning requests over capacity
0 MAC routes moved
0 Requests to move static route
0 MAC route aging requests
0 MAC routes aged
0 Bogus address in aging requests
0 Requests to age static route
0 Requests to re-ageout aged route
0 Requests involving multiple peer FEs
0 Aging acks from PFE
0 Aging non-acks from PFE
0 Aging requests timed out waiting on FEs
0 Aging requests over max-rate
0 Errors finding peer FEs
0 Unsupported platform
0 Packets dropped due to no l3 route table
0 Packets dropped due to no local ifl
0 Packets punted
0 Packets dropped due to no socket
bridge:
Input:
0 packets received
0 packets forwarded
0 packets failed to forward
0 packets dropped
0 packets with vmember lookup failures
0 packets with vlan lookup failures
0 packets with stp state lookup failures
0 packets dropped due to stp blocked/listening
0 packets dropped due to stp learning
0 packets with src MAC learning failures
0 packets with input control processing failures
Forward:
0 packets sent successfully
0 packets with send failures
0 packets forwarded to l3 interface
0 packets with l3 send failures
0 packets discarded
0 packets with l2ifl store failures
0 packets with ifl mismatch failures
0 packets with packet duplication failures
0 packets with tag lookup failures
0 packets with no route for DMAC
0 packets with no route table
```

```
0 packets with no nexthop
0 packets with dead nexthop
0 packets with eof reached error
Learning:
0 MACs learned
0 packets sent to l3 interface
0 packets with l3 send failures
0 packets hit holdq while learning
0 MAC moves
0 packets discarded
0 packets with no route for SMAC
0 packets with no nexthop
0 packets with dead nexthop
0 packets dropped due to no resolve route
0 packets with l3 ifd lookup failures
0 packets with l3 ifl lookup failures
0 packets with l3 invalid rnh
0 packets with no route for SMAC in clone learning
0 packets with no nexthop in clone learning
0 packets with dead nexthop in clone learning
0 packets dropped due to no resolve nh in clone learning
Output:
0 packets forwarded
0 packets failed to forward
0 packets with vmember lookup failures
0 packets with vlan lookup failures
0 packets with input control processing failures
Send:
0 packets sent successfully
0 packets with send failures
0 packets dropped due to interface down
0 packets with dev output failures
0 blocked ifl discards
0 packets with tag lookup failures
0 packets with stp state lookup failures
0 packets with tag insertion failures
0 packets with tag removal failures
Flood:
0 packets flooded
0 flood failures
IGMP:
0 packets sent successfully
0 packets with send failures
0 packets forwarded
0 packets failed to forward
0 packets with mpull failures
0 packets with vmember lookup failures
0 packets with vlan lookup failures
0 packets with ifl lookup failures
0 packets with tag lookup failures
Misc:
0 packets with size smaller than minimum
0 packets with double tags
0 packets with no ifl
0 packets with no family
0 packets with no route table
```

show system statistics arp

Syntax	show system statistics arp
Syntax (EX Series Switch)	show system statistics arp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics arp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics arp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Address Resolution Protocol (ARP) statistics.
Options	<p>none—Display system-wide ARP statistics.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display ARP statistics for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system-wide ARP statistics for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system-wide ARP statistics for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router</p> <p>all-members—(EX4200 switches only) (Optional) Display ARP statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display ARP statistics for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display ARP statistics for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display ARP statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display ARP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display ARP statistics for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display ARP statistics for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics arp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics arp** on page 1015
show system statistics arp (EX Series Switch) on page 1015
show system statistics arp (TX Matrix Plus Router) on page 1016

Sample Output

```
show system statistics arp user@host> show system statistics arp
arp:
44134607 datagrams received
2 ARP requests received
2026 ARP replies received
3152 resolution requests received
0 unrestricted proxy requests
0 received proxy requests
0 proxy requests not proxied
0 with bogus interface
787 with incorrect length
712 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
7603 with multicast target address
0 with my own hardware address
14218490 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
29905774 which were not for me
0 packets discarded waiting for resolution
6 packets sent after waiting for resolution
17790 ARP requests sent
2 ARP replies sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
```

```
show system statistics arp (EX Series Switch) user@host> show system statistics arp
arp:
186423 datagrams received
88 ARP requests received
88 ARP replies received
0 resolution request received
```

```

0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requests not proxied
0 restricted proxy requests not proxied
0 datagrams with bogus interface
0 datagrams with incorrect length
0 datagrams for non-IP protocol
0 datagrams with unsupported op code
0 datagrams with bad protocol address length
0 datagrams with bad hardware address length
0 datagrams with multicast source address
0 datagrams with multicast source address
0 datagrams with my own hardware address
164 datagrams for an address not on the interface
0 datagrams with a broadcast source address
0 datagrams with source address duplicate to mine
186075 datagrams which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
50 ARP requests sent
88 ARP replies sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor

```

```

show system statistics arp (TX Matrix Plus
Router)

```

```

user@host> show system statistics arp

```

```

sfc0-re0:

```

```

-----
arp:

```

```

487 datagrams received
8 ARP requests received
438 ARP replys received
438 resolution requests received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requestss not proxied
0 restricted-proxy requestss not proxied
0 with bogus interface
0 with incorrect length
0 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
0 with multicast target address
0 with my own hardware address
0 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
41 which were not for me
0 packets discarded waiting for resolution
438 packets sent after waiting for resolution
1282 ARP requests sent

```



```

8 ARP replys sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor

```

lcc0-re0:

arp:

```

19 datagrams received
0 ARP requests received
1 ARP reply received
0 resolution requests received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requestss not proxied
0 restricted-proxy requestss not proxied
0 with bogus interface
0 with incorrect length
0 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
0 with multicast target address
0 with my own hardware address
0 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
18 which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
8 ARP requests sent
0 ARP replys sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor

```

lcc1-re0:

arp:

```

17 datagrams received
0 ARP requests received
1 ARP reply received
0 resolution requests received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requestss not proxied

```

```
0 restricted-proxy requestss not proxied
0 with bogus interface
0 with incorrect length
0 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
0 with multicast target address
0 with my own hardware address
0 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
16 which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
9 ARP requests sent
0 ARP replys sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor
```

lcc2-re0:

arp:

```
18 datagrams received
1 ARP request received
1 ARP reply received
0 resolution requests received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requestss not proxied
0 restricted-proxy requestss not proxied
0 with bogus interface
0 with incorrect length
0 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
0 with multicast target address
0 with my own hardware address
0 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
16 which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
9 ARP requests sent
1 ARP reply sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
```

```

0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor

```

```
lcc3-re0:
```

```
-----
arp:
```

```

13 datagrams received
0 ARP requests received
1 ARP reply received
0 resolution requests received
0 unrestricted proxy requests
0 restricted proxy requests
0 received proxy requests
0 proxy requestss not proxied
0 restricted-proxy requestss not proxied
0 with bogus interface
0 with incorrect length
0 for non-IP protocol
0 with unsupported op code
0 with bad protocol address length
0 with bad hardware address length
0 with multicast source address
0 with multicast target address
0 with my own hardware address
0 for an address not on the interface
0 with a broadcast source address
0 with source address duplicate to mine
12 which were not for me
0 packets discarded waiting for resolution
0 packets sent after waiting for resolution
8 ARP requests sent
0 ARP replys sent
0 requests for memory denied
0 requests dropped on entry
0 requests dropped during retry
0 requests dropped due to interface deletion
0 requests on unnumbered interfaces
0 new requests on unnumbered interfaces
0 replies for from unnumbered interfaces
0 requests on unnumbered interface with non-subnetted donor
0 replies from unnumbered interface with non-subnetted donor

```

show system statistics clns

Syntax	show system statistics clns
Syntax (TX Matrix Router)	show system statistics clns <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics clns <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Connectionless Network Service (CLNS) statistics.
Options	<p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for CLNS for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for CLNS for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for CLNS for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for CLNS for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for CLNS for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for CLNS for the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display system statistics for CLNS for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Additional Information	By default, when you issue the show system statistics clns command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.
Required Privilege Level	view
List of Sample Output	show system statistics clns on page 1021 show system statistics clns (EX Series Switch) on page 1021

show system statistics clns (TX Matrix Plus Router) on page 1022**Sample Output**

```

show system statistics clns user@host> show system statistics clns
                               cln1:
                                0 total packets received
                                0 packets delivered
                                0 too small
                                0 bad header length
                                0 bad checksum
                                0 bad version
                                0 unknown or unsupported protocol
                                0 bogus sdl size
                                0 no free memory in socket buffer
                                0 send packets discarded
                                0 sbappend failure
                                0 mcopy failure
                                0 address fields were not reasonable
                                0 segment information forgotten
                                0 forwarded packets
                                0 total packets sent
                                0 output packets discarded
                                0 non-forwarded packets
                                0 packets fragmented
                                0 fragments sent
                                0 fragments discarded
                                0 fragments timed out
                                0 fragmentation prohibited
                                0 packets reconstructed
                                0 packets destined to dead nexthop
                                0 packets discarded due to no route
                                0 Error pdu rate drops
                                0 ER pdu generation failure

show system statistics clns (EX Series Switch) user@host> show system statistics clns
                               cln1:
                                0 Total packets received
                                0 Packets delivered
                                0 Too small packets
                                0 Packets with bad header length
                                0 Packets with bad checksum
                                0 Bad version packets
                                0 Unknown or unsupported protocol packets
                                0 Packets with bogus sdl size
                                0 No free memory in socket buffer
                                0 Send packets discarded
                                0 Sbappend failure
                                0 Mcopy failure
                                0 Address fields were not reasonable
                                0 Segment information forgotten
                                0 Forwarded packets
                                0 Total packets sent
                                0 Output packets discarded
                                0 Non-forwarded packets
                                0 Packets fragmented
                                0 Fragments sent
                                0 Fragments discarded
                                0 Fragments timed out
                                0 Fragmentation prohibited
                                0 Packets reconstructed

```

```

0 Packets destined to dead nexthop
0 Packets discarded due to no route
0 Error pdu rate drops
0 ER pdu generation failure

```

show system statistics user@host> **show system statistics clns**

clns (TX Matrix Plus

sfc0-re0:

Router)

c1n1:

```

0 total packets received
0 packets delivered
0 too small
0 bad header length
0 bad checksum
0 bad version
0 unknown or unsupport protocol
0 bogus sdl size
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 address fields were not reasonable
0 segment information forgotten
0 forwarded packets
0 total packets sent
0 output packets discarded
0 non-forwarded packets
0 packets fragmented
0 fragments sent
0 fragments discarded
0 fragments timed out
0 fragmentation prohibited
0 packets reconstructed
0 packets destined to dead nexthop
0 packets discarded due to no route
0 Error pdu rate drops
0 ER pdu generation failure

```

lcc0-re1:

c1n1:

```

0 total packets received
0 packets delivered
0 too small
0 bad header length
0 bad checksum
0 bad version
0 unknown or unsupport protocol
0 bogus sdl size
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 address fields were not reasonable
0 segment information forgotten
0 forwarded packets
0 total packets sent
0 output packets discarded
0 non-forwarded packets
0 packets fragmented
0 fragments sent

```

```

0 fragments discarded
0 fragments timed out
0 fragmentation prohibited
0 packets reconstructed
0 packets destined to dead nexthop
0 packets discarded due to no route
0 Error pdu rate drops
0 ER pdu generation failure

```

```
lcc1-re1:
```

```
-----
c1n1:
```

```

0 total packets received
0 packets delivered
0 too small
0 bad header length
0 bad checksum
0 bad version
0 unknown or unsupport protocol
0 bogus sdl size
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 address fields were not reasonable
0 segment information forgotten
0 forwarded packets
0 total packets sent
0 output packets discarded
0 non-forwarded packets
0 packets fragmented
0 fragments sent
0 fragments discarded
0 fragments timed out
0 fragmentation prohibited
0 packets reconstructed
0 packets destined to dead nexthop
0 packets discarded due to no route
0 Error pdu rate drops
0 ER pdu generation failure

```

```
lcc2-re1:
```

```
-----
c1n1:
```

```

0 total packets received
0 packets delivered
0 too small
0 bad header length
0 bad checksum
0 bad version
0 unknown or unsupport protocol
0 bogus sdl size
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 address fields were not reasonable
0 segment information forgotten
0 forwarded packets
0 total packets sent
0 output packets discarded

```

- 0 non-forwarded packets
- 0 packets fragmented
- 0 fragments sent
- 0 fragments discarded
- 0 fragments timed out
- 0 fragmentation prohibited
- 0 packets reconstructed
- 0 packets destined to dead nexthop
- 0 packets discarded due to no route
- 0 Error pdu rate drops
- 0 ER pdu generation failure

lcc3-re1:

c1n1:

- 0 total packets received
- 0 packets delivered
- 0 too small
- 0 bad header length
- 0 bad checksum
- 0 bad version
- 0 unknown or unsupport protocol
- 0 bogus sdl size
- 0 no free memory in socket buffer
- 0 send packets discarded
- 0 sbappend failure
- 0 mcopy failure
- 0 address fields were not reasonable
- 0 segment information forgotten
- 0 forwarded packets
- 0 total packets sent
- 0 output packets discarded
- 0 non-forwarded packets
- 0 packets fragmented
- 0 fragments sent
- 0 fragments discarded
- 0 fragments timed out
- 0 fragmentation prohibited
- 0 packets reconstructed
- 0 packets destined to dead nexthop
- 0 packets discarded due to no route
- 0 Error pdu rate drops
- 0 ER pdu generation failure

show system statistics esis

Syntax	show system statistics esis
Syntax (EX Series Switch)	show system statistics esis <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics esis <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics esis <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide End System-to-Intermediate System (ES-IS) statistics.
Options	<p>none—Display system statistics for ES-IS.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for ES-IS for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for ES-IS for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for ES-IS for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display ES-IS statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for ES-IS for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for ES-IS for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display ES-IS statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display ES-IS statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for ES-IS for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for ES-IS for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics esis** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics esis** on page 1026
show system statistics esis (EX Series Switch) on page 1026
show system statistics esis (TX Matrix Plus Router) on page 1027

Sample Output

```
show system statistics esis  user@host> show system statistics esis
                               esis:
                               0 total pkts received
                               0 total packets consumed by protocol
                               0 pdus received with bad checksum
                               0 pdus received with bad version number
                               0 pdus received with bad type field
                               0 short pdus received
                               0 bogus sdl size
                               0 bad header length
                               0 unknown or unsupported protocol
                               0 no free memory in socket buffer
                               0 send packets discarded
                               0 sbappend failure
                               0 mcopy failure
                               0 ISO family not configured
```

```
show system statistics esis (EX Series Switch)  user@host> show system statistics esis
                                                  esis:
                                                  0 Total pkts received
                                                  0 Total packets consumed by protocol
                                                  0 Pdus received with bad checksum
                                                  0 Pdus received with bad version number
                                                  0 Pdus received with bad type field
                                                  0 Short pdus received
                                                  0 Pdus withbogus sdl size
                                                  0 Pdus with bad header length
                                                  0 Pdus with unknown or unsupport protocol
                                                  0 No free memory in socket buffer
                                                  0 Send packets discarded
                                                  0 Sbappend failure
                                                  0 Mcopy failure
                                                  0 ISO family not configured
```

show system statistics
esis (TX Matrix Plus
Router)

user@host> show system statistics esis
 sfc0-re0:

```
-----
esis:
  0 total pkts received
  0 total packets consumed by protocol
  0 pdus received with bad checksum
  0 pdus received with bad version number
  0 pdus received with bad type field
  0 short pdus received
  0 bogus sdl size
  0 bad header length
  0 unknown or unsupport protocol
  0 no free memory in socket buffer
  0 send packets discarded
  0 sbappend failure
  0 mcopy failure
  0 ISO family not configured
```

1cc0-re0:

```
-----
esis:
  0 total pkts received
  0 total packets consumed by protocol
  0 pdus received with bad checksum
  0 pdus received with bad version number
  0 pdus received with bad type field
  0 short pdus received
  0 bogus sdl size
  0 bad header length
  0 unknown or unsupport protocol
  0 no free memory in socket buffer
  0 send packets discarded
  0 sbappend failure
  0 mcopy failure
  0 ISO family not configured
```

1cc1-re0:

```
-----
esis:
  0 total pkts received
  0 total packets consumed by protocol
  0 pdus received with bad checksum
  0 pdus received with bad version number
  0 pdus received with bad type field
  0 short pdus received
  0 bogus sdl size
  0 bad header length
  0 unknown or unsupport protocol
  0 no free memory in socket buffer
  0 send packets discarded
  0 sbappend failure
  0 mcopy failure
  0 ISO family not configured
```

1cc2-re0:

```
-----
esis:
  0 total pkts received
  0 total packets consumed by protocol
  0 pdus received with bad checksum
```

```

0 pdus received with bad version number
0 pdus received with bad type field
0 short pdus received
0 bogus sdl size
0 bad header length
0 unknown or unsupported protocol
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 ISO family not configured

```

lcc3-re0:

esis:

```

0 total pkts received
0 total packets consumed by protocol
0 pdus received with bad checksum
0 pdus received with bad version number
0 pdus received with bad type field
0 short pdus received
0 bogus sdl size
0 bad header length
0 unknown or unsupported protocol
0 no free memory in socket buffer
0 send packets discarded
0 sbappend failure
0 mcopy failure
0 ISO family not configured

```

show system statistics icmp

Syntax	show system statistics icmp
Syntax (EX Series Switch)	show system statistics icmp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics icmp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics icmp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Internet Control Message Protocol (ICMP) statistics.
Options	<p>none—Display system statistics for ICMP.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for ICMP for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for ICMP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for ICMP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display ICMP statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for ICMP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for ICMP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display ICMP statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display ICMP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for ICMP for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for ICMP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics icmp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on the TX Matrix router) or T1600 (in a routing matrix based on the TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics icmp on page 1030**
show system statistics icmp (EX Series Switch) on page 1030
show system statistics icmp (TX Matrix Plus Router) on page 1031

Sample Output

```
show system statistics icmp user@host> show system statistics icmp
icmp:
    0 drops due to rate limit
    0 calls to icmp_error
    0 errors not generated because old message was icmp
    Output histogram:
        echo reply: 75
    0 messages with bad code fields
    0 messages less than the minimum length
    0 messages with bad checksum
    0 messages with bad source address
    0 messages with bad length
    0 echo drops with broadcast or multicast dest in at on address
    0 timestamp drops with broadcast or multicast destination address
    Input histogram:
        echo: 75
        router advertisement: 130
    75 message responses generated
```

```
show system statistics icmp (EX Series Switch) user@host> show system statistics icmp
icmp:
    0 drops due to rate limit
    12 calls to icmp_error
    0 errors not generated because old message was icmp
    Output histogram:
        297 echo reply
        12 destination unreachable
    0 messages with bad code fields
    0 messages less than the minimum length
    0 messages with bad checksum
    0 messages with bad source address
    0 messages with bad length
    0 echo drops with broadcast or multicast destination address
    0 timestamp drops with broadcast or multicast destination address
    Input histogram:
```

297 echo
297 message responses generated

show system statistics
icmp (TX Matrix Plus
Router)

user@host> show system statistics icmp
sfc0-re0:

```
-----
icmp:
    0 drops due to rate limit
    0 calls to icmp_error
    0 errors not generated because old message was icmp
    Output histogram:
        echo reply: 21
    0 messages with bad code fields
    0 messages less than the minimum length
    0 messages with bad checksum
    0 messages with bad source address
    0 messages with bad length
    0 echo drops with broadcast or multicast destination address
    0 timestamp drops with broadcast or multicast destination address
    Input histogram:
        echo: 21
    21 message responses generated
```

lcc0-re0:

```
-----
icmp:
    0 drops due to rate limit
    1 call to icmp_error
    0 errors not generated because old message was icmp
    Output histogram:
        echo reply: 24
        destination unreachable: 1
    0 messages with bad code fields
    0 messages less than the minimum length
    0 messages with bad checksum
    0 messages with bad source address
    0 messages with bad length
    0 echo drops with broadcast or multicast destination address
    0 timestamp drops with broadcast or multicast destination address
    Input histogram:
        echo: 24
    24 message responses generated
```

lcc1-re0:

```
-----
icmp:
    0 drops due to rate limit
    0 calls to icmp_error
    0 errors not generated because old message was icmp
    Output histogram:
        echo reply: 23
    0 messages with bad code fields
    0 messages less than the minimum length
    0 messages with bad checksum
    0 messages with bad source address
    0 messages with bad length
    0 echo drops with broadcast or multicast destination address
    0 timestamp drops with broadcast or multicast destination address
    Input histogram:
        echo: 23
    23 message responses generated
```

lcc2-re0:

icmp:
 0 drops due to rate limit
 0 calls to icmp_error
 0 errors not generated because old message was icmp
 Output histogram:
 echo reply: 22
 0 messages with bad code fields
 0 messages less than the minimum length
 0 messages with bad checksum
 0 messages with bad source address
 0 messages with bad length
 0 echo drops with broadcast or multicast destination address
 0 timestamp drops with broadcast or multicast destination address
 Input histogram:
 echo: 22
 22 message responses generated

lcc3-re0:

icmp:
 0 drops due to rate limit
 0 calls to icmp_error
 0 errors not generated because old message was icmp
 Output histogram:
 echo reply: 22
 0 messages with bad code fields
 0 messages less than the minimum length
 0 messages with bad checksum
 0 messages with bad source address
 0 messages with bad length
 0 echo drops with broadcast or multicast destination address
 0 timestamp drops with broadcast or multicast destination address
 Input histogram:
 echo: 22
 22 message responses generated

show system statistics icmp6

Syntax	show system statistics icmp6
Syntax (EX Series Switch)	show system statistics icmp6 <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics icmp6 <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics icmp6 <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Internet Control Message Protocol for IPv6 (ICMPv6) statistics.
Options	<p>none—Display system statistics for ICMPv6.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for ICMPv6 for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for ICMPv6 for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for ICMPv6 for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display ICMPv6 statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for ICMPv6 for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for ICMPv6 for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display ICMPv6 statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display ICMPv6 statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for ICMPv6 for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for ICMPv6 for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics icmp6** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics icmp6** on page 1034
show system statistics icmp6 (EX Series Switch) on page 1034
show system statistics icmp6 (TX Matrix Plus Router) on page 1035

Sample Output

```
show system statistics icmp6 user@host> show system statistics icmp6
icmp6:
0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation
0 messages with bad code fields
0 messages < minimum length
0 bad checksums
0 messages with bad length
Histogram of error messages to be generated:
0 no route
0 administratively prohibited
0 beyond scope
0 address unreachable
0 port unreachable
0 packet too big
0 time exceed transit
0 time exceed reassembly
0 erroneous header field
0 unrecognized next header
0 unrecognized option
0 redirect
0 unknown
0 message responses generated
0 messages with too many ND options
```

```
show system statistics icmp6 (EX Series Switch) user@host> show system statistics icmp6
icmp6:
0 Calls to icmp_error
0 Errors not generated because old message was icmp error
0 Errors not generated because rate limitation
0 Messages with bad code fields
0 Messages < minimum length
0 Bad checksums
0 Messages with bad length
0 No route
```

```

0 Administratively prohibited
0 Beyond scope
0 Address unreachable
0 Port unreachable
0 packet too big
0 Time exceed transit
0 Time exceed reassembly
0 Erroneous header field
0 Unrecognized next header
0 Unrecognized option
0 redirect
0 Unknown
0 Message responses generated
0 Messages with too many ND options

```

Sample Output

```

show system statistics icmp6
icmp6 (TX Matrix Plus Router)
user@host> show system statistics icmp6
sfc0-re0:
-----
icmp6:
0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation
Output histogram:
    neighbor solicitation: 12
    neighbor advertisement: 4
0 messages with bad code fields
0 messages < minimum length
0 bad checksums
0 messages with bad length
Histogram of error messages to be generated:
    0 no route
    0 administratively prohibited
    0 beyond scope
    0 address unreachable
    0 port unreachable
    0 packet too big
    0 time exceed transit
    0 time exceed reassembly
    0 erroneous header field
    0 unrecognized next header
    0 unrecognized option
    0 redirect
    0 unknown
0 message responses generated
0 messages with too many ND options

lcc0-re0:
-----
icmp6:
0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation
Output histogram:
    neighbor solicitation: 12
    neighbor advertisement: 4
0 messages with bad code fields
0 messages < minimum length
0 bad checksums
0 messages with bad length

```

Histogram of error messages to be generated:

- 0 no route
- 0 administratively prohibited
- 0 beyond scope
- 0 address unreachable
- 0 port unreachable
- 0 packet too big
- 0 time exceed transit
- 0 time exceed reassembly
- 0 erroneous header field
- 0 unrecognized next header
- 0 unrecognized option
- 0 redirect
- 0 unknown

0 message responses generated
0 messages with too many ND options

lcc1-re0:

icmp6:

0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation
Output histogram:
 neighbor solicitation: 12
 neighbor advertisement: 4
0 messages with bad code fields
0 messages < minimum length
0 bad checksums
0 messages with bad length
Input histogram:
 neighbor advertisement: 2
Histogram of error messages to be generated:
 0 no route
 0 administratively prohibited
 0 beyond scope
 0 address unreachable
 0 port unreachable
 0 packet too big
 0 time exceed transit
 0 time exceed reassembly
 0 erroneous header field
 0 unrecognized next header
 0 unrecognized option
 0 redirect
 0 unknown
0 message responses generated
0 messages with too many ND options

lcc2-re0:

icmp6:

0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation
Output histogram:
 neighbor solicitation: 12
 neighbor advertisement: 4
0 messages with bad code fields
0 messages < minimum length
0 bad checksums

```

0 messages with bad length
Input histogram:
  neighbor advertisement: 2
Histogram of error messages to be generated:
  0 no route
  0 administratively prohibited
  0 beyond scope
  0 address unreachable
  0 port unreachable
  0 packet too big
  0 time exceed transit
  0 time exceed reassembly
  0 erroneous header field
  0 unrecognized next header
  0 unrecognized option
  0 redirect
  0 unknown
0 message responses generated
0 messages with too many ND options

```

lcc3-re0:

icmp6:

```

0 calls to icmp_error
0 errors not generated because old message was icmp error or so
0 errors not generated because rate limitation
Output histogram:
  neighbor solicitation: 12
  neighbor advertisement: 4
0 messages with bad code fields
0 messages < minimum length
0 bad checksums
0 messages with bad length
Input histogram:
  neighbor advertisement: 2
Histogram of error messages to be generated:
  0 no route
  0 administratively prohibited
  0 beyond scope
  0 address unreachable
  0 port unreachable
  0 packet too big
  0 time exceed transit
  0 time exceed reassembly
  0 erroneous header field
  0 unrecognized next header
  0 unrecognized option
  0 redirect
  0 unknown
0 message responses generated
0 messages with too many ND options

```

show system statistics igmp

Syntax	show system statistics igmp
Syntax (EX Series Switch)	show system statistics igmp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics igmp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics igmp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Internet Group Management Protocol (IGMP) statistics.
Options	<p>none—Display system statistics for IGMP.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for IGMP for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for IGMP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for IGMP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display IGMP statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for IGMP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for IGMP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display IGMP statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display IGMP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for IGMP for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for IGMP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics igmp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics igmp on page 1039**
show system statistics igmp (EX Series Switch) on page 1039
show system statistics igmp (TX Matrix Plus Router) on page 1039

Sample Output

```
show system statistics igmp  user@host> show system statistics igmp
                             igmp:
                                17178 messages received
                                0 messages received with too few bytes
                                0 messages received with bad checksum
                                0 membership queries received
                                0 membership queries received with invalid field(s)
                                0 membership reports received
                                0 membership reports received with invalid field(s)
                                0 membership reports received for groups to which we belong
                                0 membership reports sent
```

```
show system statistics igmp (EX Series Switch)  user@host> show system statistics igmp
                                                  igmp:
                                                    0 messages received
                                                    0 messages received with too few bytes
                                                    0 messages received with bad checksum
                                                    0 membership queries received
                                                    0 membership queries received with invalid fields
                                                    0 membership reports received
                                                    0 membership reports received with invalid fields
                                                    0 membership reports received for groups to which we belong
                                                    0 Membership reports sent
```

```
show system statistics igmp (TX Matrix Plus Router)  user@host> show system statistics igmp
sfc0-re0:
-----
igmp:
    0 messages received
    0 messages received with too few bytes
    0 messages received with bad checksum
    0 membership queries received
    0 membership queries received with invalid field(s)
    0 membership reports received
    0 membership reports received with invalid field(s)
```

```
0 membership reports received for groups to which we belong
0 membership reports sent
```

```
lcc0-re0:
```

```
-----
igmp:
```

```
0 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid field(s)
0 membership reports received
0 membership reports received with invalid field(s)
0 membership reports received for groups to which we belong
0 membership reports sent
```

```
lcc1-re0:
```

```
-----
igmp:
```

```
0 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid field(s)
0 membership reports received
0 membership reports received with invalid field(s)
0 membership reports received for groups to which we belong
0 membership reports sent
```

```
lcc2-re0:
```

```
-----
igmp:
```

```
0 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid field(s)
0 membership reports received
0 membership reports received with invalid field(s)
0 membership reports received for groups to which we belong
0 membership reports sent
```

```
lcc3-re0:
```

```
-----
igmp:
```

```
0 messages received
0 messages received with too few bytes
0 messages received with bad checksum
0 membership queries received
0 membership queries received with invalid field(s)
0 membership reports received
0 membership reports received with invalid field(s)
0 membership reports received for groups to which we belong
0 membership reports sent
```


show system statistics ip

Syntax	show system statistics ip
Syntax (EX Series Switch)	show system statistics ip <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics ip <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics ip <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide IPv4 statistics.
Options	<p>none—Display system statistics for IPv4.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for IPv4 for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for IPv4 for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for IPv4 for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display IPv4 statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for IPv4 for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for IPv4 for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display IPv4 statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display IPv4 statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for IPv4 for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for IPv4 for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics ip** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics ip** on page 1042
show system statistics ip (EX Series Switch) on page 1043
show system statistics ip (TX Matrix Plus Router) on page 1044

Sample Output

```
show system statistics ip user@host> show system statistics ip
ip:
    1752658 total packets received
    0 bad header checksums
    0 with size smaller than minimum
    0 with data size < data length
    0 with header length < data size
    0 with data length < header length
    0 with incorrect version number
    0 packets destined to dead next hop
    0 fragments received
    0 fragments dropped (dup or out of space)
    0 fragments dropped (queue overflow)
    0 fragments dropped after timeout
    0 fragments dropped due to over limit
    0 packets reassembled ok
    1709456 packets for this host
    10494 packets for unknown/unsupported protocol
    546 packets forwarded
    0 packets not forwardable
    546 redirects sent
    1340179 packets sent from this host
    0 packets sent with fabricated ip header
    0 output packets dropped due to no bufs
    0 output packets discarded due to no route
    0 output datagrams fragmented
    0 fragments created
    0 datagrams that can't be fragmented
    0 packets with bad options
    10494 packets with options handled without error
    0 strict source and record route options
    0 loose source and record route options
    0 record route options
    0 timestamp options
    0 timestamp and address options
    0 timestamp and prespecified address options
```

```

0 option packets dropped due to rate limit
10494 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent
0 outgoing TTPoIP packets dropped
0 raw packets dropped. no space in socket recv buffer

```

```

show system statistics ip (EX Series Switch) user@host> show system statistics ip
ip:

```

```

74121 total packets received
0 bad header checksums
0 with size smaller than minimum
0 with data size < data length
0 with header length < data size
0 with data length < header length
0 with incorrect version number
0 packets destined to dead next hop
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
1134061 packets for this host
0 packets for unknown/unsupported protocol
40177 packets forwarded
0 packets not forwardable
40177 redirects sent
1122558 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
0 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
0 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent
0 outgoing TTPoIP packets dropped

```

```

show system statistics ip (TX Matrix Plus Router)
user@host> show system statistics ip
sfc0-re0:
-----
ip:
  47695035 total packets received
  0 bad header checksums
  0 with size smaller than minimum
  0 with data size < data length
  0 with header length < data size
  0 with data length < header length
  0 with incorrect version number
  0 packets destined to dead next hop
  42350 fragments received
  0 fragments dropped (dup or out of space)
  0 fragments dropped (queue overflow)
  0 fragments dropped after timeout
  0 fragments dropped due to over limit
  21175 packets reassembled ok
  47674941 packets for this host
  146 packets for unknown/unsupported protocol
  0 packets forwarded
  0 packets not forwardable
  0 redirects sent
  61304579 packets sent from this host
  8496 packets sent with fabricated ip header
  0 output packets dropped due to no bufs
  0 output packets discarded due to no route
  6746344 output datagrams fragmented
  0 fragments created
  0 datagrams that can't be fragmented
  0 packets with bad options
  2400 packets with options handled without error
  0 strict source and record route options
  0 loose source and record route options
  0 record route options
  0 timestamp options
  0 timestamp and address options
  0 timestamp and prespecified address options
  0 option packets dropped due to rate limit
  2400 router alert options
  0 multicast packets dropped (no iflist)
  0 packets dropped (src and int don't match)
  0 transit re packets dropped on mgmt i/f
  0 packets used first nexthop in ecmp unilist
  12995412 incoming ttpoip packets received
  0 incoming ttpoip packets dropped
  16959177 outgoing TTPoIP packets sent
  0 outgoing TTPoIP packets dropped
  0 raw packets dropped. no space in socket recv buffer

lcc0-re0:
-----
ip:
  12990061 total packets received
  0 bad header checksums
  0 with size smaller than minimum
  0 with data size < data length
  0 with header length < data size
  0 with data length < header length
  0 with incorrect version number
  0 packets destined to dead next hop

```

```

0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
12989979 packets for this host
82 packets for unknown/unsupported protocol
0 packets forwarded
0 packets not forwardable
0 redirects sent
9318381 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
3440 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
82 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
82 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
548071 outgoing TTPoIP packets sent
0 outgoing TTPoIP packets dropped
0 raw packets dropped. no space in socket recv buffer

```

lcc1-re0:

ip:

```

12849723 total packets received
0 bad header checksums
0 with size smaller than minimum
0 with data size < data length
0 with header length < data size
0 with data length < header length
0 with incorrect version number
0 packets destined to dead next hop
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
12849641 packets for this host
82 packets for unknown/unsupported protocol
0 packets forwarded
0 packets not forwardable
0 redirects sent
7676351 packets sent from this host

```

```
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
82 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
82 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent
0 outgoing TTPoIP packets dropped
0 raw packets dropped. no space in socket recv buffer
```

lcc2-re0:

ip:

```
16926850 total packets received
0 bad header checksums
0 with size smaller than minimum
0 with data size < data length
0 with header length < data size
0 with data length < header length
0 with incorrect version number
0 packets destined to dead next hop
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
16926768 packets for this host
82 packets for unknown/unsupported protocol
0 packets forwarded
0 packets not forwardable
0 redirects sent
10039747 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
82 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
```

```

0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
82 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent
0 outgoing TTPoIP packets dropped
0 raw packets dropped. no space in socket recv buffer

```

lcc3-re0:

ip:

```

18025026 total packets received
0 bad header checksums
0 with size smaller than minimum
0 with data size < data length
0 with header length < data size
0 with data length < header length
0 with incorrect version number
0 packets destined to dead next hop
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped (queue overflow)
0 fragments dropped after timeout
0 fragments dropped due to over limit
0 packets reassembled ok
18024944 packets for this host
82 packets for unknown/unsupported protocol
0 packets forwarded
0 packets not forwardable
0 redirects sent
10456545 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets with bad options
82 packets with options handled without error
0 strict source and record route options
0 loose source and record route options
0 record route options
0 timestamp options
0 timestamp and address options
0 timestamp and prespecified address options
0 option packets dropped due to rate limit
82 router alert options
0 multicast packets dropped (no iflist)
0 packets dropped (src and int don't match)
0 transit re packets dropped on mgmt i/f
0 packets used first nexthop in ecmp unilist
0 incoming ttpoip packets received
0 incoming ttpoip packets dropped
0 outgoing TTPoIP packets sent

```

```
0 outgoing TTPoIP packets dropped
0 raw packets dropped. no space in socket recv buffer
```


show system statistics ip6

Syntax	show system statistics ip6
Syntax (EX Series Switch)	show system statistics ip6 <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics ip6 <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics ip <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide IPv6 statistics.
Options	<p>none—Display system statistics for IPv6.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for IPv6 for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for IPv6 for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for IPv6 for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display IPv6 statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for IPv6 for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for IPv6 for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display IPv6 statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display IPv6 statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for IPv6 for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for IPv6 for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics ip6** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics ip6 on page 1050**
show system statistics ip6 (EX Series Switch) on page 1051
show system statistics ip6 (TX Matrix Router) on page 1051

Sample Output

```
show system statistics ip6 user@host> show system statistics ip6
ip6:
    0 total packets received
    0 with size smaller than minimum
    0 with data size < data length
    0 with bad options
    0 with incorrect version number
    0 fragments received
    0 fragments dropped (dup or out of space)
    0 fragments dropped after timeout
    0 fragments that exceeded limit
    0 packets reassembled ok
    0 packets for this host
    0 packets forwarded
    0 packets not forwardable
    0 redirects sent
    0 packets sent from this host
    0 packets sent with fabricated ip header
    0 output packets dropped due to no bufs, etc.
    0 output packets discarded due to no route
    0 output datagrams fragmented
    0 fragments created
    0 datagrams that can't be fragmented
    0 packets that violated scope rules
    0 multicast packets which we don't join
Mbuf statistics:
    0 packets whose headers are not continuous
    0 tunneling packets that can't find gif
    0 packets discarded due to too many headers
    0 failures of source address selection
    0 forward cache hit
    0 forward cache miss
    0 packets destined to dead next hop
    0 option packets dropped due to rate limit
```

```

0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol

```

show system statistics user@host> **show system statistics ip6**
ip6 (EX Series Switch) ip6:

```

0 total packets received
0 packets with size smaller than minimum
0 packets with data size < data length
0 packets with bad options
0 packets with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too many headers
0 failures of source address selection
0 forward cache hit
0 forward cache miss
0 Packets destined to dead next hop
0 option packets dropped due to rate limit
0 Packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f

```

show system statistics user@host> **show system statistics ip6**
ip6 (TX Matrix Router) sfc0-re0:

```

-----
ip6:
0 total packets received
0 with size smaller than minimum
0 with data size < data length
0 with bad options
0 with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output packets discarded due to no route

```

```
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
Mbuf statistics:
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too may headers
0 failures of source address selection
source addresses on an outgoing I/F
    4 link-locals
source addresses of same scope
    4 link-locals
0 forward cache hit
0 forward cache miss
0 packets destined to dead next hop
0 option packets dropped due to rate limit
0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f
0 packet(null) used first nexthop in ecmp unilist
```

lcc0-re0:

ip6:

```
0 total packets received
0 with size smaller than minimum
0 with data size < data length
0 with bad options
0 with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
Mbuf statistics:
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too may headers
0 failures of source address selection
source addresses on an outgoing I/F
    4 link-locals
source addresses of same scope
    4 link-locals
0 forward cache hit
0 forward cache miss
0 packets destined to dead next hop
```

```

0 option packets dropped due to rate limit
0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f
0 packet(null) used first nexthop in ecmp unilist

```

lcc1-re0:

ip6:

```

2 total packets received
0 with size smaller than minimum
0 with data size < data length
0 with bad options
0 with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
Input histogram:
    ICMP6: 2
Mbuf statistics:
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too many headers
0 failures of source address selection
source addresses on an outgoing I/F
    4 link-locals
source addresses of same scope
    4 link-locals
0 forward cache hit
0 forward cache miss
0 packets destined to dead next hop
0 option packets dropped due to rate limit
0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f
0 packet(null) used first nexthop in ecmp unilist

```

lcc2-re0:

ip6:

```

2 total packets received
0 with size smaller than minimum
0 with data size < data length
0 with bad options
0 with incorrect version number
0 fragments received

```

```
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
0 packets that violated scope rules
0 multicast packets which we don't join
Input histogram:
    ICMP6: 2
Mbuf statistics:
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too many headers
0 failures of source address selection
source addresses on an outgoing I/F
    4 link-locals
source addresses of same scope
    4 link-locals
0 forward cache hit
0 forward cache miss
0 packets destined to dead next hop
0 option packets dropped due to rate limit
0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f
0 packet(null) used first nexthop in ecmp unilist
```

lcc3-re0:

ip6:

```
2 total packets received
0 with size smaller than minimum
0 with data size < data length
0 with bad options
0 with incorrect version number
0 fragments received
0 fragments dropped (dup or out of space)
0 fragments dropped after timeout
0 fragments that exceeded limit
0 packets reassembled ok
0 packets for this host
0 packets forwarded
0 packets not forwardable
0 redirects sent
0 packets sent from this host
0 packets sent with fabricated ip header
0 output packets dropped due to no bufs, etc.
0 output packets discarded due to no route
0 output datagrams fragmented
0 fragments created
0 datagrams that can't be fragmented
```

```
0 packets that violated scope rules
0 multicast packets which we don't join
Input histogram:
    ICMP6: 2
Mbuf statistics:
0 packets whose headers are not continuous
0 tunneling packets that can't find gif
0 packets discarded due to too many headers
0 failures of source address selection
source addresses on an outgoing I/F
    4 link-locals
source addresses of same scope
    4 link-locals
0 forward cache hit
0 forward cache miss
0 packets destined to dead next hop
0 option packets dropped due to rate limit
0 packets dropped (src and int don't match)
0 packets dropped due to bad protocol
0 transit re packet(null) dropped on mgmt i/f
0 packet(null) used first nexthop in ecmp unilist
```

show system statistics mpls

Syntax	show system statistics mpls
Syntax (EX Series Switch)	show system statistics mpls <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics mpls <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics mpls <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Multiprotocol Label Switching (MPLS) statistics.
Options	<p>none—Display system statistics for MPLS.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for MPLS for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for MPLS for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for MPLS for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display MPLS statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for MPLS for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for MPLS for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display MPLS statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display MPLS statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for MPLS for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for MPLS for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics mpls** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics mpls on page 1057**
show system statistics mpls (EX Series Switch) on page 1057
show system statistics mpls (TX Matrix Plus Router) on page 1057

Sample Output

```
show system statistics mpls  user@host> show system statistics mpls
                             mpls:
                                0 total mpls packets received
                                0 packets forwarded
                                0 packets dropped
                                0 with header too small
                                0 after tagging, can't fit link MTU
                                0 with IPv4 explicit NULL tag
                                0 with IPv4 explicit NULL cksum errors
                                0 with router alert tag
                                0 lsp ping packets (ttl-expired/router alert)
                                0 with ttl expired
                                0 with tag encoding error
                                0 packets discarded, no route
```

```
show system statistics mpls (EX Series Switch)  user@host> show system statistics mpls
                                                  mpls:
                                                    0 Total MPLS packets received
                                                    0 Packets forwarded
                                                    0 Packets dropped
                                                    0 Packets with header too small
                                                    0 After tagging, packets can't fit link MTU
                                                    0 Packets with IPv4 explicit NULL tag
                                                    0 Packets with IPv4 explicit NULL cksum errors
                                                    0 Packets with router alert tag
                                                    0 LSP ping packets (ttl-expired/router alert)
                                                    0 Packets with ttl expired
                                                    0 Packets with tag encoding error
                                                    0 Packets discarded due to no route
                                                    0 Packets used first nexthop in ecmp unilist
```

```
show system statistics mpls (TX Matrix Plus Router)  user@host> show system statistics mpls
sfc0-re0:
-----
mpls:
```

```
0 total mpls packets received
0 packets forwarded
0 packets dropped
0 with header too small
0 after tagging, can't fit link MTU
0 with IPv4 explicit NULL tag
0 with IPv4 explicit NULL cksum errors
0 with router alert tag
0 lsp ping packets (ttl-expired/router alert)
0 with ttl expired
0 with tag encoding error
0 packets discarded, no route
0 packets used first nexthop in ecmp unilist
```

lcc0-re0:

mpls:

```
0 total mpls packets received
0 packets forwarded
0 packets dropped
0 with header too small
0 after tagging, can't fit link MTU
0 with IPv4 explicit NULL tag
0 with IPv4 explicit NULL cksum errors
0 with router alert tag
0 lsp ping packets (ttl-expired/router alert)
0 with ttl expired
0 with tag encoding error
0 packets discarded, no route
0 packets used first nexthop in ecmp unilist
```

lcc1-re0:

mpls:

```
0 total mpls packets received
0 packets forwarded
0 packets dropped
0 with header too small
0 after tagging, can't fit link MTU
0 with IPv4 explicit NULL tag
0 with IPv4 explicit NULL cksum errors
0 with router alert tag
0 lsp ping packets (ttl-expired/router alert)
0 with ttl expired
0 with tag encoding error
0 packets discarded, no route
0 packets used first nexthop in ecmp unilist
```

lcc2-re0:

mpls:

```
0 total mpls packets received
0 packets forwarded
0 packets dropped
0 with header too small
0 after tagging, can't fit link MTU
0 with IPv4 explicit NULL tag
0 with IPv4 explicit NULL cksum errors
0 with router alert tag
0 lsp ping packets (ttl-expired/router alert)
0 with ttl expired
```

```
0 with tag encoding error
0 packets discarded, no route
0 packets used first nexthop in ecmp unilist
```

```
lcc3-re0:
```

```
-----
mpls:
```

```
0 total mpls packets received
0 packets forwarded
0 packets dropped
0 with header too small
0 after tagging, can't fit link MTU
0 with IPv4 explicit NULL tag
0 with IPv4 explicit NULL cksum errors
0 with router alert tag
0 lsp ping packets (ttl-expired/router alert)
0 with ttl expired
0 with tag encoding error
0 packets discarded, no route
0 packets used first nexthop in ecmp unilist
```

show system statistics rdp

Syntax	show system statistics rdp
Syntax (EX Series Switch)	show system statistics rdp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics rdp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics rdp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Reliable Datagram Protocol (RDP) statistics.
Options	<p>none—Display system statistics for RDP.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for RDP for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for RDP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for RDP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display RDP statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for RDP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for RDP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display RDP statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display RDP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for RDP for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for RDP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with *0*.

Additional Information By default, when you issue the **show system statistics rdp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics rdp on page 1061**
show system statistics rdp (EX Series Switch) on page 1061
show system statistics rdp (TX Matrix Plus Router) on page 1061

Sample Output

```
show system statistics rdp  user@host> show system statistics rdp
rdp:
    49668864 input packets
    0 discards for bad checksum
    0 discards bad sequence number
    0 refused connections
    2031513 acks received
    0 dropped due to full socket buffers
    49692 retransmits
    49668864 output packets
    24809579 acks sent
    28 connects
    0 closes
    22778052 keepalives received
    22778052 keepalives sent
```

```
show system statistics rdp (EX Series Switch) user@host> show system statistics rdp
rdp:
    0 Input packets
    0 Packets discarded for bad checksum
    0 Packets discarded due to bad sequence number
    0 Refused connections
    0 Acks received
    0 Packets dropped due to full socket buffers
    0 Retransmits
    0 Output packets
    0 Acks sent
    0 Connects
    0 Closes
    0 Keepalives received
    0 Keepalives sent
```

```
show system statistics rdp (TX Matrix Plus Router) user@host> show system statistics rdp
sfc0-re0:
-----
```

```
rdp:
  4341558 input packets
  0 discards for bad checksum
  43452 discards bad sequence number
  598 refused connections
  85711 acks received
  101 dropped due to full socket buffers
  9110 retransmits
  4335896 output packets
  734087 acks sent
  372 connects
  65 closes
  526312 keepalives received
  3506373 keepalives sent
```

```
lcc0-re0:
```

```
-----
rdp:
  810979 input packets
  0 discards for bad checksum
  477 discards bad sequence number
  484 refused connections
  21798 acks received
  0 dropped due to full socket buffers
  10305 retransmits
  813567 output packets
  242155 acks sent
  68 connects
  47 closes
  112788 keepalives received
  539244 keepalives sent
```

```
lcc1-re0:
```

```
-----
rdp:
  804747 input packets
  0 discards for bad checksum
  335 discards bad sequence number
  624 refused connections
  24275 acks received
  0 dropped due to full socket buffers
  9878 retransmits
  806163 output packets
  233079 acks sent
  67 connects
  47 closes
  112816 keepalives received
  538845 keepalives sent
```

```
lcc2-re0:
```

```
-----
rdp:
  945112 input packets
  0 discards for bad checksum
  172 discards bad sequence number
  396 refused connections
  34676 acks received
  0 dropped due to full socket buffers
  15176 retransmits
  948073 output packets
  249913 acks sent
```

68 connects
45 closes
112748 keepalives received
648232 keepalives sent

lcc3-re0:

rdp:

1247011 input packets
0 discards for bad checksum
177 discards bad sequence number
575 refused connections
51787 acks received
0 dropped due to full socket buffers
23717 retransmits
1252925 output packets
314103 acks sent
75 connects
46 closes
113132 keepalives received
863225 keepalives sent

show system statistics tcp

Syntax	show system statistics tcp
Syntax (EX Series Switch)	show system statistics tcp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics tcp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics tcp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Transmission Control Protocol (TCP) statistics.
Options	none—Display system statistics for TCP. all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for TCP for all the routers in the chassis. all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for TCP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for TCP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router. all-members—(EX4200 switches only) (Optional) Display TCP statistics for all members of the Virtual Chassis configuration. lcc <i>number</i> —(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for TCP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for TCP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3. local—(EX4200 switches only) (Optional) Display TCP statistics for the local Virtual Chassis member. member <i>member-id</i> —(EX4200 switches only) (Optional) Display TCP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9. scc—(TX Matrix routers only) (Optional) Display system statistics for TCP for the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for TCP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics tcp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics tcp** on page 1065
show system statistics tcp (EX Series Switch) on page 1066
show system statistics tcp lcc (TX Matrix Router) on page 1067
show system statistics tcp (TX Matrix Plus Router) on page 1068

Sample Output

```
show system statistics tcp  user@host> show system statistics tcp
tcp:
    3844 packets sent
        3618 data packets (1055596 bytes)
        0 data packets (0 bytes) retransmitted
        0 resends initiated by MTU discovery
        205 ack-only packets (148 packets delayed)
        0 URG only packets
        0 window probe packets
        0 window update packets
        1079 control packets
    5815 packets received
        3377 acks (for 1055657 bytes)
        24 duplicate acks
        0 acks for unsent data
        2655 packets (15004 bytes) received in-sequence
        1 completely duplicate packet (0 bytes)
        0 old duplicate packets
        0 packets with some dup. data (0 bytes duped)
        0 out-of-order packets (0 bytes)
        0 packets (0 bytes) of data after window
        0 window probes
        7 window update packets
        0 packets received after close
        0 discarded for bad checksums
        0 discarded for bad header offset fields
        0 discarded because packet too short
    1 connection request
    32 connection accepts
    0 bad connection attempts
    0 listen queue overflows
    33 connections established (including accepts)
    30 connections closed (including 0 drops)
        27 connections updated cached RTT on close
        27 connections updated cached RTT variance on close
```

```

    0 connections updated cached ssthresh on close
0 embryonic connections dropped
3374 segments updated rtt (of 3220 attempts)
0 retransmit timeouts
    0 connections dropped by rexmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
344 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
1096 correct ACK header predictions
1314 correct data packet header predictions
32 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    32 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
1058 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors

```

show system statistics user@host> **show system statistics tcp**
tcp (EX Series Switch) Tcp:

```

572724 packets sent
    21936 data packets (1887657 bytes)
    2 data packets retransmitted (20 bytes)
    0 resends initiated by MTU discovery
    3724 ack only packets (537 packets delayed)
    0 URG only packets
    1 window probe packets
    1 window update packets
    1094083 control packets
1134258 packets received
    21371 acks(for 1886660 bytes)
    5870 duplicate acks
    0 acks for unsent data
    19908 packets received in-sequence(267794 bytes)
    3022 completely duplicate packets(0 bytes)
    0 old duplicate packets
    4 packets with some duplicate data(4 bytes duped)
    2 out-of-order packets(2 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    40 window update packets
    0 packets received after close
    0 discarded for bad checksums

```

```

        0 discarded for bad header offset fields
        0 discarded because packet too short
547027 connection requests
80 connection accepts
0 bad connection attempts
0 listen queue overflows
103 connections established (including accepts)
547106 connections closed (including 6 drops)
    47 connections updated cached RTT on close
    47 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
547004 embryonic connections dropped
20862 segments updated rtt(of 567830 attempts)
2 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
3032 keepalive timeouts
    3031 keepalive probes sent
    1 connections dropped by keepalive
7823 correct ACK header predictions
12533 correct data packet header predictions
80 syncache entries added
    0 retransmitted
    0 dupsyn
    4 dropped
    80 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
1 SACK recovery episodes
1 segment retransmits in SACK recovery episodes
1 byte retransmits in SACK recovery episodes
71 SACK options (SACK blocks) received
1 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
547024 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

```

show system statistics user@host> show system statistics tcp lcc 2

tcp lcc (TX Matrix lcc2-re0:

Router)

tcp:

```

21271 packets sent
    11069 data packets (12044 bytes)
    0 data packets (0 bytes) retransmitted
    0 resends initiated by MTU discovery

```

```

    10198 ack-only packets (10194 packets delayed)
    0 URG only packets
    0 window probe packets
    0 window update packets
    4 control packets
13363 packets received
    11073 acks (for 12044 bytes)
    0 duplicate acks
    0 acks for unsent data
    12895 packets (2400874 bytes) received in-sequence
    0 completely duplicate packets (0 bytes)
    0 old duplicate packets
    0 packets with some dup. data (0 bytes duped)
    0 out-of-order packets (0 bytes)
    0 packets (0 bytes) of data after window
    0 window probes
    0 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
4 connection requests
0 connection accepts
0 bad connection attempts
0 listen queue overflows
4 connections established (including accepts)
33 connections closed (including 0 drops)
    0 connections updated cached RTT on close
    0 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
11073 segments updated rtt (of 11073 attempts)
0 retransmit timeouts
    0 connections dropped by rexmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
0 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
464 correct ACK header predictions
2172 correct data packet header predictions
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 out-of-sequence segment drops due to insufficient memory
0 RST packets
0 ICMP packets ignored by TCP

```

show system statistics user@host> **show system statistics tcp**

tcp (TX Matrix Plus sfc0-re0:

Router)

Tcp:

```

    10420 packets sent
        10203 data packets (2374613 bytes)
        0 data packets retransmitted (0 bytes)
        0 resends initiated by MTU discovery
        202 ack only packets (120 packets delayed)
        0 URG only packets
        0 window probe packets
        0 window update packets
        30 control packets
16635 packets received

```

```

    9468 acks(for 2374674 bytes)
    32 duplicate acks
    0 acks for unsent data
    7764 packets received in-sequence(38286 bytes)
    20 completely duplicate packets(0 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    356 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
10 connection requests
33 connection accepts
0 bad connection attempts
0 listen queue overflows
34 connections established (including accepts)
50 connections closed (including 0 drops)
    24 connections updated cached RTT on close
    24 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
9 embryonic connections dropped
9468 segments updated rtt(of 9256 attempts)
0 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
14 keepalive timeouts
    14 keepalive probes sent
    0 connections dropped by keepalive
6220 correct ACK header predictions
6625 correct data packet header predictions
33 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    33 completed
    0 bucket overflow
    0 cache overflow
    0 reset
    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 SACK recovery episodes
0 segment retransmits in SACK recovery episodes
0 byte retransmits in SACK recovery episodes
0 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
15 RST packets

```

```
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing
```

lcc0-re0:

Tcp:

```
1306 packets sent
    1251 data packets (161855 bytes)
    0 data packets retransmitted (0 bytes)
    0 resends initiated by MTU discovery
    51 ack only packets (1 packets delayed)
    0 URG only packets
    0 window probe packets
    0 window update packets
    6 control packets
1397 packets received
    1218 acks(for 161904 bytes)
    2 duplicate acks
    0 acks for unsent data
    612 packets received in-sequence(12495 bytes)
    0 completely duplicate packets(0 bytes)
    0 old duplicate packets
    0 packets with some duplicate data(0 bytes duped)
    0 out-of-order packets(0 bytes)
    0 packets of data after window(0 bytes)
    0 window probes
    22 window update packets
    0 packets received after close
    0 discarded for bad checksums
    0 discarded for bad header offset fields
    0 discarded because packet too short
1 connection requests
24 connection accepts
0 bad connection attempts
0 listen queue overflows
25 connections established (including accepts)
27 connections closed (including 0 drops)
    24 connections updated cached RTT on close
    24 connections updated cached RTT variance on close
    0 connections updated cached ssthresh on close
0 embryonic connections dropped
1218 segments updated rtt(of 1192 attempts)
0 retransmit timeouts
    0 connections dropped by retransmit timeout
0 persist timeouts
    0 connections dropped by persist timeout
0 keepalive timeouts
    0 keepalive probes sent
    0 connections dropped by keepalive
196 correct ACK header predictions
119 correct data packet header predictions
24 syncache entries added
    0 retransmitted
    0 dupsyn
    0 dropped
    24 completed
    0 bucket overflow
    0 cache overflow
    0 reset
```

```

    0 stale
    0 aborted
    0 badack
    0 unreach
    0 zone failures
0 cookies sent
0 cookies received
0 SACK recovery episodes
0 segment retransmits in SACK recovery episodes
0 byte retransmits in SACK recovery episodes
0 SACK options (SACK blocks) received
0 SACK options (SACK blocks) sent
0 SACK scoreboard overflow
0 ACKs sent in response to in-window but not exact RSTs
0 ACKs sent in response to in-window SYNs on established connections
0 rcv packets dropped by TCP due to bad address
0 out-of-sequence segment drops due to insufficient memory
2 RST packets
0 ICMP packets ignored by TCP
0 send packets dropped by TCP due to auth errors
0 rcv packets dropped by TCP due to auth errors
0 outgoing segments dropped due to policing

```

lcc1-re0:

 Tcp:

```

    1118 packets sent
        1066 data packets (131896 bytes)
        0 data packets retransmitted (0 bytes)
        0 resends initiated by MTU discovery
        48 ack only packets (2 packets delayed)
        0 URG only packets
        0 window probe packets
        0 window update packets
        6 control packets
    1215 packets received

```

show system statistics tnp

Syntax	show system statistics tnp
Syntax (EX Series Switch)	show system statistics tnp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics tnp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics tcp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Trivial Network Protocol (TNP) statistics.
Options	none—Display system statistics for TNP. all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for TNP for all the routers in the chassis. all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for TNP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for TNP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router. all-members—(EX4200 switches only) (Optional) Display TNP statistics for all members of the Virtual Chassis configuration. lcc <i>number</i> —(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for TNP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for TNP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3. local—(EX4200 switches only) (Optional) Display TNP statistics for the local Virtual Chassis member. member <i>member-id</i> —(EX4200 switches only) (Optional) Display TNP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9. scc—(TX Matrix routers only) (Optional) Display system statistics for TNP for the TX Matrix router (or switch-card chassis).

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for TNP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics tnp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics tnp** on page 1073
show system statistics tnp (EX Series Switch) on page 1073
show system statistics tnp (TX Matrix Plus Router) on page 1074

Sample Output

```
show system statistics tnp  user@host> show system statistics tnp
tnp:
    146742559 unicast packets received
    0 broadcast packets received
    0 fragmented packets received
    0 hello packets dropped
    0 fragments dropped
    0 fragment reassembly queue flushes
    0 hello packets received
    0 control packets received
    49670972 rdp packets received
    337101 udp packets received
    96734486 tunnel packets received
    0 input packets discarded with no protocol
    98375316 unicast packets sent
    0 broadcast packets sent
    0 fragmented packets sent
    0 hello packets dropped
    0 fragments dropped
    0 hello packets sent
    0 control packets sent
    49670972 rdp packets sent
    337101 udp packets sent
    48367243 tunnel packets sent
    0 packets sent with unknown protocol
```

```
show system statistics tnp (EX Series Switch)  user@host> show system statistics tnp
tnp:
    0 Unicast packets received
    0 Broadcast packets received
    0 Fragmented packets received
    0 Hello packets dropped
    0 Fragments dropped
    0 Fragment reassembly queue flushes
    0 Packets with tnp src address collision received
    0 Hello packets received
```

```

0 Control packets received
0 Rdp packets received
0 Udp packets received
0 Tunnel packets received
0 Input packets discarded with no protocol
0 Packets of version unspecified received
0 Packets of version 1 received
0 Packets of version 2 received
0 Packets of version 3 received
0 Unicast packets sent
0 Broadcast packets sent
0 Fragmented packets sent
0 Hello packets dropped
0 Fragments dropped
0 Hello packets sent
0 Control packets sent
0 Rdp packets sent
0 Udp packets sent
0 Tunnel packets sent
0 Packets sent with unknown protocol
0 Packets of version unspecified sent
0 Packets of version 1 sent
0 Packets of version 2 sent
0 Packets of version 3 sent

```

show system statistics
tnp (TX Matrix Plus
Router)

user@host> **show system statistics tnp**
sfc0-re0:

tnp:

```

4543208 unicast packets received
3306239 broadcast packets received
2398 fragmented packets received
0 hello packets dropped
0 fragments dropped
53 fragment reassembly queue flushes
0 packets with tnp src address collision received
3306148 hello packets received
0 control packets received
4439623 rdp packets received
103676 udp packets received
0 tunnel packets received
0 input packets discarded with no protocol
0 packets of version unspecified received
0 packets of version 1 received
8265 packets of version 2 received
7841182 packets of version 3 received

```

```

4528238 unicast packets sent
115264 broadcast packets sent
64 fragmented packets sent
0 hello packets dropped
0 fragments dropped
115264 hello packets sent
0 control packets sent
4433293 rdp packets sent
94945 udp packets sent
0 tunnel packets sent
0 packets sent with unknown protocol
0 packets of version unspecified sent
0 packets of version 1 sent
6444 packets of version 2 sent

```

4637058 packets of version 3 sent

lcc0-re0:

tnp:

977938 unicast packets received
894314 broadcast packets received
322 fragmented packets received
0 hello packets dropped
0 fragments dropped
12 fragment reassembly queue flushes
0 packets with tnp src address collision received
894294 hello packets received
0 control packets received
829776 rdp packets received
148182 udp packets received
0 tunnel packets received
0 input packets discarded with no protocol
0 packets of version unspecified received
0 packets of version 1 received
90262 packets of version 2 received
1781990 packets of version 3 received

981945 unicast packets sent
113988 broadcast packets sent
206 fragmented packets sent
0 hello packets dropped
0 fragments dropped
113988 hello packets sent
0 control packets sent
832646 rdp packets sent
149299 udp packets sent
0 tunnel packets sent
0 packets sent with unknown protocol
0 packets of version unspecified sent
0 packets of version 1 sent
89672 packets of version 2 sent
1006261 packets of version 3 sent

lcc1-re0:

tnp:

967870 unicast packets received
897834 broadcast packets received
38 fragmented packets received
0 hello packets dropped
0 fragments dropped
10 fragment reassembly queue flushes
0 packets with tnp src address collision received
897813 hello packets received
0 control packets received
822840 rdp packets received
145051 udp packets received
0 tunnel packets received
0 input packets discarded with no protocol
0 packets of version unspecified received
0 packets of version 1 received
87117 packets of version 2 received
1778587 packets of version 3 received

970975 unicast packets sent

```
114031 broadcast packets sent
25 fragmented packets sent
0 hello packets dropped
0 fragments dropped
114031 hello packets sent
0 control packets sent
824773 rdp packets sent
146202 udp packets sent
0 tunnel packets sent
0 packets sent with unknown protocol
0 packets of version unspecified sent
0 packets of version 1 sent
86595 packets of version 2 sent
998411 packets of version 3 sent
```

lcc2-re0:

tnp:

```
1131139 unicast packets received
1007204 broadcast packets received
620 fragmented packets received
0 hello packets dropped
0 fragments dropped
12 fragment reassembly queue flushes
0 packets with tnp src address collision received
1007185 hello packets received
0 control packets received
966727 rdp packets received
164431 udp packets received
0 tunnel packets received
0 input packets discarded with no protocol
0 packets of version unspecified received
0 packets of version 1 received
106518 packets of version 2 received
2031825 packets of version 3 received
```

```
1135108 unicast packets sent
114130 broadcast packets sent
397 fragmented packets sent
0 hello packets dropped
0 fragments dropped
114130 hello packets sent
0 control packets sent
969748 rdp packets sent
165360 udp packets sent
0 tunnel packets sent
0 packets sent with unknown protocol
0 packets of version unspecified sent
0 packets of version 1 sent
105801 packets of version 2 sent
1143437 packets of version 3 sent
```

lcc3-re0:

tnp:

```
1495619 unicast packets received
1211116 broadcast packets received
1186 fragmented packets received
0 hello packets dropped
0 fragments dropped
13 fragment reassembly queue flushes
```

```
0 packets with tnp src address collision received
1211088 hello packets received
0 control packets received
1275765 rdp packets received
219882 udp packets received
0 tunnel packets received
0 input packets discarded with no protocol
0 packets of version unspecified received
0 packets of version 1 received
161944 packets of version 2 received
2544791 packets of version 3 received

1502341 unicast packets sent
114160 broadcast packets sent
699 fragmented packets sent
0 hello packets dropped
0 fragments dropped
114160 hello packets sent
0 control packets sent
1281678 rdp packets sent
220663 udp packets sent
0 tunnel packets sent
0 packets sent with unknown protocol
0 packets of version unspecified sent
0 packets of version 1 sent
161167 packets of version 2 sent
1455334 packets of version 3 sent
```

show system statistics tudp

Syntax	show system statistics tudp
Syntax (EX Series Switch)	show system statistics tudp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics tudp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics tudp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Trivial User Datagram Protocol (TUDP) statistics.
Options	<p>none—Display system statistics for TUDP.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for TUDP for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for TUDP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for TUDP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display TUDP statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for TUDP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for TUDP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display TUDP statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display TUDP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for TUDP for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for TUDP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics tudp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics tudp on page 1079**
show system statistics tudp (TX Matrix Plus Router) on page 1079

Sample Output

```
show system statistics tudp user@host> show system statistics tudp
tudp:
    337109 datagrams received
    0 with incomplete header
    0 with bad data length field
    0 with bad checksum
    0 dropped due to no socket
    0 broadcast/multicast datagrams dropped due to no socket
    0 dropped due to full socket buffers
    337109 delivered
    337109 datagrams output
```

```
show system statistics tudp (TX Matrix Plus Router) user@host> show system statistics tudp
sfc0-re0:
-----
tudp:
    104389 datagrams received
    0 with incomplete header
    0 with bad data length field
    0 with bad checksum
    0 dropped due to no socket
    0 broadcast/multicast datagrams dropped due to no socket
    0 dropped due to full socket buffers
    104389 delivered
    95619 datagrams output
```

```
1cc0-re0:
-----
tudp:
    148623 datagrams received
    0 with incomplete header
    0 with bad data length field
    0 with bad checksum
    2 dropped due to no socket
    1 broadcast/multicast datagram dropped due to no socket
    0 dropped due to full socket buffers
    148620 delivered
```

150327 datagrams output

lcc1-re0:

tudp:

145493 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
0 dropped due to no socket
1 broadcast/multicast datagram dropped due to no socket
0 dropped due to full socket buffers
145492 delivered
147244 datagrams output

lcc2-re0:

tudp:

164873 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
2 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
164871 delivered
166339 datagrams output

lcc3-re0:

tudp:

220320 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
6 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
220314 delivered
221735 datagrams output

show system statistics udp

Syntax	show system statistics udp
Syntax (EX Series Switch)	show system statistics udp <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system statistics udp <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics udp <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide User Datagram Protocol (UDP) statistics.
Options	<p>none—Display system statistics for UDP.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for UDP for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for UDP for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for UDP for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches only) (Optional) Display UDP statistics for all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for UDP for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for UDP for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>local—(EX4200 switches only) (Optional) Display UDP statistics for the local Virtual Chassis member.</p> <p>member <i>member-id</i>—(EX4200 switches only) (Optional) Display TUDP statistics for the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value from 0 through 9.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for UDP for the TX Matrix router (or switch-card chassis).</p>

sfc number—(TX Matrix Plus routers only) (Optional) Display system statistics for UDP for the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system statistics udp** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system statistics udp on page 1082**
show system statistics udp (TX Matrix Plus Router) on page 1082

Sample Output

```
show system statistics udp  user@host> show system statistics udp
                             udp:
                               3658427 datagrams received
                               0 with incomplete header
                               0 with bad data length field
                               0 with bad checksum
                               3656885 dropped due to no socket
                               3656885 broadcast/multicast datagrams dropped due to no socket
                               0 dropped due to full socket buffers
                               0 not for hashed pcb
                               4291311953 delivered
                               1551 datagrams output

show system statistics udp (TX Matrix Plus Router) user@host> show system statistics udp
                                                    sfc0-re0:
                                                    -----
                                                    udp:
                                                      170 datagrams received
                                                      0 with incomplete header
                                                      0 with bad data length field
                                                      0 with bad checksum
                                                      0 dropped due to no socket
                                                      0 broadcast/multicast datagrams dropped due to no socket
                                                      0 dropped due to full socket buffers
                                                      0 not for hashed pcb
                                                      170 delivered
                                                      12079 datagrams output

                                                    1cc0-re0:
                                                    -----
                                                    udp:
                                                      55 datagrams received
                                                      0 with incomplete header
                                                      0 with bad data length field
                                                      0 with bad checksum
                                                      1 dropped due to no socket
                                                      0 broadcast/multicast datagrams dropped due to no socket
```

```
0 dropped due to full socket buffers
0 not for hashed pcb
54 delivered
3891 datagrams output
```

lcc1-re0:

udp:

```
50 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
0 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
0 not for hashed pcb
50 delivered
3620 datagrams output
```

lcc2-re0:

udp:

```
48 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
0 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
0 not for hashed pcb
48 delivered
3734 datagrams output
```

lcc3-re0:

udp:

```
48 datagrams received
0 with incomplete header
0 with bad data length field
0 with bad checksum
0 dropped due to no socket
0 broadcast/multicast datagrams dropped due to no socket
0 dropped due to full socket buffers
0 not for hashed pcb
48 delivered
3640 datagrams output
```

show system statistics vpls

Syntax	show system statistics vpls
Syntax (TX Matrix Router)	show system statistics vpls <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system statistics vpls <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display system-wide Virtual Private LAN Service (VPLS) statistics.
Options	<p>none—Display system statistics for VPLS.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system statistics for VPLS for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for VPLS for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for VPLS for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system statistics for VPLS for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system statistics for VPLS for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.</p> <p>scc—(TX Matrix routers only) (Optional) Display system statistics for VPLS for the TX Matrix router (or switch-card chassis).</p> <p>sfc <i>number</i>—(TX Matrix Plus routers only) (Optional) Display system statistics for VPLS for the TX Matrix Plus router (or switch-fabric chassis). Replace <i>number</i> with 0.</p>
Additional Information	By default, when you issue the show system statistics vpls command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.
Required Privilege Level	view

List of Sample Output **show system statistics vpls** on page 1085
 show system statistics vpls (TX Matrix Plus Router) on page 1085

Sample Output

```
show system statistics vpls  user@host> show system statistics vpls
                             vpls:
                                0 total packets received
                                0 with size smaller than minimum
                                0 with incorrect version number
                                0 packets for this host

                                0 packets with no logical interface
                                0 packets with no family
                                0 packets with no route table
                                0 packets with no auxiliary table
                                0 packets with no corefacing entry
                                0 packets with no CE-facing entry

                                0 mac route learning requests
                                0 mac routes learnt
                                0 requests to learn an existing route
                                0 learning requests while learning disabled on interface
                                0 learning requests over capacity
                                0 mac routes moved
                                0 requests to move static route

                                0 mac route aging requests
                                0 mac routes aged
                                0 bogus address in aging requests
                                0 requests to age static route
                                0 requests to re-ageout aged route
                                0 requests involving multiple peer FEs
                                0 aging acks from PFE
                                0 aging non-acks from PFE
                                0 aging requests timed out waiting on FEs
                                0 aging requests over max-rate
                                0 errors finding peer FEs
```

```
show system statistics vpls (TX Matrix Plus Router)  user@host> show system statistics vpls
                                                         sfc0-re0:
                                                         -----
                                                         vpls:
                                                            0 total packets received
                                                            0 with size smaller than minimum
                                                            0 with incorrect version number
                                                            0 packets for this host

                                                            0 packets with no logical interface
                                                            0 packets with no family
                                                            0 packets with no route table
                                                            0 packets with no auxiliary table
                                                            0 packets with no corefacing entry
                                                            0 packets with no CE-facing entry

                                                            0 mac route learning requests
                                                            0 mac routes learnt
                                                            0 requests to learn an existing route
                                                            0 learning requests while learning disabled on interface
                                                            0 learning requests over capacity
                                                            0 mac routes moved
```

```
0 requests to move static route

0 mac route aging requests
0 mac routes aged
0 bogus address in aging requests
0 requests to age static route
0 requests to re-ageout aged route
0 requests involving multiple peer FEs
0 aging acks from PFE
0 aging non-acks from PFE
0 aging requests timed out waiting on FEs
0 aging requests over max-rate
0 errors finding peer FEs
0 unsupported platform
0 dropped due to no l3 route table
0 dropped due to no local ifl
0 packets punted
0 dropped due to no socket
```

lcc0-re0:

vpls:

```
0 total packets received
0 with size smaller than minimum
0 with incorrect version number
0 packets for this host

0 packets with no logical interface
0 packets with no family
0 packets with no route table
0 packets with no auxiliary table
0 packets with no corefacing entry
0 packets with no CE-facing entry

0 mac route learning requests
0 mac routes learnt
0 requests to learn an existing route
0 learning requests while learning disabled on interface
0 learning requests over capacity
0 mac routes moved
0 requests to move static route

0 mac route aging requests
0 mac routes aged
0 bogus address in aging requests
0 requests to age static route
0 requests to re-ageout aged route
0 requests involving multiple peer FEs
0 aging acks from PFE
0 aging non-acks from PFE
0 aging requests timed out waiting on FEs
0 aging requests over max-rate
0 errors finding peer FEs
0 unsupported platform
0 dropped due to no l3 route table
0 dropped due to no local ifl
0 packets punted
0 dropped due to no socket
```

lcc1-re0:

vpls:

```

0 total packets received
0 with size smaller than minimum
0 with incorrect version number
0 packets for this host

0 packets with no logical interface
0 packets with no family
0 packets with no route table
0 packets with no auxiliary table
0 packets with no corefacing entry
0 packets with no CE-facing entry

0 mac route learning requests
0 mac routes learnt
0 requests to learn an existing route
0 learning requests while learning disabled on interface
0 learning requests over capacity
0 mac routes moved
0 requests to move static route

0 mac route aging requests
0 mac routes aged
0 bogus address in aging requests
0 requests to age static route
0 requests to re-ageout aged route
0 requests involving multiple peer FEs
0 aging acks from PFE
0 aging non-acks from PFE
0 aging requests timed out waiting on FEs
0 aging requests over max-rate
0 errors finding peer FEs
0 unsupported platform
0 dropped due to no l3 route table
0 dropped due to no local ifl
0 packets punted
0 dropped due to no socket

```

lcc2-re0:

vpls:

```

0 total packets received
0 with size smaller than minimum
0 with incorrect version number
0 packets for this host

0 packets with no logical interface
0 packets with no family
0 packets with no route table
0 packets with no auxiliary table
0 packets with no corefacing entry
0 packets with no CE-facing entry

0 mac route learning requests
0 mac routes learnt
0 requests to learn an existing route
0 learning requests while learning disabled on interface
0 learning requests over capacity
0 mac routes moved
0 requests to move static route

```

```
0 mac route aging requests
0 mac routes aged
0 bogus address in aging requests
0 requests to age static route
0 requests to re-ageout aged route
0 requests involving multiple peer FEs
0 aging acks from PFE
0 aging non-acks from PFE
0 aging requests timed out waiting on FEs
0 aging requests over max-rate
0 errors finding peer FEs
0 unsupported platform
0 dropped due to no l3 route table
0 dropped due to no local ifl
0 packets punted
0 dropped due to no socket
```

lcc3-re0:

vpls:

```
0 total packets received
0 with size smaller than minimum
0 with incorrect version number
0 packets for this host

0 packets with no logical interface
0 packets with no family
0 packets with no route table
0 packets with no auxiliary table
0 packets with no corefacing entry
0 packets with no CE-facing entry

0 mac route learning requests
0 mac routes learnt
0 requests to learn an existing route
0 learning requests while learning disabled on interface
0 learning requests over capacity
0 mac routes moved
0 requests to move static route

0 mac route aging requests
0 mac routes aged
0 bogus address in aging requests
0 requests to age static route
0 requests to re-ageout aged route
0 requests involving multiple peer FEs
0 aging acks from PFE
0 aging non-acks from PFE
0 aging requests timed out waiting on FEs
0 aging requests over max-rate
0 errors finding peer FEs
0 unsupported platform
0 dropped due to no l3 route table
0 dropped due to no local ifl
0 packets punted
0 dropped due to no socket
```


show system storage

Syntax	show system storage <detail>
Syntax (EX Series Switch)	show system storage <detail> <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system storage <detail> <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system storage <detail> <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system storage <detail> <all-members> <local> <member <i>member-id</i> >
Syntax (QFX Series)	show system storage <detail>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display statistics about the amount of free disk space in the router's or switch's file systems.
Options	<p>none—Display standard information about the amount of free disk space in the router's or switch's file systems.</p> <p>detail—(Optional) Display detailed output.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display system storage statistics for all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system storage statistics for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display system storage statistics for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Display system storage statistics for all members of the Virtual Chassis configuration.</p>

lcc *number*—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display system storage statistics for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display system storage statistics for a specific T1600 router that is connected to the TX Matrix Plus router. Replace ***number*** with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display system storage statistics for the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display system storage statistics for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display system storage statistics for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Display system storage statistics for the TX Matrix Plus router (or switch-fabric chassis). Replace ***number*** with 0.

Additional Information By default, when you issue the **show system storage** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output [show system storage on page 1091](#)
[show system storage \(TX Matrix Plus Router\) on page 1091](#)
[show system storage \(QFX Series\) on page 1093](#)

Output Fields Table 154 on page 1090 describes the output fields for the **show system storage** command. Output fields are listed in the approximate order in which they appear.

Table 154: show system storage Output Fields

Field Name	Field Description
Filesystem	Name of the file system.
Size	Size of the file system.
Used	Amount of space used in the file system.
Avail	Amount of space available in the file system.

Table 154: show system storage Output Fields (*continued*)

Field Name	Field Description
Capacity	Percentage of the file system's space that is being used.
Mounted on	Directory in which the file system is mounted.

Sample Output

```

show system storage user@host> show system storage
Filesystem          Size      Used      Avail  Capacity  Mounted on
/dev/ad0s1a          77M       37M       34M      52%      /
devfs                16K       16K        0B     100%    /dev/
/dev/vn0             12M       12M        0B     100%  /packages/mnt/jbase
/dev/vn1             39M       39M        0B     100%
/packages/mnt/jkernel-7.2R1.7
/dev/vn2             12M       12M        0B     100%
/packages/mnt/jpfe-M40-7.2R1.7
/dev/vn3             2.3M      2.3M        0B     100%
/packages/mnt/jdocs-7.2R1.7
/dev/vn4             14M       14M        0B     100%
/packages/mnt/jroute-7.2R1.7
/dev/vn5             4.5M      4.5M        0B     100%
/packages/mnt/jcrypto-7.2R1.7
mfs:172             1.5G      4.0K      1.3G        0%    /tmp
/dev/ad0s1e          12M       20K       11M        0%    /config
procfs              4.0K      4.0K        0B     100%    /proc
/dev/ad1s1f          9.4G      4.9G      3.7G      57%    /var

```

```

show system storage user@host> show system storage
(TX Matrix Plus   sfc0-re0:
Router)
-----
Filesystem          Size      Used      Avail  Capacity  Mounted on
/dev/ad0s1a          3.4G     178M      2.9G        6%      /
devfs                1.0K      1.0K        0B     100%    /dev
devfs                1.0K      1.0K        0B     100%    /dev/
/dev/md0             33M       33M        0B     100%  /packages/mnt/jbase
/dev/md1             216M      216M        0B     100%
/packages/mnt/jkernel-9.6-20090519.0
/dev/md2             66M       66M        0B     100%
/packages/mnt/jpfe-T-9.6-20090519.0
/dev/md3             4.1M      4.1M        0B     100%
/packages/mnt/jdocs-9.6-20090519.0
/dev/md4             57M       57M        0B     100%
/packages/mnt/jroute-9.6-20090519.0
/dev/md5             15M       15M        0B     100%
/packages/mnt/jcrypto-9.6-20090519.0
/dev/md6             34M       34M        0B     100%
/packages/mnt/jpfe-common-9.6-20090519.0
/dev/md7             2.0G      10.0K      1.8G        0%    /tmp
/dev/md8             2.0G       1.0M      1.8G        0%    /mfs
/dev/ad0s1e          383M       82K      352M        0%    /config
procfs              4.0K      4.0K        0B     100%    /proc
/dev/ad1s1f          52G       7.5G      40G       16%    /var

```

```
lcc0-re0:
-----
```

Filesystem	Size	Used	Avail	Capacity	Mounted on
/dev/ad0s1a	3.4G	178M	2.9G	6%	/
devfs	1.0K	1.0K	0B	100%	/dev
devfs	1.0K	1.0K	0B	100%	/dev/
/dev/md0	33M	33M	0B	100%	/packages/mnt/jbase
/dev/md1	216M	216M	0B	100%	
/packages/mnt/jkernel-9.6-20090519.0					
/dev/md2	66M	66M	0B	100%	
/packages/mnt/jpfe-T-9.6-20090519.0					
/dev/md3	4.1M	4.1M	0B	100%	
/packages/mnt/jdocs-9.6-20090519.0					
/dev/md4	57M	57M	0B	100%	
/packages/mnt/jroute-9.6-20090519.0					
/dev/md5	15M	15M	0B	100%	
/packages/mnt/jcrypto-9.6-20090519.0					
/dev/md6	34M	34M	0B	100%	
/packages/mnt/jpfe-common-9.6-20090519.0					
/dev/md7	2.0G	10.0K	1.8G	0%	/tmp
/dev/md8	2.0G	540K	1.8G	0%	/mfs
/dev/ad0s1e	383M	88K	352M	0%	/config
procfs	4.0K	4.0K	0B	100%	/proc
/dev/ad1s1f	52G	6.3G	41G	13%	/var

lcc1-re0:

Filesystem	Size	Used	Avail	Capacity	Mounted on
/dev/ad0s1a	3.4G	178M	2.9G	6%	/
devfs	1.0K	1.0K	0B	100%	/dev
devfs	1.0K	1.0K	0B	100%	/dev/
/dev/md0	33M	33M	0B	100%	/packages/mnt/jbase
/dev/md1	216M	216M	0B	100%	
/packages/mnt/jkernel-9.6-20090519.0					
/dev/md2	66M	66M	0B	100%	
/packages/mnt/jpfe-T-9.6-20090519.0					
/dev/md3	4.1M	4.1M	0B	100%	
/packages/mnt/jdocs-9.6-20090519.0					
/dev/md4	57M	57M	0B	100%	
/packages/mnt/jroute-9.6-20090519.0					
/dev/md5	15M	15M	0B	100%	
/packages/mnt/jcrypto-9.6-20090519.0					
/dev/md6	34M	34M	0B	100%	
/packages/mnt/jpfe-common-9.6-20090519.0					
/dev/md7	2.0G	10.0K	1.8G	0%	/tmp
/dev/md8	2.0G	540K	1.8G	0%	/mfs
/dev/ad0s1e	383M	88K	352M	0%	/config
procfs	4.0K	4.0K	0B	100%	/proc
/dev/ad1s1f	23G	13G	7.7G	64%	/var

lcc2-re0:

Filesystem	Size	Used	Avail	Capacity	Mounted on
/dev/ad0s1a	3.4G	178M	2.9G	6%	/
devfs	1.0K	1.0K	0B	100%	/dev
devfs	1.0K	1.0K	0B	100%	/dev/
/dev/md0	33M	33M	0B	100%	/packages/mnt/jbase
/dev/md1	216M	216M	0B	100%	
/packages/mnt/jkernel-9.6-20090519.0					
/dev/md2	66M	66M	0B	100%	
/packages/mnt/jpfe-T-9.6-20090519.0					
/dev/md3	4.1M	4.1M	0B	100%	
/packages/mnt/jdocs-9.6-20090519.0					

```

/dev/md4                57M      57M      0B      100%
/packages/mnt/jroute-9.6-20090519.0
/dev/md5                15M      15M      0B      100%
/packages/mnt/jcrypto-9.6-20090519.0
/dev/md6                34M      34M      0B      100%
/packages/mnt/jpfe-common-9.6-20090519.0
/dev/md7                2.0G    10.0K    1.8G     0% /tmp
/dev/md8                2.0G    540K    1.8G     0% /mfs
/dev/ad0s1e             383M     64K    352M     0% /config
procfs                 4.0K     4.0K     0B     100% /proc
/dev/ad1s1f            23G     3.7G    17G     18% /var

```

lcc3-re0:

```

-----
Filesystem      Size      Used      Avail  Capacity  Mounted on
/dev/ad0s1a     3.4G     178M     2.9G      6% /
devfs           1.0K     1.0K      0B     100% /dev
devfs           1.0K     1.0K      0B     100% /dev/
/dev/md0        33M      33M      0B     100% /packages/mnt/jbase
/dev/md1       216M     216M      0B     100%
/packages/mnt/jkernel-9.6-20090519.0
/dev/md2        66M      66M      0B     100%
/packages/mnt/jpfe-T-9.6-20090519.0
/dev/md3        4.1M     4.1M      0B     100%
/packages/mnt/jdocs-9.6-20090519.0
/dev/md4        57M      57M      0B     100%
/packages/mnt/jroute-9.6-20090519.0
/dev/md5        15M      15M      0B     100%
/packages/mnt/jcrypto-9.6-20090519.0
/dev/md6        34M      34M      0B     100%
/packages/mnt/jpfe-common-9.6-20090519.0
/dev/md7        2.0G    10.0K    1.8G      0% /tmp
/dev/md8        2.0G    540K    1.8G      0% /mfs
/dev/ad0s1e     383M     34K    352M      0% /config
procfs         4.0K     4.0K      0B     100% /proc
/dev/ad1s1f    23G     18G     3.5G     84% /var

```

show system storage
(QFX Series)

```

user@switch> show system storage
Filesystem      Size      Used      Avail  Capacity  Mounted on
/dev/da0s2a     343M     192M    123M     61% /
devfs           1.0K     1.0K      0B     100% /dev
/dev/md0       119M     119M      0B     100% /packages/mnt/jbase
/dev/md1       513M     513M      0B     100%
/packages/mnt/jkernel-qfx-11.1R1.5
/dev/md2        37M      37M      0B     100%
/packages/mnt/jpfe-qfx-e9xxx-11.1R1.5
/dev/md3        6.0M     6.0M      0B     100%
/packages/mnt/jdocs-qfx-11.1R1.5
/dev/md4       216M     216M      0B     100%
/packages/mnt/jroute-qfx-11.1R1.5
/dev/md5        59M      59M      0B     100%
/packages/mnt/jcrypto-qfx-11.1R1.5
/dev/md6       85M      85M      0B     100%
/packages/mnt/jswitch-qfx-11.1R1.5
/dev/md7        63M      8.0K     58M      0% /tmp
/dev/da0s2f     228M     14M    196M      7% /var
/dev/da0s3d     590M     3.0M    540M      1% /var/tmp
/dev/da0s3e     104M    162K     95M      0% /config
procfs         4.0K     4.0K      0B     100% /proc

```

show system subscriber-management summary

Syntax	show system subscriber-management summary
Release Information	Command introduced in Junos OS Release 11.1.
Description	Display complete subscriber management database summary information.
Options	none—This command has no options.
Required Privilege Level	view
List of Sample Output	show system subscriber-management summary on page 1095
Output Fields	Table 155 on page 1094 lists the output fields for the show system subscriber-management summary command. Output fields are listed in the approximate order in which they appear.

Table 155: show system subscriber-management summary Output Fields

Field Name	Field Description
Graceful Restart	State of graceful Routing Engine switchover (GRES): <ul style="list-style-type: none">• Enabled• Disabled
Mastership	State of the Routing Engine: <ul style="list-style-type: none">• Master• Standby
Database	State of the subscriber management database: <ul style="list-style-type: none">• Available• Init• Not-available
Chassisd ISSU State	State of unified ISSU chassis daemon: <ul style="list-style-type: none">• ABORT• DAEMON_ISSU_PREPARE• DAEMON_ISSU_PREPARE_DONE• DAEMON_SWITCHOVER_PREPARE• DAEMON_SWITCHOVER_PREPARE_DONE• FRU_ISSU• FRU_ISSU_DONE• IDLE• UNKNOWN

Table 155: show system subscriber-management summary Output Fields (*continued*)

Field Name	Field Description
ISSU State	<p>State of unified ISSU aggregate daemon:</p> <ul style="list-style-type: none"> • ABORT • IDLE • PREPARE • READY • SWITCHOVER_PREPARE • SWITCHOVER_READY • UNKNOWN
ISSU Wait	<p>Amount of time, in seconds, requested by a daemon to perform cleanup. If multiple daemons request time, the displayed value is the highest wait time requested by a daemon.</p>


Sample Output

```

show system subscriber-management summary
user@host> show system subscriber-management summary
General:
Graceful Restart      Enabled
Mastership            Master
Database              Available
Chassisd ISSU State   DAEMON_ISSU_PREPARE
ISSU State            PREPARE
ISSU Wait              198

```

show system switchover

Syntax	show system switchover
Syntax (TX Matrix Router)	show system switchover <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system switchover <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system switchover <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6.
Description	Display whether graceful Routing Engine switchover is configured, the state of the kernel replication (ready or synchronizing), any replication errors, and whether the primary and standby Routing Engines are using compatible versions of the kernel database.
<div>  <p>NOTE: Issue the <code>show system switchover</code> command <i>only</i> on the backup Routing Engine. This command is <i>not</i> supported on the master Routing Engine, because the kernel-replication process daemon does not run on the master Routing Engine. This process runs only on the backup Routing Engine.</p> <p>Beginning Junos OS Release 9.6, the <code>show system switchover</code> command has been deprecated on the master Routing Engine on all routers other than a TX Matrix (switch-card chassis) or a TX Matrix Plus (switch-fabric chassis) router.</p> <p>However, in a routing matrix, if you issue the <code>show system switchover</code> command on the master Routing Engine of the TX Matrix router (or switch-card chassis), the CLI displays graceful switchover information for the master Routing Engine of the T640 routers (or line-card chassis) in the routing matrix. Likewise, if you issue the <code>show system switchover</code> command on the master Routing Engine of a TX Matrix Plus router (or switch-fabric chassis), the CLI displays output for the master Routing Engine of T1600 routers (or line-card chassis) in the routing matrix.</p> </div>	
Options	all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display graceful Routing Engine switchover information for all Routing Engines on the TX Matrix router and the T640 routers configured in the routing matrix. On a TX Matrix Plus router, display graceful Routing Engine switchover information for all

Routing Engines on the TX Matrix Plus router and the T1600 routers configured in the routing matrix.

all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display graceful Routing Engine switchover information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display graceful Routing Engine switchover information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.

all-members—(MX Series routers only) (Optional) Display graceful Routing Engine switchover information for all Routing Engines on all members of the Virtual Chassis configuration.

lcc *number*—(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display graceful Routing Engine switchover information for a specific T640 router (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display graceful Routing Engine switchover information for a specific T1600 router (or line-card chassis) connected to the TX Matrix Plus router. Replace ***number*** with **0**.

local—(MX Series routers only) (Optional) Display graceful Routing Engines switchover information for all Routing Engines on the local Virtual Chassis member.

member *member-id*—(MX Series routers only) (Optional) Display graceful Routing Engine switchover information for all Routing Engines on the specified member of the Virtual Chassis configuration. Replace ***member-id*** with a value of 0 or 1.

scc—(TX Matrix router only) (Optional) Display graceful Routing Engine switchover information for the TX Matrix router (or switch-card chassis).

sfc—(TX Matrix Plus router only) (Optional) Display graceful Routing Engine switchover information for the TX Matrix Plus router (or switch-fabric chassis).

Additional Information If you issue the **show system switchover** command on a TX Matrix backup Routing Engine, the command is broadcast to all the T640 backup Routing Engines that are connected to it.

Likewise, if you issue the **show system switchover** command on a TX Matrix Plus backup Routing Engine, the command is broadcast to all the T1600 backup Routing Engines that are connected to it.

If you issue the **show system switchover** command on the active Routing Engine in the master router of an MX Series Virtual Chassis, the router displays an error message that graceful Routing Engine switchover (GRES) is not enabled on this member.

Required Privilege Level

view

List of Sample Output

show system switchover (Backup Routing Engine) on page 1098
show system switchover all-lcc (Routing Matrix) on page 1098

Output Fields Table 156 on page 1098 describes the output fields for the **show system switchover** command. Output fields are listed in the approximate order in which they appear.

Table 156: show system switchover Output Fields

Field Name	Field Description
Graceful switchover	Display graceful Routing Engine switchover status: <ul style="list-style-type: none"> • On—Indicates graceful-switchover is specified for the routing-options configuration command. • Off—Indicates graceful-switchover is not specified for the routing-options configuration command.
Configuration database	State of the configuration database: <ul style="list-style-type: none"> • Ready—Configuration database has synchronized. • Synchronizing—Configuration database is synchronizing. Displayed when there are updates within the last 5 seconds. • Synchronize failed—Configuration database synchronize process failed.
Kernel database	State of the kernel database: <ul style="list-style-type: none"> • Ready—Kernel database has synchronized. • Synchronizing—Kernel database is synchronizing. Displayed when there are updates within the last 5 seconds. • Version incompatible—The primary and standby Routing Engines are running incompatible kernel database versions. • Replication error—An error occurred when the state was replicated from the primary Routing Engine. Inspect /var/log/ksyncd for possible causes, or notify Juniper Networks customer support.
Peer state	Routing Engine peer state: <ul style="list-style-type: none"> • Steady State—Peer completed switchover transition. • Peer Connected—Peer in switchover transition.

Sample Output

```

show system switchover (Backup Routing Engine)
user@host> show system switchover
Graceful switchover: On
Configuration database: Ready
Kernel database: Ready
Peer state: Steady State

show system switchover all-lcc (Routing Matrix)
user@host> show system switchover all-lcc

1cc0-re0:
-----
Multichassis replication: On
Configuration database: Ready
Kernel database: Ready
Peer state: Steady State
1cc2-re0:
-----
Multichassis replication: On
Configuration database: Ready
Kernel database: Ready
Peer state: Steady State

```


show system uptime

Syntax	show system uptime
Syntax (EX Series Switch)	show system uptime <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system uptime <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system uptime <detail> <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system uptime <all-members> <invoke-on> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the current time and information about how long the router or switch, router or switch software, and routing protocols have been running.
Options	<p>none—Show time since the system rebooted and processes started.</p> <p>all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Show time since the system rebooted and processes started on all the routers in the chassis.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show time since the system rebooted and processes started for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, show time since the system rebooted and processes started for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Show time since the system rebooted and processes started on all members of the Virtual Chassis configuration.</p> <p>invoke-on—(MX Series routers only) (Optional) Display the time since the system rebooted and processes started on the master Routing Engine, backup Routing Engine, or both, on a router with two Routing Engines.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show time since the system rebooted and processes started for a specific T640</p>

router that is connected to the TX Matrix router. On a TX Matrix Plus router, show time since the system rebooted and processes started for a specific T1600 router that is connected to the TX Matrix Plus router. Replace **number** with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Show time since the system rebooted and processes started on the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Show time since the system rebooted and processes started on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace **member-id** with a value from 0 through 9. For an MX Series Virtual Chassis, replace **member-id** with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Show time since the system rebooted and processes started for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Show time since the system rebooted and processes started for the TX Matrix Plus router (or switch-fabric chassis). Replace **number** with 0.

Additional Information By default, when you issue the **show system uptime** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

Related Documentation

- Monitoring System Process Information
- Monitoring System Properties
- 10-Gigabit Ethernet LAN/WAN PIC with XFP (T640 Router)

List of Sample Output

show system uptime on page 1102
show system uptime all-lcc (TX Matrix Router) on page 1102
show system uptime all-lcc (TX Matrix Plus Router) on page 1102
show system uptime (QFX Series) on page 1103

Output Fields Table 157 on page 1101 describes the output fields for the **show system uptime** command. Output fields are listed in the approximate order in which they appear.

Table 157: show system uptime Output Fields

Field Name	Field Description
Current time	Current system time in UTC.

Table 157: show system uptime Output Fields (*continued*)

Field Name	Field Description
System booted	Date and time when the Routing Engine on the router or switch was last booted and how long it has been running.
Protocols started	Date and time when the routing protocols were last started and how long they have been running.
Last configured	Date and time when a configuration was last committed. Also shows name of user who issued the last commit command.
time and up	Current time, in the local time zone, and how long the router or switch has been operational.
users	Number of users logged in to the router or router.
load averages	Load averages for the last 1 minute, 5 minutes, and 15 minutes.

Sample Output

```

show system uptime user@host> show system uptime
Current time:      1998-10-13 19:45:47 UTC
System booted:     1998-10-12 20:51:41 UTC (22:54:06 ago)
Protocols started: 1998-10-13 19:33:45 UTC (00:12:02 ago)
Last configured:   1998-10-13 19:33:45 UTC (00:12:02 ago) by abc
12:45PM up 22:54, 2 users, load averages: 0.07, 0.02, 0.01

```

```

show system uptime user@host> show system uptime all-lcc
all-lcc (TX Matrix lcc0-re0:
Router) -----
Current time: 2004-09-13 09:55:35 PDT
System booted: 2004-09-13 03:13:55 PDT (06:41:40 ago)
Last configured: 2004-09-13 03:17:48 PDT (06:37:47 ago) by root
9:55AM PDT up 6:42, 1 user, load averages: 0.02, 0.03, 0.00
lcc2-re0:
-----
Current time: 2004-09-13 09:55:35 PDT
System booted: 2004-09-12 03:23:43 PDT (1d 06:31 ago)
Last configured: 2004-09-13 03:05:36 PDT (06:49:59 ago) by root
9:55AM PDT up 1 day, 6:32, 1 user, load averages: 0.02, 0.01, 0.00

```

```

show system uptime user@host> show system uptime all-lcc
all-lcc (TX Matrix Plus sfc0-re0:
Router) -----
Current time: 2009-05-25 00:24:30 PDT
System booted: 2009-05-24 06:39:33 PDT (17:44:57 ago)
Protocols started: 2009-05-24 06:40:30 PDT (17:44:00 ago)
Last configured: 2009-05-24 06:33:27 PDT (17:51:03 ago) by gregdo
12:24AM up 17:45, 2 users, load averages: 0.07, 0.05, 0.01

lcc0-re0:
-----
Current time: 2009-05-25 00:24:30 PDT
System booted: 2009-05-24 06:39:46 PDT (17:44:44 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:47 PDT (17:43:43 ago) by root

```

```
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

```
lcc1-re0:
```

```
-----
Current time: 2009-05-25 00:24:30 PDT
System booted: 2009-05-24 06:39:38 PDT (17:44:52 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:18 PDT (17:44:12 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

```
lcc2-re0:
```

```
-----
Current time: 2009-05-25 00:24:30 PDT
System booted: 2009-05-24 06:39:48 PDT (17:44:42 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:44 PDT (17:43:46 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

```
lcc3-re0:
```

```
-----
Current time: 2009-05-25 00:24:30 PDT
System booted: 2009-05-24 06:39:44 PDT (17:44:46 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:08 PDT (17:44:22 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

show system uptime (QFX Series)

```
user@switch> show system uptime
Current time: 2010-08-27 03:12:30 PDT
System booted: 2010-08-13 17:11:54 PDT (1w6d 10:00 ago)
Protocols started: 2010-08-13 17:13:56 PDT (1w6d 09:58 ago)
Last configured: 2010-08-26 05:54:00 PDT (21:18:30 ago) by regress
3:12AM up 13 days, 10:01, 3 users, load averages: 0.00, 0.00, 0.00
```

show system users

Syntax	show system users <no-resolve>
Syntax (TX Matrix Router)	show system users <all-chassis all-lcc lccnumber scc> <no-resolve>
Syntax (TX Matrix Plus Router)	show system users <detail> <all-chassis all-lcc lcc number sfc number> <no-resolve>
Syntax (MX Series Router)	show system users <all-members> <local> <member member-id> <no-resolve>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	List information about the users who are currently logged in to the router or switch.



NOTE: The **show system users** command does not list information about the automated users that are currently logged in to the router or switch from a remote client application using Junos XML APIs, such as NETCONF. It only shows details of administrative users that are logged in to a router or switch using the CLI, J-Web, or an SSH client.

Options	none—List information about the users who are currently logged in to the router or switch.
	all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Show users currently logged in to all the routers in the chassis.
	all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show users currently logged in to all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, show users currently logged in to all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.
	all-members—(MX Series routers only) (Optional) Display users currently logged in to all members of the Virtual Chassis configuration.
	lcc number—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show users currently logged in to a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, show users currently logged in to a specific

T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(MX Series routers only) (Optional) Display users currently logged in to the local Virtual Chassis member.

member *member-id*—(MX Series routers only) (Optional) Display users currently logged in to the specified member of the Virtual Chassis configuration. Replace *member-id* with a value of 0 or 1.

no-resolve—(Optional) Do not attempt to resolve IP addresses to hostnames.

scc—(TX Matrix routers only) (Optional) Show users currently logged in to the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Show users currently logged in to the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show system users** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show system users on page 1106**
show system users lcc no-resolve (TX Matrix and TX Matrix Plus Router) on page 1106
show system users (TX Matrix Plus Router) on page 1106
show system users (FX-Series switches) on page 1107
show system users no-resolve (FX-Series switches) on page 1107
show system users (QFX Series) on page 1107
show system users no-resolve (QFX Series) on page 1107

Output Fields Table 158 on page 1105 describes the output fields for the **show system users** command. Output fields are listed in the approximate order in which they appear.

Table 158: show system users Output Fields

Field Name	Field Description
<i>time and up</i>	Current time, in the local time zone, and how long the router or switch has been operational.
<i>users</i>	Number of users logged in to the router or switch.
<i>load averages</i>	Load averages for the last 1 minute, 5 minutes, and 15 minutes.
<i>USER</i>	Username.

Table 158: show system users Output Fields (*continued*)

Field Name	Field Description
TTY	Terminal through which the user is logged in.
FROM	System from which the user has logged in. A hyphen indicates that the user is logged in through the console.
LOGIN@	Time when the user logged in.
IDLE	How long the user has been idle.
WHAT	Processes that the user is running.

Sample Output

```

show system users  user@host> show system users
                    7:30PM up 4 days, 2:26, 2 users, load averages: 0.07, 0.02, 0.01
USER   TTY FROM          LOGIN@  IDLE WHAT
root   d0  -              Fri05PM 4days -csh (csh)
blue   p0  leve15.company.net 7:30PM  - cli

```

```

show system users lcc  user@host> show system users lcc 2 no-resolve
no-resolve (TX Matrix
and TX Matrix Plus
Router)
lcc2-re0:
-----
10:34AM PDT up 1 day, 7:11, 5 users, load averages: 0.03, 0.01, 0.00
USER   TTY FROM          LOGIN@  IDLE WHAT
root   d0  -              3:21AM  7:12 /bin/csh
regress p0  scc-re0        10:15AM  - telnet hostA
regress p1  scc-re0        10:16AM  - telnet hostA
regress p2  scc-re0        10:19AM  - telnet hostA
regress p3  scc-re0        10:24AM  - telnet hostA

```

```

show system users (TX  user@host> show system users
Matrix Plus Router)  sfc0-re0:
-----
1:41AM up 26 mins, 3 users, load averages: 0.08, 0.04, 0.03
USER   TTY FROM          LOGIN@  IDLE WHAT
regress p0  10.209.208.123 1:18AM  21 cli
regress p1  172.17.29.207  1:37AM  2 cli
regress p2  172.17.28.19   1:40AM  - cli

lcc0-re0:
-----
1:41AM up 26 mins, 0 users, load averages: 0.00, 0.00, 0.03

lcc1-re0:
-----
1:41AM up 26 mins, 0 users, load averages: 0.00, 0.02, 0.03

lcc2-re0:
-----
1:41AM up 26 mins, 0 users, load averages: 0.16, 0.06, 0.02

lcc3-re0:

```

```
-----
1:41AM up 26 mins, 0 users, load averages: 0.12, 0.04, 0.04
```

```
regress@aj> show system users
sfc0-re0:
```

```
-----
1:42AM up 28 mins, 4 users, load averages: 0.02, 0.03, 0.02
USER      TTY      FROM                                LOGIN@  IDLE WHAT
regress   p0       pssraj-t61.jnpr.net                1:18AM  22 cli
regress   p1       eng-shell14.juniper.net            1:37AM  - cli
regress   p2       bigpink.juniper.net                1:40AM  - cli
regress   p3       sv-cutty-01.englab.juniper.net      1:42AM  - csh (csh)
```

```
lcc0-re0:
```

```
-----
1:42AM up 28 mins, 0 users, load averages: 0.02, 0.01, 0.03
```

```
lcc1-re0:
```

```
-----
1:42AM up 28 mins, 0 users, load averages: 0.07, 0.04, 0.03
```

```
lcc2-re0:
```

```
-----
1:42AM up 27 mins, 0 users, load averages: 0.07, 0.06, 0.02
```

```
lcc3-re0:
```

```
-----
1:42AM up 28 mins, 0 users, load averages: 0.05, 0.04, 0.04
```

**show system users
(FX-Series switches)**

```
user@switch> show system users
USER      TTY      FROM                                LOGIN@  IDLE WHAT
tlewis    p0       172.22.18.117                     2:54AM  39 -cli (cli)
tlewis    p1       172.22.18.117                     3:01AM  - -cli (cli)
tcheng    p2       172.22.17.197                     3:08AM  11 -cli (cli)
```

**show system users
no-resolve (FX-Series
switches)**

```
user@switch> show system users no-resolve
USER      TTY      FROM                                LOGIN@  IDLE WHAT
tlewis    p0       172.22.18.117                     2:54AM  39 -cli (cli)
tlewis    p1       172.22.18.117                     3:01AM  - -cli (cli)
tcheng    p2       172.22.17.197                     3:08AM  11 -cli (cli)
```

**show system users
(QFX Series)**

```
user@switch> show system users
USER      TTY      FROM                                LOGIN@  IDLE WHAT
tlewis    p0       172.22.18.117                     2:54AM  39 -cli (cli)
tlewis    p1       172.22.18.117                     3:01AM  - -cli (cli)
tcheng    p2       172.22.17.197                     3:08AM  11 -cli (cli)
```

**show system users
no-resolve (QFX
Series)**

```
user@switch> show system users no-resolve
USER      TTY      FROM                                LOGIN@  IDLE WHAT
tlewis    p0       172.22.18.117                     2:54AM  39 -cli (cli)
tlewis    p1       172.22.18.117                     3:01AM  - -cli (cli)
tcheng    p2       172.22.17.197                     3:08AM  11 -cli (cli)
```

show system virtual-memory

Syntax	show system virtual-memory
Syntax (EX Series)	show system virtual-memory <all-members> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show system virtual-memory <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show system virtual-memory <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> >
Syntax (MX Series Router)	show system virtual-memory <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the usage of Junos OS kernel memory listed first by size of allocation and then by type of usage. Use the show system virtual-memory command for troubleshooting with Juniper Networks Customer Support.
Options	none—Display kernel dynamic memory usage information. all-chassis—(TX Matrix and TX Matrix Plus routers only) (Optional) Display kernel dynamic memory usage information for all chassis. all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display kernel dynamic memory usage information for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display kernel dynamic memory usage information for all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router. all-members—(EX4200 switches and MX Series routers only) (Optional) Display kernel dynamic memory usage information for all members of the Virtual Chassis configuration. lcc <i>number</i> —(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display kernel dynamic memory usage information for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, display kernel dynamic memory usage information for a specific T1600 router that is connected to the TX Matrix Plus router. Replace <i>number</i> with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display kernel dynamic memory usage information for the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display kernel dynamic memory usage information for the specified member of the Virtual Chassis configuration. For EX4200 switches, replace ***member-id*** with a value from 0 through 9. For an MX Series Virtual Chassis, replace ***member-id*** with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display kernel dynamic memory usage information for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Display kernel dynamic memory usage information for the TX Matrix Plus router (or switch-fabric chassis). Replace ***number*** with 0.

Additional Information By default, when you issue the **show system virtual-memory** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.



NOTE: The **show system virtual-memory** command with the **| display XML** pipe option now displays XML output for the command in the parent tags: **<vmstat-memstat-malloc>**, **<vmstat-memstat-zone>**, **<vmstat-sumstat>**, **<vmstat-intr>**, and **<vmstat-kernel-state>** with each child element as a separate XML tag. In Junos OS Releases 10.1 and earlier, the **| display XML** option for this command does not have an XML API element and the entire output is displayed in a single **<output>** tag element.

Required Privilege Level	view
List of Sample Output	show system virtual-memory on page 1111 show system virtual-memory scc (TX Matrix Router) on page 1115 show system virtual-memory sfc (TX Matrix Plus Router) on page 1116 show system virtual-memory display xml on page 1119 show system virtual-memory (QFX Series) on page 1141
Output Fields	Table 159 on page 1110 lists the output fields for the show system virtual-memory command. Output fields are listed in the approximate order in which they appear.

Table 159: show system virtual-memory Output Fields

Field Name	Field Description
Memory statistics by bucket size	
Size	Memory block size (bytes). The kernel memory allocator appropriates blocks of memory whose size is exactly a power of 2.
In Use	Number of memory blocks of this size that are in use (bytes).
Free	Number of memory blocks of this size that are free (bytes).
Requests	Number of memory allocation requests made.
HighWater	Maximum value the free list can have. Once the system starts reclaiming physical memory, it continues until the free list is increased to this value.
Couldfree	Total number of times that the free elements for a bucket size exceed the high-water mark for that bucket size.
Memory usage type by bucket size	
Size	Memory block size (bytes).
Type(s)	Kernel modules that are using these memory blocks. For a definition of each type, refer to a FreeBSD book.
Memory statistics by type	
Type	Kernel module that is using dynamic memory.
InUse	Number of memory blocks used by this type. The number is rounded up.
MemUse	Amount of memory in use, in kilobytes (KB).
HighUse	Maximum memory ever used by this type.
Limit	Maximum memory that can be allocated to this type.
Requests	Total number of dynamic memory allocation requests this type has made.
Type Limit	Number of times requests were blocked for reaching the maximum limit.
Kern Limit	Number of times requests were blocked for the kernel map.
Size(s)	Memory block sizes this type is using.
Memory Totals	
In Use	Total kernel dynamic memory in use (bytes, rounded up).
Free	Total kernel dynamic memory free (bytes, rounded up).

Table 159: show system virtual-memory Output Fields (*continued*)

Field Name	Field Description
Requests	Total number of memory allocation requests.
ITEM	Kernel module that is using memory.
Size	Memory block size (bytes).
Limit	Maximum memory that can be allocated to this type.
Used	Number of memory blocks used by this type. The number is rounded up.
Free	Number of memory blocks available to this type.
Requests	Total number of memory allocation requests this type has made.
interrupt	Timer events and scheduling interruptions.
total	Total number of interruptions for each type.
rate	Interruption rate.
Total	Total for all interruptions.

Sample Output

```

show system virtual-memory user@host> show system virtual-memory
Memory statistics by bucket size
Size    In Use   Free    Requests  HighWater  Couldfree
16      906     118     154876    1280       0
32      455     313     209956    640        0
64      4412    260     75380     320        20
128     3200    32      19361     160        81
256     1510    10      8844      80         4
512     446     2       5085      40         0
1K      18      2       5901      20         0
2K      1128    2       4445      10        1368
4K      185     1       456       5          0
8K      5       1       2653      5          0
16K     181     0       233       5          0
32K     2       0       1848      5          0
64K     20      0       22        5          0
128K    5       0       5         5          0
256K    2       0       2         5          0
512K    1       0       1         5          0

Memory usage type by bucket size
Size    Type(s)
16      uc_devlist, nexusdev, iftable, temp, devbuf, atexit, COS, BPF,
        DEVFS mount, DEVFS node, vnodes, mount, pcb, soname, proc-args, kld,
        MD disk, rman, ATA generic, bus, sysctl, ippool, pfestat, ifstate,
        pfe_ipc, mkey, rtable, ifmaddr, ipfw, rnode
32      atkbddev, dirrem, mkdir, diradd, freefile, freefrag, indirdep,

```

```

        bmsafemap, newblk, temp, devbuf, COS, vnodes, cluster_save buffer,
        pcb, soname, proc-args, sigio, kld, Gzip trees, taskqueue, SWAP,
        eventhandler, bus, sysctl, uidinfo, subproc, pgrp, pfestat, itable32,
        ifstate, pfe_ipc, mkey, rtable, ifmaddr, ipfw, rnode, rtnexthop
64  isadev, iftable, MFS node, allocindir, allocdirect, pagedep, temp,
        devbuf, lockf, COS, NULLFS hash, DEVFS name, vnodes,
        cluster_save buffer, vfscache, pcb, soname, proc-args, file,
        AR driver, AD driver, Gzip trees, rman, eventhandler, bus, sysctl,
        subproc, pfestat, pic, ifstate, pfe_ipc, mkey, ifaddr, rtable, ipfw
128  ZONE, freeblks, inodedep, temp, devbuf, zombie, COS, DEVFS node,
        vnodes, mount, vfscache, pcb, soname, proc-args, ttys, dev_t,
        timecounter, kld, Gzip trees, ISOFS node, bus, uidinfo, cred,
        session, pic, itable16, ifstate, pfe_ipc, rtable, ifstat, metrics,
        rtnexthop, iffamily
256  iflogical, iftable, MFS node, FFS node, newblk, temp, devbuf,
        NFS daemon, vnodes, proc-args, kqueue, file desc, Gzip trees, bus,
        subproc, itable16, ifstate, pfe_ipc, sysctl, rtnexthop
512  UFS mount, temp, devbuf, mount, BIO buffer, ptys, ttys, AR driver,
        Gzip trees, ISOFS mount, msg, ioctlops, ATA generic, bus, proc,
        pfestat, lr, ifstate, pfe_ipc, rtable, ipfw, ifstat, rtnexthop
1K   iftable, temp, devbuf, NQNFS Lease, kqueue, kld, AD driver,
        Gzip trees, sem, MD disk, bus, ifstate, pfe_ipc, ipfw
2K   uc_devlist, UFS mount, temp, devbuf, BIO buffer, pcb, AR driver,
        Gzip trees, ioctlops, bus, ipfw, ifstat, rcache
4K   memdesc, iftable, UFS mount, temp, devbuf, kld, Gzip trees, sem, msg
8K   temp, devbuf, syncache, Gzip trees
16K  indirdep, temp, devbuf, shm, msg
32K  pagedep, kld, Gzip trees
64K  VM pgdata, devbuf, MSDOSFS mount
128K UFS ihash, inodedep, NFS hash, kld, ISOFS mount
256K mbuf, vfscache
512K SWAP

```

Memory statistics by type					Type	Kern	
Type	InUse	MemUse	HighUse	Limit	Requests	Limit	Limit Size(s)
isadev	13	1K	1K127753K	13	0	0	64
atkbddev	2	1K	1K127753K	2	0	0	32
uc_devlist	24	3K	3K127753K	24	0	0	16,2K
nexusdev	3	1K	1K127753K	3	0	0	16
memdesc	1	4K	4K127753K	1	0	0	4K
mbuf	1	152K	152K127753K	1	0	0	256K
iflogical	6	2K	2K127753K	6	0	0	256
iftable	17	9K	9K127753K	18	0	0	16,64,256,1K,4K
ZONE	15	2K	2K127753K	15	0	0	128
VM pgdata	1	64K	64K127753K	1	0	0	64K
UFS mount	12	26K	26K127753K	12	0	0	512,2K,4K
UFS ihash	1	128K	128K127753K	1	0	0	128K
MFS node	6	2K	3K127753K	35	0	0	64,256
FFS node	906	227K	227K127753K	1352	0	0	256
dirrem	0	0K	4K127753K	500	0	0	32
mkdir	0	0K	1K127753K	38	0	0	32
diradd	0	0K	6K127753K	521	0	0	32
freefile	0	0K	4K127753K	374	0	0	32
freeblks	0	0K	8K127753K	219	0	0	128
freefrag	0	0K	1K127753K	193	0	0	32
allocindir	0	0K	25K127753K	1518	0	0	64
indirdep	0	0K	17K127753K	76	0	0	32,16K
allocdirect	0	0K	10K127753K	760	0	0	64
bmsafemap	0	0K	1K127753K	72	0	0	32
newblk	1	1K	1K127753K	2279	0	0	32,256
inodedep	1	128K	175K127753K	2367	0	0	128,128K

pagedep	1	32K	33K127753K	47	0	0	64,32K
temp	1239	92K	96K127753K	8364	0	0	16,32,64K
devbuf	1413	5527K	5527K127753K	1535	0	0	16,32,64,128,256
lockf	38	3K	3K127753K	2906	0	0	64
atexit	1	1K	1K127753K	1	0	0	16
zombie	0	0K	2K127753K	3850	0	0	128
NFS hash	1	128K	128K127753K	1	0	0	128K
NQNFS Lease	1	1K	1K127753K	1	0	0	1K
NFS daemon	1	1K	1K127753K	1	0	0	256
syncache	1	8K	8K127753K	1	0	0	8K
COS	353	44K	44K127753K	353	0	0	16,32,64,128
BPF	189	3K	3K127753K	189	0	0	16
MSDOSFS mount	1	64K	64K127753K	1	0	0	64K
NULLFS hash	1	1K	1K127753K	1	0	0	64
DEVFS mount	2	1K	1K127753K	2	0	0	16
DEVFS name	487	31K	31K127753K	487	0	0	64
DEVFS node	471	58K	58K127753K	479	0	0	16,128
vnodes	28	7K	7K127753K	429	0	0	16,32,64,128,256
mount	15	8K	8K127753K	18	0	0	16,128,512
cluster_save buffer	0	0K	1K127753K	55	0	0	32,64
vfscache	1898	376K	376K127753K	3228	0	0	64,128,256K
BIO buffer	49	98K	398K127753K	495	0	0	512,2K
pcb	159	16K	17K127753K	399	0	0	16,32,64,128,2K
soname	82	10K	10K127753K	42847	0	0	16,32,64,128
proc-args	57	2K	3K127753K	2105	0	0	16,32,64,128,256
ptys	32	16K	16K127753K	32	0	0	512
ttys	254	33K	33K127753K	522	0	0	128,512
kqueue	5	3K	4K127753K	23	0	0	256,1K
sigio	1	1K	1K127753K	27	0	0	32
file	383	24K	24K127753K	16060	0	0	64
file desc	76	19K	20K127753K	3968	0	0	256
shm	1	12K	12K127753K	1	0	0	16K
dev_t	286	36K	36K127753K	286	0	0	128
timecounter	10	2K	2K127753K	10	0	0	128
kld	11	117K	122K127753K	34	0	0	16,32,128,1K,4K
AR driver	1	1K	3K127753K	5	0	0	64,512,2K
AD driver	2	2K	3K127753K	2755	0	0	64,1K
Gzip trees	0	0K	46K127753K	133848	0	0	32,64,128,256
ISOFS node	1136	142K	142K127753K	1189	0	0	128
ISOFS mount	9	132K	132K127753K	10	0	0	512,128K
sem	3	6K	6K127753K	3	0	0	1K,4K
MD disk	2	2K	2K127753K	2	0	0	16,1K
msg	4	25K	25K127753K	4	0	0	512,4K,16K
rman	59	4K	4K127753K	461	0	0	16,64
ioctlops	0	0K	2K127753K	992	0	0	512,2K
taskqueue	2	1K	1K127753K	2	0	0	32
SWAP	2	413K	413K127753K	2	0	0	32,512K
ATA generic	6	3K	3K127753K	6	0	0	16,512
eventhandler	17	1K	1K127753K	17	0	0	32,64
bus	340	30K	31K127753K	794	0	0	16,32,64,128,256
sysctl	0	0K	1K127753K	130262	0	0	16,32,64
uidinfo	4	1K	1K127753K	10	0	0	32,128
cred	22	3K	3K127753K	3450	0	0	128
subproc	156	10K	10K127753K	7882	0	0	32,64,256
proc	2	1K	1K127753K	2	0	0	512
session	12	2K	2K127753K	34	0	0	128
pgrp	16	1K	1K127753K	45	0	0	32
ippool	1	1K	1K127753K	1	0	0	16
pfestat	0	0K	1K127753K	47349	0	0	16,32,64,512
pic	5	1K	1K127753K	5	0	0	64,128
lr	1	1K	1K127753K	1	0	0	512

itable32	110	4K	4K127753K	110	0	0	32
itable16	161	26K	26K127753K	161	0	0	128,256
ifstate	694	159K	160K127753K	1735	0	0	16,32,64,128,1K
pfe_ipc	0	0K	1K127753K	56218	0	0	16,32,64,128,1K
mkey	250	4K	4K127753K	824	0	0	16,32,64
ifaddr	9	1K	1K127753K	9	0	0	64
sysctl	0	0K	1K127753K	30	0	0	256
rtable	49	6K	6K127753K	307	0	0	16,32,64,128,512
ifmaddr	22	1K	1K127753K	22	0	0	16,32
ipfw	23	10K	10K127753K	48	0	0	16,32,64,512,2K
ifstat	698	805K	805K127753K	698	0	0	128,512,2K
rcache	4	8K	8K127753K	4	0	0	2K
rnode	27	1K	1K127753K	285	0	0	16,32
metrics	1	1K	1K127753K	3	0	0	128
rtnexthop	57	9K	9K127753K	312	0	0	32,128,256,512
iffamily	12	2K	2K127753K	12	0	0	128

Memory Totals: In Use Free Requests
9311K 54K 489068

ITEM	SIZE	LIMIT	USED	FREE	REQUESTS
PIPE:	192,	0,	4,	81,	4422
SWAPMETA:	160,	95814,	0,	0,	0
unpcb:	160,	0,	114,	36,	279
ripcb:	192,	25330,	5,	37,	5
syncache:	128,	15359,	0,	64,	5
tcpcb:	576,	25330,	23,	12,	32
udpcb:	192,	25330,	14,	28,	255
socket:	256,	25330,	246,	26,	819
KNOTE:	96,	0,	27,	57,	71
NFSNODE:	352,	0,	0,	0,	0
NFSMOUNT:	544,	0,	0,	0,	0
VNODE:	224,	0,	2778,	43,	2778
NAMEI:	1024,	0,	0,	8,	40725
VMSPACE:	192,	0,	57,	71,	3906
PROC:	448,	0,	73,	17,	3923
DP fakepg:	64,	0,	0,	0,	0
PV ENTRY:	28,	499566,	44530,	152053,	1525141
MAP ENTRY:	48,	0,	1439,	134,	351075
KMAP ENTRY:	48,	35645,	179,	119,	10904
MAP:	108,	0,	7,	3,	7
VM OBJECT:	92,	0,	2575,	109,	66912

792644 cpu context switches
9863474 device interrupts
286510 software interrupts
390851 traps
3596829 system calls
16 kernel threads created
3880 fork() calls
27 vfork() calls
0 rfork() calls
0 swap pager pageins
0 swap pager pages paged in
0 swap pager pageouts
0 swap pager pages paged out
380 vnode pager pageins
395 vnode pager pages paged in
122 vnode pager pageouts
1476 vnode pager pages paged out
0 page daemon wakeups

```

    0 pages examined by the page daemon
    101 pages reactivated
161722 copy-on-write faults
    0 copy-on-write optimized faults
    84623 zero fill pages zeroed
    83063 zero fill pages prezeroed
    7 intransit blocking page faults
535606 total VM faults taken
    0 pages affected by kernel thread creation
238254 pages affected by fork()
    2535 pages affected by vfork()
    0 pages affected by rfork()
283379 pages freed
    0 pages freed by daemon
190091 pages freed by exiting processes
    17458 pages active
    29166 pages inactive
    0 pages in VM cache
    10395 pages wired down
134610 pages free
    4096 bytes per page
183419 total name lookups
    cache hits (90% pos + 7% neg) system 0% per-directory
    deletions 0%, falsehits 0%, toolong 0%

```

interrupt	total	rate
ata0 irq14	113338	3
mux irq7	727643	21
fxp1 irq10	1178671	34
sio0 irq4	833	0
clk irq0	3439769	99
rtc irq8	4403221	127
Total	9863475	286

show system user@host> **show system virtual-memory scc**
virtual-memory scc
(TX Matrix Router)

```

Memory statistics by bucket size
Size  In Use  Free  Requests  HighWater  Couldfree
16     898    126   749493    1280       0
32    2018    1310  980643    640       632
64    3490   13342  935420    320      5365
...

```

```

Memory usage type by bucket size
Size  Type(s)
16  uc_devlist, COS, BPF, DEVFS mount, DEVFS node, vnodes, mount, pcb,
    soname, rman, bus, sysctl, ifstate, pfe_ipc, mkey, socket, rtable,
    ifmaddr, ipfw, rnode, iftable, temp, devbuf, atexit, proc-args, kld,
    MD disk
32  atkbddev, Gzip trees, dirrem, mkdir, diradd, freefile, freefrag,
    indirdep, bmsafemap, newblk, tseg_qent, COS, vnodes,
...

```

```

Memory statistics by type
Type  InUse  MemUse  HighUse  Limit  Requests  Limit  Kern  Size(s)
isadev  12     1K     1K166400K  12     0       0     64
atkbddev  2     1K     1K166400K  2     0       0     32
uc_devlist  24    3K     3K166400K  24     0       0    16,2K
....

```

```
Memory Totals:  In Use    Free    Requests
                  6091K    1554K    2897122
```

show system
virtual-memory sfc (TX
Matrix Plus Router)

```
user@host> show system virtual-memory sfc 0
sfc0-re0:
```

```
-----
      Type InUse MemUse HighUse Requests Size(s)
CAM dev queue      1      1K      -         1      64
      entropy  1024     64K      -       1024      64
      linker   487   6272K      -       1163 16,32,64,4096,32768,131072
      USB     127     10K      -        127 16,32,64,128,256,1024,2048
      lockf     46      3K      -      98418      64
      USBdev     10      2K      -         34 16,128,2048,16384
ifstateSLLNode      0      0K      -       1096      16
      devbuf 21243 15683K      -      21810
16,32,64,128,256,512,1024,2048,4096,8192,16384,32768,65536,131072
      temp   1283     151K      -    2483472
16,32,64,128,256,512,1024,2048,4096,8192,16384,32768,65536,131072
      ip6ndp      0      0K      -          4      64
      in6ifmulti  1      1K      -          1      64
      in6grentry  1      1K      -          1      64
      iflogical   20      5K      -         29     2048
      iffamily    45      6K      -         69 32,1024,2048
      rtnexthop  266     46K      -     608013 32,256,512,1024,2048,4096
      metrics    31      4K      -          54     256
      rnode     212      4K      -     607848 16,32
      rcache      4      8K      -          4    65536
      iflist      0      0K      -          6    16,64
      ifdevice   11      8K      -         17 16,32768
      ifstat    424     472K      -        427 512,16384,65536
      ipfw       42     23K      -         145
16,32,64,128,256,512,1024,16384,32768,65536,131072
      ifmaddr   415     11K      -        415 16,32
      rtable    329     28K      -     608066 16,32,64,128,1024,16384
      sysctl      0      0K      -     887976 16,32,64,4096,16384,32768
      ifaddr     64      5K      -          70 32,64,128
      mkey      331      6K      -     12528 16,128
      pfe_ipc     0      0K      -     7299115
16,32,64,128,256,512,1024,2048,4096,8192,16384,32768,65536,131072
      ifstate 1245054 70088K      -    3040437
16,32,64,128,256,512,1024,2048,4096,8192,16384,32768
      idxbucket   1      1K      -          1     16
      itable16  5069   1250K      -       5103 1024,4096
      itable32   157     10K      -        157      64
      itable64    2      1K      -          2     128
      lr         1      1K      -          4    16384
      pic        37      6K      -         37 64,16384
      pfestat     0      0K      -       6220 32,64,128,256,131072
      gencfg   1486     424K      -       2614 16,32,64,256,512,16384,32768,65536
      jsr         2      1K      -          22     16
      idl         1      4K      -         165
32,64,128,256,512,1024,2048,8192,16384,32768,65536,131072
      rtmsg       0      0K      -          16 131072
      module    250     16K      -        250 64,128
      mtx_pool    1      8K      -          1 64,128
      DEVFS3     113     13K      -        114     256
      DEVFS1     106     24K      -        106    2048
      pgrp        15      1K      -       8600      64
      session    11      2K      -       2829     512
      proc         2      1K      -          2    16384
      subproc    296     572K      -     24689 2048,131072
```

```

      cred      38      5K      -      619244  256
      plimit    18      4K      -      21311   2048
      uidinfo    3      1K      -         10  32,512
      sysctlloid 2701    82K      -      2701   16,32,64
      sysctltmp  0       0K      -     15572  16,32,64,1024
      umtx      171    11K      -        171   64
      SWAP       2    277K      -         2    64
      bus       779   125K      -      3072  16,32,64,128,32768
      bus-sc     67    62K      -      1477
16,32,64,512,1024,2048,8192,16384,65536,131072
      devstat    8    17K      -         8  16,131072
      eventhandler 46    2K      -         47  32,128
      kobj       93   186K      -        111  65536
      DEVFS      8     1K      -         9   16,64
      rman      106    7K      -        490  16,32,64
      sbuf       0     0K      -     28234  16,32,32768,131072

```

...

lcc0-re0:

```

-----
      Type InUse MemUse HighUse Requests Size(s)
CAM dev queue    1     1K      -         1   64
      entropy  1024    64K      -     1024   64
      linker   487   6272K      -     1163  16,32,64,4096,32768,131072
      USB     127    10K      -        127  16,32,64,128,256,1024,2048
      lockf    23     2K      -    169585   64
      USBdev   10     2K      -         34  16,128,2048,16384
      devbuf   5128  10760K      -     5310
16,32,64,128,256,512,1024,2048,4096,8192,16384,32768,65536,131072
      temp    1285    151K      -     10770
16,32,64,128,256,512,2048,4096,8192,16384,32768,65536,131072
      ip6ndp    0     0K      -         4   64
      iflogical 20     5K      -         29  2048
      iffamilly 45     6K      -         69  32,1024,2048
      rtnexthop 189    29K      -    1211988  32,256,512,1024,2048,4096
      metrics   11     2K      -         16  256
      rnode    135     3K      -    606391  16,32
      rcache     4     8K      -         4  65536
      iflist    0     0K      -          6  16,64
      ifdevice  11     8K      -         17  16,32768
      ifstat   412   471K      -        415  512,16384,65536
      ipfw      42    23K      -         91
16,32,64,128,256,512,1024,16384,32768,65536,131072
      ifmaddr   415    11K      -        415  16,32
      rtable    225    20K      -    606584  16,32,64,128,1024,16384
      sysctl     0     0K      -    2302479  16,32,64
      ifaddr    53     4K      -         69  32,64,128
      mkey     133     3K      -     8974  16,128
      pfe_ipc    0     0K      -    19035108
16,32,64,128,512,1024,2048,8192,16384,32768,65536,131072
      ifstate  710270  42176K      -    9583703
16,32,64,128,256,512,1024,2048,8192,16384,32768
      idxbucket  1     1K      -         1   16
      itable16  5045   1245K      -    1825178  1024,4096
      itable32   157    10K      -        157   64
      itable64    2     1K      -          2  128
      lr        1     1K      -          4  16384
      pic       37     6K      -         37  64,16384
      pfestat    0     0K      -     1682  32,64,128,256,131072
      gencfg   1486   424K      -     2812  16,32,64,256,512,16384,32768,65536
      jsr        0     0K      -         22   16
      idl        0     0K      -          4  32768,131072

```

rtsmg	0	OK	-	3	131072
module	250	16K	-	250	64,128
mtx_pool	1	8K	-	1	64,128
DEVFS3	108	12K	-	109	256
DEVFS1	101	23K	-	101	2048
pgrp	5	1K	-	917	64
session	5	1K	-	917	512
proc	2	1K	-	2	16384
subproc	217	441K	-	4867	2048,131072
cred	21	3K	-	48719	256
plimit	9	2K	-	5255	2048
uidinfo	2	1K	-	2	32,512
sysctluid	2786	85K	-	2786	16,32,64
sysctltmp	0	OK	-	1833	16,32,64,1024
umtx	126	8K	-	126	64
SWAP	2	277K	-	2	64
bus	780	125K	-	2734	16,32,64,128,32768
bus-sc	69	69K	-	1194	
16,32,64,512,1024,2048,8192,16384,65536,131072					
devstat	8	17K	-	8	16,131072
eventhandler	45	2K	-	46	32,128
kobj	93	186K	-	111	65536
DEVFS	8	1K	-	9	16,64
rman	94	6K	-	477	16,32,64
sbuf	0	OK	-	532	16,32,32768,131072
NULLFS hash	1	1K	-	1	64
taskqueue	5	1K	-	5	64
turnstiles	127	8K	-	127	64
Unitno	6	1K	-	44	16,64
ioctlops	0	OK	-	1771718	16,32,64,128,8192,16384,65536,131072
iov	0	OK	-	79425	16,64,128,256,512,1024,2048,131072
msg	4	25K	-	4	32768,131072
sem	4	7K	-	4	16384,32768,131072
shm	2	13K	-	4	32768
ttys	93	16K	-	195	512,32768
soname	31	3K	-	389284	16,32,64,256
pcb	101	16K	-	4374	
16,32,64,128,1024,2048,4096,16384,65536					
BIO buffer	40	80K	-	750	65536
vfscache	1	512K	-	1	65536
cluster_save buffer	0	OK	-	55	32,64
VFS hash	1	256K	-	1	32,64
vnodes	1	1K	-	1	512
mount	266	21K	-	481	16,32,64,128,256,4096,32768
vnodemarker	0	OK	-	2497	16384
pfs_nodes	25	3K	-	25	128
pfs_vncache	144	5K	-	386	32
STP	1	1K	-	1	64
GEOM	173	15K	-	1068	
16,32,64,128,256,512,2048,16384,32768,131072					
synccache	1	8K	-	1	
16,32,64,128,256,512,2048,16384,32768,131072					
tlv_stat	0	OK	-	223	
16,32,64,128,256,512,2048,16384,32768,131072					
NFS daemon	1	8K	-	1	
16,32,64,128,256,512,2048,16384,32768,131072					
p1003.1b	1	1K	-	1	16
MD disk	9	18K	-	9	65536
ata_generic	2	2K	-	25	16,16384,32768
ISOFS mount	7	1K	-	13	512

ISOFS node	1439	135K	-	1453	128
CAM SIM	1	1K	-	1	64
CAM XPT	6	1K	-	9	16,64,16384
CAM periph	1	1K	-	1	128
ad_driver	2	1K	-	2	256
pagedep	1	64K	-	105	64
inodedep	1	256K	-	552	256
newblk	1	1K	-	327	64,4096
bmsafemap	0	0K	-	19	64
allocdirect	0	0K	-	326	128
freefrag	0	0K	-	31	32
freeblks	0	0K	-	103	2048
freefile	0	0K	-	175	32
diradd	0	0K	-	590	64
mkdir	0	0K	-	166	32
dirrem	0	0K	-	382	32
savedino	0	0K	-	283	512
UFS mount	15	36K	-	15	2048,65536,131072
ata_dma	6	1K	-	6	256
UMAHash	1	4K	-	5	4096,16384,32768,65536,131072
cdev	26	3K	-	26	256
file desc	111	25K	-	5199	16,1024,2048,16384
VM pgdata	2	65K	-	2	64
sigio	1	1K	-	27	32
kenv	30	5K	-	33	16,32,64,131072
atkbddev	2	1K	-	2	32
kqueue	0	0K	-	88	1024,4096,32768
proc-args	28	2K	-	3970	32,64,128,256,512,1024
isadev	23	2K	-	23	64
zombie	1	1K	-	4651	128
ithread	92	7K	-	92	16,64,256
legacydrv	3	1K	-	3	16
memdesc	1	4K	-	1	131072
nexusdev	2	1K	-	2	16
CAM queue	3	1K	-	3	16
KTRACE	100	10K	-	100	128
kbdmux	5	9K	-	5	128,2048,65536,131072
ITEM	SIZE	LIMIT	USED	FREE	REQUESTS
UMA Kegs:	136,	0,	71,	1,	71
...					

**show system
virtual-memory |
display xml**

```

user@host> show system virtual-memory | display xml
<rpc-reply xmlns:junos="http://xml.juniper.net/junos/10.2R1/junos">
  <system-virtual-memory-information>
    <vmstat-memstat-malloc>
      <memstat-name>CAM dev queue</memstat-name>
      <inuse>1</inuse>
      <memuse>1</memuse>
      <high-use>--</high-use>
      <memstat-req>1</memstat-req>
      <memstat-size>64</memstat-size>
      <memstat-name>entropy</memstat-name>
      <inuse>1024</inuse>
      <memuse>64</memuse>
      <high-use>--</high-use>
      <memstat-req>1024</memstat-req>
      <memstat-size>64</memstat-size>
      <memstat-name>linker</memstat-name>
      <inuse>481</inuse>
      <memuse>1871</memuse>
      <high-use>--</high-use>
    
```

```
<memstat-req>1145</memstat-req>
<memstat-size>16,32,64,4096,32768,131072</memstat-size>
<memstat-name>lockf</memstat-name>
<inuse>56</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>5998</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>devbuf</memstat-name>
<inuse>2094</inuse>
<memuse>3877</memuse>
<high-use>--</high-use>
<memstat-req>2099</memstat-req>

<memstat-size>16,32,64,128,512,1024,4096,8192,16384,32768,65536,131072</memstat-size>

<memstat-name>temp</memstat-name>
<inuse>21</inuse>
<memuse>66</memuse>
<high-use>--</high-use>
<memstat-req>3127</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,4096,8192,16384,32768,65536,131072</memstat-size>

<memstat-name>ip6ndp</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>in6ifmulti</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>in6greentry</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>iflogical</memstat-name>
<inuse>13</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>13</memstat-req>
<memstat-size>64,2048</memstat-size>
<memstat-name>iffamily</memstat-name>
<inuse>28</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>28</memstat-req>
<memstat-size>32,1024,2048</memstat-size>
<memstat-name>rtnextthop</memstat-name>
<inuse>127</inuse>
<memuse>18</memuse>
<high-use>--</high-use>
<memstat-req>129</memstat-req>
<memstat-size>32,256,512,1024,2048,4096</memstat-size>
<memstat-name>metrics</memstat-name>
```



```

<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>5</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>inifmulti</memstat-name>
<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>3</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>ingrentry</memstat-name>
<inuse>6</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>6</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>rnode</memstat-name>
<inuse>68</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>76</memstat-req>
<memstat-size>16,32</memstat-size>
<memstat-name>rcache</memstat-name>
<inuse>4</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>ifdevice</memstat-name>
<inuse>4</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>ifstat</memstat-name>
<inuse>40</inuse>
<memuse>22</memuse>
<high-use>--</high-use>
<memstat-req>40</memstat-req>
<memstat-size>512,16384,32768</memstat-size>
<memstat-name>ipfw</memstat-name>
<inuse>42</inuse>
<memuse>23</memuse>
<high-use>--</high-use>
<memstat-req>91</memstat-req>

<memstat-size>16,32,64,128,256,512,1024,16384,32768,65536,131072</memstat-size>
<memstat-name>ifmaddr</memstat-name>
<inuse>103</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>103</memstat-req>
<memstat-size>16,32</memstat-size>
<memstat-name>rtable</memstat-name>
<inuse>129</inuse>
<memuse>14</memuse>
<high-use>--</high-use>
<memstat-req>139</memstat-req>
<memstat-size>16,32,64,128,1024,16384</memstat-size>
<memstat-name>sysctl</memstat-name>

```

```

<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>14847</memstat-req>
<memstat-size>16,32,64,4096,16384,32768</memstat-size>
<memstat-name>ifaddr</memstat-name>
<inuse>29</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>29</memstat-req>
<memstat-size>64,128</memstat-size>
<memstat-name>mkey</memstat-name>
<inuse>345</inuse>
<memuse>6</memuse>
<high-use>--</high-use>
<memstat-req>2527</memstat-req>
<memstat-size>16,128</memstat-size>
<memstat-name>pfe_ipc</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>1422</memstat-req>

<memstat-size>16,32,64,128,512,1024,2048,8192,16384,32768,65536,131072</memstat-size>

<memstat-name>ifstate</memstat-name>
<inuse>594</inuse>
<memuse>51</memuse>
<high-use>--</high-use>
<memstat-req>655</memstat-req>

<memstat-size>16,32,64,128,256,1024,2048,4096,16384,32768</memstat-size>
<memstat-name>itable16</memstat-name>
<inuse>276</inuse>
<memuse>52</memuse>
<high-use>--</high-use>
<memstat-req>294</memstat-req>
<memstat-size>1024,4096</memstat-size>
<memstat-name>itable32</memstat-name>
<inuse>160</inuse>
<memuse>10</memuse>
<high-use>--</high-use>
<memstat-req>160</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>itable64</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>lr</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>16384</memstat-size>
<memstat-name>pic</memstat-name>
<inuse>5</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>5</memstat-req>

```

```

<memstat-size>64,512</memstat-size>
<memstat-name>pfestat</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>162</memstat-req>
<memstat-size>16,32,128,256,16384</memstat-size>
<memstat-name>gencfg</memstat-name>
<inuse>224</inuse>
<memuse>56</memuse>
<high-use>--</high-use>
<memstat-req>540</memstat-req>
<memstat-size>16,32,64,256,512,32768,65536</memstat-size>
<memstat-name>jsr</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>idl</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>13</memstat-req>
<memstat-size>16,32,64,128,256,4096,16384,32768,131072</memstat-size>

<memstat-name>rtsmsg</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>131072</memstat-size>
<memstat-name>module</memstat-name>
<inuse>249</inuse>
<memuse>16</memuse>
<high-use>--</high-use>
<memstat-req>249</memstat-req>
<memstat-size>64,128</memstat-size>
<memstat-name>mtx_pool</memstat-name>
<inuse>1</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64,128</memstat-size>
<memstat-name>DEVFS3</memstat-name>
<inuse>109</inuse>
<memuse>12</memuse>
<high-use>--</high-use>
<memstat-req>117</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>DEVFS1</memstat-name>
<inuse>102</inuse>
<memuse>23</memuse>
<high-use>--</high-use>
<memstat-req>109</memstat-req>
<memstat-size>2048</memstat-size>
<memstat-name>pgrp</memstat-name>
<inuse>12</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>21</memstat-req>

```

```
<memstat-size>64</memstat-size>
<memstat-name>session</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
<memstat-size>512</memstat-size>
<memstat-name>proc</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>16384</memstat-size>
<memstat-name>subproc</memstat-name>
<inuse>244</inuse>
<memuse>496</memuse>
<high-use>--</high-use>
<memstat-req>1522</memstat-req>
<memstat-size>2048,131072</memstat-size>
<memstat-name>cred</memstat-name>
<inuse>30</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>11409</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>plimit</memstat-name>
<inuse>17</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>133</memstat-req>
<memstat-size>2048</memstat-size>
<memstat-name>uidinfo</memstat-name>
<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>6</memstat-req>
<memstat-size>32,512</memstat-size>
<memstat-name>sysctlpid</memstat-name>
<inuse>1117</inuse>
<memuse>34</memuse>
<high-use>--</high-use>
<memstat-req>1117</memstat-req>
<memstat-size>16,32,64</memstat-size>
<memstat-name>sysctltmp</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>743</memstat-req>
<memstat-size>16,32,64,1024</memstat-size>
<memstat-name>umtx</memstat-name>
<inuse>144</inuse>
<memuse>9</memuse>
<high-use>--</high-use>
<memstat-req>144</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>SWAP</memstat-name>
<inuse>2</inuse>
<memuse>209</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>64</memstat-size>
```

```

<memstat-name>bus</memstat-name>
<inuse>496</inuse>
<memuse>55</memuse>
<high-use>--</high-use>
<memstat-req>1196</memstat-req>
<memstat-size>16,32,64,128,32768</memstat-size>
<memstat-name>bus-sc</memstat-name>
<inuse>23</inuse>
<memuse>33</memuse>
<high-use>--</high-use>
<memstat-req>335</memstat-req>

<memstat-size>16,32,64,512,1024,2048,8192,16384,65536,131072</memstat-size>
<memstat-name>devstat</memstat-name>
<inuse>10</inuse>
<memuse>21</memuse>
<high-use>--</high-use>
<memstat-req>10</memstat-req>
<memstat-size>16,131072</memstat-size>
<memstat-name>eventhandler</memstat-name>
<inuse>35</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>36</memstat-req>
<memstat-size>32,128</memstat-size>
<memstat-name>kobj</memstat-name>
<inuse>93</inuse>
<memuse>186</memuse>
<high-use>--</high-use>
<memstat-req>111</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>DEVFS</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>9</memstat-req>
<memstat-size>16,64</memstat-size>
<memstat-name>rman</memstat-name>
<inuse>71</inuse>
<memuse>5</memuse>
<high-use>--</high-use>
<memstat-req>433</memstat-req>
<memstat-size>16,32,64</memstat-size>
<memstat-name>sbuf</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>522</memstat-req>
<memstat-size>16,32,32768,131072</memstat-size>
<memstat-name>NULLFS hash</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>taskqueue</memstat-name>
<inuse>5</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>5</memstat-req>
<memstat-size>64</memstat-size>

```

```
<memstat-name>turnstiles</memstat-name>
<inuse>145</inuse>
<memuse>10</memuse>
<high-use>--</high-use>
<memstat-req>145</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>Unitno</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>44</memstat-req>
<memstat-size>16,64</memstat-size>
<memstat-name>ioclops</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>27622</memstat-req>
<memstat-size>16,64,8192,16384,131072</memstat-size>
<memstat-name>iov</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>18578</memstat-req>
<memstat-size>16,64,128,256,512,1024,2048,131072</memstat-size>
<memstat-name>msg</memstat-name>
<inuse>4</inuse>
<memuse>25</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>32768,131072</memstat-size>
<memstat-name>sem</memstat-name>
<inuse>4</inuse>
<memuse>7</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16384,32768,131072</memstat-size>
<memstat-name>shm</memstat-name>
<inuse>9</inuse>
<memuse>20</memuse>
<high-use>--</high-use>
<memstat-req>14</memstat-req>
<memstat-size>32768</memstat-size>
<memstat-name>ttys</memstat-name>
<inuse>321</inuse>
<memuse>61</memuse>
<high-use>--</high-use>
<memstat-req>528</memstat-req>
<memstat-size>512,32768</memstat-size>
<memstat-name>ptys</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>mbuf_tag</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>23383</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>soname</memstat-name>
```

```

<inuse>115</inuse>
<memuse>12</memuse>
<high-use>--</high-use>
<memstat-req>24712</memstat-req>
<memstat-size>16,32,64,256</memstat-size>
<memstat-name>pcb</memstat-name>
<inuse>216</inuse>
<memuse>33</memuse>
<high-use>--</high-use>
<memstat-req>484</memstat-req>

<memstat-size>16,32,64,128,1024,2048,4096,16384,32768,65536</memstat-size>
<memstat-name>BIO buffer</memstat-name>
<inuse>43</inuse>
<memuse>86</memuse>
<high-use>--</high-use>
<memstat-req>405</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>vfscache</memstat-name>
<inuse>1</inuse>
<memuse>256</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>cluster_save buffer</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>32,64</memstat-size>
<memstat-name>VFS hash</memstat-name>
<inuse>1</inuse>
<memuse>128</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>32,64</memstat-size>
<memstat-name>vnodes</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>512</memstat-size>
<memstat-name>mount</memstat-name>
<inuse>290</inuse>
<memuse>23</memuse>
<high-use>--</high-use>
<memstat-req>535</memstat-req>
<memstat-size>16,32,64,128,256,4096,32768</memstat-size>
<memstat-name>vnodemarker</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>498</memstat-req>
<memstat-size>16384</memstat-size>
<memstat-name>pfs_nodes</memstat-name>
<inuse>25</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>25</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>pfs_vncache</memstat-name>

```

```
<inuse>27</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>53</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>STP</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>GEOM</memstat-name>
<inuse>146</inuse>
<memuse>11</memuse>
<high-use>--</high-use>
<memstat-req>1042</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>syncache</memstat-name>
<inuse>1</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>tlv_stat</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>8</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>NFS_daemon</memstat-name>
<inuse>1</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>p1003.1b</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>MD_disk</memstat-name>
<inuse>10</inuse>
<memuse>20</memuse>
<high-use>--</high-use>
<memstat-req>10</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>ata_generic</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>6</memstat-req>
<memstat-size>16,16384,32768</memstat-size>
<memstat-name>ISOFs_mount</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
```



```

<memstat-req>15</memstat-req>
<memstat-size>512</memstat-size>
<memstat-name>ISOF5 node</memstat-name>
<inuse>1440</inuse>
<memuse>135</memuse>
<high-use>--</high-use>
<memstat-req>1457</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>CAM SIM</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>CAM XPT</memstat-name>
<inuse>6</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>9</memstat-req>
<memstat-size>16,64,16384</memstat-size>
<memstat-name>CAM periph</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>ad_driver</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>pagedep</memstat-name>
<inuse>1</inuse>
<memuse>32</memuse>
<high-use>--</high-use>
<memstat-req>106</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>inodedep</memstat-name>
<inuse>1</inuse>
<memuse>128</memuse>
<high-use>--</high-use>
<memstat-req>464</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>newblk</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>336</memstat-req>
<memstat-size>64,4096</memstat-size>
<memstat-name>bmsafemap</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>63</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>allocdirect</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>320</memstat-req>

```

```
<memstat-size>128</memstat-size>
<memstat-name>indirdep</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>17</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>allocindir</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>freefrag</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>12</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>freeblks</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>40</memstat-req>
<memstat-size>2048</memstat-size>
<memstat-name>freefile</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>101</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>diradd</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>465</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>mkdir</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>136</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>dirrem</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>168</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>newdirblk</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>savedino</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>157</memstat-req>
<memstat-size>512</memstat-size>
```

```

<memstat-name>UFS mount</memstat-name>
<inuse>15</inuse>
<memuse>36</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
<memstat-size>2048,65536,131072</memstat-size>
<memstat-name>ata_dma</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>UMAHash</memstat-name>
<inuse>1</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>4096,16384,32768,65536</memstat-size>
<memstat-name>cdev</memstat-name>
<inuse>22</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>22</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>file_desc</memstat-name>
<inuse>141</inuse>
<memuse>32</memuse>
<high-use>--</high-use>
<memstat-req>1583</memstat-req>
<memstat-size>16,1024,2048,16384</memstat-size>
<memstat-name>VM_pgdata</memstat-name>
<inuse>2</inuse>
<memuse>65</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>sigio</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>20</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>kenv</memstat-name>
<inuse>24</inuse>
<memuse>5</memuse>
<high-use>--</high-use>
<memstat-req>27</memstat-req>
<memstat-size>16,32,64,131072</memstat-size>
<memstat-name>atkbddev</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>kqueue</memstat-name>
<inuse>15</inuse>
<memuse>9</memuse>
<high-use>--</high-use>
<memstat-req>19</memstat-req>
<memstat-size>1024,4096,32768</memstat-size>
<memstat-name>proc_args</memstat-name>

```

```
<inuse>57</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>1001</memstat-req>
<memstat-size>16,32,64,128,256,512,1024</memstat-size>
<memstat-name>isadev</memstat-name>
<inuse>21</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>21</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>zombie</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>1278</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>ithread</memstat-name>
<inuse>69</inuse>
<memuse>5</memuse>
<high-use>--</high-use>
<memstat-req>69</memstat-req>
<memstat-size>16,64,256</memstat-size>
<memstat-name>legacydrv</memstat-name>
<inuse>4</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>memdesc</memstat-name>
<inuse>1</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>131072</memstat-size>
<memstat-name>nexusdev</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>CAM queue</memstat-name>
<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>3</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>$PIR</memstat-name>
<inuse>4</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>KTRACE</memstat-name>
<inuse>100</inuse>
<memuse>10</memuse>
<high-use>--</high-use>
<memstat-req>100</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>kbdmux</memstat-name>
<inuse>5</inuse>
```

```

    <memuse>9</memuse>
    <high-use>--</high-use>
    <memstat-req>5</memstat-req>
    <memstat-size>128,2048,65536,131072</memstat-size>
</vmstat-memstat-malloc>
<vmstat-memstat-zone>
    <zone-name>UMA Kegs:</zone-name>
    <zone-size>136</zone-size>
    <count-limit>0</count-limit>
    <used>71</used>
    <free>1</free>
    <zone-req>71</zone-req>
    <zone-name>UMA Zones:</zone-name>
    <zone-size>120</zone-size>
    <count-limit>0</count-limit>
    <used>71</used>
    <free>19</free>
    <zone-req>71</zone-req>
    <zone-name>UMA Slabs:</zone-name>
    <zone-size>64</zone-size>
    <count-limit>0</count-limit>
    <used>490</used>
    <free>41</free>
    <zone-req>579</zone-req>
    <zone-name>UMA RCntSlabs:</zone-name>
    <zone-size>104</zone-size>
    <count-limit>0</count-limit>
    <used>276</used>
    <free>20</free>
    <zone-req>276</zone-req>
    <zone-name>UMA Hash:</zone-name>
    <zone-size>128</zone-size>
    <count-limit>0</count-limit>
    <used>4</used>
    <free>26</free>
    <zone-req>5</zone-req>
    <zone-name>16 Bucket:</zone-name>
    <zone-size>76</zone-size>
    <count-limit>0</count-limit>
    <used>30</used>
    <free>20</free>
    <zone-req>30</zone-req>
    <zone-name>32 Bucket:</zone-name>
    <zone-size>140</zone-size>
    <count-limit>0</count-limit>
    <used>33</used>
    <free>23</free>
    <zone-req>33</zone-req>
    <zone-name>64 Bucket:</zone-name>
    <zone-size>268</zone-size>
    <count-limit>0</count-limit>
    <used>33</used>
    <free>9</free>
    <zone-req>33</zone-req>
    <zone-name>128 Bucket:</zone-name>
    <zone-size>524</zone-size>
    <count-limit>0</count-limit>
    <used>49</used>
    <free>0</free>
    <zone-req>49</zone-req>
    <zone-name>VM OBJECT:</zone-name>

```

```
<zone-size>128</zone-size>
<count-limit>0</count-limit>
<used>2111</used>
<free>79</free>
<zone-req>25214</zone-req>
<zone-name>MAP:</zone-name>
<zone-size>160</zone-size>
<count-limit>0</count-limit>
<used>7</used>
<free>41</free>
<zone-req>7</zone-req>
<zone-name>KMAP ENTRY:</zone-name>
<zone-size>68</zone-size>
<count-limit>35336</count-limit>
<used>19</used>
<free>149</free>
<zone-req>2397</zone-req>
<zone-name>MAP ENTRY:</zone-name>
<zone-size>68</zone-size>
<count-limit>0</count-limit>
<used>2031</used>
<free>153</free>
<zone-req>62417</zone-req>
<zone-name>PV ENTRY:</zone-name>
<zone-size>24</zone-size>
<count-limit>509095</count-limit>
<used>57177</used>
<free>6333</free>
<zone-req>1033683</zone-req>
<zone-name>DP fakepg:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>mt_zone:</zone-name>
<zone-size>64</zone-size>
<count-limit>0</count-limit>
<used>238</used>
<free>57</free>
<zone-req>238</zone-req>
<zone-name>16:</zone-name>
<zone-size>16</zone-size>
<count-limit>0</count-limit>
<used>2114</used>
<free>119</free>
<zone-req>80515</zone-req>
<zone-name>32:</zone-name>
<zone-size>32</zone-size>
<count-limit>0</count-limit>
<used>1335</used>
<free>134</free>
<zone-req>10259</zone-req>
<zone-name>64:</zone-name>
<zone-size>64</zone-size>
<count-limit>0</count-limit>
<used>3529</used>
<free>129</free>
<zone-req>29110</zone-req>
<zone-name>96:</zone-name>
<zone-size>96</zone-size>
```

```
<count-limit>0</count-limit>
<used>2062</used>
<free>58</free>
<zone-req>4365</zone-req>
<zone-name>112:</zone-name>
<zone-size>112</zone-size>
<count-limit>0</count-limit>
<used>361</used>
<free>164</free>
<zone-req>24613</zone-req>
<zone-name>128:</zone-name>
<zone-size>128</zone-size>
<count-limit>0</count-limit>
<used>359</used>
<free>61</free>
<zone-req>942</zone-req>
<zone-name>160:</zone-name>
<zone-size>160</zone-size>
<count-limit>0</count-limit>
<used>364</used>
<free>44</free>
<zone-req>577</zone-req>
<zone-name>224:</zone-name>
<zone-size>224</zone-size>
<count-limit>0</count-limit>
<used>422</used>
<free>20</free>
<zone-req>1950</zone-req>
<zone-name>256:</zone-name>
<zone-size>256</zone-size>
<count-limit>0</count-limit>
<used>204</used>
<free>36</free>
<zone-req>1225</zone-req>
<zone-name>288:</zone-name>
<zone-size>288</zone-size>
<count-limit>0</count-limit>
<used>2</used>
<free>24</free>
<zone-req>10</zone-req>
<zone-name>512:</zone-name>
<zone-size>512</zone-size>
<count-limit>0</count-limit>
<used>49</used>
<free>7</free>
<zone-req>911</zone-req>
<zone-name>1024:</zone-name>
<zone-size>1024</zone-size>
<count-limit>0</count-limit>
<used>213</used>
<free>11</free>
<zone-req>1076</zone-req>
<zone-name>2048:</zone-name>
<zone-size>2048</zone-size>
<count-limit>0</count-limit>
<used>199</used>
<free>113</free>
<zone-req>640</zone-req>
<zone-name>4096:</zone-name>
<zone-size>4096</zone-size>
<count-limit>0</count-limit>
```

```
<used>144</used>
<free>7</free>
<zone-req>2249</zone-req>
<zone-name>Files:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>665</used>
<free>77</free>
<zone-req>16457</zone-req>
<zone-name>MAC labels:</zone-name>
<zone-size>20</zone-size>
<count-limit>0</count-limit>
<used>3998</used>
<free>227</free>
<zone-req>21947</zone-req>
<zone-name>PROC:</zone-name>
<zone-size>544</zone-size>
<count-limit>0</count-limit>
<used>116</used>
<free>10</free>
<zone-req>1394</zone-req>
<zone-name>THREAD:</zone-name>
<zone-size>416</zone-size>
<count-limit>0</count-limit>
<used>127</used>
<free>17</free>
<zone-req>131</zone-req>
<zone-name>KSEGRP:</zone-name>
<zone-size>88</zone-size>
<count-limit>0</count-limit>
<used>127</used>
<free>73</free>
<zone-req>131</zone-req>
<zone-name>UPCALL:</zone-name>
<zone-size>44</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>SLEEPQUEUE:</zone-name>
<zone-size>32</zone-size>
<count-limit>0</count-limit>
<used>145</used>
<free>194</free>
<zone-req>145</zone-req>
<zone-name>VMSPACE:</zone-name>
<zone-size>268</zone-size>
<count-limit>0</count-limit>
<used>57</used>
<free>13</free>
<zone-req>1335</zone-req>
<zone-name>mbuf_packet:</zone-name>
<zone-size>256</zone-size>
<count-limit>180000</count-limit>
<used>256</used>
<free>128</free>
<zone-req>49791</zone-req>
<zone-name>mbuf:</zone-name>
<zone-size>256</zone-size>
<count-limit>180000</count-limit>
<used>50</used>
```



```
<free>466</free>
<zone-req>105183</zone-req>
<zone-name>mbuf_cluster:</zone-name>
<zone-size>2048</zone-size>
<count-limit>25190</count-limit>
<used>387</used>
<free>165</free>
<zone-req>5976</zone-req>
<zone-name>mbuf_jumbo_pagesize:</zone-name>
<zone-size>4096</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>mbuf_jumbo_9k:</zone-name>
<zone-size>9216</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>mbuf_jumbo_16k:</zone-name>
<zone-size>16384</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>ACL UMA zone:</zone-name>
<zone-size>388</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>g_bio:</zone-name>
<zone-size>132</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>174</free>
<zone-req>69750</zone-req>
<zone-name>ata_request:</zone-name>
<zone-size>200</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>57</free>
<zone-req>5030</zone-req>
<zone-name>ata_composite:</zone-name>
<zone-size>192</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>GENCFG:</zone-name>
<zone-size>72</zone-size>
<count-limit>1000004</count-limit>
<used>57</used>
<free>102</free>
<zone-req>57</zone-req>
<zone-name>VNODE:</zone-name>
<zone-size>292</zone-size>
<count-limit>0</count-limit>
<used>2718</used>
<free>25</free>
```

```
<zone-req>2922</zone-req>
<zone-name>VNODEPOLL:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>S VFS Cache:</zone-name>
<zone-size>68</zone-size>
<count-limit>0</count-limit>
<used>2500</used>
<free>76</free>
<zone-req>3824</zone-req>
<zone-name>L VFS Cache:</zone-name>
<zone-size>291</zone-size>
<count-limit>0</count-limit>
<used>51</used>
<free>14</free>
<zone-req>63</zone-req>
<zone-name>NAMEI:</zone-name>
<zone-size>1024</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>8</free>
<zone-req>5330</zone-req>
<zone-name>NFSMOUNT:</zone-name>
<zone-size>480</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>NFSNODE:</zone-name>
<zone-size>460</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>PIPE:</zone-name>
<zone-size>404</zone-size>
<count-limit>0</count-limit>
<used>27</used>
<free>9</free>
<zone-req>717</zone-req>
<zone-name>KNOTE:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>42</used>
<free>64</free>
<zone-req>3311</zone-req>
<zone-name>socket:</zone-name>
<zone-size>412</zone-size>
<count-limit>25191</count-limit>
<used>343</used>
<free>8</free>
<zone-req>2524</zone-req>
<zone-name>unpcb:</zone-name>
<zone-size>140</zone-size>
<count-limit>25200</count-limit>
<used>170</used>
<free>26</free>
<zone-req>2157</zone-req>
```

```

<zone-name>ipq:</zone-name>
<zone-size>52</zone-size>
<count-limit>216</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>udpcb:</zone-name>
<zone-size>232</zone-size>
<count-limit>25194</count-limit>
<used>19</used>
<free>32</free>
<zone-req>31</zone-req>
<zone-name>inpcb:</zone-name>
<zone-size>232</zone-size>
<count-limit>25194</count-limit>
<used>40</used>
<free>28</free>
<zone-req>105</zone-req>
<zone-name>tcpcb:</zone-name>
<zone-size>520</zone-size>
<count-limit>25193</count-limit>
<used>40</used>
<free>16</free>
<zone-req>105</zone-req>
<zone-name>tcptw:</zone-name>
<zone-size>56</zone-size>
<count-limit>5092</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>syncache:</zone-name>
<zone-size>128</zone-size>
<count-limit>15360</count-limit>
<used>0</used>
<free>60</free>
<zone-req>55</zone-req>
<zone-name>tcpreass:</zone-name>
<zone-size>20</zone-size>
<count-limit>1690</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>sackhole:</zone-name>
<zone-size>20</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>ripcb:</zone-name>
<zone-size>232</zone-size>
<count-limit>25194</count-limit>
<used>5</used>
<free>29</free>
<zone-req>5</zone-req>
<zone-name>SWAPMETA:</zone-name>
<zone-size>276</zone-size>
<count-limit>94948</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>FFS inode:</zone-name>

```

```

    <zone-size>132</zone-size>
    <count-limit>0</count-limit>
    <used>1146</used>
    <free>72</free>
    <zone-req>1306</zone-req>
    <zone-name>FFS1 dinode:</zone-name>
    <zone-size>128</zone-size>
    <count-limit>0</count-limit>
    <used>1146</used>
    <free>24</free>
    <zone-req>1306</zone-req>
    <zone-name>FFS2 dinode:</zone-name>
    <zone-size>256</zone-size>
    <count-limit>0</count-limit>
    <used>0</used>
    <free>0</free>
    <zone-req>0</zone-req>
  </vmstat-memstat-zone>
  <vmstat-sumstat>
    <cpu-context-switch>934906</cpu-context-switch>
    <dev-intr>1707986</dev-intr>
    <soft-intr>33819</soft-intr>
    <traps>203604</traps>
    <sys-calls>1200636</sys-calls>
    <kernel-thrds>60</kernel-thrds>
    <fork-calls>1313</fork-calls>
    <vfork-calls>21</vfork-calls>
    <rfork-calls>0</rfork-calls>
    <swap-pageins>0</swap-pageins>
    <swap-pagedin>0</swap-pagedin>
    <swap-pageouts>0</swap-pageouts>
    <swap-pagedout>0</swap-pagedout>
    <vnode-pageins>23094</vnode-pageins>
    <vnode-pagedin>23119</vnode-pagedin>
    <vnode-pageouts>226</vnode-pageouts>
    <vnode-pagedout>3143</vnode-pagedout>
    <page-daemon-wakeup>0</page-daemon-wakeup>
    <page-daemon-examined-pages>0</page-daemon-examined-pages>
    <pages-reactivated>8821</pages-reactivated>
    <copy-on-write-faults>48364</copy-on-write-faults>
    <copy-on-write-optimized-faults>31</copy-on-write-optimized-faults>
    <zero-fill-pages-zeroed>74665</zero-fill-pages-zeroed>
    <zero-fill-pages-prezeroed>70061</zero-fill-pages-prezeroed>
    <transit-blocking-page-faults>85</transit-blocking-page-faults>
    <total-vm-faults>191824</total-vm-faults>

  <pages-affected-by-kernel-thrd-creat>0</pages-affected-by-kernel-thrd-creat>
  <pages-affected-by-fork>95343</pages-affected-by-fork>
  <pages-affected-by-vfork>3526</pages-affected-by-vfork>
  <pages-affected-by-rfork>0</pages-affected-by-rfork>
  <pages-freed>221502</pages-freed>
  <pages-freed-by-daemon>0</pages-freed-by-daemon>
  <pages-freed-by-exiting-proc>75630</pages-freed-by-exiting-proc>
  <pages-active>45826</pages-active>
  <pages-inactive>13227</pages-inactive>
  <pages-in-vm-cache>49278</pages-in-vm-cache>
  <pages-wired-down>10640</pages-wired-down>
  <pages-free>70706</pages-free>
  <bytes-per-page>4096</bytes-per-page>
  <swap-pages-used>0</swap-pages-used>
  <peak-swap-pages-used>0</peak-swap-pages-used>

```

```

<total-name-lookups>214496</total-name-lookups>
<positive-cache-hits>92</positive-cache-hits>
<negative-cache-hits>5</negative-cache-hits>
<pass2>0</pass2>
<cache-deletions>0</cache-deletions>
<cache-falsehits>0</cache-falsehits>
<toolong>0</toolong>
</vmstat-sumstat>
<vmstat-intr>
  <intr-name>irq0: clk          </intr-name>
  <intr-cnt>1243455</intr-cnt>
  <intr-rate>999</intr-rate>
  <intr-name>irq4: sio0        </intr-name>
  <intr-cnt>1140</intr-cnt>
  <intr-rate>0</intr-rate>
  <intr-name>irq8: rtc         </intr-name>
  <intr-cnt>159164</intr-cnt>
  <intr-rate>127</intr-rate>
  <intr-name>irq9: cbb1 fxp0   </intr-name>
  <intr-cnt>28490</intr-cnt>
  <intr-rate>22</intr-rate>
  <intr-name>irq10: fxp1       </intr-name>
  <intr-cnt>20593</intr-cnt>
  <intr-rate>16</intr-rate>
  <intr-name>irq14: ata0      </intr-name>
  <intr-cnt>5031</intr-cnt>
  <intr-rate>4</intr-rate>
  <intr-name>Total</intr-name>
  <intr-cnt>1457873</intr-cnt>
  <intr-rate>1171</intr-rate>
</vmstat-intr>
<vm-kernel-state>
  <vm-kmem-map-free>248524800</vm-kmem-map-free>
</vm-kernel-state>
</system-virtual-memory-information>
<cli>
  <banner></banner>
</cli>
</rpc-reply>

```

```

show system virtual-memory (QFX Series)
user@switch> show system virtual-memory | display xml
<rpc-reply xmlns:junos="http://xml.juniper.net/junos/11.1R1/junos">
  <system-virtual-memory-information>
    <vmstat-memstat-malloc>
      <memstat-name>CAM dev queue</memstat-name>
      <inuse>1</inuse>
      <memuse>1</memuse>
      <high-use>-</high-use>
      <memstat-req>1</memstat-req>
      <memstat-size>64</memstat-size>
      <memstat-name>entropy</memstat-name>
      <inuse>1024</inuse>
      <memuse>64</memuse>
      <high-use>-</high-use>
      <memstat-req>1024</memstat-req>
      <memstat-size>64</memstat-size>
      <memstat-name>linker</memstat-name>
      <inuse>481</inuse>
      <memuse>1871</memuse>
      <high-use>-</high-use>
      <memstat-req>1145</memstat-req>
    
```

```
<memstat-size>16,32,64,4096,32768,131072</memstat-size>
<memstat-name>lockf</memstat-name>
<inuse>56</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>5998</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>devbuf</memstat-name>
<inuse>2094</inuse>
<memuse>3877</memuse>
<high-use>--</high-use>
<memstat-req>2099</memstat-req>

<memstat-size>16,32,64,128,512,1024,4096,8192,16384,32768,65536,131072</memstat-size>

<memstat-name>temp</memstat-name>
<inuse>21</inuse>
<memuse>66</memuse>
<high-use>--</high-use>
<memstat-req>3127</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,4096,8192,16384,32768,65536,131072</memstat-size>

<memstat-name>ip6ndp</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>in6ifmulti</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>in6grenty</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>iflogical</memstat-name>
<inuse>13</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>13</memstat-req>
<memstat-size>64,2048</memstat-size>
<memstat-name>iffamily</memstat-name>
<inuse>28</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>28</memstat-req>
<memstat-size>32,1024,2048</memstat-size>
<memstat-name>rtnexthop</memstat-name>
<inuse>127</inuse>
<memuse>18</memuse>
<high-use>--</high-use>
<memstat-req>129</memstat-req>
<memstat-size>32,256,512,1024,2048,4096</memstat-size>
<memstat-name>metrics</memstat-name>
<inuse>3</inuse>
```

```

<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>5</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>inifmulti</memstat-name>
<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>3</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>ingrentry</memstat-name>
<inuse>6</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>6</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>rnode</memstat-name>
<inuse>68</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>76</memstat-req>
<memstat-size>16,32</memstat-size>
<memstat-name>rcache</memstat-name>
<inuse>4</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>ifdevice</memstat-name>
<inuse>4</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>ifstat</memstat-name>
<inuse>40</inuse>
<memuse>22</memuse>
<high-use>--</high-use>
<memstat-req>40</memstat-req>
<memstat-size>512,16384,32768</memstat-size>
<memstat-name>ipfw</memstat-name>
<inuse>42</inuse>
<memuse>23</memuse>
<high-use>--</high-use>
<memstat-req>91</memstat-req>

<memstat-size>16,32,64,128,256,512,1024,16384,32768,65536,131072</memstat-size>
<memstat-name>ifmaddr</memstat-name>
<inuse>103</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>103</memstat-req>
<memstat-size>16,32</memstat-size>
<memstat-name>rtable</memstat-name>
<inuse>129</inuse>
<memuse>14</memuse>
<high-use>--</high-use>
<memstat-req>139</memstat-req>
<memstat-size>16,32,64,128,1024,16384</memstat-size>
<memstat-name>sysctl</memstat-name>
<inuse>0</inuse>

```

```

<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>14847</memstat-req>
<memstat-size>16,32,64,4096,16384,32768</memstat-size>
<memstat-name>ifaddr</memstat-name>
<inuse>29</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>29</memstat-req>
<memstat-size>64,128</memstat-size>
<memstat-name>mkey</memstat-name>
<inuse>345</inuse>
<memuse>6</memuse>
<high-use>--</high-use>
<memstat-req>2527</memstat-req>
<memstat-size>16,128</memstat-size>
<memstat-name>pfe_ipc</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>1422</memstat-req>

<memstat-size>16,32,64,128,512,1024,2048,8192,16384,32768,65536,131072</memstat-size>

<memstat-name>ifstate</memstat-name>
<inuse>594</inuse>
<memuse>51</memuse>
<high-use>--</high-use>
<memstat-req>655</memstat-req>

<memstat-size>16,32,64,128,256,1024,2048,4096,16384,32768</memstat-size>
<memstat-name>itable16</memstat-name>
<inuse>276</inuse>
<memuse>52</memuse>
<high-use>--</high-use>
<memstat-req>294</memstat-req>
<memstat-size>1024,4096</memstat-size>
<memstat-name>itable32</memstat-name>
<inuse>160</inuse>
<memuse>10</memuse>
<high-use>--</high-use>
<memstat-req>160</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>itable64</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>lr</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>16384</memstat-size>
<memstat-name>pic</memstat-name>
<inuse>5</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>5</memstat-req>
<memstat-size>64,512</memstat-size>

```



```

<memstat-name>pfestat</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>162</memstat-req>
<memstat-size>16,32,128,256,16384</memstat-size>
<memstat-name>gencfg</memstat-name>
<inuse>224</inuse>
<memuse>56</memuse>
<high-use>--</high-use>
<memstat-req>540</memstat-req>
<memstat-size>16,32,64,256,512,32768,65536</memstat-size>
<memstat-name>jsr</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>idl</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>13</memstat-req>
<memstat-size>16,32,64,128,256,4096,16384,32768,131072</memstat-size>

<memstat-name>rtsmsg</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>131072</memstat-size>
<memstat-name>module</memstat-name>
<inuse>249</inuse>
<memuse>16</memuse>
<high-use>--</high-use>
<memstat-req>249</memstat-req>
<memstat-size>64,128</memstat-size>
<memstat-name>mtx_pool</memstat-name>
<inuse>1</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64,128</memstat-size>
<memstat-name>DEVFS3</memstat-name>
<inuse>109</inuse>
<memuse>12</memuse>
<high-use>--</high-use>
<memstat-req>117</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>DEVFS1</memstat-name>
<inuse>102</inuse>
<memuse>23</memuse>
<high-use>--</high-use>
<memstat-req>109</memstat-req>
<memstat-size>2048</memstat-size>
<memstat-name>pgrp</memstat-name>
<inuse>12</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>21</memstat-req>
<memstat-size>64</memstat-size>

```

```
<memstat-name>session</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
<memstat-size>512</memstat-size>
<memstat-name>proc</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>16384</memstat-size>
<memstat-name>subproc</memstat-name>
<inuse>244</inuse>
<memuse>496</memuse>
<high-use>--</high-use>
<memstat-req>1522</memstat-req>
<memstat-size>2048,131072</memstat-size>
<memstat-name>cred</memstat-name>
<inuse>30</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>11409</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>plimit</memstat-name>
<inuse>17</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>133</memstat-req>
<memstat-size>2048</memstat-size>
<memstat-name>uidinfo</memstat-name>
<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>6</memstat-req>
<memstat-size>32,512</memstat-size>
<memstat-name>sysctluid</memstat-name>
<inuse>1117</inuse>
<memuse>34</memuse>
<high-use>--</high-use>
<memstat-req>1117</memstat-req>
<memstat-size>16,32,64</memstat-size>
<memstat-name>sysctltmp</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>743</memstat-req>
<memstat-size>16,32,64,1024</memstat-size>
<memstat-name>umtx</memstat-name>
<inuse>144</inuse>
<memuse>9</memuse>
<high-use>--</high-use>
<memstat-req>144</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>SWAP</memstat-name>
<inuse>2</inuse>
<memuse>209</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>bus</memstat-name>
```

```

<inuse>496</inuse>
<memuse>55</memuse>
<high-use>--</high-use>
<memstat-req>1196</memstat-req>
<memstat-size>16,32,64,128,32768</memstat-size>
<memstat-name>bus-sc</memstat-name>
<inuse>23</inuse>
<memuse>33</memuse>
<high-use>--</high-use>
<memstat-req>335</memstat-req>

<memstat-size>16,32,64,512,1024,2048,8192,16384,65536,131072</memstat-size>
<memstat-name>devstat</memstat-name>
<inuse>10</inuse>
<memuse>21</memuse>
<high-use>--</high-use>
<memstat-req>10</memstat-req>
<memstat-size>16,131072</memstat-size>
<memstat-name>eventhandler</memstat-name>
<inuse>35</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>36</memstat-req>
<memstat-size>32,128</memstat-size>
<memstat-name>kobj</memstat-name>
<inuse>93</inuse>
<memuse>186</memuse>
<high-use>--</high-use>
<memstat-req>111</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>DEVFS</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>9</memstat-req>
<memstat-size>16,64</memstat-size>
<memstat-name>rman</memstat-name>
<inuse>71</inuse>
<memuse>5</memuse>
<high-use>--</high-use>
<memstat-req>433</memstat-req>
<memstat-size>16,32,64</memstat-size>
<memstat-name>sbuf</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>522</memstat-req>
<memstat-size>16,32,32768,131072</memstat-size>
<memstat-name>NULLFS hash</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>taskqueue</memstat-name>
<inuse>5</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>5</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>turnstiles</memstat-name>

```

```
<inuse>145</inuse>
<memuse>10</memuse>
<high-use>--</high-use>
<memstat-req>145</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>Unitno</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>44</memstat-req>
<memstat-size>16,64</memstat-size>
<memstat-name>iocltops</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>27622</memstat-req>
<memstat-size>16,64,8192,16384,131072</memstat-size>
<memstat-name>iov</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>18578</memstat-req>
<memstat-size>16,64,128,256,512,1024,2048,131072</memstat-size>
<memstat-name>msg</memstat-name>
<inuse>4</inuse>
<memuse>25</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>32768,131072</memstat-size>
<memstat-name>sem</memstat-name>
<inuse>4</inuse>
<memuse>7</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16384,32768,131072</memstat-size>
<memstat-name>shm</memstat-name>
<inuse>9</inuse>
<memuse>20</memuse>
<high-use>--</high-use>
<memstat-req>14</memstat-req>
<memstat-size>32768</memstat-size>
<memstat-name>ttys</memstat-name>
<inuse>321</inuse>
<memuse>61</memuse>
<high-use>--</high-use>
<memstat-req>528</memstat-req>
<memstat-size>512,32768</memstat-size>
<memstat-name>ptys</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>mbuf_tag</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>23383</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>soname</memstat-name>
<inuse>115</inuse>
```

```

<memuse>12</memuse>
<high-use>--</high-use>
<memstat-req>24712</memstat-req>
<memstat-size>16,32,64,256</memstat-size>
<memstat-name>pcb</memstat-name>
<inuse>216</inuse>
<memuse>33</memuse>
<high-use>--</high-use>
<memstat-req>484</memstat-req>

<memstat-size>16,32,64,128,1024,2048,4096,16384,32768,65536</memstat-size>
<memstat-name>BIO buffer</memstat-name>
<inuse>43</inuse>
<memuse>86</memuse>
<high-use>--</high-use>
<memstat-req>405</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>vfscache</memstat-name>
<inuse>1</inuse>
<memuse>256</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>cluster_save buffer</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>32,64</memstat-size>
<memstat-name>VFS hash</memstat-name>
<inuse>1</inuse>
<memuse>128</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>32,64</memstat-size>
<memstat-name>vnodes</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>512</memstat-size>
<memstat-name>mount</memstat-name>
<inuse>290</inuse>
<memuse>23</memuse>
<high-use>--</high-use>
<memstat-req>535</memstat-req>
<memstat-size>16,32,64,128,256,4096,32768</memstat-size>
<memstat-name>vnodemarker</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>498</memstat-req>
<memstat-size>16384</memstat-size>
<memstat-name>pfs_nodes</memstat-name>
<inuse>25</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>25</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>pfs_vncache</memstat-name>
<inuse>27</inuse>

```

```
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>53</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>STP</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>GEOM</memstat-name>
<inuse>146</inuse>
<memuse>11</memuse>
<high-use>--</high-use>
<memstat-req>1042</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>syncache</memstat-name>
<inuse>1</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>tlv_stat</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>8</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>NFS daemon</memstat-name>
<inuse>1</inuse>
<memuse>8</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>

<memstat-size>16,32,64,128,256,512,2048,16384,32768,131072</memstat-size>
<memstat-name>p1003.1b</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>MD disk</memstat-name>
<inuse>10</inuse>
<memuse>20</memuse>
<high-use>--</high-use>
<memstat-req>10</memstat-req>
<memstat-size>65536</memstat-size>
<memstat-name>ata_generic</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>6</memstat-req>
<memstat-size>16,16384,32768</memstat-size>
<memstat-name>ISofs mount</memstat-name>
<inuse>8</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
```

```

<memstat-size>512</memstat-size>
<memstat-name>ISOFs node</memstat-name>
<inuse>1440</inuse>
<memuse>135</memuse>
<high-use>--</high-use>
<memstat-req>1457</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>CAM SIM</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>CAM XPT</memstat-name>
<inuse>6</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>9</memstat-req>
<memstat-size>16,64,16384</memstat-size>
<memstat-name>CAM periph</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>ad_driver</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>pagedep</memstat-name>
<inuse>1</inuse>
<memuse>32</memuse>
<high-use>--</high-use>
<memstat-req>106</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>inodedep</memstat-name>
<inuse>1</inuse>
<memuse>128</memuse>
<high-use>--</high-use>
<memstat-req>464</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>newblk</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>336</memstat-req>
<memstat-size>64,4096</memstat-size>
<memstat-name>bmsafemap</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>63</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>allocdirect</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>320</memstat-req>
<memstat-size>128</memstat-size>

```

```
<memstat-name>indirdep</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>17</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>allocindir</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>freefrag</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>12</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>freeblks</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>40</memstat-req>
<memstat-size>2048</memstat-size>
<memstat-name>freefile</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>101</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>diradd</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>465</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>mkdir</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>136</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>dirrem</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>168</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>newdirblk</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>savedino</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>157</memstat-req>
<memstat-size>512</memstat-size>
<memstat-name>UFS mount</memstat-name>
```



```

<inuse>15</inuse>
<memuse>36</memuse>
<high-use>--</high-use>
<memstat-req>15</memstat-req>
<memstat-size>2048,65536,131072</memstat-size>
<memstat-name>ata_dma</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>UMAHash</memstat-name>
<inuse>1</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>4096,16384,32768,65536</memstat-size>
<memstat-name>cdev</memstat-name>
<inuse>22</inuse>
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>22</memstat-req>
<memstat-size>256</memstat-size>
<memstat-name>file_desc</memstat-name>
<inuse>141</inuse>
<memuse>32</memuse>
<high-use>--</high-use>
<memstat-req>1583</memstat-req>
<memstat-size>16,1024,2048,16384</memstat-size>
<memstat-name>VM_pgdata</memstat-name>
<inuse>2</inuse>
<memuse>65</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>sigio</memstat-name>
<inuse>1</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>20</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>kenv</memstat-name>
<inuse>24</inuse>
<memuse>5</memuse>
<high-use>--</high-use>
<memstat-req>27</memstat-req>
<memstat-size>16,32,64,131072</memstat-size>
<memstat-name>atkbddev</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>kqueue</memstat-name>
<inuse>15</inuse>
<memuse>9</memuse>
<high-use>--</high-use>
<memstat-req>19</memstat-req>
<memstat-size>1024,4096,32768</memstat-size>
<memstat-name>proc-args</memstat-name>
<inuse>57</inuse>

```

```
<memuse>3</memuse>
<high-use>--</high-use>
<memstat-req>1001</memstat-req>
<memstat-size>16,32,64,128,256,512,1024</memstat-size>
<memstat-name>isadev</memstat-name>
<inuse>21</inuse>
<memuse>2</memuse>
<high-use>--</high-use>
<memstat-req>21</memstat-req>
<memstat-size>64</memstat-size>
<memstat-name>zombie</memstat-name>
<inuse>0</inuse>
<memuse>0</memuse>
<high-use>--</high-use>
<memstat-req>1278</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>ithread</memstat-name>
<inuse>69</inuse>
<memuse>5</memuse>
<high-use>--</high-use>
<memstat-req>69</memstat-req>
<memstat-size>16,64,256</memstat-size>
<memstat-name>legacydrv</memstat-name>
<inuse>4</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>memdesc</memstat-name>
<inuse>1</inuse>
<memuse>4</memuse>
<high-use>--</high-use>
<memstat-req>1</memstat-req>
<memstat-size>131072</memstat-size>
<memstat-name>nexusdev</memstat-name>
<inuse>2</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>2</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>CAM queue</memstat-name>
<inuse>3</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>3</memstat-req>
<memstat-size>16</memstat-size>
<memstat-name>$PIR</memstat-name>
<inuse>4</inuse>
<memuse>1</memuse>
<high-use>--</high-use>
<memstat-req>4</memstat-req>
<memstat-size>32</memstat-size>
<memstat-name>KTRACE</memstat-name>
<inuse>100</inuse>
<memuse>10</memuse>
<high-use>--</high-use>
<memstat-req>100</memstat-req>
<memstat-size>128</memstat-size>
<memstat-name>kbdmux</memstat-name>
<inuse>5</inuse>
<memuse>9</memuse>
```

```

    <high-use>-</high-use>
    <memstat-req>5</memstat-req>
    <memstat-size>128,2048,65536,131072</memstat-size>
</vmstat-memstat-malloc>
<vmstat-memstat-zone>
  <zone-name>UMA Kgs:</zone-name>
  <zone-size>136</zone-size>
  <count-limit>0</count-limit>
  <used>71</used>
  <free>1</free>
  <zone-req>71</zone-req>
  <zone-name>UMA Zones:</zone-name>
  <zone-size>120</zone-size>
  <count-limit>0</count-limit>
  <used>71</used>
  <free>19</free>
  <zone-req>71</zone-req>
  <zone-name>UMA Slabs:</zone-name>
  <zone-size>64</zone-size>
  <count-limit>0</count-limit>
  <used>490</used>
  <free>41</free>
  <zone-req>579</zone-req>
  <zone-name>UMA RCntSlabs:</zone-name>
  <zone-size>104</zone-size>
  <count-limit>0</count-limit>
  <used>276</used>
  <free>20</free>
  <zone-req>276</zone-req>
  <zone-name>UMA Hash:</zone-name>
  <zone-size>128</zone-size>
  <count-limit>0</count-limit>
  <used>4</used>
  <free>26</free>
  <zone-req>5</zone-req>
  <zone-name>16 Bucket:</zone-name>
  <zone-size>76</zone-size>
  <count-limit>0</count-limit>
  <used>30</used>
  <free>20</free>
  <zone-req>30</zone-req>
  <zone-name>32 Bucket:</zone-name>
  <zone-size>140</zone-size>
  <count-limit>0</count-limit>
  <used>33</used>
  <free>23</free>
  <zone-req>33</zone-req>
  <zone-name>64 Bucket:</zone-name>
  <zone-size>268</zone-size>
  <count-limit>0</count-limit>
  <used>33</used>
  <free>9</free>
  <zone-req>33</zone-req>
  <zone-name>128 Bucket:</zone-name>
  <zone-size>524</zone-size>
  <count-limit>0</count-limit>
  <used>49</used>
  <free>0</free>
  <zone-req>49</zone-req>
  <zone-name>VM OBJECT:</zone-name>
  <zone-size>128</zone-size>

```

```
<count-limit>0</count-limit>
<used>2111</used>
<free>79</free>
<zone-req>25214</zone-req>
<zone-name>MAP:</zone-name>
<zone-size>160</zone-size>
<count-limit>0</count-limit>
<used>7</used>
<free>41</free>
<zone-req>7</zone-req>
<zone-name>KMAP ENTRY:</zone-name>
<zone-size>68</zone-size>
<count-limit>35336</count-limit>
<used>19</used>
<free>149</free>
<zone-req>2397</zone-req>
<zone-name>MAP ENTRY:</zone-name>
<zone-size>68</zone-size>
<count-limit>0</count-limit>
<used>2031</used>
<free>153</free>
<zone-req>62417</zone-req>
<zone-name>PV ENTRY:</zone-name>
<zone-size>24</zone-size>
<count-limit>509095</count-limit>
<used>57177</used>
<free>6333</free>
<zone-req>1033683</zone-req>
<zone-name>DP fakepg:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>mt_zone:</zone-name>
<zone-size>64</zone-size>
<count-limit>0</count-limit>
<used>238</used>
<free>57</free>
<zone-req>238</zone-req>
<zone-name>16:</zone-name>
<zone-size>16</zone-size>
<count-limit>0</count-limit>
<used>2114</used>
<free>119</free>
<zone-req>80515</zone-req>
<zone-name>32:</zone-name>
<zone-size>32</zone-size>
<count-limit>0</count-limit>
<used>1335</used>
<free>134</free>
<zone-req>10259</zone-req>
<zone-name>64:</zone-name>
<zone-size>64</zone-size>
<count-limit>0</count-limit>
<used>3529</used>
<free>129</free>
<zone-req>29110</zone-req>
<zone-name>96:</zone-name>
<zone-size>96</zone-size>
<count-limit>0</count-limit>
```

```
<used>2062</used>
<free>58</free>
<zone-req>4365</zone-req>
<zone-name>112:</zone-name>
<zone-size>112</zone-size>
<count-limit>0</count-limit>
<used>361</used>
<free>164</free>
<zone-req>24613</zone-req>
<zone-name>128:</zone-name>
<zone-size>128</zone-size>
<count-limit>0</count-limit>
<used>359</used>
<free>61</free>
<zone-req>942</zone-req>
<zone-name>160:</zone-name>
<zone-size>160</zone-size>
<count-limit>0</count-limit>
<used>364</used>
<free>44</free>
<zone-req>577</zone-req>
<zone-name>224:</zone-name>
<zone-size>224</zone-size>
<count-limit>0</count-limit>
<used>422</used>
<free>20</free>
<zone-req>1950</zone-req>
<zone-name>256:</zone-name>
<zone-size>256</zone-size>
<count-limit>0</count-limit>
<used>204</used>
<free>36</free>
<zone-req>1225</zone-req>
<zone-name>288:</zone-name>
<zone-size>288</zone-size>
<count-limit>0</count-limit>
<used>2</used>
<free>24</free>
<zone-req>10</zone-req>
<zone-name>512:</zone-name>
<zone-size>512</zone-size>
<count-limit>0</count-limit>
<used>49</used>
<free>7</free>
<zone-req>911</zone-req>
<zone-name>1024:</zone-name>
<zone-size>1024</zone-size>
<count-limit>0</count-limit>
<used>213</used>
<free>11</free>
<zone-req>1076</zone-req>
<zone-name>2048:</zone-name>
<zone-size>2048</zone-size>
<count-limit>0</count-limit>
<used>199</used>
<free>113</free>
<zone-req>640</zone-req>
<zone-name>4096:</zone-name>
<zone-size>4096</zone-size>
<count-limit>0</count-limit>
<used>144</used>
```

```
<free>7</free>
<zone-req>2249</zone-req>
<zone-name>Files:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>665</used>
<free>77</free>
<zone-req>16457</zone-req>
<zone-name>MAC labels:</zone-name>
<zone-size>20</zone-size>
<count-limit>0</count-limit>
<used>3998</used>
<free>227</free>
<zone-req>21947</zone-req>
<zone-name>PROC:</zone-name>
<zone-size>544</zone-size>
<count-limit>0</count-limit>
<used>116</used>
<free>10</free>
<zone-req>1394</zone-req>
<zone-name>THREAD:</zone-name>
<zone-size>416</zone-size>
<count-limit>0</count-limit>
<used>127</used>
<free>17</free>
<zone-req>131</zone-req>
<zone-name>KSEGRP:</zone-name>
<zone-size>88</zone-size>
<count-limit>0</count-limit>
<used>127</used>
<free>73</free>
<zone-req>131</zone-req>
<zone-name>UPCALL:</zone-name>
<zone-size>44</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>SLEEPQUEUE:</zone-name>
<zone-size>32</zone-size>
<count-limit>0</count-limit>
<used>145</used>
<free>194</free>
<zone-req>145</zone-req>
<zone-name>VMSPACE:</zone-name>
<zone-size>268</zone-size>
<count-limit>0</count-limit>
<used>57</used>
<free>13</free>
<zone-req>1335</zone-req>
<zone-name>mbuf_packet:</zone-name>
<zone-size>256</zone-size>
<count-limit>180000</count-limit>
<used>256</used>
<free>128</free>
<zone-req>49791</zone-req>
<zone-name>mbuf:</zone-name>
<zone-size>256</zone-size>
<count-limit>180000</count-limit>
<used>50</used>
<free>466</free>
```

```

<zone-req>105183</zone-req>
<zone-name>mbuf_cluster:</zone-name>
<zone-size>2048</zone-size>
<count-limit>25190</count-limit>
<used>387</used>
<free>165</free>
<zone-req>5976</zone-req>
<zone-name>mbuf_jumbo_pagesize:</zone-name>
<zone-size>4096</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>mbuf_jumbo_9k:</zone-name>
<zone-size>9216</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>mbuf_jumbo_16k:</zone-name>
<zone-size>16384</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>ACL_UMA_zone:</zone-name>
<zone-size>388</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>g_bio:</zone-name>
<zone-size>132</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>174</free>
<zone-req>69750</zone-req>
<zone-name>ata_request:</zone-name>
<zone-size>200</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>57</free>
<zone-req>5030</zone-req>
<zone-name>ata_composite:</zone-name>
<zone-size>192</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>GENCFG:</zone-name>
<zone-size>72</zone-size>
<count-limit>1000004</count-limit>
<used>57</used>
<free>102</free>
<zone-req>57</zone-req>
<zone-name>VNODE:</zone-name>
<zone-size>292</zone-size>
<count-limit>0</count-limit>
<used>2718</used>
<free>25</free>
<zone-req>2922</zone-req>

```

```
<zone-name>VNODEPOLL:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>S VFS Cache:</zone-name>
<zone-size>68</zone-size>
<count-limit>0</count-limit>
<used>2500</used>
<free>76</free>
<zone-req>3824</zone-req>
<zone-name>L VFS Cache:</zone-name>
<zone-size>291</zone-size>
<count-limit>0</count-limit>
<used>51</used>
<free>14</free>
<zone-req>63</zone-req>
<zone-name>NAMEI:</zone-name>
<zone-size>1024</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>8</free>
<zone-req>53330</zone-req>
<zone-name>NFSMOUNT:</zone-name>
<zone-size>480</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>NFSNODE:</zone-name>
<zone-size>460</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>PIPE:</zone-name>
<zone-size>404</zone-size>
<count-limit>0</count-limit>
<used>27</used>
<free>9</free>
<zone-req>717</zone-req>
<zone-name>KNOTE:</zone-name>
<zone-size>72</zone-size>
<count-limit>0</count-limit>
<used>42</used>
<free>64</free>
<zone-req>3311</zone-req>
<zone-name>socket:</zone-name>
<zone-size>412</zone-size>
<count-limit>25191</count-limit>
<used>343</used>
<free>8</free>
<zone-req>2524</zone-req>
<zone-name>unpcb:</zone-name>
<zone-size>140</zone-size>
<count-limit>25200</count-limit>
<used>170</used>
<free>26</free>
<zone-req>2157</zone-req>
<zone-name>ipq:</zone-name>
```



```

<zone-size>52</zone-size>
<count-limit>216</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>udpcb:</zone-name>
<zone-size>232</zone-size>
<count-limit>25194</count-limit>
<used>19</used>
<free>32</free>
<zone-req>31</zone-req>
<zone-name>inpcb:</zone-name>
<zone-size>232</zone-size>
<count-limit>25194</count-limit>
<used>40</used>
<free>28</free>
<zone-req>105</zone-req>
<zone-name>tcpb:</zone-name>
<zone-size>520</zone-size>
<count-limit>25193</count-limit>
<used>40</used>
<free>16</free>
<zone-req>105</zone-req>
<zone-name>tcptw:</zone-name>
<zone-size>56</zone-size>
<count-limit>5092</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>syncache:</zone-name>
<zone-size>128</zone-size>
<count-limit>15360</count-limit>
<used>0</used>
<free>60</free>
<zone-req>55</zone-req>
<zone-name>tcpreass:</zone-name>
<zone-size>20</zone-size>
<count-limit>1690</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>sackhole:</zone-name>
<zone-size>20</zone-size>
<count-limit>0</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>ripb:</zone-name>
<zone-size>232</zone-size>
<count-limit>25194</count-limit>
<used>5</used>
<free>29</free>
<zone-req>5</zone-req>
<zone-name>SWAPMETA:</zone-name>
<zone-size>276</zone-size>
<count-limit>94948</count-limit>
<used>0</used>
<free>0</free>
<zone-req>0</zone-req>
<zone-name>FFS inode:</zone-name>
<zone-size>132</zone-size>

```

```

    <count-limit>0</count-limit>
    <used>1146</used>
    <free>72</free>
    <zone-req>1306</zone-req>
    <zone-name>FFS1 dinode:</zone-name>
    <zone-size>128</zone-size>
    <count-limit>0</count-limit>
    <used>1146</used>
    <free>24</free>
    <zone-req>1306</zone-req>
    <zone-name>FFS2 dinode:</zone-name>
    <zone-size>256</zone-size>
    <count-limit>0</count-limit>
    <used>0</used>
    <free>0</free>
    <zone-req>0</zone-req>
</vmstat-memstat-zone>
<vmstat-sumstat>
    <cpu-context-switch>934906</cpu-context-switch>
    <dev-intr>1707986</dev-intr>
    <soft-intr>33819</soft-intr>
    <traps>203604</traps>
    <sys-calls>1200636</sys-calls>
    <kernel-thrds>60</kernel-thrds>
    <fork-calls>1313</fork-calls>
    <vfork-calls>21</vfork-calls>
    <rfork-calls>0</rfork-calls>
    <swap-pageins>0</swap-pageins>
    <swap-pagedin>0</swap-pagedin>
    <swap-pageouts>0</swap-pageouts>
    <swap-pagedout>0</swap-pagedout>
    <vnode-pageins>23094</vnode-pageins>
    <vnode-pagedin>23119</vnode-pagedin>
    <vnode-pageouts>226</vnode-pageouts>
    <vnode-pagedout>3143</vnode-pagedout>
    <page-daemon-wakeup>0</page-daemon-wakeup>
    <page-daemon-examined-pages>0</page-daemon-examined-pages>
    <pages-reactivated>8821</pages-reactivated>
    <copy-on-write-faults>48364</copy-on-write-faults>
    <copy-on-write-optimized-faults>31</copy-on-write-optimized-faults>
    <zero-fill-pages-zeroed>74665</zero-fill-pages-zeroed>
    <zero-fill-pages-prezeroed>70061</zero-fill-pages-prezeroed>
    <transit-blocking-page-faults>85</transit-blocking-page-faults>
    <total-vm-faults>191824</total-vm-faults>

<pages-affected-by-kernel-thrd-creat>0</pages-affected-by-kernel-thrd-creat>
    <pages-affected-by-fork>95343</pages-affected-by-fork>
    <pages-affected-by-vfork>3526</pages-affected-by-vfork>
    <pages-affected-by-rfork>0</pages-affected-by-rfork>
    <pages-freed>221502</pages-freed>
    <pages-freed-by-daemon>0</pages-freed-by-daemon>
    <pages-freed-by-exiting-proc>75630</pages-freed-by-exiting-proc>
    <pages-active>45826</pages-active>
    <pages-inactive>13227</pages-inactive>
    <pages-in-vm-cache>49278</pages-in-vm-cache>
    <pages-wired-down>10640</pages-wired-down>
    <pages-free>70706</pages-free>
    <bytes-per-page>4096</bytes-per-page>
    <swap-pages-used>0</swap-pages-used>
    <peak-swap-pages-used>0</peak-swap-pages-used>
    <total-name-lookups>214496</total-name-lookups>

```

```

    <positive-cache-hits>92</positive-cache-hits>
    <negative-cache-hits>5</negative-cache-hits>
    <pass2>0</pass2>
    <cache-deletions>0</cache-deletions>
    <cache-falsehits>0</cache-falsehits>
    <toolong>0</toolong>
</vmstat-sumstat>
<vmstat-intr>
  <intr-name>irq0: clk      </intr-name>
  <intr-cnt>1243455</intr-cnt>
  <intr-rate>999</intr-rate>
  <intr-name>irq4: sio0     </intr-name>
  <intr-cnt>1140</intr-cnt>
  <intr-rate>0</intr-rate>
  <intr-name>irq8: rtc      </intr-name>
  <intr-cnt>159164</intr-cnt>
  <intr-rate>127</intr-rate>
  <intr-name>irq9: cbb1 fxp0 </intr-name>
  <intr-cnt>28490</intr-cnt>
  <intr-rate>22</intr-rate>
  <intr-name>irq10: fxp1    </intr-name>
  <intr-cnt>20593</intr-cnt>
  <intr-rate>16</intr-rate>
  <intr-name>irq14: ata0    </intr-name>
  <intr-cnt>5031</intr-cnt>
  <intr-rate>4</intr-rate>
  <intr-name>Total</intr-name>
  <intr-cnt>1457873</intr-cnt>
  <intr-rate>1171</intr-rate>
</vmstat-intr>
<vm-kernel-state>
  <vm-kmem-map-free>248524800</vm-kmem-map-free>
</vm-kernel-state>
</system-virtual-memory-information>
<cli>
  <banner></banner>
</cli>
</rpc-reply>

```

show task

Syntax	show task <logical-system (all <i>logical-system-name</i>)> <summary> <task-name>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display routing protocol tasks on the Routing Engine.
Options	<p>none—Display all routing protocol tasks on the Routing Engine on all logical systems.</p> <p>logical-system (all <i>logical-system-name</i>)—(Optional) Perform this operation on all logical systems or on a particular logical system.</p> <p>summary—(Optional) Display summary information about running tasks.</p> <p><i>task-name</i>—(Optional) Display summary information about running tasks whose name matches this substring.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show task io on page 1166 • show task memory on page 1168
List of Sample Output	show task on page 1165
Output Fields	Table 160 on page 1164 describes the output fields for the show task command. Output fields are listed in the approximate order in which they appear.

Table 160: show task Output Fields

Field Name	Field Description
Pri	Current priority of the process. A lower number indicates a higher priority.
Task Name	Name of the task.
Pro	IP protocol number associated with the process.
Port	TCP or UDP port number associated with the task.
So	Socket number of the task.

Table 160: show task Output Fields (*continued*)

Field Name	Field Description
Flags	Flags for the task: <ul style="list-style-type: none"> • Accept—Task is waiting for incoming connections. • Connect—Task is waiting for a connection to be completed. • Delete—Task has been deleted and is being cleaned up. • LowPrio—Task will be dispatched to read its socket after other higher-priority tasks.

Sample Output

```

show task user@host> show task
Pri Task Name                               Pro  Port So Flags
10 IF
15 LABEL
15 ISO
15 INET                                     7
20 Aggregate
20 RT
30 ICMP                                   1    9
39 ISIS I/O                               12
40 IS-IS                                  10
40 BGP RT Background                       <LowPrio>
40 BGP.0.0.0.0+179                        179 15 <Accept LowPrio>
50 BGP_69.192.168.201.234+179             179 17 <LowPrio>
50 BGP_70.192.168.201.233+179             179 16 <LowPrio>
50 BGP_Group_69_153                       <LowPrio>
50 BGP_Group_70_153                       <LowPrio>
50 ASPaths
60 KRT                                   255    1
60 Redirect
70 MGMT.local                             14 <LowPrio>
70 MGMT_Listen./var/run/rpd_mgmt           13 <Accept LowPrio>
70 SNMP Subagent./var/run/sub_rpd.sock     8 <LowPrio>

```

show task io

Syntax	show task io <logical-system (all <i>logical-system-name</i>)>
Syntax (EX Series Switch)	show task io
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display I/O statistics for routing protocol tasks on the Routing Engine.
Options	none—Display I/O statistics for routing protocol tasks on the Routing Engine. logical-system (all <i>logical-system-name</i>)—(Optional) Perform this operation on all logical systems or on a particular logical system.
Required Privilege Level	view
List of Sample Output	show task io on page 1166
Output Fields	Table 161 on page 1166 describes the output fields for the show task io command. Output fields are listed in the approximate order in which they appear.

Table 161: show task io Output Fields

Field Name	Field Description
Task Name	Name of the task.
Reads	Number of input ready notifications.
Writes	Number of output ready notifications.
Rcvd	Number of requests to the kernel for input.
Sent	Number of requests to the kernel for output.
Dropped	Number of sent requests that failed.

Sample Output

```

user@host> show task io
Task Name           Reads  Writes  Rcvd   Sent  Dropped
LMP Client          1       1       0       0       0
IF                   0       0       0       0       0
INET6                0       0       0       0       0
INET                 0       0       0       0       0
ISO                  0       0       0       0       0
Memory               0       0       0       0       0
RPD Unix Domain Server./var/ru 0       0       0       0       0

```

RPD Unix Domain Server./var/ru	1	0	0	0	0
RPD Unix Domain Server./var/ru	2	0	0	0	0
RPD Server.0.0.0.0+666	0	0	0	0	0
Aggregate	0	0	0	0	0
RT	0	0	0	0	0
ICMP	0	0	0	0	0
Router-Advertisement	0	0	0	0	0
ICMPv6	0	0	0	0	0
IS-IS I/O./var/run/ppmd_contro	1307	1	0	0	0
l2vpn global task	0	0	0	0	0
IS-IS	0	0	0	0	0
BFD I/O./var/run/bfdd_control	1307	1	0	0	0
TED	0	0	0	0	0
ASPaths	0	0	0	0	0
Resolve tree 1	0	0	0	0	0
KStat	0	0	0	0	0
KRT Request	0	0	63	0	0
KRT Ifstate	106	0	295	0	0
KRT	0	0	0	0	0
Redirect	0	0	0	0	0
...					

show task memory

Syntax	show task memory <brief detail history summary> <logical-system (all <i>logical-system-name</i>)>
Syntax (EX Series Switch)	show task memory <brief detail history summary>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display memory utilization for routing protocol tasks on the Routing Engine.
Options	<p>none—Display standard information about memory utilization for routing protocol tasks on the Routing Engine on all logical systems.</p> <p>brief detail history summary—(Optional) Display the specified level of output. Use the history option to display a history of memory utilization information.</p> <p>logical-system (all <i>logical-system-name</i>)—(Optional) Perform this operation on all logical systems or on a particular logical system.</p>
Required Privilege Level	view
List of Sample Output	<p>show task memory on page 1169</p> <p>show task memory detail on page 1170</p>
Output Fields	Table 162 on page 1168 describes the output fields for the show task memory command. Output fields are listed in the approximate order in which they appear.

Table 162: show task memory Output Fields

Field Name	Field Description	Level of Output
Memory Currently In Use	Memory currently in use.	All levels
Memory Maximum Ever Used	Maximum memory ever used.	none specified, brief , history
Memory Available	Memory currently available.	none specified, brief
Size (kB)	Memory capacity in 1000-byte kilobytes.	none specified, brief , history , summary
%Available	Percentage of memory currently available.	none specified, brief
When	Timestamp.	none specified, brief , history

Table 162: show task memory Output Fields (*continued*)

Field Name	Field Description	Level of Output
Overall Memory Report	Memory utilization by memory size: <ul style="list-style-type: none"> • Size—Block size, in bytes. • TPT—indicates transient memory, and P indicates full page. • Allocs—Number of blocks allocated for named objects. • Mallocs—Number of blocks allocated for anonymous objects. • Alloc Bytes—Number of blocks allocated times block size. • MaxAllocs—Maximum value of Allocs. • MaxBytes—Maximum value of Alloc Bytes. • FreeBytes—Total number of bytes unused on memory pages for this block size. 	detail
Allocator Memory Report	Memory utilization by named objects: <ul style="list-style-type: none"> • Size—Size of the named object in bytes. • Alloc Size—Actual memory used by that object in bytes. • DTP—indicates debug, D T indicates transient, and P indicates full page. • Alloc Blocks—Number of named objects allocated. • AllocBytes—Number of blocks allocated times block size. • MaxAlloc Blocks—Maximum value of Alloc Blocks. • Max Alloc Bytes—Maximum value of AllocBytes. 	detail
Malloc Usage Report	Memory utilization for miscellaneous use: <ul style="list-style-type: none"> • Allocs—Number of allocations. • Bytes—Total bytes consumed. • MaxAllocs—Maximum value of Allocs. • MaxBytes—Maximum value of Bytes. • FuncCalls—Cumulative number of Allocs. 	detail
Dynamically allocated memory	Memory allocated dynamically by the system.	detail
Program data+BSS memory	Program and base station subsystem (BSS) memory.	detail
Page data overhead	Internal memory overhead.	detail
Page directory size	Internal memory overhead.	detail
Total bytes in use	Total memory, in bytes, that is currently in use and percentage of available memory (in parentheses).	detail

Sample Output

```

show task memory  user@host> show task memory
Memory           Size (kB) %Available When
Currently In Use: 29417      3%    now

```

```

Maximum Ever Used:      33882          4% 00/02/11 22:07:03
Available:              756281        100% now

```

```

show task memory user@host> show task memory detail
detail

```

```

----- Overall Memory Report -----
Size TP      Allocs  Mallocs  AllocBytes  MaxAllocs  MaxBytes  FreeBytes
  8          -      111      888        112        896      3208
 12          92      149      2892       247        2964     1204
 12 T        -        -        -          5          60        -
 16          7       11       288        23        368     3808
 20         100      33      2660       164       3280     1436
 20 T        -        -        -         40        800        -
 24         162      15      4248       177       4248     3944
 24 T        -        -        -          4          96        -
 28         371      -     10388      372      10416     1900
 32          6       23       928        30        960     3168
...
-----
                                606182                                715302                                118810

```

```

----- Allocator Memory Report -----
Name                Size Alloc DTP      Alloc      Alloc MaxAlloc  MaxAlloc
                   Size      Blocks  Bytes      Blocks  Bytes
patroot             8   12      84      1008      87      1044
sockaddr_un.i802    8   12        2       24        2       24
cos_nhm_nh          8   12        1       12        1       12
sockaddr_un.tag     8   12        3       36        4       48
gw_entry_list       8   12        1       12        1       12
bgp_riblist_01      8   12        1       12        2       24
ospf_intf_ev        8   12        -        -        6       72
krt_remnant_rt      8   12 T        -        -        5       60
...
-----
                                164108                                221552

```

```

----- Malloc Usage Report -----
Name                Allocs  Bytes MaxAllocs  MaxBytes  FuncCalls
MGMT.local          1        8        1        8        1
BGP.0.0.0.0+179     -        -        1        8        2
BGP RT Background   4     74748      4     74748      4
SNMP Subagent./var/run/ -      52        1     9172     56
OSPFv2 I/O./var/run/ppm 1     66536      2     66552    4551
OSPF                6     67655      7     67703     68
KRT                 -        -        1     3784     18
ASPaths            3        80        3        80        3
-- sockaddr --      183     2100     184     2108    1645
BFD I/O./var/run/bfdd_c 1     65535      2     65551    4555
RT                 48       872      48       872     48
Scheduler           42       628      43       628     88
--Anonymous--       56      1100      58      1140    112
--System--          82     58364     114     60044    4654
...
-----
                                337678                                352398

```

```

Dynamically allocated memory: 765952      Maximum: 765952
Program data+BSS memory:     1568768     Maximum: 1568768
Page data overhead:          53248       Maximum: 53248
Page directory size:         4096        Maximum: 4096

```

Total bytes in use: 2392064 (0% of available memory)

show task replication

Syntax	show task replication
Release Information	Command introduced in Junos OS Release 8.5. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Displays graceful Routing Engine switchover (GRES) and nonstop active routing (NSR) status. When you issue this command on the master Routing Engine, the status of nonstop active routing synchronization is also displayed.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show task replication (Issued on the Master Routing Engine) on page 1172 show task replication (Issued on the Backup Routing Engine) on page 1173
Output Fields	Table 163 on page 1172 lists the output fields for the show task replication command. Output fields are listed in the approximate order in which they appear.

Table 163: show task replication Output Fields

Field Name	Field Description
Stateful replication	Displays whether or not graceful Routing Engine switchover is configured. The status can be Enabled or Disabled .
RE mode	Displays the Routing Engine on which the command is issued: Master , Backup , or Not applicable (when the router has only one Routing Engine).
Protocol	Protocol that are supported by nonstop active routing.
Synchronization Status	Nonstop active routing synchronization status for the supported protocols. States are NotStarted , InProgress , and Complete .

Sample Output

```

show task replication (Issued on the Master Routing Engine)
user@host> show task replication
Stateful Replication: Enabled
RE mode: Master

Protocol      Synchronization Status
OSPF          NotStarted
BGP           Complete
IS-IS        NotStarted
LDP           Complete

```

show task replication	user@host> show task replication
(Issued on the Backup	Stateful Replication: Enabled
Routing Engine)	RE mode: Master

show version

Syntax	show version <brief detail>
Syntax (EX Series Switch)	show version <all-members> <brief detail> <local> <member <i>member-id</i> >
Syntax (TX Matrix Router)	show version <brief detail> <all-chassis all-lcc lcc <i>number</i> scc>
Syntax (TX Matrix Plus Router)	show version <all-chassis all-lcc lcc <i>number</i> sfc <i>number</i> > <brief detail>
Syntax (MX Series Router)	show version <brief detail> <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. sfc option introduced for the TX Matrix Plus router in Junos OS Release 9.6. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the hostname and version information about the software running on the router or switch.
Options	<p>none—Display standard information about the hostname and version of the software running on the router or switch.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>all-lcc—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display the hostname and version information about the software running on all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, display the hostname and version information about the software running on all T1600 routers (or line-card chassis) connected to the TX Matrix Plus router.</p> <p>all-members—(EX4200 switches and MX Series routers only) (Optional) Display standard information about the hostname and version of the software running on all members of the Virtual Chassis configuration.</p> <p>lcc <i>number</i>—(TX Matrix and TX Matrix Plus routers only) (Optional) On a TX Matrix router, display the hostname and version information about the software running on a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus</p>

router, display the hostname and version information about the software running on a specific T1600 router that is connected to the TX Matrix Plus router. Replace *number* with a value from 0 through 3.

local—(EX4200 switches and MX Series routers only) (Optional) Display standard information about the hostname and version of the software running on the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Display standard information about the hostname and version of the software running on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

scc—(TX Matrix routers only) (Optional) Display the hostname and version information about the software running on the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Display the hostname and version information about the software running on the TX Matrix Plus router (or switch-fabric chassis). Replace *number* with 0.

Additional Information By default, when you issue the **show version** command on a TX Matrix or TX Matrix Plus master Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) master Routing Engines connected to it. Likewise, if you issue the same command on the TX Matrix or TX Matrix Plus backup Routing Engine, the command is broadcast to all the T640 (in a routing matrix based on a TX Matrix router) or T1600 (in a routing matrix based on a TX Matrix Plus router) backup Routing Engines that are connected to it.

Required Privilege Level view

List of Sample Output **show version on page 1176**
show version (TX Matrix Plus Router) on page 1176
show version (QFX Series) on page 1181

Sample Output

```

show version      user@host> show version
                    Hostname: router1
                    Model: m20
                    JUNOS Base OS boot [7.2-20050312.0]
                    JUNOS Base OS Software Suite [7.2-20050312.0]
                    JUNOS Kernel Software Suite [7.2R1.7]
                    JUNOS Packet Forwarding Engine Support (M20/M40) [7.2R1.7]
                    JUNOS Routing Software Suite [7.2R1.7]
                    JUNOS Online Documentation [7.2R1.7]
                    JUNOS Crypto Software Suite [7.2R1.7]

                    {master}

                    user@host> show version psd 1
                    psd1-re0:
                    -----
                    Hostname: china
                    Model: t640
                    JUNOS Base OS boot [9.1I20080311_1959_adthakur]
                    JUNOS Base OS Software Suite [9.1-20080321.0]
                    JUNOS Kernel Software Suite [9.1-20080321.0]
                    JUNOS Crypto Software Suite [9.1-20080321.0]
                    JUNOS Packet Forwarding Engine Support (M/T Common) [9.1-20080321.0]
                    JUNOS Packet Forwarding Engine Support (T-series) [9.1-20080321.0]
                    JUNOS Online Documentation [9.1-20080321.0]
                    JUNOS Routing Software Suite [9.1-20080321.0]
                    labpkg [7.0]

show version (TX  user@host> show version
Matrix Plus Router) sfc0-re0:
                    -----
                    Type InUse MemUse HighUse Requests Size(s)
                    file desc 164 35K - 4034 16,1024,2048,16384
                    sigio 1 1K - 50 32
                    kenv 28 5K - 31 16,32,64,131072
                    kqueue 5 3K - 119 1024,4096,32768
                    proc-args 66 3K - 2951 16,32,64,128,256,512,1024,2048
                    zombie 0 0K - 3513 128
                    ithread 100 7K - 100 16,64,256
                    CAM queue 3 1K - 3 16
                    KTRACE 100 10K - 100 128
                    entropy 1024 64K - 1024 64
                    USB 127 10K - 127 16,32,64,128,256,1024,2048
                    linker 485 6216K - 1166 16,32,64,4096,32768,131072
                    USBdev 10 1K - 34 16,128,2048,16384
                    lockf 50 4K - 64872 64
                    devbuf 21086 15337K - 21661
                    16,32,64,128,256,512,1024,2048,4096,16384,32768,65536,131072
                    temp 1249 149K - 9479
                    16,32,64,128,256,512,2048,4096,16384,32768,65536,131072
                    ip6ndp 0 0K - 4 64
                    in6ifmulti 1 1K - 1 64
                    in6grentry 1 1K - 1 64
                    iftable 13 3K - 14 16,64,4096
                    iflogical 17 4K - 24 64,2048
                    iffamilly 45 6K - 63 32,1024,2048
                    rtnexthop 206 36K - 380
                    16,32,64,256,512,1024,2048,4096,8192,16384

```


metrics	5	1K	-	25	256
inifmulti	6	1K	-	12	64
ingrentry	12	1K	-	24	64
rnode	126	3K	-	240	16, 32
rcache	4	8K	-	4	65536
tagbh	10	2K	-	20	256
ifdevice	11	8K	-	11	16, 32768
ifstat	2817	2765K	-	2825	16, 32, 1024, 16384, 32768, 65536
ipfw	32	22K	-	43	
16, 32, 64, 128, 256, 512, 16384, 32768, 65536, 131072					
ifmaddr	399	11K	-	435	16, 32
rtable	208	19K	-	340	16, 32, 64, 128, 1024, 16384
sysctl	0	0K	-	1188265	16, 32, 64, 4096, 16384, 32768
ifaddr	45	3K	-	57	32, 64, 128
mkey	354	6K	-	4690	16, 128
pfe_ipc	0	0K	-	11456	
16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536, 131072					
ifstate	5961	435K	-	6846	
16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 16384, 32768					
itable16	249	39K	-	294	256, 4096
itable32	148	5K	-	148	32
itable64	2	1K	-	2	64
lr	1	1K	-	1	16384
pic	29	3K	-	29	64, 16384
pfestat	0	0K	-	2820	32, 128, 65536
gencfg	1499	200K	-	6086	
16, 32, 64, 128, 512, 4096, 16384, 32768, 65536					
jsr	2	1K	-	10	16
idl	1	4K	-	121	
32, 64, 128, 256, 512, 1024, 2048, 4096, 16384, 32768, 65536, 131072					
rtsmsg	0	0K	-	16	131072
DEVFS2	108	2K	-	108	16
DEVFS3	204	23K	-	205	256
module	247	16K	-	247	64, 128
mtx_pool	1	8K	-	1	
DEVFS1	108	27K	-	108	4096
pgrp	20	2K	-	275	64
session	14	2K	-	173	512
proc	2	1K	-	2	16384
subproc	302	601K	-	3815	4096, 131072
cred	45	5K	-	33092	256
plimit	22	5K	-	1363	2048
uidinfo	3	1K	-	6	32, 512
sysctlold	2548	78K	-	2548	16, 32, 64
sysctltmp	0	0K	-	1449	16, 32, 64, 1024
umtx	162	11K	-	162	64
SWAP	2	277K	-	2	64
bus	781	126K	-	3263	16, 32, 64, 128, 32768
bus-sc	67	62K	-	1623	
16, 32, 64, 512, 1024, 4096, 16384, 65536, 131072					
DEVFS	14	1K	-	15	16, 64
devstat	8	17K	-	8	16, 131072
eventhandler	42	2K	-	42	32, 128
kobj	93	186K	-	111	65536
rman	106	7K	-	490	16, 32, 64
sbuf	0	0K	-	1112	16, 32, 32768, 131072
NULLFS hash	1	1K	-	1	64
taskqueue	5	1K	-	5	64
turnstiles	163	11K	-	163	64
Unitno	6	1K	-	10	16, 64
ioctlops	0	0K	-	477380	16, 32, 64, 128, 16384, 65536, 131072

iov	0	OK	-	49032	16, 64, 128, 256, 512, 1024, 2048, 131072
msg	4	25K	-	4	32768, 131072
sem	4	7K	-	4	16384, 32768, 131072
shm	3	14K	-	8	32768
ttys	412	60K	-	863	512, 32768
ptys	4	1K	-	4	128
mbextcnt	0	OK	-	42	16
soname	104	11K	-	104726	16, 32, 64, 256
pcb	256	32K	-	1097	
16, 32, 64, 128, 1024, 2048, 4096, 16384, 32768, 65536					
BIO buffer	44	88K	-	723	65536
vfscache	1	512K	-	1	
cluster_save buffer	0	OK	-	-	30 32, 64
VFS hash	1	256K	-	1	
vnodes	1	1K	-	1	512
mount	274	23K	-	489	16, 32, 64, 128, 256, 4096, 32768
vnodemarker	0	OK	-	1699	16384
pfs_nodes	25	3K	-	25	128
pfs_vncache	227	8K	-	429	32
GEOM	173	15K	-	1068	
16, 32, 64, 128, 256, 512, 2048, 16384, 32768, 131072					
STP	1	1K	-	1	64
CAM dev queue	1	1K	-	1	64
syncache	1	8K	-	1	
tlv_stat	0	OK	-	238	
NFS daemon	1	8K	-	1	
pagedep	1	64K	-	124	64
inodedep	1	256K	-	605	256
newblk	1	1K	-	611	64, 4096
bmsafemap	0	OK	-	47	64
allocdirect	0	OK	-	605	128
indirdep	0	OK	-	6	32
allocindir	0	OK	-	5	64
freefrag	0	OK	-	91	32
freeblks	0	OK	-	93	2048
freefile	0	OK	-	161	32
diradd	0	OK	-	603	64
mkdir	0	OK	-	166	32
dirrem	0	OK	-	312	32
newdirblk	0	OK	-	1	32
savedino	0	OK	-	294	512
UFS mount	15	36K	-	15	4096, 65536, 131072
UMAHash	1	16K	-	7	4096, 16384, 32768, 65536, 131072
MD disk	9	18K	-	9	65536
ata_generic	2	2K	-	21	16, 16384, 32768
ISOFS mount	7	1K	-	13	512
VM pgdata	2	65K	-	2	64
ISOFS node	1405	132K	-	1419	128
CAM SIM	1	1K	-	1	64
atkbddev	2	1K	-	2	32
Gzip trees	0	OK	-	470292	32, 64, 128, 1024, 8192, 32768, 65536, 131072
CAM XPT	6	1K	-	9	16, 64, 16384
isadev	23	2K	-	23	64
CAM periph	1	1K	-	1	128
I/O APIC	1	1K	-	1	32768
ad_driver	2	1K	-	2	256
legacydrv	3	1K	-	3	16
memdesc	1	4K	-	1	131072
MP Table	1	1K	-	1	128
nexusdev	2	1K	-	2	16

	ata_dma	6	1K	-	6	256	
	cdev	26	3K	-	26	256	
	kbdmux	5	9K	-	5	128,4096,65536,131072	
ITEM	SIZE	LIMIT	USED	FREE	REQUESTS		
UMA Kegs:	136,	0,	69,	3,	69		
UMA Zones:	120,	0,	69,	21,	69		
UMA Slabs:	64,	0,	1681,	30,	17268		
UMA RCntSlabs:	104,	0,	2419,	23,	2419		
UMA Hash:	128,	0,	4,	26,	5		
16 Bucket:	76,	0,	32,	18,	32		
32 Bucket:	140,	0,	35,	21,	35		
64 Bucket:	268,	0,	32,	10,	32		
128 Bucket:	524,	0,	105,	0,	105		
VM OBJECT:	128,	0,	3767,	193,	69113		
MAP:	160,	0,	7,	41,	7		
KMAP ENTRY:	68,	44352,	26,	142,	40036		
MAP ENTRY:	68,	0,	2718,	474,	195484		
PV ENTRY:	24,	1259180,	107193,	12722,	5133143		
DP fakepg:	72,	0,	0,	0,	0		
mt_zone:	64,	0,	231,	64,	231		
16:	16,	0,	4447,	222,	1707104		
32:	32,	0,	5559,	204,	427638		
64:	64,	0,	23128,	59,	191981		
96:	96,	0,	3628,	92,	36576		
112:	112,	0,	782,	93,	51883		
128:	128,	0,	727,	143,	2028		
160:	160,	0,	1041,	39,	9623		
208:	208,	0,	302,	40,	5625		
256:	256,	0,	627,	18,	4296		
272:	272,	0,	48,	22,	3160		
512:	512,	0,	666,	14,	5529		
1024:	1024,	0,	420,	12,	15128		
2048:	2048,	0,	1909,	17,	13067		
4096:	4096,	0,	228,	19,	7877		
Files:	72,	0,	586,	103,	124488		
PROC:	544,	0,	139,	22,	3652		
THREAD:	416,	0,	161,	1,	162		
KSEGRP:	88,	0,	161,	39,	162		
UPCALL:	44,	0,	0,	0,	0		
SLEEPQUEUE:	32,	0,	163,	176,	163		
VMSPACE:	268,	0,	66,	18,	3569		
mbuf_packet:	256,	180000,	256,	128,	27221		
mbuf:	256,	180000,	4110,	501,	2286155		
mbuf_cluster:	2048,	30000,	4487,	351,	697551		
mbuf_jumbo_pagesize:	4096,		0,	0,	0,	0	
mbuf_jumbo_9k:	9216,	0,	0,	0,	0		
mbuf_jumbo_16k:	16384,	0,	0,	0,	0		
ACL UMA zone:	388,	0,	0,	0,	0		
g_bio:	132,	0,	0,	290,	97288		
ata_request:	200,	0,	0,	76,	5910		
ata_composite:	192,	0,	0,	0,	0		
VNODE:	292,	0,	4128,	32,	4583		
VNODEPOLL:	72,	0,	0,	0,	0		
S VFS Cache:	68,	0,	3890,	86,	9271		
L VFS Cache:	291,	0,	17,	22,	24		
NAMEI:	1024,	0,	0,	36,	341732		
NFSMOUNT:	480,	0,	0,	0,	0		
NFSNODE:	460,	0,	0,	0,	0		
PIPE:	404,	0,	29,	7,	1825		
KNOTE:	72,	0,	35,	71,	15004		

socket:	412,	30006,	352,	26,	4683
ipq:	52,	288,	0,	0,	0
udpcb:	224,	30005,	24,	27,	232
inpcb:	224,	30005,	35,	33,	140
tcpcb:	520,	30002,	35,	7,	140
tcptw:	56,	6030,	0,	134,	66
syncache:	128,	15360,	0,	60,	41
tcpreass:	20,	2028,	0,	0,	0
sackhole:	20,	0,	0,	0,	0
ripcb:	224,	30005,	5,	29,	7
unpcb:	140,	30016,	150,	46,	3791
SWAPMETA:	276,	121576,	0,	0,	0
FFS inode:	132,	0,	2385,	51,	2622
FFS1 dinode:	128,	0,	2385,	45,	2622
FFS2 dinode:	256,	0,	0,	0,	0

```

19933113 cpu context switches
5244831 device interrupts
154821 software interrupts
459702 traps
8357837 system calls
    76 kernel threads created
3442 fork() calls
134 vfork() calls
    0 rfork() calls
    0 swap pager pageins
    0 swap pager pages paged in
    0 swap pager pageouts
    0 swap pager pages paged out
504 vnode pager pageins
538 vnode pager pages paged in
380 vnode pager pageouts
3646 vnode pager pages paged out
    0 page daemon wakeups
    0 pages examined by the page daemon
56570 pages reactivated
127752 copy-on-write faults
    39 copy-on-write optimized faults
200992 zero fill pages zeroed
196746 zero fill pages prezeroed
    27 intransit blocking page faults
443499 total VM faults taken
    0 pages affected by kernel thread creation
441644 pages affected by fork()
52141 pages affected by vfork()
    0 pages affected by rfork()
420183 pages freed
    0 pages freed by daemon
206284 pages freed by exiting processes
52228 pages active
56648 pages inactive
52413 pages in VM cache
17956 pages wired down
654199 pages free
    4096 bytes per page
    0 swap pages used
    0 peak swap pages used
1295493 total name lookups
    cache hits (93% pos + 5% neg) system 0% per-directory
    deletions 0%, falsehits 0%, toolong 0%
interrupt                                total      rate

```

irq4: sio0	5131	1
irq16: uhci0 uhci*	164201	40
irq17: uhci1 uhci*	386684	95
cpu0: timer	8131301	2017
Total	8687317	2155
vm.kmem_map_free: 618377216		

```
show version (QFX Series) user@switch> show version
Hostname: switch
Model: qfx_s3500
JUNOS Base OS boot [11.1R1]
JUNOS Base OS Software Suite [11.1R1]
JUNOS Kernel Software Suite [11.1R1]
JUNOS Crypto Software Suite [11.1R1]
JUNOS Online Documentation [11.1R1]
JUNOS Enterprise Software Suite [11.1R1]
JUNOS Packet Forwarding Engine Support (QFX) [11.1R1]
JUNOS Routing Software Suite [11.1R1]
```

show version invoke-on

Syntax	show version invoke-on (all-routing-engines other-routing-engine)
Syntax (MX Series Router)	show version invoke-on (all-routing-engines other-routing-engine) <all-members> <local> <member <i>member-id</i> >
Release Information	Command introduced before JUNOS Release 7.4.
Description	Display the hostname and version information about the software running on a router with two Routing Engines.
Options	<p>all-routing-engines—Display the hostnames and version information about the software running on all master and backup Routing Engines on a routing matrix based on the TX Matrix or TX Matrix Plus router or on a router that has dual Routing Engines.</p> <p>other-routing-engine—Display the hostnames and version information about the software running on the other Routing Engine. For example, if you issue this command on the master Routing Engine on an M320 router, the JUNOS Software displays the hostname and version information on the backup Routing Engine. On a routing matrix based on the TX Matrix or TX Matrix Plus router, if you issue this command on the TX Matrix or TX Matrix Plus router's master Routing Engine, the JUNOS Software displays all the hostnames and version information on all the backup Routing Engines.</p> <p>all-members—(MX Series routers only) (Optional) Display the hostnames and version information about the software running on all master and backup Routing Engines on all members of the Virtual Chassis configuration. Specify the all-members option before the invoke-on keyword.</p> <p>local—(MX Series routers only) (Optional) Display the hostnames and version information about the software running on all master and backup Routing Engines on the local Virtual Chassis member. Specify the local option before the invoke-on keyword.</p> <p>member <i>member-id</i>—(MX Series routers only) (Optional) Display the hostnames and version information about the software running on all master and backup Routing Engines on the specified member of the Virtual Chassis configuration. Replace <i>member-id</i> with a value of 0 or 1. Specify the member <i>member-id</i> option before the invoke-on keyword.</p>
Required Privilege Level	view
List of Sample Output	<p>show version invoke-on all-routing-engines (TX Matrix Router) on page 1183</p> <p>show version invoke-on other-routing-engine (TX Matrix Router) on page 1185</p> <p>show version invoke-on all-routing-engines (TX Matrix Plus Router) on page 1186</p> <p>show version invoke-on other-routing-engine (TX Matrix Plus Router) on page 1191</p>

Sample Output

```

show version      user@host> show version invoke-on all-routing-engines
invoke-on        scc-re0:
all-routing-engines
(TX Matrix Router)
-----
Hostname: bob
Model: TX Matrix
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]
JUNOS Support Tools Package [7.1-20041025.1]

scc-re1:
-----
Hostname: bob1
Model: TX Matrix
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]
JUNOS Support Tools Package [7.1-20041025.1]

lcc0-re0:
-----
Hostname: cas
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc0-re1:
-----
Hostname: cas1-lcc0
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc1-re0:
-----
Hostname: jas
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]

```

JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc1-re1:

Hostname: jas1
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc2-re0:

Hostname: dew
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc2-re1:

Hostname: dew1
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc3-re0:

Hostname: wa
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc3-re1:

Hostname: wa1
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041025.1]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]


```

JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

show version user@host> show version invoke-on other-routing-engine
invoke-on scc-re1:
other-routing-engine -----
(TX Matrix Router) Hostname: bob1
Model: TX Matrix
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]
JUNOS Support Tools Package [7.1-20041025.1]

lcc0-re1:
-----
Hostname: cas1-lcc0
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]
lcc1-re1:
-----
Hostname: jas1
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

lcc2-re1:
-----
Hostname: dew1
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041024.0]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]
JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]
lcc3-re1:
-----
Hostname: wal
Model: t640
JUNOS Base OS boot [7.1-20041024.0]
JUNOS Base OS Software Suite [7.1-20041025.1]
JUNOS Kernel Software Suite [7.1-20041024.0]
JUNOS Packet Forwarding Engine Support (T-Series) [7.1-20041024.0]
JUNOS Routing Software Suite [7.1-20041024.0]

```

```

JUNOS Online Documentation [7.1-20041024.0]
JUNOS Crypto Software Suite [7.1-20041024.0]

show version user@host> show version invoke-on all-routing-engines
invoke-on sfc0-re0:
all-routing-engines -----
(TX Matrix Plus
Router)
Hostname: aj
Model: txp
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc0-re0:
-----
Hostname: lj
Model: tl600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc1-re0:
-----
Hostname: mj
Model: tl600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]

```

```
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

```
lcc2-re0:
```

```
-----
Hostname: pj
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

```
lcc3-re0:
```

```
-----
Hostname: tj
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

```
sfc0-re1:
```

```
-----
Hostname: aj1
Model: txp
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
```

JUNOS Routing Software Suite [9.6-20090519.0]

lcc0-re1:

```
-----
Hostname: ljl
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

lcc1-re1:

```
-----
Hostname: mjl
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

lcc2-re1:

```
-----
Hostname: pj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

```
lcc3-re1:
```

```
-----
Hostname: tj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

```
lcc0-re0:
```

```
-----
Hostname: lj
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

```
lcc0-re1:
```

```
-----
Hostname: lj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]
```

lcc1-re0:

Hostname: mj
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc1-re1:

Hostname: mj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc2-re0:

Hostname: pj
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc2-re1:

```

-----
Hostname: pj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

```

```
lcc3-re0:
```

```

-----
Hostname: tj
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

```

```
lcc3-re1:
```

```

-----
Hostname: tj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

```

```

show version   user@host> show version invoke-on other-routing-engine
invoke-on

```

**other-routing-engine
(TX Matrix Plus
Router)****sfc0-re1:**

Hostname: aj1
Model: txp
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc0-re1:

Hostname: lj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]

lcc1-re1:

Hostname: mj1
Model: t1600
JUNOS Base OS boot [9.6-20090519.0]
JUNOS Base OS Software Suite [9.6-20090519.0]
JUNOS Kernel Software Suite [9.6-20090519.0]
JUNOS Crypto Software Suite [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]
JUNOS Online Documentation [9.6-20090519.0]
JUNOS Voice Services Container package [9.6-20090519.0]
JUNOS Border Gateway Function package [9.6-20090519.0]
JUNOS Services AACL Container package [9.6-20090519.0]
JUNOS Services LL-PDF Container package [9.6-20090519.0]
JUNOS Services Stateful Firewall [9.6-20090519.0]
JUNOS AppId Services [9.6-20090519.0]
JUNOS IDP Services [9.6-20090519.0]
JUNOS Routing Software Suite [9.6-20090519.0]


lcc2-re1:


```
-----  
Hostname: pj1  
Model: t1600  
JUNOS Base OS boot [9.6-20090519.0]  
JUNOS Base OS Software Suite [9.6-20090519.0]  
JUNOS Kernel Software Suite [9.6-20090519.0]  
JUNOS Crypto Software Suite [9.6-20090519.0]  
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]  
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]  
JUNOS Online Documentation [9.6-20090519.0]  
JUNOS Voice Services Container package [9.6-20090519.0]  
JUNOS Border Gateway Function package [9.6-20090519.0]  
JUNOS Services AACL Container package [9.6-20090519.0]  
JUNOS Services LL-PDF Container package [9.6-20090519.0]  
JUNOS Services Stateful Firewall [9.6-20090519.0]  
JUNOS AppId Services [9.6-20090519.0]  
JUNOS IDP Services [9.6-20090519.0]  
JUNOS Routing Software Suite [9.6-20090519.0]
```

lcc3-re1:

```
-----  
Hostname: tj1  
Model: t1600  
JUNOS Base OS boot [9.6-20090519.0]  
JUNOS Base OS Software Suite [9.6-20090519.0]  
JUNOS Kernel Software Suite [9.6-20090519.0]  
JUNOS Crypto Software Suite [9.6-20090519.0]  
JUNOS Packet Forwarding Engine Support (M/T Common) [9.6-20090519.0]  
JUNOS Packet Forwarding Engine Support (T-Series) [9.6-20090519.0]  
JUNOS Online Documentation [9.6-20090519.0]  
JUNOS Voice Services Container package [9.6-20090519.0]  
JUNOS Border Gateway Function package [9.6-20090519.0]  
JUNOS Services AACL Container package [9.6-20090519.0]  
JUNOS Services LL-PDF Container package [9.6-20090519.0]  
JUNOS Services Stateful Firewall [9.6-20090519.0]  
JUNOS AppId Services [9.6-20090519.0]  
JUNOS IDP Services [9.6-20090519.0]  
JUNOS Routing Software Suite [9.6-20090519.0]
```

start shell

Syntax	<code>start shell (csh sh)</code> <code><user username></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Exit from the CLI environment and create a UNIX-level shell. To return to the CLI, type exit from the shell.
	<div> NOTE:<ul style="list-style-type: none">To issue this command, the user must have the required login access privileges configured by including the permissions statement at the [edit system login class class-name] hierarchy level.UNIX wheel group membership or permissions are no longer required to issue this command.</div>
Options	<code>csh</code> —Create a UNIX C shell. <code>sh</code> —Create a UNIX Bourne shell. <code>user username</code> —(Optional) Start the shell as another user.
Additional Information	When you are in the shell, the shell prompt has the following format: <code>username@hostname%</code> An example of the prompt is: <code>root@host%</code>
Required Privilege Level	shell and maintenance
List of Sample Output	start shell csh on page 1194
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
start shell csh  user@host> start shell csh
                  %
                  exit
                  %
                  username@hostname% start shell sh
```

```
%  
exit  
user@host>
```

test aaa authd-lite user

Syntax	<code>test aaa authd-lite user <i>username</i> password <i>password</i> profile <i>access-profile-name</i> <port <i>nas-port</i>> <zero-stats></code>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Verify authd-lite subscriber access authentication, accounting, and address allocation configuration.
Options	<p><i>username</i>—Specify the subscriber username to test.</p> <p><i>password password</i>—Specify the password associated with the username.</p> <p><i>profile access-profile-name</i>—Specify the access profile associated with the subscriber.</p> <p><i>port nas-port</i>—(Optional) Specify the NAS port used for the test.</p> <p><i>zero-stats</i>—(Optional) Specify that no accounting statistics are set for this test.</p>
Required Privilege Level	view
List of Sample Output	test aaa authd-lite user on page 1196
Output Fields	<p>When you enter this command, you are provided feedback on the status of your request. For information about output fields related to authentication, accounting, and subscriber-specific information, see the show network-access aaa statistics, show network-access aaa subscribers, and show subscribers commands.</p> <p>The test command does not support volume-time accounting. If volume-time accounting is configured for the test subscriber, the test command replaces the statistics with time-only accounting statistics.</p>

Sample Output

test aaa authd-lite user The following example tests the configuration for authd-lite subscriber brady-t with a password of a11pr0 and an access profile of employee12, and displays the resulting output:

```

user@host> test aaa authd-lite user brady-t password a11pr0 profile employee12
Authentication Grant
*****User Attributes*****
  User Name -                               brady-t
  Framed Ipv6 Prefix -                       ::/0
  Framed Ipv6 Pool -                         NULL
  Nas Ipv6 Address -                         ::
  NDRA Ipv6 Prefix -                         NULL
  Login Ipv6 Host -                          ::
  Framed Interface Id: -                     0:0:0:0
  Delegated Ipv6 Prefix -                   ::/0
  NDRA Ipv6 Pool -                           NULL
  User Password -                           a11pr0
  Nas Ip Address -                           0.0.0.0

```

	NAS Port -	0	
	Service Type-	0	
	Framed IP Address -	0.0.0.0	
	Framed IP Netmask -	0.0.0.0	
	Filter Id -	NULL	
	Framed MTU -	0	
	Reply Message -	NULL	
	Framed Route-	not set	
	Framed MTU -	0	
	Class -	SBR2CL	Virtual Router
Name	NULL		
	Primary DNS IP Address -	0.0.0.0	
	Secondary DNS IP Address -	0.0.0.0	
	Primary WINS IP Address -	0.0.0.0	
	Secondary WINS IP Address -	0.0.0.0	
	Ingress Statistics	disabled	
	Egress Statistics	disabled	
	Ingress Policy Name	not set	
	Engress Policy Name	not set	
	IGMP	disabled	
	Redirect VR Name	not set	
	Service Bundle	not set	
	Framed Ip Route Tag	not set	
	LI Action	0	
	LI Interception Identifier	0	
	LI Mediation Device IP Address	0.0.0.0	
	LI_Mediation_Device_Port_Number	0	
	Activate Service	NULL	
	Deactivate Service	NULL	
	Service Statistics	0	
	Ignore_DF_Bit -	disabled	
	IGMP Access Group Name	not set	
	IGMP Access Source Group_Name -	not set	
	MLD Access Group Name	not set	
	MLD Access Source Group Name	not set	
	MLD Version -	MLD Version not set	
	IGMP Version	IGMP Version not set	
	IGMP Immediate Leave -	disabled	
	MLD Immediate Leave -	disabled	
	IPv6_Ingress_Policy_Name -	not set	
	IPv6_Egress_Policy_Name -	not set	
	Cos_Parameter_Type -	not set	
	Service Interim Acct Interval	0	
	Max Clients Per Interface	0	
	Cos_Scheduler_Pmt_Type	not set	
	Session Timeout	599999940	
	NAS Port Type	0	
	Framed Pool	NULL	
	Idle Timeout	0	
	Acct-start sent		
	Acct-start succeeded		
	Pausing 10 seconds		
	Interim-Acct sent		
	Acct-interim succeeded		
	Pausing 10 seconds		
	Acct-stop sent		
	Acct-stop succeeded		
	Logging out subscriber		
	Test complete. Exiting		

test aaa dhcp user

Syntax `test aaa dhcp user username`
 `<logical-system logical-system-name>`
 `<mac-address mac-address>`
 `<option-82 option-82>`
 `<password password>`
 `<profile access-profile-name>`
 `<routing-instance routing-instance-name>`
 `<source-address source-address>`

Release Information Command introduced in Junos OS Release 11.2.

Description Verify Dynamic Host Configuration Protocol (DHCP) subscriber access authentication, accounting, and address allocation configuration.

Options *username*—Specify the subscriber username to test.

logical-system logical-system-name—(Optional) Specify the logical system in which the subscriber is authenticated.

mac-address mac-address—(Optional) Specify the MAC address of the DHCP client.

option-82 option-82—(Optional) Specify the DHCP relay agent information option (option-82) value.

password password—(Optional) Specify the password associated with the username.

profile access-profile-name—(Optional) Specify the access profile associated with the subscriber.

routing-instance routing-instance-name—(Optional) Specify the routing instance in which the subscriber is authenticated.

source-address source-address—(Optional) Specify the IP address of the outgoing interface.

Required Privilege Level view

List of Sample Output **test aaa dhcp user on page 1199**

Output Fields When you enter this command, you are provided feedback on the status of your request. For information about output fields related to authentication, accounting, and subscriber-specific information, see the **show network-access aaa statistics**, **show network-access aaa subscribers**, and **show subscribers** commands.

The **test** command does not support volume-time accounting. If volume-time accounting is configured for the test subscriber, the **test** command replaces the statistics with time-only accounting statistics.

Sample Output

test aaa dhcp user The following example tests the configuration for DHCP subscriber esmeralda and password rch4Astar, and displays the resulting output:

```

user@host> test aaa dhcp user esmeralda password rch4Astar
Authentication Grant
*****Attributes*****
      User Name - esmeralda
      Client IP Address - 192.168.1.2
      Client IP Netmask - 255.255.0.0
      Reply Message - NULL
      Primary DNS IP Address - 0.0.0.0
      Secondary DNS IP Address - 0.0.0.0
      Primary WINS IP Address - 0.0.0.0
      Secondary WINS IP Address - 0.0.0.0
      Framed Pool - addr_pool5
      Session Timeout - 0
      Idle Timeout - 0
      Service Type - 0
      DHCP Guided Relay Server - 0
      Client Ipv6 Address - ::
      Client Ipv6 Mask - null
      Framed Ipv6 Prefix - ::/0
      Framed Ipv6 Pool - not-set
      Nas Ipv6 Address - ::
      NDRA Ipv6 Prefix - not-set
      Login Ipv6 Host - ::
      Framed Interface Id: - 0:0:0:0
      Delegated Ipv6 Prefix - ::/0
      Delegated Ipv6 Pool - not-set
      User Password - testpw
      NAS Ip Address - 0.0.0.0
      NAS Port - 0
      NAS Port Type - 5
      Dhcp Mac Address - AB:CD:00:00:00:01
      Dhcp GI Address - 192.168.2.254
Client Session Activate request sent
Client Session Activated
      Filter Id - not set
      Framed MTU - (null)
      Framed Route - not set
      IGMP - disabled
      Redirect VR Name - default
      Service Bundle - Null
      Ingress Policy Name - not set
      Egress Policy Name - not set
      Framed Ip Route Tag - not set
      LI Action - 0
      LI Interpet Id - 0
      Med Ipaddress - 0.0.0.0
      Med Port Number - 0
      Ignore DF Bit - disabled
      IGMP Access Group Name - not set
      IGMP Access Source Group Name - not set
      MLD Access Group Name - not set
      MLD Access Source Group Name - not set
      IGMP Version - IGMP Version not set
      MLD Version - MLD Version not set
      IGMP Immediate Leave - disabled

```

```
MLD Immediate Leave -           disabled
IPv6 Ingress Policy Name -      not set
IPv6 Egress Policy Name -      not set
Cos Parameter Type -           not set
Cos Scheduler Parameter Type -  not set
Acct Session ID-               9
Acct Interim Interval -        0
Acct Type -                    0
Ingress Statistics              disabled
Egress Statistics              disabled
****Pausing 10 seconds before disconnecting the test user*****
Logging out subscriber
Test complete. Exiting
```


test aaa ppp user

Syntax	test aaa ppp user <i>username</i> <logical-system <i>logical-system-name</i> > <password <i>password</i> > <profile <i>access-profile-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 11.2.
Description	Verify Point-to-Point Protocol (PPP) subscriber access authentication, accounting, and address allocation configuration.
Options	<p><i>username</i>—Specify the subscriber username to test.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Specify the logical system in which the subscriber is authenticated.</p> <p>password <i>password</i>—(Optional) Specify the password associated with the username.</p> <p>profile <i>access-profile-name</i>—(Optional) Specify the access profile associated with the subscriber.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Specify the routing instance in which the subscriber is authenticated.</p>
Required Privilege Level	view
List of Sample Output	<p>test aaa ppp user on page 1201</p> <p>test aaa ppp user (tunneled user) on page 1203</p>
Output Fields	<p>When you enter this command, you are provided feedback on the status of your request. For information about output fields related to authentication, accounting, and subscriber-specific information, see the show network-access aaa statistics, show network-access aaa subscribers, and show subscribers commands.</p> <p>The test command does not support volume-time accounting. If volume-time accounting is configured for the test subscriber, the test command replaces the statistics with time-only accounting statistics.</p>

Sample Output

test aaa ppp user The following example tests the configuration for PPP subscriber jilldoe and password 92&tDcb, and displays the resulting output:

```
user@host> test aaa ppp user jilldoe password 92&tDcb
Authentication Grant
*****User Attributes*****
  User Name -                jilldoe
  Client IP Address -        192.168.1.5
  Client IP Netmask -        255.255.0.0
  Virtual Router Name -      default
```

```

Reply Message - NULL
Primary DNS IP Address - 0.0.0.0
Secondary DNS IP Address - 0.0.0.0
Primary WINS IP Address - 0.0.0.0
Secondary WINS IP Address - 0.0.0.0
Framed Pool - addr_pool3
Session Timeout - 0
Idle Timeout - 0
Service Type - 0
Client Ipv6 Address - ::
Client Ipv6 Mask - null
Framed Ipv6 Prefix - ::/0
Framed Ipv6 Pool - not-set
Nas Ipv6 Address - ::
NDRA Ipv6 Prefix - not-set
Login Ipv6 Host - ::
Framed Interface Id - 0:0:0:0
Delegated Ipv6 Prefix - ::/0
Delegated Ipv6 Pool - not-set
User Password - 92&tDcb
CHAP Password - NULL
NAS Ip Address - 0.0.0.0
NAS Port - 0
NAS Port Type - 5
Client Session Activate request sent
Client Session Activated
Filter Id - not set
Framed MTU - (null)
Framed Route - not set
Ingress Policy Name - not set
Egress Policy Name - not set
IGMP - disabled
Redirect VR Name - default
Service Bundle - Null
Framed Ip Route Tag - not set
LI Action - 0
LI Intercpet Id - 0
Med Ipaddress - 0.0.0.0
Med Port Number - 0
Ignore DF Bit - disabled
IGMP Access Group Name - not set
IGMP Access Source Group Name - not set
MLD Access Group Name - not set
MLD Access Source Group Name - not set
IGMP Version - IGMP Version not set
MLD Version - MLD Version not set
IGMP Immediate Leave - disabled
MLD Immediate Leave - disabled
IPv6 Ingress Policy Name - not set
IPv6 Egress Policy Name - not set
Cos Parameter Type - not-set
Cos Scheduler Parameter Type - not-set
Acct Session ID- 8
Acct Interim Interval - 0
Acct Type - 0
Ingress Statistics disabled
Egress Statistics disabled
****Pausing 10 seconds before disconnecting the test user*****

```

```
Logging out subscriber
Test complete. Exiting
```

test aaa ppp user (tunneled user) The following example tests the configuration for PPP tunneled subscriber accounting14, with password bncntr14 and access profile finance-b, and displays the resulting output:

```
user@host> test aaa ppp user accounting14 password bncntr14 profile finance-b
Authentication Grant with Tunnel Attributes
*****Tunnel Attributes*****
      ****Tunnel Definiton -
      Tunnel Medium          -      1
      Tunnel Type            -      3
      Tunnel Max Sessions    -     100
      Tunnel Server Endpoint -    1.2.3.4
      Tunnel Client Endpoint -    2.3.4.5
      Tunnel Server AuthId   -     rt1
      Tunnel Client AuthId   -     ts1
      Tunnel Password        -     radius
      Tunnel Assignment Id    -     til
      Tunnel Logical System   -
      Tunnel Routing Instance -
****Pausing 10 seconds before disconnecting the test user*****
Logging out subscriber
Test complete. Exiting
```

test configuration

Syntax	<code>test configuration <i>filename</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Verify that the syntax of a configuration file is correct. If the configuration contains any errors, a message is displayed to indicate the line number and column number in which the error was found.
Options	<i>filename</i> —Name of the configuration file.
Required Privilege Level	view
List of Sample Output	test configuration on page 1204
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
test configuration  user@host> test configuration terminal
                    [Type ^D to end input]
                    system {
                    host-name bluesky;
                    paris-23;
                    login;
                    }
                    terminal:3:(8) syntax error: paris
                    [edit system]
                    'paris-23;'
                    syntax error
                    terminal:4:(11) statement must contain additional statements: ;
                    [edit system login]
                    'login ;'
                    statement must contain additional statements
                    configuration syntax failed
```

Virtual Chassis Operational Mode Commands

Table 164 on page 1205 summarizes the command-line interface (CLI) commands you can use to administer and monitor a Virtual Chassis configuration for MX Series 3D Universal Edge Routers. Commands are listed in alphabetical order.

Table 164: Virtual Chassis Operational Mode Commands

Task	Command
Remove the member ID from a router that you want to remove from a Virtual Chassis.	<code>request virtual-chassis member-id delete</code>
Assign a member ID to a router that you want to add as a member of a Virtual Chassis.	<code>request virtual-chassis member-id set</code>
Change the mastership in a Virtual Chassis by switching the global roles of the master router and backup router.	<code>request virtual-chassis routing-engine master switch</code>
Remove a Virtual Chassis port from a member router in a Virtual Chassis.	<code>request virtual-chassis vc-port delete</code>
Create a Virtual Chassis port to interconnect member routers in a Virtual Chassis.	<code>request virtual-chassis vc-port set</code>
Display information about neighbor reachability from each member router in a Virtual Chassis.	<code>show virtual-chassis active-topology</code>
Display information about neighbor reachability for each hardware device in a Virtual Chassis.	<code>show virtual-chassis device-topology</code>
Display the entries (neighbors) in the Virtual Chassis Control Protocol (VCCP) database for a Virtual Chassis.	<code>show virtual-chassis protocol adjacency</code>
Display the entries in the VCCP link-state database for a Virtual Chassis.	<code>show virtual-chassis protocol database</code>
Display VCCP information about Virtual Chassis port interfaces in a Virtual Chassis.	<code>show virtual-chassis protocol interface</code>

Table 164: Virtual Chassis Operational Mode Commands (*continued*)

Task	Command
Display the VCCP unicast and multicast routing tables for a Virtual Chassis.	show virtual-chassis protocol route
Display VCCP statistics for one or both member routers, or for a specified Virtual Chassis port interface, in a Virtual Chassis.	show virtual-chassis protocol statistics
Display information about the status of both member routers in a Virtual Chassis.	show virtual-chassis status
Display the operational status of the Virtual Chassis ports for both member routers, or for a specified member router, in a Virtual Chassis.	show virtual-chassis vc-port

**NOTE:**

Virtual Chassis configurations are supported on the following routers with Trio Modular Port Concentrator/Modular Interface Card (MPC/MIC) interfaces:

- MX240 3D Universal Edge Router
- MX480 3D Universal Edge Router
- MX960 3D Universal Edge Router



NOTE: For information about how to configure a Virtual Chassis for MX Series routers, see the [Junos OS High Availability Configuration Guide](#).

request virtual-chassis member-id delete (MX Series Virtual Chassis)

Syntax request virtual-chassis member-id delete

Release Information Command introduced in Junos OS Release 11.2.

Description Remove (**delete**) the member ID from an MX Series router that you want to remove from a Virtual Chassis configuration.



NOTE: Issuing the command to remove the member ID causes the router to reboot, and requires you to confirm that you want to proceed with this operation. If you do not confirm the operation, the software cancels the command.

Required Privilege Level system-control

Related Documentation

- Deleting Member IDs in a Virtual Chassis Configuration
- Example: Deleting a Virtual Chassis Configuration for MX Series 3D Universal Edge Routers

List of Sample Output request virtual-chassis member-id delete on page 1207

Sample Output

```
request virtual-chassis member-id delete
user@host> request virtual-chassis member-id delete
This command will disable virtual-chassis mode and reboot the system.
Continue? [yes,no] (no)
```

request virtual-chassis member-id set (MX Series Virtual Chassis)

Syntax request virtual-chassis member-id set member *member-id*

Release Information Command introduced in Junos OS Release 11.2.

Description Assign (**set**) a member ID to an MX Series router that you want to add as a member of a Virtual Chassis configuration.



.....
NOTE: Issuing the command to assign a member ID causes the router to reboot, and requires you to confirm that you want to proceed with this operation. If you do not confirm the operation, the software cancels the command.
.....

Options member *member-id*—Numeric value that identifies a member router in a Virtual Chassis configuration. When you assign a member ID to a router, assign the same member ID defined for this router in the MX Series Virtual Chassis preprovisioned configuration. Replace *member-id* with the value 0 or 1.

Required Privilege Level system-control

Related Documentation

- Configuring Member IDs for a Virtual Chassis
- Example: Configuring Interchassis Redundancy for MX Series 3D Universal Edge Routers Using a Virtual Chassis

List of Sample Output request virtual-chassis member-id set on page 1208

Sample Output

```
request virtual-chassis member-id set  user@host> request virtual-chassis member-id set member 0
                                         This command will enable virtual-chassis mode and reboot the system.
                                         Continue? [yes,no] (no)
```


request virtual-chassis routing-engine master switch (MX Series Virtual Chassis)

Syntax request virtual-chassis routing-engine master switch

Release Information Command introduced in Junos OS Release 11.2.

Description Change the mastership in an MX Series Virtual Chassis by switching the global roles of the master router and backup router in the Virtual Chassis configuration. Using this command, which must be issued from the master router, causes the current master router in the Virtual Chassis to become the backup router, and the current backup router to become the master router.

For MX Series routers with dual Routing Engines in a Virtual Chassis, the local roles (master and standby) of the Routing Engines in each member router do not change after you issue the **request virtual-chassis routing-engine master switch** command.



NOTE: Before you issue the **request virtual-chassis routing-engine master switch** command from the master router in the Virtual Chassis, make sure that the system configuration is synchronized between the master router and backup router. If the configuration on the master router and backup router is not synchronized, or if you attempt to issue the **request virtual-chassis routing-engine master switch** command from the backup router instead of from the master router, the router displays an error message and rejects the command.

If you issue the **request virtual-chassis routing-engine master switch** command when the Virtual Chassis is in a transition state (for example, the backup router is disconnecting from the Virtual Chassis), the router does not process the command.

Required Privilege Level system-control

Related Documentation

- Switching the Global Master and Backup Roles in a Virtual Chassis Configuration
- Mastership Election in a Virtual Chassis

List of Sample Output

request virtual-chassis routing-engine master switch (From Master Router) on page 1209

request virtual-chassis routing-engine master switch (Error When Configuration Not Synchronized) on page 1210

request virtual-chassis routing-engine master switch (Error When Run from Backup Router) on page 1210

Sample Output

```
{master:member0-re0}
user@host> request virtual-chassis routing-engine master switch
```

switch (From Master Router)	Do you want to continue ? [yes,no] (no)
request virtual-chassis routing-engine master switch (Error When Configuration Not Synchronized)	{master:member0-re0} user@host> request virtual-chassis routing-engine master switch Error: mastership switch request NOT honored, backup not ready
request virtual-chassis routing-engine master switch (Error When Run from Backup Router)	{backup:member1-re0} user@host1> request virtual-chassis routing-engine master switch error: Virtual Chassis member is not the protocol master

request virtual-chassis vc-port delete (MX Series Virtual Chassis)

Syntax request virtual-chassis vc-port delete fpc-slot *fpc-slot-number* pic-slot *pic-slot-number* port *port-number*
<(local | member *member-id*)>

Release Information Command introduced in Junos OS Release 11.2.

Description Remove (**delete**) a Virtual Chassis port from a member router in an MX Series Virtual Chassis configuration. After a Virtual Chassis port is created, it is renamed **vc-slot/pic/port**, and is no longer available for configuration as a standard network port. After you remove a Virtual Chassis port, it becomes available to the global configuration and can again function as a standard network port.



NOTE: If the member ID has not been set on the router where you issue the **request virtual-chassis vc-port delete** command, the software prevents the removal of the Virtual Chassis port on the router. To set the member ID, use the **request virtual-chassis member-id set** command.

Options fpc-slot *fpc-slot-number*—Number of the Flexible PIC Concentrator (FPC) slot on which the Virtual Chassis port resides. The slot number corresponds to the Modular Port Concentrator (MPC) slot number. Replace *fpc-slot-number* with a value appropriate for your router:

- MX960 router—0 through 11.
- MX480 router—0 through 5.
- MX240 router—0 through 2.

pic-slot *pic-slot-number*—Number of the PIC slot on which the Virtual Chassis port resides. Replace *pic-slot-number* with a value in the range 0 through 3.

port *port-number*—Number of the port on the PIC on which the Virtual Chassis port resides. Replace *port-number* with a value appropriate for your PIC.

local—(Optional) Delete the Virtual Chassis port on the member router on which you are issuing the command. This is the default behavior if you do not specify the **local** or **member** options.

member *member-id*—(Optional) Numeric value that identifies the remote Virtual Chassis member on which you want to delete the Virtual Chassis port. Replace *member-id* with the value 0 or 1.

Required Privilege Level system-control

**Related
Documentation**

- [Deleting Virtual Chassis Ports in a Virtual Chassis Configuration](#)
- [Example: Deleting a Virtual Chassis Configuration for MX Series 3D Universal Edge Routers](#)

List of Sample Output [request virtual-chassis vc-port delete \(Remove vcp-3/2/1\) on page 1212](#)

Sample Output

```
request virtual-chassis vc-port delete (Remove vcp-3/2/1)
user@host> request virtual-chassis vc-port delete fpc-slot 3 pic-slot 2 port 1
vc-port successfully deleted
```

request virtual-chassis vc-port set (MX Series Virtual Chassis)

Syntax request virtual-chassis vc-port set fpc-slot *fpc-slot-number* pic-slot *pic-slot-number* port *port-number*
<(local | member *member-id*)>

Release Information Command introduced in Junos OS Release 11.2.

Description Create (**set**) a Virtual Chassis port on an MX Series router through which the router connects to other member routers in the Virtual Chassis. You can create Virtual Chassis ports only on Trio Modular Port Concentrator/Modular Interface Card (MPC/MIC) network ports on MX Series routers.

After a Virtual Chassis port is created, it is renamed **vcp-slot/pic/port**, and is no longer available for configuration as a standard network port. Virtual Chassis ports can be used only to interconnect the MX Series routers in the Virtual Chassis.



NOTE: If the member ID has not been set on the router where you issue the **request virtual-chassis vc-port set** command, the software prevents the creation of the Virtual Chassis port on the router. To set the member ID, use the **request virtual-chassis member-id set** command.

Options fpc-slot *fpc-slot-number*—Number of the Flexible PIC Concentrator (FPC) slot on which the Virtual Chassis port resides. The slot number corresponds to the Modular Port Concentrator (MPC) slot number. Replace *fpc-slot-number* with a value appropriate for your router:

- MX960 router—0 through 11.
- MX480 router—0 through 5.
- MX240 router—0 through 2.

When you issue the **show interfaces** command on a member router in an MX Series Virtual Chassis, the FPC slot number displayed in the command output reflects the FPC slot numbering and offset used in the Virtual Chassis instead of the physical slot number where the FPC is actually installed. The router with member ID 0 in the Virtual Chassis uses FPC slot numbers 0 through 11 with no offset, and the router with member ID 1 uses FPC slot numbers 12 through 23, with an offset of 12. For example, a 10-Gigabit Ethernet interface that appears as **xe-14/2/2** (FPC slot 14, PIC slot 2, port 2) in the **show interfaces** command is actually interface **xe-2/2/2** (FPC slot 2, PIC slot 2, port 2) on member ID 1 after deducting the FPC slot numbering offset of 12 for member ID 1.

pic-slot *pic-slot-number*—Number of the PIC slot on which the Virtual Chassis port resides. Replace *pic-slot-number* with a value in the range 0 through 3.

port *port-number*—Number of the port on the PIC on which the Virtual Chassis port resides. Replace *port-number* with a value appropriate for your PIC.

local—(Optional) Set the Virtual Chassis port on the member router on which you are issuing the command. This is the default behavior if you do not specify the **local** or **member** options.

member *member-id*—(Optional) Numeric value that identifies the remote Virtual Chassis member on which you want to create the Virtual Chassis port. Replace ***member-id*** with the value 0 or 1.

Required Privilege Level system-control

Related Documentation

- [Configuring Virtual Chassis Ports to Interconnect Member Routers](#)
- [Example: Configuring Interchassis Redundancy for MX Series 3D Universal Edge Routers Using a Virtual Chassis](#)
- [Guidelines for Configuring Virtual Chassis Ports](#)

List of Sample Output

[request virtual-chassis vc-port set \(No Existing Network Port\) on page 1214](#)
[request virtual-chassis vc-port set \(Existing Network Port Converted\) on page 1214](#)
[request virtual-chassis vc-port set \(On Local Router\) on page 1214](#)
[request virtual-chassis vc-port set \(On Remote Member Router 1\) on page 1214](#)

Sample Output

request virtual-chassis vc-port set (No Existing Network Port)

```
user@host> request virtual-chassis vc-port set fpc-slot 1 pic-slot 1 port 0
vc-port successfully set
```

request virtual-chassis vc-port set (Existing Network Port Converted)

```
user@host> request virtual-chassis vc-port set fpc-slot 2 pic-slot 1 port 1
Port conversion initiated, use "show virtual chassis vc-port" to verify
```

request virtual-chassis vc-port set (On Local Router)

```
user@host> request virtual-chassis vc-port set fpc-slot 2 pic-slot 1 port 3 local
vc-port successfully set
```

request virtual-chassis vc-port set (On Remote Member Router 1)

```
user@host> request virtual-chassis vc-port set fpc-slot 5 pic-slot 3 port 10 member 1
vc-port successfully set
```

show virtual-chassis active-topology (MX Series Virtual Chassis)

Syntax	show virtual-chassis active-topology <(all-members local member <i>member-id</i>)>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display information about neighbor reachability from each member router in an MX Series Virtual Chassis configuration. You can issue the show virtual-chassis active-topology command from the console of either member router in the Virtual Chassis.
Options	<p>all-members—(Optional) Display neighbor reachability information for both member routers in a Virtual Chassis configuration. This is the default behavior if no options are specified.</p> <p>local—(Optional) Display neighbor reachability information for the member router on which you are issuing the command.</p> <p>member <i>member-id</i>—(Optional) Display neighbor reachability information for the specified Virtual Chassis member router. Replace <i>member-id</i> with the value 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Verifying Neighbor Reachability for Member Routers in a Virtual Chassis
List of Sample Output	<p>show virtual-chassis active-topology all-members on page 1215</p> <p>show virtual-chassis active-topology local on page 1216</p> <p>show virtual-chassis active-topology member 1 on page 1216</p>
Output Fields	Table 165 on page 1215 lists the output fields for the show virtual-chassis active-topology command. Output fields are listed in the approximate order in which they appear.

Table 165: show virtual-chassis active-topology Output Fields

Field Name	Field Description
membern	Member ID of the Virtual Chassis member router for which output is displayed.
Destination ID	Member ID of the destination (neighbor) router.
Next-hop	Member ID and Virtual Chassis port interface (in the format <i>vcp-slot/pic/port.logical-unit-number</i>) of the next-hop to which the router forwards packets for the destination ID.

Sample Output

```

show virtual-chassis {master:member0-re0}
  active-topology
    all-members
user@host> show virtual-chassis active-topology all-members
member0:
-----

```

```

        Destination ID      Next-hop
        1                    1(vcp-5/0/0.32768)

member1:
-----
        Destination ID      Next-hop
        0                    0(vcp-1/3/0.32768)

show virtual-chassis {master:member0-re0}
active-topology local
user@host> show virtual-chassis active-topology local

        Destination ID      Next-hop
        1                    1(vcp-5/0/0.32768)

show virtual-chassis {master:member0-re0}
active-topology
member 1
user@host> show virtual-chassis active-topology member 1
member1:
-----
        Destination ID      Next-hop
        0                    0(vcp-1/3/0.32768)

```


show virtual-chassis device-topology (MX Series Virtual Chassis)

Syntax	show virtual-chassis device-topology <(all-members local member <i>member-id</i>)>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display information about neighbor reachability for each hardware device in an MX Series Virtual Chassis configuration. On the MX Series router, there is only one active device for each member router. You can issue the show virtual-chassis device-topology command from the console of either member router in the Virtual Chassis.
Options	<p>all-members—(Optional) Display neighbor reachability information for the device in both member routers in a Virtual Chassis configuration.</p> <p>local—(Optional) Display neighbor reachability information for the device in the member router on which you are issuing the command. This is the default behavior if no options are specified.</p> <p>member <i>member-id</i>—(Optional) Display neighbor reachability information for the device in the specified Virtual Chassis member router. Replace <i>member-id</i> with the value 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Verifying Neighbor Reachability for Hardware Devices in a Virtual Chassis
List of Sample Output	<p>show virtual-chassis device-topology all-members on page 1218</p> <p>show virtual-chassis device-topology local on page 1218</p> <p>show virtual-chassis device-topology member 1 on page 1218</p>
Output Fields	Table 166 on page 1217 lists the output fields for the show virtual-chassis device-topology command. Output fields are listed in the approximate order in which they appear.

Table 166: show virtual-chassis device-topology Output Fields

Field Name	Field Description
membern	Member ID of the Virtual Chassis member router for which output is displayed.
Member	Identifier assigned to the member router in the preprovisioned Virtual Chassis configuration.
Device	<p>Identifier assigned to the device in the member router.</p> <p>Because there is only one active device per member router in an MX Series Virtual Chassis configuration, the values in the Device and Member fields are identical.</p>

Table 166: show virtual-chassis device-topology Output Fields (*continued*)

Field Name	Field Description
Status	Status of the device: <ul style="list-style-type: none"> • Prsnt—Device is currently connected to the Virtual Chassis. • NotPrsnt—Device is not currently connected to the Virtual Chassis.
System ID	Unique identifier derived from the device's media access control (MAC) address. The System ID is included in each Virtual Chassis Control Protocol (VCCP) packet to identify the packet owner to all members of the Virtual Chassis.
Neighbor List Member/Device/Interface	Member IDs, Device IDs, and Virtual Chassis port interfaces (in the format vcp-slot/pic/port) to which this device is connected.

Sample Output

```
show virtual-chassis {master:member0-re0}
```

```
device-topology user@host> show virtual-chassis device-topology all-members
all-members member0:
```

```
-----
                        Neighbor List
Member  Device  Status  System ID      Member  Device  Interface
  0       0    Prsnt   b0c6.9abf.6800    1       1    vcp-5/0/0
  1       1    Prsnt   001d.b510.0800    0       0    vcp-1/3/0
```

```
member1:
```

```
-----
                        Neighbor List
Member  Device  Status  System ID      Member  Device  Interface
  0       0    Prsnt   b0c6.9abf.6800    1       1    vcp-5/0/0
  1       1    Prsnt   001d.b510.0800    0       0    vcp-1/3/0
```

```
show virtual-chassis {master:member0-re0}
```

```
device-topology local user@host> show virtual-chassis device-topology local
```

```
-----
                        Neighbor List
Member  Device  Status  System ID      Member  Device  Interface
  0       0    Prsnt   b0c6.9abf.6800    1       1    vcp-5/0/0
  1       1    Prsnt   001d.b510.0800    0       0    vcp-1/3/0
```

```
show virtual-chassis {master:member0-re0}
```

```
device-topology user@host> show virtual-chassis device-topology member 1
member 1 member1:
```

```
-----
                        Neighbor List
Member  Device  Status  System ID      Member  Device  Interface
  0       0    Prsnt   b0c6.9abf.6800    1       1    vcp-5/0/0
  1       1    Prsnt   001d.b510.0800    0       0    vcp-1/3/0
```

show virtual-chassis protocol adjacency (MX Series Virtual Chassis)

Syntax	show virtual-chassis protocol adjacency <(brief detail extensive)> <(all-members local member <i>member-id</i>)> < <i>system-id</i> >
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display the entries (neighbors) in the Virtual Chassis Control Protocol (VCCP) adjacency database for an MX Series Virtual Chassis configuration. You can issue the show virtual-chassis protocol adjacency command from the console of either member router in the Virtual Chassis.
Options	<p>brief detail extensive—(Optional) Display the specified level of output. Using the brief option is equivalent to issuing the command with no options (the default). The detail option provides more output than the brief option. The extensive option provides complete output and is most useful for customer support personnel.</p> <p>all-members—(Optional) Display the VCCP adjacency database for both member routers in a Virtual Chassis. This is the default behavior if no options are specified.</p> <p>local—(Optional) Display the VCCP adjacency database for the member router on which you are issuing the command.</p> <p>member <i>member-id</i>—(Optional) Display the VCCP adjacency database for the specified member router. Replace <i>member-id</i> with the value 0 or 1.</p> <p><i>system-id</i>—(Optional) Display the VCCP adjacency database for the device with the specified system ID.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Viewing Information in the Virtual Chassis Control Protocol Adjacency Database
List of Sample Output	<p>show virtual-chassis protocol adjacency all-members brief on page 1221</p> <p>show virtual-chassis protocol adjacency member 0 detail on page 1222</p> <p>show virtual-chassis protocol adjacency member 0 detail 001d.b510.0800 on page 1222</p> <p>show virtual-chassis protocol adjacency local extensive on page 1222</p>
Output Fields	Table 167 on page 1219 lists the output fields for the show virtual-chassis protocol adjacency command. Output fields are listed in the approximate order in which they appear.

Table 167: show virtual-chassis protocol adjacency Output Fields

Field Name	Field Description	Level of Output
membern	Member ID of the Virtual Chassis member router for which output is displayed.	All levels

Table 167: show virtual-chassis protocol adjacency Output Fields (*continued*)

Field Name	Field Description	Level of Output
Interface	Name of the Virtual Chassis port interface, in the format <i>vcp-slot/pic/port.logical-unit-number</i> .	brief
System	System ID of the device associated with the Virtual Chassis port interface. The System ID is derived from the device's media access control (MAC) address.	brief
State	State of the adjacency: <ul style="list-style-type: none"> • Up—The adjacency is up. • Down—The adjacency is down. 	All levels
Hold (secs)	Remaining hold time of the adjacency, in seconds.	brief
system-id	System ID of the device associated with the Virtual Chassis port interface. The System ID is derived from the device's media access control (MAC) address.	detail, extensive
interface-name	Name of the Virtual Chassis port interface, in the format <i>vcp-slot/pic/port.logical-unit-number</i> .	detail, extensive
Expires in	Number of seconds until the adjacency expires.	detail, extensive
Priority	Priority to become the designated intermediate system.	detail, extensive
Up/Down transitions	Count of adjacency status changes from Up to Down or from Down to Up .	detail, extensive
Last transition	Time of the last Up/Down transition.	detail, extensive

Table 167: show virtual-chassis protocol adjacency Output Fields (*continued*)

Field Name	Field Description	Level of Output
Transition log	<p>List of recent adjacency transitions, including:</p> <ul style="list-style-type: none"> • When—Date and time at which a VCCP adjacency transition occurred. • State—Current state of the VCCP adjacency: <ul style="list-style-type: none"> • Up—Adjacency is up and operational. • Down—Adjacency is down and not available. • Rejected—Adjacency has been rejected. • Event—Type of transition that occurred: <ul style="list-style-type: none"> • Seenself—Possible routing loop has been detected. • Interface down—Virtual Chassis port interface has gone down and is no longer available. • Error—Adjacency error. • Down reason—Reason that a VCCP adjacency is down: <ul style="list-style-type: none"> • 3-Way Handshake Failed—Connection establishment failed. • Address Mismatch—Address mismatch caused link failure. • Aged Out—Link expired. • ISO Area Mismatch—VCCP area mismatch caused link failure. • Bad Hello—Unacceptable hello message caused link failure. • BFD Session Down—Bidirectional failure detection caused link failure. • Interface Disabled—Virtual Chassis port interface is disabled. • Interface Down—Virtual Chassis port interface is unavailable. • Interface Level Disabled—VCCP level is disabled. • Level Changed—VCCP level has changed on the adjacency. • Level Mismatch—Levels on adjacency are not compatible. • MPLS LSP Down—Label-switched path (LSP) is unavailable. • MT Topology Changed—VCCP topology has changed. • MT Topology Mismatch—VCCP topology is mismatched. • Remote System ID Changed—Adjacency peer system ID changed. • Protocol Shutdown—VCCP is disabled. • CLI Command—Adjacency brought down by user. • Unknown—Unknown. 	extensive

Sample Output

```

show virtual-chassis {master:member0-re0}
protocol adjacency
all-members brief
user@host> show virtual-chassis protocol adjacency all-members brief
member0:
-----
Interface          System           State           Hold (secs)
vcp-5/0/0.32768    001d.b510.0800  Up              57
member1:
-----

```

	Interface	System	State	Hold (secs)
	vcp-1/3/0.32768	b0c6.9abf.6800	Up	58


```

show virtual-chassis {master:member0-re0}
protocol adjacency
member 0 detail
user@host> show virtual-chassis protocol adjacency member 0 detail
member0:
-----

001d.b510.0800
  interface-name: vcp-5/0/0.32768, State: Up, Expires in 57 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 18:50:41 ago

```



```

show virtual-chassis {master:member0-re0}
protocol adjacency
member 0 detail
001d.b510.0800
user@host> show virtual-chassis protocol adjacency member 0 detail 001d.b510.0800
member0:
-----

001d.b510.0800
  interface-name: vcp-5/0/0.32768, State: Up, Expires in 58 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 18:52:08 ago

```



```

show virtual-chassis {master:member0-re0}
protocol adjacency
local extensive
user@host> show virtual-chassis protocol adjacency local extensive

001d.b510.0800
  interface-name: vcp-5/0/0.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 18:52:40 ago
  Transition log:
    When                State    Event           Down reason
    Mon Sep 20 17:26:44  Up      Seenself

```

show virtual-chassis protocol database (MX Series Virtual Chassis)

Syntax	show virtual-chassis protocol database <(brief detail extensive)> <(all-members local member <i>member-id</i>)> < <i>system-id</i> >
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display the entries in the Virtual Chassis Control Protocol (VCCP) link-state database for an MX Series Virtual Chassis configuration. The VCCP link-state database contains information about protocol data unit (PDU) packets. You can issue the show virtual-chassis protocol database command from the console of either member router in the Virtual Chassis.
Options	<p>brief detail extensive—(Optional) Display the specified level of output. Using the brief option is equivalent to issuing the command with no options (the default). The detail option provides more output than the brief option. The extensive option provides complete output and is most useful for customer support personnel.</p> <p>all-members—(Optional) Display the VCCP link-state database for both member routers in a Virtual Chassis. This is the default behavior if no options are specified.</p> <p>local—(Optional) Display the VCCP link-state database for the member router on which you are issuing the command.</p> <p>member <i>member-id</i>—(Optional) Display the VCCP link-state database for the specified member router. Replace <i>member-id</i> with the value 0 or 1.</p> <p><i>system-id</i>—(Optional) Display the VCCP link-state database for the neighbor with the specified system ID.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Viewing Information in the Virtual Chassis Control Protocol Link-State Database
List of Sample Output	<p>show virtual-chassis protocol database all-members brief on page 1225</p> <p>show virtual-chassis protocol database member 0 detail on page 1226</p> <p>show virtual-chassis protocol database member 0 b0c6.9abf.6800 detail on page 1226</p> <p>show virtual-chassis protocol database member 0 extensive on page 1226</p>
Output Fields	Table 168 on page 1223 lists the output fields for the show virtual-chassis protocol database command. Output fields are listed in the approximate order in which they appear.

Table 168: show virtual-chassis protocol database Output Fields

Field Name	Field Description	Level of Output
membern	Member ID of the Virtual Chassis member router for which output is displayed.	All levels

Table 168: show virtual-chassis protocol database Output Fields (*continued*)

Field Name	Field Description	Level of Output
LSP ID	Link-state PDU (LSP) identifier.	All levels
Sequence	Sequence number of the link-state PDU.	All levels
Checksum	Checksum value of the link-state PDU.	All levels
Lifetime	Remaining lifetime of the link-state PDU, in seconds.	All levels
number LSPs	Total number of link-state PDUs in the specified link-state database.	none, brief
Neighbor, Neighbor Info	Media access control (MAC) address of the neighbor on the advertising system.	detail, extensive
Interface	Name of the Virtual Chassis port interface, in the format <i>vcp-slot/pic/port.logical-unit-number</i> .	detail, extensive
Metric	Metric value of the prefix or neighbor.	detail, extensive
Header	Link-state PDU (LSP) packet header: <ul style="list-style-type: none"> • LSP ID—LSP identifier in the header. • Length—Header length, in bytes. • Allocated length—Length available for the header, in bytes. • Remaining lifetime—Remaining lifetime of the link-state PDU, in seconds. • Interface—The interface from which the LSP is received. • Estimated free bytes—Estimated number of available bytes in the LSP. • Actual free bytes—Actual number of available bytes in the LSP. • Aging timer expires in—Remaining lifetime of the LSP, in seconds. 	extensive
Packet	Link-state PDU (LSP) packet: <ul style="list-style-type: none"> • LSP ID—Identifier for the link-state packet. • Length—Packet length, in bytes. • Lifetime—Remaining lifetime, in seconds. • Checksum—Checksum of the link-state PDU. • Sequence—Sequence number of the link-state PDU. This number increments whenever the link-state PDU is updated. • Fixed length—Set length for the packet, in bytes. • Version—Protocol version. • Sysid length—Length of the system ID, in bytes. The value 0 represents 6 bytes. • Packet type—Protocol data unit (PDU) type of the LSP. • SW version—Junos OS Release number. 	extensive

Table 168: show virtual-chassis protocol database Output Fields (*continued*)

Field Name	Field Description	Level of Output
TLVs	<p>Link-state PDU (LSP) type, length, and value (TLV):</p> <ul style="list-style-type: none"> • Member ID—Identifier configured for the Virtual Chassis member router. • VC ID—Identifier assigned to the Virtual Chassis member router. • Flags—Internal flags that keep track of the member state for the purpose of mastership election in the Virtual Chassis. • Priority—Priority value associated with the role assigned to a member router in the preprovisioned Virtual Chassis configuration. For example, the priority value for the routing-engine role is 129. The priority value is used for mastership election in the Virtual Chassis. • System ID—System ID of the device associated with the Virtual Chassis port interface. The System ID is derived from the device's media access control (MAC) address. • Device ID—Identifier for the device; usually the same as the Member ID. • Neighbor Info—System ID, Virtual Chassis port interface, and metric value for VCCP neighbor. • Topology Info—System ID of the VCCP neighbor. • IRI Addr Info—Internal routing interface (IRI) IP address, which is reserved for internal communication. • Master Info—System ID of the master router in the Virtual Chassis. • Backup Info—System ID of the backup router in the Virtual Chassis. • Stable State Info—Internal state information used for mastership election in the Virtual Chassis. • Member Info—System ID, Member ID, and role of each member router in the Virtual Chassis. • Provision Info—Member ID and chassis serial number specified for each member router in the preprovisioned configuration for an MX Series Virtual Chassis. • Unknown TLV—Type and length of TLVs with unsupported content received on this device. 	extensive
<i>number queued</i>	Number of link-state PDUs queued on the specified Virtual Chassis port interface.	extensive

Sample Output

```

show virtual-chassis {master:member1-re0}
protocol database
all-members brief
user@host> show virtual-chassis protocol database all-members brief
member0:
-----
LSP ID                Sequence Checksum Lifetime
001d.b510.0800.00-00  0x9eb   0xb8f1    115
b0c6.9abf.6800.00-00  0x9ee   0x8f35    116
  2 LSPs

member1:
-----
LSP ID                Sequence Checksum Lifetime
001d.b510.0800.00-00  0x9eb   0xb8f1    117
b0c6.9abf.6800.00-00  0x9ee   0x8f35    114
  2 LSPs

```

```

show virtual-chassis {master:member1-re0}
  protocol database
    member 0 detail
user@host> show virtual-chassis protocol database member 0 detail
member0:
-----
001d.b510.0800.00-00 Sequence: 0x9f5, Checksum: 0x5b2b, Lifetime: 116 secs
Neighbor: b0c6.9abf.6800.00 Interface: vcp-1/3/0.32768 Metric: 15

b0c6.9abf.6800.00-00 Sequence: 0x9f8, Checksum: 0x326e, Lifetime: 117 secs
Neighbor: 001d.b510.0800.00 Interface: vcp-5/0/0.32768 Metric: 15

show virtual-chassis {master:member1-re0}
  protocol database
    member 0
b0c6.9abf.6800 detail
user@host> show virtual-chassis protocol database member 0 b0c6.9abf.6800 detail
member0:
-----
b0c6.9abf.6800.00-00 Sequence: 0xa06, Checksum: 0x925b, Lifetime: 117 secs
Neighbor: 001d.b510.0800.00 Interface: vcp-5/0/0.32768 Metric: 15

show virtual-chassis {master:member1-re0}
  protocol database
    member 0 extensive
user@host> show virtual-chassis protocol database member 0 extensive
member0:
-----
001d.b510.0800.00-00 Sequence: 0xa09, Checksum: 0xa696, Lifetime: 116 secs
Neighbor: b0c6.9abf.6800.00 Interface: vcp-1/3/0.32768 Metric: 15

Header: LSP ID: 001d.b510.0800.00-00, Length: 804 bytes
Allocated length: 804 bytes,
Remaining lifetime: 116 secs, Interface: 64
Estimated free bytes: 0, Actual free bytes: 0
Aging timer expires in: 116 secs

Packet: LSP ID: 001d.b510.0800.00-00, Length: 804 bytes, Lifetime : 118 secs
Checksum: 0xa696, Sequence: 0xa09,
Fixed length: 27 bytes, Version: 1, Sysid length: 0 bytes
Packet type: 18, SW version: 11.1

TLVs:
Node Info: Member ID: 1, VC ID: 5a6a.e747.8511, Flags: 3, Priority: 129
System ID: 001d.b510.0800, Device ID: 1
Unknown TLV, Type: 0, Length: 0
...
Unknown TLV, Type: 0, Length: 0
Unknown TLV, Type: 1, Length: 1
Neighbor Info: b0c6.9abf.6800.00, Interface: vcp-1/3/0.32768, Metric: 15
Topology Info: System ID: 001d.b510.0800,
Topology Info: System ID: b0c6.9abf.6800,
IRI Addr Info: IP Address: 128.0.0.1,
IRI Addr Info: IP Address: 128.0.0.4,
IRI Addr Info: IP Address: 128.0.0.5,
IRI Addr Info: IP Address: 128.0.0.6,
IRI Addr Info: IP Address: 128.0.0.17,
Master Info: System ID: 001d.b510.0800
Backup Info: System ID: b0c6.9abf.6800
Stable State Info: Master ID: 001d.b510.0800, Backup ID: b0c6.9abf.6800
Member Info: System ID: b0c6.9abf.6800, Member ID: 0 Member role: Backup
System ID: b0c6.9abf.6800, Device ID: 0

```

Member Info: System ID: 001d.b510.0800, Member ID: 1 Member role: Master
 System ID: 001d.b510.0800, Device ID: 1
 Provision Info: Member ID: 1 Serial Number: JN10C78D1AFC,
 Provision Info: Member ID: 0 Serial Number: JN115FDADAFB,
 Unknown TLV, Type: 24, Length: 1
 Unknown TLV, Type: 28, Length: 56

1 queued :
 Send PSN on vcp-5/0/0.32768 for 00:00:01

b0c6.9abf.6800.00-00 Sequence: 0xa0d, Checksum: 0x82d2, Lifetime: 118 secs
 Neighbor: 001d.b510.0800.00 Interface: vcp-5/0/0.32768 Metric: 15

Header: LSP ID: b0c6.9abf.6800.00-00, Length: 808 bytes
 Allocated length: 1400 bytes,
 Remaining lifetime: 118 secs, Interface: 0
 Estimated free bytes: 546, Actual free bytes: 592
 Aging timer expires in: 118 secs

Packet: LSP ID: b0c6.9abf.6800.00-00, Length: 808 bytes, Lifetime : 118 secs
 Checksum: 0x82d2, Sequence: 0xa0d,
 Fixed length: 27 bytes, Version: 1, Sysid length: 0 bytes
 Packet type: 18, SW version: 11.1

TLVs:

Node Info: Member ID: 0, VC ID: 5a6a.e747.8511, Flags: 5, Priority: 129
 System ID: b0c6.9abf.6800, Device ID: 0
 Unknown TLV, Type: 0, Length: 0
 ...
 Unknown TLV, Type: 0, Length: 0
 Unknown TLV, Type: 1, Length: 1
 Neighbor Info: 001d.b510.0800.00, Interface: vcp-5/0/0.32768, Metric: 15
 Topology Info: System ID: 001d.b510.0800,
 Topology Info: System ID: b0c6.9abf.6800,
 IRI Addr Info: IP Address: 128.0.0.1,
 IRI Addr Info: IP Address: 128.0.0.4,
 IRI Addr Info: IP Address: 128.0.0.5,
 IRI Addr Info: IP Address: 128.0.0.6,
 IRI Addr Info: IP Address: 128.0.0.17,
 IRI Addr Info: IP Address: 128.0.0.21,
 Master Info: System ID: 001d.b510.0800
 Backup Info: System ID: b0c6.9abf.6800
 Stable State Info: Master ID: 001d.b510.0800, Backup ID: b0c6.9abf.6800
 Member Info: System ID: b0c6.9abf.6800, Member ID: 0 Member role: Backup
 System ID: b0c6.9abf.6800, Device ID: 0
 Member Info: System ID: 001d.b510.0800, Member ID: 1 Member role: Master
 System ID: 001d.b510.0800, Device ID: 1
 Provision Info: Member ID: 1 Serial Number: JN10C78D1AFC,
 Provision Info: Member ID: 0 Serial Number: JN115FDADAFB,
 Unknown TLV, Type: 24, Length: 1
 Unknown TLV, Type: 28, Length: 56

1 queued :
 Retransmit on vcp-5/0/0.32768 for 00:00:01

show virtual-chassis protocol interface (MX Series Virtual Chassis)

Syntax	show virtual-chassis protocol interface <(brief detail)> <interface-name> <(all-members local member <i>member-id</i>)>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display Virtual Chassis Control Protocol (VCCP) information about Virtual Chassis port interfaces in an MX Series Virtual Chassis. You can issue the show virtual-chassis protocol interface command from the console of either member router in the Virtual Chassis.
Options	<p>brief detail—(Optional) Display the specified level of output. Using the brief option is equivalent to issuing the command with no options (the default). The detail option provides more output than the brief option.</p> <p>all-members—(Optional) Display VCCP information about Virtual Chassis port interfaces for both member routers in a Virtual Chassis. This is the default behavior if no options are specified.</p> <p>interface-name—(Optional) Display VCCP information about Virtual Chassis port interfaces for the specified Virtual Chassis port, in the format vcp-slot/pic/port.logical-unit-number.</p> <p>local—(Optional) Display VCCP information about Virtual Chassis port interfaces for the member router on which you are issuing the command.</p> <p>member <i>member-id</i>—(Optional) Display VCCP information about Virtual Chassis port interfaces for the specified member router. Replace <i>member-id</i> with the value 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Viewing Information About Virtual Chassis Port Interfaces in the Virtual Chassis Control Protocol Database
List of Sample Output	<p>show virtual-chassis protocol interface brief all-members on page 1229</p> <p>show virtual-chassis protocol interface detail all-members on page 1230</p> <p>show virtual-chassis protocol interface detail local on page 1230</p>
Output Fields	Table 169 on page 1228 lists the output fields for the show virtual-chassis protocol interface command. Output fields are listed in the approximate order in which they appear.

Table 169: show virtual-chassis protocol interface Output Fields

Field Name	Field Description	Level of Output
membern	Member ID of the Virtual Chassis member router for which output is displayed.	All levels

Table 169: show virtual-chassis protocol interface Output Fields (*continued*)

Field Name	Field Description	Level of Output
Interface	Name of the Virtual Chassis port interface, in the format <i>vcp-slot/pic/port.logical-unit-number</i> .	brief
State	State of the Virtual Chassis port interface: <ul style="list-style-type: none"> • Up—The interface is up. • Down—The interface is down. 	brief
Metric	Metric value for this Virtual Chassis port interface.	All levels
<i>vcp-slot/ pic/port. logical-unit-number</i>	Name of the Virtual Chassis port interface.	detail
Index	Interface index number assigned by the Junos OS software.	detail
State	Internal implementation information.	detail
LSP interval	Interval, in milliseconds, between link-state protocol data units (PDUs) sent from the interface.	detail
type Hello padding	Type of hello padding: <ul style="list-style-type: none"> • Adaptive—On point-to-point connections, the hello packets are padded from the initial detection of a new neighbor until the neighbor verifies the adjacency as Up in the adjacency state type, length, and value (TLV). If the neighbor does not support the adjacency state TLV, then padding continues. On LAN connections, padding starts from the initial detection of a new neighbor until there is at least one active adjacency on the interface. • Loose—(Default) The hello packet is padded from the initial detection of a new neighbor until the adjacency transitions to the Up state. • Strict—Padding is performed on all interface types and for all adjacency states, and is continuous. 	detail
Adjacencies	Number of adjacencies established on this Virtual Chassis port interface.	detail
Hello(s)	Hello interval for the Virtual Chassis port interface.	detail
Hold(s)	Hold time for the Virtual Chassis port interface.	detail

Sample Output

```

show virtual-chassis {master:member1-re0}
protocol interface brief
all-members
user@host> show virtual-chassis protocol interface brief all-members
member0:
-----
IS-IS interface database:
Interface          State      Metric
vcp-5/0/0.32768    Up         15

```

```

member1:
-----
IS-IS interface database:
Interface          State      Metric
vcp-1/3/0.32768    Up         15

show virtual-chassis {master:member1-re0}
protocol interface
detail all-members  user@host> show virtual-chassis protocol interface detail all-members
member0:
-----

IS-IS interface database:
vcp-5/0/0.32768
  Index: 64, State: 0x46
  LSP interval: 100 ms, Loose Hello padding
  Adjacencies Metric Hello (s) Hold (s)n      1    15      3    60

member1:
-----

IS-IS interface database:
vcp-1/3/0.32768
  Index: 64, State: 0x86
  LSP interval: 100 ms, Loose Hello padding
  Adjacencies Metric Hello (s) Hold (s)n      1    15      3    60

show virtual-chassis {master:member1-re0}
protocol interface
detail local        user@host> show virtual-chassis protocol interface detail local

IS-IS interface database:
vcp-1/3/0.32768
  Index: 64, State: 0x46
  LSP interval: 100 ms, Loose Hello padding
  Adjacencies Metric Hello (s) Hold (s)n      1    15      3    60

```

show virtual-chassis protocol route (MX Series Virtual Chassis)

Syntax	show virtual-chassis protocol route < <i>destination-id</i> > <(all-members local member <i>member-id</i>)>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display the Virtual Chassis Control Protocol (VCCP) unicast and multicast routing tables for an MX Series Virtual Chassis. You can issue the show virtual-chassis protocol route command from the console of either member router in the Virtual Chassis.
Options	<p>all-members—(Optional) Display the VCCP unicast and multicast routing tables for both member routers in a Virtual Chassis configuration. This is the default behavior if no options are specified.</p> <p><i>destination-id</i>—(Optional) Display the VCCP unicast and multicast routing tables to the destination with the specified system ID.</p> <p>local—(Optional) Display the VCCP unicast and multicast routing tables for the member router on which you are issuing the command.</p> <p>member <i>member-id</i>—(Optional) Display the VCCP unicast and multicast routing tables for the specified member router. Replace <i>member-id</i> with the value 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Viewing Virtual Chassis Control Protocol Routing Tables
List of Sample Output	<p>show virtual-chassis protocol route all-members on page 1232</p> <p>show virtual-chassis protocol route member 0 001d.b510.0800 (For Specific Member ID and Destination ID) on page 1232</p>
Output Fields	Table 170 on page 1231 lists the output fields for the show virtual-chassis protocol route command. Output fields are listed in the approximate order in which they appear.

Table 170: show virtual-chassis protocol route Output Fields

Field Name	Field Description
membern	Member ID of the Virtual Chassis member router for which output is displayed.
Dev	System ID of the device (member router) that stores the VCCP routing tables. The System ID is derived from the router's media access control (MAC) address.
ucast routing table	VCCP unicast routing table.
mcast routing table	VCCP multicast routing table.

Table 170: show virtual-chassis protocol route Output Fields (*continued*)

Field Name	Field Description
Current version	Version of the shortest-path-first (SPF) algorithm that generated the VCCP unicast or multicast routing table.
System ID	System ID of the device, derived from the device's MAC address.
Version	Version of the SPF algorithm that generated this route in the VCCP unicast or multicast routing table.
Metric	Metric value required to reach this device.
Interface	Name of the Virtual Chassis port interface (in the format vcp-slot/pic/port.logical-unit-number) that interconnects the devices.
Via	MAC address of the next-hop device, if applicable.

Sample Output

```

show virtual-chassis {master:member1-re0}
protocol route
all-members
user@host> show virtual-chassis protocol route all-members
member0:
-----
Dev b0c6.9abf.6800 ucast routing table          Current version: 17
-----
System ID      Version  Metric Interface  Via
001d.b510.0800    17      15 vcp-5/0/0.32768 001d.b510.0800
b0c6.9abf.6800    17      0
Dev b0c6.9abf.6800 mcast routing table          Current version: 17
-----
System ID      Version  Metric Interface  Via
001d.b510.0800    17
b0c6.9abf.6800    17      vcp-5/0/0.32768
member1:
-----
Dev 001d.b510.0800 ucast routing table          Current version: 17
-----
System ID      Version  Metric Interface  Via
001d.b510.0800    17      0
b0c6.9abf.6800    17      15 vcp-1/3/0.32768 b0c6.9abf.6800
Dev 001d.b510.0800 mcast routing table          Current version: 17
-----
System ID      Version  Metric Interface  Via
001d.b510.0800    17      vcp-1/3/0.32768
b0c6.9abf.6800    17
show virtual-chassis {master:member1-re0}
protocol route member
user@host> show virtual-chassis protocol route member 0 001d.b510.0800

```



```

0 001d.b510.0800 member0:
(For Specific Member -----
ID and Destination ID) Dev b0c6.9abf.6800 ucast routing table          Current version: 17
-----
System ID      Version  Metric Interface  Via
001d.b510.0800    17      15 vcp-5/0/0.32768 001d.b510.0800
b0c6.9abf.6800    17        0

Dev b0c6.9abf.6800 mcast routing table          Current version: 17
-----
System ID      Version  Metric Interface  Via
001d.b510.0800    17
b0c6.9abf.6800    17      vcp-5/0/0.32768

```

show virtual-chassis protocol statistics (MX Series Virtual Chassis)

Syntax	show virtual-chassis protocol statistics < <i>interface-name</i> > <(all-members local member <i>member-id</i>)>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display Virtual Chassis Control Protocol (VCCP) statistics for one or both member routers, or for a specified Virtual Chassis port interface, in an MX Series Virtual Chassis. You can issue the show virtual-chassis protocol statistics command from the console of either member router in the Virtual Chassis.
Options	<p>all-members—(Optional) Display VCCP statistics for both member routers in a Virtual Chassis configuration. This is the default behavior if no options are specified.</p> <p><i>interface-name</i>—(Optional) Display VCCP statistics for the specified Virtual Chassis port interface, in the format vcp-slot/pic/port.logical-unit-number.</p> <p>local—(Optional) Display VCCP statistics for the member router on which you are issuing the command.</p> <p>member <i>member-id</i>—(Optional) Display VCCP statistics for the specified member router. Replace <i>member-id</i> with the value 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Viewing Virtual Chassis Control Protocol Statistics for Member Routers and Virtual Chassis Ports
List of Sample Output	<p>show virtual-chassis protocol statistics all-members on page 1235</p> <p>show virtual-chassis protocol statistics vcp-1/3/0.32768 member 1 (For Specific Virtual Chassis Port Interface and Member ID) on page 1236</p>
Output Fields	Table 171 on page 1234 lists the output fields for the show virtual-chassis protocol statistics command. Output fields are listed in the approximate order in which they appear.

Table 171: show virtual-chassis protocol statistics Output Fields

Field Name	Field Description
membern	Member ID of the Virtual Chassis member router for which output is displayed.
PDU type	Type of protocol data unit (PDU).
Received	Number of PDUs received since VCCP started or since the statistics were set to zero.
Processed	Number of PDUs received minus the number of PDUs dropped.
Drops	Number of PDUs dropped.

Table 171: show virtual-chassis protocol statistics Output Fields (*continued*)

Field Name	Field Description
Sent	Number of PDUs transmitted since VCCP started or since the statistics were set to zero.
Rexmit	Number of PDUs retransmitted since VCCP started or since the statistics were set to zero.
Total packets received	Total number of PDUs received since VCCP started or since the statistics were set to zero.
Sent	Total number of PDUs transmitted since VCCP started or since the statistics were set to zero.
LSP queue length	Number of link-state PDUs waiting in the queue to be processed.
Drops	Number of link-state PDUs dropped.
SPF runs	Number of shortest-path-first (SPF) calculations performed.
Fragments rebuilt	Number of link-state PDU fragments computed by the local system.
LSP regenerations	Number of regenerated link-state PDUs. A link-state PDU is regenerated when the PDU nears the end of its lifetime and has not changed.
Purges initiated	Number of purges initiated by the software. A purge is initiated when the software determines that it must remove a link-state PDU from the network.

Sample Output

```

show virtual-chassis {master:member1-re0}
protocol statistics
all-members
user@host> show virtual-chassis protocol statistics all-members
member0:
-----
IS-IS statistics for b0c6.9abf.6800:
PDU type      Received    Processed    Drops      Sent      Rexmit
LSP           2937       2937         0          2934      0
HELLO         2913       2913         0          2922      0
CSNP           1          1           0           1         0
PSNP          2916       2916         0          2925      0
Unknown        0          0           0           0         0
Totals        8767       8767         0          8782      0

Total packets received: 8767 Sent: 8782

LSP queue length: 0 Drops: 0
SPF runs: 17
Fragments rebuilt: 2955
LSP regenerations: 14
Purges initiated: 0

member1:
-----

```

```
IS-IS statistics for 001d.b510.0800:
PDU type      Received    Processed      Drops      Sent      Rexmit
LSP            2934         2934           0         2937         0
HELLO          2922         2922           0         2914         0
CSNP            1             1             0             1         0
PSNP           2925         2925           0         2916         0
Unknown         0             0             0             0         0
Totals         8782         8782           0         8768         0
```

Total packets received: 8782 Sent: 8768

```
LSP queue length: 0 Drops: 0
SPF runs: 17
Fragments rebuilt: 2953
LSP regenerations: 11
Purges initiated: 0
```

```
show virtual-chassis {master:member1-re0}
protocol statistics
vcp-1/3/0.32768
member1 (For Specific Virtual Chassis Port
Interface and Member ID)
user@host> show virtual-chassis protocol statistics vcp-1/3/0.32768 member 1
member1:
-----
vcp-1/3/0.32768
IS-IS statistics for 001d.b510.0800:
PDU type      Received    Processed      Drops      Sent      Rexmit
LSP            3013         3013           0         3016         0
HELLO          3001         3001           0         2993         0
CSNP            1             1             0             1         0
PSNP           3003         3003           0         2994         0
Unknown         0             0             0             0         0
Totals         9018         9018           0         9004         0

Total packets received: 9018 Sent: 9004
```

show virtual-chassis status (MX Series Virtual Chassis)

Syntax	show virtual-chassis status
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display information about the status of both member routers in an MX Series Virtual Chassis configuration. You can issue the show virtual-chassis status command from the console of either member router in the Virtual Chassis.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Verifying the Status of Virtual Chassis Member Routers Configuring Interchassis Redundancy for MX Series 3D Universal Edge Routers Using a Virtual Chassis Example: Configuring Interchassis Redundancy for MX Series 3D Universal Edge Routers Using a Virtual Chassis
List of Sample Output	show virtual-chassis status on page 1238
Output Fields	Table 172 on page 1237 lists the output fields for the show virtual-chassis status command. Output fields are listed in the approximate order in which they appear.

Table 172: show virtual-chassis status Output Fields

Field Name	Field Description
Virtual Chassis ID	Assigned ID that applies to the entire Virtual Chassis configuration.
Member ID	Member ID assigned in the preprovisioned Virtual Chassis configuration, and the Flexible PIC Concentrator (FPC) slot range, including offset, for each member router in the Virtual Chassis.
Status	State of the member router: <ul style="list-style-type: none"> Prsnt—Router is currently connected to the Virtual Chassis. NotPrsnt—Router is not currently connected to the Virtual Chassis.
Serial No	Serial number of the member router.
Model	Model number of the member router.
Mastership priority	Metric used by the Virtual Chassis software for the mastership election algorithm. This value is assigned by the software and is not configurable in the current release.
Role	Role of the member router in the Virtual Chassis: Master or Backup . The asterisk (*) following the Role denotes the router on which the show virtual-chassis status command was issued.

Table 172: show virtual-chassis status Output Fields (*continued*)

Field Name	Field Description
Neighbor List ID Interface	Member IDs and Virtual Chassis port interfaces (in the format vcp-slot/pic/port) to which this member router is connected.

Sample Output

```

show virtual-chassis {master:member1-re0}
status
user@host> show virtual-chassis status
Preprovisioned Virtual Chassis
Virtual Chassis ID: 5a6a.e747.8511

Member ID      Status  Serial No  Model  Mastership  Role  Neighbor List
priority      ID      Interface
0 (FPC 0- 11) Prsnt  JN115FDADAFB mx480    129  Backup    1 vcp-5/0/0
1 (FPC 12- 23) Prsnt  JN10C78D1AFC mx240    129  Master*   0 vcp-1/3/0

```

show virtual-chassis vc-port (MX Series Virtual Chassis)

Syntax	show virtual-chassis vc-port <(all-members local member <i>member-id</i>)>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display the operational status of the Virtual Chassis ports for both member routers or for a specified member router in an MX Series Virtual Chassis configuration. You can issue the show virtual-chassis vc-port command from the console of either member router in the Virtual Chassis.
Options	<p>all-members—(Optional) Display the operational status of the Virtual Chassis ports for both member routers in a Virtual Chassis configuration.</p> <p>local—(Optional) Display the operational status of the Virtual Chassis ports on the member router on which you are issuing the command. This is the default behavior if no options are specified.</p> <p>member <i>member-id</i>—(Optional) Display the operational status of the Virtual Chassis ports on the specified member router. Replace <i>member-id</i> with the value 0 or 1.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> Verifying the Operation of Virtual Chassis Ports Configuring Interchassis Redundancy for MX Series 3D Universal Edge Routers Using a Virtual Chassis Example: Configuring Interchassis Redundancy for MX Series 3D Universal Edge Routers Using a Virtual Chassis
List of Sample Output	<p>show virtual-chassis vc-port all-members on page 1240</p> <p>show virtual-chassis vc-port local on page 1240</p> <p>show virtual-chassis vc-port member 0 on page 1240</p>
Output Fields	Table 173 on page 1239 lists the output fields for the show virtual-chassis vc-port command. Output fields are listed in the approximate order in which they appear.

Table 173: show virtual-chassis vc-port Output Fields

Field Name	Field Description
membern	Member ID of the Virtual Chassis member router for which output is displayed.
Interface or Slot/PIC/Port	Location, in the format <i>slot/pic/port</i> , of the Virtual Chassis ports configured on the member router.
Type	Type of Virtual Chassis port. Configured indicates that the Virtual Chassis port is properly configured.

Table 173: show virtual-chassis vc-port Output Fields (*continued*)

Field Name	Field Description
Trunk ID	Trunk ID value assigned to a link aggregation group (LAG) formed by the Virtual Chassis. A positive number indicates that a trunk exists. The value -1 indicates that a trunk is not present.
Status	State of the Virtual Chassis port interface: Up , Down , or Absent .
Speed (mbps)	Speed, in megabits per second, of the Virtual Chassis port interface.
Neighbor ID Interface	Member IDs and Virtual Chassis port interfaces (in vcp-slot/pic/port format) that are connected to this member router.

Sample Output

```

show virtual-chassis {master:member1-re0}
vc-port all-members
user@host> show virtual-chassis vc-port all-members
member0:
-----
Interface      Type      Trunk  Status  Speed  Neighbor
or             ID        ID      (mbps)  ID  Interface
Slot/PIC/Port
5/0/0          Configured -1     Up      10000   1    vcp-1/3/0

member1:
-----
Interface      Type      Trunk  Status  Speed  Neighbor
or             ID        ID      (mbps)  ID  Interface
Slot/PIC/Port
1/3/0          Configured -1     Up      10000   0    vcp-5/0/0

show virtual-chassis {master:member1-re0}
vc-port local
user@host> show virtual-chassis vc-port local

Interface      Type      Trunk  Status  Speed  Neighbor
or             ID        ID      (mbps)  ID  Interface
Slot/PIC/Port
1/3/0          Configured -1     Up      10000   0    vcp-5/0/0

show virtual-chassis {master:member1-re0}
vc-port member 0
user@host> show virtual-chassis vc-port member 0
member0:
-----
Interface      Type      Trunk  Status  Speed  Neighbor
or             ID        ID      (mbps)  ID  Interface
Slot/PIC/Port
5/0/0          Configured -1     Up      10000   1    vcp-1/3/0

```


PART 3

Class of Service

- [Class-of-Service Operational Mode Commands on page 1243](#)

Class-of-Service Operational Mode Commands

Table 174 on page 1243 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot class of service (CoS). Commands are listed in alphabetical order.

Table 174: Class-of-Service (CoS) Operational Mode Commands

Task	Command
Display the entire CoS configuration, including system-chosen defaults.	show class-of-service
(J Series routers only) Display trigger points and associated rates for CoS adaptive shapers.	show class-of-service adaptive-shaper
For each CoS classifier, display the mapping of code point value to forwarding class and loss priority.	show class-of-service classifier
Display the mapping of CoS code point aliases to corresponding bit patterns.	show class-of-service code-point-aliases
Display data points for each CoS random early detection (RED) drop profile.	show class-of-service drop-profile
(M320 routers and T Series routers only) Display the mapping of CoS schedulers to switch fabric traffic priorities and a summary of scheduler parameters for each priority.	show class-of-service fabric scheduler-map
(M320 routers and T Series routers only) Display CoS switch fabric queue statistics.	show class-of-service fabric statistics
Display the mapping of forwarding class names to queue numbers.	show class-of-service forwarding-class
Display entire CoS configuration as it exists in the forwarding table.	show class-of-service forwarding-table

Table 174: Class-of-Service (CoS) Operational Mode Commands (*continued*)

Task	Command
Display the mapping of code point value to queue number and loss priority for each classifier as it exists in the forwarding table.	show class-of-service forwarding-table classifier
For each logical interface, display either the table index of the classifier for a given code point type or the queue number (if it is a fixed classification) in the forwarding table.	show class-of-service forwarding-table classifier mapping
Display the data points of all random early detection (RED) drop profiles as they exist in the forwarding table.	show class-of-service forwarding-table drop-profile
(M320 routers and T Series routers only) Display the scheduler map information as it exists in the forwarding table for switch fabric.	show class-of-service forwarding-table fabric scheduler-map
(J Series routers only) Display the mapping of code point value to loss priority as it exists in the forwarding table.	show class-of-service forwarding-table loss-priority-map
(J Series routers only) For each logical interface, display the loss priority table index.	show class-of-service forwarding-table loss-priority-map mapping
Display mapping of queue number and loss priority to code point value for each rewrite rule as it exists in the forwarding table.	show class-of-service forwarding-table rewrite-rule
For each logical interface, display the table identifier of the rewrite rule map for each code point type.	show class-of-service forwarding-table rewrite-rule mapping
For each physical interface, display the scheduler map information as it exists in the forwarding table.	show class-of-service forwarding-table scheduler-map
For Adaptive Services (AS) PIC link services IQ interfaces (lsq) only, display fragmentation properties for specific forwarding classes.	show class-of-service fragmentation-map
Display the logical and physical interface associations for the classifier, rewrite rules, and scheduler map objects.	show class-of-service interface
Display the configured shaping rate and the quality of service (QoS) adjusted shaping rate for each logical interface set configured for hierarchical class of service (CoS).	show class-of-service interface-set

Table 174: Class-of-Service (CoS) Operational Mode Commands (*continued*)

Task	Command
(J Series routers only) Display mapping of code point value to loss priority.	show class-of-service loss-priority-map
Display the mapping of forwarding classes and loss priority to code point values.	show class-of-service rewrite-rule
(M Series and T Series routers only) Display mapping of CoS objects to routing instances.	show class-of-service routing-instance
Display mapping of schedulers to forwarding classes and a summary of scheduler parameters for each entry.	show class-of-service scheduler-map
For Gigabit Ethernet IQ and Channelized IQ PICs only, display traffic shaping and scheduling profiles.	show class-of-service traffic-control-profile
For IQE PICs only, display translation table information.	show class-of-service translation-table
(J Series routers only) Display virtual channel information.	show class-of-service virtual-channel
(J Series routers only) Display virtual channel group information.	show class-of-service virtual-channel-group



NOTE: For information about how to configure CoS, see the *Junos OS Class of Service Configuration Guide*. For information about the related `show interfaces queue` command, see the *Junos OS Interfaces Command Reference*.

show class-of-service

Syntax	show class-of-service
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	Display the entire class-of-service (CoS) configuration, including system-chosen defaults. Executing this command is equivalent to executing all show class-of-service commands in succession.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service on page 1246
Output Fields	See the output field descriptions for the commands.

Sample Output

```

user@host> show class-of-service
Forwarding class                               Queue
  best-effort                                0
  expedited-forwarding                       1
  assured-forwarding                         2
  network-control                            3
Code point type: dscp
  Alias      Bit pattern
  af11       001010
  af12       001100
  af13       001110
...
Code point type: dscp-ipv6
  Alias      Bit pattern
  af11       001010
  af12       001100
  af13       001110
...
Code point type: exp
  Alias      Bit pattern
  af11       100
  af12       101
  be         000
...
Code point type: ieee-802.1
  Alias      Bit pattern
  af11       100
  af12       101
  be         000
...
Classifier: dscp-default, Code point type: dscp, Index: 6
  Code point      Forwarding class      Loss priority
  000000          best-effort            low
  000001          best-effort            low

```

```

000010          best-effort          low
....
Classifier: dscp-ipv6-default, Code point type: dscp-ipv6, Index: 7
  Code point      Forwarding class      Loss priority
  000000          best-effort          low
  000001          best-effort          low
  000010          best-effort          low
...
Loss-priority-map: frame-relay-de-default, Code point type: frame-relay-de, Index:
12
  Code point      Loss priority
  0              low
  1              high

Rewrite rule: dscp-default, Code point type: dscp, Index: 23
  Forwarding class      Loss priority      Code point
  best-effort          low                000000
  best-effort          high               000000
  expedited-forwarding low               101110
...
Rewrite rule: dscp-ipv6-default, Code point type: dscp-ipv6, Index: 24
  Forwarding class      Loss priority      Code point
  best-effort          low                000000
  best-effort          high               000000
...
....
Drop profile: <default-drop-profile>, Type: discrete, Index: 1
  Fill level      Drop probability
  100             100

Scheduler map: <default>, Index: 2

  Scheduler: <default-be>, Forwarding class: best-effort, Index: 16
  Transmit rate: 95 percent, Rate Limit: none, Buffer size: 95 percent, Priority:
low
  Drop profiles:
    Loss priority  Protocol  Index  Name
    Low           any       1      <default-drop-profile>
    Medium low    any       1      <default-drop-profile>
    Medium high   any       1      <default-drop-profile>
    High          any       1      <default-drop-profile>
...
Physical interface: fe-0/0/0, Index: 137
Queues supported: 8, Queues in use: 4
Scheduler map: <default>, Index: 2

Logical interface: fe-0/0/0.0, Index: 69
  Object      Name              Type      Index
  Adaptive-shaper fr-shaper              35320
  Classifier    ipprec-compatibility ip         11

Physical interface: fe-0/0/1, Index: 138
Queues supported: 8, Queues in use: 4
Scheduler map: <default>, Index: 2
...

```

show class-of-service adaptive-shaper

Syntax	<code>show class-of-service adaptive-shaper</code> <code><adaptive-shaper-name></code>
Release Information	Introduced before Junos OS Release 7.4.
Description	(J Series routers only) Display trigger points and associated rates for class-of-service (CoS) adaptive shapers.
Options	none—Display all adaptive shaper information. <i>adaptive-shaper-name</i> —(Optional) Display information for the named adaptive shaper.
Required Privilege Level	view
List of Sample Output	show class-of-service adaptive-shaper on page 1248
Output Fields	Table 175 on page 1248 describes the output fields for the show class-of-service adaptive-shaper command. Output fields are listed in the approximate order in which they appear.

Table 175: show class-of-service adaptive-shaper Output Fields

Field Name	Field Description
Adaptive shaper	Name of the adaptive shaper.
Index	Internal index of the adaptive shaper.
Trigger type	Adaptive shaper trigger type. The trigger type can be the backward explicit congestion notification (BECN) bit in Frame Relay packet headers.
Shaping rate	CoS adaptive shaping rate.

Sample Output

```

show class-of-service adaptive-shaper  user@host> show class-of-service adaptive-shaper
                                     Adaptive shaper: as, Index: 3155
                                     Trigger type      Shaping rate
                                     BECN              30 percent

```


show class-of-service classifier

Syntax	show class-of-service classifier <name <i>name</i> > <type dscp type dscp-ipv6 type exp type ieee-802.1 type inet-precedence>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	For each class-of-service (CoS) classifier, display the mapping of code point value to forwarding class and loss priority.
Options	<p>none—Display all classifiers.</p> <p>name <i>name</i>—(Optional) Display named classifier.</p> <p>type dscp—(Optional) Display all classifiers of the Differentiated Services code point (DSCP) type.</p> <p>type dscp-ipv6—(Optional) Display all classifiers of the DSCP for IPv6 type.</p> <p>type exp—(Optional) Display all classifiers of the MPLS experimental (EXP) type.</p> <p>type ieee-802.1—(Optional) Display all classifiers of the ieee-802.1 type.</p> <p>type inet-precedence—(Optional) Display all classifiers of the inet-precedence type.</p>
Required Privilege Level	view
List of Sample Output	<p>show class-of-service classifier type ieee-802.1 on page 1250</p> <p>show class-of-service classifier type ieee-802.1 (QFX Series) on page 1250</p>
Output Fields	Table 176 on page 1249 describes the output fields for the show class-of-service classifier command. Output fields are listed in the approximate order in which they appear.

Table 176: show class-of-service classifier Output Fields

Field Name	Field Description
Classifier	Name of the classifier.
Code point type	Type of the classifier: exp (not on EX Series switch), dscp , dscp-ipv6 (not on EX Series switch), ieee-802.1 , or inet-precedence .
Index	Internal index of the classifier.
Code point	Code point value used for classification
Forwarding class	Classification of a packet affecting the forwarding, scheduling, and marking policies applied as the packet transits the router.

Table 176: show class-of-service classifier Output Fields (*continued*)

Field Name	Field Description
Loss priority	Loss priority value used for classification. For most platforms, the value is high or low . For some platforms, the value is high , medium-high , medium-low , or low .

Sample Output

```

show class-of-service classifier type ieee-802.1
  classifier type
  ieee-802.1
user@host> show class-of-service classifier type ieee-802.1
Classifier: ieee802.1-default, Code point type: ieee-802.1, Index: 3
Code Point      Forwarding Class      Loss priority
000             best-effort           low
001             best-effort           high
010             expedited-forwarding  low
011             expedited-forwarding  high
100             assured-forwarding    low
101             assured-forwarding    medium-high
110             network-control       low
111             network-control       high

Classifier: users-ieee802.1, Code point type: ieee-802.1
Code point      Forwarding class      Loss priority
100             expedited-forwarding  low

show class-of-service classifier type ieee-802.1
  classifier type
  ieee-802.1 (QFX
  Series)
user@switch> show class-of-service classifier type ieee-802.1
Classifier: ieee8021p-default, Code point type: ieee-802.1, Index: 11
Code point      Forwarding class      Loss priority
000             best-effort           low
001             best-effort           low
010             best-effort           low
011             best-effort           low
100             best-effort           low
101             best-effort           low
110             network-control      low
111             network-control      low

Classifier: ieee-mcast, Code point type: ieee-802.1, Index: 46
Code point      Forwarding class      Loss priority
000             mcast-be              low
001             mcast-be              low
010             mcast-be              low
011             mcast-be              low
100             mcast-be              low
101             mcast-be              low
110             mcast-nc              low
111             mcast-nc              low

```

show class-of-service code-point-aliases

Syntax	<code>show class-of-service code-point-aliases</code> <code><dscp dscp-ipv6 exp ieee-802.1 inet-precedence></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the mapping of class-of-service (CoS) code point aliases to corresponding bit patterns.
Options	<p><code>none</code>—Display code point aliases of all code point types.</p> <p><code>dscp</code>—(Optional) Display Differentiated Services code point (DSCP) aliases.</p> <p><code>dscp-ipv6</code>—(Optional) Display IPv6 DSCP aliases.</p> <p><code>exp</code>—(Optional) Display MPLS EXP code point aliases.</p> <p><code>ieee-802.1</code>—(Optional) Display IEEE-802.1 code point aliases.</p> <p><code>inet-precedence</code>—(Optional) Display IPv4 precedence code point aliases.</p>
Required Privilege Level	view
List of Sample Output	show class-of-service code-point-aliases exp on page 1252
Output Fields	Table 177 on page 1251 describes the output fields for the show class-of-service code-point-aliases command. Output fields are listed in the approximate order in which they appear.

Table 177: show class-of-service code-point-aliases Output Fields

Field Name	Field Description
Code point type	Type of the code points displayed: dscp , dscp-ipv6 (not on EX Series switch or the QFX Series), exp (not on EX Series switch or the QFX Series), ieee-802.1 , or inet-precedence (not on the QFX Series).
Alias	Alias for a bit pattern.
Bit pattern	Bit pattern for which the alias is displayed.

Sample Output

```
show class-of-service user@host> show class-of-service code-point-aliases exp
code-point-aliases exp Code point type: exp
  Alias      Bit pattern
  af11      100
  af12      101
  be        000
  be1       001
  cs6       110
  cs7       111
  ef        010
  ef1       011
  nc1       110
  nc2       111
```

show class-of-service drop-profile

Syntax	show class-of-service drop-profile <profile-name <i>profile-name</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display data points for each class-of-service (CoS) random early detection (RED) drop profile.
Options	none—Display all drop profiles. profile-name <i>profile-name</i> —(Optional) Display the specified profile only.
Required Privilege Level	view
List of Sample Output	show class-of-service drop-profile on page 1254
Output Fields	Table 178 on page 1253 describes the output fields for the show class-of-service drop-profile command. Output fields are listed in the approximate order in which they appear.

Table 178: show class-of-service drop-profile Output Fields

Field Name	Field Description
Drop profile	Name of a drop profile.
Type	Type of this drop profile: discrete or interpolated .
Index	Internal index of this drop profile.
Fill Level	Percentage fullness of a queue.
Drop probability	Drop probability at this fill level.

Sample Output

```
show class-of-service user@host> show class-of-service drop-profile
drop-profile Drop profile: <default-drop-profile>, Type: discrete, Index: 1
  Fill level Drop probability
    100      100
Drop profile: user-drop-profile, Type: interpolated, Index: 2989
  Fill level Drop probability
    0        0
    1        1
    2        2
    4        4
    5        5
    6        6
    8        8
   10       10
   12       15
   14       20
   15       23
... 64 entries total
   90       96
   92       96
   94       97
   95       98
   96       98
   98       99
   99       99
  100      100
```

show class-of-service fabric scheduler-map

Syntax	show class-of-service fabric scheduler-map
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Display the mapping of class-of-service (CoS) schedulers to switch fabric traffic priorities and a summary of scheduler parameters for each priority.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service fabric scheduler-map on page 1255
Output Fields	Table 179 on page 1255 describes the output fields for the show class-of-service fabric scheduler-map command. Output fields are listed in the approximate order in which they appear.

Table 179: show class-of-service fabric scheduler-map Output Fields

Field Name	Field Description
Fabric priority	Indicates the fabric traffic priority. Currently, two priorities are supported: low and high .
Scheduler	Name of the scheduler.
Index	Index of the indicated object. Objects that have indexes in this output include schedulers and drop profiles.
Drop profiles	Display the assignment of drop profile by name and index to a given loss priority and protocol pair: <ul style="list-style-type: none"> • Loss priority—Packet loss priority for drop profile assignment. • Protocol—Transport protocol for drop profile assignment. • Name—Name of the drop profile.

Sample Output

```

user@host> show class-of-service fabric scheduler-map
show class-of-service fabric scheduler-map
Fabric priority: low
Scheduler: fab-ef-scheduler, Index: 60211
Drop profiles:
  Loss priority  Protocol  Index  Name
  Low           non-TCP  44321  fab-ef-profile
  Low           TCP      44321  fab-ef-profile
  High          non-TCP  44321  fab-ef-profile
  High          TCP      44321  fab-ef-profile

Fabric priority: high
Scheduler: fab-ef-scheduler, Index: 60211
Drop profiles:

```

Loss priority	Protocol	Index	Name
Low	non-TCP	44321	fab-ef-profile
Low	TCP	44321	fab-ef-profile
High	non-TCP	44321	fab-ef-profile
High	TCP	44321	fab-ef-profile

show class-of-service fabric statistics

Syntax	show class-of-service fabric statistics <destination <i>fpc-number</i> > <source <i>fpc-number</i> > <summary>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Display class-of-service (CoS) switch fabric queue statistics.
Options	<p>none—Same as summary.</p> <p>destination <i>fpc-number</i>—(Optional) Display details for the specified destination Flexible PIC Concentrator (FPC). The FPC number is a value from 0 through 7.</p> <p>source <i>fpc-number</i>—(Optional) Display details for the specified source FPC. The FPC number is a value from 0 through 7.</p> <p>summary—(Optional) Display all switch fabric statistics.</p>
Required Privilege Level	view
List of Sample Output	show class-of-service fabric statistics on page 1258
Output Fields	Table 180 on page 1257 describes the output fields for the show class-of-service fabric statistics command. Output fields are listed in the approximate order in which they appear.

Table 180: show class-of-service fabric statistics Output Fields

Field Name	Field Description
Destination FPC Index	Index number associated with the destination FPC
Source PFC Index	Index number associated with the source FPC.
Total statistics	<p>Fabric queue statistic totals:</p> <ul style="list-style-type: none"> • Packets—Total packet count for high-priority and low-priority queues. • Bytes—Total byte count for high-priority and low-priority queues. • pps—Total packets-per-second count for high-priority and low-priority queues. • bps—Total bytes-per-second count for high-priority and low-priority queues.
Tx statistics	<p>Fabric queue statistics for transmitted traffic:</p> <ul style="list-style-type: none"> • Packets—Transmitted packet count for high-priority and low-priority queues. • Bytes—Transmitted byte count for high-priority and low-priority queues. • pps—Transmitted packets-per-second count for high-priority and low-priority queues. • bps—Transmitted bytes-per-second count for high-priority and low-priority queues.

Table 180: show class-of-service fabric statistics Output Fields (*continued*)

Field Name	Field Description
Drop statistics	<p>Fabric queue statistics for dropped traffic:</p> <ul style="list-style-type: none"> • Packets—Dropped packet count for high-priority and low-priority queues. • Bytes—Dropped byte count for high-priority and low-priority queues. • pps—Dropped packets-per-second count for high-priority and low-priority queues. • bps—Dropped bytes-per-second count for high-priority and low-priority queues.

Sample Output

```

show class-of-service fabric statistics user@host> show class-of-service fabric statistics
fabric statistics Destination FPC Index: 0, Source FPC Index: 0
Total statistics: High priority Low priority
Packets: 0 0
Bytes : 0 0
Pps : 0 0
Bps : 0 0
Tx statistics: High priority Low priority
Packets: 0 0
Bytes : 0 0
Pps : 0 0
Bps : 0 0
Drop statistics: High priority Low priority
Packets: 0 0
Bytes : 0 0
Pps : 0 0
Bps : 0 0

Destination FPC Index: 0, Source FPC Index: 1
Total statistics: High priority Low priority
Packets: 0 0
Bytes : 0 0
Pps : 0 0
Bps : 0 0
Tx statistics: High priority Low priority
Packets: 0 0
Bytes : 0 0
Pps : 0 0
Bps : 0 0
Drop statistics: High priority Low priority
Packets: 0 0
Bytes : 0 0
...

```

show class-of-service forwarding-class

Syntax	show class-of-service forwarding-class <forwarding-class-map-name>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display the mapping of forwarding class maps and names to queue numbers.
Options	forwarding-class-map-name—(Optional) Display the forwarding class configuration for a specific forwarding class map name. If this option is omitted, information for all forwarding class maps will be displayed.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-class on page 1259 show class-of-service forwarding-class forwarding-class-map-name on page 1260
Output Fields	Table 181 on page 1259 describes the output fields for the show class-of-service forwarding-class command. Output fields are listed in the approximate order in which they appear.

Table 181: show class-of-service forwarding-class Output Fields

Field Name	Field Description
Forwarding class map	Classification of a packet affecting the forwarding, scheduling, and marking policies applied as the packet transits the router.
ID	Forwarding class identifier.
Queue	Queue corresponding to the forwarding class name.
Restricted Queue	(T Series platforms only) Forwarding class restricted queue number. The queue number assigned if the PIC is restricted to four queues.
Fabric Priority	(M320 and T Series platforms only) Forwarding class queue priority.

Sample Output

```

user@host> show class-of-service forwarding-class
show class-of-service forwarding-class
Forwarding class map FCMAP1  ID      Queue  Restricted queue  Fabric
                               Priority
fc0                          0       0           0                low
fc2                          1       1           1                low
fc4                          2       2           2                low
fc6                          3       3           3                low
fc1                          4       0           0                low
fc3                          5       1           1                low
fc5                          6       2           2                low
fc7                          7       3           3                low
fc8                          8       4           0                low
fc9                          9       4           0                low

```

fc10	10	5	1	low
fc11	11	5	1	low
fc12	12	6	2	low
fc13	13	6	2	low
fc14	14	7	3	low
fc15	15	7	3	low

Sample Output

```
show class-of-service forwarding-class FCMAP1
show class-of-service forwarding-class FCMAP1
Forwarding class map FCMAP1
```

forwarding-class-map-name	ID	Queue	Restricted queue	Fabric Priority
fc0	0	0	0	low
fc2	1	1	1	low
fc4	2	2	2	low
fc6	3	3	3	low
fc1	4	0	0	low
fc3	5	1	1	low
fc5	6	2	2	low
fc7	7	3	3	low
fc8	8	4	0	low
fc9	9	4	0	low
fc10	10	5	1	low
fc11	11	5	1	low
fc12	12	6	2	low
fc13	13	6	2	low
fc14	14	7	3	low
fc15	15	7	3	low

show class-of-service forwarding-table

Syntax	show class-of-service forwarding-table
Syntax (TX Matrix and TX Matrix Plus Router)	show class-of-service forwarding-table <lcc <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the entire class-of-service (CoS) configuration as it exists in the forwarding table. Executing this command is equivalent to executing all show class-of-service forwarding-table commands in succession.
Options	<i>lcc number</i> —(TX Matrix and TX Matrix Plus router only) (Optional) On a TX Matrix router, display the forwarding table configuration for a specific T640 router (or line-card chassis) configured in a routing matrix. On a TX Matrix Plus router, display the forwarding table configuration for a specific T1600 router (or line-card chassis) configured in the routing matrix. Replace <i>number</i> with a value from 0 through 3.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table on page 1261 show class-of-service forwarding-table lcc (TX Matrix Plus Router) on page 1262
Output Fields	See the output field descriptions for show class-of-service forwarding-table commands: <ul style="list-style-type: none"> • show class-of-service forwarding-table classifier • show class-of-service forwarding-table classifier mapping • show class-of-service forwarding-table drop-profile • show class-of-service forwarding-table fabric scheduler-map • show class-of-service forwarding-table loss-priority-map • show class-of-service forwarding-table loss-priority-map mapping • show class-of-service forwarding-table rewrite-rule • show class-of-service forwarding-table rewrite-rule mapping • show class-of-service forwarding-table scheduler-map

Sample Output

```

show class-of-service forwarding-table user@host> show class-of-service forwarding-table
Classifier table index: 9, # entries: 8, Table type: EXP
Entry #   Code point   Forwarding-class #   PLP
0         000           0                   0
1         001           0                   1
2         010           1                   0
3         011           1                   1
4         100           2                   0

```

5	101	2	1
6	110	3	0
7	111	3	1

Interface	Index	Table Index/ Q num	Table type
sp-0/0/0.1001	66	11	IPv4 precedence
sp-0/0/0.2001	67	11	IPv4 precedence
sp-0/0/0.16383	68	11	IPv4 precedence
fe-0/0/0.0	69	11	IPv4 precedence

Interface: sp-0/0/0 (Index: 129, Map index: 2, Map type: FINAL,
Num of queues: 2):
Entry 0 (Scheduler index: 16, Forwarding-class #: 0):
Tx rate: 0 Kb (95%), Buffer size: 95 percent
Priority low
PLP high: 1, PLP low: 1, PLP medium-high: 1, PLP medium-low: 1
Entry 1 (Scheduler index: 18, Forwarding-class #: 3):
Tx rate: 0 Kb (5%), Buffer size: 5 percent
Priority low
PLP high: 1, PLP low: 1, PLP medium-high: 1, PLP medium-low: 1

Interface: fe-0/0/0 (Index: 137, Map index: 2, Map type: FINAL,
Num of queues: 2):
Entry 0 (Scheduler index: 16, Forwarding-class #: 0):
Tx rate: 0 Kb (95%), Buffer size: 95 percent
Priority low
PLP high: 1, PLP low: 1, PLP medium-high: 1, PLP medium-low: 1
Entry 1 (Scheduler index: 18, Forwarding-class #: 3):
Tx rate: 0 Kb (5%), Buffer size: 5 percent
Priority low
PLP high: 1, PLP low: 1, PLP medium-high: 1, PLP medium-low: 1

Interface: fe-0/0/1 (Index: 138, Map index: 2, Map type: FINAL,
Num of queues: 2):
Entry 0 (Scheduler index: 16, Forwarding-class #: 0):
Tx rate: 0 Kb (95%), Buffer size: 95 percent
Priority low
PLP high: 1, PLP low: 1, PLP medium-high: 1, PLP medium-low: 1
Entry 1 (Scheduler index: 18, Forwarding-class #: 3):
Tx rate: 0 Kb (5%), Buffer size: 5 percent
Priority low
PLP high: 1, PLP low: 1, PLP medium-high: 1, PLP medium-low: 1

...

RED drop profile index: 1, # entries: 1
Drop
Entry Fullness(%) Probability(%)
0 100 100

**show class-of-service
forwarding-table lcc
(TX Matrix Plus
Router)**

user@host> show class-of-service forwarding-table lcc 0
lcc0-re0:

```
-----
Classifier table index: 9, # entries: 64, Table type: IPv6 DSCP
Entry # Code point Forwarding-class # PLP
0 000000 0 0
1 000001 0 0
2 000010 0 0
3 000011 0 0
4 000100 0 0
```

5	000101	0	0
6	000110	0	0
7	000111	0	0
8	001000	0	0
9	001001	0	0
10	001010	0	0
11	001011	0	0
12	001100	0	0
13	001101	0	0
14	001110	0	0
15	001111	0	0
16	010000	0	0
17	010001	0	0
18	010010	0	0
19	010011	0	0
20	010100	0	0
21	010101	0	0
22	010110	0	0
23	010111	0	0
24	011000	0	0
25	011001	0	0
26	011010	0	0
27	011011	0	0
28	011100	0	0
29	011101	0	0
30	011110	0	0
31	011111	0	0
32	100000	0	0
33	100001	0	0
34	100010	0	0
35	100011	0	0
36	100100	0	0
37	100101	0	0
38	100110	0	0
39	100111	0	0
40	101000	0	0
41	101001	0	0
42	101010	0	0
43	101011	0	0
44	101100	0	0
45	101101	0	0
46	101110	0	0
...			

show class-of-service forwarding-table classifier

Syntax	show class-of-service forwarding-table classifier
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the mapping of code point value to queue number and loss priority for each classifier as it exists in the forwarding table.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table classifier on page 1264
Output Fields	Table 182 on page 1264 describes the output fields for the show class-of-service forwarding-table classifier command. Output fields are listed in the approximate order in which they appear.

Table 182: show class-of-service forwarding-table classifier Output Fields

Field Name	Field Description
Classifier table index	Index of the classifier table.
Entries	Total number of entries.
Table type	Type of code points in the table: DSCP , EXP (not on the QFX Series), IEEE 802.1 , IPv4 precedence (not on the QFX Series), or IPv6 DSCP (not on the QFX Series).
Entry #	Entry number.
Code point	Code point value used for classification.
Forwarding-class #	Forwarding class to which the code point is assigned.
PLP	Packet loss priority value set by classification. For most platforms, the value can be 0 or 1 . For some platforms, the value is 0 , 1 , 2 , or 3 . The value 0 represents low PLP. The value 1 represents high PLP. The value 2 represents medium-low PLP. The value 3 represents medium-high PLP.

Sample Output

```

show class-of-service forwarding-table classifier
user@host> show class-of-service forwarding-table classifier
Classifier table index: 62436, # entries: 64, Table type: DSCP
Entry #   Code point   Forwarding-class #   PLP
  0         000000         0                   0

```


1	000001	0	0
2	000010	0	0
3	000011	0	0
4	000100	0	0
5	000101	0	0
6	000110	0	0
7	000111	0	0
8	001000	0	0
9	001001	0	0
10	001010	1	1
11	001011	0	0
...			
60	111100	0	0
61	111101	0	0
62	111110	0	0
63	111111	0	0

show class-of-service forwarding-table classifier mapping

Syntax	show class-of-service forwarding-table classifier mapping
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	For each logical interface, display either the table index of the classifier for a given code point type or the queue number (if it is a fixed classification) in the forwarding table.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table classifier mapping on page 1266
Output Fields	Table 183 on page 1266 describes the output fields for the show class-of-service forwarding-table classifier mapping command. Output fields are listed in the approximate order in which they appear.

Table 183: show class-of-service forwarding-table classifier mapping Output Fields

Field Name	Field Description
Table index/ Q num	If the type is Fixed , the number of the queue to which the interface is mapped. For all other types, this value is the classifier index number.
Interface	Name of the logical interface.
Index	Logical interface index.
Table type	Type of code points in the table: DSCP , EXP (not on the QFX Series), IEEE 802.1 , IPv4 precedence (not on the QFX Series), or IPv6 DSCP (not on the QFX Series).

Sample Output

```

user@host> show class-of-service forwarding-table classifier mapping
show class-of-service forwarding-table classifier mapping
          Table index/
Interface  Index    Q num    Table type
so-5/0/0.0   10    62436    DSCP
so-0/1/0.0   11    62436    DSCP
so-0/2/0.0   12      1    Fixed
so-0/2/1.0   13    62436    DSCP
so-0/2/1.0   13    62437    IEEE 802.1
so-0/2/2.0   14    62436    DSCP
so-0/2/2.0   14    62438    IPv4 precedence

```

show class-of-service forwarding-table drop-profile

Syntax	show class-of-service forwarding-table drop-profile
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the data points of all random early detection (RED) drop profiles as they exist in the forwarding table.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table drop-profile on page 1267
Output Fields	Table 184 on page 1267 describes the output fields for the show class-of-service forwarding-table drop-profile command. Output fields are listed in the approximate order in which they appear.

Table 184: show class-of-service forwarding-table drop-profile Output Fields

Field Name	Field Description
RED drop profile index	Index of this drop profile.
# entries	Number of entries in a particular RED drop profile index.
Entry	Drop profile entry number.
Fullness(%)	Percentage fullness of a queue.
Drop probability(%)	Drop probability at this fill level.

Sample Output

```

show class-of-service forwarding-table drop-profile
user@host> show class-of-service forwarding-table drop-profile
RED drop profile index: 4, # entries: 1
      Drop
Entry  Fullness(%)  Probability(%)
  0         100         100

RED drop profile index: 8742, # entries: 3
      Drop
Entry  Fullness(%)  Probability(%)
  0         10         10
  1         20         20
  2         30         30

RED drop profile index: 24627, # entries: 64
      Drop

```

Entry	Fullness(%)	Probability(%)
0	0	0
1	1	1
2	2	2
3	4	4
...		
61	98	99
62	99	99
63	100	100

RED drop profile index: 25393, # entries: 64

Entry	Fullness(%)	Drop Probability(%)
0	0	0
1	1	1
2	2	2
3	4	4
...		
61	98	98
62	99	99
63	100	100

show class-of-service forwarding-table fabric scheduler-map

Syntax	show class-of-service forwarding-table fabric scheduler-map
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Display the scheduler map information as it exists in the forwarding table for switch fabric.
Options	This command has no options.
Additional Information	For information about how PLP priority is assigned to packets, see the Junos OS Class of Service Configuration Guide .
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table fabric scheduler-map on page 1269
Output Fields	Table 185 on page 1269 describes the output fields for the show class-of-service forwarding-table fabric scheduler-map command. Output fields are listed in the approximate order in which they appear.

Table 185: show class-of-service forwarding-table fabric scheduler-map Output Fields

Field Name	Field Description
Fabric priority	Fabric traffic priority: low and high .
Scheduler index	Index of the scheduler applied to a fabric traffic priority.
PLP high	Drop profile index for high-packet-loss-priority (PLP) packets.
PLP low	Drop profile index for low-PLP packets.
TCP PLP high	Drop profile index for low-PLP and Transmission Control Protocol (TCP) packets.
TCP PLP low	Drop profile index for high-PLP and TCP packets.

Sample Output

```

show class-of-service forwarding-table fabric scheduler-map
user@host> show class-of-service forwarding-table fabric scheduler-map
Fabric priority: low
  Scheduler index: 60211
    PLP high: 44321, PLP low: 44321, TCP PLP high: 44321, TCP PLP low: 44321

Fabric priority: high
  Scheduler index: 60211
    PLP high: 44321, PLP low: 44321, TCP PLP high: 44321, TCP PLP low: 44321

```


show class-of-service forwarding-table loss-priority-map

Syntax	show class-of-service forwarding-table loss-priority-map
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series routers only) Display the mapping of code point value to loss priority as it exists in the forwarding table.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table loss-priority-map on page 1271
Output Fields	Table 186 on page 1271 describes the output fields for the show class-of-service forwarding-table loss-priority-map command. Output fields are listed in the approximate order in which they appear.

Table 186: show class-of-service forwarding-table loss-priority-map Output Fields

Field Name	Field Description
Loss priority map table index	Loss priority map table index.
Entries	Number of table entries.
Table type	Table type: Frame-Relay DE .
Entry #	Table entry number.
Code point	Code point value.
PLP	Packet loss priority value. For most platforms, the value is 0 or 1. For some platforms, the value is 0, 1, 2, or 3. The value 0 represents low PLP. The value 1 represents high PLP. The value 2 represents medium-low PLP. The value 3 represents medium-high PLP.

Sample Output

```

show class-of-service forwarding-table loss-priority-map
user@host> show class-of-service forwarding-table loss-priority-map
loss-priority-map table index: 2212, # entries: 2, Table type: Frame-Relay DE
Entry #   Code point   PLP
  0         0         2
  1         1         3

loss-priority-map table index: 11038, # entries: 2, Table type: Frame-Relay DE
Entry #   Code point   PLP

```

0	0	3
1	1	1

show class-of-service forwarding-table loss-priority-map mapping

Syntax	show class-of-service forwarding-table loss-priority-map mapping
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series Services Routers only) For each logical interface, display the loss priority table index.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table loss-priority-map mapping on page 1273
Output Fields	Table 187 on page 1273 describes the output fields for the show class-of-service forwarding-table loss-priority-map mapping command. Output fields are listed in the approximate order in which they appear.

Table 187: show class-of-service forwarding-table loss-priority-map mapping Output Fields

Field Name	Field Description
Interface	Name of the logical interface.
Index	Logical interface index.
Table index	Loss priority table index.
Table type	Table type: Frame-Relay DE .

Sample Output

```

show class-of-service forwarding-table loss-priority-map mapping
user@host> show class-of-service forwarding-table loss-priority-map mapping
Interface      Index  Table index  Table type
fe-0/0/0.0     67     11038        Frame-Relay DE
tl-0/0/2.0     69     2212         Frame-Relay DE

```

show class-of-service forwarding-table rewrite-rule

Syntax	show class-of-service forwarding-table rewrite-rule
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display mapping of queue number and loss priority to code point value for each rewrite rule as it exists in the forwarding table.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table rewrite-rule on page 1274
Output Fields	Table 188 on page 1274 describes the output fields for the show class-of-service forwarding-table rewrite-rule command. Output fields are listed in the approximate order in which they appear.

Table 188: show class-of-service forwarding-table rewrite-rule Output Fields

Field Name	Field Description
Rewrite table index	Index for this rewrite rule.
# entries	Number of entries in this rewrite rule.
Table type	Type of table: DSCP , EXP (not on the QFX Series), EXP-PUSH-3 (not on the QFX Series), EXP-SWAP-PUSH-2 (J Series routers only), IEEE 802.1, IPv4 precedence (not on the QFX Series), IPv6 DSCP (not on the QFX Series), or Fixed .
Q#	Queue number to which this entry is assigned.
Low bits	Code point value for low-priority loss profile.
State	State of this code point: enabled , rewritten , or disabled .
High bits	Code point value for high-priority loss profile.

Sample Output

```

show class-of-service forwarding-table rewrite-rule
user@host> show class-of-service forwarding-table rewrite-rule
Rewrite table index: 3753, # entries: 4, Table type: DSCP
Q#      Low bits  State      High bits  State
0       000111   Enabled    001010     Enabled
2       000000   Disabled    001100     Enabled

```

1	101110	Enabled	110111	Enabled
3	110000	Enabled	111000	Enabled

show class-of-service forwarding-table rewrite-rule mapping

Syntax	show class-of-service forwarding-table rewrite-rule mapping
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	For each logical interface, display the table identifier of the rewrite rule map for each code point type.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table rewrite-rule mapping on page 1276
Output Fields	Table 189 on page 1276 describes the output fields for the show class-of-service forwarding-table rewrite-rule mapping command. Output fields are listed in the approximate order in which they appear.

Table 189: show class-of-service forwarding-table rewrite-rule mapping Output Fields

Field Name	Field Description
Interface	Name of the logical interface.
Index	Logical interface index.
Table index	Rewrite table index.
Type	Type of classifier: DSCP , EXP (not on the QFX Series), EXP-PUSH-3 (not on the QFX Series), EXP-SWAP-PUSH-2 (not on the QFX Series), Frame-Relay DE (J Series routers only), IEEE 802.1 , IPv4 precedence (not on the QFX Series), IPv6 DSCP (not on the QFX Series), or Fixed .

Sample Output

```

show class-of-service forwarding-table rewrite-rule mapping
user@host> show class-of-service forwarding-table rewrite-rule mapping
Interface      Index  Table index  Type
so-5/0/0.0     10     3753         DSCP
so-0/1/0.0     11     3753         DSCP
so-0/2/0.0     12     3753         DSCP
so-0/2/1.0     13     3753         DSCP
so-0/2/2.0     14     3753         DSCP
so-0/2/3.0     15     3753         DSCP

```

show class-of-service forwarding-table scheduler-map

Syntax	show class-of-service forwarding-table scheduler-map
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	For each physical interface, display the scheduler map information as it exists in the forwarding table.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service forwarding-table scheduler-map on page 1278
Output Fields	Table 190 on page 1277 describes the output fields for the show class-of-service forwarding-table scheduler-map command. Output fields are listed in the approximate order in which they appear.

Table 190: show class-of-service forwarding-table scheduler-map Output Fields

Field Name	Field Description
Interface	Name of the physical interface.
Index	Physical interface index.
Map index	Scheduler map index.
Num of queues	Number of queues defined in this scheduler map.
Entry	Number of this entry in the scheduler map.
Scheduler index	Scheduler policy index.
Forwarding-class #	Forwarding class number to which this entry is applied.
Tx rate	Configured transmit rate of the scheduler (in bps). The rate is a percentage of the total interface bandwidth, or the keyword remainder , which indicates that the scheduler receives the remaining bandwidth of the interface.
Max buffer delay	Amount of transmit delay (in milliseconds) or buffer size of the queue. This amount is a percentage of the total interface buffer allocation or the keyword remainder , which indicates that the buffer is sized according to what remains after other scheduler buffer allocations.
High priority is set	If this line appears in the output, the queue priority is high. Otherwise, it is low.
PLP high	Drop profile index for a high packet loss priority profile.

Table 190: show class-of-service forwarding-table scheduler-map Output Fields (*continued*)

Field Name	Field Description
PLP low	Drop profile index for a low packet loss priority profile.
PLP medium-high	Drop profile index for a medium-high packet loss priority profile.
PLP medium-low	Drop profile index for a medium-low packet loss priority profile.
TCP PLP high	Drop profile index for a high TCP packet loss priority profile.
TCP PLP low	Drop profile index for a low TCP packet loss priority profile.
Policy is exact	If this line appears in the output, exact rate limiting is enabled. Otherwise, no rate limiting is enabled.

Sample Output

```

show class-of-service forwarding-table scheduler-map
user@host> show class-of-service forwarding-table scheduler-map
Interface: so-5/0/0 (Index: 9, Map index: 17638, Num of queues: 2):
  Entry 0 (Scheduler index: 6090, Forwarding-class #: 0):
    Tx rate: 0 Kb (30%), Max buffer delay: 39 bytes (0%)
    Priority low
    PLP high: 25393, PLP low: 24627, TCP PLP high: 25393, TCP PLP low: 8742
    Policy is exact
  Entry 1 (Scheduler index: 38372, Forwarding-class #: 1):
    Traffic chunk: Max = 0 bytes, Min = 0 bytes
    Tx rate: 0 Kb (40%), Max buffer delay: 68 bytes (0%)
    Priority high
    PLP high: 25393, PLP low: 24627, TCP PLP high: 25393, TCP PLP low: 8742

Interface: at-6/1/0 (Index: 10, Map index: 17638, Num of queues: 2):
  Entry 0 (Scheduler index: 6090, Forwarding-class #: 0):
    Traffic chunk: Max = 0 bytes, Min = 0 bytes
    Tx rate: 0 Kb (30%), Max buffer delay: 39 bytes (0%)
    Priority high
    PLP high: 25393, PLP low: 24627, TCP PLP high: 25393, TCP PLP low: 8742
  Entry 1 (Scheduler index: 38372, Forwarding-class #: 1):
    Traffic chunk: Max = 0 bytes, Min = 0 bytes
    Tx rate: 0 Kb (40%), Max buffer delay: 68 bytes (0%)
    Priority low
    PLP high: 25393, PLP low: 24627, TCP PLP high: 25393, TCP PLP low: 8742

```

show class-of-service fragmentation-map

Syntax	show class-of-service fragmentation-map
Release Information	Command introduced in Junos OS Release 7.5.
Description	For Adaptive Services (AS) PIC link services IQ interfaces (lsq) only, display fragmentation properties for specific forwarding classes.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show class-of-service fragmentation-map on page 1279
Output Fields	Table 191 on page 1279 describes the output fields for the show class-of-service fragmentation-map command. Output fields are listed in the approximate order in which they appear.

Table 191: show class-of-service fragmentation-map Output Fields

Field Name	Field Description
Fragmentation map	Name of the class of service (CoS) fragmentation map.
Index	Index number of the CoS fragmentation map.
Forwarding class	Name of the associated forwarding class.
Fragmentation threshold	Maximum size of each multilink fragment.
No Fragmentation	Packets of this class are not fragmented.
Multilink Class	For multilink multiclass PPP only, the multilink class number corresponding to the forwarding class.

Sample Output

```

show class-of-service fragmentation-map
user@host> show class-of-service fragmentation-map
  Fragmentation map: fragmap2, Index: 19801
    Forwarding class: fcDefault
    No Fragmentation

  Forwarding class: fcCopper
    Fragmentation threshold: 64, Multilink Class: 1

  Forwarding class: fcSilver
    Fragmentation threshold: 100, Multilink Class: 0

  Forwarding class: fcCritical
    Fragmentation threshold: 64, Multilink Class: 0

```

Fragmentation map: fragmap, Index: 23147
Forwarding class: fcDefault
No Fragmentation

Forwarding class: fcSilver
Fragmentation threshold: 100

Forwarding class: fcCritical
Fragmentation threshold: 100

show class-of-service interface

Syntax	<code>show class-of-service interface</code> <code><interface-name></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches. Forwarding class map information added in Junos OS Release 9.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the logical and physical interface associations for the classifier, rewrite rules, and scheduler map objects.
Options	<code>none</code> —Display class-of-service (CoS) associations for all physical and logical interfaces. <code>interface-name</code> —(Optional) Display CoS associations for the specified interface.
Required Privilege Level	view
List of Sample Output	<code>show class-of-service interface (Physical)</code> on page 1282 <code>show class-of-service interface (Logical)</code> on page 1282 <code>show class-of-service interface (Gigabit Ethernet)</code> on page 1283
Output Fields	Table 192 on page 1281 describes the output fields for the <code>show class-of-service interface</code> command. Output fields are listed in the approximate order in which they appear.

Table 192: show class-of-service interface Output Fields

Field Name	Field Description
Physical interface	Name of a physical interface.
Index	Index of this interface or the internal index of this object.
Dedicated Queues	Status of dedicated queues configured on an interface. Supported on Trio MPC/MIC interfaces on MX Series routers only.
Queues supported	Number of queues you can configure on the interface.
Queues in use	Number of queues currently configured.
Total non-default queues created	Number of queues created in addition to the default queues. Supported on Trio MPC/MIC interfaces on MX Series routers.
Shaping rate	Maximum transmission rate on the physical interface. You can configure the shaping rate on the physical interface, or on the logical interface, but not both. Therefore, the Shaping rate field is displayed for the physical interface or the logical interface, but not both.
Scheduler map	Name of the output scheduler map associated with this interface.
Input shaping rate	For Gigabit Ethernet IQ2 PICs, maximum transmission rate on the input interface.

Table 192: show class-of-service interface Output Fields (*continued*)

Field Name	Field Description
Input scheduler map	For Gigabit Ethernet IQ2 PICs, name of the input scheduler map associated with this interface.
Chassis scheduler map	Name of the scheduler map associated with the packet forwarding component queues.
Rewrite	Name and type of the rewrite rules associated with this interface.
Classifier	Name and type of classifiers associated with this interface.
Forwarding-class-map	Name of the forwarding map associated with this interface.
Congestion-notification	Congestion notification state, enabled or disabled (QFX Series only).
Logical interface	Name of a logical interface.
Shaping rate	Maximum transmission rate on the logical interface. You can configure the shaping rate on the physical interface, or on the logical interface, but not both. Therefore, the Shaping rate field is displayed for the physical interface or the logical interface, but not both.
Object	Category of an object: Classifier , Fragmentation-map (for LSQ interfaces only), Scheduler-map , Rewrite , or Translation Table (for IQE PICs only).
Name	Name of an object.
Type	Type of an object: dscp , dscp-ipv6 , exp , ieee-802.1 , ip , or inet-precedence .

Sample Output

```

user@host> show class-of-service interface so-0/2/3
show class-of-service interface (Physical) Physical interface: so-0/2/3, Index: 135
Queues supported: 8, Queues in use: 4
Total non-default queues created: 4
Scheduler map: <default>, Index: 2032638653

Logical interface: fe-0/0/1.0, Index: 68, Dedicated Queues: no
Shaping rate: 32000
Object      Name      Type
Index
Scheduler-map  <default>
27
Rewrite      exp-default  exp
21
Classifier    exp-default  exp
5
Classifier    ipprec-compatibility  ip
8
Forwarding-class-map  exp-default  exp
5

user@host> show class-of-service interface so-0/2/3.0
show class-of-service interface (Logical) Logical interface: so-0/2/3.0, Index: 68, Dedicated Queues: no
Shaping rate: 32000

```

Object Index	Name	Type
Scheduler-map	<default>	
27		
Rewrite	exp-default	exp
21		
Classifier	exp-default	exp
5		
Classifier	ipprec-compatibility	ip
8		
Forwarding-class-map	exp-default	exp
5		

```

show class-of-service user@host> show class-of-service interface ge-6/2/0
interface Physical interface: ge-6/2/0, Index: 175
(Gigabit Ethernet) Queues supported: 4, Queues in use: 4
Scheduler map: <default>, Index: 2
Input scheduler map: <default>, Index: 3
Chassis scheduler map: <default-chassis>, Index: 4

```

show class-of-service interface-set

Syntax	show class-of-service interface-set <i><interface-set-name></i>
Release Information	Command introduced in Junos OS Release 9.4.
Description	Display the configured shaping rate and the adjusted shaping rate for each logical interface set configured for hierarchical class of service (CoS).
Options	none—Display CoS associations for all logical interface sets. <i>interface-set-name</i> —(Optional) Display CoS associations for the specified interface set.
Required Privilege Level	view
List of Sample Output	show class-of-service interface-set on page 1285
Output Fields	Table 193 on page 1284 describes the output fields for the show class-of-service interface-set command. Output fields are listed in the approximate order in which they appear.

Table 193: show class-of-service interface-set Output Fields

Field Name	Field Description
Interface-set	Name of a logical interface set composed of one or more logical interfaces for which hierarchical scheduling is enabled.
Index	Index of this interface set or the internal index of this object.
Physical interface	Name of a physical interface.
Queues supported	Number of queues you can configure on the interface.
Queues in use	Number of queues currently configured.
Output traffic control profile	Name of the output traffic-control profile attached to the logical interface set.
Adjusting application	<p>Name of the application that communicates shaping-rate adjustment information to the Junos class-of-service process (cosd) on the broadband services router (BSR). The BSR uses the information from this application to perform shaping-rate adjustments on the scheduler node that manages the interface set. The adjusting application can be one of the following:</p> <p>ancp LS-0—Junos Access Node Control Profile process (ancpd) that performs shaping-rate adjustments on schedule nodes that are logical interface sets configured to represent subscriber local loops. When the synchronization speed of the DSL line changes, ancpd communicates the local loop speed to cosd over the default logical system, LS-0, and then the BSR throttles the shaping rate on the scheduler node to the loop speed.</p>

Table 193: show class-of-service interface-set Output Fields (*continued*)

Field Name	Field Description
Adjustment type	Type of shaping-rate adjustment performed by the BSR on the scheduler node. The type of adjustment can be one of the following: absolute—The configured shaping rate is adjusted by an absolute value as opposed to by a percentage of the configured rate.
Configured shaping rate	The maximum transmission rate on the physical interface as configured by the output traffic-control profile attached to the scheduler node.
Adjustment value	Value of the shaping-rate adjustment information sent by the adjusting application to cosd .

Sample Output

```

show class-of-service user@host> show class-of-service interface-set example-ifset-ge-4/0/0-7
interface-set          Interface-set: example-ifset-ge-4/0/0-7, Index: 8
                        Physical interface: ge-4/0/0, Index: 270
                        Queues supported: 8, Queues in use: 8
                        Output traffic control profile: example-tcp-basic-rate, Index: 11395
                        Adjusting application: ancp LS-0
                        Adjustment type: absolute
                        Configured shaping rate: 50000000
                        Adjustment value: 888000

```

show class-of-service loss-priority-map

Syntax	show class-of-service loss-priority-map <name <i>name</i> > <type frame-relay-de>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series Services Router only) Display mapping of code point value to loss priority.
Options	<p>none—Display all loss priority maps.</p> <p>name <i>name</i>—(Optional) Display the specified loss priority map.</p> <p>type frame-relay-de—(Optional) Display Frame Relay discard eligible code point.</p>
Required Privilege Level	view
List of Sample Output	show class-of-service loss-priority-map on page 1286
Output Fields	Table 194 on page 1286 describes the output fields for the show class-of-service loss-priority-map command. Output fields are listed in the approximate order in which they appear.

Table 194: show class-of-service loss-priority-map Output Fields

Field Name	Field Description
Loss-priority-map	Name of the loss priority map.
Code point type	Type: frame-relay-de.
Index	Internal index.
Code point	Code point value.
Loss priority	Loss priority of low, medium-low, medium-high, or high.

Sample Output

```

user@host> show class-of-service loss-priority-map
Loss-priority-map: frame-relay-de-default, Code point type: frame-relay-de, Index:
9
  Code point      Loss priority
  0               low
  1               high

Loss-priority-map: bar, Code point type: frame-relay-de, Index: 2212
  Code point      Loss priority
  0               medium-low
  1               medium-high

```

```
Loss-priority-map: abc, Code point type: frame-relay-de, Index: 11038
  Code point      Loss priority
  0               medium-high
  1               high
```

show class-of-service rewrite-rule

Syntax	show class-of-service rewrite-rule <name <i>name</i> > <type <i>type</i> >
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the mapping of forwarding classes and loss priority to code point values.
Options	<p>none—Display all rewrite rules.</p> <p>name <i>name</i>—(Optional) Display the specified rewrite rule.</p> <p>type <i>type</i>—(Optional) Display the rewrite rule of the specified type. The rewrite rule type can be one of the following:</p> <ul style="list-style-type: none"> • dscp—For IPv4 traffic. • dscp-ipv6—For IPv6 traffic. • exp—For MPLS traffic. • frame-relay-de—(J Series routers only) For Frame Relay traffic. • ieee-802.1—For Layer 2 traffic. • inet-precedence—For IPv4 traffic.
Required Privilege Level	view
List of Sample Output	<p>show class-of-service rewrite-rule type dscp on page 1289</p> <p>show class-of-service rewrite-rule type dscp (QFX Series) on page 1289</p>
Output Fields	Table 195 on page 1288 describes the output fields for the show class-of-service rewrite-rule command. Output fields are listed in the approximate order in which they appear.

Table 195: show class-of-service rewrite-rule Output Fields

Field Name	Field Description
Rewrite rule	Name of the rewrite rule.
Code point type	Type of rewrite rule: dscp , dscp-ipv6 , exp , frame-relay-de , or inet-precedence .
Forwarding class	Classification of a packet affecting the forwarding, scheduling, and marking policies applied as the packet transits the router or switch.
Index	Internal index for this particular rewrite rule.
Loss priority	Loss priority for rewriting.

Table 195: show class-of-service rewrite-rule Output Fields (*continued*)

Field Name	Field Description
Code point	Code point value to rewrite.

Sample Output

```

show class-of-service user@host> show class-of-service rewrite-rule type dscp
rewrite-rule type dscp Rewrite rule: dscp-default, Code point type: dscp
  Forwarding class      Loss priority      Code point
  gold                  high              000000
  silver                low               110000
  silver                high              111000
  bronze                low               001010
  bronze                high              001100
  lead                  high              101110

Rewrite rule: abc-dscp-rewrite, Code point type: dscp, Index: 3245
Forwarding class      Loss priority      Code point
  gold                  low               000111
  gold                  high              001010
  silver                low               110000
  silver                high              111000
  bronze                high              001100
  lead                  low               101110
  lead                  high              110111

```

Sample Output

```

show class-of-service user@host> show class-of-service rewrite-rule type dscp
rewrite-rule type dscp Rewrite rule: dscp-default, Code point type: dscp, Index: 31
(QFX Series)  Forwarding class      Loss priority      Code point
  best-effort      low               000000
  best-effort      high              000000
  fcoe              low               101110
  fcoe              high              101110
  no-loss           low               001010
  no-loss           high              001100
  newclass          low               110000
  newclass          high              111000

```

show class-of-service routing-instance

Syntax	<code>show class-of-service routing-instance</code> <code><routing-instance-name></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M Series and T Series routers only) Display mapping of class of service (CoS) objects to routing instances.
Options	<i>routing-instance-name</i> —(Optional) Name of a routing instance.
Required Privilege Level	view
List of Sample Output	show class-of-service routing-instance on page 1290
Output Fields	Table 196 on page 1290 describes the output fields for the show class-of-service routing-instance command. Output fields are listed in the approximate order in which they appear.

Table 196: show class-of-service routing-instance Output Fields

Field Name	Field Description
Index	Internal index.
Name	Name of an object.
Object	Category of an object: Classifier .
Routing instance	Name of a routing instance.
Type	Type: exp .

Sample Output

```

user@host> show class-of-service routing-instance
Routing Instance : vpn1
  Object      Name      Type      Index
  Classifier  exp-default exp        8

Routing Instance : vpn2
  Object      Name      Type      Index
  Classifier  test2     exp       57507

```

show class-of-service scheduler-map

Syntax	show class-of-service scheduler-map <name>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	Display the mapping of schedulers to forwarding classes and a summary of scheduler parameters for each entry.
Options	none—Display all scheduler maps. name—(Optional) Display a summary of scheduler parameters for each forwarding class to which the named scheduler is assigned.
Required Privilege Level	view
List of Sample Output	show class-of-service scheduler-map on page 1292
Output Fields	Table 197 on page 1291 describes the output fields for the show class-of-service scheduler-map command. Output fields are listed in the approximate order in which they appear.

Table 197: show class-of-service scheduler-map Output Fields

Field Name	Field Description
Scheduler map	Name of the scheduler map.
Index	Index of the indicated object. Objects having indexes in this output include scheduler maps, schedulers, and drop profiles.
Scheduler	Name of the scheduler.
Forwarding class	Classification of a packet affecting the forwarding, scheduling, and marking policies applied as the packet transits the router.
Transmit rate	Configured transmit rate of the scheduler (in bps). The rate is a percentage of the total interface bandwidth, or the keyword remainder , which indicates that the scheduler receives the remaining bandwidth of the interface.
Rate Limit	Rate limiting configuration of the queue. Possible values are none , meaning no rate limiting, and exact , meaning the queue only transmits at the configured rate.
Maximum buffer delay	Amount of transmit delay (in milliseconds) or the buffer size of the queue. The buffer size is shown as a percentage of the total interface buffer allocation, or by the keyword remainder to indicate that the buffer is sized according to what remains after other scheduler buffer allocations.
Priority	Scheduling priority: low or high .

Table 197: show class-of-service scheduler-map Output Fields (*continued*)

Field Name	Field Description
Drop profiles	Table displaying the assignment of drop profile by name and index to a given loss priority and protocol pair.
Loss priority	Packet loss priority for drop profile assignment.
Protocol	Transport protocol for drop profile assignment.
Name	Name of the drop profile.

Sample Output

```

show class-of-service scheduler-map user@host> show class-of-service scheduler-map
Scheduler map: dd-scheduler-map, Index: 84

Scheduler: aa-scheduler, Index: 8721, Forwarding class: aa-forwarding-class
Transmit rate: 30 percent, Rate Limit: none, Maximum buffer delay: 39 ms,
Priority: high
Drop profiles:
  Loss priority  Protocol  Index  Name
  Low           non-TCP   8724   aa-drop-profile
  Low           TCP       9874   bb-drop-profile
  High          non-TCP   8833   cc-drop-profile
  High          TCP       8484   dd-drop-profile

Scheduler: bb-scheduler, Forwarding class: aa-forwarding-class
Transmit rate: 40 percent, Rate limit: none, Maximum buffer delay: 68 ms,
Priority: high
Drop profiles:
  Loss priority  Protocol  Index  Name
  Low           non-TCP   8724   aa-drop-profile
  Low           TCP       9874   bb-drop-profile
  High          non-TCP   8833   cc-drop-profile
  High          TCP       8484   dd-drop-profile

```

show class-of-service traffic-control-profile

Syntax	show class-of-service traffic-control-profile <profile-name>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	For Gigabit Ethernet IQ, Channelized IQ PICs, EQ DPCs, and Trio MPC/MIC interfaces only, display traffic shaping and scheduling profiles.
Options	none—Display all profiles. profile-name—(Optional) Display information about a single profile.
Required Privilege Level	view
List of Sample Output	show class-of-service traffic-control-profile on page 1294
Output Fields	Table 198 on page 1293 describes the output fields for the show class-of-service traffic-control-profile command. Output fields are listed in the approximate order in which they appear.

Table 198: show class-of-service traffic-control-profile Output Fields

Field Name	Field Description
Traffic control profile	Name of the traffic-control profile.
Index	Index number of the traffic-control profile.
Shaping rate	Configured shaping rate, in bps.
Shaping rate priority high	Configured shaping rate for high-priority traffic, in bps
Shaping rate priority medium	Configured shaping rate for medium-priority traffic, in bps
Shaping rate priority low	Configured shaping rate for low-priority traffic, in bps
Shaping rate excess high	Configured shaping rate for high-priority excess traffic, in bps
Shaping rate excess low	Configured shaping rate for low-priority excess traffic, in bps
Scheduler map	Name of the associated scheduler map.
Delay Buffer rate	Configured delay-buffer rate, in bps.
Excess rate	Configured excess rate, in percent or proportion.

Table 198: show class-of-service traffic-control-profile Output Fields (*continued*)

Field Name	Field Description
Guaranteed rate	Configured guaranteed rate, in bps.
Overhead accounting mode	Configured shaping mode, either frame-mode or cell-mode .
Overhead bytes	Configured byte adjustment value.

Sample Output

```
show class-of-service traffic-control-profile user@host> show class-of-service traffic-control-profile
Traffic control profile: Profile1, Index: 57625
  Scheduler map: m1
  Delay Buffer rate: 500000
  Guaranteed rate: 1000000

Traffic control profile: Profile2, Index: 57624
  Scheduler map: m2
  Delay Buffer rate: 600000
  Guaranteed rate: 2000000

Traffic control profile: Profile3, Index: 57627
  Scheduler map: m3
  Delay Buffer rate: 800000
  Guaranteed rate: 3000000

Traffic control profile: Profile4, Index: 57626
  Scheduler map: m4
  Delay Buffer rate: 750000
  Guaranteed rate: 4000000
```

show class-of-service translation-table

Syntax	<pre>show class-of-service translation-table <name translation-table-name> <type (to-dscp-from-dscp to-dscp-ipv6-from-dscp-ipv6 to-exp-from-exp to-inet-precedence-from-inet-precedence)></pre>
Release Information	Command introduced in Junos OS Release 9.3 for IQE PICs.
Description	Display the mapping of class-of-service (CoS) translation table code points to corresponding bit patterns.
Options	<p>none—Display translation table code points for all translation tables.</p> <p>name—(Optional) Display information for the named translation table.</p> <p>type—(Optional) Display information for a certain translation table type:</p> <ul style="list-style-type: none"> to-dscp-from-dscp—Display DSCP translation table information. to-dscp-ipv6-from-dscp-ipv6—Display DSCP IPv6 translation table information. to-exp-from-exp—Display MPLS EXP translation table information. to-inet-precedence-from-intet-precedence—Display Internet precedence translation table information.
Required Privilege Level	view
List of Sample Output	<p>show class-of-service translation-table on page 1296</p> <p>show class-of-service translation-table name exp-trans-table on page 1297</p> <p>show class-of-service translation-table type to-dscp-ipv6-from-dscp-ipv6 on page 1297</p>
Output Fields	Table 199 on page 1295 describes the output fields for the show class-of-service translation-table command. Output fields are listed in the approximate order in which they appear.

Table 199: show class-of-service translation-table Output Fields

Field Name	Field Description
Translation Table	Name of the translation table.
Translation table type	Name of the translation table.
Index	Internal index number of the translation table.
From Code Point	Value of code point received.
To Code Point	Value of translated code point.

Sample Output

```

show class-of-service user@host> show class-of-service translation-table
translation-table
Translation Table: inet-trans-table, Translation table type: inet-to-inet, Index:
61075
  From Code point    To Code Point
  000                101
  001                111
  010                101
  011                111
  100                101
  101                101
  110                001
  111                000

Translation Table: dscp-trans-table, Translation table type: dscp-to-dscp, Index:
6761
  From Code point    To Code Point
  000000            000111
  000001            000111
  000010            000111
  000011            000111
  000100            000111
  000101            000111
  000110            000111
  000111            111000
  001000            000111
  001001            000111
  001010            000111
  001011            000111
  001100            000111
  001101            000111
  001110            000111
  001111            000111
  010000            000111
  010001            000111
  010010            000111
  010011            000111
  010100            000111
  010101            000111
  010110            000111
  010111            000111
  011000            000111
  011001            000111
  011010            000111
  011011            000111
  011100            000111
  011101            000111
  011110            000111
  011111            000111
  100000            000111
  100001            000111
  100010            000111
  100011            000111
  100100            000111
  100101            000111
  100110            000111
  100111            111000
  101000            000111
  101001            000111
  101010            000111

```


101011	000111
101100	000111
101101	000111
101110	000111
101111	000111
110000	000111
110001	000111
110010	000111
110011	000111
110100	000111
110101	000111
110110	000111
110111	000111
111000	000111
111001	000111
111010	000111
111011	000111
111100	000111
111101	000111
111110	000001
111111	000000

```

show class-of-service user@host> show class-of-service translation-table name exp-trans-table
translation-table name Translation Table: exp-trans-table, Translation table type: exp-to-exp, Index:
exp-trans-table 9048
                  From Code point    To Code Point
                  000                101
                  001                111
                  010                101
                  011                111
                  100                101
                  101                101
                  110                001
                  111                000

```

```

show class-of-service user@host> show class-of-service translation-table type to-dscp-ipv6-from-dscp-ipv6
translation-table type Translation Table: dscp-ipv6-trans-table, Translation table type:
to-dscp-ipv6-from-dscp-ipv6 dscp-ipv6-to-dscp-ipv6, Index: 64704
                           From Code point    To Code Point
                           000000            000111
                           000001            000111
                           000010            000111
                           000011            000111
                           000100            000111
                           000101            000111
                           000110            000111
                           000111            111000
                           001000            000111
                           001001            000111
                           001010            000111
                           001011            000111
                           001100            000111
                           001101            000111
                           001110            000111
                           001111            000111
                           010000            000111
                           010001            000111
                           010010            000111
                           010011            000111
                           010100            000111

```

010101	000111
010110	000111
010111	000111
011000	000111
011001	000111
011010	000111
011011	000111
011100	000111
011101	000111
011110	000111
011111	000111
100000	000111
100001	000111
100010	000111
100011	000111
100100	000111
100101	000111
100110	000111
100111	111000
101000	000111
101001	000111
101010	000111
101011	000111
101100	000111
101101	000111
101110	000111
101111	000111
110000	000111
110001	000111
110010	000111
110011	000111
110100	000111
110101	000111
110110	000111
110111	000111
111000	000111
111001	000111
111010	000111
111011	000111
111100	000111
111101	000111
111110	000001
111111	000000

show class-of-service virtual-channel

- Syntax

show class-of-service virtual channel
 <virtual-channel-name>
- Release Information

Command introduced before Junos OS Release 7.4.
- Description

(J Series Services Router only) Display virtual channel information.
- Options

none—Display all virtual channels.

virtual-channel-name—(Optional) Display the specified virtual channel only.
- Required Privilege Level

view
- List of Sample Output

show class-of-service virtual-channel on page 1299
- Output Fields

Table 200 on page 1299 describes the output fields for the **show class-of-service virtual-channel** command. Output fields are listed in the approximate order in which they appear.

Table 200: show class-of-service virtual-channel Output Fields

Field Name	Field Description
Virtual channel	Name of a virtual channel.
Index	Internal index.

Sample Output

show class-of-service virtual-channel

user@host> show class-of-service virtual-channel
Virtual channel: vc-1, Index: 1
Virtual channel: vc-2, Index: 2

show class-of-service virtual-channel-group

Syntax	show class-of-service virtual channel group <virtual-channel-group-name>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(J Series Services Router only) Display virtual channel group information.
Options	none—Display all virtual channel groups. virtual-channel-group-name—(Optional) Display the specified virtual channel group only.
Required Privilege Level	view
List of Sample Output	show class-of-service virtual-channel-group on page 1300
Output Fields	Table 201 on page 1300 describes the output fields for the show class-of-service virtual-channel-group command. Output fields are listed in the approximate order in which they appear.

Table 201: show class-of-service virtual-channel-group Output Fields

Field Name	Field Description
Virtual channel group	Name of a virtual channel group.
Index	Internal index.

Sample Output

```
show class-of-service virtual-channel-group user@host> show class-of-service virtual-channel-group
Virtual channel group: vc-gp, Index: 16321
    Virtual channel: vc-1
        Scheduler map: sc-map
        Shaping rate : 100 percent
```

PART 4

Services

- Generic Services Operational Mode Commands on page 1303
- Border Signaling Gateway Operational Mode Commands on page 1313
- Compressed Real-Time Transport Protocol Operational Mode Commands on page 1355
- CoS Services Operational Mode Commands on page 1363
- Data Link Switching Operational Mode Commands on page 1369
- Diameter Base Protocol Operational Mode Commands on page 1383
- Distributed Denial-of-Service Protection Operational Mode Commands on page 1425
- Dynamic Application Awareness Operational Mode Commands on page 1459
- Flow Collection and Monitoring Operational Mode Commands on page 1479
- Intrusion Detection Service Operational Mode Commands on page 1543
- IP Security Operational Mode Commands on page 1557
- Layer 2 Tunneling Protocol Operational Mode Commands on page 1633
- Link Services Operational Mode Commands on page 1671
- Mobile IP Operational Mode Commands on page 1677
- Network Address Translation Operational Mode Commands on page 1689
- PGCP Operational Mode Commands for the BGF Feature on page 1695
- PTSP Operational Mode Commands on page 1747
- Service Sets Operational Mode Commands on page 1761
- Softwire Operational Mode Commands on page 1779
- Stateful Firewall Operational Mode Commands on page 1783

CHAPTER 16

Generic Services Operational Mode Commands

Table 202 on page 1303 summarizes the generic command-line interface (CLI) commands you can use with services. Commands are listed in alphabetical order.

Table 202: Generic Services Operational Mode Commands

Task	Command
Clear flow session table entries.	clear services flows
Display flow session table entries.	show services flows

clear services flows

Syntax clear services flows
 <application-protocol *protocol*>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <interface *interface-name*>
 <ip-action>
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>

Release Information Command introduced in Junos OS Release 9.5.
 ip-action option introduced in Junos OS Release 10.0.
 application-protocol option introduced in Junos OS Release 11.1.

Description Clear flow session table entries.

Options none—Clear all flows.

application-protocol—(Optional) Clear flows for one of the following application protocols:

- **bootp**—Bootstrap protocol
- **dce-rpc**—Distributed Computing Environment-Remote Procedure Call protocols
- **dce-rpc-portmap**—Distributed Computing Environment-Remote Procedure Call protocols portmap service
- **dns**—Domain Name System protocol
- **exec**—Exec
- **ftp**—File Transfer Protocol
- **h323**—H.323 standards
- **icmp**—Internet Control Message Protocol
- **iiop**—Internet Inter-ORB Protocol
- **login**—Login
- **netbios**—NetBIOS
- **netshow**—NetShow
- **pptp**—Point-to-Point Tunneling Protocol
- **realaudio**—RealAudio
- **rpc**—Remote Procedure Call protocol
- **rpc-portmap**—Remote Procedure Call protocol portmap service
- **rtsp**—Real-Time Streaming Protocol
- **shell**—Shell

- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet
- **talk**—Talk Program
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

destination-port *destination-port*—(Optional) Clear flows for a particular destination port. The range of values is from 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Clear flows for a particular destination prefix.

interface *interface-name*—(Optional) Clear flows for a particular interface. On M Series and T Series routers, the *interface-name* can be *ms-fpc/pic/port* or *rspnumber*. On J Series routers, the *interface-name* is *ms-pim/O/port*.

ip-action—(Optional) Clear **ip-action** entries generated by the router to log, drop, or block traffic based on previous matches. The IP action options and targets are configured at the **[edit security idp idp-policy *policy-name* rulebase-ips rule *rule-name* then]** hierarchy level.

protocol—(Optional) Clear flows for one of the following IP types:

- **number**—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **icmp6**—Internet Control Message Protocol version 6
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-over-IP Encapsulation Protocol
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Transmission Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

`service-set service-set`—(Optional) Clear flows for a particular service set.

`source-port source-port`—(Optional) Clear flows for a particular source port. The range of values is from 0 through 65535.

`source-prefix source-prefix`—(Optional) Clear flows for a particular source prefix.

Required Privilege Level

clear

Related Documentation

- [show services flows on page 1307](#)

List of Sample Output

[clear services flows on page 1306](#)
[clear services flows ip-action on page 1306](#)

Output Fields

Table 203 on page 1306 lists the output fields for the **clear services flows** command. Output fields are listed in the approximate order in which they appear.

Table 203: clear services flows Output Fields

Field Name	Field Description
Interface	Name of an interface.
Service set	Name of the service set from which flows are being cleared.
Flows removed	Number of flows removed.

Sample Output

```
clear services flows user@host> clear services flows
Interface  Service set      Flows removed
ms-2/0/0   IDP                1

clear services flows ip-action user@host> clear services flows ip-action
Interface  Service set      Flows removed
ms-4/0/0   idp-service      1
```

show services flows

Syntax	<pre>show services flows <all brief extensive terse> <application-protocol <i>protocol</i>> <count> <destination-port <i>destination-port</i>> <destination-prefix <i>destination-prefix</i>> <interface <i>interface-name</i>> <limit <i>number</i>> <protocol <i>protocol</i>> <service-set <i>service-set</i>> <source-port <i>source-port</i>> <source-prefix <i>source-prefix</i>></pre>
Release Information	<p>Command introduced in Junos OS Release 9.5.</p> <p>all option introduced in Junos OS Release 11.1.</p> <p>application-protocol option introduced in Junos OS Release 11.1.</p>
Description	Display flow session table entries.
Options	<p>none—Display standard information about all flows.</p> <p>all brief extensive terse—(Optional) Display the specified level of output.</p> <p>application-protocol—(Optional) Display information about one of the following application protocols:</p> <ul style="list-style-type: none"> • bootp—Bootstrap protocol • dce-rpc—Distributed Computing Environment-Remote Procedure Call protocols • dce-rpc-portmap—Distributed Computing Environment-Remote Procedure Call protocols portmap service • dns—Domain Name System protocol • exec—Exec • ftp—File Transfer Protocol • h323—H.323 standards • icmp—Internet Control Message Protocol • iiop—Internet Inter-ORB Protocol • login—Login • netbios—NetBIOS • netshow—NetShow • pptp—Point-to-Point Tunneling Protocol • realaudio—RealAudio • rpc—Remote Procedure Call protocol

- **rpc-portmap**—Remote Procedure Call protocol portmap service
- **rtsp**—Real-Time Streaming Protocol
- **shell**—Shell
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet
- **talk**—Talk Program
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame



NOTE: The flows for the DCE RPC ALG match the flows for the DCE RPC Portmap ALG. The flows for the RPC ALG match the flows for the RPC Portmap ALG.

count—(Optional) Display a count of the matching entries.

destination-port *destination-port*—(Optional) Display information for a particular destination port. The range of values is from 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Display information for a particular destination prefix.

interface *interface-name*—(Optional) Display information about a particular interface. On M Series and T Series routers, *interface-name* can be **ms-fpc/pic/port** or **rspnumber**. On J Series routers, *interface-name* is **ms-pim/O/port**.

limit *number*—(Optional) Maximum number of entries to display.

protocol *protocol*—(Optional) Display information about one of the following IP types:

- **number**—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **icmp6**—Internet Control Message Protocol version 6
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol

- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Transmission Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Display information for a particular service set.

source-port *source-port*—(Optional) Display information for a particular source port. The range of values is from 0 to 65535.

source-prefix *source-prefix*—(Optional) Display information for a particular source prefix.

Required Privilege Level

view

Related Documentation

- [clear services flows on page 1304](#)

List of Sample Output

[show services flows on page 1310](#)
[show services flows all on page 1310](#)
[show services flows brief on page 1311](#)
[show services flows extensive on page 1311](#)
[show services flows application-protocol on page 1311](#)
[show services flows count on page 1311](#)
[show services flows destination port on page 1311](#)
[show services flows destination prefix on page 1311](#)
[show services flows interface on page 1312](#)
[show services flows protocol on page 1312](#)
[show services flows service-set on page 1312](#)
[show services flows source port on page 1312](#)
[show services flows source prefix on page 1312](#)

Output Fields

Table 204 on page 1309 lists the output fields for the **show services flows** command. Output fields are listed in the approximate order in which they appear.

Table 204: show services flows Output Fields

Field Name	Field Description	Level of Output
Interface	Name of the interface.	All levels
Service set	Name of a service set. Individual empty service sets are not displayed. If no service set has any flows, a flow table header is displayed for each service set.	All levels
Flow Count	Number of flows in a session.	count only

Table 204: show services flows Output Fields (*continued*)

Field Name	Field Description	Level of Output
Flow or Flow Prot	Protocol used for this flow.	All levels
Source	Source prefix of the flow in the format <i>source-prefix:port</i> . For ICMP flows, port information is not displayed.	All levels
Dest	Destination prefix of the flow. For ICMP flows, port information is not displayed.	All levels
State	Status of the flow: <ul style="list-style-type: none"> • Drop—Drop all packets in the flow without response. • Forward—Forward the packet in the flow without looking at it. • Reject—Drop all packets in the flow with response. • Watch—Inspect packets in the flow. 	All levels
Dir	Direction of the flow: input (I) or output (O).	All levels
Frm count	Number of frames in the flow.	All levels
Byte count	Number of bytes in the flow.	extensive
Flow role	Flow role.	extensive
Timeout	Timeout value.	extensive
Flow path	Flow path: symmetric or asymmetric.	extensive

Sample Output

show services flows

```

user@host> show services flows
Interface: ms-2/0/0, Service set: IDP
Flow
TCP      10.2.2.2:33656 -> 10.1.1.2:80    Forward I      6
TCP      10.1.1.2:80   -> 10.2.2.2:33656 Forward O      5
ICMP     10.1.1.2       -> 10.2.2.2       Forward I     102
ICMP     10.2.2.2       -> 10.1.1.2       Forward O     102
ICMP     10.2.2.2       -> 10.1.1.2       Forward I      97
ICMP     10.1.1.2       -> 10.2.2.2       Forward O      97

```

show services flows all

```

user@host> show services flows all
Interface: ms-2/0/0, Service set: idp-1
Flow
TCP      10.1.1.2:32769 -> 20.1.1.2:80    Forward I    353431
TCP      20.1.1.2:80   -> 10.1.1.2:32769 Forward O    353429
TCP      10.1.1.2:32771 -> 20.1.1.2:80    Forward I    353562
TCP      20.1.1.2:80   -> 10.1.1.2:32771 Forward O    353560
TCP      10.1.1.2:32770 -> 20.1.1.2:80    Forward I    353577
TCP      20.1.1.2:80   -> 10.1.1.2:32770 Forward O    353575
TCP      10.1.1.2:32768 -> 20.1.1.2:80    Forward I    353610

```

TCP	20.1.1.2:80	->	10.1.1.2:32768	Forward	0	353608
TCP	10.1.1.2:32777	->	20.1.1.2:80	Forward	I	353625
TCP	20.1.1.2:80	->	10.1.1.2:32777	Forward	0	353624
TCP	10.1.1.2:32776	->	20.1.1.2:80	Forward	I	353643
TCP	20.1.1.2:80	->	10.1.1.2:32776	Forward	0	353642
TCP	10.1.1.2:32775	->	20.1.1.2:80	Forward	I	353658
TCP	20.1.1.2:80	->	10.1.1.2:32775	Forward	0	353657
TCP	10.1.1.2:32774	->	20.1.1.2:80	Forward	I	353676
TCP	20.1.1.2:80	->	10.1.1.2:32774	Forward	0	353674
TCP	10.1.1.2:32773	->	20.1.1.2:80	Forward	I	353692
TCP	20.1.1.2:80	->	10.1.1.2:32773	Forward	0	353690
TCP	10.1.1.2:32772	->	20.1.1.2:80	Forward	I	353704
TCP	20.1.1.2:80	->	10.1.1.2:32772	Forward	0	353702

show services flows brief The output for the **show services flows brief** command is identical to that for the **show services flows** command. For sample output, see **show services flows**.

show services flows extensive

```
user@host> show services flows extensive
Interface: ms-2/0/0, Service set: IDP
Flow                                     State  Dir      Frm count
TCP      10.2.2.2:33656 ->      10.1.1.2:80    Forward I           6
  Byte count: 346
  Flow role: Unknown, Timeout: 0, Flow path: Asymmetric
TCP      10.1.1.2:80 ->      10.2.2.2:33656 Forward 0           5
  Byte count: 334
  Flow role: Unknown, Timeout: 0, Flow path: Symmetric
ICMP     10.1.1.2 ->      10.2.2.2      Forward I          144
  Byte count: 12096
  Flow role: Unknown, Timeout: 0, Flow path: Symmetric
ICMP     10.2.2.2 ->      10.1.1.2      Forward 0          144
  Byte count: 12096
  Flow role: Unknown, Timeout: 0, Flow path: Symmetric
```

show services flows application-protocol

```
user@router> show services flows application-protocol dce-rpc
Interface: ms-2/0/0, Service set: ss-1
Flow                                     State  Dir      Frm count
TCP      192.168.200.65:1260 -> 192.168.200.69:5315 Forward I          14
TCP      192.168.200.69:5315 ->  16.16.16.16:1031 Forward 0           11
TCP      192.168.200.65:1251 -> 192.168.200.69:1026 Forward I           7
TCP      192.168.200.69:1026 ->  16.16.16.16:1029 Forward 0           5
```

show services flows count

```
user@host> show services flows count
Interface  Service set      Flow count
ms-2/0/0   IDP              6
```

show services flows destination port

```
user@router> show services flows destination-port 80
Interface: ms-2/0/0, Service set: IDP
Flow                                     State  Dir      Frm count
TCP      10.2.2.2:33656 ->      10.1.1.2:80    Forward I           6
```

show services flows destination prefix

```
user@router> show services flows destination-prefix 10.1.1.2
Interface: ms-2/0/0, Service set: IDP
Flow                                     State  Dir      Frm count
TCP      10.2.2.2:33656 ->      10.1.1.2:80    Forward I           6
ICMP     10.2.2.2 ->      10.1.1.2      Forward 0          137
ICMP     10.2.2.2 ->      10.1.1.2      Forward I          132
```

```

show services flows user@router> show services flows interface ms-2/0/0
interface Interface: ms-2/0/0, Service set: IDP
Flow
TCP      10.2.2.2:33656 -> 10.1.1.2:80 Forward I Frm count
TCP      10.1.1.2:80 -> 10.2.2.2:33656 Forward 0 5
ICMP     10.1.1.2 -> 10.2.2.2 Forward I 162
ICMP     10.2.2.2 -> 10.1.1.2 Forward 0 162
ICMP     10.2.2.2 -> 10.1.1.2 Forward I 157
ICMP     10.1.1.2 -> 10.2.2.2 Forward 0 157

show services flows user@router> show services flows protocol icmp
protocol Interface: ms-2/0/0, Service set: IDP
Flow
ICMP     10.1.1.2 -> 10.2.2.2 Forward I 202
ICMP     10.2.2.2 -> 10.1.1.2 Forward 0 202
ICMP     10.2.2.2 -> 10.1.1.2 Forward I 197
ICMP     10.1.1.2 -> 10.2.2.2 Forward 0 197

show services flows user@router> show services flows service-set sample
service-set Interface: ms-2/0/0, Service set: sample
Flow
TCP      10.2.2.2:33656 -> 10.1.1.2:80 Forward I 6
TCP      10.1.1.2:80 -> 10.2.2.2:33656 Forward 0 5
ICMP     10.1.1.2 -> 10.2.2.2 Forward I 220
ICMP     10.2.2.2 -> 10.1.1.2 Forward 0 220
ICMP     10.2.2.2 -> 10.1.1.2 Forward I 215
ICMP     10.1.1.2 -> 10.2.2.2 Forward 0 215

show services flows user@router> show services flows source-port 0
source port Interface: ms-2/0/0, Service set: IDP
Flow
TCP      10.2.2.2:33656 -> 10.1.1.2:80 Forward I 6
TCP      10.1.1.2:80 -> 10.2.2.2:33656 Forward 0 5
ICMP     10.1.1.2 -> 10.2.2.2 Forward I 235
ICMP     10.2.2.2 -> 10.1.1.2 Forward 0 235
ICMP     10.2.2.2 -> 10.1.1.2 Forward I 230
ICMP     10.1.1.2 -> 10.2.2.2 Forward 0 230

show services flows user@router> show services flows source-prefix 10.2.2.2
source prefix Interface: ms-2/0/0, Service set: IDP
Flow
TCP      10.2.2.2:33656 -> 10.1.1.2:80 Forward I 6
TCP      10.1.1.2:80 -> 10.2.2.2:33656 Forward 0 5
ICMP     10.1.1.2 -> 10.2.2.2 Forward I 235
ICMP     10.2.2.2 -> 10.1.1.2 Forward 0 235
ICMP     10.2.2.2 -> 10.1.1.2 Forward I 230
ICMP     10.1.1.2 -> 10.2.2.2 Forward 0 230

```


Border Signaling Gateway Operational Mode Commands

Table 205 on page 1313 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot border signaling gateway operations.

Table 205: Border Signaling Gateway Operational Mode Commands

Task	Command
Clear entries in the denied messages log.	<code>clear services border-signaling-gateway denied-messages</code>
Clear entries in the name resolution cache.	<code>clear services border-signaling-gateway name-resolution-cache</code>
Clear registration statistics.	<code>clear services border-signaling-gateway registrations statistics</code>
Clear subscriber registrations.	<code>clear services border-signaling-gateway registrations subscription</code>
Clear border signaling gateway statistical counters.	<code>clear services border-signaling-gateway statistics</code>
Show address bindings for registered subscribers.	<code>show services border-signaling-gateway address-of-record bindings</code>
Display border signaling gateway admission control information.	<code>show services border-signaling-gateway admission-control</code>
Display border signaling gateway processing statistics for a given contact.	<code>show services border-signaling-gateway by-contact</code>
Display border signaling gateway processing statistics for a given request Uniform Resource Identifier (URI).	<code>show services border-signaling-gateway by-request-uri</code>
Display border signaling gateway processing statistics for all calls grouped by server or for a selected server.	<code>show services border-signaling-gateway calls by-server</code>

Table 205: Border Signaling Gateway Operational Mode Commands (*continued*)

Task	Command
Display border signaling gateway processing statistics for all calls grouped by service point or for a selected service point.	show services border-signaling-gateway calls by-service-point
Display a histogram of call durations for the border signaling gateway group by server or for a selected server.	show services border-signaling-gateway calls-duration by-server
Display a histogram of call durations for the border signaling gateway group by service point or for a selected service point.	show services border-signaling-gateway calls-duration by-service-point
Display border signaling gateway processing statistics for failed calls grouped by server or for a selected server.	show services border-signaling-gateway calls-failed by-server
Display border signaling gateway processing statistics for failed calls grouped by service point or for a selected service point.	show services border-signaling-gateway calls-failed by-service-point
Display border signaling gateway denied messages information.	show services border-signaling-gateway denied-messages
Display entries in the border signaling gateway name resolution cache.	show services border-signaling-gateway name-resolution-cache
Display registrations information.	show services border-signaling-gateway registrations
Display routing blacklist information.	show services border-signaling-gateway routing-blacklist
Display border signaling gateway high availability, B2BUA, and SIP stack status.	show services border-signaling-gateway status

clear services border-signaling-gateway denied-messsages

Syntax	clear services border-signaling-gateway denied-messsages gateway gateway <backup master>
Release Information	Command introduced in Junos OS Release 9.4.
Description	This command clears border signaling gateway (BSG) denied messages information for the specified gateway and updates the last reset date and time.
Options	gateway gateway —The BSG for which denied messages information is to be cleared. backup master —(Optional) Clear denied messages information for the backup BSG or for the master BSG. If you do not specify an option, the master option is the default.
Required Privilege Level	view
List of Sample Output	clear services border-signaling-gateway gateway statistics on page 1315
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services	user@host> clear services border-signaling-gateway statistics
border-signaling-gateway	Last Reset 2008 12 18 06:00
gateway statistics	

clear services border-signaling-gateway name-resolution-cache

Syntax	<code>clear services border-signaling-gateway name-resolution-cache (all by-fqdn <i>fqdn</i>) gateway <i>gateway-name</i> <backup master></code>
Release Information	Command introduced in Junos OS Release 10.0.
Description	Clear entries in the Domain Name System (DNS) name resolution cache.
Options	<p><code>all</code>—Clear all entries in the name resolution cache.</p> <p><code>by-fqdn <i>fqdn</i></code>—Clear cache entries for a specific fully qualified domain name (FQDN).</p> <p><code>gateway <i>gateway-name</i></code>—Clear cache entries associated with this border signalling gateway (BSG).</p> <p><code>backup</code>—(Optional) Clear cache entries for the backup BSG.</p> <p><code>master</code>—(Optional) Clear cache entries for the master BSG. If you do not specify the <code>master</code> or <code>backup</code> option, the <code>master</code> option is the default.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show services border-signaling-gateway name-resolution-cache on page 1347
List of Sample Output	clear services border-signaling-gateway name-resolution-cache on page 1316
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>clear services border-signaling-gateway name-resolution-cache</code>	<code>user@host> clear services border-signaling-gateway name-resolution-cache all gateway bsg-1</code>
--	--

clear services border-signaling-gateway registrations statistics

Syntax	<code>clear services border-signaling-gateway registrations statistics gateway <i>gateway-name</i> <backup master></code>
Description	Clear registration statistics for the BSG.
Options	<p><code>gateway <i>gateway-name</i></code>—Clear registration statistics associated with this border signalling gateway (BSG).</p> <p><code>backup</code>—(Optional) Clear registration statistics for the backup BSG.</p> <p><code>master</code>—(Optional) Clear registration statistics for the master BSG. If you do not specify the <code>master</code> or <code>backup</code> option, the <code>master</code> option is the default.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear services border-signaling-gateway registrations subscription on page 1318 • show services border-signaling-gateway registrations on page 1349
List of Sample Output	clear services border-signaling-gateway registration statistics on page 1317
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services      user@host> clear services border-signaling-gateway registration statistics gateway bsg-1
border-signaling-gateway
registration statistics
```

clear services border-signaling-gateway registrations subscription

Syntax	<code>clear services border-signaling-gateway registrations statistics gateway <i>gateway-name</i></code> <code>all [<i>AOR</i></code> <code>graceful forceful</code> <code><backup master></code>
Description	Clear subscriber registration AOR mapping from the BSG and, optionally, send unregister messages to the Registrar.
Options	<p><code>all</code>—Clear AOR mapping for all subscriber AORs .</p> <p><code>AOR</code>—Clear AOR mapping for this subscriber AOR only.</p> <p><code>forceful</code>—Do not send unregister messages to the Registrar.</p> <p><code>graceful</code>—Send information to the registrar.</p> <p><code>gateway-name</code>—Clear information for this BSG.</p> <p><code>backup</code>—(Optional) Clear information for the backup BSG.</p> <p><code>master</code>—(Optional) Clear information for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view

clear services border-signaling-gateway statistics

Syntax	<code>clear services border-signaling-gateway gateway <i>gateway</i> statistics</code> <code><backup master></code>
Release Information	Command introduced in Junos OS Release 9.4.
Description	This command clears a border signaling gateway (BSG) statistics for the specified gateway.
Options	<p><i>gateway-name</i>—The BSG for which statistics are to be cleared.</p> <p>backup—(Optional) Clear statistics for the backup BSG.</p> <p>master—(Optional) Clear statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	clear services border-signaling-gateway gateway statistics on page 1319
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services      user@host> clear services border-signaling-gateway statistics
border-signaling-gateway
gateway statistics
```

show services border-signaling-gateway address-of-record bindings

Syntax	<code>show services border-signaling-gateway address-of-record bindings gateway <i>gateway-name</i></code> <code> all</code> <code><summary detail></code> <code><backup master></code>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display subscriber registration information based on the subscriber's address-of-record (AOR) information for the BSG.
Options	<p><code>all</code>—Show information for all subscribers.</p> <p>—Show information for this subscriber.</p> <p><code>summary</code>—Show summary information only for this AOR (subscriber).</p> <p><code>detail</code>—Show detailed information for a specified AOR.</p> <p><code>gateway-name</code>—Show information for this BSG.</p> <p><code>backup</code>—(Optional) Show information for the backup BSG.</p> <p><code>master</code>—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	<p><code>show services border-signaling-gateway address-of-record bindings summary</code> on page 1321</p> <p><code>show services border-signaling-gateway address-of-record bindings detailed</code> on page 1321</p> <p><code>show services border-signaling-gateway address-of-record bindings all detailed</code> on page 1321</p>
Output Fields	Table 206 on page 1320 lists the output fields for the show services border-signaling-gateway address-of-record bindings command. Output fields are listed in the approximate order in which they appear.

Table 206: show services border-signaling-gateway address-of-record bindings Output Fields

Field Name	Field Description	Level of Output
bindings	Subscriber registrations.	
URI	The URI of a unique subscriber registration.	summary detail
Registered from Realm	The signaling realm from which the subscriber registered.	summary detail
First registration time	The first time a subscriber registered from this URI.	detail

Table 206: show services border-signaling-gateway address-of-record bindings Output Fields (*continued*)

Field Name	Field Description	Level of Output
Last registration time	The most recent time a subscriber registered from this URI.	detail
Expiration time	The duration, in seconds, of a period of time during which the subscriber does not re-register from this URI, after which the subscriber's registration expires.	detail
Registered from sp	The service point from which the subscriber registered.	summary detail
Translated URI	The translated (local or hidden) URI that the BSG uses.	detail
Has active call	The active call indicator.	detail

Sample Output

```

show services border-signaling-gateway address-of-record bindings summary
user@host> show services border-signaling-gateway address-of-record bindings
alice@atlanta.com gateway bsg1 summary
address-of-record: alice@atlanta.com
bindings:
  URI : alice@pc33.atlanta.com
  Registered from Realm : atlanta.com
  Registered from sp : ms-1/0/0

  URI : alice@wonderland.com
  Registered from Realm : wonderland.com
  Registered from sp : ms-1/0/0

```

```

show services border-signaling-gateway address-of-record bindings detailed
user@host> show services border-signaling-gateway address-of-record bindings
alice@atlanta.com gateway bsg1 summary detail
address-of-record: alice@atlanta.com
  URI : alice@pc33.atlanta.com
  Registered from Realm : atlanta.com
  First registration time: 22/4/2009 17:24
  Last registration time : 27/4/2009 7:35
  Expiration time : 300s
  Registered from sp : ms-1/0/0
  Translated URI : alice-LU
  Has active call : Yes

  URI : alice@wonderland.com
  Registered from Realm : wonderland.com
  First registration time: 12/5/2009 00:24
  Last registration time : 19/5/2009 8:35
  Expiration time : 270s
  Registered from sp : ms-1/0/0
  Translated URI : alice-LU2
  Has active call : No

```

```

show services border-signaling-gateway
user@host> show services border-signaling-gateway address-of-record bindings all gateway
bsg1 summary detail
address-of-record: alice@atlanta.com
  URI : alice@pc33.atlanta.com

```

**address-of-record
bindings all detailed**

```
Registered from Realm : atlanta.com
First registration time: 22/4/2009 17:24
Last registration time : 27/4/2009 7:35
Expiration time       : 300s
Registered from sp    : ms-1/0/0
Translated URI        : alice-LU
Has active call       : Yes

URI                  : alice@wonderland.com
Registered from Realm : wonderland.com
First registration time: 12/5/2009 00:24
Last registration time : 19/5/2009 8:35
Expiration time       : 270s
Registered from sp    : ms-1/0/0
Translated URI        : alice-LU2
Has active call       : No
```

address-of-record: bob@builder.com

```
URI                  : bob@the.builder.com
Registered from Realm : builder.com
First registration time: 1/5/2009 00:24
Last registration time : 1/5/2009 8:35
Expiration time       : 30s
Registered from sp    : ms-1/0/0
Translated URI        : bob-LU
Has active call       : Yes
```

show services border-signaling-gateway admission-control

Syntax	<code>show services border-signaling-gateway admission-control gateway <i>gateway-name</i> <backup master></code>
Release Information	Command introduced in Junos OS Release 9.5.
Description	Display border signaling gateway (BSG) Call Admission Control (CAC) information.
Options	<p><i>gateway-name</i>—Display information about each CAC controller associated with this BSG.</p> <p><code>backup</code>—(Optional) Show statistics for the backup BSG.</p> <p><code>master</code>—(Optional) Show statistics for the primary BSG. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway admission-control on page 1324
Output Fields	Table 207 on page 1323 lists the output fields for the show services border-signaling-gateway admission-control command. Output fields are listed in the approximate order in which they appear.

Table 207: show services border-signaling-gateway admission-control Output Fields

Field Name	Field Description
Admission controller	The admission controller for which statistics are displayed.
Dialogs	<p>Information on CAC for dialogs, including the following:</p> <ul style="list-style-type: none"> • Active—Active dialogs shown as a percentage of CAC maximum concurrent dialogs, the number of active dialogs and the CAC maximum for concurrent dialogs. • Events handled—Number of events handled. • Attempts rejected due to concurrent exception—Number of attempts rejected because they exceeded the maximum concurrent dialogs limit. • Attempts rejected due to rate exception—Number of attempts rejected because they exceeded the maximum rate for admission of dialogs per second.
Transactions	<p>Information on CAC for transactions, including the following:</p> <ul style="list-style-type: none"> • Active—Active transactions shown as a percentage of CAC maximum concurrent transactions, the number of active transactions and the CAC maximum for concurrent transactions. • Events handled—Number of events handled. • Attempts rejected due to concurrent exception—Number of attempts rejected because they exceeded the maximum concurrent transactions limit. • Attempts rejected due to rate exception—Number of attempts rejected because they exceeded the maximum rate for admission of transactions per second.

Sample Output

```
show services user@host> show services border-signaling-gateway admission-control gateway bsg1
border-signaling-gateway Admission controller: Controller1
admission-control Dialogs
Active: 2% (20 out of 1000 allowed)
Attempts handled: 5500
Attempts rejected due to concurrent exception: 2
Attempts rejected due to rate exception: 4
Transactions
Active: 0% (10 out of 50000 allowed)
Attempts handled: 20000
Attempts rejected due to concurrent exception: 10
Attempts rejected due to rate exception: 1
```

show services border-signaling-gateway by-contact

Syntax	<code>show services border-signaling-gateway by-contact <contact> (brief detail summary) gateway gateway-name <backup master></code>
Release Information	Command introduced in Junos OS Release 9.4.
Description	Display border signaling gateway (BSG) statistics for active calls for a specific BSG, filtered by contact. Display results for all calls by omitting the variable <i>contact</i> .
Options	<p><i>contact</i>—(Optional) Display information for this contact. When <i>contact</i> is omitted, information is displayed for all calls.</p> <p><i>brief</i>—Display abbreviated information for the specified contact.</p> <p><i>detail</i>—Display a detailed listing of BSG statistics for the specified contact.</p> <p><i>summary</i>—Display only the number of active calls for the contact.</p> <p><i>gateway-name</i>—Display information about statistics associated with this BSG.</p> <p><i>backup</i>—(Optional) Show statistics for the backup BSG.</p> <p><i>master</i>—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	<p><code>show services border-signaling-gateway by-contact brief</code> on page 1326</p> <p><code>show services border-signaling-gateway by-contact detail</code> on page 1326</p>
Output Fields	Table 208 on page 1325 lists the output fields for the <code>show services border-signaling-gateway by-contact</code> command. Output fields are listed in the approximate order in which they appear.

Table 208: show services border-signaling-gateway by-contact Output Fields

Field Name	Field Description	Level of Output
Signaling Source IP	Source IP for signaling.	none brief
Signaling Destination IP	Destination IP for signaling.	none brief
Call ID	Call ID. Each active call is listed by call ID.	none brief
Local URI	Local Uniform Resource Identifier (URI) for the displayed call ID.	detail
Remote URI	Remote URI for the displayed call ID.	detail
Local Tag	Local tag for the displayed call ID.	detail

Table 208: show services border-signaling-gateway by-contact Output Fields (*continued*)

Field Name	Field Description	Level of Output
Remote Tag	Remote tag for the displayed call ID.	detail
Next Hop	Next hop address for the displayed call ID.	detail
Media IP	The IP through which the Real-Time Transport Protocol (RTP) is passed.	detail
Media Port	The port through which the RTP is passed.	detail
Media Status	The status of the media (Enabled or Disabled).	detail
Admission Control Profile	Admission control profiles for this BSG.	detail
Manipulation Rules	Header manipulation rules applied on messages sent toward the user agent server (UAS), or the call recipient, of the transaction and dialog that was matched. A rule is marked [Defunct] if it was changed after it was already applied to a call.	detail

Sample Output

```

show services border-signaling-gateway by-contact brief
user@host> show services border-signaling-gateway by-contact juniper.net brief gateway bsg1
Signaling Source IP      : 172.223.3.22
Signaling Destination IP : 10.2.3.55
Call-ID                  : 65689654
Signaling Source IP      : 172.223.3.22
Signaling Destination IP : 101.21.4.88
Call-ID                  : 321456

```

```

show services border-signaling-gateway by-contact detail
user@host> show services border-signaling-gateway by-contact juniper.net detail gateway bsg1
Signaling Source IP      : 60.100.102.1
Signaling Destination IP : 60.1.7.100
Call-ID                  : 1-3117@60.1.7.100
Local URI                 : 60.100.102.1
Remote URI                : sip:60.1.7.100:5060
Local Tag                 : bsg+1000001+1060000+3a2e567a
Remote Tag                : 1
Next Hop                  : 10.2.3.200
Admission Control Profile : ACProfile1
Manipulation Rules        : ManipulationTowardsPeer1, HM_rule_2 [Defunct]

Media IP                  : 60.1.7.100
Media Port                : 6000
Media Status              : Enabled

```

show services border-signaling-gateway by-request-uri

Syntax	<code>show services border-signaling-gateway by-request-uri <request-uri> (brief detail summary) gateway gateway-name <backup master></code>
Release Information	Command introduced in Junos OS Release 9.4.
Description	Display border signaling gateway (BSG) statistics for active calls for a specific BSG, filtered by Uniform Resource Identifier (URI). Display results for all calls by omitting the variable <i>contact</i> .
Options	<p><i>request-uri</i>—(Optional) Display information for this request URI. When <i>contact</i> is omitted, information is displayed for all calls.</p> <p><i>brief</i>—Display abbreviated information for the request URI.</p> <p><i>detail</i>—Display a detailed listing of BSG statistics for the request URI.</p> <p><i>summary</i>—Display only the number of active calls for the request URI.</p> <p><i>gateway-name</i>—Display information about statistics associated with this VBGF.</p> <p><i>backup</i>—(Optional) Show statistics for the backup BSG.</p> <p><i>master</i>—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	<p><code>show services border-signaling-gateway by-request-uri brief</code> on page 1328</p> <p><code>show services border-signaling-gateway by-request-uri sip:juniper.net detail</code> on page 1328</p>
Output Fields	Table 209 on page 1327 lists the output fields for the <code>show services border-signaling-gateway by-request-uri</code> command. Output fields are listed in the approximate order in which they appear.

Table 209: show services border-signaling-gateway by-request-URI Output Fields

Field Name	Field Description	Level of Output
Signaling Source IP	Source IP for signaling.	none brief
Signaling Destination IP	Destination IP for signaling.	none brief
Call ID	Call ID. Each active call is listed by call ID.	none brief
Local URI	Local URI for the displayed call ID.	detail
Remote URI	Remote URI for the displayed call ID.	detail

Table 209: show services border-signaling-gateway by-request-uri Output Fields (*continued*)

Field Name	Field Description	Level of Output
Local Tag	Local tag for the displayed call ID.	detail
Remote Tag	Remote tag for the displayed call ID.	detail
Next Hop	Next hop address for the displayed call ID.	detail
Media IP	The IP through which the RTP is passed.	detail
Media Port	The port through which the RTP is passed.	detail
Media Status	The status of the media (Enabled or Disabled).	detail
Admission Controller	Admission controllers for this BSG.	detail
Manipulation Rules	Header manipulation rules applied on messages sent toward the user agent server (UAS), or the call recipient, of the transaction and dialog that was matched. A rule is marked [Defunct] if it was changed after it was already applied to a call.	detail

Sample Output

```

show services border-signaling-gateway by-request-uri brief
user@host> show services border-signaling-gateway by-request-uri sip:juniper.net brief gateway
bsg1
  Signaling Source IP      : 172.223.3.22
  Signaling Destination IP : 10.2.3.55
  Call-ID                  : 65689654

  Signaling Source IP      : 172.223.3.22
  Signaling Destination IP : 101.21.4.88
  Call-ID                  : 321456

show services border-signaling-gateway by-request-uri sip:juniper.net detail
user@host> show services border-signaling-gateway by-request-uri sip:juniper.net detail gateway
bsg1
  Signaling Source IP      : 60.100.102.1
  Signaling Destination IP : 60.1.7.100
  Call-ID                  : 1-3117@60.1.7.100
  Local URI                : 60.100.102.1
  Remote URI               : sip:60.1.7.100:5060
  Local Tag                : bsg+1000001+1060000+3a2e567a
  Remote Tag               : 1
  Next Hop                 : 10.2.3.200
  Admission Control Profile : ACProfile1
  Manipulation Rules       : ManipulationTowardsPeer1, HM_rule_2 [Defunct]

  Media IP                 : 60.1.7.100
  Media Port               : 6000

```


Media Status : Enabled

show services border-signaling-gateway calls by-server

Syntax	show services border-signaling-gateway calls by-server <server-name> gateway gateway-name <backup master>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display border signaling gateway (BSG) call statistics grouped by server.
Options	<p><i>server-name</i>—(Optional) String of one or more characters used to select servers for which call statistics are displayed. Results are shown for all servers with names beginning with the specified string. When you omit this option, call statistics are displayed for all servers and grouped by server.</p> <p><i>gateway-name</i>—Name of the gateway for which call statistics are displayed.</p> <p><i>backup</i>—(Optional) Show statistics for the backup BSG.</p> <p><i>master</i>—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway calls by-server on page 1330
Output Fields	Table 210 on page 1330 lists the output fields for the show services border-signaling-gateway statistics calls by-server command. Output fields are listed in the approximate order in which they appear.

Table 210: show services border-signaling-gateway calls by-server Output Fields

Field Name	Field Description
Statistics Start	Date and time when accumulation of the current set of statistics began.
Server	Server for which statistics are displayed.
Failed Calls	Number of failed calls.
Completed Calls	Number of completed calls.
Active Calls	Number of active calls.

Sample Output

```

show services border-signaling-gateway calls by-server
user@host> show services border-signaling-gateway calls by-server gateway bsg1
Statistics start      : 22/2/2010 13:24
Server               : zone-110

```

```
Failed calls      : 0
Active calls      : 0
Completed calls   : 0

Server            : zone-120
Failed calls      : 2
Active calls      : 0
Completed calls   : 0

Server            : zone-130
Failed calls      : 0
Active calls      : 0
Completed calls   : 0

Server            : zone-210
Failed calls      : 0
Active calls      : 0
Completed calls   : 0

Server            : zone-220
Failed calls      : 0
Active calls      : 0
Completed calls   : 0

Server            : zone-230
Failed calls      : 0
Active calls      : 0
Completed calls   : 0
```

show services border-signaling-gateway calls by-service-point

Syntax	show services border-signaling-gateway calls by-service-point <service-point-name> gateway gateway-name <backup master>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display border signaling gateway (BSG) call statistics by service point .
Options	<p><i>service-point-name</i>—(Optional) Name of the service point for which call statistics are displayed. When you omit this option, call statistics are displayed for all service points and grouped by service point.</p> <p><i>gateway-name</i>—Name of the gateway for which call statistics are displayed.</p> <p>backup—(Optional) Show statistics for the backup BSG.</p> <p>master—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway calls by-service-point on page 1333
Output Fields	Table 211 on page 1332 lists the output fields for the show services border-signaling-gateway statistics calls by-service-point command. Output fields are listed in the approximate order in which they appear.

Table 211: show services border-signaling-gateway calls by-service-point Output Fields

Field Name	Field Description
Statistics Start	Date and time when accumulation of the current set of statistics began.
Service point	Service point for which statistics are displayed.
Direction	Direction of calls on this service point. Possible values: <ul style="list-style-type: none"> Egress—Calls are outbound from this service point. Ingress—Calls are inbound to this service point.
Failed Calls	Number of failed calls.
Completed Calls	Number of completed calls.
Active Calls	Number of active calls.

Sample Output

```
show services user@host> show services border-signaling-gateway calls by-service-point gateway bsg1
border-signaling-gateway Statistics start : 02-02-2010 11:38:00.
calls by-service-point

Service point : sip-5060-tcp
Direction : Egress
Failed calls : 0
Active calls : 0
Completed calls : 0

Service point : sip-5060-tcp
Direction : Ingress
Failed calls : 0
Active calls : 0
Completed calls : 0

Service point : sip-5060-udp
Direction : Egress
Failed calls : 2
Active calls : 0
Completed calls : 0

Service point : sip-5060-udp
Direction : Ingress
Failed calls : 2
Active calls : 0
Completed calls : 0
```

show services border-signaling-gateway calls-duration by-server

Syntax	show services border-signaling-gateway calls-duration by-server <server-name> gateway gateway-name <backup master>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display a histogram showing the number of calls, by duration, for a specific BSG since the last time statistics were cleared.
Options	<p><i>server-name</i>—(Optional) String of one or more characters used to select servers for which call duration statistics are displayed. Results are shown for all servers with names beginning with the specified string. When you omit this option, call duration statistics are displayed for all servers and grouped by server.</p> <p><i>gateway-name</i>—Display information about statistics associated with this BSG.</p> <p><i>backup</i>—(Optional) Show statistics for the backup BSG.</p> <p><i>master</i>—(Optional) Show statistics for the primary BSG. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway calls-duration by-server on page 1334
Output Fields	Table 212 on page 1334 lists the output fields for the show services border-signaling-gateway calls-duration by-server command. Output fields are listed in the approximate order in which they appear.

Table 212: show services border-signaling-gateway calls-duration by-serverOutput Fields

Field Name	Field Description	Level of Output
Server	Server for calls shown in the histogram..	none brief
Duration[Min]	Duration category in which calls fall. The first category is "greater than or equal to zero" and "less than 1." The other duration categories are defined similarly.	none brief
Number of Calls	Number of calls in the duration category.	detailed

Sample Output

```

show services border-signaling-gateway calls-duration by-server
user@host> show services border-signaling-gateway calls-duration by-server gateway bsg1
Server                               : zone-110
Duration[Min]      Number of calls
0 - 1              0
1 - 2              0
2 - 3              0

```

3 - 4	0
4 - 5	0
5 - 6	0
6 - 7	0
7 - 8	0
8 - 9	0
9 - 10	0
10 - 11	0
11 - 12	0
12 - 13	0
13 - 14	0
14 - 15	0
15 - 16	0
16 - 17	0
17 - 18	0
18 - 19	0
19 - 20	0
20 - 21	0
21 - 22	0
22 - 23	0
23 - 24	0
24 - 25	0
25 - 26	0
26 - 27	0
27 - 28	0
28 - 29	0
29 - INF	0

Server : zone-120

Duration[Min]	Number of calls
0 - 1	0
1 - 2	0
2 - 3	0
3 - 4	0
4 - 5	0
5 - 6	0
6 - 7	0
7 - 8	0
8 - 9	0
9 - 10	0
10 - 11	0
11 - 12	0
12 - 13	0
13 - 14	0
14 - 15	0
15 - 16	0
16 - 17	0
17 - 18	0
18 - 19	0
19 - 20	0
20 - 21	0
21 - 22	0
22 - 23	0
23 - 24	0
24 - 25	0
25 - 26	0
26 - 27	0
27 - 28	0
28 - 29	0
29 - INF	0

```
Server                               : zone-210

Duration[Min]      Number of calls
0 - 1              0
1 - 2              0
2 - 3              0
3 - 4              0
4 - 5              0
5 - 6              0
6 - 7              0
7 - 8              0
8 - 9              0
9 - 10             0
10 - 11            0
11 - 12            0
12 - 13            0
13 - 14            0
14 - 15            0
15 - 16            0
16 - 17            0
17 - 18            0
18 - 19            0
19 - 20            0
20 - 21            0
21 - 22            0
22 - 23            0
23 - 24            0
24 - 25            0
25 - 26            0
26 - 27            0
27 - 28            0
28 - 29            0
29 - INF           0
```


show services border-signaling-gateway calls-duration by-service-point

Syntax	show services border-signaling-gateway calls-duration by-service-point < <i>service-point-name</i> > <i>gateway gateway-name</i> <backup master>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display histograms for one or more service points showing the number of calls, by duration, for a specific BSG since the last time statistics were cleared.
Options	<p><i>service-point-name</i>—(Optional) Service point for which call duration statistics are displayed. When you omit this option, call duration statistics are displayed for all service points and grouped by service point.</p> <p><i>gateway-name</i>—Display information about statistics associated with this BSG.</p> <p>backup—(Optional) Show statistics for the backup BSG.</p> <p>master—(Optional) Show statistics for the primary BSG. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway calls-duration by-service-point on page 1338
Output Fields	Table 213 on page 1337 lists the output fields for the show services border-signaling-gateway calls-duration by-service-point command. Output fields are listed in the approximate order in which they appear.

Table 213: show services border-signaling-gateway calls-duration by-service-point Output Fields

Field Name	Field Description	Level of Output
Service Point	Service point for calls shown in the histogram.	none brief
Direction	Direction of calls on this service point. Possible values: <ul style="list-style-type: none"> Egress—Calls are outbound from this service point. Ingress—Calls are inbound to this service point. 	none brief
Duration[Min]	Duration category in which calls fall. The first category is “greater than or equal to zero” and “less than 1.” The other duration categories are defined similarly.	none brief
Number of Calls	Number of calls in the duration category.	detailed

Sample Output

```

show services user@host> show services border-signaling-gateway calls-duration by-service-point gateway
border-signaling-gateway bsg1
calls-duration
by-service-point
Statistics start : 02-02-2010 11:38:00.

Service point : sip-5060-tcp
Direction : Egress

Duration[Min]      Number of calls
0 - 1              0
1 - 2              0
2 - 3              0
3 - 4              0
4 - 5              0
5 - 6              0
6 - 7              0
7 - 8              0
8 - 9              0
9 - 10             0
10 - 11            0
11 - 12            0
12 - 13            0
13 - 14            0
14 - 15            0
15 - 16            0
16 - 17            0
17 - 18            0
18 - 19            0
19 - 20            0
20 - 21            0
21 - 22            0
22 - 23            0
23 - 24            0
24 - 25            0
25 - 26            0
26 - 27            0
27 - 28            0
28 - 29            0
29 - INF           0

Service point : sip-5060-tcp
Direction : Ingress

Duration[Min]      Number of calls
0 - 1              0
1 - 2              0
2 - 3              0
3 - 4              0
4 - 5              0
5 - 6              0
6 - 7              0
7 - 8              0
8 - 9              0
9 - 10             0
10 - 11            0
11 - 12            0
12 - 13            0
13 - 14            0
14 - 15            0
15 - 16            0

```

16 - 17	0
17 - 18	0
18 - 19	0
19 - 20	0
20 - 21	0
21 - 22	0
22 - 23	0
23 - 24	0
24 - 25	0
25 - 26	0
26 - 27	0
27 - 28	0
28 - 29	0
29 - INF	0

show services border-signaling-gateway calls-failed by-server

Syntax	<code>show services border-signaling-gateway calls-failed by-server <server-name> gateway gateway-name <backup master></code>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display BSG (border signaling gateway) failed call statistics by server.
Options	<p><i>server-name</i>—(Optional) String of one or more characters used to select servers for which failed call statistics are displayed. Results are shown for all servers with names beginning with the specified string. When you omit this option, failed call statistics are displayed for all servers and grouped by server.</p> <p><i>gateway-name</i>—The gateway for which statistics are displayed.</p> <p><i>backup</i>—(Optional) Show statistics for the backup BSG.</p> <p><i>master</i>—(Optional) Show statistics for the master BSG. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway calls-failed by-server on page 1341
Output Fields	Table 214 on page 1340 lists the output fields for the show services border-signaling-gateway calls-failed by-server command. Output fields are listed in the approximate order in which they appear.

Table 214: show services border-signaling-gateway calls-failed by-server Output Fields

Field Name	Field Description
Statistics Start	Date and time when the accumulation of the current set of statistics began.
Server	Server name.
Protocol error	Number of calls that failed due to protocol errors.
Inactive timeout	Number of calls for which a dialog was closed due to an inactive call timeout violation.
Configured behavior policy rejection	Number of calls that failed due to configured rejection policy.
4/5/6XX response	Number of calls that failed because the call setup failed for reasons other than timeout.
Internal error	Number of calls that failed because the BSG sustained an internal error that terminated one of dialogs comprising a call during setup.
Setup media failure	Number of calls that failed due to a media failure during setup.

Table 214: show services border-signaling-gateway calls-failed-by-server Output Fields (*continued*)

Field Name	Field Description
Established call media inactivity	Number of established calls for which a dialog was closed because the BGF identified media inactivity for the dialog.
CAC policy rejection	Number of calls for which an initial INVITE was rejected due to CAC (call admission control) enforcement.
Default behavior policy rejection	Number of calls for which an initial INVITE was rejected due to no policy match.
Transport conflict policy rejection	Number of calls for which the requested transport on the INVITE conflicts with the transport details of the selected egress service-point.
Setup timeout	Number of calls that failed for one of the following reasons: <ul style="list-style-type: none"> • An INVITE was sent by the BSG and no reply was received. • An INVITE was sent by the BSG, a 1XX was received, and nothing else was received after that. • An INVITE was received by the BSG and nothing else was sent on this open transaction.
Transport error	Number of calls that failed due to a transport error.
Canceled calls	Number of canceled calls.

Sample Output

```

show services border-signaling-gateway calls-failed-by-server user@host> show services border-signaling-gateway calls-failed-by-server gateway bsg1

Statistics start      : 02-02-2010  11:38:00.

Server                : zone-110
Protocol error        : 0
Inactive timeout      : 0
Configured behavior policy rejection : 0
4/5/6XX response      : 0
Internal error        : 0
Setup media failure    : 0
Established call media inactivity : 0
CAC policy rejection   : 0
Default behavior policy rejection : 0
Transport conflict policy rejection : 0
Setup timeout         : 0
Transport error        : 0
Canceled calls        : 0

Server                : zone-120
Protocol error        : 0
Inactive timeout      : 0
Configured behavior policy rejection : 0
4/5/6XX response      : 0
Internal error        : 0
Setup media failure    : 0
Established call media inactivity : 0

```

CAC policy rejection	: 0
Default behavior policy rejection	: 0
Transport conflict policy rejection	: 0
Setup timeout	: 2
Transport error	: 0
Canceled calls	: 0

show services border-signaling-gateway calls-failed-by-service-point

Syntax	<code>show services border-signaling-gateway calls-failed-by-service-point <service-point-name> gateway gateway-name <backup master></code>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display BSG (border signaling gateway) failed call statistics by service point.
Options	<p><i>service-point-name</i>—(Optional) Service point for which failed call statistics are displayed. When you omit this option, failed call statistics are displayed for all service points and grouped by service point.</p> <p><i>gateway-name</i>—The gateway for which statistics are displayed.</p> <p><i>backup</i>—(Optional) Show statistics for the backup BSG.</p> <p><i>master</i>—(Optional) Show statistics for the master BSG. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway calls-failed-by-service-point on page 1344
Output Fields	Table 215 on page 1343 lists the output fields for the show services border-signaling-gateway calls-failed-by-service-point command. Output fields are listed in the approximate order in which they appear.

Table 215: show services border-signaling-gateway calls-failed-by-service-point Output Fields

Field Name	Field Description
Statistics Start	Date and time when the accumulation of the current set of statistics began.
Service Point	Service-point name.
Direction	Direction of calls on this service point. Possible values: <ul style="list-style-type: none"> Egress—Calls are outbound from this service point. Ingress—Calls are inbound to this service point.
Protocol error	Number of calls that failed due to protocol errors.
Inactive timeout	Number of calls for which a dialog was closed due to an inactive call timeout violation.
Configured behavior policy rejection	Number of calls that failed due to configured rejection policy.
4/5/6XX response	Number of calls that failed because the call setup failed for reasons other than timeout.

Table 215: show services border-signaling-gateway calls-failed-by-service-point Output Fields (*continued*)

Field Name	Field Description
Internal error	Number of calls that failed because the BSG sustained an internal error that terminated one of dialogs comprising a call during setup.
Setup media failure	Number of calls that failed due to a media failure during setup.
Established call media inactivity	Number of established calls for which a dialog was closed because the BGF identified media inactivity for the dialog.
CAC policy rejection	Number of calls for which an initial INVITE was rejected due to CAC (call admission control) enforcement.
Default behavior policy rejection	Number of calls for which an initial INVITE was rejected due to no policy match.
Transport conflict policy rejection	Number of calls for which the requested transport on the INVITE conflicts with the transport details of the selected egress service-point.
Setup timeout	Number of calls that failed for one of the following reasons: <ul style="list-style-type: none"> • An INVITE was sent by the BSG and no reply was received. • An INVITE was sent by the BSG, a 1XX was received, and nothing else was received after that. • An INVITE was received by the BSG and nothing else was sent on this open transaction.
Transport error	Number of calls that failed due to a transport error.
Canceled calls	Number of canceled calls.

Sample Output

```

show services user@host> show services border-signaling-gateway calls-failed by-service-point gateway bsg1
border-signaling-gateway
calls-failed
by-service-point
Statistics start      : 02-02-2010  11:38:00.
Service point        : sip-5060-tcp
Direction            : Egress
Protocol error       : 0
Inactive timeout     : 0
Configured behavior policy rejection : 0
4/5/6XX response    : 0
Internal error       : 0
Setup media failure  : 0
Established call media inactivity : 0
CAC policy rejection : 0
Default behavior policy rejection : 0
Transport conflict policy rejection : 0
Setup timeout        : 0
Transport error      : 0
Canceled calls       : 0

Service point        : sip-5060-tcp

```



```
Direction : Ingress
Protocol error : 0
Inactive timeout : 0
Configured behavior policy rejection : 0
4/5/6XX response : 0
Internal error : 0
Setup media failure : 0
Established call media inactivity : 0
CAC policy rejection : 0
Default behavior policy rejection : 0
Transport conflict policy rejection : 0
Setup timeout : 0
Transport error : 0
Canceled calls : 0

Service point : sip-5060-udp
Direction : Egress
Protocol error : 0
Inactive timeout : 0
Configured behavior policy rejection : 0
4/5/6XX response : 0
Internal error : 0
Setup media failure : 0
Established call media inactivity : 0
CAC policy rejection : 0
Default behavior policy rejection : 0
Transport conflict policy rejection : 0
Setup timeout : 2
Transport error : 0
Canceled calls : 0

Service point : sip-5060-udp
Direction : Ingress
Protocol error : 0
Inactive timeout : 0
Configured behavior policy rejection : 0
4/5/6XX response : 0
Internal error : 0
Setup media failure : 0
Established call media inactivity : 0
CAC policy rejection : 0
Default behavior policy rejection : 0
Transport conflict policy rejection : 0
Setup timeout : 2
Transport error : 0
Canceled calls : 0
```

show services border-signaling-gateway denied-messages

Syntax	show services border-signaling-gateway denied-messages gateway <i>gateway-name</i> <backup master>
Release Information	Command introduced in Junos OS Release 9.4.
Description	Display border signaling gateway (BSG) statistics for messages denied due to an overload condition.
Options	<i>gateway-name</i> —Display information about statistics associated with this BSG. backup—(Optional) Show statistics for the backup BSG. master—(Optional) Show statistics for the master BSG. If you do not specify the master or backup options, the master option is the default.
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway denied-messages on page 1346
Output Fields	The logged date and time of each denied message since the last reset of denied message log statistics is shown. A maximum of 10 dropped messages can be displayed.

Sample Output

show services border-signaling-gateway denied-messages	<pre>user@host> show services border-signaling-gateway denied-messages gateway bsg1 Last Reset 2008 12 18 06:00 Last Over Load Drops 1. 2009 10 31 17:43 2. 2009 07 21 09:00</pre>
---	---

show services border-signaling-gateway name-resolution-cache

Syntax	show services border-signaling-gateway name-resolution-cache (all fqdn <i>fqdn</i>) gateway <i>gateway-name</i> <backup master>
Release Information	Command introduced in Junos OS Release 10.0.
Description	Display entries in the name resolution cache.
Options	<p>all—Display all entries in the name resolution cache.</p> <p><i>fqdn fqdn</i>—Display entries for a specific fully qualified domain name (FQDN).</p> <p><i>gateway gateway-name</i>—Display information about the name resolution cache associated with this border signaling gateway (BSG).</p> <p>backup—(Optional) Display information about the name resolution cache associated with the backup BSG.</p> <p>master—(Optional) Display information about the name resolution cache associated with the master BSG. If you do not specify the master or backup option, the master option is the default.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">clear services border-signaling-gateway name-resolution-cache on page 1316
List of Sample Output	show services border-signaling-gateway name-resolution-cache on page 1348
Output Fields	Table 216 on page 1347 lists the output fields for the show services border-signaling-gateway name-resolution-cache command. Output fields are listed in the approximate order in which they appear.

Table 216: show services border-signaling-gateway name-resolution-cache Output Fields

Field Name	Field Description
Name	Name of the SIP server. The value can be a server name or a service record name.
Type	Type of Domain Name System (DNS) record: <ul style="list-style-type: none">A—Address recordsNAPTR—Name authority pointer (NAPTR) recordsSRV—Service records

Table 216: show services border-signaling-gateway name-resolution-cache Output Fields (*continued*)

Field Name	Field Description
RData	Contents of the DNS Record Data field. For A type records, an IP address. For NAPTR records, the FQDN. For SRV type records, a host name.
TTL Expiry	Time to live. Indicates the time in seconds that the server will remain in the cache.
Blacklist Expiry	If the server is on the blacklist, the time in seconds that the server will remain on the blacklist.

Sample Output

```

show services user@host> show services border-signaling-gateway name-resolution-cache by-fqdn
border-signaling-gateway example.com gateway bsg-1
name-resolution-cache

```

Name	Type	RData	TTL Expiry	Blacklist Expiry
sip._udp.example.com	SRV	server1.example.com.	86400	
		server2.example.com.	86400	
		server3.example.com.	86400	
server1.example.com	A	192.168.1.10	43200	
server2.example.com	A	192.168.2.20	86400	300
		192.168.2.21	86400	
server3.example.com	A	192.168.3.30	86400	280

show services border-signaling-gateway registrations

Syntax	show services border-signaling-gateway registrations gateway <i>gateway-name</i> all <i>realm</i> <summary detail> <backup master>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display registration statistics for the BSG.
Options	<i>realm</i> —Show information for this signaling realm. all—Show information for all signaling realms. <i>gateway-name</i> —Show information for this BSG. backup—(Optional) Show information for the backup BSG. master—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway registrations realm on page 1349 show services border-signaling-gateway registrations realm all on page 1350
Output Fields	Table 217 on page 1349 lists the output fields for the show services border-signaling-gateway registrations command. Output fields are listed in the approximate order in which they appear.

Table 217: show services border-signaling-gateway registrations Output Fields

Field Name	Field Description	Level of Output
Statistics start	Date and time statistics accumulation began. This date is refreshed when statistics are cleared.	
Active Registrations	The number of active registrations.	summary detail
	Name of signaling realm (uncaptioned field).	

Sample Output

show services border-signaling-gateway registrations realm	user@host> show services border-signaling-gateway registrations realm atlanta.com gateway bsg1 Statistics Start : 22/4/2009 13:24 Active Registrations : 3344
--	--

```
show services user@host> show services border-signaling-gateway registration realm all gateway
border-signaling-gateway Statistics Start : 22/4/2009 13:24
registrations realm all atlanta.com
                        Active Registrations : 3344

                        biloxi.com
                        Active Registrations : 17000
```

show services border-signaling-gateway routing-blacklist

Syntax	show services border-signaling-gateway routing-blacklist gateway gateway-name <backup master>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display unavailable server information from the routing blacklist.
Options	gateway-name—Name of the gateway for which call statistics are displayed. backup—(Optional) Show statistics for the backup BSG. master—(Optional) Show statistics for the master BSG. If you do not specify the master or backup option, the master option is the default.
Required Privilege Level	view
List of Sample Output	show services border-signaling-gateway routing-blacklist on page 1351
Output Fields	Table 218 on page 1351 lists the output fields for the show services border-signaling-gateway statistics routing-blacklist command. Output fields are listed in the approximate order in which they appear.

Table 218: show services border-signaling-gateway routing-blacklist Output Fields

Field Name	Field Description
last availability	The last time the server responded to an availability check.
next check	The next time the server will be checked for availability.
next availability	For servers that are not checked for availability, the time that the server is scheduled to be removed from the blacklist.

Sample Output

```
show services border-signaling-gateway routing-blacklist
user@host> show services border-signaling-gateway routing-blacklist bsg1
Statistics start      : 22/4/2008 13:24
Servers actively checked for availability:
Florida 1.2.3.4 last availability: 23/8/2009 12:24:21 next check: 23/8/2009
17:31:43
Georgia 5.6.7.8 last availability: 23/8/2009 9:53:09 next check: 23/8/2009
17:32:15

Servers not actively checked for availability:
sip.att.com 10.10.250.17 next availability: 23/8/2009 17:47:02
sip.jnpr.com 62.17.56.28 next availability: 24/8/2009 02:49:51
```

show services border-signaling-gateway status

Syntax	show services border-signaling-gateway status gateway <i>gateway-name</i> <backup master>
Release Information	Command introduced in Junos OS Release 9.10.
Description	Displays status information for the master or backup BSG, B2BUA connection, and SIP stack connection.
Options	<p><i>gateway-name</i>—Name of the gateway for which status is displayed.</p> <p>backup—(Optional) Show status information for the backup BSG.</p> <p>master—(Optional) Show status information for the master BSG. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	<p>show services border-signaling-gateway status on page 1353</p> <p>show services border-signaling-gateway status backup (primary as backup) on page 1353</p>
Output Fields	Table 219 on page 1352 lists the output fields for the show services border-signaling-gateway status command. Output fields are listed in the approximate order in which they appear.

Table 219: show services border-signaling-gateway status Output Fields

Field Name	Field Description
State	<p>Redundancy state of the BSG being displayed. Possible values:</p> <ul style="list-style-type: none"> Master—The BSG is functioning as the master in a partnered pair. Backup—The BSG is functioning as the backup in partnered. Standalone—No backup is configured. The BSG is running in standalone mode. <p>The state displayed is backup only if you specified the backup option in the command.</p>
Local	<p>Information about the local BSG, initially configured as the Master in a partnered pair, including:</p> <ul style="list-style-type: none"> Interface—The name of the service interface for the BSG. IP address—The IP address of the service interface for the BSG. RMS role—The configured role of this BSG. Possible values: <ul style="list-style-type: none"> Primary—The BSG is configured as primary. Secondary—The BSG is configured as secondary.

Table 219: show services border-signaling-gateway status Output Fields (continued)

Field Name	Field Description
Remote	Information about the remote BSG, initially configured as the Backup in a partnered pair, including: <ul style="list-style-type: none">Interface—The name of the interface for the BSG.IP address—The IP address of the interface for the BSG.RMS role—The configured role of this BSG. Possible values:<ul style="list-style-type: none">Primary—The BSG is configured as primary.Primary—The BSG is configured as secondary.
B2BUA Connection	Information about the B2BUA connection, including: <ul style="list-style-type: none">Status—The connection status. Possible values:<ul style="list-style-type: none">ConnectedDisconnectedTCP—Internal routing interface address.
SIP Stack	Information about the SIP stack connection, including: <ul style="list-style-type: none">Status—The connection status. Possible values:<ul style="list-style-type: none">ConnectedDisconnectedTCP—Internal routing interface address.

Sample Output

```
show services border-signaling-gateway status
user@host> show services border-signaling-gateway status gateway bsg1
Redundancy information:
  State: Master
  Local:
    Interface name: ms-0/3/0
    IP address: 20.0.0.19
    RMS role: Primary
  Remote:
    Interface name: ms-1/3/0
    IP address: 20.0.0.35
    RMS role: Secondary
  B2BUA connection:
    Status: Connected
    tcp 20.0.0.19:32024 => 20.0.0.35:50783
  SIP stack connection:
    Status: Connected
    tcp 20.0.0.19:58875 => 20.0.0.35:16386
```

Sample Output

```
show services border-signaling-gateway status backup (primary as backup)
This example shows the primary RMS partner serving as the backup after a switchover.
user@host> show services border-signaling-gateway status gateway bsg1 backup
Redundancy information:
  State: Backup
```

```
Local:
  Interface name: ms-0/3/0
  IP address: 20.0.0.19
  RMS role: Primary
Remote:
  Interface name: ms-1/3/0
  IP address: 20.0.0.35
  RMS role: Secondary
B2BUA connection:
  Status: Connected
  tcp 20.0.0.19:32024 => 20.0.0.35:50783
SIP stack connection:
  Status: Connected
  tcp 20.0.0.19:58875 => 20.0.0.35:16386
```

Compressed Real-Time Transport Protocol Operational Mode Commands

Table 220 on page 1355 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot Compressed Real-Time Transport Protocol (CRTP) services. Commands are listed in alphabetical order.

Table 220: CRTP Operational Mode Commands

Task	Command
Clear CRTP flows statistics.	<code>clear services crtp statistics</code>
Display CRTP output.	<code>show services crtp</code>
Display CRTP flows.	<code>show services crtp flows</code>



NOTE: CRTP is supported on the following interfaces:

- M Series and T Series routers—Link services intelligent queuing (IQ) (`lsq-fpc/pic/port`)
- J Series router—Link services (`ls-pim/0/port`)



NOTE: For information about how to configure CRTP services, see the *Junos OS Services Interfaces Configuration Guide*.

clear services crtp statistics

Syntax	clear services crtp statistics <interface <i>interface-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear Compressed Real-Time Transport Protocol (CRTP) flow statistics.
Options	<p>none—Clear CRTP flow statistics on all interfaces.</p> <p>interface <i>interface-name</i>—(Optional) Clear CRTP flow statistics for the specified interface:</p> <ul style="list-style-type: none">• On M Series and T Series routers, a link services IQ (<i>lsq-fpc/pic/port</i>) or redundant link services IQ (<i>rlsq-fpc/pic/port</i>) interface• On the J Series router, a link services (<i>ls-pim/0/port</i>) interface
Required Privilege Level	view
List of Sample Output	clear services crtp statistics on page 1356
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services crtp statistics	user@host> clear services crtp statistics
--------------------------------	---

show services crtp

Syntax	show services crtp <extensive> <interface <i>interface-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Compressed Real-Time Transport Protocol (CRTP) extensive output.
Options	<p>none—Display CRTP extensive output for all interfaces.</p> <p>extensive—(Optional) Display extensive CRTP information.</p> <p>interface <i>interface-name</i>—(Optional) Display CRTP flow statistics for the specified interface:</p> <ul style="list-style-type: none"> On M Series and T Series routers, a link services IQ (lsq-fpc/pic/port) or redundant link services IQ (rlsq-fpc/pic/port) interface On the J Series router, a link services (ls-pim/0/port) interface
Required Privilege Level	view
List of Sample Output	show services crtp extensive on page 1358
Output Fields	Table 221 on page 1357 lists the output fields for the show services crtp command. Output fields are listed in the approximate order in which they appear.

Table 221: show services crtp Output Fields

Field Name	Field Description
Interface	Name of the physical interface.
Port minimum Port maximum	Compression is applied to UDP packets with even ports in the specified range.
Maximum UDP compressed sessions	Maximum value of a context identifier in the space of context identifiers allocated for UDP.
CRTP maximum period	Maximum interval between full headers. Suggested value is 256.
CRTP maximum time	Maximum time interval between full headers. Suggested value is 5 seconds.
Compression ratio	Ratio of received packet size to compressed packet size, in percentage. For example, if the packet size is 100 bytes when it is received, and is 40 bytes after compression, the compression ratio is $100 \div 40 / 100 * 100 = 60\%$.

Table 221: show services crtp Output Fields (*continued*)

Field Name	Field Description
Decompression ratio	Ratio of received packet size to decompressed packet size, in percentage. For example, if the packet size is 40 bytes when it is received, and is 100 bytes after compression, the decompression ratio is $100 \div 40/100 * 100 = 60\%$.
Discards	Number of frames that the incoming packet match code discarded because they were not recognized.
Sessions	Total number of active CRTP sessions.
IP bytes	Number of IP bytes sent and received.
Compressed bytes	Number of compressed IP header bytes sent and received.
CRTP packets	Number of CRTP packets sent and received.
CUDP/CNTCP packets	Number of compressed UDP packets and compressed non-TCP packets sent and received.
Full header packets	Number of full header packets sent and received. Full header packets communicate the uncompressed IP header plus any following headers and data to establish the uncompressed header state in the decompressor for a particular context.
Context state packet	Number of context state packets sent and received. Context state packets are sent from the decompressor to the compressor to communicate a list of context IDs for which synchronization is lost or might be lost.
IP packets	Number of IP packets sent and received.
Compressed packets	Number of compressed packets sent and received.

Sample Output

**show services crtp
extensive**

```

user@host> show services crtp extensive
Interface: lsq-1/1/0.1
  Port minimum: 2000, Port maximum: 64009
  Maximum UDP compressed sessions: 256
  CRTP maximum period: 256, CRTP maximum time: 5
  Compression ratio: 0, Decompression ratio: 0, Discards: 0
  CRTP stats
    Receive      Transmit
  Sessions           1           1
  IP bytes           60          60
  Compressed bytes   61          60
  CRTP packets       0           0
  CUDP/CNTCP packets 0           0
  Full header packets 1           1
  Context state packets 0           0

```

IP packets	1	1
Compressed packets	1	1

show services crtp flows

Syntax	show services crtp flows <interface <i>interface-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display Compressed Real-Time Transport Protocol (CRTP) flows.
Options	<p>none—Display CRTP flows for all interfaces.</p> <p>interface <i>interface-name</i>—(Optional) Display CRTP flows for the specified interface:</p> <ul style="list-style-type: none"> On M Series and T Series routers, a link services IQ (lsq-fpc/pic/port) or redundant link services IQ (rlsq-fpc/pic/port) interface On the J Series router, a link services (ls-pim/0/port) interface
Required Privilege Level	view
List of Sample Output	show services crtp flows on page 1360
Output Fields	Table 222 on page 1360 lists the output fields for the show services crtp flows command. Output fields are listed in the approximate order in which they appear.

Table 222: show services crtp flows Output Fields

Field Name	Field Description
Interface	Name of the physical interface.
Flow	Received or transmitted flow.
Source	IP source address.
Destination	IP destination address.
SSRC ID	Synchronization source (SSRC) identifier. One of the fields in the RTP header used to select the context. The SSRC identifier is a randomly chosen value unique within a particular CRTP session.
Ctx ID	Session context ID. Indicates the session context in which to interpret the packet. The decompressor can use the context ID to index its table of stored session contexts directly.

Sample Output

```

show services crtp flows user@host> show services crtp flows
Interface: lsq-1/1/0.1
Flow          Source          Destination          SSRC ID  Ctx ID

```


Receive	60.1.1.3:28004	80.1.1.3:26000	123	0
Transmit	80.1.1.3:26000	60.1.1.3:28004	123	2

CoS Services Operational Mode Commands

Table 223 on page 1363 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot class-of-service (CoS) services on the Adaptive Services PIC. Commands are listed in alphabetical order.

Table 223: CoS Services Operational Mode Commands

Task	Command
Clear CoS statistics.	<code>clear services cos statistics</code>
Display CoS statistics.	<code>show services cos statistics</code>



NOTE: CoS services are supported on the adaptive services interface on the following routers:

- J Series—`sp-pim/0/slot`
- M Series and T Series—`sp-fpc/pic/port`

CoS services are also supported on the redundant adaptive services interface (`rspnumber`) on M Series and T Series routers.



NOTE: For information about how to configure CoS services, see the *Junos OS Services Interfaces Configuration Guide*.

clear services cos statistics

Syntax	<code>clear services cos statistics</code> <code><interface <i>interface-name</i>></code> <code><service-set <i>service-set-name</i>></code>
Release Information	Command introduced in Junos OS Release 8.1.
Description	Clear statistics for class-of-service (CoS) code point bit patterns and forwarding classes as configured in CoS services for the AS PIC.
Options	<code>none</code> —Clear all services CoS statistics. <code>interface <i>interface-name</i></code> —(Optional) Clear statistics for the specified interface only. <code>service-set <i>service-set-name</i></code> —(Optional) Clear statistics for the specified service set only.
Required Privilege Level	view
List of Sample Output	clear services cos statistics on page 1364
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services cos    user@host> clear services cos statistics
statistics
```

show services cos statistics

Syntax	<pre>show services cos statistics <brief detail extensive> <diffserv forwarding-class> <interface <i>interface-name</i>> <service-set <i>service-set-name</i>> <summary></pre>
Release Information	Command introduced in Junos OS Release 8.1.
Description	Display the mapping of class-of-service (CoS) code point aliases to corresponding bit patterns and the mapping of forwarding class names to queue numbers as configured in CoS services for the AS PIC.
Options	<p>none—Display all services CoS statistics.</p> <p>brief detail extensive—(Optional) Display the specified level of output.</p> <p>diffserv forwarding-class—(Optional) Display only the selected information, either DiffServ codepoints or forwarding classes.</p> <p>interface <i>interface-name</i>—(Optional) Display statistics for the specified interface only.</p> <p>service-set <i>service-set-name</i>—(Optional) Display statistics for the specified service set only.</p> <p>summary—(Optional) Display summary of statistics on a per-interface basis.</p>
Required Privilege Level	view
List of Sample Output	<p>show services cos statistics on page 1366</p> <p>show services cos statistics brief on page 1367</p> <p>show services cos statistics detail on page 1367</p> <p>show services cos statistics extensive on page 1367</p>
Output Fields	Table 224 on page 1365 describes the output fields for the show services cos statistics command. Output fields are listed in the approximate order in which they appear.

Table 224: show services cos statistics Output Fields

Field Name	Field Description	Level of Output
Interface	Name of interface.	All levels
Service set	Name of service set.	All levels
DSCP	DiffServ code point bit pattern.	All levels
Packets in	Number of packets received.	All levels

Table 224: show services cos statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
Packets out	Number of packets transmitted.	All levels
Forwarding class	Forwarding class queue number.	All levels

Sample Output

```

show services cos statistics user@host> show services cos statistics
Interface: sp-1/0/0, Service set: scos
DSCP          Packets in      Packets out
000000          0             0
000001          0             0
000010          0             0
000011          0             0
000100          0             0
000101          0             0
000110          0             0
000111          0             0
001000          0             0
001001          0             0
001010          0             0
001011          0             0
001100          0             0
001101          0             0
001110          0             0
001111          0             0
010000          0             0
010001          0             0
010010          0             0
010011          0             0
010100          0             0
010101          0             0
010110          0             0
010111          0             0
011000          0             0
011001          0             0
011010          0             0
011011          0             0
011100          0             0
011101          0             0
011110          0             0
011111          0             0
100000          0             0
100001          0             0
100010          0             0
100011          0             0
100100          0             0
100101          0             0
100110          0             0
100111          0             0
101000          0             0
101001          0             0
101010          0             0
101011          0             0
101100          0             0

```

101101	0	0
101110	0	0
101111	0	0
110000	0	0
110001	0	0
110010	0	0
110011	0	0
110100	0	0
110101	0	0
110110	0	0
110111	0	0
111000	0	0
111001	0	0
111010	0	0
111011	0	0
111100	0	0
111101	0	0
111110	0	0
111111	0	0
Forwarding class	Packets in	Packets out
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0

show services cos statistics brief The output for the **show services cos statistics brief** command is identical to that for the **show services cos statistics** command.

show services cos statistics detail The output for the **show services cos statistics detail** command is identical to that for the **show services cos statistics** command.

show services cos statistics extensive The output for the **show services cos statistics extensive** command is identical to that for the **show services cos statistics** command.

Data Link Switching Operational Mode Commands

Table 225 on page 1369 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot data link switching (DLSw) on J Series routers. Commands are listed in alphabetical order.

Table 225: DLSw Operational Mode Commands

Task	Command
Clear DLSw reachability.	<code>clear dlsw reachability</code>
Display DLSw peer capability.	<code>show dlsw capabilities</code>
Display information about configured DLSw circuits.	<code>show dlsw circuits</code>
Display DLSw peer information.	<code>show dlsw peers</code>
Display information about the cached media access control (MAC) entries.	<code>show dlsw reachability</code>
Display logical link control type 2 (LLC2) redundancy information for DLSw.	<code>show llc2 redundancy</code>
Display LLC2 redundancy statistics.	<code>show llc2 redundancy interface statistics</code>
Display LLC2 redundancy MAC translation information.	<code>show llc2 redundancy mac-translation</code>
Display LLC2 redundancy tracking information.	<code>show llc2 redundancy track</code>



NOTE: DLSw is supported only on the J Series router.



NOTE: For information about how to configure DLSw, see the *Junos OS Services Interfaces Configuration Guide* or the *J Series Services Router Advanced WAN Access Configuration Guide*.

clear dlsw reachability

Syntax	clear dlsw reachability
Release Information	Command introduced in Junos OS Release 8.0.
Description	Clear the data-link switching (DLSw) reachability cache.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show dlsw reachability on page 1376
List of Sample Output	clear dlsw reachability on page 1370
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear dlsw reachability user@host> clear dlsw reachability

show dlsw capabilities

Syntax	show dlsw capabilities
Release Information	Command introduced in Junos OS Release 7.4.
Description	(J Series routers only) Display information about data link switching (DLSw) capabilities of a specific remote peer or all peers.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show dlsw capabilities on page 1371
Output Fields	Table 226 on page 1371 describes the output fields for the show dlsw capabilities command. Output fields are listed in the approximate order in which they appear.

Table 226: show dlsw capabilities Output Fields

Field Name	Field Description
Peer	IP address of the peer DLSw router.
Vendor ID	Numerical value assigned to Juniper Networks.
Version number	DLSw version.
Initial pacing window size	Receive window size for incoming transport connections with the DLSw peer.
Version string	Juniper Networks software version information.

Sample Output

```

show dlsw capabilities user@host> show dlsw capabilities
Peer: 217.110.111.134
  Vendor ID           : 000585
  Version number      : 0200
  Initial pacing window size : 32
  Version string      :
    Juniper Networks, Inc. j2300 internet router
    Junos OS Release 7.4I0 [builder]
    Build date: 2005-07-15 07:13:17 UTC
    Copyright (c) 1996-2005 Juniper Networks, Inc.
```

show dlsw circuits

Syntax	show dlsw circuits <brief detail>
Release Information	Command introduced in Junos OS Release 7.4.
Description	(J Series router only) Display information about configured data link switching (DLSw) circuits.
Options	none—Display information about all DLSw circuits. brief detail—(Optional) Display the specified level of output.
Required Privilege Level	view
List of Sample Output	show dlsw circuits on page 1373 show dlsw circuits detail on page 1373
Output Fields	Table 227 on page 1372 describes the output fields for the show dlsw circuits command. Output fields are listed in the approximate order in which they appear.

Table 227: show dlsw circuits Output Fields

Field Name	Field Description	Level of Output
Circuit id	Circuit ID	detail
Local address	MAC address of the local DLSw peer.	All levels
LSAP	Number of the local service access point.	All levels
Remote address	MAC address of the remote DLSw peer.	All levels
DSAP	Number of the destination service access point.	All levels
Peer or remote peer address	IP address of the remote DLSw peer.	All levels
Circuit state	State of the circuit.	detail
Uptime	How long the circuit has been established.	All levels
Max BTU size	Maximum packet size.	detail
Circuit priority	Traffic priority on the circuit.	detail

Table 227: show dlsw circuits Output Fields (*continued*)

Field Name	Field Description	Level of Output
Statistics	Statistics: <ul style="list-style-type: none"> • I-frames received—Number of I-frames received. • I-frames sent—Number of I-frames sent. • Bytes in I-frames received—Number of bytes in I-frames received. • Bytes in I-frames sent—Number of bytes in I-frames sent. • I-frames rejected—Number of I-frames rejected. • Bytes in I-frames rejected—Number of bytes in I-frames rejected. • I-frames retransmitted—Number of I-frames retransmitted. • Bytes in retransmitted I-frames—Number of bytes in I-frames retransmitted. • Reject frames received—Number of reject frames received. • Reject frames sent—Number of reject frames sent. • XID frames received—Number of XID frames received. • XID frames sent—Number of XID frames sent. 	detail

Sample Output

```

show dlsw circuits user@host> show dlsw circuits
Local address      LSAP  Remote address    DSAP  Peer      Uptime
22:22:00:00:00:06  04    44:44:00:00:00:06  04    10.255.18.2  00:06:42

show dlsw circuits user@host> show dlsw circuits detail
detail Circuit ID: 9ad20498aa04
Local address: 22:22:00:00:00:06, LSAP: 04
Remote address: 44:44:00:00:00:06, DSAP: 04
Remote peer address: 18.255.18.2
Circuit state: Connected
Uptime: 00:09:02
Max BTU size: 1466
Circuit priority: 3
Statistics:
  I-frames received : 0
  I-frames sent : 0
  Bytes in I-frames received : 0
  Bytes in I-frames sent : 0
  I-frames rejected : 0
  Bytes in I-frames rejected : 0
  I-frames retransmitted : 0
  Bytes in retransmitted I-frames : 0
  Reject frames received : 0
  Reject frames sent : 0
  XID frames received : 2
  XID frames sent : 2

```

show dlsw peers

Syntax	show dlsw peers <brief detail> <peer-ip <i>ip-address</i> >
Release Information	Command introduced in Junos OS Release 7.4.
Description	(J Series router only) Display data link switching (DLSw) peer status.
Options	none—Display information about all DLSw peers. brief detail—(Optional) Display the specified level of output. peer-ip <i>ip-address</i> —(Optional) Display information about only the specified DLSw peer.
Required Privilege Level	view
List of Sample Output	show dlsw peers brief on page 1375 show dlsw peers detail on page 1375
Output Fields	Table 228 on page 1374 describes the output fields for the show dlsw peers command. Output fields are listed in the approximate order in which they appear.

Table 228: show dlsw peers Output Fields

Field Name	Field Description	Level of Output
Peer	IP address of the remote DLSw peer.	All levels
State	Status of the connection.	All levels
Circuits	Number of circuits on the DLSw network.	All levels
Uptime	How long the circuit has been established.	All levels
Local address	IP address of the local DLSw peer.	detail
Connected time	Length of time the connection is established.	detail
Receive initial pacing	Size of the initial pacing frame.	detail
No circuits timeout	Length of time before a circuit times out.	detail
Type-of-service value	CoS type-of-service (ToS) number.	detail
Peer cost	Preference for establishing a circuit with this peer.	detail
Load balancing	Whether load balancing is enabled and what algorithm is used.	detail

Table 228: show dlsw peers Output Fields (*continued*)

Field Name	Field Description	Level of Output
Circuit weight	Extent to which this peer should participate in establishing circuits.	detail
Statistics	Statistics: <ul style="list-style-type: none"> • Data packets received—Number of packets received. • Data packets sent—Number of packets sent. • Data bytes received—Number of bytes received. • Data bytes sent—Number of bytes sent. • Control packets received—Number of control packets received. • Control packets sent—Number of control packets sent. • CANUREACH_ex received—Number of CANUREACH messages received. • CANUREACH_ex sent—Number of CANUREACH messages sent. • ICANREACH_ex received—Number of ICANREACH messages received. • ICANREACH_ex sent—Number of ICANREACH messages sent. 	detail

Sample Output

```

show dlsw peers brief  user@host> show dlsw peers brief
Peer      State      Circuits   Uptime
17.255.17.2  Connected    0         00:00:00
18.255.18.2  Connected    1         00:12:03

show dlsw peers detail  user@host> show dlsw peers detail
Peer: 10.255.18.2
State: Connected, Circuits: 1, Local address: 10.255.4.50
Uptime: 00:15:05
Receive initial pacing: 20, No circuits timeout: 0
Type-of-service value: 0
Peer cost: 100, Load balancing: Circuit Weight
Circuit weight: 2
Statistics:
  Data packets received : 0
  Data packets sent : 0
  Data bytes received : 0
  Data bytes sent : 0
  Control packets received : 7
  Control packets sent : 8
  CANUREACH_ex received : 0
  CANUREACH_ex sent : 1
  ICANREACH_ex received : 1
  ICANREACH_ex sent : 0

```

show dlsw reachability

Syntax	show dlsw reachability
Release Information	Command introduced in Junos OS Release 7.4.
Description	(J Series router only) Display media access control (MAC) and IP addresses of remote data link switching (DLSw) peers.
Required Privilege Level	view
List of Sample Output	show dlsw reachability on page 1376
Output Fields	Table 229 on page 1376 describes the output fields for the show dlsw reachability command. Output fields are listed in the approximate order in which they appear.

Table 229: show dlsw reachability Output Fields

Field Name	Field Description
MAC index	Number assigned to the DLSw peer.
MAC address	MAC address of the DLSw peer.
Location	Peer location: local or remote .
Peer/interface	Peer interface name or IP address.

Sample Output

```

show dlsw reachability user@host> show dlsw reachability
MAC index MAC address      Location      Peer/Interface
    0  44:44:00:00:00:06  remote      17.255.17.2
                                     18.255.18.2
    1  22:22:00:00:00:06  local       fe-0/0/1.0

```


show llc2 redundancy

Syntax	show llc2 redundancy <brief detail> <interface statistics mac-translation track (dlsw-remote-destination dlsw-remote-peer interfaces)>
Release Information	Command introduced in Junos OS Release 7.5.
Description	(J Series router only) Display logical link control type 2 (LLC2) redundancy information for data link switching (DLSw).
Options	none—Display basic LLC2 redundancy information. Same as brief . brief detail—(Optional) Display the specified level of output.
Required Privilege Level	view
List of Sample Output	show llc2 redundancy on page 1378 show llc2 redundancy detail on page 1378
Output Fields	Table 230 on page 1377 describes the output fields for the show llc2 redundancy command. Output fields are listed in the approximate order in which they appear.

Table 230: show llc2 redundancy Output Fields

Field Name	Field Description	Level of Output
Interface	IP address of the remote DLSw peer.	All levels
Unit	Logical interface unit number.	brief
Group	Group number.	All levels
Int state or Interface state	Interface state: up or down .	All levels
Er state or state	Indicates master or backup router.	All levels
Index	Number assigned to the router.	detail
Priority	Order to take over as master.	detail
Advertisement interval	Length of time between sending hello packets.	detail
Preempt	Master took over because of a failure.	detail
Advertisement timer	Times the advertisement intervals.	detail
Master router uptime	Length of time the master router has been available.	detail

Table 230: show llc2 redundancy Output Fields (*continued*)

Field Name	Field Description	Level of Output
Tracking	Whether tracking options are enabled or disabled.	detail

Sample Output

```
show llc2 redundancy  user@host> show llc2 redundancy
Interface  Unit  Group  Int state  ER state
fe-0/0/1.0  0    5      up        master

show llc2 redundancy  user@host> show llc2 redundancy detail
detail          Interface:fe-0/0/1.0 Index 69
                Interface state: up, Group 5, State master,
                Priority:255, Advertisement interval 5,
                Preempt:yes, Advertisement timer 0.0,
                Master router uptime:361476.770, Tracking: enabled
```

show llc2 redundancy interface statistics

Syntax	show llc2 redundancy interface statistics
Release Information	Command introduced in Junos OS Release 7.5.
Description	(J Series router only) Display logical link control type 2 (LLC2) redundancy interface statistics for data link switching (DLSw).
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show llc2 redundancy interface statistics on page 1379
Output Fields	Table 231 on page 1379 lists the output fields for the show llc2 redundancy interface statistics command. Output fields are listed in the approximate order in which they appear.

Table 231: show llc2 redundancy interface statistics Output Fields

Field Name	Field Description
Interface	Name of the configured physical interface.
Index	Number assigned to the interface.
Group	Number of the redundancy group.
Interface ERED PDU statistics	
Advertisement sent	Number of packets sent to advertise the router on the network.
Advertisement received	Number of packets received as advertisements on the network.
Interface ERED PDU error statistics	
Invalid ERED TTL value received	Number of invalid Ethernet redundancy time-to-live (TTL) values.

Sample Output

```

show llc2 redundancy interface statistics user@host> show llc2 redundancy interface statistics
Interface : fe-0/0/1.0, Index : 69, Group : 5
Interface ERED PDU statistics
  Advertisement sent           : 2959
  Advertisement received       : 0
Interface ERED PDU error statistics
  Invalid ERED TTL value received : 0

```

show llc2 redundancy mac-translation

Syntax	show llc2 redundancy mac-translation
Release Information	Command introduced in Junos OS Release 7.5.
Description	(J Series router only) Display logical link control type 2 (LLC2) redundancy media access control (MAC) translation information for data link switching (DLSw).
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show llc2 redundancy mac-translation on page 1380
Output Fields	Table 232 on page 1380 lists the output fields for the show llc2 redundancy mac-translation command. Output fields are listed in the approximate order in which they appear.

Table 232: show llc2 redundancy mac-translation Output Fields

Field Name	Field Description
Local mac	MAC address of the local DLSw peer router.
Remote mac	MAC address of the remote DLSw peer router.
Interface	Physical interface configured for Ethernet redundancy.
Group	Assigned redundancy group number.

Sample Output

```

user@host> show llc2 redundancy mac-translation
show llc2 redundancy mac-translation
Local mac      Remote mac      Interface      group
44:44:44:44:44 44:44:44:44:10:25 fe-0/0/1.0     5
44:44:44:44:44:33 44:44:44:44:10:16 fe-0/0/1.0     5
44:44:44:44:44:48 44:44:44:44:10:39 fe-0/0/1.0     5
09:00:2b:00:00:04 09:00:2b:00:00:05 fe-0/0/1.0     5
00:00:5e:00:01:01 00:0d:88:45:ce:5c fe-0/0/1.0     5

```

show llc2 redundancy track

Syntax	show llc2 redundancy <brief detail> <interface statistics mac-translation track (dlsw-remote-destination dlsw-remote-peer interfaces)>
Release Information	Command introduced in Junos OS Release 7.5.
Description	(J Series router only) Display logical link control type 2 (LLC2) redundancy tracking information for data link switching (DLSw).
Options	<p>brief detail—(Optional) Display the specified level of output.</p> <p>dlsw-remote-destination—(Optional) Display LLC2 remote destination tracking information.</p> <p>dlsw-remote-peer—(Optional) Display LLC2 remote peer tracking information.</p> <p>interfaces—(Optional) Display LLC2 interface tracking information.</p>
Required Privilege Level	view
List of Sample Output	<p>show llc2 redundancy track dlsw-remote-destination on page 1382</p> <p>show llc2 redundancy track dlsw-remote-peer on page 1382</p> <p>show llc2 redundancy track interfaces on page 1382</p>
Output Fields	Table 233 on page 1381 lists the output fields for the show llc2 redundancy track command. Output fields are listed in the approximate order in which they appear.

Table 233: show llc2 redundancy track Output Fields

Field Name	Field Description
Remote dest	MAC address of the remote peer router.
Peer dest	IP address of the remote peer.
Track if	Physical interface configured for tracking.
Connectivity	Status of the connection.
Cost	Value assigned to place the router in a redundancy hierarchy.
Interface	Physical interfaces configured for DLSw redundancy.
Group	Assigned redundancy group number.
Cfg	Priority value configured on the router.
Run	Value after all priority values are applied.

Table 233: show llc2 redundancy track Output Fields (*continued*)

Field Name	Field Description
ER state	Status of the router: master or backup .

Sample Output

```

show llc2 redundancy track dlsw-remote-destination
user@host> show llc2 redundancy track dlsw-remote-destination
Remote dest      Reachability Cost  Interface  Group  Cfg  Run  ER state
44:44:44:44:44:45 reachable    15   fe-0/0/1.0  5     255  255  master
dlsw-remote-destination
44:44:44:44:44:49 unknown      35   fe-0/0/1.0  5     255  255  master

show llc2 redundancy track dlsw-remote-peer
user@host> show llc2 redundancy track dlsw-remote-peer
Remote peer      Connectivity Cost  Interface  Group  Cfg  Run  ER state
dlsw-remote-peer
10.255.110.38    yes      10   fe-0/0/1.0  5     255  245  master
2.2.2.3          no       10   fe-0/0/1.0  5     255  245  master
10.255.110.39    yes      10   fe-0/0/1.0  5     255  245  master

show llc2 redundancy track interfaces
user@host> show llc2 redundancy track interfaces
Track if  State Cost  Interface  Group  Cfg  Run  ER state
e1-0/0/2.0 yes    10   fe-0/0/1.0  5     255  255  master

```

Diameter Base Protocol Operational Mode Commands

Table 234 on page 1383 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot Diameter base protocol services.

Table 234: Diameter Base Protocol Operational Mode Commands

Task	Command
Clear Diameter function statistics.	clear diameter function statistics
Clear Diameter peers.	clear diameter peer
Clear pending Gx-Plus login and logout requests.	clear network-access gx-plus replay
Clear Gx-Plus statistics.	clear network-access gx-plus statistics
Display information about the Diameter node.	show diameter
Display information about Diameter functions.	show diameter function
Display Diameter function statistics.	show diameter function statistics
Display information about Diameter instances.	show diameter instance
Display information about Diameter network elements.	show diameter network-element
Display information about Diameter network element maps.	show diameter network-element map
Display information about Diameter peers.	show diameter peer
Display information about Diameter peer maps.	show diameter peer map
Display Diameter peer statistics.	show diameter peer statistics
Display information about Diameter routes.	show diameter route

Table 234: Diameter Base Protocol Operational Mode Commands *(continued)*

Task	Command
Display Gx-Plus provisioning state, synchronization state, and statistics information.	show network-access gx-plus



NOTE: For information about how to configure Diameter Base Protocol services, see the *Junos OS Subscriber Access Configuration Guide*.

clear diameter function statistics

Syntax	<code>clear diameter function <function-name> statistics</code>
Release Information	Command introduced in Junos OS Release 9.6. Support for PTSP introduced in Junos OS Release 10.2. Support for Gx-Plus introduced in Junos OS Release 11.2.
Description	Clear current statistics accumulated for a specified function (application) or for all functions associated with the Diameter instance.
Options	<i>function-name</i> —(Optional) Clear statistics for the specified function. Currently, Gx-Plus, JSRC, and packet-triggered-subscribers are supported functions.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Gx-Plus for Provisioning Subscribers Overview • Juniper Networks Session and Resource Control (SRC) and JSRC Overview • PTSP Overview • show diameter on page 1389 • show diameter function on page 1395 • show diameter function statistics on page 1398
List of Sample Output	clear diameter function statistics on page 1385
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear diameter function statistics
user@host> clear diameter function jsrsrc statistics
```

clear diameter peer

Syntax	<code>clear diameter peer <i>peer-name</i></code> <code><connection statistics></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Delete the specified Diameter peer and clear all statistics or only current statistics for the specified peer.
Options	<p><i>peer-name</i>—Delete the Diameter peer.</p> <p><i>connection</i>—(Optional) Clear all peer statistics and restart the peer state machine for the specified Diameter peer. This is the default action.</p> <p><i>statistics</i>—(Optional) Clear current statistics for the specified Diameter peer.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show diameter on page 1389• show diameter peer on page 1409• show diameter peer map on page 1413• show diameter peer statistics on page 1416
List of Sample Output	clear diameter peer on page 1386
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear diameter peer `user@host> clear diameter peer peer5 connection`

clear network-access gx-plus replay

Syntax	clear network-access gx-plus replay
Release Information	Command introduced in Junos OS Release 11.2.
Description	Clear pending Gx-Plus login and logout requests (replays). Sends JSER message to PCRF that includes the Juniper-Event-Type AVP (AVP code 2103) with a value of 3 indicating a discovery request. The PCRF returns a JDER message to initiate discovery of all subscribers. When this discovery completes, all pending subscriber requests are cleared.
Options	This command has no options.
Required Privilege Level	clear
List of Sample Output	clear network-access gx-plus replay on page 1387
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear network-access gx-plus replay	user@host> clear network-access gx-plus replay
--	--

clear network-access gx-plus statistics

Syntax	clear network-access gx-plus statistics
Release Information	Command introduced in Junos OS Release 11.2.
Description	Clear Gx-Plus statistics.
Options	This command has no options.
Required Privilege Level	clear
List of Sample Output	clear network-access gx-plus statistics on page 1388
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear network-access gx-plus statistics	user@host> clear network-access gx-plus statistics
--	--

show diameter

Syntax	show diameter <brief detail summary>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display information about the Diameter node.
Options	brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes Diameter node status. The brief output adds summary information about functions, instances, network elements, and peers. The detail output adds summary information about routes.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear diameter function statistics on page 1385 • clear diameter peer on page 1386
List of Sample Output	show diameter brief on page 1392 show diameter detail on page 1393 show diameter summary on page 1393
Output Fields	Table 235 on page 1389 lists the output fields for the show diameter command. Output fields are listed in the approximate order in which they appear.

Table 235: show diameter Output Fields

Field Name	Field Description	Level of Output
Diameter process id	ID number of the Diameter process.	All levels
Functions	Number of functions associated with Diameter.	All levels
Connected functions	Number of functions with active Diameter connections.	All levels
Instances	Number of configured Diameter instances.	All levels
Network elements (NEs)	Number of configured Diameter network elements.	All levels
Connected NEs	Number of Diameter network elements with active connections.	All levels
Peers	Number of Diameter peer nodes.	All levels
Activated peers	Number of Diameter peers with active connections.	All levels

Table 235: show diameter Output Fields (*continued*)

Field Name	Field Description	Level of Output
Open peers	Number of peers in the open state, without active network element connections but available for a connection.	All levels
Transports	Number of transports configured.	All levels
Requests queued for network transmit	Number of requests waiting to be sent to the Diameter peers.	All levels
Answers queued for network transmit	Number of replies waiting to be sent to the Diameter peers.	All levels
Expected answers from network	Number of replies expected to be received from the Diameter peers.	All levels
Requests queued for function transmit	Number of requests waiting to be sent to the functions associated with Diameter.	All levels
Answers queued for function transmit	Number of replies waiting to be sent to the functions associated with Diameter.	All levels
Expected answers from functions	Number of replies expected to be received from the functions associated with Diameter.	All levels
Memory used by network transmit queues	Amount of memory consumed by network transmit queues.	All levels
Memory used by function transmit queues	Amount of memory consumed by function transmit queues.	All levels
Function	Name of the function for which information is displayed.	brief detail
State	State of the Diameter connection with the function: Connected or Disconnect (disconnected).	brief detail
Upstream Transaction Utilization	Percent of upstream traffic used for this function.	brief detail
Downstream Transaction Utilization	Percent of downstream traffic used for this function.	brief detail
Net Queue Buffer Utilization	Percent of network transmission buffer used for this function.	brief detail

Table 235: show diameter Output Fields (*continued*)

Field Name	Field Description	Level of Output
Func Queue Buffer Utilization	Percent of function transmission buffer used for this function.	brief detail
Routed Dests	Number of destinations that have this function associated with their routes.	brief detail
Name	Name of the Diameter instance.	brief detail
Origin-Realm	Value of Origin-Realm attribute-value pair (AVP).	brief detail
Origin Host	Value of Origin-Host AVP.	brief detail
NE-Total	Number of configured network elements.	brief detail
NE-Connected	Number of network elements with active Diameter connections.	brief detail
Name	Name of the Diameter network element.	brief detail
Instance	Name of the Diameter instance in which the network element is configured.	brief detail
State	State of the network element: <ul style="list-style-type: none"> • Connecting—None of the network element peers are in the open state and available for connection. • Selecting—One network element peer is connected and the network element is waiting for another peer to reach the open state so that it can be connected. • Partially-Connected—One network element peer is in the open state and connected. • Post-selection-delay—Three or more peers are in the open state and the network element is waiting to deactivate the peers in excess of two. • Fully-connected—Two network element peers are in the open state and connected. 	brief detail
Primary Peer	Primary peer for the network element, based on the configured peer priority.	brief detail
Secondary Peer	Secondary peer for the network element, based on the configured peer priority.	brief detail
Peer	Name of the peer.	brief detail
Instance	Name of the Diameter instance in which the peer is configured.	brief detail

Table 235: show diameter Output Fields (*continued*)

Field Name	Field Description	Level of Output
State	State of the peer: <ul style="list-style-type: none"> • Bad-Config—Misconfiguration. • Bad-Remote—Remote side does not conform to one of the decisions or is sending malformed messages. • Closed—Normal disconnect due to a request from the remote site or due to excessive watchdog timeouts. • Destructing—Peer to be deleted on the next timer tick. Until then, it performs no actions. • Disabled—Peer is administratively disabled. • Internal-error—Internal error has been detected and the peer is in the process of restarting. • No-Activation—Peer is not used by any Diameter network element. • Rejected—Connection was rejected by remote side of the connection. • Suspended—All other reasons to be suspended. 	brief detail
NE-Count	Number of network elements associated with the peer.	brief detail
Activated Count	Activation status of the peer: <ul style="list-style-type: none"> • 1—Peer is activated. • 0—Peer is not activated. 	brief detail
Primary Count	Status of the peer: primary (1) or secondary (0).	brief detail
Secondary Count	Status of the peer: secondary (0) or primary (1).	brief detail
Route	Name of the Diameter route.	detail
NE	Name of the Diameter network element in which the route is configured	detail
Instance	Name of the Diameter instance in which the route is configured.	detail
Valid	Determination of whether the route is valid: yes or no .	detail
Up	State of the route: yes for an active route, no for an inactive route.	detail

Sample Output

```
show diameter brief  user@host> show diameter brief
```

```
Diameter node:
Diameter process id      :      1446
Functions                 :       4
Connected functions      :       2
Instances                 :       1
Network elements(NEs)    :       1
Connected NEs            :       0
Peers                     :       2
```



```

Activated peers           : 1
Open peers               : 0
Transports               : 1
Requests queued for network transmit : 0
Answers queued for network transmit : 0
Expected answers from network : 0
Requests queued for function transmit : 0
Answers queued for function transmit : 0
Expected answers from functions : 0
Memory used by network transmit queues : 0
Memory used by function transmit queues : 0

```

Diameter function list:

Function	State	Upstream Transaction Utilization	Downstream Transaction Utilization	Net Queue Buffer Utilization	Func Queue Buffer Utilization	Routed Dests
charging-	Disconnec	0	0	0	0	0
gx-plus	Connected	0	0	0	0	1
jsrc	Connected	0	0	0	0	0
packet-tr	Disconnec	0	0	0	0	0

Diameter instances:

Name	Origin-Realm	Origin-Host	NE-Total	NE-Connected
master	orrr	ohhh	1	0

Diameter network-elements:

Name	Instance	State	Primary Peer	Secondary Peer
n0	master	Connecting	<NONE>	<NONE>

Diameter peer list:

Peer	Instance	State	NE-Count	Activated Count	Primary Count	Secondary Count
p0	master	Suspended	1	1	0	0
p100	master	No-Activation	0	0	0	0

show diameter detail user@host> show diameter detail

```

...
Diameter routes:
Route      NE      Instance  Valid Up
dne-route1 dne1    master   yes   no

```

show diameter summary user@host> show diameter summary

```

Diameter node:
Diameter process id      : 1446
Functions                : 4
Connected functions      : 2
Instances                : 1
Network elements(NEs)    : 1
Connected NEs            : 0
Peers                    : 2
Activated peers          : 1
Open peers               : 0
Transports               : 1
Requests queued for network transmit : 0
Answers queued for network transmit : 0
Expected answers from network : 0
Requests queued for function transmit : 0
Answers queued for function transmit : 0
Expected answers from functions : 0

```

```
Memory used by network transmit queues :      0
Memory used by function transmit queues :      0
```

show diameter function

Syntax	show diameter function <brief detail summary> <function-name>
Release Information	Command introduced in Junos OS Release 9.6. Support for PTSP introduced in Junos OS Release 10.2. Support for Gx-Plus introduced in Junos OS Release 11.2.
Description	Display information about all functions associated with Diameter instances or only the specified function.
Options	brief detail summary —(Optional) Display the specified level of output. The summary output is displayed by default and includes basic function information. The brief output displays the summary information in a different format. The detail output adds information to the brief output. function-name —(Optional) Display information for only the specified function. Currently, Gx-Plus, JSRC, and packet-triggered-subscribers are supported functions.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear diameter function statistics on page 1385
List of Sample Output	show diameter function on page 1397 show diameter function brief on page 1397 show diameter function detail on page 1397
Output Fields	Table 236 on page 1395 lists the output fields for the show diameter function command. Output fields are listed in the approximate order in which they appear.

Table 236: show diameter function Output Fields

Field Name	Field Description	Level of Output
Function name	Name of the function for which information is displayed.	All levels
State	State of the Diameter connection with the function.	All levels
Upstream transaction utilization	Percent of upstream traffic used for this function.	All levels
Downstream transaction utilization	Percent of downstream traffic used for this function.	All levels
Network transmit buffer utilization	Percent of network transmission buffer used for this function.	All levels

Table 236: show diameter function Output Fields (*continued*)

Field Name	Field Description	Level of Output
Function transmit buffer utilization	Percent of function transmission buffer used for this function.	All levels
Routed destinations	Number of destinations that have this function associated with their routes.	All levels
Requests queued for network tx	Number of requests waiting to be sent to the Diameter peers for this function.	detail
Pending answers from network	Number of replies expected from the Diameter peers for this function.	detail
Answers queued for function tx	Number of replies waiting to be sent to this function.	detail
Total upstream transactions pending	Total number of messages queued for this function.	detail
Upstream transactions limit	Total number of messages queued for this function.	detail
Requests queued for function tx	Number of requests waiting to be sent to this function.	detail
Pending answers from function	Number of replies expected to be received from this function.	detail
Answers queued for network tx	Number of replies waiting to be sent to this function.	detail
Total downstream transactions pending	Total number of messages queued for the Diameter peers.	detail
Downstream transactions limit	Maximum number of messages that can be queued for the Diameter peers.	detail
Buffers used by network tx queue	Number of buffers used by messages queued for the Diameter peers.	detail
Limit on network tx queue buffers	Maximum buffer capacity available for messages queued for the Diameter peers.	detail
Buffers used by function tx queue	Number of buffers used by messages queued for this function.	detail
Limit on function tx queue buffers	Maximum buffer capacity available for messages queued for this function.	detail

Sample Output

```

show diameter function user@host> show diameter function
Diameter function list:

```

Function	State	Upstream Transaction Utilization %	Downstream Transaction Utilization %	Net Queue Buffer Utilization %	Func Queue Buffer Utilization %	Routed Dests
jsrc	Disconnec	0	0	0	0	0

```

show diameter function brief user@host> show diameter function brief
Diameter function:
  Function name          : gx-plus
  State                  : Connected
  Upstream transaction utilization : 0 %
  Downstream transaction utilization : 0 %
  Network transmit buffer utilization : 0 %
  Function transmit buffer utilization : 0 %
  Routed destinations    : 1
  Function name          : jsrc
  State                  : Disconnected
  Upstream transaction utilization : 0 %
  Downstream transaction utilization : 0 %
  Network transmit buffer utilization : 0 %
  Function transmit buffer utilization : 0 %
  Routed destinations    : 0

```

```

show diameter function detail user@host> show diameter function detail
Diameter function:
  Function name          : jsrc
  State                  : Disconnected
  Upstream transaction utilization : 0 %
  Downstream transaction utilization : 0 %
  Network transmit buffer utilization : 0 %
  Function transmit buffer utilization : 0 %
  Routed destinations    : 0
  Requests queued for network tx : 0
  Pending answers from network : 0
  Answers queued for function tx : 0
  Total upstream transactions pending : 0
  Upstream transactions limit : 1024
  Requests queued for function tx : 0
  Pending answers from function : 0
  Answers queued for network tx : 0
  Total downstream transactions pending : 0
  Downstream transactions limit : 1024
  Buffers used by network tx queue : 0
  Limit on network tx queue buffers : 10485760
  Buffers used by function tx queue : 0
  Limit on function tx queue buffers : 10485760

```

show diameter function statistics

Syntax	show diameter function statistics <brief detail summary> <function-name>
Release Information	Command introduced in Junos OS Release 9.6. Support for PTSP introduced in Junos OS Release 10.2. Support for Gx-Plus introduced in Junos OS Release 11.2.
Description	Display statistics about all functions associated with Diameter instances or only the specified function.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes basic function statistics. The brief output displays the summary information in a different format and adds numbers accumulated since the Diameter node was started. The detail output adds information to the brief output.</p> <p>function-name—(Optional) Display information for only the specified function. Currently, Gx-Plus, JSRC, and packet-triggered-subscribers are supported functions. When you specify a function, the brief output is displayed by default, even when you explicitly specify summary.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear diameter function statistics on page 1385
List of Sample Output	<p>show diameter function statistics on page 1399</p> <p>show diameter function statistics brief on page 1400</p> <p>show diameter function statistics detail on page 1400</p>
Output Fields	Table 237 on page 1398 lists the output fields for the show diameter function statistics command. Output fields are listed in the approximate order in which they appear.

Table 237: show diameter function statistics Output Fields

Field Name	Field Description	Level of Output
Function	Name of the function for which information is displayed.	All levels
Delivered Requests	Number of requests delivered by Diameter to the application.	All levels
Delivered Answers	Number of answers delivered by Diameter to the application.	All levels
Delivered Messages	Total number of messages delivered by Diameter to the application.	All levels
Forwarded Requests	Number of requests sent by Diameter to the network.	All levels

Table 237: show diameter function statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
Forwarded Answers	Number of answers sent by Diameter to the network.	All levels
Forwarded Messages	Number of messages sent by Diameter to the network.	All levels
Function name	Name of the function for which information is displayed.	All levels
Over-limit network requests	Number of requests sent to Diameter peers that exceeded the limit on the network transmit queue.	detail
Over-limit network answers	Number of answers sent to Diameter peers that exceeded the limit on the network transmit queue.	detail
Over-limit network messages	Total number of messages sent to Diameter peers that exceeded the limit on the network transmit queue.	detail
Failed to deliver requests	Number of requests sent by Diameter to its application that were not successfully delivered.	detail
Failed to deliver answers	Number of answers sent by Diameter to its application that were not successfully delivered.	detail
Failed to deliver messages	Total number of messages sent by Diameter to its application that were not successfully delivered.	detail
Over-limit function requests	Number of requests sent to Diameter peers that exceeded the limit on the function transmit queue.	detail
Over-limit function answers	Number of answers sent to Diameter peers that exceeded the limit on the function transmit queue.	detail
Over-limit function messages	Total number of messages sent to Diameter peers that exceeded the limit on the function transmit queue.	detail
Failed to forward requests	Number of requests that were not successfully sent by Diameter to the network.	detail
Failed to forward answers	Number of answers that were not successfully sent by Diameter to the network.	detail
Failed to forward messages	Total number of messages that were not successfully sent by Diameter to the network.	detail

Sample Output

```

show diameter function statistics user@host> show diameter function statistics
Diameter function statistics:
Delivered Delivered Delivered Forwarded Forwarded Forwarded

```

Function	Requests	Answers	Messages	Requests	Answers	Messages
jsrc	0	0	0	0	0	0

show diameter user@host> **show diameter function statistics brief**
function statistics brief

```
Diameter function statistics:
  Function name           : jsrc

  Delivered requests      :      0      0
  Delivered answers       :      0      0
  Delivered messages      :      0      0
  Forwarded requests      :      0      0
  Forwarded answers       :      0      0
  Forwarded messages      :      0      0
```

show diameter user@host> **show diameter function statistics detail**
function statistics
detail

```
Diameter function statistics:
  Function name           : jsrc

  Delivered requests      :      0      0
  Delivered answers       :      0      0
  Delivered messages      :      0      0
  Forwarded requests      :      0      0
  Forwarded answers       :      0      0
  Forwarded messages      :      0      0
  Over-limit network requests :      0      0
  Over-limit network answers :      0      0
  Over-limit network messages :      0      0
  Failed to deliver requests :      0      0
  Failed to deliver answers  :      0      0
  Failed to deliver messages :      0      0
  Over-limit function requests :      0      0
  Over-limit function answers :      0      0
  Over-limit function messages :      0      0
  Failed to forward requests :      0      0
  Failed to forward answers  :      0      0
  Failed to forward messages :      0      0
```


show diameter instance

Syntax	show diameter instance <brief detail summary> <instance-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display information about all Diameter instances or only the specified instance.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes basic instance information. The brief output displays the summary information in a different format. The detail output is the same as the brief output.</p> <p>instance-name—(Optional) Display information for only the specified Diameter instance.</p>
Required Privilege Level	view
List of Sample Output	<p>show diameter instance on page 1402</p> <p>show diameter instance detail on page 1402</p>
Output Fields	Table 238 on page 1401 lists the output fields for the show diameter instance command. Output fields are listed in the approximate order in which they appear.

Table 238: show diameter instance Output Fields

Field Name	Field Description	Level of Output
name	Name of the Diameter instance.	summary
Origin-realm	Value of Origin-Realm AVP.	summary
Origin-host	Value of Origin-Host AVP.	summary
NE-total	Total number of network elements configured for this instance.	summary
NE-connected	Number of network elements with active Diameter connections.	summary
Instance name	Name of the Diameter instance.	brief detail
Origin realm	Value of Origin-Realm AVP.	brief detail
Origin host	Value of Origin-Host AVP.	brief detail
NEs	Total number of network elements configured for this instance.	brief detail
Connected NEs	Number of network elements with active Diameter connections.	brief detail

Sample Output

```
show diameter instance user@host> show diameter instance
Diameter instances:
  Name      Origin-Realm  Origin-Host  NE-Total  NE-Connected
  master    rrrr          hhhh         1          1
```

```
show diameter instance detail user@host> show diameter instance detail
Diameter instance:
  Instance name : master

  Origin realm  : rrrr

  Origin host   : hhhh

  NEs           : 1
  Connected NEs : 1
```

show diameter network-element

Syntax	show diameter network-element <brief detail summary> <element-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display information about all Diameter network elements or only the specified network element.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes basic network element information. The brief output displays the summary information in a different format. The detail output adds information to the brief output.</p> <p>element-name—(Optional) Display information for only the specified network element.</p>
Required Privilege Level	view
List of Sample Output	<p>show diameter network-element on page 1404</p> <p>show diameter network-element detail on page 1404</p>
Output Fields	Table 239 on page 1403 lists the output fields for the show diameter network-element command. Output fields are listed in the approximate order in which they appear.

Table 239: show diameter network-element Output Fields

Field Name	Field Description	Level of Output
Name	Name of the Diameter network element.	summary
Instance	Name of the Diameter instance in which the network element is configured.	summary
State	State of the network element: <ul style="list-style-type: none"> Connecting—None of the network element peers are in the open state and available for connection. Selecting—One network element peer is connected and the network element is waiting for another peer to reach the open state so that it can be connected. Partially-Connected—One network element peer is in the open state and connected. Post-selection-delay—Three or more peers are in the open state and the network element is waiting to deactivate the peers in excess of two. Fully-connected—Two network element peers are in the open state and connected. 	All levels
Primary peer	Primary peer for the network element, based on the configured peer priority.	All levels
Secondary peer	Secondary peer for the network element, based on the configured peer priority.	All levels

Table 239: show diameter network-element Output Fields (*continued*)

Field Name	Field Description	Level of Output
NE name	Name of the Diameter network element.	brief detail
Instance name	Name of the Diameter instance in which the network element is configured.	brief detail
Peers	Number of configured peers.	brief detail
Activated peers	Number of peers that have been activated.	brief detail
Open peers	Number of peers in the open state, without active network element connections but available for a connection.	brief detail
Routes	Number of routes configured for the network element.	brief detail
Invalid routes	Number of routes that are invalid because they lack one or more of the following: application and partition, Diameter instance, or destination realm.	brief detail
Activation delay	Period in milliseconds between peer activations by the network element.	brief detail
First selection delay	Period in milliseconds that the network element waited after connecting to the first peer to allow other peers to reach the open state.	brief detail
Post selection delay	Period in milliseconds that the network element waited after having two peers in the open state before deactivating all lower-priority peers.	brief detail

Sample Output

```

show diameter network-element user@host> show diameter network-element
Diameter network-elements:
      Name      Instance      State      Primary      Secondary
      ne0       master      Fully-connected p0      p1

show diameter network-element detail user@host> show diameter network-element detail
Diameter network-element:
  NE name      : ne0
  Instance name : master
  State        : Fully-connected
  Primary peer  : p0
  Secondary peer : p1
  Peers         : 5
  Activated peers : 4
  Open peers    : 2
  Routes        : 1
  Invalid routes : 0

```

Activation delay : 10000 ms
First selection delay : 0 ms
Post selection delay : 30000 ms

show diameter network-element map

Syntax	show diameter network-element map <brief detail summary> <element-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display network-element-to-peer mapping information for all Diameter network elements or only the specified network element.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default. The brief output and detail output display the summary information in a different format.</p> <p>element-name—(Optional) Display information for only the specified network element.</p>
Required Privilege Level	view
List of Sample Output	<p>show diameter network-element map on page 1407</p> <p>show diameter network-element map detail on page 1407</p>
Output Fields	Table 240 on page 1406 lists the output fields for the show diameter network-element map command. Output fields are listed in the approximate order in which they appear.

Table 240: show diameter network-element map Output Fields

Field Name	Field Description	Level of Output
Name	Name of the Diameter network element.	summary
Instance	Name of the Diameter instance in which the network element is configured.	summary
Peer	Name of the peer.	All levels
Priority	Priority configured for the peer. A lower number indicates a higher priority.	All levels
State	State of the peer: <ul style="list-style-type: none"> Activated—Peer has been activated (selected) by the network element. Not-Activated—Peer has not been selected by the network element. Primary—Peer that is connected to the network element and has the higher priority of the two connected peers. Secondary—Peer that is connected to the network element and has the lower priority of the two connected peers. 	summary
NE name	Name of the Diameter network element.	brief detail
Instance name	Name of the Diameter instance in which the network element is configured.	brief detail

Table 240: show diameter network-element map Output Fields (*continued*)

Field Name	Field Description	Level of Output
Usage	State of the peer: <ul style="list-style-type: none"> Activated—Peer has been activated (selected) by the network element. Not-Activated—Peer has not been selected by the network element. Primary—Peer that is connected to the network element and has the higher priority of the two connected peers. Secondary—Peer that is connected to the network element and has the lower priority of the two connected peers. 	brief detail

Sample Output

```

show diameter network-element map user@host> show diameter network-element map

```

```

Diameter network-element peers:
  Name      Instance  Peer      Priority  State
  ne0       master   p288      30       Activated
  ne0       master   p0        20       Primary
  ne0       master   pA        15       Activated
  ne0       master   p1        10       Secondary
  ne0       master   pB        5       Not-Activated

```

```

show diameter network-element map detail user@host> show diameter network-element map detail

```

```

Diameter network-element peers:
  NE name      : ne0

  Instance name : master

  Peer         : p288

  Priority      : 30
  Usage        : Activated

  NE name      : ne0

  Instance name : master

  Peer         : p0

  Priority      : 20
  Usage        : Primary

  NE name      : ne0

  Instance name : master

  Peer         : pA

  Priority      : 15
  Usage        : Activated

  NE name      : ne0

```

Instance name	: master
Peer	: p1
Priority	: 10
Usage	: Secondary
NE name	: ne0
Instance name	: master
Peer	: pB
Priority	: 5
Usage	: Not-Activated

show diameter peer

Syntax	show diameter peer <brief detail summary> <peer-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display information about all peers associated with Diameter instances or only the specified peer.
Options	brief detail summary —(Optional) Display the specified level of output. The summary output is displayed by default and includes basic peer information. The brief output displays the summary information in a different format. The detail output adds information to the brief output. peer-name —(Optional) Display information for only the specified peer.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear diameter peer on page 1386
List of Sample Output	show diameter peer on page 1411 show diameter peer detail on page 1411
Output Fields	Table 241 on page 1409 lists the output fields for the show diameter peer command. Output fields are listed in the approximate order in which they appear.

Table 241: show diameter peer Output Fields

Field Name	Field Description	Level of Output
Peer	Name of the peer.	brief summary
Instance	Name of the Diameter instance in which the peer is configured.	brief summary

Table 241: show diameter peer Output Fields (*continued*)

Field Name	Field Description	Level of Output
State	State of the peer: <ul style="list-style-type: none"> • Bad-Config—Misconfiguration. • Bad-Remote—Remote side does not conform to one of the decisions or is sending malformed messages. • Closed—Normal disconnect due to a request from the remote site or due to excessive watchdog timeouts. • Destructing—Peer to be deleted on the next timer tick; until then, it performs no actions. • Disabled—Peer is administratively disabled. • Internal-error—Internal error has been detected and the peer is in the process of restarting. • No-Activation—Peer is not used by any Diameter network element. • Rejected—Connection was rejected by remote side of the connection. • Suspended—All other reasons to be suspended. 	All levels
NE-Count	Number of network elements associated with the peer.	brief summary
Activated Count	Activation status of the peer: <ul style="list-style-type: none"> • 1—Peer is activated. • 0—Peer is not activated. 	All levels
Primary Count	Status of the peer, primary (1) or secondary (0).	All levels
Secondary Count	Secondary (0) versus Primary (1) status of the peer.	All levels
Peer name	Name of the peer.	detail
NEs	Number of network elements associated with the peer.	detail
Vrf	Logical system:routing instance of the configuration.	detail
Remote address	Remote IP address of the peer.	detail
Remote port	Remote port on the peer on which the connection is made.	detail
Remote end origin realm	Name of the realm of the Diameter node that originates messages to the peer.	detail
Remote end origin host	Name of the host of the Diameter node that originates messages to the peer.	detail
Local address	Local IP address on the Diameter origin node.	detail
Local port	Local port on the Diameter origin node.	detail
Local transport	Number of transports configured.	detail

Table 241: show diameter peer Output Fields (*continued*)

Field Name	Field Description	Level of Output
Time since last enable	Period since peer was enabled in <i>hh:mm:ss</i> format.	detail
In state time	Period that peer has been in present state in <i>hh:mm:ss</i> format.	detail
Remaining in state time	Period that peer will remain in present state in <i>hh:mm:ss</i> format.	detail
Missing wd events	Number of missed watchdog events.	detail
Tx queue length	Number of messages in the transmit queue.	detail
Answer waiting count	Number of answers on which the peer is waiting.	detail
Time since last rx	Number of milliseconds since the last message was received by the peer.	detail
Time until wd timeout	Time remaining until next watchdog event.	detail
Operation timeout	Watchdog timeout period.	detail
Suspended timeout base	Base timeout period in suspended states (suspended, rejected, bad-remonte, bad-config). This timeout doubles after each consecutive suspension, until the maximum value of 600 seconds is reached.	detail
Closed timeout	Timeout period in normal closed state, such as when an external peer requested a disconnect.	detail
Connection timeout	Timeout period for establishing a connection.	detail

Sample Output

```
show diameter peer user@host> show diameter peer
```

```
Diameter peer list:
```

Peer	Instance	State	NE-Count	Activated Count	Primary Count	Secondary Count
p0	master	I-Open	1	1	1	0
p1	master	I-Open	1	1	0	1
p288	master	Suspended	1	1	0	0
pA	master	Suspended	1	1	0	0
pB	master	No-Activation	1	0	0	0
pc	master	No-Activation	0	0	0	0
pd	master	No-Activation	0	0	0	0

```
show diameter peer detail user@host> show diameter peer detail
detail
```

```
Diameter peer:
```

```
Peer name           : p0
State               : I-Open
NEs                 : 1
Activated count     : 1
Primary count       : 1
Secondary count     : 0
Vrf                 : default:master
Remote address      : 10.10.5.28
Remote port         : 62917
Remote end origin realm : rrrrA
Remote end origin host : hhhhA
Local address       : 10.6.128.155
Local port          : 57095
Local transport     : <NO-TRANSPORT>
Time since last enable : 08:56.200
In state time       : 08:56.200
Remaining in state time : no limit
Missed wd events    : 0
Tx queue length     : 0
Answer waiting count : 0
Time since last rx   : 2200 ms
Time until wd timeout : 3800 ms
Operation timeout    : 6000 ms
Suspended timeout base : 30000 ms
Closed timeout       : 30000 ms
Connection timeout   : 6000 ms
```

```
Peer name           : p1
State               : I-Open
NEs                 : 1
Activated count     : 1
Primary count       : 0
Secondary count     : 1
Vrf                 : default:master
Remote address      : 10.10.5.28
Remote port         : 58490
Remote end origin realm : rrrrA
Remote end origin host : hhhhB
Local address       : 10.6.128.155
Local port          : 49293
Local transport     : <NO-TRANSPORT>
Time since last enable : 08:56.200
In state time       : 08:36.000
Remaining in state time : no limit
Missed wd events    : 0
Tx queue length     : 0
Answer waiting count : 0
Time since last rx   : 0 ms
Time until wd timeout : 6000 ms
Operation timeout    : 6000 ms
Suspended timeout base : 30000 ms
Closed timeout       : 30000 ms
Connection timeout   : 6000 ms
```

show diameter peer map

Syntax	show diameter peer map <brief detail summary> <peer-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display peer-to-network-element mapping information for all peers associated with Diameter instances or with the specified peer.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes basic peer information. The brief output displays the summary information in a different format. The detail output adds information to the brief output.</p> <p>peer-name—(Optional) Display mapping information for only the specified peer.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear diameter peer on page 1386
List of Sample Output	<p>show diameter peer map on page 1414</p> <p>show diameter peer map detail on page 1414</p>
Output Fields	Table 242 on page 1413 lists the output fields for the show diameter peer map command. Output fields are listed in the approximate order in which they appear.

Table 242: show diameter peer map Output Fields

Field Name	Field Description	Level of Output
Peer	Name of the peer.	All levels
Instance	Name of the Diameter instance in which the network element is configured.	All levels
NE	Name of the Diameter network element.	All levels
Priority	Priority configured for the peer. A lower number indicates a higher priority.	All levels
State	State of the peer: <ul style="list-style-type: none"> Activated—Peer has been activated (selected) by the network element. Not-Activated—Peer has not been selected by the network element. Primary—Peer that is connected to the network element and has the higher priority of the two connected peers. Secondary—Peer that is connected to the network element and has the lower priority of the two connected peers. 	All levels
Instance name	Name of the Diameter instance in which the network element is configured.	brief detail

Table 242: show diameter peer map Output Fields (*continued*)

Field Name	Field Description	Level of Output
NE name	Name of the Diameter network element.	brief detail
Usage	Role of the peer for the network element, Primary or Secondary .	brief detail

Sample Output

show diameter peer map user@host> show diameter peer map

```
Diameter peer usage by network elements:
Peer      Instance  NE      Priority State
p0        master    ne0     20    Primary
p1        master    ne0     10    Secondary
p288      master    ne0     30    Activated
pA        master    ne0     15    Activated
pB        master    ne0     5     Not-Activated
```

show diameter peer map detail user@host> show diameter peer map detail

```
Diameter network-element peers:
Peer      : p0

Instance name      : master

NE name           : ne0

Priority           :      20
Usage             : Primary

Peer             : p1

Instance name      : master

NE name           : ne0

Priority           :      10
Usage             : Secondary

Peer             : p288

Instance name      : master

NE name           : ne0

Priority           :      30
Usage             : Activated

Peer             : pA

Instance name      : master

NE name           : ne0

Priority           :      15
```

Usage	: Activated
Peer	: pB
Instance name	: master
NE name	: ne0
Priority	: 5
Usage	: Not-Activated

show diameter peer statistics

Syntax	show diameter peer statistics <brief detail summary> <peer-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display statistics about all peers associated with Diameter instances or only the specified peer.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes basic function statistics. The brief output displays the summary information in a different format and adds numbers accumulated since the peer was connected. The detail output adds information to the brief output.</p> <p>peer-name—(Optional) Display information for only the specified peer. When you specify a peer, the brief output is displayed by default, even when you explicitly specify summary.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear diameter peer on page 1386
List of Sample Output	<p>show diameter peer statistics on page 1417</p> <p>show diameter peer statistics detail on page 1417</p>
Output Fields	Table 243 on page 1416 lists the output fields for the show diameter peer statistics command. Output fields are listed in the approximate order in which they appear.

Table 243: show diameter peer statistics Output Fields

Field Name	Field Description	Level of Output
Peer	Name of the peer.	summary brief
Instance	Name of the Diameter instance in which the network element is configured.	summary brief
Rx	Total number of messages received.	summary brief
Rx-Peer	Number of messages received by the peer.	summary brief
Rx-node	Number of messages received by the Diameter node.	summary brief
Forw	Total number of forwarded messages.	summary brief
Tx-Peer	Number of messages transmitted by the peer.	summary brief

Table 243: show diameter peer statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
Tx	Total number of transmitted messages.	summary brief
Peer name	Name of the peer.	detail
Instance name	Name of the Diameter instance in which the network element is configured.	detail

Sample Output

show diameter peer statistics user@host> show diameter peer statistics

```
Diameter peer statistics:
Peer      Instance  Rx      Rx-Peer  Rx-Node  Forw     Tx-Peer  Tx
-----
p0        master    113     113      0        0        113
113
p1        master    110     110      0        0        110
110
p288      master    0       0        0        0        0
0
pA        master    0       0        0        0        0
0
pB        master    0       0        0        0        0
0
pc        master    0       0        0        0        0
0
pd        master    0       0        0        0        0
0
```

show diameter peer statistics detail user@host> show diameter peer statistics detail

```
Diameter peer statistics:
Peer name      : p0
Instance name  : master
Current        Since last enable
Rx errors      : 0          0
Rx messages    : 114        114
Rx handled by peer : 114        114
Rx dropped msgs : 0          0
Rx unmatched answers : 0          0
Rx answers     : 0          0
Rx requests    : 0          0
Rx total       : 0          0
Forw to connection : 0          0
Forw to peer     : 0          0
Forw to routed dest : 0          0
Total forwarding : 0          0
Forwarding failures : 0          0
Forwarding success : 0          0
Moved-in messages : 0          0
Moved-out messages : 0          0
Rerouted messages : 0          0
Dropped tx messages : 0          0
Tx by peer      : 114        114
```

Tx errors	:	0	0		
Tx total	:	114	114		
Connection attempts	:	0	1		
Connection fails	:	0	0		
Connections	:	0	1		
Passive terminations	:	0	0		
Active terminations	:	0	0		
Passive disconnects	:	0	0		
Active disconnects	:	0	0		
Rx block requests	:	0	0		
Rx block timeoutss	:	0	0		
Connection management messages					
		Rx current	Rx since last enable	Tx current	Tx since last enable
CER	:	0	0	1	1
CEA	:	1	1	0	0
DWR	:	0	0	113	113
DWA	:	113	113	0	0
DPR	:	0	0	0	0
DPA	:	0	0	0	0
Peer name : p1					
Instance name : master					
		Current	Since last enable		
Rx errors	:	0	0		
Rx messages	:	110	110		
Rx handled by peer	:	110	110		
Rx dropped msgs	:	0	0		
Rx unmatched answers	:	0	0		
Rx answers	:	0	0		
Rx requests	:	0	0		
Rx total	:	0	0		
Forw to connection	:	0	0		
Forw to peer	:	0	0		
Forw to routed dest	:	0	0		
Total forwarding	:	0	0		
Forwarding failures	:	0	0		
Forwarding success	:	0	0		
Moved-in messages	:	0	0		
Moved-out messages	:	0	0		
Rerouted messages	:	0	0		
Dropped tx messages	:	0	0		
Tx by peer	:	110	110		
Tx errors	:	0	0		
Tx total	:	110	110		
Connection attempts	:	0	1		
Connection fails	:	0	0		
Connections	:	0	1		
Passive terminations	:	0	0		
Active terminations	:	0	0		
Passive disconnects	:	0	0		
Active disconnects	:	0	0		
Rx block requests	:	0	0		
Rx block timeoutss	:	0	0		
Connection management messages					
		Rx current	Rx since last enable	Tx current	Tx since last enable
CER	:	0	0	1	1
CEA	:	1	1	0	0

DWR	:	0	0	109	109
DWA	:	109	109	0	0
DPR	:	0	0	0	0
DPA	:	0	0	0	0

show diameter route

Syntax	show diameter route <brief detail summary> <route-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display information about all routes associated with Diameter instances or only the specified route.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The summary output is displayed by default and includes basic function information. The brief output displays the summary information in a different format. The detail output adds information to the brief output.</p> <p>route-name—(Optional) Display information for only the specified route.</p>
Required Privilege Level	view
List of Sample Output	<p>show diameter route on page 1421</p> <p>show diameter route detail on page 1421</p>
Output Fields	Table 244 on page 1420 lists the output fields for the show diameter route command. Output fields are listed in the approximate order in which they appear.

Table 244: show diameter route Output Fields

Field Name	Field Description	Level of Output
Route	Name of the route.	summary brief
NE	Name of the network element associated with the route.	summary brief
Instance	Name of the Diameter instance in which the route is configured.	summary brief
NE name	Name of the network element associated with the route.	brief detail
Instance name	Name of the Diameter instance in which the route is configured.	brief detail
Valid	Determination whether the route is valid, yes or no .	All levels
Up	State of the route, yes (up) or no (down).	All levels
Function	Name of the function associated with the route.	brief detail
Partition	Partition associated with the function.	brief detail
Dest-realm	Destination realm configured for the route.	brief detail

Table 244: show diameter route Output Fields (*continued*)

Field Name	Field Description	Level of Output
Dest-host	Destination hostname configured for the route.	brief detail
Metric	Metric associated with the destination and function to create the route.	brief detail
Score	Value that represents how a route is configured. The basic score is 0. Points are added according to the following scheme: <ul style="list-style-type: none"> • Function is specified—Add 3. • Function partition is specified—Add 1. • Destination realm is specified—Add 1. • Destination host is specified—Add 1. 	brief detail

Sample Output

show diameter route user@host> show diameter route

```
Diameter routes:
Route      NE      Instance  Valid Up
rA         ne0     master    yes   yes
```

show diameter route detail user@host> show diameter route detail

```
Diameter route:
Route name      : rA
NE name         : ne0
Instance name   : master
Valid           : yes
Up              : yes
Function        : jsrc
Partition       : jsrc-a
Dest-realm      : outer-realm
Dest-host       : outer-host
Metric          :      50
Score           :      6
```

show network-access gx-plus

Syntax	show network-access gx-plus <state statistics sync-state>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display Gx-Plus provisioning state, synchronization state, and statistics information.
Options	state—(Optional) Display Gx-Plus provisioning state. statistics—(Optional) Display Gx-Plus statistics. sync-state—(Optional) Display Gx-Plus synchronization state.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear network-access gx-plus replay on page 1387 clear network-access gx-plus statistics on page 1388
List of Sample Output	show network-access gx-plus state on page 1423 show network-access gx-plus statistics on page 1423 show network-access gx-plus sync-state on page 1423
Output Fields	Table 245 on page 1422 lists the output fields for the show network-access gx-plus command. Output fields are listed in the approximate order in which they appear.

Table 245: show network-access gx-plus Output Fields

Field Name	Field Description
Gx-plus state	State of the Gx-Plus application, including the following: <ul style="list-style-type: none"> Engine created Partition configured Configuration active Diameter interface configured Total number of entries—Number of provisioned, pending, and terminating subscribers. Number of pending entries—Number of pending subscribers. Number of pending logouts—Number of subscribers logging out.
Sync-Event	Type of synchronization event.
Timeout	Number of times notification sent without response.
Gx-plus general counters	Number and state of general events.
Gx-plus sync-event counters	Number and state of synchronization events.

Sample Output

```

show network-access user@host> show network-access gx-plus state
gx-plus state
  Engine created           : yes
  Partition configured     : yes
  Configuration active     : yes
  Diameter interface configured : yes
  Total number of entries  : 0
  Number of pending entries : 0
  Number of pending logouts : 0

show network-access user@host> show network-access gx-plus statistics
gx-plus statistics
Gx-plus general counters:
  Counter                Value
  engine created         1
  initial config: active 1
  recovery: process restart 1
  diameter-app initial config: success 1

Gx-plus sync-event counters:
  Category    Counter    Value
  warm-boot   activated   1

  warm-boot   posted     1

  warm-boot   response    1

  awd         posted     12

  awd         response    12

show network-access user@host> show network-access gx-plus sync-state
gx-plus sync-state
Gx-plus sync-events:
  Sync-Event    Timeout
  cold-boot     6100

```


Distributed Denial-of-Service Protection Operational Mode Commands

Table 246 on page 1425 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot the distributed denial-of-service (DDoS) protection feature. Commands are listed in alphabetical order.

Table 246: DDoS Protection Operational Mode Commands

Task	Command
Clear current DDoS protection statistics or violation states.	<code>clear ddos-protection protocols</code>
Display DDoS protection configuration information and statistics.	<code>show ddos-protection protocols</code>
Display DDoS protection configuration information.	<code>show ddos-protection protocols parameters</code>
Display traffic statistics and DDoS policer violation statistics.	<code>show ddos-protection protocols statistics</code>
Display the number of DDoS policer violations.	<code>show ddos-protection protocols violations</code>
Display DDoS protection global statistics for bandwidth violations.	<code>show ddos-protection statistics</code>
Display the DDoS protection version.	<code>show ddos-protection version</code>



NOTE: For information about how to configure DDoS protection parameters, see the *Junos OS System Basics Configuration Guide*.

clear ddos-protection protocols

Syntax	<code>clear ddos-protection protocols</code> (<i>protocol-group</i> < <i>packet-type</i> > <i>states</i> <i>protocol-group</i> < <i>packet-type</i> > <i>statistics</i> <i>states</i> <i>statistics</i>)
Release Information	Command introduced in Junos OS Release 11.2.
Description	Clear current DDoS protection statistics or violation states for all packet types in all protocol groups, for all packet types in a particular protocol group, or for a particular packet type in a particular protocol group.
Options	<i>protocol-group</i> —(Optional) Protocol group that is cleared. <i>packet-type</i> —(Optional) Packet type in a particular protocol group that is cleared. <i>state</i> —Clear DDoS protection violation states for a packet type, for a protocol group, or for all protocol groups. <i>statistics</i> —Clear DDoS protection statistics such as packet counts and rates for a packet type, for a protocol group, or for all protocol groups.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show ddos-protection protocols on page 1427• show ddos-protection statistics on page 1457• show ddos-protection version on page 1458
List of Sample Output	clear ddos-protection protocols on page 1426
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>clear ddos-protection protocols</code>	<code>user@host> clear ddos-protection protocols dhcpv4 bootp states</code>
--	--

show ddos-protection protocols

Syntax	<code>show ddos-protection protocols <protocol-group (aggregate packet-type)></code>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display DDoS protection configuration and statistics for protocol groups or individual packet types.
Options	<p>none—Display information for all packet types in all protocol groups.</p> <p>aggregate—(Optional) Display DDoS protection information for the aggregate policer. The aggregate option is available for all protocol groups.</p> <p>protocol-group—(Optional) Display DDoS protection information for one of the following protocol groups:</p> <ul style="list-style-type: none"> • anyp—ANCP traffic. • anypv6—ANCPv6 traffic. • arp—ARP traffic. • atm—ATM traffic. • bfd—BFD traffic. • bfdv6—BFDv6 traffic. • bgp—BGP traffic. • bgpv6—BGPv6 traffic. • control—Control traffic. • demux-autosense—Demux autosensing traffic. • dhcipv4—DHCPv4 traffic. • dhcipv6—DHCPv6 traffic. • diameter—Diameter and Gx-Plus traffic. • dns—DNS traffic. • dtcp—DTCP traffic. • dynamic-vlan—Dynamic VLAN exception traffic. • egpv6—EGPv6 traffic. • eoam—EOAM traffic. • esmc—ESMC traffic. • firewall-host—Firewall send-to-host traffic. • firewall-reject—Packets rejected by a firewall. • ftp—FTP traffic.

- **ftp6**—FTPv6 traffic.
- **gre**—GRE traffic.
- **icmp**—ICMP traffic.
- **igmp**—IGMP traffic
- **igmp-snoop**—Control traffic for IGMP snooping.
- **igmpv4v6**—IGMP v4/v6 traffic.
- **igmpv6**—IGMPv6 traffic.
- **ip-fragments**—IP fragments traffic.
- **ip-options**—IP traffic with IP packet header options.
- **ipv4-unclassified**—Unclassified IPv4 host-bound traffic.
- **ipv6-unclassified**—Unclassified IPv6 host-bound traffic.
- **isis**—IS-IS traffic.
- **jfm**—JFM traffic.
- **l2tp**—L2TP traffic.
- **lACP**—LACP traffic.
- **ldp**—LDP traffic.
- **ldpv6**—LDPv6 traffic.
- **lldp**—LLDP traffic.
- **lmp**—LMP traffic.
- **lmpv6**—LMPv6 traffic.
- **mac-host**—Layer 2 MAC send-to-host traffic.
- **mlp**—MLP traffic.
- **msdp**—MSDP traffic.
- **msdpv6**—MSDPv6 traffic.
- **multicast-copy**—Host copy traffic due to multicast routing.
- **mvrp**—MVRP traffic.
- **ntp**—NTP traffic.
- **oam-lfm**—OAM-LFM traffic.
- **ospf**—OSPF traffic.
- **ospfv3v6**—OSPFv3/IPv6 traffic.
- **pfe-alive**—Packet Forwarding Engine keepalive traffic
- **pim**—PIM traffic.
- **pmvrp**—PMVRP traffic.

- **pos**—POS traffic.
- **ppp**—PPP traffic.
- **pppoe**—PPPoE traffic.
- **ptp**—PTP traffic.
- **pvstp**—PVSTP traffic.
- **radius**—RADIUS traffic.
- **redirect**—Traffic that triggers ICMP redirects.
- **rip**—RIP traffic.
- **ripv6**—RIPv6 traffic.
- **rsvp**—RSVP traffic.
- **rsvpv6**—RSVPv6 traffic.
- **services**—Service traffic.
- **snmp**—SNMP traffic.
- **snmpv6**—SNMPv6 traffic.
- **ssh**—SSH traffic.
- **sshv6**—SSHv6 traffic.
- **stp**—STP traffic.
- **tacacs**—TACACS traffic.
- **tcp-flags**—Traffic with TCP flags.
- **telnet**—TELNET traffic.
- **telnetv6**—TELNETv6 traffic.
- **ttl**—TTL traffic.
- **tunnel-fragment**—Tunnel fragments traffic.
- **virtual-chassis**—Virtual chassis traffic.
- **vrrp**—VRRP traffic.
- **vrrpv6**—VRRPv6 traffic.

packet-type—(Optional) Display DDoS protection information for the specified packet type in the protocol group. The available packet types vary by protocol group. Only an aggregate policer is available for protocol groups that are not in the following list.

- **dhcipv4**—The following packet types are available for DHCPv4 traffic:
 - **ack**—DHCPACK packets.
 - **bad-packets**—DHCPv4 packets with bad formats.
 - **bootp**—DHCPBOOTP packets.

- **decline**—DHCPDECLINE packets.
- **discover**—DHCDISCOVER packets.
- **force-renew**—DHCPFORCERENEW packets.
- **inform**—DHCPINFORM packets.
- **lease-active**—DHCPLEASEACTIVE packets.
- **lease-query**—DHCPLEASEQUERY packets.
- **lease-unassigned**—DHCPLEASEUNASSIGNED packets.
- **lease-unknown**—DHCPLEASEUNKNOWN packets.
- **nak**—DHCPNAK packets.
- **no-message-type**—DHCP packets that are missing the message type..
- **offer**—DHCOFFER packets.
- **release**—DHCPACK packets.
- **renew**—DHCPRENEW packets.
- **request**—DHCPREQUEST packets.
- **unclassified**— All unclassified packets in the protocol group.
- **dhcpv6**—The following packet types are available for DHCPv6 traffic:
 - **advertise**—ADVERTISE packets.
 - **confirm**—CONFIRM packets.
 - **decline**—DECLINE packets.
 - **information-request**—INFORMATION-REQUEST packets.
 - **leasequery**—LEASEQUERY packets.
 - **leasequery-data**—LEASEQUERY-DATA packets.
 - **leasequery-done**—LEASEQUERY-DONE packets.
 - **leasequery-reply**—LEASEQUERY-REPLY packets.
 - **rebind**—REBIND packets.
 - **reconfigure**—RECONFIGURE packets.
 - **relay-forward**—RELAY-FORWARD packets.
 - **relay-reply**—RELAY-REPLY packets.
 - **release**—RELEASE packets.

- **renew**—RENEW packets.
- **reply**—REPLY packets.
- **request**—REQUEST packets.
- **solicit**—SOLICIT packets.
- **unclassified**— All unclassified packets in the protocol group.
- **ip-fragments**—The following packet types are available for IP fragments:
 - **first-fragment**—First IP fragment.
 - **trail-fragment**—Last IP fragment.
- **ip-options**—The following packet types are available for IP option traffic:
 - **router-alert**—Router alert options packets.
 - **unclassified**— All unclassified packets in the protocol group.
- **ipv4-unclassified**— All unclassified host-bound IPv4 traffic.
- **ipv6-unclassified**— All unclassified host-bound IPv6 traffic.
- **mlp**—The following MLP packet types are available:
 - **aging-exception**—MLP aging exception packets.
 - **packets**—MLP packets.
 - **unclassified**— All unclassified packets in the protocol group.
- **ppp**—The following PPP packet types are available:
 - **authentication**—PPP authentication protocol packets.
 - **ipcp**—IP Control Protocol packets.
 - **ipv6cp**—IPv6 Control Protocol packets.
 - **isis**—IS-IS packets.
 - **lcp**—Link Control Protocol packets.
 - **mplscp**—MPLS Control Protocol packets.
 - **unclassified**— All unclassified packets in the protocol group.
- **pppoe**—The following PPPoE packet types are available:
 - **padi**—PADI packets.
 - **padm**—PADM packets.
 - **padn**—PADN packets.
 - **pado**—PADO packets.

- **padr**—PADR packets.
- **pads**—PADS packets.
- **padt**—PADT packets.
- **radius**—The following RADIUS packet types are available:
 - **accounting**—RADIUS accounting packets.
 - **authorization**—RADIUS authorization packets.
 - **server**—RADIUS server traffic.
 - **unclassified**— All unclassified packets in the protocol group.
- **tcp-flags**—The following TCP-flagged packet types are available:
 - **established**—TCP ACK and RST connection packets.
 - **initial**—TCP SYN and SYN ACK packets.
- **virtual-chassis**—The following packet types are available for virtual chassis packets:
 - **control-low**—Low-priority control packets.
 - **control-high**—High-priority control packets.
 - **unclassified**— All unclassified packets in the protocol group.
 - **vc-packets**—All exception packets on the virtual chassis link.
 - **vc-ttl-errors**—Virtual chassis TTL error packets.

parameters—(Optional) Display policer configuration information for all packet types for a particular protocol group or for all protocol groups.

statistics—(Optional) Display traffic and policer violation statistics for information for all packet types for a particular protocol group or for all protocol groups.

violations—(Optional) Display information about policer violations for all packet types for a particular protocol group or for all protocol groups.

Required Privilege Level

view

Related Documentation

- [clear ddos-protection protocols on page 1426](#)
- [show ddos-protection protocols parameters on page 1439](#)
- [show ddos-protection protocols statistics on page 1445](#)
- [show ddos-protection protocols violations on page 1455](#)

List of Sample Output

[show ddos-protection protocols on page 1435](#)
[show ddos-protection protocols pppoe padr on page 1437](#)

Output Fields Table 247 on page 1433 lists the output fields for the **show ddos-protection protocols** command. Output fields are listed in the approximate order in which they appear.

Table 247: show ddos-protection protocols Output Fields

Field Name	Field Description
Protocol Group	Name of protocol group.
Packet type	Name of packet type in protocol group.
Bandwidth	Bandwidth policer value; number of packets per second that is allowed before a violation is declared.
Burst	Burst policer value; the maximum number of packets that is allowed in a burst before a violation is declared.
Priority	Priority of the packet type in the event of traffic congestion: low , medium , or high . Lower priority packets can be dropped when insufficient bandwidth is available.
Recover time	Time that must pass since the last violation before the traffic flow is considered to have recovered from the attack. A notification is generated when the timer expires.
Enabled	State of the policer, enabled (Yes) or disabled (No).
Bypass aggregate	State of the bypass aggregate configuration: <ul style="list-style-type: none"> • Yes—The aggregate policer is bypassed. • No—The aggregate policer is enforced. This field appears only for individual policers.
System-wide information	The following information collected for the router: <ul style="list-style-type: none"> • A message indicates whether the policer has been violated • No. of FPCs currently receiving excess traffic—Number of cards that are currently in violation of a policer • No. of FPCs that have received excess traffic—Number of cards that have at some point been in violation of a policer • Violation first detected at—Timestamp of the first violation • Violation last seen at—Timestamp of the last observed violation • Duration of violation—Length of the violation • Number of violations—Number of times the violation has occurred • Received—Number of packets received at all card slots and the Routing Engine • Dropped—Number of packets dropped regardless of where they were dropped • Arrival rate—Current traffic rate for packets arriving from all cards and at the Routing Engine • Max arrival rate—Highest traffic rate for packets arriving from all cards and at the Routing Engine

Table 247: show ddos-protection protocols Output Fields (*continued*)

Field Name	Field Description
Routing Engine information	<p>The following information collected for the Routing Engine:</p> <ul style="list-style-type: none"> • A message indicates whether the policer has been violated; the policer might be passed at the individual cards, but the combined rate of packets arriving at the Routing Engine can exceed the configured policer value • Violation first detected at—Timestamp of the first violation • Violation last seen at—Timestamp of the last observed violation • Duration of violation—Length of the violation • Number of violations—Number of times the violation has occurred • Received—Number of packets received at the Routing Engine from all cards • Dropped—Number of packets dropped at the Routing Engine; includes packets dropped by the aggregate policer and by individual protocol policers • Arrival rate—Current traffic rate for packets arriving at the Routing Engine from all cards • Max arrival rate—Highest traffic rate for packets arriving at the Routing Engine from all cards • Dropped by aggregate policer—Number of packets dropped by the aggregate policer • Dropped by individual policers—Number of packets dropped by individual policer
FPC slot information	<p>The following information collected for the card in the indicated slot:</p> <ul style="list-style-type: none"> • Bandwidth—Bandwidth scaling percentage and the number of packets per second that is allowed before a violation is declared • Burst—Burst scaling percentage and the maximum number of packets that is allowed in a burst before a violation is declared • A message indicates whether the policer has been violated • Violation first detected at—Timestamp of the first violation • Violation last seen at—Timestamp of the last observed violation • Duration of violation—Length of the violation • Number of violations—Number of times the violation has occurred • Received—Number of packets received on the line card • Dropped—Number of packets dropped at the line card; includes packets dropped by the aggregate policer and by individual protocol policers • Arrival rate—Current traffic rate for packets arriving at the line card • Max arrival rate—Highest traffic rate for packets arriving at the line card • Dropped by this policer—Number of packets dropped by the individual policer • Dropped by aggregate policer—Number of packets dropped by the aggregate policer
Bypass aggr.	<p>State of the bypass aggregate configuration:</p> <ul style="list-style-type: none"> • Yes—The aggregate policer configuration is bypassed. • No—The aggregate policer configuration is enforced. <p>Dashes indicate that the bypass aggregate configuration is not available; this is possible only for aggregate policers.</p>

Table 247: show ddos-protection protocols Output Fields (*continued*)

Field Name	Field Description
FPC Mod	Indicates whether configuration has changed from the default for any line cards. <ul style="list-style-type: none"> No—The default configuration has not changed from the default for the packet type. Yes—The default configuration has changed from the default for the packet type

Sample Output

```

user@host> show ddos-protection protocols
show ddos-protection protocols
Protocol Group: IPv4-Unclassified

Packet type: aggregate (Aggregate for unclassified host-bound IPv4 traff)
Aggregate policer configuration:
  Bandwidth:      20000 pps
  Burst:          20000 packets
  Priority:        medium
  Recover time:   300 seconds
  Enabled:        Yes
System-wide information:
  Aggregate bandwidth is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
Routing Engine information:
  Aggregate policer is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
  Dropped by individual policers: 0
FPC slot 1 information:
  Bandwidth: 100% (20000 pps), Burst: 100% (20000 packets), enabled
  Aggregate policer is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
  Dropped by individual policers: 0

Protocol Group: IPv6-Unclassified

Packet type: aggregate (Aggregate for unclassified host-bound IPv6 traff)
Aggregate policer configuration:
  Bandwidth:      20000 pps
  Burst:          20000 packets
  Priority:        medium
  Recover time:   300 seconds
  Enabled:        Yes
System-wide information:
  Aggregate bandwidth is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
Routing Engine information:
  Aggregate policer is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
  Dropped by individual policers: 0

```

```
FPC slot 1 information:
  Bandwidth: 100% (20000 pps), Burst: 100% (20000 packets), enabled
  Aggregate policer is never violated
  Received: 0                      Arrival rate: 0 pps
  Dropped: 0                      Max arrival rate: 0 pps
  Dropped by individual policers: 0

...

Protocol Group: PPPoE

Packet type: aggregate (Aggregate for all PPPoE control traffic)
Aggregate policer configuration:
  Bandwidth: 2000 pps
  Burst: 2000 packets
  Priority: medium
  Recover time: 300 seconds
  Enabled: Yes
System-wide information:
  Aggregate bandwidth is never violated
  Received: 23398498              Arrival rate: 4000 pps
  Dropped: 0                    Max arrival rate: 4002 pps
Routing Engine information:
  Aggregate policer is never violated
  Received: 5853755              Arrival rate: 1002 pps
  Dropped: 0                    Max arrival rate: 1009 pps
  Dropped by individual policers: 0
FPC slot 1 information:
  Bandwidth: 100% (2000 pps), Burst: 100% (2000 packets), enabled
  Aggregate policer is never violated
  Received: 23398498              Arrival rate: 4000 pps
  Dropped: 17549330             Max arrival rate: 4002 pps
  Dropped by individual policers: 17549330

Packet type: padi (PPPoE PADI)
Individual policer configuration:
  Bandwidth: 500 pps
  Burst: 500 packets
  Priority: low
  Recover time: 300 seconds
  Enabled: Yes
  Bypass aggregate: No
System-wide information:
  Bandwidth is being violated!
  No. of FPCs currently receiving excess traffic: 1
  No. of FPCs that have received excess traffic: 1
  Violation first detected at: 2011-04-19 08:23:17 PDT
  Violation last seen at: 2011-04-19 10:01:32 PDT
  Duration of violation: 01:38:15 Number of violations: 1
  Received: 11799251              Arrival rate: 2000 pps
  Dropped: 8849675              Max arrival rate: 2001 pps
Routing Engine information:
  Policer is never violated
  Received: 2950794              Arrival rate: 501 pps
  Dropped: 0                    Max arrival rate: 505 pps
  Dropped by aggregate policer: 0
FPC slot 1 information:
  Bandwidth: 100% (500 pps), Burst: 100% (500 packets), enabled
  Policer is currently being violated!
  Violation first detected at: 2011-04-19 08:23:17 PDT
  Violation last seen at: 2011-04-19 10:01:32 PDT
```

```

    Duration of violation: 01:38:15 Number of violations: 1
    Received: 11799251           Arrival rate: 2000 pps
    Dropped: 8849675           Max arrival rate: 2001 pps
    Dropped by this policer: 8849675
    Dropped by aggregate policer: 0
...

Packet type: padr (PPPoE PADR)
Individual policer configuration:
    Bandwidth: 500 pps
    Burst: 500 packets
    Priority: medium
    Recover time: 300 seconds
    Enabled: Yes
    Bypass aggregate: No
System-wide information:
    Bandwidth is being violated!
    No. of FPCs currently receiving excess traffic: 1
    No. of FPCs that have received excess traffic: 1
    Violation first detected at: 2011-04-19 08:23:17 PDT
    Violation last seen at: 2011-04-19 10:04:27 PDT
    Duration of violation: 01:41:10 Number of violations: 1
    Received: 12149327           Arrival rate: 2000 pps
    Dropped: 9112247           Max arrival rate: 2001 pps
Routing Engine information:
    Policer is never violated
    Received: 3037111           Arrival rate: 500 pps
    Dropped: 0                 Max arrival rate: 504 pps
    Dropped by aggregate policer: 0
FPC slot 1 information:
    Bandwidth: 100% (500 pps), Burst: 100% (500 packets), enabled
    Policer is currently being violated!
    Violation first detected at: 2011-04-19 08:23:17 PDT
    Violation last seen at: 2011-04-19 10:04:27 PDT
    Duration of violation: 01:41:10 Number of violations: 1
    Received: 12149327           Arrival rate: 2000 pps
    Dropped: 9112247           Max arrival rate: 2001 pps
    Dropped by this policer: 9112247
    Dropped by aggregate policer: 0
...

```

```

show ddos-protection protocols pppoe padr
user@host> show ddos-protection protocols pppoe padr
Protocol Group: PPPoE

```

```

Packet type: padr (PPPoE PADR)
Individual policer configuration:
    Bandwidth: 500 pps
    Burst: 500 packets
    Priority: medium
    Recover time: 300 seconds
    Enabled: Yes
    Bypass aggregate: No
System-wide information:
    Bandwidth is being violated!
    No. of FPCs currently receiving excess traffic: 1
    No. of FPCs that have received excess traffic: 1
    Violation first detected at: 2011-04-19 08:23:17 PDT
    Violation last seen at: 2011-04-19 10:04:27 PDT
    Duration of violation: 01:41:10 Number of violations: 1
    Received: 12149327           Arrival rate: 2000 pps

```

```

Dropped: 9112247          Max arrival rate: 2001 pps
Routing Engine information:
  Policer is never violated
  Received: 3037111        Arrival rate: 500 pps
  Dropped: 0              Max arrival rate: 504 pps
  Dropped by aggregate policer: 0
FPC slot 1 information:
  Bandwidth: 100% (500 pps), Burst: 100% (500 packets), enabled
  Policer is currently being violated!
  Violation first detected at: 2011-04-19 08:23:17 PDT
  Violation last seen at: 2011-04-19 10:04:27 PDT
  Duration of violation: 01:41:10 Number of violations: 1
  Received: 12149327       Arrival rate: 2000 pps
  Dropped: 9112247        Max arrival rate: 2001 pps
  Dropped by this policer: 9112247
  Dropped by aggregate policer: 0

```

show ddos-protection protocols parameters

Syntax	<code>show ddos-protection protocols <protocol-group> parameters</code> <code><brief detail></code>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display DDoS protection configuration information for protocol groups or individual packet types.
Options	<p><code>none</code>—Display information for all protocol groups or for a particular protocol group.</p> <p><code>brief detail</code>—(Optional) Display the specified level of output. The brief output displays basic function information. The detail output adds information to the brief output; it is identical to the output displayed when you choose no option.</p> <p><code>protocol-group</code>—(Optional) Display DDoS protection information for a particular protocol group. See show ddos-protection protocols for a list of available groups.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear ddos-protection protocols on page 1426 • show ddos-protection protocols on page 1427 • show ddos-protection protocols statistics on page 1445 • show ddos-protection protocols violations on page 1455
List of Sample Output	<p><code>show ddos-protection protocols parameters</code> on page 1441</p> <p><code>show ddos-protection protocols parameters brief</code> on page 1442</p> <p><code>show ddos-protection protocols dhcpv4 parameters brief</code> on page 1443</p> <p><code>show ddos-protection protocols dhcpv4 parameters</code> on page 1443</p>
Output Fields	Table 248 on page 1439 lists the output fields for the show ddos-protection protocols parameters command. Output fields are listed in the approximate order in which they appear.

Table 248: show ddos-protection protocols parameters Output Fields

Field Name	Field Description	Level of Output
Protocol Group	Name of protocol group.	All levels
Packet type	Name of packet type in protocol group.	All levels
Bandwidth	<p>Bandwidth policer value; number of packets per second that is allowed before a violation is declared.</p> <p>In the brief output, an asterisk indicates the value has been modified from the default.</p>	All levels

Table 248: show ddos-protection protocols parameters Output Fields (*continued*)

Field Name	Field Description	Level of Output
Burst	<p>Burst policer value; the maximum number of packets that is allowed in a burst before a violation is declared.</p> <p>In the brief output, an asterisk indicates the value has been modified from the default.</p>	All levels
Priority	<p>Priority of the packet type in the event of traffic congestion: low, medium, or high. Lower priority packets can be dropped when insufficient bandwidth is available.</p> <p>In the brief output, an asterisk indicates the value has been modified from the default.</p>	All levels
Recover time	<p>Time that must pass since the last violation before the traffic flow is considered to have recovered from the attack. A notification is generated when the timer expires.</p> <p>In the brief output, an asterisk indicates the value has been modified from the default.</p>	All levels
Enabled	State of the policer, enabled (Yes) or disabled (No).	detail none
Bypass aggregate	<p>State of the bypass aggregate configuration:</p> <ul style="list-style-type: none"> • Yes—The aggregate policer is bypassed. • No—The aggregate policer is enforced. <p>This field appears only for individual policers.</p>	detail none
FPC slot information	<p>The following configuration information for the card in the indicated slot:</p> <ul style="list-style-type: none"> • Bandwidth—Bandwidth scale and the number of packets per second that is allowed before a violation is declared • Burst—Burst scale and the maximum number of packets that is allowed in a burst before a violation is declared • enabled or disabled—State of the line card policer 	detail none
Number of policers modified	<p>Number of policers that have been changed from the default configuration.</p> <p>An asterisk by a particular value indicates that value has been modified.</p>	brief
Policer Enabled	State of the policer, enabled (Yes) or disabled (No).	brief
Bypass aggr.	<p>State of the bypass aggregate configuration:</p> <ul style="list-style-type: none"> • Yes—The aggregate policer is bypassed. • No—The aggregate policer is enforced. <p>Dashes indicate that the bypass aggregate configuration is not available; this is possible only for aggregate policers.</p>	brief

Table 248: show ddos-protection protocols parameters Output Fields (*continued*)

Field Name	Field Description	Level of Output
FPC Mod	<p>Indicates whether configuration has changed from the default for any line cards.</p> <ul style="list-style-type: none"> No—The default configuration has not changed from the default for the packet type. Yes—The default configuration has changed from the default for the packet type 	brief

Sample Output

```

user@host> show ddos-protection protocols parameters
show ddos-protection protocols parameters Protocol Group: IPv4-Unclassified

Packet type: aggregate (Aggregate for unclassified host-bound IPv4 traff)
Aggregate policer configuration:
  Bandwidth:      20000 pps
  Burst:          20000 packets
  Priority:        medium
  Recover time:   300 seconds
  Enabled:        Yes
FPC slot 1 information:
  Bandwidth: 100% (20000 pps), Burst: 100% (20000 packets), enabled

Protocol Group: IPv6-Unclassified

Packet type: aggregate (Aggregate for unclassified host-bound IPv6 traff)
Aggregate policer configuration:
  Bandwidth:      20000 pps
  Burst:          20000 packets
  Priority:        medium
  Recover time:   300 seconds
  Enabled:        Yes
FPC slot 1 information:
  Bandwidth: 100% (20000 pps), Burst: 100% (20000 packets), enabled

...

Protocol Group: PPPoE

Packet type: aggregate (Aggregate for all PPPoE control traffic)
Aggregate policer configuration:
  Bandwidth:      800 pps
  Burst:          2000 packets
  Priority:        medium
  Recover time:   300 seconds
  Enabled:        Yes
FPC slot 1 information:
  Bandwidth: 100% (800 pps), Burst: 100% (2000 packets), enabled

Packet type: padi (PPPoE PADI)
Individual policer configuration:
  Bandwidth:      500 pps
  Burst:          500 packets
  Priority:        low
  Recover time:   300 seconds
  Enabled:        Yes

```

```

    Bypass aggregate: No
FPC slot 1 information:
    Bandwidth: 100% (500 pps), Burst: 100% (500 packets), enabled

```

```

Packet type: pado (PPPoE PADO)
Individual policer configuration:
    Bandwidth:      0 pps
    Burst:          0 packets
    Priority:        low
    Recover time:    300 seconds
    Enabled:        Yes
    Bypass aggregate: No
FPC slot 1 information:
    Bandwidth: 100% (0 pps), Burst: 100% (0 packets), enabled

```

```

Packet type: padr (PPPoE PADR)
Individual policer configuration:
    Bandwidth:      500 pps
    Burst:          500 packets
    Priority:        medium
    Recover time:    300 seconds
    Enabled:        Yes
    Bypass aggregate: No
FPC slot 1 information:
    Bandwidth: 100% (500 pps), Burst: 100% (500 packets), enabled

```

show ddos-protection protocols parameters brief

```
user@host> show ddos-protection protocols parameters brief
```

```
Number of policers modified: 3
```

Protocol group	Packet type	Bandwidth (pps)	Burst (pkts)	Priority	Recover time(sec)	Policer enabled	Bypass aggr.	FPC mod
ipv4-uncls	aggregate	20000	20000	medium	300	Yes	--	No
ipv6-uncls	aggregate	20000	20000	medium	300	Yes	--	No
dynvlan	aggregate	1000	500	low	300	Yes	--	No
ppp	aggregate	16000	16000	medium	300	Yes	--	No
ppp	unclass	1000	500	low	300	Yes	No	No
ppp	lcp	12000	12000	low	300	Yes	No	No
ppp	auth	2000	2000	medium	300	Yes	No	No
ppp	ipcp	2000	2000	high	300	Yes	No	No
ppp	ipv6cp	2000	2000	high	300	Yes	No	No
ppp	mplscp	2000	2000	high	300	Yes	No	No
ppp	isis	2000	2000	high	300	Yes	No	No
pppoe	aggregate	800*	2000	medium	300	Yes	--	No
pppoe	padi	500	500	low	300	Yes	No	No
pppoe	pado	0	0	low	300	Yes	No	No
pppoe	padr	500	500	medium	300	Yes	No	No
pppoe	pads	0	0	low	300	Yes	No	No
pppoe	padt	1000	1000	high	300	Yes	No	No
pppoe	padm	0	0	low	300	Yes	No	No
pppoe	padn	0	0	low	300	Yes	No	No
dhcpv4	aggregate	669*	5000	medium	300	Yes	--	No
dhcpv4	unclass..	300	150	low	300	Yes	No	No
dhcpv4	discover	100*	500	low	300	Yes	No	No
dhcpv4	offer	1000	1000	low	300	Yes	No	No
dhcpv4	request	1000	1000	medium	300	Yes	No	No
dhcpv4	decline	500	500	low	300	Yes	No	No
dhcpv4	ack	500	500	medium	300	Yes	No	No
dhcpv4	nak	500	500	low	300	Yes	No	No
dhcpv4	release	2000	2000	high	300	Yes	No	No
dhcpv4	inform	500	500	low	300	Yes	No	No
dhcpv4	renew	2000	2000	high	300	Yes	No	No
dhcpv4	forcerenew	2000	2000	high	300	Yes	No	No

dhcpv4	leasequery	2000	2000	high	300	Yes	No	No
dhcpv4	leaseuna..	2000	2000	high	300	Yes	No	No
dhcpv4	leaseunk..	2000	2000	high	300	Yes	No	No
dhcpv4	leaseact..	2000	2000	high	300	Yes	No	No
dhcpv4	bootp	300	300	low	300	Yes	No	No
dhcpv4	no-msgtype	0	0	low	300	Yes	No	No
dhcpv4	bad-pack..	0	0	low	300	Yes	No	No

...

icmp	aggregate	20000	20000	high	300	Yes	--	No
igmp	aggregate	20000	20000	high	300	Yes	--	No
ospf	aggregate	20000	20000	high	300	Yes	--	No
rsvp	aggregate	20000	20000	high	300	Yes	--	No
pim	aggregate	20000	20000	high	300	Yes	--	No
rip	aggregate	20000	20000	high	300	Yes	--	No
ptp	aggregate	20000	20000	high	300	Yes	--	No
bfd	aggregate	20000	20000	high	300	Yes	--	No
lmp	aggregate	20000	20000	high	300	Yes	--	No
ldp	aggregate	20000	20000	high	300	Yes	--	No
msdp	aggregate	20000	20000	high	300	Yes	--	No
bgp	aggregate	20000	20000	low	300	Yes	--	No
vrrp	aggregate	20000	20000	high	300	Yes	--	No
telnet	aggregate	20000	20000	low	300	Yes	--	No
ftp	aggregate	20000	20000	low	300	Yes	--	No
ssh	aggregate	20000	20000	low	300	Yes	--	No
snmp	aggregate	20000	20000	low	300	Yes	--	No
ancp	aggregate	20000	20000	low	300	Yes	--	No

...

show ddos-protection protocols dhcpv4 parameters brief

**protocols dhcpv4
parameters brief**

user@host> show ddos-protection protocols dhcpv4 parameters brief
Number of policers modified: 2

Protocol group	Packet type	Bandwidth (pps)	Burst (pkts)	Priority	Recover time(sec)	Policer enabled	Bypass aggr.	FPC mod
dhcpv4	aggregate	669*	5000	medium	300	Yes	--	No
dhcpv4	unclass..	300	150	low	300	Yes	No	No
dhcpv4	discover	100*	500	low	300	Yes	No	No
dhcpv4	offer	1000	1000	low	300	Yes	No	No
dhcpv4	request	1000	1000	medium	300	Yes	No	No
dhcpv4	decline	500	500	low	300	Yes	No	No
dhcpv4	ack	500	500	medium	300	Yes	No	No
dhcpv4	nak	500	500	low	300	Yes	No	No
dhcpv4	release	2000	2000	high	300	Yes	No	No
dhcpv4	inform	500	500	low	300	Yes	No	No
dhcpv4	renew	2000	2000	high	300	Yes	No	No
dhcpv4	forcerenew	2000	2000	high	300	Yes	No	No
dhcpv4	leasequery	2000	2000	high	300	Yes	No	No
dhcpv4	leaseuna..	2000	2000	high	300	Yes	No	No
dhcpv4	leaseunk..	2000	2000	high	300	Yes	No	No
dhcpv4	leaseact..	2000	2000	high	300	Yes	No	No
dhcpv4	bootp	300	300	low	300	Yes	No	No
dhcpv4	no-msgtype	0	0	low	300	Yes	No	No
dhcpv4	bad-pack..	0	0	low	300	Yes	No	No

show ddos-protection protocols dhcpv4 parameters

**protocols dhcpv4
parameters**

user@host> show ddos-protection protocols dhcpv4 parameters
Protocol Group: DHCPv4

Packet type: aggregate (aggregate for all DHCPv4 traffic)
Aggregate policer configuration:
Bandwidth: 669 pps

Burst: 5000 packets
Priority: medium
Recover time: 300 seconds
Enabled: Yes
FPC slot 1 information:
Bandwidth: 100% (669 pps), Burst: 100% (5000 packets), enabled

Packet type: unclassified (Unclassified DHCPv4 traffic)
Individual policer configuration:
Bandwidth: 300 pps
Burst: 150 packets
Priority: low
Recover time: 300 seconds
Enabled: Yes
Bypass aggregate: No
FPC slot 1 information:
Bandwidth: 100% (300 pps), Burst: 100% (150 packets), enabled

Packet type: discover (DHCPv4 DHCPDISCOVER)
Individual policer configuration:
Bandwidth: 100 pps
Burst: 500 packets
Priority: low
Recover time: 300 seconds
Enabled: Yes
Bypass aggregate: No
FPC slot 1 information:
Bandwidth: 100% (100 pps), Burst: 100% (500 packets), enabled

Packet type: offer (DHCPv4 DHCPOFFER)
Individual policer configuration:
Bandwidth: 1000 pps
Burst: 1000 packets
Priority: low
Recover time: 300 seconds
Enabled: Yes
Bypass aggregate: No
FPC slot 1 information:
Bandwidth: 100% (1000 pps), Burst: 100% (1000 packets), enabled

Packet type: request (DHCPv4 DHCPREQUEST)
Individual policer configuration:
Bandwidth: 1000 pps
Burst: 1000 packets
Priority: medium
Recover time: 300 seconds
Enabled: Yes
Bypass aggregate: No
FPC slot 1 information:
Bandwidth: 100% (1000 pps), Burst: 100% (1000 packets), enabled

...

show ddos-protection protocols statistics

Syntax	<code>show ddos-protection protocols <protocol-group> statistics</code> <code><brief detail></code>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display traffic statistics and DDoS policer violation statistics for all protocol groups or for a particular protocol group.
Options	<p><code>none</code>—Display information for all protocol groups.</p> <p><code>brief detail</code>—(Optional) Display the specified level of output. The brief output displays basic function information. The detail output adds information to the brief output; it is identical to the output displayed when you choose no option.</p> <p><code>protocol-group</code>—(Optional) Display DDoS protection information for a particular protocol group. See show ddos-protection protocols for a list of available groups.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear ddos-protection protocols on page 1426 • show ddos-protection protocols on page 1427 • show ddos-protection protocols parameters on page 1439 • show ddos-protection protocols violations on page 1455
List of Sample Output	<p><code>show ddos-protection protocols statistics</code> on page 1447</p> <p><code>show ddos-protection protocols statistics brief</code> on page 1450</p> <p><code>show ddos-protection protocols pppoe statistics</code> on page 1451</p> <p><code>show ddos-protection protocols pppoe statistics brief</code> on page 1454</p>
Output Fields	Table 249 on page 1445 lists the output fields for the show ddos-protection protocols statistics command. Output fields are listed in the approximate order in which they appear.

Table 249: show ddos-protection protocols statistics Output Fields

Field Name	Field Description	Level of Output
Protocol Group	Name of protocol group.	All levels
Packet type	Name of packet type in protocol group.	All levels

Table 249: show ddos-protection protocols statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
System-wide information	<p>The following information collected for the router:</p> <ul style="list-style-type: none"> • A message indicates whether the policer has been violated • No. of FPCs currently receiving excess traffic—Number of cards that are currently in violation of a policer • No. of FPCs that have received excess traffic—Number of cards that have at some point been in violation of a policer • Violation first detected at—Timestamp of the first violation • Violation last seen at—Timestamp of the last observed violation • Duration of violation—Length of the violation • Number of violations—Number of times the violation has occurred • Received—Number of packets received at all card slots and the Routing Engine • Dropped—Number of packets dropped regardless of where they were dropped • Arrival rate—Current traffic rate for packets arriving from all cards and at the Routing Engine • Max arrival rate—Highest traffic rate for packets arriving from all cards and at the Routing Engine 	detail none
Routing Engine information	<p>The following information collected for the Routing Engine:</p> <ul style="list-style-type: none"> • A message indicates whether the policer has been violated; the policer might be passed at the individual cards, but the combined rate of packets arriving at the Routing Engine can exceed the configured policer value • Violation first detected at—Timestamp of the first violation • Violation last seen at—Timestamp of the last observed violation • Duration of violation—Length of the violation • Number of violations—Number of times the violation has occurred • Received—Number of packets received at the Routing Engine from all cards • Dropped—Number of packets dropped at the Routing Engine; includes packets dropped by the aggregate policer and by individual protocol policers • Arrival rate—Current traffic rate for packets arriving at the Routing Engine from all cards • Max arrival rate—Highest traffic rate for packets arriving at the Routing Engine from all cards • Dropped by aggregate policer—Number of packets dropped by the aggregate policer • Dropped by individual policers—Number of packets dropped by individual policer 	detail none

Table 249: show ddos-protection protocols statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
FPC slot information	<p>The following information collected for the card in the indicated slot:</p> <ul style="list-style-type: none"> • A message indicates whether the policer has been violated • Violation first detected at—Timestamp of the first violation • Violation last seen at—Timestamp of the last observed violation • Duration of violation—Length of the violation • Number of violations—Number of times the violation has occurred • Received—Number of packets received on the line card • Dropped—Number of packets dropped at the line card; includes packets dropped by the aggregate policer and by individual protocol policers • Arrival rate—Current traffic rate for packets arriving at the line card • Max arrival rate—Highest traffic rate for packets arriving at the line card • Dropped by this policer—Number of packets dropped by the individual policer • Dropped by aggregate policer—Number of packets dropped by the aggregate policer 	detail none
Received (packets)	Number of packets of this packet type or protocol group received at all cards and the Routing Engine.	brief
Dropped (packets)	Number of packets dropped for this packet type or protocol group, regardless of where the packets were dropped.	brief
Rate (pps)	Highest observed traffic rate for this packet type or protocol group.	brief
Violation counts	Number of violations of the policer bandwidth.	brief
State	<p>Violation state of the packet type:</p> <ul style="list-style-type: none"> • Ok—Policer has not been violated for this packet type • Viol—Policer has been violated for this packet type 	brief

Sample Output

```

show ddos-protection protocols statistics  user@host> show ddos-protection protocols statistics
                                           Protocol Group: IPv4-Unclassified

                                           Packet type: aggregate
                                           System-wide information:
                                           Aggregate bandwidth is never violated
                                           Received: 0                      Arrival rate: 0 pps
                                           Dropped: 0                      Max arrival rate: 0 pps
                                           Routing Engine information:
                                           Aggregate policer is never violated
                                           Received: 0                      Arrival rate: 0 pps
                                           Dropped: 0                      Max arrival rate: 0 pps
                                           Dropped by individual policers: 0
                                           FPC slot 1 information:
                                           Aggregate policer is never violated
                                           Received: 0                      Arrival rate: 0 pps
                                           Dropped: 0                      Max arrival rate: 0 pps

```

Dropped by individual policers: 0

Protocol Group: IPv6-Unclassified

Packet type: aggregate

System-wide information:

Aggregate bandwidth is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Routing Engine information:

Aggregate policer is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Dropped by individual policers: 0

FPC slot 1 information:

Aggregate policer is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Dropped by individual policers: 0

Protocol Group: PPPoE

Packet type: aggregate

System-wide information:

Aggregate bandwidth is never violated

Received: 61961244 Arrival rate: 4000 pps

Dropped: 0 Max arrival rate: 4002 pps

Routing Engine information:

Aggregate policer is never violated

Received: 15488871 Arrival rate: 1001 pps

Dropped: 0 Max arrival rate: 1011 pps

Dropped by individual policers: 0

FPC slot 1 information:

Aggregate policer is never violated

Received: 61961244 Arrival rate: 4000 pps

Dropped: 46473017 Max arrival rate: 4002 pps

Dropped by individual policers: 46473017

Packet type: padi

System-wide information:

Bandwidth is being violated!

No. of FPCs currently receiving excess traffic: 1

No. of FPCs that have received excess traffic: 1

Violation first detected at: 2011-04-19 08:23:17 PDT

Violation last seen at: 2011-04-19 12:41:23 PDT

Duration of violation: 04:18:06 Number of violations: 1

Received: 30980622 Arrival rate: 2000 pps

Dropped: 23236505 Max arrival rate: 2001 pps

Routing Engine information:

Policer is never violated

Received: 7744433 Arrival rate: 500 pps

Dropped: 0 Max arrival rate: 505 pps

Dropped by aggregate policer: 0

FPC slot 1 information:

Policer is currently being violated!

Violation first detected at: 2011-04-19 08:23:17 PDT

Violation last seen at: 2011-04-19 12:41:23 PDT

Duration of violation: 04:18:06 Number of violations: 1

Received: 30980622 Arrival rate: 2000 pps

Dropped: 23236505 Max arrival rate: 2001 pps

Dropped by this policer: 23236505
Dropped by aggregate policer: 0

Packet type: pado

System-wide information:

Bandwidth is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Routing Engine information:

Policer is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Dropped by aggregate policer: 0

FPC slot 1 information:

Policer is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Dropped by aggregate policer: 0

Packet type: padr

System-wide information:

Bandwidth is being violated!

No. of FPCs currently receiving excess traffic: 1

No. of FPCs that have received excess traffic: 1

Violation first detected at: 2011-04-19 08:23:17 PDT

Violation last seen at: 2011-04-19 12:43:23 PDT

Duration of violation: 04:20:06 Number of violations: 1

Received: 31220846 Arrival rate: 2000 pps

Dropped: 23416690 Max arrival rate: 2001 pps

Routing Engine information:

Policer is never violated

Received: 7806417 Arrival rate: 499 pps

Dropped: 0 Max arrival rate: 506 pps

Dropped by aggregate policer: 0

FPC slot 1 information:

Policer is currently being violated!

Violation first detected at: 2011-04-19 08:23:17 PDT

Violation last seen at: 2011-04-19 12:43:23 PDT

Duration of violation: 04:20:06 Number of violations: 1

Received: 31220846 Arrival rate: 2000 pps

Dropped: 23416690 Max arrival rate: 2001 pps

Dropped by this policer: 23416690

Dropped by aggregate policer: 0

Packet type: pads

System-wide information:

Bandwidth is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Routing Engine information:

Policer is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Dropped by aggregate policer: 0

FPC slot 1 information:

Policer is never violated

Received: 0 Arrival rate: 0 pps

Dropped: 0 Max arrival rate: 0 pps

Dropped by aggregate policer: 0

Packet type: padt

```

System-wide information:
  Bandwidth is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
Routing Engine information:
  Policer is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
  Dropped by aggregate policer: 0
FPC slot 1 information:
  Policer is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
  Dropped by aggregate policer: 0

```

```

Packet type: padm
System-wide information:
  Bandwidth is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
Routing Engine information:
  Policer is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
  Dropped by aggregate policer: 0
FPC slot 1 information:
  Policer is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
  Dropped by aggregate policer: 0

```

```

Packet type: padn
System-wide information:
  Bandwidth is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
Routing Engine information:
  Policer is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
  Dropped by aggregate policer: 0
FPC slot 1 information:
  Policer is never violated
  Received: 0          Arrival rate: 0 pps
  Dropped: 0          Max arrival rate: 0 pps
  Dropped by aggregate policer: 0

```

...

show ddos-protection protocols statistics brief

```
user@host> show ddos-protection protocols statistics brief
```

Protocol group	Packet type	Received (packets)	Dropped (packets)	Rate (pps)	Violation counts	State
ipv4-unc1s	aggregate	0	0	0	0	Ok
ipv6-unc1s	aggregate	0	0	0	0	Ok
dynvlan	aggregate	0	0	0	0	Ok
ppp	aggregate	0	0	0	0	Ok
ppp	unclass	0	0	0	0	Ok
ppp	lcp	0	0	0	0	Ok
ppp	auth	0	0	0	0	Ok
ppp	ipcp	0	0	0	0	Ok

ppp	ipv6cp	0	0	0	0	Ok
ppp	mplscp	0	0	0	0	Ok
ppp	isis	0	0	0	0	Ok
pppoe	aggregate	61561238	0	4000	0	Ok
pppoe	padi	30780619	23086506	2000	1	Viol
pppoe	pado	0	0	0	0	Ok
pppoe	padr	30780619	23086499	2000	1	Viol
pppoe	pads	0	0	0	0	Ok
pppoe	padt	0	0	0	0	Ok
pppoe	padm	0	0	0	0	Ok
pppoe	padn	0	0	0	0	Ok
dhcpv4	aggregate	0	0	0	0	Ok
dhcpv4	unclass..	0	0	0	0	Ok
dhcpv4	discover	0	0	0	0	Ok
dhcpv4	offer	0	0	0	0	Ok
dhcpv4	request	0	0	0	0	Ok
dhcpv4	decline	0	0	0	0	Ok
dhcpv4	ack	0	0	0	0	Ok
dhcpv4	nak	0	0	0	0	Ok
dhcpv4	release	0	0	0	0	Ok
dhcpv4	inform	0	0	0	0	Ok
dhcpv4	renew	0	0	0	0	Ok
dhcpv4	forcerenew	0	0	0	0	Ok
dhcpv4	leasequery	0	0	0	0	Ok
dhcpv4	leaseuna..	0	0	0	0	Ok
dhcpv4	leaseunk..	0	0	0	0	Ok
dhcpv4	leaseact..	0	0	0	0	Ok
dhcpv4	bootp	0	0	0	0	Ok
dhcpv4	no-msgtype	0	0	0	0	Ok
dhcpv4	bad-pack..	0	0	0	0	Ok
...						
icmp	aggregate	0	0	0	0	Ok
igmp	aggregate	0	0	0	0	Ok
ospf	aggregate	0	0	0	0	Ok
rsvp	aggregate	0	0	0	0	Ok
pim	aggregate	0	0	0	0	Ok
rip	aggregate	0	0	0	0	Ok
ptp	aggregate	0	0	0	0	Ok
bfd	aggregate	0	0	0	0	Ok
lmp	aggregate	0	0	0	0	Ok
ldp	aggregate	0	0	0	0	Ok
msdp	aggregate	0	0	0	0	Ok
bgp	aggregate	0	0	0	0	Ok
vrrp	aggregate	0	0	0	0	Ok
telnet	aggregate	0	0	0	0	Ok
...						

**show ddos-protection
protocols pppoe
statistics**

user@host> show ddos-protection protocols pppoe statistics

Protocol Group: PPPoE

Packet type: aggregate

System-wide information:

Aggregate bandwidth is never violated

Received: 60381200 Arrival rate: 4000 pps

Dropped: 0 Max arrival rate: 4002 pps

Routing Engine information:

Aggregate policer is never violated

```
Received: 15095242          Arrival rate: 1001 pps
Dropped: 0                  Max arrival rate: 1011 pps
Dropped by individual policers: 0
FPC slot 1 information:
Aggregate policer is never violated
Received: 60381200          Arrival rate: 4000 pps
Dropped: 45287921           Max arrival rate: 4002 pps
Dropped by individual policers: 45287921

Packet type: padi
System-wide information:
Bandwidth is being violated!
No. of FPCs currently receiving excess traffic: 1
No. of FPCs that have received excess traffic: 1
Violation first detected at: 2011-04-19 08:23:17 PDT
Violation last seen at: 2011-04-19 12:34:48 PDT
Duration of violation: 04:11:31 Number of violations: 1
Received: 30190600          Arrival rate: 2000 pps
Dropped: 22643960           Max arrival rate: 2001 pps
Routing Engine information:
Policer is never violated
Received: 7547621           Arrival rate: 499 pps
Dropped: 0                  Max arrival rate: 505 pps
Dropped by aggregate policer: 0
FPC slot 1 information:
Policer is currently being violated!
Violation first detected at: 2011-04-19 08:23:17 PDT
Violation last seen at: 2011-04-19 12:34:48 PDT
Duration of violation: 04:11:31 Number of violations: 1
Received: 30190600          Arrival rate: 2000 pps
Dropped: 22643960           Max arrival rate: 2001 pps
Dropped by this policer: 22643960
Dropped by aggregate policer: 0

Packet type: pado
System-wide information:
Bandwidth is never violated
Received: 0                  Arrival rate: 0 pps
Dropped: 0                  Max arrival rate: 0 pps
Routing Engine information:
Policer is never violated
Received: 0                  Arrival rate: 0 pps
Dropped: 0                  Max arrival rate: 0 pps
Dropped by aggregate policer: 0
FPC slot 1 information:
Policer is never violated
Received: 0                  Arrival rate: 0 pps
Dropped: 0                  Max arrival rate: 0 pps
Dropped by aggregate policer: 0

Packet type: padr
System-wide information:
Bandwidth is being violated!
No. of FPCs currently receiving excess traffic: 1
No. of FPCs that have received excess traffic: 1
Violation first detected at: 2011-04-19 08:23:17 PDT
Violation last seen at: 2011-04-19 12:34:48 PDT
Duration of violation: 04:11:31 Number of violations: 1
Received: 30190600          Arrival rate: 2000 pps
Dropped: 22643961           Max arrival rate: 2001 pps
Routing Engine information:
```

```

Policer is never violated
Received: 7547621           Arrival rate: 501 pps
Dropped: 0                 Max arrival rate: 506 pps
Dropped by aggregate policer: 0
FPC slot 1 information:
Policer is currently being violated!
Violation first detected at: 2011-04-19 08:23:17 PDT
Violation last seen at: 2011-04-19 12:34:48 PDT
Duration of violation: 04:11:31 Number of violations: 1
Received: 30190600          Arrival rate: 2000 pps
Dropped: 22643961           Max arrival rate: 2001 pps
Dropped by this policer: 22643961
Dropped by aggregate policer: 0

```

```

Packet type: pads
System-wide information:
Bandwidth is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Routing Engine information:
Policer is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Dropped by aggregate policer: 0
FPC slot 1 information:
Policer is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Dropped by aggregate policer: 0

```

```

Packet type: padt
System-wide information:
Bandwidth is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Routing Engine information:
Policer is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Dropped by aggregate policer: 0
FPC slot 1 information:
Policer is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Dropped by aggregate policer: 0

```

```

Packet type: padm
System-wide information:
Bandwidth is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Routing Engine information:
Policer is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Dropped by aggregate policer: 0
FPC slot 1 information:
Policer is never violated
Received: 0                 Arrival rate: 0 pps
Dropped: 0                 Max arrival rate: 0 pps
Dropped by aggregate policer: 0

```

```

Packet type: padn
System-wide information:
  Bandwidth is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
Routing Engine information:
  Policer is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
  Dropped by aggregate policer: 0
FPC slot 1 information:
  Policer is never violated
  Received: 0           Arrival rate: 0 pps
  Dropped: 0           Max arrival rate: 0 pps
  Dropped by aggregate policer: 0

```

```

show ddos-protection protocols pppoe statistics brief
user@host> show ddos-protection protocols pppoe statistics brief

```

Protocol	Packet	Received	Dropped	Rate	Violation	State
group	type	(packets)	(packets)	(pps)	counts	
pppoe	aggregate	60901227	0	4000	0	Ok
pppoe	padi	30450613	22838981	2000	1	Viol
pppoe	pado	0	0	0	0	Ok
pppoe	padr	30450614	22838977	2000	1	Viol
pppoe	pads	0	0	0	0	Ok
pppoe	padt	0	0	0	0	Ok
pppoe	padm	0	0	0	0	Ok
pppoe	padn	0	0	0	0	Ok

show ddos-protection protocols violations

Syntax	show ddos-protection protocols <i><protocol-group></i> violations
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display information about DDoS policer violations for all protocol groups or for a particular protocol group.
Options	<i>protocol-group</i> —(Optional) Display DDoS protection information for a particular protocol group. See show ddos-protection protocols for a list of available groups.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear ddos-protection protocols on page 1426 • show ddos-protection protocols on page 1427 • show ddos-protection protocols parameters on page 1439 • show ddos-protection protocols statistics on page 1445
List of Sample Output	show ddos-protection protocols violations on page 1456 show ddos-protection protocols dhcpv4 violations on page 1456 show ddos-protection protocols pppoe violations on page 1456
Output Fields	Table 250 on page 1455 lists the output fields for the show ddos-protection protocols violations command. Output fields are listed in the approximate order in which they appear.

Table 250: show ddos-protection protocols violations Output Fields

Field Name	Field Description
Number of packet types that are being violated	Number of individual policers and aggregate policers that are currently being violated
Protocol Group	Name of protocol group
Packet type	Name of packet type in protocol group
Bandwidth (pps)	Policer bandwidth
Arrival rate (pps)	Current traffic rate for packets arriving from all cards and at the Routing Engine
Peak rate (pps)	Highest traffic rate for packets arriving from all cards and at the Routing Engine
Policer bandwidth violation detected at	Timestamp of the policer violation

Table 250: show ddos-protection protocols violations Output Fields (*continued*)

Field Name	Field Description
Detected on	Slot number of the card on which the violation was detected

Sample Output

```

user@host> show ddos-protection protocols violations
Number of packet types that are being violated: 2
Protocol  Packet      Bandwidth  Arrival  Peak      Policer bandwidth
group     type        (pps)      rate(pps) rate(pps) violation detected at
pppoe     padi        500        2000     2001      2011-04-19 08:23:17 PDT
          Detected on: FPC-1
pppoe     padr        500        1999     2001      2011-04-19 08:23:17 PDT
          Detected on: FPC-1

user@host> show ddos-protection protocols dhcpv4 violations
Number of packet types that are being violated: 0

user@host> show ddos-protection protocols pppoe violations
Number of packet types that are being violated: 2
Protocol  Packet      Bandwidth  Arrival  Peak      Policer bandwidth
group     type        (pps)      rate(pps) rate(pps) violation detected at
pppoe     padi        500        2000     2001      2011-04-19 08:23:17 PDT
          Detected on: FPC-1
pppoe     padr        500        1999     2001      2011-04-19 08:23:17 PDT
          Detected on: FPC-1

```


show ddos-protection statistics

Syntax	show ddos-protection statistics
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display DDoS protection global statistics for bandwidth violations.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear ddos-protection protocols on page 1426 • show ddos-protection protocols on page 1427 • show ddos-protection version on page 1458
List of Sample Output	show ddos-protection statistics on page 1457
Output Fields	Table 251 on page 1457 lists the output fields for the show ddos-protection statistics command. Output fields are listed in the approximate order in which they appear.

Table 251: show ddos-protection statistics Output Fields

Field Name	Field Description
Currently violated packet types	Number of packet types currently experiencing a bandwidth violation.
Packet types have seen violations	Number of packet types that have experienced a bandwidth violation since statistics were cleared.
Total violation counts	Total number of bandwidth violations.

Sample Output

```

show ddos-protection statistics  user@host> show ddos-protection statistics
                                DDOS protection global statistics:
                                Currently violated packet types:      2
                                Packet types have seen violations:    2
                                Total violation counts:                2

```

show ddos-protection version

Syntax	show ddos-protection version
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display the DDoS protection version.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• clear ddos-protection protocols on page 1426• show ddos-protection protocols on page 1427• show ddos-protection statistics on page 1457
List of Sample Output	show ddos-protection version on page 1458
Output Fields	Table 252 on page 1458 lists the output fields for the show ddos-protection version command. Output fields are listed in the approximate order in which they appear.

Table 252: show ddos-protection version Output Fields

Field Name	Field Description
Version	Version number of the DDoS protection code.
Total protocol groups	Number of protocol groups configured with DDoS protection.
Total tracked packet types	Number of protocol packet types configured with DDoS protection.

Sample Output

```
show ddos-protection version  user@host> show ddos-protection version
                               DDOS protection, Version 1.0
                               Total protocol groups      = 83
                               Total tracked packet types  = 154
```

Dynamic Application Awareness Operational Mode Commands

Table 253 on page 1459 summarizes the command line interface (CLI) commands that you can use to monitor and troubleshoot services pertaining to Dynamic Application Awareness operations.

Table 253: Dynamic Application Awareness Operational Mode Commands

Task	Command
Clear entries from application system cache.	<code>clear services application-identification application-system-cache</code>
Clear application- aware access list (AACL) statistics.	<code>clear services application-aware-access-list statistics</code>
Clear application identification counters.	<code>clear services application-identification counter</code>
Clear IDP ip-action entries.	<code>clear services flows ip-action</code>
Clear local policy decision function (L-PDF) statistics.	<code>clear services local-policy-decision-function statistics</code>
Display application-aware-access-list (AACL) flows.	<code>show services application-aware-access-list flows</code>
Display application-aware-access-list (AACL) statistics.	<code>show services application-aware-access-list statistics</code>
Display the database of cached values stored by the application identification (APPID) system.	<code>show services application-identification application-system-cache</code>
Display application identification (APPID) counter statistics.	<code>show services application-identification counter</code>
Display local policy decision function (L-PDF) flows.	<code>show services local-policy-decision-function flows</code>
Display local policy decision function (L-PDF) statistics.	<code>show services local-policy-decision-function statistics</code>



NOTE: For information about how to configure adaptive services, see the *Junos OS Services Interfaces Configuration Guide*.

clear services application-identification application-system-cache

Syntax	<code>clear services application-identification application-system-cache</code>
Release Information	Command introduced in Junos OS Release 9.5.
Description	Clear entries from application system cache.
Options	This command has no options.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show services application-identification application-system-cache on page 1470

clear services application-aware-access-list statistics

Syntax	clear services application-aware-access-list statistics
Release Information	Command introduced in Junos OS Release 9.5.
Description	Clear application aware access list (AACL) statistics.
Options	This command has no options.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show services application-aware-access-list statistics on page 1468

clear services application-identification counter

Syntax	clear services application-identification counter
Release Information	Command introduced in Junos OS Release 9.5.
Description	Clear application identification counters.
Options	This command has no options.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show services application-identification counter on page 1472

clear services flows ip-action

Syntax	clear services flows ip-action
Release Information	Command introduced in Junos OS Release 10.0.
Description	Clear ip-action entries generated by the router to log, drop, or block traffic based on previous matches. The IP action options and targets are configured at the [edit security idp idp-policy <i>policy-name</i> rulebase-ips rule <i>rule-name</i> then] hierarchy level.
Options	This command has no options.
Required Privilege Level	clear
Output Fields	When you issue this command, you are provided feedback on the status of your request.

Sample Output

```
user@host> clear services flows ip-action
Interface  Service set
ms-4/0/0   idp-service
Flows removed
1
```


clear services local-policy-decision-function statistics

Syntax	clear services local-policy-decision-function statistics
Release Information	Command introduced in Junos OS Release 9.5.
Description	Clear local policy decision function (L-PDF) statistics.
Options	This command has no options.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show services local-policy-decision-function statistics on page 1476

show services application-aware-access-list flows

Syntax	show services application-aware-access-list flows <interface <i>interface-name</i>> <subscriber <i>subscriber-name</i>>
Release Information	Command introduced in Junos OS Release 10.1.
Description	Display application-aware-access-list (AACL) flows
Options	<p>interface <i>interface-name</i>—Displays AACL flows for the specified interface(s) only. The keyword, interface, must be appended to the command.</p> <p>subscriber <i>subscriber-name</i>—Displays AACL flows for the specified subscriber(s) only. The keyword, subscriber, must be appended to the command.</p>
Required Privilege Level	view
List of Sample Output	<p>show services application-aware-access-list flows by interface on page 1467</p> <p>show services application-aware-access-list flows by subscriber on page 1467</p>
Output Fields	Table 254 on page 1466 lists the output fields for the show services application-aware-access-list flows command. Output fields are listed in the approximate order in which they appear.

Table 254: show services application-aware-access-list flows Output Fields

Field Name	Field Description	Level of Output
5-tuple	<p>This field comprises five components of the given flow. The components are:</p> <ul style="list-style-type: none"> • Src IP • Dest IP • Src Port • Dest Port • Protocol 	All levels
Application-ID	The identification number associated with the application.	All levels
Dir	<p>The direction in terms of input or output.</p> <ul style="list-style-type: none"> • Input (I) • Output (O) 	All levels
Off	<p>The status of offload to Packet Forwarding Engine. The various options are:</p> <ul style="list-style-type: none"> • Not Offloaded (-) • Policer Offloaded, Flow Not Offloaded (P) • Policer Not Offloaded, Flow Offloaded (F) • Policer and Offloaded (P+F) 	All levels

Table 254: show services application-aware-access-list flows Output Fields (*continued*)

Field Name	Field Description	Level of Output
Actions	<p>The types of actions displayed are:</p> <ul style="list-style-type: none"> • discard: (D) • accept : A • accept, count [T]: C-A or C-G or C-T • accept, fwd-class [C]: FC • accept, policer [P]: P • accept, count [T], fwd-class [C]: C-T+FC • accept, count [T], policer [P]: C-T+P • accept, fwd-class [C], policer [P]: FC+P • accept, count[T],fwd-class[C],policer[P]: C-T+FC+P 	All levels

Sample Output

```

show services application-aware-access-list flows by interface
user@host>show services application-aware-access-list flows interface ge-1/0/5.0
Interface: ge-1/0/5.0
Service-set: aac1-countApps
Service-set interface: ms-0/0/0
Currently active flows: 2
High watermark flows: 2

5-tuple                               Application-ID
Dir Off Action
-----
1.0.5.2:47072-> 10.10.254.116:80 ,6 junos:http [64]
I - C-T
10.10.254.116:80 -> 1.0.5.2:47072,6 junos:http [64]
O - C-T

show services application-aware-access-list flows by subscriber
user@host>show services application-aware-access-list flows subscriber user@juniper.net
Subscriber: user@juniper.net
Service-set: ss1
Service-set interface: ms-2/0/0
Currently active flows: 4
High watermark flows: 40

5-tuple                               Application-ID   Dir Off Action
150.100.100.100:20109->160.200.200.200:80,17 junos:http [64] I - C-T+FC+P
160.200.200.200:80->150.100.100.100:20109,17 junos:http [64] O - C-T+FC+P
150.100.100.100:20108->160.100.100.100:80,17 junos:http [64] I P+F C-T+FC+P
160.100.100.100:80->150.100.100.100:20108,17 junos:http [64] O P+F C-T+FC+P

```

show services application-aware-access-list statistics

Syntax	show services application-aware-access-list statistics <interface <i>interface-name</i>> <subscriber <i>subscriber-name</i>>
Release Information	Command introduced in Junos OS Release 9.5.
Description	Display application-aware-access-list (AACL) statistics.
Options	interface <i>interface-name</i> —(Optional) Displays AACL statistics for the specified interface(s) only. subscriber <i>subscriber-name</i> —(Optional) Displays AACL statistics for the specified subscriber(s) only.
Required Privilege Level	view
List of Sample Output	show services application-aware-access-list statistics by interface on page 1469 show services application-aware-access-list statistics by subscriber on page 1469
Output Fields	Table 255 on page 1468 lists the output fields for the show services application-aware-access-list statistics command. Output fields are listed in the approximate order in which they appear.

Table 255: show services application-aware-access-list statistics Output Fields

Field Name	Field Description	Level of Output
Interface	Interface name.	Subscriber option
Subscriber	Subscriber identifier.	Interface option
Service-set-interface	Service set interface name.	All levels
Service set	Service set name.	All levels
Application group	Application group identifier.	All levels
Packets in	Number of ingress packets.	All levels
Bytes in	Number of ingress bytes.	All levels
Packets out	Number of egress packets.	All levels
Bytes out	Number of egress bytes.	All levels

Sample Output

```

show services application-aware-access-list statistics by interface
user@host> show services application-aware-access-list statistics interface ge-0/0/0.100
Subscriber: user@juniper.net

service-set: IDP
service-set interface: ms-2/0/0

```

Application group	Application	Packets in	Bytes in
Packets out	Bytes out		
6	junos:ftp [63] 346	5	334

```

show services application-aware-access-list statistics by subscriber
user@host> show services application-aware-access-list statistics subscriber user@juniper.net
Interface: ge-1/1/0.0

Service-set-interface: ms-1/3/0
Service set: aacl-svc-set

```

Application-aware-access-list statistics

Application group	Packets in	Bytes in	Packets out	Bytes
P2P	16284	400	32025	200
FTP	8700	20000	5231000	100

show services application-identification application-system-cache

Syntax `show application-identification application-system-cache
<interface interface-name>`

Release Information Command introduced in Junos OS Release 9.5.
interface option added in Junos OS Release 10.1.

Description Display the database of cached values stored by the application identification (APPID) system.



NOTE: The `show services application-identification application-system-cache` command gives the information only when the application identifier (AI) is matched with the signature.

Options `interface interface-name`—Displays the services interfaces to query.

Required Privilege Level view

List of Sample Output `show application-identification application-system-cache` on page 1470

Output Fields Table 256 on page 1470 lists the output fields for the `command-name` command. Output fields are listed in the approximate order in which they appear.

Table 256: show application-identification application-system-cache Output Fields

Field Name	Field Description	Level of Output
IP address	IP address.	All levels
Port	Port number.	All levels
Protocol	Protocol name.	All levels
Application	Application number.	All levels
CPU	CPU number	All levels

Sample Output

```

show application-identification application-system-cache
user@host> show application-identification application-system-cache interface ms-1/0/0
pic: 2/0
IP address      Port      Protocol  Application  CPU

```

10.1.1.2	81	TCP	63	18
----------	----	-----	----	----

show services application-identification counter

Syntax	show services application-identification counter <interface <i>interface-name</i>>
Release Information	Command introduced in Junos OS Release 9.5. interface option added in Junos OS Release 10.1.
Description	Display application identification (APPID) counter statistics.
Options	interface <i>interface-name</i> —Displays the services interfaces to query.
Required Privilege Level	view
List of Sample Output	show services application-identification counter on page 1473
Output Fields	Table 257 on page 1472 lists the output fields for the show services application-identification counter command. Output fields are listed in the approximate order in which they appear.

Table 257: show services application-identification counter Output Fields

Field Name	Field Description
pic	PIC number.
Total sessions	Total number of sessions.
Total identified sessions	Total number of identified sessions.
Total unidentified sessions	Total number of unidentified sessions.
Total identified-by-address sessions	Number of sessions identified by address.
Total unidentified-by-address sessions	Number of sessions not identified by address.
Total identified-by-port sessions	Number of sessions identified by port.
Total unidentified-by-port sessions	Number of sessions not identified by port.
Total identified-by-icmp sessions	Number of sessions identified by ICMP.
Total unidentified-by-icmp sessions	Number of sessions not identified by ICMP.
Total identified-by-ip-protocol sessions	Number of sessions identified by IP protocol.
Total unidentified-by-ip-protocol sessions	Number of sessions not identified by IP protocol.
Total identified-by-signature sessions	Number of sessions identified by signature.
Total unidentified-by-signature sessions	Number of sessions not identified by signature.

Table 257: show services application-identification counter Output Fields (*continued*)

Field Name	Field Description
Total unspecified encrypted sessions	Number of encrypted sessions not specified by normal processes.
Total encrypted P2P sessions	Number of encrypted point-to-point sessions.
Total application system cache hits	Number of sessions found in the application system cache.
Total application system cache misses	Number of sessions not found in the application system cache.
Total identified-by-protocol sessions	Number of sessions identified by protocol.
Total unidentified-by-protocol sessions	Number of sessions not identified by protocol.

Sample Output

```

show services application-identification counter
user@host> show services application-identification counter interface ms-1/0/0
Counter Statistics:
  pic: 1/1
  Total sessions: 11
  Total identified sessions: 11
  Total un-identified sessions: 0
Address Method
  Total identified-by-address sessions: 0
  Total unidentified-by-address sessions: 11
Port Method
  Total identified-by-port sessions: 1
  Total unidentified-by-port sessions: 0
  Total identified-by-icmp sessions: 0
  Total unidentified-by-icmp sessions: 0
  Total identified-by-ip-protocol sessions: 0
  Total unidentified-by-ip-protocol sessions: 0
Signature Method
  Total identified-by-signature sessions: 11
  Total unidentified-by-signature sessions: 0
  Total unspecified encrypted sessions: 2
  Total encrypted P2P sessions: 2
  Total application system cache hits: 10
  Total application system cache misses: 1
Protocol Method
  Total identified-by-protocol sessions: 0
  Total unidentified-by-protocol sessions: 0

```

show services local-policy-decision-function flows

Syntax	show services local-policy-decision-function flows (interface <i>interface-name</i> subscriber <i>subscriber-name</i>)
Release Information	Command introduced in Junos OS Release 9.5.
Description	Display local policy decision function (L-PDF) flows.
Options	interface <i>interface-name</i> —Display L-PDF flows for the specified interfaces only. subscribers <i>subscriber-name</i> —Display L-PDF flows for the specified subscribers only.
Required Privilege Level	view
List of Sample Output	show services local-policy-decision-function flows by interface on page 1475 show services local-policy-decision-function flows by subscriber on page 1475
Output Fields	Table 258 on page 1474 lists the output fields for the show services local-policy-decision-function flows command. Output fields are listed in the approximate order in which they appear.

Table 258: show services local-policy-decision-function flows Output Fields

Field Name	Field Description
Interface	Interface name.
service-set	Service set name.
service-set-interface	Service set interface name.
Currently active flows	Number of currently active flows.
High watermark flows	Maximum number of flows.
Protocol	(With interface option) Protocol identifier.
Source address	(With interface option) Source address.
Source port	(With interface option) Source port.
Destination address	(With interface option) Destination address.
Destination port	(With interface option) Destination port.
Application	(With interface option) Application name.
Application group	(With interface option) Application group identifier.

Sample Output

```

show services local-policy-
decision-function
flows by interface user@host> show services local-policy-decision-function flows subscriber user@juniper.net
Interface: ge-0/0/5.26

service-set: aac1_ms30
service-set interface: ms-3/0/0

Currently active flows: 0
High watermark flows: 0

show services local-policy-
decision-function
flows by subscriber user@host> show services local-policy-decision-function flows interface ge-1/1/0
Interface: ge-1/1/0.0

service-set: IDP
service-set interface: ms-2/0/0

Currently active flows: 2
High watermark flows: 2

Protocol   Source address   Source port   Destination address   Destination port
Application Application group

tcp        10.1.1.2         81            20.1.1.2              32813
junos:ftp [63]      unknown [1023]

tcp        20.1.1.2         32813         10.1.1.2              81
junos:ftp [63]      unknown [1023]

```

show services local-policy-decision-function statistics

Syntax	show services local-policy-decision-function statistics (<i>interface interface-name</i> <i>subscriber subscriber-name</i>)
Release Information	Command introduced in Junos OS Release 9.5.
Description	Display local-policy-decision-function (L-PDF) statistics.
Options	interface interface-name —Display L-PDF statistics for the specified interface(s) only. subscribersubscriber-name —Display L-PDF statistics for the specified subscriber(s) only.
Required Privilege Level	view
List of Sample Output	show services local-policy-decision-function statistics by interface on page 1477 show services local-policy-decision-function statistics by subscriber on page 1477
Output Fields	Table 259 on page 1476 lists the output fields for the show services local-policy-decision-function statistics command. Output fields are listed in the approximate order in which they appear.

Table 259: show services local-policy-decision-function statistics Output Fields

Field Name	Field Description
Interface	Interface name.
service-set	Service set name.
service-set-interface	Service set interface name.
Application group	Application group identifier.
Application	Application name.
Packets in	Number of ingress packets.
Bytes in	Number of ingress bytes.
Packets out	Number of egress packets.
Bytes out	Number of egress bytes.

Sample Output

```

show services user@host> show services local-policy-decision-function statistics interface ge-1/1/0
local-policy-decision-function Interface: ge-1/1/0.0
statistics by interface service-set: IDP
                        service-set interface: ms-2/0/0

Application group      Application      Packets in      Bytes in
      Packets out      Bytes out
                        junos:ftp [63]      5              334
                        6              346

show services user@host> show services local-policy-decision-function statistics subscriber user@juniper.net
local-policy-decision-function Service-set-interface: ms-1/3/0
statistics by subscriber Service set: aacl-svc-set
Application-aware-access-list statistics

Application group      Packets in      Bytes in      Packets out      Bytes
out
P2P                    16284           400           32025           200
FTP                    8700            20000         5231000         100

```


Flow Collection and Monitoring

Operational Mode Commands

Table 260 on page 1479 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot flow collection and monitoring services. In the table, the commands are grouped by functionality. In the remainder of this chapter, they are listed strictly in alphabetical order.

Table 260: Flow Collection and Monitoring Operational Commands

Task	Command
Active Flow Monitoring	
Display information about next-hop groups.	show forwarding-options next-hop-group
Display information about port-mirroring instances.	show forwarding-options port-mirroring
Display information about aggregated flows.	show services accounting aggregation
Display information about flow aggregation templates.	show services accounting aggregation template
Display error statistics.	show services accounting errors
Display the number of active flow statistics.	show services accounting flow
Display information about the flows being processed by the accounting service.	show services accounting flow-detail
Display memory and flow record statistics.	show services accounting memory
Display packet size distribution histogram.	show services accounting packet-size-distribution
Display available PICs for the service and redundancy model.	show services accounting status
Display the CPU usage of the PIC.	show services accounting usage

Table 260: Flow Collection and Monitoring Operational Commands (*continued*)

Task	Command
Dynamic Flow Capture	
Clear dynamic flow capture information.	clear services dynamic-flow-capture
Display information for a content destination.	show services dynamic-flow-capture content-destination
Display information for a control source.	show services dynamic-flow-capture control-source
Display dynamic flow capture statistics.	show services dynamic-flow-capture statistics
Flow Collection	
Clear the flow collector statistics for one interface or all interfaces.	clear services flow-collector statistics
Switch to the primary server.	request services flow-collector change-destination primary interface
Switch to the secondary server.	request services flow-collector change-destination secondary interface
Transfer a test file to the primary or secondary FTP server configured as a flow collector.	request services flow-collector test-file-transfer
Display information about the files present on the collector service.	show services flow-collector file interface
Display the number of packets received by one or more flow collection interfaces from one or all monitoring interfaces.	show services flow-collector input interface
Display overall statistics for the flow collector application.	show services flow-collector interface
Passive Flow Monitoring	
Clear passive monitoring statistics.	clear passive-monitoring statistics
Display error statistics.	show passive-monitoring error
Display the number of active flow statistics.	show passive-monitoring flow
Display memory and flow record statistics.	show passive-monitoring memory
Display available PICs for the service and redundancy model.	show passive-monitoring status

Table 260: Flow Collection and Monitoring Operational Commands (*continued*)

Task	Command
Display the CPU usage of the PIC.	show passive-monitoring usage



NOTE: Active flow monitoring is supported on the adaptive services interface (*sp-fpc/pic/port*) on J Series, M Series, and T Series routers, and on the flow monitoring (*mo-fpc/pic/port*) interface on the M Series and T Series routers.

Flow collection is supported on the flow collector interface (*cp-fpc/pic/ /port*) on M40e, M160, and M320 routers and on the T Series routers.

Passive flow monitoring is supported on the flow monitoring interface (*mo-fpc/pic/port*) on the M40e, M160, and M320 routers and on the T Series routers.



NOTE: For information about how to configure flow collection and monitoring services, see the *Junos OS Services Interfaces Configuration Guide*.

clear services dynamic-flow-capture

Syntax	clear services dynamic-flow-capture capture-group <i>group-name</i> <criteria-identifier <i>identifier</i> > <destination-identifier <i>identifier</i> > <force> <static>
Release Information	Command introduced in Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Clear dynamic flow capture information for specified capture group.
Options	capture-group <i>group-name</i> —Capture-group identifier. criteria-identifier <i>identifier</i> —(Optional) Criteria identifier. destination-identifier <i>identifier</i> —(Optional) Content destination identifier. force—(Optional) Force clearing of criteria. static—(Optional) Clear static criteria.
Required Privilege Level	network
List of Sample Output	clear services dynamic-flow-capture on page 1482
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services dynamic-flow-capture	user@host> clear services dynamic-flow-capture capture-group flow-a
--	---

clear passive-monitoring statistics

Syntax	clear passive-monitoring statistics (all interface <i>interface-name</i>)
Release Information	Command introduced in Junos OS Release 7.6.
Description	(M40e, M160, and M320 routers and T Series routers only) Clear statistics for one passive monitoring interface or for all passive monitoring interfaces.
Options	all—Clear statistics for all configured passive monitoring interfaces. interface <i>interface-name</i> —Clear statistics for the specified passive monitoring interface (<i>mo-fpc/pic/port</i>).
Required Privilege Level	network
List of Sample Output	clear passive-monitoring statistics on page 1483
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear      user@host> clear passive-monitoring statistics interface mo-5/0/0
passive-monitoring
statistics
```

clear services flow-collector statistics

Syntax	clear services flow-collector statistics (all interface <i>interface-name</i>)
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Clear statistics for one flow collector interface or for all flow collector interfaces.
Options	all—Clear statistics for all configured flow collector interfaces. interface <i>interface-name</i> —Clear statistics for the specified flow collector interface (<i>cp-fpc/pic/port</i>).
Required Privilege Level	network
List of Sample Output	clear services flow-collector statistics on page 1484
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services flow-collector statistics	user@host> clear services flow-collector statistics interface cp-5/0/0 Flow collector interface: cp-5/0/0 Interface state: Collecting flows Statistics cleared successfully
---	--

request services flow-collector change-destination primary interface

Syntax	request services flow-collector change-destination primary interface <i>cp-fpc/pic/port</i> <clear-files> <clear-logs> <immediately gracefully>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Switch to the primary File Transfer Protocol (FTP) server that is configured as a flow collector.
Options	<p>none—Switch to the primary FTP server.</p> <p><i>cp-fpc/pic/port</i>—Specify the flow collector interface name for the primary destination.</p> <p>clear-files—(Optional) Request clearing of existing data files in the FTP wait queue when the switch takes place.</p> <p>clear-logs—(Optional) Request clearing of existing logs when the switch takes place.</p> <p>immediately gracefully—(Optional) Specify whether you want the switch to take place immediately, or to affect only newly created files.</p>
Required Privilege Level	maintenance
List of Sample Output	request services flow-collector change-destination primary interface on page 1485
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request services flow-collector change-destination primary interface	<pre>user@host> request services flow-collector change-destination primary interface cp-6/0/0 Flow collector interface: cp-6/0/0 Interface state: Collecting flows Destination change successful</pre>
---	---

request services flow-collector change-destination secondary interface

Syntax	<code>request services flow-collector change-destination secondary interface <i>cp-fpc/pic/port</i> <clear-files> <clear-logs> <immediately gracefully></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Switch to the secondary File Transfer Protocol (FTP) server that is configured as a flow collector.
Options	<p><code>none</code>—Switch to the secondary FTP server.</p> <p><code>cp-fpc/pic/port</code>—Specify the flow collector interface name (<i>cp-fpc/pic/port</i>) for the secondary destination.</p> <p><code>clear-files</code>—(Optional) Request clearing of existing data files in the FTP wait queue when the switch takes place.</p> <p><code>clear-logs</code>—(Optional) Request clearing of existing logs when the switch takes place.</p> <p><code>immediately gracefully</code>—(Optional) Specify whether you want the switch to take place immediately, or to affect only newly created files.</p>
Required Privilege Level	maintenance
List of Sample Output	request services flow-collector change-destination secondary interface on page 1486
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request services flow-collector change-destination secondary interface	<pre>user@host> request services flow-collector change-destination secondary interface cp-6/0/0 Flow collector interface: cp-6/0/0 Interface state: Collecting flows Destination change successful</pre>
---	---

request services flow-collector test-file-transfer

Syntax	<code>request services flow-collector test-file-transfer <i>filename</i> interface (all <i>cp-fpc/pic/port</i>) (channel-zero channel-one) (primary secondary)</code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Transfer a test file to the primary or secondary File Transfer Protocol (FTP) server that is configured as a flow collector. This command verifies that the output side of the flow collector interface is operating properly.
Options	<p><i>filename</i>—Name of the test file to transfer.</p> <p>interface all <i>cp-fpc/pic/port</i>—Transfer a test file of flows from all configured flow collector interfaces or from only the specified interface.</p> <p>channel-zero channel-one—Transfer a file from export channel 0 (unit 0) or channel 1 (unit 1) of the PIC.</p> <p>primary secondary—Transfer a file to the primary or secondary server configured as a flow collector.</p>
Required Privilege Level	network
List of Sample Output	request services flow-collector test-file-transfer on page 1487
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

request services  user@router> request services flow-collector test-file-transfer test_file interface cp-7/1/0
flow-collector    channel-one primary
test-file-transfer

Flow collector interface: cp-7/1/0
Interface state: Collecting flows
Response: Test file transfer successfully scheduled

```

show forwarding-options next-hop-group

Syntax	<code>show forwarding-options next-hop-group</code> <code><terse brief detail></code> <code><group-name></code>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display current state of next-hop groups.
Options	<code>terse brief detail</code> —(Optional) Display the specified level of output. <code>group-name</code> —(Optional) Display a single next-hop group.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show forwarding-options port-mirroring on page 1491
List of Sample Output	show forwarding-options next-hop-group terse on page 1489 show forwarding-options next-hop-group brief on page 1489 show forwarding-options next-hop-group detail on page 1489
Output Fields	Table 261 on page 1488 lists the output fields for the <code>show forwarding-options next-hop-group</code> command. Output fields are listed in the approximate order in which they appear.

Table 261: show forwarding-options next-hop-group Output Fields

Field Name	Field Description	Level of Output
Next-hop-group	Name of next-hop group.	All levels
Type	Next-hop group type, such as <code>inet</code> or <code>layer-2</code> .	All levels
State	Next-hop group state, either up or down .	All levels
Members Interfaces	Names of interfaces to which next-hop group members belong.	brief detail
Members Subgroup	Names of subgroups to which next-hop group members belong.	brief detail
Number of members configured	Number of next-hop group members configured.	detail
Number of members that are up	Number of next-hop group members that are up.	detail
Number of subgroups configured	Number of subgroups configured.	detail

Table 261: show forwarding-options next-hop-group Output Fields (*continued*)

Field Name	Field Description	Level of Output
Number of subgroups that are up	Number of subgroups that are up.	detail

Sample Output

```

show forwarding-options next-hop-group terse
user@host> show forwarding-options next-hop-group terse
Next-hop-group      Type      State
inet_nhg            inet      up
vpls_nhg            layer-2   up
vpls_nhg_2          layer-2   down

show forwarding-options next-hop-group brief
user@host> show forwarding-options next-hop-group brief
Next-hop-group: inet_nhg
Type: inet      State: up
Members Interfaces:
  ge-2/0/2.101 next-hop 101.2.0.2

Next-hop-group: vpls_nhg
Type: layer-2   State: up
Members Interfaces:
  ge-2/0/1.100
  ge-2/2/9.0
Members Subgroup: vpls_subg
Members Interfaces:
  ge-2/0/1.101
  ge-2/2/9.1

Next-hop-group: vpls_nhg_2
Type: layer-2   State: down

show forwarding-options next-hop-group detail
user@host> show forwarding-options next-hop-group detail
Next-hop-group: inet_nhg
Type: inet      State: up
Number of members configured      : 2
Number of members that are up    : 1
Number of subgroups configured    : 0
Number of subgroups that are up  : 0
Members Interfaces:              State
  ge-2/0/2.101 next-hop 101.2.0.2   up
  ge-2/2/8.2   next-hop 2.8.0.2    down

Next-hop-group: vpls_nhg
Type: layer-2   State: up
Number of members configured      : 2
Number of members that are up    : 2
Number of subgroups configured    : 1
Number of subgroups that are up  : 1
Members Interfaces:              State
  ge-2/0/1.100                    up
  ge-2/2/9.0                      up
Members Subgroup: vpls_subg      up
Number of members configured      : 2
Number of members that are up    : 2

```

```
Members Interfaces:
  ge-2/0/1.101      up
  ge-2/2/9.1        up

Next-hop-group: vpls_nhg_2
Number of members configured : 2
Number of members that are up : 0
Number of subgroups configured : 0
Number of subgroups that are up : 0
Type: layer-2          State: down
Members Interfaces:    State
  ge-2/2/1.100         down
  ge-2/3/9.0           down
```

show forwarding-options port-mirroring

Syntax	show forwarding-options port-mirroring <terse detail> <instance-name>
Release Information	Command introduced in Junos OS Release 9.6.
Description	Display current state of port-mirroring instances.
Options	terse detail —(Optional) Display the specified level of output. instance-name —(Optional) Display a single port-mirroring instance.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show forwarding-options next-hop-group on page 1488
List of Sample Output	show forwarding-options port-mirroring terse on page 1492 show forwarding-options port-mirroring detail on page 1492
Output Fields	Table 262 on page 1491 lists the output fields for the show forwarding-options port-mirroring command. Output fields are listed in the approximate order in which they appear.

Table 262: show forwarding-options port-mirroring Output Fields

Field Name	Field Description	Level of Output
Instance Name	Name of port-mirroring instance.	All levels
Instance Id	Instance identification number.	All levels
State	Instance state, either up or down .	All levels
Input parameters		
Rate	Rate (ratio of packets sampled).	detail
Run-length	Run length (number of consecutive packets sampled).	detail
Maximum-packet-length	Maximum packet length.	detail
Output parameters		
Family	Protocol family.	detail
State	Instance state, either up or down .	detail
Destination	Destination (next-hop group name).	detail

Sample Output

```
show forwarding-options port-mirroring terse
forwarding-options
port-mirroring terse
user@host> show forwarding-options port-mirroring terse
Instance Name      Instance Id  State
&global_instance  1          up
inst1              2          up

show forwarding-options port-mirroring detail
forwarding-options
port-mirroring detail
user@host> show forwarding-options port-mirroring detail
Instance Name: &global_instance
Instance Id: 1      State: up
  Input parameters:
    Rate:          10
    Run-length:    4
    Maximum-packet-length: 0
  Output parameters:
    Family: inet   State: up Destination: inet_nhg
    Family: vpls/bridge State: up Destination: vpls_nhg

Instance Name: inst1
Instance Id: 2      State: up
  Input parameters:
    Rate:          1
    Run-length:    0
    Maximum-packet-length: 200
  Output parameters:
    Family: inet   State: up Destination: inet_nhg
    Family: vpls/bridge State: down Destination: vpls_nhg_2
```

show passive-monitoring error

Syntax	<code>show passive-monitoring error (* all mo-fpc/pic/port)</code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display passive monitoring error statistics.
Options	<code>* all mo-fpc/pic/port</code> —Display error statistics for monitoring interfaces. Use a wildcard character, specify all interfaces, or provide a specific interface name.
Required Privilege Level	view
List of Sample Output	show passive-monitoring error all on page 1494
Output Fields	Table 263 on page 1493 lists the output fields for the show passive-monitoring error command. Output fields are listed in the approximate order in which they appear.

Table 263: show passive-monitoring error Output Fields

Field Name	Field Description
Passive monitoring interface	Name of the passive monitoring interface.
Local interface index	Index counter of the local interface.
Interface state	State of the passive monitoring interface: <ul style="list-style-type: none"> • Monitoring—Specified interface is actively monitoring. • Disabled—Specified interface has been disabled from the CLI. • Not monitoring—The interface is operational, but not monitoring. This condition occurs when an interface first comes online, or when the interface is operational, but no logical unit has been configured under the physical interface. • Unknown—Unknown state. • Error—An error occurred during the process of determining the state of the interface.
Error information	
Packets dropped (no memory)	Number of packets dropped because of memory shortage.
Packets dropped (not IP)	Number of non-IP packets dropped.
Packets dropped (not IPv4)	Number of packets dropped because they failed the IPv4 version check.
Packets dropped (header too small)	Number of packets dropped because the packet length or IP header length was too small.

Table 263: show passive-monitoring error Output Fields (*continued*)

Field Name	Field Description
Memory allocation failures	Number of flow record memory allocation failures. A small number reflects failures to replenish the free list. A large number indicates the monitoring station is almost out of memory space.
Memory free failures	Number of flow record memory free failures.
Memory free list failures	Number of flow records received from free list that failed. Memory is nearly exhausted or too many new flows greater than 128 KB are being created per second.
Memory warning	Whether the flows have exceeded 1 million packets per second (Mpps) on a Monitoring Services PIC or 2 Mpps on a Monitoring Services II PIC. The response can be Yes or No .
Memory overload	Whether the memory has been overloaded. The response can be Yes or No .
PPS overload	Whether the PIC is receiving more packets per second than the configured threshold. The response can be Yes or No .
BPS overload	Whether the PIC is receiving more bits per second than the configured threshold. The response can be Yes or No .

Sample Output

```

show user@host> show passive-monitoring error all
passive-monitoring Passive monitoring interface: mo-4/0/0, Local interface index: 44
error all          Interface state: Monitoring
                   Error information
                   Packets dropped (no memory): 0, Packets dropped (not IP): 0
                   Packets dropped (not IPv4): 0, Packets dropped (header too small): 0
                   Memory allocation failures: 0, Memory free failures: 0
                   Memory free list failures: 0
                   Memory warning: No, Memory overload: No, PPS overload: No, BPS overload: No

Passive monitoring interface: mo-4/1/0, Local interface index: 45
Interface state: Not monitoring
Error information
Packets dropped (no memory): 0, Packets dropped (not IP): 0
Packets dropped (not IPv4): 0, Packets dropped (header too small): 0
Memory allocation failures: 0, Memory free failures: 0
Memory free list failures: 0
Memory warning: No, Memory overload: No, PPS overload: No, BPS overload: No

```

show passive-monitoring flow

Syntax	<code>show passive-monitoring flow (* all mo-<i>fpc/pic/port</i>)</code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display passive flow statistics.
Options	<code>* all mo-<i>fpc/pic/port</i></code> —Display passive flow statistics for monitoring interfaces. Use a wildcard character, specify all interfaces, or provide a specific interface name.
Required Privilege Level	view
List of Sample Output	show passive-monitoring flow all on page 1496
Output Fields	Table 264 on page 1495 lists the output fields for the show passive-monitoring flow command. Output fields are listed in the approximate order in which they appear.

Table 264: show passive-monitoring flow Output Fields

Field Name	Field Description
Passive monitoring interface	Name of the passive monitoring interface.
Local interface index	Index counter of the local interface.
Interface state	State of the passive monitoring interface: <ul style="list-style-type: none"> • Monitoring—Specified interface is actively monitoring. • Disabled—Specified interface has been disabled from the CLI. • Not monitoring—The interface is operational, but not monitoring. This condition occurs when an interface first comes online, or when the interface is operational, but no logical unit has been configured under the physical interface. • Unknown—Unknown state. • Error—An error occurred during the process of determining the state of the interface.
Flow information	
Flow packets	Number of packets received by an operational PIC.
Flow bytes	Number of bytes received by an operational PIC.
Flow packets 10-second rate	Number of packets per second handled by the PIC and displayed as a 10-second average.
Flow bytes 10-second rate	Number of bytes per second handled by the PIC and displayed as a 10-second average.
Active flows	Number of currently active flows tracked by the PIC.
Total flows	Total number of flows received by an operational PIC.

Table 264: show passive-monitoring flow Output Fields (*continued*)

Field Name	Field Description
Flows exported	Total number of flows exported by an operational PIC.
Flows packets exported	Total number of cflowd packets exported by an operational PIC.
Flows inactive timed out	Total number of flows that are exported because of inactivity.
Flows active timed out	Total number of long-lived flows that are exported because of an active timeout.

Sample Output

```

show user@host> show passive-monitoring flow all
passive-monitoring Passive monitoring interface: mo-4/0/0, Local interface index: 44
flow all Interface state: Monitoring
Flow information
Flow packets: 6533434, Flow bytes: 653343400
Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
Active flows: 0, Total flows: 1599
Flows exported: 1599, Flows packets exported: 55
Flows inactive timed out: 1599, Flows active timed out: 0

Passive monitoring interface: mo-4/1/0, Local interface index: 45
Interface state: Monitoring
Flow information
Flow packets: 6537780, Flow bytes: 653778000
Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
Active flows: 0, Total flows: 1601
Flows exported: 1601, Flows packets exported: 55
Flows inactive timed out: 1601, Flows active timed out: 0

```


show passive-monitoring memory

Syntax	<code>show passive-monitoring memory (* all mo-fpc/pic/port)</code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display passive monitoring memory and flow record statistics
Options	<code>* all mo-fpc/pic/port</code> —Display memory and flow record statistics for monitoring interfaces. Use a wildcard character, specify all interfaces, or provide a specific interface name.
Required Privilege Level	view
List of Sample Output	<code>show passive-monitoring memory all</code> on page 1497
Output Fields	Table 265 on page 1497 lists the output fields for the <code>show passive-monitoring memory</code> command. Output fields are listed in the approximate order in which they appear.

Table 265: show passive-monitoring memory Output Fields

Field Name	Field Description
Passive monitoring interface	Name of the passive monitoring interface.
Local interface index	Index counter of the local interface.
Memory utilization	
Allocation count	Number of flow records allocated.
Free count	Number of flow records freed.
Maximum allocated	Maximum number of flow records allocated since the monitoring station booted. This number represents the peak number of flow records allocated at a time.
Allocations per second	Flow records allocated per second during the last statistics interval on the PIC.
Frees per second	Flow records freed per second during the last statistics interval on the PIC.
Total memory used, Total memory free	Total memory currently used and total amount of memory currently free (in bytes).

Sample Output

```

user@host> show passive-monitoring memory all
Passive monitoring interface: mo-4/0/0, Local interface index: 44
Memory utilization
Allocation count: 1600, Free count: 1599, Maximum allocated: 1600

```

```
Allocations per second: 3200, Frees per second: 1438
Total memory used (in bytes): 103579176, Total memory free (in bytes):
163914184
```

show passive-monitoring status

Syntax	<code>show passive-monitoring status (* all mo-fpc/pic/port)</code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display passive monitoring status.
Options	<code>* all mo-fpc/pic/port</code> —Display status for monitoring interfaces. Use a wildcard character, specify all interfaces, or provide a specific interface name.
Required Privilege Level	view
List of Sample Output	show passive-monitoring status all on page 1500
Output Fields	Table 266 on page 1499 lists the output fields for the show passive-monitoring status command. Output fields are listed in the approximate order in which they appear.

Table 266: show passive-monitoring status Output Fields

Output Field	Output Field Description
Passive monitoring interface	Name of the passive monitoring interface.
Local interface index	Index counter of the local interface.
Interface state	Monitoring state of the passive monitoring interface. <ul style="list-style-type: none"> • Monitoring—PIC is actively monitoring. • Disabled—PIC has been disabled using the CLI. • Not monitoring—PIC is operational, but not monitoring. This condition can happen while the PIC is coming online, or when the PIC is operational but has no logical unit configured under the physical interface. • Unknown
Group index	Integer that represents the monitoring group of which the PIC is a member. Group index is a mapping from the group name to an index. It is not related to the number of monitoring groups.
Export interval	Configured export interval for cflowd records, in seconds.
Export format	Configured export format (only cflowd version 5 is supported).
Protocol	Protocol the PIC is configured to monitor (only IPv4 is supported).
Engine type	Configured engine type that is inserted in output cflowd packets.
Engine ID	Configured engine ID that is inserted in output cflowd packets.

Sample Output

```
show user@host> show passive-monitoring status all
passive-monitoring Passive monitoring interface: mo-4/0/0, Local interface index: 44
status all         Interface state: Monitoring
                   Group index: 0
                   Export interval: 15 secs, Export format: cflowd v5
                   Protocol: IPv4, Engine type: 1, Engine ID: 1

Passive monitoring interface: mo-4/1/0, Local interface index: 45
Interface state: Disabled

Passive monitoring interface: mo-4/2/0, Local interface index: 46
Interface state: Not monitoring
```

show passive-monitoring usage

Syntax	show passive-monitoring usage (* all mo-fpc/pic/port)
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display passive monitoring usage statistics.
Options	* all mo-fpc/pic/port—Display usage statistics for monitoring interfaces. Use a wildcard character, specify all interfaces, or provide a specific interface name.
Required Privilege Level	view
List of Sample Output	show passive-monitoring usage all on page 1501
Output Fields	Table 267 on page 1501 lists the output fields for the show passive-monitoring usage command. Output fields are listed in the approximate order in which they appear.

Table 267: show passive-monitoring usage Output Fields

Output Field	Output Field Description
Passive monitoring interface	Name of the passive monitoring interface.
Local interface index	Index counter of the local interface.
CPU utilization	
Uptime	Time, in milliseconds, that the PIC has been operational.
Interrupt time	Total time that the PIC has spent processing packets since the last PIC reset.
Load (5 second)	CPU load on the PIC, averaged more than 5 seconds. The number is a percentage obtained by dividing the time spent on active tasks by the total elapsed time.
Load (1 minute)	CPU load on the PIC, averaged more than 1 minute. The number is a percentage obtained by dividing the time spent on active tasks by the total elapsed time.

Sample Output

```

user@host> show passive-monitoring usage
Passive monitoring interface: mo-4/0/0, Local interface index: 44
CPU utilization
  Uptime: 653155 milliseconds, Interrupt time: 40213754 microseconds
  Load (5 second): 20%, Load (1 minute): 17%

Passive monitoring interface: mo-4/1/0, Local interface index: 45
CPU utilization
  Uptime: 652292 milliseconds, Interrupt time: 40223178 microseconds
  Load (5 second): 22%, Load (1 minute): 15%
```

```
Passive monitoring interface: mo-4/2/0, Local interface index: 46
CPU utilization
  Uptime: 649491 milliseconds, Interrupt time: 40173645 microseconds
  Load (5 second): 22%, Load (1 minute): 10098862%
```

show services accounting aggregation

Syntax	<pre>show services accounting aggregation <i>aggregation-type</i> <<i>aggregation-value</i>> <detail extensive terse> <limit <i>limit-value</i>> < name <i>service-name</i>> <order (bytes packets)></pre>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display information about the aggregated active flows being processed by the accounting service.
Options	<p><i>aggregation-type</i> <<i>aggregation-value</i>>—Display information for a particular aggregation type and optional value:</p> <ul style="list-style-type: none"> as <<i>source-as-value</i> <i>destination-as-value</i> <i>input-snmp-interface-index-value</i> <i>output-snmp-interface-index-value</i>>—Aggregate by autonomous system (AS). destination-prefix <<i>destination-prefix-value</i> <i>destination-as-value</i> <i>output-snmp-interface-index-value</i>>—Aggregate by destination prefix. protocol-port <<i>protocol-value</i> <i>source-port-value</i> <i>destination-port-value</i>>—Aggregate by protocol and port. source-destination-prefix <<i>source-prefix-value</i> <i>destination-prefix-value</i> <i>destination-as-value</i> <i>source-as-value</i> <i>input-snmp-interface-index-value</i> <i>output-snmp-interface-index-value</i>>—Aggregate by source and destination prefix. source-prefix <<i>source-prefix-value</i> <i>source-as-value</i> <i>input-snmp-interface-index-value</i>>—Aggregate by source prefix. <p>detail extensive terse—(Optional) Display the specified level of output.</p> <p>limit <i>limit-value</i>—(Optional) Limit the display output to this number of flows. The default is no limit.</p> <p>name <i>service-name</i>—(Optional) Display information about the aggregated flows for a particular service name.</p> <p>order (bytes packets)—(Optional) Display the flow with the ordering of the highest number, either by byte count or by packet count.</p>
Additional Information	For information about aggregation configuration options, see the Junos OS Services Interfaces Configuration Guide .
Required Privilege Level	view
List of Sample Output	<pre>show services accounting aggregation protocol-port detail on page 1505 show services accounting aggregation source-destination-prefix on page 1505</pre>

show services accounting aggregation source-destination- prefix order packet detail on page 1505

show services accounting aggregation source-destination- prefix extensive limit on page 1506

show services accounting aggregation source-destination-prefix name terse on page 1506

Output Fields Table 268 on page 1504 lists the output fields for the **show services accounting aggregation** command. Output fields are listed in the approximate order in which they appear.

Table 268: show services accounting aggregation Output Fields

Field Name	Field Description
Service Accounting interface	Name of the service accounting interface.
Local interface index	Index corresponding to the service accounting interface.
Service name	Name of a service that was configured at the [edit forwarding-options accounting] hierarchy level. The default display, (default sampling), indicates the service was configured at the [edit forwarding-options sampling-level] hierarchy level.
Protocol	Protocol identifier and number.
Source Port	Source port identifier and number.
Destination Port	Destination port identifier and number.
Source-AS	Source autonomous system (AS) number.
Destination-AS	Destination AS number.
Source Prefix	Source prefix.
Destination Prefix	Destination prefix.
Source address	Source address.
Source prefix length	Source prefix length.
Destination address	Destination address.
Destination prefix length	Destination prefix length.
Input SNMP interface index	SNMP index of the interface the packet came in on.
Output SNMP interface index	SNMP index of the interface the packet went out on.

Table 268: show services accounting aggregation Output Fields (*continued*)

Field Name	Field Description
Start time	Actual time when the packet in this aggregation was first seen.
End time	Actual time when the packet in this aggregation was last seen.
Flow count	Number of flows in the aggregation.
Packet count	Number of packets in the aggregation.
Byte count	Number of bytes in the aggregation.

Sample Output

```

show services accounting aggregation protocol-port detail
user@host> show service accounting aggregation protocol-port detail
Service Accounting interface: mo-2/0/0, Local interface index: 468
Service name: (default sampling)
  Protocol: 6, Source port: 20, Destination port: 20
  Start time: 442349, End time: 6425714
  Flow count: 194, Packet count: 4294964388, Byte count: 4294781184

  Protocol: 0, Source port: 0, Destination port: 0
  Start time: 442349, End time: 6425749
  Flow count: 204, Packet count: 4294964324, Byte count: 4294777088

  Protocol: 17, Source port: 123, Destination port: 123
  Start time: 442364, End time: 6425784
  Flow count: 186, Packet count: 4294964152, Byte count: 4294766080

show services accounting aggregation source-destination-prefix
user@host> show service accounting aggregation source-destination-prefix
Service Accounting interface: rsp0, Local interface index: 171
Service name: (default sampling)
Interface state: Accounting
Source          Destination    Input          Output          Flow    Packet
              Byte          prefix         interface       interface      count      count
prefix          count
11.1.0.0/20     40.0.0.0/24   ge-5/0/1.0     ge-5/0/0.0      256     491761
31472704
11.1.0.0/20     40.0.1.36/32  ge-5/0/1.0     ge-5/0/0.0      1
1926           123264
11.1.0.0/20     40.0.1.59/32  ge-5/0/1.0     ge-5/0/0.0      1
1926           123264
11.1.0.0/20     40.0.3.63/32  ge-5/0/1.0     ge-5/0/0.0      1
1925           123200
11.1.0.0/20     40.0.3.32/32  ge-5/0/1.0     ge-5/0/0.0      1
1925

show services accounting aggregation source-destination-
user@host> show service accounting aggregation source-destination-prefix order packet detail
name t2 input-snmp-interface-index 538
Service Accounting interface: mo-2/0/0, Local interface index: 468
Service name: t2
Source          Destination    Input SNMP     Output SNMP     Flow    Packet    Byte

```

```

prefix order packet
detail

```

Prefix	Prefix	Index	Index	Count	Count	Count
11.1.1.2/20	30.0.167.1/0	538	432	1	60	46483
11.1.1.2/20	30.0.168.1/0	538	432	1	60	5191
11.1.1.2/20	30.0.154.1/0	538	432	2	60	45504
11.1.1.2/20	30.0.76.1/0	538	432	1	60	42177
11.1.1.2/20	30.0.149.1/0	538	432	1	60	49184
11.1.1.2/20	30.0.113.1/0	538	432	2	60	48757

```

show services
accounting
aggregation
source-destination-
prefix extensive limit

```

```

user@host> show service accounting aggregation source-destination-prefix name t2 extensive
limit 3
Service Accounting interface: mo-2/0/0, Local interface index: 542
Service name: t2

Source address: 11.1.1.2, Source prefix length: 20
Destination address: 44.200.176.1, Destination prefix length: 0
Input SNMP interface index: 24, Output SNMP interface index: 26
Source-AS: 69, Destination-AS: 69
Start time: Fri Feb 21 14:16:57 2003, End time: Fri Feb 21 14:22:50 2003
Flow count: 0, Packet count: 6, Byte count: 5340

Source address: 11.1.1.2, Source prefix length: 20
Destination address: 45.243.160.1, Destination prefix length: 0
Input SNMP interface index: 24, Output SNMP interface index: 26
Source-AS: 69, Destination-AS: 69
Start time: Fri Feb 21 14:16:57 2003, End time: Fri Feb 21 14:22:50 2003
Flow count: 0, Packet count: 6, Byte count: 5490

Source address: 11.1.1.2, Source prefix length: 20
Destination address: 45.162.160.1, Destination prefix length: 0
Input SNMP interface index: 24, Output SNMP interface index: 26
Source-AS: 69, Destination-AS: 69
Start time: Fri Feb 21 14:16:57 2003, End time: Fri Feb 21 14:22:50 2003
Flow count: 0, Packet count: 6, Byte count: 4079

```

```

show services
accounting
aggregation
source-destination-prefix
name terse

```

```

user@host> show service accounting aggregation source-destination-prefix name T3 terse
Service Accounting interface: rsp0, Local interface index: 171
Service name: T3
Interface state: Accounting

```

Source	Destination	Input	Output	Flow	Packet
prefix	prefix	interface	interface	count	count
11.1.0.0/20	50.0.0.0/24	ge-5/0/1.0	ge-5/0/0.0	256	639822
40948608					
11.1.0.0/20	50.0.2.67/32	ge-5/0/1.0	ge-5/0/0.0	1	
2485	159040				
11.1.0.0/20	50.0.2.92/32	ge-5/0/1.0	ge-5/0/0.0	1	
2485					

show services accounting aggregation template

Syntax	show services accounting aggregation template <template-name <i>template-name</i>>
Release Information	Command introduced in Junos OS Release 8.3.
Description	Display information for flow aggregation version 9 templates.
Options	<template-name <i>template-name</i>> —(Optional) Display information for the specified template only.
Required Privilege Level	view
List of Sample Output	show services accounting aggregation template on page 1507
Output Fields	Table 269 on page 1507 lists the output fields for the show services accounting aggregation template command. Output fields are listed in the approximate order in which they appear.

Table 269: show services accounting aggregation template Output Fields

Field Name	Field Description
MPLS Label 1	Position of first MPLS label.
MPLS Label 2	Position of second MPLS label.
MPLS Label 3	Position of third MPLS label.
MPLS Top Level Address	Outer top label FEC IP address.
Packet Count	Number of packets sent.

Sample Output

```

show services accounting aggregation template user@host> show services accounting aggregation template template-name mpls
MPLS label 1: 299808, MPLS label 2: 0, MPLS label 3: 0
Source address: 11.1.1.2, Destination address: 10.255.15.22, Top Label Address: 22.15.255.10
Source port: 0, Destination port: 0
Protocol: 61, TOS: 0, TCP flags: 0
Source mask: 24, Destination mask: 32
Input SNMP interface index: 503, Output SNMP interface index: 505
Start time: 40780, End time: 157330
Packet count: 3949198, Byte count: 181663062

```

show services accounting errors

Syntax	show services accounting errors <name (* all <i>service-name</i>)>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display active flow error statistics.
Options	<p>none—Display error statistics for all services accounting instances.</p> <p>name (* all <i>service-name</i>)—(Optional) Display active flow error statistics. Use a wildcard character, specify all services, or provide a specific service name.</p>
Required Privilege Level	view
List of Sample Output	<p>show services accounting errors (Monitoring PIC interface) on page 1509</p> <p>show services accounting errors (Service PIC interface) on page 1509</p>
Output Fields	Table 270 on page 1508 lists the output fields for the show services accounting errors command. Output fields are listed in the approximate order in which they appear.

Table 270: show services accounting errors Output Fields

Field	Field Description
Service Accounting interface	Name of the service accounting interface.
Local interface index	Index counter of the local interface.
Service name	Name of a service that was configured at the [edit forwarding-options accounting] hierarchy level. The default display, (default sampling), indicates the service was configured at the [edit forwarding-options sampling-level] hierarchy level.
Error Information	
Packets dropped (no memory)	Number of packets dropped because of memory shortage.
Packets dropped (not IP)	Number of non-IP packets dropped.
Packets dropped (not IPv4)	Number of packets dropped because they failed the IPv4 version check.
Packets dropped (header too small)	Number of packets dropped because the packet length or IP header length was too small.
Memory allocation failures	Number of flow record memory allocation failures. A small number reflects failures to replenish the free list. A large number indicates the monitoring station is almost out of memory space.

Table 270: show services accounting errors Output Fields (*continued*)

Field	Field Description
Memory free failures	Number of flow record memory free failures.
Memory free list failures	Number of flow records received from the free list that failed. Memory is nearly exhausted, or too many new flows greater than 128 KB are being created per second.
Memory overload	Whether the memory has been overloaded. The response can be Yes or No .
PPS overload	Whether the PIC is receiving more packets per second than the configured threshold. The response can be Yes or No .
BPS overload	Whether the PIC is receiving more bits per second than the configured threshold. The response can be Yes or No .

Sample Output

```

show services accounting errors (Monitoring PIC interface)
user@host> show services accounting errors
Service Accounting interface: mo-1/1/0, Local interface index: 15
Service name: (default sampling)
Error information
  Packets dropped (no memory): 0, Packets dropped (not IP): 0
  Packets dropped (not IPv4): 0, Packets dropped (header too small): 0
  Memory allocation failures: 0, Memory free failures: 0
  Memory free list failures: 0
  Memory overload: No, PPS overload: No, BPS overload: No

```

Sample Output

```

show services accounting errors (Service PIC interface)
user@host> show services accounting errors
Service Accounting interface: sp-0/1/0
Service name: (default sampling)
Error information
  Service sets dropped: 0, Active timeout failures: 0
  Export packet failures: 0, Flow creation failures: 0
  Memory overload: No

Service Accounting interface: sp-1/0/0
Service name: (default sampling)
Error information
  Service sets dropped: 0, Active timeout failures: 0
  Export packet failures: 0, Flow creation failures: 0
  Memory overload: No

```

show services accounting flow

Syntax	show services accounting flow <name (* all <i>service-name</i>)>
Release Information	Command introduced before Junos OS Release 7.4. Junos OS Release 10.0 added the capability to display output from multiple sampling instances.
Description	Display active flow statistics.
Options	none—Display active flow statistics for all service instances. name (* all <i>service-name</i>)—(Optional) Display services accounting active flow statistics. Use a wildcard character, specify all services, or provide a specific service name.
Required Privilege Level	view
List of Sample Output	show services accounting flow (flow aggregation v5/v8 configuration) on page 1511 show services accounting flow (flow aggregation v9 configuration) on page 1511 show services accounting flow name on page 1511 show services accounting flow name all on page 1511 show services accounting flow (multiple sampling instances) on page 1512
Output Fields	Table 271 on page 1510 lists the output fields for the show services accounting flow command. Output fields are listed in the approximate order in which they appear.

Table 271: show services accounting flow Output Fields

Output Field	Output Field Description
Service Accounting interface	Name of the service accounting interface.
Local interface index	Index counter of the local interface.
Service name	Name of a service that was configured at the [edit forwarding-options accounting] hierarchy level. The default display, (default sampling), indicates the service was configured at the [edit forwarding-options sampling-level] hierarchy level.
Flow Information	
Flow packets	Number of packets received by an operational PIC.
Flow bytes	Number of bytes received by an operational PIC.
Flow packets 10-second rate	Number of packets per second handled by the PIC and displayed as a 10-second average.
Flow bytes 10-second rate	Number of bytes per second handled by the PIC and displayed as a 10-second average.

Table 271: show services accounting flow Output Fields (*continued*)

Output Field	Output Field Description
Active flows	Number of currently active flows tracked by the PIC.
Total flows	Total number of flows received by an operational PIC.
Flows exported	Total number of flows exported by an operational PIC.
Flows packets exported	Total number of cflowd packets exported by an operational PIC.
Flows inactive timed out	Total number of flows that are exported because of inactivity.
Flows active timed out	Total number of long-lived flows that are exported because of an active timeout.

Sample Output

```

show services accounting flow (flow aggregation v5/v8 configuration)
user@host> show services accounting flow
Service Accounting interface: rsp0, Local interface index: 171
Service name: (default sampling)
Interface state: Accounting
Flow information
  Flow packets: 87168293, Flow bytes: 5578770752
  Flow packets 10-second rate: 45762, Flow bytes 10-second rate: 2928962
  Active flows: 1000, Total flows: 2000
  Flows exported: 19960, Flows packets exported: 582
  Flows inactive timed out: 1000, Flows active timed out: 29000

show services accounting flow (flow aggregation v9 configuration)
user@host> show services accounting flow
Flow information
  Service Accounting interface: sp-7/1/0, Local interface index: 149
  Flow packets: 0, Flow bytes: 0
  Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
  Active flows: 0, Total flows: 0
  Flows exported: 0, Flows packets exported: 1
  Flows inactive timed out: 0, Flows active timed out: 0

show services accounting flow name
user@host> show services accounting flow count2
Service Accounting interface: mo-1/1/0, Local interface index: 15
Service name: count2
Flow information
  Flow packets: 0, Flow bytes: 0
  Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
  Active flows: 0, Total flows: 0
  Flows exported: 0, Flows packets exported: 0
  Flows inactive timed out: 0, Flows active timed out: 0

show services accounting flow name all
user@host> show services accounting flow name all
Service Accounting interface: rsp0, Local interface index: 171
Service name: T2
Interface state: Accounting
Flow information
  Flow packets: 37609891, Flow bytes: 2407033024
  Flow packets 10-second rate: 45762, Flow bytes 10-second rate: 2928953
  Active flows: 1000, Total flows: 1000

```

```
Flows exported: 6705, Flows packets exported: 198
Flows inactive timed out: 0, Flows active timed out: 13000
```

```
Service Accounting interface: rsp0, Local interface index: 171
```

```
Service name: T3
```

```
Interface state: Accounting
```

```
Flow information
```

```
Flow packets: 37750807, Flow bytes: 2416051712
```

```
Flow packets 10-second rate: 45762, Flow bytes 10-second rate: 2928940
```

```
Active flows: 1000, Total flows: 1000
```

```
Flows exported: 13437, Flows packets exported: 378
```

```
Flows inactive timed out: 0, Flows active timed out: 13000
```

```
Service Accounting interface: rsp0, Local interface index: 171
```

```
Service name: T4
```

```
Interface state: Accounting
```

```
Flow information
```

```
Flow packets: 0, Flow bytes: 0
```

```
Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
```

```
Active flows: 0, Total flows: 0
```

```
Flows exported: 0, Flows packets exported: 0
```

```
Flows inactive timed out: 0, Flows active timed out: 0
```

```
Service Accounting interface: rsp0, Local interface index: 171
```

```
Service name: count1
```

```
Interface state: Accounting
```

```
Flow information
```

```
Flow packets: 0, Flow bytes: 0
```

```
Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
```

```
Active flows: 0, Total flows: 0
```

```
Flows exported: 0, Flows packets exported: 0
```

```
Flows inactive timed out: 0, Flows active timed out: 0
```

**show services
accounting flow
(multiple sampling
instances)**

```
user@host> show services accounting flow
```

```
Flow information
```

```
Service Accounting interface: sp-2/0/0, Local interface index: 215
```

```
Flow packets: 9867, Flow bytes: 631488
```

```
Flow packets 10-second rate: 0, Flow bytes 10-second rate: 628
```

```
Active flows: 2, Total flows: 10
```

```
Flows exported: 4028, Flows packets exported: 6150
```

```
Flows inactive timed out: 8, Flows active timed out: 4026
```

```
Service Accounting interface: sp-2/1/0, Local interface index: 223
```

```
Flow packets: 0, Flow bytes: 0
```

```
Flow packets 10-second rate: 0, Flow bytes 10-second rate: 0
```

```
Active flows: 0, Total flows: 0
```

```
Flows exported: 0, Flows packets exported: 1
```

```
Flows inactive timed out: 0, Flows active timed out: 0
```


show services accounting flow-detail

Syntax show services accounting flow-detail
 <detail | extensive | terse>
 <filters>
 <limit *limit-value*>
 <name (* | all | *service-name*)>
 <order (bytes | packets)>

Release Information Command introduced before Junos OS Release 7.4.

Description Display information about the flows being processed by the accounting service.

Options detail | extensive | terse—(Optional) Display the specified level of output.

filters—(Optional) Filter the display output of the currently active flow records. The following filters query actively changing data structures and result in different results for multiple invocations:

- **destination-as**—Display flow records filtered by destination autonomous system information.
- **destination-port**—Display flow records filtered by destination port information.
- **destination-prefix**—Display flow records filtered by destination prefix information.
- **input-snmp-interface-index**—Display flow records filtered by SNMP input interface index information.
- **output-snmp-interface-index**—Display flow records filtered by SNMP output interface index information.
- **proto**—Display flow records filtered by protocol type.
- **source-as**—Display flow records filtered by source autonomous system information.
- **source-port**—Display flow records filtered by source port information.
- **source-prefix**—Display flow records filtered by source prefix information.
- **tos**—Display flow records filtered by type of service classification.

limit *limit-value*—(Optional) Limit the display output to the specified number of flows. The default is no limit.

name (* | all | *service-name*)—(Optional) Display information about the flows being processed. Use a wildcard character, specify all services, or provide a specific services name.

order (bytes | packets)—(Optional) Display the flow with the ordering of the highest number, either by byte count or by packet count.

Additional Information When no PIC is active, or when no route record has been downloaded from the PIC, this command reports no flows, even though packets are being sampled. This command

displays information about two concurrent sessions only. If a third session is attempted, the command pauses with no output until one of the previous sessions is completed.

Required Privilege Level view

List of Sample Output

- show services accounting flow-detail on page 1515**
- show services accounting flow-detail limit on page 1516**
- show services accounting flow-detail name extensive on page 1516**
- show services accounting flow-detail limit order bytes on page 1516**
- show services accounting flow-detail source-port on page 1517**

Output Fields Table 272 on page 1514 lists the output fields for the **show services accounting flow-detail** command. Output fields are listed in the approximate order in which they appear.

Table 272: show services accounting flow-detail Output Fields

Field Name	Field Description	Output Level
Service Accounting interface	Name of the service accounting interface.	All levels
Service name	Name of a service that was configured at the [edit forwarding-options accounting] hierarchy level. The default display, (default sampling) , indicates the service was configured at the [edit forwarding-options sampling] hierarchy level.	All levels
Local interface index	Index counter of the local interface.	All levels
TOS	Type-of-service value from the IP header.	extensive
Input SNMP interface index	SNMP index of the interface on which the packet came in.	extensive
Output SNMP interface index	SNMP index of the interface on which the packet went out.	extensive
Source-AS	Source AS number.	extensive
Destination-AS	Destination AS number.	extensive
Protocol	Name of the protocol used for the packet flow from the corresponding source address.	All levels
Input interface	Interface on which the packets were received.	All levels
Output interface	Interface on which the packets were transmitted.	All levels
TCP flags	Number of TCP header flags detected in the flow.	extensive
Source address	Address where the flow originated.	All levels
Source port	Name of the source port.	All levels

Table 272: show services accounting flow-detail Output Fields (*continued*)

Field Name	Field Description	Output Level
Source prefix length	Source prefix length.	extensive
Destination address	Address where the flow is sent.	All levels
Destination prefix length	Destination prefix length.	extensive
Destination port	Name of the destination port.	All levels
Start time	Actual time when the packet in this aggregation was first seen.	detail extensive
End time	Actual time when the packet in this aggregation was last seen.	detail extensive
Packet count	Number of packets in the aggregation.	All levels
Byte count	Number of bytes in the aggregation.	All levels
Time since last active timeout	Amount of time elapsed since the last active timeout, in the format <i>hh:mm:ss</i> .	None specified
Packet count for last active timeout	Number of packets in the aggregation since the last active timeout.	None specified
Byte count for last active timeout	Number of bytes in the aggregation since the last active timeout.	None specified

Sample Output

show services accounting flow-detail In this sample, the output is split into three sections, with ellipses (...) indicating where the sections are continued.

```

user@host> show services accounting flow-detail
Service Accounting interface: rsp0, Local interface index: 171
Service name: (default sampling)
Interface state: Accounting

```

Protocol	Input interface	Source address	Source port	Output interface...
tcp(6)	ge-5/0/1.0	11.1.1.2	0	ge-5/0/0.0
tcp(6)	ge-5/0/1.0	11.1.1.2	0	ge-5/0/0.0

Destination address	Destination port	Packet count	Byte count	Time since last active timeout...
40.0.3.149	0	2660	170240	00:00:58
40.0.3.138	0	2660	170240	00:00:58

Packet count for last active timeout	Byte count for last active timeout
2805	179520
2805	179520

show services accounting flow-detail limit In this sample, the output is split into three sections, with ellipses (...) indicating where the sections are continued.

```
user@host> show services accounting flow-detail limit 1
Service Accounting interface: rsp0, Local interface index: 171
Service name: (default sampling)
Interface state: Accounting
Protocol  Input          Source          Source  Output
         interface      address         port    interface...
tcp(6)    ge-5/0/1.0          11.1.1.2        0      ge-5/0/0.0

Destination      Destination      Packet      Byte      Time since last
address          port            count       count    active timeout...
40.0.3.149              0             2158      138112    00:00:47

Packet count for      Byte count for
last active timeout   last active timeout
2827                  180928
```

show services accounting flow-detail name extensive

```
user@host> show services accounting flow-detail name cf-2 extensive
Service Accounting interface: mo-0/2/0, Local interface index: 145
Service name: cf-2
  TOS: 0, Protocol: udp(17), TCP flags: 0
  Source address: 10.10.10.1, Source prefix length: 0, Destination address:
20.20.20.20,
Destination prefix length: 0, Source port: 1173, Destination port: 69
  Input SNMP interface index: 65, Output SNMP interface index: 0, Source-AS: 0,
Destination-AS: 0
  Start time: 62425, End time: 635265, Packet count: 165845, Byte count: 9453165
```

show services accounting flow-detail limit order bytes The output of the following command is displayed over 141 columns, not the standard 80 columns. In this sample, the output is split into three sections, with ellipses (...) indicating where the sections are continued.

```
user@host> show services accounting flow-detail limit 5 order bytes
Service Accounting interface: mo-2/0/0, Local interface index: 356
Service name: (default sampling)
Protocol  Input          Source          Source  Output
         interface      address         port    interface...
icmp(1)    ge-2/3/0.0          11.1.1.2        0      .local.
icmp(1)    ge-2/3/0.0          11.1.1.2        0      .local.
icmp(1)    ge-2/3/0.0          11.1.1.2        0      .local.
icmp(1)    ge-2/3/0.0          11.1.1.2        0      .local.
icmp(1)    ge-2/3/0.0          11.1.1.2        0      .local.

Destination      Destination      Packet      Byte      Time since last
address          port            count       count    active timeout...
51.88.128.2              0             16       12148    Not applicable
52.78.144.2              0             16       15229    Not applicable
51.147.192.2             0             16       13296    Not applicable
51.136.16.2             0             16       13924    Not applicable
50.214.48.2             0             16       13428    Not applicable

Packet count for      Byte count for
last active timeout   last active timeout
Not applicable        Not applicable
Not applicable        Not applicable
Not applicable        Not applicable
```

Not applicable	Not applicable
Not applicable	Not applicable

```
show services accounting flow-detail name cf-2 detail source-port 1173
user@host>
Service Accounting interface: mo-0/2/0, Local interface index: 145
Service name: cf-2
Protocol: udp(17), Source address: 10.10.10.1, Source port: 1173, Destination
address: 20.20.20.20, Destination port: 69
Start time: 62425, End time: 811115, Packet count: 142438, Byte count: 8118966
```

show services accounting memory

Syntax	show services accounting memory
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display memory and flow record statistics.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show services accounting memory (Monitoring PIC interface) on page 1518 show services accounting memory (Service PIC interface) on page 1519
Output Fields	Table 273 on page 1518 lists the output fields for the show services accounting memory command. Output fields are listed in the approximate order in which they appear.

Table 273: show services accounting memory Output Fields

Output Field	Output Field Description
Service Accounting interface	Name of the service accounting interface.
Memory Utilization	
Local interface index	Index counter of the local interface.
Allocation count	Number of flow records allocated.
Free count	Number of flow records freed.
Maximum allocated	Maximum number of flow records allocated since the monitoring station booted. This number represents the peak number of flow records allocated at a time.
Allocations per second	Flow records allocated per second during the last statistics interval on the PIC.
Frees per second	Flow records freed per second during the last statistics interval on the PIC.
Total memory used	Total amount of memory currently used (in bytes).
Total memory free	Total amount of memory currently free (in bytes).

Sample Output

```

show services accounting memory (Monitoring PIC interface)
user@host> show services accounting memory
Service Accounting interface: mo-2/0/0, Local interface index: 468
Memory utilization
Allocation count: 437340, Free count: 433699, Maximum allocated: 6782
Allocations per second: 3366, Frees per second: 6412

```

```
Total memory used (in bytes): 133460320,  
Total memory free (in bytes): 133918352
```

Sample Output

```
show services accounting memory (Service PIC interface) user@host> show services accounting memory  
Service Accounting interface: sp-0/1/0  
Memory utilization  
Allocation count: 1000, Free count: 0  
Allocations per second: 0, Frees per second: 0  
Total memory used (in bytes): 218158272  
Total memory free (in bytes): 587147696  
  
Service Accounting interface: sp-1/0/0  
Memory utilization  
Allocation count: 1000, Free count: 0  
Allocations per second: 0, Frees per second: 0  
Total memory used (in bytes): 218157592  
Total memory free (in bytes): 587148376
```

show services accounting packet-size-distribution

Syntax	show services accounting packet-size-distribution <name (* all <i>service-name</i>)>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display a packet size distribution histogram.
Options	<p>none—Display a packet size distribution histogram of all accounting services.</p> <p>name (* all <i>service-name</i>)—(Optional) Display a packet size distribution histogram. Use a wildcard character, specify all services, or provide a specific services name.</p>
Required Privilege Level	view
List of Sample Output	show services accounting packet-size-distribution name on page 1520
Output Fields	Table 274 on page 1520 lists the output fields for the show services accounting packet-size-distribution command. Output fields are listed in the approximate order in which they appear.

Table 274: show services accounting packet-size-distribution Output Fields

Field Name	Field Description
Service Accounting interface	Name of the service accounting interface.
Service name	Name of a service that was configured at the [edit-forwarding-options accounting] hierarchy level. The default display, (default sampling), indicates the service was configured at the [edit-forwarding-options sampling-level] hierarchy level.
Local interface index	Index counter of the local interface.
Range start	Smallest packet length (in bytes) to count.
Range end	Largest packet length (in bytes) to count.
Number of packets	Count of packets detected in the size between Range start and Range end.
Percentage packets	Percentage of the total number of packets that are in this size range.

Sample Output

```

show services accounting packet-size-distribution name
user@host> show services accounting packet-size-distribution name test3
Service Accounting interface: mo-0/2/0, Local interface index: 163
Service name: test3

```


Range start	Range end	Number of packets	Percentage packets
32	64	2924	100

show services accounting status

Syntax	show services accounting status <name (* all <i>service-name</i>)>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display available Physical Interface Cards (PICs) for accounting services.
Options	<p>none—Display available PICs for all accounting services.</p> <p>name (* all <i>service-name</i>)—(Optional) Display available PICs. Use a wildcard character, specify all services, or provide a specific services name.</p>
Required Privilege Level	view
List of Sample Output	<p>show services accounting status name (Monitoring PIC interface) on page 1523</p> <p>show services accounting status name (Service PIC interface) on page 1523</p>
Output Fields	Table 275 on page 1522 lists the output fields for the show services accounting status command. Output fields are listed in the approximate order in which they appear.

Table 275: show services accounting status Output Fields

Field	Field Description
Service Accounting interface	Name of the service accounting interface.
Service name	Name of a service that was configured at the [edit-forwarding-options accounting] hierarchy level. The default display, (default sampling), indicates the service was configured at the [edit-forwarding-options sampling-level] hierarchy level.
Local interface index	Index counter of the local interface.
Interface state	<p>Accounting state of the passive monitoring interface.</p> <ul style="list-style-type: none"> • Accounting—PIC is actively accounting. • Disabled—PIC has been disabled from the CLI. • Not accounting—PIC is up but not accounting. This can happen while the PIC is coming online, or when the PIC is up but has no logical unit configured under the physical interface. • Unknown
Group index	Integer that represents the monitoring group of which the PIC is a member. Group index is a mapping from the group name to an index. It is not related to the number of monitoring groups.
Export interval (in seconds)	Configured export interval for cflowd records, in seconds.
Export format	Configured export format (only cflowd version 5 is supported).

Table 275: show services accounting status Output Fields (*continued*)

Field	Field Description
Protocol	Protocol the PIC is configured to monitor (only IPv4 is supported).
Engine type	Configured engine type that is inserted in output cflowd packets.
Engine ID	Configured engine ID that is inserted in output cflowd packets.

Sample Output

```

show services user@host> show services accounting status name count1
accounting status Service Accounting interface: mo-2/0/0, Local interface index: 468
name (Monitoring PIC Service name: count1
interface) Interface state: Accounting
Group index: 0
Export interval (in seconds): 60, Export format: cflowd v8
Protocol: IPv4, Engine type: 55, Engine ID: 5

```

Sample Output

```

show services user@host> show services accounting status name
accounting status Service Accounting interface: sp-0/1/0
name (Service PIC Interface state: Accounting
interface) Export format: 9, Route record count: 0
IFL to SNMP index count: 7, AS count: 0
Configuration set: Yes, Route record set: No, IFL SNMP map set: Yes

Service Accounting interface: sp-1/0/0
Interface state: Accounting
Export format: 9, Route record count: 33
IFL to SNMP index count: 7, AS count: 1
Configuration set: Yes, Route record set: Yes, IFL SNMP map set: Yes

```

show services accounting usage

Syntax	show services accounting usage <name <i>service-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display the CPU usage of PIC used for active flow monitoring.
Options	none—Display CPU usage for all service names. name <i>service-name</i> —(Optional) Display CPU usage for the specified service name.
Additional Information	When no route record has been downloaded from the PIC, this command reports no flows, even though packets are being sampled.
Required Privilege Level	view
List of Sample Output	show services accounting usage (Monitoring PIC interface) on page 1525 show services accounting usage (Service PIC interface) on page 1525
Output Fields	Table 276 on page 1524 lists the output fields for the show services accounting usage command. Output fields are listed in the approximate order in which they appear.

Table 276: show services accounting usage Output Fields

Output Field	Output Field Description
Service Accounting interface	Name of the service accounting interface.
Service name	Name of a service that was configured at the [edit-forwarding-options accounting] hierarchy level. The default display, (default sampling), indicates the service was configured at the [edit-forwarding-options sampling-level] hierarchy level.
Local interface index	Index counter of the local interface.
Uptime	Time that the PIC has been operational (in milliseconds).
Interrupt time	Total time that the PIC has spent processing packets since the last PIC reset (in microseconds).
Load (5 second)	CPU load on the PIC, averaged more than 5 seconds. The number is a percentage obtained by dividing the time spent on active tasks by the total elapsed time.
Load (1 minute)	CPU load on the PIC, averaged more than 1 minute. The number is a percentage obtained by dividing the time spent on active tasks by the total elapsed time.

Sample Output

```
show services accounting usage (Monitoring PIC interface) user@host> show services accounting usage
Service Accounting interface: mo-1/1/0, Local interface index: 15
Service name: (default sampling)
CPU utilization
  Uptime: 600413856 milliseconds, Interrupt time: 2403 microseconds
  Load (5 second): 43%, Load (1 minute): 24%
```

Sample Output

```
show services accounting usage (Service PIC interface) user@host> show services accounting usage
Service Accounting interface: sp-0/1/0
Service name: (default sampling)
CPU utilization
  Uptime: 7853940 milliseconds, Interrupt time: 0 microseconds
  Load (5 second): 2%, Load (1 minute): 0%
```

```
Service Accounting interface: sp-0/1/0
Service name: (default sampling)
CPU utilization
  Uptime: 331160 milliseconds, Interrupt time: 0 microseconds
  Load (5 second): 2%, Load (1 minute): 0%
```

show services dynamic-flow-capture content-destination

Syntax	show services dynamic-flow-capture content-destination capture-group <i>group-name</i> destination-identifier <i>identifier</i> <terse>
Release Information	Command introduced in Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Display information about the content destination that receives packets from the dynamic flow capture (DFC) interface.
Options	capture-group <i>group-name</i> —Capture-group identifier. destination-identifier <i>identifier</i> —Content destination identifier. terse—(Optional) Display summary information.
Required Privilege Level	view
List of Sample Output	show services dynamic-flow-capture content-destination on page 1527
Output Fields	Table 277 on page 1526 lists the output fields for the show services dynamic-flow-capture content-destination command. Output fields are listed in the approximate order in which they appear.

Table 277: show services dynamic-flow-capture content-destination Output Fields

Output Field	Output Field Description	Level of Output
Capture group	Name of the capture group.	to be provided
Content destination	Name of the content destination.	to be provided
Criteria	Number of criteria specified.	to be provided
Bandwidth	Bandwidth used by the matched traffic.	to be provided
Matched packets	Number of matched packets sent to the content destination.	to be provided
Matched bytes	Number of matched bytes sent to the content destination.	to be provided
Congestion notifications	Number of notification messages sent.	to be provided

Sample Output

```
show services      user@host> show services dynamic-flow-capture content-destination capture-group g1
dynamic-flow-capture destination-identifier cd1 terse
content-destination      Capture group: g1, Content destination: cd1, Criteria: 0, Bandwidth: 0, Matched
                        packets: 0, Matched bytes: 0, Congestion notifications: 0
```

show services dynamic-flow-capture control-source

Syntax	show services dynamic-flow-capture control-source capture-group <i>group-name</i> control-source <i>identifier</i> <detail terse>
Release Information	Command introduced in Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Display information about the control source that makes dynamic flow capture requests to the dynamic flow capture interface.
Options	capture-group <i>group-name</i> —Capture group identifier. control-source <i>identifier</i> —Control source identifier. detail terse—(Optional) Display the specified level of output.
Required Privilege Level	view
List of Sample Output	show services dynamic-flow-capture control-source on page 1529 show services dynamic-flow-capture control-source detail on page 1529
Output Fields	Table 278 on page 1528 lists the output fields for the show services dynamic-flow-capture control-source command. Output fields are listed in the approximate order in which they appear.

Table 278: show services dynamic-flow-capture control-source Output Fields

Output Field	Output Field Description
Capture group	Name of the capture group.
Control source	Name of the control source.
Criteria added, Criteria add failed	Number of criteria added or added and failed.
Active criteria	Number of active criteria.
Static criteria, Dynamic criteria	Number of static or dynamic criteria.
Control protocol requests	Total number of control protocol requests.
Requests	Number of Add , Delete , List , Refresh , and No-op control protocol requests.
Failed	Number of Add , Delete , List , Refresh , and No-op failed control protocol requests.
Add request rate	Rate of add requests.

Table 278: show services dynamic-flow-capture control-source Output Fields (*continued*)

Output Field	Output Field Description
Add request peak rate	Peak rate of add requests.
Bandwidth across all criteria	Bandwidth used by all the requests.
Total notifications	Total number of notifications sent and the number of notifications by category: Restart , Rollover , Timeout , Congestion , Congestion delete , and Dups (duplicates) dropped.
Criteria deleted	Total number of criteria deleted and the number of deleted criteria by category: Timeout idle , Timeout total , Packets , and Bytes .
Sequence number	Sequence number.

Sample Output

```

show services dynamic-flow-capture control-source user@host> show services dynamic-flow-capture control-source source-identifier cs0_cg0
capture-group cg_0
Capture group: cg_0, Control source: cs0_cg0
Criteria added: 28, Criteria add failed: 0, Active criteria: 0, Control protocol
requests: 28, Add request rate: 0,
Add request peak rate: 1, Bandwidth across all criteria: 0, Total notifications:
1, Criteria deleted: 28, Sequence number: 0

show services dynamic-flow-capture control-source detail user@host> show services dynamic-flow-capture control-source source-identifier cs0_cg0
capture-group cg_0 detail
Capture group: cg_0, Control source: cs0_cg0
Criteria added: 28, Criteria add failed: 0
Active criteria: 0
Static criteria: 0, Dynamic criteria: 0
Control protocol requests: 28

```

	Add	Delete	List	Refresh	No-op
Requests	28	0	0	0	0
Failed	0	0	0	0	0

```

Add request rate: 0
Add request peak rate: 1
Bandwidth across all criteria: 0
Total notifications: 1
Restart: 1, Rollover: 0, No-op: 0, Timeout: 0, Congestion: 0, Congestion
delete: 0, Dups dropped: 0
Criteria deleted: 28
Timeout idle: 0, Timeout total: 0, Packets: 0, Bytes: 0
Sequence number: 0

```

show services dynamic-flow-capture statistics

Syntax	show services dynamic-flow-capture statistics capture-group <i>group-name</i>
Release Information	Command introduced in Junos OS Release 7.4.
Description	(M320 routers and T Series routers only) Display statistics information about the capture group specified for dynamic flow capture.
Options	capture-group <i>group-name</i> —Capture group identifier.
Required Privilege Level	view
List of Sample Output	show services dynamic-flow-capture statistics on page 1531
Output Fields	Table 279 on page 1530 lists the output fields for the show services dynamic-flow-capture statistics command. Output fields are listed in the approximate order in which they appear.

Table 279: show services dynamic-flow-capture statistics Output Fields

Output Field	Output Field Description
Input	<p>Incoming dynamic flow capture packet statistics:</p> <ul style="list-style-type: none"> • Control protocol packets—Number of control protocol packets received. • Captured data packets—Number of data packets captured. • Control IRI packets—Number of control IRI packets received.
Control protocol drops	<p>Control protocol packets dropped for the following reasons:</p> <ul style="list-style-type: none"> • Not IP packets—Dropped packets were not IP packets. • Not UDP packets—Dropped packets were not User Datagram Protocol (UDP) packets. • Invalid destination address—Dropped packets had invalid destination addresses. • No memory—Packets dropped because of insufficient memory. • Unauthorized control source—Packets dropped because the control source was not authenticated. • Bad request—Packets dropped because the request was invalid. • Unknown control source—Packets dropped because the control source was not known. • Not DTCP—Dropped packets did not adhere to the control protocol format. • Bad command line—Packets dropped because of a version mismatch. • Bandwidth exceeded—Packets dropped because the bandwidth was exceeded. • Drop rate due to exceeded bandwidth—Rate of traffic dropped because the bandwidth was exceeded. • Other—Packets dropped for other reasons or undetermined causes.

Table 279: show services dynamic-flow-capture statistics Output Fields (*continued*)

Output Field	Output Field Description
Input drops	<p>Incoming dynamic flow capture packets dropped for the following reasons:</p> <ul style="list-style-type: none"> • Unknown packets—Packets dropped because the packet type was not recognized. • Captured data not IPv4—Packets dropped because they were not IPv4 packets. • Captured data too small—Packets dropped because they were smaller than the size reported in their headers. • Captured data drops—Data packets dropped because of undetermined causes. • Captured data not matched—Packets dropped because they did not match filter criteria. • Bandwidth exceeded—Packets dropped because the bandwidth was exceeded. • Drop rate due to exceeded bandwidth—Rate of traffic dropped because the bandwidth was exceeded.
Output	<p>Outgoing dynamic flow capture packet statistics:</p> <ul style="list-style-type: none"> • Control protocol packets—Number of control protocol packets sent. • Captured data packets—Number of captured data packets sent.
Output drops	<p>Outgoing packets dropped:</p> <ul style="list-style-type: none"> • Control protocol drops—Number of control protocol packets dropped. • Captured data drops—Number of captured data packets dropped.
Flow Statistics	<p>DFC flow statistics:</p> <ul style="list-style-type: none"> • Active flow cache entries • Active flow cache usage percentage • Flow cache entries allocated • Number of control sources • Number of content destinations • Number of criteria • Maximum criteria matching one flow • Cached flows purged for memory • Maximum filters matching one packet

Sample Output

```

show services dynamic-flow-capture statistics
user@host> show services dynamic-flow-capture statistics capture-group g1
Input:
    Control protocol packets: 643, Captured data packets: 69977, Control IRI packets:
    337

Control protocol drops:

    Not IP packets: 0, Not UDP packets: 3, Invalid destination address: 0, No memory:
    0, Unauthorized control source: 0,

    Bad request: 0, Unknown control source: 0, Not DTCP: 0, Bad command line: 0,
    Bandwidth exceeded: 0,

    Drop rate due to exceeded bandwidth: 0, Other: 0

```

Input drops:

Unknown packets: 0, Captured data not IPv4: 0, Captured data too small: 0,
Captured data drops: 0, Captured data not matched: 0,

Bandwidth exceeded: 0, Drop rate due to exceeded bandwidth: 0

Output:

Control protocol packets: 644, Captured data packets: 1119624

Output drops:

Control protocol drops: 0, Captured data drops: 0

Flow Statistics:

Active flow cache entries: 40, Active flow cache usage percentage: 0, Flow cache
entries allocated: 40,

Number of control sources: 4, Number of content destinations: 64, Number of
criteria: 640,

Maximum criteria matching one flow: 16, Cached flows purged for memory: 0,
Maximum filters matching one packet: 16

show services flow-collector file interface

Syntax	show services flow-collector file interface (all cp-fpc/pic/port) <detail extensive terse>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display information about flow collector files.
Options	all cp-fpc/pic/port—Display file information for all configured flow collector interfaces or for the specified interface. detail extensive terse—(Optional) Display the specified level of output.
Additional Information	No entries are displayed for files that have been successfully transferred.
Required Privilege Level	view
List of Sample Output	show services flow-collector file interface extensive on page 1534
Output Fields	Table 280 on page 1533 lists the output fields for the show services flow-collector file interface command. Output fields are listed in the approximate order in which they appear.

Table 280: show services flow-collector file interface Output Fields

Output Field	Output Field Description	Level of Output
Filename	Name of the file created on the flow collector interface.	All levels
Flows	Total number of collector flows for which records are present in the file.	none specified
Throughput	Throughput statistics: <ul style="list-style-type: none"> • Flow records—Number of flow records in the file. <ul style="list-style-type: none"> • per second—Average number of flow records per second. • peak per second—Peak number of flow records per second. • Uncompressed bytes—Total file size before compression. <ul style="list-style-type: none"> • per second—Average number of uncompressed bytes per second. • peak per second—Peak number of uncompressed bytes per second. • Compressed bytes—Total file size after compression. <ul style="list-style-type: none"> • per second—Average number of compressed bytes per second. • peak per second—Peak number of compressed bytes per second. 	extensive

Table 280: show services flow-collector file interface Output Fields (*continued*)

Output Field	Output Field Description	Level of Output
Status	<p>File statistics:</p> <ul style="list-style-type: none"> • Compressed blocks—(extensive output only) Data blocks in the file that have been compressed. The file is exported only when the compressed block count and block count become the same. • Block count—(extensive output only) Total number of data blocks in the file. • State—Processing state of the file. <ul style="list-style-type: none"> • Active—The flow collector interface is writing to the file. • Export 1—File export is in progress to the primary server. • Export 2—File export is in progress to the secondary server. • Wait—File is pending export. • Transfer attempts 0—Number of attempts made to transfer the file. If the file is successfully transferred in the first attempt, this field is 0. 	All levels

Sample Output

```

show services flow-collector file interface extensive
user@host> show services flow-collector file interface cp-3/2/0 extensive
Filename: cFlowd-py69Ni69-0-20031112_014301-so_3_0_0.bcp.bi.gz
Throughput:
  Flow records: 188365, per second: 238, peak per second: 287
  Uncompressed bytes: 21267756, per second: 27007, peak per second: 32526
  Compressed bytes: 2965643, per second: 0, peak per second: 22999
Status:
  Compressed blocks: 156, Block count: 156
  State: Active, Transfer attempts: 0

```

show services flow-collector input interface

Syntax	show services flow-collector input interface (all cp-fpc/pic/port) <detail extensive terse>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display the number of packets received by collector interfaces from monitoring interfaces.
Options	all cp-fpc/pic/port—Display packets received by all configured flow collector interfaces or by the specified interface. detail extensive terse—(Optional) Display the specified level of output.
Required Privilege Level	view
List of Sample Output	show services flow-collector input interface on page 1535 show services flow-collector input interface all on page 1535
Output Fields	Table 281 on page 1535 lists the output fields for the show services flow-collector input interface command. Output fields are listed in the approximate order in which they appear.

Table 281: show services flow-collector input interface Output Fields

Output Field	Output Field Description
Interface	Name of the monitoring interface.
Packets	Number of packets traveling from the monitoring interface to the flow collector interface.
Bytes	Number of bytes traveling from the monitoring interface to the flow collector interface.

Sample Output

```

show services flow-collector input interface user@host> show services flow-collector input interface cp-3/2/0
Interface                                     Packets      Bytes
mo-3/0/0.0                                   21706        32328568
mo-3/1/0.0                                   21706        32329096

show services flow-collector input interface all user@host> show services flow-collector input interface all
Flow collector interface: cp-6/1/0
Interface state: Collecting flows
Interface                                     Packets      Bytes
mo-3/0/0.0                                   274          416232
mo-3/3/0.0                                   274          416184
mo-1/0/0.0                                   274          416232
mo-1/1/0.0                                   274          416232
mo-1/2/0.0                                   274          416232

```

mo-1/3/0.0	274	416232
mo-3/1/0.0	274	416232
mo-4/0/0.0	274	416232
mo-4/1/0.0	274	416232
mo-4/2/0.0	274	416184
mo-4/3/0.0	274	416232
mo-5/0/0.0	274	416232
mo-5/1/0.0	274	416232
mo-5/2/0.0	274	416232
mo-5/3/0.0	274	416232
mo-6/0/0.0	274	416232

Flow collector interface: cp-6/3/0
Interface state: Collecting flows

show services flow-collector interface

Syntax	show services flow-collector interface (all cp-fpc/pic/port) <detail extensive terse>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M40e, M160, and M320 routers and T Series routers only) Display overall statistics for the flow collector application.
Options	all cp-fpc/pic/port—Display statistics for flow collector applications on all interfaces or for the specified interface. detail extensive terse—(Optional) Display the specified level of output.
Required Privilege Level	view
List of Sample Output	show services flow-collector interface all detail on page 1540 show services flow-collector interface all extensive on page 1540 show services flow-collector interface all terse on page 1542 show services flow-collector interface extensive on page 1542
Output Fields	Table 282 on page 1537 lists the output fields for the show services flow-collector interface command. Output fields are listed in the approximate order in which they appear.

Table 282: show services flow-collector interface Output Fields

Output Field	Output Field Description	Level of Output
Flow collector interface	Name of the flow collector interface.	All levels
Interface state	Collecting flow state for the interface.	All levels
Packets	Total number of packets received.	none specified
Flows Uncompressed Bytes	Total uncompressed data size for all files created on this PIC.	none specified
Compressed Bytes	Total compressed data size for all files created on this PIC.	none specified
FTP bytes	Total number of bytes transferred to the FTP server, including those dropped during transfer.	none specified
FTP files	Total number of FTP transfers attempted by the server.	none specified
Memory	Bytes used on the PIC and bytes free.	detail extensive

Table 282: show services flow-collector interface Output Fields (*continued*)

Output Field	Output Field Description	Level of Output
Input	Incoming flow collector packet statistics: <ul style="list-style-type: none"> • Packets—Number of packets received on the unit. <ul style="list-style-type: none"> • per second—Average number of packets per second. • peak per second—Peak number of packets per second. • Bytes—Number of bytes received on the unit. <ul style="list-style-type: none"> • per second—Average number of bytes per second. • peak per second—Peak number of bytes per second. • Flow records processed—Number of records in the flow collector packets that were processed by the flow-collector interface. <ul style="list-style-type: none"> • per second—Average number of flow records processed per second. • peak per second—Peak number of flow records per second. 	detail extensive
Allocation	Data block statistics: <ul style="list-style-type: none"> • Blocks allocated—Total number of data blocks (containing flow records) allocated to the files created on this PIC. <ul style="list-style-type: none"> • per second—Average number of blocks allocated per second. • peak per second—Peak number of blocks allocated per second. • Blocks freed—Total number of data blocks freed. <ul style="list-style-type: none"> • per second—Average number of blocks freed per second. • peak per second—Peak number of blocks freed per second. • Blocks unavailable—Total number of data block requests denied, typically because of a memory shortage. <ul style="list-style-type: none"> • per second—Average number of blocks unavailable per second. • peak per second—Peak number of blocks unavailable per second. 	extensive
Files	File statistics, incremented since the PIC last booted: <ul style="list-style-type: none"> • Files created—Total number of files created on this PIC. • Files exported— Number of files successfully created and exported. • Files destroyed— (extensive output only) Number of files successfully exported and files dropped by the flow collection interface. 	detail extensive
Throughput	Throughput statistics: <ul style="list-style-type: none"> • Uncompressed bytes—Total uncompressed data size for all files created on this PIC. <ul style="list-style-type: none"> • per second—Average number of uncompressed bytes per second. • peak per second—Peak number of uncompressed bytes per second. • Compressed bytes—Total compressed data size for all files created on this PIC. <ul style="list-style-type: none"> • per second—Average number of compressed bytes per second. • peak per second—Peak number of compressed bytes per second. 	detail extensive

Table 282: show services flow-collector interface Output Fields (*continued*)

Output Field	Output Field Description	Level of Output
Packet drops	<p>Number of packets dropped for the following causes:</p> <ul style="list-style-type: none"> • No memory—Packets dropped because of insufficient memory. • Not IP—Packets dropped because they are not IP packets. • Not IPv4—Packets dropped because they are not IP version 4 packets. • Too small—Packets dropped because each packet was smaller than the size reported in its header. • Fragments—Packets dropped because of fragmentation. Fragments are not reassembled. • ICMP—Packets dropped because they are not ICMP packets. • TCP—Packets dropped because they are not TCP packets. • Unknown—Packets dropped because of undetermined causes. • Not Junos flow—Packets dropped because they are not interpreted by the Junos OS. The Junos OS interprets only IPv4, UDP cflowd version 5 packets. 	extensive
File transfer	<p>File transfer statistics:</p> <ul style="list-style-type: none"> • FTP bytes—Total number of bytes transferred to the FTP server, including those dropped during transfer. • FTP files—Total number of FTP transfers attempted by the server. • FTP failure—Total number of FTP failures encountered by the server. 	detail extensive
Flow collector interface	Physical interface acting as a flow collector.	detail
Export channel	<p>Export channel 0 is unit 0. Export channel 1 is unit 1. Flow receive channel is unit 2. Server status statistics are the following:</p> <ul style="list-style-type: none"> • Current server Primary or Secondary—Current FTP server being used. Value is • Primary server state—State of the server: <ul style="list-style-type: none"> • OK—Server is operating without problems. • FTP error—Server encountered an FTP protocol error while sending files. • Network error—Flow-collector interface has errors when contacting the primary FTP server. • Unknown—First file transfer has not been sent to the primary server. • Secondary server state—State of the server: <ul style="list-style-type: none"> • OK—Server is operating without errors. • FTP error—Server encountered an FTP protocol error while sending files. • Network error—Flow-collector interface has errors when contacting the secondary FTP server. • Unknown—First file transfer has not been sent to the secondary server. • Not configured—Secondary server is not configured. 	detail extensive

Sample Output

```

show services      user@host> show services flow-collector interface all detail
flow-collector    Flow collector interface: cp-6/1/0
interface all detail Interface state: Collecting flows
Memory:
  Used: 51452732, Free: 440329088
Input:
  Packets: 4384, per second: 0, peak per second: 156
  Bytes: 6659616, per second: 0, peak per second: 249695
  Flow records processed: 131070, per second: 0, peak per second: 4914
Files:
  Files created: 1, per second: 0, peak per second: 0
  Files exported: 1, per second: 0, peak per second: 0
Throughput:
  Uncompressed bytes: 13742307, per second: 0, peak per second: 593564
  Compressed bytes: 3786177, per second: 0, peak per second: 162826
File Transfer:
  FTP bytes: 3786247, per second: 0, peak per second: 378620
  FTP files: 1, per second: 0, peak per second: 0
  FTP failure: 0
Export channel: 0
  Current server: Primary
  Primary server state: OK, Secondary server state: OK
Export channel: 1
  Current server: Primary
  Primary server state: Unknown, Secondary server state: OK

Flow collector interface: cp-6/3/0
Interface state: Collecting flows
Memory:
  Used: 51452732, Free: 440329088
Input:
  Packets: 0, per second: 0, peak per second: 0
  Bytes: 0, per second: 0, peak per second: 0
  Flow records processed: 0, per second: 0, peak per second: 0
Files:
  Files created: 0, per second: 0, peak per second: 0
  Files exported: 0, per second: 0, peak per second: 0
Throughput:
  Uncompressed bytes: 0, per second: 0, peak per second: 0
  Compressed bytes: 0, per second: 0, peak per second: 0
File Transfer:
  FTP bytes: 70, per second: 0, peak per second: 6
  FTP files: 0, per second: 0, peak per second: 0
  FTP failure: 0
Export channel: 0
  Current server: Primary
  Primary server state: Unknown, Secondary server state: OK
Export channel: 1
  Current server: Primary
  Primary server state: Unknown, Secondary server state: OK

show services      user@host> show services flow-collector interface all extensive
flow-collector    Flow collector interface: cp-6/1/0
interface all extensive Interface state: Collecting flows
Memory:
  Used: 51452732, Free: 440329088
Input:
  Packets: 4384, per second: 0, peak per second: 156

```

Bytes: 6659616, per second: 0, peak per second: 249695
Flow records processed: 131070, per second: 0, peak per second: 4914

Allocation:
Blocks allocated: 108, per second: 0, peak per second: 0
Blocks freed: 108, per second: 0, peak per second: 10
Blocks unavailable: 0, per second: 0, peak per second: 0

Files:
Files created: 1, per second: 0, peak per second: 0
Files exported: 1, per second: 0, peak per second: 0
Files destroyed: 1, per second: 0, peak per second: 0

Throughput:
Uncompressed bytes: 13742307, per second: 0, peak per second: 593564
Compressed bytes: 3786177, per second: 0, peak per second: 162826

Packet drops:
No memory: 0, Not IP: 0
Not IPv4: 0, Too small: 0
Fragments: 0, ICMP: 0
TCP: 0, Unknown: 0
Not JUNOS flow: 0

File Transfer:
FTP bytes: 3786247, per second: 0, peak per second: 378620
FTP files: 1, per second: 0, peak per second: 0
FTP failure: 0

Export channel: 0
Current server: Primary
Primary server state: OK, Secondary server state: OK

Export channel: 1
Current server: Primary
Primary server state: Unknown, Secondary server state: OK

Flow collector interface: cp-6/3/0
Interface state: Collecting flows

Memory:
Used: 51452732, Free: 440329088

Input:
Packets: 0, per second: 0, peak per second: 0
Bytes: 0, per second: 0, peak per second: 0
Flow records processed: 0, per second: 0, peak per second: 0

Allocation:
Blocks allocated: 0, per second: 0, peak per second: 0
Blocks freed: 0, per second: 0, peak per second: 0
Blocks unavailable: 0, per second: 0, peak per second: 0

Files:
Files created: 0, per second: 0, peak per second: 0
Files exported: 0, per second: 0, peak per second: 0
Files destroyed: 0, per second: 0, peak per second: 0

Throughput:
Uncompressed bytes: 0, per second: 0, peak per second: 0
Compressed bytes: 0, per second: 0, peak per second: 0

Packet drops:
No memory: 0, Not IP: 0
Not IPv4: 0, Too small: 0
Fragments: 0, ICMP: 0
TCP: 0, Unknown: 0
Not JUNOS flow: 0

File Transfer:
FTP bytes: 70, per second: 0, peak per second: 6
FTP files: 0, per second: 0, peak per second: 0
FTP failure: 0

Export channel: 0
Current server: Primary

```

Primary server state: Unknown, Secondary server state: OK
Export channel: 1
Current server: Primary
Primary server state: Unknown, Secondary server state: OK

```

**show services
flow-collector
interface all terse**

```

user@host> show services flow-collector interface all terse
Flow collector interface: cp-6/1/0
Interface state: Collecting flows
  Packets      Bytes      Flows Uncompressed   Compressed   FTP bytes FTP files
                Bytes      Bytes
        4384    6659616    131070    13742307    3786177    3786247      1

Flow collector interface: cp-6/3/0
Interface state: Collecting flows
  Packets      Bytes      Flows Uncompressed   Compressed   FTP bytes FTP files
                Bytes      Bytes
         0         0         0         0         0         70         0

```

**show services
flow-collector
interface extensive**

```

user@host> show services flow-collector interface cp-5/2/0 extensive
Flow collector interface: cp-5/2/0
Interface state: Collecting flows
Memory:
  Used: 458311860, Free: 40810008
Input:
  Packets: 922629, per second: 2069, peak per second: 3266
  Bytes: 1376559252, per second: 3096940, peak per second: 4880051
  Flow records processed: 25764957, per second: 42564, peak per second: 98124
Allocation:
  Blocks allocated: 20862, per second: 31, peak per second: 72
  Blocks freed: 17161, per second: 40, peak per second: 202
  Blocks unavailable: 58786, per second: 652, peak per second: 1120
Files:
  Files created: 52, per second: 0, peak per second: 0
  Files exported: 42, per second: 0, peak per second: 0
  Files destroyed: 42, per second: 0, peak per second: 0
Throughput:
  Uncompressed bytes: 2592070401, per second: 7297307,
  peak per second: 8630023
  Compressed bytes: 659600068, per second: 1858458, peak per second: 2198471
Packet drops:
  No memory: 58786, Not IP: 0
  Not IPv4: 0, Too small: 0
  Fragments: 0, ICMP: 0
  TCP: 0, Unknown: 0
  Not JUNOS flow: 0
File Transfer:
  FTP bytes: 585981447, per second: 1313320, peak per second: 4857798
  FTP files: 48, per second: 0, peak per second: 0
  FTP failure: 8
Export channel: 0
  Current server: Primary
  Primary server state: FTP error, Secondary server state: Not configured
Export channel: 1
  Current server: Primary
  Primary server state: OK, Secondary server state: Not configured

```

Intrusion Detection Service Operational Mode Commands

Table 283 on page 1543 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot the intrusion detection service (IDS). Commands are listed in alphabetical order.

Table 283: IDS Operational Mode Commands

Task	Command
Clear (set to zero) IDS events and event information.	<code>clear services ids</code>
Clear the IDS events for a particular address that might be under attack.	<code>clear services ids destination-table</code>
Clear the IDS attack source and destination address pair table.	<code>clear services ids pair-table</code>
Clear all IDS events for addresses that are suspected attackers.	<code>clear services ids source-table</code>
Display IDS event information.	<code>show services ids</code>



NOTE: IDS is supported on the adaptive services interface on the following routers:

- J Series routers—`sp-pim/0/slot`
- M Series and T Series routers—`sp-fpc/pic/port`

IDS is also supported on the redundant adaptive services interface (`rspnumber`) on M Series and T Series routers.



NOTE: For information about how to configure IDS, see the *Junos OS Services Interfaces Configuration Guide*.

clear services ids

Syntax	clear services ids <interface <i>interface-name</i> > <service-set <i>service-set-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear intrusion detection service (IDS) events.
Options	<p>none—Clear all IDS events for all adaptive services interfaces for all service sets, and clear and reset IDS.</p> <p>interface <i>interface-name</i>—(Optional) On M Series and T Series routers, the <i>interface-name</i> can be <i>sp-fpc/pic/port</i> or <i>rspnumber</i>. On the J Series, the <i>interface-name</i> is <i>sp-pim/0/port</i>.</p> <p>service-set <i>service-set-name</i>—(Optional) Clear all IDS events for a particular service set.</p>
Required Privilege Level	view
List of Sample Output	clear services ids on page 1544
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services ids user@host> clear services ids

clear services ids destination-table

Syntax	clear services ids destination-table <destination-prefix <i>destination-prefix-name</i> > <interface <i>interface-name</i> > <service-set <i>service-set-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear the intrusion detection service (IDS) events for a particular address that might be under attack.
Options	<p>none—Clear the attack destination address table.</p> <p>destination-prefix <i>destination-prefix-name</i>—(Optional) Clear the attack destination table for a particular destination prefix.</p> <p>interface <i>interface-name</i>—(Optional) Clear the attack destination table for a particular interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>sp-fpc/pic/port</i> or <i>rspnumber</i>. On the J Series routers, the <i>interface-name</i> is <i>sp-pim/O/port</i>.</p> <p>service-set <i>service-set-name</i>—(Optional) Clear the attack destination table for a particular service set.</p>
Required Privilege Level	view
List of Sample Output	clear services ids destination-table on page 1545
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services ids destination-table
user@host> clear services ids destination-table
```

clear services ids pair-table

Syntax	<code>clear services ids pair-table</code> <code><destination-prefix <i>destination-prefix-name</i>></code> <code><interface <i>interface-name</i>></code> <code><service-set <i>service-set-name</i>></code> <code><source-prefix <i>source-prefix-name</i>></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear the intrusion detection service (IDS) attack source and destination address pair table.
Options	<p><code>none</code>—Clear the attack source and destination address pair table.</p> <p><code>destination-prefix <i>destination-prefix-name</i></code>—(Optional) Clear the attack source and destination address pair table for a particular destination prefix.</p> <p><code>interface <i>interface-name</i></code>—(Optional) Clear the attack destination table for a particular interface. On M Series and T Series routers, the <i>interface-name</i> can be <code>sp-fpc/pic/port</code> or <code>rspnumber</code>. On the J Series routers, the <i>interface-name</i> is <code>sp-pim/0/port</code>.</p> <p><code>service-set <i>service-set-name</i></code>—(Optional) Clear the attack source and destination address pair table for a particular service set.</p> <p><code>source-prefix <i>source-prefix-name</i></code>—(Optional) Clear the attack source and destination address pair table for a particular source prefix.</p>
Required Privilege Level	view
List of Sample Output	clear services ids pair-table on page 1546
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>clear services ids pair-table</code>	<code>user@host> clear services ids pair-table</code>
--	--

clear services ids source-table

Syntax	clear services ids source-table <interface <i>interface-name</i> > <service-set <i>service-set-name</i> > <source-prefix <i>source-prefix-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear all intrusion detection service (IDS) events for addresses that are suspected attackers.
Options	<p>none—Clear the attack source address table.</p> <p>interface <i>interface-name</i>—(Optional) On M Series and T Series routers, the <i>interface-name</i> can be <i>sp-fpc/pic/port</i> or <i>rspnumber</i>. On the J Series routers, the <i>interface-name</i> is <i>sp-pim/0/port</i>.</p> <p>service-set <i>service-set-name</i>—(Optional) Clear the attack source address table for a particular service set.</p> <p>source-prefix <i>source-prefix-name</i>—(Optional) Clear the attack source address table for a particular source prefix.</p>
Required Privilege Level	view
List of Sample Output	clear services ids source-table on page 1547
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services ids source-table
user@host> clear services ids source-table
```

show services ids

Syntax show services ids (destination-table | pair-table | source-table)
 <brief | extensive | terse>
 <destination-prefix *destination-prefix-name*>
 <interface *interface-name*>
 <limit *number*>
 <order (anomalies | bytes | flows | packets)>
 <service-set *service-set-name*>
 <source-prefix *source-prefix-name*>
 <threshold *number*>

Release Information Command introduced before Junos OS Release 7.4.

Description Display information about intrusion detection service (IDS) events. All events gathered by IDS are reported as anomalies. For example, events such as **create forward or watch flow**, **FTP passive**, and **FTP active** are genuinely allowed by the stateful firewall but are logged as anomalies to track the rates and number for these events.

Options destination-table—Display information for an address under possible attack.

 pair-table—Display information for a particular suspected attack source and destination address pair.

 source-table—Display information for an address that is a suspected attacker.

 brief | extensive | terse—(Optional) Display the specified level of output.

 destination-prefix *destination-prefix-name*—(Optional) Display information for a particular destination prefix.

 interface *interface-name*—(Optional) On M Series and T Series routers, the *interface-name* can be **sp-fpc/pic/port** or **rspnumber**. On J Series routers, the *interface-name* is **sp-pim/O/port**.

 limit *number*—(Optional) Maximum number of entries to display. By default, all tables display the top 32 entries sorted by the number of events for the criteria chosen. To display additional entries, configure the limit option to set up to 256 entries.

 order—(Optional) Display events according to one of the following table-ordering criteria. The default is anomalies.

- **anomalies**—Display information for particular anomalies.
- **bytes**—Order output by number of bytes received.
- **flows**—Order output by number of flows.
- **packets**—Order output by number of packets received.

 service-set *service-set-name*—(Optional) Display information about a particular service set.

source-prefix *source-prefix-name*—(Optional) Display information about a particular source prefix.

threshold number—(Optional) Limit the display to events with this number of anomalies, bytes, flows, or packets, whichever criterion you specify for order. For example, to display all events with more than 100 flows, specify *order flows* and *threshold 100*.

Required Privilege Level view

List of Sample Output *show services ids destination-table* on page 1552
show services ids destination-table extensive on page 1552
show services ids destination-table extensive order anomalies on page 1552
show services ids pair-table extensive on page 1553
show services ids pair-table extensive limit on page 1553
show services ids source-table extensive on page 1554
show services ids source-table extensive limit on page 1554

Output Fields Table 284 on page 1549 lists the output fields for the *show services ids* command. Output fields are listed in the approximate order in which they appear.

Table 284: show services ids Output Fields

Field Name	Field Description	Output Level
Interface	Name of an adaptive services interface.	All levels
Service set	Name of a service set. Individual empty service sets are not displayed, but if no service set has any flows, a flow table header is printed for each service set.	All levels
Sorting order	Primary mode to display information: Anomalies , Bytes , Flows , or Packets .	All levels
Source address	Name of the source address.	All levels
Dest address	Name of the destination address.	All levels
Time	Total time the information has been in the table.	All levels
Flags	Flags can be Forced , F (terse output only), SYNcookie , S (terse output only), Forced+SYNcookie , and F+S (terse output only). The SYNcookie flag is visible only in the destination table.	All levels
Application	Configured application, such as FTP or Telnet .	All levels
Bytes	Total number of bytes sent from the source to the destination address, in thousands (k) or millions (m).	All levels
Packets	Total number of packets sent from the source to the destination address, in thousands (k) or millions (m).	All levels
Flows	Total number of flows of packets sent from the source to the destination address, in thousands (k) or millions (m).	All levels

Table 284: show services ids Output Fields (*continued*)

Field Name	Field Description	Output Level
Anomalies	Total number of packets in the anomaly table, in thousands (k) or millions (m).	All levels
Anomaly description	<p>One or more of the following types of anomalies. For more information, see the detailed descriptions in the stateful firewall section of the Junos OS System Log Messages Reference.</p> <ul style="list-style-type: none"> • First packet of TCP session not SYN • ICMP echo request dropped, because sequence number duplicated • ICMP echo reply dropped. No matching sequence number • ICMP echo request dropped. Too many echo requests without echo reply • ICMP header length check failed • ICMP packet length greater than 64K • IP fragment assembly timeout • IP fragment length error • IP fragment overlap • IP packet length greater than 64K • IP packet too short • IP packet with broadcast destination address • IP packet with checksum error • IP packet with incorrect length • IP packet with TTL equal to 0 	extensive

Table 284: show services ids Output Fields (*continued*)

Field Name	Field Description	Output Level
Anomaly description (continued)	<ul style="list-style-type: none"> • IP packet with version other than 4 • Land attack (IP src address = dest address) • No matching SFW rule; attempting to create discard flow • Number of open sessions exceeds IDS limit; packet dropped • Packet rate exceeds IDS limit; packet dropped • Session creation rate exceeds IDS limit; packet dropped • SFW application message too long • SFW discard packet contains non-configured IP option types • SFW drop packet because of discard flow • SFW dropped TCP watch packet • SFW rules request FTP active mode data packets to be accepted; attempting to create forward flow • SFW rules request FTP passive mode data packets to be accepted; attempting to create forward flow • SFW rules request packet to be accepted; attempting to create forward or watch flow • SFW rules request packet to be discarded; attempting to create discard flow • SFW rules request packet to be rejected; attempting to create reject flow • SFW discard flow requires packet to be dropped • SFW SYN defense • Smurf attack (ping to IP broadcast address) • TCP FIN/RST or SYN/(URG FIN RST) flags set • TCP header length check failed • TCP port scan (port not in LISTEN state) • TCP seq number zero and FIN/PSH/RST flags set • TCP seq number zero and no flags set • TCP source or destination port zero • TCP SYN flood attack • UDP header length check failed • UDP port scan (port not in LISTEN state) • UDP source or destination port zero 	extensive
Count	Number of times that a particular anomaly occurred, in thousands (k) or millions (M).	extensive
Rate (eps)	Anomaly events per second. The IDS subsystem attempts to maintain a weighted average of rates, which might not reflect the exact incoming rate of attack at low rates. However, at high rates exceeding 160 events per second, the rates generally match.	extensive
Elapsed	Time since the same type of event last occurred.	extensive
Total IDS table entries	Number of entries in the IDS table. This number is not necessarily the sum of all entries displayed.	All levels

Table 284: show services ids Output Fields (*continued*)

Field Name	Field Description	Output Level
Total failed IDS table entry insertions	Number of IDS entries not allowed into the table because the table was full	All levels
Total number of events (closed flows and anomalies detected)	Total number of events since the system was started or since the show ids services command was executed.	All levels

Sample Output

```

show services ids destination-table
user@host> show services ids destination-table
Interface: sp-1/3/0, Service set: null-sfw
Sorting order: Packets
Source address      Dest address   Time    Flags           Application
any                -> 10.58.255.146 36m12s SYN cookie
Bytes: 35.0 m, Packets: 822.0 k, Flows: 274.0 k, Anomalies: 2251.0 k

Total IDS table entries: 87
Total failed IDS table entry insertions 0
Total number of events (closed flows and anomalies detected): 2606018

show services ids destination-table extensive
user@host> show services ids destination-table extensive
Interface: sp-1/3/0, Service set: null-sfw
Sorting order: Packets
Source address      Dest address   Time    Flags           Application
any                -> 10.58.255.146 35m52s SYN cookie
Bytes: 34.0 m, Packets: 798.0 k, Flows: 266.0 k, Anomalies: 2251.0 k
Anomalies
First packet of TCP session not SYN      160.0 k    0         14s
TCP source or destination port zero      634.0 k    154.6     3m37s
UDP source or destination port zero      633.0 k    170.0     3m37s
ICMP header length check failed          2875      0.9       3m37s
IP fragment assembly timeout             820.0 k    12.8      3m18s
UDP header length check failed            385       0.5       3m53s
TCP header length check failed            383       0.5       3m53s

Total IDS table entries:
87
Total failed IDS table entry insertions
0
Total number of events (closed flows and anomalies detected):
2598063

show services ids destination-table extensive order anomalies
user@host> show services ids destination-table extensive order anomalies
Interface: sp-0/2/0, Service set: ss1
IDS sorting order: Anomalies
Source address      Dest address   Time    Flags           Application
15.1.1.1           -> 15.99.1.1     1m28s   junos-ftp
Bytes: 1065, Packets: 18, Flows: 1, Anomalies: 10

```



```

Anomaly description                                Count   Rate(eps)  Elapsed
creating forward or watch flow                      1       15.6      1m28s
Number of open sessions exceeds IDS limit           9        0.8        18s

Total IDS table entries:                           3
Total failed IDS table entry insertions              0
Total number of events (closed flows and anomalies): 11

show services ids pair-table extensive
user@host> show services ids pair-table extensive
Interface: sp-3/2/0, Service set: ss_all_limits
IDS sorting order: Packets
Source address   Dest address   Time  Flags   Application
15.1.1.4         -> 15.99.1.4     2m20s   junos-ftp

Bytes: 5.7k, Packets: 102.0, Flows: 41.0, Anomalies: 462.0
Anomaly description                                Count   Rate   Elapsed
creating forward or watch flow                      41.0    8.8    2m17s

Packet rate exceeds IDS src limit                   21.0    7.1    2m17s

Session creation rate exceeds IDS src limit          359.0   99.7    2m16s

TCP SYN flood attack                               41.0    1.9    1m30s

Total IDS table entries:                           3
Total failed IDS table entry insertions              0
Total number of events (closed flows and anomalies): 462

show services ids pair-table extensive limit
user@host> show services ids pair-table extensive limit 3
Interface: sp-1/3/0, Service set: null-sfw
Sorting order: Packets
Source address   Dest address   Time  Flags   Application
10.58.255.18     -> 10.58.255.146  38m41s SYN cookie

Bytes: 286.0 m, Packets: 2823.0 k, Flows: 324.0 k, Anomalies: 387.0 k
Anomalies
First packet of TCP session not SYN                 160.0 k   0.1     25s
TCP source or destination port zero                  69.0 k   14.1    6m26s
UDP source or destination port zero                  68.0 k   12.7    6m26s
ICMP header length check failed                      318      0.1     7m6s
IP fragment assembly timeout                         88.0 k    1.3     6m7s
UDP header length check failed                       39       0.0    6m58s
TCP header length check failed                       46       0.0    6m45s

10.58.255.23     -> 10.58.255.146  18m48s SYN cookie

Bytes: 104.0 m, Packets: 421.0 k, Flows: 230, Anomalies: 124.0 k
Anomalies
TCP source or destination port zero                  37.0 k    9.8    6m26s
UDP source or destination port zero                  37.0 k    8.4    6m26s
IP fragment assembly timeout                         48.0 k    1.0     6m7s
ICMP header length check failed                      190      0.2    6m47s
UDP header length check failed                       29       0.0    6m51s
TCP header length check failed                       23       0.0    6m59s

10.58.255.25     -> 10.58.255.146  18m48s SYN cookie

Bytes: 104.0 m, Packets: 420.0 k, Flows: 232, Anomalies: 123.0 k
Anomalies
TCP source or destination port zero                  37.0 k    9.8    6m26s
UDP source or destination port zero                  37.0 k    8.6    6m26s
IP fragment assembly timeout                         48.0 k    1.5     6m7s

```

ICMP header length check failed	173	0.1	6m43s
UDP header length check failed	24	0.0	6m43s
TCP header length check failed	19	0.0	6m56s

Total IDS table entries:

87

Total failed IDS table entry insertions

0

Total number of events (closed flows and anomalies detected):

2659291

show services ids source-table extensive

user@host> show services ids source-table extensive

Interface: sp-3/2/0, Service set: ss_all_limits

IDS sorting order: Packets

Source address	Dest address	Time	Flags	Application
15.1.1.4	->	any	2m43s	junos-ftp

Bytes: 5.7k, Packets: 102.0, Flows: 41.0, Anomalies: 462.0

Anomaly description	Count	Rate	Elapsed
creating forward or watch flow	41.0	8.8	2m40s
Packet rate exceeds IDS src limit	21.0	7.1	2m40s
Session creation rate exceeds IDS src limit	359.0	99.7	2m39s
TCP SYN flood attack	41.0	1.9	1m53s

Total IDS table entries:

3

Total failed IDS table entry insertions

0

Total number of events (closed flows and anomalies):

462

show services ids source-table extensive limit

user@host> show services ids source-table extensive limit 3

Interface: sp-1/3/0, Service set: null-sfw

Sorting order: Packets

Source address	Dest address	Time	Flags	Application
----------------	--------------	------	-------	-------------

10.58.255.18 -> any 40m 0s SYN cookie

Bytes: 250.0 m, Packets: 1978.0 k, Flows: 356.0 k, Anomalies: 387.0 k

Anomalies	Count	Rate(eps)	Elapsed
TCP source or destination port zero	37.0 k	9.8	6m26s
First packet of TCP session not SYN	160.0 k	0.0	40s
TCP source or destination port zero	69.0 k	62.5	7m45s
UDP source or destination port zero	68.0 k	56.2	7m45s
ICMP header length check failed	319	0.1	7m49s
IP fragment assembly timeout	89.0 k	4.4	7m26s
UDP header length check failed	39	0.0	8m17s
TCP header length check failed	46	0.0	8m4s

10.58.255.30 -> any 20m 7s SYN cookie

Bytes: 107.0 m, Packets: 427.0 k, Flows: 264, Anomalies: 125.0 k

Anomalies	Count	Rate(eps)	Elapsed
UDP source or destination port zero	38.0 k	65.5	7m45s
TCP source or destination port zero	37.0 k	38.1	7m45s
IP fragment assembly timeout	49.0 k	4.1	7m26s
TCP header length check failed	24	0.0	9m23s
ICMP header length check failed	165	0.1	8m6s
UDP header length check failed	26	0.0	8m13s

10.58.255.17 -> any 20m10s SYN cookie

Bytes: 107.0 m, Packets: 426.0 k, Flows: 262, Anomalies: 125.0 k

Anomalies	Count	Rate(eps)	Elapsed
TCP source or destination port zero	38.0 k	55.	7m45s
UDP source or destination port zero	38.0 k	55.1	7m45s
ICMP header length check failed	147	0.1	7m50s
IP fragment assembly timeout	49.0 k	2.8	7m26s
TCP header length check failed	22	0.0	9m33s
UDP header length check failed	22	0.0	8m1s

Total IDS table entries:
87

Total failed IDS table entry insertions
0

Total number of events (closed flows and anomalies detected):
2691423

Interface: sp-1/3/0, Service set: blue

NAT pool	Address	Port	Ports in use
d2-pool	10.59.16.100-10.59.16.100	4000-4002	1

IP Security Operational Mode Commands

Table 285 on page 1557 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot IP Security (IPsec) services. In the table, the commands are grouped by the interfaces on which they are supported. In the remainder of this chapter, the commands are listed in alphabetical order.

- Services Interfaces:
 - M Series, MX Series and T Series routers—***sp-fpc/pic/port*** or ***ms-fpc/pic/port***. IPsec is also supported on the redundant services interface (***rspnumber***).
- Encryption Interfaces (M Series and T Series routers only) ***es-fpc/pic/port***.

Table 285: IPsec Services Operational Mode Commands

Task	Command
Services Interface	
Delete certificate authority (CA) digital certificates from the router.	clear security pki ca-certificate
Delete manually generated local digital certificate requests from the router.	clear security pki certificate-request
Delete all CRLs from the router.	clear security pki crl
Clear public key infrastructure (PKI) key pair information for local digital certificates from the router.	clear security pki key-pair
Delete local digital certificates, certificate requests, and the corresponding public/private key pairs from the router.	clear security pki local-certificate
Delete local and remote certificates from the IPsec configuration memory cache.	clear services ipsec-vpn certificates
Clear IPsec statistics.	clear services ipsec-vpn ipsec statistics

Table 285: IPsec Services Operational Mode Commands (*continued*)

Task	Command
Clear either Internet Key Exchange (IKE) or IPsec VPN security associations.	clear services ipsec-vpn ike security-associations clear services ipsec-vpn ipsec security-associations
Request a digital certificate from a CA online by using the Simple Certificate Enrollment Protocol (SCEP).	request security pki ca-certificate enroll
Manually load a CA digital certificate from a specified location.	request security pki ca-certificate load
Verify the digital certificate installed for the specified certificate authority (CA).	request security pki ca-certificate verify
Manually install a CRL on the router.	request security pki crl load
Manually generate a local digital certificate request in the Public-Key Cryptography Standards #10 (PKCS-10) format.	request security pki generate-certificate-request
Generate a Public Key Infrastructure (PKI) public and private key pair for a local digital certificate.	request security pki generate-key-pair
Request a CA to enroll and install a local digital certificate online by using the SCEP.	request security pki local-certificate enroll
Manually generate a self-signed certificate for the given distinguished name.	request security pki local-certificate generate-self-signed
Manually load a local digital certificate from a specified location.	request security pki local-certificate load
Verify the validity of the local digital certificate identifier.	request security pki local-certificate verify
Switch between the primary and backup IPsec VPN tunnels.	request services ipsec-vpn ipsec switch tunnel
Display information about authentication keychains configured for the BGP Protocol, the LDP routing protocols, the Bidirectional Forwarding Detection (BFD) Protocol, and the IS-IS Protocol.	show security keychain
Display information about certificate authority (CA) digital certificates installed in the router.	show security pki ca-certificate
Display information about manually generated local digital certificate requests that are stored in the router.	show security pki certificate-request

Table 285: IPsec Services Operational Mode Commands (*continued*)

Task	Command
Display information about the local digital certificates and the corresponding public keys installed in the router.	show security pki local-certificate
Display local and remote certificates installed in the IPsec configuration memory cache that are used for the IKE negotiation.	show services ipsec-vpn certificates
Display IKE VPN security associations for service sets.	show services ipsec-vpn ike security-associations
Display IPsec VPN security associations for service sets.	show services ipsec-vpn ipsec security-associations
Display IPsec VPN statistics for service sets.	show services ipsec-vpn ipsec statistics
Encryption Interface	
Clear Internet Key Exchange (IKE) security associations.	clear ike security-associations
Clear IPsec security associations.	clear ipsec security-associations
Switch between primary and backup interfaces and tunnels.	request ipsec switch
Obtain a public key certificate from a certification authority.	request security certificate (signed) request security certificate (unsigned)
Generate a public and private key pair.	request security key-pair
Add a certificate provided by the Juniper Networks certificate authority.	request system certificate add
Display IKE security association information.	show ike security-associations
Display the IPsec certificate database.	show ipsec certificates
Display primary and backup interface and tunnel information.	show ipsec redundancy
Display IPsec security association information.	show ipsec security-associations
Display installed certificates signed by the Juniper Networks certificate authority.	show system certificate



.....

NOTE: For information about how to configure IPsec services, see the *Junos OS Services Interfaces Configuration Guide* for adaptive services interfaces and the *Junos OS System Basics Configuration Guide* for encryption interfaces.

.....

clear ike security-associations

Syntax	clear ike security-associations <destination-ip-address>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Encryption interface on M Series and T Series routers only) Clear information about the current Internet Key Exchange (IKE) security association. This command is valid for dynamic security associations only.
Options	none—Clear all IKE security associations. destination-ip-address—(Optional) Clear the IKE security association at the specified destination address.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show ike security-associations on page 1594
List of Sample Output	clear ike security-associations on page 1561
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear ike security-associations user@host> clear ike security-associations
```

clear ipsec security-associations

Syntax	<code>clear ipsec security-associations</code> <code><sa-name></code>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Encryption interface on M Series and T Series routers only) Clear information about the current IP Security (IPsec) security association. This command is valid for dynamic security associations only. When this command is issued, a new security association is created.
Options	<code>none</code> —Clear all IPsec security associations. <code>sa-name</code> —(Optional) Clear the specified security association.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show ipsec security-associations on page 1603
List of Sample Output	clear ipsec security-associations on page 1562
Output Fields	See the show ipsec security-associations for an explanation of output fields.

Sample Output

clear ipsec security-associations The following output from the **show ipsec security-associations detail** command is displayed before and after the **clear ipsec security-associations** command is issued:

```
user@host> show ipsec security-associations detail
Security association: sa-dynamic, Interface family: Up

Direction: inbound, SPI: 242379418, State: Installed
Mode: tunnel, Type: dynamic
Protocol: ESP, Authentication: hmac-md5-96, Encryption: None
Soft lifetime: Expires in 22979 seconds
Hard lifetime: Expires in 28739 seconds

Direction: outbound, SPI: 368592771, State: Installed
Mode: tunnel, Type: dynamic
Protocol: ESP, Authentication: hmac-md5-96, Encryption: None
Soft lifetime: Expires in 22979 seconds
Hard lifetime: Expires in 28739 seconds

user@host> clear ipsec security-associations

user@host> show ipsec security-associations detail
Security association: sa-dynamic, Interface family: Up

Direction: inbound, SPI: 1031597683, State: Installed
Mode: tunnel, Type: dynamic
Protocol: ESP, Authentication: hmac-md5-96, Encryption: None
Soft lifetime: Expires in 23037 seconds
```

Hard lifetime: Expires in 28797 seconds

Direction: outbound, SPI: 1618419878, State: Installed
Mode: tunnel, Type: dynamic
Protocol: ESP, Authentication: hmac-md5-96, Encryption: None
Soft lifetime: Expires in 23037 seconds
Hard lifetime: Expires in 28797 seconds

clear security pki ca-certificate

Syntax	clear security pki ca-certificate (all ca-profile <i>ca-profile-name</i>)
Release Information	Command introduced in Junos OS Release 7.5.
Description	Delete certificate authority (CA) digital certificates from the router.
Options	<p>all—Delete all CA digital certificates from the router.</p> <p>ca-profile <i>ca-profile-name</i>—Delete the specified CA profile.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• request security pki ca-certificate enroll on page 1576• request security pki ca-certificate load on page 1577• show security pki ca-certificate on page 1606
List of Sample Output	clear security pki ca-certificate all on page 1564
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear security pki ca-certificate all	user@host> clear security pki ca-certificate all
--	--

clear security pki certificate-request

Syntax	clear security pki certificate-request (all certificate-id <i>certificate-id-name</i>)
Release Information	Command introduced in Junos OS Release 7.5.
Description	Delete manually generated local digital certificate requests from the router.
Options	all—Delete all local digital certificate requests from the router. certificate-id <i>certificate-id-name</i> —Delete the specified local digital certificate and corresponding public/private key pair.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • show security pki certificate-request on page 1610
List of Sample Output	clear security pki certificate-request all on page 1565
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear security pki user@host> clear security pki certificate-request all
certificate-request all
```

clear security pki crl

Syntax	clear security pki crl (all ca-profile <i>ca-profile-name</i>)
Release Information	Command introduced in Junos 8.1
Description	Delete certificate revocation lists (CRLs) from the router.
Options	all—Delete all CRLs from the router. ca-profile <i>ca-profile-name</i> —Delete CRLs associated with the specified CA profile.
Required Privilege Level	clear
List of Sample Output	clear security pki crl ca-profile all on page 1566
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear security pki crl ca-profile all	user@host> clear security pki crl ca-profile all
--	--

clear security pki key-pair

Syntax	clear security pki key-pair (all certificate-id <i>certificate-id-name</i>)
Release Information	Command introduced in Junos OS Release 8.5.
Description	Clear public key infrastructure (PKI) key pair information for local digital certificates from the router.
Options	<p>all—Delete all local digital certificates, certificate requests, and the corresponding public and private key pairs from the router.</p> <p>certificate-id <i>certificate-id-name</i>—Delete the specified local digital certificate and corresponding public/private key pair.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• request security pki local-certificate enroll on page 1583• show security pki local-certificate on page 1614
Output Fields	This command produces no output.

Sample Output

```
clear security pki key pair  
user@host> clear security pki key pair
```

clear security pki local-certificate

Syntax	clear security pki local-certificate <all certificate-id <i>certificate-id-name</i> system-generated>
Release Information	Command introduced in Junos OS Release 7.5.
Description	Delete local digital certificates, certificate requests, and the corresponding public/private key pairs from the router.
Options	<p>all—(Optional) Delete all local digital certificates, certificate requests, and the corresponding public and private key pairs from the router.</p> <p>certificate-id <i>certificate-id-name</i>—(Optional) Delete the specified local digital certificate and corresponding public and private key pair.</p> <p>system-generated—(Optional) Auto-generated self-signed certificate.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• request security pki local-certificate enroll on page 1583• show security pki local-certificate on page 1614
List of Sample Output	clear security pki local-certificate all on page 1568
Output Fields	This command produces no output.

Sample Output

clear security pki local-certificate all	user@host> clear security pki local-certificate all
---	---

clear services ipsec-vpn certificates

Syntax	clear services ipsec-vpn certificates (all service-set <i>service-set</i>) <certificate-cache-entry <i>number</i> >
Release Information	Command introduced in Junos OS Release 7.5.
Description	(Adaptive services interfaces only) Delete digital certificates from the IPsec configuration memory cache. Issuing this command also clears the certificate revocation list (CRL) from the cache along with the certificates.
Options	all—Delete digital certificates for all service sets. service-set <i>service-set</i> —Delete digital certificates for the specified service set. certificate-cache-entry <i>number</i> —(Optional) Delete digital certificates matching a specified cache entry number. To view the certificate cache entry numbers, issue the show services ipsec-vpn certificates command.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • show services ipsec-vpn certificates on page 1617
List of Sample Output	clear services ipsec-vpn certificates all on page 1569
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services ipsec-vpn certificates all
user@host> clear services ipsec-vpn certificates all
```

clear services ipsec-vpn ike security-associations

Syntax	clear services ipsec-vpn ike security-associations <peer-address-name> <service-set service-set-name>
Release Information	Command introduced before Junos OS Release 7.4. service-set option added in Junos OS Release 8.5.
Description	(Adaptive services interfaces only) Clear Internet Key Exchange (IKE) security associations.
Options	<i>peer-address-name</i> —(Optional) Clear only the security association specified by the peer address. <i>service-set service-set-name</i> —(Optional) Clear only the security association specified by the service-set name.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show services ipsec-vpn ike security-associations on page 1620
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services ipsec-vpn ike security-associations	user@host> clear services ipsec-vpn ike security-associations
--	---

clear services ipsec-vpn ipsec statistics

Syntax	clear services ipsec-vpn ipsec statistics <remote-gateway <i>address</i> > <service-set <i>service-set-name</i> >
Release Information	Command introduced in Junos OS Release 8.1.
Description	(Adaptive services interface only) Clear IP Security (IPsec) statistics.
Options	<i>remote-gateway address</i> —(Optional) Clear statistics for the specified remote system. <i>service-set service-set-name</i> —(Optional) Clear statistics for the specified service set.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show services ipsec-vpn ipsec statistics on page 1627
List of Sample Output	clear services ipsec-vpn ipsec statistics on page 1571
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services ipsec-vpn ipsec statistics	user@host> clear services ipsec-vpn ipsec statistics
---	--

clear services ipsec-vpn ipsec security-associations

Syntax	<code>clear services ipsec-vpn security-associations</code> <code><peer-address-name></code> <code><remote-gateway remote-gateway-address></code> <code><service-set-name></code> <code><tunnel-index tunnel-index-number></code>
Release Information	Command introduced before Junos OS Release 7.4. remote-gateway , service-set-name , and tunnel-index options added in Junos OS Release 8.4.
Description	(Adaptive services interfaces only) Clear IP Security (IPsec) security associations. You can combine the options for greater specificity.
Options	<p><i>peer-address-name</i>—(Optional) Clear only the security association specified by the peer address.</p> <p><i>remote-gateway remote-gateway-address</i>—(Optional) Clear only the security association specified by the remote gateway address.</p> <p><i>service-set-name</i>—(Optional) Clear only the security association specified by the service-set name.</p> <p><i>tunnel-index tunnel-index-number</i>—(Optional) Clear only the security association specified by the tunnel index number.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show services ipsec-vpn ipsec security-associations on page 1624
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services user@host> clear services ipsec-vpn ipsec security-associations
ipsec-vpn ipsec
security-associations
```

request security certificate (signed)

Syntax	request security certificate enroll filename <i>filename</i> subject <i>subject</i> alternative-subject <i>alternative-subject</i> certification-authority <i>certification-authority</i> encoding (binary pem) key-file <i>key-file</i> domain-name <i>domain-name</i>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(Encryption interface on M Series and T Series routers and EX Series switches only) Obtain a signed certificate from a certificate authority (CA). The signed certificate validates the CA and the owner of the certificate. The results are saved in a specified file to the <code>/var/etc/ikecert</code> directory.
Options	filename <i>filename</i> —File that stores the certificate. subject <i>subject</i> —Distinguished name (dn), which consists of a set of components—for example, an organization (o), an organization unit (ou), a country (c), and a locality (l). alternative-subject <i>alternative-subject</i> —Tunnel source address. certification-authority <i>certification-authority</i> —Name of the certificate authority profile in the configuration. encoding (binary pem)—File format used for the certificate. The format can be a binary file or privacy-enhanced mail (PEM), an ASCII base64-encoded format. The default format is binary. key-file <i>key-file</i> —File containing a local private key. domain-name <i>domain-name</i> —Fully qualified domain name.
Required Privilege Level	maintenance
List of Sample Output	request security certificate (signed) on page 1573
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request security certificate (signed) user@host> request security certificate enroll filename host.crt subject c=uk,o=london
alternative-subject 10.50.1.4 certification-authority verisign key-file host-1.prv domain-name
host.juniper.net
CA name: juniper.net CA file: ca_verisign
local pub/private key pair: host.prv
subject: c=uk,o=london domain name: host.juniper.net
alternative subject: 10.50.1.4
Encoding: binary
Certificate enrollment has started. To view the status of your enrollment, check
the key management process (kmd) log file at /var/log/kmd. <-----
```

request security certificate (unsigned)

Syntax	<code>request security certificate enroll filename <i>filename</i> ca-file <i>ca-file</i> ca-name <i>ca-name</i> encoding (binary perm) url <i>url</i></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(Encryption interface on M Series and T Series routers and EX Series switches only) Obtain a certificate from a certificate authority (CA). The results are saved in a specified file to the <code>/var/etc/ikecert</code> directory.
Options	<code>filename <i>filename</i></code> —File that stores the public key certificate. <code>ca-file <i>ca-file</i></code> —Name of the certificate authority profile in the configuration. <code>ca-name <i>ca-name</i></code> —Name of the certificate authority. <code>encoding (binary pem)</code> —File format used for the certificate. The format can be a binary file or privacy-enhanced mail (PEM), an ASCII base64-encoded format. The default value is binary . <code>url <i>url</i></code> —Certificate authority URL.
Required Privilege Level	maintenance
List of Sample Output	request security certificate (unsigned) on page 1574
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request security certificate (unsigned)	<pre>user@host> request security certificate enroll filename ca_verisign ca-file verisign ca-name juniper.net urlxyzcompany URL http://<verisign ca-name xyzcompany url>/cgi-bin/pkiclient.exe CA name: juniper.net CA file: verisign Encoding: binary Certificate enrollment has started. To view the status of your enrollment, check the key management process (kmd) log file at /var/log/kmd. <-----</pre>
--	---

request security key-pair

Syntax	<code>request security key-pair <i>filename</i></code> <code><size <i>key-size</i>></code> <code><type (rsa dsa)></code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(Encryption interface on M Series and T Series routers and EX Series switches only) Generate a public and private key pair for a digital certificate.
Options	<i>filename</i> —Name of a file in which to store the key pair. <i>size key-size</i> —(Optional) Key size, in bits. The key size can be 512 , 1024 , or 2048 . The default value is 1024 . <i>type</i> —(Optional) Algorithm used to encrypt the key: <ul style="list-style-type: none"> • rsa—RSA algorithm. This is the default. • dsa—Digital signature algorithm with Secure Hash Algorithm (SHA).
Required Privilege Level	maintenance
List of Sample Output	request security key-pair on page 1575
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request security user@host> request security key-pair security-key-file
key-pair
```

request security pki ca-certificate enroll

Syntax	request security pki ca-certificate enroll ca-profile <i>ca-profile-name</i>
Release Information	Command introduced in Junos OS Release 7.5.
Description	Request a digital certificate from a certificate authority (CA) online by using the Simple Certificate Enrollment Protocol (SCEP).
Options	ca-profile <i>ca-profile-name</i> —CA profile name.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• clear security pki ca-certificate on page 1564• show security pki ca-certificate on page 1606
List of Sample Output	request security pki ca-certificate enroll on page 1576
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request security pki ca-certificate enroll user@host> request security pki ca-certificate enroll ca-profile entrust
Received following certificates:
Certificate: C=us, O=juniper, CN=First Officer
Fingerprint: 46:71:15:34:f0:a6:41:76:65:81:33:4f:68:47:c4:df:78:b8:e3:3f
Certificate: C=us, O=juniper, CN=First Officer
Fingerprint: bc:78:87:9b:a7:91:13:20:71:db:ac:b5:56:71:42:ad:1a:b6:46:17
Certificate: C=us, O=juniper
Fingerprint: 00:8e:6f:58:dd:68:bf:25:0a:e3:f9:17:70:d6:61:f3:53:a7:79:10
Do you want to load the above CA certificate ? [yes,no] (no) yes
```


request security pki ca-certificate load

Syntax	request security pki ca-certificate load ca-profile <i>ca-profile-name</i> filename <i>path/filename</i>
Release Information	Command introduced in Junos OS Release 7.5.
Description	Manually load a certificate authority (CA) digital certificate from a specified location.
Options	<p>ca-profile <i>ca-profile-name</i>—Load the specified CA profile.</p> <p>filename <i>path/filename</i>—Directory location and filename of the CA digital certificate.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • clear security pki ca-certificate on page 1564 • show security pki ca-certificate on page 1606
List of Sample Output	request security pki ca-certificate load on page 1577
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request security pki user@host> request security pki ca-certificate load ca-profile ca-private filename pki-file
ca-certificate load
```

request security pki ca-certificate verify

Syntax	request security pki ca-certificate verify ca-profile <i>ca-profile-name</i>
Release Information	Command introduced in Junos OS Release 8.5.
Description	Verify the digital certificate installed for the specified certificate authority (CA).
Options	ca-profile <i>ca-profile-name</i> —Name of the local digital certificate identifier.
Required Privilege Level	maintenance
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

You receive the following response before the certificate revocation list (CRL) is downloaded:

```
request security pki ca-certificate verify ca-profile ca1 (CRL not downloaded)
user@host> request security pki ca-certificate verify ca-profile ca1
```

```
CA certificate ca1: CRL verification in progress. Please check the PKId debug
logs for completion status
```

request security pki crt load

Syntax	<code>request security pki crt load ca-profile <i>ca-profile-name</i> filename <i>path/filename</i></code>
Release Information	Command introduced in Junos OS Release 8.1.
Description	Manually install a certificate revocation list (CRL) on the router from a specified location.
Options	<code>ca-profile <i>ca-profile-name</i></code> —Load the specified certificate authority (CA) profile. <code>filename <i>path/filename</i></code> —Directory location and filename of the CRL.
Required Privilege Level	maintenance
List of Sample Output	request security pki crt load on page 1579
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>request security pki crt load</code>	<code>user@host> request security pki crt load ca-profile ca-private filename pki-file</code>
--	--

request security pki generate-certificate-request

Syntax	request security pki generate-certificate-request certificate-id <i>certificate-id-name</i> domain-name <i>domain-name</i> subject <i>subject-distinguished-name</i> <email <i>email-address</i> > <filename (<i>path</i> terminal)> <ip-address <i>ip-address</i> >
Release Information	Command introduced in Junos OS Release 7.5.
Description	Manually generate a local digital certificate request in the Public-Key Cryptography Standards #10 (PKCS-10) format.
Options	<p>certificate-id <i>certificate-id-name</i>—Name of the local digital certificate and the public/private key pair.</p> <p>domain-name <i>domain-name</i>—Fully qualified domain name (FQDN). The FQDN provides the identity of the certificate owner for Internet Key Exchange (IKE) negotiations and provides an alternative to the subject name.</p> <p>subject <i>subject-distinguished-name</i>—Distinguished name format that contains the common name, department, company name, state, and country:</p> <ul style="list-style-type: none">• CN—Common name• OU—Organizational unit name• O—Organization name• ST—State• C—Country <p>email <i>email-address</i>—(Optional) E-mail address of the certificate holder.</p> <p>filename (<i>path</i> terminal)—(Optional) Location where the local digital certificate request should be placed or the login terminal.</p> <p>ip-address <i>ip-address</i>—(Optional) IP address of the router.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• clear security pki certificate-request on page 1565• show security pki certificate-request on page 1610
List of Sample Output	request security pki generate-certificate-request on page 1581
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request security pki user@host> request security pki generate-certificate-request certificate-id local-entrust2
generate-certificate-request domain-name router2.juniper.net filename entrust-req2 subject cn=router2.juniper.net
```

```
Generated certificate request
-----BEGIN CERTIFICATE REQUEST-----
MIIBoTCCAQoCAQAwGjEYMBYGA1UEAxMPdHxLmp1bm1wZXIubmVOMIGfMA0GCSqG
SIb3DQEBAQUAA4GNADCBiQKBgQCiUFk1Qws1Ud+AqN5DDxRs2kVyKEhh9qoVFnz+
Hz4c9vsy3B8E1wTJlkmIt2cB3yi fB6zePd+6WYpf57Crwre7YqPkiXM31F6z3YjX
H+1BPNbCxNWYvyrnSyVYDbFj8o0Xyqog8ACDFVL2JBWrPNBYy7imq/K9soDBbAs6
5hZqqwIDAQABoEcwRQYJKoZIhvcNAQkOMTgwNjA0BGNVHQ8BAf8EBAMCB4AwJAYD
VR0RAQH/BBowGIIWdHxLmVuZ2xhYi5qdW5pcGVyLm5ldDANBgkqhkiG9w0BAQF
AAOBgQBc2rq1v5S0QXH7LCb/FdqAL8ZM6GoaN5d6cGwq4bB6a7UQFgtoH406gQ3G
3iH0Zfz4xMIBpJYuGd1dkqgvcd0H3AgTsLkfn7Wi3x5H2qeQVs9bvL4P5nvEZLND
EIMUHwteo1ZCiZ70f09Fer9cXWHSQs1UtXtgPqQJy2xIeImLgw==
-----END CERTIFICATE REQUEST-----
Fingerprint:
0d:90:b8:d2:56:74:fc:84:59:62:b9:78:71:9c:e4:9c:54:ba:16:97 (sha1)
1b:08:d4:f7:90:f1:c4:39:08:c9:de:76:00:86:62:b8 (md5)
```

request security pki generate-key-pair

Syntax	request security pki generate-key-pair certificate-id <i>certificate-id-name</i> <size (512 1024 2048) >
Release Information	Command introduced in Junos OS Release 7.5.
Description	Generate a Public Key Infrastructure (PKI) public and private key pair for a local digital certificate.
Options	<p>certificate-id <i>certificate-id-name</i>—Name of the local digital certificate and the public/private key pair.</p> <p>size—(Optional) Key pair size. The key pair size can be 512, 1024, or 2048 bits.</p>
Required Privilege Level	maintenance
List of Sample Output	request security pki generate-key-pair on page 1582
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request security pki generate-key-pair	user@host> request security pki generate-key-pair certificate-id billy size 2048 Generated key pair billy, key size 2048 bits
---	--

request security pki local-certificate enroll

Syntax	request security pki local-certificate enroll <i>ca-profile ca-profile-name</i> <i>certificate-id certificate-id-name</i> challenge-password <i>password</i> domain-name <i>domain-name</i> subject <i>subject-distinguished-name</i> <email <i>email-address</i> > <ip-address <i>ip-address</i> >
Release Information	Command introduced in Junos OS Release 7.5.
Description	Request that a certificate authority (CA) enroll and install a local digital certificate online by using the Simple Certificate Enrollment Protocol (SCEP).
Options	<p><i>ca-profile ca-profile-name</i>—CA profile name.</p> <p><i>certificate-id certificate-id-name</i>—Name of the local digital certificate and the public/private key pair.</p> <p>challenge-password <i>password</i>—Password set by the administrator and normally obtained from the SCEP enrollment webpage of the CA. The password is 16 characters in length.</p> <p>domain-name <i>domain-name</i>—Fully qualified domain name (FQDN). The FQDN provides the identity of the certificate owner for Internet Key Exchange (IKE) negotiations and provides an alternative to the subject name.</p> <p>subject <i>subject-distinguished-name</i>—Distinguished name format that contains the common name, department, company name, state, and country:</p> <ul style="list-style-type: none"> • CN—Common name • OU—Organizational unit name • O—Organization name • ST—State • C—Country <p>email <i>email-address</i>—(Optional) E-mail address of the certificate holder.</p> <p>ip-address <i>ip-address</i>—(Optional) IP address of the router.</p>
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show security pki local-certificate on page 1614
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
user@host> request security pki local-certificate enroll certificate-id r3-entrust-scep ca-profile  
entrust domain-name router3.juniper.net subject "CN=router3,OU=Engineering,O=juniper,C=US"  
challenge-password 123
```

Certificate enrollment has started. To view the status of your enrollment, check the public key infrastructure log (pkid) log file at /var/log/pkid. Please save the challenge-password for revoking this certificate in future. Note that this password is not stored on the router.

request security pki local-certificate generate-self-signed

Syntax	request security pki local-certificate generate-self-signed certificate-id <i>certificate-id-name</i> domain-name <i>domain-name</i> ip-address <i>ip-address</i> email <i>email-address</i> subject <i>subject-distinguished-name</i>
Release Information	Command introduced in Junos OS Release 9.1.
Description	Manually generate a self-signed certificate for the given distinguished name.
Options	<p>certificate-id <i>certificate-id-name</i>—Name of the local digital certificate and the public/private key pair.</p> <p>domain-name <i>domain-name</i>—Fully qualified domain name (FQDN). The FQDN provides the identity of the certificate owner for Internet Key Exchange (IKE) negotiations and provides an alternative to the subject name.</p> <p>email <i>email-address</i>—E-mail address of the certificate holder.</p> <p>ip-address <i>ip-address</i>—IP address of the router.</p> <p>subject <i>subject-distinguished-name</i>—Distinguished name format that contains the common name, department, company name, state, and country:</p> <ul style="list-style-type: none"> • CN—Common name • OU—Organizational unit name • O—Organization name • ST—State • C—Country
Required Privilege Level	maintenance security
Related Documentation	<ul style="list-style-type: none"> • show security pki local-certificate on page 1614
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
user@host> request security pki local-certificate generate-self-signed certificate-id self-cert
subject cn=abc domain-name juniper.net email mholmes@juniper.net
Self-signed certificate generated and loaded successfully
```

request security pki local-certificate load

Syntax	<code>request security pki local-certificate load certificate-id <i>certificate-id-name</i> filename <i>path</i></code>
Release Information	Command introduced in Junos OS Release 7.5.
Description	Manually load a local digital certificate from a specified location.
Options	<p><code>certificate-id <i>certificate-id-name</i></code>—Name of the public/private key pair mapped to the local digital certificate.</p> <p><code>filename <i>path/filename</i></code>—Directory location and filename of the local digital certificate provided by the CA.</p>
Required Privilege Level	maintenance
List of Sample Output	request security pki local-certificate load on page 1586
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>request security pki local-certificate load</code>	<pre>user@host> request security pki local-certificate load filename /tmp/router2-cert certificate-id local-entrust2 Local certificate local-entrust2 loaded successfully</pre>
--	--

request security pki local-certificate verify

Syntax	request security pki local-certificate verify certificate-id <i>certificate-id-name</i>
Release Information	Command introduced in Junos OS Release 8.5.
Description	Verify the validity of the local digital certificate identifier.
Options	certificate-id <i>certificate-id-name</i> —Display the specified certificate identifier name.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none"> • show security pki local-certificate on page 1614
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

You receive the following response before the certificate revocation list (CRL) is downloaded:

```
request security pki local-certificate verify certificate-id bme1 (not downloaded)
user@host> request security pki local-certificate verify certificate-id bme1
```

```
Local certificate bme1: CRL verification in progress. Please check the PKId debug
logs for completion status
```

You receive the following response after the certificate revocation list (CRL) is downloaded

```
request security pki local-certificate verify certificate bme1 (downloaded)
user@host> request security pki local-certificate verify certificate-id bme1
Local certificate bme1 verification success
```

request ipsec switch

Syntax	request ipsec switch (interface <es-fpc/pic/port> security-associations <sa-name>)
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	(Encryption interface on M Series and T Series routers and EX series switches only) Manually switch from the primary to the backup encryption services interface, or switch from the primary to the backup IP Security (IPsec) tunnel.
Options	interface <es-fpc/pic/port>—Switch to the backup encryption interface. security-associations <sa-name>—Switch to the backup tunnel.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show ipsec redundancy on page 1601
List of Sample Output	request ipsec switch on page 1588
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
request ipsec switch  user@host> request ipsec switch security-associations sa-private
```

request services ipsec-vpn ipsec switch tunnel

Syntax	request services ipsec-vpn ipsec switch tunnel local-gateway <i>address</i> remote-gateway <i>address</i> <routing-instance <i>instance-name</i> >
Release Information	Command introduced before Junos OS Release 7.4. routing-instance option added in Release 8.1.
Description	(Adaptive services interface only) Manually switch between primary and backup IP Security (IPsec) tunnels.
Options	local-gateway <i>address</i> —Gateway address of the local system. remote-gateway <i>address</i> —Gateway address of the remote system. routing-instance <i>instance-name</i> —(Optional) VRF instance associated with local gateway address.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show services ipsec-vpn ipsec security-associations on page 1624
List of Sample Output	request services ipsec-vpn ipsec switch tunnel on page 1589
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request services ipsec-vpn ipsec switch tunnel	user@host> request services ipsec-vpn ipsec switch tunnel local-gateway 10.1.1.1 remote gateway 10.100.10.1
--	---

show security keychain

Syntax	show security keychain <brief detail>
Release Information	Command introduced in Junos OS Release 11.2.
Description	Display information about authentication keychains configured for the Border Gateway Protocol (BGP), the Label Distribution Protocol (LDP) routing protocols, the Bidirectional Forwarding Detection (BFD) protocol, and the Intermediate System-to-Intermediate System (IS-IS) protocol.
Options	none—Display information about authentication keychains. brief detail—(Optional) Display the specified level of output.
Required Privilege Level	view
List of Sample Output	show security keychain brief on page 1591 show security keychain detail on page 1592
Output Fields	Table 286 on page 1590 describes the output fields for the show security keychain command. Output fields are listed in the approximate order in which they appear.

Table 286: show security keychain Output Fields

Field Name	Field Description	Level of Output
keychain	The name of the keychain in operation.	All levels
Active-ID Send	Number of routing protocols packets sent with the active key.	All levels
Active-ID Receive	Number of routing protocols packets received with the active key.	All levels
Next-ID Send	Number of routing protocols packets sent with the next key.	All levels
Next-ID Receive	Number of routing protocols packets received with the next key.	All levels
Transition	Amount of time until the current key will be replaced with the next key in the keychain.	All levels
Tolerance	Configured clock-skew tolerance, in seconds, for accepting keys for a key chain.	All levels
Id	Identification number configured for the current key.	detail
Algorithm	Authentication algorithm configured for the current key.	detail

Table 286: show security keychain Output Fields (*continued*)

Field Name	Field Description	Level of Output
State	<p>State of the current key.</p> <p>The value can be:</p> <ul style="list-style-type: none"> • receive • send • send-receive <p>For the active key, the State can be send-receive, send, or receive. For keys that have a future start time, the State is inactive. Compare the State field to the Mode field.</p>	detail
Option	<p>For IS-IS only, the option determines how Junos OS encodes the message authentication code in routing protocol packets.</p> <p>The values can be:</p> <ul style="list-style-type: none"> • basic—Based on RFC 5304. • isis-enhanced—Based on RFC 5310. <p>The default value is basic. When you configure the isis-enhanced option, Junos OS sends RFC 5310-encoded routing protocol packets and accepts both RFC 5304-encoded and RFC 5310-encoded routing protocol packets that are received from other devices.</p> <p>When you configure basic (or do not include the options statement in the key configuration) Junos OS sends and receives RFC 5304-encoded routing protocols packets, and drops 5310-encoded routing protocol packets that are received from other devices.</p> <p>Because this setting is for IS-IS only, the TCP and the BFD protocol ignore the encoding option configured in the key.</p>	detail
Start-time	Time that the current key became active.	detail
Mode	<p>Mode of each key (Informational only.)</p> <p>The value can be</p> <ul style="list-style-type: none"> • receive • send • send-receive <p>The mode of the key is based on the configuration. Suppose you configure two keys, one with a start-time of today and the other with a start-time of next week. For both keys, the Mode can be send-receive, send, or receive, regardless of the configured start-time. Compare the Mode field to the State field.</p>	detail

Sample Output

```

show security keychain brief user@host> show security keychain brief
keychain                    Active-ID  Next-ID  Transition  Tolerance
                        Send  Receive  Send  Receive

```

```

hakr                      3      3      1      1      1d 23:58      3600

```

```

show security keychain    user@host> show security keychain detail
detail                   keychain      Active-ID      Next-ID      Transition  Tolerance
                        Send  Receive    Send  Receive
hakr                    3      3      1      1      1d 23:58      3600
                        Id 3, Algorithm hmac-md5, State send-receive, Option basic
                        Start-time Wed Aug 11 16:28:00 2010, Mode send-receive
                        Id 1, Algorithm hmac-md5, State inactive, Option basic
                        Start-time Fri Aug 20 11:30:57 2010, Mode send-receive

```


request system certificate add

Syntax	<code>request system certificate add (<i>filename</i> terminal)</code>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	(Encryption interface on M Series, T Series routers and QFX Series switches only) Add a certificate provided by the Juniper Networks certificate authority (CA).
Options	<i>filename</i> —Filename (URL, local, or remote). terminal—Use login terminal.
Required Privilege Level	maintenance
List of Sample Output	request system certificate add on page 1593
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

request system certificate add	<code>user@host> request system certificate add terminal</code>
---	--

show ike security-associations

Syntax	show ike security-associations <brief detail> <peer-address>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Encryption interface on M Series and T Series routers only) Display information about Internet Key Exchange (IKE) security associations.
Options	<p>none—Display standard information about all IKE security associations.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>peer-address—(Optional) Display IKE security associations for the specified peer address.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear ike security-associations on page 1561
List of Sample Output	<p>show ike security-associations on page 1597</p> <p>show ike security-associations detail on page 1597</p>
Output Fields	Table 287 on page 1594 lists the output fields for the show ike security-associations command. Output fields are listed in the approximate order in which they appear.

Table 287: show ike security-associations Output Fields

Field Name	Field Description	Level of Output
IKE peer	Remote end of the IKE negotiation.	detail
Role	Part played in the IKE session. The router triggering the IKE negotiation is the initiator, and the router accepting the first IKE exchange packets is the responder.	detail
Remote Address	Responder's address.	none specified
State	State of the IKE security association: <ul style="list-style-type: none"> Matured—The IKE security association is established. Not matured—The IKE security association is in the process of negotiation. 	none specified
Initiator cookie	When the IKE negotiation is triggered, a random number is sent to the remote node.	All levels

Table 287: show ike security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Responder cookie	<p>The remote node generates its own random number and sends it back to the initiator as a verification that the packets were received.</p> <p>Of the numerous security services available, protection against denial of service (DoS) is one of the most difficult to address. A “cookie” or anticlogging token (ACT) is aimed at protecting the computing resources from attack without spending excessive CPU resources to determine the cookie's authenticity. An exchange prior to CPU-intensive public key operations can thwart some DoS attempts (such as simple flooding with invalid IP source addresses).</p>	All levels
Exchange type	<p>Specifies the number of messages in an IKE exchange, and the payload types that are contained in each message. Each exchange type provides a particular set of security services, such as anonymity of the participants, perfect forward secrecy of the keying material, and authentication of the participants. Junos OS supports two types of exchanges:</p> <ul style="list-style-type: none"> • Main—The exchange is done with six messages. Main encrypts the payload, protecting the identity of the neighbor. • Aggressive—The exchange is done with three messages. Aggressive does not encrypt the payload, leaving the identity of the neighbor unprotected. 	All Levels
Authentication method	Type of authentication determines which payloads are exchanged and when they are exchanged. The Junos OS supports only pre-shared keys .	detail
Local	Prefix and port number of the local end.	detail
Remote	Prefix and port number of the remote end.	detail
Lifetime	Number of seconds remaining until the IKE security association expires.	detail
Algorithms	<p>Header for the IKE algorithms output.</p> <ul style="list-style-type: none"> • Authentication—Type of authentication algorithm used: md5 or sha1. • Encryption—Type of encryption algorithm used: des-cbc, 3des-cbc, or None. • Pseudo random function—Function that generates highly unpredictable random numbers: hmac-md5 or hmac-sha1. 	detail
Traffic statistics	<p>Number of bytes and packets received and transmitted on the IKE security association.</p> <ul style="list-style-type: none"> • Input bytes, Output bytes—Number of bytes received and transmitted on the IKE security association. • Input packets, Output packets—Number of packets received and transmitted on the IKE security association. 	detail

Table 287: show ike security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Flags	Notification to the key management process of the status of the IKE negotiation: <ul style="list-style-type: none"> • caller notification sent—Caller program notified about the completion of the IKE negotiation. • waiting for done—Negotiation is done. The library is waiting for the remote end retransmission timers to expire. • waiting for remove—Negotiation has failed. The library is waiting for the remote end retransmission timers to expire before removing this negotiation. • waiting for policy manager—Negotiation is waiting for a response from the policy manager. 	detail
IPsec security associates	Number of IPsec security associations created and deleted with this IKE security association.	detail
Phase 2 negotiations in progress	Number of phase 2 IKE negotiations in progress and status information: <ul style="list-style-type: none"> • Negotiation type—Type of phase 2 negotiation. The Junos OS currently supports quick mode. • Message ID—Unique identifier for a phase 2 negotiation. • Local identity—Identity of the local phase 2 negotiation. The format is <i>id-type-name (proto-name:port-number,[O..id-data-len] = iddata-presentation)</i> • Remote identity—Identity of the remote phase 2 negotiation. The format is <i>id-type-name (proto-name:port-number,[O..id-data-len] = iddata-presentation)</i> • Flags—Notification to the key management process of the status of the IKE negotiation: <ul style="list-style-type: none"> • caller notification sent—Caller program notified about the completion of the IKE negotiation. • waiting for done—Negotiation is done. The library is waiting for the remote end retransmission timers to expire. • waiting for remove—Negotiation has failed. The library is waiting for the remote end retransmission timers to expire before removing this negotiation. • waiting for policy manager—Negotiation is waiting for a response from the policy manager. 	detail

Sample Output

```

show ike security-associations user@host> show ike security-associations
Remote Address  State      Initiator cookie  Responder cookie  Exchange type
4.4.4.4         Matured          93870456fa000011  723a20713700003e  Main

show ike security-associations detail user@host> show ike security-associations detail
IKE peer 4.4.4.4
Role: Initiator, State: Matured
Initiator cookie: cf22bd81a7000001, Responder cookie: fe83795c2800002e
Exchange type: Main, Authentication method: Pre-shared-keys
Local: 4.4.4.5:500, Remote: 4.4.4.4:500
Lifetime: Expires in 187 seconds
Algorithms:
Authentication      : md5
Encryption           : 3des-cbc
Pseudo random function: hmac-md5
Traffic statistics:
Input bytes  :          1000
Output bytes :          1280
Input packets:           5
Output packets:          9
Flags: Caller notification sent
IPsec security associations: 2 created, 0 deleted
Phase 2 negotiations in progress: 1

Negotiation type: Quick mode, Role: Initiator, Message ID: 3582889153
Local: 4.4.4.5:500, Remote: 4.4.4.4:500
Local identity: ipv4_subnet(tcp:80,[0..7]=10.1.1.0/24)
Remote identity: ipv4_subnet(tcp:100,[0..7]=10.1.2.0/24)
Flags: Caller notification sent, Waiting for done

```

show ipsec certificates

Syntax	show ipsec certificates <brief detail> <crl <i>crl-name</i> <i>serial-number</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Encryption interface on M Series and T Series routers only) Display information about the IPsec certificate database.
Options	<p>none—Display standard information about all of the entries in the IPsec certificate database.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>crl <i>crl-name</i> <i>serial-number</i>—(Optional) Display information about the entries on the certificate revocation list (CRL) or for the specified serial number. A CRL is a timestamped list identifying revoked certificates. The CRL is signed by a certificate authority (CA) or CRL issuer and made freely available in a public repository. Each revoked certificate is identified in a CRL by its certificate serial number.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear ipsec security-associations on page 1562
List of Sample Output	show ipsec certificates detail on page 1599
Output Fields	Table 288 on page 1598 lists the output fields for the show ipsec certificates command. Output fields are listed in the approximate order in which they appear.

Table 288: show ipsec certificates Output Fields

Field Name	Field Description	Level of Output
Database	Display information about the IPsec certificate database. <ul style="list-style-type: none"> Total entries—Number of database entries, including entries that are not trusted or that are in the process of being deleted. Active entries—Number of database entries, excluding entries that are marked as deleted. Locked entries—Number of statically configured database entries that cannot expire, such as CA certificates that are root or trusted. 	All levels
Subject	Distinguished name for the certificate for C, O, CN , as described in RFC 3280, <i>Internet x.509 Public Key Infrastructure Certificate and Certificate Revocation List (CRL) Profile</i> .	All levels
ID	Identification number of the database entry. ID is generated by the internal certificate database.	All levels

Table 288: show ipsec certificates Output Fields (*continued*)

Field Name	Field Description	Level of Output
References	Reference number the certificate manager has for the particular entry.	detail
Serial	Unique serial number assigned to each certificate by the CA.	All levels
Flags	State of the certificate. <ul style="list-style-type: none"> • Trusted—Passed validity checks. • Not trusted—Failed validity checks. • Root—Entry is locked and may have been learned through IKE or a locally configured CA certificate. • Non-root—Entry is not locked. • Crl-issuer—Entity issues CRLs. • Non-crl-issuer—Entity does not issue CRLs. 	detail
Validity period starts	Start time that the certificate is valid, in the format <i>yyyy mon dd, hh:mm:ss GMT</i> .	detail
Validity period ends	End time that the certificate is valid, in the format <i>yyyy mon dd, hh:mm:ss GMT</i> .	detail
Alternative name information	Auxiliary identity for the certificate: <i>dns-name</i> , <i>email-address</i> , <i>ip-address</i> , or <i>uri</i> (uniform resource identifier).	detail
Issuer	Information about the entity that has signed and issued the CRL as described in RFC 2459, <i>Internet X.509 Public Key Infrastructure Certificate and CRL Profile</i> .	detail

Sample Output

```

show ipsec certificates user@host> show ipsec certificates detail
detail Database: Total entries: 3 Active entries: 4 Locked entries: 1
Subject: C=us, O=x
ID: 5, References: 0, Serial: 22314868
Flags: Trusted Non-root Crl-issuer
Validity period starts: 2003 Mar 1st, 01:20:42 GMT
Validity period ends: 2003 Mar 31st, 01:50:42 GMT
Alternative name information:
IP address: 10.20.210.1
Issuer: C=FI, O=Company-ABC, CN=Company ABC class 2

Subject: C=us, O=x
ID: 4, References: 0, Serial: 22315496
Flags: Trusted Non-root Crl-issuer
Validity period starts: 2003 Mar 1st, 01:21:45 GMT
Validity period ends: 2003 Mar 31st, 01:51:45 GMT
Alternative name information:
IP address: 10.20.210.20
Issuer: C=FI, O=Company-ABC, CN=Company ABC class 2

Subject: C=FI, O=SSH Company-ABC, CN=Company ABC class 2
ID: 1, References: 1, Serial: 1538512
Flags: Trusted Root Non-crl-issuer
Validity period starts: 2001 Aug 1st, 07:08:32 GMT

```

Validity period ends: 2004 Aug 1st, 07:08:32 GMT
Alternative name information:
Email address: certifier-support@ssh.com
Issuer: C=FI, O=Company-ABC, CN=Company ABC class 2

show ipsec redundancy

Syntax	show ipsec redundancy (interface <es-fpc/pic/port> security association <sa-name>)
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Encryption interface on M Series and T Series routers only) Display information about IPsec redundancy.
Options	<p>interface <es-fpc/pic/port>—Display information about all encryption interfaces, or optionally, about a particular encryption interface.</p> <p>security association <sa-name>—Display information about all remote tunnels, or optionally, about a particular remote tunnel.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> request ipsec switch on page 1588
List of Sample Output	<p>show ipsec redundancy interface on page 1602</p> <p>show ipsec redundancy security-associations on page 1602</p>
Output Fields	Table 289 on page 1601 lists the output fields for the show ipsec redundancy command. Output fields are listed in the approximate order in which they appear.

Table 289: show ipsec redundancy Output Fields

Field Name	Field Description
Failure counter	Number of times a PIC switched between primary and backup interfaces, or the number of times the tunnel switched between the primary and remote peers since the software has been activated.
Primary interface '	Name of the interface configured to be the primary interface.
Backup interface	Name of the interface configured to be the backup interface.
State	State of the primary or backup interface can be Active , Offline , or Standby . Both ES PICs are initialized to Offline . For primary and remote peers, State can be Active or Standby . Both peers are in a state of Standby by default (there is not yet a connection between the two peers).
Security association	Name of the security association.
Local IP	Local IP address.
Primary remote IP	IP address of the configured primary remote peer.
Backup remote IP	IP address of the configured backup remote peer.

Sample Output

show ipsec redundancy interface	<pre>user@host> show ipsec redundancy interface Failure counter: 0 Primary interface: es-1/3/0, State: Active Backup interface : es-1/1/0, State: Standby</pre>
show ipsec redundancy security-associations	<pre>user@host> show ipsec redundancy security-associations sa-dynamic Security association: sa-dynamic, Failure counter: 0 Local IP: 4.4.4.4 Primary remote IP: 4.4.4.5, State: Standby Backup remote IP : 3.3.3.3, State: Standby</pre>

show ipsec security-associations

Syntax	show ipsec security-associations <brief detail> <sa-name>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Encryption interface on M Series and T Series routers only) Display information about the IPsec security associations applied to the local or transit traffic stream.
Options	<p>none—Display standard information about all IPsec security associations.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>sa-name—(Optional) Display the specified IPsec security association.</p>
Required Privilege Level	view
List of Sample Output	<p>show ipsec security-associations sa-name on page 1605</p> <p>show ipsec security-associations sa-name detail on page 1605</p>
Output Fields	Table 290 on page 1603 lists the output fields for the show ipsec security-associations command. Output fields are listed in the approximate order in which they appear.

Table 290: show ipsec security-associations Output Fields

Field Name	Field Description	Level of Output
Security association	Name of the security association.	All levels
Interface family	<p>Status of the interface family of the security association. If the interface family field is absent, it is a transport mode security association. The interface family can have one of three options:</p> <ul style="list-style-type: none"> • Up—The security association is referenced in the interface family and the interface family is up. • Down—The security association is referenced in the interface family and the interface family is down. • No reference—The security association is not referenced in the interface family. 	All levels
Local gateway	Gateway address of the local system.	All levels
Remote gateway	Gateway address of the remote system.	All levels
Local identity	Prefix and port number of the local end	All levels
Remote identity	Prefix and port number of the remote end.	All levels
Direction	Direction of the security association: inbound or outbound .	All levels
SPI	Value of the security parameter index.	All levels

Table 290: show ipsec security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
AUX-SPI	Value of the auxiliary security parameter index. <ul style="list-style-type: none"> When the value is AH or ESP, AUX-SPI is always 0. When the value is AH+ESP, AUX-SPI is always a positive integer. 	All levels
State	Status of the security association: <ul style="list-style-type: none"> Installed—The security association is installed in the security association database. (For transport mode security associations, the value of State must always be Installed.) Not installed—The security association is not installed in the security association database. 	detail
Mode	Mode of the security association: <ul style="list-style-type: none"> transport—Protects single host-to-host protections. tunnel—Protects connections between security gateways. 	All levels
Type	Type of security association: <ul style="list-style-type: none"> manual—Security parameters require no negotiation. They are static, and are configured by the user. dynamic—Security parameters are negotiated by the IKE protocol. Dynamic security associations are not supported in transport mode. 	All levels
Protocol	Protocol supported: <ul style="list-style-type: none"> transport mode—Supports Encapsulation Security Protocol (ESP) or Authentication Header (AH). tunnel mode—Supports ESP or AH+ESP. 	All levels
Authentication	Type of authentication used: hmac-md5-96 , hmac-sha1-96 , or None .	detail
Encryption	Type of encryption used: des-cbc , 3des-csc , or None .	detail
Soft lifetime Hard lifetime	(dynamic output only) Each lifetime of a security association has two display options, hard and soft, one of which must be present for a dynamic security association. The hard lifetime specifies the lifetime of the SA. The soft lifetime , which is derived from the hard lifetime, informs the IPsec key management system that the SA is about to expire. This allows the key management system to negotiate a new SA before the hard lifetime expires. <ul style="list-style-type: none"> Expires in seconds seconds—Number of seconds left until the security association expires. Expires in kilobytes kilobytes—Number of kilobytes left until the security association expires. 	detail
Anti-replay service	State of the service that prevents packets from being replayed: Enabled or Disabled .	detail

Table 290: show ipsec security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Replay window size	Configured size, in packets, of the antireplay service window: 32 or 64 . The antireplay window size protects the receiver against replay attacks by rejecting old or duplicate packets. If the replay window size is 0 , the antireplay service is disabled.	detail

Sample Output

```

show ipsec security-associations sa-name
user@host> show ipsec security-associations sa-cosmic brief
Security association: sa-cosmic, Interface family: Up
Local gateway: 21.21.1.1, Remote gateway: 21.21.2.1
Local identity: ipv4_subnet(any:0,[0..7]=0.0.0.0/0)
Remote identity: ipv4_subnet(any:0,[0..7]=0.0.0.0/0)
Direction SPI      AUX-SPI      Mode      Type      Protocol
inbound  2908734119  0          tunnel    dynamic   AH
outbound 3494029335  0          tunnel    dynamic   AH

show ipsec security-associations sa-name detail
user@host> show ipsec security-associations sa-cosmic detail
Security association: sa-cosmic, Interface family: Up

Local gateway: 21.21.1.1, Remote gateway: 21.21.2.1
Local identity: ipv4_subnet(any:0,[0..7]=0.0.0.0/0)
Remote identity: ipv4_subnet(any:0,[0..7]=0.0.0.0/0)
Direction: inbound, SPI: 2908734119, AUX-SPI: 0, State: Installed
Mode: tunnel, Type: dynamic
Protocol: AH, Authentication: hmac-md5-96, Encryption: None
Soft lifetime: Expired
Hard lifetime: Expires in 120 seconds
Anti-replay service: Disabled

Direction: outbound, SPI: 3494029335, AUX-SPI: 0, State: Installed
Mode: tunnel, Type: dynamic
Protocol: AH, Authentication: hmac-md5-96, Encryption: None
Soft lifetime: Expired
Hard lifetime: Expires in 120 seconds
Anti-replay service: Disabled

```

show security pki ca-certificate

Syntax	show security pki ca-certificate <brief detail> <ca-profile <i>ca-profile-name</i> >
Release Information	Command introduced in Junos OS Release 7.5.
Description	Display information about certificate authority (CA) digital certificates installed in the router.
Options	<p>none—(Same as brief) Display information about all CA digital certificates.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>ca-profile <i>ca-profile-name</i>—(Optional) Display information about only the specified CA profile.</p>
Required Privilege Level	view
List of Sample Output	<p>show security pki ca-certificate on page 1607</p> <p>show security pki ca-certificate detail on page 1608</p>
Output Fields	Table 291 on page 1606 lists the output fields for the show security pki ca-certificate command. Output fields are listed in the approximate order in which they appear.

Table 291: show security pki ca-certificate Output Fields

Field Name	Field Description	Level of Output
Certificate identifier	Name of the digital certificate.	All levels
Certificate version	Revision number of the digital certificate.	detail
Serial number	Unique serial number of the digital certificate.	detail
Issued by	Authority that issued the digital certificate.	none brief
Issued to	Device that was issued the digital certificate.	none brief
Issuer	<p>Authority that issued the digital certificate, including details of the authority organized using the distinguished name format. Possible subfields are:</p> <ul style="list-style-type: none"> • Common name—Name of the authority. • Organization—Organization of origin. • Organizational unit—Department within an organization. • State—State of origin. • Country—Country of origin. 	detail

Table 291: show security pki ca-certificate Output Fields (*continued*)

Field Name	Field Description	Level of Output
Subject	Details of the digital certificate holder organized using the distinguished name format. Possible subfields are: <ul style="list-style-type: none"> • Common name—Name of the requestor. • Organization—Organization of origin. • Organizational unit—Department within an organization. • State—State of origin. • Country—Country of origin. 	detail
Validity	Time period when the digital certificate is valid. Values are: <ul style="list-style-type: none"> • Not before—Start time when the digital certificate becomes valid. • Not after—End time when the digital certificate becomes invalid. 	All levels
Public key algorithm	Encryption algorithm used with the private key, such as rsaEncryption(1024 bits) .	All levels
Signature algorithm	Encryption algorithm that the CA used to sign the digital certificate, such as sha1WithRSAEncryption .	detail
Fingerprint	Secure Hash Algorithm (SHA1) and Message Digest 5 (MD5) hashes used to identify the digital certificate.	detail
Distribution CRL	Distinguished name information and the URL for the certificate revocation list (CRL) server.	detail
Use for key	Use of the public key, such as Certificate signing , CRL signing , Digital signature , or Key encipherment .	detail

Sample Output

```

show security pki user@host> show security pki ca-certificate
ca-certificate Certificate identifier: entrust
                Issued to: juniper, Issued by: juniper
                Validity:
                  Not before: 2005 Oct 18th, 23:54:22 GMT
                  Not after: 2025 Oct 19th, 00:24:22 GMT
                Public key algorithm: rsaEncryption(1024 bits)

                Certificate identifier: entrust
                Issued to: First Officer, Issued by: juniper
                Validity:
                  Not before: 2005 Oct 18th, 23:55:59 GMT
                  Not after: 2008 Oct 19th, 00:25:59 GMT
                Public key algorithm: rsaEncryption(1024 bits)

                Certificate identifier: entrust
                Issued to: First Officer, Issued by: juniper
                Validity:
                  Not before: 2005 Oct 18th, 23:55:59 GMT

```

**show security pki
ca-certificate detail**

```

Not after: 2008 Oct 19th, 00:25:59 GMT
Public key algorithm: rsaEncryption(1024 bits)

user@host> show security pki ca-certificate detail
Certificate identifier: entrust
Certificate version: 3
Serial number: 4355 9235
Issuer:
  Organization: juniper, Country: us
Subject:
  Organization: juniper, Country: us
Validity:
  Not before: 2005 Oct 18th, 23:54:22 GMT
  Not after: 2025 Oct 19th, 00:24:22 GMT
Public key algorithm: rsaEncryption(1024 bits)
cb:9e:2d:c0:70:f8:ea:3c:f2:b5:f0:02:48:87:dc:68:99:a3:57:4f
0e:b9:98:0b:95:47:0d:1f:97:7c:53:17:dd:1a:f8:da:e5:08:d1:1c
78:68:1f:2f:72:9f:a2:cf:81:e3:ce:c5:56:89:ce:f0:97:93:fa:36
19:3e:18:7d:8c:9d:21:fe:1f:c3:87:8d:b3:5d:f3:03:66:9d:16:a7
bf:18:3f:f0:7a:80:f0:62:50:43:83:4f:0e:d7:c6:42:48:c0:8a:b2
c7:46:30:38:df:9b:dc:bc:b5:08:7a:f3:cd:64:db:2b:71:67:fe:d8
04:47:08:07:de:17:23:13
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
  00:8e:6f:58:dd:68:bf:25:0a:e3:f9:17:70:d6:61:f3:53:a7:79:10 (sha1)
  71:6f:6a:76:17:9b:d6:2a:e7:5a:72:97:82:6d:26:86 (md5)
Distribution CRL:
  C=us, O=juniper, CN=CRL1
  http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: CRL signing, Certificate signing
Certificate identifier: entrust
Certificate version: 3
Serial number: 4355 925c
Issuer:
  Organization: juniper, Country: us
Subject:
  Organization: juniper, Country: us, Common name: First Officer
Validity:
  Not before: 2005 Oct 18th, 23:55:59 GMT
  Not after: 2008 Oct 19th, 00:25:59 GMT
Public key algorithm: rsaEncryption(1024 bits)
c0:a4:21:32:95:0a:cd:ec:12:03:d1:a2:89:71:8e:ce:4e:a6:f9:2f
1a:9a:13:8c:f6:a0:3d:c9:bd:9d:c2:a0:41:77:99:1b:1e:ed:5b:80
34:46:f8:5b:28:34:38:2e:91:7d:4e:ad:14:86:78:67:e7:02:1d:2e
19:11:b7:fa:0d:ba:64:20:e1:28:4e:3e:bb:6e:64:dc:cd:b1:b4:7a
ca:8f:47:dd:40:69:c2:35:95:ce:b8:85:56:d7:0f:2d:04:4d:5d:d8
42:e1:4f:6b:bf:38:c0:45:1e:9e:f0:b4:7f:74:6f:e9:70:fd:4a:78
da:eb:10:27:bd:46:34:33
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
  bc:78:87:9b:a7:91:13:20:71:db:ac:b5:56:71:42:ad:1a:b6:46:17 (sha1)
  23:79:40:c9:6d:a6:f0:ca:e0:13:30:d4:29:6f:86:79 (md5)
Distribution CRL:
  C=us, O=juniper, CN=CRL1
  http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: Key encipherment
Certificate identifier: entrust
Certificate version: 3
Serial number: 4355 925b
Issuer:
  Organization: juniper, Country: us

```


Subject:
Organization: juniper, Country: us, Common name: First Officer
Validity:
Not before: 2005 Oct 18th, 23:55:59 GMT
Not after: 2008 Oct 19th, 00:25:59 GMT
Public key algorithm: rsaEncryption(1024 bits)
ea:75:c4:f3:58:08:ea:65:5c:7e:b3:de:63:0a:cf:cf:ec:9a:82:e2
d7:e8:b9:2f:bd:4b:cd:86:2f:f1:dd:d8:a2:95:af:ab:51:a5:49:4e
00:10:c6:25:ff:b5:49:6a:99:64:74:69:e5:8c:23:5b:b4:70:62:8e
e4:f9:a2:28:d4:54:e2:0b:1f:50:a2:92:cf:6c:8f:ae:10:d4:69:3c
90:e2:1f:04:ea:ac:05:9b:3a:93:74:d0:59:24:e9:d2:9d:c2:ef:22
b9:32:c7:2c:29:4f:91:cb:5a:26:fe:1d:c0:36:dc:f4:9c:8b:f5:26
af:44:bf:53:aa:d4:5f:67
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
46:71:15:34:f0:a6:41:76:65:81:33:4f:68:47:c4:df:78:b8:e3:3f (sha1)
ee:cc:c7:f4:5d:ac:65:33:0a:55:db:59:72:2c:dd:16 (md5)
Distribution CRL:
C=us, O=juniper, CN=CRL1
http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: Digital signature

show security pki certificate-request

Syntax	show security pki certificate-request <brief detail> <certificate-id <i>certificate-id-name</i> >
Release Information	Command introduced in Junos OS Release 7.5.
Description	Display information about manually generated local digital certificate requests that are stored in the router.
Options	<p>none—(same as brief) Display information about all local digital certificate requests.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>certificate-id <i>certificate-id-name</i>—(Optional) Display information about only the specified local digital certificate request</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear security pki certificate-request on page 1565
List of Sample Output	<p>show security pki certificate-request on page 1611</p> <p>show security pki certificate-request detail on page 1611</p>
Output Fields	Table 292 on page 1610 lists the output fields for the show security pki certificate-request command. Output fields are listed in the approximate order in which they appear.

Table 292: show security pki certificate-request Output Fields

Field Name	Field Description	Level of Output
Certificate identifier	Name of the digital certificate.	All levels
Certificate version	Revision number of the digital certificate.	detail
Issued to	Device that was issued the digital certificate.	none brief
Subject	<p>Details of the digital certificate holder organized using the distinguished name format. Possible subfields are:</p> <ul style="list-style-type: none"> Common name—Name of the authority. Organization—Organization of origin. Organizational unit—Department within an organization. State—State of origin. Country—Country of origin. 	detail
Alternate subject	Domain name or IP address of the device related to the digital certificate.	detail

Table 292: show security pki certificate-request Output Fields (*continued*)

Field Name	Field Description	Level of Output
Validity	Time period when the digital certificate is valid. Values are: <ul style="list-style-type: none"> • Not before—Time when the digital certificate becomes valid. • Not after—End time when the digital certificate becomes invalid. 	All levels
Public key algorithm	Encryption algorithm used with the private key, such as rsaEncryption(1024 bits) .	All levels
Public key verification status	Public key verification status: Failed or Passed . The detail output also provides the verification hash.	All levels
Fingerprint	Secure Hash Algorithm (SHA1) and Message Digest 5 (MD5) hashes used to identify the digital certificate.	detail
Use for key	Use of the public key, such as Certificate signing , CRL signing , Digital signature , or Key encipherment .	detail

Sample Output

```

show security pki certificate-request user@host> show security pki certificate-request
Certificate identifier: local-microsoft-2
Issued to: router2.juniper.net
Public key algorithm: rsaEncryption(1024 bits)
Public key verification status: Passed

show security pki certificate-request detail user@host> show security pki certificate-request detail
Certificate identifier: local-entrust3
Certificate version: 3
Subject:
  Common name: router3.juniper.net
Alternate subject: router3.juniper.net
Public key algorithm: rsaEncryption(1024 bits)
Public key verification status: Passed
fb:79:df:d4:a9:03:0f:d3:69:7e:c1:e4:27:35:9c:d9:b1:a2:47:78
d2:6d:f3:e5:f4:68:4f:b3:04:45:88:57:99:82:39:a6:51:9e:5f:42
23:3f:d7:6e:3d:a5:54:a9:b1:2d:6e:90:dd:12:8a:bf:ef:2b:20:50
ba:f0:da:d9:0c:ad:5e:d6:c6:98:3a:ae:3f:90:dd:94:78:c1:ea:2e
7c:f0:2d:d4:79:d4:cd:f0:52:df:5e:72:f2:e7:ae:66:f7:61:f4:bc
72:57:3e:6c:6d:d3:24:58:8b:f4:ef:da:2a:6a:fa:eb:98:f8:34:84
79:54:da:4f:d3:6f:52:1f
Fingerprint:
7c:e8:f9:45:93:8d:a3:92:7f:18:29:02:f1:c8:e2:85:3d:ad:df:1f (sha1)
00:4e:df:a0:6b:ad:8c:50:da:7c:a1:cf:5d:37:b0:ea (md5)
Use for key: Digital signature

```

show security pki crt

Syntax	show security pki crt <brief detail> <ca-profile <i>ca-profile-name</i> >
Release Information	Command introduced in Junos OS Release 8.1.
Description	Display information about the certificate revocation lists (CRLs) that are stored in the router.
Options	<p>none—(same as brief) Display information about all CRLs.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>ca-profile <i>ca-profile-name</i>—(Optional) Display CRL information about only the specified CA profile.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear security pki crt on page 1566
List of Sample Output	<p>show security pki crt on page 1613</p> <p>show security pki crt detail on page 1613</p>
Output Fields	Table 293 on page 1612 shows the output fields for the show security pki crt command. Output fields are listed in the approximate order in which they appear.

Table 293: show security pki crt Output Fields

Field Name	Field Description	Level of Output
CA profile	Name of the configured CA profile.	All levels
CRL version	Revision number of the certificate revocation list.	All levels
CRL number	Number of the certificate revocation list	All levels
CRL issuer	Device that was issued the certificate revocation list.	All levels
Issuer	<p>Details of the digital certificate holder organized using the distinguished name format. Possible subfields are:</p> <ul style="list-style-type: none"> Common name—Name of the authority. Organization—Organization of origin. Organizational unit—Department within an organization. State—State of origin. Country—Country of origin. 	detail
Effective date	Date and time the certificate revocation list becomes valid.	All levels

Table 293: show security pki crl Output Fields (*continued*)

Field Name	Field Description	Level of Output
Next update	Date and time the router will download the latest version of the certificate revocation list.	All levels
Revocation List	<p>List of digital certificates that have been revoked before their expiration date. Values are:</p> <ul style="list-style-type: none"> • Serial number—Unique serial number of the digital certificate • Revocation date—Date and time that the digital certificate was revoked. 	detail

Sample Output

```

show security pki crl  CA profile entrust
                        CRL version: V2
                        CRL number: 24
                        CRL issuer: C=CA, O=juniper
                        Effective date: 2006 May 31st, 05:35:25 GMT
                        Next update: 2006 Jun 1st, 06:35:25 GMT

show security pki crl  CA profile: entrust
detail                CRL version: V2
                        CRL number: 24
                        Issuer:
                        Organization: juniper, Country: ca
                        Validity:
                        Effective date: 2006 May 31st, 05:35:25 GMT
                        Next update: 2006 Jun 1st, 06:35:25 GMT
                        Revocation List:
                        Serial number      Revocation date
                        4451aca3 2006      May 25th, 09:13:38 GMT
                        4451aca4 2006      May 25th, 10:11:33 GMT
                        4451acb4 2006      May 29th, 11:28:54 GMT
                        4451aceb 2006      May 29th, 11:29:01 GMT
                        4451acfe 2006      May 29th, 11:29:17 GMT
                        4451acff 2006      May 31st, 05:29:55 GMT

```

show security pki local-certificate

Syntax	show security pki local-certificate <brief detail> <certificate-id <i>certificate-id-name</i> > <system-generated>
Release Information	Command introduced in Junos OS Release 7.5.
Description	Display information about the local digital certificates and the corresponding public keys installed in the router.
Options	<p>none—(same as brief) Display information about all local digital certificates and corresponding public keys.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>certificate-id <i>certificate-id-name</i>—(Optional) Display information about only the specified the local digital certificate and corresponding public keys.</p> <p>system-generated—(Optional) Auto-generated self-signed certificate.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear security pki local-certificate on page 1568
List of Sample Output	<p>show security pki local-certificate on page 1615</p> <p>show security pki local-certificate detail on page 1616</p>
Output Fields	Table 294 on page 1614 lists the output fields for the show security pki local-certificate command. Output fields are listed in the approximate order in which they appear.

Table 294: show security pki local-certificate Output Fields

Field Name	Field Description	Level of Output
Certificate identifier	Name of the digital certificate.	All levels
Certificate version	Revision number of the digital certificate.	detail
Serial number	Unique serial number of the digital certificate.	detail
Issued by	Authority that issued the digital certificate.	none brief
Issued to	Device that was issued the digital certificate.	none brief

Table 294: show security pki local-certificate Output Fields (*continued*)

Field Name	Field Description	Level of Output
Issuer	Authority that issued the digital certificate, including details of the authority organized using the distinguished name format. Possible subfields are: <ul style="list-style-type: none"> • Common name—Name of the authority. • Organization—Organization of origin. • Organizational unit—Department within an organization. • State—State of origin. • Country—Country of origin. 	detail
Subject	Details of the digital certificate holder organized using the distinguished name format. Possible subfields are: <ul style="list-style-type: none"> • Common name—Name of the authority. • Organization—Organization of origin. • Organizational unit—Department within an organization. • State—State of origin. • Country—Country of origin. 	detail
Alternate subject	Domain name or IP address of the device related to the digital certificate.	detail
Validity	Time period when the digital certificate is valid. Values are: <ul style="list-style-type: none"> • Not before—Start time when the digital certificate becomes valid. • Not after—End time when the digital certificate becomes invalid. 	All levels
Public key algorithm	Encryption algorithm used with the private key, such as rsaEncryption (1024 bits) .	All levels
Public key verification status	Public key verification status: Failed or Passed . The detail output also provides the verification hash.	All levels
Signature algorithm	Encryption algorithm that the CA used to sign the digital certificate, such as sha1WithRSAEncryption .	detail
Fingerprint	Secure Hash Algorithm (SHA1) and Message Digest 5 (MD5) hashes used to identify the digital certificate.	detail
Distribution CRL	Distinguished name information and URL for the certificate revocation list (CRL) server.	detail
Use for key	Use of the public key, such as Certificate signing , CRL signing , Digital signature , or Key encipherment .	detail

Sample Output

```

show security pki  user@host> show security pki local-certificate
local-certificate  Certificate identifier: local-entrust2
                   Issued to: router2.juniper.net, Issued by: juniper
                   Validity:

```

```
Not before: 2005 Nov 21st, 23:28:22 GMT
Not after: 2008 Nov 21st, 23:58:22 GMT
Public key algorithm: rsaEncryption(1024 bits)
Public key verification status: Passed
```

**show security pki
local-certificate detail**

```
user@host> show security pki local-certificate detail
Certificate identifier: local-entrust3
Certificate version: 3
Serial number: 4355 94f9
Issuer:
  Organization: juniper, Country: us
Subject:
  Organization: juniper, Country: us, Common name: router3.juniper.net
Alternate subject: router3.juniper.net
Validity:
  Not before: 2005 Nov 21st, 23:33:58 GMT
  Not after: 2008 Nov 22nd, 00:03:58 GMT
Public key algorithm: rsaEncryption(1024 bits)
Public key verification status: Passed
fb:79:df:d4:a9:03:0f:d3:69:7e:c1:e4:27:35:9c:d9:b1:a2:47:78
d2:6d:f3:e5:f4:68:4f:b3:04:45:88:57:99:82:39:a6:51:9e:5f:42
23:3f:d7:6e:3d:a5:54:a9:b1:2d:6e:90:dd:12:8a:bf:ef:2b:20:50
ba:f0:da:d9:0c:ad:5e:d6:c6:98:3a:ae:3f:90:dd:94:78:c1:ea:2e
7c:f0:2d:d4:79:d4:cd:f0:52:df:5e:72:f2:e7:ae:66:f7:61:f4:bc
72:57:3e:6c:6d:d3:24:58:8b:f4:ef:da:2a:6a:fa:eb:98:f8:34:84
79:54:da:4f:d3:6f:52:1f
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
  61:3a:d0:b4:7a:16:9b:39:ba:81:3f:9d:ab:34:e5:c8:be:3b:a1:6d (sha1)
  60:a0:ff:58:05:4a:65:73:9d:74:3a:e1:83:6f:1b:c8 (md5)
Distribution CRL:
  C=us, O=juniper, CN=CRL1
  http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: Digital signature
```


show services ipsec-vpn certificates

Syntax	show services ipsec-vpn certificates <brief detail> <service-set <i>service-set</i> >
Release Information	Command introduced in Junos OS Release 7.5.
Description	(Adaptive services interfaces only) Display local and remote certificates installed in the IPsec configuration memory cache that are used for the IKE negotiation.
Options	<p>none—(same as brief) Display information about local and remote certificates associated with all service sets.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>service-set <i>service-set</i>—(Optional) Display information about local and remote certificates associated with only the specified service set.</p>
Required Privilege Level	view
List of Sample Output	<p>show security ipsec-vpn certificates on page 1618</p> <p>show security ipsec-vpn certificates detail on page 1618</p>
Output Fields	Table 295 on page 1617 lists the output fields for the show services ipsec-vpn certificates command. Output fields are listed in the approximate order in which they appear.

Table 295: show services ipsec-vpn certificates Output Fields

Field Name	Field Description	Level of Output
Service set	Name of the IPsec service set.	All levels
Total entries	Number of certificate cache entries.	All levels
Certificate cache entry	Identification number of the certificate cache entry.	All levels
Flags	Information about the digital certificate, including whether the certificate is a root certificate and trusted.	none brief
Issued to	Device that was issued the digital certificate.	none brief
Issued by	Authority that issued the digital certificate.	none brief
Certificate version	Revision number of the digital certificate.	detail
Serial number	Unique serial number of the digital certificate.	detail
Alternate subject	Domain name or IP address of the device related to the digital certificate.	All levels

Table 295: show services ipsec-vpn certificates Output Fields (*continued*)

Field Name	Field Description	Level of Output
Validity	Time period when the digital certificate is valid. Values are: <ul style="list-style-type: none"> Not before—Start time when the digital certificate becomes valid. Not after—End time when the digital certificate becomes invalid. 	none brief
Public key algorithm	Specifies the encryption algorithm used with the private key, such as rsaEncryption (1024 bits) .	detail
Signature algorithm	Encryption algorithm that the CA used to sign the digital certificate, such as sha1WithRSAEncryption .	detail
Fingerprint	Secure Hash Algorithm (SHA1) and Message Digest 5 (MD5) hashes used to identify the digital certificate.	detail
Distribution CRL	Distinguished name information and the URL for the certificate revocation list (CRL) server.	detail
Use for key	Use of the public key, such as Certificate signing , CRL signing , Digital signature , or Key encipherment .	detail

Sample Output

```

show security ipsec-vpn certificates user@host> show services ipsec-vpn certificates
Service set: serviceset-dynamic-BiEspsha3des, Total entries: 3
Certificate cache entry: 3
  Flags: Non-root Trusted
  Issued to: router3.juniper.net, Issued by: juniper
  Alternate subject: router3.juniper.net
  Validity:
    Not before: 2005 Nov 21st, 23:33:58 GMT
    Not after: 2008 Nov 22nd, 00:03:58 GMT

Certificate cache entry: 2
  Flags: Non-root Trusted
  Issued to: router2.juniper.net, Issued by: juniper
  Alternate subject: router2.juniper.net
  Validity:
    Not before: 2005 Nov 21st, 23:28:22 GMT
    Not after: 2008 Nov 21st, 23:58:22 GMT

Certificate cache entry: 1
  Flags: Root Trusted
  Issued to: juniper, Issued by: juniper
  Validity:
    Not before: 2005 Oct 18th, 23:54:22 GMT
    Not after: 2025 Oct 19th, 00:24:22 GMT

show security ipsec-vpn certificates detail user@host> show services ipsec-vpn certificates detail
Service set: serviceset-dynamic-BiEspsha3des, Total entries: 3
Certificate cache entry: 3
  Certificate version: 3
  Serial number: 4355 94f9
  Alternate subject: router3.juniper.net

```

```
Public key algorithm: rsaEncryption
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
  61:3a:d0:b4:7a:16:9b:39:ba:81:3f:9d:ab:34:e5:c8:be:3b:a1:6d (sha1)
  60:a0:ff:58:05:4a:65:73:9d:74:3a:e1:83:6f:1b:c8 (md5)
Distribution CRL:
  C=us, O=juniper, CN=CRL1
  http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: Digital signature

Certificate cache entry: 2
Certificate version: 3
Serial number: 4355 94f8
Alternate subject: router2.juniper.net
Public key algorithm: rsaEncryption
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
  30:c3:a4:04:da:33:9d:60:23:5a:48:75:48:2c:f0:c6:96:6c:31:fa (sha1)
  9a:a2:ce:ef:7e:10:80:a0:c8:4d:2f:e7:e1:d3:69:9d (md5)
Distribution CRL:
  C=us, O=juniper, CN=CRL1
  http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: Digital signature

Certificate cache entry: 1
Certificate version: 3
Flags: Root
Serial number: 4355 9235
Public key algorithm: rsaEncryption
Signature algorithm: sha1WithRSAEncryption
Fingerprint:
  00:8e:6f:58:dd:68:bf:25:0a:e3:f9:17:70:d6:61:f3:53:a7:79:10 (sha1)
  71:6f:6a:76:17:9b:d6:2a:e7:5a:72:97:82:6d:26:86 (md5)
Distribution CRL:
  C=us, O=juniper, CN=CRL1
  http://CA-1/CRL/juniper_us_crlfile.crl
Use for key: CRL signing, Certificate signing
```

show services ipsec-vpn ike security-associations

Syntax	show services ipsec-vpn ike security-associations <brief detail> <peer-address>
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Adaptive services interface only) Display information for Internet Key Exchange (IKE) security associations. If no security association is specified, the information for all security associations is displayed.
Options	<p>none—(same as brief) Display standard information for all IPsec security associations.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>peer-address—(Optional) Display information about a particular security association address.</p>
Required Privilege Level	view
List of Sample Output	<p>show services ipsec-vpn ike security-associations on page 1622</p> <p>show services ipsec-vpn ike security-associations detail on page 1622</p>
Output Fields	Table 296 on page 1620 lists the output fields for the show services ipsec-vpn ike security-associations command. Output fields are listed in the approximate order in which they appear.

Table 296: show services ipsec-vpn ike security-associations Output Fields

Field Name	Field Description	Level of Output
IKE peer	Remote end of the IKE negotiation.	detail
Role	Part played in the IKE session. The router triggering the IKE negotiation is the initiator, and the router accepting the first IKE exchange packets is the responder.	detail
Remote Address	Responder's address.	none specified
State	State of the IKE security association: <ul style="list-style-type: none"> • Matured—IKE security association is established. • Not matured—The IKE security association is in the process of negotiation. 	none specified
Initiator cookie	When the IKE negotiation is triggered, a random number is sent to the remote node.	All levels

Table 296: show services ipsec-vpn ike security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Responder cookie	<p>The remote node generates its own random number and sends it back to the initiator as a verification that the packets were received.</p> <p>Of the numerous security services available, protection against denial of service (DoS) is one of the most difficult to address. A “cookie” or anticlogging token (ACT) is aimed at protecting the computing resources from attack without spending excessive CPU resources to determine the cookie's authenticity. An exchange prior to CPU-intensive public key operations can thwart some DoS attempts (such as simple flooding with invalid IP source addresses).</p>	All levels
Exchange type	<p>Specifies the number of messages in an IKE exchange, and the payload types that are contained in each message. Each exchange type provides a particular set of security services, such as anonymity of the participants, perfect forward secrecy of the keying material, and authentication of the participants. Junos OS supports two types of exchanges:</p> <ul style="list-style-type: none"> • Main—The exchange is done with six messages. Main encrypts the payload, protecting the identity of the neighbor. • Aggressive—The exchange is done with three messages. Aggressive does not encrypt the payload, leaving the identity of the neighbor unprotected. 	All levels
Authentication method	Type of authentication determines which payloads are exchanged and when they are exchanged. The Junos OS supports only pre-shared keys .	detail
Local	Prefix and port number of the local end.	detail
Remote	Prefix and port number of the remote end.	detail
Lifetime	Number of seconds remaining until the IKE security association expires.	detail
Algorithms	<p>Header for the IKE algorithms output.</p> <ul style="list-style-type: none"> • Authentication—(detail output only) Type of authentication algorithm used: md5 or sha1 • Encryption—(detail output only) Type of encryption algorithm used: des-cbc, 3des-cbc, or None. • Pseudo random function—Function that generates highly unpredictable random numbers: hmac-md5 or hmac-sha1. 	detail
Traffic statistics	<p>Number of bytes and packets received and transmitted on the IKE security association.</p> <ul style="list-style-type: none"> • Input bytes, Output bytes—Number of bytes received and transmitted on the IKE security association. • Input packets, Output packets—Number of packets received and transmitted on the IKE security association. 	detail

Table 296: show services ipsec-vpn ike security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Flags	Notification to the key management process of the status of the IKE negotiation: <ul style="list-style-type: none"> caller notification sent—Caller program notified about the completion of the IKE negotiation. waiting for done—Negotiation is done. The library is waiting for the remote end retransmission timers to expire. waiting for remove—Negotiation has failed. The library is waiting for the remote end retransmission timers to expire before removing this negotiation. waiting for policy manager—Negotiation is waiting for a response from the policy manager. 	detail
IPsec security associates	Number of IPsec security associations created and deleted with this IKE security association.	detail
Phase 2 negotiations in progress	Number of phase 2 IKE negotiations in progress and status information: <ul style="list-style-type: none"> Negotiation type—Type of phase 2 negotiation. The Junos OS currently supports quick mode. Message ID—Unique identifier for a phase 2 negotiation. Local identity—Identity of the local phase 2 negotiation. The format is <i>id-type-name (proto-name:port-number,[0..id-data-len] = iddata-presentation)</i>. Remote identity—Identity of the remote phase 2 negotiation. The format is <i>id-type-name (proto-name:port-number,[0..id-data-len] = iddata-presentation)</i>. Flags—Notification to the key management process of the status of the IKE negotiation: <ul style="list-style-type: none"> caller notification sent—Caller program notified about the completion of the IKE negotiation. waiting for done—Negotiation is done. The library is waiting for the remote end retransmission timers to expire. waiting for remove—Negotiation has failed. The library is waiting for the remote end retransmission timers to expire before removing this negotiation. waiting for policy manager—Negotiation is waiting for a response from the policy manager. 	detail

Sample Output

```

show services ipsec-vpn ike security-associations user@host> show services ipsec-vpn ike security-associations
Remote Address      State      Initiator cookie  Responder cookie  Exchange type
6.6.6.1             Matured    062d291d21275fc7  82ef00e3d1f1c981  Main
6.6.6.1             Matured    cd6d581d7bb1664d  88a707779f3ad8d1  Main

show services ipsec-vpn ike security-associations detail user@host> show services ipsec-vpn ike security-associations detail
IKE peer 4.4.4.4
Role: Initiator, State: Matured
Initiator cookie: cf22bd81a7000001, Responder cookie: fe83795c2800002e
Exchange type: Main, Authentication method: Pre-shared-keys
Local: 4.4.4.5:500, Remote: 4.4.4.4:500
Lifetime: Expires in 187 seconds

```

```
Algorithms:
Authentication      : md5
Encryption          : 3des-cbc
Pseudo random function: hmac-md5
Traffic statistics:
Input bytes   :      1000
Output bytes  :      1280
Input packets:        5
Output packets:       9
Flags: Caller notification sent
IPsec security associations: 2 created, 0 deleted
Phase 2 negotiations in progress: 1

Negotiation type: Quick mode, Role: Initiator, Message ID: 3582889153
Local: 4.4.4.5:500, Remote: 4.4.4.4:500
Local identity: ipv4_subnet(tcp:80,[0..7]=10.1.1.0/24)
Remote identity: ipv4_subnet(tcp:100,[0..7]=10.1.2.0/24)
Flags: Caller notification sent, Waiting for done
```

show services ipsec-vpn ipsec security-associations

Syntax	show services ipsec-vpn ipsec security-associations <brief detail extensive> <service-set <i>service-set-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	(Adaptive services interface only) Display IPsec security associations for the specified service set. If no service set is specified, the security associations for all service sets are displayed.
Options	<p>none—Display standard information about IPsec security associations for all service sets.</p> <p>brief detail extensive—(Optional) Display the specified level of output.</p> <p>service-set <i>service-set-name</i>—(Optional) Display information about a particular service set.</p>
Required Privilege Level	view
List of Sample Output	show services ipsec-vpn ipsec security associations extensive on page 1626
Output Fields	Table 297 on page 1624 lists the output fields for the show services ipsec-vpn ipsec security-associations command. Output fields are listed in the approximate order in which they appear.

Table 297: show services ipsec-vpn ipsec security-associations Output Fields

Field Name	Field Description	Level of Output
Service set	Name of the service set for which the IPsec security associations are defined. If appropriate, includes the outside service interface VRF name.	All levels
Rule	Name of the rule set applied to the security association.	detail extensive
Term	Name of the IPsec term applied to the security association.	detail extensive
Tunnel index	Numeric identifier of the specific IPsec tunnel for the security association.	detail extensive
Local gateway	Gateway address of the local system.	All levels
Remote gateway	Gateway address of the remote system.	All levels
IPsec inside interface	Name of the logical interface hosting the IPsec tunnels.	All levels
Local identity	Prefix and port number of the local end	All levels
Remote identity	Prefix and port number of the remote end.	All levels

Table 297: show services ipsec-vpn ipsec security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Primary remote gateway	IP address of the configured primary remote peer.	All levels
Backup remote gateway	IP address of the configured backup remote peer.	All levels
State	State of the primary or backup interface: Active , Offline , or Standby . Both ES PICs are initialized to Offline . For primary and backup peers, State can be Active or Standby . If both peers are in a state of Standby , no connection exists yet between the two peers.	All levels
Failover counter	Number of times a PIC switched between primary and backup interfaces, or the number of times the tunnel switched between the primary and remote peers since the software has been activated.	All levels
Direction	Direction of the security association: inbound or outbound .	All levels
SPI	Value of the security parameter index.	All levels
AUX-SPI	Value of the auxiliary security parameter index. <ul style="list-style-type: none"> When the value of Protocol is AH or ESP, AUX-SPI is always 0. When the value of Protocol is AH+ESP, AUX-SPI is always a positive integer. 	All levels
Mode	Mode of the security association: <ul style="list-style-type: none"> transport—Protects single host-to-host protections. tunnel—Protects connections between security gateways. 	detail extensive
Type	Type of security association: <ul style="list-style-type: none"> manual—Security parameters require no negotiation. They are static, and are configured by the user. dynamic—Security parameters are negotiated by the IKE protocol. Dynamic security associations are not supported in transport mode. 	detail extensive
State	Status of the security association: <ul style="list-style-type: none"> Installed—The security association is installed in the security association database. (For transport mode security associations, the value of State must always be Installed) Not installed—The security association is not installed in the security association database. 	detail extensive
Protocol	Protocol supported: <ul style="list-style-type: none"> transport mode supports Encapsulation Security Protocol (ESP) or Authentication Header (AH). tunnel mode supports ESP or AH+ESP. 	All levels
Authentication	Type of authentication used: hmac-md5-96 , hmac-sha1-96 , or none .	detail extensive

Table 297: show services ipsec-vpn ipsec security-associations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Encryption	Type of encryption algorithm used: can be aes-cbc (128 bits) , aes-cbc (192 bits) , aes-cbc (256 bits) , des-cbc , 3des-cbc , or None .	detail
Soft lifetime Hard lifetime	Each lifetime of a security association has two display options, hard and soft, one of which must be present for a dynamic security association. The hard lifetime specifies the lifetime of the SA. The soft lifetime, which is derived from the hard lifetime, informs the IPsec key management system that the SA is about to expire. This information allows the key management system to negotiate a new SA before the hard lifetime expires. <ul style="list-style-type: none"> • Expires in seconds seconds—Number of seconds left until the security association expires. • Expires in kilobytes kilobytes—Number of kilobytes left until the security association expires. 	detail extensive
Anti-replay service	State of the service that prevents packets from being replayed: Enabled or Disabled .	detail extensive
Replay window size	Configured size, in packets, of the antireplay service window: 32 or 64 . The antireplay window size protects the receiver against replay attacks by rejecting old or duplicate packets. If the replay window size is 0 , antireplay service is disabled.	detail

Sample Output

```

show services ipsec-vpn ipsec security associations extensive
user@host> show services ipsec-vpn ipsec security-associations extensive
Service set: service-set-1
Rule: _junos_, Term: term-1, Tunnel index: 1
Local gateway: 101.101.101.2, Remote gateway: 14.14.14.4
IPSec inside interface: sp-2/0/0.1 Local identity:
ipv4_subnet(any:0,[0..7]=0.0.0.0/0)
Remote identity: ipv4_subnet(any:0,[0..7]=0.0.0.0/0)
Primary remote gateway: 101.101.101.1, State: Standby
Backup remote gateway: 14.14.14.4, State: Active
Failover counter: 1

Direction: inbound, SPI: 3743521590, AUX-SPI: 0
Mode: tunnel, Type: dynamic, State: Installed
Protocol: ESP, Authentication: hmac-sha1-96, Encryption: 3des-cbc
Soft lifetime: Expires in 23043 seconds
Hard lifetime: Expires in 23178 seconds
Anti-replay service: Enabled, Replay window size: 64

Direction: outbound, SPI: 2551045240, AUX-SPI: 0
Mode: tunnel, Type: dynamic, State: Installed
Protocol: ESP, Authentication: hmac-sha1-96, Encryption: 3des-cbc
Soft lifetime: Expires in 23043 seconds
Hard lifetime: Expires in 23178 seconds
Anti-replay service: Enabled, Replay window size: 64

```

show services ipsec-vpn ipsec statistics

Syntax	show services ipsec-vpn ipsec statistics <brief detail> <remote-gw remote-peer-address> <service-set service-set-name>
Release Information	Command introduced before Junos OS Release 7.4. New fields added in Junos OS Release 10.0.
Description	(Adaptive services interface only) Display IPsec statistics for the specified service set. If no service set is specified, the statistics for all service sets are displayed.
Options	none—Display standard IPsec statistics for all service sets. brief detail—(Optional) Display the specified level of output. remote-gw remote-peer-address—(Optional) Display IPsec statistics for an individual IPsec tunnel and an individual remote host. service-set service-set-name—(Optional) Display information about a particular service set.
Required Privilege Level	view
List of Sample Output	show services ipsec-vpn ipsec statistics detail on page 1629 show services ipsec-vpn ipsec statistics remote-gw on page 1629
Output Fields	Table 298 on page 1627 lists the output fields for the show services ipsec-vpn ipsec statistics command. Output fields are listed in the approximate order in which they appear.

Table 298: show services ipsec-vpn ipsec statistics Output Fields

Field Name	Field Description	Level of Output
PIC	The physical interface on which the IPsec tunnel is configured.	All levels
Service set	Name of the service set for which the IPsec tunnel is defined.	All levels
Local gateway	Gateway address of the local system.	All levels
Remote gateway	Gateway address of the remote system.	All levels
Tunnel index	Numeric identifier of the specific IPsec tunnel for the security association.	All levels

Table 298: show services ipsec-vpn ipsec statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
ESP statistics	Encapsulation Security Payload (ESP) statistics: <ul style="list-style-type: none"> • Encrypted bytes—Total number of bytes encrypted by the local system across the IPsec tunnel. • Decrypted bytes—Total number of bytes decrypted by the local system across the IPsec tunnel. • Encrypted packets—Total number of packets encrypted by the local system across the IPsec tunnel. • Decrypted packets—Total number of packets decrypted by the local system across the IPsec tunnel. 	All levels
AH Statistics	Authentication Header statistics: <ul style="list-style-type: none"> • Input bytes—Total number of bytes received by the local system across the IPsec tunnel. • Output bytes—Total number of bytes transmitted by the local system across the IPsec tunnel. • Input packets—Total number of packets received by the local system across the IPsec tunnel. • Output packets—Total number of packets transmitted by the local system across the IPsec tunnel. 	All levels
Errors	<ul style="list-style-type: none"> • AH authentication failures—Number of authentication header (AH) failures. An AH failure occurs when there is a mismatch of the authentication header in a packet transmitted across an IPsec tunnel. • ESP authentication failures—Number of Encapsulation Security Payload (ESP) failures. An ESP failure occurs when there is an authentication mismatch in ESP packets. • ESP Decryption failures—Number of ESP decryption failures. • Bad headers—Number of invalid headers detected. • Bad trailers—Number of invalid trailers detected. • Replay before window drops—Number of replay errors. A replay error is generated when a duplicate packet is received within the replay window. • Replayed pkts—Number of packets replayed. • IP integrity errors—Number of IP integrity errors. • Exceeds tunnel MTU—Number of times the tunnel maximum transmission unit (MTU) value was exceeded. • Rule lookup failures—Number of rule lookup failures. • No SA errors—Number of errors resulting from a missing security association (SA). • Flow errors—Number of flow errors. • Misc errors—Number of miscellaneous errors. 	All levels

Sample Output

```

show services      user@host> show services ipsec-vpn ipsec statistics
ipsec-vpn ipsec    PIC: sp-0/2/0, Service set: ss0
statistics detail

ESP Statistics:
  Encrypted bytes:          0
  Decrypted bytes:          0
  Encrypted packets:        0
  Decrypted packets:        0
AH Statistics:
  Input bytes:              168
  Output bytes:             168
  Input packets:            2
  Output packets:           2
Errors:
  AH authentication failures: 0
  ESP authentication failures: 0
  ESP decryption failures:    0
  Bad headers: 0, Bad trailers: 0
  Replay before window drops: 0, Replayed pkts: 0
  IP integrity errors: 0, Exceeds tunnel MTU: 0
  Rule lookup failures: 0, No SA errors: 0
  Flow errors: 0, Misc errors: 0


show services      user@host> show services ipsec-vpn ipsec statistics remote-gw 22.22.2.1
ipsec-vpn ipsec    PIC: sp-3/1/0, Service set: service-set-2
statistics remote-gw Local gateway: 22.22.1.1, Remote gateway: 22.22.2.1, Tunnel index: 2

ESP Statistics:
  Encrypted bytes:          0
  Decrypted bytes:          0
  Encrypted packets:        0
  Decrypted packets:        0
AH Statistics:
  Input bytes:              0
  Output bytes:             0
  Input packets:            0
  Output packets:           0
Errors:
  AH authentication failures: 0
  ESP authentication failures: 0
  ESP decryption failures:    0
  Bad headers: 0, Bad trailers: 0
  Replay before window drops: 0, Replayed pkts: 0
  IP integrity errors: 0, Exceeds tunnel MTU: 0
  Rule lookup failures: 0, No SA errors: 0
  Flow errors: 0, Misc errors: 0

```

show system certificate

Syntax	show system certificate <certificate-id>
Release Information	Command introduced before Junos OS Release 7.4. Command introduced in Junos OS Release 11.1 for the QFX Series.
Description	(Encryption interface on M Series, T Series routers, and QFX Series switches only) Display installed certificates signed by the Juniper Networks certificate authority.
Options	none—Display all installed certificates signed by the Juniper Networks certificate authority. certificate-id—(Optional) Display the details of a particular certificate.
Required Privilege Level	maintenance
List of Sample Output	show system certificate on page 1631 show system certificate (QFX Series) on page 1631
Output Fields	Table 299 on page 1630 lists the output fields for the show system certificate command. Output fields are listed in the approximate order in which they appear.

Table 299: show system certificate Output Fields

Field Name	Field Description
Certificate identifier	Unique identifier associated with a certificate. The certificate identifier is the common name of the subject.
Issuer Subject	Information about the certificate issuer and the distinguished name (DN) of the issuer, respectively: <ul style="list-style-type: none"> • Organization—Name of the owner's organization. • Organizational unit—Name of the owner's department. • Country—Two-character country code in which the owner's system is located. • State—State in the USA in which the owner is using the certificate. • Locality—City in which the owner's system is located. • Common name—Name of the owner of the certificate. • E-mail address—E-mail address of the owner of the certificate.
Validity	When a certificate is valid.
Signature algorithm	Encryption algorithm applied to the installed certificate.
Public key algorithm	Encryption algorithm applied to the public key.

Sample Output

```

user@host> show system certificate
Certificate identifier: Dallas-v3
  Issuer:
    Organization: Juniper Networks, Organizational unit: Juniper CA,
    Country: US, State: CA, Locality: Sunnyvale, Common name: Dallas CA,
    E-mail address:ca@juniper.net
  Subject:
    Organization: Juniper Networks, Organizational unit: Juniper CA,
    Country: US, State: CA, Locality: Sunnyvale, Common name: Dallas-v3,
    E-mail address:ca@juniper.net
  Validity:
    Not before: Mar 13 03:23:25 2004 GMT
    Not after: Mar 24 03:23:25 2014 GMT
  Signature algorithm: sha1WithRSAEncryption
  Public key algorithm: dsaEncryption

```

```

user@host> show system certificate
Certificate identifier: Dallas-v3
  Issuer:
    Organization: Juniper Networks, Organizational unit: Juniper CA,
    Country: US, State: CA, Locality: Sunnyvale, Common name: Dallas CA,
    E-mail address:ca@juniper.net
  Subject:
    Organization: Juniper Networks, Organizational unit: Juniper CA,
    Country: US, State: CA, Locality: Sunnyvale, Common name: Dallas-v3,
    E-mail address:ca@juniper.net
  Validity:
    Not before: Mar 13 03:23:25 2004 GMT
    Not after: Mar 24 03:23:25 2014 GMT
  Signature algorithm: sha1WithRSAEncryption
  Public key algorithm: dsaEncryption

```


Layer 2 Tunneling Protocol Operational Mode Commands

Table 300 on page 1633 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot Layer 2 Tunneling Protocol (L2TP) services. Commands are listed in alphabetical order.

Table 300: L2TP Services Operational Mode Commands

Task	Command
Clear L2TP destinations.	<code>clear services l2tp destination</code>
Clear L2TP multilink bundles.	<code>clear services l2tp multilink</code>
Clear L2TP sessions.	<code>clear services l2tp session</code>
Clear statistics for L2TP sessions.	<code>clear services l2tp session statistics</code>
Clear L2TP tunnels.	<code>clear services l2tp tunnel</code>
Clear statistics for L2TP tunnels.	<code>clear services l2tp tunnel statistics</code>
Display information about L2TP tunnel destinations.	<code>show services l2tp destination</code>
Display L2TP multilink bundles.	<code>show services l2tp multilink</code>
Display RADIUS server and statistics information.	<code>show services l2tp radius</code>
Display active L2TP sessions.	<code>show services l2tp session</code>
Display L2TP summary information.	<code>show services l2tp summary</code>
Display active L2TP tunnels.	<code>show services l2tp tunnel</code>
Display active L2TP users.	<code>show services l2tp user</code>



NOTE: L2TP services are supported on the adaptive services (*sp-fpc/pic/port*) interface on M7i and M10i routers.



NOTE: For information about how to configure L2TP services, see the *Junos OS Services Interfaces Configuration Guide*.

clear services l2tp destination

Syntax	clear services l2tp destination all
Release Information	Command introduced in Junos OS Release 10.4.
Description	Clear all Layer 2 Tunneling Protocol (L2TP) destinations and all tunnels and sessions that belong to the destinations. This command is available only for LAC on MX Series routers.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show services l2tp destination on page 1645
List of Sample Output	clear services l2tp destination all on page 1635
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services l2tp destination all
user@host> clear services l2tp destination all
Destination 2 closed
```

clear services l2tp multilink

Syntax	clear services l2tp multilink (all <statistics> bundle-id <i>number</i> <statistics> statistics (all bundle-id <i>number</i>))
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M10i and M7i routers only) Close Layer 2 Tunneling Protocol (L2TP) multilink sessions or clear session statistics.
Options	<p>all <statistics>—Close all L2TP multilink sessions or clear statistics for all L2TP multilink sessions.</p> <p>bundle-id <i>number</i> <statistics>—L2TP multilink bundle ID. The value is an internally generated number from 1 to 65535. Close the specified L2TP multilink session, or using the statistics keyword with this option, clear statistics for the specified session.</p> <p>statistics (all bundle-id <i>number</i>)—Clear all session statistics or clear statistics for the specified multilink bundle ID.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• show services l2tp multilink on page 1648
List of Sample Output	clear services l2tp multilink statistics all on page 1636
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services l2tp multilink statistics all	user@host> clear services l2tp multilink statistics all Multilink 1 statistics cleared
---	---

clear services l2tp session

Syntax	clear services l2tp session (all interface <i>sp-fpc/pic/port</i> local-gateway <i>gateway-address</i> local-gateway-name <i>gateway-name</i> local-tunnel-id <i>tunnel-id</i> peer-gateway <i>gateway-address</i> peer-gateway-name <i>gateway-name</i> tunnel-group <i>group-name</i> user <i>username</i>)
Release Information	Command introduced before Junos OS Release 7.4. Support for MX Series routers added in Junos OS Release 10.4.
Description	(M10i and M7i routers: LNS only. MX Series routers: LAC only.) Clear Layer 2 Tunneling Protocol (L2TP) sessions.
Options	<p>all—Close all L2TP sessions.</p> <p>interface <i>sp-fpc/pic/port</i>—Clear only the L2TP sessions using the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.</p> <p>local-gateway <i>gateway-address</i>—Clear only the L2TP sessions associated with the specified local gateway address.</p> <p>local-gateway-name <i>gateway-name</i>—Clear only the L2TP sessions associated with the specified local gateway name.</p> <p>local-session-id <i>session-id</i> —Clear only the L2TP sessions with this identifier for the local endpoint of the L2TP session.</p> <p>local-tunnel-id <i>tunnel-id</i>—Clear only the L2TP sessions associated with the specified local tunnel identifier.</p> <p>peer-gateway <i>gateway-address</i>—Clear only the L2TP sessions associated with the peer gateway with the specified address.</p> <p>peer-gateway-name <i>gateway-name</i>—Clear only the L2TP sessions associated with the peer gateway with the specified name.</p> <p>tunnel-group <i>group-name</i>—Clear only the L2TP sessions associated with the specified tunnel group. This option is not available for L2TP LAC on MX Series routers.</p> <p>user <i>username</i> —Clear only the L2TP sessions for the specified username. This option is not available for L2TP LAC on MX Series routers.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • clear services l2tp session statistics on page 1639 • show services l2tp session on page 1655
List of Sample Output	clear services l2tp session on page 1638
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services l2tp session user@host> clear services l2tp session 31694
                               Session 31694 closed
```

clear services l2tp session statistics

Syntax	clear services l2tp session statistics (all interface <i>sp-fpc/pic/port</i> local-gateway <i>gateway-address</i> local-gateway-name <i>gateway-name</i> local-session-id <i>session-id</i> local-tunnel-id <i>tunnel-id</i> peer-gateway <i>gateway-address</i> peer-gateway-name <i>gateway-name</i> tunnel-group <i>group-name</i> user <i>username</i>)
Release Information	Command introduced before Junos OS Release 7.4. Support for MX Series routers added in Junos OS Release 10.4.
Description	(M10i and M7i routers: LNS only. MX Series routers: LAC only.) Clear statistics for Layer 2 Tunneling Protocol (L2TP) sessions.
Options	<p>all—Clear statistics for all L2TP sessions.</p> <p>interface <i>sp-fpc/pic/port</i>—Clear statistics for only the L2TP sessions using the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.</p> <p>local-gateway <i>gateway-address</i>—Clear statistics for only the L2TP sessions associated with the local gateway with the specified address.</p> <p>local-gateway-name <i>gateway-name</i>—Clear statistics for only the L2TP sessions associated with the local gateway with the specified name.</p> <p>local-session-id <i>session-id</i>—Clear statistics for only the L2TP sessions with this identifier for the local endpoint of the L2TP session.</p> <p>local-tunnel-id <i>tunnel-id</i>—Clear statistics for only the L2TP sessions associated with the specified local tunnel identifier.</p> <p>peer-gateway <i>gateway-address</i>—Clear statistics for only the L2TP sessions associated with the peer gateway with the specified address.</p> <p>peer-gateway-name <i>gateway-name</i>—Clear statistics for only the L2TP sessions associated with the peer gateway with the specified name.</p> <p>tunnel-group <i>group-name</i>—Clear statistics for only the L2TP sessions associated with the specified tunnel group. This option is not available for L2TP LAC on MX Series routers.</p> <p>user <i>username</i> <statistics>—Clear statistics for only the L2TP sessions for the specified username. This option is not available for L2TP LAC on MX Series routers.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear services l2tp session on page 1637 • show services l2tp session on page 1655
List of Sample Output	clear services l2tp session statistics all on page 1640

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services l2tp session statistics all
user@host> clear services l2tp session statistics all
Session 26497 statistics cleared
```


clear services l2tp tunnel

Syntax	clear services l2tp tunnel (all interface <i>sp-fpc/pic/port</i> local-gateway <i>gateway-address</i> local-gateway-name <i>gateway-name</i> local-tunnel-id <i>tunnel-id</i> peer-gateway <i>gateway-address</i> peer-gateway-name <i>gateway-name</i> tunnel-group <i>group-name</i>)
Release Information	Command introduced before Junos OS Release 7.4. Support for MX Series routers added in Junos OS Release 10.4.
Description	(M10i and M7i routers: LNS only. MX Series routers: LAC only.) Clear Layer 2 Tunneling Protocol (L2TP) tunnels.
Options	<p>all—Clear all L2TP tunnels.</p> <p>interface <i>sp-fpc/pic/port</i>—Clear only the L2TP tunnels using the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.</p> <p>local-gateway <i>gateway-address</i>—Clear only the L2TP tunnels associated with the local gateway with the specified address.</p> <p>local-gateway-name <i>gateway-name</i>—Clear only the L2TP tunnels associated with the local gateway with the specified name.</p> <p>local-tunnel-id <i>tunnel-id</i>—Clear only the L2TP tunnels that have the specified local tunnel identifier.</p> <p>peer-gateway <i>gateway-address</i>—Clear only the L2TP tunnels associated with the peer gateway with the specified address.</p> <p>peer-gateway-name <i>gateway-name</i>—Clear only the L2TP tunnels associated with the peer gateway with the specified name.</p> <p>tunnel-group <i>group-name</i>—Clear only the L2TP tunnels in the specified tunnel group. This option is not available for L2TP LAC on MX Series routers.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear services l2tp tunnel statistics on page 1643 show services l2tp tunnel on page 1663
List of Sample Output	clear services l2tp tunnel on page 1641
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services l2tp tunnel
user@host> clear services l2tp tunnel 17185
```

Tunnel 17185 closed

clear services l2tp tunnel statistics

Syntax	clear services l2tp tunnel statistics (all interface <i>sp-fpc/pic/port</i> local-gateway <i>gateway-address</i> local-gateway-name <i>gateway-name</i> local-tunnel-id <i>tunnel-id</i> peer-gateway <i>gateway-address</i> peer-gateway-name <i>gateway-name</i> tunnel-group <i>group-name</i>)
Release Information	Command introduced before Junos OS Release 7.4. Support for MX Series routers added in Junos OS Release 10.4.
Description	(M10i and M7i routers: LNS only. MX Series routers: LAC only.) Clear statistics for Layer 2 Tunneling Protocol (L2TP) tunnels.
Options	<p>all—Clear statistics for all L2TP tunnels.</p> <p>interface <i>sp-fpc/pic/port</i>—Clear statistics for only the L2TP tunnels using the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.</p> <p>local-gateway <i>gateway-address</i>—Clear statistics for only the L2TP tunnels associated with the local gateway with the specified address.</p> <p>local-gateway-name <i>gateway-name</i>—Clear statistics for only the L2TP tunnels associated with the local gateway with the specified name.</p> <p>local-tunnel-id <i>tunnel-id</i>—Clear statistics for only the L2TP tunnels that have the specified local tunnel identifier.</p> <p>peer-gateway <i>gateway-address</i>—Clear statistics for only the L2TP tunnels associated with the peer gateway with the specified address.</p> <p>peer-gateway-name <i>gateway-name</i>—Clear statistics for only the L2TP tunnels associated with the peer gateway with the specified name.</p> <p>tunnel-group <i>group-name</i>—Clear statistics for only the L2TP tunnels in the specified tunnel group. This option is not available for L2TP LAC on MX Series routers.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> clear services l2tp tunnel on page 1641 show services l2tp tunnel on page 1663
List of Sample Output	clear services l2tp tunnel statistics all on page 1643
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services l2tp tunnel statistics all
user@host> clear services l2tp tunnel statistics all
```

Tunnel 9933 statistics cleared

show services l2tp destination

Syntax	show services l2tp destination <brief detail extensive> <local-gateway <i>gateway-address</i> > <peer-gateway <i>gateway-address</i> >
Release Information	Command introduced in Junos OS Release 10.4.
Description	Display information about L2TP tunnel destinations. This statement is available only for LAC on MX Series routers.
Options	<p>brief detail—(Optional) Display the specified level of information.</p> <p>local-gateway <i>gateway-address</i>—(Optional) Display L2TP session information for only the specified local gateway address.</p> <p>local-gateway-name <i>gateway-name</i>—(Optional) Display L2TP session information for only the specified local gateway name.</p> <p>peer-gateway <i>gateway-address</i>—(Optional) Display L2TP session information for only the specified peer gateway address.</p> <p>peer-gateway-name <i>gateway-name</i>—(Optional) Display L2TP session information for only the specified peer gateway name.</p>
Required Privilege Level	view
List of Sample Output	<p>show services l2tp destination on page 1646</p> <p>show services l2tp destination detail on page 1646</p> <p>show services l2tp destination extensive on page 1646</p>
Output Fields	Table 301 on page 1645 lists the output fields for the show services l2tp destination command. Output fields are listed in the approximate order in which they appear.

Table 301: show services l2tp destination Output Fields

Field Name	Field Description
Local Name	Name of this destination.
Remote IP	IP address of the remote peer (LNS).
Tunnels	<p>Number of tunnel connections for the destination in the following categories:</p> <ul style="list-style-type: none"> total active failed

Table 301: show services l2tp destination Output Fields (*continued*)

Field Name	Field Description
Sessions	Number of session connections for the destination in the following categories: <ul style="list-style-type: none"> total active failed
State	Administrative state of the L2TP destination: <ul style="list-style-type: none"> Enabled—No restrictions exist on creation or operation of sessions and tunnels for this destination. Disabled—Existing sessions and tunnels for this destination have been disabled and no new sessions or tunnels will be created while in the Disabled state.
Local IP	IP address of the local gateway (LAC).
Transport	Medium used for tunneling. Only ipUdp is supported.
Logical System	Logical system in which the tunnel is configured.
Router Instance	Routing instance in which the tunnel is configured.
Lockout State	Reachability state of the destination: <ul style="list-style-type: none"> not locked—Destination is considered reachable. waiting for lockout timeout—Destination is locked out by L2TP because it is unreachable, so no attempts are made to reach the destination until the lockout timeout (300 seconds) expires, unless this is the only destination available for tunneling the subscriber.
Connections	Number of total, active, and failed tunnel and session connections for the destination.

Sample Output

```

show services l2tp destination user@host> show services l2tp destination
                                Local Name  Remote IP  Tunnels  Sessions  State
                                1           10.10.1.1    1         1         Enabled

show services l2tp destination detail user@host> show services l2tp destination detail
Local name: 1
Remote IP: 10.1.1.1
Tunnels: 1, Sessions: 1
State: Enabled
Local IP: 10.1.1.2
Transport: ipUdp, Logical System: default, Router Instance: default
Lockout State: not locked

show services l2tp destination extensive user@host> show services l2tp destination extensive
Local name: 1
Remote IP: 10.1.1.1
State: Enabled
Local IP: 10.1.1.2
Transport: ipUdp, Logical System: default, Router Instance: default
Lockout State: not locked

```

Connections	Totals	Active	Failed
Tunnels	1	1	0
Sessions	1	1	0

show services l2tp multilink

Syntax	show services l2tp multilink <brief detail extensive statistics> <bundle-id <i>number</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M10i and M7i routers only) Display L2TP output organized by multilink bundle.
Options	<p>none—Same as brief.</p> <p>brief detail extensive statistics—(Optional) Display the specified level of output. Use the statistics option to display packets and bytes that have been encapsulated in the Multilink Protocol. Nonmultilink packets received on member sessions are not counted here.</p> <p>bundle-id <i>number</i>—(Optional) Display L2TP multilink bundle information for only the specified bundle.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear services l2tp multilink on page 1636
List of Sample Output	show services l2tp multilink extensive on page 1650
Output Fields	Table 302 on page 1648 lists the output fields for the show services l2tp multilink command. Output fields are listed in the approximate order in which they appear.

Table 302: show services l2tp multilink Output Fields

Field Name	Field Description
Bundle ID	Bundle identifier.
Links	Number of links in the multilink bundle.
Bundle endpoint	Endpoint discriminator that represents the device transmitting the packet.
Input MRRU	Maximum packet size that the input interface can process.
Output MRRU	Maximum packet size that the output interface can process.
Session local ID	Identifier of the local endpoint of the L2TP session, as assigned by the L2TP network server (LNS).
Session remote ID	Identifier of the remote endpoint of the L2TP session, as assigned by the L2TP access concentrator (LAC).

Table 302: show services l2tp multilink Output Fields (*continued*)

Field Name	Field Description
State	<p>Status of the L2TP session:</p> <ul style="list-style-type: none"> • Established—The session is operating. • closed—The session is being closed. • destroyed—The session is being destroyed. • clean-up—The session is being cleaned up. • lns-ic-accept-new—A new session is being accepted. • lns-ic-idle—The session has been created and is idle. • lns-ic-reject-new—The new session is being rejected. • lns-ic-wait-connect—The session is waiting for the peer's incoming call connected (ICCN) message.
Username	Name of the user logged in to the session.
Mode	Mode of the interface representing the multilink bundle: dedicated or shared .
Local IP	IP address of the local endpoint of the Point-to-Point Protocol (PPP) session.
Remote IP	IP address of the remote endpoint of the PPP session.
Local name	Name of the LNS instance in which the session was created.
Remote name	Name of the LAC from which the session was created.
Local MRU	Maximum receive unit (MRU) setting of the local device, in bytes.
Remote MRU	MRU setting of the remote device, in bytes.
Statistics since	<p>Date and time when collection of the following statistics began:</p> <ul style="list-style-type: none"> • Control Tx—Amount of control information transmitted, in packets and bytes. • Control Rx—Amount of control information received, in packets and bytes. • Data Tx—Amount of data transmitted, in packets and bytes. • Data Rx—Amount of data received, in packets and bytes. • Errors Tx—Number of errors transmitted, in packets. • Errors Rx—Number of errors received, in packets.

Sample Output

```
show services l2tp      user@host> show services l2tp multilink extensive
multilink extensive    Bundle ID: 1
                        Links: 2, Bundle endpoint: user@juniper.com
                        Input MRRU: 1524, Output MRRU: 1524
                        Session local ID: 46122, Session remote ID: 39307
                        State: Established, Username: user1@juniper.com, Mode: dedicated
                        Local IP: 10.58.255.129:1701, Remote IP: 10.58.255.131:1701
                        Local name: router3, Remote name: router4
                        Session local ID: 4254, Session remote ID: 39308
                        State: Established, Username: user2@juniper.com, Mode: dedicated
                        Local IP: 10.1.255.1:1701, Remote IP: 10.1.255.2:1701
                        Local name: router1, Remote name: router2
                        Statistics since: Mon May 17 11:47:35 2004
```

	Packets	Bytes
Control Tx	7	196
Control Rx	3	90
Data Tx	0	0
Data Rx	0	0
Errors Tx	0	
Errors Rx	0	

show services l2tp radius

Syntax	<pre>show services l2tp radius <accounting (servers statistics)> <authentication (servers statistics)> <servers> <statistics></pre>
Release Information	Command introduced in Junos OS Release 9.0.
Description	(M7i, M10i, and M120 routers only) Display RADIUS servers and statistics information for the RADIUS servers configured on the router.
Options	<p>You must include one of the following keywords to provide a valid completion for the command:</p> <p>accounting (servers statistics)—(Optional) Display RADIUS servers or statistical accounting information only.</p> <p>authentication (servers statistics)—(Optional) Display RADIUS servers or statistical authentication information only.</p> <p>servers—(Optional) Display RADIUS authentication and accounting server information only.</p> <p>statistics—(Optional) Display RADIUS authentication and accounting statistics information only.</p>
Required Privilege Level	view
List of Sample Output	<p>show services l2tp radius servers on page 1652</p> <p>show services l2tp radius statistics on page 1653</p>
Output Fields	Table 303 on page 1651 lists the output fields for the show services l2tp radius command. Output fields are listed in the approximate order in which they appear.

Table 303: show services l2tp radius Output Fields

Field Name	Field Description
IP Address	IP address of the server.
State	(servers keyword only) Present state of the server.
UDP Port	Number of the UDP port used to send authentication or accounting messages to the server.
Retry Count	(servers keyword only) Number of times the RADIUS client resends a packet if no ACK is received.
Timeout	(servers keyword only) Length of time the client waits for an ACK before retransmission.
Pending Requests	(servers keyword only) Number of client pending authentication or accounting requests.

Table 303: show services l2tp radius Output Fields (*continued*)

Field Name	Field Description
Maximum Sessions	(servers keyword only) Maximum number of pending requests on each RADIUS client before the server moves to the next RADIUS client, which is 200 times the maximum number of clients that can be created on a server (which is 12).
Dead Time	(servers keyword only) Interval to wait before retrying a server after it fails to send a response to an authentication or accounting request.
Secret Type	(servers keyword only) Secret type configured on the RADIUS server.
Profile	(servers keyword only) Name of profile configured for the RADIUS server.
Access requests	(statistics keyword only) Number of access requests sent to the server.
Rollover requests	(statistics keyword only) Number of requests coming into the server as a result of the previous server timing out.
Retransmissions	(statistics keyword only) Number of retransmissions.
Access accepts	(statistics keyword only) Number of access accept messages received from the server.
Access rejects	(statistics keyword only) Number of access reject messages received from the server.
Access challenges	(statistics keyword only) Number of access challenges received from the server.
Malformed responses	(statistics keyword only) Number of responses with attributes having an invalid length or unexpected attributes (such as two attributes when the response is required to have at most one).
Bad authenticators	(statistics keyword only) Number of responses in which the authenticator is incorrect for the matching request. This can occur if the RADIUS secrets for the client and server do not match.
Requests pending	(statistics keyword only) Number of requests waiting for a response.
Request timeouts	(statistics keyword only) Number of requests that timed out.
Unknown responses	(statistics keyword only) Number of unknown responses. The RADIUS response type in the header is invalid or unsupported.
Packets dropped	(statistics keyword only) Number of packets dropped because they are too short or because the router receives a response for which there is no corresponding request. For example, if the router sends a request that times out, the router removes the request from the list and sends a new request. If the server is slow and sends a response to the first request after the router removes the request, the packet is dropped.

Sample Output

```

show services l2tp radius servers user@host> show services l2tp radius servers
                                     RADIUS Authentication Servers

                                     UDP  Retry          Pending  Maximum  Dead    Secret

```

IP Address	State	Port	Count	Timeout	Requests	Sessions	Time	Type
17.1.1.1	Active	1812	2	25	0	2400	300	radius-key
133.122.1.1	Active	1812	5	35	0	2400	300	radius-key
134.141.1.1	Active	1812	2	25	0	2400	300	radius-key
172.28.30.174	Active	1812	7	75	0	2400	300	radius-key
172.28.30.175	Active	1812	7	75	0	2400	300	radius-key
172.28.30.176	Active	1812	4	55	0	2400	300	radius-key
172.128.30.176	Active	1812	3	3	0	2400	300	none-set
172.128.130.174	Active	1812	7	75	0	2400	300	radius-key

RADIUS Accounting Servers

IP Address	State	UDP Port	Retry Count	Timeout	Pending Requests	Maximum Sessions	Dead Time	Secret Type
17.1.1.1	Active	1813	2	25	0	2400	300	radius-key
133.122.1.1	Active	1813	5	35	0	2400	300	radius-key
134.141.1.1	Active	1813	2	25	0	2400	300	radius-key
172.28.30.174	Active	1813	7	75	0	2400	300	radius-key
172.28.30.175	Active	1813	7	75	0	2400	300	radius-key
172.28.30.176	Active	1813	4	55	0	2400	300	radius-key
172.128.30.176	Active	1813	3	3	0	2400	300	none-set
172.128.130.174	Active	1813	7	75	0	2400	300	radius-key

RADIUS Accounting Servers

Profile: user1

```
show services l2tp radius statistics
user@host> show services l2tp radius statistics
RADIUS Authentication Statistics
```

```
Authentication statistics:
Server 17.1.1.1, UDP port: 1812
Access requests      : 40
Rollover requests    : 5
Retransmissions      : 2
Access accepts       : 39
Access rejects       : 1
Access challenges     : 3
Malformed responses  : 0
Bad authenticators    : 0
Requests pending     : 1
Request timeouts     : 0
Unknown responses    : 0
Packets dropped       : 0
```

RADIUS Accounting Statistics

Accounting statistics:

Server 172.128.130.174, UDP port: 1813

Total requests	: 9
Start requests	: 6
Interim requests	: 1
Stop requests	: 2
Rollover requests	: 0
Retransmissions	: 1
Total response	: 9
Start responses	: 6
Interim responses	: 1
Stop responses	: 2
Malformed responses	: 0
Bad authenticators	: 0
Requests pending	: 1
Request timeouts	: 0
Unknown responses	: 0
Packets dropped	: 0

show services l2tp session

Syntax show services l2tp session
 <brief | detail | extensive | statistics>
 <interface *sp-fpc/pic/port*>
 <local-gateway *gateway-address*>
 <local-gateway-name *gateway-name*>
 <local-session-id *session-id*>
 <local-tunnel-id *tunnel-id*>
 <peer-gateway *gateway-address*>
 <peer-gateway-name *gateway-name*>
 <tunnel-group *group-name*>
 <user *username*>

Release Information Command introduced before Junos OS Release 7.4.
 Support for MX Series routers added in Junos OS Release 10.4.

Description (M10i and M7i routers: LNS only. MX Series routers: LAC only.) Display a list of active L2TP sessions.

Options none—Display standard information about all active L2TP sessions.

brief | detail | extensive | statistics—(Optional) Display the specified level of output. Use the **statistics** option to display packet and byte counts for each session.

interface *sp-fpc/pic/port*—(Optional) Display L2TP session information for only the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.

local-gateway *gateway-address*—(Optional) Display L2TP session information for only the specified local gateway address.

local-gateway-name *gateway-name*—(Optional) Display L2TP session information for only the specified local gateway name.

local-session-id *session-id*—(Optional) Display L2TP session information for only the specified local session identifier.

local-tunnel-id *tunnel-id*—(Optional) Display L2TP session information for only the specified local tunnel identifier.

peer-gateway *gateway-address*—(Optional) Display L2TP session information for only the specified peer gateway address.

peer-gateway-name *gateway-name*—(Optional) Display L2TP session information for only the specified peer gateway name.

tunnel-group *group-name*—(Optional) Display L2TP session information for only the specified tunnel group. To display information about L2TP CPU and memory usage, you can include the tunnel group name in the **show services service-sets memory-usage *group-name*** and **show services service-sets cpu-usage *group-name*** commands. This option is not available for L2TP LAC on MX Series routers.

`user username`—(Optional) Display L2TP session information for only the specified username.

Required Privilege Level view

Related Documentation

- [clear services l2tp session on page 1637](#)

List of Sample Output

- [show services l2tp session \(LNS\) on page 1658](#)
- [show services l2tp session \(LAC\) on page 1658](#)
- [show services l2tp session detail \(LAC\) on page 1658](#)
- [show services l2tp session extensive \(LAC\) on page 1659](#)
- [show services l2tp session extensive \(LNS\) on page 1659](#)

Output Fields Table 304 on page 1656 lists the output fields for the **show services l2tp session** command. Output fields are listed in the approximate order in which they appear.

Table 304: show services l2tp session Output Fields

Field Name	Field Description	Level of Output
Interface	(LNS only) Name of an adaptive services interface.	All levels
Tunnel group	(LNS only) Name of a tunnel group.	All levels
Tunnel local ID	Identifier of the local endpoint of the tunnel, as assigned by the L2TP network server (LNS).	All levels
Session local ID	Identifier of the local endpoint of the L2TP session, as assigned by the LNS.	All levels
Session remote ID	Identifier of the remote endpoint of the L2TP session, as assigned by the L2TP access concentrator (LAC).	All levels
State	State of the L2TP session: <ul style="list-style-type: none"> • Established—The session is operating. This is the only state supported for the LAC. • closed—The session is being closed. • destroyed—The session is being destroyed. • clean-up—The session is being cleaned up. • lns-ic-accept-new—A new session is being accepted. • lns-ic-idle—The session has been created and is idle. • lns-ic-reject-new—The new session is being rejected. • lns-ic-wait-connect—The session is waiting for the peer's incoming call connected (ICCN) message. 	All levels
Bundle ID	(LNS only) Bundle identifier. Indicates the session is part of a multilink bundle. Sessions that have a blank Bundle field are not participating in the Multilink Protocol. Sessions in a multilink bundle might belong to different L2TP tunnels. For L2TP output organized by bundle ID, issue the show services l2tp multilink extensive command.	All levels

Table 304: show services l2tp session Output Fields (*continued*)

Field Name	Field Description	Level of Output
Mode	(LNS) Mode of the interface representing the session: shared or exclusive . (LAC) Mode of the interface representing the session: shared or dedicated . Only dedicated is currently supported for the LAC.	extensive
Local IP	IP address of local endpoint of the Point-to-Point Protocol (PPP) session.	extensive
Remote IP	IP address of remote endpoint of the PPP session.	extensive
Username	(LNS only) Name of the user logged in to the session.	All levels
Assigned IP address	(LNS only) IP address assigned to remote client.	extensive
Local name	For LNS, name of the LNS instance in which the session was created. For LAC, name of the LAC.	extensive
Remote name	For LNS, name of the LAC from which the session was created. For LAC, name of the LAC instance.	extensive
Local MRU	(LNS only) Maximum receive unit (MRU) setting of the local device, in bytes.	extensive
Remote MRU	(LNS only) MRU setting of the remote device, in bytes.	extensive
Tx speed	Transmit speed of the physical PPP link, in bps.	extensive
Rx speed	Receive speed of the physical PPP link, in bps.	extensive
Bearer type	Type of bearer enabled: <ul style="list-style-type: none"> • 0—Might indicate that the call was not received over a physical link (for example, when the LAC and PPP are located in the same subsystem). • 1—Digital access requested. • 2—Analog access requested. • 4—Asynchronous Transfer Mode (ATM) bearer support. 	extensive
Framing type	Type of framing enabled: <ul style="list-style-type: none"> • 1—Synchronous framing • 2—Asynchronous framing 	extensive
LCP renegotiation	(LNS only) Whether Link Control Protocol (LCP) renegotiation is configured: On or Off .	extensive
Authentication	Type of authentication algorithm used: Challenge Handshake Authentication Protocol (CHAP) or Password Authentication Protocol (PAP).	extensive
Interface ID	(LNS only) Identifier used to look up the logical interface for this session.	extensive
Interface unit	Logical interface for this session.	All levels

Table 304: show services l2tp session Output Fields (*continued*)

Field Name	Field Description	Level of Output
Call serial number	Unique serial number assigned to the call.	extensive
Policer bandwidth	Maximum policer bandwidth configured for this session.	extensive
Policer burst size	Maximum policer burst size configured for this session.	extensive
Firewall filter	Configured firewall filter name.	extensive
Session encapsulation overhead	Overhead allowance configured for this session, in bytes.	extensive
Session cell overhead	Cell overhead activation (On or Off).	extensive
Create time	Date and time when the call was created.	extensive
Up time	Length of time elapsed since the call became active, in hours, minutes, and seconds.	extensive
Idle time	Length of time elapsed since the call became idle, in hours, minutes, and seconds.	extensive
Statistics since	Date and time when collection of the following statistics began: <ul style="list-style-type: none"> Control Tx—Amount of control information transmitted, in packets and bytes. Control Rx—Amount of control information received, in packets and bytes. Data Tx—Amount of data transmitted, in packets and bytes. Data Rx—Amount of data received, in packets and bytes. Errors Tx—Number of errors transmitted, in packets. Errors Rx—Number of errors received, in packets. 	extensive

Sample Output

```

show services l2tp session (LNS) user@host> show services l2tp session
Interface: sp-1/2/0, Tunnel group: group1, Tunnel local ID: 8802
Local Remote Interface State Bundle Username
ID ID unit
37966 5 2 Established

show services l2tp session (LAC) user@host> show services l2tp session
Tunnel local ID: 31889
Local Remote State Interface Interface
ID ID unit unit Name
31694 1 Established 311 pp0

show services l2tp session detail (LAC) user@host> show services l2tp session detail
Tunnel local ID: 31889
Session local ID: 31694, Session remote ID: 1, Interface unit: 311

```

```

State: Established, Interface: pp0, Mode: Dedicated
Local IP: 10.1.1.2:1701, Remote IP: 10.1.1.1:1701
Local name: ce-lac, Remote name: ce-lns

```

**show services l2tp
session extensive
(LAC)**

```

user@host> show services l2tp session extensive
Tunnel local ID: 31889
  Session local ID: 31694, Session remote ID:      1
    Interface unit: 311
    State: Established, Mode: Dedicated
    Local IP: 10.10.1.2:1701, Remote IP: 10.10.1.1:1701
    Local name: ce-lac, Remote name: ce-lns
    Tx speed: 0, Rx speed: 0
    Bearer type: 1, Framing type: 1
    LCP renegotiation: N/A, Authentication: None, Interface ID: N/A
    Interface unit: 311, Call serial number: 0
    Policer bandwidth: 0, Policer burst size: 0
    Policer exclude bandwidth: 0, Firewall filter: 0
    Session encapsulation overhead: 0, Session cell overhead: 0
    Create time: Tue Aug 24 14:38:23 2010, Up time: 01:06:25
    Idle time: N/A

```

**show services l2tp
session extensive
(LNS)**

```

user@host> show services l2tp session extensive
Interface: sp-1/2/0, Tunnel group: group1, Tunnel local ID: 62746
  Session local ID: 56793, Session remote ID: 53304
    State: Established, Bundle ID: 5, Mode: shared
    Local IP: 10.128.1.1:1701, Remote IP: 10.128.1.2:1701
    Username: usr1@juniper_1.net, Assigned IP address: 10.50.2.1/32
    Local MRU: 4000, Remote MRU: 1500, Tx speed: 64000, Rx speed: 64000
    Bearer type: 2, Framing type: 1
    LCP renegotiation: Off, Authentication: CHAP, Interface ID: unit_20
    Interface unit: 20, Call serial number: 4137941434
    Policer bandwidth: 64000, Policer burst size: 51200
    Firewall filter: f1
    Session encapsulation overhead: 16, Session cell overhead: On
    Create time: Tue Mar 23 14:13:15 2004, Up time: 01:16:41
    Idle time: 00:00:00

```

	Packets	Bytes
Control Tx	4	88
Control Rx	2	28
Data Tx	0	0
Data Rx	461	29.0k
Errors Tx	0	
Errors Rx	0	

```

Interface: sp-1/2/0, Tunnel group: group_company_dns, Tunnel local ID: 37266
  Session local ID: 39962, Session remote ID: 53303
    State: Established, Bundle ID: 5, Mode: shared
    Local IP: 10.128.11.1:1701, Remote IP: 10.128.11.2:1701
    Username: usr1@company.com, Assigned IP address: 10.46.2.3/24
    Local name: router-1, Remote name: router-2
    Local MRU: 4470, Remote MRU: 4470, Tx speed: 155000000, Rx speed: 155000000
    Bearer type: 2, Framing type: 1
    LCP renegotiation: Off, Authentication: CHAP, Interface ID: unit_31
    Interface unit: 31, Call serial number: 4137941433
    Policer bandwidth: 64000, Policer burst size: 51200
    Firewall filter: f1
    Create time: Tue Mar 23 14:13:17 2004, Up time: 01:16:39
    Idle time: 01:16:36
    Statistics since: Tue Mar 23 14:13:15 2004
      Packets      Bytes

```

Control Tx	6	196
Control Rx	4	150
Data Tx	0	0
Data Rx	1	80
Errors Tx	0	
Errors Rx	0	

show services l2tp summary

Syntax	show services l2tp summary <interface sp-fpc/pic/port>
Release Information	Command introduced before Junos OS Release 7.4. Support for MX Series routers added in Junos OS Release 10.4.
Description	(M10i and M7i routers: LNS only. MX Series routers: LAC only.) Display Layer 2 Tunneling Protocol (L2TP) summary information.
Options	none—Display complete L2TP summary information. For LNS on M Series routers, display L2TP summary information for all adaptive services interfaces. interface sp-fpc/pic/port—(Optional) Display L2TP summary information for only the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.
Required Privilege Level	view
List of Sample Output	show services l2tp summary (LAC) on page 1662 show services l2tp summary (LNS) on page 1662
Output Fields	Table 305 on page 1661 lists the output fields for the show services l2tp summary command. Output fields are listed in the approximate order in which they appear.

Table 305: show services l2tp summary Output Fields

Field Name	Field Description
Failover within a preference level	(LAC only) State of this tunnel selection method on the LAC. When enabled, tunnel selection fails over within a preference level. When disabled, tunnel selection drops to the next lower preference level.
Weighted load balancing	(LAC only) State of this tunnel selection method on the LAC. When enabled, the maximum session limit of a tunnel determines its weight within a preference level. Tunnel selection proceeds from greatest to least weight. When disabled, selection defaults to a round robin method.
Tunnel authentication challenge	(LAC only) State of tunnel authentication, indicating whether the LAC and LNS exchange an authentication challenge and response during the establishment of the tunnel. The state is Enabled when a secret is configured in the tunnel profile or on the RADIUS server in the Tunnel-Password attribute [69]. The state is Disabled when the secret is not present.
Calling number avp	(LAC only) When the state is Enabled , the LAC includes the value of the Calling Number AVP 22 in ICRQ packets sent to the LNS. When the state is Disabled , the attribute is not sent to the LNS.

Table 305: show services l2tp summary Output Fields (*continued*)

Field Name	Field Description
Failover Protocol	(LAC only) When the state is enabled, the LAC operates in the default <i>failover-protocol-fall-back-to-silent-failover</i> manner. When the state is disabled, the disable-failover-protocol statement has been issued and the LAC operates only in silent failover mode.
Destinations	(LAC only) Number of L2TP destinations for the LAC.
Tunnels	Number of L2TP tunnels established on the router.
Sessions	Number of L2TP sessions established on the router.
Control	Count of L2TP control packets and bytes sent and received.
Data	Count of L2TP data packets and bytes sent and received.
Errors	Count of L2TP error packets and bytes sent and received.

Sample Output

```

show services l2tp summary (LAC) user@host> show services l2tp summary
Failover within a preference level is Disabled
Weighted load balancing is Enabled
Tunnel authentication challenge is Enabled
Calling number avp is Enabled
Failover Protocol is Disabled
Destinations: 1 Tunnels: 1, Sessions: 1
  Tx packets  Rx packets  Memory (bytes)
Control      260          144      11513856
Data         7.5k        16.9k        8.3k
Errors         0           0
show services l2tp summary (LNS) user@host> show services l2tp summary
Tunnels: 2, Sessions: 2, Errors: 0
  Tx packets  Rx packets  Memory (bytes)
Control      6k          9k        688k
Data        70k         70k       3054

```

show services l2tp tunnel

Syntax	<pre>show services l2tp tunnel <brief detail extensive statistics> <interface sp-fpc/pic/port> <local-gateway gateway-address> <local-gateway-name gateway-name> <local-tunnel-id tunnel-id> <peer-gateway gateway-address> <peer-gateway-name gateway-name> <tunnel-group group-name></pre>
Release Information	<p>Command introduced before Junos OS Release 7.4.</p> <p>Support for MX Series routers added in Junos OS Release 10.4.</p>
Description	(M10i and M7i routers: LNS only. MX Series routers: LAC only.) Display a list of active Layer 2 Tunneling Protocol (L2TP) tunnels.
Options	<p>none—Display standard information about all active L2TP tunnels.</p> <p>brief detail extensive statistics—(Default) Display the specified level of output. Use the statistics option to display L2TP tunnel statistics.</p> <p>interface sp-fpc/pic/port—(Optional) Display L2TP tunnel information for only the specified adaptive services interface. This option is not available for L2TP LAC on MX Series routers.</p> <p>local-gateway gateway-address—(Optional) Display L2TP tunnel information for only the specified local gateway address.</p> <p>local-gateway-name gateway-name—(Optional) Display L2TP tunnel information for only the specified local gateway name.</p> <p>local-tunnel-id tunnel-id—(Optional) Display L2TP tunnel information for only the specified local tunnel identifier.</p> <p>peer-gateway gateway-address—(Optional) Display L2TP tunnel information for only the specified peer gateway address.</p> <p>peer-gateway-name gateway-name—(Optional) Display L2TP tunnel information for only the specified peer gateway name.</p> <p>tunnel-group group-name—(Optional) Display L2TP tunnel information for only the specified tunnel group. This option is not available for L2TP LAC on MX Series routers.</p>
Required Privilege Level	view
List of Sample Output	<pre>show services l2tp tunnel (LAC) on page 1665 show services l2tp tunnel detail (LAC) on page 1665 show services l2tp tunnel extensive (LAC) on page 1665 show services l2tp tunnel extensive (LNS) on page 1666</pre>

Output Fields Table 306 on page 1664 lists the output fields for the **show services l2tp tunnel** command. Output fields are listed in the approximate order in which they appear.

Table 306: show services l2tp tunnel Output Fields

Field Name	Field Description
Interface	(LNS only) Name of an adaptive services interface.
Tunnel group	(LNS only) Name of a tunnel group.
Local ID	On the LNS, number assigned by the LNS that identifies the local endpoint of the tunnel relative to the LNS: the LNS. On the LAC, number assigned by the LAC that identifies the local endpoint of the tunnel relative to the LAC: the LAC.
Remote ID	On the LNS, number assigned by the LAC that identifies the remote endpoint of the tunnel relative to the LNS: the LAC. On the LAC, number assigned by the LNS that identifies the remote endpoint of the tunnel relative to the LAC: the LNS.
Remote IP	IP address of the peer endpoint of the tunnel.
Sessions	Number of L2TP sessions established through the tunnel.
State	State of the L2TP tunnel: <ul style="list-style-type: none"> • cc_responder_accept_new—The tunnel has received and accepted the start control connection request (SCCRQ). • cc_responder_reject_new—The tunnel has received and rejected the SCCRQ. • cc_responder_idle—The tunnel has just been created. • cc_responder_wait_ctl_conn—The tunnel has sent the start control connection response (SCCRP) and is waiting for the start control connection connected (SCCCN) message. • clean-up—The tunnel is being cleaned up. • closed—The tunnel is being closed. • destroyed—The tunnel is being destroyed. • Established—The tunnel is operating. This is the only state supported for the LAC. • Terminate—The tunnel is terminating. • Unknown—The tunnel is not connected to the router.
Tunnel Name	(LAC only) Name of the created tunnel. This value includes the destination name followed by the value of the RADIUS Tunnel-Assignment-ID VSA [82].
Local IP	IP address of the local endpoint of the tunnel.
Local name	Name used for local tunnel endpoint during tunnel negotiation.
Remote name	Name used for remote tunnel endpoint during tunnel negotiation.

Table 306: show services l2tp tunnel Output Fields (*continued*)

Field Name	Field Description
Effective Peer Resync Mechanism	(LAC only) Peer resynchronization mechanism (PRM) in effect for the tunnel: <ul style="list-style-type: none"> • Failover protocol • Silent failover—Recovery takes place in the failed endpoint only using the proprietary silent failover protocol.
Max sessions	Maximum number of sessions that can be established on this tunnel.
Window size	Number of control messages that can be sent without receipt of an acknowledgment.
Hello interval	Interval between the transmission of hello messages, in seconds.
Create time	Date and time when the tunnel was created. While the LNS and LAC are connected, this value should correspond to the router's uptime. If connection to the LAC is severed, the State changes to Unknown and the Create time value resets.
Up time	Amount of time elapsed since the tunnel became active, in hours, minutes, and seconds.
Idle time	Amount of time elapsed since the tunnel became idle, in hours, minutes, and seconds.
Statistics since	Date and time when collection of the following statistics began: <ul style="list-style-type: none"> • Control Tx—Amount of control information transmitted, in packets and bytes. • Control Rx—Amount of control information received, in packets and bytes. • Data Tx—Amount of data transmitted, in packets and bytes. • Data Rx—Amount of data received, in packets and bytes. • Errors Tx—Number of errors transmitted, in packets. • Errors Rx—Number of errors received, in packets.

Sample Output

```

show services l2tp tunnel (LAC) user@host> show services l2tp tunnel
                                Local ID Remote ID Remote IP Sessions State
                                17185      1 10.10.1.1:1701      1 Established

show services l2tp tunnel detail (LAC) user@host> show services l2tp tunnel detail
Tunnel local ID: 31889, Tunnel remote ID: 1
Remote IP: 100.1.1.1:1701
Sessions: 1, State: Established
Tunnel Name: 1/tunnel-to-LNS-1
Local IP: 100.1.1.2:1701
Local name: ce-lac, Remote name: ce-lns
Effective Peer Resync Mechanism: silent failover

show services l2tp tunnel extensive (LAC) user@host> show services l2tp tunnel extensive
Tunnel local ID: 17185, Tunnel remote ID: 1
Remote IP: 10.10.1.1:1701
Sessions: 1, State: Established
Tunnel Name: 2/tunnel-to-LNS-2
Local IP: 100.1.1.2:1701

```

```

Local name: ce-lac, Remote name: ce-lns
Effective Peer Resync Mechanism: failover protocol
Max sessions: 32000, Window size: 4, Hello interval: 60
Create time: Tue Nov 9 15:23:29 2010, Up time: 00:00:26
Idle time: 00:00:00

```

**show services l2tp
tunnel extensive (LNS)**

```

user@host> show services l2tp tunnel extensive
Interface: sp-1/2/0, Tunnel group: group1
Tunnel local ID: 62746, Tunnel remote ID: 16930
Remote IP: 10.128.1.2:1701
Sessions: 1, State: Established
Local IP: 10.128.1.1:1701
Local name: router-1, Remote name: router-2
Max sessions: 50, Window size: 32, Hello interval: 60
Create time: Tue Mar 23 14:13:15 2004, Up time: 01:14:58
Idle time: 00:00:07
Statistics since: Tue Mar 23 14:13:13 2004

```

	Packets	Bytes
Control Tx	80	1152
Control Rx	3	272
Data Tx	0	0
Data Rx	450	28.0k
Errors Tx	0	
Errors Rx	0	

```

Interface: sp-1/2/0, Tunnel group: group_company_dns
Tunnel local ID: 37266, Tunnel remote ID: 36217
Remote IP: 10.128.11.2:1701
Sessions: 1, State: Established
Local IP: 10.128.11.1:1701
Local name: router-1, Remote name: router-2
Max sessions: unlimited, Window size: 32, Hello interval: 60
Create time: Tue Mar 23 14:13:15 2004, Up time: 01:14:59
Idle time: 01:14:55
Statistics since: Tue Mar 23 14:13:13 2004

```

	Packets	Bytes
Control Tx	81	1164
Control Rx	3	273
Data Tx	0	0
Data Rx	1	80
Errors Tx	0	
Errors Rx	0	

show services l2tp user

Syntax	show services l2tp user <brief detail extensive statistics> <user <i>username</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	(M10i and M7i routers only) Display a list of active Layer 2 Tunneling Protocol (L2TP) users.
Options	<p>none—Display all active L2TP users.</p> <p>brief detail extensive statistics—(Optional) Display the specified level of output. Use the statistics option to display L2TP user statistics.</p> <p>user <i>username</i>—(Optional) Display L2TP user information for only the specified username.</p>
Required Privilege Level	view
List of Sample Output	show services l2tp user extensive on page 1669
Output Fields	Table 307 on page 1667 lists the output fields for the show services l2tp user command. Output fields are listed in the approximate order in which they appear.

Table 307: show services l2tp user Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Tunnel group	Name of a tunnel group.
Tunnel local ID	Local identifier of the tunnel, as assigned by the L2TP network server (LNS).
Session local ID	Local identifier of the session, as assigned by the L2TP network server (LNS).
Session remote ID	Remote identifier of the session, as assigned by the L2TP access concentrator (LAC).
State	<p>State of the L2TP session:</p> <ul style="list-style-type: none"> • Established—The session is operating. • closed—The session is being closed. • destroyed—The session is being destroyed. • clean-up—The session is being cleaned up. • Ins-ic-accept-new—A new session is being accepted. • Ins-ic-idle—The session has been created and is idle. • Ins-ic-reject-new—The new session is being rejected. • Ins-ic-wait-connect—The session is waiting for the peer's incoming call connected (ICCN) message.

Table 307: show services l2tp user Output Fields (*continued*)

Field Name	Field Description
Mode	Mode of the interface representing the session: shared or exclusive .
Local IP	IP address of the local endpoint of the tunnel.
Remote IP	IP address of the peer endpoint of the tunnel.
Username	Name of the user logged in to the session.
Assigned IP address	IP address assigned to remote client.
Local name	Name of the local device.
Remote name	Name of the remote device.
Local MRU	Maximum receive unit (MRU) setting of the local device, in bytes.
Remote MRU	MRU setting of the remote device, in bytes.
Tx speed	Transmit speed of the tunnel session, in bps.
Rx speed	Receive speed of the tunnel session, in bps.
Bearer type	Type of bearer enabled: <ul style="list-style-type: none"> • 0—Might indicate that the call was not received over a physical link (for example, when the LAC and PPP are located in the same subsystem) • 1—Digital access requested • 2—Analog access requested • 4—Asynchronous Transfer Mode (ATM) bearer support
Framing type	Type of framing enabled: <ul style="list-style-type: none"> • 1—Synchronous framing • 2—Asynchronous framing
LCP renegotiation	Whether Link Control Protocol (LCP) renegotiation is configured: On or Off .
Authentication	Type of authentication algorithm used: Challenge Handshake Authentication Protocol (CHAP) or Password Authentication Protocol (PAP).
Interface ID	Name of the logical unit.
Interface unit	Logical unit number.
Call serial number	Unique serial number assigned to the call.
Create time	Date and time when the call was created.

Table 307: show services l2tp user Output Fields (*continued*)

Field Name	Field Description
Up time	Amount of time elapsed since the call became active, in hours, minutes, and seconds.
Idle time	Amount of time elapsed since the call became idle, in hours, minutes, and seconds.
Statistics since	<p>Date and time when collection of the following statistics began:</p> <ul style="list-style-type: none"> • Control Tx—Amount of control information transmitted, in packets and bytes. • Control Rx—Amount of control information received, in packets and bytes. • Data Tx—Amount of data transmitted, in packets and bytes. • Data Rx—Amount of data received, in packets and bytes. • Errors Tx—Number of errors transmitted, in packets. • Errors Rx—Number of errors received, in packets.

Sample Output

```

show services l2tp user extensive user@host> show services l2tp user extensive
Interface: sp-1/2/0, Tunnel group: group1, Tunnel local ID: 62746
Session local ID: 56793, Session remote ID: 53304
State: Established, Mode: shared
Local IP: 10.128.1.1:1701, Remote IP: 10.128.1.2:1701
Username: usr1@juniper_1.net, Assigned IP address: 10.50.2.1/32
Local name: router-1, Remote name: router-2
Local MRU: 4000, Remote MRU: 1500, Tx speed: 64000, Rx speed: 64000
Bearer type: 2, Framing type: 1
LCP renegotiation: Off, Authentication: CHAP, Interface ID: unit_20
Interface unit: 20, Call serial number: 4137941434
Create time: Tue Mar 23 14:13:15 2004, Up time: 01:16:41
Idle time: 00:00:00
Statistics since: Tue Mar 23 14:13:13 2004
      Packets      Bytes
Control Tx         4        88
Control Rx         2        28
Data Tx            0         0
Data Rx          461      29.0k
Errors Tx          0
Errors Rx          0
Interface: sp-1/2/0, Tunnel group: group_company_dns, Tunnel local ID: 37266
Session local ID: 39962, Session remote ID: 53303
State: Established, Username: usr1@company_dns.com, Mode: shared
Local IP: 10.128.11.1:1701, Remote IP: 10.128.11.2:1701
Username: usr1@company_dns.com, Assigned IP address: 10.48.1.1/32
Local name: router-1, Remote name: router-2
Local MRU: 4470, Remote MRU: 4470, Tx speed: 155000000,
Rx speed: 155000000
Bearer type: 2, Framing type: 1
LCP renegotiation: Off, Authentication: CHAP, Interface ID: unit_31
Interface unit: 31, Call serial number: 4137941433
Create time: Tue Mar 23 14:13:17 2004, Up time: 01:16:39
Idle time: 01:16:36
Statistics since: Tue Mar 23 14:13:15 2004
      Packets      Bytes
Control Tx         6        196
Control Rx         4        150

```

Data Tx	0	0
Data Rx	1	80
Errors Tx	0	
Errors Rx	0	

Link Services Operational Mode Commands

Table 308 on page 1671 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot Link Services IQ (LSQ) PICs.

Table 308: Link Services Operational Mode Commands

Task	Command
Display information about Link Services IQ (LSQ) PIC CPU usage.	<code>show services link-services cpu-usage</code>



NOTE: LSQ functionality is supported on the adaptive services interface on the following routers:

- J Series routers—`ls-pim/0/slot`
- M Series and T Series routers—`lsq-fpc/pic/port`



NOTE: For information about how to configure link services, see the *Junos OS Services Interfaces Configuration Guide*.

show services link-services cpu-usage

Syntax	show services link-services cpu-usage <brief detail> <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 8.4.
Description	(M Series and T Series routers only) Display information about Link Services IQ (LSQ) CPU usage.
Options	none—Display standard information about CPU usage for all LSQ interfaces. brief detail—(Optional) Display the specified level of output. interface <i>interface-name</i> —(Optional) Display information about the specified LSQ interface.
Required Privilege Level	view
List of Sample Output	show services link-services cpu-usage brief (AS PIC) on page 1674 show services link-services cpu-usage brief (MultiServices PIC) on page 1674 show services link-services cpu-usage detail (AS PIC) on page 1674 show services link-services cpu-usage detail (MultiServices PIC) on page 1675
Output Fields	Table 309 on page 1672 lists the output fields for the show services link-services cpu-usage command. Output fields are listed in the approximate order in which they appear.

Table 309: show services link-services cpu-usage Output Fields

Field Name	Field Description	Level of Output
Role	CPU functional category.	brief
1 Second Average	Percentage of usage during 1-second duration.	All levels
5 Second Average	Percentage of usage during 5-second duration.	All levels
QoS	Quality of service (QoS) CPU, which takes care of queuing and scheduling of incoming IP packets on a per-bundle basis. It schedules packets with higher QoS values first.	All levels
Sequencer	Assigns sequence numbers to outgoing MLPPP fragments and interleaves link fragmentation and interleaving (LFI) traffic.	All levels
Load Balancer	Distributes load across different fragmenter CPUs.	All levels
Fragmenter	Main LSQ CPU; fragments IP packets into MLPPP fragments and also reassembles MLPPP fragments into IP packets.	All levels
Total	Sum of all CPU functions.	brief

Table 309: show services link-services cpu-usage Output Fields (*continued*)

Field Name	Field Description	Level of Output
Idle	Counts idle cycles when the CPU does not have any work.	detail
Timer	Takes care of periodic events driven by a timer, such as timeouts.	detail
System	System housekeeping thread.	detail
Input (QoS)	Acquires and queues incoming IP frames from hardware interfaces.	detail
Output (QoS)	Sends scheduled frames to the next processing CPU.	detail
Output Frags (QoS)	Sends outstanding frames to the fragmenter CPU.	detail
Bypass (QoS)	Sends outstanding frames for LFI.	detail
Free frame (QoS)	Frees dropped frames.	detail
CPUnumber	Identifier number of specific CPU.	detail
Drop (Fragmenter)	Drops frames that have been marked by the QoS CPU.	detail
Frag (Fragmenter)	Fragments IP frames into MLPPP fragments.	detail
Reass (Fragmenter)	Reassembles MLPPP fragments into IP frames.	detail
Freeback (Fragmenter)	Handles freeback of credits from other CPUs (MultiServices PICs only).	detail
Input LFI (Sequencer)	Receives LFI traffic from QoS CPU and transmits it with strict priority over MLPPP.	detail
Input Frag (Sequencer)	Receives MLPPP fragments from fragmenter CPUs, assigns sequence numbers, and appends MLPPP headers.	detail
Output Frag (Sequencer)	Load-balances and transmits fragments across links.	detail
Retry (Sequencer)	Retries transmission if hardware was busy in the previous attempt.	detail
Input Alloc (Load Balancer)	Acquires frames from hardware interfaces and validates them.	detail
Input (Load Balancer)	Performs error and sanity checks and check frames for PortMapping.	detail
Output (Load Balancer)	Sends frame to next processing CPU.	detail

Table 309: show services link-services cpu-usage Output Fields (*continued*)

Field Name	Field Description	Level of Output
Freeback (Load Balancer)	Handles freeback of credits from other CPUs.	detail

Sample Output

```

show services user@host> show services link-services cpu-usage interface lsq-0/0/0 brief
link-services
cpu-usage brief (AS PIC)
  Role           1 Second Average    5 Second Average
  QoS              1.0%                1.0%
  Sequencer        0.1%                0.1%
  Fragmenter       0.1%                0.1%
  Total            0.1%                0.1%

```

```

show services user@host> show services link-services cpu-usage interface lsq-0/0/0 brief
link-services
cpu-usage brief (MultiServices PIC)
  Role           1 Second Average    5 Second Average
  QoS              0.1%                0.1%
  Fragmenter       0.1%                0.1%
  Load Balancer   0.0%                0.0%
  Total            0.1%                0.1%

```

```

show services user@host> show services link-services cpu-usage interface lsq-0/0/0 detail
link-services
cpu-usage detail (AS PIC)
  QoS              Idle   Timer  System  Input  Output  Output  Bypass  Free
                   frame
  CPU0             99.1%  0.9%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU1             99.8%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  1 sec ave        99.5%  0.5%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
  5 sec ave        99.5%  0.5%   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%

  Fragmenter       Idle   Timer  System  Drop   Frag   Reass   Free
                   back
  CPU0             96.6%  0.1%   0.0%   0.0%   0.0%   3.3%   0.0%
  CPU1             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU2             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU3             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU4             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU5             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU6             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU7             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  CPU8             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%   0.0%
  1 sec ave        99.5%  0.1%   0.0%   0.0%   0.0%   0.4%   0.0%
  5 sec ave        99.5%  0.1%   0.0%   0.0%   0.0%   0.4%   0.0%

  Sequencer        Idle   System  Input  Input  Output  Retry
                   LFI   Frag   Frag
  CPU0             99.9%  0.1%   0.0%   0.0%   0.0%   0.0%
  CPU1             100.0% 0.0%   0.0%   0.0%   0.0%   0.0%
  1 sec ave        99.9%  0.1%   0.0%   0.0%   0.0%   0.0%
  5 sec ave        99.9%  0.1%   0.0%   0.0%   0.0%   0.0%

```

```

show services user@host> show services link-services cpu-usage interface lsq-0/0/0 detail
link-services QoS Idle Timer System Input Output Output Bypass Free
cpu-usage detail Frags frame
(MultiServices PIC)
CPU0 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU1 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU2 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU3 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU4 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0%
1 sec ave 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
5 sec ave 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%

Fragmenter Idle Timer System Drop Frag Reass Free
back
CPU0 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU1 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU2 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU3 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU4 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU5 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU6 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU7 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU8 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU9 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU10 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU11 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU12 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU13 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU14 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU15 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU16 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU17 99.9% 0.1% 0.0% 0.0% 0.0% 0.0% 0.0%
1 sec ave 99.9% 0.1% 0.0% 0.0% 0.0% 0.0%
5 sec ave 99.9% 0.1% 0.0% 0.0% 0.0% 0.0%

Load-Balancer Idle System Input Input Output Free
Alloc back
CPU0 100.0% 0.0% 0.0% 0.0% 0.0% 0.0%
CPU1 100.0% 0.0% 0.0% 0.0% 0.0% 0.0%
1 sec ave 100.0% 0.0% 0.0% 0.0% 0.0%
5 sec ave 100.0% 0.0% 0.0% 0.0% 0.0%

```


Mobile IP Operational Mode Commands

Table 310 on page 1677 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot Mobile IP services.

Table 310: Mobile IP Operational Mode Commands

Task	Command
Clear information about Mobile IP bindings.	clear mobile-ip binding
Display information about Mobile IP home agent bindings	show mobile-ip home-agent bindings
Display general information about Mobile IP home agent.	show mobile-ip home-agent overview
Display information about traffic specific to Mobile IP home agents.	show mobile-ip home-agent traffic
Display information about Mobile IP home agent virtual networks.	show mobile-ip home-agent virtual-network
Display information about the WiMAX Forum Network Architecture release.	show mobile-ip wimax release



NOTE: For information about how to configure Mobile IP services, see the *Junos OS Subscriber Access Configuration Guide*.

clear mobile-ip binding

Syntax	clear mobile-ip binding (all ip-address <i>ip-address</i> nai <i>nai-string</i>) <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.3.
Description	Clear the Mobile IP binding.
Options	<p>all—Clear all Mobile IP bindings.</p> <p>ip-address <i>ip-address</i>—Clear the Mobile IP bindings for the specified IP home address (HoA).</p> <p>nai <i>nai-string</i>—Clear the Mobile IP bindings for the specified network access identifier.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Clear the Mobile IP bindings for the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Clear the Mobile IP bindings for the specified routing instance.</p>
Required Privilege Level	clear
List of Sample Output	clear mobile-ip binding on page 1678
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear mobile-ip binding user@host> clear mobile-ip binding all

show mobile-ip home-agent bindings

Syntax	show mobile-ip home-agent bindings <ip-address <i>ip-address</i> nai <i>nai-string</i> summary> <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display information about Mobile IP home agent bindings.
Options	<p>ip-address <i>ip-address</i>—(Optional) Display information for the specified Mobile IP home address.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Display information for the specified logical system.</p> <p>nai <i>nai-string</i>—(Optional) Display information for the specified Mobile IP network access identifier.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Display information for the specified routing instance.</p> <p>summary—(Optional) Display only summary (total bindings) information.</p>
Required Privilege Level	view
List of Sample Output	<p>show mobile-ip home-agent bindings on page 1680</p> <p>show mobile-ip home-agent bindings ip-address on page 1680</p> <p>show mobile-ip home-agent bindings nai on page 1680</p> <p>show mobile-ip home-agent bindings summary on page 1681</p>
Output Fields	Table 311 on page 1679 lists the output fields for the show mobile-ip home-agent bindings command. Output fields are listed in the approximate order in which they appear.

Table 311: show mobile-ip home-agent bindings Output Fields

Field Name	Field Description
Home Address	Home address of the mobile node.
NAI	Network access identifier of the mobile node.
Home agent	Home agent address of the mobile node.
Care-of-address	Care of address used by the mobile node.
Lifetime Granted	Lifetime granted for the mobile node.
Lifetime Remaining	Remaining lifetime for the mobile node.

Table 311: show mobile-ip home-agent bindings Output Fields (*continued*)

Field Name	Field Description
Tunnel Type	Type of tunnel requested by the mobile node.
Tunnel ID	Tunnel ID the mobile node is using.
Tunnel Source	Tunnel source address the mobile node is using.
Tunnel Destination	Tunnel destination address the mobile node is using.
Identification	Identification value received from the mobile node.
Revocation Support	Whether registration revocation is supported for this binding.
Notify MN	Whether mobile node notification has been negotiated.
Total Bindings	Total number of Mobile IP home agent bindings.

Sample Output

```

show mobile-ip user@host> show mobile-ip home-agent bindings
home-agent bindings
Home address  NAI          Home agent  Care-of-address
10.1.1.3      abcde@def.com  10.1.1.1   50.50.50.1
30.1.1.3      -              55.55.55.1 50.50.50.1
20.1.1.3      def@def.com    20.1.1.1   60.50.50.1

```

```

show mobile-ip user@host> show mobile-ip home-agent bindings ip-address 10.1.1.3
home-agent bindings
ip-address
Home address      : 10.1.1.3
NAI               : abcde@def.com
Home agent        : 10.1.1.1
Care-of-address   : 50.50.50.1
Lifetime Granted  : 180
Lifetime Remaining : 20
Tunnel Type       : IP-IP
Tunnel ID         : 10
Tunnel Source     : 10.1.1.1
Tunnel Destination : 50.50.50.1
Identification    : ABCD1234.4321ABCD
Revocation Support : Enabled
Notify MN of Revocation : Enabled

```

```

show mobile-ip user@host> show mobile-ip home-agent bindings nai abcde@def.com
home-agent bindings
nai
Home address      : 10.1.1.3
NAI               : abcde@def.com
Home agent        : 10.1.1.1
Care-of-address   : 50.50.50.1
Lifetime Granted  : 180
Lifetime Remaining : 20
Tunnel Type       : IP-IP
Tunnel ID         : 10
Tunnel Source     : 10.1.1.1
Tunnel Destination : 50.50.50.1
Identification    : ABCD1234.4321ABCD

```



```
Revocation Support : Enabled
Notify MN           : Enabled
```

```
show mobile-ip      user@host> show mobile-ip home-agent bindings summary
home-agent bindings Total bindings : 3
summary
```

show mobile-ip home-agent overview

Syntax	show mobile-ip home-agent overview <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display overview information for Mobile IP home agent.
Options	logical-system <i>logical-system-name</i> —(Optional) Display information for the specified logical system. routing-instance <i>routing-instance-name</i> —(Optional) Display information for the specified routing instance.
Required Privilege Level	view
List of Sample Output	show mobile-ip home-agent overview on page 1682
Output Fields	Table 312 on page 1682 lists the output fields for the show mobile-ip home-agent overview command. Output fields are listed in the approximate order in which they appear.

Table 312: show mobile-ip home-agent overview Output Fields

Field Name	Field Description
Status	Total number of registration requests received.
Service Enabled on	Total number of registration requests forwarded.
Home Agents	Total number of registration requests denied.
Authentication	Total number of registration replies sent.

Sample Output

```

show mobile-ip user@host> show mobile-ip home-agent overview
home-agent overview
Status          : Active
Service Enabled on : ge-0/0/3.0, ge-0/0/2.0
Home agents     : 10.1.1.1, 20.1.1.1, 55.55.55.1
Authentication  : AAA

```

show mobile-ip home-agent traffic

Syntax	show mobile-ip home-agent traffic <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display information about Mobile IP home agent protocol statistics.
Options	<p>logical-system <i>logical-system-name</i>—(Optional) Display information for the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Display information for the specified routing instance.</p>
Required Privilege Level	view
List of Sample Output	show mobile-ip home-agent traffic on page 1684
Output Fields	Table 313 on page 1683 lists the output fields for the show mobile-ip home-agent traffic command. Output fields are listed in the approximate order in which they appear.

Table 313: show mobile-ip home-agent traffic Output Fields

Field Name	Field Description
Registration request received	Total number of registration requests received.
Registration request forwarded	Total number of registration requests forwarded.
Registration request denied	Total number of registration requests denied.
Registration replies sent	Total number of registration replies sent.
Registration Errors unspecified	Total number of registration requests denied by the home agent for reasons unspecified.
Registration Errors Administrative prohibited	Total number of registration requests denied by home agent as “administrative prohibited.”
Registration Errors Insufficient Resource	Total number of registration requests denied by the home agent for insufficient resources.
Registration Errors Bad request form	Total number of registration requests denied by the home agent due to a bad request form.

Table 313: show mobile-ip home-agent traffic Output Fields (*continued*)

Field Name	Field Description
Registration Errors Too many Bindings	Total number of registration requests denied by the home agent for having too many bindings.
Registration Errors Unknown HA	Total number of registration requests denied by the home agent for having an unknown home agent.
Registration Errors ID mismatch	Total number of registration requests denied by the home agent for having a mismatched ID.
Registration Errors Authentication failed MN	Total number of registration requests denied by the home agent because the mobile node failed authentication.
Registration Errors Authentication failed FA	Total number of registration requests denied by the home agent because the foreign agent failed authentication.

Sample Output

```

show mobile-ip home-agent traffic user@host> show mobile-ip home-agent traffic
Registration Request
  Received : 10
  Forwarded : 5
  Denied : 5
Registration Replies
  Sent : 5
Registration Errors
  Unspecified : 0
  Administrative prohibited : 0
  Insufficient Resource : 0
  Bad request form : 0
  Too many Bindings : 0
  Unknown HA : 0
  ID mismatch : 0
  Unavailable Reverse tunnel : 0
  Unavailable Encapsulation : 0
  Reverse Tunnel Mandatory : 0
  Authentication failed MN : 0
  Authentication failed FA : 0

```

show mobile-ip home-agent virtual-network

Syntax	show mobile-ip home-agent virtual-network <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.3.
Description	Display information about Mobile IP home agent virtual networks.
Options	<p>logical-system <i>logical-system-name</i>—(Optional) Display information for the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Display information for the specified routing instance.</p>
Required Privilege Level	view
List of Sample Output	show mobile-ip home-agent virtual-network on page 1686
Output Fields	Table 314 on page 1685 lists the output fields for the show mobile-ip home-agent virtual-network command. Output fields are listed in the approximate order in which they appear.

Table 314: show mobile-ip home-agent virtual-network Output Fields

Field Name	Field Description
Home agent address	Home agent address of the mobile node.
Registration Lifetime	Maximum registration lifetime that home agent allows.
Time Tolerance	Number of seconds the time stamp may differ.
Address Pool	Address pool configured.
Total MNs	Current number of mobile nodes that the home agent is serving.
Home address	Home address of the mobile node.
NAI	Network access identifier of the mobile node.
Care-of-address	Care of address used by the mobile node.
RegLifetime Granted	Lifetime granted for the mobile node.
RegLifetime Remaining	Remaining lifetime for the mobile node.

Sample Output

```
show mobile-ip user@host> show mobile-ip home-agent virtual-network
home-agent      Home Agent Address : 55.55.55.55
virtual-network Registration Lifetime : 1800
                Time Tolerance      : 120
                Address Pool        : 10.1.1.10 - 10.1.1.50
                Total MN's          : 2

                MN's :
                Home address       : 60.60.60.1
                NAI                : abcde@def.com
                Care-of-address    : 50.50.50.1
                Reglifetime granted : 120
                Reglifetime remaining: 100

                Home address       : 70.70.70.1
                NAI                : def@def.com
                Care-of-address    : 80.80.80.1
                Reglifetime granted : 120
                Reglifetime remaining: 100
```

show mobile-ip wimax release

Syntax	show mobile-ip wimax release <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in Junos OS Release 9.5.
Description	Display the WiMAX Forum Network Architecture release that is supported by the current Mobile IP implementation.
Options	logical-system <i>logical-system-name</i> —(Optional) Display information for the specified logical system. routing-instance <i>routing-instance-name</i> —(Optional) Display information for the specified routing instance.
Required Privilege Level	view
List of Sample Output	show mobile-ip wimax release on page 1687
Output Fields	Table 315 on page 1687 lists the output fields for the show mobile-ip wimax release command. Output fields are listed in the approximate order in which they appear.

Table 315: show mobile-ip wimax release Output Fields

Field Name	Field Description
Release	WiMAX Forum Network Architecture release number.
Version	WiMAX Forum Network Architecture version number.

Sample Output

```
show mobile-ip wimax release user@host> show mobile-ip wimax release
                             Release 1, Version 1.2
```


Network Address Translation Operational Mode Commands

Table 316 on page 1689 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot Network Address Translation (NAT) services.

Table 316: NAT Operational Mode Commands

Task	Command
Display information about NAT address and port mappings.	<code>show services nat mapping</code>
Display information about NAT pools.	<code>show services nat pool</code>



NOTE: NAT is supported on the adaptive services interface on the following routers:

- J Series routers—*sp-pim/0/slot*
- M Series and T Series routers—*sp-fpc/pic/port*

NAT is also supported on the redundant adaptive services interface (*rspnumber*) on M Series and T Series routers.



NOTE: For information about how to configure NAT services, see the *Junos OS Services Interfaces Configuration Guide*.

show services nat mapping

Syntax	<code>show services nat mapping</code> <code><brief detail summary></code> <code><pool-name></code>
Release Information	Command introduced in Junos OS Release 10.1. summary option introduced in Junos OS Release 11.1.
Description	Display information about Network Address Translation (NAT) address and port mappings.
Options	none—Display standard information about all NAT pools. brief detail summary—(Optional) Display the specified level of output. pool-name—(Optional) Display information about the specified NAT pool.
Required Privilege Level	view
List of Sample Output	<code>show services nat mapping brief</code> on page 1691 <code>show services nat mapping detail</code> on page 1691 <code>show services nat mapping pool-name</code> on page 1691 <code>show services nat mapping summary</code> on page 1691
Output Fields	Table 317 on page 1690 lists the output fields for the show services nat mapping command. Output fields are listed in the approximate order in which they appear.

Table 317: show services nat mapping Output Fields

Field Name	Field Description	Level of Output
Interface	Name of a service interface.	All levels
Service set	Name of a service set. Individual empty service sets are not displayed, but if none of the service sets has any flows, a flow table header is printed for each service set.	All levels
NAT pool	Name of the NAT pool.	All levels
Address Mapping	Mapping performed by NAT to conceal the network address.	All levels
No. of Port Mappings	Number of port mappings.	All levels
Port mapping	Port mapping performed by NAT.	detail
Flow Count	Number of flows.	detail
Total number of address mappings:	Total number of address mappings for all interfaces and service sets.	summary

Table 317: show services nat mapping Output Fields (*continued*)

Field Name	Field Description	Level of Output
Total number of endpoint independent port mappings:	Total number of port mappings for interfaces and services sets.	summary
Total number of endpoint independent filters:	Total number of independent filters that filter out only packets that are not destined to the internal address and port regardless of the external IP address and port source.	summary

Sample Output

```

show services nat mapping brief  user@host> show services nat mapping brief
                                Interface: sp-2/3/0, Service set: s1

                                NAT pool: p1
                                Address Mapping: 2.1.20.10 ---> 34.34.34.34
                                No. of port mappings: 1

show services nat mapping detail user@host> show services nat mapping detail
                                Interface: sp-2/3/0, Service set: s1

                                NAT pool: p1
                                Address Mapping: 2.1.20.10 ---> 34.34.34.34, No. of port mappings: 1
                                Port mapping: 49604 --> 1024, Flow Count: 2

show services nat mapping pool-name user@host> show services nat mapping p1
                                Interface: sp-2/3/0, Service set: s1

                                NAT pool: p1
                                Address Mapping: 2.1.20.10 ---> 34.34.34.34
                                No. of port mappings: 1

show services nat mapping summary user@host> show services nat mapping summary
                                Total number of address mappings:          500000
                                Total number of endpoint independent port mappings: 500000
                                Total number of endpoint independent filters:    0

```

show services nat pool

Syntax	show services nat pool <brief detail> <pool-name> pgcp <ports-per-session remotely-controlled>
Release Information	Command introduced before Junos OS Release 7.4. pgcp option added in Junos OS Release 8.5.
Description	Display information about Network Address Translation (NAT) pools.
Options	<p>none—Display standard information about all NAT pools.</p> <p>brief detail—(Optional) Display the specified level of output.</p> <p>pool-name—(Optional) Display information about the specified NAT pool.</p> <p>pgcp—(Optional) Display information about a NAT pool that is exclusive to the BGF.</p> <p>ports-per-session—(Optional) Display the number of ports allocated per session from the NAT pool.</p> <p>remotely-controlled—(Optional) Display if the NAT pool is explicitly specified by the gateway controller.</p>
Required Privilege Level	view
List of Sample Output	<p>show services nat pool brief on page 1693</p> <p>show services nat pool detail on page 1693</p>
Output Fields	Table 318 on page 1692 lists the output fields for the show services nat pool command. Output fields are listed in the approximate order in which they appear.

Table 318: show services nat pool Output Fields

Field Name	Field Description	Level of Output
Interface	Name of an adaptive services interface.	All levels
Service set	Name of a service set. Individual empty service sets are not displayed, but if none of the service sets has any flows, a flow table header is printed for each service set.	All levels
NAT pool	Name of the Network Address Translation pool.	All levels
Type or Translation type	Address translation type: basic-nat-pt , basic-nat44 , basic-nat66 , dnat-44 , dynamic-nat44 , napt44 , napt-66 , napt-pt , stateful-nat64 .	All levels
Address or Address range	IPv4 address range of the pool.	All levels

Table 318: show services nat pool Output Fields (*continued*)

Field Name	Field Description	Level of Output
Port or Port range	Port range of the pool. Applicable only for dynamic NAT pools. Not displayed for static NAT pools.	All levels
Ports used' or Ports in use	Number of ports allocated in this pool with this name. Applicable only for dynamic NAT pools. Not displayed for static NAT pools.	All levels
Out of port errors	Number of port allocation errors. Applicable only for dynamic NAT pools. Not displayed for static NAT pools.	detail
Max ports used	Maximum number of ports used. Applicable only for dynamic NAT pools. Not displayed for static NAT pools.	detail
Addresses in use	Number of addresses in use for dynamic source address NAT pools.	detail

Sample Output

```

show services nat pool brief  user@host> show services nat pool brief
                                Interface: ms-1/0/0, Service set: s1
                                NAT pool      Type      Address                                Port      Ports used
                                dest-pool     DNAT-44   10.10.10.2-10.10.10.2
                                napt-pool     NAPT-44   50.50.50.1-50.50.50.254          1024-63487  0
                                source-dynamic-pool DYNAMIC NAT44 40.40.40.1-40.40.40.254
                                source-static-pool BASIC NAT44 30.30.30.1-30.30.30.254

show services nat pool detail user@host> show services nat pool detail
                                Interface: ms-1/0/0, Service set: s1
                                NAT pool: dest-pool, Translation type: DNAT-44
                                Address range: 10.10.10.2-10.10.10.2
                                NAT pool: napt-pool, Translation type: NAPT-44
                                Address range: 50.50.50.1-50.50.50.254
                                Port range: 1024-63487, Ports in use: 0, Out of port errors: 0, Max ports
                                used: 0
                                NAT pool: source-dynamic-pool, Translation type: DYNAMIC NAT44
                                Address range: 40.40.40.1-40.40.40.254
                                Out of address errors: 0, Addresses in use: 0
                                NAT pool: source-static-pool, Translation type: BASIC NAT44
                                Address range: 30.30.30.1-30.30.30.254

```


PGCP Operational Mode Commands for the BGF Feature

Table 319 on page 1695 summarizes the Packet Gateway Control Protocol (PGCP) command-line interface (CLI) commands you can use to monitor and troubleshoot the PGCP service that is used for the border gateway function (BGF) feature. Commands are listed in alphabetical order.

Table 319: PGCP Services Operational Mode Commands

Task	Command
Clear gates on a virtual BGF.	clear services pgcp gates
Clear statistical information.	clear services pgcp statistics
Display information about the configuration for a virtual BGF.	show services pgcp active-configuration
Display in-depth information about a particular gate on a virtual BGF.	show services pgcp gate
Display summary information about all gates on a virtual BGF.	show services pgcp gates
Display information about H.248 root terminations.	show services pgcp root-termination
Display information about BGF statistics.	show services pgcp statistics
Display information about conversations.	show services pgcp conversations
Display information about flows.	show services pgcp flows
Display summary information about terminations.	show services pgcp terminations



NOTE:

PGCP services are supported on Adaptive Services (AS) PICS, Multiservices (*sp-fpc/pic/port*) PICS, and the Multiservices Dense Port Concentrator (MS-DPC) on the following routers:

- Juniper Networks M120 Multiservice Edge Router
- Juniper Networks M320 Multiservice Edge Router
- Juniper Networks T640 Core Router



NOTE: For information about how to use PGCP services to monitor the BGF feature, see the *Junos Multiplay Solutions Guide*.

clear services pgcp gates

Syntax	clear services pgcp gates gateway <i>gateway-name</i>
Release Information	Command introduced in Junos OS Release 8.5.
Description	<p>Clear all gates on a virtual border gateway function (BGF). Use this command only for debugging and testing purposes. The recommended way to clear the state of gates is to use the set services-state out-of-service-graceful statement at the [edit services pgcp gateway <gateway-name>] hierarchy.</p> <p>When you enter this command, the virtual BGF sends an H.248 FO/905 message to the gateway controller. The status of the virtual BGF then changes to In-Service (Disconnected). The virtual BGF then reregisters with the gateway controller by sending an RE/901 message, and the status of the virtual BGF changes to In-Service (Registered).</p>
Options	<p>gates—Clear gate information.</p> <p>gateway <i>gateway-name</i>—Clear statistics associated with this virtual BGF.</p>
Required Privilege Level	view
List of Sample Output	clear services pgcp gates on page 1697
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services pgcp  user@host> clear services pgcp gates
gates
```

clear services pgcp statistics

Syntax	clear services pgcp statistics gateway <i>gateway-name</i> <virtual-interface <i>interface-number</i>>
Release Information	Command introduced in Junos OS Release 9.3. gateway option added in Junos OS Release 9.5. virtual-interface option added in Junos OS Release 11.1.
Description	Clear statistics for a virtual border gateway function (BGF).
Options	<i>gateway-name</i> —Name of the virtual BGF for which you want to clear statistics. <i>interface-number</i> —Number of the virtual interface for which you want to clear statistics. When you specify a virtual interface, statistics are cleared for that virtual interface only.
Required Privilege Level	view
List of Sample Output	clear services pgcp statistics on page 1698
Output Fields	When you enter this command, you receive either command prompt (indicating success) or an error message.

Sample Output

clear services pgcp statistics	user@host> clear services pgcp statistics gateway <i>gateway-name</i>
---------------------------------------	---

show services pgcp active-configuration

Syntax	show services pgcp active-configuration gateway <i>gateway-name</i> <backup> <master>
Release Information	Command introduced in Junos OS Release 8.4. gateway option introduced in Junos OS Release 9.5. backup option introduced in Junos OS Release 9.6. master option introduced in Junos OS Release 9.6.
Description	Display information about the active Packet Gateway Control Protocol (PGCP) configuration, which includes information received from the adaptive services process and information negotiated with the gateway controller.
Options	gateway <i>gateway-name</i> —Display information about the active configuration associated with this virtual border gateway function (BGF). backup —(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant MultiServices PIC (rms) interface. master —(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, the active configuration on the Routing Engine is displayed. If the virtual BGF is running on a services PIC, the active configuration on the primary services PIC is displayed. If you do not specify the master or backup options, the master option is the default.
Required Privilege Level	view
List of Sample Output	show services pgcp active-configuration (controller: border signaling gateway) on page 1703 show services pgcp active-configuration (controller: external) on page 1705
Output Fields	Table 320 on page 1699 lists the output fields for the show services pgcp active-configuration command. Output fields are listed in the approximate order in which they appear.

Table 320: show services pgcp active-configuration Output Fields

Field Name	Field Description
BGF virtual interface configuration	Information about the virtual interface configuration. <ul style="list-style-type: none"> Virtual interface name—Name of the virtual interface. Routing Instance name—Name of the routing instance associated with the virtual interface. Status—Service status of the virtual interface: In-Service, In-Service (Graceful Shutdown), Out-of-Service, Out-of-Service (Physical Interface). Interface name—Name of the service interface for the virtual interface.

Table 320: show services pgcp active-configuration Output Fields (*continued*)

Field Name	Field Description
Virtual BGF configuration	<p>Information about the active virtual BGF configuration.</p> <ul style="list-style-type: none"> • Name—Name of the virtual BGF. • IP address—IP address of the virtual BGF. • Routing Instance—Name of the routing instance associated with the virtual BGF. • Port—Port of the virtual BGF. • Platform—Service interface for the BGF. • Status—Service state of the virtual BGF: <ul style="list-style-type: none"> • In-Service (Disconnected)—The virtual BGF is configured to be in service; however, it is disconnected from the gateway controller. • In-Service (Registering)—The virtual BGF is in the process of registering with the gateway controller. • In-Service (Registered)—The virtual BGF has completed registration with the gateway controller. • In-Service (Graceful Shutdown)—The virtual BGF is in draining mode because of a graceful shutdown. • In-Service (Shutdown)—The virtual BGF is shut down because of a forced shutdown. • Out-Of-Service—The virtual BGF is not connected to the gateway controller. • Active gateway controller—Gateway controller that is currently controlling this virtual BGF. NULL means that there is no active gateway controller. • Replication socket <ul style="list-style-type: none"> • Connected (Ready)—The replication is ready and a switchover can be processed. • Connected (Syncing)—The replication is synchronizing. Performing a switchover is not safe. • Connected (Error)—An error occurred in the previous switchover. • Disconnected—The backup Routing Engine is down. There is no route to the backup Routing Engine. • Synchronization state—The status of the synchronization between the internal state of the pgcpd process and the flow of media on a data PIC after a failover of the pgcpd process. <ul style="list-style-type: none"> • Idle—The pgcpd process and the data PIC media flow are in synch. • Initializing—The pgcpd process is reading the current status of the data PIC to determine required synchronization. • synchronizing—The pgcpd process is synchronizing it's internal state with the data PIC. <p>NOTE: BGF service is not affected when synchronizing. Gates can be created, modified, and deleted normally.</p> <ul style="list-style-type: none"> • Cleanup timeout [secs]—Time to wait before the virtual BGF removes gates following a disconnection from the gateway controller. • Maximum concurrent calls—Maximum number of concurrent calls allowed on the BGF. • Gate inactivity delay—Time to wait before packet inactivity detection begins on a gate for which there is no latching event. • Gate inactivity duration—Time during which the virtual BGF monitors gates for packet inactivity.

Table 320: show services pgcp active-configuration Output Fields (*continued*)

Field Name	Field Description
H248 timers configuration	<p>Information about the H.248 timers configuration.</p> <ul style="list-style-type: none"> • Max waiting delay (MWD)—Maximum time the virtual BGF waits before contacting a new gateway controller when the connection to the controlling gateway controller is lost. • Max retransmission delay (T-MAX)—Maximum delay time allowed a transaction resulting from retransmissions. • Initial average ack delay (I-AAD)—Average network propagation delay time. • Maximum net propogation delay (M-NPD)—Maximum network propagation delay time.
H248 options configuration	<p>Information about the H.248 options configuration.</p> <ul style="list-style-type: none"> • Wildcard response service-change—Whether or not the virtual BGF issues service change notifications as wildcard notifications. • Event history—Whether or not the virtual BGF has enabled its history of all event notifications to be accessed by the gateway controller.
H248 diffserv configuration	<p>Information about the H.248 DiffServ configuration.</p> <ul style="list-style-type: none"> • DSCP—DSCP value set in the DiffServ configuration. If there is no configured value, the default value is shown.
Notification Behavior	<p>Information about the regulation of media inactivity notifications sent to the gateway controller.</p> <ul style="list-style-type: none"> • Notification Regulation—Either the percentage of notification to be suppressed, expressed as a number from 0 through 100, or the value once, meaning that only the first of a series of media inactivity notifications is sent to the gateway controller.
Application data inactivity detection	<p>Information about the reporting of media inactivity events.</p> <ul style="list-style-type: none"> • IP flow stop detection—Default method for reporting media inactivity.
Event timestamp Notification	<p>Information about the availability of event timestamp information.</p> <ul style="list-style-type: none"> • Requested timestamp—Whether or not the virtual BGF has enabled timestamp information for events to be viewed by the gateway controller.
H248 segmentation	<p>Information about the H.248 segmentation configuration.</p> <ul style="list-style-type: none"> • MG segmentation timer—The time within which the gateway controller waits to receive outstanding message segments from the virtual BGF after it receives the SegmentationCompleteToken message. • MG maximum PDU size—The maximum size of the virtual BGF's incoming protocol data unit for the control association's transport protocol. The gateway controller should avoid building messages that exceed this size. • MGC segmentation timer—The time within which the virtual BGF waits to receive outstanding message segments from the gateway controller after it receives the SegmentationCompleteToken message. • MGC maximum PDU size—The maximum size of the gateway controller's incoming protocol data unit for the control association's transport protocol. The virtual BGF will not build messages that exceed this size. • minimum—Minimum value accepted from the gateway controller. • maximum—Maximum value accepted from the gateway controller. • default—Default value that is used when the gateway controller does not set a value.

Table 320: show services pgcp active-configuration Output Fields (*continued*)

Field Name	Field Description
H248 base root	<p>Information about the H.248 base root configuration.</p> <ul style="list-style-type: none"> • Normal MG execution time—The interval within which the gateway controller waits for a response to transactions from the virtual BGF (exclusive of network delay). • MG Provisional response timer—The time within which the gateway controller waits for a pending response from the virtual BGF if a transaction cannot be completed. • MG Originated pending limit—The number of transaction pending messages that the gateway controller can receive from the virtual BGF. • Normal MGC execution time—The interval within which the virtual BGF waits for a response to a transaction from the gateway controller (exclusive of network delay). • MGC Provisional response timer—The time within which the virtual BGF waits for a pending response from the gateway controller if a transaction cannot be completed. • MGC Originated pending limit—The number of transaction pending messages that the virtual BGF can receive from the gateway controller. • minimum—Minimum value accepted from the gateway controller. • maximum—Maximum value accepted from the gateway controller. • default—Default value that is used when the gateway controller does not set a value.
Inactivity Timer	<p>Information about inactivity timer configuration.</p> <ul style="list-style-type: none"> • Default—Whether the inactivity timer is on or off by default. • Maximum inactivity time default—Default value for the inactivity timer. This value is used if the gateway controller does not send an inactivity timer value. • minimum—Minimum value accepted from the gateway controller. • maximum—Maximum value accepted from the gateway controller. • default—Default value that is used when the gateway controller does not set a value.
Fast update filters	<p>Information about the fast update filter (FUF) configuration.</p> <ul style="list-style-type: none"> • Maximum terms—Maximum number of FUF terms that can be installed for the virtual BGF. • Maximum term percentage—Maximum percentage of gates with FUF filters relative to all gates currently installed for the virtual BGF.
Overload control configuration	<p>Information about the overload control configuration.</p> <ul style="list-style-type: none"> • Queue limit percentage—Maximum percentage of the work queue for H.248 transactions that can be used before overload messages are generated. • Reject new calls threshold—Maximum percentage of the work queue for H.248 transactions that can be used before all new, non-emergency calls are rejected. • Reject all transactions threshold—Maximum percentage of the work queue for H.248 transactions that can be used before all non-emergency transactions are rejected.
Gateway controller configuration	<p>Information about the gateway controller configuration.</p> <ul style="list-style-type: none"> • Controller name—Name of the gateway controller. • Controller IP address—For an external controller, the IP address of the gateway controller. When the controller is a BSG instance, this field contains internal. • Controller port—Listening port of the gateway controller to which the virtual BGF sends messages.

Table 320: show services pgcp active-configuration Output Fields (*continued*)

Field Name	Field Description
BGF rule configuration	<p>Information about the rule configuration.</p> <ul style="list-style-type: none"> • Rule name—Name of the rule set. • Virtual BGF—Name of the virtual BGF that processes the rule set.
BGF service set configuration	<p>Information about the service set configuration.</p> <ul style="list-style-type: none"> • Service set name—Name of the service set. • Service set id—Numeric identifier of the service set. • Rule name—Name of the rule set configured for the service set.
BGF MultiServices PIC status	<p>Information about the services PICs' status.</p> <ul style="list-style-type: none"> • Name—Name of the services interface. • Status—Status of the services interface: Connected.
Firewall	<p>Information about firewall filter status for the virtual BGF.</p> <ul style="list-style-type: none"> • Status—Status of the firewall associated with the virtual BGF: Connected or Unsupported Platform. • Number of terms—Number of match condition terms used in the virtual BGF. For each filter, a default term is installed to allow traffic to pass through (otherwise, all traffic is dropped because it is the default firewall action). For example, there are two terms listed when there are two filters. • Number of filters—Number of firewall filters used in the virtual BGF.

Sample Output

```

show services pgcp active-configuration (controller: border signaling gateway)
user@host> show services pgcp active-configuration gateway BGF1

BGF virtual interface configuration:
  Virtual Interface name: 10
    Routing Instance name: inet.0
    Status                  : In-Service
    Interface name          : sp-1/0/0
BGF virtual interface configuration:
  Virtual Interface name: 20
    Routing Instance name: inet.0
    Status                  : In-Service
    Interface name          : sp-1/0/0
Virtual BGF configuration:
  Name                      : BGF1
  IP address                 : 0.0.0.0
  Routing-instance           : inet.0
  Port                       : 2944
  Platform                   : sp-1/1/0
  Status                     : In-Service (Registering)
  Active gateway controller  : internal
  Replication socket         : Ready
  Synchronization state      : Disabled
  Cleanup timeout [secs]     : 0
  Maximum concurrent calls   : 8101
  Gate inactivity delay [secs] : 3600
  Gate inactivity duration (Q-MI ) [secs] : 3600

```

```

H248 timers configuration:
  Max waiting delay (MWD) [millisec]      : 2000
  Max retransmission delay (T-MAX) [millisec] : 20000
  Initial average ack delay (I-AAD) [millisec]: 1000
  Max net propagation delay (M-NPD) [millisec]: 5000

H248 options configuration:
  Wildcard response service-change      : NO
  Event history                          : NO

H248 diffserv configuration:
  dscp                                   : 0x00

Notification Behavior:
  Notification Regulation                : 0

Application data inactivity detection:
  IP flow stop detection                 : default - immediate

Event timestamp Notification
  Requested timestamp                   : requested

H248 segmentation
  :                                     minimum    maximum    default
MG segmentation timer [millisec]      : 500      30000     4000
MG maximum PDU size [bytes]           : 512      65507     1472
MGC segmentation timer [millisec]     : 500      30000     4000
MGC maximum PDU size [bytes]          : 512      65507     1472

H248 base root
  :                                     minimum    maximum    default
Normal MG execution time [millisec]   : 500      29000     500
MG Provisional response timer [millisec] : 500      30000     2000
MG Originated pending limit           : 1        512       4
Normal MGC execution time [millisec]   : 500      29000     500
MGC Provisional response timer [millisec]: 500      30000     4000
MGC Originated pending limit           : 1        512       4

Inactivity Timer:
  Detect                               : Off
  Maximum inactivity time [10 millisec]:
      minimum    maximum    default
      100        65535     12000

Fast update filters:
  Maximum terms                        : 2000

Overload control configuration:
  Queue limit percentage               : 70
  Reject new calls threshold           : 80
  Reject all commands threshold        : 90

Gateway controller configuration:
  Controller name                      : internal
  Controller IP address                 : 0.0.0.0
  Controller port                       : 2944

BGF rule configuration:
  Rule name                           : pgcp-rule
  Virtual BGF                          : BGF1

BGF service set configuration:
  Service set name                     : bgf-service-set
  Service set id                       : 1

```



```

Rule name          : pgcp-rule

BGF MultiServices PIC status:
Name       : sp-1/0/0
Status    : Connected

Firewall:
Status      : Unsupported platform
Number of terms : 0
Number of filters : 0

show services pgcp active-configuration (controller: external)
user@host> show services pgcp active-configuration gateway BGF1
BGF virtual interface configuration:
Virtual Interface name: 11
Routing Instance name: vrf_1
Status                : In-Service
Interface name        : sp-3/0/0.11

BGF virtual interface configuration:
Virtual Interface name: 10
Routing Instance name: vrf_0
Status                : In-Service
Interface name        : sp-3/0/0.10

Virtual BGF configuration:
Name                  : BGF1
IP address            : 1.1.24.1
Routing-instance      : vrf_1
Port                 : 2944
Platform              : rms1 [1]
Status                : In-Service (Registering)
Active gateway controller : PGC1
Replication socket     : Ready
Synchronization state  : Disabled
Cleanup timeout [secs] : 0
Maximum concurrent calls : 8101
Gate inactivity delay [secs] : 3600
Gate inactivity duration (Q-MI ) [secs] : 3600

H248 timers configuration:
Max waiting delay (MWD) [millisec] : 2000
Max retransmission delay (T-MAX) [millisec] : 20000
Initial average ack delay (I-AAD) [millisec]: 1000
Max net propagation delay (M-NPD) [millisec]: 5000

H248 options configuration:
Wildcard response service-change : NO
Event history                     : NO

H248 diffserv configuration:
dscp : 0x00

Notification Behavior:
Notification Regulation : 0

Application data inactivity detection:
IP flow stop detection : default - immediate

Event timestamp Notification
Requested timestamp : requested

```

```

H248 segmentation      :           minimum      maximum
    default
    MG segmentation timer [millisec] : 500      30000
    4000
    MG maximum PDU size [bytes]      : 512      65507
    1472
    MGC segmentation timer [millisec] : 500      30000
    4000
    MGC maximum PDU size [bytes]      : 512      65507
    1472

H248 base root          :           minimum      maximum
    default
    Normal MG execution time [millisec] : 500      29000
    500
    MG Provisional response timer [millisec] : 500      30000
    2000
    MG Originated pending limit          : 1      512
    4
    Normal MGC execution time [millisec] : 500      29000
    500
    MGC Provisional response timer [millisec]: 500      30000
    4000
    MGC Originated pending limit          : 1      512
    4

Inactivity Timer:
    Detect                  :      Off
    Maximum inactivity time [10 millisec]:
v           minimum      maximum      default
           100          65535      12000

Fast update filters:
    Maximum terms          : 2000

Overload control configuration:
    Queue limit percentage : 70
    Reject new calls threshold : 80
    Reject all commands threshold : 90

Gateway controller configuration:
    Controller name        : PGC1
    Controller IP address  : 10.50.240.101
    Controller port        : 35101

    Controller name        : PGC2
    Controller IP address  : 0.0.0.0
    Controller port        : 2944

BGF rule configuration:
    Rule name              : pgcp-rule1
    Virtual BGF            : BGF1

BGF service set configuration:
    Service set name       : pgcp-svc-set1
    Service set id         : 1
    Rule name              : pgcp-rule1

BGF MultiServices PIC status:
    Name                   : sp-3/0/0
    Status                  : Connected

```

```
Firewall:
  Status      : Unsupported platform
  Number of terms : 0
  Number of filters : 0
```

show services pgcp gate

Syntax	show services pgcp gate gateway-name gateway-name gate-id gate-id < brief extensive session-mirroring statistics > < master backup >
Release Information	Command introduced in Junos OS Release 9.5. statistics option introduced in Junos OS Release 9.1. session-mirroring option introduced in Junos OS Release 9.2. gateway option introduced in Junos OS Release 9.5. master option introduced in Junos OS Release 9.6 backup option introduced in Junos OS Release 9.6
Description	Display in-depth information about a Packet Gateway Control Protocol (PGCP) gate.
Options	gateway gateway-name —(Optional) Display information about gates associated with this virtual border gateway function (BGF). gate-id gate-id —(Optional) Display information about a particular gate. brief —(Optional) Display brief output. extensive —(Optional) Display extensive output. session-mirroring —(Optional) Display the session mirroring information for gates that are being mirrored. You must have a login with sufficient permission to view session mirroring information. The set system login class class-name permissions pgcp-session-mirroring command grants this permission. statistics —(Optional) Display statistics for gates. master —(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant MultiServices PIC (rms) interface. backup —(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, gate information for the routing engine is displayed. If the virtual BGF is running on a services PIC, gate information the primary services PIC is displayed. If you do not specify the master or backup options, the master option is the default.
Required Privilege Level	view pgcp-session-mirroring—To view session mirroring fields.
Related Documentation	<ul style="list-style-type: none">• show services pgcp gates on page 1716
List of Sample Output	show services pgcp gate on page 1713 show services pgcp gate extensive on page 1714 show services pgcp gate statistics on page 1714 show services pgcp gate session-mirroring on page 1715

Output Fields Table 321 on page 1709 lists the output fields for the **show services pgcp gate** command. Output fields are listed in the approximate order in which they appear.

Table 321: show services pgcp gate Output Fields

Field Name	Field Description	Output Level
Gate information	Information about the gate.	brief, extensive
Direction	Direction of the gate.	brief, extensive
State	State of the gate: <ul style="list-style-type: none"> • active • disabled • closed 	brief, extensive
remote source address	IP address of the remote source of the gate.	brief, extensive
remote source port	Port of the remote source of the gate.	brief, extensive
remote dest address	IP address of the remote destination of the gate.	brief, extensive
remote dest port	Port of the remote destination of the gate.	brief, extensive
local source address	IP address of the local source of the gate.	brief, extensive
local source port	Port of the local source of the gate.	brief, extensive
local dest address	IP address of the local destination of the gate.	brief, extensive
local dest port	Port of the local destination of the gate.	brief, extensive
transport	Transport protocol.	brief, extensive
gate version	Numeric identifier for the version of the gate.	brief, extensive
latch	Latch status: <ul style="list-style-type: none"> • latch • none 	brief, extensive
yellow action	Action to take in this state.	brief, extensive
red action	Action to take in this state.	brief, extensive
notifications	Number of notifications.	brief, extensive
User Data	Numeric identifier for the user data.	brief, extensive

Table 321: show services pgcp gate Output Fields (*continued*)

Field Name	Field Description	Output Level
Transport	H.248 media descriptor field: <ul style="list-style-type: none"> • udp • tcp • rtp • avp 	extensive
RTCP	Additional (shadow) gate allocated for the Real-Time Control Protocol (RTCP): auto or off.	extensive
Latch	State of the latch action on the gate: <ul style="list-style-type: none"> • none • latch • relatch 	extensive
DSCP	DiffServ code point (DSCP) marking value for the gate.	extensive
Policing	Status of policing on the gate: <ul style="list-style-type: none"> • On • Off 	extensive
Fast update filter	Status of the fast update filter: <ul style="list-style-type: none"> • On • Off 	extensive
Gate Statistics	Statistics for the specific gate.	statistics
Output Packets	Number of output packets from the PIC.	statistics
Input Packets	The number of PIC input packets plus the number of packets that the Packet Forwarding Engine dropped because they did not conform to rate limits.	statistics
Dropped Packets	Number of packets that the Packet Forwarding Engine and the PIC dropped because they did not conform to rate limits.	statistics
Lost RTP Packets	Number of RTP packets that have been lost on this gate.	statistics
Fractional lost RTP Packets	The fraction of RTP data packets that the remote side lost. The fraction is expressed as a percentage value.	statistics
RTCP Statistics	RTCP statistics for packets sent and received.	statistics
RTCP Sender Statistics	RTCP statistics for the sending endpoint.	statistics
SSRC	Synchronization source ID for the sending endpoint.	statistics

Table 321: show services pgcp gate Output Fields (*continued*)

Field Name	Field Description	Output Level
Sender Octets	Number of octets sent.	statistics
Sender Packets	Number of packets sent.	statistics
Invalid Packets	Number of invalid packets.	statistics
RTCP Receiver Statistics	Statistics for the endpoint receiving the RTCP packets.	statistics
SSRC	Synchronization source ID for the receiving endpoint.	statistics
Lost packets	The number of RTP data packets that the remote side lost in the current transmission.	statistics
Lost fraction	The fraction (percentage) of RTP data packets that the remote side lost in the current transmission.	statistics
Jitter	An estimate of the statistical variance of the RTP data packet interarrival time. The jitter is measured in the units of the RTP timestamp and represents the mean deviation of the difference in packet spacing at the receiver compared to the sender for a pair of packets.	statistics
Received RTCP-XR Statistics:	Statistics on RTCP packets sent and received.	statistics
Packet loss concealment	Method of packet loss concealment: <ul style="list-style-type: none"> • U—Unspecified • E—Enhanced • D—Disabled • S—Standard 	statistics
Loss Rate	The fraction of RTP data packets from the source lost since the beginning of reception.	statistics
Discard Rate	The fraction of RTP data packets from the source that have been discarded since the beginning of reception.	statistics
Round Trip Delay	The most recent round-trip time between interfaces, in milliseconds.	statistics
End System Delay	The most recently estimated end system delay, expressed in milliseconds.	statistics
Signal Level	The voice signal relative level shown as the ratio of the signal level to dBm0.	statistics
Noise Level	The ratio of the silent period background noise level to dBm0.	statistics

Table 321: show services pgcp gate Output Fields (*continued*)

Field Name	Field Description	Output Level
RERL	The residual echo return loss value expressed as an integer in the range from 0 to 100 dB. A value of 94 corresponds to "toll quality", and values of 50 or less are regarded as unusable. This metric includes the effects of delay.	statistics
R Factor	A voice quality metric describing the segment of the call that is carried over this RTP session expressed as an integer in the range from 0 to 100 dB. A value of 94 corresponds to "toll quality", and values of 50 or less are regarded as unusable. This metric includes the effects of delay. A value of 127 indicates that this parameter is unavailable.	statistics
Ext. R Factor	The external R factor is a voice quality metric describing the segment of the call that is carried over a network segment external to the RTP segment, such as a cellular network. Its values are interpreted in the same manner as for the RTPR factor. This metric includes the effects of delay and relates to the outward voice path from the VoIP termination for which this metrics block applies.	statistics
MOS-LQ	The estimated mean opinion score for listening quality (MOS-LQ) is a voice quality metric on a scale from 1 to 5, in which 5 represents excellent and 1 represents unacceptable. It includes the effects of delay and other effects that would affect listening quality.	statistics
MOS-CQ	The estimated mean opinion score for conversational quality (MOS-CQ) is a voice quality metric on a scale from 1 to 5, in which 5 represents excellent and 1 represents unacceptable. It includes the effects of delay and other effects that would affect conversational quality.	statistics
Received RTCP Burst Metrics Statistics	This section provides statistics for burst metrics received from the far end of the RTCP session.	statistics
Minimum Gap Threshold	This field contains the value used for this report block to determine if a gap exists. The recommended value of 16 corresponds to a burst period having a minimum density of 6.25 percent of lost or discarded packets, which may cause noticeable degradation in call quality. During gap periods defined with a threshold of 16, each lost or discarded packet is preceded by and followed by a sequence of at least 16 received non-discarded packets.	statistics
Burst Density	The fraction of RTP data packets within burst periods since the beginning of reception that were either lost or discarded.	statistics
Burst Duration	The mean duration of the burst periods that have occurred since the beginning of reception, in milliseconds.	statistics
Gap Loss Density	The fraction of RTP data packets within inter-burst gaps since the beginning of reception that were either lost or discarded.	statistics

Table 321: show services pgcp gate Output Fields (*continued*)

Field Name	Field Description	Output Level
Gap Duration	The mean duration of the gap periods that have occurred since the beginning of reception, in milliseconds.	statistics
Gate Measured Rate	Current gate throughput measured in bytes per second.	statistics
Rate-Limiting Statistics	Counter showing data traffic statistics based on the TRTC (two-rate-three-colors) policer.	statistics
FUF statistics	The number of dropped packets when the Fast Update Filter was enabled on the gate.	statistics
Drop count	The number of packets dropped by the data PIC.	statistics
Session mirroring status	Status of session mirroring: <ul style="list-style-type: none"> • On • Off 	session mirroring
Session mirroring correlation number	Indicates whether the data mirrors are encrypted.	session mirroring
Session mirroring target ID list	One or more targets of the mirrored packets.	session mirroring
Session mirroring direction	Direction of session mirroring: <ul style="list-style-type: none"> • Egress • Ingress 	session mirroring

Sample Output

```

show services pgcp gate user@host> show services pgcp gate gateway pg1 gate-id 4295033088
Gate information:
Direction: A->B

State: active

remote source address: 3.0.0.101

remote source port: *

remote dest address: 4.0.0.102

remote dest port: 5060

local source address: -

local source port: -

local dest address: 3.99.99.100

```

```
local dest port: 5060

transport: udp

gate version: 00

latch: none

yellow action: forward

red action: drop

notifications: 64

User Data: 0001102000000000
```

```
show services pgcp gate extensive
user@host> show services pgcp gate gateway pg1 gate-id 2817498611968 extensive
Gate information:
=====
```

```
Gate id: 2817498611968
Gate state: active
Direction: A->B
Action: drop
Remote source address: *
Remote source port: *
Remote destination address: 3.0.0.102
Remote destination port: 20000
Local source address: [20.50.150.1]
Local source port: [2334]
Local destination address: 10.50.150.1
Local destination port: 2334
Transport: rtp/avp
RTCP: On
Latch: none
DSCP: 0x40 (Effective 16)
Policing: Off
Fast update filter: Off
```

```
show services pgcp gate statistics
user@host> show services pgcp gate gateway pg1 gate-id 98784313601 statistics
Gate Statistics:
=====
```

```
Output packets: 0
Input packets: 0
Dropped packets: 0
Lost RTP packets: 0
Fractional lost RTP packets: 0
```

```
RTCP statistics:
=====
```

```
RTCP Sender statistics:
SSRC : 122598409 Sender octets: 268632      Sender packets: 1599
Invalid packets: 0
```

```
RTCP Receiver statistics:
SSRC: 14479      Lost packets: 0      Lost fraction: 0.00
Jitter: 0
```

```
Received RTCP-XR Statistics:
Packet Loss Concealment: 0      Loss Rate: 0      Discard Rate: 0
```

Round Trip Delay: 0 End System Delay: 0 Signal Level: 0
 Noise Level: 0 RERL: 0 R Factor: 0
 Ext. R Factor: 0 MOS-LQ: 0 MOS-CQ: 0

Received RTCP Burst Metrics Statistics:
 Minimum Gap Threshold: 0 Burst Density: 0 Burst Duration: 0
 Gap loss Density: 0 Gap Duration: 0

Gate measured rate: 0

Rate limiting statistics:

Mark Color	Number of Packets	Number of Bytes
Green	205	41000
Yellow	0	0
Red	0	0

FUF statistics:
 Drop count: 0

```

show services pgcp user@host> show services pgcp gate gateway pg1 gate-id 4295033088 session-mirroring
gate session-mirroring
Gate information:
Gate id: 4295033088
Session mirroring status: On
Session mirroring correlation number: 0x8040c020a060e010
Session mirroring target ID list: [008040c0, ffffffff80]
Session mirroring direction: Egress

```

show services pgcp gates

Syntax	show services pgcp gates gateway gateway-name <brief extensive count> <destination-routing-instance vrf> <source-routing-instance vrf> <backup master>
Release Information	Command introduced in Junos OS Release 8.4. brief extensive count options introduced in Junos OS Release 8.5. gateway option introduced in Junos OS Release 9.1 destination-routing-instance option introduced in Junos OS Release 9.3. source-routing-instance option introduced in Junos OS Release 9.3. gateway option was revised in Junos OS Release 9.5. master option introduced in Junos OS Release 9.6 backup option introduced in Junos OS Release 9.6
Description	Display information about gates.
Options	brief —(Optional) Display brief output. extensive —(Optional) Display extensive output. count —(Optional) Display the number of gates currently installed. destination-routing-instance —(Optional) Display information for a particular destination VPN routing and forwarding instance (VRF). source-routing-instance —(Optional) Display information for a particular source VPN routing and forwarding instance (VRF). gateway-name —Name of the virtual BGF for which you want to display gate information. backup —(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant MultiServices PIC (rms) interface. master —(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, gate information for the routing engine is displayed. If the virtual BGF is running on a services PIC, gate information the primary services PIC is displayed. If you do not specify the master or backup options, the master option is the default.
Required Privilege Level	view
List of Sample Output	show services pgcp gates on page 1719 show services pgcp gates gateway count on page 1720 show services pgcp gates gateway extensive on page 1720

Output Fields Table 322 on page 1717 lists the output fields for the **show services pgcp gates** command. Output fields are listed in the approximate order in which they appear.

Table 322: show services pgcp gates Output Fields

Field Name	Field Description	Level of Output
Virtual BGF configuration	Information about the virtual BGF configuration. <ul style="list-style-type: none">• Name—Name of the virtual BGF.• IP address—IP address of the virtual BGF.• Port—Port of the virtual BGF.• Status—Service state of the virtual BGF.	All levels

Table 322: show services pgcp gates Output Fields (*continued*)

Field Name	Field Description	Level of Output
Gate information	<p>Information about gates that are currently installed.</p> <ul style="list-style-type: none"> • Gate id—Numeric identifier of the gate. • Direction—Direction of the gate. <ul style="list-style-type: none"> • A is the termination that was created first. • B is the termination that was created second. • Gate state—State of the gate: Active, Disabled, or Closed. • Action—(extensive level only) Action applied to the gate: forward, add, or drop. • VRF—(extensive level only) If you have VPN aggregation configured, shows the source (ingress) VRF and the destination (egress) VRF. • Remote source address—(extensive level only) IPv4 or IPv6 address of the remote source. • Remote source port—(extensive level only) Remote source port. • Remote destination address—(extensive level only) IPv4 or IPv6 address of the remote destination. • Remote destination port—(extensive level only) Remote destination port. • Local source address—(extensive level only) IPv4 or IPv6 address of the local source. • Local source port—(extensive level only) Local source port. • Local destination address—(extensive level only) IPv4 or IPv6 address of the local destination. • Local destination address —(extensive level only) Local destination port. • Transport—(extensive level only) H.248 media descriptor field: udp, tcp, or rtp avp. • RTCP—(extensive level only) Additional (shadow) gate allocated for the Real-Time Control Protocol (RTCP): auto or off. • Latch—(extensive level only) State of the latch action on the gate: none, latch, or relatch. • DSCP—(extensive level only) DiffServ code point (DSCP) marking value for the gate. • Policing—(extensive level only) Status of policing on the gate: On or Off. • Gate SDR—(extensive level only) Current sustained data rate enforced on the gate. • Gate PDR—(extensive level only) Current peak data rate enforced on the gate. • Gate MBS—(extensive level only) Current maximum burst size enforced on the gate. • RTCP SDR—(extensive level only) Current sustained data rate enforced on RTCP gates. • RTCP PDR—(extensive level only) Current peak data rate enforced on RTCP gates. 	All levels (unless otherwise specified)

Table 322: show services pgcp gates Output Fields (*continued*)

Field Name	Field Description	Level of Output
	<ul style="list-style-type: none"> • RTCP MBS—(extensive level only) Current maximum burst size enforced on RTCP gates. • Fast update filter—(extensive level only) Status of the fast update filter: On or Off. • Service set id—Numeric identifier of the service set. • Media card—Name of the services interface. • Media handler—Name of the service set. • termination-id-string—Name of the termination. 	
Virtual BGF	(count keyword only) Name of the virtual BGF.	none specified
Gate count	(count keyword only) Number of gates currently installed on the virtual BGF.	none specified

Sample Output

```

show services pgcp user@host> show services pgcp gates gateway bgf-1
gates Virtual BGF configuration:
      Name                : bgf-1
      IP address           : 3.0.0.2
      Port                 : 2944
      Status               : Connected

      Gate information:
      Gate id: 4295033088
      Gate state: Active
      Service set id: 1
      Media card: sp-0/3/0
      Media handler: pgcp-svc-set-1
      Termination-id-string: ip/0/r1mvi2/1

      Gate id: 4295033089
      Gate state: Active
      Service set id: 1
      Media card: sp-0/3/0
      Media handler: pgcp-svc-set-1
      Termination-id-string: ip/0/r1mvi0/2

      Gate id: 8590000384
      Gate state: Active
      Service set id: 1
      Media card: sp-0/3/0
      Media handler: pgcp-svc-set-1
      Termination-id-string: ip/0/r1mvi2/3

      Gate id: 8590000385
      Gate state: Active
      Service set id: 1
      Media card: sp-0/3/0
      Media handler: pgcp-svc-set-1
      Termination-id-string: ip/0/r1mvi0/4

```

```
show services pgcp      user@host> show services pgcp gates gateway bgf-1 count
gates gateway count    Virtual BGF                               Gate count
bgf-1                                                           4
```

```
show services pgcp      user@host> show services pgcp gates gateway bgf-1 extensive
gates gateway          Virtual BGF configuration:
extensive
```

```
      Name                : bgf-1
      IP address           : 10.9.1.138
      Port                 : 2944
      Status               : In-Service
```

Gate information:

=====

```
Gate id: 4295033089
Gate state: active
Direction: B->A
Action: forward
VRF: vrf-1 -> vrf-2
Remote source address: 4.0.0.102
Remote source port: *
Remote destination address: 3.0.0.101
Remote destination port: 20000
Local source address: [3.99.99.100]
Local source port: [1024]
Local destination address: 4.99.99.100
Local destination port: 1028
Transport: rtp/avp
RTCP: Off
Latch: none
DSCP: 0x00 (Effective 0)
Policing: On
Gate SDR : 10000 bytes per second
Gate PDR : 10000 bytes per second
Gate MBS : 1000 bytes
RTCP SDR : 500 bytes per second
RTCP PDR : 500 bytes per second
RTCP MBS : 1000 bytes
Fast update filter: Off
```

Gate information:

=====

```
Gate id: 4295033088
Gate state: active
Direction: A->B
Action: forward
VRF: vrf-2 -> vrf-1
Remote source address:
Remote source port: *
Remote destination address: 4.0.0.102
Remote destination port: 10000
Local source address: [4.99.99.100]
Local source port: [1028]
Local destination address: 3.99.99.100
```


Local destination port: 1024
Transport: rtp/avp
RTCP: Off
Latch: none
DSCP: 0x00 (Effective 0)
Policing: Off
Fast update filter: Off

show services pgcp root-termination


Syntax	show services pgcp root-termination gateway <i>gateway-name</i> <backup master>
Release Information	Command introduced in Junos OS Release 8.5. gateway option introduced in Junos OS Release 9.5. master option introduced in Junos OS Release 9.6 backup option introduced in Junos OS Release 9.6
Description	Display information about the H.248 root termination.
<div>  <p>NOTE: This command is not applicable when the gateway controller for the BGF is a BSG.</p> </div>	
Options	<p>gateway <i>gateway-name</i>—Display information about root terminations in H.248 transactions associated with this virtual BGF.</p> <p>backup—(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant MultiServices PIC (rms) interface.</p> <p>master—(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, the route terminations on the routing engine are displayed. If the virtual BGF is running on a services PIC, the route terminations on primary services PIC are displayed. If you do not specify the master or backup options, the master option is the default.</p>
Required Privilege Level	view
List of Sample Output	show services pgcp root-termination on page 1722
Output Fields	Table 323 on page 1722 lists the output fields for the show services pgcp root-termination command. Output fields are listed in the approximate order in which they appear.

Table 323: show services pgcp root-termination Output Fields

Field Name	Field Description
Root termination information	Information about the root terminations in H.248 transactions.

Sample Output

```

show services pgcp root-termination  user@host> show services pgcp root-termination bgf-1
Root termination information:

ROOT {

```

```
MEDIA {  
    TERMINATIONSTATE { SERVICESTATES = INSERVICE,  
        ROOT/MAXNUMBEROFCONTEXTS = 20000,  
        ROOT/MAXTERMINATIONSPERCONTEXT = 2,  
        ROOT/MGCMORIGINATEDPENDINGLIMIT = 15,  
        ROOT/MGCPROVISIONALRESPONSETIMERVALUE = 2000,  
        ROOT/MGCMORIGINATEDPENDINGLIMIT = 15,  
        ROOT/MGPROVISIONALRESPONSETIMERVALUE = 2000,  
        ROOT/NORMALMGCEXECUTIONTIME = 1000,  
        ROOT/NORMALMGCEXECUTIONTIME = 1000,  
        SEG/MGCMAXPDUSIZE = 500,  
        SEG/MGCSEGMENTATIONTIMERVALUE = 6000,  
        SEG/MGMAXPDUSIZE = 500,  
        SEG/MGSEGMENTATIONTIMERVALUE = 6000 }  
},
```

show services pgcp statistics

Syntax	show services pgcp statistics gateway <i>gateway-name</i> <brief extensive> <backup master> <virtual-interface <i>interface-number</i> >
Release Information	Command introduced in Junos OS Release 8.4. brief extensive option introduced in Junos OS Release 9.3. gateway option introduced in Junos OS Release 9.5. master option introduced in Junos OS Release 9.6. backup option introduced in Junos OS Release 9.6. virtual-interface option introduced in Junos OS 11.1
Description	Display information about statistics associated with the virtual border gateway function (vBGF) or for a specific virtual interface on the vBGF.
Options	gateway <i>gateway-name</i> —Display information about statistics associated with this virtual BGF. brief extensive—(Optional) Display the specified level of output. The default level is brief. backup —(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant Multiservices PIC (rms) interface. master —(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, statistics on the Routing Engine are displayed. If the virtual BGF is running on a services PIC, statistics on the primary services PIC are displayed. If you do not specify the master or backup options, the master option is the default.
Required Privilege Level	view
List of Sample Output	show services pgcp statistics on page 1728 show services pgcp statistics extensive on page 1729
Output Fields	Table 324 on page 1725 lists the output fields for the show services pgcp statistics command. Output fields are listed in the approximate order in which they appear.

Table 324: show services pgcp statistics Output Fields

Field Name	Field Description	Level of Output
Virtual BGF configuration	<p>Information about the virtual BGF configuration.</p> <ul style="list-style-type: none"> • Name—Name of the virtual BGF. • Platform—The service interface for the BGF. • IP address—IP address of the virtual BGF. • Routing Instance—Name of the routing instance associated with the virtual BGF. • Port—Port of the virtual BGF. • Status—Status of the virtual BGF: In-Service, Out-of-Service, • Active gateway controller—Gateway controller that is currently controlling this virtual BGF. NULL means that there is no active gateway controller. • Replication socket <ul style="list-style-type: none"> • Connected (Ready)—The replication is ready and a switchover can be processed. • Connected (Syncing)—The replication is synchronizing. Performing a switchover is not safe. • Connected (Error)—An error occurred in the previous switchover. • Disconnected—The backup Routing Engine is down. There is no route to the backup Routing Engine. • Synchronization state—The status of the synchronization between the internal state of the pgcpd process and the flow of media on a data PIC after a failover of the pgcpd process. <ul style="list-style-type: none"> • Idle—The pgcpd process and the data PIC media flow are in synch. • Initializing—The pgcpd process is reading the current status of the data PIC to determine required synchronization. • synchronizing—The pgcpd process is synchronizing its internal state with the data PIC. <p>NOTE: BGF service is not affected when synchronizing. Gates can be created, modified, and deleted normally.</p> <ul style="list-style-type: none"> • Up time—The time, in hours, minutes, and seconds, since the pgcpd process started. <p>NOTE: This metric is not affected by changes to the BGF's administrative state (in-service, out-of-service) or clearing of statistics by use of the clear services pgcp statistics command.</p> <ul style="list-style-type: none"> • Load status—Describes the current load on the system. <ul style="list-style-type: none"> • Normal—The system is not overloaded. • Overloaded—The system is sending overload messages to the gateway controller. • Overloaded (rejecting new calls)—The system is overloaded and is rejecting all attempts to create new gates. 	all
Usage Counters	<p>Information about usage of contexts and emergency contexts.</p> <ul style="list-style-type: none"> • Contexts—The number of active contexts out of the total number of contexts. • Emergency contexts—The number of active contexts that are emergency contexts. 	
BGF MultiServices PIC status	<p>Information about the Multiservice PIC providing the BGF service.</p> <ul style="list-style-type: none"> • Name—Service interface assigned for the BGF. • Status—Connection status of the BGF. 	

Table 324: show services pgcp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
Traffic summary	<p>Traffic statistics accumulated since the last time statistics were cleared. Statistics shown are for either the vBGF or for a specifically requested virtual interface.</p> <ul style="list-style-type: none"> • Input Packets—Number of packets received. • Output Packets—Number of packets sent. • Input Octets—Number of octets received. • Output Octets—Number of octets sent. • Dropped packets—Number of packets dropped for each of the following reasons: <ul style="list-style-type: none"> • Rate limit—Number of packets dropped due to rate limiting. • Explicit drop—Packets dropped due to actions on the control plane, such as send-only, receive-only, out-of-service, remote-destination-unknown. • Algs—Count of packets dropped due to L4-L7 validation by ALGs (Application Layer Gateways). • Other—Total number of packets dropped for any of the following reasons: <ul style="list-style-type: none"> • Basic packet verification failure • Source ifl does not match • NAT translation failure ipv4 to ipv6 • Virtual interface out of service • Latching operation not completed 	
H.248 statistics	<p>Information about H.248 statistics. Statistics shown are for either the vBGF or for a specifically requested virtual interface. If the vBGF's controller is a BSG, the statistics represent the number of API messages that are used in lieu of actual H.248 messages.</p> <ul style="list-style-type: none"> • Messages received—Number of H.248 messages received. • Messages sent—Number of H.248 messages sent. • Protocol errors—Number of errors detected for this virtual BGF, including: <ul style="list-style-type: none"> • Syntax errors detected in received messages. • Outgoing transactions that have failed for protocol reasons. 	all
Received Commands	<p>Information about command requests received by the virtual BGF. The following information is shown for each possible command.</p> <ul style="list-style-type: none"> • Total—Total number of commands received, including commands with wildcard termination IDs. • Wildcards—Number of commands received that contain wildcard termination IDs. • Success—Number of success replies sent by the virtual BGF. • Error—Number of error replies sent by the virtual BGF. <p>Commands are not counted in the following cases:</p> <ul style="list-style-type: none"> • The command was not executed because of a previous error. • The command was not fully executed because of its own syntax error, which made it impossible to obtain the command type itself. 	all

Table 324: show services pgcp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
Sent Commands	<p>Information about command requests sent by the virtual BGF. The following information is shown for each possible command.</p> <ul style="list-style-type: none"> • Total—Total number of commands sent, including commands with wildcard termination IDs. • Wildcards—Number of commands sent that contain wildcard termination IDs. • Success—Number of success replies received by the virtual BGF. • Error—Number of error replies received by the virtual BGF. <p>Commands are not counted in the following cases:</p> <ul style="list-style-type: none"> • The command was not executed because of a previous error. • The command was not fully executed because of its own syntax error, which made it impossible to obtain the command type itself. 	none brief
ROOT SVC	<p>Information about ServiceChange requests sent by the virtual BGF on the root termination.</p> <ul style="list-style-type: none"> • Total—Total number of commands sent, including commands with wildcard termination IDs. • Wildcards—Number of commands sent that contain wildcard termination IDs. • Success—Number of success replies received by the virtual BGF. • Error—Number of error replies received by the virtual BGF. <p>Commands are not counted in the following cases:</p> <ul style="list-style-type: none"> • The command was not executed because of a previous error. • The command was not fully executed because of its own syntax error, which made it impossible to obtain the command type itself. 	extensive
Termination SVC	<p>Information about ServiceChange requests sent by the virtual BGF on the IP termination.</p> <ul style="list-style-type: none"> • Total—Total number of commands sent, including commands with wildcard termination IDs. • Wildcards—Number of commands sent that contain wildcard termination IDs. • Success—Number of success replies received by the virtual BGF. • Error—Number of error replies received by the virtual BGF. <p>Commands are not counted in the following cases:</p> <ul style="list-style-type: none"> • The command was not executed because of a previous error. • The command was not fully executed because of its own syntax error, which made it impossible to obtain the command type itself. 	extensive

Table 324: show services pgcp statistics Output Fields (*continued*)

Field Name	Field Description	Level of Output
ROOT Notify	<p>Information about notifications sent by the virtual BGF on the root termination.</p> <ul style="list-style-type: none"> ocp/mg_overloaded—MG overload notifications. it/ito—Inactivity timeout notifications. Total—Total number of notifications sent, including notifications with wildcard termination IDs. Wildcards—Number of notifications sent that contain wildcard termination IDs. Success—Number of success replies received by the virtual BGF. Error—Number of error replies received by the virtual BGF. <p>Commands are not counted in the following cases:</p> <ul style="list-style-type: none"> The command was not executed because of a previous error. The command was not fully executed because of its own syntax error, which made it impossible to obtain the command type itself. 	extensive
Termination Notify	<p>Information about notifications sent by the virtual BGF on the IP termination.</p> <ul style="list-style-type: none"> adid/ipstop—IP flow stop detection notifications. nt/qualert—Quality alert notifications. adr/rtac—Remote source address changed notifications. hangterm/thb—Termination heartbeat notifications. Total—Total number of notifications sent, including notifications with wildcard termination IDs. Wildcards—Number of notifications sent that contain wildcard termination IDs. Success—Number of success replies received by the virtual BGF. Error—Number of error replies received by the virtual BGF. <p>Commands are not counted in the following cases:</p> <ul style="list-style-type: none"> The command was not executed because of a previous error. The command was not fully executed because of its own syntax error, which made it impossible to obtain the command type itself. 	extensive

Sample Output

```

show services pgcp statistics user@host> show services pgcp statistics gateway bgf-1
Virtual BGF configuration:
  Name                : bgf-1
  Platform             : routing-engine [0]
  IP address           : 10.50.30.100
  Routing-instance     : ri-2
  Port                : 2944
  Status              : In-Service (Registered)
  Active gateway controller : PGC1
  Replication socket   : Disconnected
  Synchronization state : Disabled
  Up time              : 1 day, 22 hours, 50 minutes, 37
seconds
  Load status         : Normal

```


BGF MultiServices PIC status:

Name : sp-0/3/0
Status : Connected

Statistics since: 3 Days 2 hours 20 secs

Traffic Summary:

Input Packets: 1044066
Output Packets: 1024066
Input Octets: 121044066
Output Octets: 101024066
Dropped packets:
Rate limit: 20/120
Explicit drop: 0/0
Algs: 10/540
Other: 0/0

Usage counters:

Contexts : 11 / 6000
Emergency contexts : 0

H.248 statistics:

Messages received : 5
Messages sent : 3
Protocol errors : 0

Received Commands	Total	Wildcard	Success	Error
Add	0	0	0	0
Add (emergency)	0	0	0	0
AuditValue	1	0	1	0
Modify	1	0	1	0
ServiceChange	0	0	0	0
Subtract	0	0	0	0
Sent Commands	Total	Wildcard	Success	Error
Notify	0	0	0	0
ServiceChange	1	0	1	0

**show services pgcp
statistics extensive**

user@host> show services pgcp statistics gateway bgf-1 extensive

Virtual BGF configuration:

Name : bgf-1
IP address : 10.50.150.100
Port : 2944
Status : In-Service (Registered)

H.248 statistics:

Messages received : 5
Messages sent : 3
Protocol errors : 0

Received Commands	Total	Wildcard	Success	Error
Add	0	0	0	0
Add (emergency)	0	0	0	0

AuditValue	1	0	1	0
Modify	1	0	1	0
ServiceChange	0	0	0	0
Subtract	0	0	0	0
Sent Commands	Total	Wildcard	Success	Error
Notify	0	0	0	0
ServiceChange	1	0	1	0
ROOT SVC	Total	Wildcard	Success	Error
DC/900	0	0	0	0
FL/908	0	0	0	0
FL/909	0	0	0	0
FL/919	0	0	0	0
FL/920	0	0	0	0
FO/904	0	0	0	0
FO/905	0	0	0	0
FO/908	0	0	0	0
GR/905	0	0	0	0
HO/903	0	0	0	0
RS/900	0	0	0	0
RS/901	1	0	1	0
RS/902	0	0	0	0
RS/918	0	0	0	0
Termination SVC	Total	Wildcard	Success	Error
FO/904	0	0	0	0
FO/905	0	0	0	0
FO/906	0	0	0	0
FO/907	0	0	0	0
FO/910	0	0	0	0
FO/915	0	0	0	0
GR/905	0	0	0	0
RS/900	0	0	0	0
RS/918	0	0	0	0
ROOT Notify	Total	Wildcard	Success	Error
ocp/mg_overloaded	0	0	0	0
it/ito	1404	0	1404	0
Termination Notify	Total	Wildcard	Success	Error
adid/ipstop	0	0	0	0
nt/qualert	0	0	0	0
adr/rtac	0	0	0	0
hangterm/thb	0	0	0	0

show services pgcp conversations

Syntax show services pgcp conversations gateway *gateway-name*
 <brief | extensive | terse>
 <backup | master>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <destination-routing-instance *vrf*>
 <gate-id *gate-id*>
gateway-name
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>
 <source-routing-instance *vrf*>

Release Information Command introduced in Junos OS Release 8.4.
gateway-name option added in Junos OS Release 9.2.
master option introduced in Junos OS Release 9.6
backup option introduced in Junos OS Release 9.6

Description Display information about Packet Gateway Control Protocol (PGCP) conversations.

Options gateway *gateway-name*—Display information about statistics associated with this virtual border gateway function (BGF).

none—Display standard information about all PGCP conversations.

brief | extensive | terse—(Optional) Display the specified level of output.

backup—(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant Multiservices PIC (rms) interface.

master—(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, the conversations on the routing engine are displayed. If the virtual BGF is running on a services PIC, the conversations on the primary services PIC are displayed. If you do not specify the **master** or **backup** options, the **master** option is the default.

destination-port *destination-port*—(Optional) Display information for a particular destination port.

destination-prefix *destination-prefix*—(Optional) Display information for a particular destination prefix.

destination-routing-instance *vrf*—(Optional) Display information for a particular destination VPN routing and forwarding instance (VRF).

gate *gate-id*—(Optional) Display information about a particular gate.

gateway-name—Display information about a virtual BGF.

`protocol protocol`—(Optional) Display information about one of the following IP protocol types:

- **number**—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-over-IP Encapsulation Protocol
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

`service-set service-set`—(Optional) Display information for the specific service set.

`source-port source-port`—(Optional) Display information for a particular source port. The range of values is from 0 to 65535.

`source-prefix source-prefix`—(Optional) Display information for a particular source prefix.

`source-routing-instance vrf`—(Optional) Display information for a particular source VPN routing and forwarding instance (VRF).

Required Privilege Level view

List of Sample Output [show services pgcp conversations on page 1734](#)
[show services pgcp conversations extensive on page 1734](#)

Output Fields Table 325 on page 1732 lists the output fields for the **show services pgcp conversations** command. Output fields are listed in the approximate order in which they appear.

Table 325: show services pgcp conversations Output Fields

Field Name	Field Description	Level of Output
Interface	Name of a services interface.	All levels
Service set	Name of a service set. Individual empty service sets are not displayed. If no service set has any flows, a flow table header is printed for each service set.	All levels

Table 325: show services pgcp conversations Output Fields (*continued*)

Field Name	Field Description	Level of Output
Conversation	Information about a group of related flows. <ul style="list-style-type: none"> • ALG Protocol—Application-level gateway protocol. • Number of initiators—Number of flows that initiated a session. • Number of responders—Number of flows that responded in a session. 	All levels
Flow	Protocol used for this flow.	All levels
Source	Source prefix of the flow, in the format <i>source-prefix-port</i> .	All levels
Destination	Destination prefix of the flow.	All levels
State	Status of the flow: <ul style="list-style-type: none"> • Drop—Drop all packets in the flow without response. • Forward—Forward the packet in the flow without looking at it. • Reject—Drop all packets in the flow with response. • Watch—Inspect packets in the flow. 	All levels
Dir	Direction of the flow: input (I) or output (O).	All levels
Frm Count	Number of frames in the flow.	All levels
Gate id	Numeric identifier of the gate.	All levels
NAT source	Original and translated source IPv4 or IPv6 addresses are displayed if Network Address Translation (NAT) is configured on this particular flow or conversation.	All levels
NAT dest	Original and translated destination IPv4 or IPv6 addresses are displayed if NAT is configured on this particular flow or conversation.	All levels
Byte count	Number of bytes forwarded in the flow.	extensive
Flow role	Role of the flow that is under evaluation: Initiator , Master , Responder , or Unknown .	extensive
Timeout	Lifetime of the flow, in seconds.	extensive
Tman Policing	Whether traffic-management policing is ON or OFF	extensive
SDR	Sustained data rate being enforced for the gate.	extensive
SDR MBS	Sustained data rate maximum burst size being enforced for the gate.	extensive
PDR	Peak data rate being enforced for the gate.	extensive
PDR MBS	Peak data rate maximum burst size being enforced for the gate.	extensive

Sample Output

```

user@host> show services pgcp conversations
Interface: sp-0/3/0, Service set: bgf-svc-set-1

Conversation: ALG protocol: any
Number of initiators: 2, Number of responders: 2
Flow      State  Dir      Frm count
UDP      4.0.0.102:0  ->  4.99.99.100:1024 Forward I      20051
Gate id: 8590000385
  NAT source 4.0.0.102:0 -> 3.99.99.100:1024
  NAT dest 4.99.99.100:1024 -> 3.0.0.101:49174
UDP      4.0.0.102:0  -> 4.99.99.100:1025 Forward I      0
Gate id: 8590000385
  NAT source 4.0.0.102:0 -> 3.99.99.100:1025
  NAT dest 4.99.99.100:1025 -> 3.0.0.101:49175
UDP      0.0.0.0:0 -> 3.99.99.100:1024 Forward I      19551
Gate id: 8590000384
  NAT source 0.0.0.0:0 -> 4.99.99.100:1024
  NAT dest 3.99.99.100:1024 -> 4.0.0.102:49234
UDP      0.0.0.0:0 -> 3.99.99.100:1025 Forward I      0
Gate id: 8590000384
  NAT source 0.0.0.0:0 -> 4.99.99.100:1025
  NAT dest 3.99.99.100:1025 -> 4.0.0.102:49235

Conversation: ALG protocol: any
Number of initiators: 1, Number of responders: 1
Flow      State  Dir      Frm count
UDP      3.0.0.101:0 -> 3.99.99.100:5060 Forward I      2
Gate id: 4295033088
  NAT source 3.0.0.101:0 -> 4.99.99.100:5060
  NAT dest 3.99.99.100:5060 -> 4.0.0.102:5060
UDP      4.0.0.102:0 -> 4.99.99.100:5060 Forward I      3
Gate id: 4295033089
  NAT source 4.0.0.102:0 -> 3.99.99.100:5060
  NAT dest 4.99.99.100:5060 -> 3.0.0.101:5060

user@host> show services pgcp conversations bgf-1 extensive
Interface: rsp1, Service set: bgf-svc-set-1

Number of initiators: 2, Number of responders: 2
Flow      State  Dir      Frm count
Gate id: 4295033088
UDP      4.0.0.102:0 -> 10.50.100.1:1024 Forward I      0
  NAT source 4.0.0.102:0 -> 20.50.100.1:1024
  NAT dest 10.50.100.1:1024 -> 4.0.0.101:10000
Byte count: 0
Flow role: Master, Timeout: 429496728
Tman Policing: ON
SDR : 10000 bytes per second
SDR MBS: 1000 bytes
PDR : 10000 bytes per second
PDR MBS: 1000 bytes
Gate id: 4295033088
UDP      4.0.0.102:0 -> 10.50.100.1:1025 Forward I      0
  NAT source 4.0.0.102:0 -> 20.50.100.1:1025
  NAT dest 10.50.100.1:1025 -> 4.0.0.101:10001
Byte count: 0
Flow role: Initiator, Timeout: 429496728
Tman Policing: ON

```

```
SDR      : 500 bytes per second
SDR MBS: 1000 bytes
PDR      : 500 bytes per second
PDR MBS: 1000 bytes
Gate id: 4295033089
UDP      4.0.0.101:0      ->    20.50.100.1:1024 Forward I      0
    NAT source      4.0.0.101:0      ->    10.50.100.1:1024
    NAT dest      20.50.100.1:1024      ->    4.0.0.102:10000
Byte count: 0
Flow role: Responder, Timeout: 6000
Tman Policing: OFF
Gate id: 4295033089
UDP      4.0.0.101:0      ->    20.50.100.1:1025 Forward I      0
    NAT source      4.0.0.101:0      ->    10.50.100.1:1025
    NAT dest      20.50.100.1:1025      ->    4.0.0.102:10001
Byte count: 0
Flow role: Responder, Timeout: 429496728
Tman Policing: OFF
```

show services pgcp flows

Syntax `show services pgcp flows gateway gateway-name`
 `<brief | extensive | terse>`
 `<backup | master>`
 `<count>`
 `<destination-port destination-port>`
 `<destination-prefix destination-prefix>`
 `<destination-routing-instance vrf>`
 `<gate-id gate-id>`
 `<gateway-name>`
 `<protocol protocol>`
 `<service-set service-set>`
 `<source-port source-port>`
 `<source-prefix source-prefix>`
 `<source-routing-instance vrf>`

Release Information Command introduced in Junos OS Release 8.4.
 gate-id option added in Release 9.2.
 gateway-name option added in Junos OS Release 9.2.
 destination-routing-instance option added in Junos OS Release 9.3.
 source-routing-instance option added in Junos OS Release 9.3.
 master option introduced in Junos OS Release 9.6
 backup option introduced in Junos OS Release 9.6

Description Display information for Packet Gateway Control Protocol (PGCP) flows.

Options `gateway gateway-name`—Display information about statistics associated with this virtual border gateway function (BGF).

`none`—Display standard information about all PGCP flows.

`brief | extensive | terse`—(Optional) Display the specified level of output.

backup—(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant Multiservices PIC (rms) interface.

master—(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, the flows on the routing engine are displayed. If the virtual BGF is running on a services PIC, the flows on the primary services PIC are displayed. If you do not specify the **master** or **backup** options, the **master** option is the default.

`count`—(Optional) Display a count of the matching entries.

`destination-port destination-port`—(Optional) Display information for a particular destination port.

`destination-prefix destination-prefix`—(Optional) Display information for a particular destination prefix.

destination-routing-instance *vrf*—(Optional) Display information for a particular destination VPN routing and forwarding instance (VRF).

gate *gate-id*—(Optional) Display information about a particular gate.

gateway-name—(Optional) Display information about a particular virtual BGF.

protocol *protocol*—(Optional) Display information about one of the following IP protocol types:

- **number**—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Display information for a particular service set.

source-port *source-port*—(Optional) Display information for a particular source port.

source-prefix *source-prefix*—(Optional) Display information for a particular source prefix.

source-routing-instance *vrf*—(Optional) Display information for a particular source VPN routing and forwarding instance (VRF).

Required Privilege Level	view
List of Sample Output	show services pgcp flows on page 1739 show services pgcp flows extensive on page 1739
Output Fields	Table 326 on page 1738 lists the output fields for the show services pgcp flows command. Output fields are listed in the approximate order in which they appear.

Table 326: show services pgcp flows Output Fields

Field Name	Field Description	Level of Output
Interface	Name of the services interface.	All levels
Service set	Name of a service set. Individual empty service sets are not displayed. If no service set has any flows, a flow table header is displayed for each service set.	All levels
Flow	Protocol used for this flow.	All levels
Source	Source prefix of the flow in the format <i>source-prefix:port</i> .	All levels
Dest	Destination prefix of the flow.	All levels
State	Status of the flow: <ul style="list-style-type: none"> • Drop—Drop all packets in the flow without response. • Forward—Forward the packet in the flow without looking at it. • Reject—Drop all packets in the flow with response. • Watch—Inspect packets in the flow. 	All levels
Dir	Direction of the flow: input (I), output (O), or unknown (U).	All levels
Frm count	Number of frames in the flow.	All levels
Gate id	Numeric identifier of the gate.	All levels
NAT source	Original and translated source IPv4 or IPv6 addresses are displayed if Network Address Translation (NAT) is configured on this particular flow or conversation.	All levels
NAT dest	Original and translated destination IPv4 or IPv6 addresses are displayed if NAT is configured on this particular flow or conversation.	All levels
VRF	If you have VPN aggregation configured, shows the source (ingress) VRF and the destination (egress) VRF.	extensive
Byte count	Number of bytes forwarded in the flow.	extensive
Flow role	Role of the flow that is under evaluation: Initiator , Master , Responder , or Unknown .	extensive
Timeout	Lifetime of the flow, in seconds.	extensive
Tman Policing	Whether traffic-management policing is ON or OFF	extensive
SDR	Sustained data rate being enforced for the gate.	extensive
SDR MBS	Sustained data rate maximum burst size being enforced for the gate.	extensive
PDR	Peak data rate being enforced for the gate.	extensive
PDR MBS	Peak data rate maximum burst size being enforced for the gate.	extensive

Sample Output

```

show services pgcp flows user@host> show services pgcp flows gateway VBGFI
Interface: sp-0/3/0, Service set: bgf-svc-set-1
Flow State Dir Frm count
UDP 4.0.0.102:0 -> 4.99.99.100:1024 Forward I 21531
Gate id: 8590000385
  NAT source 4.0.0.102:0 -> 3.99.99.100:1024
  NAT dest 4.99.99.100:1024 -> 3.0.0.101:49174
UDP 0.0.0.0:0 -> 3.99.99.100:1024 Forward I 20999
Gate id: 8590000384
  NAT source 0.0.0.0:0 -> 4.99.99.100:1024
  NAT dest 3.99.99.100:1024 -> 4.0.0.102:49234
UDP 4.0.0.102:0 -> 4.99.99.100:5060 Forward I 3
Gate id: 4295033089
  NAT source 4.0.0.102:0 -> 3.99.99.100:5060
  NAT dest 4.99.99.100:5060 -> 3.0.0.101:5060
UDP 3.0.0.101:0 -> 3.99.99.100:5060 Forward I 2
Gate id: 4295033088
  NAT source 3.0.0.101:0 -> 4.99.99.100:5060
  NAT dest 3.99.99.100:5060 -> 4.0.0.102:5060
UDP 0.0.0.0:0 -> 3.99.99.100:1025 Forward I 0
Gate id: 8590000384
  NAT source 0.0.0.0:0 -> 4.99.99.100:1025
  NAT dest 3.99.99.100:1025 -> 4.0.0.102:49235
UDP 4.0.0.102:0 -> 4.99.99.100:1025 Forward I 0
Gate id: 8590000385
  NAT source 4.0.0.102:0 -> 3.99.99.100:1025
  NAT dest 4.99.99.100:1025 -> 3.0.0.101:49175

show services pgcp flows extensive user@host> show services pgcp flows bgf-1 extensive
Interface: rsp1, Service set: bgf-svc-set-1
Flow State Dir Frm count
Gate id: 4295033088
UDP 4.0.0.102:0 -> 10.50.100.1:1024 Forward U 0
  NAT source 4.0.0.102:0 -> 20.50.100.1:1024
  NAT dest 10.50.100.1:1024 -> 4.0.0.101:10000
VRF: vrf1 -> vrf2
  Byte count: 0
  Flow role: Master, Timeout: 429496728
  Tman Policing: ON
  SDR : 10000 bytes per second
  SDR MBS: 1000 bytes
  PDR : 10000 bytes per second
  PDR MBS: 1000 bytes
Gate id: 4295033088
UDP 4.0.0.102:0 -> 10.50.100.1:1025 Forward U 0
  NAT source 4.0.0.102:0 -> 20.50.100.1:1025
  NAT dest 10.50.100.1:1025 -> 4.0.0.101:10001
VRF: vrf1 -> vrf2
  Byte count: 0
  Flow role: Initiator, Timeout: 429496728
  Tman Policing: ON
  SDR : 500 bytes per second
  SDR MBS: 1000 bytes
  PDR : 500 bytes per second
  PDR MBS: 1000 bytes
Gate id: 4295033089
UDP 4.0.0.101:0 -> 20.50.100.1:1024 Forward U 0
  NAT source 4.0.0.101:0 -> 10.50.100.1:1024

```

```
      NAT dest      20.50.100.1:1024    ->      4.0.0.102:10000
VRF:  vrf1 -> vrf2
      Byte count: 0
      Flow role: Responder, Timeout: 6000
      Tman Policing: OFF
Gate id: 4295033089
UDP      4.0.0.101:0      ->      20.50.100.1:1025 Forward U      0
      NAT source      4.0.0.101:0      ->      10.50.100.1:1025
      NAT dest      20.50.100.1:1025    ->      4.0.0.102:10001
VRF:  vrf1 -> vrf2
      Byte count: 0
      Flow role: Responder, Timeout: 429496728
      Tman Policing: OFF
```

show services pgcp terminations

Syntax	show services pgcp terminations gateway <i>gateway-name</i> <brief h248 count> <backup master> <termination-prefix <i>prefix</i>>
Release Information	<p>Command introduced in Junos OS Release 8.4.</p> <p>brief h248 count option introduced in Junos OS Release 8.5.</p> <p>termination-prefix option introduced in Junos OS Release 8.5.</p> <p>gateway option revised in Junos OS Release 9.5.</p> <p>master option introduced in Junos OS Release 9.6</p> <p>backup option introduced in Junos OS Release 9.6</p>
Description	Display summary information about all Packet Gateway Control Protocol (PGCP) terminations.
Options	<p>gateway <i>gateway-name</i>—Display information about terminations associated with this virtual border gateway function (BGF).</p> <p>brief h248 count—(Optional) Display the specified level of output.</p> <p>backup—(Optional) Display information for the backup services PIC. This option applies if you are running the virtual BGF on a services PIC or MS-DPC, and you have a primary and backup PIC configured on a virtual redundant Multiservices PIC (rms) interface.</p> <p>master—(Optional) Display information for the Routing Engine or primary services PIC. If the virtual BGF is running on the Routing Engine, the terminations on the routing engine are displayed. If the virtual BGF is running on a services PIC, the terminations on the primary services PIC are displayed. If you do not specify the master or backup options, the master option is the default.</p> <p>termination-prefix <i>prefix</i>—(Optional) Display information based on the termination prefix.</p>
Required Privilege Level	view
List of Sample Output	<p>show services pgcp terminations on page 1742</p> <p>show services pgcp terminations brief on page 1743</p> <p>show services pgcp terminations count on page 1743</p> <p>show services pgcp terminations h248 on page 1743</p> <p>show services pgcp terminations termination-prefix brief on page 1745</p> <p>show services pgcp terminations termination-prefix h248 on page 1745</p>
Output Fields	Table 327 on page 1742 lists the output fields for the show services pgcp terminations command. Output fields are listed in the approximate order in which they appear.

Table 327: show services pgcp terminations Output Fields

Field Name	Field Description	Level of Output
virtual BGF configuration	Information about the virtual BGF configuration. <ul style="list-style-type: none"> Name—Name of the BGF. IP address—IP address of the BGF. Port—Port of the BGF. Status—Status of the BGF. 	All levels except count
Termination name	Name of the termination.	none specified and brief
State	State of the termination: In-service or Out-of-service .	none specified and brief
Duration	Period of time that termination and gates exist, in milliseconds.	none specified and brief
Gate-id	Numeric identifier of the termination.	none specified and brief
Direction	<ul style="list-style-type: none"> A is the termination that was created first. B is the termination that was created second. 	none specified and brief
State	State of the gate: active , disabled , or closed .	none specified and brief
Action	Action applied to the gate: forward , add , or drop .	none specified and brief
Gateway name	Name of the BGF.	none specified and brief
Terminations count	Number of terminations.	count
Termination Information	Information about the termination in the form of an H.248 transaction.	h248

Sample Output

```

show services pgcp terminations user@host> show services pgcp terminations gateway bgf-1
Virtual BGF configuration:

      Name                : bgf-1
      IP address           : 3.0.0.2
      Port                 : 2944
      Status               : In-Service

Termination name          State          Duration(msecs)
ip/4/vif-0/2              In-service    9628

```

Gate-id	Direction	State	Action
4295033088	A->B	active	forward
4295033089	B->A	active	forward

Termination name	State	Duration(msecs)
ip/4/vif-0/3	In-service	9632

Gate-id	Direction	State	Action
4295033088	A->B	active	forward
4295033089	B->A	active	forward

```
show services pgcp terminations brief
Virtual BGF configuration:
```

```
Name          : pg1
IP address    : 3.0.0.2
Port          : 2944
Status        : In-Service
```

Termination name	State		Duration(msecs)
ip/4/vif-0/1	In-service	109735	
Gate-id	Direction	State	Action
4295033088	A->B	active	forward
4295033089	B->A	active	drop

Termination name	State		Duration(msecs)
ip/4/vif-0/2	In-service	109736	
Gate-id	Direction	State	Action
4295033088	A->B	active	forward
4295033089	B->A	active	drop

```
show services pgcp terminations count
user@host> show services pgcp terminations gateway bgf-1 count
Virtual BGF Terminations Count
bgf-1 2
```

```
show services pgcp terminations h248
user@host> show services pgcp terminations gateway bgf-1 h248
Termination information:
```

```
ip/4/vif-0/2 {
    MEDIA {
        TERMINATIONSTATE { SERVICESTATES = INSERVICE },
        STREAM = 1 {
            LOCALCONTROL { MODE = SENDRECEIVE,
                DS/DSCP = 00,
                TMAN/MBS = 10,
                TMAN/PDR = 0,
                TMAN/POL = ON,
                TMAN/SDR = 1000,
                MGCINFO/DB = 00,
                GM/RSB = ON,
                GM/SAF = ON,
                GM/SAM = "[42.0.3.11]",
                GM/SPF = OFF,
```

```

                                GM/ESAS = OFF,
                                GM/ESPS = OFF },

                                LOCAL {
v=0
c=IN IP4 40.1.1.100
m=- 1024 rtp/avp -
b=AS:0
                                },
                                REMOTE {
v=0
c=IN IP4 42.0.3.11
m=- 10000 rtp/avp -
b=AS:0
                                }
                                }
                                },
                                SIGNALS { IPNAPT/LATCH { STREAM = 1, NAPT = OFF, NOTIFYCOMPLETION = { TIMEOUT
} } },
                                EVENTS { HANGTERM/THB { TIMERX= 30 } }

                                }

Termination information:
ip/4/vif-0/2 {
    MEDIA {
        TERMINATIONSTATE { SERVICESTATES = INSERVICE },
        STREAM = 1 {
            LOCALCONTROL { MODE = SENDRECEIVE,
                                DS/DSCP = 00,
                                TMAN/MBS = 10,
                                TMAN/PDR = 0,
                                TMAN/POL = ON,
                                TMAN/SDR = 1000,
                                MGCINFO/DB = 00,
                                GM/RSB = ON,
                                GM/SAF = ON,
                                GM/SAM = "[42.0.3.11]",
                                GM/SPF = OFF,
                                GM/ESAS = OFF,
                                GM/ESPS = OFF },

                                LOCAL {
v=0
c=IN IP4 40.1.1.100
m=- 1024 rtp/avp -
b=AS:0
                                },
                                REMOTE {
v=0
c=IN IP4 42.0.3.11
m=- 10000 rtp/avp -
b=AS:0
                                }
                                }
                                },
                                SIGNALS { IPNAPT/LATCH { STREAM = 1, NAPT = OFF, NOTIFYCOMPLETION = { TIMEOUT
} } }.
                                EVENTS { HANGTERM/THB { TIMERX= 30 } }

                                }

```



```

show services pgcp terminations brief gateway bgf-1 termination-prefix ip/4/vif-0/2
Virtual BGF configuration:
Name : bgf-1
IP address : 10.50.10.100
Port : 2944
Status : Connected

Termination name      State      Duration(msecs)
ip/4/vif-0/2          In-service 42068
Gate-id               Direction State      Action
184683659520          A->B      active    forward
184683659521          B->A      active    forward

show services pgcp terminations h248 gateway bgf-1 termination-prefix ip/4/vif-0/2
Termination information:
ip/4/vif-0/2 {
  MEDIA {
    TERMINATIONSTATE { SERVICESTATES = INSERVICE },
    STREAM = 1 {
      LOCALCONTROL { MODE = SENDRECEIVE,
        DS/DSCP = 00,
        TMAN/MBS = 10,
        TMAN/PDR = 0,
        TMAN/POL = ON,
        TMAN/SDR = 1000,
        MGCINFO/DB = 00,
        GM/RSB = ON,
        GM/SAF = ON,
        GM/SAM = "[42.0.3.11]",
        GM/SPF = OFF,
        GM/ESAS = OFF,
        GM/ESPS = OFF },
      LOCAL {
        v=0
        c=IN IP4 40.1.1.100
        m=- 1024 rtp/avp -
        b=AS:0
      },
      REMOTE {
        v=0
        c=IN IP4 42.0.3.11
        m=- 10000 rtp/avp -
        b=AS:0
      }
    },
    SIGNALS { IPNAPT/LATCH { STREAM = 1, NAPT = OFF, NOTIFYCOMPLETION = { TIMEOUT
    } } },
    EVENTS { HANGTERM/THB { TIMERX= 30 } }
  }
}

```


PTSP Operational Mode Commands

Table 328 on page 1747 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot the packet-triggered subscribers and policy control (PTSP) services. Commands are listed in alphabetical order.

Table 328: PTSP Operational Mode Commands

Task	Command
Clear the packet-triggered subscriber session and log out the specified subscriber.	clear services subscriber sessions
Display bandwidth information about the packet-triggered subscribers.	show services subscriber bandwidth
Display information about the active dynamic policies applied to the specific subscribers.	show services subscriber dynamic-policies
Display information about the data flows associated with the specific subscriber.	show services subscriber flows
Display information about the active packet-triggered subscriber sessions on the router.	show services subscriber sessions
Display information about the data traffic statistics for the specified packet-triggered subscriber and for each service rule attached to that subscriber.	show services subscriber statistics



NOTE: PTSP services are supported on the MultiServices Dense Port Concentrator (MS-DCP) on the MX Series routers.



NOTE: For information about how to configure the PTSP services, see the *Junos OS Subscriber Access Configuration Guide*.

clear services subscriber sessions

Syntax	<code>clear services subscriber sessions client-id <i>client-id</i></code>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Clear the packet-triggered subscriber sessions on the router to log out the subscribers.
Options	<code>client-id <i>client-id</i></code> —Logs out the packet-triggered subscriber with this client ID. The client ID is a generated identifier assigned to each packet-triggered subscriber known to the router.
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none">• show services subscriber sessions on page 1756
List of Sample Output	clear services subscriber sessions on page 1748
Output Fields	When you issue this command, you are provided feedback on the status of your request.

Sample Output

<code>clear services subscriber sessions</code>	<pre>user@host> clear services subscriber sessions client-id 1 Initiated logout request for 1 subscriber session(s)</pre>
---	--

show services subscriber bandwidth

Syntax	<pre>show services subscriber bandwidth <client-id <i>client-id</i>> <interface <i>interface-name</i>> <top-talkers <i>top-talkers</i>> <ip-address <i>ip-address</i>> <service-interface <i>interface-name</i>> <top-talkers <i>top-talkers</i>></pre>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display bandwidth information about subscribers with the specified criteria. The bandwidth is computed at fixed intervals on the MS-DPC and only the last interval is used for comparison.
Options	<p>client-id <i>client-id</i>—(Optional) Displays bandwidth information for the subscriber with this client ID. The client ID is a generated identifier assigned to each packet-triggered subscriber known to the router.</p> <p>interface <i>interface-name</i>—(Optional) Displays bandwidth information for the subscriber with this underlying interface name.</p> <p>ip-address <i>ip-address</i>—(Optional) Displays bandwidth information for the subscriber with this IPv4 address.</p> <p>service-interface <i>interface-name</i>—(Optional) Displays bandwidth information for the subscriber with this service interface name.</p> <p>top-talkers <i>number-top-talkers</i>—(Optional) Displays bandwidth information for the specified number of subscribers using the most bandwidth based on the input-bps or output-bps values for the interface or service interface.</p>
Required Privilege Level	view
List of Sample Output	show services subscriber bandwidth client-id on page 1750
Output Fields	Table 329 on page 1749 lists the output fields for the show services subscriber bandwidth command. Output fields are listed in the approximate order in which they appear.

Table 329: show services subscriber bandwidth Output Fields

Field Name	Field Description
client-id	Client identifier.
input-bps	Ingress bandwidth in bytes per second.
output-bps	Egress bandwidth in bytes per second.
input-pps	Ingress bandwidth in packets per second.
output-pps	Egress bandwidth in packets per second.

Sample Output

```
show services subscriber bandwidth client-id 1
subscriber bandwidth client-id
client-id      input-bps      output-bps      input-pps      output-pps
1              20             20             1000          1000
```

show services subscriber dynamic-policies

Syntax	show services subscriber dynamic-policies client-id <i>client-id</i>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display information about the active dynamic policies applied to the specified subscriber.
Options	client-id <i>client-id</i> —Displays information about the active dynamic policies applied to the subscriber with this client ID. The client ID is a generated identifier assigned to each packet-triggered subscriber known to the router.
Required Privilege Level	view
List of Sample Output	show services subscriber dynamic-policies client-id on page 1752
Output Fields	Table 330 on page 1751 lists the output fields for the show services subscriber dynamic-policies command. Output fields are listed in the approximate order in which they appear.

Table 330: show services subscriber dynamic-policies Output Fields

Field Name	Field Description
Subscriber session	Client identifier.
Policy name	Dynamic policy identifier.
rpr	Rule precedence for the dynamic policy.
d	Direction of the dynamic policy.
Template	Service rule associated with the dynamic policy.
tpr	Term precedence.
ra	Remote address.
rm	Remote address mask.
lpl	Lower boundary for the local port range.
lph	Upper boundary for the local port range.
rpl	Lower boundary for the remote port range.
rph	Upper boundary for the remote port range.
p	Protocol.

Table 330: show services subscriber dynamic-policies Output Fields (*continued*)

Field Name	Field Description
a-f	Action.
a-s	Type of statistics collection and aggregation.
a-fc	Forwarding class.
a-p-l	Policer instance.
a-p-bw	Policer bandwidth.
a-p-mbs	Policer maximum burst size.
a-fu	Unit number for forwarding instance.
anl	Application names.
agl	Application group name.

Sample Output

```

show services subscriber dynamic-policies client-id
user@host> show services subscriber dynamic-policies client-id 1
Subscriber session 1 policy
Policy name: 1311465998724890695
rpr: 200
d: input-output
  Template: __svc_rule__
  tpr: 100
  ra: 0.0.0.0
  rm: 0
  lpl: 0
  lph: 65535
  rpl: 0
  rph: 65535
  p: 0
  a-f: accept forwarding-class
  a-s:
  a-fc: assured-forwarding
  a-p-i: 0
  a-p-bw: 0
  a-p-mbs: 0
  a-fu: 0
  anl: junos:http
  agl: junos:web
  Template: __svc_rule__
  tpr: 100
  ra: 10.10.10.0
  rm: 0
  lpl: 0
  lph: 65535
  rpl: 0
  rph: 65535

```



```
p: 0
a-f: accept
a-s:
a-fc:
a-p-i: 0
a-p-bw: 0
a-p-mbs: 0
a-fu: 0
anl:
agl:
```

show services subscriber flows

Syntax	show services subscriber flows client-id <i>client-id</i>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display information about the data flows associated with the specified subscriber.
Options	client-id <i>client-id</i> —Displays information about the data flows associated with the subscriber identified by this client ID. The client ID is a generated identifier assigned to each packet-triggered subscriber known to the router.
Required Privilege Level	view
List of Sample Output	show services subscriber flows client-id on page 1754
Output Fields	Table 331 on page 1754 lists the output fields for the show services subscriber flows command. Output fields are listed in the approximate order in which they appear.

Table 331: show services subscriber flows Output Fields

Field Name	Field Description
Subscriber session	Client identifier.
Number of data flows	Number of data sessions associated with this subscriber.
Data flow high-water-mark	High water mark number of concurrent data sessions for this subscriber. This value is never reset during the login session.
5-tuple	5 tuple information for each flow.
Application-ID	Application ID for each flow.
Policy-name	Service rule name for each flow.
Dir	Direction of each flow.
Packets	Information about counter statistics for each flow.
Bytes	Information about counter statistics for each flow.
Action	Action of the service rule for each flow.

Sample Output

```

show services subscriber flows client-id
user@host> show services subscriber flows client-id 1
Subscriber session 1
Number of data flows: 1
Data flows high-water-mark: 8180

```

5-tuple			Application-ID	Policy-name	Dir
80.1.1.2:45287->90.2.255.2:80,6			junos:http	ptsp-appl/23	I
Packets	Bytes	Action			
6	511	C-T			

show services subscriber sessions

Syntax	<pre>show services subscriber sessions <brief detail summary> <client-id <i>client-id</i>> <interface <i>interface-name</i>> <ip-address <i>ip-address</i>> <routing-instance <i>routing-instance-name</i>> <service-interface <i>interface-name</i>> <user-id <i>user-id</i>></pre>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display information about the active packet-triggered subscriber sessions on the router.
Options	<p>brief detail summary—(Optional) Display the specified level of output. The default level is brief.</p> <p>client-id <i>client-id</i>—(Optional) Displays information about the active packet-triggered subscriber sessions for this client ID. The client ID is a generated identifier assigned to each packet-triggered subscriber known to the router.</p> <p>interface <i>interface-name</i>—(Optional) Displays information about the active packet-triggered subscriber sessions for the subscriber with this underlying interface name.</p> <p>ip-address <i>ip-address</i>—(Optional) Displays information about the active packet-triggered subscriber sessions for the subscriber with this IP address.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Displays information about the active packet-triggered subscriber sessions for the subscriber on this routing instance.</p> <p>service-interface <i>interface-name</i>—(Optional) Displays information about the active packet-triggered subscriber sessions for the subscriber with this service interface name.</p> <p>user-id <i>user-id</i>—(Optional) Displays information about the active packet-triggered subscriber sessions with this user ID.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none">• clear services subscriber sessions on page 1748
List of Sample Output	<p>show services subscriber sessions client-id summary on page 1757</p> <p>show services subscriber sessions client-id on page 1757</p> <p>show services subscriber sessions client-id detail on page 1757</p>
Output Fields	Table 332 on page 1757 lists the output fields for the show services subscriber sessions command. Output fields are listed in the approximate order in which they appear.

Table 332: show services subscriber sessions Output Fields

Field Name	Field Description
Client-ID	Client identifier.
IP-address	IPv4 address.
Underlying-interface	Interface where services are applied.
User-name	Subscriber identifier.
Service interface name	Location of the MS-DPC on which the subscriber is instantiated.
Routing instance	Routing instance on which the subscriber is instantiated.
State	State of the subscriber.

Sample Output

```

show services subscriber sessions client-id summary
user@host> show services subscriber sessions client-id 1 summary
1

show services subscriber sessions client-id
user@host> show services subscriber sessions client-id 1
Client-ID      IP-address      Underlying-interface  User-name
1              80.1.1.2        ge-1/3/2.1           ip80.1.1.2@default

show services subscriber sessions client-id detail
user@host> show services subscriber sessions client-id 1 detail
Subscriber session 1
  User name: ip80.1.1.2@default
  Interface name: ge-1/3/2.1
  User IP address: 80.1.1.2
  Service interface name: ms-2/0/0
  Routing instance: default
  State: logged in
  Login time: Tue Dec 29 19:56:07 2009
  1 service session(s) instantiated:
  Service session 1323423760868442114 => State: activated

```

show services subscriber statistics

Syntax	show services subscriber statistics client-id <i>client-id</i>
Release Information	Command introduced in Junos OS Release 10.2.
Description	Display information about the data traffic statistics for the specified packet-triggered subscriber and for each service rule attached to that subscriber.
Options	client-id <i>client-id</i> —Displays information about the data traffic statistics associated with the subscriber identified by this client ID. The client ID is a generated identifier assigned to each packet-triggered subscriber known to the router.
Required Privilege Level	view
List of Sample Output	show services subscriber statistics client-id by rule on page 1758 show services subscriber statistics client-id by application on page 1758
Output Fields	Table 333 on page 1758 lists the output fields for the show services subscriber statistics command. Output fields are listed in the approximate order in which they appear.

Table 333: show services subscriber statistics Output Fields

Field Name	Field Description
Aggregation-level	Type of statistics collected — subscriber and service rule or application.
Name/Id	Identifier for Aggregation-level field.
Packets-in	Number of ingress packets.
Packets-out	Number of egress packets.
Bytes-in	Number of ingress bytes.
Bytes-out	Number of egress bytes.

Sample Output

```

show services subscriber statistics client-id by rule
user@host> show services subscriber statistics client-id 1
Aggregation-level Name/Id   Packets-in Packets-out Bytes-in Bytes-out
subscriber        1           5           5        1000    1000
dynamic rule      ptsp-rule   5           5        1000    1000

```

Sample Output

```

show services subscriber statistics client-id by application
user@host> show services subscriber statistics client-id 1

```

Aggregation-level	Name/Id	Packets-in	Packets-out	Bytes-in	Bytes-out
subscriber	1	4358118	3630087	371167451	3301658453
application group	any	4358118	3631768	371167451	3304179953

Service Sets Operational Mode Commands

Table 334 on page 1761 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot service sets. Commands are listed in alphabetical order.

Table 334: Service Sets Operational Mode Commands

Task	Command
Clear service sets dropped packet statistics.	clear services service-sets statistics packet-drops
Clear service sets syslog statistics.	clear services service-sets statistics syslog
Display service sets CPU utilization.	show services service-sets cpu-usage
Display services sets memory utilization.	show services service-sets memory-usage
Display plug-in information for service sets.	show services service-sets plug-ins
Display service sets dropped packet statistics.	show services service-sets statistics packet-drops
Display service sets syslog statistics.	show services service-sets statistics syslog
Display services sets TCP maximum segment size (MSS) statistics.	show services service-sets statistics tcp-mss
Display service sets summary information.	show services service-sets summary



.....

NOTE: Service sets are supported on the adaptive services interface on the following routers:

- J Series routers—*sp-pim/0/slot*
- M Series and T Series routers—*ms-fpc/pic/port* or *sp-fpc/pic/port*

Service sets are also supported on the redundant adaptive services interface (*rspnumber*) on M Series and T Series routers.



.....

NOTE: For information about how to configure service sets, see the *Junos OS Services Interfaces Configuration Guide*.

.....

clear services service-sets statistics packet-drops

Syntax	clear services service-sets statistics packet-drops <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 7.4.
Description	Clear dropped-packet statistics for one adaptive services interface or for all adaptive services interfaces.
Options	<p>none—Clear dropped-packet statistics for all configured adaptive services interfaces.</p> <p>interface <i>interface-name</i>—(Optional) Clear dropped-packet statistics for the specified adaptive services interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i>, <i>sp-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>sp-pim/0/port</i>.</p>
Required Privilege Level	network
Related Documentation	<ul style="list-style-type: none"> • show services service-sets statistics packet-drops on page 1771
List of Sample Output	clear services service-sets statistics packet-drops on page 1763
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```

clear services user@host> clear services service-sets statistics packet-drops interface sp-5/0/0
service-sets statistics Flow collector interface: cp-5/0/0
packet-drops      Interface state: Collecting flows
                  Statistics cleared successfully

```

clear services service-sets statistics syslog

Syntax	clear services service-sets statistics syslog <service-set <i>service-set-name</i> > <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 11.1.
Description	Clear system log statistics for one services interface or for all services interfaces, and for one named service set or all service sets on the interface or interfaces.
Options	<p>none—Clear system log for all configured services interfaces and their service sets.</p> <p>interface <i>interface-name</i>—(Optional) Clear system log statistics for the specified services interface. On M Series, MX Series, and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i>, <i>sp-fpc/pic/port</i>, or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>sp-pim/O/port</i>.</p> <p>service-set <i>service-set-name</i>—(Optional) Clear system log statistics for the specified services interface.</p>
Required Privilege Level	network
Related Documentation	<ul style="list-style-type: none">• show services service-sets statistics syslog on page 1773
List of Sample Output	clear services service-sets statistics syslog on page 1764
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

clear services	user@host> clear services service-sets statistics syslog interface sp-5/0/0
service-sets statistics	Flow collector interface: cp-5/0/0
syslog	Interface state: Collecting flows
	Statistics cleared successfully

show services service-sets cpu-usage

Syntax	show services service-sets cpu-usage <interface <i>interface-name</i> > <service-set <i>service-set-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display service set CPU usage as a percentage. The command is supported only on Adaptive Services PICs (SP PICs).
Options	<p>none—Display CPU usage for all adaptive services interfaces and service sets.</p> <p>interface <i>interface-name</i>—(Optional) Display CPU usage for a particular interface. On M Series and T Series routers, the <i>interface-name</i> parameter can have the value <i>sp-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, <i>interface-name</i> is <i>sp-pim/O/port</i>.</p> <p>service-set <i>service-set-name</i>—(Optional) Display CPU usage for a particular service set. For the Layer 2 Tunneling Protocol (L2TP), you can use a tunnel group to represent a service set.</p>
Required Privilege Level	view
List of Sample Output	show services service-sets cpu-usage on page 1765
Output Fields	Table 335 on page 1765 lists the output fields for the show services service-sets cpu-usage command. Output fields are listed in the approximate order in which they appear.

Table 335: show services service-sets cpu-usage Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface
Service set (system category)	Name of the CPU usage category: <ul style="list-style-type: none"> • idp_recommended—Name of the service sets (displays all the service sets attached to the service PICs) • Idle • System • Receive • Transmit
CPU utilization %	Percentage of the CPU resources being used

Sample Output

```

show services user@host> show services service-sets cpu-usage
service-sets cpu-usage
Interface      Service set (system category)      CPU utilization %
sp-4/1/0      idp_recommended                    18.20 %
sp-4/1/0      Idle                               44.69 %

```

sp-4/1/0	System	7.01 %
sp-4/1/0	Receive	15.10 %
sp-4/1/0	Transmit	15.00 %

show services service-sets memory-usage

Syntax show services service-sets memory-usage
 <interface *interface-name*>
 <service-set *service-set-name*>
 <zone>

Release Information Command introduced before Junos OS Release 7.4.

Description Display service set memory usage.

Options none—Display service set memory usage.

interface *interface-name*—(Optional) Display memory usage for a particular interface. On M Series and T Series routers, the *interface-name* can be *ms-fpc/pic/port*, *sp-fpc/pic/port*, or *rspnumber*. On J Series routers, the *interface-name* is *sp-pim/0/port*.



NOTE: This command is not supported on Multilink Protocol–based services PICs..

service-set *service-set-name*—(Optional) Display memory usage for a particular service set. For Layer 2 Tunneling Protocol (L2TP), you can use a tunnel group to represent a service set.

zone—(Optional) Display the memory usage zone of the adaptive services interface or an individual service set.

Required Privilege Level view

List of Sample Output show services service-sets memory-usage on page 1768
 show services service-sets memory-usage zone on page 1768
 show services service-sets memory-usage interface on page 1768

Output Fields Table 336 on page 1767 lists the output fields for the **show services service-sets memory-usage** command. Output fields are listed in the approximate order in which they appear.

Table 336: show services service-sets memory-usage Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface
Service set	Name of a service set
Bytes Used	Number of bytes of memory being used

Table 336: show services service-sets memory-usage Output Fields (*continued*)

Field Name	Field Description
Memory zone	<p>Memory zone in which the adaptive services interface is currently operating:</p> <ul style="list-style-type: none"> • Green—All new flows are allowed. • Yellow—Unused memory is reclaimed. All new flows are allowed. • Orange—New flows are allowed only for service sets that are using less than their equal share of memory. • Red—No new flows are allowed.

Sample Output

```

show services user@host> show services service-sets memory-usage
service-sets Interface Service set Bytes Used
memory-usage ms-4/0/0 N/A 14817036
ms-4/1/0 N/A 14691700

```

```

show services user@host> show services service-sets memory-usage zone
service-sets Interface Memory zone
memory-usage zone

```

```

show services user@host> show services service-sets memory-usage interface ms-4/1/0
service-sets Interface Service Set Bytes Used
memory-usage ms-4/1/0 N/A 14691700
interface

```


show services service-sets plug-ins

Syntax	show services service-sets plug-ins <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 9.5.
Description	Display plug-in information for service sets. The command is supported only on Multiservices PICs.
Options	none—Display plug-in information for all adaptive services interfaces. interface <i>interface-name</i> —(Optional) Display plug-in information for a particular interface. On M Series and T Series routers, <i>interface-name</i> can be <i>ms-fpc/pic/port</i> .
Required Privilege Level	view
List of Sample Output	show services service-sets plug-ins on page 1769 show services service-sets plug-ins interface on page 1770
Output Fields	Table 337 on page 1769 lists the output fields for the show services service-sets plug-ins command. Output fields are listed in the approximate order in which they appear.

Table 337: show services service-sets plug-ins Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface
Service set	Name of the configured service set
State	Status of the service set: <ul style="list-style-type: none"> Ready—Service set is active. Not Ready—Service set is either initialized with no policy set or policy is being added or deleted.
Plugins configured	Number of plug-ins configured
Plugin	Name of the configured plug-in
Plugin ID	ID of the configured plug-in

Sample Output

```

show services service-sets plug-ins user@host> show services service-sets plug-ins
Interface: ms-4/0/0
Service-set: IDP, State: Ready
Plugins configured: 5
Plugin: jnx-msvcs-tcp-tracker-plugin, ID: 4
Plugin: junos-msp-appid, ID: 0

```

```
Plugin: junos-msp-idp, ID: 1
Plugin: junos-msp-aac1, ID: 2
Plugin: junos-msp-llpdf, ID: 3
```

```
Interface: ms-4/1/0
Service-set: idp2, State: Ready
Plugins configured: 5
  Plugin: jnx-msvcs-tcp-tracker-plugin, ID: 4
  Plugin: junos-msp-appid, ID: 0
  Plugin: junos-msp-idp, ID: 1
  Plugin: junos-msp-aac1, ID: 2
  Plugin: junos-msp-llpdf, ID: 3
```

```
show services user@host> show services service-sets plug-ins interface ms-4/1/0
service-sets plug-ins
interface
  Interface: ms-4/1/0
  Service-set: idp2, State: Ready
  Plugins configured: 5
    Plugin: jnx-msvcs-tcp-tracker-plugin, ID: 4
    Plugin: junos-msp-appid, ID: 0
    Plugin: junos-msp-idp, ID: 1
    Plugin: junos-msp-aac1, ID: 2
    Plugin: junos-msp-llpdf, ID: 3
```

show services service-sets statistics packet-drops

Syntax	show services service-sets statistics packet-drops <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 7.4.
Description	Display the number of dropped packets for service sets exceeding CPU limits or memory limits.
Options	<p>none—Display the number of dropped service sets packets for all adaptive services interfaces.</p> <p>interface <i>interface-name</i>—(Optional) Display the number of dropped service sets packets for a particular interface. On M Series and T Series routers, <i>interface-name</i> can be <i>ms-fpc/pic/port</i>, <i>sp-fpc/pic/port</i>, or <i>rspnumber</i>. On J Series routers, <i>interface-name</i> is <i>sp-pim/0/port</i>.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear services flow-collector statistics on page 1484
List of Sample Output	show services service-sets statistics packet-drops interface on page 1771
Output Fields	Table 338 on page 1771 lists the output fields for the show services service-sets packet-drops command. Output fields are listed in the approximate order in which they appear.

Table 338: show services service-sets packet-drops Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of a service set.
CPU limit Drops	Number of packets dropped because the service set exceeded the average CPU limit.
Memory limit Drops	Number of packets dropped because the service set exceeded the memory limit.
Flow limit Drops	Number of packets dropped because the service set exceeded the flow limit.

Sample Output

```

show services service-sets statistics packet-drops interface
user@host> show services service-sets statistics packet-drops interface sp-1/0/0

```

Interface	Service Set	Cpu limit Drops	Memory limit Drops	Flow limit Drops
sp-1/0/0	sset1	0	0	0

show services service-sets statistics syslog

Syntax	show services service-sets statistics syslog <interface <i>interface-name</i> > <service-set <i>service-set-name</i> > <brief detail>
Release Information	Command introduced in Junos OS Release 11.1.
Description	Display the system log statistics with optional filtering by interface and service set name..
Options	<p>none—Display the system log statistics for all services interfaces and all service sets.</p> <p>brief—(Default) Display abbreviated system log statistics.</p> <p>detail—Display detailed system log statistics.</p> <p>interface <i>interface-name</i>—(Optional) Display the system log statistics for a specific adaptive service interface. On M Series and T Series routers, <i>interface-name</i> can be <i>ms-fpc/pic/port</i>, <i>sp-fpc/pic/port</i>, or <i>rspnumber</i>. On J Series routers, <i>interface-name</i> is <i>sp-pim/0/port</i>.</p> <p>service-set <i>service-set name</i>—(Optional) Display the system log statistics for a specific named service-set.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear services service-sets statistics syslog on page 1764
List of Sample Output	<p>show services service-sets statistics syslog brief on page 1774</p> <p>show services service-sets statistics syslog detail on page 1774</p>
Output Fields	Table 339 on page 1773 lists the output fields for the show services service-sets statistics syslog command. Output fields are listed in the approximate order in which they appear.

Table 339: show services service-sets statistics syslog Output Fields

Field Name	Field Description	Level
Interface	Name of a services interface.	all
Message rate limit	Maximum number of messages per second written to the interface's system log.	all
Service set	Name of a service set.	all
Messages sent	Number of messages sent.	brief
Messages dropped	Number of messages dropped.	brief

Table 339: show services service-sets statistics syslog Output Fields (*continued*)

Field Name	Field Description	Level
<i>class name</i>	<p>Logs created for events for each of the following classes:</p> <ul style="list-style-type: none"> • Session open logs • Session close logs • Packet logs • Stateful firewall logs • ALG logs • NAT logs • IDS logs • All other logs <p>The following information is displayed for system log messages for each class of event that is logged:</p> <ul style="list-style-type: none"> • Messages sent—Number of messages sent for session open events. • Messages dropped—Number of messages dropped for session open events. Counts are given for these drop reasons: <ul style="list-style-type: none"> • low priority—The priority of the message was too low for the message to be sent. • no class set—Specific classes of event messages were configured and this class was not selected. • above rate limit—The maximum number of system log messages per second was exceeded. 	detail

Sample Output

```

show services user@host> show services service-sets statistics syslog brief
service-sets statistics
syslog brief
Interface: sp-1/1/0
  Message rate limit: 200000
  Service-set: sset-sfw-sp1
    Messages sent: 20
    Messages dropped: 3488
  Service-set: sset-nat-sp1
    Messages sent: 18
    Messages dropped: 91
Interface: sp-1/2/0
  Message rate limit: 15000
  Service-set: sset-sfw-sp2
    Messages sent: 210
    Messages dropped: 579

```

Sample Output

```

show services user@host> show services service-sets statistics syslog detail
service-sets statistics
syslog detail
Interface: sp-1/2/0
  Message rate limit: 10
  Service-set: sset-sfw
    Messages sent: 0
    Messages dropped: 1600
  Session open logs:
    Sent: 0

```

```
    Dropped: 1277 (low priority: 1277, no class set: 0, above rate limit: 0)
Session close logs:
    Sent: 0
    Dropped: 0 (low priority: 0, no class set: 0, above rate limit: 0)
Packet logs:
    Sent: 0
    Dropped: 323 (low priority: 323, no class set: 0, above rate limit: 0)
Stateful firewall logs:
    Sent: 0
    Dropped: 0 (low priority: 0, no class set: 0, above rate limit: 0)
ALG logs:
    Sent: 0
    Dropped: 0 (low priority: 0, no class set: 0, above rate limit: 0)
NAT logs:
    Sent: 0
    Dropped: 0 (low priority: 0, no class set: 0, above rate limit: 0)
IDS logs:
    Sent: 0
    Dropped: 0 (low priority: 0, no class set: 0, above rate limit: 0)
Other logs:
    Sent: 0
    Dropped: 0 (low priority: 0, no class set: 0, above rate limit: 0)
```

show services service-sets statistics tcp-mss

Syntax	show services service-sets statistics tcp-mss <interface <i>interface-name</i> >
Release Information	Command introduced in Junos OS Release 9.5.
Description	(M Series and T Series routers only) Display TCP maximum segment size (MSS) statistics for service sets.
Options	none—Display service set TCP MSS information for all adaptive services interfaces. interface <i>interface-name</i> —(Optional) Display TCP MSS statistics for a particular interface. The <i>interface-name</i> can be <i>ms-fpc/pic/port</i> , <i>sp-fpc/pic/port</i> , or <i>rsp number</i> .
Required Privilege Level	view
List of Sample Output	show services service-sets statistics tcp-mss on page 1776
Output Fields	Table 340 on page 1776 lists the output fields for the show services service-sets statistics tcp-mss command. Output fields are listed in the approximate order in which they appear.

Table 340: show services service-sets statistics tcp-mss Output Fields

Field Name	Field Description
Interface	Name of the adaptive services interface.
Service Set	Name of the configured service set.
SYN Received	Number of TCP SYN packets received.
SYN Modified	Number of TCP SYN packets with the MSS value modified to match the MSS value specified in the TCP MSS configuration.

Sample Output

```

show services user@host> show services service-sets statistics tcp-mss
service-sets statistics
tcp-mss      Interface  Service Set      SYN Received  SYN Modified
              sp-1/2/0    asq_ipsec_svc_0      500           220

```


show services service-sets summary

Syntax	show services service-sets summary <interface <i>interface-name</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display service set summary information.
Options	none—Display service set summary information for all adaptive services interfaces. interface <i>interface-name</i> —(Optional) Display service set summary information for a particular interface. On M Series and T Series routers, <i>interface-name</i> can be <i>ms-fpc/pic/port</i> , <i>sp-fpc/pic/port</i> , or <i>rspnumber</i> . On J Series routers, <i>interface-name</i> is <i>sp-pim/O/port</i> .
Required Privilege Level	view
List of Sample Output	show services service-sets summary on page 1777 show services service-sets summary interface on page 1778
Output Fields	Table 341 on page 1777 lists the output fields for the show services service-sets summary command. Output fields are listed in the approximate order in which they appear.

Table 341: show services service-sets summary Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface
Service type	Type of adaptive service, such as stateful firewall (SFW), Network Address Translation (NAT), intrusion detection service (IDS), Layer 2 Tunneling Protocol (L2TP), Compressed Real-Time Transport Protocol (CRTP), or IP Security (IPsec)
Service sets configured	Total number of service sets configured on the PIC that use internal service set IDs and do not consume external service sets, including CRTP and L2TP
Bytes used	Bytes used by a particular service or all services
Policy bytes used	Policy bytes used by a particular service or all services
CPU utilization	Percentage of the CPU resources being used

Sample Output

show services service-sets summary	user@host> show services service-sets summary				
	Service sets		CPU		
	Interface	configured	Bytes used	Policy bytes used	utilization

ms-4/0/0	1	14821556 (4.53 %)	855124 (0.40 %)	N/A
ms-4/1/0	1	14691700 (4.49 %)	855068 (0.40 %)	N/A

show services
service-sets summary
interface

user@host> show services service-sets summary interface sp-1/3/0
Interface: sp-1/3/0

Service type	Service sets configured	Bytes used	CPU utilization
SFW/NAT/IDS	1	54 (0.00 %)	N/A
L2TP	1	58 (0.00 %)	N/A
CRTP	1	58 (0.00 %)	N/A
System	0	920831 (0.44 %)	N/A
Idle	0	0 (0.00 %)	N/A
Total	3	921001 (0.44 %)	N/A

Softwire Operational Mode Commands

Table 342 on page 1779 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot softwire services. Commands are listed in alphabetical order.

Table 342: Softwire Operational Mode Commands

Task	Command
Clear softwire statistics	clear services softwire statistics
Show softwire information	show services softwire

clear services software statistics

Syntax	<code>clear services software statistics</code> <code><interface <i>interface-name</i>></code>
Release Information	Command introduced in Junos OS Release 10.4.
Description	Clear software statistics.
Options	<code>interface <i>interface-name</i></code> — (Optional) Name of the interface servicing the software. When you omit this option, data for all interfaces are cleared.
Required Privilege Level	view
List of Sample Output	clear services software statistics on page 1780
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

<code>clear services software statistics</code>	<code>user@host> clear services software statistics</code>
---	---

show services software

Syntax	<count>
Release Information	Command introduced in JUNOS Release 10.4.
Description	Display information about software services. Information is displayed of both 6rd and DS-Lite services.
Options	count <i>interface-name</i> —(Optional) Display the current software counts for a service set for both DS-Lite and 6rd.
Required Privilege Level	view
List of Sample Output	show services software on page 1781 show services software count on page 1781
Output Fields	Table 343 on page 1781 lists the output fields for the command-name command. Output fields are listed in the approximate order in which they appear.

Table 343: show-services-software Output Fields

Field Name	Field Description	Level of Output
Interface	Interface for which information is displayed.	All levels
Service Set	Service set containing the software rules for the interface.	All levels
Software	Name of the software concentrator.	All levels
Direction	Direction of the flow.	All levels
Flow count	Number of flows.	All levels

Sample Output

```

show services software  user@host> show services software
                        Interface: sp-3/0/0, Service set: v6rd-dom1-dom3-service-set
                        Software
                        10.10.10.2      ->      30.30.30.1      Direction      Flow count
                                           I                      13

show services software  user@host> show services software count
count                  Interface  Service set      DS-Lite      6RD
                        sp-0/0/0  dslite-svc-set1  2            0

```


Stateful Firewall Operational Mode Commands

Table 344 on page 1783 summarizes the command-line interface (CLI) commands you can use to monitor and troubleshoot stateful firewall services. Commands are listed in alphabetical order.

Table 344: Stateful Firewall Services Operational Mode Commands

Task	Command
Clear stateful firewall flows.	<code>clear services stateful-firewall flows</code>
Clear stateful firewall Session Initiation Protocol (SIP) call information.	<code>clear services stateful-firewall sip-call</code>
Clear stateful firewall SIP register information.	<code>clear services stateful-firewall sip-register</code>
Clear stateful firewall statistics.	<code>clear services stateful-firewall statistics</code>
Display stateful firewall conversation information.	<code>show services stateful-firewall conversations</code>
Display stateful firewall flow information.	<code>show services stateful-firewall flows</code>
Display stateful firewall SIP call information.	<code>show services stateful-firewall sip-call</code>
Display stateful firewall SIP register information.	<code>show services stateful-firewall sip-register</code>
Display stateful firewall statistics.	<code>show services stateful-firewall statistics</code>
Display statistics information for the application protocol SIP.	<code>show services stateful-firewall statistics application-protocol sip</code>



.....

NOTE: Stateful firewall services are supported on the adaptive services interface on the following routers:

- J Series routers—*sp-pim/0/slot*
- M Series and T Series routers—*ms-fpc/pic/port*, or *sp-fpc/pic/port*

Stateful firewall services are also supported on the redundant adaptive services interface (*rspnumber*) on M Series and T Series routers. For information about how to configure stateful firewall services, see the [Junos OS Services Interfaces Configuration Guide](#).

.....

clear services stateful-firewall flows

Syntax	<pre>clear services stateful-firewall flows <application-protocol <i>protocol</i>> <destination-port <i>destination-port</i>> <destination-prefix <i>destination-prefix</i>> <interface <i>interface-name</i>> <protocol <i>protocol</i>> <service-set <i>service-set</i>> <source-port <i>source-port</i>> <source-prefix <i>source-prefix</i>></pre>
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear stateful firewall flows.
Options	<p>none—Clear all stateful firewall flows.</p> <p><i>destination-port destination-port</i>—(Optional) Clear stateful firewall flows for a particular destination port. The range of values is 0 to 65535.</p> <p><i>destination-prefix destination-prefix</i>—(Optional) Clear stateful firewall flows for a particular destination prefix.</p> <p><i>interface interface-name</i>—(Optional) Clear stateful firewall flows for a particular interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>ms-pim/0/port</i>.</p> <p><i>protocol</i>—(Optional) Clear stateful firewall flows for one of the following IP types:</p> <ul style="list-style-type: none"> • <i>number</i>—Numeric protocol value from 0 to 255. • <i>ah</i>—IPsec Authentication Header protocol • <i>egp</i>—An exterior gateway protocol • <i>esp</i>—IPsec Encapsulating Security Payload protocol • <i>gre</i>—A generic routing encapsulation protocol • <i>icmp</i>—Internet Control Message Protocol • <i>igmp</i>—Internet Group Management Protocol • <i>ipip</i>—IP-over-IP Encapsulation Protocol • <i>ospf</i>—Open Shortest Path First protocol • <i>pim</i>—Protocol Independent Multicast protocol • <i>rsvp</i>—Resource Reservation Protocol • <i>sctp</i>—Stream Control Protocol • <i>tcp</i>—Transmission Control Protocol • <i>udp</i>—User Datagram Protocol

`service-set service-set`—(Optional) Clear stateful firewall flows for a particular service set.

`source-port source-port`—(Optional) Clear stateful firewall flows for a particular source port. The range of values is from 0 through 65535.

`source-prefix source-prefix`—(Optional) Clear stateful firewall flows for a particular source prefix.

Required Privilege Level view

Related Documentation • [show services stateful-firewall flows on page 1798](#)

List of Sample Output [clear services stateful-firewall flows on page 1786](#)

Output Fields Table 345 on page 1786 lists the output fields for the **clear services stateful-firewall flows** command. Output fields are listed in the approximate order in which they appear.

Table 345: clear services stateful-firewall flows Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of the service set from which flows are being cleared.
Conv removed	Number of conversations removed.

Sample Output

```

clear services stateful-firewall flows user@host> clear services stateful-firewall flows
Interface  Service set                               Conv removed
ms-0/3/0   svc_set_trust                             0
ms-0/3/0   svc_set_untrust                           0

```

clear services stateful-firewall sip-call

Syntax	<pre>clear services stateful-firewall sip-call <application-protocol <i>protocol</i>> <destination-port <i>destination-port</i>> <destination-prefix <i>destination-prefix</i>> <interface <i>interface-name</i>> <protocol <i>protocol</i>> <service-set <i>service-set</i>> <source-port <i>source-port</i>> <source-prefix <i>source-prefix</i>></pre>
Release Information	Command introduced in Junos OS Release 7.4.
Description	Clear Session Initiation Protocol (SIP) call information in stateful firewall flows.
Options	<p>none—Clear stateful firewall statistics for all interfaces and all service sets.</p> <p>application-protocol—(Optional) Clear information about one of the following application protocols:</p> <ul style="list-style-type: none"> • bootp—(SIP only) Bootstrap protocol • dce-rpc—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols • dce-rpc-portmap—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols portmap service • dns—(SIP only) Domain Name System protocol • exec—(SIP only) Exec • ftp—(SIP only) File Transfer Protocol • h323—H.323 standards • icmp—Internet Control Message Protocol • iiop—Internet Inter-ORB Protocol • login—Login • netbios—NetBIOS • netshow—NetShow • realaudio—RealAudio • rpc—Remote Procedure Call protocol • rpc-portmap—Remote Procedure Call protocol portmap service • rtsp—Real-Time Streaming Protocol • shell—Shell • sip—Session Initiation Protocol

- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

destination-port *destination-port*—(Optional) Clear information for a particular destination port. The range of values is 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Clear information for a particular destination prefix.

interface *interface-name*—(Optional) Clear information for a particular adaptive services interface. On M Series and T Series routers, the *interface-name* can be **sp-fpc/pic/port** or **rspnumber**. On J Series routers, the *interface-name* is **sp-pim/0/port**.

protocol—(Optional) Clear information about one of the following IP types:

- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ipv6**—IPv6 within IP
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Clear information for a particular service set.

source-port *source-port*—(Optional) Clear information for a particular source port. The range of values is 0 to 65535.

source-prefix *source-prefix*—(Optional) Clear information for a particular source prefix.

Required Privilege Level view

Related Documentation

- [show services stateful-firewall sip-call on page 1803](#)

List of Sample Output

[clear services stateful-firewall sip-call on page 1789](#)

Output Fields

Table 346 on page 1789 lists the output fields for the `clear services stateful-firewall sip-call` command. Output fields are listed in the approximate order in which they appear.

Table 346: clear services stateful-firewall sip-call Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of the service set from which flows are being cleared.
SIP calls removed	Number of SIP calls removed.

Sample Output

`clear services stateful-firewall sip-call`

```
user@host> clear services stateful-firewall sip-call
Interface  Service set      SIP calls removed
sp-0/3/0   test_sip_777     1
```

clear services stateful-firewall sip-register

Syntax clear services stateful-firewall sip-register
 <application-protocol *protocol*>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <interface *interface-name*>
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>

Release Information Command introduced in Junos OS Release 7.4.

Description Clear Session Initiation Protocol (SIP) register information in stateful firewall flows.

Options application-protocol—(Optional) Clear information about one of the following application protocols:

- **bootp**—(SIP only) Bootstrap protocol
- **dce-rpc**—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols
- **dce-rpc-portmap**—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols portmap service
- **dns**—(SIP only) Domain Name System protocol
- **exec**—(SIP only) Exec
- **ftp**—(SIP only) File Transfer Protocol
- **h323**—H.323 standards
- **icmp**—Internet Control Message Protocol
- **iiop**—Internet Inter-ORB Protocol
- **login**—Login
- **netbios**—NetBIOS
- **netshow**—NetShow
- **realaudio**—RealAudio
- **rpc**—Remote Procedure Call protocol
- **rpc-portmap**—Remote Procedure Call protocol portmap service
- **rtsp**—Real-Time Streaming Protocol
- **shell**—Shell
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet

- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

destination-port *destination-port*—(Optional) Clear information for a particular destination port. The range of values is 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Clear information for a particular destination prefix.

interface *interface*—(Optional) Clear information about a particular interface. On M Series and T Series routers, the *interface-name* can be **sp-fpc/pic/port** or **rspnumber**. On the J Series routers, the *interface-name* is **sp-pim/O/port**.

protocol—(Optional) Clear information about one of the following IP types:

- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ipv6**—IPv6 within IP
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Clear information for a particular service set.

source-port *source-port*—(Optional) Clear information for a particular source port. The range of values is 0 through 65535.

source-prefix *source-prefix*—(Optional) Clear information for a particular source prefix.

Required Privilege Level view

Related Documentation • [show services stateful-firewall sip-register on page 1808](#)

List of Sample Output **clear services stateful-firewall sip-register** on page 1792

Output Fields Table 347 on page 1792 lists the output fields for the **clear services stateful-firewall sip-register** command. Output fields are listed in the approximate order in which they appear.

Table 347: clear services stateful-firewall sip-register Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of the service set from which flows are being cleared.
SIP registration removed	Number of SIP registers removed.

Sample Output

clear services

stateful-firewall

sip-register

user@host>

clear services stateful-firewall sip-register

Interface Service set

sp-0/3/0 test_sip_777

SIP registration removed

1

clear services stateful-firewall statistics

Syntax	clear services stateful-firewall statistics <interface <i>interface-name</i> > <service-set <i>service-set</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Clear stateful firewall statistics.
Options	<p>none—Clear stateful firewall statistics for all interfaces and all service sets.</p> <p>interface <i>interface-name</i>—(Optional) Clear stateful firewall statistics for the specified interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>ms-pim/0/port</i>.</p> <p>service-set <i>service-set</i>—(Optional) Clear stateful firewall statistics for the specified service set.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show services stateful-firewall statistics on page 1812
List of Sample Output	clear services stateful-firewall statistics on page 1793
Output Fields	When you enter this command, you are provided feedback on the status of your request.

Sample Output

```
clear services stateful-firewall statistics
user@host> clear services stateful-firewall statistics
```

show services stateful-firewall conversations

Syntax show services stateful-firewall conversations
 <brief | extensive | terse>
 <application-protocol *protocol*>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <interface *interface-name*>
 <limit *number*>
 <pgcp>
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>

Release Information Command introduced before Junos OS Release 7.4.
 pgcp option introduced in Junos OS Release 8.4.

Description Display information about stateful firewall conversations.

Options none—Display standard information about all stateful firewall conversations.

 brief | extensive | terse—(Optional) Display the specified level of output.

 application-protocol *protocol*—(Optional) Display information about one of the following application protocols:

- **bootp**—Bootstrap protocol
- **dce-rpc**—Distributed Computing Environment-Remote Procedure Call protocols
- **dce-rpc-portmap**—Distributed Computing Environment-Remote Procedure Call protocols portmap service
- **dns**—Domain Name System protocol
- **exec**—Exec
- **ftp**—File Transfer Protocol
- **h323**—H.323 standards
- **icmp**—Internet Control Message Protocol
- **iiop**—Internet Inter-ORB Protocol
- **login**—Login
- **netbios**—NetBIOS
- **netshow**—NetShow
- **realaudio**—RealAudio
- **rpc**—Remote Procedure Call protocol
- **rpc-portmap**—Remote Procedure Call protocol portmap service
- **rtsp**—Real-Time Streaming Protocol

- **shell**—Shell
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

destination-port *destination-port*—(Optional) Display information for a particular destination port. The range of values is 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Display information for a particular destination prefix.

interface *interface-name*—(Optional) Display information about a particular interface. On M Series and T Series routers, the *interface-name* can be *sp-fpc/pic/port* or *rspnumber*. On J Series routers, the *interface-name* is *sp-pim/0/port*.

limit *number*—(Optional) Maximum number of entries to display.

pgcp —(Optional) Display information about stateful firewall conversations for Packet Gateway Control Protocol (PGCP) flows.

protocol *protocol*—(Optional) Display information about one of the following IP types:

- **number**—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Display information for the specific service set.

source-port *source-port*—(Optional) Display information for a particular source port. The range of values is 0 to 65535.

source-prefix *source-prefix*—(Optional) Display information for a particular source prefix.

Required Privilege Level view

List of Sample Output **show services stateful-firewall conversations on page 1797**
show services stateful-firewall conversations destination-port on page 1797

Output Fields Table 348 on page 1796 lists the output fields for the **show services stateful-firewall conversations** command. Output fields are listed in the approximate order in which they appear.

Table 348: show services stateful-firewall conversations Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of a service set. Individual empty service sets are not displayed, but if no service set has any flows, a flow table header is printed for each service set.
Conversation	Information about a group of related flows. <ul style="list-style-type: none"> • ALG Protocol—Application-level gateway protocol. • Number of initiators—Number of flows that initiated a session. • Number of responders—Number of flows that responded in a session.
Flow or Flow Prot	Protocol used for this flow.
Source	Source prefix of the flow, in the format <i>source-prefix-port</i> .
Destination	Destination prefix of the flow.
State	Status of the flow: <ul style="list-style-type: none"> • Drop—Drop all packets in the flow without response. • Forward—Forward the packet in the flow without looking at it. • Reject—Drop all packets in the flow with response. • Watch—Inspect packets in the flow.
Dir	Direction of the flow: input (I) or output (O).
Source NAT	Original and translated source IPv4 or IPv6 addresses are displayed if Network Address Translation (NAT) is configured on this particular flow or conversation.
Frm Count	Number of frames in the flow.
Destin NAT	Original and translated destination IPv4 or IPv6 addresses are displayed if NAT is configured on this particular flow or conversation.

Table 348: show services stateful-firewall conversations Output Fields (*continued*)

Field Name	Field Description
Byte count	Number of bytes forwarded in the flow.
TCP established	Whether a TCP connection was established: Yes or No .
TCP window size	Negotiated TCP connection window size, in bytes.
TCP acknowledge	TCP acknowledgment sequence number.
TCP tickle	Whether TCP inquiry mode is on (enabled or disabled) and the time remaining to send the next inquiry, in seconds.
Master flow	Flow that initiated the conversation.
Timeout	Lifetime of the flow, in seconds.

Sample Output

```

show services stateful-firewall conversations
user@host> show services stateful-firewall conversations
Interface: sp-1/3/0, Service set: green
Conversation: ALG Protocol: any, Number of initiators: 1,
Number of responders: 1

Flow
Prot    Source                Dest                State    Dir    Frm count
TCP     10.58.255.50:33005->  10.58.255.178:23   Forward  I      13
      Source NAT    10.58.255.50:33005->  10.59.16.100:4000
      Destin NAT    10.58.255.178:23 ->  0.0.0.0:4000
Byte count:          918
TCP established, TCP window size: 65535, TCP acknowledge: 2502627025
TCP tickle enabled, 0 seconds,
Master flow, Timeout: 30 seconds
TCP     10.58.255.178:23 ->  10.59.16.100:4000 Forward  0      8

show services stateful-firewall conversations destination-port 21
user@host> show services stateful-firewall conversations destination-port 21
Interface: sp-0/3/0, Service set: svc_set_trust

Interface: sp-0/3/0, Service set: svc_set_untrust
Conversation: ALG protocol: ftp
Number of initiators: 1, Number of responders: 1
Flow
TCP     10.50.10.2:2143 ->  10.50.20.2:21      Watch  0      0
TCP     10.50.20.2:21 ->  10.50.10.2:2143    Watch  I      0
TCP     10.50.20.2:21 ->  10.50.10.2:2143    Watch  I      0

```

show services stateful-firewall flows

Syntax show services stateful-firewall flows
 <brief | extensive | summary | terse>
 <application-protocol *protocol*>
 <count>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <interface *interface-name*>
 <limit *number*>
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>

Release Information Command introduced before Junos OS Release 7.4.
pgcp option introduced in Junos OS Release 8.4.
application-protocol option introduced in Junos OS Release 10.4.

Description Display stateful firewall flow table entries. When the interface is used for software processing, the type of software concentrator (**DS-LITE** or **6rd**) is shown, and frame counts are provided.

Options none—Display standard information about all stateful firewall flows.

brief | extensive | summary | terse—(Optional) Display the specified level of output.

application-protocol *application-protocol*—(Optional) Display information about one of the following application-level gateway (ALG) protocol types:

- **bootp**—Bootstrap protocol
- **dce-rpc**—Distributed Computing Environment (DCE) remote procedure call (RPC) protocol



NOTE: Use this option to select Microsoft Remote Procedure Call (MSRPC).

- **dce-rpc-portmap**—Distributed Computing Environment (DCE) remote procedure call (RPC) portmap protocol
- **dns**—Domain Name Service protocol
- **exec**—Remote execution protocol
- **ftp**—File Transfer Protocol
- **h323**—H.323 protocol
- **icmp**—Internet Control Message Protocol
- **iioip**—Internet Inter-ORB Protocol

- **ip**—Internet protocol
- **netbios**—NetBIOS protocol
- **netshow**—Netshow protocol
- **pptp**—Point-to-Point Tunneling Protocol
- **realaudio**—RealAudio protocol
- **rpc**—Remote Procedure Call protocol



NOTE: Use this option to select Sun Microsystems Remote Procedure Call protocol (SunRPC).

- **rpc-portmap**—Remote Procedure Call portmap protocol
- **rtsp**—Real-Time Streaming Protocol
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **talk**—Talk protocol
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

count—(Optional) Display a count of the matching entries.

destination-port *destination-port*—(Optional) Display information for a particular destination port. The range of values is from 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Display information for a particular destination prefix.

interface *interface-name*—(Optional) Display information about a particular interface. On M Series and T Series routers, *interface-name* can be **ms-fpc/pic/port** or **rspnumber**. On J Series routers, *interface-name* is **ms-pim/0/port**.

limit *number*—(Optional) Maximum number of entries to display.

protocol *protocol*—(Optional) Display information about one of the following IP types:

- **number**—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol

- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Display information for a particular service set.

source-port *source-port*—(Optional) Display information for a particular source port. The range of values is from 0 to 65535.

source-prefix *source-prefix*—(Optional) Display information for a particular source prefix.

Required Privilege Level view

Related Documentation • [clear services stateful-firewall flows on page 1785](#)

List of Sample Output [show services stateful-firewall flows on page 1801](#)
[show services stateful-firewall flows \(For Software Flows\) on page 1801](#)
[show services stateful-firewall flows brief on page 1802](#)
[show services stateful-firewall flows extensive on page 1802](#)
[show services stateful-firewall flows count on page 1802](#)
[show services stateful-firewall flows destination port on page 1802](#)
[show services stateful-firewall flows source port on page 1802](#)
[show services stateful-firewall flows \(Twice NAT\) on page 1802](#)

Output Fields Table 349 on page 1800 lists the output fields for the **show services stateful-firewall flows** command. Output fields are listed in the approximate order in which they appear.

Table 349: show services stateful-firewall flows Output Fields

Field Name	Field Description
Interface	Name of the interface.
Service set	Name of a service set. Individual empty service sets are not displayed. If no service set has any flows, a flow table header is displayed for each service set.
Flow Count	Number of flows in a session.
Flow or Flow Prot	Protocol used for this flow.

Table 349: show services stateful-firewall flows Output Fields (*continued*)

Field Name	Field Description
Source	Source prefix of the flow in the format <i>source-prefix:port</i> . For ICMP flows, port information is not displayed.
Dest	Destination prefix of the flow. For ICMP flows, port information is not displayed.
State	Status of the flow: <ul style="list-style-type: none"> • Drop—Drop all packets in the flow without response. • Forward—Forward the packet in the flow without looking at it. • Reject—Drop all packets in the flow with response. • Watch—Inspect packets in the flow.
Dir	Direction of the flow: input (I) or output (O).
Frm count	Number of frames in the flow.

Sample Output

show services stateful-firewall flows user@host> **show services stateful-firewall flows**
Interface: ms-1/3/0, Service set: green

```
Flow
Prot    Source                Dest                State    Dir    Frm count
TCP     10.58.255.178:23    -> 10.59.16.100:4000 Forward  O
TCP     10.58.255.50:33005-> 10.58.255.178:23 Forward  I      1
Source NAT 10.58.255.50:33005-> 10.59.16.100:4000
Destin NAT 10.58.255.178:23    -> 0.0.0.0:4000
```

show services stateful-firewall flows When a service set includes software processing, the following output format is used for the software flows:

(For Software Flows)

```
user@host> show services stateful-firewall flows
Interface: sp-0/1/0, Service set: dslite-svc-set2
Flow
TCP     200.200.200.2:80    -> 44.44.44.1:1025 Forward  O      219942
NAT dest 44.44.44.1:1025    -> 20.20.1.4:1025
Software 2001::2        -> 1001::1
TCP     20.20.1.2:1025    -> 200.200.200.2:80 Forward  I      110244
NAT source 20.20.1.2:1025 -> 44.44.44.1:1024
Software 2001::2        -> 1001::1
TCP     200.200.200.2:80 -> 44.44.44.1:1024 Forward  O      219140
NAT dest 44.44.44.1:1024 -> 20.20.1.2:1025
Software 2001::2        -> 1001::1
DS-LITE 2001::2          -> 1001::1 Forward  I      988729
TCP     200.200.200.2:80 -> 44.44.44.1:1026 Forward  O      218906
NAT dest 44.44.44.1:1026 -> 20.20.1.3:1025
Software 2001::2        -> 1001::1
TCP     20.20.1.3:1025 -> 200.200.200.2:80 Forward  I      110303
NAT source 20.20.1.3:1025 -> 44.44.44.1:1026
Software 2001::2        -> 1001::1
TCP     20.20.1.4:1025 -> 200.200.200.2:80 Forward  I      110944
```

	NAT source	20.20.1.4:1025	->	44.44.44.1:1025			
	Softwire	2001::2	->	1001::1			
show services stateful-firewall flows brief	The output for the show services stateful-firewall flows brief command is identical to that for the show services stateful-firewall flows command. For sample output, see show services stateful-firewall flows .						
show services stateful-firewall flows extensive	user@host> show services stateful-firewall flows extensive						
	Interface: ms-0/3/0, Service set: ss_nat						
	Flow count			State	Dir		Frm
	TCP	16.1.0.1:2330	->	16.49.0.1:21	Forward	I	
	8						
	NAT source	16.1.0.1:2330	->	16.41.0.1:2330			
	NAT dest	16.49.0.1:21	->	16.99.0.1:21			
	Byte count: 455, TCP established, TCP window size: 57344						
	TCP acknowledge: 3251737524, TCP tickle enabled, tcp_tickle: 0						
	Flow role: Master, Timeout: 720						
	TCP	16.99.0.1:21	->	16.41.0.1:2330	Forward	0	
	5						
	NAT source	16.99.0.1:21	->	16.49.0.1:21			
	NAT dest	16.41.0.1:2330	->	16.1.0.1:2330			
	Byte count: 480, TCP established, TCP window size: 57344						
	TCP acknowledge: 463128048, TCP tickle enabled, tcp_tickle: 0						
	Flow role: Responder, Timeout: 720						
show services stateful-firewall flows count	user@host> show services stateful-firewall flows count						
	Interface	Service set					Flow Count
	ms-1/3/0	green					2
show services stateful-firewall flows destination port	user@router> show services stateful-firewall flows destination-port 21						
	Interface: ms-0/3/0, Service set: svc_set_trust						
	Flow			State	Dir		Frm count
	Interface: ms-0/3/0, Service set: svc_set_untrust						
	Flow			State	Dir		Frm count
	TCP	10.50.10.2:2143	->	10.50.20.2:21	Watch	0	0
show services stateful-firewall flows source port	user@router> show services stateful-firewall flows source-port 2143						
	Interface: ms-0/3/0, Service set: svc_set_trust						
	Flow			State	Dir		Frm count
	Interface: ms-0/3/0, Service set: svc_set_untrust						
	Flow			State	Dir		Frm count
	TCP	10.50.10.2:2143	->	10.50.20.2:21	Watch	0	0
show services stateful-firewall flows (Twice NAT)	user@router> show services stateful-firewall flows						
	Flow			State	Dir		Frm count
	UDP	40.0.0.8:23439	->	80.0.0.1:16485	Watch	I	20
	NAT source	40.0.0.8:23439	->	172.16.1.10:1028			
	NAT dest	80.0.0.1:16485	->	192.16.1.10:22415			
	UDP	192.16.1.10:22415	->	172.16.1.10:1028	Watch	0	20
	NAT source	192.16.1.10:22415	->	80.0.0.1:16485			
	NAT dest	172.16.1.10:1028	->	40.0.0.8:23439			

show services stateful-firewall sip-call

Syntax show services stateful-firewall sip-call
 <brief | extensive | terse>
 <application-protocol *protocol*>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <interface *interface-name*>
 <limit *number*>
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>

Release Information Command introduced in Junos OS Release 7.4.

Description Display stateful firewall Session Initiation Protocol (SIP) call information.

Options count—(Optional) Display a count of the matching entries.

brief—(Optional) Display brief SIP call information.

extensive—(Optional) Display detailed SIP call information.

terse—(Optional) Display terse SIP call information.

application-protocol—(Optional) Display information about one of the following application protocols:

- **bootp**—(SIP only) Bootstrap protocol
- **dce-rpc**—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols
- **dce-rpc-portmap**—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols portmap service
- **dns**—(SIP only) Domain Name System protocol
- **exec**—(SIP only) Exec
- **ftp**—(SIP only) File Transfer Protocol
- **h323**—H.323 standards
- **icmp**—Internet Control Message Protocol
- **iiop**—Internet Inter-ORB Protocol
- **login**—Login
- **netbios**—NetBIOS
- **netshow**—NetShow
- **realaudio**—RealAudio
- **rpc**—Remote Procedure Call protocol

- **rpc-portmap**—Remote Procedure Call protocol portmap service
- **rtsp**—Real-Time Streaming Protocol
- **shell**—Shell
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

destination-port *destination-port*—(Optional) Display information for a particular destination port. The range of values is from 0 to 65535.

destination-prefix *destination-prefix*—(Optional) Display information for a particular destination prefix.

interface *interface-name*—(Optional) Display information about a particular adaptive services interface. On M Series and T Series routers, *interface-name* can be **sp-fpc/pic/port** or **rspnumber**. On J Series routers, *interface-name* is **sp-pim/0/port**.

limit *number*—(Optional) Maximum number of entries to display.

protocol—(Optional) Display information about one of the following IP types:

- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ipv6**—IPv6 within IP
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Display information for a particular service set.

source-port source-port—(Optional) Display information for a particular source port. The range of values is from 0 to 65535.

source-prefix source-prefix—(Optional) Display information for a particular source prefix.

Required Privilege Level view

Related Documentation • [clear services stateful-firewall sip-call on page 1787](#)

List of Sample Output [show services stateful-firewall sip-call extensive on page 1806](#)

Output Fields Table 350 on page 1805 lists the output fields for the **show services stateful-firewall sip-call** command. Output fields are listed in the approximate order in which they appear.

Table 350: show services stateful-firewall sip-call Output Fields

Field Name	Field Description
<i>Interface</i>	Name of an adaptive services interface.
<i>Service set</i>	Name of a service set.
<i>From</i>	Initiator address.
<i>To</i>	Responder address.
<i>Call ID</i>	SIP call identification string.
<i>Number of initiator flows</i>	Number of control , contact , or media initiator flows.
<i>Number of responder flows</i>	Number of control , contact , or media responder flows.
<i>protocol</i>	Protocol used for this flow.
<i>source-prefix</i>	Source prefix of the flow in the format <i>source-prefix : port</i> .
<i>destination-prefix</i>	Destination prefix of the flow.
<i>state</i>	Status of the flow: <ul style="list-style-type: none"> • Drop—Drop all packets in the flow without a response. • Forward—Forward the packet in the flow without examining it. • Reject—Drop all packets in the flow with a response. • Unknown—Unknown status. • Watch—Inspect packets in the flow.
<i>direction</i>	Direction of the flow: input (I), output (O), or unknown (U).

Table 350: show services stateful-firewall sip-call Output Fields (*continued*)

Field Name	Field Description
<i>frame-count</i>	Number of frames in the flow.
Byte count	Number of bytes forwarded in the flow.
Flow role	Role of the flow that is under evaluation: Initiator , Master , Responder , or Unknown .
Timeout	Lifetime of the flow, in seconds.

Sample Output

**show services
stateful-firewall
sip-call extensive**

```

user@host> show services stateful-firewall sip-call extensive
Interface: sp-0/3/0, Service set: test_sip_777
From: : 6507771234@10.200.100.1:0;000ff73ac89900021bb231dc-3ef68435
To: : 4085551234@10.200.100.1:0;0011bb65c2a3000777bd0fc-5748b749
Call ID: : 000ff73a-c8990004-0741adac-3e027c7e@10.20.70.2
Number of control initiator flows: : 1, Number of control responder flows:
: 1
UDP          10.20.70.2:50354 -> 10.200.100.1:5060 Watch I
2
  Byte count: 1112
  Flow role: Master, Timeout: 30
UDP          10.200.100.1:5060 -> 10.20.170.111:50354 Watch 0
0
  Byte count: 0
  Flow role: Responder, Timeout: 30
UDP          0.0.0.0:0 -> 10.20.170.111:5060 Watch 0
7
  Byte count: 2749
  Flow role: Responder, Timeout: 30
Number of contact initiator flows: 1, Number of contact responder flows: 1
UDP          0.0.0.0:0 -> 10.20.140.11:5060 Watch I
1
  Byte count: 409
  Flow role: Master, Timeout: 30
UDP          10.20.140.11:31864 -> 10.20.170.111:18808 Forward 0
622
  Byte count: 124400
  Flow role: Master, Timeout: 30
UDP          0.0.0.0:0 -> 10.20.170.111:18809 Forward 0
0
  Byte count: 0
  Flow role: Initiator, Timeout: 30
Number of media initiator flows: 4, Number of media responder flows: 0
UDP          10.20.70.2:18808 -> 10.20.140.11:31864 Forward I
628
  Byte count: 125600
  Flow role: Initiator, Timeout: 30
UDP          0.0.0.0:0 -> 10.20.140.11:31865 Forward I
0
  Byte count: 0
  Flow role: Initiator, Timeout: 30

```

```
0          0.0.0.0:0    ->      0.0.0.0:0    Unknown  U
0
  Byte count: 0
  Flow role: Unknown, Timeout: 0
0          0.0.0.0:0    ->      0.0.0.0:0    Unknown  U
Interface: sp-0/3/0, Service set: test_sip_888
```

show services stateful-firewall sip-register

Syntax show services stateful-firewall sip-register
 <brief | extensive | terse>
 <application-protocol *protocol*>
 <destination-port *destination-port*>
 <destination-prefix *destination-prefix*>
 <interface *interface-name*>
 <limit *number*>
 <protocol *protocol*>
 <service-set *service-set*>
 <source-port *source-port*>
 <source-prefix *source-prefix*>

Release Information Command introduced in Junos OS Release 7.4.

Description Display stateful firewall Session Initiation Protocol (SIP) register information.

Options count—(Optional) Display a count of the matching entries.

 brief—(Optional) Display brief SIP register information.

 extensive—(Optional) Display detailed SIP register information.

 terse—(Optional) Display terse SIP register information.

 application-protocol—(Optional) Display information about one of the following application protocols:

- **bootp**—(SIP only) Bootstrap protocol
- **dce-rpc**—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols
- **dce-rpc-portmap**—(SIP only) Distributed Computing Environment-Remote Procedure Call protocols portmap service
- **dns**—(SIP only) Domain Name System protocol
- **exec**—(SIP only) Exec
- **ftp**—(SIP only) File Transfer Protocol
- **h323**—H.323 standards
- **icmp**—Internet Control Message Protocol
- **iiop**—Internet Inter-ORB Protocol
- **login**—Login
- **netbios**—NetBIOS
- **netshow**—NetShow
- **realaudio**—RealAudio
- **rpc**—Remote Procedure Call protocol

- **rpc-portmap**—Remote Procedure Call protocol portmap service
- **rtsp**—Real-Time Streaming Protocol
- **shell**—Shell
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **sqlnet**—SQLNet
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

destination-port *destination-port*—(Optional) Display information for a particular destination port.

destination-prefix *destination-prefix*—(Optional) Display information for a particular destination prefix. The range of values is from 0 to 65535.

interface *interface-name*—(Optional) Display information about a particular interface. On M Series and T Series routers, the *interface-name* can be *sp-fpc/pic/port* or *rspnumber*. On J Series routers, the *interface-name* is *sp-pim/0/port*.

limit *number*—(Optional) Maximum number of entries to display.

protocol—(Optional) Display information about one of the following IP types:

- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol
- **ipip**—IP-within-IP Encapsulation Protocol
- **ipv6**—IPv6 within IP
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

service-set *service-set*—(Optional) Display information for a particular service set.

source-port *source-port*—(Optional) Display information for a particular source port. The range of values is from 0 to 65535.

source-prefix *source-prefix*—(Optional) Display information for a particular source prefix.

Required Privilege Level view

Related Documentation • [clear services stateful-firewall sip-register on page 1790](#)

List of Sample Output [show services stateful-firewall sip-register extensive on page 1810](#)

Output Fields Table 351 on page 1810 lists the output fields for the **show services stateful-firewall sip-register** command. Output fields are listed in the approximate order in which they appear.

Table 351: show services stateful-firewall sip-register Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of a service set.
SIP Register	Register information header.
Protocol	Protocol used for this flow.
Registered IP	Register IP address.
Port	Register port number.
Expiration timeout	Configured lifetime, in seconds.
Timeout remaining	Lifetime remaining, in seconds.
From	Initiator address.
To	Responder address.
Call ID	SIP call identification string.

Sample Output

show services stateful-firewall sip-register extensive

```
user@host> show services stateful-firewall sip-register extensive
Interface: sp-0/3/0, Service set: test_sip_777
```

```
SIP Register: Protocol: UDP, Registered IP: 10.20.170.111, Port: 5060, Acked
Expiration timeout: 36000, Timeout remaining: 35544
From: : 6507771234@10.200.100.1:0;
To: : 6507771234@10.200.100.1:0;
Call ID: : 000ff73a-c8990002-23b1d942-2ba1f91f@10.20.70.2
```

Interface: sp-0/3/0, Service set: test_sip_888

SIP Register: Protocol: UDP, Registered IP: 10.20.170.112, Port: 5060, Acked
Expiration timeout: 36000, Timeout remaining: 35549
From: : 8881234@10.200.100.1:0;
To: : 8881234@10.200.100.1:0;
Call ID: : 00112096-81fc0002-23b38905-7cb41f62@10.20.71.2

show services stateful-firewall statistics

Syntax	show services stateful-firewall statistics <application-protocol <i>protocol</i> > <brief detail extensive summary> <interface <i>interface-name</i> > <service-set <i>service-set</i> >
Release Information	Command introduced before Junos OS Release 7.4.
Description	Display stateful firewall statistics.
Options	<p>none—Display standard information about all stateful firewall statistics.</p> <p>brief detail extensive summary—(Optional) Display the specified level of output.</p> <p>interface <i>interface-name</i>—(Optional) Display information about a particular interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>ms-pim/O/port</i>.</p> <p>service-set <i>service-set</i>—(Optional) Display information about a particular service set.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> clear services stateful-firewall statistics on page 1793
List of Sample Output	show services stateful-firewall statistics extensive on page 1815
Output Fields	Table 352 on page 1812 lists the output fields for the show services stateful-firewall statistics command. Output fields are listed in the approximate order in which they appear.

Table 352: show services stateful-firewall statistics Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of a service set.
New flows	Rule match counters for new flows: <ul style="list-style-type: none"> Accept—New flows accepted. Discard—New flows discarded. Reject—New flows rejected.
Existing flows	Rule match counters for existing flows: <ul style="list-style-type: none"> Accept—Match existing forward or watch flow. Discard—Match existing discard flow. Reject—Match existing reject flow.

Table 352: show services stateful-firewall statistics Output Fields (*continued*)

Field Name	Field Description
Drops	Drop counters: <ul style="list-style-type: none"> • TCP SYN defense—Packets dropped by SYN defender. • NAT ports exhausted—Hide mode. The router has no available Network Address Translation (NAT) ports for a given address or pool.
Errors	Total errors, categorized by protocol: <ul style="list-style-type: none"> • IP—Total IP version 4 errors. • TCP—Total Transmission Control Protocol (TCP) errors. • UDP—Total User Datagram Protocol (UDP) errors. • ICMP—Total Internet Control Message Protocol (ICMP) errors. • Non-IP—Total non-IPv4 errors.
IP Errors	IPv4 errors: <ul style="list-style-type: none"> • IP packet length inconsistencies—IP packet length does not match the Layer 2 reported length. • Minimum IP header length check failures—Minimum IP header length is 20 bytes. The received packet contains less than 20 bytes. • Reassembled packet exceeds maximum IP length—After fragment reassembly, the reassembled IP packet length exceeds 65,535. • Illegal source address 0—Source address is not a valid address. Invalid addresses are, loopback, broadcast, multicast, and reserved addresses. Source address 0, however, is allowed to support BOOTP and the destination address 0xffffffff. • Illegal destination address 0—Destination address is not a valid address. The address is reserved. • TTL zero errors—Received packet had a time-to-live (TTL) value of 0. • IP protocol number 0 or 255—IP protocol is 0 or 255. • Land attack—IP source address is the same as the destination address. • Smurf attack—Echo request is sent to a directed broadcast address. • Non-IP packets—Packet did not conform to the IP standard. • IP option—Packet dropped because of a nonallowed IP option. • Non-IPv4 packets—Packet was not IPv4. (Only IPv4 is supported.) • Bad checksum—Packet had an invalid IP checksum. • Illegal IP fragment length—Illegal fragment length. All fragments (other than the last fragment) must have a length that is a multiple of 8 bytes. • IP fragment overlap—Fragments have overlapping fragment offsets. • IP fragment reassembly timeout—Some of the fragments for an IP packet were not received in time, and the reassembly handler dropped partial fragments.

Table 352: show services stateful-firewall statistics Output Fields (*continued*)

Field Name	Field Description
TCP Errors	<p>TCP protocol errors:</p> <ul style="list-style-type: none"> • TCP header length inconsistencies—Minimum TCP header length is 20 bytes, and the IP packet received does not contain at least 20 bytes. • Source or destination port number is zero—TCP source or destination port is zero. • Illegal sequence number, flags combination—Dropped because of TCP errors, such as an illegal sequence number, which causes an illogical combination of flags to be set. • SYN attack (multiple SYN messages seen for the same flow)—Multiple SYN packets received for the same flow are treated as a SYN attack. The packets might be retransmitted SYN packets and therefore valid, but a large number is cause for concern. • First packet not SYN—First packets for a connection are not SYN packets. These packets might originate from previous connections or from someone performing an ACK/FIN scan. • TCP port scan (Handshake, RST seen from server for SYN)—In the case of a SYN defender, if an RST (reset) packet is received instead of a SYN/ACK message, someone is probably trying to scan the server. This behavior can result in false alarms if the RST packet is not combined with an intrusion detection service (IDS). • Bad SYN cookie response—SYN cookie generates a SYN/ACK message for all incoming SYN packets. If the ACK received for the SYN/ACK message does not match, this counter is incremented.
UDP Errors	<p>UDP protocol errors:</p> <ul style="list-style-type: none"> • IP data length less than minimum UDP header length (8 bytes)—Minimum UDP header length is 8 bytes. The received IP packets contain less than 8 bytes. • Source or destination port is zero—UDP source or destination port is 0. • UDP port scan (ICMP error seen for UDP flow)—ICMP error is received for a UDP flow. This could be a genuine UDP flow, but it is counted as an error.
ICMP Errors	<p>ICMP protocol errors:</p> <ul style="list-style-type: none"> • IP data length less than minimum ICMP header length (8 bytes)—ICMP header length is 8 bytes. This counter is incremented when received IP packets contain less than 8 bytes. • ICMP error length inconsistencies—Minimum length of an ICMP error packet is 48 bytes, and the maximum length is 576 bytes. This counter is incremented when the received ICMP error falls outside this range. • Ping duplicate sequence number—Received ping packet has a duplicate sequence number. • Ping mismatched sequence number—Received ping packet has a mismatched sequence number.

Sample Output

```

show services stateful-firewall statistics extensive
user@host> show services stateful-firewall statistics extensive
Interface: ms-1/3/0
Service set: interface-svc-set
New flows:
  Accept: 907, Discard: 0, Reject: 0
Existing flows:
  Accept: 3535, Discard: 0, Reject: 0
Drops:
  IP option: 0, TCP SYN defense: 0
  NAT ports exhausted: 0
Errors:
  IP: 0, TCP: 0
  UDP: 0, ICMP: 0
  Non-IP packets: 0, ALG: 0
IP errors:
  IP packet length inconsistencies: 0
  Minimum IP header length check failures: 0
  Reassembled packet exceeds maximum IP length: 0
  Illegal source address: 0
  Illegal destination address: 0
  TTL zero errors: 0, IP protocol number 0 or 255: 0
  Land attack: 0, Smurf attack: 0
  Non IP packets: 0, IP option: 0
  Non-IPv4 packets: 0, Bad checksum: 0
  Illegal IP fragment length: 0
  IP fragment overlap: 0
  IP fragment reassembly timeout: 0
TCP errors:
  TCP header length inconsistencies: 0
  Source or destination port number is zero: 0
  Illegal sequence number, flags combination: 0
  SYN attack (multiple SYNs seen for the same flow): 0
  First packet not SYN: 0
  TCP port scan (Handshake, RST seen from server for SYN): 0
  Bad SYN cookie response: 0
UDP errors:
  IP data length less than minimum UDP header length (8 bytes): 0
  Source or destination port is zero: 0
  UDP port scan (ICMP error seen for UDP flow): 0
ICMP errors:
  IP data length less than minimum ICMP header length (8 bytes): 0
  ICMP error length inconsistencies: 0
  Ping duplicate sequence number: 0
  Ping mismatched sequence number: 0
ALG drops:
  BOOTP: 0, DCE-RPC: 0, DCE-RPC portmap: 0
  DNS: 0, Exec: 0, FTP: 0
  ICMP: 0
  Login: 0, Netbios: 0, Netshow: 0
  RPC: 0, RPC portmap: 0
  RTSP: 0, Shell: 0
  SNMP: 0, Sqlnet: 0, TFTP: 0
  Traceroute: 0

```

show services stateful-firewall statistics application-protocol sip

Syntax	show services stateful-firewall application-protocol sip
Release Information	Command introduced in Junos OS Release 7.4.
Description	Display stateful firewall Session Initiation Protocol (SIP) statistics.
Options	This command has no options.
Required Privilege Level	view
List of Sample Output	show services stateful-firewall statistics application-protocol-sip on page 1817
Output Fields	Table 353 on page 1816 lists the output fields for the show services stateful-firewall statistics application-protocol-sip command. Output fields are listed in the approximate order in which they appear.

Table 353: show services stateful-firewall statistics application-protocol-sip Output Fields

Field Name	Field Description
Interface	Name of an adaptive services interface.
Service set	Name of the service set flow.
ALG	Name of the application-layer gateway.
Active SIP call count	Number of active SIP calls.
Active SIP registration count	Number of active SIP registrations.
REGISTER	Number of new, invalid, and retransmitted register requests sent to the SIP registrar.
INVITE	Number of new, invalid, and retransmitted invite messages sent by user agent clients.
ReINVITE	Number of new, invalid, and retransmitted reinvite messages sent by user agent clients.
ACK	Number of new, invalid, and retransmitted ACK messages received (in response to a SIP Call Invite message).
BYE	Number of new, invalid, and retransmitted requests to terminate SIP dialogues.
CANCEL	Number of new, invalid, and retransmitted SIP request cancellations.
SUBSCRIBE	Number of new, invalid, and retransmitted SIP requests to subscribe for event notifications.
NOTIFY	Number of new, invalid, and retransmitted event notifications in SIP dialogues.

Table 353: show services stateful-firewall statistics application-protocol-sip
Output Fields (continued)

Field Name	Field Description
OPTIONS	Number of new, invalid, and retransmitted requests to query SIP capabilities.
INFO	Number of new, invalid, and retransmitted requests carrying application-level information.
UPDATE	Number of new, invalid, and retransmitted SIP dialogue updates.
REFER	Number of new, invalid, and retransmitted requests to the recipient to contact a third party.
Provisional responses	Number of new, invalid, and retransmitted responses from the user agent server to indicate the progress of a SIP transaction.
OK responses to INVITES	OK responses sent from the user agent clients to user agent servers in response to Invite messages. The server can then return an ACK message.
OK responses to non-INVITES	OK responses to SIP messages other than an Invite message.
Redirection responses	Responses from the user agent server to a user agent client requesting the client to contact a different SIP uniform resource identifier (URI).
Request failure responses	Responses that indicate a definite failure from a particular server. The client must not retry the same request without modification after receiving this response.
Server failure responses	Responses that indicate a server failure.
Global failure responses	Responses that indicate a server has definitive information about a particular user, not just the particular instance indicated in the Request URI.
Invalid responses	Responses that are invalid.
Response (all) retransmits	Retransmissions of all responses.
Parser	Syntax errors, content errors, and unknown methods counted by the message parser.

Sample Output

```

show services stateful-firewall statistics application-protocol-sip
user@host> show services stateful-firewall statistics application-protocol sip
Interface: sp-0/3/0
Service set: test_sip_777, ALG: SIP
Active SIP call count: 0, Active SIP registration count: 1

```

	New	Invalid	Retransmit
REGISTER	2		
INVITE	1		0
ReINVITE	1		
ACK	1	0	0
BYE	0	0	
CANCEL	0	0	

```
SUBSCRIBE      0      0
NOTIFY         0      0
OPTIONS        0      0
INFO           0      0
UPDATE        0      0
REFER          0      0
Provisional responses (18x): 1, OK responses to INVITEs: 2
OK responses to non-INVITEs: 2, Redirection (3xx) responses: 0
Request failure (4xx) responses: 0, Server failure (5xx) responses: 0
Global failure (6xx) responses: 0, Invalid responses: 0
Response (all) retransmits: 0
Parser:
  Syntax errors: 0, Content errors: 0, Unknown methods: 0
Service set: test_sip_888, ALG: SIP
Active SIP call count: 0, Active SIP registration count: 1
      New      Invalid      Retransmit
REGISTER      2
INVITE         0      0      0
ReINVITE       0
ACK            0      0      0
BYE            0      0
CANCEL         0      0
SUBSCRIBE      0      0
NOTIFY         0      0
OPTIONS        0      0
INFO           0      0
UPDATE        0      0
REFER          0      0
Provisional responses (18x): 0, OK responses to INVITEs: 0
OK responses to non-INVITEs: 2, Redirection (3xx) responses: 0
Request failure (4xx) responses: 0, Server failure (5xx) responses: 0
Global failure (6xx) responses: 0, Invalid responses: 0
Response (all) retransmits: 0
Parser:
  Syntax errors: 0, Content errors: 0, Unknown methods: 0
```

PART 5

Index

- Index on page 1821
- Index of Statements and Commands on page 1843

Index

Symbols

#, comments in configuration statements.....	xxvii
(), in syntax descriptions.....	xxvii
/altconfig directory	
altconfig file system.....	766
/altroot directory	
altroot file system.....	766
/config directory	
config file system.....	766
< >, in syntax descriptions.....	xxvi
[], in configuration statements.....	xxvii
{ }, in configuration statements.....	xxvii
(pipe), in syntax descriptions.....	xxvii

A

AAA	
subscriber sessions	
displaying.....	849
subscriber statistics	
clearing.....	711, 712
displaying.....	843
subscribers	
displaying.....	846
logging out.....	712
AACL	
statistics	
clearing.....	1462
aborting partitioning operation.....	753
accounting.....	137
accounting profiles	
records, displaying.....	156
status, displaying.....	152
active flow monitoring	
aggregated flows, displaying.....	1503
available PICs, displaying.....	1522
CPU usage, displaying.....	1524
error statistics, displaying.....	1508
flow statistics, displaying.....	1510
flows, detailed information, displaying.....	1513

memory statistics, displaying.....	1518
packet size distribution, displaying.....	1520
adaptive shapers, displaying.....	1248
address assignment pools	
displaying.....	852
Address Resolution Protocol.....	703
aggregated flows, displaying.....	1503
alarms, displaying	
chassis.....	204
health monitor.....	672
RMON.....	684
system.....	866
application-aware-access-list See aacl	
archival configuration	
displaying.....	890
archiving files.....	568
arithmetic and relational operators	
for monitor traffic command.....	108
ARP table	
clearing.....	703
displaying.....	820
associations, clearing.....	1572
ATM nodes, reachability.....	8
authorization See permissions	
autoinstallation, displaying the status of.....	874

B

backing up partitions.....	766
backup Junos OS files, deleting.....	784
backup software, displaying information.....	971
BERT	
DS0 test	
starting.....	35
stopping.....	36
E1 test	
starting.....	37
stopping.....	38
E3 test	
starting.....	39
stopping.....	40

T1 test		
starting.....	49	
stopping.....	50	
T3 test		
starting.....	51	
stopping.....	52	
binding		
clearing Mobile IP.....	1678	
binding state of DHCP client		
clearing.....	704	
displaying.....	828	
binding state of DHCPv6 client		
clearing.....	708	
displaying.....	835	
bit error rate test See BERT		
boot messages, displaying.....	875	
Border Signaling Gateway.....	1313	
border-signaling-gateway		
address-of-record bindings, displaying.....	1320	
calls, displaying by server.....	1330	
calls, displaying by service-point.....	1332	
registrations statistics, clearing.....	1317	
registrations subscriptions, clearing.....	1318	
registrations, displaying.....	1349	
routing-blacklist, displaying.....	1351	
statistics, displaying.....	1323, 1325, 1327, 1346	
statistics, displaying by server.....	1334, 1340	
statistics, displaying by service point.....	1343	
statistics, displaying by service-point.....	1337	
status, displaying.....	1352	
braces, in configuration statements.....	xxvii	
brackets		
angle, in syntax descriptions.....	xxvi	
square, in configuration statements.....	xxvii	
BSG		
clear gateway denied messages		
information.....	1315	
clear gateway statistics.....	1319	
buffers, displaying system.....	882	
bypass LSPs, testing.....	25	
C		
CB		
environmental information, displaying.....	237	
Ethernet switch, displaying port		
information.....	304	
operation of, controlling.....	167	
SPMB operation, restarting.....	197	
certificates		
for IKE negotiation, displaying.....	1617	
installed, displaying.....	1630	
key pairs, generating.....	1575	
PKI		
CA certificates, clearing.....	1564	
CA certificates, displaying.....	1606	
CA certificates, loading manually.....	1577	
certificate revocation lists, clearing.....	1566	
certificate revocation lists,		
displaying.....	1612	
certificate revocation lists, loading		
manually.....	1579	
key pair, generating.....	1582	
local certificates, clearing.....	1567, 1568	
local certificates, displaying.....	1614	
local certificates, loading manually.....	1586	
local certificates, requesting		
manually.....	1580, 1585	
local certificates, requesting online.....	1576	
local certificates, requesting that CA		
install.....	1583	
local certificates, requests, clearing.....	1565	
local certificates, requests,		
displaying.....	1610	
provided by Juniper Networks, adding.....	1593	
signed certificate, obtaining.....	1573	
unsigned certificate, obtaining.....	1574	
CFEB		
operation, controlling.....	169	
statistics, displaying.....	589	
status, displaying.....	208	
chassis		
alarm conditions, displaying.....	204	
cip information, displaying.....	210, 248	
craft interface display messages		
clearing the display of.....	165	
displaying.....	201	
displaying through the CLI.....	212	
stopping the display of.....	201	
environmental information, displaying.....	220	
Ethernet switch information, displaying.....	304	
firmware version, displaying.....	398	
forwarding process, displaying.....	405	
installed hardware, displaying.....	423	
location, displaying.....	471	
MAC addresses, displaying.....	474	
network services, displaying.....	477	
serial numbers, displaying.....	423	

- switch fabric errors
 - displaying.....320
- switch fabric status
 - FPCs, displaying.....323
 - SIBs, displaying.....373
- switch fabric topology, displaying.....383
- synchronization (MX Series).....199
- synchronization source information,
 - displaying.....534
- temperature threshold settings,
 - displaying.....537
- checksum
 - calculating for a file.....570, 571, 572
 - displaying values for all files.....867
- CIP
 - operation of, controlling.....170
- cleanup, storage space.....811
- clear arp command.....703
- clear chassis display message command.....165
- clear cli logical-system command.....545
- clear ddos-protection protocols command.....1426
- clear dhcp server binding command.....704
- clear dhcp server statistics command.....706
- clear dhcpv6 server binding command.....708
- clear dhcpv6 server statistics command.....710
- clear diameter function statistics command.....1385
- clear diameter peer command.....1386
- clear dlsw reachability command.....1370
- clear ike security-associations command.....1561
- clear ipsec security-associations command.....1562
- clear lldp neighbor command.....138
- clear lldp statistics command.....139
- clear log command.....567
- clear mobile-ip binding command.....1678
- clear network-access aaa statistics command.....711
- clear network-access aaa subscriber
 - command.....712
- clear network-access gx-plus replay
 - command.....1387
- clear network-access gx-plus statistics
 - command.....1388
- clear passive-monitoring statistics
 - command.....1483
- clear security pki ca-certificate command.....1564
- clear security pki certificate-request
 - command.....1565
- clear security pki crl command.....1566
- clear security pki key-pair.....1567
- clear security pki local-certificate command.....1568
- clear services application-aware-access-list
 - statistics command.....1462
- clear services application-identification
 - application-system-cache command.....1461
- clear services application-identification counter
 - command.....1463
- clear services border-signaling-gateway
 - denied-messages command.....1315
- clear services border-signaling-gateway
 - name-resolution-cache command.....1316
- clear services border-signaling-gateway
 - registrations statistics command.....1317
- clear services border-signaling-gateway
 - registrations subscription, command.....1318
- clear services border-signaling-gateway statistics
 - command.....1319
- clear services cos statistics command.....1364
- clear services crtp statistics command.....1356
- clear services dynamic-flow-capture
 - command.....1482
- clear services flow-collector statistics
 - command.....1484
- clear services flows command.....1304
- clear services flows ip-action command.....1464
- clear services ids command.....1544
- clear services ids destination-table
 - command.....1545
- clear services ids pair-table command.....1546
- clear services ids source-table command.....1547
- clear services ipsec-vpn certificates
 - command.....1569
- clear services ipsec-vpn ike security-associations
 - command.....1570
- clear services ipsec-vpn ipsec security-associations
 - command.....1572
- clear services ipsec-vpn ipsec statistics
 - command.....1571
- clear services l2tp destination command.....1635
- clear services l2tp multilink command.....1636
- clear services l2tp session command.....1637
- clear services l2tp session statistics
 - command.....1639
- clear services l2tp tunnel command.....1641
- clear services l2tp tunnel statistics
 - command.....1643
- clear services local-policy-decision-function
 - statistics command.....1465
- clear services pgcp command.....1697
- clear services pgcp statistics command.....1698

clear services rpm twamp server connection command.....	62	commit operations, pending clearing.....	713
clear services service-sets statistics packet-drops command.....	1763	displaying.....	888
clear services service-sets statistics syslog command.....	1764	commit scripts converting.....	765
clear services softwire statistics command.....	1780	comparing files.....	573
clear services stateful-firewall flows command.....	1785	completing partial command entry.....	546
clear services stateful-firewall sip-call command.....	1787	Compressed Real-Time Transport Protocol See	
clear services stateful-firewall sip-register command.....	1790	CRTP services	
clear services stateful-firewall statistics command.....	1793	compressing files.....	568
clear services subscriber sessions command.....	1748	configuration deleting rescue configuration.....	741
clear snmp statistics command.....	664	displaying	
clear system commit command.....	713	archival configuration.....	890
clear system reboot command.....	714	CoS.....	1246
clear system services dhcp binding command.....	717	current configuration.....	822
clear system services dhcp conflict command.....	718	previous configuration.....	958
clear system services dhcp statistics command.....	719	rescue configuration.....	891
CLI		saving rescue configuration.....	742
command completion.....	546	syntax, verifying.....	1204
command history		configuration mode, entering.....	720
displaying.....	563	configure command.....	720
current working directory		conflicting IP addresses, displaying.....	963
displaying.....	562	connections	
setting.....	547	IP sockets, displaying active.....	893
date		SSH, opening.....	658
setting.....	556	testing	
exiting to create UNIX-level shell.....	1194	ATM connections.....	8
idle timeout, setting.....	548	CLNS connections.....	10
logical system instance, setting.....	549	general connections.....	4
logical system view, clearing.....	545	MPLS Layer 2 circuit connections.....	12
permissions, displaying.....	559	MPLS Layer 2 VPN connections.....	15
prompt, setting.....	550	MPLS Layer 3 VPN connections.....	18
restart, after software upgrade.....	551	MPLS LDP connections.....	20
screen length, setting.....	552	MPLS LSP-endpoint connections.....	23
screen width, setting.....	553	MPLS RSVP connections.....	25
settings, displaying.....	557	content destination	
terminal type, setting.....	554	dynamic flow capture, displaying.....	1526
timestamp, setting.....	555	Control Board See CB	
CLNS node reachability, checking.....	10	control source,	
command-name command.....	1466	dynamic flow capture, displaying.....	1528
comments, in configuration statements.....	xxvii	conventions	
		text and syntax.....	xxvi
		converting scripts.....	765
		copying	
		files.....	576
		core-dumps	
		usage information, displaying.....	911

CoS

adaptive shaper information, displaying.....	1248
configuration, displaying.....	1246
forwarding table, displaying	
classifier information.....	1266
code point value to loss priority.....	1264
code point value to loss priority, J Series.....	1271
code point value to queue number.....	1264
configuration.....	1261
loss priority table indexes, J Series.....	1273
RED drop profiles.....	1267
rewrite rules.....	1274
rewrite rules, table identifiers.....	1276
scheduler map for switch fabric.....	1269
scheduler map information.....	1277
fragmentation map, displaying.....	1279
interface sets, displaying.....	1284
interfaces, displaying.....	1281
mapping, displaying	
code point aliases to bit patterns.....	1251
code point value to forwarding class.....	1249
code point value to loss priority.....	1249
code point value to loss priority, J Series.....	1286
CoS objects to routing instances.....	1290
forwarding classes to queue numbers.....	1259
schedulers to forwarding classes.....	1291
schedulers to switch fabric priority.....	1255
translation table bits.....	1295
RED profile information, displaying.....	1253
rewrite rules, displaying.....	1288
routing instance information, displaying.....	1290
scheduler map information, displaying.....	1291
scheduler parameters, displaying.....	1255
switch fabric queue statistics, displaying.....	1257
traffic-control profile information, displaying.....	1293
virtual channel group information, displaying.....	1300
virtual channel information, displaying.....	1299
CoS services	
clear statistics.....	1364
mapping, displaying	
code point aliases to bit patterns.....	1365

craft interface display messages

clearing.....	165
displaying	
on the craft interface display.....	201
through the CLI.....	212
stopping.....	201
CRTCP services	
flows, displaying.....	1360
output, displaying.....	1357
statistics, clearing.....	1356
curly braces, in configuration statements.....	xxvii
current time, displaying.....	1100
current working directory	
displaying.....	562
setting.....	547
customer support.....	xxvii
contacting JTAC.....	xxvii
system information, displaying.....	735

D

data link switching See DLSW

date

setting from CLI.....	556
DDoS protection.....	1425
clearing statistics and violations.....	1426
protocol information, displaying.....	1427
protocol policer information, displaying.....	1439
protocol policer violation information, displaying.....	1455
protocol statistics information, displaying.....	1445
statistics, displaying.....	1457
version, displaying.....	1458

deleting

backup Junos file.....	784
files.....	578
software packages.....	781

DHCP

address bindings	
clearing.....	717
displaying.....	960
address conflicts	
clearing.....	718
displaying.....	963
address pools, displaying.....	966
address statistics	
clearing.....	719
displaying.....	968

extended server binding		peer statistics	
clearing.....	704	displaying.....	1416
displaying.....	828	peer status	
extended server statistics		displaying.....	1409
clearing.....	706	route information	
displaying.....	832	displaying.....	1420
global settings, displaying.....	964	digital certificates <i>See</i> certificates	
DHCP client		Direct Memory Access <i>See</i> DMA statistics	
binding state		directories	
clearing.....	704	usage information, displaying.....	917
displaying.....	828	working, displaying.....	562
statistics		disk space available, displaying.....	1089
clearing.....	706	DLSW	
displaying.....	832	circuits, displaying.....	1372
DHCP local server		peers	
reconfigure client bindings.....	724	addresses, displaying.....	1376
DHCPv6		capabilities, displaying.....	1371
extended server binding		status, displaying.....	1374
clearing.....	708	DMA statistics, displaying.....	624
displaying.....	835	DNS	
extended server statistics		hostnames, displaying.....	842
clearing.....	710	documentation	
displaying.....	839	comments on.....	xxvii
DHCPv6 client		Domain Name System <i>See</i> DNS	
binding state		DPC poweron sequence	
clearing.....	708	displaying for a router.....	493
displaying.....	835	drop profiles, displaying data points.....	1253
statistics		dynamic application awareness.....	1459
clearing.....	710	dynamic flow capture	
displaying.....	839	content destination, displaying.....	1526
DHCPv6 local server		control source, displaying.....	1528
reconfigure client bindings.....	726	statistics	
Diameter base protocol		clearing.....	1482
clearing function statistics.....	1385	displaying.....	1530
clearing peers.....	1386	Dynamic Host Configuration Protocol <i>See</i> DHCP	
function statistics			
displaying.....	1398	E	
function status		environmental information	
displaying.....	1395	CB, displaying.....	237
instance information		chassis, displaying.....	210, 220, 248
displaying.....	1401	FPC, displaying.....	250
network element information		FPM, displaying.....	260
displaying.....	1403	MCSs, displaying.....	264
network element map information		PCGs, displaying.....	266
displaying.....	1406	PEMs, displaying.....	268
node status		Routing Engines, displaying.....	274
displaying.....	1389	SCG, displaying.....	277
peer map		SFM, displaying.....	281
displaying.....	1413	SIB, displaying.....	284

- ETH-DM See monitor ethernet delay-measurement command
- ETH-LM See monitor ethernet loss-measurement command
- Ethernet frame
 - delay measurement (ETH-DM), displaying.....79
 - loss-measurement (ETH-LM), displaying.....84
- Ethernet switch information, displaying.....304
- F**
 - facilities data link See FDL
 - far-end alarm and control See FEAC
 - FDL
 - loopback test, performing.....41
 - payload loopback test, performing.....43
 - FEAC
 - line loopback test, initiating.....44
 - line loopback test, terminating.....45
 - FEB
 - firmware version, displaying.....398
 - operation of, controlling (M120 routers only).....183
 - statistics, displaying.....592
 - status, displaying.....395
 - FEB redundancy group
 - status, displaying, M120 routers.....495
 - file archive command.....568
 - file checksum md5 command.....570
 - file checksum sha-256 command.....572
 - file checksum sha1 command.....571
 - file compare command.....573
 - file copy command.....576
 - file delete command.....578
 - file list command.....579
 - file rename command.....581
 - file show command.....583
 - file systems
 - checksum values, displaying.....867
 - free disk space, displaying.....1089
 - partitions, backing up.....766
 - files
 - archiving.....568
 - calculating checksum.....570, 571, 572
 - comparing.....573
 - compressing.....568
 - contents, displaying.....583
 - copying.....576
 - deleting.....578
 - list of, displaying.....579
 - log file, clearing.....567
 - renaming.....581
 - status of, displaying.....99
 - firmware
 - chassis, displaying.....398
 - system, displaying.....920
 - upgrading J Series PIMs.....743
 - flow aggregation
 - templates.....1507
 - flow collector services
 - interface files, displaying.....1533
 - packets received, displaying.....1535
 - primary server, switching to.....1485
 - secondary server, switching to.....1486
 - statistics
 - displaying.....1537
 - dropped-packet, clearing.....1763, 1764
 - interface, clearing.....1484
 - test file, transferring.....1487
 - flow monitoring
 - active
 - aggregated flows, displaying.....1503
 - CPU usage, displaying.....1524
 - detailed information, displaying.....1513
 - error statistics, displaying.....1508
 - flow statistics, displaying.....1510
 - memory statistics, displaying.....1518
 - packet size distribution, displaying.....1520
 - PICs, displaying available.....1522
 - passive
 - flow statistics, displaying.....1495
 - memory and flow statistics, displaying.....1497
 - status, displaying.....1499
 - usage statistics, displaying.....1501
 - flows
 - access-list.....1466
 - list-flows.....1466
 - font conventions.....xxvi
 - forwarding classes, displaying.....1259, 1365
 - forwarding process, displaying.....405
 - forwarding table
 - CoS information, displaying
 - classifier information.....1266
 - code point value to loss priority.....1264
 - code point value to loss priority, J Series.....1271
 - code point value to queue number.....1264
 - configuration.....1261

loss priority per classifier.....	1264
loss priority table indexes, J Series.....	1273
RED drop profiles.....	1267
rewrite rules.....	1274
scheduler map.....	1277
switch fabric scheduler map.....	1269
FPC	
environmental information, displaying.....	250
firmware version, displaying.....	398
installed, displaying list.....	423
operation of, controlling.....	173
statistics, displaying.....	595
status, displaying.....	406
switch fabric status, displaying.....	320, 323
FPM	
environmental information, displaying.....	260
resynchronizing craft interface status.....	175
fragmentation map	
CoS information, displaying.....	1279
free disk space, displaying.....	1089
freeing up storage space.....	811
Front Panel Module See FPM	
function statistics	
clearing Diameter base protocol.....	1385
G	
graceful switchover, displaying.....	1096
Gx-Plus	
displaying.....	1422
pending requests	
clearing.....	1387
statistics	
clearing.....	1388
H	
halts	
pending	
clearing.....	714
displaying.....	955
requesting.....	744
hard disk	
partitioning	
aborting.....	753
requesting.....	755
hardware, installed, displaying.....	423
health monitor alarms, displaying.....	672
heat dissipation	
ratings	
displaying for a router.....	485
history, CLI commands	
displaying.....	563
hostnames, DNS, displaying.....	842
hosts, reachability	
ATM connections.....	8
general connections.....	4
MPLS Layer 2 circuits.....	12
MPLS Layer 2 VPN connections.....	15
MPLS Layer 3 VPN connections.....	18
MPLS LDP LSPs.....	20
MPLS LSP endpoints.....	23
MPLS RSVP LSPs.....	25
I	
I/O statistics, routing protocol tasks,	
displaying.....	1166
icons defined, notice.....	xxv
idle timeout	
user, setting.....	548
IDS events	
clearing	
for a destination.....	1545
for interfaces and services.....	1544
for source addresses.....	1547
for source and destination pairs.....	1546
displaying.....	1548
IKE	
adaptive services interfaces	
security associations, clearing.....	1570
security associations, displaying.....	1620
statistics, clearing.....	1571
encryption services interfaces	
security associations, clearing.....	1561
security associations, displaying.....	1594
installing software.....	775
interface diagnostics operational mode	
commands.....	33, 52
interface statistics, real-time, displaying.....	89
Internet Key Exchange See IKE	
intrusion detection service See IDS events	
IP addresses	
conflicting, displaying.....	963
removing from DHCP server conflict list.....	718
IP multicast	
tracing routes	
from the receiver to the source.....	112
from the source to the gateway	
router.....	119

from the source to the receiver.....114
 listen for responses.....117
 IP sockets, displaying active.....893
 ip-action
 clearing.....1464
 IPsec services
 adaptive services interfaces
 backup and primary, switching
 tunnels.....1589
 IKE security associations, clearing.....1570
 IKE security associations,
 displaying.....1620
 IPSec security associations, clearing.....1572
 IPSec security associations,
 displaying.....1624
 IPSec statistics, clearing.....1571
 IPSec statistics, displaying.....1627
 encryption services interfaces
 backup and primary, switching
 interfaces.....1588
 backup and primary, switching
 services.....1588
 certificate database, displaying.....1598
 IKE security associations, clearing.....1561
 IKE security associations,
 displaying.....1594
 IPSec security associations,
 clearing.....1562
 IPSec security associations,
 displaying.....1603
 redundancy information, displaying.....1601
 IS-IS
 authentication, displaying.....1590

J

Junos OS
 alarms, displaying.....866
 autoinstallation status, displaying.....874
 backup files, deleting.....784
 boot messages, displaying.....875
 buffers, displaying.....882
 checksum values, displaying.....867
 core-dumps, displaying.....911
 directory usage, displaying.....917
 disk space, displaying.....1089
 halt, requesting a.....744
 loaded extensions, displaying.....974

pending reboots
 clearing.....714
 displaying.....955
 processes, displaying.....927
 queue statistics, displaying.....949
 rebooting.....761
 SRC client, displaying.....970
 system statistics, displaying.....980
 tasks, displaying
 I/O statistics.....1166
 memory usage.....1168
 protocol.....1164
 unified ISSU.....785, 808
 unified ISSU for MX Series 3D Universal Edge
 Routers.....789
 uptime, displaying.....1100
 version, displaying
 general.....1174
 virtual memory, displaying.....1108
 JUNOS Software
 bundles, deleting.....781
 packages, deleting.....781
 powering off.....757
 rolling back.....802
 unified ISSU
 aborting.....772
 upgrade
 performing.....775
 validating candidate.....805
 version, displaying
 for two Routing Engines.....1182

K

kernel memory usage, displaying.....1108
 kernel replication state, displaying.....1096
 key pair for digital certificate, generating.....1575
 keyboard sequences
 used with monitor interface command.....89
 used with monitor interface traffic
 command.....89
 used with monitor mpls command.....96

L

L-PDF
 statistics
 clearing.....1465
 L2TP LAC services
 destination
 clearing.....1635

L2TP services	
multilink sessions	
clearing.....	1636
displaying.....	1648
RADIUS information.....	1651
session statistics	
clearing.....	1639
sessions	
clearing.....	1637
displaying.....	1655
summary information, displaying.....	1661
tunnel destination	
displaying.....	1645
tunnel statistics, clearing.....	1643
tunnels, clearing.....	1641
tunnels, displaying.....	1663
user information, displaying.....	1667
Layer 2 circuits	
reachability, testing.....	12
Layer 2 Tunneling Protocol See L2TP	
Layer 2 VPNs	
reachability, testing.....	15
Layer 3 VPNs	
reachability, testing.....	18
LCC	
operation, receiving.....	195
operation, transmitting.....	196
LDP	
tracing LSPs.....	127
LDP LSPs	
ping interval.....	20
licenses	
adding.....	749
deleting.....	750
displaying.....	922
saving.....	751
line-card chassis	
operation, controlling.....	177
status, displaying.....	470
list-flows.....	1466
See also list-statistics	
LLDP	
displaying.....	140
local information, displaying.....	142
neighbor	
clearing.....	138
neighbors, displaying.....	144
remote global statistics, displaying.....	148
statistics	
clearing.....	139
statistics, displaying.....	150
location, chassis.....	471
log files	
clearing contents of.....	567
contents, displaying.....	585
display of	
starting.....	100
stopping.....	102
status, displaying.....	99
logging out users.....	752
logical operators	
for monitor traffic command.....	106
logical system view, clearing.....	545
login, specifying a Routing Engine.....	729
logout, users.....	752
LSPs	
LDP, ping interval.....	20
RSVP, ping interval.....	25
RSVP, real-time status.....	96
LSQ	
CPU usage information, displaying.....	1672
M	
MAC addresses	
displaying.....	474
manuals	
comments on.....	xxvii
match conditions	
for monitor traffic command.....	105
MCS	
environmental information, displaying.....	264
operation of, controlling.....	178
MD5 checksum, calculating.....	570
memory, displaying for tasks.....	1168
messages	
boot, displaying.....	875
user screens, displaying on.....	728
MIBs	
SNMP object values, displaying.....	681
MICs	
operation of, controlling.....	182
Miscellaneous Control Subsystem See MCS	
Mobile IP	
binding information, displaying.....	1679
clearing Mobile IP binding.....	1678
home agent overview information,	
displaying.....	1682

- home agent traffic information,
 - displaying.....1683
- virtual network information, displaying.....1685
- WiMAX Forum Network Architecture release
 - number, displaying.....1687
- monitor ethernet delay-measurement
 - command.....79
- monitor ethernet loss-measurement
 - command.....84
- monitor interface command.....89
- monitor label-switched-path command.....96
- monitor list command.....99
- monitor start command.....100
- monitor stop command.....102
- monitor traffic command.....103
- MPLS
 - Layer 2 circuit connections
 - operability, checking.....12
 - Layer 2 VPN connections
 - operability, checking.....15
 - Layer 3 VPN connections
 - operability, checking.....18
 - LDP-signaled LSP connections
 - operability, checking.....20
 - LSP endpoint connections
 - operability, checking.....23
 - tracing LSPs.....127, 130
- mtrace command.....112
- mtrace from-source command.....114
- mtrace monitor command.....117
- mtrace to-gateway command.....119
- MX Series Virtual Chassis commands
 - show virtual-chassis protocol adjacency.....1219

N

- NAT
 - mapping information, displaying.....1690
 - status information, displaying.....1692
- neighbor
 - LLDP.....138
- Network Time Protocol See NTP
- next hops
 - PFE, displaying.....608
- notice icons defined.....xxv
- notification statistics, displaying for PFE.....637
- NTP
 - peer status, displaying.....853
 - peer values, displaying.....855

O

- op command.....722
- op scripts
 - converting.....765
 - executing.....722
- operational mode scripts, executing.....722
- output control keys
 - for monitor interface command.....89
 - for monitor interface traffic command.....90
 - for monitor mpls command.....96

P

- P2MP LSPs, testing.....25
- P2MP LSPs, tracing.....130
- Packet Forwarding Engine See PFE
- Packet Forwarding Engine clock generator See PCG
- Packet Gateway Control Protocol See PGCP
- packet headers, transmitted, displaying.....103
- packet size distribution, displaying.....1520
- packet-triggered subscribers and policy control See PTSP
- parentheses, in syntax descriptions.....xxvii
- partial command entry, completing.....546
- partitioning the hard disk
 - aborting.....753
 - requesting.....755
- partitions, backing up.....766
- passive flow monitoring
 - error statistics, displaying.....1493
 - flow statistics, displaying.....1495
 - memory statistics, displaying.....1497
 - PICs, displaying available.....1499
 - statistics, clearing.....1483
 - usage statistics, displaying.....1501
- PCG
 - environmental information, displaying.....266
 - operation of, controlling.....179
- peers
 - clearing Diameter base protocol.....1386
- PEM, environmental information, displaying.....268
- permissions, CLI, displaying.....559
- PFE
 - CFEB statistics, displaying.....589
 - DMA statistics, displaying.....624
 - error statistics, displaying.....628
 - forwarding process status, displaying.....602
 - forwarding statistics, displaying.....602
 - FPC statistics, displaying.....595
 - IPv4 statistics, displaying.....631

IPv6 statistics, displaying.....	634	power consumption	
LCC statistics, displaying.....	605	displaying for a router.....	485
next hops, displaying.....	608	Power Entry Module.....	268
notification statistics, displaying.....	637	power usage	
PCG operation, controlling.....	179	displaying for a router.....	488
polled I/O statistics, displaying.....	639	powering off routing software	
resource usage, displaying.....	653	requesting a system power off.....	757
routing table, displaying.....	612	processes	
SCB information, displaying.....	617	displaying information.....	927
SFM information, displaying.....	619	restarting.....	813
SSB statistics, displaying.....	621	prompt	
terse information, displaying.....	651	setting to display in CLI.....	550
traffic statistics protocol bfd, displaying.....	644	PTSP	
traffic statistics protocol cfm, displaying.....	647	subscriber bandwidth, displaying.....	1749
traffic statistics protocol lfm, displaying.....	649	subscriber dynamic policies, displaying.....	1751
traffic statistics, displaying.....	641	subscriber flows, displaying.....	1754
version, displaying.....	656	subscriber sessions	
PGCP		clearing.....	1748
clear gate statistics.....	1697, 1698	displaying.....	1756
configuration, displaying.....	1699	subscriber statistics, displaying.....	1758
conversations, displaying.....	1731		
flows, displaying.....	1736	Q	
gate information, displaying.....	1708, 1716	queues	
H.248 information, displaying.....	1722	CoS switch fabric statistics, displaying.....	1257
statistics, displaying.....	1724	forwarding class mapping, displaying.....	1259
termination information, displaying.....	1741	statistics, displaying.....	949
PICs		R	
active flow monitoring		radius diagnostics testing.....	53
available PICs, displaying.....	1522	RADIUS information	
CPU usage, displaying.....	1524	displaying.....	1651
installed, displaying list.....	423	random early detection.....	1253
operation of, controlling.....	180	real-time monitoring	
status		Ethernet frame delay measurement	
displaying for a specific PIC.....	478	(ETH-DM).....	79
displaying FPCs and PICs.....	406	Ethernet frame loss-measurement	
ping atm command.....	8	(ETH-LM).....	84
ping clns command.....	10	files.....	99
ping command.....	4	interfaces.....	89
ping mpls l2circuit command.....	12	IP multicast paths.....	112
ping mpls l2vpn command.....	15	RSVP LSPs.....	96
ping mpls l3vpn command.....	18	traffic.....	103
ping mpls ldp command.....	20	rebooting router software	
ping mpls lsp-end-point command.....	23	pending reboots	
ping mpls rsvp command.....	25	clearing.....	714
ping vpls instance command.....	30	displaying.....	955
PKI See certificates, PKI		requesting a system reboot.....	761
polled I/O statistics, displaying for PFE.....	639	RED drop profiles, displaying.....	1253
port mirroring			
displaying.....	1491		

- redundancy group
 - status, displaying, M120 routers.....495
- Remote Monitoring.....684
- remote system access, operational mode
 - commands.....657, 660
- removing
 - backup Junos file.....784
 - files.....578
 - software packages.....781
- renaming files.....581
- replication errors, displaying.....1096
- request chassis cb command.....167
- request chassis cfeb command.....169
- request chassis cib command.....170
- request chassis fpc command.....173
- request chassis fpm resync command.....175
- request chassis lcc command.....177
- request chassis mcs command.....178
- request chassis mic command.....182
- request chassis pcg command.....179
- request chassis pic command.....180
- request chassis redundancy feb slot
 - command.....183
- request chassis routing-engine master
 - command.....184
- request chassis scg command.....188
- request chassis sfm command.....189
- request chassis sfm master switch command.....190
- request chassis sib command.....191
- request chassis sib f13 train-link-receive slot
 - command.....193
- request chassis sib f13 train-link-transmit slot
 - command.....194
- request chassis sib train-link-receive slot
 - command.....195
- request chassis sib train-link-transmit slot
 - command.....196
- request chassis spmb restart command.....197
- request chassis ssb master switch command.....198
- request chassis synchronization mode
 - command.....199
- request chassis synchronization switch
 - command.....200
- request dhcp server reconfigure command.....724
- request dhcpv6 server reconfigure command.....726
- request ipsec switch command.....1588
- request message command.....728
- request routing-engine login command.....729
- request security certificate (signed)
 - command.....1573
- request security certificate (unsigned)
 - command.....1574
- request security key-pair command.....1575
- request security pki ca-certificate enroll
 - command.....1576
- request security pki ca-certificate load
 - command.....1577
- request security pki ca-certificate verify
 - command.....1578
- request security pki crt load command.....1579
- request security pki generate-certificate-request
 - command.....1580
- request security pki generate-key-pair
 - command.....1582
- request security pki local-certificate enroll
 - command.....1583
- request security pki local-certificate
 - generate-self-signed command.....1585
- request security pki local-certificate load
 - command.....1586
- request security pki local-certificate verify
 - command.....1587
- request services flow-collector change-destination
 - primary interface command.....1485
- request services flow-collector change-destination
 - secondary interface command.....1486
- request services flow-collector test-file-transfer
 - command.....1487
- request services ipsec-vpn ipsec switch tunnel
 - command.....1589
- request services static-subscribers login group
 - command.....731
- request services static-subscribers login interface
 - command.....732
- request services static-subscribers logout group
 - command.....733
- request services static-subscribers logout interface
 - command.....734
- request snmp spoof-trap command.....666
- request support information command.....735
- request system certificate add command.....1593
- request system configuration rescue delete
 - command.....741
- request system configuration rescue save
 - command.....742
- request system firmware command.....743
- request system halt command.....744

request system license add command.....	749	rollback	
request system license delete command.....	750	displaying.....	958
request system license save command.....	751	requesting.....	802
request system logout command.....	752	routes, displaying	
request system partition abort command.....	753	to specified network host.....	122
request system partition hard-disk command.....	755	Routing Engines	
request system power-off command.....	757	connections, displaying.....	893
request system reboot command.....	761	environmental information, displaying.....	274
request system scripts convert.....	765	hostname information, displaying.....	1182
request system snapshot command.....	766	login connection, specifying.....	729
request system software abort command.....	772	operation of, controlling.....	184
request system software add command.....	775	status, displaying.....	498
request system software delete command.....	781	switchover information, displaying.....	1096
request system software delete-backup		version information, displaying.....	1182
command.....	784	routing protocol tasks	
request system software in-service-upgrade		displaying.....	1164
command.....	785, 808	statistics, displaying.....	1166
for MX Series 3D Universal Edge Routers.....	789	RPM services	
request system software rollback command.....	802	probe results	
request system software validate command.....	805	history, displaying.....	64
request system storage cleanup command.....	811	recent, displaying.....	67
request virtual-chassis member-id delete		protocols and ports, displaying.....	63
command.....	1207	RPM TWAMP server	
request virtual-chassis member-id set		connections, clearing.....	62
command.....	1208	connections, displaying.....	73
request virtual-chassis routing-engine master		sessions, displaying.....	75
switch command.....	1209	RSVP	
request virtual-chassis vc-port delete		LSP connections	
command.....	1211	operability, checking.....	25
request virtual-chassis vc-port set command.....	1213	LSPs, real-time status.....	96
rescue configuration		tracing LSPs.....	130
deleting.....	741	RSVP LSPs	
displaying.....	891	ping interval.....	25
saving.....	742	S	
restart command.....	813	sampling	
restart-auto-negotiation, performing.....	48	next-hop-groups, displaying.....	1488
restarting		port-mirroring instances, displaying.....	1491
software processes.....	813	SCB	
resynchronizing FPM status.....	175	firmware version, displaying.....	398
reverting to earlier software.....	802	PFE information, displaying.....	617
rewrite rules, displaying		status, displaying.....	510
information.....	1288	SCG	
mapping of code point value to loss		environmental information, displaying.....	277
priority.....	1274	operation, controlling.....	188
mapping of code point value to queue		screen length, setting.....	552
number.....	1274	screen width, setting.....	553
table identifiers.....	1276	scripts	
RMON alarms and events, displaying.....	684	converting.....	765

-
- security certificate See certificates
 - self diagnosis See op scripts
 - serial numbers, displaying.....423
 - services sets
 - CPU usage, displaying.....1765
 - dropped packet statistics
 - clearing.....1763
 - displaying.....1771
 - memory usage, displaying.....1767
 - plug-ins, displaying.....1769
 - summary information, displaying.....1777
 - syslog statistics
 - clearing.....1764
 - displaying.....1773
 - Session and Resource Control.....970
 - set chassis display message command.....201
 - set cli complete-on-space command.....546
 - set cli directory command.....547
 - set cli idle-timeout command.....548
 - set cli logical-system command.....549
 - set cli prompt command.....550
 - set cli restart-on-upgrade command.....551
 - set cli screen-length command.....552
 - set cli screen-width command.....553
 - set cli terminal command.....554
 - set cli timestamp command.....555
 - set date command.....556
 - SFC
 - operation, receiving.....193
 - operation, transmitting.....194
 - SFM
 - environmental information, displaying.....281
 - firmware version, displaying.....398
 - master, determining.....190
 - operation, controlling.....189
 - statistics, displaying.....619
 - status, displaying.....512
 - sha-256 checksum, calculating.....572
 - SHA-1 checksum, calculating.....571
 - show accounting profile command.....152
 - show accounting records command.....156
 - show application-identification
 - application-system-cache command.....1470
 - show arp command.....820
 - show chassis alarms command.....204
 - show chassis cfeb command.....208
 - show chassis cip command.....210
 - show chassis craft-interface command.....212
 - show chassis environment cb command.....237
 - show chassis environment cip command.....248
 - show chassis environment command.....220
 - show chassis environment fpc command.....250
 - show chassis environment fpm command.....260
 - show chassis environment mcs command.....264
 - show chassis environment pcg command.....266
 - show chassis environment pem command.....268
 - show chassis environment routing-engine
 - command.....274
 - show chassis environment scg command.....277
 - show chassis environment sfm command.....281
 - show chassis environment sib command.....284
 - show chassis ethernet-switch command.....304
 - show chassis fabric errors command.....320
 - show chassis fabric fpcs command.....323
 - show chassis fabric plane command.....348
 - show chassis fabric sibs command.....373
 - show chassis fabric topology command.....383
 - show chassis fan command.....317
 - show chassis feb command.....395
 - show chassis firmware command.....398
 - show chassis forwarding command.....405
 - show chassis fpc command.....406
 - show chassis hardware command.....423
 - show chassis in-service-upgrade command.....468
 - show chassis lccs command.....470
 - show chassis location command.....471
 - show chassis mac-addresses command.....474
 - show chassis network services command.....477
 - show chassis pic command.....478
 - show chassis power command.....488, 493
 - show chassis power-ratings command.....485
 - show chassis psd command.....494
 - show chassis redundancy feb command.....495
 - show chassis routing-engine command.....498
 - show chassis scb command.....510
 - show chassis sfm command.....512
 - show chassis sibs command.....515
 - show chassis spmb command.....521
 - show chassis spmb sibs command.....528
 - show chassis ssb command.....532
 - show chassis synchronization command.....534
 - show chassis temperature-thresholds
 - command.....537
 - show class-of-service adaptive-shaper
 - command.....1248
 - show class-of-service classifier command.....1249
 - show class-of-service code-point-aliases
 - command.....1251

show class-of-service command.....	1246	show class-of-service virtual-channel-group	
show class-of-service drop-profile		command.....	1300
command.....	1253	show cli authorization command.....	559
show class-of-service fabric scheduler-map		show cli command.....	557
command.....	1255	show cli directory command.....	562
show class-of-service fabric statistics		show cli history command.....	563
command.....	1257	show configuration command.....	822
show class-of-service forwarding-class		show database-replication statistics	
command.....	1259	command.....	825
show class-of-service forwarding-table classifier		show database-replication summary	
command.....	1264	command.....	826
show class-of-service forwarding-table classifier		show ddos-protection protocols command.....	1427
mapping command.....	1266	show ddos-protection protocols parameters	
show class-of-service forwarding-table		command.....	1439
command.....	1261	show ddos-protection protocols statistics	
show class-of-service forwarding-table drop-profile		command.....	1445
command.....	1267	show ddos-protection protocols violations	
show class-of-service forwarding-table fabric		command.....	1455
scheduler-map command.....	1269	show ddos-protection statistics command.....	1457
show class-of-service forwarding-table		show ddos-protection version command.....	1458
loss-priority-map command.....	1271	show dhcp server binding command.....	828
show class-of-service forwarding-table		show dhcp server statistics command.....	832
loss-priority-map mapping command.....	1273	show dhcpv6 server binding command.....	835
show class-of-service forwarding-table rewrite-rule		show dhcpv6 server statistics command.....	839
command.....	1274	show diameter command.....	1389
show class-of-service forwarding-table rewrite-rule		show diameter function command.....	1395
mapping command.....	1276	show diameter function statistics command.....	1398
show class-of-service forwarding-table		show diameter instance command.....	1401
scheduler-map command.....	1277	show diameter network-element command.....	1403
show class-of-service fragmentation-map		show diameter network-element map	
command.....	1279	command.....	1406
show class-of-service interface command.....	1281	show diameter peer command.....	1409
show class-of-service interface-set		show diameter peer map command.....	1413
command.....	1284	show diameter peer statistics command.....	1416
show class-of-service loss-priority-map		show diameter route command.....	1420
command.....	1286	show dlsw capabilities command.....	1371
show class-of-service rewrite-rule		show dlsw circuits command.....	1372
command.....	1288	show dlsw peers command.....	1374
show class-of-service routing-instance		show dlsw reachability command.....	1376
command.....	1290	show forwarding-options next-hop-group	
show class-of-service scheduler-map		command.....	1488
command.....	1291	show forwarding-options port-mirroring	
show class-of-service traffic-control-profile		command.....	1491
command.....	1293	show host command.....	842
show class-of-service translation-table		show ike security-associations command.....	1594
command.....	1295	show ipsec certificates command.....	1598
show class-of-service virtual-channel		show ipsec redundancy command.....	1601
command.....	1299	show ipsec security-associations command.....	1603
		show llc2 redundancy command.....	1377

show llc2 redundancy interface statistics command.....	1379
show llc2 redundancy mac-translation command.....	1380
show llc2 redundancy track command.....	1381
show lldp command.....	140
show lldp local-information command.....	142
show lldp neighbors command.....	144
show lldp remote-global-statistics command.....	148
show lldp statistics command.....	150
show log command.....	585
show mobile-ip home-agent bindings command.....	1679
show mobile-ip home-agent overview command.....	1682
show mobile-ip home-agent traffic command.....	1683
show mobile-ip home-agent virtual-network command.....	1685
show mobile-ip wimax release command.....	1687
show network-access aaa statistics command.....	843
show network-access aaa subscriber session-id command.....	849
show network-access aaa subscribers command.....	846
show network-access address-assignment pool command.....	852
show network-access gx-plus command.....	1422
show ntp associations command.....	853
show ntp status command.....	855
show passive-monitoring error command.....	1493
show passive-monitoring flow command.....	1495
show passive-monitoring memory command.....	1497
show passive-monitoring status command.....	1499
show passive-monitoring usage command.....	1501
show pfe cfeb command.....	589
show pfe feb command.....	592
show pfe fpc command.....	595
show pfe fwdd command.....	602
show pfe lcc command.....	605
show pfe next-hop command.....	608
show pfe resource usage memory command.....	653
show pfe route command.....	612
show pfe scb command.....	617
show pfe sfm command.....	619
show pfe ssb command.....	621
show pfe statistics dma command.....	624
show pfe statistics error command.....	628
show pfe statistics ip command.....	631
show pfe statistics ip6 command.....	634
show pfe statistics notification command.....	637
show pfe statistics pio command.....	639
show pfe statistics traffic command.....	641
show pfe statistics traffic protocol bfd command.....	644
show pfe statistics traffic protocol cfm command.....	647
show pfe statistics traffic protocol lfm command.....	649
show pfe terse command.....	651
show pfe version command.....	656
show security keychain command.....	1590
show security pki ca-certificate command.....	1606
show security pki certificate-request command.....	1610
show security pki crl command.....	1612
show security pki local-certificate command.....	1614
show services accounting aggregation command.....	1503
show services accounting aggregation template command.....	1507
show services accounting errors command.....	1508
show services accounting flow command.....	1510
show services accounting flow-detail command.....	1513
show services accounting memory command.....	1518
show services accounting packet-size-distribution command.....	1520
show services accounting status command.....	1522
show services accounting usage command.....	1524
show services application-aware-access-list statistics command.....	1468
show services application-identification counter command.....	1472
show services border-signaling-gateway address-of-record bindings command.....	1320
show services border-signaling-gateway admission-control command.....	1323
show services border-signaling-gateway by-contact command.....	1325
show services border-signaling-gateway by-request-uri command.....	1327
show services border-signaling-gateway calls by-server command.....	1330

show services border-signaling-gateway calls by-service-point command.....	1332
show services border-signaling-gateway calls-duration by-server command.....	1334
show services border-signaling-gateway calls-duration by-service-point command.....	1337
show services border-signaling-gateway calls-failed by-server command.....	1340
show services border-signaling-gateway calls-failed by-service-point command.....	1343
show services border-signaling-gateway denied-messages command.....	1346
show services border-signaling-gateway name-resolution-cache command.....	1347
show services border-signaling-gateway registrations command.....	1349
show services border-signaling-gateway routing-blacklist command.....	1351
show services border-signaling-gateway status command.....	1352
show services cos statistics command.....	1365
show services crtp command.....	1357
show services crtp flows command.....	1360
show services dynamic-flow-capture content-destination command.....	1526
show services dynamic-flow-capture control-source command.....	1528
show services dynamic-flow-capture statistics command.....	1530
show services flow-collector file interface command.....	1533
show services flow-collector input interface command.....	1535
show services flow-collector interface command.....	1537
show services flows command.....	1307
show services ids command.....	1548
show services ipsec-vpn certificates command.....	1617
show services ipsec-vpn ike security-associations command.....	1620
show services ipsec-vpn ipsec security-associations command.....	1624
show services ipsec-vpn ipsec statistics command.....	1627
show services l2tp destination command.....	1645
show services l2tp multilink command.....	1648
show services l2tp radius command.....	1651
show services l2tp session command.....	1655
show services l2tp summary command.....	1661
show services l2tp tunnel command.....	1663
show services l2tp user command.....	1667
show services link-services cpu-usage command.....	1672
show services local-policy-decision-function flows command.....	1474
show services local-policy-decision-function statistics command.....	1476
show services nat mapping command.....	1690
show services nat pool command.....	1692
show services pgcp active-configuration command.....	1699
show services pgcp conversations command.....	1731
show services pgcp flows command.....	1736
show services pgcp gate command.....	1708
show services pgcp gates command.....	1716
show services pgcp root-termination command.....	1722
show services pgcp statistics command.....	1724
show services pgcp terminations command.....	1741
show services rpm active-servers command.....	63
show services rpm history-results command.....	64
show services rpm probe-results command.....	67
show services rpm twamp server connection command.....	73
show services rpm twamp server session command.....	75
show services service-sets cpu-usage command.....	1765
show services service-sets memory-usage command.....	1767
show services service-sets plug-ins command.....	1769
show services service-sets statistics packet-drops command.....	1771
show services service-sets statistics syslog command.....	1773
show services service-sets statistics tcp-mss command.....	1776
show services service-sets summary command.....	1777
show services softwire command.....	1781
show services stateful-firewall conversations command.....	1794
show services stateful-firewall flows command.....	1798
show services stateful-firewall sip-call command.....	1803

-
- show services stateful-firewall sip-register
 - command.....1808
 - show services stateful-firewall statistics
 - application-protocol sip command.....1816
 - show services stateful-firewall statistics
 - command.....1812
 - show services subscriber bandwidth
 - command.....1749
 - show services subscriber dynamic-policies
 - command.....1751
 - show services subscriber flows command.....1754
 - show services subscriber sessions command.....1756
 - show services subscriber statistics
 - command.....1758
 - show snmp health-monitor command.....672
 - show snmp inform-statistics command.....679
 - show snmp mib command.....681
 - show snmp rmon command.....684
 - show snmp statistics command.....688
 - show snmp v3 command.....692
 - show static-subscribers sessions command.....856
 - show subscribers command.....858
 - show system alarms command.....866
 - show system audit command.....867
 - show system autoinstallation status
 - command.....874
 - show system boot-messages command.....875
 - show system buffers command.....882
 - show system certificate command.....1630
 - show system commit command.....888
 - show system configuration archival
 - command.....890
 - show system configuration rescue command.....891
 - show system connections command.....893
 - show system core-dumps command.....911
 - show system directory-usage command.....917
 - show system firmware command.....920
 - show system license command.....922
 - show system processes command.....927
 - show system queues command.....949
 - show system reboot command.....955
 - show system rollback command.....958
 - show system services dhcp binding
 - command.....960
 - show system services dhcp conflict
 - command.....963
 - show system services dhcp global command.....964
 - show system services dhcp pool command.....966
 - show system services dhcp statistics
 - command.....968
 - show system services service-deployment
 - command.....970
 - show system snapshot command.....971
 - show system software command.....974
 - show system statistics arp command.....1014
 - show system statistics clns command.....1020
 - show system statistics
 - command.713, 728, 741, 888, 980, 1100, 1194, 1204, 1593
 - show system statistics esis command.....1025
 - show system statistics icmp command.....1029
 - show system statistics icmp6 command.....1033
 - show system statistics igmp command.....1038
 - show system statistics ip command.....1041
 - show system statistics ip6 command.....1049
 - show system statistics mpls command.....1056
 - show system statistics rdp command.....1060
 - show system statistics tcp command.....1064
 - show system statistics tnp command.....1072
 - show system statistics tudp command.....1078
 - show system statistics udp command.....1081
 - show system statistics vpls command.....1084
 - show system storage command.....1089
 - show system subscriber-management summary
 - command.....1094
 - show system switchover command.....1096
 - show system uptime command.....1100
 - show system users command.....1104
 - show system virtual-memory command.....1108
 - show task command.....1164
 - show task io command.....1166
 - show task memory command.....1168
 - show task replication command.....1172
 - show version command.....1174
 - show version invoke-on command.....1182
 - show virtual-chassis active-topology
 - command.....1215
 - show virtual-chassis device-topology
 - command.....1217
 - show virtual-chassis protocol adjacency
 - command.....1219
 - show virtual-chassis protocol database
 - command.....1223
 - show virtual-chassis protocol interface
 - command.....1228
 - show virtual-chassis protocol route
 - command.....1231

show virtual-chassis protocol statistics	
command.....	1234
show virtual-chassis status command.....	1237
show virtual-chassis vc-port command.....	1239
SIB	
environmental information, displaying.....	284
information, displaying.....	515
operation, controlling.....	191
SPMB status, displaying.....	528
status, displaying.....	515
switch fabric status, displaying.....	373
switch fabric topology, displaying.....	383
Simple Network Management Protocol <i>See</i> SNMP	
SLAX	
converting to XSLT.....	765
SNMP	
health monitor alarms, displaying.....	672
inform statistics, displaying.....	679
MIB object values, displaying.....	681
RMON alarms and events, displaying.....	684
statistics	
clearing.....	664
displaying.....	688
version 3 configuration, displaying.....	692
SNMP inform statistics, displaying.....	679
SNMP traps	
spoofing.....	666
sockets, displaying active IP.....	893
software <i>See</i> Junos OS	
softwire.....	1779
SONET Clock Generator <i>See</i> SCG	
SPMB	
information, displaying.....	521
restarting.....	197
SIB status, displaying.....	528
SRC client information, displaying.....	970
SSB	
firmware version, displaying.....	398
operation, controlling.....	198
statistics, displaying.....	621
status, displaying.....	532
ssh command.....	658
SSH, opening a connection.....	658
start shell command.....	1194
startup messages, displaying.....	875
stateful firewall	
conversations	
displaying.....	1794
flows	
clearing.....	1785
displaying.....	1798
SIP call information	
clearing.....	1787
displaying.....	1803
SIP register information	
clearing.....	1790
displaying.....	1808
SIP statistics	
displaying.....	1816
statistics	
clearing.....	1793
displaying.....	1812
static subscribers	
forced group logout.....	733
forced logout.....	734
interface group state reset.....	731
interface state reset.....	732
session status	
displaying.....	856
statistics	
ACL	
clearing.....	1462
active flow error.....	1508
active flow instances.....	1510
active flow memory utilization.....	1518
aggregated active flow.....	1503
DHCP server, displaying.....	968
dynamic flow capture	
clearing.....	1482
displaying.....	1530
interfaces, real-time.....	89
L-PDF	
clearing.....	1465
LLDP.....	139
protocol-related, displaying.....	980
routing protocol I/O, displaying.....	1166
system queues, displaying.....	949
T640 router, displaying.....	605
storage space, freeing.....	811
subscriber access	
subscriber information, displaying.....	858
subscriber management database	
statistics information, displaying.....	825
summary information, displaying.....	826, 1094

subscribers
 displaying.....858
 support, technical See technical support
 system information, displaying.....735
 switch fabric
 errors, displaying.....320
 queue statistics, displaying.....1257
 scheduler mapping, displaying.....1255, 1269
 status, displaying.....323, 373
 switch fabric topology, displaying.....383
 Switch Interface Board See SIB
 Switch Processor Mezzanine Board See SPMB
 Switching and Forwarding Module.....189
 See also SFM
 switchover, displaying information about.....1096
 synchronization (MX Series).....199
 synchronization source, displaying.....534
 synchronized Ethernet
 Sync-E.....199
 syntax conventions.....xxvi
 syntax of configuration files, verifying.....1204
 System and Switch Board See SSB
 System Control Board See SCB

T

T640 router
 operation of, controlling.....177
 statistics, displaying.....605
 status, displaying.....470
 tasks
 I/O statistics, displaying.....1166
 memory usage, displaying.....1168
 protocol, displaying.....1164
 tcp-mss
 statistics, displaying.....1776
 technical support
 contacting JTAC.....xxvii
 system information, displaying.....735
 telnet command.....660
 templates
 flow aggregation.....1507
 terminal screen length, setting.....552
 terminal screen width, setting.....553
 terminal type
 setting.....554
 terminating partitioning operation.....753
 test aaa authd-lite user command.....1196
 test aaa dhcp user command.....1198
 test aaa ppp user command.....1201

test access profile command.....54
 test access radius-server command.....58
 test configuration command.....1204
 test interface fdl-line-loop command.....41
 test interface fdl-payload-loop command.....43
 test interface feac-loop-initiate command.....44
 test interface feac-loop-terminate command.....45
 test interface inband-line-loop command.....46
 test interface inband-payload-loop command.....47
 test interface restart-auto-negotiation
 command.....48
 test interface ds0-bert-start command.....35
 test interface ds0-bert-stop command.....36
 test interface e1-bert-start command.....37
 test interface e1-bert-stop command.....38
 test interface e3-bert-start command.....39
 test interface e3-bert-stop command.....40
 test interface t1-bert-start command.....49
 test interface t1-bert-stop command.....50
 test interface t3-bert-start command.....51
 test interface t3-bert-stop command.....52
 text message on craft interface
 clearing.....165
 displaying.....201
 time, displaying.....1100
 timeout, user, setting.....548
 timestamp, CLI output, setting.....555
 topic1.....1781
 topic2
 sub-topic.....1781
 trace files
 display of
 starting.....100
 stopping.....102
 status, displaying.....99
 traceroute command.....122
 traceroute monitor command.....125
 traceroute mpls ldp.....127
 traceroute mpls ldp command.....127
 traceroute mpls rsvp.....130
 traceroute mpls rsvp command.....130
 tracing IP multicast path
 from receiver to source.....112
 from router to gateway.....119
 from server to router.....114
 tracing routes
 from the receiver to the source.....112
 from the source to the gateway router.....119

from the source to the receiver.....	114
monitoring.....	117
traffic, real-time monitoring.....	103
traps	
spoofing.....	666
tty connections	
specifying for login.....	729
TWAMP server	
connections, clearing.....	62
connections, displaying.....	73
sessions, displaying.....	75

U

unified in-service software upgrade See unified ISSU	
Unified in-service software upgrade See Unified	
ISSU for MX Series 3D Universal Edge Routers	
unified ISSU.....	785
aborting.....	772
status, displaying.....	468
validating requirements.....	808
Unified ISSU for MX Series 3D Universal Edge	
Routers.....	789
UNIX-level shell, creating.....	1194
upgrading software	
performing.....	775
uptime, displaying.....	1100
user timeout, setting.....	548
users	
CLI permissions, displaying.....	559
logged in, displaying.....	1104
logging users out.....	752
logs, displaying.....	585
messages, displaying for.....	728

V

validating software.....	805
verifying syntax of configuration file.....	1204
version	
firmware, displaying.....	398
software, displaying	
for two Routing Engines.....	1182
general.....	1174
Virtual Chassis commands	
request virtual-chassis member-id	
delete.....	1207
request virtual-chassis member-id set.....	1208
request virtual-chassis routing-engine master	
switch.....	1209
request virtual-chassis vc-port delete.....	1211

request virtual-chassis vc-port set.....	1213
show virtual-chassis active-topology.....	1215
show virtual-chassis device-topology.....	1217
show virtual-chassis protocol database.....	1223
show virtual-chassis protocol interface.....	1228
show virtual-chassis protocol route.....	1231
show virtual-chassis protocol statistics.....	1234
show virtual-chassis status.....	1237
show virtual-chassis vc-port.....	1239
Virtual Chassis, operational mode	
commands.....	1205
virtual memory, displaying.....	1108
VPLS	
testing connectivity.....	30

W

working directory	
current, displaying.....	562
current, setting.....	547

X

XSLT	
converting to SLAX.....	765

Index of Statements and Commands

C

chassis	
synchronization (MX Series).....	199
clear arp command.....	703
clear chassis display message command.....	165
clear cli logical-system command.....	545
clear ddos-protection protocols command.....	1426
clear dhcp server binding command.....	704
clear dhcp server statistics command.....	706
clear dhcpv6 server binding command.....	708
clear dhcpv6 server statistics command.....	710
clear diameter function statistics command.....	1385
clear diameter peer command.....	1386
clear dlsw reachability command.....	1370
clear ike security-associations command.....	1561
clear ipsec security-associations command.....	1562
clear lldp neighbor command.....	138
clear lldp statistics command.....	139
clear log command.....	567
clear mobile-ip binding command.....	1678
clear network-access aaa statistics command.....	711
clear network-access aaa subscriber command.....	712
clear network-access gx-plus replay command.....	1387
clear network-access gx-plus statistics command.....	1388
clear passive-monitoring statistics command.....	1483
clear security pki ca-certificate command.....	1564
clear security pki certificate-request command.....	1565
clear security pki crl command.....	1566
clear security pki key-pair.....	1567
clear security pki local-certificate command.....	1568
clear services application-aware-access-list statistics command.....	1462
clear services application-identification application-system-cache command.....	1461
clear services application-identification counter command.....	1463
clear services border-signaling-gateway denied-messages command.....	1315
clear services border-signaling-gateway name-resolution-cache command.....	1316
clear services border-signaling-gateway registrations statistics command.....	1317
clear services border-signaling-gateway registrations subscription, command.....	1318
clear services border-signaling-gateway statistics command.....	1319
clear services cos statistics command.....	1364
clear services crtp statistics command.....	1356
clear services dynamic-flow-capture command.....	1482
clear services flow-collector statistics command.....	1484
clear services flows command.....	1304
clear services flows ip-action command.....	1464
clear services ids command.....	1544
clear services ids destination-table command.....	1545
clear services ids pair-table command.....	1546
clear services ids source-table command.....	1547
clear services ipsec-vpn certificates command.....	1569
clear services ipsec-vpn ike security-associations command.....	1570
clear services ipsec-vpn ipsec security-associations command.....	1572
clear services ipsec-vpn ipsec statistics command.....	1571
clear services l2tp destination command.....	1635
clear services l2tp multilink command.....	1636
clear services l2tp session command.....	1637
clear services l2tp session statistics command.....	1639
clear services l2tp tunnel command.....	1641
clear services l2tp tunnel statistics command.....	1643

clear services local-policy-decision-function statistics command.....	1465
clear services pgcp command.....	1697
clear services pgcp statistics command.....	1698
clear services rpm twamp server connection command.....	62
clear services service-sets statistics packet-drops command.....	1763
clear services service-sets statistics syslog command.....	1764
clear services software statistics command.....	1780
clear services stateful-firewall flows command.....	1785
clear services stateful-firewall sip-call command.....	1787
clear services stateful-firewall sip-register command.....	1790
clear services stateful-firewall statistics command.....	1793
clear services subscriber sessions command.....	1748
clear snmp statistics command.....	664
clear system commit command.....	713
clear system reboot command.....	714
clear system services dhcp binding command.....	717
clear system services dhcp conflict command.....	718
clear system services dhcp statistics command.....	719
command-name command.....	1466
configure command.....	720

F

file archive command.....	568
file checksum md5 command.....	570
file checksum sha-256 command.....	572
file checksum sha1 command.....	571
file compare command.....	573
file copy command.....	576
file delete command.....	578
file list command.....	579
file rename command.....	581
file show command.....	583

M

monitor ethernet delay-measurement command.....	79
monitor ethernet loss-measurement command.....	84
monitor interface command.....	89
monitor label-switched-path command.....	96

monitor list command.....	99
monitor start command.....	100
monitor stop command.....	102
monitor traffic command.....	103
mtrace command.....	112
mtrace from-source command.....	114
mtrace monitor command.....	117
mtrace to-gateway command.....	119

O

op command.....	722
-----------------	-----

P

ping atm command.....	8
ping clns command.....	10
ping command.....	4
ping mpls l2circuit command.....	12
ping mpls l2vpn command.....	15
ping mpls l3vpn command.....	18
ping mpls ldp command.....	20
ping mpls lsp-end-point command.....	23
ping mpls rsvp command.....	25
ping vpls instance command.....	30

R

request chassis cb command.....	167
request chassis cfeb command.....	169
request chassis cib command.....	170
request chassis fpc command.....	173
request chassis fpm resync command.....	175
request chassis lcc command.....	177
request chassis mcs command.....	178
request chassis mic command.....	182
request chassis pcg command.....	179
request chassis pic command.....	180
request chassis redundancy feb slot command.....	183
request chassis routing-engine master command.....	184
request chassis scg command.....	188
request chassis sfm command.....	189
request chassis sfm master switch command.....	190
request chassis sib command.....	191
request chassis sib f13 train-link-receive slot command.....	193
request chassis sib f13 train-link-transmit slot command.....	194
request chassis sib train-link-receive slot command.....	195

request chassis sib train-link-transmit slot command.....	196	request services static-subscribers logout group command.....	733
request chassis spmb restart command.....	197	request services static-subscribers logout interface command.....	734
request chassis ssb master switch command.....	198	request snmp spoof-trap command.....	666
request chassis synchronization mode command.....	199	request support information command.....	735
request chassis synchronization switch command.....	200	request system certificate add command.....	1593
request dhcp server reconfigure command.....	724	request system configuration rescue delete command.....	741
request dhcpv6 server reconfigure command.....	726	request system configuration rescue save command.....	742
request ipsec switch command.....	1588	request system firmware command.....	743
request message command.....	728	request system halt command.....	744
request routing-engine login command.....	729	request system license add command.....	749
request security certificate (signed) command.....	1573	request system license delete command.....	750
request security certificate (unsigned) command.....	1574	request system license save command.....	751
request security key-pair command.....	1575	request system logout command.....	752
request security pki ca-certificate enroll command.....	1576	request system partition abort command.....	753
request security pki ca-certificate load command.....	1577	request system partition hard-disk command.....	755
request security pki ca-certificate verify command.....	1578	request system power-off command.....	757
request security pki crt load command.....	1579	request system reboot command.....	761
request security pki generate-certificate-request command.....	1580	request system scripts convert.....	765
request security pki generate-key-pair command.....	1582	request system snapshot command.....	766
request security pki local-certificate enroll command.....	1583	request system software abort command.....	772
request security pki local-certificate generate-self-signed command.....	1585	request system software add command.....	775
request security pki local-certificate load command.....	1586	request system software delete command.....	781
request security pki local-certificate verify command.....	1587	request system software delete-backup command.....	784
request services flow-collector change-destination primary interface command.....	1485	request system software in-service-upgrade command.....	785, 808
request services flow-collector change-destination secondary interface command.....	1486	for MX Series 3D Universal Edge Routers.....	789
request services flow-collector test-file-transfer command.....	1487	request system software rollback command.....	802
request services ipsec-vpn ipsec switch tunnel command.....	1589	request system software validate command.....	805
request services static-subscribers login group command.....	731	request system storage cleanup command.....	811
request services static-subscribers login interface command.....	732	request virtual-chassis member-id delete command.....	1207
		request virtual-chassis member-id set command.....	1208
		request virtual-chassis routing-engine master switch command.....	1209
		request virtual-chassis vc-port delete command.....	1211
		request virtual-chassis vc-port set command.....	1213
		restart command.....	813

S

set chassis display message command.....	201
set cli complete-on-space command.....	546
set cli directory command.....	547

set cli idle-timeout command.....	548
set cli logical-system command.....	549
set cli prompt command.....	550
set cli restart-on-upgrade command.....	551
set cli screen-length command.....	552
set cli screen-width command.....	553
set cli terminal command.....	554
set cli timestamp command.....	555
set date command.....	556
show accounting profile command.....	152
show accounting records command.....	156
show application-identification application-system-cache command.....	1470
show arp command.....	820
show chassis alarms command.....	204
show chassis cfeb command.....	208
show chassis cip command.....	210
show chassis craft-interface command.....	212
show chassis environment cb command.....	237
show chassis environment cip command.....	248
show chassis environment command.....	220
show chassis environment fpc command.....	250
show chassis environment fpm command.....	260
show chassis environment mcs command.....	264
show chassis environment pcg command.....	266
show chassis environment pem command.....	268
show chassis environment routing-engine command.....	274
show chassis environment scg command.....	277
show chassis environment sfm command.....	281
show chassis environment sib command.....	284
show chassis ethernet-switch command.....	304
show chassis fabric errors command.....	320
show chassis fabric fpcs command.....	323
show chassis fabric plane command.....	348
show chassis fabric sibs command.....	373
show chassis fabric topology command.....	383
show chassis fan command.....	317
show chassis feb command.....	395
show chassis firmware command.....	398
show chassis forwarding command.....	405
show chassis fpc command.....	406
show chassis hardware command.....	423
show chassis in-service-upgrade command.....	468
show chassis lccs command.....	470
show chassis location command.....	471
show chassis mac-addresses command.....	474
show chassis network services command.....	477
show chassis pic command.....	478
show chassis power command.....	488, 493
show chassis power-ratings command.....	485
show chassis psd command.....	494
show chassis redundancy feb command.....	495
show chassis routing-engine command.....	498
show chassis scb command.....	510
show chassis sfm command.....	512
show chassis sibs command.....	515
show chassis spmb command.....	521
show chassis spmb sibs command.....	528
show chassis ssb command.....	532
show chassis synchronization command.....	534
show chassis temperature-thresholds command.....	537
show class-of-service adaptive-shaper command.....	1248
show class-of-service classifier command.....	1249
show class-of-service code-point-aliases command.....	1251
show class-of-service command.....	1246
show class-of-service drop-profile command.....	1253
show class-of-service fabric scheduler-map command.....	1255
show class-of-service fabric statistics command.....	1257
show class-of-service forwarding-class command.....	1259
show class-of-service forwarding-table classifier command.....	1264
show class-of-service forwarding-table classifier mapping command.....	1266
show class-of-service forwarding-table command.....	1261
show class-of-service forwarding-table drop-profile command.....	1267
show class-of-service forwarding-table fabric scheduler-map command.....	1269
show class-of-service forwarding-table loss-priority-map command.....	1271
show class-of-service forwarding-table loss-priority-map mapping command.....	1273
show class-of-service forwarding-table rewrite-rule command.....	1274
show class-of-service forwarding-table rewrite-rule mapping command.....	1276
show class-of-service forwarding-table scheduler-map command.....	1277

show class-of-service fragmentation-map command.....	1279	show diameter network-element map command.....	1406
show class-of-service interface command.....	1281	show diameter peer command.....	1409
show class-of-service interface-set command.....	1284	show diameter peer map command.....	1413
show class-of-service loss-priority-map command.....	1286	show diameter peer statistics command.....	1416
show class-of-service rewrite-rule command.....	1288	show diameter route command.....	1420
show class-of-service routing-instance command.....	1290	show dlsw capabilities command.....	1371
show class-of-service scheduler-map command.....	1291	show dlsw circuits command.....	1372
show class-of-service traffic-control-profile command.....	1293	show dlsw peers command.....	1374
show class-of-service translation-table command.....	1295	show dlsw reachability command.....	1376
show class-of-service virtual-channel command.....	1299	show forwarding-options next-hop-group command.....	1488
show class-of-service virtual-channel-group command.....	1300	show forwarding-options port-mirroring command.....	1491
show cli authorization command.....	559	show host command.....	842
show cli command.....	557	show ike security-associations command.....	1594
show cli directory command.....	562	show ipsec certificates command.....	1598
show cli history command.....	563	show ipsec redundancy command.....	1601
show configuration command.....	822	show ipsec security-associations command.....	1603
show database-replication statistics command.....	825	show llc2 redundancy command.....	1377
show database-replication summary command.....	826	show llc2 redundancy interface statistics command.....	1379
show ddos-protection protocols command.....	1427	show llc2 redundancy mac-translation command.....	1380
show ddos-protection protocols parameters command.....	1439	show llc2 redundancy track command.....	1381
show ddos-protection protocols statistics command.....	1445	show lldp command.....	140
show ddos-protection protocols violations command.....	1455	show lldp local-information command.....	142
show ddos-protection statistics command.....	1457	show lldp neighbors command.....	144
show ddos-protection version command.....	1458	show lldp remote-global-statistics command.....	148
show dhcp server binding command.....	828	show lldp statistics command.....	150
show dhcp server statistics command.....	832	show log command.....	585
show dhcpv6 server binding command.....	835	show mobile-ip home-agent bindings command.....	1679
show dhcpv6 server statistics command.....	839	show mobile-ip home-agent overview command.....	1682
show diameter command.....	1389	show mobile-ip home-agent traffic command.....	1683
show diameter function command.....	1395	show mobile-ip home-agent virtual-network command.....	1685
show diameter function statistics command.....	1398	show mobile-ip wimax release command.....	1687
show diameter instance command.....	1401	show network-access aaa statistics command.....	843
show diameter network-element command.....	1403	show network-access aaa subscriber session-id command.....	849
		show network-access aaa subscribers command.....	846
		show network-access address-assignment pool command.....	852
		show network-access gx-plus command.....	1422

show ntp associations command.....	853
show ntp status command.....	855
show passive-monitoring error command.....	1493
show passive-monitoring flow command.....	1495
show passive-monitoring memory command.....	1497
show passive-monitoring status command.....	1499
show passive-monitoring usage command.....	1501
show pfe cfeb command.....	589
show pfe feb command.....	592
show pfe fpc command.....	595
show pfe fwdd command.....	602
show pfe lcc command.....	605
show pfe next-hop command.....	608
show pfe resource usage memory command.....	653
show pfe route command.....	612
show pfe scb command.....	617
show pfe sfm command.....	619
show pfe ssb command.....	621
show pfe statistics dma command.....	624
show pfe statistics error command.....	628
show pfe statistics ip command.....	631
show pfe statistics ip6 command.....	634
show pfe statistics notification command.....	637
show pfe statistics pio command.....	639
show pfe statistics traffic command.....	641
show pfe statistics traffic protocol bfd command.....	644
show pfe statistics traffic protocol cfm command.....	647
show pfe statistics traffic protocol lfm command.....	649
show pfe terse command.....	651
show pfe version command.....	656
show security keychain command.....	1590
show security pki ca-certificate command.....	1606
show security pki certificate-request command.....	1610
show security pki crl command.....	1612
show security pki local-certificate command.....	1614
show services accounting aggregation command.....	1503
show services accounting aggregation template command.....	1507
show services accounting errors command.....	1508
show services accounting flow command.....	1510
show services accounting flow-detail command.....	1513
show services accounting memory command.....	1518
show services accounting packet-size-distribution command.....	1520
show services accounting status command.....	1522
show services accounting usage command.....	1524
show services application-aware-access-list statistics command.....	1468
show services application-identification counter command.....	1472
show services border-signaling-gateway address-of-record bindings command.....	1320
show services border-signaling-gateway admission-control command.....	1323
show services border-signaling-gateway by-contact command.....	1325
show services border-signaling-gateway by-request-uri command.....	1327
show services border-signaling-gateway calls by-server command.....	1330
show services border-signaling-gateway calls by-service-point command.....	1332
show services border-signaling-gateway calls-duration by-server command.....	1334
show services border-signaling-gateway calls-duration by-service-point command.....	1337
show services border-signaling-gateway calls-failed by-server command.....	1340
show services border-signaling-gateway calls-failed by-service-point command.....	1343
show services border-signaling-gateway denied-messages command.....	1346
show services border-signaling-gateway name-resolution-cache command.....	1347
show services border-signaling-gateway registrations command.....	1349
show services border-signaling-gateway routing-blacklist command.....	1351
show services border-signaling-gateway status command.....	1352
show services cos statistics command.....	1365
show services crtp command.....	1357
show services crtp flows command.....	1360
show services dynamic-flow-capture content-destination command.....	1526
show services dynamic-flow-capture control-source command.....	1528
show services dynamic-flow-capture statistics command.....	1530

show services flow-collector file interface command.....	1533	show services service-sets cpu-usage command.....	1765
show services flow-collector input interface command.....	1535	show services service-sets memory-usage command.....	1767
show services flow-collector interface command.....	1537	show services service-sets plug-ins command.....	1769
show services flows command.....	1307	show services service-sets statistics packet-drops command.....	1771
show services ids command.....	1548	show services service-sets statistics syslog command.....	1773
show services ipsec-vpn certificates command.....	1617	show services service-sets statistics tcp-mss command.....	1776
show services ipsec-vpn ike security-associations command.....	1620	show services service-sets summary command.....	1777
show services ipsec-vpn ipsec security-associations command.....	1624	show services softwire command.....	1781
show services ipsec-vpn ipsec statistics command.....	1627	show services stateful-firewall conversations command.....	1794
show services l2tp destination command.....	1645	show services stateful-firewall flows command.....	1798
show services l2tp multilink command.....	1648	show services stateful-firewall sip-call command.....	1803
show services l2tp radius command.....	1651	show services stateful-firewall sip-register command.....	1808
show services l2tp session command.....	1655	show services stateful-firewall statistics application-protocol sip command.....	1816
show services l2tp summary command.....	1661	show services stateful-firewall statistics command.....	1812
show services l2tp tunnel command.....	1663	show services subscriber bandwidth command.....	1749
show services l2tp user command.....	1667	show services subscriber dynamic-policies command.....	1751
show services link-services cpu-usage command.....	1672	show services subscriber flows command.....	1754
show services local-policy-decision-function flows command.....	1474	show services subscriber sessions command.....	1756
show services local-policy-decision-function statistics command.....	1476	show services subscriber statistics command.....	1758
show services nat mapping command.....	1690	show snmp health-monitor command.....	672
show services nat pool command.....	1692	show snmp inform-statistics command.....	679
show services pgcp active-configuration command.....	1699	show snmp mib command.....	681
show services pgcp conversations command.....	1731	show snmp rmon command.....	684
show services pgcp flows command.....	1736	show snmp statistics command.....	688
show services pgcp gate command.....	1708	show snmp v3 command.....	692
show services pgcp gates command.....	1716	show static-subscribers sessions command.....	856
show services pgcp root-termination command.....	1722	show subscribers command.....	858
show services pgcp statistics command.....	1724	show system alarms command.....	866
show services pgcp terminations command.....	1741	show system audit command.....	867
show services rpm active-servers command.....	63	show system autoinstallation status command.....	874
show services rpm history-results command.....	64	show system boot-messages command.....	875
show services rpm probe-results command.....	67	show system buffers command.....	882
show services rpm twamp server connection command.....	73		
show services rpm twamp server session command.....	75		

show system certificate command.....	1630
show system commit command.....	888
show system configuration archival command.....	890
show system configuration rescue command.....	891
show system connections command.....	893
show system core-dumps command.....	911
show system directory-usage command.....	917
show system firmware command.....	920
show system license command.....	922
show system processes command.....	927
show system queues command.....	949
show system reboot command.....	955
show system rollback command.....	958
show system services dhcp binding command.....	960
show system services dhcp conflict command.....	963
show system services dhcp global command.....	964
show system services dhcp pool command.....	966
show system services dhcp statistics command.....	968
show system services service-deployment command.....	970
show system snapshot command.....	971
show system software command.....	974
show system statistics arp command.....	1014
show system statistics clns command.....	1020
show system statistics command.....	713, 728, 741, 888, 980, 1100, 1194, 1204, 1593
show system statistics esis command.....	1025
show system statistics icmp command.....	1029
show system statistics icmp6 command.....	1033
show system statistics igmp command.....	1038
show system statistics ip command.....	1041
show system statistics ip6 command.....	1049
show system statistics mpls command.....	1056
show system statistics rdp command.....	1060
show system statistics tcp command.....	1064
show system statistics tnp command.....	1072
show system statistics tudp command.....	1078
show system statistics udp command.....	1081
show system statistics vpls command.....	1084
show system storage command.....	1089
show system subscriber-management summary command.....	1094
show system switchover command.....	1096
show system uptime command.....	1100
show system users command.....	1104
show system virtual-memory command.....	1108
show task command.....	1164
show task io command.....	1166
show task memory command.....	1168
show task replication command.....	1172
show version command.....	1174
show version invoke-on command.....	1182
show virtual-chassis active-topology command.....	1215
show virtual-chassis device-topology command.....	1217
show virtual-chassis protocol adjacency command.....	1219
show virtual-chassis protocol database command.....	1223
show virtual-chassis protocol interface command.....	1228
show virtual-chassis protocol route command.....	1231
show virtual-chassis protocol statistics command.....	1234
show virtual-chassis status command.....	1237
show virtual-chassis vc-port command.....	1239
ssh command.....	658
start shell command.....	1194
synchronization (MX Series).....	199
 T	
telnet command.....	660
test aaa authd-lite user command.....	1196
test aaa dhcp user command.....	1198
test aaa ppp user command.....	1201
test access profile command.....	54
test access radius-server command.....	58
test configuration command.....	1204
test interface fdl-line-loop command.....	41
test interface fdl-payload-loop command.....	43
test interface feac-loop-initiate command.....	44
test interface feac-loop-terminate command.....	45
test interface inband-line-loop command.....	46
test interface inband-payload-loop command.....	47
test interface restart-auto-negotiation command.....	48
test interface ds0-bert-start command.....	35
test interface ds0-bert-stop command.....	36
test interface e1-bert-start command.....	37
test interface e1-bert-stop command.....	38
test interface e3-bert-start command.....	39
test interface e3-bert-stop command.....	40

test interface t1-bert-start command.....	49
test interface t1-bert-stop command.....	50
test interface t3-bert-start command.....	51
test interface t3-bert-stop command.....	52
traceroute command.....	122
traceroute monitor command.....	125
traceroute mpls ldp command.....	127
traceroute mpls rsvp command.....	130

