



---

Junos<sup>®</sup> OS

# Subscriber Interfaces Over MPLS Pseudowires Feature Guide

Release  
13.2



---

Published: 2013-07-31

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, California 94089  
USA  
408-745-2000  
[www.juniper.net](http://www.juniper.net)

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

*Junos® OS Subscriber Interfaces Over MPLS Pseudowires Feature Guide*

13.2

Copyright © 2013, Juniper Networks, Inc.  
All rights reserved.

The information in this document is current as of the date on the title page.

## YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

## END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

# Table of Contents

	About the Documentation . . . . .	ix
	Documentation and Release Notes . . . . .	ix
	Supported Platforms . . . . .	ix
	Using the Examples in This Manual . . . . .	ix
	Merging a Full Example . . . . .	x
	Merging a Snippet . . . . .	x
	Documentation Conventions . . . . .	xi
	Documentation Feedback . . . . .	xiii
	Requesting Technical Support . . . . .	xiii
	Self-Help Online Tools and Resources . . . . .	xiii
	Opening a Case with JTAC . . . . .	xiv
<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Subscriber Interfaces Over MPLS Pseudowires in Subscriber Access Networks . . . . .</b>	<b>3</b>
	Pseudowire Subscriber Logical Interfaces Overview . . . . .	3
	Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview . . . . .	5
	CoS Two-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces . . . . .	5
	CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces . . . . .	7
	Three-Level Scheduling Hierarchy: Pseudowire Logical Interfaces over a Transport Logical Interface . . . . .	8
	Three-Level Scheduling Hierarchy : Pseudowire Service Logical Interfaces over a Pseudowire Service Interface Set . . . . .	8
	Three-Level Scheduling Hierarchy Combined Deployment Scenario . . . . .	9
<b>Part 2</b>	<b>Configuration</b>	
<b>Chapter 2</b>	<b>Configuration Tasks for Subscriber Interfaces over MPLS Pseudowires . . . . .</b>	<b>13</b>
	Configuring a Pseudowire Subscriber Logical Interface . . . . .	13
	Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router . . . . .	15
	Configuring a Pseudowire Subscriber Logical Interface Device . . . . .	15
	Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface . . . . .	17
	Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces . . . . .	17

	Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces . . . . .	18
	Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface . . . . .	19
<b>Chapter 3</b>	<b>CoS Configuration Tasks for Subscriber Interfaces over MPLS Pseudowires . . . . .</b>	<b>21</b>
	CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces . . . . .	21
	Configuring CoS Two-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces . . . . .	22
	Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces (Logical Interfaces over a Transport Logical Interface) . . . . .	24
	Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces (Logical Interfaces over a Pseudowire Interface Set) . . . . .	26
<b>Chapter 4</b>	<b>Configuration Statements . . . . .</b>	<b>29</b>
	anchor-point (Pseudowire Subscriber Interfaces) . . . . .	29
	device-count (Pseudowire Subscriber Interfaces) . . . . .	30
	encapsulation (Logical Interface) . . . . .	31
	flexible-vlan-tagging . . . . .	35
	hierarchical-scheduler (Subscriber Interfaces on MX Series Routers) . . . . .	36
	input-hierarchical-policer . . . . .	37
	mtu . . . . .	38
	no-gratuitous-arp-request . . . . .	40
	no-vlan-id-validate . . . . .	40
	ps0 (Pseudowire Subscriber Interfaces) . . . . .	41
	pseudowire-service (Pseudowire Subscriber Interfaces) . . . . .	42
	stacked-vlan-tagging . . . . .	42
	unit . . . . .	43
	untagged . . . . .	49
	vlan-tagging . . . . .	50
<b>Part 3</b>	<b>Administration</b>	
<b>Chapter 5</b>	<b>Monitoring Commands . . . . .</b>	<b>53</b>
	show interfaces ps0 (Pseudowire Subscriber Interfaces) . . . . .	54
<b>Part 4</b>	<b>Troubleshooting</b>	
<b>Chapter 6</b>	<b>Acquiring Troubleshooting Information . . . . .</b>	<b>59</b>
	Collecting Subscriber Access Logs Before Contacting Juniper Technical Support . . . . .	59
<b>Part 5</b>	<b>Index</b>	
	Index . . . . .	65

# List of Figures

Part 1	Overview
Chapter 1	<b>Subscriber Interfaces Over MPLS Pseudowires in Subscriber Access Networks . . . . . 3</b>
	Figure 1: MPLS Access Network with Subscriber Management Support . . . . . 4
	Figure 2: Pseudowire Subscriber Interface Protocol Stack . . . . . 4
	Figure 3: MPLS Pseudowire Subscriber Interface Two-Level Scheduler Configuration . . . . . 6
	Figure 4: Three-Level Scheduling Hierarchy Case 1: Pseudowire Service Logical Interfaces over a Transport Logical Interface . . . . . 8
	Figure 5: Three-Level Scheduling Hierarchy Case 2: Pseudowire Service Logical Interfaces over a Pseudowire Service Interface Set . . . . . 9
	Figure 6: Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces-Deployment Scenario . . . . . 9



# List of Tables

	<b>About the Documentation</b> . . . . .	<b>ix</b>
	Table 1: Notice Icons . . . . .	xi
	Table 2: Text and Syntax Conventions . . . . .	xi
<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Subscriber Interfaces Over MPLS Pseudowires in Subscriber Access Networks</b> . . . . .	<b>3</b>
	Table 3: Two-Level Hierarchical Scheduling-Interface Hierarchy Versus Scheduling Nodes . . . . .	6
	Table 4: Three-Level Hierarchical Scheduling-Interface Hierarchy Versus CoS Scheduling Node Levels . . . . .	7
<b>Part 3</b>	<b>Administration</b>	
<b>Chapter 5</b>	<b>Monitoring Commands</b> . . . . .	<b>53</b>
	Table 5: show interfaces ps0 Output Fields . . . . .	54





# About the Documentation

- Documentation and Release Notes on page ix
- Supported Platforms on page ix
- Using the Examples in This Manual on page ix
- Documentation Conventions on page xi
- Documentation Feedback on page xiii
- Requesting Technical Support on page xiii

## Documentation and Release Notes

---

To obtain the most current version of all Juniper Networks<sup>®</sup> technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

## Supported Platforms

---

For the features described in this document, the following platforms are supported:

- MX Series

## Using the Examples in This Manual

---

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

## Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xml;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

## Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the **load** command, see the *CLI User Guide*.

## Documentation Conventions

Table 1 on page xi defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2 on page xi defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
<b>Bold text like this</b>	Represents text that you type.	To enter configuration mode, type the <b>configure</b> command:  user@host> <b>configure</b>
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> <b>show chassis alarms</b>  No alarms currently active

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
<i>Italic text like this</i>	<ul style="list-style-type: none"> <li>Introduces or emphasizes important new terms.</li> <li>Identifies book names.</li> <li>Identifies RFC and Internet draft titles.</li> </ul>	<ul style="list-style-type: none"> <li>A policy <i>term</i> is a named structure that defines match conditions and actions.</li> <li><i>Junos OS System Basics Configuration Guide</i></li> <li>RFC 1997, <i>BGP Communities Attribute</i></li> </ul>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name:  [edit] root@# <b>set system domain-name</b> <i>domain-name</i>
<b>Text like this</b>	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> <li>To configure a stub area, include the <b>stub</b> statement at the [edit protocols ospf area area-id] hierarchy level.</li> <li>The console port is labeled <b>CONSOLE</b>.</li> </ul>
< > (angle brackets)	Enclose optional keywords or variables.	<b>stub &lt;default-metric metric&gt;;</b>
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	<b>broadcast   multicast</b>  <b>(string1   string2   string3)</b>
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	<b>rsvp { # Required for dynamic MPLS only</b>
[ ] (square brackets)	Enclose a variable for which you can substitute one or more values.	<b>community name members [ community-ids ]</b>
Indentation and braces ( { } )	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
<b>GUI Conventions</b>		
<b>Bold text like this</b>	Represents graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> <li>In the Logical Interfaces box, select <b>All Interfaces</b>.</li> <li>To cancel the configuration, click <b>Cancel</b>.</li> </ul>
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select <b>Protocols&gt;Ospf</b> .

## Documentation Feedback

---

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net), or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

## Requesting Technical Support

---

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

## Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>

- Join and participate in the Juniper Networks Community Forum:  
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

## Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

## PART 1

# Overview

- [Subscriber Interfaces Over MPLS Pseudowires in Subscriber Access Networks on page 3](#)





## CHAPTER 1

# Subscriber Interfaces Over MPLS Pseudowires in Subscriber Access Networks

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [CoS Two-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 5](#)
- [CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 7](#)

## Pseudowire Subscriber Logical Interfaces Overview


---

Subscriber management supports the creation of subscriber interfaces over point-to-point MPLS pseudowires. The pseudowire subscriber interface capability enables service providers to extend an MPLS domain from the access-aggregation network to the service edge, where subscriber management is performed. Service providers can take advantage of MPLS capabilities such as failover, rerouting, and uniform MPLS label provisioning, while using a single pseudowire to service a large number of DHCP and PPPoE subscribers in the service network.

The pseudowire is a tunnel that is either an MPLS-based Layer 2 VPN or Layer 2 circuit. The pseudowire tunnel transports Ethernet encapsulated traffic from an access node (for example, a DSLAM or other aggregation device) to the MX Series router that hosts the subscriber management services. The termination of the pseudowire tunnel on the MX Series router is similar to a physical Ethernet termination, and is the point at which subscriber management functions are performed. A service provider can configure multiple pseudowires on a per-DSLAM basis and then provision support for a large number of subscribers on a specific pseudowire. [Figure 1 on page 4](#) shows an MPLS network that provides subscriber management support.

At the access node end of the pseudowire, the subscriber traffic can be groomed into the pseudowire in a variety of ways, limited only by the number and types of interfaces that can be stacked on the pseudowire. You specify an anchor point, which identifies the logical tunnel interface that terminates the pseudowire tunnel at the access node.


Figure 1: MPLS Access Network with Subscriber Management Support



**NOTE:** Subscriber interfaces over MPLS pseudowires are supported on MX Series routers with MPCs.

Figure 2 on page 4 shows the protocol stack for a pseudowire subscriber logical interface. The pseudowire is a virtual device that is stacked above the logical tunnel anchor point on the physical interface (the IFD), and supports a circuit-oriented Layer 2 protocol (either Layer 2 VPN or Layer 2 circuit). The Layer 2 protocol provides the transport and service logical interfaces, and supports the protocol family (IPv4, IPv6, or PPPoE).

Figure 2: Pseudowire Subscriber Interface Protocol Stack



The pseudowire configuration is transparent to the subscriber management applications and has no impact on the packet payloads that are used for subscriber management.

Subscriber applications such as DHCP and PPPoE can be stacked over Layer 2 similar to the way in which they are stacked over a physical interface.

**Related  
Documentation**

- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)

---

## Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview

Junos OS supports two aspects of CoS for MPLS pseudowire subscriber interfaces. You can apply CoS rewrite rules and behavior aggregate (BA) classifiers to MPLS pseudowire subscriber interfaces. In addition, CoS performs egress hierarchical shaping towards the subscriber on MPLS pseudowire subscriber interfaces.

Hierarchical CoS enables you to apply traffic scheduling and queuing parameters and packet transmission scheduling parameters to an individual subscriber interface rather than to all interfaces configured on the port. Hierarchical CoS is supported on MX Series routers with either EQ DPCs or MPC/MICs installed.

On Juniper Networks MX Series routers, MPC/MIC and EQ DPC interfaces support a four-level CoS scheduling hierarchy that, when fully configured, consists of the physical interface (level 1), the interface set or the underlying interface (level 2), one or more logical interfaces (level 3), and one or more queues (level 4). Although all CoS scheduling hierarchies are four-level, level 1 is always the physical interface and level 4 is always the queue. Hierarchical scheduling configurations consist of the type of interfaces you configure; for example, a logical interface or an interface set and where those interfaces reside in the scheduling hierarchy, either level 2 or level 3. Because many hierarchical scheduling configurations are possible, we use the terms *two-level hierarchical scheduling* and *three-level hierarchical scheduling* in this discussion.

**Related  
Documentation**

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- [Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers](#)
- [CoS Two-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 5](#)
- [CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 7](#)
- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)

---

## CoS Two-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces

Two-level hierarchical scheduling limits the number of hierarchical levels in the scheduling hierarchy to two. In a two-level scheduling hierarchy, all logical interfaces and interface

sets share a single level 2 node. [Table 3 on page 6](#) summarizes the interface hierarchy and the CoS scheduler node levels for two-level hierarchical scheduling.


**Table 3: Two-Level Hierarchical Scheduling-Interface Hierarchy Versus Scheduling Nodes**

Level 1	Level 2	Level 3	Level 4
Physical interface	–	Pseudowire transport logical interface	One or more queues
Physical interface	–	Interface set	One or more queues
Physical interface	–	Pseudowire service logical interface	One or more queues

You use the two-level hierarchical scheduling when you have many pseudowires but you do not require shaping specific to the subscriber logical interface. For example, when your configuration is one subscriber per pseudowire interface.

[Figure 3 on page 6](#) shows a two-level hierarchical scheduling configuration for the MPLS pseudowires. In this configuration, level 1 is the physical interface used for the logical tunnel anchor node. All of the pseudowire transport interfaces share a single level 2 node. The level 3 nodes are the pseudowire transport logical interfaces (ps0.0, ps1.0, and ps2.0). In this configuration, interface sets are not configured and only the logical interfaces have traffic control profiles.

**Figure 3: MPLS Pseudowire Subscriber Interface Two-Level Scheduler Configuration**



Two-level hierarchical scheduling has up to eight class of service queues. For this configuration, include the **maximum-hierarchy-levels 2** option under the **[edit interfaces interface-name hierarchical-scheduler]** statement at the physical interface for the anchor logical tunnel.



**NOTE:** You cannot configure shaping policies on both the pseudowire logical interfaces and the subscriber logical interfaces over the same pseudowire. If a traffic-control profile is configured on a pseudowire logical interface, and CoS policies are configured on the subscriber logical interface over another pseudowire, all of the logical interfaces are at level 3 and act as peers.

#### Related Documentation

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- [Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers](#)
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 7](#)
- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [Configuring CoS Two-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces on page 22](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)

## CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces

In three-level hierarchical scheduling, the CoS scheduler nodes at level 1, level 2, and level 3 form a scheduling hierarchy. You can configure many different three-level scheduling hierarchies, depending on the location of the interface set and the use of underlying interfaces. In all variations, the physical interface on which the logical tunnel resides is a level 1 CoS scheduler node and the queues reside at level 4. Three-level scheduling hierarchies can have up to eight class of service queues.

[Table 4 on page 7](#) summarizes the most common three-level hierarchical scheduling configurations and shows the interface hierarchy and CoS scheduler nodes.

**Table 4: Three-Level Hierarchical Scheduling-Interface Hierarchy Versus CoS Scheduling Node Levels**

Level 1	Level 2	Level 3	Level 4
Physical interface	Pseudowire interface set	Pseudowire service logical interfaces	One or more queues
Physical interface	Pseudowire transport logical interface	Pseudowire interface set	One or more queues
Physical interface	Pseudowire transport logical interface	Pseudowire service logical interfaces	One or more queues


### Three-Level Scheduling Hierarchy: Pseudowire Logical Interfaces over a Transport Logical Interface

Figure 4 on page 8 shows an MPLS pseudowire three-level scheduling hierarchy that includes two pseudowire service logical interfaces over a pseudowire transport logical interface. This variation uses the following scheduler nodes:

- Level 4—Forwarding class-based queues
- Level 3—Pseudowire service logical interfaces (ps0.1 and ps0.2) for subscriber sessions
- Level 2—Pseudowire transport logical interface (ps0.0)
- Level 1—Common/shared physical interface of the logical tunnel anchor point

You apply the traffic-control profiles at the pseudowire transport logical interfaces (level 2) and the pseudowire service logical interfaces (level 3).

**Figure 4: Three-Level Scheduling Hierarchy Case 1: Pseudowire Service Logical Interfaces over a Transport Logical Interface**




### Three-Level Scheduling Hierarchy : Pseudowire Service Logical Interfaces over a Pseudowire Service Interface Set

Figure 5 on page 9 shows another variation of MPLS pseudowire three-level hierarchical scheduling that includes two pseudowire service logical interfaces over a pseudowire service interface set. This variation uses the following CoS scheduler nodes:

- Level 4—Forwarding class-based queues
- Level 3—Pseudowire service logical interfaces (ps0.1 and ps0.2)
- Level 2—Pseudowire service interface set
- Level 1—Common/shared physical interface of the logical tunnel anchor point

You apply the traffic-control profile at the pseudowire service interfaces (level 3) and at the interface set (level 2). This variation is most useful for subscriber edge deployments.


**Figure 5: Three-Level Scheduling Hierarchy Case 2: Pseudowire Service Logical Interfaces over a Pseudowire Service Interface Set**



### Three-Level Scheduling Hierarchy Combined Deployment Scenario

Figure 6 on page 9 shows a deployment scenario that combines the three-level hierarchical scheduling scenarios in Figure 4 on page 8 and Figure 5 on page 9.

**Figure 6: Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces-Deployment Scenario**



This variation uses the following CoS scheduler nodes:

- Level 4—Forwarding class-based queues
- Level 3—Pseudowire service logical interfaces (ps0.1, ps0.2, ps1.1, and ps1.2)

- Level 2—Service interface set for pseudowire service interfaces (ps0.1 and ps0.2) and transport logical interface (ps1.0) for the pseudowire service logical interfaces (ps1.1 and ps1.2)
- Level 1—Common/shared physical interface of the logical tunnel anchor point

You apply the traffic-control profiles to the interfaces at both level 2 and level 3, as well as the interface set at level 2.

**Related  
Documentation**

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- *Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers*
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Transport Logical Interface\) on page 24](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Pseudowire Interface Set\) on page 26](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)



## PART 2

# Configuration

- [Configuration Tasks for Subscriber Interfaces over MPLS Pseudowires on page 13](#)
- [CoS Configuration Tasks for Subscriber Interfaces over MPLS Pseudowires on page 21](#)
- [Configuration Statements on page 29](#)



## CHAPTER 2

# Configuration Tasks for Subscriber Interfaces over MPLS Pseudowires

- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- [Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router on page 15](#)
- [Configuring a Pseudowire Subscriber Logical Interface Device on page 15](#)
- [Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface on page 17](#)
- [Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces on page 17](#)
- [Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces on page 18](#)
- [Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface on page 19](#)

## Configuring a Pseudowire Subscriber Logical Interface

---

A pseudowire subscriber logical interface terminates an MPLS pseudowire tunnel from an access node to the MX Series router that hosts subscriber management, and enables you to perform subscriber management services at the interface.

To create a pseudowire subscriber logical interface:

1. Specify the number of pseudowire logical interfaces that the router can support.  
[See “Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router” on page 15.](#)
2. Configure the pseudowire subscriber logical interface device.  
[See “Configuring a Pseudowire Subscriber Logical Interface Device” on page 15.](#)
3. Configure the transport logical interface.  
[See “Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface” on page 17.](#)

4. Configure the signaling for the pseudowire subscriber interface. You can use either Layer 2 circuit signaling or Layer 2 VPN signaling. The two signaling types are mutually exclusive for a given pseudowire.

- To configure Layer 2 circuit signaling, see [“Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces”](#) on page 17.
- To configure Layer 2 VPN signaling, see [“Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces”](#) on page 18.

5. Configure the service logical interface.

See [“Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface”](#) on page 19.

6. Configure the underlying interface device.

See *Configuring an Underlying Interface for Dynamic PPPoE Subscriber Interfaces*.

7. Configure CoS parameters and BA classification.

See [“CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces”](#) on page 21.

8. (Optional) Associate a dynamic profile with the pseudowire subscriber logical interface.

You can associate DHCP, PPPoE, IP demux, and VLAN dynamic profiles with pseudowire subscriber logical interfaces. The support is similar to the typical Ethernet interface support.



**NOTE:** When using a PPPoE dynamic profile to create a pseudowire subscriber logical interface over a demux interface device, the dynamic profile must explicitly specify the correct pseudowire interface device over which the interface is created. The dynamic profile does not automatically create the interface over the demux0 interface device, as is the case with a VLAN demux interface.

---

For additional information about associating dynamic profiles to interfaces, see *Dynamic Profile Attachment to DHCP Subscriber Interfaces Overview* and *Configuring VLAN Interfaces to Use Dynamic Profiles*.

9. (Optional) Configure interface set support for pseudowire subscriber logical interfaces.

See *Configuring Interface Sets and Applying Interface Sets*.

10. (Optional) Stack PPPoE logical interfaces over a pseudowire logical device.

#### Related Documentation

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)

## Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router

You must set the maximum number of pseudowire logical interface devices (pseudowire tunnels) that the router can use for subscriber logical interfaces. You can specify a maximum of 2048 pseudowire logical interface devices for an MX Series router. Each pseudowire device supports a maximum of 4000 subscriber logical interfaces.

A PFE can host a maximum of 2048 pseudowire logical interface devices, which is the chassis maximum. This PFE hosting support provides the configuration flexibility needed for special cases that might occur for business edge scenarios. However, you can exceed the available PFE resources as you configure additional services on the pseudowire logical interface devices ports. To support a scaled configuration, ensure that you populate the appropriate number of PFEs for the chassis, and that you distribute the pseudowire logical interface devices across the PFEs in such a way that ensures that no PFE is overwhelmed by the anticipated peak load. As part of the network planning for your particular deployment, you must consider the exact mix of the distribution of the pseudowire logical interface devices and the services associated with the devices.



**BEST PRACTICE:** A configured pseudowire logical interface device consumes resources from shared pools even when the device has no active subscriber logical interfaces. To conserve resources, do not deploy an excessive number of pseudowire devices that you do not intend to use.

To configure the number of pseudowire logical interface devices that you want the router to support:

1. Specify that you want to configure the pseudowire service.  

```
[edit chassis]
user@host# edit pseudowire-service
```
2. Set the maximum number of pseudowire logical interface devices.  

```
[edit chassis pseudowire-service]
user@host# set device-count 500
```

### Related Documentation

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)

## Configuring a Pseudowire Subscriber Logical Interface Device

To configure a pseudowire logical interface device that the router uses for subscriber logical interfaces, you specify the logical tunnel that processes the pseudowire termination. You can also configure additional optional parameters for the interface device, such as VLAN tagging method, MTU, and gratuitous ARP support.

To configure the pseudowire subscriber interface device:

1. Specify that you want to configure the pseudowire subscriber logical interface device.

```
user@host# edit interfaces ps0
```

2. Specify the logical tunnel interface that is the anchor point for the pseudowire logical interface device. The anchor point must be an *lt* device in the format *lt-fpc/pic/port*.

```
[edit interfaces ps0]  
user@host# set anchor-point lt-1/0/10
```

3. (Optional) Specify the VLAN tagging method used for the pseudowire logical interface device. You can specify single tagging, dual (stacked) tagging, mixed (flexible) tagging, or no tagging.

```
[edit interfaces ps0]  
user@host# set flexible-vlan-tagging
```

See *Enabling VLAN Tagging* for additional information about VLAN tagging.

4. (Optional) Specify the MTU for the pseudowire logical interface device. If you do not explicitly configure the MTU, the router uses the default value of 1500.

```
[edit interfaces ps0]  
user@host# set mtu 2500
```

See *Setting the Protocol MTU* for additional information.

5. (Optional) Specify that the pseudowire logical interface device does not respond to gratuitous ARP requests.

```
[edit interfaces ps0]  
user@host# set no-gratuitous-arp-request
```

See *Configuring Gratuitous ARP* for additional information.

6. Configure additional optional parameters for the pseudowire logical interface device, such as *description*, *apply-groups*, *apply-groups-except*, and *traceoptions*.

- Related Documentation**
- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
  - [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)

## Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface

---

This topic describes how to configure a pseudowire transport logical interface. A pseudowire device can have only one transport logical interface.

A pseudowire logical device and its related pseudowire logical interfaces are dependent on the state of the underlying logical transport interface device, which is either the Layer 2 VPN or Layer 2 circuit.



**NOTE:** We recommend that you use unit 0 to represent the transport logical interface for the pseudowire device. Non-zero unit numbers represent *service* logical interfaces used for pseudowire subscriber interfaces.

To configure a pseudowire transport logical interface:

1. Specify that you want to configure the pseudowire subscriber logical interface device.

```
[edit]
user@host# edit interfaces ps0
```

2. Specify that you want to configure unit 0, which represents the transport logical interface.

```
[edit interfaces ps0]
user@host# edit unit 0
```

3. Specify the **ethernet-ccc** encapsulation method for the transport logical interface.

```
[edit interfaces ps0 unit 0]
user@host# set encapsulation ethernet-ccc
```

### Related Documentation

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)

---

## Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces

---

This topic describes the steps for configuring Layer 2 circuit signaling used for the pseudowire subscriber logical interface support. You can also use Layer 2 VPN signaling for pseudowire subscriber logical interfaces. The two methods are mutually exclusive; you can use only one method for a particular pseudowire.

To configure Layer 2 circuit signaling for pseudowire interfaces:

1. Specify that you want to configure Layer 2 circuit parameters at the protocols hierarchy level.

```
[edit protocols]
user@host# edit l2circuit
```

2. Specify the IP address of the neighbor, to identify the PE router used for the Layer 2 circuit.

```
[edit protocols l2circuit]
user@host# edit neighbor 192.168.102.15
```

3. Specify the interface used by the Layer 2 circuit traffic.

```
[edit protocols l2circuit neighbor 192.168.102.15]
user@host# edit interface ps1.0
```

4. Configure the virtual circuit ID that identifies the Layer 2 circuit for the pseudowire.

```
[edit protocols l2circuit neighbor 192.168.102.15 interface ps1.0]
user@host# set virtual-circuit-id 5
```

5. (Optional) If multiple VLAN interfaces are carried over the pseudowire Layer 2 payload, configure the **no-vlan-id-validate** statement. This statement prevents VLAN validation in the signaling.

```
[edit protocols l2circuit neighbor 192.168.102.15 interface ps1.0]
user@host# set no-vlan-id-validate
```

For more information about Layer 2 circuits, see *Configuring Interfaces for Layer 2 Circuits*.

#### Related Documentation

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- [Configuring Interfaces for Layer 2 Circuits](#)

---

## Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces

This topic describes the steps for configuring Layer 2 VPN signaling used for the pseudowire subscriber logical interface support. You can also use Layer 2 circuit signaling for pseudowire subscriber logical interfaces. The two methods are mutually exclusive; you can use only one method on a particular pseudowire.

To configure Layer 2 VPN signaling for pseudowire interfaces:

1. Specify the name of the routing instance you want to configure.

```
[edit]
user@host# edit routing-instances l2vpn0
```

2. Configure the Layer 2 VPN routing instance type.

```
[edit routing-instances l2vpn0]
user@host# set instance-type l2vpn
```

3. Associate the pseudowire logical interface for the Layer 2 VPN.

```
[edit routing-instances l2vpn0]
user@host# set interface ps1.0
```

4. Configure the unique identifier for the routes that belong to the Layer 2 VPN.

```
[edit routing-instances l2vpn0]
user@host# set route-distinguisher 111.1.1.1:100
```



5. Configure the VPN routing and forwarding (VRF) target of the routing instance.

```
[edit routing-instances l2vpn0]
user@host# set vrf-target target:10:100
```

6. Specify that you want to configure the Layer 2 VPN protocol for the routing instance.

```
[edit routing-instances l2vpn0]
user@host# edit protocols l2vpn
```

7. Configure the encapsulation type for the routing instance.

```
[edit routing-instances l2vpn0 protocols l2vpn]
user@host# set encapsulation-type ethernet
```

8. Specify the site name and site identifier for the Layer 2 VPN.

```
[edit routing-instances l2vpn0 protocols l2vpn]
user@host# set site PE1 site-identifier 1
```

9. Specify the interface that connects to the site, and the remote interface to which you want the specified interface to connect.

```
[edit routing-instances l2vpn0 protocols l2vpn]
user@host# set interface ps1.0 remote-site-id 2
```

10. Configure the tracing options for traffic that uses the Layer 2 VPN.

```
[edit routing-instances l2vpn0 protocols l2vpn]
user@host# set traceoptions file l2vpn flag all
```

#### Related Documentation

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)

## Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface

This topic describes how to configure a pseudowire service logical interface. Service logical interfaces represent the attachment circuits for pseudowire logical interfaces.

As described in the “[Pseudowire Subscriber Logical Interfaces Overview](#)” on page 3, you can choose whether to configure a service logical interface together with a higher subscriber logical interface, depending upon the business need. In a broadband edge configuration, the higher subscriber logical interface is the demarcation point for subscribers. However, in a business edge configuration, the service logical interface is the demarcation point for the business subscribers, and also serves as the subscriber logical interface, so no subscriber logical interfaces are explicitly configured.



**NOTE:** Non-zero unit numbers represent *service* logical interfaces used for pseudowire subscriber interfaces. Use unit 0 to represent the *transport* logical interface for the pseudowire device.

To configure a pseudowire service logical interface:

1. Specify that you want to configure the pseudowire subscriber logical interface device.

```
[edit]
user@host# edit interfaces ps0
```

2. Configure the unit for the service logical interface. Use a non-zero unit number.

```
[edit interfaces ps0]
user@host# edit unit 1
```

3. Configure the VLAN tag IDs.

```
[edit interfaces ps0 unit 1]
user@host# set vlan-tags outer 1 inner 1
```

4. Configure the interface to respond to ARP requests when the device has an active route to the ARP request target address.

```
[edit interfaces ps0 unit 1]
user@host# set proxy-arp
```

5. Specify that you want to configure the protocol family information. Pseudowire service logical interfaces support IPv4 (inet), IPv6 (inet6), and PPPoE (pppoe) protocol families.

For example, to configure the IPv4 family:

- a. Specify that you want to configure IPv4.

```
[edit interfaces ps0 unit 1]
user@host# edit family inet
```

- b. Configure the parameters for the family.

```
[edit interfaces ps0 unit 1 family inet]
user@host# set filter input filter 1 output filter 4
user@host# set mac-validate loose
user@host# set input-hierarchical-policer policer-1
user@host# set unnumbered-address lo0.0 preferred-source-address 100.0.0.1
```

**Related  
Documentation**

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)

## CHAPTER 3

# CoS Configuration Tasks for Subscriber Interfaces over MPLS Pseudowires

- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [Configuring CoS Two-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces on page 22](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Transport Logical Interface\) on page 24](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Pseudowire Interface Set\) on page 26](#)

## CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces

---

CoS supports two-level and three-level hierarchies for MPLS pseudowire subscriber interfaces.

To configure two-level scheduling, include the **maximum-hierarchy-levels 2** option under the **[edit interfaces *interface-name* hierarchical-scheduler]** statement on the physical interface of the logical tunnel anchor point.

To configure three-level hierarchical scheduling, include the **implicit-hierarchy** option under the **[edit interfaces *interface-name* hierarchical-scheduler]** statement on the physical interface of the logical tunnel anchor point. Use the following guidelines for configuring the **implicit-hierarchy** option:

- If an output traffic-control profile is configured on the pseudowire transport interface and on a pseudowire service interface, the two interfaces form a scheduling hierarchy. The pseudowire transport interface resides in a level 2 scheduler node and the pseudowire service interface resides in a level 3 scheduler node.
- If an output traffic-control profile is configured on the pseudowire services interface but not on a pseudowire transport interface, the pseudowire services interface resides in a level 3 scheduler node.
- If an output traffic-control profile is only configured on the pseudowire transport interface and not on the pseudowire services interface, the pseudowire transport interface resides in a level 3 scheduler node and all pseudowire traffic uses this node.

If the **implicit-hierarchy** option is not set on the logical tunnel anchor point, logical interfaces behave normally with the hierarchical-scheduler mode configured with or without the **hierarchical-scheduler maximum-hierarchy-levels** option under the **[edit interfaces interface-name hierarchical-scheduler]** statement. In this case, when you apply a traffic-control profile to the pseudowire and service logical interfaces, they both reside in level 3 scheduler nodes and do not form a scheduling hierarchy, which might not be the desirable behavior. In business edge, where only the pseudowire logical interfaces need to be shaped, applying the traffic-control profile at just the transport logical interface may be sufficient.

When configuring the logical tunnel physical interface for the maximum hierarchy level, all pseudowire logical interfaces operating on the physical interface use the same hierarchy model. If you want to mix two-level and three-level scheduling hierarchies, you can group the pseudowires together by hierarchy levels and share the same logical tunnel anchor point or you can use three-level scheduling for all pseudowires over the anchor point.

To specify rewrite rules and classifiers on pseudowire interfaces, reference the pseudowire device under the **[edit class-of-service interfaces]** hierarchy level and specify the rewrite rules and classifiers for the pseudowire interfaces.

To control all pseudowire traffic using the same logical tunnel interface, apply CoS policies at the physical interface for the anchor logical tunnel.

**Related  
Documentation**

- [Pseudowire Subscriber Logical Interfaces Overview on page 3](#)
- [Configuring a Pseudowire Subscriber Logical Interface on page 13](#)
- [Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers](#)
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [Configuring CoS Two-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces on page 22](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Transport Logical Interface\) on page 24](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Pseudowire Interface Set\) on page 26](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)

---

## Configuring CoS Two-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces

---

Before configuring CoS parameters for MPLS pseudowire subscriber interfaces, you must first complete these tasks:

1. Configure the pseudowire logical interfaces. See [“Configuring a Pseudowire Subscriber Logical Interface” on page 13](#).
2. Configure the pseudowire device count. See [“Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router” on page 15](#).

3. Configure the pseudowire device including the logical tunnel anchor point. See [“Configuring a Pseudowire Subscriber Logical Interface Device”](#) on page 15.
4. Configure the pseudowire transport logical interface. See [“Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface”](#) on page 17.
5. Configure the pseudowire signaling (either Layer 2 circuit signaling or Layer 2 VPN signaling). See [“Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces”](#) on page 17 or [“Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces”](#) on page 18.
6. Configure the pseudowire logical interfaces. See [“Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface”](#) on page 19.

To configure CoS policies on MPLS pseudowire subscriber interfaces using two-level scheduling:

1. Configure the hierarchical scheduler for the physical interface used for the logical tunnel (anchor point). For two-level scheduling the hierarchical scheduler must be set to **maximum-scheduler levels 2**.

```
[edit]
user@host#edit interfaces ps ps-anchor-device-name
user@host#set hierarchical-scheduler maximum-hierarchy-levels 2
```

2. Specify the traffic-control profile to use on the pseudowire logical interface.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#set output-traffic-control-profile profile-name
```

3. Configure the rewrite rule.

The available rewrite rule types for pseudowire interfaces are **dscp** and **inet-precedence**.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#edit rewrite-rules (dscp | inet-precedence) rewrite-name
user@host#edit forwarding-class class-name
user@host#set loss-priority class-name code-point (alias | bits)
```

4. Configure the classifier.

The available classifier types for pseudowire interfaces are **dscp** and **inet-precedence**.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#edit classifiers (dscp | inet-precedence) classifier-name
user@host#edit forwarding-class class-name
user@host#set loss-priority class-name code-points [aliases] [bit-patterns]
```

5. Apply the rewrite rule and classifier to the pseudowire interface.

For the *interface\_name* parameter, specify the pseudowire device name.

```
[edit class-of-service interfaces interface_name unit logical-unit-number]
```

```
user@host#set rewrite-rule (dscp | inet-precedence) (rewrite-name | default) protocol
protocol-types
user@host#set classifiers (dscp | inet-precedence) (classifier-name | default)
```

**Related  
Documentation**

- [CoS on Ethernet Pseudowires in Universal Edge Networks Overview](#)
- For more information about rewrite rules and classifiers, see the *Junos OS Class of Service Library for Routing Devices*
- [Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers](#)
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [CoS Two-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 5](#)
- [CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 7](#)
- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)

## **Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces (Logical Interfaces over a Transport Logical Interface)**

---

Before configuring CoS three-level scheduling on pseudowire logical interfaces over a transport logical interface, you must first complete these tasks:

1. Configure the pseudowire logical interfaces. See [“Configuring a Pseudowire Subscriber Logical Interface” on page 13](#).
2. Configure the pseudowire device count. See [“Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router” on page 15](#).
3. Configure the pseudowire device including the logical tunnel anchor point. See [“Configuring a Pseudowire Subscriber Logical Interface Device” on page 15](#).
4. Configure the pseudowire transport logical interface. See [“Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface” on page 17](#).
5. Configure the pseudowire signaling (either Layer 2 circuit signaling or Layer 2 VPN signaling). See [“Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces” on page 17](#) or [“Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces” on page 18](#).
6. Configure the pseudowire logical interfaces. See [“Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface” on page 19](#).

Three-level scheduling on pseudowire logical interfaces over a transport logical interface requires you to apply the traffic-control profiles at both the pseudowire logical interface and the pseudowire transport logical interface. To configure CoS policies on three-level scheduling on pseudowire logical interfaces over a transport logical interface:

1. Configure the hierarchical scheduler for the physical interface used for the logical tunnel (anchor point). For three-level scheduling the hierarchical scheduler must be set to **implicit-hierarchy**.

```
[edit]
user@host#edit interfaces ps-anchor-device-name
user@host#set hierarchical-scheduler implicit-hierarchy
```

2. Specify the traffic-control profile to use on the pseudowire logical interface.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#set output-traffic-control-profile profile-name
```

3. Specify the traffic-control profile to use on the pseudowire transport logical interface.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#set output-traffic-control-profile profile-name
```

4. Configure the rewrite rule.

The available rewrite rule types for pseudowire interfaces are **dscp** and **inet-precedence**.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#edit rewrite-rules (dscp | inet-precedence) rewrite-name
user@host#edit forwarding-class class-name
user@host#set loss-priority class-name code-point (alias | bits)
```

5. Configure the classifier.

The available classifier types for pseudowire interfaces are **dscp** and **inet-precedence**.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#edit classifiers (dscp | inet-precedence) classifier-name
user@host#edit forwarding-class class-name
user@host#set loss-priority class-name code-points [aliases] [bit-patterns]
```

6. Apply the rewrite rule and classifier to the pseudowire interfaces.

For the *interface\_name* parameter, specify the pseudowire device name.

```
[edit class-of-service interfaces interface_name unit logical-unit-number]
user@host#set rewrite-rule (dscp | inet-precedence) (rewrite-name | default) protocol
protocol-types
user@host#set classifiers (dscp | inet-precedence) (classifier-name | default)
```

**Related Documentation**

- *CoS on Ethernet Pseudowires in Universal Edge Networks Overview*
- For more information about rewrite rules and classifiers, see the *Junos OS Class of Service Library for Routing Devices*
- *Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers*
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 7](#)
- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Pseudowire Interface Set\) on page 26](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)

## **Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces (Logical Interfaces over a Pseudowire Interface Set)**

---

Before configuring three-level scheduling on pseudowire logical interfaces over a pseudowire logical interface set, you must first complete the following tasks:

1. Configure the pseudowire logical interfaces. See [“Configuring a Pseudowire Subscriber Logical Interface” on page 13](#).
2. Configure the pseudowire device count. See [“Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router” on page 15](#).
3. Configure the pseudowire device including the logical tunnel anchor point. See [“Configuring a Pseudowire Subscriber Logical Interface Device” on page 15](#).
4. Configure the pseudowire transport logical interface. See [“Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface” on page 17](#).
5. Configure the pseudowire signaling (either Layer 2 circuit signaling or Layer 2 VPN signaling). See [“Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces” on page 17](#) or [“Configuring Layer 2 VPN Signaling for Pseudowire Subscriber Logical Interfaces” on page 18](#).
6. Configure the pseudowire logical interfaces. See [“Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface” on page 19](#).

Three-level scheduling on pseudowire logical interfaces over a pseudowire logical interface set requires you to apply the traffic-control profiles at both the pseudowire logical interface and the pseudowire logical interface-set. To configure CoS policies on MPLS pseudowire subscriber interfaces using three-level implicit hierarchical scheduling:

1. Configure the hierarchical scheduler for the physical interface used for the logical tunnel (anchor point). For three-level scheduling the hierarchical scheduler must be set to **implicit-hierarchy**.



```
[edit]
user@host#edit interfaces ps-anchor-device-name
user@host#set hierarchical-scheduler implicit-hierarchy
```

- Specify the traffic-control profile to use on the pseudowire logical interfaces.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#set output-traffic-control-profile profile-name
```

- Define a pseudowire logical interface set and configure the traffic-control profile used for the interface set.

```
[edit class-of-service]
user@host#edit interfaces
user@host#edit interface-set interface-set-name
user@host#edit output-traffic-control-profile profile-name
```

- Group the pseudowire logical interfaces in the pseudowire logical interface set.

```
[edit ]
user@host#edit interfaces
user@host#edit interface-set interface-set-name
user@host#edit interface ps ps-device-name
user@host#edit unit logical-unit-number
```

- Configure the rewrite rule.

The available rewrite rule types for pseudowire interfaces are **dscp** and **inet-precedence**.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#edit rewrite-rules (dscp | inet-precedence) rewrite-name
user@host#edit forwarding-class class-name
user@host#set loss-priority class-name code-point (alias | bits)
```

- Configure the classifier.

The available classifier types for pseudowire interfaces are **dscp** and **inet-precedence**.

```
[edit class-of-service]
user@host#edit interfaces ps ps-device-name
user@host#edit unit logical-unit-number
user@host#edit classifiers (dscp | inet-precedence) classifier-name
user@host#edit forwarding-class class-name
user@host#set loss-priority class-name code-points [aliases] [bit-patterns]
```

- Apply the rewrite rule and classifier to the pseudowire interfaces.

For the *interface\_name* parameter, specify the ps device name.

```
[edit class-of-service interfaces interface_name unit logical-unit-number]
user@host#set rewrite-rule (dscp | inet-precedence) (rewrite-name | default) protocol
protocol-types
user@host#set classifiers (dscp | inet-precedence) (classifier-name | default)
```

#### Related Documentation

- *CoS on Ethernet Pseudowires in Universal Edge Networks Overview*

- For more information about rewrite rules and classifiers, see the *Junos OS Class of Service Library for Routing Devices*
- *Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers*
- [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)
- [CoS Three-Level Hierarchical Scheduling on MPLS Pseudowire Subscriber Interfaces on page 7](#)
- [CoS Configuration Overview for MPLS Pseudowire Subscriber Interfaces on page 21](#)
- [Configuring CoS Three-Level Hierarchical Scheduling for MPLS Pseudowire Subscriber Interfaces \(Logical Interfaces over a Transport Logical Interface\) on page 24](#)
- [hierarchical-scheduler \(Subscriber Interfaces on MX Series Routers\) on page 36](#)

## CHAPTER 4

# Configuration Statements

### anchor-point (Pseudowire Subscriber Interfaces)

---

<b>Syntax</b>	anchor-point <i>lt-device</i> ;
<b>Hierarchy Level</b>	[edit interfaces ps0]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.1.
<b>Description</b>	Specify the logical tunnel (lt) interface that identifies the Packet Forwarding Engine that processes the pseudowire termination.
<b>Options</b>	<i>lt-device</i> —An lt device in the format <i>lt-fpc/pic/port</i>
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Pseudowire Subscriber Logical Interfaces Overview on page 3</a></li><li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface on page 13</a></li><li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface Device on page 15</a></li></ul>

## device-count (Pseudowire Subscriber Interfaces)

---

<b>Syntax</b>	device-count <i>number</i> ;
<b>Hierarchy Level</b>	[edit chassis pseudowire-service]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.1.
<b>Description</b>	Configure the number of pseudowire logical devices available to the router.
<b>Options</b>	<i>number</i> —Number of devices. <b>Range:</b> 1 through 2048
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Pseudowire Subscriber Logical Interfaces Overview on page 3</a></li><li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface on page 13</a></li><li>• <a href="#">Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router on page 15</a></li></ul>

## encapsulation (Logical Interface)

<b>Syntax</b>	encapsulation (atm-ccc-cell-relay   atm-ccc-vc-mux   atm-cisco-nlpid   atm-mlppp-llc   atm-nlpid   atm-ppp-llc   atm-ppp-vc-mux   atm-snap   atm-tcc-snap   atm-tcc-vc-mux   atm-vc-mux   ether-over-atm-llc   ether-vpls-over-atm-llc   ether-vpls-over-fr   ether-vpls-over-ppp   ethernet   ethernet-ccc   ethernet-vpls   ethernet-vpls-fr   frame-relay-ccc   frame-relay-ether-type   frame-relay-ether-type-tcc   frame-relay-ppp   frame-relay-tcc   gre-fragmentation   multilink-frame-relay-end-to-end   multilink-ppp   ppp-over-ether   ppp-over-ether-over-atm-llc   vlan-bridge   vlan-ccc   vlan-vci-ccc   vlan-tcc   vlan-vpls);
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> <b>unit</b> <i>logical-unit-number</i> ], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> <b>unit</b> <i>logical-unit-number</i> ], [edit interfaces <i>rlsq number</i> <b>unit</b> <i>logical-unit-number</i> ]
<b>Release Information</b>	Statement introduced before Junos OS Release 7.4. Statement introduced in Junos OS Release 12.1X48 for PTX Series Packet Transport Routers ( <b>vlan-ccc</b> and <b>vlan-tcc</b> options only). Statement introduced in Junos OS Release 12.2 for the ACX Series Universal Access Routers. Only the <b>atm-ccc-cell-relay</b> and <b>atm-ccc-vc-mux</b> options are supported on ACX Series routers.
<b>Description</b>	Configure a logical link-layer encapsulation type.
<b>Options</b>	<p><b>atm-ccc-cell-relay</b>—Use ATM cell-relay encapsulation.</p> <p><b>atm-ccc-vc-mux</b>—Use ATM virtual circuit (VC) multiplex encapsulation on CCC circuits. When you use this encapsulation type, you can configure the <b>ccc</b> family only.</p> <p><b>atm-cisco-nlpid</b>—Use Cisco ATM network layer protocol identifier (NLPID) encapsulation. When you use this encapsulation type, you can configure the <b>inet</b> family only.</p> <p><b>atm-mlppp-llc</b>—For ATM2 IQ interfaces only, use Multilink Point-to-Point (MLPPP) over AAL5 LLC. For this encapsulation type, your router must be equipped with a Link Services or Voice Services PIC. MLPPP over ATM encapsulation is not supported on ATM2 IQ OC48 interfaces.</p> <p><b>atm-nlpid</b>—Use ATM NLPID encapsulation. When you use this encapsulation type, you can configure the <b>inet</b> family only.</p> <p><b>atm-ppp-llc</b>—(ATM2 IQ interfaces and MX Series routers with MPC/MIC interfaces using the ATM MIC with SFP only) Use PPP over AAL5 LLC encapsulation.</p> <p><b>atm-ppp-vc-mux</b>—(ATM2 IQ interfaces and MX Series routers with MPC/MIC interfaces using the ATM MIC with SFP only) Use PPP over ATM AAL5 multiplex encapsulation.</p> <p><b>atm-snap</b>—(All interfaces including MX Series routers with MPC/MIC interfaces using the ATM MIC with SFP) Use ATM subnetwork attachment point (SNAP) encapsulation.</p> <p><b>atm-tcc-snap</b>—Use ATM SNAP encapsulation on translational cross-connect (TCC) circuits.</p>

**atm-tcc-vc-mux**—Use ATM VC multiplex encapsulation on TCC circuits. When you use this encapsulation type, you can configure the **tcc** family only.

**atm-vc-mux**—(All interfaces including MX Series routers with MPC/MIC interfaces using the ATM MIC with SFP) Use ATM VC multiplex encapsulation. When you use this encapsulation type, you can configure the **inet** family only.

**ether-over-atm-llc**—(All IP interfaces including MX Series routers with MPC/MIC interfaces using the ATM MIC with SFP) For interfaces that carry IP traffic, use Ethernet over ATM LLC encapsulation. When you use this encapsulation type, you cannot configure multipoint interfaces.

**ether-vpls-over-atm-llc**—For ATM2 IQ interfaces only, use the Ethernet virtual private LAN service (VPLS) over ATM LLC encapsulation to bridge Ethernet interfaces and ATM interfaces over a VPLS routing instance (as described in RFC 2684, *Multiprotocol Encapsulation over ATM Adaptation Layer 5*). Packets from the ATM interfaces are converted to standard ENET2/802.3 encapsulated Ethernet frames with the frame check sequence (FCS) field removed.

**ether-vpls-over-fr**—For E1, T1, E3, T3, and SONET interfaces only, use the Ethernet virtual private LAN service (VPLS) over Frame Relay encapsulation to support Bridged Ethernet over Frame Relay encapsulated TDM interfaces for VPLS applications, per RFC 2427, *Multiprotocol Interconnect over Frame Relay*.



**NOTE:** The SONET/SDH OC3/STM1 (Multi-Rate) MIC with SFP, the Channelized SONET/SDH OC3/STM1 (Multi-Rate) MIC with SFP, and the DS3/E3 MIC do not support Ethernet over Frame Relay encapsulation.

---

**ether-vpls-over-ppp**—For E1, T1, E3, T3, and SONET interfaces only, use the Ethernet virtual private LAN service (VPLS) over Point-to-Point Protocol (PPP) encapsulation to support Bridged Ethernet over PPP-encapsulated TDM interfaces for VPLS applications.

**ethernet**—Use Ethernet II encapsulation (as described in RFC 894, *A Standard for the Transmission of IP Datagrams over Ethernet Networks*).

**ethernet-ccc**—Use Ethernet CCC encapsulation on Ethernet interfaces.

**ethernet-vpls**—Use Ethernet VPLS encapsulation on Ethernet interfaces that have VPLS enabled and that must accept packets carrying standard Tag Protocol ID (TPID) values.



**NOTE:** The built-in Gigabit Ethernet PIC on an M7i router does not support extended VLAN VPLS encapsulation.

---

**ethernet-vpls-fr**—Use in a VPLS setup when a CE device is connected to a PE device over a time-division multiplexing (TDM) link. This encapsulation type enables the PE device to terminate the outer layer 2 Frame Relay connection, use the 802.1p bits inside the inner Ethernet header to classify the packets, look at the MAC address from the Ethernet header, and use the MAC address to forward the packet into a given VPLS instance.

**frame-relay-ccc**—Use Frame Relay encapsulation on CCC circuits. When you use this encapsulation type, you can configure the **ccc** family only.

**frame-relay-ether-type**—Use Frame Relay ether type encapsulation for compatibility with Cisco Frame Relay. The physical interface must be configured with flexible-frame-relay encapsulation.

**frame-relay-ether-type-tcc**—Use Frame Relay ether type TCC for Cisco-compatible Frame Relay on TCC circuits to connect different media. The physical interface must be configured with flexible-frame-relay encapsulation.

**frame-relay-ppp**—Use PPP over Frame Relay circuits. When you use this encapsulation type, you can configure the **ppp** family only. J Series routers do not support frame-relay-ppp encapsulation.

**frame-relay-tcc**—Use Frame Relay encapsulation on TCC circuits for connecting different media. When you use this encapsulation type, you can configure the **tcc** family only.

**gre-fragmentation**—For adaptive services interfaces only, use GRE fragmentation encapsulation to enable fragmentation of IPv4 packets in GRE tunnels. This encapsulation clears the do not fragment (DF) bit in the packet header. If the packet's size exceeds the tunnel's maximum transmission unit (MTU) value, the packet is fragmented before encapsulation.

**multilink-frame-relay-end-to-end**—Use MLFR FRF.15 encapsulation. This encapsulation is used only on multilink, link services, and voice services interfaces and their constituent T1 or E1 interfaces, and is supported on LSQ and redundant LSQ interfaces.

**multilink-ppp**—Use MLPPP encapsulation. This encapsulation is used only on multilink, link services, and voice services interfaces and their constituent T1 or E1 interfaces.

**ppp-over-ether**—For underlying Ethernet interfaces on J Series routers, use PPP over Ethernet encapsulation. When you use this encapsulation type, you cannot configure the interface address. Instead, configure the interface address on the PPP interface. You also use PPP over Ethernet encapsulation to configure an underlying Ethernet interface for a dynamic PPPoE logical interface on M120 and M320 routers with Intelligent Queuing 2 (IQ2) PICs, and on MX Series routers with MPCs.

**ppp-over-ether-over-atm-llc**—(J Series routers and MX Series routers with MPCs using the ATM MIC with SFP only) For underlying ATM interfaces, use PPP over Ethernet over ATM LLC encapsulation. When you use this encapsulation type, you cannot configure the interface address. Instead, configure the interface address on the PPP interface.

**vlan-bridge**—Use Ethernet VLAN bridge encapsulation on Ethernet interfaces that have IEEE 802.1Q tagging, flexible-ethernet-services, and bridging enabled and that must accept packets carrying TPID 0x8100 or a user-defined TPID.

**vlan-ccc**—Use Ethernet virtual LAN (VLAN) encapsulation on CCC circuits. When you use this encapsulation type, you can configure the **ccc** family only.

**vlan-vci-ccc**—Use ATM-to-Ethernet interworking encapsulation on CCC circuits. When you use this encapsulation type, you can configure the **ccc** family only.

**vlan-tcc**—Use Ethernet VLAN encapsulation on TCC circuits. When you use this encapsulation type, you can configure the **tcc** family only.

**vlan-vpls**—Use Ethernet VLAN encapsulation on VPLS circuits.

<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
---------------------------------	---

**Related Documentation**


- *Configuring Layer 2 Switching Cross-Connects Using CCC*
- *Configuring the Encapsulation for Layer 2 Switching TCCs*
- *Configuring Interface Encapsulation on Logical Interfaces*
- *Configuring MPLS LSP Tunnel Cross-Connects Using CCC*
- *Circuit and Translational Cross-Connects Overview*
- *Identifying the Access Concentrator*
- *Configuring ATM Interface Encapsulation*
- *Configuring VLAN Encapsulation*
- *Configuring Extended VLAN Encapsulation*
- *Configuring ISDN Logical Interface Properties*
- *Configuring ATM-to-Ethernet Interworking*
- *Configuring Interface Encapsulation on PTX Series Packet Transport Routers*
- *Configuring CCC Encapsulation for Layer 2 VPNs*
- *Configuring TCC Encapsulation for Layer 2 VPNs and Layer 2 Circuits*
- *Configuring ATM for Subscriber Access*
- *Junos OS Services Interfaces Library for Routing Devices*
- *CoS on ATM IMA Pseudowire Interfaces Overview*
- *Configuring Policing on an ATM IMA Pseudowire*



## flexible-vlan-tagging

<b>Syntax</b>	flexible-vlan-tagging;
<b>Hierarchy Level</b>	[edit interfaces <i>ge-fpc/pic/port</i> ], [edit interfaces <i>et-fpc/pic/port</i> ], [edit interfaces <i>ps0</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.1. Support for aggregated Ethernet added in Junos OS Release 9.0. Statement introduced in Junos OS Release 12.1x48 for PTX Series Packet Transport Routers.
<b>Description</b>	Support simultaneous transmission of 802.1Q VLAN single-tag and dual-tag frames on logical interfaces on the same Ethernet port, and on pseudowire logical interfaces.  This statement is supported on M Series and T Series routers, for Fast Ethernet and Gigabit Ethernet interfaces only on Gigabit Ethernet IQ2 and IQ2-E, IQ, and IQE PICs, and for aggregated Ethernet interfaces with member links in IQ2, IQ2-E, and IQ PICs or in MX Series DPCs, or on Ethernet interfaces for PTX Series Packet Transport Routers or 100-Gigabit Ethernet Type 5 PIC with CFP.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <i>Configuring Mixed Tagging</i></li> <li>• <i>Configuring Flexible VLAN Tagging on PTX Series Packet Transport Routers</i></li> </ul>

## hierarchical-scheduler (Subscriber Interfaces on MX Series Routers)

<b>Syntax</b>	<pre> hierarchical-scheduler {     implicit-hierarchy;     maximum-hierarchy-levels <i>number</i>; } </pre>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> ]
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 10.1.</p> <p><b>implicit-hierarchy</b> option introduced in Junos OS Release 13.1.</p>
<b>Description</b>	On MX Series routers with MPC/MICs, configure the parameters for hierarchical scheduling on the interface.
<div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p><b>NOTE:</b> To enable hierarchical scheduling on MX Series routers, configure the <b>hierarchical-scheduler</b> statement at each member physical interface level of a particular aggregated Ethernet interface as well as at that aggregated Ethernet interface level. On other routing platforms, it is enough if you include this statement at the aggregated Ethernet interface level.</p> </div> </div>	
<b>Options</b>	<p><b>implicit-hierarchy</b>—Configure three-level hierarchical scheduling. When you include the <b>implicit-hierarchy</b> option, a hierarchical relationship is formed between the CoS scheduler nodes at level 1, level 2, and level 3. The <b>implicit-hierarchy</b> option is supported only on MPC/MIC subscriber interfaces and interface sets running over aggregated Ethernet on MX Series routers.</p> <p><b>maximum-hierarchy-levels <i>number</i></b>—Configure two-level hierarchical scheduling. Specify the maximum number of hierarchical scheduling levels allowed for node scaling. The only supported value is 2. The <b>maximum-hierarchy-levels</b> option is supported on MPC/MIC or EQ DPC subscriber interfaces and interface sets running over aggregated Ethernet on MX Series routers.</p> <ul style="list-style-type: none"> <li>If you include the <b>maximum-hierarchy-levels</b> option, interface sets are allowed only at level 3; they are not allowed at level 2. In this case, if you configure a level 2 interface set, you generate Packet Forwarding Engine errors.</li> <li>If you do not include the <b>maximum-hierarchy-levels</b> option, interface sets can be at either level 2 or level 3, depending on whether the member logical interfaces within the interface set have a traffic control profile. If any member logical interface has a traffic control profile, then the interface set is a level 2 CoS scheduler node. If no member logical interface has a traffic control profile, the interface set is at level 3.</li> </ul>
<b>Required Privilege Level</b>	<p>view-level—To view this statement in the configuration.</p> <p>control-level—To add this statement to the configuration.</p>

- Related Documentation**
- *Understanding Two-Level and Three-level Hierarchical CoS for Subscriber Interfaces on MX Series Routers*
  - *Configuring Hierarchical CoS for a Subscriber Interface of Aggregated Ethernet Links*
  - *Junos OS Class of Service Library for Routing Devices*
  - *Configuring Hierarchical Schedulers for CoS*
  - [Hierarchical CoS on MPLS Pseudowire Subscriber Interfaces Overview on page 5](#)

---

## input-hierarchical-policer

---

<b>Syntax</b>	<code>input-hierarchical-policer <i>policer-name</i>;</code>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> layer2-policer], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> layer2-policer],
<b>Release Information</b>	Statement introduced in Junos OS Release 9.5.
<b>Description</b>	Apply a hierarchical policer to the Layer 2 input traffic for all protocol families at the physical or logical interface.
<b>Options</b>	<i>policer-name</i> —Name of the hierarchical policer.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Hierarchical Policers</i></li><li>• <i>layer2-policer (Hierarchical Policar)</i></li></ul>

## mtu

<b>Syntax</b>	<code>mtu bytes;</code>
<b>Hierarchy Level</b>	<p>[edit interfaces <i>interface-name</i>],</p> <p>[edit interfaces <i>interface-name</i> <b>unit</b> <i>logical-unit-number</i> family <i>family</i>],</p> <p>[edit interfaces <i>interface-range name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> <b>unit</b> <i>logical-unit-number</i> family <i>family</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> protocols l2circuit local-switching interface <i>interface-name</i> backup-neighbor <i>address</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> protocols l2circuit neighbor <i>address</i> interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> protocols l2circuit neighbor <i>address</i> interface <i>interface-name</i> backup-neighbor <i>address</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> protocols l2vpn interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> protocols vpls],</p> <p>[edit protocols l2circuit local-switching interface <i>interface-name</i> backup-neighbor <i>address</i>],</p> <p>[edit protocols l2circuit neighbor <i>address</i> interface <i>interface-name</i>],</p> <p>[edit protocols l2circuit neighbor <i>address</i> interface <i>interface-name</i> backup-neighbor <i>address</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols l2vpn interface <i>interface-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols vpls]</p>
<b>Release Information</b>	<p>Statement introduced before Junos OS Release 7.4.</p> <p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Support for Layer 2 VPNs and VPLS introduced in Junos OS Release 10.4.</p> <p>Statement introduced in Junos OS Release 12.1X48 for PTX Series Packet Transport Routers.</p> <p>Statement introduced in Junos OS Release 12.2 for ACX Series Universal Access Routers.</p> <p>Support at the [set interfaces <i>interface-name</i> <b>unit</b> <i>logical-unit-number</i> <b>family</b> <i>ccc</i>] hierarchy level introduced in Junos OS Release 12.3R3 for MX Series routers.</p>
<b>Description</b>	<p>Specify the maximum transmission unit (MTU) size for the media or protocol. The default MTU size depends on the device type. Changing the media MTU or protocol MTU causes an interface to be deleted and added again.</p> <p>To route jumbo data packets on the routed VLAN interface (RVI) on EX Series switches, you must configure the jumbo MTU size on the member physical interfaces and also on the RVI itself (the <b>vlan</b> interface).</p>



**CAUTION:** For EX Series switches, setting or deleting the jumbo MTU size on the RVI (the **vlan** interface) while the switch is transmitting packets might cause packets to be dropped.



**NOTE:** If a packet whose size is larger than the configured MTU size is received on the receiving interface, the packet is eventually dropped. The value

considered for MRU (maximum receive unit) size is also the same as the MTU size configured on that interface.



**NOTE:** Not all devices allow you to set an MTU value, and some devices have restrictions on the range of allowable MTU values. You cannot configure an MTU for management Ethernet interfaces (fxp0, em0, or me0) or for loopback, multilink, and multicast tunnel devices.

For more information about configuring MTU for specific interfaces and router or switch combinations, see *Configuring the Media MTU*.

**Options** *bytes*—MTU size.

**Range:** 256 through 9192 bytes, 256 through 9500 bytes (Junos OS 12.1X48R2 for PTX Series routers)

**Default:** 1500 bytes (INET, INET6, and ISO families), 1448 bytes (MPLS), 1514 bytes (EX Series switch interfaces)

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

**Related Documentation**

- *Configuring Gigabit Ethernet Interfaces (CLI Procedure)*
- *Configuring the Media MTU*
- *Configuring the MTU for Layer 2 Interfaces*
- *Configuring Routed VLAN Interfaces (CLI Procedure)*
- *Setting the Protocol MTU*

## no-gratuitous-arp-request

---

<b>Syntax</b>	no-gratuitous-arp-request;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 9.6 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX Series Universal Access Routers.
<b>Description</b>	For Ethernet interfaces and pseudowire logical interfaces, do not respond to gratuitous ARP requests.
<b>Default</b>	Gratuitous ARP responses are enabled on all Ethernet interfaces.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring Gratuitous ARP</i></li><li>• <i>gratuitous-arp-reply</i></li></ul>

## no-vlan-id-validate

---

<b>Syntax</b>	no-vlan-id-validate;
<b>Hierarchy Level</b>	[edit logical-systems <i>logical-system-name</i> protocols l2circuit neighbor <i>address</i> interface <i>interface-name</i> ], [edit protocols l2circuit neighbor <i>address</i> interface <i>interface-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.1.
<b>Description</b>	Uniquely identify a Layer 2 circuit for either a standard pseudowire or a redundant pseudowire.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring Interfaces for Layer 2 Circuits</i></li><li>• <a href="#">Pseudowire Subscriber Logical Interfaces Overview on page 3</a></li><li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface on page 13</a></li><li>• <a href="#">Configuring Layer 2 Circuit Signaling for Pseudowire Subscriber Logical Interfaces on page 17</a></li></ul>

## ps0 (Pseudowire Subscriber Interfaces)

<b>Syntax</b>	<pre>ps0 {     anchor-point <i>lt-device</i>;     mtu <i>bytes</i>;     no-gratuitous-arp-request;     (flexible-vlan-tagging   stacked-vlan-tagging   untagged   vlan-tagging); }</pre>
<b>Hierarchy Level</b>	[edit logical-systems transport-ls interfaces]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.1.
<b>Description</b>	<p>Configure the pseudowire logical device.</p> <p>The remaining statements are explained separately.</p>
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Pseudowire Subscriber Logical Interfaces Overview on page 3</a></li> <li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface on page 13</a></li> <li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface Device on page 15</a></li> <li>• <a href="#">Configuring the Transport Logical Interface for a Pseudowire Subscriber Logical Interface on page 17</a></li> <li>• <a href="#">Configuring the Service Logical Interface for a Pseudowire Subscriber Logical Interface on page 19</a></li> </ul>

## pseudowire-service (Pseudowire Subscriber Interfaces)

---

<b>Syntax</b>	<code>pseudowire-service {     device-count <i>number</i>; }</code>
<b>Hierarchy Level</b>	[edit chassis]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.1.
<b>Description</b>	Configure properties for the pseudowire devices on the router.  The remaining statement is explained separately.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Pseudowire Subscriber Logical Interfaces Overview on page 3</a></li><li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface on page 13</a></li><li>• <a href="#">Configuring the Maximum Number of Pseudowire Logical Interface Devices Supported on the Router on page 15</a></li></ul>

## stacked-vlan-tagging

---

<b>Syntax</b>	<code>stacked-vlan-tagging;</code>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> ]
<b>Release Information</b>	Statement introduced before Junos OS Release 7.4. Statement introduced in Junos OS Release 12.2 for ACX Series Universal Access Routers.
<b>Description</b>	For Gigabit Ethernet IQ interfaces, Gigabit Ethernet, 10-Gigabit Ethernet LAN/WAN PIC, and 100-Gigabit Ethernet Type 5 PIC with CFP, enable stacked VLAN tagging for all logical interfaces on the physical interface.  For pseudowire subscriber interfaces, enable stacked VLAN tagging for logical interfaces on the pseudowire service.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Stacking and Rewriting Gigabit Ethernet VLAN Tags Overview</a></li><li>• <a href="#">vlan-tags (Stacked VLAN Tags)</a></li></ul>



## unit

```

Syntax  unit logical-unit-number {
    accept-source-mac {
        mac-address mac-address {
            policer {
                input cos-policer-name;
                output cos-policer-name;
            }
        }
    }
    accounting-profile name;
    advisory-options {
        downstream-rate rate;
        upstream-rate rate;
    }
    allow-any-vci;
    atm-scheduler-map (map-name | default);
    backup-options {
        interface interface-name;
    }
    bandwidth rate;
    cell-bundle-size cells;
    clear-dont-fragment-bit;
    compression {
        rtp {
            maximum-contexts number <force>;
            f-max-period number;
            queues [ queue-numbers ];
            port {
                minimum port-number;
                maximum port-number;
            }
        }
    }
    compression-device interface-name;
    copy-tos-to-outer-ip-header;
    demux-destination family;
    demux-source family;
    demux-options {
        underlying-interface interface-name;
    }
    description text;
    interface {
        l2tp-interface-id name;
        (dedicated | shared);
    }
    dialer-options {
        activation-delay seconds;
        callback;
        callback-wait-period time;
        deactivation-delay seconds;
        dial-string [ dial-string-numbers ];
        idle-timeout seconds;
    }
  }

```

```

incoming-map {
    caller caller-id | accept-all;
    initial-route-check seconds;
    load-interval seconds;
    load-threshold percent;
    pool pool-name;
    redial-delay time;
    watch-list {
        [ routes ];
    }
}
}
disable;
disable-mlppp-inner-ppp-pfc;
dlci dlci-identifier;
drop-timeout milliseconds;
dynamic-call-admission-control {
    activation-priority priority;
    bearer-bandwidth-limit kilobits-per-second;
}
encapsulation type;
epd-threshold cells plp1 cells;
family family-name {
    ... the family subhierarchy appears after the main [edit interfaces interface-name unit
        logical-unit-number] hierarchy ...
}
fragment-threshold bytes;
inner-vlan-id-range start start-id end end-id;
input-vlan-map {
    (pop | pop-pop | pop-swap | push | push-push | swap |
    swap-push | swap-swap);
    inner-tag-protocol-id tpid;
    inner-vlan-id number;
    tag-protocol-id tpid;
    vlan-id number;
}
interleave-fragments;
inverse-arp;
layer2-policer {
    input-policer policer-name;
    input-three-color policer-name;
    output-policer policer-name;
    output-three-color policer-name;
}
link-layer-overhead percent;
minimum-links number;
mrru bytes;
multicast-dlci dlci-identifier;
multicast-vci vpi-identifier.vci-identifier;
multilink-max-classes number;
multipoint;
oam-liveness {
    up-count cells;
    down-count cells;
}
oam-period (disable | seconds);

```

```

output-vlan-map {
    (pop | pop-pop | pop-swap | push | push-push | swap |
    swap-push | swap-swap);
    inner-tag-protocol-id tpid;
    inner-vlan-id number;
    tag-protocol-id tpid;
    vlan-id number;
}
passive-monitor-mode;
peer-unit unit-number;
plp-to-clp;
point-to-point;
ppp-options {
    chap {
        access-profile name;
        default-chap-secret name;
        local-name name;
        passive;
    }
    compression {
        acfc;
        pfc;
    }
    dynamic-profile profile-name;
    lcp-restart-timer milliseconds;
    loopback-clear-timer seconds;
    ncp-restart-timer milliseconds;
    pap {
        access-profile name;
        default-pap-password password;
        local-name name;
        local-password password;
        passive;
    }
}
pppoe-options {
    access-concentrator name;
    auto-reconnect seconds;
    (client | server);
    service-name name;
    underlying-interface interface-name;
}
pppoe-underlying-options {
    access-concentrator name;
    dynamic-profile profile-name;
    max-sessions number;
}
proxy-arp;
service-domain (inside | outside);
shaping {
    (cbr rate | rtvbr peak rate sustained rate burst length | vbr peak rate sustained rate burst length);
    queue-length number;
}
short-sequence;
targeted-distribution;

```

```
transmit-weight number;  
(traps | no-traps);  
trunk-bandwidth rate;  
trunk-id number;  
tunnel {  
    backup-destination address;  
    destination address;  
    key number;  
    routing-instance {  
        destination routing-instance-name;  
    }  
    source source-address;  
    ttl number;  
}  
vci vpi-identifier.vci-identifier;  
vci-range start start-vci end end-vci;  
vpi vpi-identifier;  
vlan-id number;  
vlan-id-range number-number;  
vlan-tags inner tpid.vlan-id outer tpid.vlan-id;  
family family {  
    accounting {  
        destination-class-usage;  
        source-class-usage {  
            (input | output | input output);  
        }  
    }  
    access-concentrator name;  
    address address {  
        ... the address subhierarchy appears after the main [edit interfaces interface-name unit  
        logical-unit-number family family-name] hierarchy ...  
    }  
    bridge-domain-type (bvlan | svlan);  
    bundle interface-name;  
    core-facing;  
    demux-destination {  
        destination-prefix;  
    }  
    demux-source {  
        source-prefix;  
    }  
    duplicate-protection;  
    dynamic-profile profile-name;  
    filter {  
        group filter-group-number;  
        input filter-name;  
        input-list [ filter-names ];  
        output filter-name;  
        output-list [ filter-names ];  
    }  
    interface-mode (access | trunk);  
    ipsec-sa sa-name;  
    isid-list all-service-groups;  
    keep-address-and-control;  
    mac-validate (loose | strict);  
    max-sessions number;
```

```

mtu bytes;
multicast-only;
no-redirects;
policer {
    arp policer-template-name;
    input policer-template-name;
    output policer-template-name;
}
primary;
protocols [inet iso mpls];
proxy inet-address address;
receive-options-packets;
receive-ttl-exceeded;
remote (inet-address address | mac-address address);
rpf-check {
    fail-filter filter-name
    mode loose;
}
sampling {
    input;
    output;
}
service {
    input {
        post-service-filter filter-name;
        service-set service-set-name <service-filter filter-name>;
    }
    output {
        service-set service-set-name <service-filter filter-name>;
    }
}
service-name-table table-name
(translate-discard-eligible | no-translate-discard-eligible);
(translate-fecn-and-becn | no-translate-fecn-and-becn);
translate-plp-control-word-de;
unnumbered-address interface-name destination address destination-profile profile-name;
vlan-id number;
vlan-id-list [number number-number];
address address {
    arp ip-address (mac | multicast-mac) mac-address <publish>;
    broadcast address;
    destination address;
    destination-profile name;
    eui-64;
    master-only;
    multipoint-destination address {
        dlci dlci-identifier;
        epd-threshold cells <plp1 cells>;
        inverse-arp;
        oam-liveness {
            up-count cells;
            down-count cells;
        }
        oam-period (disable | seconds);
        shaping {

```

```

        (cbr rate | rtvbr burst length peak rate sustained rate | vbr burst length peak rate
         sustained rate);
        queue-length number;
    }
    vci vpi-identifier.vci-identifier;
}
preferred;
primary;
(vrrp-group | vrrp-inet6-group) group-number {
    (accept-data | no-accept-data);
    advertise-interval seconds;
    authentication-type authentication;
    authentication-key key;
    fast-interval milliseconds;
    (preempt | no-preempt) {
        hold-time seconds;
    }
    priority number;
    track {
        interface interface-name {
            bandwidth-threshold bits-per-second priority-cost number;
        }
        priority-hold-time seconds;
        route ip-address/prefix-length routing-instance instance-name priority-cost cost;
    }
    virtual-address [ addresses ];
    virtual-link-local-address ipv6-address;
    vrrp-inherit-from {
        active-interface interface-name;
        active-group group-number;
    }
}
}
}
}

```

**Hierarchy Level** [edit interfaces *interface-name*],  
[edit logical-systems *logical-system-name* interfaces *interface-name*],  
[edit interfaces interface-set *interface-set-name* interface *interface-name*]

**Release Information** Statement introduced before Junos OS Release 7.4.

**Description** Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.

**Options** *logical-unit-number*—Number of the logical unit.

**Range:** 0 through 1,073,741,823 for demux and PPPoE static interfaces only. 0 through 16,385 for all other static interface types.

The remaining statements are explained separately.

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

- Related Documentation**
- *Configuring Logical Interface Properties*
  - *Example: Configuring E-LINE and E-LAN Services for a PBB Network on MX Series Routers*
  - *Junos OS Services Interfaces Library for Routing Devices*

---

## untagged

---

<b>Syntax</b>	untagged;
<b>Hierarchy Level</b>	[edit interfaces ps0]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.1.
<b>Description</b>	Specify that the router supports untagged traffic on pseudowire subscriber interfaces.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Pseudowire Subscriber Logical Interface Device on page 15</a></li></ul>

## vlan-tagging

---

<b>Syntax</b>	vlan-tagging;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> ], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> ]
<b>Release Information</b>	Statement introduced before Junos OS Release 7.4. Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 12.2 for ACX Series Universal Access Routers. Statement introduced in Junos OS Release 13.2 for PTX Series Routers.
<b>Description</b>	For Fast Ethernet and Gigabit Ethernet interfaces, aggregated Ethernet interfaces configured for VPLS, and pseudowire subscriber interfaces, enable the reception and transmission of 802.1Q VLAN-tagged frames on the interface.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Example: Configuring Layer 3 Subinterfaces for a Distribution Switch and an Access Switch</i></li><li>• <i>Example: Configuring BGP Autodiscovery for LDP VPLS</i></li><li>• <i>Configuring a Layer 3 Subinterface (CLI Procedure)</i></li><li>• <i>Configuring Tagged Aggregated Ethernet Interfaces</i></li><li>• <i>Configuring Interfaces for VPLS Routing</i></li><li>• <i>Enabling VLAN Tagging</i></li><li>• <i>802.1Q VLANs Overview</i></li><li>• <i>vlan-id</i></li></ul>



## PART 3

# Administration

- [Monitoring Commands on page 53](#)



## CHAPTER 5

# Monitoring Commands

## show interfaces ps0 (Pseudowire Subscriber Interfaces)

<b>Syntax</b>	show interfaces ps0 <brief   detail   extensive   terse>
<b>Release Information</b>	Command introduced at Junos OS Release 13.1.
<b>Description</b>	Display status information about the pseudowire subscriber interface.
<b>Options</b>	<b>brief   detail   extensive   terse</b> —(Optional) Display the specified level of output.
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Pseudowire Subscriber Logical Interfaces Overview on page 3</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show interfaces ps0 on page 56</a>
<b>Output Fields</b>	<a href="#">Table 5 on page 54</a> lists the output fields for the <b>show interfaces ps0</b> command. Output fields are listed in the approximate order in which they appear.

**Table 5: show interfaces ps0 Output Fields**

Field Name	Field Description	Level of Output
<b>Physical Interface</b>		
<b>Physical interface</b>	Name of the physical interface.	<b>brief detail extensive</b> none
<b>Enabled</b>	State of the interface. Possible values are described in the “Enabled Field” section under <i>Common Output Fields Description</i> .	<b>brief detail extensive</b> none
<b>Interface index</b>	Physical interface index number, which reflects its initialization sequence.	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	SNMP index number for the physical interface.	<b>detail extensive</b> none
<b>Type</b>	Physical interface type (Software-Pseudo).	<b>brief detail extensive</b> none
<b>Link-level type</b>	Encapsulation being used on the physical interface.	<b>brief detail extensive</b>
<b>MTU</b>	MTU size on the physical interface.	<b>brief detail extensive</b>
<b>Clocking</b>	Reference clock source. It can be <b>Internal</b> or <b>External</b> .	<b>brief detail extensive</b>
<b>Speed</b>	Speed at which the interface is running.	<b>brief detail extensive</b>
<b>Device flags</b>	Information about the physical device. Possible values are described in the “Device Flags” section under <i>Common Output Fields Description</i> .	<b>brief detail extensive</b> none

Table 5: show interfaces ps0 Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Interface flags</b>	Information about the interface. Possible values are described in the "Interface Flags" section under <i>Common Output Fields Description</i> .	<b>brief detail extensive</b> none
<b>Current address</b>	Configured MAC address.	<b>detail extensive</b> none
<b>Hardware address</b>	MAC address of the hardware.	<b>detail extensive</b> none
<b>Last flapped</b>	Date, time, and how long ago the interface went from down to up or up to down. The format is Last flapped: <i>year-month-day hours:minutes:seconds: timezone (hours:minutes:seconds ago)</i> . or Never. For example, Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago).	<b>detail extensive</b> none
<b>input packets</b>	Number of packets received on the logical interface.	<b>detail extensive</b> none
<b>output packets</b>	Number of packets transmitted on the logical interface.	<b>detail extensive</b> none
Logical Interface		
<b>Logical interface</b>	Name of the logical interface.	<b>brief detail extensive</b> none
<b>Index</b>	Logical interface index number (which reflects its initialization sequence).	<b>detail extensive</b> none
<b>SNMP ifIndex</b>	Logical interface SNMP interface index number.	<b>detail extensive</b> none
<b>Flags</b>	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under <i>Common Output Fields Description</i> .	<b>brief detail extensive</b> none
<b>Encapsulation</b>	Type of encapsulation configured on the logical interface.	<b>brief extensive</b> none
<b>Input packets</b>	Number of packets received on the logical interface.	none
<b>Output packets</b>	Number of packets transmitted on the logical interface.	none
<b>Protocol</b>	Protocol family configured on the logical interface.	<b>detail extensive</b> none
<b>MTU</b>	MTU size on the logical interface.	<b>detail extensive</b> none
<b>Flags</b>	Information about the protocol family flags. Possible values are described in the "Family Flags" section under <i>Common Output Fields Description</i> .	<b>detail extensive</b> none
<b>Addresses, Flags</b>	Information about the addresses configured for the protocol family. Possible values are described in the "Addresses Flags" section under <i>Common Output Fields Description</i> .	<b>detail extensive</b> none
<b>Destination</b>	IP address of the remote side of the connection.	<b>detail extensive</b> none
<b>Local</b>	IP address of the logical interface.	<b>detail extensive terse</b> none

Table 5: show interfaces ps0 Output Fields (*continued*)

Field Name	Field Description	Level of Output
<b>Broadcast</b>	Broadcast address.	detail extensive none

## Sample Output

### show interfaces ps0

```

user@host> show interfaces ps0
Physical interface: ps0, Enabled, Physical link is Up
  Interface index: 166, SNMP ifIndex: 658
  Type: Software-Pseudo, Link-level type: 90, MTU: 1518, Clocking: 1, Speed: 800mbps

Device flags : Present Running
Interface flags: Point-To-Point Internal: 0x4000
Current address: 00:1d:b5:a8:19:4a, Hardware address: 00:1d:b5:a8:19:4a
Last flapped : Never
  Input packets : 0
  Output packets: 0

Logical interface ps0.0 (Index 74) (SNMP ifIndex 656)
  Flags: Point-To-Point 0x4000 Encapsulation: Ethernet-CCC
  Input packets : 482
  Output packets: 0
  Protocol ccc, MTU: 1518
  Flags: Is-Primary

Logical interface ps0.1 (Index 78) (SNMP ifIndex 665)
  Flags: Point-To-Point 0x4000 VLAN-Tag [ 0x8100.100 ] Encapsulation: ENET2
  Input packets : 0
  Output packets: 482
  Protocol inet, MTU: 1500
  Flags: Sendbcast-pkt-to-re
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 20.0.0/24, Local: 20.0.0.1, Broadcast: 20.0.0.255

Logical interface ps0.32767 (Index 75) (SNMP ifIndex 692)
  Flags: Point-To-Point 0x4000 VLAN-Tag [ 0x0000.0 ] Encapsulation: ENET2
  Input packets : 0
  Output packets: 0

```

## PART 4

# Troubleshooting

- [Acquiring Troubleshooting Information on page 59](#)





## CHAPTER 6

# Acquiring Troubleshooting Information

- [Collecting Subscriber Access Logs Before Contacting Juniper Technical Support on page 59](#)

### Collecting Subscriber Access Logs Before Contacting Juniper Technical Support

**Problem** When you experience a subscriber access problem in your network, we recommend that you collect certain logs before you contact Juniper Technical Support. This topic shows you the most useful logs for a variety of network implementations. In addition to the relevant log information, you must also collect standard troubleshooting information and send it to Juniper Technical Support in your request for assistance.

**Solution** To collect standard troubleshooting information:

- Redirect the command output to a file.

```
user@host> request support information | save rsi-1
```

To configure logging to assist Juniper Technical Support:

1. Review the following blocks of statements to determine which apply to your configuration.

[edit]

```
set system syslog archive size 100m files 25
set system auto-configuration traceoptions file filename
set system auto-configuration traceoptions file filename size 100m files 25
set protocols ppp-service traceoptions file filename size 100m files 25
set protocols ppp-service traceoptions level all
set protocols ppp-service traceoptions flag all
set protocols ppp traceoptions file filename size 100m files 25
set protocols ppp traceoptions level all
set protocols ppp traceoptions flag all
set protocols ppp monitor-session all
set interfaces pp0 traceoptions flag all
set demux traceoptions file filename size 100m files 25
set demux traceoptions level all
set demux traceoptions flag all
set system processes dhcp-service traceoptions file filename
set system processes dhcp-service traceoptions file size 100m
set system processes dhcp-service traceoptions file files 25
set system processes dhcp-service traceoptions flag all
set class-of-service traceoptions file filename
set class-of-service traceoptions file size 100m
set class-of-service traceoptions flag all
set class-of-service traceoptions file files 25
set routing-options traceoptions file filename
set routing-options traceoptions file size 100m
set routing-options traceoptions flag all
set routing-options traceoptions file files 25
set interfaces traceoptions file filename
set interfaces traceoptions file size 100m
set interfaces traceoptions flag all
set interfaces traceoptions file files 25
set system processes general-authentication-service traceoptions file filename
set system processes general-authentication-service traceoptions file size 100m
set system processes general-authentication-service traceoptions flag all
set system processes general-authentication-service traceoptions file files 25
```

2. Copy the relevant statements into a text file and modify the log filenames as you want.
3. Copy the statements from the text file and paste them into the CLI on your router to configure logging.
4. Commit the logging configuration to begin collecting information.



**NOTE:** The maximum file size for DHCP local server and DHCP relay log files is 1 GB. The maximum number of log files for DHCP local server and DHCP relay is 1000.



**BEST PRACTICE:** Enable these logs only to collect information when troubleshooting specific problems. Enabling these logs during normal operations can result in reduced system performance.

**Related  
Documentation**

- *Compressing Troubleshooting Logs from /var/logs to Send to Juniper Technical Support*



## PART 5

# Index

- [Index on page 65](#)



# Index

## Symbols

#, comments in configuration statements.....	xii
( ), in syntax descriptions.....	xii
802.1Q VLANs	
mixed VLAN tagging.....	35
VLAN tagging.....	50
< >, in syntax descriptions.....	xii
[ ], in configuration statements.....	xii
{ }, in configuration statements.....	xii
(pipe), in syntax descriptions.....	xii

## A

anchor logical tunnel.....	21
anchor-point statement	
pseudowires.....	29

## B

braces, in configuration statements.....	xii
brackets	
angle, in syntax descriptions.....	xii
square, in configuration statements.....	xii

## C

comments, in configuration statements.....	xii
conventions	
text and syntax.....	xi
CoS	
hierarchical scheduling	
three-level.....	36
two-level.....	36
implicit-hierarchy statement.....	36
maximum-hierarchy-levels statement.....	36
curly braces, in configuration statements.....	xii
customer support.....	xiii
contacting JTAC.....	xiii

## D

device-count statement	
pseudowires.....	30
documentation	
comments on.....	xiii

## E

encapsulation statement	
logical interfaces.....	31
Ethernet interfaces	
mixed VLAN tagging.....	35
VLAN tagging.....	50

## F

Fast Ethernet interfaces	
VLAN tagging.....	50
flexible-vlan-tagging statement.....	35
font conventions.....	xi

## G

Gigabit Ethernet interfaces	
VLAN tagging.....	50

## H

hierarchical-scheduler	
implicit-hierarchy.....	24, 26
hierarchical-scheduler statement.....	36

## I

implicit-hierarchy.....	7, 21, 24, 26
implicit-hierarchy statement.....	36
input-hierarchical-policer statement.....	37
interfaces	
mixed VLAN tagging.....	35

## L

log files	
collecting for Juniper Technical Support.....	59

## M

manuals	
comments on.....	xiii
maximum-hierarchy-levels 2.....	5, 21
maximum-scheduler levels 2.....	22
maximum-hierarchy-levels statement.....	36
mixed VLAN tagging.....	35
MPLS pseudowire	
anchor logical tunnel.....	21
CoS	
overview.....	5
CoS configuration	
overview.....	21
hierarchical-scheduler.....	5
implicit-hierarchy.....	7, 8, 24, 26
maximum-scheduler levels 2.....	22

implicit-hierarchy.....	21	pseudowire-service statement	
maximum-hierarchy-levels 2.....	5, 21	pseudowires.....	42
ps device-name.....	22, 24, 26	pseudowires	
subscriber interfaces.....	5	mixed VLAN tagging.....	35
three-level scheduling		<b>S</b>	
configuring.....	24, 26	service logical interface	
deployment scenario.....	9	pseudowire subscriber interfaces.....	19
logical interfaces over a pseudowire		show interfaces (Pseudowire Subscriber Interfaces)	
interface set.....	26	command.....	54
logical interfaces over a transport logical		signaling	
interface.....	24	pseudowire subscriber interfaces.....	17, 18
overview.....	7, 8	stacked-vlan-tagging statement.....	42
Pseudowire Logical Interface Set.....	8	support, technical See technical support	
Transport Logical Interface.....	7	syntax conventions.....	xi
two-level scheduling		<b>T</b>	
configuring.....	22	technical support	
overview.....	5	collecting logs for.....	59
mtu statement.....	38	contacting JTAC.....	xiii
<b>N</b>		trace operations	
no-gratuitous-arp-request statement.....	40	collecting logs for Juniper technical	
no-vlan-id-validate.....	40	support.....	59
<b>P</b>		transport logical interface	
parentheses, in syntax descriptions.....	xii	pseudowire subscriber interfaces.....	17
physical interfaces		troubleshooting subscriber access	
mixed VLAN tagging.....	35	collecting logs for Juniper Technical	
VLAN tagging.....	50	Support.....	59
ps0 statement		<b>U</b>	
pseudowires.....	41	unit statement.....	43
pseudowire interface set.....	26	untagged statement	
pseudowire logical interface device		pseudowires.....	49
configuring.....	15	<b>V</b>	
pseudowire subscriber interface.....	15	VLAN tagging.....	50
Pseudowire Logical Interface Set.....	8	vlan-tagging statement.....	50
pseudowire statements			
anchor-point.....	29		
ps0.....	41		
pseudowire-service.....	42		
pseudowire subscriber interfaces.....	3		
displaying.....	54		
Layer 2 circuit signaling.....	17		
Layer 2 VPN signaling.....	18		
service logical interface configuration.....	19		
transport logical interface configuration.....	17		
pseudowire subscriber logical interface			
device configuration.....	15		
pseudowire logical interface device.....	15		