



JUNOS® Software

Services Interfaces Configuration Guide

Release 9.5

Juniper Networks, Inc.

1194 North Mathilda Avenue
Sunnyvale, California 94089
USA

408-745-2000

www.juniper.net

Part Number: 530-029314-01, Revision 1

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, the Juniper Networks logo, JUNOS, NetScreen, ScreenOS, and Steel-Belted Radius are registered trademarks of Juniper Networks, Inc. in the United States and other countries. JUNOSe is a trademark of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

JUNOS® Software Services Interfaces Configuration Guide

Release 9.5

Copyright © 2009, Juniper Networks, Inc.

All rights reserved. Printed in USA.

Writing: Alan Twigg, Justine Kangas, Myron Weintraub

Editing: Sonia Saruba, Benjamin Mann

Illustration: Nathaniel Woodward

Cover Design: Edmonds Design

Revision History

10 April 2009—530-029314-01 Revision 1

The information in this document is current as of the date listed in the revision history.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. The JUNOS software has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

READ THIS END USER LICENSE AGREEMENT ("AGREEMENT") BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE. BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. **The Parties.** The parties to this Agreement are (i) Juniper Networks, Inc. (if the Customer's principal office is located in the Americas) or Juniper Networks (Cayman) Limited (if the Customer's principal office is located outside the Americas) (such applicable entity being referred to herein as "Juniper"), and (ii) the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software ("Customer") (collectively, the "Parties").

2. **The Software.** In this Agreement, "Software" means the program modules and features of the Juniper or Juniper-supplied software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller, or which was embedded by Juniper in equipment which Customer purchased from Juniper or an authorized Juniper reseller. "Software" also includes updates, upgrades and new releases of such software. "Embedded Software" means Software which Juniper has embedded in or loaded onto the Juniper equipment and any updates, upgrades, additions or replacements which are subsequently embedded in or loaded onto the equipment.

3. **License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

- a. Customer shall use Embedded Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller.
- b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees; provided, however, with respect to the Steel-Belted Radius or Odyssey Access Client software only, Customer shall use such Software on a single computer containing a single physical random access memory space and containing any number of processors. Use of the Steel-Belted Radius or IMS AAA software on multiple computers or virtual machines (e.g., Solaris zones) requires multiple licenses, regardless of whether such computers or virtualizations are physically contained on a single chassis.
- c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer's use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, realms, devices, links, ports or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. In addition, such limits may restrict the use of the Software to managing certain kinds of networks or require the Software to be used only in conjunction with other specific Software. Customer's use of the Software shall be subject to all such limitations and purchase of all applicable licenses.
- d. For any trial copy of the Software, Customer's right to use the Software expires 30 days after download, installation or use of the Software. Customer may operate the Software after the 30-day trial period only if Customer pays for a license to do so. Customer may not extend or create an additional trial period by re-installing the Software after the 30-day trial period.
- e. The Global Enterprise Edition of the Steel-Belted Radius software may be used by Customer only to manage access to Customer's enterprise network. Specifically, service provider customers are expressly prohibited from using the Global Enterprise Edition of the Steel-Belted Radius software to support any commercial network access services.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. **Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any 'locked' or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use Embedded Software on non-Juniper equipment; (j) use Embedded Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. **Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. **Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. **Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. **Warranty, Limitation of Liability, Disclaimer of Warranty.** The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE, EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. **Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. **Taxes.** All license fees payable under this agreement are exclusive of tax. Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software. If applicable, valid exemption documentation for each taxing jurisdiction shall be provided to Juniper prior to invoicing, and Customer shall promptly notify Juniper if their exemption is revoked or modified. All payments made by Customer shall be net of any applicable withholding tax. Customer will provide reasonable assistance to Juniper in connection with such withholding taxes by promptly: providing Juniper with valid tax receipts and other required documentation showing Customer's payment of any withholding taxes; completing appropriate applications that would reduce the amount of withholding tax to be paid; and notifying and assisting Juniper in any audit or tax proceeding related to transactions hereunder. Customer shall comply with all applicable tax laws and regulations, and Customer will promptly pay or reimburse Juniper for all costs and damages related to any liability incurred by Juniper as a result of Customer's non-compliance or delay with its responsibilities herein. Customer's obligations under this Section shall survive termination or expiration of this Agreement.

11. **Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. **Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14(ALT III) as applicable.

13. **Interface Information.** To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. **Third Party Software.** Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License ("GPL") or the GNU Library General Public License ("LGPL")), Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. **Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous

agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).

Abbreviated Table of Contents

	About This Guide	xlix
Part 1	Overview	
Chapter 1	Services Interfaces Overview	3
Chapter 2	Services Interfaces Configuration Statements	5
Part 2	Adaptive Services	
Chapter 3	Adaptive Services Overview	33
Chapter 4	Applications Configuration Guidelines	59
Chapter 5	Summary of Applications Configuration Statements	97
Chapter 6	Stateful Firewall Services Configuration Guidelines	107
Chapter 7	Summary of Stateful Firewall Configuration Statements	117
Chapter 8	Network Address Translation Services Configuration Guidelines	129
Chapter 9	Summary of Network Address Translation Configuration Statements	151
Chapter 10	Intrusion Detection Service Configuration Guidelines	175
Chapter 11	Summary of Intrusion Detection Service Configuration Statements	187
Chapter 12	IPsec Services Configuration Guidelines	209
Chapter 13	Summary of IPsec Services Configuration Statements	253
Chapter 14	Layer 2 Tunneling Protocol Services Configuration Guidelines	287
Chapter 15	Summary of Layer 2 Tunneling Protocol Configuration Statements	305
Chapter 16	Link Services IQ Interfaces Configuration Guidelines	319
Chapter 17	Summary of Link Services IQ Configuration Statements	381
Chapter 18	Voice Services Configuration Guidelines	393
Chapter 19	Summary of Voice Services Configuration Statements	407
Chapter 20	Class-of-Service Configuration Guidelines	419
Chapter 21	Summary of Class-of-Service Configuration Statements	429
Chapter 22	Service Set Configuration Guidelines	443
Chapter 23	Summary of Service Set Configuration Statements	457
Chapter 24	Service Interface Configuration Guidelines	475
Chapter 25	Summary of Service Interface Configuration Statements	489
Chapter 26	PGCP Configuration Guidelines for the BGF Feature	507
Chapter 27	Summary of PGCP Configuration Statements	513
Chapter 28	Service Interface Pools Configuration Guidelines	611
Chapter 29	Summary of Service Interface Pools Statements	613
Chapter 30	Border Signaling Gateway Configuration Guidelines	615

Chapter 31	Summary of Border Signaling Gateway Configuration Statements	619
Part 3	Dynamic Application Awareness	
Chapter 32	Dynamic Application Awareness Overview	671
Chapter 33	Application Identification Configuration Guidelines	675
Chapter 34	Summary of Application Identification Configuration Statements	685
Chapter 35	Application-Aware Access List Configuration Guidelines	705
Chapter 36	Summary of AACL Configuration Statements	711
Chapter 37	Local Policy Decision Function Configuration Guidelines	723
Chapter 38	Summary of L-PDF Configuration Statements	727
Part 4	Data Link Switching	
Chapter 39	Data Link Switching Overview	735
Chapter 40	Data Link Switching Configuration Guidelines	737
Chapter 41	Summary of Data Link Switching Configuration Statements	749
Part 5	Encryption Services	
Chapter 42	Encryption Overview	771
Chapter 43	Encryption Interfaces Configuration Guidelines	773
Chapter 44	Summary of Encryption Configuration Statements	783
Part 6	Flow Monitoring and Discard Accounting Services	
Chapter 45	Flow Monitoring and Discard Accounting Overview	793
Chapter 46	Flow Monitoring and Discard Accounting Configuration Guidelines	797
Chapter 47	Summary of Flow-Monitoring Configuration Statements	845
Chapter 48	Flow Collection Configuration Guidelines	901
Chapter 49	Summary of Flow Collection Configuration Statements	913
Chapter 50	Dynamic Flow Capture Configuration Guidelines	931
Chapter 51	Flow-Tap Configuration Guidelines	943
Chapter 52	Summary of Dynamic Flow Capture and Flow-Tap Configuration Statements	951
Part 7	Link and Multilink Services	
Chapter 53	Link and Multilink Services Overview	971
Chapter 54	Link and Multilink Services Configuration Guidelines	975
Chapter 55	Summary of Multilink and Link Services Configuration Statements	1017
Part 8	Real-Time Performance Monitoring Services	
Chapter 56	Real-Time Performance Monitoring Services Overview	1041
Chapter 57	Real-Time Performance Monitoring Configuration Guidelines	1043

Chapter 58	Summary of Real-Time Performance Monitoring Configuration Statements	1061
Part 9	Tunnel Services	
Chapter 59	Tunnel Services Overview	1089
Chapter 60	Tunnel Interfaces Configuration Guidelines	1093
Chapter 61	Summary of Tunnel Services Configuration Statements	1109
Part 10	Index	
	Index	1125
	Index of Statements and Commands	1145

Table of Contents

	About This Guide	xlix
	JUNOS Documentation and Release Notes	xlix
	Objectives	i
	Audience	i
	Supported Platforms	li
	Using the Indexes	li
	Using the Examples in This Manual	li
	Merging a Full Example	lii
	Merging a Snippet	lii
	Documentation Conventions	liii
	Documentation Feedback	lv
	Requesting Technical Support	lv
Part 1	Overview	
Chapter 1	Services Interfaces Overview	3
	Services PIC Types	3
	Supported Platforms	4
Chapter 2	Services Interfaces Configuration Statements	5
	[edit applications] Hierarchy Level	5
	[edit forwarding-options] Hierarchy Level	6
	[edit interfaces] Hierarchy Level	8
	[edit logical-systems] Hierarchy Level	11
	[edit protocols] Hierarchy Level	11
	[edit services] Hierarchy Level	12

Part 2**Adaptive Services**

Chapter 3**Adaptive Services Overview****33**

Enabling Service Packages	35
Layer 2 Service Package Capabilities and Interfaces	38
Services Configuration Procedure	39
Packet Flow Through the Adaptive Services or MultiServices PIC	40
Stateful Firewall Overview	41
Stateful Firewall Support for Application Protocols	42
Stateful Firewall Anomaly Checking	42
Network Address Translation Overview	44
Traditional NAT	44
Twice NAT	45
IPsec Overview	45
IPsec	46
Security Associations	46
IKE	46
Comparison of IPsec Services and ES Interface Configuration	47
Layer 2 Tunneling Protocol Overview	48
Voice Services Overview	48
Class of Service Overview	49
Examples: Services Interfaces Configuration	49

Chapter 4**Applications Configuration Guidelines****59**

Configuring Application Protocol Properties	60
Configuring an Application Protocol	60
Configuring the Network Protocol	62
Configuring the ICMP Code and Type	63
Configuring Source and Destination Ports	65
Configuring the Inactivity Timeout Period	68
Configuring SIP	68
Configuring an SNMP Command for Packet Matching	69
Configuring an RPC Program Number	69
Configuring the TTL Threshold	69
Configuring a Universal Unique Identifier	70
Configuring Application Sets	70
ALG Descriptions	70
Basic TCP ALG	71
Basic UDP ALG	71
BOOTP	72
DCE RPC Services	72
FTP	72
H323	73
ICMP	73
IIOP	74
NetShow	74
RealAudio	74

RPC and RPC Portmap Services	74
RTSP	76
SMB	76
SNMP	76
SQLNet	77
TFTP	77
Traceroute	77
UNIX Remote-Shell Services	77
WinFrame	78
Verifying the Output of ALG Sessions	78
FTP Example	78
Sample Output	78
FTP System Log Messages	79
Analysis	80
Troubleshooting Questions	80
RTSP ALG Example	81
Sample Output	81
Analysis	81
Troubleshooting Questions	82
System Log Messages	83
System Log Configuration	84
System Log Output	85
JUNOS Default Groups	85
Examples: Referencing the Preset Statement from the JUNOS Default Group	91
Examples: Configuring Application Protocols	93

Chapter 5

Summary of Applications Configuration Statements **97**

application	97
application-protocol	98
application-set	99
applications	99
destination-port	100
icmp-code	100
icmp-type	101
inactivity-timeout	101
learn-sip-register	102
protocol	103
rpc-program-number	104
sip-call-hold-timeout	104
snmp-command	105
source-port	105
ttl-threshold	106
uuid	106

Chapter 6	Stateful Firewall Services Configuration Guidelines	107
	Configuring Stateful Firewall Rules	108
	Configuring Match Direction for Stateful Firewall Rules	108
	Configuring Match Conditions in Stateful Firewall Rules	109
	Configuring Actions in Stateful Firewall Rules	110
	Configuring IP Option Handling	111
	Configuring Stateful Firewall Rule Sets	112
	Examples: Configuring Stateful Firewall Rules	112
Chapter 7	Summary of Stateful Firewall Configuration Statements	117
	allow-ip-options	118
	application-sets	119
	applications	119
	destination-address	120
	destination-address-range	120
	destination-prefix-list	121
	from	121
	match-direction	122
	rule	123
	rule-set	124
	services	124
	source-address	125
	source-address-range	125
	source-prefix-list	126
	syslog	126
	term	127
	then	128
Chapter 8	Network Address Translation Services Configuration Guidelines	129
	Configuring Addresses and Ports for Use in NAT Rules	130
	Configuring Pools of Addresses and Ports	130
	Specifying Destination and Source Prefixes when Pools Are Not Used	132
	Requirements for NAT Addresses	132
	Configuring IPv6 Multicast Filters	133
	Configuring NAT Rules	133
	Configuring Match Direction for NAT Rules	134
	Configuring NAT Type for Terms in NAT Rules	135
	Configuring Match Conditions in NAT Rules	136
	Configuring Actions in NAT Rules	137
	Configuring NAT Rule Sets	139
	Examples: Configuring NAT Rules	139
	Example: Configuring Dynamic Source Translation	140
	Example: Configuring Static Source Translation	140
	Example: Configuring Dynamic and Static Source Translation	140

Example: Configuring an Oversubscribed Pool with No Fallback	141
Example: Configuring an Oversubscribed Pool with Fallback to NAPT	142
Example: Configuring Static Source Translation with Multiple Prefixes and Address Ranges	142
Example: Assigning Addresses from a Dynamic Pool for Static Use	143
Example: Configuring NAT Rules Without Defining a Pool	144
Example: Preventing Translation of Specific Addresses	144
Example: Configuring NAT for Multicast Traffic	145
Rendezvous Point Configuration	145
Router 1 Configuration	148
Example: Configuring Twice NAT	149
Example: Configuring Full-Cone NAT	149

Chapter 9

Summary of Network Address Translation Configuration Statements

151

address	151
address-range	152
application-sets	152
applications	153
destination-address	153
destination-address-range	154
destination-pool	154
destination-prefix	155
destination-prefix-list	155
from	156
hint	157
ipv6-multicast-interfaces	157
match-direction	158
nat-type	158
no-translation	159
overload-pool	159
overload-prefix	160
pgcp	160
pool	161
port	162
ports-per-session	162
remotely-controlled	163
rule	164
rule-set	165
services	165
source-address	166
source-address-range	166
source-pool	167
source-prefix	167
source-prefix-list	168
syslog	168
term	169
then	170

translated	171
translation-type	172
translation-type (Traditional NAT)	172
translation-type (Twice NAT)	172
transport	173

Chapter 10**Intrusion Detection Service Configuration Guidelines 175**

Configuring IDS Rules	177
Configuring Match Direction for IDS Rules	178
Configuring Match Conditions in IDS Rules	179
Configuring Actions in IDS Rules	180
Configuring IDS Rule Sets	183
Examples: Configuring IDS Rules	184

Chapter 11**Summary of Intrusion Detection Service Configuration Statements 187**

aggregation	187
application-sets	188
applications	188
by-destination	189
by-pair	190
by-source	191
destination-address	192
destination-address-range	192
destination-prefix	193
destination-prefix-ipv6	193
destination-prefix-list	194
force-entry	194
from	195
ignore-entry	195
logging	196
match-direction	196
mss	197
rule	198
rule-set	199
services	199
session-limit	200
source-address	201
source-address-range	201
source-prefix	202
source-prefix-ipv6	202
source-prefix-list	203
syn-cookie	203
syslog	204
term	205
then	207
threshold	208

Chapter 12**IPsec Services Configuration Guidelines****209**

Minimum Security Association Configurations	211
Minimum Manual SA Configuration	211
Minimum Dynamic SA Configuration	211
Configuring Security Associations	212
Configuring Manual Security Associations	213
Configuring the Direction for IPsec Processing	213
Configuring the Protocol for a Manual IPsec SA	214
Configuring the Security Parameter Index	215
Configuring the Auxiliary Security Parameter Index	215
Configuring Authentication for a Manual IPsec SA	215
Configuring Encryption for a Manual IPsec SA	216
Configuring Dynamic Security Associations	217
Clearing Security Associations	218
Configuring IKE Proposals	218
Configuring the Authentication Algorithm for an IKE Proposal	219
Configuring the Authentication Method for an IKE Proposal	219
Configuring the Diffie-Hellman Group for an IKE Proposal	220
Configuring the Encryption Algorithm for an IKE Proposal	220
Configuring the Lifetime for an IKE SA	221
Example: Configuring an IKE Proposal	221
Configuring IKE Policies	221
Configuring the Mode for an IKE Policy	223
Configuring the Proposals in an IKE Policy	223
Configuring the Preshared Key for an IKE Policy	223
Configuring the Local Certificate for an IKE Policy	224
Configuring a Certificate Revocation List	224
Configuring the Description for an IKE Policy	225
Configuring Local and Remote IDs for IKE Phase 1 Negotiation	225
Example: Configuring an IKE Policy	226
Configuring IPsec Proposals	227
Configuring the Authentication Algorithm for an IPsec Proposal	227
Configuring the Description for an IPsec Proposal	227
Configuring the Encryption Algorithm for an IPsec Proposal	228
Configuring the Lifetime for an IPsec SA	228
Configuring the Protocol for a Dynamic SA	229
Configuring IPsec Policies	229
Configuring the Description for an IPsec Policy	230
Configuring Perfect Forward Secrecy	230
Configuring the Proposals in an IPsec Policy	230
Example: Configuring an IPsec Policy	231
Configuring IPsec Rules	231
Configuring Match Direction for IPsec Rules	232
Configuring Match Conditions in IPsec Rules	233
Configuring Actions in IPsec Rules	234
Enabling IPsec Packet Fragmentation	235
Configuring Destination Addresses for Dead Peer Detection	235
Disabling IPsec Anti-Replay	236

Enabling System Log Messages	237
Specifying the MTU for IPsec Tunnels	237
Configuring IPsec Rule Sets	237
Configuring Dynamic Endpoints for IPsec Tunnels	237
Authentication Process	238
Implicit Dynamic Rules	239
Reverse Route Insertion	239
Configuring an IKE Access Profile	240
Referencing the IKE Access Profile in a Service Set	241
Configuring the Interface Identifier	242
Default IKE and IPsec Proposals	242
Tracing IPsec Operations	243
Examples: Configuring IPsec Services	244
Example: Configuring Statically Assigned Tunnels	244
Example: Configuring Dynamically Assigned Tunnels	247

Chapter 13

Summary of IPsec Services Configuration Statements **253**

authentication	253
authentication-algorithm	254
authentication-algorithm (IKE)	254
authentication-algorithm (IPsec)	254
authentication-method	255
auxiliary-spi	255
backup-remote-gateway	256
clear-dont-fragment-bit	256
clear-ike-sas-on-pic-restart	257
clear-ipsec-sas-on-pic-restart	257
description	258
destination-address	258
dh-group	259
direction	260
dynamic	261
encryption	262
encryption-algorithm	263
from	264
ike	265
initiate-dead-peer-detection	266
ipsec	266
ipsec-inside-interface	267
lifetime-seconds	267
local-certificate	268
local-id	268
manual	269
match-direction	269
mode	270
no-anti-replay	270

perfect-forward-secrecy	271
policy	272
policy (IKE)	272
policy (IPsec)	273
pre-shared-key	273
proposal	274
proposal (IKE)	274
proposal (IPsec)	275
proposals	275
protocol	276
remote-gateway	276
remote-id	277
rule	278
rule-set	279
services	279
source-address	280
spi	280
syslog	281
term	282
then	283
traceoptions	284
tunnel-mtu	285

Chapter 14**Layer 2 Tunneling Protocol Services Configuration Guidelines 287**

L2TP Services Configuration Overview	289
L2TP Minimum Configuration	290
Configuring L2TP Tunnel Groups	292
Configuring Access Profiles for L2TP Tunnel Groups	293
Configuring the Local Gateway Address and PIC	293
Configuring Window Size for L2TP Tunnels	294
Configuring Timers for L2TP Tunnels	294
Hiding Attribute-Value Pairs for L2TP Tunnels	295
Configuring System Logging of L2TP Tunnel Activity	295
Configuring the Identifier for Logical Interfaces that Provide L2TP Services	296
Example: Configuring Multilink PPP on a Shared Logical Interface	297
AS PIC Redundancy for L2TP Services	298
Tracing L2TP Operations	299
Examples: Configuring L2TP Services	300

Chapter 15**Summary of Layer 2 Tunneling Protocol Configuration Statements 305**

facility-override	305
hello-interval	306
hide-avps	306
host	307
l2tp-access-profile	307
local-gateway address	308

log-prefix	308
maximum-send-window	309
ppp-access-profile	309
receive-window	310
retransmit-interval	310
service-interface	311
services	312
services (Hierarchy)	312
services (L2TP System Logging)	313
syslog	314
traceoptions	315
tunnel-group	317
tunnel-timeout	318

Chapter 16

Link Services IQ Interfaces Configuration Guidelines 319

Layer 2 Service Package Capabilities and Interfaces	320
Configuring LSQ Interface Redundancy Across Multiple Routers Using SONET	
APS	322
Configuring the Association between LSQ and SONET Interfaces	322
Configuring SONET APS Interoperability with Cisco Systems FRF.16	323
Restrictions on APS Redundancy for LSQ Interfaces	324
Configuring LSQ Interface Redundancy in a Single Router Using SONET	
APS	324
Configuring LSQ Interface Redundancy in a Single Router Using Virtual	
Interfaces	324
Configuring Redundant Paired LSQ Interfaces	325
Restrictions on Redundant LSQ Interfaces	326
Configuring Link State Replication for Redundant Link PICs	327
Examples: Configuring Redundant LSQ Interfaces for Failure	
Recovery	328
Configuring CoS Scheduling Queues on Logical LSQ Interfaces	332
Configuring Scheduler Buffer Size	334
Configuring Scheduler Priority	334
Configuring Scheduler Shaping Rate	334
Configuring Drop Profiles	335
Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces	336
Reserving Bundle Bandwidth for Link-Layer Overhead on LSQ Interfaces	338
Configuring Multiclass MLPPP on LSQ Interfaces	338
Oversubscribing Interface Bandwidth on LSQ Interfaces	340
Example: Oversubscribing an LSQ Interface	343
Configuring Guaranteed Minimum Rate on LSQ Interfaces	343
Example: Configuring Guaranteed Minimum Rate	346
Configuring Link Services and CoS on Services PICs	347
Configuring Link Services and CoS on J-series Services Routers	350
Configuring LSQ Interfaces as NxT1 or NxT1 Bundles Using MLPPP	351
Example: Configuring an LSQ Interface as an NxT1 Bundle Using	
MLPPP	354

Configuring LSQ Interfaces as NxT1 or NxE1 Bundles Using FRF.16	356
Example: Configuring an LSQ Interface as an NxT1 Bundle Using FRF.16	359
Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using MLPPP and LFI	362
Example: Configuring an LSQ Interface for a Fractional T1 Interface Using MLPPP and LFI	364
Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using FRF.12	366
Examples: Configuring an LSQ Interface for a Fractional T1 Interface Using FRF.12	369
Configuring LSQ Interfaces as NxT1 or NxE1 Bundles Using FRF.15	373
Configuring LSQ Interfaces for T3 Links Configured for Compressed RTP over MLPPP	374
Configuring LSQ Interfaces as T3 or OC3 Bundles Using FRF.12	375
Configuring LSQ Interfaces for ATM2 IQ Interfaces Using MLPPP	377

Chapter 17**Summary of Link Services IQ Configuration Statements 381**

cisco-interoperability	381
forwarding-class	382
fragment-threshold	383
fragmentation-map	383
fragmentation-maps	384
hot-standby	384
link-layer-overhead	385
lsq-failure-options	385
multilink-class	386
multilink-max-classes	386
no-fragmentation	387
no-termination-request	387
per-unit-scheduler	388
preserve-interface	388
primary	389
redundancy-options	389
secondary	390
trigger-link-failure	390
warm-standby	391

Chapter 18**Voice Services Configuration Guidelines 393**

Configuring Services Interfaces for Voice Services	394
Configuring the Logical Interface Address for the MLPPP Bundle	394
Configuring Compression of Voice Traffic	395
Configuring Delay-Sensitive Packet Interleaving	396
Example: Configuring Compression of Voice Traffic	396
Configuring Encapsulation for Voice Services	397

Configuring Network Interfaces for Voice Services	397
Configuring Voice Services Bundles with MLPPP Encapsulation	398
Configuring the Compression Interface with PPP Encapsulation	398
Configuring VoIP Routing on J-series Services Routers	398
Functional Components	399
Configuring the VoIP Interface	399
Configuring the Media Gateway Controller List	400
Configuring Dynamic Call Admission Control	401
Examples: Configuring Voice Services	402

Chapter 19**Summary of Voice Services Configuration Statements 407**

activation-priority	407
address	408
bearer-bandwidth-limit	409
bundle	409
compression	410
compression-device	410
dynamic-call-admission-control	411
encapsulation	412
f-max-period	412
family	413
fragment-threshold	414
interfaces	414
maximum-contexts	415
port	415
queues	416
rtp	416
unit	417

Chapter 20**Class-of-Service Configuration Guidelines 419**

Restrictions and Cautions for CoS Configuration on Services Interfaces	420
Configuring CoS Rules	420
Configuring Match Direction for CoS Rules	421
Configuring Match Conditions In CoS Rules	422
Configuring Actions in CoS Rules	423
Configuring Application Profiles for Use as CoS Rule Actions	424
Configuring Reflexive and Reverse CoS Rule Actions	424
Example: Configuring CoS Rules	425
Configuring CoS Rule Sets	425
Examples: Configuring CoS on Services Interfaces	426

Chapter 21**Summary of Class-of-Service Configuration Statements 429**

application-profile	429
application-sets	430
applications	430
destination-address	431

destination-prefix-list	431
dscp	432
forwarding-class	432
from	433
match-direction	433
(reflexive reverse)	434
rule	435
rule-set	436
services	436
sip-text	437
sip-video	437
sip-voice	438
source-address	438
source-prefix-list	439
syslog	439
term	440
then	441

Chapter 22**Service Set Configuration Guidelines****443**

Configuring Service Sets to be Applied to Services Interfaces	444
Configuring Interface Service Sets	444
Configuring Next-Hop Service Sets	445
Determining Traffic Direction	446
Interface Style Service Sets	447
Next-Hop Style Service Sets	447
Configuring Service Rules	448
Configuring IPsec Service Sets	448
Configuring the Local Gateway Address for IPsec Service Sets	449
IKE Addresses in VRF Instances	449
Configuring IKE Access Profiles for IPsec Service Sets	450
Configuring Certification Authorities for IPsec Service Sets	450
Configuring Service Set Limitations	451
Configuring System Logging for Service Sets	451
Enabling Services PICs to Accept Multicast Traffic	453
Tracing Services PIC Operations	453
Configuring the Adaptive Services Log Filename	454
Configuring the Number and Size of Adaptive Services Log Files	454
Configuring Access to the Log File	454
Configuring a Regular Expression for Lines to Be Logged	455
Configuring the Trace Operations	455
Example: Configuring Service Sets	456

Chapter 23**Summary of Service Set Configuration Statements****457**

adaptive-services-pics	457
allow-multicast	458
facility-override	458
host	459
ids-rules	459

ike-access-profile	460
interface-service	460
ipsec-vpn-options	461
ipsec-vpn-rules	461
local-gateway	462
log-prefix	462
logging	463
max-flows	463
nat-rules	464
next-hop-service	465
pgcp-rules	466
service-interface	466
service-set	467
services	468
services (Hierarchy)	468
services (System Logging)	469
stateful-firewall-rules	470
syslog	470
tcp-mss	471
traceoptions	472
trusted-ca	473

Chapter 24**Service Interface Configuration Guidelines****475**

Services Interface Naming Overview	476
Configuring the Address and Domain for Services Interfaces	478
Configuring Default Timeout Settings for Services Interfaces	478
Configuring System Logging for Services Interfaces	479
Enabling Fragmentation on GRE Tunnels	480
Applying Filters and Services to Interfaces	481
Configuring Service Filters	482
Configuring AS or MultiServices PIC Redundancy	483
Examples: Configuring Services Interfaces	486

Chapter 25**Summary of Service Interface Configuration Statements****489**

address	489
clear-dont-fragment-bit	490
dial-options	491
facility-override	492
family	493
host	494
inactivity-timeout	494
input	495
interfaces	495
log-prefix	496
open-timeout	496
output	497
post-service-filter	497
primary	498

redundancy-options	498
secondary	499
service	499
service-domain	500
service-filter	500
service-set	501
services	502
services-options	503
syslog	504
unit	505

Chapter 26**PGCP Configuration Guidelines for the BGF Feature****507****Chapter 27****Summary of PGCP Configuration Statements****513**

administrative	514
administrative (Control Association)	514
administrative (Virtual Interface)	515
algorithm	515
application-data-inactivity-detection	516
audit-observed-events-returns	516
base-root	517
bgf-core	518
cancel-graceful	519
cancel-graceful (Control Association)	519
cancel-graceful (Virtual Interface)	520
cleanup-timeout	520
context-indications	521
control-association-indications	522
controller-address	522
controller-failure	523
controller-port	523
data-inactivity-detection	524
default	525
delivery-function	526
destination-address	526
destination-port	527
detect	527
diffserv	528
disable-session-mirroring	528
disconnect	529
down	529
dscp	530
encoding	530
event-timestamp-notification	531
failover-cold	531
failover-warm	532
failure	533
failure (Control Association)	533
failure (Virtual Interface)	534

fast-update-filters	534
file	535
flag	536
gateway	537
gateway-address	541
gateway-controller	542
gateway-port	543
graceful	544
graceful (Control Association)	544
graceful (Virtual Interface)	545
graceful-restart	545
h248-options	546
h248-properties	548
h248-stack	551
h248-timers	552
hanging-termination-detection	552
inactivity-delay	553
inactivity-duration	553
inactivity-timer	554
inactivity-timeout	554
initial-average-ack-delay	555
interface	555
interim-ah-scheme	556
ip-flow-stop-detection	556
latch-deadlock-delay	557
link-loss	557
max-burst-size	558
max-burst-size (All Streams)	558
max-burst-size (RTCP Streams)	559
max-concurrent-calls	560
maximum-fuf-percentage	561
maximum-inactivity-time	562
maximum-net-propagation-delay	563
maximum-synchronization-mismatches	563
maximum-synchronization-time	564
maximum-terms	564
maximum-waiting-delay	565
media	565
media-service	566
mg-maximum-pdu-size	567
mg-originated-pending-limit	568
mg-provisional-response-timer-value	569
mg-segmentation-timer	570
mgc-maximum-pdu-size	571
mgc-originated-pending-limit	572
mgc-provisional-response-timer-value	573
mgc-segmentation-timer	574
monitor	575
nat-pool	575
network-operator-id	576
no-rtcp-check	576

normal-mg-execution-time	577
normal-mgc-execution-time	578
notification-behavior	579
notification-rate-limit	579
notification-regulation	580
no-dscp-bit-mirroring	580
overload-control	581
peak-data-rate	582
peak-data-rate (All Streams)	582
peak-data-rate (RTCP)	583
queue-limit-percentage	584
reconnect	585
reject-all-commands-threshold	585
reject-new-calls-threshold	586
report-service-change	586
request-timestamp	587
routing-instance	587
rtp	588
rtcp	588
rule	589
rule-set	589
sbc-utils	590
segmentation	591
send-notification-on-delay	592
service-change	593
service-change-type	594
service-interface	594
service-state	595
service-state (Virtual BGF)	595
service-state (Virtual Interface)	596
services	596
session-mirroring	597
source-address	597
source-port	598
state-loss	598
stop-detection-on-drop	599
sustained-data-rate	600
sustained-data-rate	600
sustained-data-rate (RTCP Streams)	601
timerx	602
tmax-retransmission-delay	602
traceoptions	603
traffic-management	604
up	605
use-lower-case	605
use-wildcard-response	606
virtual-interface	606
virtual-interface-down	607
virtual-interface-indications	608
virtual-interface-up	608
warm	609

Chapter 28	Service Interface Pools Configuration Guidelines	611
	Configuring Service Interface Pools	611
Chapter 29	Summary of Service Interface Pools Statements	613
	interface	613
	pool	614
	service-interface-pools	614
Chapter 30	Border Signaling Gateway Configuration Guidelines	615
Chapter 31	Summary of Border Signaling Gateway Configuration Statements	619
	admission-control	620
	admission-control (Border Signaling Gateway)	620
	admission-control (New Call Usage Policy)	620
	committed-burst-size	621
	committed-information-rate	621
	datastore	622
	dialogs	623
	dscp	624
	egress-service-point	624
	embedded-spdf	625
	file	626
	flag	627
	framework	629
	from	631
	from (New Call Usage Policy)	632
	from (New Transaction Policy)	633
	from (Service Class)	634
	gateway	635
	media-policy	638
	media-type	638
	minimum	639
	new-call-usage-policies	639
	new-call-usage-policy	640
	new-call-usage-policy-set	641
	new-transaction-policies	641
	new-transaction-policy	642
	new-transaction-policy-set	643
	next-hop	644
	route	645
	sbc-utils	646
	service-class	647

service-interface	648
service-interface (Gateway)	648
service-interface (Service Point)	648
service-point	649
service-point-type	649
service-policies	650
services	650
session-trace	651
signaling	652
sip	654
sip-stack	656
term	658
term (New Call Usage Policy)	658
term (New Transaction Policy)	659
term (Service Class)	660
then	661
then (New Call Usage Policy)	661
then (New Transaction Policy)	662
then (Service Class)	663
timer-c	663
timers	664
traceoptions	665
transactions	666
transport-details	667

Part 3

Dynamic Application Awareness

Chapter 32

Dynamic Application Awareness Overview **671**

IDP Overview	671
APPID Overview	672
AACL Overview	672
L-PDF Overview	673

Chapter 33

Application Identification Configuration Guidelines **675**

Defining an Application Identification	676
Configuring APPID Rules	677
Configuring Application Profiles	679
Configuring Application Groups	679
Configuring Global APPID Properties	680
Configuring Automatic Download of Software Updates	680
Tracing APPID Operations	681
Configuring the APPID Log Filename	682
Configuring the Number and Size of APPID Log Files	682
Configuring Access to the Log File	682

Configuring a Regular Expression for Lines to Be Logged	683
Configuring the Tracing Flags	683
Examples: Configuring Application Identification Properties	683

Chapter 34**Summary of Application Identification Configuration Statements 685**

address	685
application	686
application (Defining)	686
application (Including in Rule)	686
application-group	687
application-groups	687
application-system-cache-timeout	688
applications	688
automatic	689
destination	689
disable	690
disable (APPID Application)	690
disable (APPID Application Group)	690
disable (APPID Port Mapping)	690
download	691
idle-timeout	691
index	692
ip	692
max-checked-bytes	693
min-checked-bytes	693
no-application-identification	694
no-application-system-cache	694
no-clear-application-system-cache	694
no-signature-based	695
order	695
port-mapping	696
port-range	696
profile	697
rule	698
rule (Configuring)	698
rule (Including in Rule Set)	699
rule-set	699
services	700
session-timeout	700
source	701
traceoptions	702
type	703
type-of-service	703
url	704

Chapter 35	Application-Aware Access List Configuration Guidelines	705
	Configuring ACL Rules	706
	Configuring Match Direction for ACL Rules	706
	Configuring Match Conditions in ACL Rules	707
	Configuring Actions in ACL Rules	708
	Configuring ACL Rule Sets	709
	Example: Configuring ACL Rules	709
Chapter 36	Summary of ACL Configuration Statements	711
	applications	711
	application-groups	712
	application-group-any	712
	destination-address	713
	destination-address-range	713
	destination-prefix-list	714
	from	714
	match-direction	715
	rule	716
	rule-set	717
	services	717
	source-address	718
	source-address-range	718
	source-prefix-list	719
	term	720
	then	721
Chapter 37	Local Policy Decision Function Configuration Guidelines	723
	Configuring L-PDF Profiles	723
	Applying L-PDF Profiles to Service Sets	724
	Tracing L-PDF Operations	725
Chapter 38	Summary of L-PDF Configuration Statements	727
	acl-fields	728
	policy-decision-statistics-profile	729
	traceoptions	730

Part 4	Data Link Switching	
Chapter 39	Data Link Switching Overview	735
	Overview	735
	DLSw Standards	735
Chapter 40	Data Link Switching Configuration Guidelines	737
	Configuring DLSw	738
	Minimum DLSw Configuration	738
	Configuring the Remote Peer	738
	Configuring Load Balancing	738
	Configuring DLSw Timers	739
	Configuring the Local Peer	740
	Examples: Configuring DLSw Peers	740
	Configuring the Initial Pacing Window	740
	Configuring the Idle Timeout	741
	Configuring the Multicast Address	741
	Configuring Class of Service	741
	Example: Configuring CoS for a DLSw Connection	741
	Tracing DLSw Protocol Traffic	743
	Configuring Logical Link Control on Interfaces	743
	Example: Configuring LLC Options on an Interface	744
	Configuring DLSw Ethernet Redundancy Using LLC2 Properties	744
	Example: Configuring DLSw Ethernet Redundancy	746
Chapter 41	Summary of Data Link Switching Configuration Statements	749
	advertise-interval	749
	circuit-weight	750
	connection-idle-timeout	750
	cost	751
	destination	751
	destination-interface	752
	dls w	752
	dls w-cos	753
	explorer-wait-time	753
	hold-time	754
	interface	755
	load-balance	755
	local-mac	756
	local-peer	756
	map	757
	multicast-address	757
	no-preempt	757
	peer	758
	preempt	759
	priority	760

promiscuous	760
protocols	761
reachability-cache-timeout	761
receive-initial-pacing	762
redundancy-group	763
remote-mac	763
remote-peer	764
traceoptions	765
track	767
type-of-service	768

Part 5 Encryption Services

Chapter 42 Encryption Overview 771

Chapter 43 Encryption Interfaces Configuration Guidelines 773

Configuring Encryption Interfaces	773
Specifying the Security Association Name for Encryption Interfaces	774
Configuring the MTU for Encryption Interfaces	774
Example: Configuring an Encryption Interface	774
Configuring Filters for Traffic Transiting the ES PIC	775
Traffic Overview	775
Configuring the Security Association	776
Configuring an Outbound Traffic Filter	777
Example: Configuring an Outbound Traffic Filter	777
Applying the Outbound Traffic Filter	778
Example: Applying the Outbound Traffic Filter	778
Configuring an Inbound Traffic Filter	778
Example: Configuring an Inbound Traffic Filter	779
Applying the Inbound Traffic Filter to the Encryption Interface	779
Example: Applying the Inbound Traffic Filter to the Encryption Interface	779
Configuring an ES Tunnel Interface for a Layer 3 VPN	780
Configuring ES PIC Redundancy	780
Example: Configuring ES PIC Redundancy	781
Configuring IPsec Tunnel Redundancy	781

Chapter 44 Summary of Encryption Configuration Statements 783

address	783
backup-destination	784
backup-interface	784
destination	785
es-options	785
family	786
filter	787

interfaces	787
ipsec-sa	788
source	788
tunnel	789
unit	790

Part 6

Flow Monitoring and Discard Accounting Services

Chapter 45

Flow Monitoring and Discard Accounting Overview 793

Passive Flow Monitoring	793
Active Flow Monitoring	794

Chapter 46

Flow Monitoring and Discard Accounting Configuration Guidelines 797

Configuring Traffic Sampling	801
Minimum Configuration for Traffic Sampling	801
Configuring Traffic Sampling	802
Disabling Traffic Sampling	803
Configuring Traffic Sampling Output	803
Traffic Sampling Output Format	805
Tracing Traffic Sampling Operations	805
Traffic Sampling Examples	806
Example: Sampling a Single SONET Interface	806
Example: Sampling All Traffic from a Single IP Address	807
Example: Sampling All FTP Traffic	808
Configuring Flow Monitoring	809
Configuring Flow-Monitoring Interfaces	809
Configuring Flow-Monitoring Properties	810
Directing Traffic to Flow-Monitoring Interfaces	811
Exporting Flows	811
Configuring Time Periods when Flow Monitoring is Active and Inactive	811
Example: Configuring Flow Monitoring	812
Enabling Flow Aggregation	813
Configuring Flow Aggregation to Use Version 5 or Version 8 cflowd	814
Configuring Flow Aggregation to Use Version 9 Flow Templates	816
Configuring the Traffic to be Sampled	817
Configuring the Version 9 Template Properties	817
Restrictions	818
Fields Included in Each Template Type	819
MPLS Sampling Behavior	820
Verification	820
Examples: Configuring Version 9 Flow Templates	821

Directing Replicated Flows to Multiple Flow Servers	822
Directing Replicated Routing Engine–Based Sampling Flows to Multiple Servers	822
Directing Replicated Version 9 Flow Aggregates to Multiple Servers	823
Logging cflowd Flows Before Export	824
Configuring Port Mirroring	825
Configuring Tunnels	827
Filter-Based Forwarding with Multiple Monitoring Interfaces	828
Restrictions	828
Configuring Port Mirroring on Services Interfaces	829
Examples: Configuring Port Mirroring	830
Load Balancing Among Multiple Monitoring Interfaces	833
Configuring Discard Accounting	837
Enabling Passive Flow Monitoring	838
Passive Flow Monitoring for MPLS Encapsulated Packets	839
Removing MPLS Labels from Incoming Packets	840
Example: Enabling Passive Flow Monitoring	841
Configuring Services Interface Redundancy with Flow Monitoring	843

Chapter 47

Summary of Flow-Monitoring Configuration Statements **845**

accounting	846
address	847
aggregate-export-interval	847
aggregation	848
autonomous-system-type	849
cflowd	850
cflowd (Discard Accounting and Sampling)	850
cflowd (Flow Monitoring)	851
core-dump	851
destination	852
disable	852
engine-id	853
engine-type	853
export-format	854
family	855
family (Interfaces)	855
family (Monitoring)	856
family (Port Mirroring)	857
family (Sampling)	857
file	858
file (Sampling)	858
file (Trace Options)	858
filename	859
files	859
filter	860
flow-active-timeout	861
flow-export-destination	862
flow-inactive-timeout	862
flow-monitoring	863

forwarding-options	864
input	865
input (Port Mirroring)	865
input (Sampling)	865
input-interface-index	866
interface	867
interface (Accounting or Sampling)	867
interface (Monitoring)	868
interface (Port Mirroring)	868
interfaces	869
ipv4-template	869
ipv6-template	869
label-position	870
local-dump	870
max-packets-per-second	871
monitoring	872
mpls-ipv4-template	873
mpls-template	873
multiservice-options	874
next-hop	874
next-hop-group	875
no-core-dump	875
no-filter-check	876
no-local-dump	876
no-stamp	876
no-syslog	876
no-world-readable	876
option-refresh-rate	877
output	878
output (Accounting)	878
output (Monitoring)	879
output (Port Mirroring)	879
output (Sampling)	880
output-interface-index	881
passive-monitor-mode	881
pop-all-labels	882
port	882
port-mirroring	883
rate	884
receive-options-packets	884
receive-ttl-exceeded	885
required-depth	885
run-length	886
sampling	887
sampling (Forwarding Options)	888
sampling (Interfaces)	889
services	889
size	890
source-address	891
stamp	891
syslog	892

template	893
template (Forwarding Options)	893
template (Services)	894
template-refresh-rate	895
traceoptions	895
unit	896
version	897
version9	898
version9 (Forwarding Options)	898
version9 (Services)	899
world-readable	900

Chapter 48**Flow Collection Configuration Guidelines 901**

Configuring Flow Collection	903
Configuring Destination FTP Servers for Flow Records	903
Configuring a Packet Analyzer	904
Configuring File Formats	904
Configuring Interface Mappings	905
Configuring Transfer Logs	905
Configuring Retry Attempts	906
Sending cflowd Records to Flow Collector Interfaces	906
Configuring Flow Collection Mode and Interfaces on Services PICs	906
Example: Configuring Flow Collection	907

Chapter 49**Summary of Flow Collection Configuration Statements 913**

analyzer-address	913
analyzer-id	913
archive-sites	914
collector	914
data-format	915
destinations	915
filename-prefix	916
file-specification	917
file-specification (File Format)	917
file-specification (Interface Mapping)	917
flow-collector	918
ftp	920
ftp (Flow Collector Files)	921
ftp (Transfer Log Files)	922
interface-map	922
maximum-age	923
name-format	924
password	926
password (Flow Collector File Servers)	926
password (Transfer Log File Servers)	926
retry	927
retry-delay	927
transfer	928

transfer-log-archive	928
username	929
variant	929

Chapter 50 Dynamic Flow Capture Configuration Guidelines 931

Dynamic Flow Capture Architecture	931
Liberal Sequence Windowing	932
Configuring Dynamic Flow Capture	932
Configuring the Capture Group	933
Configuring the Content Destination	934
Configuring the Control Source	935
Configuring the DFC PIC Interface	936
Configuring System Logging	937
Configuring Thresholds	937
Limiting the Number of Duplicates of a Packet	938
Example: Configuring Dynamic Flow Capture	939

Chapter 51 Flow-Tap Configuration Guidelines 943

Flow-Tap Architecture	944
Configuring the Flow-Tap Service	945
Configuring the Flow-Tap Interface	945
Strengthening Flow-Tap Security	946
Restrictions on Flow-Tap Services	946
Configuring FlowTapLite	947
Examples: Configuring Flow-Tap Services	948

Chapter 52 Summary of Dynamic Flow Capture and Flow-Tap Configuration Statements 951

address	951
allowed-destinations	952
capture-group	953
content-destination	954
control-source	955
duplicates-dropped-periodicity	955
dynamic-flow-capture	956
flow-tap	957
flow-tap-lite	957
g-duplicates-dropped-periodicity	958
g-max-duplicates	958
hard-limit	959
hard-limit-target	959
input-packet-rate-threshold	960
interface	960
interfaces	961
max-duplicates	961
minimum-priority	962

no-syslog	962
notification-targets	963
pic-memory-threshold	963
service-port	964
services	964
shared-key	965
soft-limit	965
soft-limit-clear	966
source-addresses	966
ttl	967

Part 7

Link and Multilink Services

Chapter 53

Link and Multilink Services Overview	971
---	------------

Chapter 54

Link and Multilink Services Configuration Guidelines	975
---	------------

Multilink and Link Services PICs Overview	976
Configuring the Number of Bundles on Link Services PICs	977
Configuring the Links in a Multilink or Link Services Bundle	978
Multilink and Link Services Logical Interface Configuration Overview	979
Default Settings for Multilink and Link Services Logical Interfaces	980
Configuring Encapsulation for Multilink and Link Services Logical Interfaces	981
Configuring the Drop Timeout Period on Multilink and Link Services Logical Interfaces	982
Limiting Packet Payload Size on Multilink and Link Services Logical Interfaces	983
Configuring the Minimum Number of Active Links on Multilink and Link Services Logical Interfaces	984
Configuring MRRU on Multilink and Link Services Logical Interfaces	985
Configuring the Sequence Header Format on Multilink and Link Services Logical Interfaces	986
Configuring DLCIs on Link Services Logical Interfaces	986
Configuring Point-to-Point DLCIs for MLFR FRF.16 and MLPPP Bundles	987
Configuring Multicast-Capable DLCIs for MLFR FRF.16 Bundles	987
Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces	988
Configuring LFI with DLCI Scheduling	989
Example: Configuring LFI with DLCI Scheduling	989
Configuring Compressed RTP on J-series Services Routers	990
Example: Configuring Compressed RTP with MLPPP Encapsulation	992
Example: Configuring Compressed RTP with PPP Encapsulation	992
Configuring Link Services Physical Interfaces	993
Default Settings for Link Services Interfaces	993
Configuring Encapsulation for Link Services Physical Interfaces	994

Configuring Acknowledgment Timers on Link Services Physical Interfaces	994
Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16	995
Configuring Keepalives on Link Services Physical Interfaces	996
Configuring CoS on Link Services Interfaces	997
CoS for Link Services Interfaces on J-series Services Routers	997
CoS for Link Services Interfaces on M-series and T-series Routing Platforms	997
Example: Configuring CoS on Link Services Interfaces	999
Examples: Configuring Multilink Interfaces	1002
Example: Configuring a Multilink Interface with MLPPP	1003
Example: Configuring a Multilink Interface with MLPPP over ATM 2 Interfaces	1003
Configuring a Multilink Interface with MLFR FRF.15	1005
Examples: Configuring Link Interfaces	1006
Example: Configuring a Link Services Interface with Two Links	1006
Example: Configuring a Link Services Interface with MLPPP	1007
Example: Configuring a Link Services Interface with MLFR FRF.15	1008
Example: Configuring a Link Services PIC with MLFR FRF.16	1009
Example: Configuring Link and Voice Services Interfaces with a Combination of Bundle Types	1009

Chapter 55

Summary of Multilink and Link Services Configuration Statements

1017

acknowledge-retries	1017
acknowledge-timer	1018
action-red-differential-delay	1018
address	1019
bundle	1019
compression-device	1020
destination	1020
disable-mlppp-inner-ppp-pfc	1021
dlci	1021
drop-timeout	1022
encapsulation	1023
encapsulation (Logical Interface)	1023
encapsulation (Physical Interface)	1024
family	1025
fragment-threshold	1026
hello-timer	1026
interfaces	1027
interleave-fragments	1027
lmi-type	1028
minimum-links	1028
mlfr-uni-nni-bundle-options	1029
mrru	1030
mtu	1031
multicast-dlci	1031

n391	1032
n392	1032
n393	1033
red-differential-delay	1033
short-sequence	1034
t391	1034
t392	1035
unit	1036
yellow-differential-delay	1037

Part 8

Real-Time Performance Monitoring Services

Chapter 56	Real-Time Performance Monitoring Services Overview	1041
-------------------	---	-------------

Chapter 57	Real-Time Performance Monitoring Configuration Guidelines	1043
-------------------	--	-------------

Configuring BGP Neighbor Discovery Through RPM	1044
Configuring Real-Time Performance Monitoring	1046
Configuring RPM Probes	1046
Configuring RPM Receiver Servers	1051
Limiting the Number of Concurrent RPM Probes	1051
Configuring RPM Timestamping	1052
Configuring RPM Timestamps on M-series, MX-series, and T-series Routing Platforms	1052
Configuring RPM Timestamps on J-series Services Routers	1054
Configuring TWAMP	1054
Configuring TWAMP Interfaces	1055
Configuring TWAMP Servers	1055
Examples: Configuring BGP Neighbor Discovery Through RPM	1056
Examples: Configuring Real-Time Performance Monitoring	1057

Chapter 58	Summary of Real-Time Performance Monitoring Configuration Statements	1061
-------------------	---	-------------

authentication-mode	1061
client-list	1062
data-fill	1062
data-size	1063
destination-interface	1064
destination-port	1065
dscp-code-point	1066
hardware-timestamp	1067
history-size	1067
inactivity-timeout	1068
logical-system	1068
maximum-connections	1069
maximum-connections-per-client	1069

maximum-sessions	1070
maximum-sessions-per-connection	1070
moving-average-size	1071
one-way-hardware-timestamp	1071
port	1072
port (RPM)	1072
port (TWAMP)	1072
probe	1073
probe-count	1074
probe-interval	1074
probe-limit	1075
probe-server	1075
probe-type	1076
routing-instance	1076
routing-instances	1077
rpm	1077
server	1078
services	1078
source-address	1079
target	1079
tcp	1080
test	1081
test-interval	1082
thresholds	1083
traps	1084
twamp	1085
twamp-server	1085
udp	1086

Part 9

Tunnel Services

Chapter 59

Tunnel Services Overview

1089

Chapter 60

Tunnel Interfaces Configuration Guidelines

1093

Configuring Unicast Tunnels	1093
Configuring a Key Number on GRE Tunnels	1095
Enabling Fragmentation on GRE Tunnels	1096
Specifying an MTU Setting for the Tunnel	1096
Configuring a GRE Tunnel to Copy ToS Bits to the Outer IP Header	1097
Configuring Packet Reassembly	1097
Restricting Tunnels to Multicast Traffic	1098
Configuring Logical Tunnel Interfaces	1098
Connecting Logical Systems	1099
Configuring Logical Tunnels on J-series Platforms	1100
Configuring Tunnel Interfaces for Routing Table Lookup	1100
Configuring Virtual Loopback Tunnels for VRF Table Lookup	1101
Configuring PIM Tunnels	1102

Configuring IPv6-over-IPv4 Tunnels	1103
Configuring Dynamic Tunnels	1103
Configuring Tunnel Interfaces on MX-series Routers	1104
Examples: Configuring Unicast Tunnels	1104
Example: Configuring a Virtual Loopback Tunnel for VRF Table Lookup	1105
Example: Configuring an IPv6-over-IPv4 Tunnel	1106
Example: Configuring Logical Tunnels	1106

Chapter 61

Summary of Tunnel Services Configuration Statements	1109
--	-------------

allow-fragmentation	1109
backup-destination	1110
copy-tos-to-outer-ip-header	1110
destination	1111
destination (Tunnel Remote End)	1111
destination (Routing Instance)	1111
destination-networks	1112
do-not-fragment	1112
dynamic-tunnels	1113
interfaces	1113
key	1114
multicast-only	1114
peer-unit	1115
reassemble-packets	1115
routing-instance	1116
routing-instances	1116
routing-options	1117
source	1117
source-address	1118
ttl	1118
tunnel	1119
tunnel-type	1120
unit	1121

Part 10**Index**

Index	1125
Index of Statements and Commands	1145

List of Figures

Part 2	Adaptive Services	
Chapter 3	Adaptive Services Overview	33
	Figure 1: Packet Flow Through the Adaptive Services or MultiServices PIC	41
Chapter 8	Network Address Translation Services Configuration Guidelines	129
	Figure 2: Configuring NAT for Multicast Traffic	145
Chapter 12	IPsec Services Configuration Guidelines	209
	Figure 3: IPsec Dynamic Endpoint Tunneling Topology	247
Part 4	Data Link Switching	
Chapter 40	Data Link Switching Configuration Guidelines	737
	Figure 4: DLSw Ethernet Redundancy Topology	746
Part 5	Encryption Services	
Chapter 43	Encryption Interfaces Configuration Guidelines	773
	Figure 5: Example: IPsec Tunnel Connecting Security Gateways	775
	Figure 6: IPsec Tunnel Redundancy	782
Part 6	Flow Monitoring and Discard Accounting Services	
Chapter 45	Flow Monitoring and Discard Accounting Overview	793
	Figure 7: Passive Monitoring Application Topology	794
	Figure 8: Active Monitoring Configuration Topology	796
Chapter 46	Flow Monitoring and Discard Accounting Configuration Guidelines	797
	Figure 9: Configure Sampling Rate	803
Chapter 48	Flow Collection Configuration Guidelines	901
	Figure 10: Flow Collector Interface Topology Diagram	907
Chapter 50	Dynamic Flow Capture Configuration Guidelines	931
	Figure 11: Dynamic Flow Capture Topology	932
Chapter 51	Flow-Tap Configuration Guidelines	943
	Figure 12: Flow-Tap Topology	945
Part 7	Link and Multilink Services	
Chapter 54	Link and Multilink Services Configuration Guidelines	975
	Figure 13: Multilink Interface Configuration	978

List of Tables

About This Guide	xlix
Table 1: Additional Books Available Through http://www.juniper.net/books	xlix
Table 2: Notice Icons	liii
Table 3: Text and Syntax Conventions	liv

Part 2

Adaptive Services

Chapter 3	Adaptive Services Overview	33
	Table 4: AS and MultiServices PIC Services by Service Package, PIC, and Platform	36
	Table 5: Statement Equivalents for ES and AS Interfaces	47
Chapter 4	Applications Configuration Guidelines	59
	Table 6: Application Protocols Supported by Services Interfaces	61
	Table 7: Network Protocols Supported by Services Interfaces	63
	Table 8: ICMP Codes and Types Supported by Services Interfaces	64
	Table 9: Port Names Supported by Services Interfaces	65
	Table 10: Supported RPC Services	74
Chapter 6	Stateful Firewall Services Configuration Guidelines	107
	Table 11: IP Option Values	111
Chapter 12	IPsec Services Configuration Guidelines	209
	Table 12: Default IKE and IPsec Proposals for Dynamic Negotiations	242
Chapter 14	Layer 2 Tunneling Protocol Services Configuration Guidelines	287
	Table 13: System Log Message Severity Levels	295
Chapter 22	Service Set Configuration Guidelines	443
	Table 14: System Log Message Severity Levels	452
	Table 15: Adaptive Services Tracing Flags	455
Chapter 24	Service Interface Configuration Guidelines	475
	Table 16: System Log Message Severity Levels	479

Part 7

Link and Multilink Services

Chapter 54	Link and Multilink Services Configuration Guidelines	975
	Table 17: Multilink Services PIC Capacities	977
	Table 18: Multilink and Link Services Logical Interface Statements	980
	Table 19: Link Services Physical Interface Statements for MLFR FRF.16	993
	Table 20: Link Services CoS Queues	998
	Table 21: Link Services Bundle	1006

Part 9	Tunnel Services	
Chapter 59	Tunnel Services Overview	1089
	Table 22: Tunnel Interface Types	1089
Chapter 60	Tunnel Interfaces Configuration Guidelines	1093
	Table 23: Methods for Configuring Egress Filtering	1101

About This Guide

This preface provides the following guidelines for using the *JUNOS® Software Services Interfaces Configuration Guide*:

- JUNOS Documentation and Release Notes on page xlix
- Objectives on page I
- Audience on page I
- Supported Platforms on page li
- Using the Indexes on page li
- Using the Examples in This Manual on page li
- Documentation Conventions on page liii
- Documentation Feedback on page lv
- Requesting Technical Support on page lv

JUNOS Documentation and Release Notes

For a list of related JUNOS documentation, see <http://www.juniper.net/techpubs/software/junos/>.

If the information in the latest *JUNOS Release Notes* differs from the information in the documentation, follow the *JUNOS Release Notes*.

To obtain the most current version of all Juniper Networks technical documentation, see the product documentation page on the Juniper Networks Web site at <http://www.juniper.net/>.

Table 1 on page xlix lists additional books on Juniper Networks solutions that you can order through your bookstore. A complete list of such books is available at <http://www.juniper.net/books>.

Table 1: Additional Books Available Through <http://www.juniper.net/books>

Book	Description
<i>Interdomain Multicast Routing</i>	Provides background and in-depth analysis of multicast routing using Protocol Independent Multicast sparse mode (PIM SM) and Multicast Source Discovery Protocol (MSDP); details any-source and source-specific multicast delivery models; explores multiprotocol BGP (MBGP) and multicast IS-IS; explains Internet Gateway Management Protocol (IGMP) versions 1, 2, and 3; lists packet formats for IGMP, PIM, and MSDP; and provides a complete glossary of multicast terms.

Table 1: Additional Books Available Through <http://www.juniper.net/books> (continued)

Book	Description
<i>JUNOS Cookbook</i>	Provides detailed examples of common JUNOS software configuration tasks, such as basic router configuration and file management, security and access control, logging, routing policy, firewalls, routing protocols, MPLS, and VPNs.
<i>MPLS-Enabled Applications</i>	Provides an overview of Multiprotocol Label Switching (MPLS) applications (such as Layer 3 virtual private networks [VPNs], Layer 2 VPNs, virtual private LAN service [VPLS], and pseudowires), explains how to apply MPLS, examines the scaling requirements of equipment at different points in the network, and covers the following topics: point-to-multipoint label switched paths (LSPs), DiffServ-aware traffic engineering, class of service, interdomain traffic engineering, path computation, route target filtering, multicast support for Layer 3 VPNs, and management and troubleshooting of MPLS networks.
<i>OSPF and IS-IS: Choosing an IGP for Large-Scale Networks</i>	Explores the full range of characteristics and capabilities for the two major link-state routing protocols: Open Shortest Path First (OSPF) and IS-IS. Explains architecture, packet types, and addressing; demonstrates how to improve scalability; shows how to design large-scale networks for maximum security and reliability; details protocol extensions for MPLS-based traffic engineering, IPv6, and multipoint-to-multipoint routing; and covers troubleshooting for OSPF and IS-IS networks.
<i>Routing Policy and Protocols for Multivendor IP Networks</i>	Provides a brief history of the Internet, explains IP addressing and routing (Routing Information Protocol [RIP], OSPF, IS-IS, and Border Gateway Protocol [BGP]), explores ISP peering and routing policies, and displays configurations for both Juniper Networks and other vendors' routers.
<i>The Complete IS-IS Protocol</i>	Provides the insight and practical solutions necessary to understand the IS-IS protocol and how it works by using a multivendor, real-world approach.

Objectives

This guide provides an overview of the services interfaces provided by JUNOS software and describes how to configure these properties on the router.



NOTE: For additional information about the JUNOS software—either corrections to or information that might have been omitted from this guide—see the software release notes at <http://www.juniper.net/>.

Audience

This guide is designed for network administrators who are configuring and monitoring a Juniper Networks M-series, MX-series, T-series, EX-series, or J-series router or switch.

To use this guide, you need a broad understanding of networks in general, the Internet in particular, networking principles, and network configuration. You must also be familiar with one or more of the following Internet routing protocols:

- Border Gateway Protocol (BGP)
- Distance Vector Multicast Routing Protocol (DVMRP)

- Intermediate System-to-Intermediate System (IS-IS)
- Internet Control Message Protocol (ICMP) router discovery
- Internet Group Management Protocol (IGMP)
- Multiprotocol Label Switching (MPLS)
- Open Shortest Path First (OSPF)
- Protocol-Independent Multicast (PIM)
- Resource Reservation Protocol (RSVP)
- Routing Information Protocol (RIP)
- Simple Network Management Protocol (SNMP)

Personnel operating the equipment must be trained and competent; must not conduct themselves in a careless, willfully negligent, or hostile manner; and must abide by the instructions provided by the documentation.

Supported Platforms

For the features described in this manual, the JUNOS software currently supports the following platforms:

- J-series
- M-series
- MX-series
- T-series
- EX-series

Using the Indexes

This reference contains two indexes: a complete index that includes topic entries, and an index of statements and commands only.

In the index of statements and commands, an entry refers to a statement summary section only. In the complete index, the entry for a configuration statement or command contains at least two parts:

- The primary entry refers to the statement summary section.
- The secondary entry, *usage guidelines*, refers to the section in a configuration guidelines chapter that describes how to use the statement or command.

Using the Examples in This Manual

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. If the example

configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xsl;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file `ex-script-snippet.conf`. Copy the `ex-script-snippet.conf` file to the `/var/tmp` directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the `load merge relative` configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the `load` command, see the *JUNOS CLI User Guide*.

Documentation Conventions

Table 2 on page liii defines notice icons used in this guide.

Table 2: Notice Icons





Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 3 on page liv defines the text and syntax conventions used in this guide.

Table 3: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: user@host> configure
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> show chassis alarms No alarms currently active
<i>Italic text like this</i>	<ul style="list-style-type: none"> Introduces important new terms. Identifies book names. Identifies RFC and Internet draft titles. 	<ul style="list-style-type: none"> A policy <i>term</i> is a named structure that defines match conditions and actions. <i>JUNOS System Basics Configuration Guide</i> RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i>
Plain text like this	Represents names of configuration statements, commands, files, and directories; IP addresses; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> To configure a stub area, include the stub statement at the [edit protocols ospf area area-id] hierarchy level. The console port is labeled CONSOLE.
< > (angle brackets)	Enclose optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Enclose a variable for which you can substitute one or more values.	community name members [<i>community-ids</i>]
Indentation and braces ({ })	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
; (semicolon)	Identifies a leaf statement at a configuration hierarchy level.	

Table 3: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
J-Web GUI Conventions		
Bold text like this	Represents J-Web graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> ■ In the Logical Interfaces box, select All Interfaces. ■ To cancel the configuration, click Cancel.
> (bold right angle bracket)	Separates levels in a hierarchy of J-Web selections.	In the configuration editor hierarchy, select Protocols > Ospf .

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document name
- Document part number
- Page number
- Software release version (not required for *Network Operations Guides [NOGs]*)

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need postsales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the JTAC User Guide located at <http://www.juniper.net/customers/support/downloads/710059.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC Hours of Operation —The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base:
<http://kb.juniper.net/>
- Download the latest versions of software and review release notes:
<http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications:
<https://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum:
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool located at <https://tools.juniper.net/SerialNumberEntitlementSearch/>.

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/> .
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, visit us at <http://www.juniper.net/support/requesting-support.html>.

Part 1

Overview

- Services Interfaces Overview on page 3
- Services Interfaces Configuration Statements on page 5

Chapter 1

Services Interfaces Overview

Interfaces used in router networks fall into two categories:

- Networking interfaces, such as Ethernet and SONET interfaces, that primarily provide traffic connectivity. For more information on these interfaces, see the *JUNOS Network Interfaces Configuration Guide*.
- Services interfaces that provide specific capabilities for manipulating traffic before it is delivered to its destination.

This chapter includes the following sections:

- Services PIC Types on page 3
- Supported Platforms on page 4

Services PIC Types

Services interfaces enable you to add services to your network incrementally. The JUNOS software supports the following services PICs:

- Adaptive services interfaces (Adaptive Services [AS] PICs and MultiServices PICs)—Enable you to perform multiple services on the same PIC by configuring a set of services and applications. The AS and MultiServices PICs offer a special range of services you configure in one or more service sets: stateful firewalls, Network Address Translation (NAT), intrusion detection service (IDS), class-of-service functionality, and IP Security (IPsec). You can also configure voice services and Layer 2 Tunneling Protocol (L2TP) services. For more information about these services, see “Adaptive Services Overview” on page 33.



NOTE: On Mx-series routers, the MultiServices DPC provides essentially the same capabilities as the MultiServices PIC. The interfaces on both platforms are configured in the same way.

- ES PIC—Provides a security suite for the IP version 4 (IPv4) and IP version 6 (IPv6) network layers. The suite provides functionality such as authentication of origin, data integrity, confidentiality, replay protection, and nonrepudiation of source. It also defines mechanisms for key generation and exchange, management of security associations, and support for digital certificates. For more information about encryption interfaces, see “Encryption Interfaces Configuration Guidelines” on page 773.

- **Monitoring Services PICs**—Enable you to monitor traffic flow and export the monitored traffic. Monitoring traffic allows you to perform the following tasks:
 - Gather and export detailed information about IPv4 traffic flows between source and destination nodes in your network.
 - Sample all incoming IPv4 traffic on the monitoring interface and present the data in cflowd record format.
 - Perform discard accounting on an incoming traffic flow.
 - Encrypt or tunnel outgoing cflowd records, intercepted IPv4 traffic, or both.
 - Direct filtered traffic to different packet analyzers and present the data in its original format.

For more information about flow monitoring interfaces, see “Flow Monitoring and Discard Accounting Configuration Guidelines” on page 797.

- **Multilink Services and Link Services PICs**—Enable you to split, recombine, and sequence datagrams across multiple logical data links. The goal of multilink operation is to coordinate multiple independent links between a fixed pair of systems, providing a virtual link with greater bandwidth than any of the members. The JUNOS software supports two services PICs based on the Multilink Protocol: the Multilink Services PIC and the Link Services PIC. For more information about multilink and link services interfaces, see “Link and Multilink Services Configuration Guidelines” on page 975.
- **Tunnel Services PIC**—By encapsulating arbitrary packets inside a transport protocol, provides a private, secure path through an otherwise public network. Tunnels connect discontinuous subnetworks and enable encryption interfaces, virtual private networks (VPNs), and MPLS. For more information about tunnel interfaces, see “Tunnel Interfaces Configuration Guidelines” on page 1093.

Supported Platforms

For information about which platforms support Adaptive Services and MultiServices PICs and their features, see Table 4 on page 36.

For information about PIC support on a specific M-series or T-series platform, see the appropriate *PIC Guide* for the platform.

For information about MS-DPC support on a specific MX-series platform, see the appropriate *DPC Guide* for the platform.

For information about services supported on J-series Services Routers, see the J-series documentation, in particular the *J-series Services Router Advanced WAN Access Configuration Guide*.

Chapter 2

Services Interfaces Configuration Statements

This chapter shows the complete configuration statement hierarchies for configuring services interfaces. It lists all the statements that pertain to configuring services and shows their level in the configuration hierarchy. When you are configuring the JUNOS software, your current hierarchy level is shown in the banner on the line preceding the `user@host#` prompt.

For a complete list of the JUNOS configuration statements, see the *JUNOS Hierarchy and RFC Reference*.

This chapter is organized as follows:

- [edit applications] Hierarchy Level on page 5
- [edit forwarding-options] Hierarchy Level on page 6
- [edit interfaces] Hierarchy Level on page 8
- [edit logical-systems] Hierarchy Level on page 11
- [edit protocols] Hierarchy Level on page 11
- [edit services] Hierarchy Level on page 12

[edit applications] Hierarchy Level

To configure application protocols, include the following statements at the [edit applications] hierarchy level of the configuration:

```
application application-name {  
  application-protocol protocol-name;  
  destination-port port-number;  
  icmp-code value;  
  icmp-type value;  
  inactivity-timeout value;  
  learn-sip-register;  
  protocol type;  
  rpc-program-number number;  
  sip-call-hold-timeout seconds;  
  snmp-command command;  
  source-port port-number;  
  ttl-threshold value;  
  uuid hex-value;
```

```

}
application-set application-set-name {
    application application-name;
}

```

[edit forwarding-options] Hierarchy Level

To configure flow monitoring and accounting properties, include the following statements at the [edit forwarding-options] hierarchy level:



NOTE: For the complete [edit forwarding-options] hierarchy, see the *JUNOS Policy Framework Configuration Guide*. This listing includes only the statements used in flow monitoring and accounting services.

```

accounting name {
    output {
        aggregate-export-interval seconds;
        cflowd hostname {
            aggregation {
                autonomous-system;
                destination-prefix;
                protocol-port;
                source-destination-prefix {
                    caida-compliant;
                }
                source-prefix;
            }
            autonomous-system-type (origin | peer);
            port port-number;
            version format;
        }
        flow-active-timeout seconds;
        flow-inactive-timeout seconds;
        interface interface-name {
            engine-id number;
            engine-type number;
            source-address address;
        }
    }
}
monitoring name {
    family inet {
        output {
            cflowd hostname port port-number;
            export-format format;
            flow-active-timeout seconds;
            flow-export-destination {
                collector-pic;
            }
            flow-inactive-timeout seconds;
            interface interface-name {
                engine-id number;
            }
        }
    }
}

```

```

        engine-type number;
        input-interface-index number;
        output-interface-index number;
        source-address address;
    }
}
}
next-hop-group group-name {
    interface interface-name {
        next-hop address;
    }
}
port-mirroring {
    input {
        rate rate;
        run-length number;
    }
    family (inet | inet6) {
        output {
            interface interface-name {
                next-hop address;
            }
            no-filter-check;
        }
    }
    traceoptions {
        file filename {
            files number;
            size bytes;
            (world-readable | no-world-readable);
        }
    }
}
sampling {
    disable;
    input {
        family (inet | inet6 | mpls) {
            max-packets-per-second number;
            rate number;
            run-length number;
        }
    }
    output {
        aggregate-export-interval seconds;
        cflowd hostname {
            aggregation {
                autonomous-system;
                destination-prefix;
                protocol-port;
                source-destination-prefix {
                    caida-compliant;
                }
                source-prefix;
            }
            autonomous-system-type (origin | peer);
            version9 {

```

```

        template template-name;
    }
    (local-dump | no-local-dump);
    port port-number;
    source-address address;
    version format;
}
file {
    disable;
    filename filename;
    files number;
    size bytes;
    (stamp | no-stamp);
    (world-readable | no-world-readable);
}
flow-active-timeout seconds;
flow-inactive-timeout seconds;
interface interface-name {
    engine-id number;
    engine-type number;
    source-address address;
}
}
traceoptions {
    file filename {
        files number;
        size bytes;
        (world-readable | no-world-readable);
    }
}
}
}

```

[edit interfaces] Hierarchy Level

To configure services interfaces, include the following statements at the [edit interfaces] hierarchy level of the configuration. The statements can also be configured at the [edit logical-systems *logical-system-name* interfaces] hierarchy level.



NOTE: For the complete [edit interfaces] hierarchy, see the *JUNOS Network Interfaces Configuration Guide*. This listing includes only the statements used in configuring services.

```

[edit interfaces]
interface-name {
    (atm-options | fastether-options | gige-ether-options | sonet-options) {
        mpls {
            pop-all-labels {
                required-depth number;
            }
        }
    }
}
encapsulation type;

```



```

lsq-failure-options {
    no-termination-request;
    trigger-link-failure interface-name;
}
mlfr-uni-nni-bundle-options {
    acknowledge-retries number;
    acknowledge-timer milliseconds;
    action-red-differential-delay (disable-tx | remove-link);
    drop-timeout milliseconds;
    fragment-threshold bytes;
    cisco-interoperability send-lip-remove-link-for-link-reject;
    hello-timer milliseconds;
    lmi-type (ansi | itu);
    minimum-links number;
    mrru bytes;
    n391 number;
    n392 number;
    n393 number;
    red-differential-delay milliseconds;
    t391 number;
    t392 number;
    yellow-differential-delay milliseconds;
    encapsulation type;
}
passive-monitor-mode;
unit logical-unit-number {
    clear-dont-fragment-bit;
    compression {
        rtp {
            f-max-period number;
            maximum-contexts number <force>;
            port {
                minimum port-number;
                maximum port-number;
            }
            queues [ queue-numbers ];
        }
    }
    compression-device interface-name;
    copy-tos-to-outer-ip-header;
    disable-mlppp-inner-ppp-pfc;
    dlci dlci-identifier;
    drop-timeout milliseconds;
    dial-options {
        ipsec-interface-id name;
        l2tp-interface-id name;
        (dedicated | shared);
    }
    dynamic-call-admission-control {
        activation-priority priority;
        bearer-bandwidth-limit kilobits-per-second;
    }
    encapsulation type;
    family family {
        accounting {
            destination-class-usage;

```

```

        source-class-usage direction;
    }
    address address {
        destination address;
    }
    bundle (ml-fpc/pic/port | ls-fpc/pic/port);
    ipsec-sa ipsec-sa;
    multicast-only;
    receive-options-packets;
    receive-ttl-exceeded;
    sampling direction;
    service {
        input {
            service-set service-set-name <service-filter filter-name>;
            post-service-filter filter-name;
        }
        output {
            service-set service-set-names <service-filter filter-name>;
        }
    }
}
fragment-threshold bytes;
interleave-fragments;
minimum-links number;
mrru bytes;
multicast-dlci dlci-identifier;
peer-unit unit-number;
reassemble-packets;
rpm client;
service-domain (inside | outside);
short-sequence;
tunnel {
    allow-fragmentation;
    backup-destination address;
    destination destination-address;
    do-not-fragment;
    key number;
    routing-instance {
        destination routing-instance-name;
    }
    source-address address;
    ttl number;
}
twamp-server;
}
multiservice-options {
    (core-dump | no-core-dump);
    (syslog | no-syslog);
}
services-options {
    inactivity-timeout seconds;
    open-timeout seconds;
    syslog {
        host hostname {
            services severity-level;
            facility-override facility-name;
        }
    }
}

```

```

        log-prefix prefix-value;
    }
}

rls {
    redundancy-options {
        hot-standby | warm-standby;
        primary lsq-fpc/pic/port;
        secondary lsq-fpc/pic/port;
    }
}

rsp {
    redundancy-options {
        primary sp-fpc/pic/port;
        secondary sp-fpc/pic/port;
    }
}

so-fpc/pic/port {
    unit logical-unit-number {
        passive-monitor-mode;
    }
}

```

[edit logical-systems] Hierarchy Level

The following lists the statements that can be configured at the [edit logical-systems] hierarchy level that are documented in this manual. For more information about logical systems, see the *JUNOS Routing Protocols Configuration Guide*.

```
logical-system-name {
    interfaces interface-name {
        interface-configuration;
    }
}
```

[edit protocols] Hierarchy Level

To configure data link switching (DLSw), include the following statements at the [edit protocols] hierarchy level of the configuration:

```

dlsnw {
  connection-idle-timeout time;
  dlsnw-cos {
    destination-interface interface-name;
    type-of-service number;
  }
  explorer-wait-time seconds;
  load-balance circuit-weight;
  local-peer peer-address;
  multicast-address address;
  promiscuous;
  reachability-cache-timeout seconds;
}

```

```

receive-initial-pacing number;
remote-peer peer-address {
    circuit-weight weight;
    cost cost;
}
traceoptions {
    file name <replace> <size size> <files number> <no-stamp> <world-readable |
    no-world-readable>;
    flag flag <flag-modifier> <disable>;
}
}

```

[edit services] Hierarchy Level

To configure services, include the following statements at the [edit services] hierarchy level of the configuration:

```

aacl {
    rule rule-name {
        match-direction (input | output | input-output);
        term term-name {
            from {
                application-group-any;
                application-groups [ application-group-names ];
                applications [ application-names ];
                destination-address address <any-unicast>;
                destination-address-range low minimum-value high maximum-value;
                destination-prefix-list list-name;
                source-address address <any-unicast>;
                source-address-range low minimum-value high maximum-value;
                source-prefix-list list-name;
            }
            then {
                (accept | discard);
                (count application-group-name | forwarding-class class-name);
            }
        }
    }
    rule-set rule-set-name {
        [ rule rule-names ];
    }
}
adaptive-services-pics {
    traceoptions {
        file filename <files number> <size size> <world-readable | no-world-readable>
        <match regex>;
        flag flag;
    }
}
application-identification {
    application application-name {
        disable;
        idle-timeout seconds;
        index number;
        session-timeout seconds;
    }
}

```

```

type type;
type-of-service service-type;
port-mapping {
    port-range {
        tcp (port | range);
        udp (port | range);
    }
    disable;
}
}
application-group group-name {
    application-groups {
        name [application-group-name];
    }
    applications {
        name [application-name];
    }
    index number;
    disable;
}
application-system-cache-timeout seconds;
max-checked-bytes bytes;
min-checked-bytes bytes;
no-application-identification;
no-application-system-cache;
no-clear-application-system-cache;
no-signature-based;
profile profile-name {
    [ rule-set rule-set-name ];
}
rule rule-name {
    address address-name {
        destination {
            ip address</prefix-length>;
            port-range {
                tcp [ ports-and-port-ranges ];
                udp [ ports-and-port-ranges ];
            }
        }
        source {
            ip address</prefix-length>;
            port-range {
                tcp [ ports-and-port-ranges ];
                udp [ ports-and-port-ranges ];
            }
        }
        order number;
    }
    application application-name;
    disable;
}
rule-set rule-set-name {
    rule application-rule-name;
}
traceoptions {

```

```

    file filename <files number> <match regex> <size size> <world-readable |
      no-world-readable>;
    flag flag;
    no-remote-trace;
  }
}
border-signaling-gateway {
  gateway gateway-name {
    embedded-spdp {
      service-class service-class-name {
        term term-name {
          from {
            media-type (any-media | audio | video);
          }
          then {
            committed-burst-size bytes;
            committed-information-rate bytes-per-second;
            dscp (alias | do-not-change | dscp-value);
            reject;
          }
        }
      }
    }
  }
}
service-interface name;
service-point service-point-name {
  service-point-type service-point-type;
  port-number {
    ip-address ip-address;
    transport-protocol (udp | tcp);
  }
  service-interface interface-name.unit-number;
  service-policies {
    new-call-usage-policies [ policy-and-policy-set-names ];
    new-transaction-policies [ policy-and-policy-set-names ];
  }
}
sip {
  new-call-usage-policy policy-name {
    term term-name {
      from {
        contact [ contact-fields ];
        method {
          method-invite;
        }
        request-uri [ uri-fields ];
        source-address [ ip-addresses ];
      }
      then {
        (accept | reject);
        media-policy service-class-name;
        trace;
      }
    }
  }
  new-call-usage-policy-set policy-set-name {
    policy-name [ policy-names ];
  }
}

```

```

}
new-transaction-policy policy-name {
  term term-name {
    from {
      contact [ contact-fields ];
      method {
        method-invite;
        method-message;
        method-options;
        method-publish;
        method-refer;
        method-register;
        method-subscribe;
      }
      request-uri [ uri-fields ];
      source-address [ ip-addresses ];
    }
    then {
      (accept | reject);
      route {
        egress-service-point service-point-name;
        next-hop (request-uri | address ipv4-address <port port-number>
          <transport-protocol (udp | tcp)>);
      }
      trace;
    }
  }
}
new-transaction-policy-set policy-set-name {
  policy-name [ policy-names ];
}
timers {
  inactive-call seconds;
  inactive-call seconds;
  timer-c seconds;
}
}
traceoptions {
  file {
    filename filename;
    files number-of-files;
    match regular-expression;
    size maximum-trace-file-size;
  }
  flag {
    datastore {
      data trace-level;
      db trace-level;
      handle trace-level;
      minimum trace-level;
    }
    framework {
      action trace-level;
      event trace-level;
      executor trace-level;
    }
  }
}

```

```

        freezer trace-level;
        minimum trace-level;
        memory-pool trace-level;
    }
    minimum trace-level;
    sbc-utils {
        common trace-level;
        configuration trace-level;
        device-monitor trace-level;
        ipc trace-level;
        memory-management trace-level;
        message trace-level;
        minimum trace-level;
        user-interface trace-level;
    }
    session-trace trace-level;
    signaling {
        b2b trace-level;
        b2b-wrapper trace-level;
        minimum trace-level;
        policy trace-level;
        sip-stack-wrapper trace-level;
        topology-hiding trace-level;
        ua trace-level;
    }
    sip-stack {
        dev-logging;
        event-tracing;
        ips-tracing;
        pd-log-detail (full | summary);
        pd-log-level (audit | exception | problem);
        per-tracing;
        verbose-logging;
    }
}
}
}
}
}
cos {
    application-profile profile-name {
        sip-text {
            dscp (alias | bits);
            forwarding-class class-name;
        }
        sip-video {
            dscp (alias | bits);
            forwarding-class class-name;
        }
        sip-voice {
            dscp (alias | bits);
            forwarding-class class-name;
        }
    }
}
rule rule-name {
    match-direction (input | output | input-output);
    term term-name {

```



```

    from {
        application-sets set-name;
        applications [ application-names ];
        destination-address address;
        destination-prefix-list list-name <except>;
        source-address address;
        source-prefix-list list-name <except>;
    }
    then {
        application-profile profile-name;
        dscp (alias | bits);
        forwarding-class class-name;
        (reflexive | reverse) {
            application-profile profile-name;
            dscp (alias | bits);
            forwarding-class class-name;
            syslog;
        }
        syslog;
    }
}
rule-set rule-set-name {
    rule rule-name;
}
}
dynamic-flow-capture {
    capture-group client-name {
        content-destination identifier {
            address address;
            hard-limit bandwidth;
            hard-limit-target bandwidth;
            soft-limit bandwidth;
            soft-limit-clear bandwidth;
            ttl hops;
        }
        control-source identifier {
            allowed-destinations [ destination ];
            minimum-priority value;
            no-syslog;
            notification-targets address port port-number;
            service-port port-number;
            shared-key value;
            source-addresses [ address ];
        }
        duplicates-dropped-periodicity seconds;
        input-packet-rate-threshold rate;
        interfaces interface-name;
        max-duplicates number;
        pic-memory-threshold percentage percentage;
    }
    g-max-duplicates number;
    g-duplicates-dropped-periodicity seconds;
}
flow-collector {

```

```

analyzer-address address;
analyzer-id name;
destinations {
  ftp:url {
    password "password";
  }
  file-specification {
    variant variant-number {
      data-format format;
      name-format format;
      transfer {
        record-level number;
        timeout seconds;
      }
    }
  }
}
interface-map {
  collector interface-name;
  file-specification variant-number;
  interface-name {
    collector interface-name;
    file-specification variant-number;
  }
}
retry number;
retry-delay seconds;
transfer-log-archive {
  archive-sites {
    ftp:url {
      password "password";
      username username;
    }
  }
  filename-prefix prefix;
  maximum-age minutes;
}
}
flow-monitoring {
  version9 {
    template template-name {
      flow-active-timeout seconds;
      flow-inactive-timeout seconds;
      ipv4-template;
      ipv6-template;
      mpls-template {
        label-position [ positions ];
      }
      mpls-ipv4-template {
        label-position [ positions ];
      }
      option-refresh-rate packets packets seconds seconds;
      template-refresh-rate packets packets seconds seconds;
    }
  }
}
}
flow-tapflow-tap {

```

```

    interface interface-name;
}
flow-tap-lite {
    interface interface-name;
}
ids {
    rule rule-name {
        match-direction (input | output | input-output);
        term term-name {
            from {
                application-sets set-name;
                applications [ application-names ];
                destination-address (address | any-unicast) <except>;
                destination-address-range low minimum-value high maximum-value<except>;
                destination-prefix-list list-name <except>;
                source-address (address | any-unicast) <except>;
                source-address-range low minimum-value high maximum-value <except>;
                source-prefix-list list-name <except>;
            }
            then {
                aggregation {
                    destination-prefix prefix-number | destination-prefix-ipv6 prefix-number;
                    source-prefix prefix-number | source-prefix-ipv6 prefix-number;
                }
                (force-entry | ignore-entry);
                logging {
                    syslog;
                    threshold rate;
                }
                session-limit {
                    by-destination {
                        hold-time seconds;
                        maximum number;
                        packets number;
                        rate number;
                    }
                    by-pair {
                        maximum number;
                        packets number;
                        rate number;
                    }
                    by-source {
                        hold-time seconds;
                        maximum number;
                        packets number;
                        rate number;
                    }
                }
                syn-cookie {
                    mss value;
                    threshold rate;
                }
            }
        }
    }
}
rule-set rule-set-name {

```

```

        rule rule-name;
    }
}
ipsec-vpn {
    clear-ike-sas-on-pic-restart;
    clear-ipsec-sas-on-pic-restart;
    ike {
        proposal proposal-name {
            authentication-algorithm (md5 | sha1 | sha-256);
            authentication-method (dsa-signatures | pre-shared-keys | rsa-signatures);
            description description;
            dh-group (group1 | group2);
            encryption-algorithm algorithm;
            lifetime-seconds seconds;
        }
        policy policy-name {
            description description;
            local-certificate identifier;
            local-id (ipv4_addr ipv4-address | ipv6_addr ipv6-address | key-id identifier);
            mode (aggressive | main);
            pre-shared-key (ascii-text key | hexadecimal key);
            proposals [ proposal-names ];
            remote-id {
                ipv4_addr [ values ];
                ipv6_addr [ values ];
                key_id [ values ];
            }
        }
    }
}
ipsec {
    proposal proposal-name {
        authentication-algorithm (hmac-md5-96 | hmac-sha1-96);
        description description;
        encryption-algorithm algorithm;
        lifetime-seconds seconds;
        protocol (ah | esp | bundle);
    }
    policy policy-name {
        description description;
        perfect-forward-secrecy {
            keys (group1 | group2);
        }
        proposals [ proposal-names ];
    }
}
rule rule-name {
    match-direction (input | output);
    term term-name {
        from {
            destination-address address;
            ipsec-inside-interface interface-name;
            source-address address;
        }
        then {
            backup-remote-gateway address;
            clear-dont-fragment-bit;
        }
    }
}

```

```

dynamic {
    ike-policy policy-name;
    ipsec-policy policy-name;
}
initiate-dead-peer-detection;
manual {
    direction (inbound | outbound | bidirectional) {
        authentication {
            algorithm (hmac-md5-96 | hmac-sha1-96);
            key (ascii-text key | hexadecimal key );
        }
        auxiliary-spi spi-value;
        encryption {
            algorithm algorithm;
            key (ascii-text key | hexadecimal key );
        }
        protocol (ah | bundle | esp);
        spi spi-value;
    }
}
no-anti-replay;
remote-gateway address;
syslog;
tunnel-mtu bytes;
}
}
rule-set rule-set-name {
    rule rule-name;
}
}
traceoptions {
    file {
        files number;
        size bytes;
    }
    flag flag;
}
}
}
l2tp {
    tunnel-group name {
        hello-interval seconds;
        hide-avps;
        l2tp-access-profile profile-name;
        local-gateway address address;
        maximum-send-window packets;
        ppp-access-profile profile-name;
        receive-window packets;
        retransmit-interval seconds;
        service-interface interface-name;
        syslog {
            host hostname {
                services severity-level;
                facility-override facility-name;
                log-prefix prefix-value;
            }
        }
    }
}
}

```

```

        tunnel-timeout seconds;
    }
    traceoptions {
        debug-level level;
        filter {
            protocol name;
        }
        flag flag;
        interfaces interface-name {
            debug-level level;
            flag flag;
        }
    }
}
logging {
    traceoptions {
        file filename <files number> <size size> <world-readable | no-world-readable>
        <match regex>;
        flag flag;
    }
}
nat {
    ipv6-multicast-interfaces (all | interface-name) {
        disable;
    }
    pool nat-pool-name {
        address ip-prefix</prefix-length>;
        address-range low minimum-value high maximum-value;
        pgcp {
            hint [ hint-strings ];
            ports-per-session ports;
            remotely-controlled;
            transport;
        }
        port (automatic | range low minimum-value high maximum-value) {
            random-allocation;
        }
    }
}
rule rule-name {
    match-direction (input | output);
    term term-name {
        nat-type(full-cone | symmetric);
        from {
            application-sets set-name;
            applications [ application-names ];
            destination-address (address | any-unicast) <except>;
            destination-address-range low minimum-value high maximum-value
            <except>;
            destination-prefix-list list-name <except>;
            source-address (address | any-unicast) <except>;
            source-address-range low minimum-value high maximum-value <except>;
            source-prefix-list list-name <except>;
        }
        then {
            syslog;
            translated {

```

```

        destination-pool nat-pool-name;
        destination-prefix destination-prefix;
        overload-pool overload-pool-name;
        overload-prefix overload-prefix;
        source-pool nat-pool-name;
        source-prefix source-prefix;
        translation-type (destination type | source type);
    }
}
}
rule-set rule-set-name {
    rule rule-name;
}
}
pgcp {
    gateway gateway-name {
        cleanup-timeout seconds;
        gateway-address gateway-address;
        fast-update-filters {
            maximum-terms number-of-terms;
            maximum-fuf-percentage percentage;
        }
        gateway-controller gateway-controller-name {
            controller-address ip-address;
            controller-port port-number;
            interim-ah-scheme {
                algorithm algorithm;
            }
        }
    }
    gateway-port gateway-port;
    graceful-restart {
        maximum-synchronization-mismatches number-of-mismatches;
        maximum-synchronization-time seconds;
    }
    data-inactivity-detection {
        inactivity-delay;
        latch-deadlock-delay seconds;
        send-notification-on-delay;
        inactivity-duration seconds;
        no-rtcp-check
        stop-detection-on-drop;
        report-service-change {
            service-change-type (forced-906 | forced-910);
        }
    }
}
h248-properties {
    application-data-inactivity-detection {
        ip-flow-stop-detection (regulated-notify | immediate-notify);
    }
    base-root {
        mg-provisional-response-timer-value {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
    }
}

```

```

mg-provisional-response-timer-value {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
}
mgc-originated-pending-limit {
    default number-of-messages;
    maximum number-of-messages;
    minimum number-of-messages;
}
mgc-originated-pending-limit {
    default number-of-messages;
    maximum number-of-messages;
    minimum number-of-messages;
}
normal-mg-execution-time {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
}
normal-mgc-execution-time {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
}
}
diffserv {
    dscp {
        default (dscp-value | alias | do-not-change);
    }
}
event-timestamp-notification {
    request-timestamp (requested | suppressed | autonomous);
}
{
    hanging-termination-detection {
        timerx seconds;
    }
}
notification-behavior {
    notification-regulation default (once | 0 - 100);
}
segmentation {
    mg-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
    mgc-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
}
mg-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
}

```



```

    mgc-maximum-pdu-size {
        default bytes;
        maximum bytes;
        minimum bytes;
    }
}
traffic-management {
    peak-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
        rtcp {
            fixed-value bytes-per-second;
            percentage percentage;
        }
    }
    sustained-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
        rtcp {
            fixed-value bytes-per-second;
            percentage percentage;
        }
    }
    max-burst-size {
        default bytes;
        maximum bytes;
        minimum bytes;
        rtcp {
            fixed-value bytes;
            percentage percentage;
        }
    }
}
inactivity-timer {
    inactivity-timeout {
        detect;
        maximum-inactivity-time {
            default 10-millisecond-units;
            maximum 10-millisecond-units;
            minimum 10-millisecond-units;
        }
    }
}
}
h248-options {
    audit-observed-events-returns;
    encoding {
        no-dscp-bit-mirroring;
        use-lower-case
    }
    service-change {
        context-indications {
            state-loss (forced-910 | forced-915 | none);
        }
    }
}

```

```

control-association-indications {
  disconnect {
    controller-failure (failover-909 | restart-902);
    reconnect (disconnected-900 | restart-902);
  }
  down {
    administrative (forced-905 | forced-908 | none);
    failure (forced-904 | forced-908 | none);
    graceful (graceful-905 | none);
  }
  up {
    cancel-graceful (none | restart-918);
    failover-cold (failover-920 | restart-901);
    failover-warm (failover-919 | restart-902);
  }
}
virtual-interface-indications {
  virtual-interface-down {
    administrative (forced-905 | forced-906 | none);
    failure (forced-904 | forced-906 | none);
    graceful (graceful-905 | none);
    link-loss (forced-906 | none);
  }
  use-wildcard-response;
  virtual-interface-up {
    cancel-graceful (none | restart-918);
    warm (none | restart-900);
  }
}
}
h248-timers {
  initial-average-ack-delay milliseconds;
  maximum-net-propagation-delay milliseconds;
  maximum-waiting-delay milliseconds;
  tmax-retransmission-delay milliseconds;
}
max-concurrent-calls number-of-calls;
monitor {
  media {
    rtcp;
    rtp;
  }
}
service-state (in-service | out-of-service-forced | out-of-service-graceful);
session-mirroring {
  delivery-function delivery-function-name {
    destination-address destination-address;
    destination-port destination-port;
    network-operator-id network-operator-id;
    source-address source-address;
    source-port source-port;
  }
  disable-session-mirroring;
}
}

```

```

media-service media-service-name {
    nat-pool nat-pool-name;
}
rule rule-name {
    gateway gateway-name;
    media-service media-service-name;
}
rule-set rule-set-name {
    rule rule-name1;
    rule rule-name2;
    rule rule-name3;
}
traceoptions {
    file filename <files number> <match regex> <size size> <world-readable |
        no-world-readable>;
    flag flag;
}
virtual-interface interface-number {
    media-service media-service-name;
    interface interface-identifier;
    routing-instance instance-name {
        service-interface interface-name.unit-number;
    }
    service-state (in-service | out-of-service-forced | out-of-service-graceful);
}
session-mirroring {
    delivery-function delivery-function-name {
        destination-address destination-address;
        destination-port destination-port;
        network-operator-id network-operator-id;
        source-address source-address;
        source-port source-port;
    }
    disable-session-mirroring;
}
}
rpm {
    bgp {
        data-fill data;
        data-size size;
        destination-port port;
        history-size size;
        logical-system logical-system-name <routing-instances routing-instance-name>;
        probe-count count;
        probe-interval seconds;
        probe-type type;
        routing-instances instance-name;
        test-interval interval;
    }
    probe owner {
        test test-name {
            data-fill data;
            data-size size;
            destination-interface interface-name;
            destination-port port;

```

```

        dscp-code-point dscp-bits;
        hardware-timestamp;
        history-size size;
        moving-average-size number;
        one-way-hardware-timestamp;
        probe-count count;
        probe-interval seconds;
        probe-type type;
        routing-instance instance-name;
        source-address address;
        target (url | address);
        test-interval interval;
        thresholds thresholds;
        traps traps;
    }
}
probe-limit limit;
probe-server {
    tcp {
        destination-interface interface-name;
        port (RPM) number;
    }
    udp {
        destination-interface interface-name;
        port (RPM) number;
    }
}
twamp {
    server {
        authentication-mode (authenticated | encrypted | none);
        client-list list-name {
            address address;
        }
        inactivity-timeout seconds;
        maximum-connections count;
        maximum-connections-per-client count;
        maximum-sessions count;
        maximum-sessions-per-connection count;
        port number;
    }
}
}
service-set service-set-name {
    aacl-rules rule-name;
    policy-decision-statistics-profile profile-name;
    (ids-rules rule-names | ids-rule-sets rule-set-name);
    (ipsec-vpn-rules rule-names | ipsec-vpn-rule-sets rule-set-name);
    (nat-rules rule-names | nat-rule-sets rule-set-name);
    (pgcp-rules rule-names | pgcp-rule-sets rule-set-name);
    (stateful-firewall-rules rule-names | stateful-firewall-rule-sets rule-set-name);
    allow-multicast;
    extension-service service-name {
        provider-specific rules;
    }
    interface-service {

```

```

        service-interface interface-name;
    }
    ipsec-vpn-options {
        ike-access-profile profile-name;
        local-gateway address;
        trusted-ca [ ca-profile-name ];
    }
    max-flows number;
    next-hop-service {
        inside-service-interface interface-name.unit-number;
        outside-service-interface interface-name.unit-number;
        service-interface-pool name;
    }
    syslog {
        host hostname {
            services severity-level;
            facility-override facility-name;
            log-prefix prefix-value;
        }
    }
}
stateful-firewall {
    rule rule-name {
        match-direction (input | output | input-output);
        term term-name {
            from {
                application-sets set-name;
                applications [ application-names ];
                destination-address (address | any-unicast) <except>;
                destination-address-range low minimum-value high maximum-value
                    <except>;
                destination-prefix-list list-name <except>;
                source-address (address | any-unicast) <except>;
                source-address-range low minimum-value high maximum-value <except>;
                source-prefix-list list-name <except>;
            }
            then {
                (accept | discard | reject);
                allow-ip-options [ values ];
                syslog;
            }
        }
    }
}
rule-set rule-set-name {
    rule rule-name;
}
}
}

```


Part 2

Adaptive Services

- Adaptive Services Overview on page 33
- Applications Configuration Guidelines on page 59
- Summary of Applications Configuration Statements on page 97
- Stateful Firewall Services Configuration Guidelines on page 107
- Summary of Stateful Firewall Configuration Statements on page 117
- Network Address Translation Services Configuration Guidelines on page 129
- Summary of Network Address Translation Configuration Statements on page 151
- Intrusion Detection Service Configuration Guidelines on page 175
- Summary of Intrusion Detection Service Configuration Statements on page 187
- IPsec Services Configuration Guidelines on page 209
- Summary of IPsec Services Configuration Statements on page 253
- Layer 2 Tunneling Protocol Services Configuration Guidelines on page 287
- Summary of Layer 2 Tunneling Protocol Configuration Statements on page 305
- Link Services IQ Interfaces Configuration Guidelines on page 319
- Summary of Link Services IQ Configuration Statements on page 381
- Voice Services Configuration Guidelines on page 393
- Summary of Voice Services Configuration Statements on page 407
- Class-of-Service Configuration Guidelines on page 419
- Summary of Class-of-Service Configuration Statements on page 429
- Service Set Configuration Guidelines on page 443
- Summary of Service Set Configuration Statements on page 457
- Service Interface Configuration Guidelines on page 475
- Summary of Service Interface Configuration Statements on page 489
- PGCP Configuration Guidelines for the BGF Feature on page 507
- Summary of PGCP Configuration Statements on page 513
- Service Interface Pools Configuration Guidelines on page 611
- Summary of Service Interface Pools Statements on page 613
- Border Signaling Gateway Configuration Guidelines on page 615
- Summary of Border Signaling Gateway Configuration Statements on page 619

Chapter 3

Adaptive Services Overview

The Adaptive Services (AS) and MultiServices PICs provide *adaptive services interfaces*, which allow you to coordinate multiple services on a single PIC by configuring a set of services and applications. The AS and MultiServices PICs offers a special range of services you configure in one or more service sets.

The AS PIC is available in two versions that differ in memory size:

- The Adaptive Services PIC with 256 megabytes (MB) of memory is supported on all M-series routing platforms except the M320 router.
- The Adaptive Services II PIC with 512 MB of memory is supported on all M-series and T-series routing platforms, including the M320 router.

The M7i router includes the Adaptive Services Module (ASM), an integrated version of the AS PIC as an optional component, which offers all the features of the standalone version at a reduced bandwidth.



NOTE: To take advantage of the features available on the AS PIC, you must install it in an Enhanced Flexible PIC Concentrator (FPC) in an M-series router equipped with an Internet Processor II application-specific integrated circuit (ASIC), or a similarly equipped T-series routing platform. To find out whether your router hardware is suitably equipped, use the **show chassis hardware** command. For more information, see the *JUNOS System Basics and Services Command Reference*.

The MultiServices PIC is available in three versions, the MultiServices 100, the MultiServices 400, and the MultiServices 500, which differ in memory size and performance. All versions offer enhanced performance in comparison with AS PICs. MultiServices PICs are supported on M-series and T-series routing platforms except M20 routers.

The MultiServices DPC is available for MX-series routers; it includes a subset of the functionality supported on the MultiServices PIC. Currently the MultiServices DPC supports the following Layer 3 services: stateful firewall, NAT, IDS, IPsec, active flow monitoring, RPM, and generic routing encapsulation (GRE) tunnels (including GRE key and fragmentation); it also supports graceful Routing Engine switchover (GRES). For more information about supported packages, see “Enabling Service Packages” on page 35.



NOTE: The Adaptive Services and MultiServices PICs are polling based and not interrupt based; as a result, a high value in the `show chassis pic` “Interrupt load average” field may not mean that the PIC has reached its maximum limit of processing.

The following services are configured within a service set and are available only on adaptive services interfaces:

- Stateful firewall—A type of firewall filter that considers state information derived from previous communications and other applications when evaluating traffic.
- Network Address Translation (NAT)—A security procedure for concealing host addresses on a private network behind a pool of public addresses.
- Intrusion detection service (IDS)—A set of tools for detecting, redirecting, and preventing certain kinds of network attack and intrusion.
- IP Security (IPsec)—A set of tools for configuring manual or dynamic security associations (SAs) for encryption of data traffic.
- Class of service (CoS)—A subset of CoS functionality for services interfaces, limited to DiffServ code point (DSCP) marking and forwarding-class assignment. CoS BA classification is not supported on services interfaces.

The configuration for these services comprises a series of rules that you can arrange in order of precedence as a *rule set*. Each rule follows the structure of a firewall filter, with a **from** statement containing input or match conditions and a **then** statement containing actions to be taken if the match conditions are met.

The following services are also configured on the AS and MultiServices PICs, but do not use the rule set definition:

- Layer 2 Tunneling Protocol (L2TP)—A tool for setting up secure tunnels using Point-to-Point Protocol (PPP) encapsulation across Layer 2 networks.
- Link Services Intelligent Queuing (LSQ)—Interfaces that support JUNOS software class-of-service (CoS) components, link fragmentation and interleaving (LFI) (FRF.12), Multilink Frame Relay (MLFR) user-to-network interface (UNI) network-to-network interface (NNI) (FRF.16), and Multilink PPP (MLPPP).
- Voice services—A feature that uses the Compressed Real-Time Transport Protocol (CRTP) to enable voice over IP traffic to use low-speed links more effectively.

In addition, JUNOS software includes the following tools for configuring services:

- Application protocols definition—Allows you to configure properties of application protocols that are subject to processing by router services, and group the application definitions into application sets.
- Service-set definition—Allows you to configure combinations of directional rules and default settings that control the behavior of each service in the service set.



NOTE: Logging of adaptive services interfaces messages to an external server by means of the `fxp0` port is not supported on M-series routers. The architecture does not support system logging traffic out of a management interface. Instead, access to an external server is supported on a Packet Forwarding Engine interface.

This chapter includes the following topics:

- Enabling Service Packages on page 35
- Services Configuration Procedure on page 39
- Packet Flow Through the Adaptive Services or MultiServices PIC on page 40
- Stateful Firewall Overview on page 41
- Network Address Translation Overview on page 44
- IPsec Overview on page 45
- Layer 2 Tunneling Protocol Overview on page 48
- Voice Services Overview on page 48
- Class of Service Overview on page 49
- Examples: Services Interfaces Configuration on page 49

Enabling Service Packages

For AS PICs, MultiServices PICs, and the internal Adaptive Services Module (ASM) in the M7i platform, there are two service packages: Layer 2 and Layer 3. Both service packages are supported on all adaptive services interfaces, but you can enable only one service package per PIC, with the exception of a combined package supported on the ASM. On a single routing platform, you can enable both service packages by installing two or more PICs on the platform.



NOTE: Graceful Routing Engine switchover (GRES) is automatically enabled on all services PICs and DPCs except the ES PIC. It is supported on all M-series and T-series platforms except for TX Matrix installations. Layer 3 services should retain state after switchover, but Layer 2 services will restart. For IPsec services, Internet Key Exchange (IKE) negotiations are not stored and must be restarted after switchover. For more information about GRES, see the *JUNOS High Availability Configuration Guide*.

You enable service packages per PIC, not per port. For example, if you configure the Layer 2 service package, the entire PIC uses the configured package. To enable a service package, include the `service-package` statement at the `[edit chassis fpc slot-number pic pic-number adaptive-services]` hierarchy level, and specify `layer-2` or `layer-3`:

```
[edit chassis fpc slot-number pic pic-number adaptive-services]
service-package (layer-2 | layer-3);
```

To determine which package an AS PIC supports, issue the `show chassis hardware` command: if the PIC supports the Layer 2 package, it is listed as **Link Services II**, and if it supports the Layer 3 package, it is listed as **Adaptive Services II**. To determine which package a MultiServices PIC supports, issue the `show chassis pic fpc-slot slot-number pic-slot slot-number` command. The **Package** field displays the value **Layer-2** or **Layer-3**.



NOTE: The ASM has a default option (**layer-2-3**) that combines the features available in the Layer 2 and Layer 3 service packages.

After you commit a change in the service package, the PIC is taken offline and then brought back online immediately. You do not need to manually take the PIC offline and online.



NOTE: Changing the service package causes all state information associated with the previous service package to be lost. You should change the service package only when there is no active traffic going to the PIC.

The services supported in each package differ by PIC and platform type. Table 4 on page 36 lists the services supported within each service package for each PIC and platform. Some of these services are also available on J-series Services Routers, but they are implemented in a different way and do not use the Layer 2 and Layer 3 service packages. For more information, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

On the AS and MultiServices PICs, *link services* support includes JUNOS software CoS components, LFI (FRF.12), MLFR end-to-end (FRF.15), MLFR UNI NNI (FRF.16), MLPPP (RFC 1990), and multiclass MLPPP. For more information, see “Layer 2 Service Package Capabilities and Interfaces” on page 38 and “Link Services IQ Interfaces Configuration Guidelines” on page 319.



NOTE: The AS PIC II for Layer 2 Service is dedicated to supporting the Layer 2 service package only.

For additional information about Layer 3 services, see the *JUNOS Feature Guide*.

Table 4: AS and MultiServices PIC Services by Service Package, PIC, and Platform

Services	ASM	AS/AS2 PICs and MultiServices PICs	AS/AS2 and MultiServices PICs	AS2 and MultiServices PICs	AS2 and MultiServices PICs
Layer 2 Service Package (Only)	M7i	M7i, M10i, and M20	M40e and M120	M320, T320, and T640	TX Matrix

Link Services:

Table 4: AS and MultiServices PIC Services by Service Package, PIC, and Platform (continued)

Services	ASM	AS/AS2 PICs and MultiServices PICs	AS/AS2 and MultiServices PICs	AS2 and MultiServices PICs	AS2 and MultiServices PICs
■ Link services	Yes	Yes	Yes	Yes	No
■ Multiclass MLPPP	Yes	Yes	Yes	Yes	No
Voice Services:					
■ CRTP and LFI	Yes	Yes	Yes	Yes	No
■ CRTP and MLPPP	Yes	Yes	Yes	Yes	No
■ CRTP over PPP (without MLPPP)	Yes	Yes	Yes	Yes	No
Layer 3 Service Package (Only)	M7i	M7i, M10i, and M20	M40e and M120	M320, T320, and T640	TX Matrix
Security Services:					
■ CoS	Yes	Yes	Yes	Yes	No
■ Intrusion detection system (IDS)	Yes	Yes	Yes	Yes	No
■ IPsec	Yes	Yes	Yes	Yes	No
■ NAT	Yes	Yes	Yes	Yes	No
■ Stateful firewall	Yes	Yes	Yes	Yes	No
Accounting Services:					
■ Active monitoring	Yes	Yes	Yes	Yes	Yes
■ Dynamic flow capture (MultiServices 400 PIC only)	No	No	No	Yes	No
■ Flow-tap	Yes	Yes	Yes (M40e only)	Yes	No
■ Passive monitoring (MultiServices 400 PIC only)	No	Yes	Yes (M40e only)	Yes	No
■ Port mirroring	Yes	Yes	Yes	Yes	Yes
LNS Services:					
■ L2TP LNS	Yes	Yes (M7i and M10i only)	Yes (M120 only)	No	No
Voice Services:					

Table 4: AS and MultiServices PIC Services by Service Package, PIC, and Platform (continued)

Services	ASM	AS/AS2 PICs and MultiServices PICs	AS/AS2 and MultiServices PICs	AS2 and MultiServices PICs	AS2 and MultiServices PICs
■ BGF	Yes	Yes	Yes	Yes	No
Layer 2 and Layer 3 Service Package (Common Features)	M7i	M7i, M10i, and M20	M40e and M120	M320, T320, and T640	TX Matrix
RPM Services:					
■ RPM probe timestamping	Yes	Yes	Yes	Yes	No
Tunnel Services:					
■ GRE (gr-fpc/pic/port)	Yes	Yes	Yes	Yes	Yes
■ GRE fragmentation (clear-dont-fragment-bit)	Yes	Yes	Yes	No	No
■ GRE key	Yes	Yes	Yes	Yes	No
■ IP-IP tunnels (ip-fpc/pic/port)	Yes	Yes	Yes	Yes	Yes
■ Logical tunnels (lt-fpc/pic/port)	No	No	No	No	No
■ Multicast tunnels (mt-fpc/pic/port)	Yes	Yes	Yes	Yes	Yes
■ PIM de-encapsulation (pd-fpc/pic/port)	Yes	Yes	Yes	Yes	Yes
■ PIM encapsulation (pe-fpc/pic/port)	Yes	Yes	Yes	Yes	Yes
■ Virtual tunnels (vt-fpc/pic/port)	Yes	Yes	Yes	Yes	Yes

Layer 2 Service Package Capabilities and Interfaces

When you enable the Layer 2 service package, you can configure link services. On the AS and MultiServices PICs and the ASM, link services include support for the following:

- JUNOS CoS components—“Link Services IQ Interfaces Configuration Guidelines” on page 319 describes how the JUNOS CoS components work on link services IQ (lsq) interfaces. For detailed information about JUNOS CoS components, see the *JUNOS Class of Service Configuration Guide*.
- LFI on Frame Relay links using FRF.12 end-to-end fragmentation—The standard for FRF.12 is defined in the specification FRF.12, *Frame Relay Fragmentation Implementation Agreement*.
- LFI on MLPPP links.

- MLFR UNI NNI (FRF.16)—The standard for FRF.16 is defined in the specification FRF.16.1, *Multilink Frame Relay UNI/NNI Implementation Agreement*.
- MLPPP (RFC 1990)

For the LSQ interface on the AS and MultiServices PICs, the configuration syntax is almost the same as for Multilink and Link Services PICs. The primary difference is the use of the interface-type descriptor **lsq** instead of **ml** or **ls**. When you enable the Layer 2 service package, the following interfaces are automatically created:

```
gr-fpc/pic/port
ip-fpc/pic/port
lsq-fpc/pic/port
lsq-fpc/pic/port:0
...
lsq-fpc/pic/port:N
mt-fpc/pic/port
pd-fpc/pic/port
pe-fpc/pic/port
sp-fpc/pic/port
vt-fpc/pic/port
```

Interface types **gr**, **ip**, **mt**, **pd**, **pe**, and **vt** are standard tunnel interfaces that are available on the AS and MultiServices PICs whether you enable the Layer 2 or the Layer 3 service package. These tunnel interfaces function the same way for both service packages, except that the Layer 2 service package does not support some tunnel functions, as shown in Table 4 on page 36.

Interface type **lsq-fpc/pic/port** is the physical link services IQ (**lsq**) interface. Interface types **lsq-fpc/pic/port:0** through **lsq-fpc/pic/port:N** represent FRF.16 bundles. These interface types are created when you include the **mlfr-uni-nni-bundles** statement at the [edit chassis fpc slot-number pic pic-number] option. For more information, see “Link Services IQ Interfaces Configuration Guidelines” on page 319 and “Link and Multilink Services Configuration Guidelines” on page 975.



NOTE: Interface type **sp** is created because it is needed by the JUNOS software. For the Layer 2 service package, the **sp** interface is not configurable, but you should not disable it.

Services Configuration Procedure

You follow these general steps to configure services:

1. Define application objects by configuring statements at the [edit applications] hierarchy level.
2. Define service rules by configuring statements at the [edit services (ids | ipsec-vpn | nat | stateful-firewall) rule] hierarchy level.
3. Group the service rules by configuring the **rule-set** statement at the [edit services (ids | ipsec-vpn | nat | stateful-firewall)] hierarchy level.

4. Group service rule sets under a service-set definition by configuring the **service-set** statement at the **[edit services]** hierarchy level.
5. Apply the service set on an interface by including the **service-set** statement at the **[edit interfaces *interface-name* unit *logical-unit-number* family inet service (input | output)]** hierarchy level. Alternatively, you can configure logical interfaces as a next-hop destination by including the **next-hop-service** statement at the **[edit services service-set *service-set-name*]** hierarchy level.



NOTE: You can configure IDS, NAT, and stateful firewall service rules within the same service set. You must configure IPsec services in a separate service set, although you can apply both service sets to the same PIC.

Packet Flow Through the Adaptive Services or MultiServices PIC

You can optionally configure service sets to be applied at one of three points while the packets transit the router:

- An interface service set applied at the inbound interface.
- A next-hop service set applied at the forwarding table.
- An interface service set applied at the outbound interface.

The packet flow is as follows, graphically displayed in Figure 1 on page 41. (You can configure a service set as either an interface service set or a next-hop service set.)

1. Packets enter the router on the inbound interface.
2. A policer, filter, service filter, service set, postservice filter, and input forwarding-table filter are applied sequentially to the traffic; these are all optional items in the configuration. If an interface service set is applied, the packets are forwarded to the AS or MultiServices PIC for services processing and then sent back to the Packet Forwarding Engine; if a service filter is also applied, only packets matching the service filter are sent to the PIC. The optional postservice filter is applied and postprocessing takes place.
3. A next-hop service set can be applied to the VPN routing and forwarding (VRF) table or to **inet.0**. If it is applied, packets are sent to the PIC for services processing and sent back to the Packet Forwarding Engine.




NOTE: For NAT, the next-hop service set can only be applied to the VRF table. For all other services, the next-hop service set can be applied to either the VRF table or to **inet.0**.

4. On the output interface, an output filter, output policer, and interface service set can be applied sequentially to the traffic if you have configured any of these items. If an interface service set is applied, the traffic is forwarded to the PIC for

processing and sent back to the Packet Forwarding Engine, which then forwards the traffic.

5. Packets exit the router.

Figure 1: Packet Flow Through the Adaptive Services or MultiServices PIC



NOTE: When an AS PIC experiences persistent back pressure as a result of high traffic volume for 3 seconds, the condition triggers an automatic core dump and reboot of the PIC to help clear the blockage. A system log message at level LOG_ERR is generated. This mechanism applies to both Layer 2 and Layer 3 service packages.

Stateful Firewall Overview

Routers use firewalls to track and control the flow of traffic. Adaptive Services and MultiServices PICs employ a type of firewall called a *stateful firewall*. Contrasted with a *stateless* firewall that inspects packets in isolation, a stateful firewall provides an extra layer of security by using state information derived from past communications and other applications to make dynamic control decisions for new communication attempts.

Stateful firewalls group relevant *flows* into *conversations*. A flow is identified by the following five properties:

- Source address
- Source port
- Destination address
- Destination port
- Protocol

A typical Transmission Control Protocol (TCP) or User Datagram Protocol (UDP) conversation consists of two flows: the initiation flow and the responder flow.

However, some conversations, such as an FTP conversation, might consist of two control flows and many data flows.

Firewall rules govern whether the conversation is allowed to be established. If a conversation is allowed, all flows within the conversation are permitted, including flows that are created during the life cycle of the conversation.

You configure stateful firewalls using a powerful rule-driven conversation handling path. A *rule* consists of direction, source address, source port, destination address, destination port, IP protocol value, and application protocol or service. In addition to the specific values you configure, you can assign the value **any** to rule objects, addresses, or ports, which allows them to match any input value. Finally, you can optionally negate the rule objects, which negates the result of the type-specific match.

Firewall rules are directional. For each new conversation, the router software checks the initiation flow matching the direction specified by the rule.

Firewall rules are ordered. The software checks the rules in the order in which you include them in the configuration. The first time the firewall discovers a match, the router implements the action specified by that rule. Rules still unchecked are ignored.

For more information about configuring stateful firewalls, see “Stateful Firewall Services Configuration Guidelines” on page 107.

Stateful Firewall Support for Application Protocols

By inspecting the application protocol data, the AS or MultiServices PIC firewall can intelligently enforce security policies and allow only the minimal required packet traffic to flow through the firewall.

The firewall rules are configured in relation to an interface. By default, the stateful firewall allows all sessions initiated from the hosts behind the interface to pass through the router.

Stateful Firewall Anomaly Checking

The stateful firewall recognizes the following events as anomalies and sends them to the IDS software for processing:

- IP anomalies:
 - IP version is not correct.
 - IP header length field is too small.
 - IP header length is set larger than the entire packet.
 - Bad header checksum.
 - IP total length field is shorter than header length.
 - Packet has incorrect IP options.

- Internet Control Message Protocol (ICMP) packet length error.
- Time-to-live (TTL) equals 0.
- IP address anomalies:
 - IP packet source is a broadcast or multicast.
 - Land attack (source IP equals destination IP).
- IP fragmentation anomalies:
 - IP fragment overlap.
 - IP fragment missed.
 - IP fragment length error.
 - IP packet length is more than 64 kilobytes (KB).
 - Tiny fragment attack.
- TCP anomalies:
 - TCP port 0.
 - TCP sequence number 0 and flags 0.
 - TCP sequence number 0 and FIN/PSH/RST flags set.
 - TCP flags with wrong combination (TCP FIN/RST or SYN/(URG|FIN|RST)).
 - Bad TCP checksum.
- UDP anomalies:
 - UDP source or destination port 0.
 - UDP header length check failed.
 - Bad UDP checksum.
- Anomalies found through stateful TCP or UDP checks:
 - SYN followed by SYN-ACK packets without ACK from initiator.
 - SYN followed by RST packets.
 - SYN without SYN-ACK.
 - Non-SYN first flow packet.
 - ICMP unreachable errors for SYN packets.
 - ICMP unreachable errors for UDP packets.
- Packets dropped according to stateful firewall rules.

If you employ stateful anomaly detection in conjunction with stateless detection, IDS can provide early warning for a wide range of attacks, including these:

- TCP or UDP network probes and port scanning

- SYN flood attacks
- IP fragmentation-based attacks such as teardrop, bonk, and boink

Network Address Translation Overview

NAT is a mechanism for concealing a set of host addresses on a private network behind a pool of public addresses. It can be used as a security measure to protect the host addresses from direct targeting in network attacks.

You can configure NAT using traditional NAT or twice NAT, as described in the following sections:

- Traditional NAT on page 44
- Twice NAT on page 45

Traditional NAT

Traditional NAT, specified in RFC 3022, *Traditional IP Network Address Translator*, is fully supported by JUNOS software. In addition, network address port translation (NAPT) is supported for source addresses.

The AS and MultiServices PIC interfaces support three types of NAT processing:

- Static-source NAT hides a private network without using NAPT.
- Dynamic-source NAT hides a private network using NAPT.
- Static-destination NAT makes selected private servers accessible.

You can implement NAT to hide one or many hosts on a private network behind a pool of public IP addresses. The pool can be as small as one IP address, or it can be a set of contiguous IP addresses. You can specify a port range to restrict port translation when NAT is configured in dynamic-source mode.

Private address to public address binding can be either static or dynamic. In the basic NAT mode, a NAT rule can force a private IP address to be always bound to a public address; in the NAPT mode, a NAT rule can force a paired private address and private TCP or UDP port to be mapped to a public IP and public TCP or UDP port. However, when the address binding is not statically forced by the NAT rules, NAT can dynamically pick an available address or address and TCP or UDP port pairing when a new session starts. You can specify multiple prefixes and address ranges in a dynamic or static source NAT pool.

The option to assign NAT addresses statically from a dynamic NAT pool enables you to advertise one subnet that represents the NAT pool and use an address within that subnet for static rules. Statically assigned addresses are not reused for dynamic assignment and can only be used for static-source NAT (not for static-destination NAT).

You can configure an overload (fallback) pool to be used when the source pool of addresses is exhausted. The overload pool must be configured with NAPT.

You can also configure NAT rules without configuring a pool by directly specifying the address prefix to be translated within the rule. And, within the rule, you can assign particular addresses that you do not want to be translated.

Like most traditional NAT implementations, the JUNOS implementation of NAT supports sessions initiated from the private side only. Sessions initiated from the public side are supported only when you configure static address binding.

You are not required to configure a stateful firewall rule to allow NAT traffic. By default, NAT traffic is allowed unless it is explicitly configured to be dropped. If only NAT is configured in a service set, all traffic is accepted.

For more information about configuring NAT rules, see “Network Address Translation Services Configuration Guidelines” on page 129.

Twice NAT

Twice NAT, specified in RFC 2663, *IP Network Address Translator (NAT) Terminology and Considerations*, is fully supported by JUNOS software.

In twice NAT, both the source and destination addresses are subject to translation as packets traverse the NAT router. For example, you would use twice NAT when you are connecting two networks in which all or some addresses in one network overlap with addresses in another network (whether the network is private or public). In traditional NAT, only one of the addresses is translated.

To configure twice NAT, you must specify both a destination address and a source address for the match direction, pool or prefix, and translation type.

You can configure application-level gateways (ALGs) for ICMP and traceroute under stateful firewall, NAT, or CoS rules when twice NAT is configured in the same service set. These ALGs cannot be applied to flows created by the Packet Gateway Controller Protocol (PGCP). Twice NAT does not support other ALGs. By default, the twice NAT feature can affect IP, TCP, and UDP headers embedded in the payload of ICMP error messages.

For more information about configuring NAT rules, see “Network Address Translation Services Configuration Guidelines” on page 129.

IPsec Overview

The JUNOS software supports IPsec. This section discusses the following topics, which provide background information about configuring IPsec:

- IPsec on page 46
- Security Associations on page 46
- IKE on page 46
- Comparison of IPsec Services and ES Interface Configuration on page 47

For a list of the IPsec and IKE standards supported by the JUNOS software, see the *JUNOS Hierarchy and RFC Reference*.

IPsec

The IPsec architecture provides a security suite for the IP version 4 (IPv4) and IP version 6 (IPv6) network layers. The suite provides such functionality as authentication of origin, data integrity, confidentiality, replay protection, and nonrepudiation of source. In addition to IPsec, the JUNOS software also supports the Internet Key Exchange (IKE), which defines mechanisms for key generation and exchange, and manages security associations (SAs).

IPsec also defines a security association and key management framework that can be used with any network layer protocol. The SA specifies what protection policy to apply to traffic between two IP-layer entities. IPsec provides secure tunnels between two peers.

Security Associations

To use IPsec security services, you create SAs between hosts. An SA is a simplex connection that allows two hosts to communicate with each other securely by means of IPsec. There are two types of SAs:

- Manual SAs require no negotiation; all values, including the keys, are static and specified in the configuration. Manual SAs statically define the security parameter index (SPI) values, algorithms, and keys to be used, and require matching configurations on both ends of the tunnel. Each peer must have the same configured options for communication to take place.
- Dynamic SAs require additional configuration. With dynamic SAs, you configure IKE first and then the SA. IKE creates dynamic security associations; it negotiates SAs for IPsec. The IKE configuration defines the algorithms and keys used to establish the secure IKE connection with the peer security gateway. This connection is then used to dynamically agree upon keys and other data used by the dynamic IPsec SA. The IKE SA is negotiated first and then used to protect the negotiations that determine the dynamic IPsec SAs.

IKE

IKE is a key management protocol that creates dynamic SAs; it negotiates SAs for IPsec. An IKE configuration defines the algorithms and keys used to establish a secure connection with a peer security gateway.

IKE performs the following tasks:

- Negotiates and manages IKE and IPsec parameters.
- Authenticates secure key exchange.
- Provides mutual peer authentication by means of shared secrets (not passwords) and public keys.
- Provides identity protection (in main mode).

IKE consists of two phases. In the first phase, it negotiates security attributes and establishes shared secrets to form the bidirectional IKE SA. In the second phase,

inbound and outbound IPsec SAs are established and the IKE SA secures the exchanges. IKE also generates keying material, provides Perfect Forward Secrecy, and exchanges identities.

Comparison of IPsec Services and ES Interface Configuration

Table 5 on page 47 compares the top-level configuration of IPsec features on the ES PIC interfaces and on the AS or MultiServices PIC interfaces.

Table 5: Statement Equivalents for ES and AS Interfaces

ES PIC Configuration	AS and MultiServices PIC IPsec Configuration
[edit security ipsec] proposal {...}	[edit services ipsec-vpn ipsec] proposal {...}
[edit security ipsec] policy {...}	[edit services ipsec-vpn ipsec] policy {...}
[edit security ipsec] security-association sa-dynamic {...}	[edit services ipsec-vpn rule <i>rule-name</i>] term <i>term-name</i> match-conditions {...} then dynamic {...}]
[edit security ipsec] security-association sa-manual {...}	[edit services ipsec-vpn rule <i>rule-name</i>] term <i>term-name</i> match-conditions {...} then manual {...}]
[edit security ike] proposal {...}	[edit services ipsec-vpn ike] proposal {...}
[edit security ike] policy {...}	[edit services ipsec-vpn ike] policy {...}
Not available	[edit services ipsec-vpn] rule-set {...}
Not available	[edit services ipsec-vpn] service-set {...}
[edit interfaces es- <i>fpc/pic/port</i>] tunnel source <i>address</i>	[edit services ipsec-vpn service-set <i>set-name</i> ipsec-vpn local-gateway <i>address</i>]
[edit interfaces es- <i>fpc/pic/port</i>] tunnel destination <i>address</i>	[edit services ipsec-vpn rule <i>rule-name</i>] remote-gateway <i>address</i>

For more information about configuring IPsec services on an AS or MultiServices PIC, see “IPsec Services Configuration Guidelines” on page 209. For more information about configuring encryption services on an ES PIC, see “Encryption Interfaces Configuration Guidelines” on page 773.



NOTE: Although many of the same statements and properties are valid on both platforms, the configurations are not interchangeable. You must commit a complete configuration for the PIC type that is installed in your router.

Layer 2 Tunneling Protocol Overview

L2TP is defined in RFC 2661, *Layer Two Tunneling Protocol (L2TP)*.

L2TP facilitates the tunneling of PPP packets across an intervening network in a way that is as transparent as possible to both end users and applications. It employs access profiles for group and individual user access, and uses authentication to establish secure connections between the two ends of each tunnel. Multilink PPP functionality is also supported.

The L2TP services are supported on the following routers only:

- M7i routers with AS PICs
- M10i routers with AS and MultiServices 100 PICs
- M120 routers with AS, MultiServices 100, and MultiServices 400 PICs

For more information about configuring L2TP services, see “Layer 2 Tunneling Protocol Services Configuration Guidelines” on page 287.

Voice Services Overview

Adaptive services interfaces include a voice services feature that allows you to specify interface type *lsq-fpc/pic/port* to accommodate voice over IP (VoIP) traffic. This interface uses compressed RTP (CRTP), which is defined in RFC 2508, *Compressing IP/UDP/RTP Headers for Low-Speed Serial Links*.

CRTP enables VoIP traffic to use low-speed links more effectively, by compressing the 40-byte IP/UDP/RTP header down to 2 to 4 bytes in most cases.

Voice services on the AS and MultiServices PICs support single-link PPP-encapsulated IPv4 traffic over the following physical interface types: ATM2, DS3, E1, E3, OC3, OC12, STM1, and T1, including the channelized versions of these interfaces.



NOTE: On J-series Services Routers, you can configure CRTP with MLPPP or PPP logical interface encapsulation on link services (ls-) interfaces. For more information, see “Configuring Compressed RTP on J-series Services Routers” on page 990.

Voice services do not require a separate service rules configuration.

Voice services also support LFI on M-series routers, except the M320 router. For more information about configuring voice services, see “Voice Services Configuration Guidelines” on page 393.

For link services IQ interfaces (**lsq**) only, you can configure CRTP with multiclass MLPPP (MCML). MCML greatly simplifies packet ordering issues that occur when multiple links are used. Without MCML, all voice traffic belonging to a single flow is hashed to a single link in order to avoid packet ordering issues. With MCML, you can assign voice traffic to a high-priority class, and you can use multiple links. For more information about MCML support on link services IQ interfaces, see “Configuring Link Services and CoS on Services PICs” on page 347.

Class of Service Overview

The CoS configuration available for the AS PIC enables you to configure Differentiated Services (DiffServ) code point (DSCP) marking and forwarding-class assignment for packets transiting the AS PIC. You can configure the CoS service alongside the stateful firewall and NAT services, using a similar rule structure. The component structures are described in detail in the *JUNOS Class of Service Configuration Guide*.

Standards for Differentiated Services are described in the following documents:

- RFC 2474, *Definition of the Differentiated Services Field (DS Field) in the IPv4 and IPv6 Headers*
- RFC 2475, *An Architecture for Differentiated Services*



NOTE: CoS BA classification is not supported on services interfaces.

For more information about configuring CoS services, see “Class-of-Service Configuration Guidelines” on page 419.

Examples: Services Interfaces Configuration

The following configuration includes all the items necessary to configure services on an interface. For examples showing individual service configurations, see the chapters that describe each service in detail.

```
[edit]
interfaces {
  fe-0/1/0 {
    unit 0 {
      family inet {
        service {
          input {
            service-set Firewall-Set;
          }
          output {
            service-set Firewall-Set;
          }
        }
      }
      address 10.1.3.2/24;
    }
  }
}
```

```

fe-0/1/1 {
  unit 0 {
    family inet {
      filter {
        input Sample;
      }
      address 172.16.1.2/24;
    }
  }
}
sp-1/0/0 {
  unit 0 {
    family inet {
      address 172.16.1.3/24 {
      }
    }
  }
}
}
forwarding-options {
  sampling {
    input {
      family inet {
        rate 1;
      }
    }
    output {
      cflowd 10.1.3.1 {
        port 2055;
        version 5;
      }
      flow-inactive-timeout 15;
      flow-active-timeout 60;
      interface sp-1/0/0 {
        engine-id 1;
        engine-type 136;
        source-address 10.1.3.2;
      }
    }
  }
}
}
firewall {
  filter Sample {
    term Sample {
      then {
        count Sample;
        sample;
        accept;
      }
    }
  }
}
}
services {
  stateful-firewall {
    rule Rule1 {
      match-direction input;
    }
  }
}

```

```

term 1 {
    from {
        application-sets Applications;
    }
    then {
        accept;
    }
}
term accept {
    then {
        accept;
    }
}
}
rule Rule2 {
    match-direction output;
    term Local {
        from {
            source-address {
                10.1.3.2/32;
            }
        }
        then {
            accept;
        }
    }
}
}
ids {
    rule Attacks {
        match-direction output;
        term Match {
            from {
                application-sets Applications;
            }
            then {
                logging {
                    syslog;
                }
            }
        }
    }
}
}
nat {
    pool public {
        address-range low 172.16.2.1 high 172.16.2.32;
        port automatic;
    }
    rule Private-Public {
        match-direction input;
        term Translate {
            then {
                translated {
                    source-pool public;
                    translation-type source dynamic;
                }
            }
        }
    }
}

```

```

    }
  }
}
service-set Firewall-Set {
  stateful-firewall-rules Rule1;
  stateful-firewall-rules Rule2;
  nat-rules Private-Public;
  ids-rules Attacks;
  interface-service {
    service-interface sp-1/0/0;
  }
}
}
applications {
  application ICMP {
    application-protocol icmp;
  }
  application FTP {
    application-protocol ftp;
    destination-port ftp;
  }
  application-set Applications {
    application ICMP;
    application FTP;
  }
}
}

```

The following example combines VPN routing and forwarding (VRF) and services configuration:

```

[edit policy-options]
policy-statement test-policy {
  term t1 {
    then reject;
  }
}
[edit routing-instances]
test {
  interface ge-0/2/0.0;
  interface sp-1/3/0.20;
  instance-type vrf;
  route-distinguisher 10.58.255.1:37;
  vrf-import test-policy;
  vrf-export test-policy;
  routing-options {
    static {
      route 0.0.0.0/0 next-table inet.0;
    }
  }
}
[edit interfaces]
ge-0/2/0 {
  unit 0 {
    family inet {
      service {

```

```

        input service-set nat-me;
        output service-set nat-me;
    }
}
}
sp-1/3/0 {
    unit 0 {
        family inet;
    }
    unit 20 {
        family inet;
        service-domain inside;
    }
    unit 21 {
        family inet;
        service-domain outside;
    }
}
[edit services]
stateful-firewall {
    rule allow-any-input {
        match-direction input;
        term t1 {
            then accept;
        }
    }
}
nat {
    pool hide-pool {
        address 10.58.16.100;
        port automatic;
    }
    rule hide-all-input {
        match-direction input;
        term t1 {
            then {
                translated {
                    source-pool hide-pool;
                    translation-type source dynamic;
                }
            }
        }
    }
}
service-set nat-me {
    stateful-firewall-rules allow-any-input;
    nat-rules hide-all-input;
    interface-service {
        service-interface sp-1/3/0.20;
    }
}
}

```

The following example shows dynamic-source NAT applied as a next-hop service:

```
[edit interfaces]
```

```

ge-0/2/0 {
  unit 0 {
    family mpls;
  }
}
sp-1/3/0 {
  unit 0 {
    family inet;
  }
  unit 20 {
    family inet;
  }
  unit 32 {
    family inet;
  }
}
[edit routing-instances]
protected-domain {
  interface ge-0/2/0.0;
  interface sp-1/3/0.20;
  instance-type vrf;
  route-distinguisher 10.58.255.17:37;
  vrf-import protected-domain-policy;
  vrf-export protected-domain-policy;
  routing-options {
    static {
      route 0.0.0.0/0 next-hop sp-1/3/0.20;
    }
  }
}
[edit policy-options]
policy-statement protected-domain-policy {
  term t1 {
    then reject;
  }
}
[edit services]
stateful-firewall {
  rule allow-all {
    match-direction input;
    term t1 {
      then {
        accept;
      }
    }
  }
}
nat {
  pool my-pool {
    address 10.58.16.100;
    port automatic;
  }
  rule hide-all {
    match-direction input;
    term t1 {
      then {

```

```

        translated {
            source-pool my-pool;
            translation-type source dynamic;
        }
    }
}
}
}
service-set null-sfw-with-nat {
    stateful-firewall-rules allow-all;
    nat-rules hide-all;
    next-hop-service {
        inside-service-interface sp-1/3/0.20;
        outside-service-interface sp-1/3/0.32;
    }
}

```

The following example configuration enables NAT between VRFs with overlapping private addresses, using distinct public addresses for the source and destination NAT in this scenario:

- A host in vrf-a traverses 10.58.16.201 to reach 10.58.0.2 in vrf-b.
- A host in vrf-b traverses 10.58.16.101 to reach 10.58.0.2 in vrf-a.

```

[edit interfaces]
ge-0/2/0 {
    unit 0 {
        family inet {
            address 10.58.0.1/24;
            service {
                input service-set vrf-a-svc-set;
                output service-set vrf-a-svc-set;
            }
        }
    }
}
ge-0/3/0 {
    unit 0 {
        family inet {
            address 10.58.0.1/24;
            service {
                input service-set vrf-b-svc-set;
                output service-set vrf-b-svc-set;
            }
        }
    }
}
sp-1/3/0 {
    unit 0 {
        family inet;
    }
    unit 10 {
        family inet;
        service-domain inside;
    }
    unit 20 {

```

```

        family inet;
        service-domain inside;
    }
}
[edit policy-options]
policy-statement test-policy {
    term t1 {
        then reject;
    }
}
[edit routing-instances]
vrf-a {
    interface ge-0/2/0.0;
    interface sp-1/3/0.10;
    instance-type vrf;
    route-distinguisher 10.1.1.1:1;
    vrf-import test-policy;
    vrf-export test-policy;
    routing-options {
        static {
            route 0.0.0.0/0 next-table inet.0;
        }
    }
}
vrf-b {
    interface ge-0/3/0.0;
    interface sp-1/3/0.20;
    instance-type vrf;
    route-distinguisher 10.2.2.2:2;
    vrf-import test-policy;
    vrf-export test-policy;
    routing-options {
        static {
            route 0.0.0.0/0 next-table inet.0;
        }
    }
}
[edit services]
stateful-firewall {
    rule allow-all {
        match-direction input-output;
        term t1 {
            then {
                accept;
            }
        }
    }
}
nat {
    pool vrf-a-src-pool {
        address 10.58.16.100;
        port automatic;
    }
    pool vrf-a-dst-pool {
        address 10.58.0.2;
    }
}

```



```

rule vrf-a-input {
    match-direction input;
    term t1 {
        then {
            translated {
                source-pool vrf-a-src-pool;
                translation-type source dynamic;
            }
        }
    }
}
rule vrf-a-output {
    match-direction output;
    term t1 {
        from {
            destination-address 10.58.16.101;
        }
        then {
            translated {
                destination-pool vrf-a-dst-pool;
                translation-type destination static;
            }
        }
    }
}
pool vrf-b-src-pool {
    address 10.58.16.200;
    port automatic;
}
pool vrf-b-dst-pool {
    address 10.58.0.2;
}
rule vrf-b-input {
    match-direction input;
    term t1 {
        then {
            translated {
                source-pool vrf-b-src-pool;
                translation-type source dynamic;
            }
        }
    }
}
rule vrf-b-output {
    match-direction output;
    term t1 {
        from {
            destination-address 10.58.16.201;
        }
        then {
            translated {
                destination-pool vrf-b-dst-pool;
                translation-type destination static;
            }
        }
    }
}

```

```

    }
  }
  service-set vrf-a-svc-set {
    stateful-firewall-rules allow-all;
    nat-rules vrf-a-input;
    nat-rules vrf-a-output;
    interface-service {
      service-interface sp-1/3/0.10;
    }
  }
  service-set vrf-b-svc-set {
    stateful-firewall-rules allow-all;
    nat-rules vrf-b-input;
    nat-rules vrf-b-output;
    interface-service {
      service-interface sp-1/3/0.20;
    }
  }
}

```

The following example supports Bootstrap Protocol (BOOTP) and broadcast addresses:

```

[edit applications]
application bootp {
  application-protocol bootp;
  protocol udp;
  destination-port 67;
}
[edit services]
stateful-firewall bootp-support {
  rule bootp-allow {
    direction input;
    term bootp-allow {
      from {
        destination-address {
          any-unicast;
          255.255.255.255;
        }
        application bootp;
      }
      then {
        accept;
      }
    }
  }
}
}

```

Chapter 4

Applications Configuration Guidelines

You can define application protocols for the stateful firewall and Network Address Translation (NAT) services to use in match condition rules. An application protocol, or application layer gateway (ALG), defines application parameters using information from network Layer 3 and above. Examples of such applications are FTP and H.323.

To configure applications that are used with services, include the following statements at the [edit applications] hierarchy level:

```
[edit applications]
application application-name {
  application-protocol protocol-name;
  destination-port port-number;
  icmp-code value;
  icmp-type value;
  inactivity-timeout value;
  learn-sip-register;
  protocol type;
  rpc-program-number number;
  sip-call-hold-timeout seconds;
  snmp-command command;
  source-port port-number;
  ttl-threshold value;
  uuid hex-value;
}
application-set application-set-name {
  application application-name;
}
```

This chapter includes the following sections:

- Configuring Application Protocol Properties on page 60
- Configuring Application Sets on page 70
- ALG Descriptions on page 70
- Verifying the Output of ALG Sessions on page 78
- JUNOS Default Groups on page 85
- Examples: Configuring Application Protocols on page 93

Configuring Application Protocol Properties

To configure application properties, include the **application** statement at the [edit applications] hierarchy level:

```
[edit applications]
application application-name {
  application-protocol protocol-name;
  destination-port port-number;
  icmp-code value;
  icmp-type value;
  inactivity-timeout value;
  learn-sip-register;
  protocol type;
  rpc-program-number number;
  sip-call-hold-timeout seconds;
  snmp-command command;
  source-port port-number;
  ttl-threshold value;
  uuid hex-value;
}
```

You can group application objects by configuring the **application-set** statement; for more information, see “Configuring Application Sets” on page 70.

This section includes the following tasks for configuring applications:

- Configuring an Application Protocol on page 60
- Configuring the Network Protocol on page 62
- Configuring the ICMP Code and Type on page 63
- Configuring Source and Destination Ports on page 65
- Configuring the Inactivity Timeout Period on page 68
- Configuring SIP on page 68
- Configuring an SNMP Command for Packet Matching on page 69
- Configuring an RPC Program Number on page 69
- Configuring the TTL Threshold on page 69
- Configuring a Universal Unique Identifier on page 70

Configuring an Application Protocol

The **application-protocol** statement allows you to specify which of the supported application protocols (ALGs) to configure and include in an application set for service processing. To configure application protocols, include the **application-protocol** statement at the [edit applications application *application-name*] hierarchy level:

```
[edit applications application application-name]
application-protocol protocol-name;
```

Table 6 on page 61 shows the list of supported protocols. For more information about specific protocols, see “ALG Descriptions” on page 70.

Table 6: Application Protocols Supported by Services Interfaces

Protocol Name	CLI Value	Comments
Bootstrap protocol (BOOTP)	bootp	Supports BOOTP and dynamic host configuration protocol (DHCP).
Distributed Computing Environment (DCE) remote procedure call (RPC)	dce-rpc	Requires the protocol statement to have the value udp or tcp . Requires a uuid value. You cannot specify destination-port or source-port values.
DCE RPC portmap	dce-rpc-portmap	Requires the protocol statement to have the value udp or tcp . Requires a destination-port value.
Domain Name System (DNS)	dns	Requires the protocol statement to have the value udp . This application protocol closes the DNS flow as soon as the DNS response is received.
Exec	exec	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
FTP	ftp	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
H.323	h323	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
Internet Control Message Protocol (ICMP)	icmp	Requires the protocol statement to have the value icmp or to be unspecified.
Internet Inter-ORB Protocol (IIOP) Transmission Control Protocol (TCP)	iiop	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
IP	ip	–
Login	login	–
NetBIOS	netbios	Requires the protocol statement to have the value udp or to be unspecified. Requires a destination-port value.
NetShow	netshow	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
RealAudio	realaudio	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
Real-Time Streaming Protocol (RTSP)	rtsp	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
RPC User Datagram Protocol (UDP) or TCP	rpc	Requires the protocol statement to have the value udp or tcp . Requires a rpc-program-number value. You cannot specify destination-port or source-port values.
RPC port mapping	rpc-portmap	Requires the protocol statement to have the value udp or tcp . Requires a destination-port value.
Session Initiation Protocol (SIP)	sip	For more information, see “Configuring SIP” on page 68.

Table 6: Application Protocols Supported by Services Interfaces (*continued*)

Protocol Name	CLI Value	Comments
Shell	shell	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.
SNMP	snmp	Requires the protocol statement to have the value udp or to be unspecified. Requires a destination-port value.
SQLNet	sqlnet	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port or source-port value.
Trace route	traceroute	Requires the protocol statement to have the value udp or to be unspecified. Requires a destination-port value.
Trivial FTP (TFTP)	tftp	Requires the protocol statement to have the value udp or to be unspecified. Requires a destination-port value.
WinFrame	winframe	Requires the protocol statement to have the value tcp or to be unspecified. Requires a destination-port value.



NOTE: You can configure application-level gateways (ALGs) for ICMP and trace route under stateful firewall, NAT, or CoS rules when twice NAT is configured in the same service set. These ALGs cannot be applied to flows created by the Packet Gateway Controller Protocol (PGCP). Twice NAT does not support any other ALGs. NAT applies only the IP address and TCP or UDP headers, but not the payload.

For more information about configuring twice NAT, see “Network Address Translation Services Configuration Guidelines” on page 129.

Configuring the Network Protocol

The **protocol** statement allows you to specify which of the supported network protocols to match in an application definition. To configure network protocols, include the **protocol** statement at the [edit applications application *application-name*] hierarchy level:

```
[edit applications application application-name]
protocol type;
```

You specify the protocol type as a numeric value; for the more commonly used protocols, text names are also supported in the command-line interface (CLI). Table 7 on page 63 shows the list of the supported protocols.

Table 7: Network Protocols Supported by Services Interfaces

Network Protocol Type	CLI Value	Comments
IP Security (IPsec) authentication header (AH)	ah	–
External Gateway Protocol (EGP)	egp	–
IPsec Encapsulating Security Payload (ESP)	esp	–
Generic routing encapsulation (GR)	gre	–
ICMP	icmp	Requires an <code>application-protocol</code> value of <code>icmp</code> .
Internet Group Management Protocol (IGMP)	igmp	–
IP in IP	ipip	–
OSPF	ospf	–
Protocol Independent Multicast (PIM)	pim	–
Resource Reservation Protocol (RSVP)	rsvp	–
TCP	tcp	Requires a <code>destination-port</code> or <code>source-port</code> value unless you specify <code>application-protocol rcp</code> or <code>dce-rcp</code> .
UDP	udp	Requires a <code>destination-port</code> or <code>source-port</code> value unless you specify <code>application-protocol rcp</code> or <code>dce-rcp</code> .
Virtual Router Redundancy Protocol (VRRP)	vrrp	–

For a complete list of possible numeric values, see RFC 1700, *Assigned Numbers (for the Internet Protocol Suite)*.



NOTE: IP version 6 (IPv6) is not supported as a network protocol in application definitions.

By default, the twice NAT feature can affect IP, TCP, and UDP headers embedded in the payload of ICMP error messages. You can include the `protocol tcp` and `protocol udp` statements with the `application` statement for twice NAT configurations. For more information about configuring twice NAT, see “Network Address Translation Services Configuration Guidelines” on page 129.

Configuring the ICMP Code and Type

The ICMP code and type provide additional specification, in conjunction with the network protocol, for packet matching in an application definition. To configure ICMP

settings, include the `icmp-code` and `icmp-type` statements at the [edit applications application *application-name*] hierarchy level:

```
[edit applications application application-name]
  icmp-code value;
  icmp-type value;
```

You can include only one ICMP code and type value. The `application-protocol` statement must have the value `icmp`. Table 8 on page 64 shows the list of supported ICMP values.

Table 8: ICMP Codes and Types Supported by Services Interfaces

CLI Statement	Description
<code>icmp-code</code>	<p>This value or keyword provides more specific information than <code>icmp-type</code>. Because the value's meaning depends upon the associated <code>icmp-type</code> value, you must specify <code>icmp-type</code> along with <code>icmp-code</code>. For more information, see the <i>JUNOS Policy Framework Configuration Guide</i>.</p> <p>In place of the numeric value, you can specify one of the following text synonyms (the field values are also listed). The keywords are grouped by the ICMP type with which they are associated:</p> <p>parameter-problem: <code>ip-header-bad</code> (0), <code>required-option-missing</code> (1)</p> <p>redirect: <code>redirect-for-host</code> (1), <code>redirect-for-network</code> (0), <code>redirect-for-tos-and-host</code> (3), <code>redirect-for-tos-and-net</code> (2)</p> <p>time-exceeded: <code>ttl-eq-zero-during-reassembly</code> (1), <code>ttl-eq-zero-during-transit</code> (0)</p> <p>unreachable: <code>communication-prohibited-by-filtering</code> (13), <code>destination-host-prohibited</code> (10), <code>destination-host-unknown</code> (7), <code>destination-network-prohibited</code> (9), <code>destination-network-unknown</code> (6), <code>fragmentation-needed</code> (4), <code>host-precedence-violation</code> (14), <code>host-unreachable</code> (1), <code>host-unreachable-for-TOS</code> (12), <code>network-unreachable</code> (0), <code>network-unreachable-for-TOS</code> (11), <code>port-unreachable</code> (3), <code>precedence-cutoff-in-effect</code> (15), <code>protocol-unreachable</code> (2), <code>source-host-isolated</code> (8), <code>source-route-failed</code> (5)</p>
<code>icmp-type</code>	<p>Normally, you specify this match in conjunction with the <code>protocol</code> match statement to determine which protocol is being used on the port. For more information, see the <i>JUNOS Policy Framework Configuration Guide</i>.</p> <p>In place of the numeric value, you can specify one of the following text synonyms (the field values are also listed): <code>echo-reply</code> (0), <code>echo-request</code> (8), <code>info-reply</code> (16), <code>info-request</code> (15), <code>mask-request</code> (17), <code>mask-reply</code> (18), <code>parameter-problem</code> (12), <code>redirect</code> (5), <code>router-advertisement</code> (9), <code>router-solicit</code> (10), <code>source-quench</code> (4), <code>time-exceeded</code> (11), <code>timestamp</code> (13), <code>timestamp-reply</code> (14), or <code>unreachable</code> (3).</p>



NOTE: If you configure an interface with an input firewall filter that includes a reject action and with a service set that includes stateful firewall rules, the router executes the input firewall filter before the stateful firewall rules are run on the packet. As a result, when the Packet Forwarding Engine sends an ICMP error message out through the interface, the stateful firewall rules might drop the packet because it was not seen in the input direction.

Possible workarounds are to include a forwarding-table filter to perform the reject action, because this type of filter is executed after the stateful firewall in the input direction, or to include an output service filter to prevent the locally generated ICMP packets from going to the stateful firewall service.

Configuring Source and Destination Ports

The TCP or UDP source and destination port provide additional specification, in conjunction with the network protocol, for packet matching in an application definition. To configure ports, include the **destination-port** and **source-port** statements at the [edit applications application *application-name*] hierarchy level:

```
[edit applications application application-name]
destination-port value;
source-port value;
```

You must define one source or destination port. Normally, you specify this match in conjunction with the **protocol** match statement to determine which protocol is being used on the port; for constraints, see Table 6 on page 61.

You can specify either a numeric value or one of the text synonyms listed in Table 9 on page 65.

Table 9: Port Names Supported by Services Interfaces

Port Name	Corresponding Port Number
afs	1483
bgp	179
biff	512
bootpc	68
bootps	67
cmd	514
cvspserver	2401
dhcp	67
domain	53

Table 9: Port Names Supported by Services Interfaces *(continued)*

Port Name	Corresponding Port Number
eklogin	2105
ekshell	2106
exec	512
finger	79
ftp	21
ftp-data	20
http	80
https	443
ident	113
imap	143
kerberos-sec	88
klogin	543
kpasswd	761
krb-prop	754
krbupdate	760
kshell	544
ldap	389
login	513
mobileip-agent	434
mobileip-mn	435
msdp	639
netbios-dgm	138
netbios-ns	137
netbios-ssn	139
nfsd	2049
nntp	119
ntalk	518

Table 9: Port Names Supported by Services Interfaces *(continued)*

Port Name	Corresponding Port Number
ntp	123
pop3	110
pptp	1723
printer	515
radacct	1813
radius	1812
rip	520
rkinit	2108
smtp	25
snmp	161
snmptrap	162
snpp	444
socks	1080
ssh	22
sunrpc	111
syslog	514
tacacs-ds	65
talk	517
telnet	23
tftp	69
timed	525
who	513
xmcp	177
zephyr-clt	2103
zephyr-hm	2104

For more information about matching criteria, see the *JUNOS Policy Framework Configuration Guide*.

Configuring the Inactivity Timeout Period

You can specify a timeout period for application inactivity. If the software has not detected any activity during the duration, the flow becomes invalid when the timer expires. To configure a timeout period, include the `inactivity-timeout` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
  inactivity-timeout seconds;
```

The default value is 30 seconds. The value you configure for an application overrides any global value configured at the `[edit interfaces interface-name service-options]` hierarchy level; for more information, see “Configuring Default Timeout Settings for Services Interfaces” on page 478.

Configuring SIP

The Session Initiation Protocol (SIP) is a generalized protocol for communication between endpoints involved in Internet services such as telephony, fax, video conferencing, instant messaging, and file exchange. The supported standard is described in RFC 3261, *SIP: Session Initiation Protocol*, which includes stateful firewall and Network Address Translation (NAT) support for SIP dialogs and UDP IPv4 transport of SIP messages.

To implement SIP on adaptive services interfaces, you configure the `application-protocol` statement at the `[edit applications application application-name]` hierarchy level with the value `sip`. For more information about this statement, see “Configuring an Application Protocol” on page 60. In addition, there are two other statements you can configure to modify how SIP is implemented:

- You can enable the router to accept any incoming SIP calls for the endpoint devices that are behind the NAT firewall. When a device behind the firewall registers with the proxy that is outside the firewall, the AS or MultiServices PIC maintains the registration state. When the `learn-sip-register` statement is enabled, the router can use this information to accept inbound calls. If this statement is not configured, no inbound calls are accepted; only the devices behind the firewall can call devices outside the firewall.

To configure SIP registration, include the `learn-sip-register` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
  learn-sip-register;
```

You can also manually inspect the SIP register by issuing the `show services stateful-firewall sip-register` command; for more information, see the *JUNOS System Basics and Services Command Reference*.

- You can specify a timeout period for the duration of SIP calls that are placed on hold. When a call is put on hold, there is no activity and flows might time out

after the configured `inactivity-timeout` period expires, resulting in call state teardown. To avoid this, when a call is put on hold, the flow timer is reset to the `sip-call-hold-timeout` cycle to preserve the call state and flows for longer than the `inactivity-timeout` period.

To configure a timeout period, include the `sip-call-hold-timeout` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
sip-call-hold-timeout seconds;
```

The default value is 7200 seconds and the range is from 0 through 36,000 seconds (10 hours).

Configuring an SNMP Command for Packet Matching

You can specify an SNMP command setting for packet matching. To configure SNMP, include the `snmp-command` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
snmp-command value;
```

The supported values are `get`, `get-next`, `set`, and `trap`. You can configure only one value for matching. The `application-protocol` statement at the `[edit applications application application-name]` hierarchy level must have the value `snmp`. For information about specifying the application protocol, see “Configuring an Application Protocol” on page 60.

Configuring an RPC Program Number

You can specify an RPC program number for packet matching. To configure an RPC program number, include the `rpc-program-number` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
rpc-program-number number;
```

The range of values used for DCE or RPC is from 100,000 through 400,000. The `application-protocol` statement at the `[edit applications application application-name]` hierarchy level must have the value `rpc`. For information about specifying the application protocol, see “Configuring an Application Protocol” on page 60.

Configuring the TTL Threshold

You can specify a trace route time-to-live (TTL) threshold value, which controls the acceptable level of network penetration for trace routing. To configure a TTL value, include the `ttl-threshold` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
ttl-threshold value;
```

The `application-protocol` statement at the `[edit applications application application-name]` hierarchy level must have the value `traceroute`. For information about specifying the application protocol, see “Configuring an Application Protocol” on page 60.

Configuring a Universal Unique Identifier

You can specify a Universal Unique Identifier (UUID) for DCE RPC objects. To configure a UUID value, include the `uuid` statement at the `[edit applications application application-name]` hierarchy level:

```
[edit applications application application-name]
  uuid hex-value;
```

The `uuid` value is in hexadecimal notation. The `application-protocol` statement at the `[edit applications application application-name]` hierarchy level must have the value `dce-rpc`. For information about specifying the application protocol, see “Configuring an Application Protocol” on page 60. For more information on UUID numbers, see <http://www.opengroup.org/onlinepubs/9629399/apdx.htm>.

Configuring Application Sets

You can group the applications you have defined into a named object by including the `application-set` statement at the `[edit applications]` hierarchy level with an `application` statement for each application:

```
[edit applications]
  application-set application-set-name {
    application application;
  }
```

For an example of a typical application set, see “Examples: Configuring Application Protocols” on page 93.

ALG Descriptions

This section includes details about the ALGs. It includes the following:

- Basic TCP ALG on page 71
- Basic UDP ALG on page 71
- BOOTP on page 72
- DCE RPC Services on page 72
- FTP on page 72
- H323 on page 73
- ICMP on page 73
- IIOP on page 74
- NetShow on page 74
- RealAudio on page 74
- RPC and RPC Portmap Services on page 74

- RTSP on page 76
- SMB on page 76
- SNMP on page 76
- SQLNet on page 77
- TFTP on page 77
- Traceroute on page 77
- UNIX Remote-Shell Services on page 77
- WinFrame on page 78

Basic TCP ALG

This ALG performs basic sanity checking on TCP packets. If it finds errors, it generates the following anomaly events and system log messages:

- TCP source or destination port zero
- TCP header length check failed
- TCP sequence number zero and no flags are set
- TCP sequence number zero and FIN/PSH/RST flags are set
- TCP FIN/RST or SYN(URG|FIN|RST) flags set

The TCP ALG performs the following steps:

1. When the router receives a SYN packet, the ALG creates TCP forward and reverse flows and groups them in a *conversation*. It tracks the TCP three-way handshake.
2. The SYN-defense mechanism tracks the TCP connection establishment state. It expects the TCP session to be established within a small time interval (currently 4 seconds). If the TCP three-way handshake is not established in that period, the session is terminated.
3. A keepalive mechanism detects TCP sessions with nonresponsive endpoints.
4. ICMP errors are allowed only if there is a flow that matches the selector information specified in the ICMP data.

Basic UDP ALG

This ALG performs basic sanity checking on UDP headers. If it finds errors, it generates the following anomaly events and system log messages:

- UDP source or destination port 0
- UDP header length check failed

The UDP ALG performs the following steps:

1. When it receives the first packet, the ALG creates bidirectional flows to accept forward and reverse UDP session traffic.

2. If the session is idle for more than the maximum allowed idle time (the default is 30 seconds), the flows are deleted.
3. ICMP errors are allowed only if there is a flow that matches the selector information specified in the ICMP data.

BOOTP

The Bootstrap Protocol client retrieves its networking information from a server across the network. It sends out a general broadcast message to request the information, which is returned by the Bootstrap Protocol server. For the protocol specification, see <ftp://ftp.isi.edu/in-notes/rfc951.txt>.

Stateful firewall support requires that you configure the BOOTP ALG on UDP server port 67 and client port 68. If the client sends a broadcast message, you should configure the broadcast address in the **from** statement of the service rule. NAT is not performed on the BOOTP traffic, even if the NAT rule matches the traffic. If the BOOTP relay feature is activated on the router, the remote BOOTP server is assumed to assign addresses for clients masked by NAT translation.

DCE RPC Services

DCE RPC services are mainly used by Microsoft applications. The ALG uses well-known TCP port 135 for port mapping services and uses the Universal Unique Identifier (UUID) instead of the program number to identify protocols. The main application-based DCE RPC is the Microsoft Exchange Protocol.

Support for stateful firewall and NAT services requires that you configure the DCE RPC portmap ALG on TCP port 135. The DCE RPC ALG uses the TCP protocol with application-specific UUIDs.

FTP

FTP is the File Transfer Protocol, specified in RFC 959. In addition to the main control connection, data connections are also made for any data transfer between the client and the server, and the host, port, and direction are negotiated through the control channel.

For non-passive-mode FTP, the JUNOS stateful firewall service scans the client-to-server application data for the PORT command, which provides the IP address and port number to which the server connects. For passive-mode FTP, the JUNOS stateful firewall service scans the client-to-server application data for the PASV command and then scans the server-to-client responses for the 227 response, which contains the IP address and port number to which the client connects.

There is an additional complication: FTP represents these addresses and port numbers in ASCII. As a result, when addresses and ports are rewritten, the TCP sequence number might be changed, and thereafter the NAT service needs to maintain this delta in SEQ and ACK numbers by performing sequence NAT on all subsequent packets.

Support for stateful firewall and NAT services requires that you configure the FTP ALG on TCP port 21 to enable the FTP control protocol. The ALG performs the following tasks:

- Automatically allocates data ports and firewall permissions for dynamic data connection
- Creates flows for the dynamically negotiated data connection
- Monitors the control connection in both active and passive modes
- Rewrites the control packets with the appropriate NAT address and port information

H323

H323 is a suite of ITU protocols for audio-video conferencing and collaboration applications. H323 consists of h.225 call signaling protocols and h.245, the control protocol for media communication. During h.225 negotiation, endpoints create a call by exchanging call signaling messages on the control channel and negotiate a new control channel for h.245. A new control connection is created for h.245 messages. Messages are exchanged on the h.245 control channel to open media channels.

The JUNOS stateful firewall service monitors the h.225 control channel to open the h.245 control channel. Once the h.245 channel is created, the stateful firewall service also monitors this channel for media channel information and allows the media traffic through the firewall. The H323 ALG supports static destination, static source, and dynamic source NAT by rewriting the appropriate addresses and ports in the h.225 and h.245 messages.

ICMP

The Internet Control Message Protocol (ICMP) is defined in RFC 792. The JUNOS stateful firewall service allows ICMP messages to be filtered by specific type or specific type code value. ICMP error packets that lack a specifically configured type and code are matched against any existing flow in the opposite direction to check for the legitimacy of the error packet. ICMP error packets that pass the filter matching are subject to NAT translation.

The ICMP ALG always tracks ping traffic statefully using the ICMP sequence number. Each echo reply is forwarded only if there is an echo request with the corresponding sequence number. For any ping flow, only 20 echo requests can be forwarded without receiving an echo reply. When you configure dynamic NAT, the PING packet identifier is translated to allow additional hosts in the NAT pool to use the same identifier.

Support for stateful firewall and NAT services requires that you configure the ICMP ALG if the protocol is needed. You can configure the ICMP type and code for additional filtering.

IIOP

Oracle Application Server NameServer Internet Inter-ORB Protocol (IIOP) is used in distributed computing based on CORBA (Common Object Request Broker Architecture). Even though CORBA and IIOP are OMG standards, no fixed port is assigned for IIOP. Each vendor implementing CORBA chooses a port. Java Virtual machine uses port 1975 by default, while ORBIX uses port 3075 by default.

The IIOP ALG monitors the control packets, dynamically opens flows, and performs NAT address and port rewrites.

NetShow

The Microsoft protocol ms-streaming is used by NetShow, the Microsoft media server. This protocol supports several transport protocols: TCP, UDP, and HTTP. The client starts a TCP connection on port 1755 and sends the PORT command to the server. The server then starts UDP on that port to the client. Support for stateful firewall and NAT services requires that you configure the NetShow ALG on UDP port 1755.

RealAudio

The Real Networks PNA protocol RealAudio is not a separate service. RealAudio was the original protocol used by RealPlayer. Newer versions of RealPlayer use RTSP.

Support for stateful firewall and NAT services requires that you configure the RealAudio ALG on TCP port 7070. The stateful firewall monitors the traffic on the TCP control channel and dynamically opens the ports for data channels.

RPC and RPC Portmap Services

The Remote Procedure Call (RPC) ALG uses well-known ports TCP 111 and UDP 111 for port mapping, which dynamically assigns and opens ports for RPC services. The RPC Portmap ALG keeps track of port requests and dynamically opens the firewall for these requested ports. The RPC ALG can further restrict the RPC protocol by specifying allowed program numbers.

The ALG includes the RPC services listed in Table 10 on page 74:

Table 10: Supported RPC Services

Name	Description	Comments
rpc.mountd	Network File Server (NFS) mount daemon for details, see the UNIX man page for rpc.mountd(8).	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050).
rpc.nfsprog	Used as part of NFS. For details, see RFC 1094. See also RFC1813 for NFS v3.	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050).

Table 10: Supported RPC Services (continued)

Name	Description	Comments
<code>rpc-nisplus</code>	Network Information Service Plus (NIS +), designed to replace NIS; it is a default naming service for Sun Solaris and is not related to the old NIS. No protocol information is available.	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050).
<code>rpc-nlockmgr</code>	Network lock manager.	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-nlockmgr</code> service can be allowed or blocked based on RPC program 100021.
<code>rpc-pcnfsd</code>	Kernel statistics server. For details, see the UNIX man pages for <code>rstatd</code> and <code>rpc.rstatd</code> .	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-rstat</code> service can be allowed or blocked based on RPC program 150001.
<code>rpc-rwall</code>	Used to write a message to users; for details, see the UNIX man page for <code>rpc.rwalld</code> .	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-rwall</code> service can be allowed or blocked based on RPC program 150008.
<code>rpc-ybind</code>	NIS binding process. For details, see the UNIX man page for <code>ybind</code> .	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-ybind</code> service can be allowed or blocked based on RPC program 100007.
<code>rpc-yppasswd</code>	NIS password server. For details, see the UNIX man page for <code>yppasswd</code> .	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-yppasswd</code> service can be allowed or blocked based on RPC program 100009.
<code>rpc-ypserv</code>	NIS server. For details, see the UNIX man page for <code>ypserv</code> .	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-ypserv</code> service can be allowed or blocked based on RPC program 100004.
<code>rpc-yupdated</code>	Network updating tool.	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-yupdated</code> service can be allowed or blocked based on RPC program 100028.
<code>rpc-ypxfrd</code>	NIS map transfer server. For details, see the UNIX man page for <code>rpc.ypxfrd</code> .	The base support is RPC v2 and the port mapper service on port 111 (see RFC 1050). Once the RPC program table is built, <code>rpc-ypxfrd</code> service can be allowed or blocked based on RPC program 100069.

Support for stateful firewall and NAT services that use port mapping requires that you configure the RPC portmap ALG on TCP/UDP destination port 111 and the RPC ALG for both TCP and UDP. You can specify one or more `rpc-program-number` values to further restrict allowed RPC protocols.

RTSP

The Real-Time Streaming Protocol (RTSP) controls the delivery of data with real-time properties such as audio and video. The streams controlled by RTSP may use RTP, but it is not required. Media may be transmitted on the same RTSP control stream. This is an HTTP-like text-based protocol, but client and server maintain session information. A session is established using the SETUP message and terminated using the TEARDOWN message. The transport (the media protocol, address, and port numbers) is negotiated in the setup and the setup-response.

Support for stateful firewall and NAT services requires that you configure the RTSP ALG for TCP port 554.

The ALG monitors the control connection, opens flows dynamically for media (RTP/RTSP) streams, and performs NAT address and port rewrites.

SMB

Server message block (SMB) is a popular PC protocol that allows sharing of files, disks, directories, printers, and in some cases, COM ports across a network. SMB is a client/server, request-response-based protocol. Though there are some exceptions to this, most of the communication takes place using the request reply paradigm. Servers make file systems and resources available to clients on the network. Clients can send commands (**smb**s) to the server that allow them to access these shared resources. SMB can run over multiple protocols, including TCP/IP, NetBEUI, and IPX/SPX. In almost all cases, the NetBIOS interface is used. Microsoft is trying to rename SMB-based networking to Windows Networking and the protocol to CIFS. The SMB protocol is undocumented, although there is a public CIFS group. For more information, refer to the following link on CIFS: <ftp://ftp.microsoft.com/developr/drg/CIFS/>.

The SMB name service uses well-known UDP and TCP port 137, without requiring a special ALG. For NetBIOS data tunneled through UDP port 138 or TCP port 139, you must configure the NetBIOS ALG. Support for stateful firewall and NAT services requires that you configure the NetBIOS ALG on UDP port 138 and TCP port 139. For SMB name services, both TCP and UDP port 137 must be opened, without a special ALG.

SNMP

SNMP is a communication protocol for managing TCP/IP networks, including both individual network devices and aggregated devices. The protocol is defined by RFC 1157. SNMP runs on top of UDP.

The JUNOS stateful firewall service implements the SNMP ALG to inspect the SNMP type. SNMP does not enforce stateful flow. Each SNMP type needs to be specifically enabled. Full SNMP support of stateful firewall services requires that you configure the SNMP ALG on UDP port 161. This enables the SNMP **get** and **get-next** commands, as well as their response traffic in the reverse direction: UDP port 161 enables the SNMP **get-response** command. If SNMP traps are permitted, you can configure them on UDP port 162, enabling the SNMP **trap** command.

SQLNet

The SQLNet protocol is used by Oracle SQL servers to execute SQL commands from clients, including load balancing and application-specific services.

Support of stateful firewall and NAT services requires that you configure the SQLNet ALG for TCP port 1521.

The ALG monitors the control packets, opens flows dynamically for data traffic, and performs NAT address and port rewrites.

TFTP

The Trivial File Transfer Protocol (TFTP) is specified in RFC 1350. The initial TFTP requests are sent to UDP destination port 69. Additional flows can be created to **get** or **put** individual files. Support of stateful firewall and NAT services requires that you configure the TFTP ALG for UDP destination port 69.

Traceroute

Traceroute is a tool for displaying the route that packets take to a network host. It uses the IP TTL field to trigger ICMP time-exceeded messages from routers or gateways. It sends UDP datagrams to destination ports that are believed to be not in use; destination ports are numbered using the formula: $+ nhops - 1$. The default base port is 33434. To support traceroute through the firewall, two types of traffic must be passed through:

1. UDP probe packets (UDP destination port > 33000 , IP TTL < 30)
2. ICMP response packets (ICMP type time-exceeded)

When NAT is applied, the IP address and port within the ICMP error packet also need to be changed.

Support of stateful firewall and NAT services requires you to configure the Traceroute ALG for UDP destination port 33434 to 33450. In addition, you can configure the TTL threshold to prevent UDP flood attacks with large TTL values.

UNIX Remote-Shell Services

Three protocols form the basis for UNIX remote-shell services:

Exec—Remote command execution; enables a user on the client system to execute a command on the remote system. The first command from client (**rcmd**) to server (**rshd**) uses well-known TCP port 512. A second TCP connection can be opened at the request of **rcmd**. The client port number for the second connection is sent to the server as an ASCII string.

Login—Better known as **rlogin**; uses well-known TCP port 513. For details, see RFC 1282. No special firewall processing is required.

Shell—Remote command execution; enables a user on the client system to execute a command on the remote system. The first command from client (`rcmd`) to server (`rshd`) uses well-known TCP port 514. A second TCP connection can be opened at the request of `rcmd`. The client port number for the second connection is sent to the server as an ASCII string.

Support of stateful firewall services requires that you configure the Exec ALG on TCP port 512, the Login ALG on TCP port 513, and the Shell ALG on TCP port 514. NAT remote-shell services require that any dynamic source port assigned be within the port range 512 to 1023. If you configure a NAT pool, this port range is reserved exclusively for remote shell applications.

WinFrame

WinFrame application server software provides access to virtually any Windows application, across any type of network connection to any type of client. This protocol is mainly used by the Citrix Windows application. Support of stateful firewall and NAT services requires that you configure the WinFrame ALG for TCP destination port 1494 and UDP port 1604.

Verifying the Output of ALG Sessions

This section contains examples of successful output from ALG sessions and information on system log configuration. You can compare the results of your sessions to check whether the configurations are functioning correctly.

- FTP Example on page 78
- RTSP ALG Example on page 81
- System Log Messages on page 83

FTP Example

This example analyzes the output during an active FTP session. It consists of four different flows; two are control flows and two are data flows. The example consists of the following parts:

- Sample Output on page 78
- FTP System Log Messages on page 79
- Analysis on page 80
- Troubleshooting Questions on page 80

Sample Output

The following is a complete sample output from the `show services stateful-firewall conversations application-protocol ftp` operational mode command:

```
user@host>show services stateful-firewall conversations application-protocol ftp
Interface: sp-1/3/0, Service set: CLBJI1-AAF001
Conversation: ALG protocol: ftp
  Number of initiators: 2, Number of responders: 2
```

Flow				State	Dir	Frm count
TCP	NAT source	1.1.79.2:14083 -> 1.1.79.2:14083	-> 194.250.1.237:50118	Watch	I	13
TCP	NAT source	1.1.79.2:14104 -> 1.1.79.2:14104	-> 194.250.1.237:50119	Forward	I	3
TCP	NAT dest	2.2.2.2:21 -> 194.250.1.237:50118	-> 1.1.79.2:14083	Watch	O	12
TCP	NAT dest	2.2.2.2:20 -> 194.250.1.237:50119	-> 1.1.79.2:14104	Forward	O	5

For each flow, the first line shows flow information, including protocol (TCP), source address, source port, destination address, destination port, flow state, direction, and frame count.

- The state of a flow can be **Watch**, **Forward**, or **Drop**:
 - A **Watch** flow state indicates that the control flow is monitored by the ALG for information in the payload. NAT processing is performed on the header and payload as needed.
 - A **Forward** flow forwards the packets without monitoring the payload. NAT is performed on the header as needed.
 - A **Drop** flow drops any packet that matches the 5 tuple.
- The frame count (**Frm count**) shows the number of packets that were processed on that flow.

The second line shows the NAT information.

- **source** indicates source NAT.
- **dest** indicates destination NAT.
- The first address and port in the NAT line are the original address and port being translated for that flow.
- The second address and port in the NAT line are the translated address and port for that flow.

FTP System Log Messages

System log messages are generated during an FTP session. For more information about system logs, see “System Log Messages” on page 83.

The following system log messages are generated during creation of the FTP control flow:

- Rule Accept system log:


```
Oct 27 11:42:54 (FPC Slot 1, PIC Slot 1) {ss_ftp}[FWNAT]:
  ASP_SFW_RULE_ACCEPT: proto 6 (TCP) application: ftp,
  fe-3/3/3.0:1.1.1.2:4450 -> 2.2.2.2:21, Match SFW accept rule-set:, rule: ftp,
  term: 1
```
- Create Accept Flow system log:

```
Oct 27 11:42:54 (FPC Slot 1, PIC Slot 1) {ss_ftp}[FWNAT]:
ASP_SFW_CREATE_ACCEPT_FLOW: proto 6 (TCP) application: ftp,
fe-3/3/3.0:1.1.1.2:4450 -> 2.2.2.2:21, creating forward or watch flow
```

- System log for data flow creation:

```
Oct 27 11:43:30 (FPC Slot 1, PIC Slot 1) {ss_ftp}[FWNAT]:
ASP_SFW_FTP_ACTIVE_ACCEPT: proto 6 (TCP) application: ftp,
so-2/1/2.0:2.2.2.2:20 -> 1.1.1.2:50726, Creating FTP active mode forward
flow
```

Analysis

Control Flows

The control flows are established after the three-way handshake is complete.

- Control flow from FTP client to FTP server. TCP destination port is 21.

```
TCP          1.1.79.2:14083 ->      2.2.2.2:21    Watch    I
 13
NAT source   1.1.79.2:14083  ->    194.250.1.237:50118
```

- Control flow from FTP server to FTP client. TCP source port is 21.

```
TCP          2.2.2.2:21    ->    194.250.1.237:50118 Watch    O
 12
NAT dest     194.250.1.237:50118 ->      1.1.79.2:14083
```

Data Flows

A data port of 20 is negotiated for data transfer during the course of the FTP control protocol. These two flows are data flows between the FTP client and the FTP server:

```
TCP          1.1.79.2:14104 ->      2.2.2.2:20    Forward  I           3
NAT source   1.1.79.2:14104  ->    194.250.1.237:50119
TCP          2.2.2.2:20    ->    194.250.1.237:50119 Forward  O           5
NAT dest     194.250.1.237:50119 ->      1.1.79.2:14104
```

Troubleshooting Questions

- How do I know if the FTP ALG is active?
 - The ALG protocol field in the conversation should display `ftp`.
 - There should be a valid frame count (**Frm count**) in the control flows.
 - A valid frame count in the data flows indicates that data transfer has taken place.
- What do I need to check if the FTP connection is established but data transfer does not take place?

- Most probably, the control connection is up, but the data connection is down.
 - Check the conversations output to determine whether both the control and data flows are present.
3. How do I interpret each flow? What does each flow mean?
- FTP control flow initiator flow—Flow with destination port 21
 - FTP control flow responder flow—Flow with source port ;21
 - FTP data flow initiator flow—Flow with destination port 20
 - FTP data flow responder flow—Flow with source port 20

RTSP ALG Example

The following is an example of an RTSP conversation. The RealAudio application uses the RTSP protocol for control connection. Once the connection is set up, the media is sent using UDP protocol (RTP).

This example consists of the following:

- Sample Output on page 81
- Analysis on page 81
- Troubleshooting Questions on page 82

Sample Output

Here is the output from the `show services stateful-firewall conversations operational` mode command:

```
user@host# show services stateful-firewall conversations
```

```
Interface: sp-3/2/0, Service set: svc_set
```

```
Conversation: ALG protocol: rtsp
```

```
Number of initiators: 5, Number of responders: 5
```

Flow			State	Dir	Frm count
TCP	1.1.1.3:58795	-> 2.2.2.2:554	Watch	I	7
UDP	1.1.1.3:1028	-> 2.2.2.2:1028	Forward	I	0
UDP	1.1.1.3:1029	-> 2.2.2.2:1029	Forward	I	0
UDP	1.1.1.3:1030	-> 2.2.2.2:1030	Forward	I	0
UDP	1.1.1.3:1031	-> 2.2.2.2:1031	Forward	I	0
TCP	2.2.2.2:554	-> 1.1.1.3:58795	Watch	O	5
UDP	2.2.2.2:1028	-> 1.1.1.3:1028	Forward	O	6
UDP	2.2.2.2:1029	-> 1.1.1.3:1029	Forward	O	0
UDP	2.2.2.2:1030	-> 1.1.1.3:1030	Forward	O	3
UDP	2.2.2.2:1031	-> 1.1.1.3:1031	Forward	O	0

Analysis

An RTSP conversation should consist of TCP flows corresponding to the RTSP control connection. There should be two flows, one in each direction, from client to server and from server to client:

```

TCP          1.1.1.3:58795 ->      2.2.2.2:554  Watch    I          7
TCP          2.2.2.2:554  ->      1.1.1.3:58795 Watch    O          5

```

- The RTSP control connection for the initiator flow is sent from destination port 554.
- The RTSP control connection for the responder flow is sent from source port 554.

The UDP flows correspond to RTP media sent over the RTSP connection.

Troubleshooting Questions

1. Media does not work when the RTSP ALG is configured. What do I do?
 - Check RTSP conversations to see whether both TCP and UDP flows exist.
 - The ALG protocol should be displayed as `rtsp`.



NOTE: The state of the flow is displayed as **Watch**, because the ALG processing is taking place and the client is essentially “watching” or processing payload corresponding to the application. For FTP and RTSP ALG flows, the control connections are always **Watch** flows.

2. How do I check for ALG errors?

- You can check for errors by issuing the following command. Each ALG has a separate field for ALG packet errors.

```
user@host# show services stateful-firewall statistics extensive
```

```
Interface: sp-3/2/0
Service set: svc_set
New flows:
  Accepts: 1347, Discards: 0, Rejects: 0
Existing flows:
  Accepts: 144187, Discards: 0, Rejects: 0
Drops:
  IP option: 0, TCP SYN defense: 0
  NAT ports exhausted: 0
Errors:
  IP: 0, TCP: 276
  UDP: 0, ICMP: 0
  Non-IP packets: 0, ALG: 0
IP errors:
  IP packet length inconsistencies: 0
  Minimum IP header length check failures: 0
  Reassembled packet exceeds maximum IP length: 0
  Illegal source address: 0
  Illegal destination address: 0
  TTL zero errors: 0, Illegal IP protocol number (0 or 255): 0
  Land attack: 0
  Non-IPv4 packets: 0, Bad checksum: 0
  Illegal IP fragment length: 0
  IP fragment overlap: 0
  IP fragment reassembly timeout: 0
  Unknown: 0
TCP errors:
  TCP header length inconsistencies: 0
  Source or destination port number is zero: 0
  Illegal sequence number and flags combinations: 0
  SYN attack (multiple SYN messages seen for the same flow): 276
  First packet not a SYN message: 0
  TCP port scan (TCP handshake, RST seen from server for SYN): 0
  Bad SYN cookie response: 0
UDP errors:
  IP data length less than minimum UDP header length (8 bytes): 0
  Source or destination port number is zero: 0
  UDP port scan (ICMP error seen for UDP flow): 0
ICMP errors:
  IP data length less than minimum ICMP header length (8 bytes): 0
  ICMP error length inconsistencies: 0
  Duplicate ping sequence number: 0
  Mismatched ping sequence number: 0
ALG errors:
  BOOTP: 0, DCE-RPC: 0, DCE-RPC portmap: 0
  DNS: 0, Exec: 0, FTP: 0
  H323: 0, ICMP: 0, IIOP: 0
  Login: 0, NetBIOS: 0, NetShow: 0
  Real Audio: 0, RPC: 0, RPC portmap: 0
  RTSP: 0, Shell: 0, SIP: 0
  SNMP: 0, SQLNet: 0, TFTP: 0
  Traceroute: 0
```

System Log Messages

Enabling system log generation and checking the system log are also helpful for ALG flow analysis. This section contains the following:

- System Log Configuration on page 84
- System Log Output on page 85

System Log Configuration

You can configure the enabling of system log messages at a number of different levels in the JUNOS CLI. As shown in the following sample configurations, the choice of level depends on how specific you want the event logging to be and what options you want to include. For details on the configuration options, see the *JUNOS System Basics Configuration Guide* (system level) or the *JUNOS Services Interfaces Configuration Guide* (all other levels).

1. At the topmost global level:

```
user@host# show system syslog
file messages {
    any any;
}
```

2. At the AS PIC level:

```
user@host# show interfaces sp-3/2/0
services-options {
    syslog {
        host local {
            services any;
        }
    }
    open-timeout 3600;
    inactivity-timeout 3600;
}
unit 0 {
    family inet;
}
```

3. At the service set level:

```
user@host# show services service-set svc_set
syslog {
    host local {
        services any;
    }
}
stateful-firewall-rules allow_rtsp;
interface-service {
    service-interface sp-3/2/0;
}
```

4. At the service rule level:

```

user@host# show services stateful-firewall rule allow_rtsp
match-direction input-output;
term 0 {
  from {
    applications junos-rtsp;
  }
  then {
    accept;
    syslog;
  }
}

```

System Log Output

System log messages are generated during flow creation, as shown in the following examples:

The following system log message indicates that the ASP matched an accept rule:

```

Oct 25 16:11:37 (FPC Slot 3, PIC Slot 2) {svc_set}[FWNAT]: ASP_SFW_RULE_ACCEPT:
proto 6 (TCP) application: rtsp, ge-2/0/1.0:1.1.1.2:35595 -> 2.2.2.2:554, Match
SFW accept rule-set: , rule: allow_rtsp, term: 0

```

The following system log message indicates that the AS PIC created a valid flow:

```

Oct 25 16:11:37 (FPC Slot 3, PIC Slot 2) {svc_set}[FWNAT]:
ASP_SFW_CREATE_ACCEPT_FLOW: proto 6 (TCP) application: rtsp,
ge-2/0/1.0:1.1.1.2:35595 -> 2.2.2.2:554, creating forward or watch flow

```

The following system log message indicates that the packet did not match any rule on the AS PIC:

```

Oct 25 16:03:13 (FPC Slot 3, PIC Slot 2) {svc_set}[FWNAT]: ASP_SFW_NO_RULE_DROP:
proto 17 (UDP), ge-2/0/3.0:2.2.2.2:1334 -> 1.1.1.78:1334, No matching SFW rule

```

If the AS PIC does not create data flows and starts receiving data, this message is logged. It represents an error condition for ALG processing.

For a complete listing of system log messages, see the *JUNOS System Log Messages Reference*.

JUNOS Default Groups

The JUNOS software provides a default, hidden configuration group called **junos-defaults** that is automatically applied to the configuration of your routing platform. The **junos-defaults** group contains preconfigured statements that contain predefined values for common applications. Some of the statements must be referenced to take effect, such as applications like FTP or Telnet. Other statements are applied automatically, such as terminal settings. All of the preconfigured statements begin with the reserved name **junos-**.



NOTE: You can override the JUNOS default configuration values, but you cannot delete or edit them. If you delete a configuration, the defaults return when a new configuration is added.

You cannot use the **apply-groups** statement with the JUNOS defaults group.

To view the full set of available preset statements from the JUNOS default group, issue the **show groups junos-defaults** configuration mode command. The following example displays a partial list of JUNOS default groups that use application protocols (ALGs).

```
user@host# show groups junos-defaults
... output for other groups defined at the [edit groups junos-defaults] hierarchy level
...
applications {
  # File Transfer Protocol
  application junos-ftp {
    application-protocol ftp;
    protocol tcp;
    destination-port 21;
  }
  # Trivial File Transfer Protocol
  application junos-tftp {
    application-protocol tftp;
    protocol udp;
    destination-port 69;
  }
  # RPC port mapper on TCP
  application junos-rpc-portmap-tcp {
    application-protocol rpc-portmap;
    protocol tcp;
    destination-port 111;
  }
  # RPC port mapper on UDP
  application junos-rpc-portmap-udp {
    application-protocol rpc-portmap;
    protocol udp;
    destination-port 111;
  }
  # IP Protocol
  application junos-ip {
    application-protocol ip;
  }
  # remote exec
  application junos-rexec {
    application-protocol exec;
    protocol tcp;
    destination-port 512;
  }
  # remote login
  application junos-rlogin {
    application-protocol login;
    protocol tcp;
  }
}
```

```

        destination-port 513;
    }
    # remote shell
    application junos-rsh {
        application-protocol shell;
        protocol tcp;
        destination-port 514;
    }
    # Real-Time Streaming Protocol
    application junos-rtsp {
        application-protocol rtsp;
        protocol tcp;
        destination-port 554;
    }
    # Oracle SQL servers use this protocol to execute SQL commands
    # from clients, load balance, use application-specific servers, and so on.
    application junos-sqlnet {
        application-protocol sqlnet;
        protocol tcp;
        destination-port 1521;
    }
    # H.323 Protocol for audio/video conferencing
    application junos-h323 {
        application-protocol h323;
        protocol tcp;
        destination-port 1720;
    }
    # Internet Inter-ORB Protocol is used for CORBA applications.
    # The ORB protocol in Java virtual machine uses port 1975 as a default.
    application junos-iiop-java {
        application-protocol iiop;
        protocol tcp;
        destination-port 1975;
    }
    # Internet Inter-ORB Protocol is used for CORBA applications.
    # ORBIX is a CORBA framework from Iona Technologies that uses
    # port 3075 as a default.
    application junos-iiop-orbix {
        application-protocol iiop;
        protocol tcp;
        destination-port 3075;
    }
    # RealPlayer uses RealAudio for real-time streaming.
    # This was the original RealPlayer protocol.
    # RTSP is more widely used by RealPlayer,
    # but it still supports RealAudio.
    application junos-realaudio {
        application-protocol realaudio;
        protocol tcp;
        destination-port 7070;
    }
    # Traceroute application
    application junos-traceroute {
        application-protocol traceroute;
        protocol udp;
        destination-port 33435-33450;
    }

```

```

        ttl-threshold 30;
    }
    # Traceroute application that stops at device supporting firewall
    # (packets with ttl > 1 will be discarded).
    application junos-traceroute-ttl-1 {
        application-protocol traceroute;
        protocol udp;
        destination-port 33435-33450;
        ttl-threshold 1;
    }
    # The full range of known RPC programs using UDP.
    # Specific program numbers are assigned to certain applications.
    application junos-rpc-services-udp {
        application-protocol rpc;
        protocol udp;
        rpc-program-number 100001-400000;
    }
    # The full range of known RPC programs using TCP.
    # Specific program numbers are assigned to certain applications.
    application junos-rpc-services-tcp {
        application-protocol rpc;
        protocol tcp;
        rpc-program-number 100001-400000;
    }
    # All ICMP traffic
    # This can be made more restrictive by specifying ICMP type and code.
    application junos-icmp-all {
        application-protocol icmp;
    }
    # ICMP ping; the echo reply is allowed upon return.
    application junos-icmp-ping {
        application-protocol icmp;
        icmp-type echo-request;
    }
    # Protocol used by Windows Media Server and Windows Media Player
    application junos-netshow {
        application-protocol netshow;
        protocol tcp;
        destination-port 1755;
    }
    # NetBIOS, the networking protocol used on Windows networks;
    # includes name service port, both UDP and TCP.
    application junos-netbios-name-udp {
        application-protocol netbios;
        protocol udp;
        destination-port 137;
    }
    application junos-netbios-name-tcp {
        protocol tcp;
        destination-port 137;
    }
    # NetBIOS, the networking protocol used on Windows networks;
    # includes datagram service port.
    application junos-netbios-datagram {
        application-protocol netbios;
        protocol udp;
    }

```



```

        destination-port 138;
    }
    # NetBIOS, the networking protocol used on Windows networks;
    # includes session service port.
    application junos-netbios-session {
        protocol tcp;
        destination-port 139;
    }
    # DCE-RPC port mapper on TCP
    application junos-dce-rpc-portmap {
        application-protocol dce-rpc-portmap;
        protocol tcp;
        destination-port 135;
    }
    # MS Exchange requires these three UUID values.
    application junos-dcerpc-endpoint-mapper-service {
        application-protocol dce-rpc;
        protocol tcp;
        uuid e1af8308-5d1f-11c9-91a4-08002b14a0fa;
    }
    application junos-ssh {
        protocol tcp;
        destination-port 22;
    }
    application junos-telnet {
        protocol tcp;
        destination-port 23;
    }
    application junos-smtp {
        protocol tcp;
        destination-port 25;
    }
    application junos-dns-udp {
        protocol udp;
        destination-port 53;
    }
    application junos-dns-tcp {
        protocol tcp;
        destination-port 53;
    }
    application junos-tacacs {
        protocol tcp;
        destination-port 49;
    }
    # TACACS Database Service
    application junos-tacacs-ds {
        protocol tcp;
        destination-port 65;
    }
    application junos-dhcp-client {
        protocol udp;
        destination-port 68;
    }
    application junos-dhcp-server {
        protocol udp;
        destination-port 67;
    }

```

```

}
application junos-bootpc {
    protocol udp;
    destination-port 68;
}
application junos-bootps {
    protocol udp;
    destination-port 67;
}
application junos-http {
    protocol tcp;
    destination-port 80;
}
application junos-https {
    protocol tcp;
    destination-port 443;
}
# SIP control session for VoIP
application junos-sip {
    application-protocol sip;
    protocol udp;
    destination-port 5060;
    learn-sip-register;
}
# " junos-algs-outbound" defines a set of all applications
# requiring an ALG. Useful for defining a rule for an untrusted
# network to allow trusted network users to use all the
# JUNOS-supported ALGs initiated from the trusted network.
application-set junos-algs-outbound {
    application junos-ftp;
    application junos-tftp;
    application junos-rpc-portmap-tcp;
    application junos-rpc-portmap-udp;
    application junos-snmp-get;
    application junos-snmp-get-next;
    application junos-snmp-response;
    application junos-snmp-trap;
    application junos-rexec;
    application junos-rlogin;
    application junos-rsh;
    application junos-rtsp;
    application junos-citrix-winfile;
    application junos-citrix-winfile-udp;
    application junos-sqlnet;
    application junos-h323;
    application junos-iiop-java;
    application junos-iiop-orbix;
    application junos-realaudio;
    application junos-traceroute;
    application junos-rpc-services-udp;
    application junos-rpc-services-tcp;
    application junos-icmp-all;
    application junos-netshow;
    application junos-netbios-name-udp;
    application junos-netbios-datagram;
    application junos-dce-rpc-portmap;

```

```

    application junos-dcerpc-msexchange-directory-rfr;
    application junos-dcerpc-msexchange-information-store;
    application junos-dcerpc-msexchange-directory-nsp;
    application junos-sip;
}
# "junos-management-inbound" represents the group of applications
# that might need access to the trusted network from the untrusted
# network for management purposes.
# The set is intended for a UI to display management choices.
# NOTE: It is not recommended that you use the entire set directly in
# a firewall rule and open up firewall to all of these
# applications. Also, you should always specify the source
# and destination prefixes when using each application.
application-set junos-management-inbound {
    application junos-snmp-get;
    application junos-snmp-get-next;
    application junos-snmp-response;
    application junos-snmp-trap;
    application junos-ssh;
    application junos-telnet;
    application junos-http;
    application junos-https;
    application junos-xnm-ssl;
    application junos-xnm-clear-text;
    application junos-icmp-ping;
    application junos-traceroute-ttl-1;
}
}
}
}

```

To reference statements available from the `junos-defaults` group, include the selected `junos-default-name` statement at the applicable hierarchy level. To configure application protocols, see “Configuring an Application Protocol” on page 60; for details about a specific protocol, see “ALG Descriptions” on page 70.

Examples: Referencing the Preset Statement from the JUNOS Default Group

The following example is a preset statement from the JUNOS default groups that is available for FTP in a stateful firewall:

```

[edit]
groups {
  junos-defaults {
    applications {
      application junos-ftp { # Use FTP default configuration
        application-protocol ftp;
        protocol tcp;
        destination-port 21;
      }
    }
  }
}

```

To reference a preset JUNOS default statement from the JUNOS default groups, include the `junos-default-name` statement at the applicable hierarchy level. For example,

to reference the JUNOS default statement for FTP in a stateful firewall, include the `junos-ftp` statement at the `[edit services stateful-firewall rule rule-name term term-name from applications]` hierarchy level.

```
[edit]
services {
  stateful-firewall {
    rule my-rule {
      term my-term {
        from {
          applications junos-ftp; #Reference predefined statement, junos-ftp,
        }
      }
    }
  }
}
```

The following example shows configuration of the default JUNOS IP ALG:

```
[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          applications junos-ip;
        }
        then {
          accept;
          syslog;
        }
      }
    }
  }
}
```

If you configure the IP ALG in the stateful firewall rule, it is matched by any IP traffic, but if there is any other more specific application that matches the same traffic, the IP ALG will not be matched. For example, in the following configuration, both the ICMP ALG and the IP ALG are configured, but traffic is matched for ICMP packets, because it is the more specific match.

```
[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          applications [ junos-ip junos-icmp-all ];
        }
        then {
          accept;
          syslog;
        }
      }
    }
  }
}
```

```

    }
  }
}

```

Examples: Configuring Application Protocols

The following example shows an application protocol definition describing a special FTP application running on port 78:

```

[edit applications]
application my-ftp-app {
  application-protocol ftp;
  protocol tcp;
  destination-port 78;
  timeout 100; # inactivity timeout for FTP service
}

```

The following example shows a special ICMP protocol (`application-protocol icmp`) of type 8 (ICMP echo):

```

[edit applications]
application icmp-app {
  application-protocol icmp;
  protocol icmp;
  icmp-type icmp-echo;
}

```

The following example shows a possible application set:

```

[edit applications]
application-set basic {
  http;
  ftp;
  telnet;
  nfs;
  icmp;
}

```

The software includes a predefined set of well-known application protocols. The set includes applications for which the TCP and UDP destination ports are already recognized by stateless firewall filters.

The following example shows a complete configuration for SIP and its related statements:

```

[edit]
applications {
  application sip {
    application-protocol sip;
    protocol udp;
    destination-port 5060;
    inactivity-timeout 300;
    learn-sip-register;
  }
}

```

```

}
interfaces {
  sp-0/2/0 {
    services-options {
      syslog {
        host local {
          services any;
        }
      }
    }
    unit 0 {
      family inet;
    }
  }
  ge-1/0/0 {
    description amazon_eth2;
    unit 0 {
      family inet {
        service {
          input {
            service-set test_sip;
          }
          output {
            service-set test_sip;
          }
        }
      }
      address 10.200.1.1/30;
    }
  }
  ge-1/1/0 {
    description maxtor_eth1;
    unit 0 {
      family inet {
        address 10.100.1.1/30;
      }
    }
  }
}
services {
  stateful-firewall {
    rule sip {
      match-direction input-output;
      term 0 {
        from {
          applications sip;
        }
        then {
          accept;
        }
      }
    }
  }
}
ids {
  rule ids {
    match-direction input-output;
  }
}

```

```
term 0 {  
  then {  
    force-entry;  
    logging {  
      threshold 1;  
      syslog;  
    }  
  }  
}  
}  
}  
}  
service-set test_sip {  
  syslog {  
    host local {  
      services any;  
    }  
  }  
  stateful-firewall-rules sip;  
  ids-rules ids;  
  interface-service {  
    service-interface sp-0/2/0;  
  }  
}  
}
```


Chapter 5

Summary of Applications Configuration Statements

The following sections explain each of the applications configuration statements. The statements are organized alphabetically.

application

Syntax application *application-name* {
 application-protocol *protocol-name*;
 destination-port *port-number*;
 icmp-code *value*;
 icmp-type *value*;
 inactivity-timeout *value*;
 learn-sip-register;
 protocol *type*;
 rpc-program-number *number*;
 sip-call-hold-timeout *seconds*;
 snmp-command *command*;
 source-port *port-number*;
 ttl-threshold *number*;
 uuid *hex-value*;
 }

Hierarchy Level [edit applications],
 [edit applications application-set *application-set-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure properties of an application and whether to include it in an application set.

Options *application-name*—Identifier of the application.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Application Protocol Properties” on page 60.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

application-protocol

Syntax	<code>application-protocol <i>protocol-name</i>;</code>
Hierarchy Level	<code>[edit applications application <i>application-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4. <code>login</code> and <code>sip</code> options introduced in JUNOS Release 7.4. <code>ip</code> option introduced in JUNOS Release 8.2.
Description	Identify the application protocol name. Application protocols are also called application layer gateways (ALGs).
Options	<p><i>protocol-name</i>—Name of the protocol. The following protocols are supported:</p> <ul style="list-style-type: none"> <code>bootp</code> <code>dce-rpc</code> <code>dce-rpc-portmap</code> <code>dns</code> <code>exec</code> <code>ftp</code> <code>h323</code> <code>icmp</code> <code>iiop</code> <code>ip</code> <code>login</code> <code>netbios</code> <code>netshow</code> <code>realaudio</code> <code>rpc</code> <code>rpc-portmap</code> <code>rtsp</code> <code>shell</code> <code>sip</code> <code>snmp</code> <code>sqlnet</code> <code>tftp</code> <code>traceroute</code> <code>winframe</code>

Usage Guidelines See “Configuring an Application Protocol” on page 60.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

application-set

Syntax `application-set application-set-name {
 application application-name;
}`

Hierarchy Level [edit applications]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure one or more applications to include in an application set.

Options *application-set-name*—Identifier of an application set.

Usage Guidelines See “Configuring Application Sets” on page 70.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

applications

Syntax `applications { ... }`

Hierarchy Level [edit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the applications used in services.

Usage Guidelines See “Applications Configuration Guidelines” on page 59.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

destination-port

Syntax	<code>destination-port <i>port-value</i>;</code>
Hierarchy Level	<code>[edit applications application <i>application-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Transmission Control Protocol (TCP) or User Datagram Protocol (UDP) destination port number.
Options	<i>port-value</i> —Identifier for the port. For a complete list, see “Configuring Source and Destination Ports” on page 65.
Usage Guidelines	See “Configuring Source and Destination Ports” on page 65.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

icmp-code

Syntax	<code>icmp-code <i>value</i>;</code>
Hierarchy Level	<code>[edit applications application <i>application-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Internet Control Message Protocol (ICMP) code value.
Options	<i>value</i> —The ICMP code value. For a complete list, see “Configuring the ICMP Code and Type” on page 63.
Usage Guidelines	See “Configuring the ICMP Code and Type” on page 63.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

icmp-type

Syntax	icmp-type <i>value</i> ;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	ICMP packet type value.
Options	<i>value</i> —The ICMP type value, such as echo or echo-reply . For a complete list, see “Configuring the ICMP Code and Type” on page 63.
Usage Guidelines	See “Configuring the ICMP Code and Type” on page 63.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

inactivity-timeout

Syntax	inactivity-timeout <i>seconds</i> ;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Inactivity timeout period, in seconds.
Options	<i>seconds</i> —Length of time the application is inactive before it times out. Default: 60 seconds
Usage Guidelines	See “Configuring the Inactivity Timeout Period” on page 68.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

learn-sip-register

Syntax	learn-sip-register;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Activate SIP register to accept potential incoming SIP calls.
Usage Guidelines	See “Configuring SIP” on page 68.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

protocol

Syntax protocol *type*;

Hierarchy Level [edit applications application *application-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Networking protocol type or number.

Options *type*—Networking protocol type. The following text values are supported:

ah
egp
esp
gre
icmp
igmp
ipip
ospf
pim
rsvp
tcp
udp
vrrp



NOTE: IP version 6 (IPv6) is not supported as a network protocol in application definitions.

Usage Guidelines See “Configuring the Network Protocol” on page 62.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rpc-program-number

Syntax	rpc-program-number <i>number</i> ;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Remote procedure call (RPC) or Distributed Computing Environment (DCE) value.
Options	<i>number</i> —RPC or DCE program value. Range: 100,000 through 400,000
Usage Guidelines	See “Configuring an RPC Program Number” on page 69.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

sip-call-hold-timeout

Syntax	sip-call-hold-timeout <i>seconds</i> ;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Timeout period for SIP calls placed on hold, in seconds.
Options	<i>seconds</i> —Length of time the application holds a SIP call open before it times out. Default: 7200 seconds Range: 0 through 36,000 seconds (10 hours)
Usage Guidelines	See “Configuring SIP” on page 68.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

snmp-command

Syntax	snmp-command <i>command</i> ;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	SNMP command format.
Options	<i>command</i> —Supported commands are SNMP <i>get</i> , <i>get-next</i> , <i>set</i> , and <i>trap</i> .
Usage Guidelines	See “Configuring an SNMP Command for Packet Matching” on page 69.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-port

Syntax	source-port <i>port-number</i> ;
Hierarchy Level	[edit applications application <i>application-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Source port identifier.
Options	<i>port-value</i> —Identifier for the port. For a complete list, see “Configuring Source and Destination Ports” on page 65.
Usage Guidelines	See “Configuring Source and Destination Ports” on page 65.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ttl-threshold

Syntax	<code>ttl-threshold <i>number</i>;</code>
Hierarchy Level	<code>[edit applications application <i>application-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the traceroute time-to-live (TTL) threshold value. This value sets the acceptable level of network penetration for trace routing.
Options	<i>number</i> —TTL threshold value.
Usage Guidelines	See “Configuring the TTL Threshold” on page 69.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

uuid

Syntax	<code>uuid <i>hex-value</i>;</code>
Hierarchy Level	<code>[edit applications application <i>application-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the Universal Unique Identifier (UUID) for DCE RPC objects.
Options	<i>hex-value</i> —Hexadecimal value.
Usage Guidelines	See “Configuring a Universal Unique Identifier” on page 70.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 6

Stateful Firewall Services Configuration Guidelines

To configure stateful firewall services, include the `stateful-firewall` statement at the `[edit services]` hierarchy level:

```
[edit services]
stateful-firewall {
  rule rule-name {
    match-direction (input | output | input-output);
    term term-name {
      from {
        application-sets set-name;
        applications [ application-names ];
        destination-address (address | any-unicast) <except>;
        destination-address-range low minimum-value high maximum-value <except>;
        destination-prefix-list list-name <except>;
        source-address (address | any-unicast) <except>;
        source-address-range low minimum-value high maximum-value <except>;
        source-prefix-list list-name <except>;
      }
      then {
        (accept | discard | reject);
        allow-ip-options [ values ];
        syslog;
      }
    }
  }
  rule-set rule-set-name {
    [ rule rule-names ];
  }
}
```

This chapter contains the following sections:

- Configuring Stateful Firewall Rules on page 108
- Configuring Stateful Firewall Rule Sets on page 112
- Examples: Configuring Stateful Firewall Rules on page 112

Configuring Stateful Firewall Rules

To configure a stateful firewall rule, include the `rule rule-name` statement at the `[edit services stateful-firewall]` hierarchy level:

```
[edit services stateful-firewall]
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address address <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      destination-prefix-list list-name <except>;
      source-address address <except>;
      source-address-range low minimum-value high maximum-value <except>;
      source-prefix-list list-name <except>;
    }
    then {
      (accept | discard | reject);
      allow-ip-options [ values ];
      syslog;
    }
  }
}
```

Each stateful firewall rule consists of a set of terms, similar to a filter configured at the `[edit firewall]` hierarchy level. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software.

The following sections explain how to configure the components of stateful firewall rules:

- Configuring Match Direction for Stateful Firewall Rules on page 108
- Configuring Match Conditions in Stateful Firewall Rules on page 109
- Configuring Actions in Stateful Firewall Rules on page 110

Configuring Match Direction for Stateful Firewall Rules

Each rule must include a `match-direction` statement that specifies the direction in which the rule match is applied. To configure where the match is applied, include the `match-direction` statement at the `[edit services stateful-firewall rule rule-name]` hierarchy level:

```
[edit services stateful-firewall rule rule-name]
match-direction (input | output | input-output);
```

If you configure **match-direction input-output**, bidirectional rule creation is allowed.

The match direction is used with respect to the traffic flow through the AS or MultiServices PIC. When a packet is sent to the PIC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the AS or MultiServices PIC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the PIC, the packet direction is output. For more information on inside and outside interfaces, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

On the PIC, a flow lookup is performed. If no flow is found, rule processing is performed. All rules in the service set are considered. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that matches the packet direction are considered.

Configuring Match Conditions in Stateful Firewall Rules

To configure stateful firewall match conditions, include the **from** statement at the [edit services stateful-firewall rule *rule-name* term *term-name*] hierarchy level:

```
[edit services stateful-firewall rule rule-name term term-name]
from {
  application-sets set-name;
  applications [ application-names ];
  destination-address (address | any-unicast) <except>;
  destination-address-range low minimum-value high maximum-value <except>;
  destination-prefix-list list-name <except>;
  source-address (address | any-unicast) <except>;
  source-address-range low minimum-value high maximum-value <except>;
  source-prefix-list list-name <except>;
}
```

The source address and destination address can be either IPv4 or IPv6. You can use either the source address or the destination address as a match condition, in the same way that you would configure a firewall filter; for more information, see the *JUNOS Policy Framework Configuration Guide*. You can use the wildcard value **any-unicast**, which denotes matching all unicast addresses.

Alternatively, you can specify a list of source or destination prefixes by configuring the **prefix-list** statement at the [edit policy-options] hierarchy level and then including either the **destination-prefix-list** or the **source-prefix-list** statement in the stateful firewall rule. For an example, see “Examples: Configuring Stateful Firewall Rules” on page 112.

If you omit the **from** term, the stateful firewall accepts all traffic and the default protocol handlers take effect:

- User Datagram Protocol (UDP), Transmission Control Protocol (TCP), and Internet Control Message Protocol (ICMP) create a bidirectional flow with a predicted reverse flow.
- IP creates a unidirectional flow.

You can also include application protocol definitions you have configured at the **[edit applications]** hierarchy level; for more information, see “Applications Configuration Guidelines” on page 59.

- To apply one or more specific application protocol definitions, include the **applications** statement at the **[edit services stateful-firewall rule *rule-name* term *term-name* from]** hierarchy level.
- To apply one or more sets of application protocol definitions you have defined, include the **application-sets** statement at the **[edit services stateful-firewall rule *rule-name* term *term-name* from]** hierarchy level.



NOTE: If you include one of the statements that specifies application protocols, the router derives port and protocol information from the corresponding configuration at the **[edit applications]** hierarchy level; you cannot specify these properties as match conditions.

Configuring Actions in Stateful Firewall Rules

To configure stateful firewall actions, include the **then** statement at the **[edit services stateful-firewall rule *rule-name* term *term-name*]** hierarchy level:

```
[edit services stateful-firewall rule rule-name term term-name]
then {
  (accept | discard | reject);
  allow-ip-options [ values ];
  syslog;
}
```

You must include one of the following three possible actions:

- **accept**—The packet is accepted and sent on to its destination.
- **discard**—The packet is not accepted and is not processed further.
- **reject**—The packet is not accepted and a rejection message is returned; UDP sends an ICMP unreachable code and TCP sends RST. Rejected packets can be logged or sampled.

You can optionally configure the firewall to record information in the system logging facility by including the **syslog** statement at the **[edit services stateful-firewall rule *rule-name* term *term-name* then]** hierarchy level. This statement overrides any **syslog** setting included in the service set or interface default configuration.

Configuring IP Option Handling

You can optionally configure the firewall to inspect IP header information by including the `allow-ip-options` statement at the `[edit services stateful-firewall rule rule-name term term-name then]` hierarchy level. When you configure this statement, all packets that match the criteria specified in the `from` statement are subjected to additional matching criteria. A packet is accepted only when all of its IP option types are configured as values in the `allow-ip-options` statement. If you do not configure `allow-ip-options`, only packets without IP header options are accepted.

The additional IP header option inspection applies only to the `accept` and `reject` stateful firewall actions. This configuration has no effect on the `discard` action. When the IP header inspection fails, reject frames are not sent; in this case, the `reject` action has the same effect as `discard`.

If an IP option packet is accepted by the stateful firewall, Network Address Translation (NAT) and intrusion detection service (IDS) are applied in the same way as to packets without IP option headers. The IP option configuration appears only in the stateful firewall rules; NAT applies to packets with or without IP options.

When a packet is dropped because it fails the IP option inspection, this exception event generates both IDS event and system log messages. The event type depends on the first IP option field rejected.

Table 11 on page 111 lists the possible values for the `allow-ip-options` statement. You can include a range or set of numeric values, or one or more of the predefined IP option settings. You can enter either the option name or its numeric equivalent. For more information, refer to <http://www.iana.org/assignments/ip-parameters>.

Table 11: IP Option Values

IP Option Name	Numeric Value	Comment
any	0	Any IP option
ip-security	130	–
ip-stream	136	–
loose-source-route	131	–
route-record	7	–
router-alert	148	–
strict-source-route	137	–
timestamp	68	–

Configuring Stateful Firewall Rule Sets

The `rule-set` statement defines a collection of stateful firewall rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the `rule-set` statement at the `[edit services stateful-firewall]` hierarchy level with a `rule` statement for each rule:

```
[edit services stateful-firewall]
rule-set rule-set-name {
    rule rule-name;
}
```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

Examples: Configuring Stateful Firewall Rules

The following example show a stateful firewall configuration containing two rules, one for input matching on a specified application set and the other for output matching on a specified source address:

```
[edit services]
stateful-firewall {
    rule Rule1 {
        match-direction input;
        term 1 {
            from {
                application-sets Applications;
            }
            then {
                accept;
            }
        }
        term accept {
            then {
                accept;
            }
        }
    }
    rule Rule2 {
        match-direction output;
        term Local {
            from {
                source-address {
                    10.1.3.2/32;
                }
            }
            then {
```



```

        accept;
    }
}
}

```

The following example has a single rule with two terms. The first term rejects all traffic in `my-application-group` that originates from the specified source address, and provides a detailed system log record of the rejected packets. The second term accepts Hypertext Transfer Protocol (HTTP) traffic from anyone to the specified destination address.

```

[edit services stateful-firewall]
rule my-firewall-rule {
  match-direction input-output;
  term term1 {
    from {
      source-address 10.1.3.2/32;
      application-sets my-application-group;
    }
    then {
      reject;
      syslog;
    }
  }
  term term2 {
    from {
      destination-address 10.2.3.2;
      applications http;
    }
    then {
      accept;
    }
  }
}

```

The following example shows use of source and destination prefix lists. This requires two separate configuration items.

You configure the prefix list at the `[edit policy-options]` hierarchy level:

```

[edit]
policy-options {
  prefix-list p1 {
    1.1.1.1/32;
    2.2.2.0/24;
  }
  prefix-list p2 {
    3.3.3.3/32;
    4.4.4.0/24;
  }
}

```

You reference the configured prefix list in the stateful firewall rule:

```

[edit]

```

```

services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          source-prefix-list {
            p1;
          }
          destination-prefix-list {
            p2;
          }
        }
        then {
          accept;
        }
      }
    }
  }
}

```

This is equivalent to the following configuration:

```

[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          source-address {
            1.1.1.1/32;
            2.2.2.0/24;
          }
          destination-address {
            3.3.3.3/32;
            4.4.4.0/24;
          }
        }
        then {
          accept;
        }
      }
    }
  }
}

```

You can use the **except** qualifier with the prefix lists, as in the following example. In this case, the **except** qualifier applies to all prefixes included in prefix list **p2**.

```

[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {

```

```

from {
    source-prefix-list {
        p1;
    }
    destination-prefix-list {
        p2 except;
    }
}
then {
    accept;
}
}
}
}
}
}

```

For additional examples that combine stateful firewall configuration with other services and with virtual private network (VPN) routing and forwarding (VRF) tables, see “Examples: Services Interfaces Configuration” on page 49.

Chapter 7

Summary of Stateful Firewall Configuration Statements

The following sections explain each of the stateful firewall services statements. The statements are organized alphabetically.

allow-ip-options

- Syntax** `allow-ip-options [values];`
- Hierarchy Level** [edit services stateful-firewall rule *rule-name* term *term-name* then]
- Release Information** Statement introduced before JUNOS Release 7.4.
- Description** Configure how the stateful firewall handles IP header information. This statement is optional.
- Options** *value*—Can be a set or range of numeric values, or one or more of the following predefined option types. You can enter either the option name or its numeric equivalent.

Option Name	Numeric Value
any	0
ip-security	130
ip-stream	8
loose-source-route	3
route-record	7
router-alert	148
strict-source-route	9
timestamp	4

- Usage Guidelines** See “Configuring Actions in Stateful Firewall Rules” on page 110.
- Required Privilege Level** interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

application-sets

Syntax	<code>applications-sets <i>set-name</i>;</code>
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more target application sets.
Options	<i>set-name</i> —Name of the target application set.
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

applications

Syntax	<code>applications [<i>application-names</i>];</code>
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more applications to which the stateful firewall services apply.
Options	<i>application-name</i> —Name of the target application.
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address

Syntax	destination-address (<i>address</i> any-unicast) <except>;
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4. any-unicast and except options introduced in JUNOS Release 7.6. address option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address for rule matching.
Options	<p>address—Destination IPv4 or IPv6 address or prefix value.</p> <p>any-unicast—Match all unicast packets.</p> <p>except—(Optional) Exclude the specified address, prefix, or unicast packets from rule matching.</p>
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

destination-address-range

Syntax	destination-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.6. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address range for rule matching.
Options	<p><i>minimum-value</i>—Lower boundary for the IPv4 or IPv6 address range.</p> <p><i>maximum-value</i>—Upper boundary for the IPv4 or IPv6 address range.</p> <p>except—(Optional) Exclude the specified address range from rule matching.</p>
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

destination-prefix-list

Syntax	<code>destination-prefix-list <i>list-name</i> <except>;</code>
Hierarchy Level	<code>[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]</code>
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the destination prefix list for rule matching. You configure the prefix list by including the <code>prefix-list</code> statement at the <code>[edit policy-options]</code> hierarchy level.
Options	<p><i>list-name</i>—Destination prefix list.</p> <p><code>except</code>—(Optional) Exclude the specified prefix list from rule matching.</p>
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

from

Syntax	<pre>from { application-sets <i>set-name</i>; applications [<i>application-names</i>]; destination-address (<i>address</i> any-unicast) <except>; destination-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>; destination-prefix-list <i>list-name</i> <except>; source-address (<i>address</i> any-unicast) <except>; source-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>; source-prefix-list <i>list-name</i> <except>; }</pre>
Hierarchy Level	<code>[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify input conditions for a stateful firewall term.
Options	<p>For information on match conditions, see the description of firewall filter match conditions in the <i>JUNOS Policy Framework Configuration Guide</i>.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Stateful Firewall Rules” on page 108.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

match-direction

Syntax	match-direction (input output input-output);
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the direction in which the rule match is applied.
Options	<p>input—Apply the rule match on the input side of the interface.</p> <p>output—Apply the rule match on the output side of the interface.</p> <p>input-output—Apply the rule match bidirectionally.</p>
Usage Guidelines	See “Configuring Stateful Firewall Rules” on page 108.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

rule

Syntax

```
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address (address | any-unicast) <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      destination-prefix-list list-name <except>;
      source-address (address | any-unicast) <except>;
      source-address-range low minimum-value high maximum-value <except>;
      source-prefix-list list-name <except>;
    }
    then {
      (accept | discard | reject);
      syslog;
    }
  }
}
```

Hierarchy Level [edit services stateful-firewall],
[edit services stateful-firewall rule-set *rule-set-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the rule the router uses when applying this service.

Options *rule-name*—Identifier for the collection of terms that constitute this rule.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Stateful Firewall Rules” on page 108.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rule-set

Syntax	<code>rule-set <i>rule-set-name</i> { [rule <i>rule-names</i>]; }</code>
Hierarchy Level	[edit services stateful-firewall]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the rule set the router uses when applying this service.
Options	<i>rule-set-name</i> —Identifier for the collection of rules that constitute this rule set.
Usage Guidelines	See “Configuring Stateful Firewall Rule Sets” on page 112.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	<code>services stateful-firewall { ... }</code>
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the service rules to be applied to traffic.
Options	<i>stateful-firewall</i> —Identifies the stateful firewall set of rules statements.
Usage Guidelines	See “Stateful Firewall Services Configuration Guidelines” on page 107.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address

Syntax	source-address (<i>address</i> any-unicast) <except>;
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4. any-unicast and except options introduced in JUNOS Release 7.6. address option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Source address for rule matching.
Options	address—Source IPv4 or IPv6 address or prefix value. any-unicast—Any unicast packet. except—(Optional) Exclude the specified address, prefix, or unicast packets from rule matching.
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address-range

Syntax	source-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.6. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Source address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range. except—(Optional) Exclude the specified address, prefix, or unicast packets from rule matching.
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix-list

Syntax	source-prefix-list <i>list-name</i> <except>;
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the source prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Destination prefix list. except—(Optional) Exclude the specified prefix list from rule matching.
Usage Guidelines	See “Configuring Match Conditions in Stateful Firewall Rules” on page 109.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

syslog

Syntax	syslog;
Hierarchy Level	[edit services stateful-firewall rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable system logging. The system log information from the Adaptive Services or MultiServices PIC is passed to the kernel for logging in the /var/log directory. This setting overrides any syslog statement setting included in the service set or interface default configuration.
Usage Guidelines	See “Configuring Actions in Stateful Firewall Rules” on page 110.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

term

Syntax `term term-name {`
 `from {`
 `application-sets set-name;`
 `applications [application-names];`
 `destination-address (address | any-unicast) <except>;`
 `destination-address-range low minimum-value high maximum-value <except>;`
 `destination-prefix-list list-name <except>;`
 `source-address (address | any-unicast) <except>;`
 `source-address-range low minimum-value high maximum-value <except>;`
 `source-prefix-list list-name <except>;`
 `}`
 `then {`
 `(accept | discard | reject);`
 `syslog;`
 `}`
 `}`

Hierarchy Level [edit services stateful-firewall rule *rule-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the stateful firewall term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Stateful Firewall Rules” on page 108.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

then

Syntax then {
 (accept | discard | reject);
 syslog;
 }

Hierarchy Level [edit services stateful-firewall rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the stateful firewall term actions. You can configure the router to accept, discard, or reject the targeted traffic. The other actions are optional.

Options accept—Accept the traffic and send it on to its destination.

 discard—Do not accept traffic or process it further.

 reject—Do not accept the traffic and return a rejection message. Rejected traffic can be logged or sampled.

 The remaining statement is explained separately.

Usage Guidelines See “Configuring Actions in Stateful Firewall Rules” on page 110.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Policy Framework Configuration Guide*

Chapter 8

Network Address Translation Services Configuration Guidelines

To configure Network Address Translation (NAT) services, include the `nat` statement at the [edit services] hierarchy level:

```
[edit services]
nat {
  ipv6-multicast-interfaces (all | interface-name) {
    disable;
  }
  pool nat-pool-name {
    address ip-prefix</prefix-length>;
    address-range low minimum-value high maximum-value;
    pgcp {
      hint [ hint-strings ];
      ports-per-session ports;
      remotely-controlled;
      transport [ transport-protocols ];
    }
    port (automatic | range low value high value) {
      random-allocation;
    }
  }
  rule rule-name {
    match-direction (input | output);
    term term-name {
      nat-type (full-cone | symmetric);
      from {
        application-sets set-name;
        applications [ application-names ];
        destination-address (address | any-unicast) <except>;
        destination-address-range low minimum-value high maximum-value <except>;
        destination-prefix-list list-name <except>;
        source-address (address | any-unicast) <except>;
        source-address-range low minimum-value high maximum-value <except>;
        source-prefix-list list-name <except>;
      }
      then {
        no-translation;
        translated {
          destination-pool nat-pool-name;
          destination-prefix destination-prefix;
        }
      }
    }
  }
}
```

```

        overload-pool overload-pool-name;
        overload-prefix overload-prefix;
        source-pool nat-pool-name;
        source-prefix source-prefix;
        translation-type (destination type | source type);
        translation-type {
            source type;
            destination type;
        }
    }
    syslog;
}
}
}
rule-set rule-set-name {
    [ rule rule-names ];
}
}

```

This chapter includes the following sections:

- Configuring Addresses and Ports for Use in NAT Rules on page 130
- Configuring NAT Rules on page 133
- Configuring NAT Rule Sets on page 139
- Examples: Configuring NAT Rules on page 139

Configuring Addresses and Ports for Use in NAT Rules

For information about configuring translated addresses, see the following sections:

- Configuring Pools of Addresses and Ports on page 130
- Specifying Destination and Source Prefixes when Pools Are Not Used on page 132
- Requirements for NAT Addresses on page 132
- Configuring IPv6 Multicast Filters on page 133

Configuring Pools of Addresses and Ports

You can use the **pool** statement to define the addresses (or prefixes), address ranges, and ports used for network address translation. You can also use the **pgcp** option with the **pool** statement to specify that NAT pool is used exclusively by the BGF. To configure the information, include the **pool** statement at the **[edit services nat]** hierarchy level:

```

[edit services nat]
pool nat-pool-name {
    address ip-prefix</prefix-length>;
    address-range low minimum-value high maximum-value;
    pgcp;
    port (automatic | range low minimum-value high maximum-value) {
        random-allocation;
    }
}

```

```
}
```

To configure pools for traditional NAT, specify either a destination pool or a source pool. To configure pools for twice NAT, specify both the destination pool and the source pool.

With static source NAT and dynamic source NAT, you can specify multiple IPv4 or IPv6 addresses (or prefixes) and IPv4 and IPv6 address ranges. Up to 10 prefixes or address ranges (or a combination) can be supported within a single pool.

With static destination NAT, you can also specify multiple address prefixes and address ranges in a single term. Multiple destination NAT terms can share a destination NAT pool. However, the netmask or range for the **from** address must be smaller or equal to the netmask or range for the destination pool address. If you define the pool to be larger than required, some addresses will not be used. For example, if you define the pool size as 100 addresses and the rule specifies only 80 addresses, the last 20 addresses in the pool are not used.

For constraints on specific translation types, see “Configuring Actions in NAT Rules” on page 137.

With source static NAT, the prefixes and address ranges cannot overlap between separate pools. However, source dynamic NAT (without NAPT) and destination static NAT allow more than one rule or service set to refer to the same pool, and allow multiple pools to have subnets that can overlap. A prefix pool can be used by multiple rules or terms.



NOTE: When you configure address pools for NAT and user access, these address pools can overlap with one another. To configure overlapping address pools, include the **address** or **address-range** statement at the `[edit access address-pool pool-name]` and `[edit services nat pool pool-name]` hierarchy level.

In an address range, the **low** value must be a lower number than the **high** value. When multiple address ranges and prefixes are configured, the prefixes are depleted first, followed by the address ranges.

When you specify a port for dynamic source NAT, address ranges are limited to a maximum of 32 addresses, for a total of approximately 2,000 flows. A dynamic NAT pool with no address port translation supports up to 65,535 addresses. There is no limit on the pool size for static source NAT.

The **port** statement specifies port assignment for the translated addresses. To configure automatic assignment of ports, include the **port automatic** statement at the `[edit services nat pool nat-pool-name]` hierarchy level. To configure a specific range of port numbers, include the **port range low *minimum-value* high *maximum-value*** statement at the `[edit services nat pool nat-pool-name]` hierarchy level. By default, the JUNOS software allocates NAT ports sequentially. To configure random port allocation, include the **random-allocation** statement.

Specifying Destination and Source Prefixes when Pools Are Not Used

You can directly specify the destination or source prefix used in network address translation without configuring a pool. When you configure prefixes for twice NAT, you must specify both a destination prefix and a source prefix.

To configure the information, include the `rule` statement at the `[edit services nat]` hierarchy level:

```
[edit services nat]
rule rule-name {
  term term-name {
    then {
      translated {
        destination-prefix prefix;
        source-prefix prefix;
      }
    }
  }
}
```

Requirements for NAT Addresses

You must configure a specific address, a prefix, or the address-range boundaries:

- If you specify a specific address or prefix, it is assumed the translated address belongs to the `inet.0` routing instance. The following addresses, while valid in `inet.0`, cannot be used for NAT translation:
 - 0.0.0.0/32
 - 127.0.0.0/8 (loopback)
 - 128.0.0.0/16 (martian)
 - 191.255.0.0/16 (martian)
 - 192.0.0.0/24 (martian)
 - 223.255.255.0/24 (martian)
 - 224.0.0.0/4 (multicast)
 - 240.0.0.0/4 (reserved)
 - 255.255.255.255 (broadcast)
- You can specify one or more IPv4 or IPv6 address prefixes in the `pool` statement and in the `from` clause of the NAT rule term. This enables you to configure source translation from a private subnet to a public subnet without defining a rule term for each address in the subnet. Destination translation cannot be configured by this method. For examples, see “Examples: Configuring NAT Rules” on page 139.
- When you configure static source NAT, the `address` prefix size you configure at the `[edit services nat pool pool-name]` hierarchy level must be larger than the

`source-address` prefix range configured at the [edit services nat rule *rule-name* term *term-name* from] hierarchy level. The `source-address` prefix range must also map to a single subnet or range of IPv4 or IPv6 addresses in the `pool` statement. Any pool addresses that are not used by the `source-address` prefix range are left unused; pools cannot be shared.



NOTE: When you include a NAT configuration that changes IP addresses, it might affect forwarding path features elsewhere in your router configuration, such as source class usage (SCU), destination class usage (DCU), filter-based forwarding, or other features that target specific IP addresses or prefixes.

NAT configuration might also affect routing protocols operation, because the protocol peering, neighbor, and interface addresses can be altered when routing protocols packets transit the Adaptive Services (AS) or MultiServices PIC.

Configuring IPv6 Multicast Filters

To enable multicast filters on Ethernet interfaces when IPv6 NAT is used for neighbor discovery, you must include the `ipv6-multicast-interfaces` statement at the [edit services nat] hierarchy level.

```
[edit services nat]
ipv6-multicast-interfaces (all | interface-name) {
  disable;
}
```

By default, multicast filters are not enabled on media interfaces. To enable filters on all interfaces, include the `ipv6-multicast-interfaces all` statement. To enable filters on a specified interface only, include the `ipv6-multicast-interfaces interface-name` statement.

To disable filters that were previously enabled, include the `disable` statement.

Configuring NAT Rules

To configure a NAT rule, include the `rule rule-name` statement at the [edit services nat] hierarchy level:

```
[edit services nat]
rule rule-name {
  match-direction (input | output);
  term term-name {
    nat-type (full-cone | symmetric);
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address (address | any-unicast) <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      destination-prefix-list list-name <except>;
      source-address (address | any-unicast) <except>;
```

```

        source-address-range low minimum-value high maximum-value <except>;
        source-prefix-list list-name <except>;
    }
    then {
        no-translation;
        translated {
            destination-pool nat-pool-name;
            destination-prefix prefix;
            overload-pool overload-pool-name;
            overload-prefix overload-prefix;
            source-pool nat-pool-name;
            source-prefix prefix;
            translation-type (destination type | source type);
            translation-type {
                source type;
                destination type;
            }
        }
        syslog;
    }
}

```

Each NAT rule consists of a set of terms, similar to a firewall filter. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software.

The following sections explain how to configure the components of NAT rules:

- Configuring Match Direction for NAT Rules on page 134
- Configuring NAT Type for Terms in NAT Rules on page 135
- Configuring Match Conditions in NAT Rules on page 136
- Configuring Actions in NAT Rules on page 137

Configuring Match Direction for NAT Rules

Each rule must include a **match-direction** statement that specifies the direction in which the match is applied. To configure where the match is applied, include the **match-direction** statement at the **[edit services nat rule *rule-name*]** hierarchy level:

```

[edit services nat rule rule-name]
match-direction (input | output);

```

The match direction is used with respect to the traffic flow through the AS or MultiServices PIC. When a packet is sent to the PIC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the AS or MultiServices PIC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the PIC, the packet direction is output. For more information on inside and outside interfaces, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

On the AS or MultiServices PIC, a flow lookup is performed. If no flow is found, rule processing is performed. All rules in the service set are considered. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that matches the packet direction are considered.

Configuring NAT Type for Terms in NAT Rules

The NAT type specifies whether a particular term supports traditional NAT processing or full-cone NAT. A *full-cone* NAT is one in which all requests from the same internal IP address and port are mapped to the same external IP address and port. In addition, any external host can send a packet to the internal host by sending it to the mapped external address. Full-cone NAT is useful if you want to allow external hosts from the public network to connect to internal hosts using public IP addresses. However, we recommend that you use this feature along with strict firewall rules that allow only the intended traffic from the public network to reach the customer-edge router.

To configure the NAT type, include the `nat-type` statement at the [edit services nat rule *rule-name* term *term-name*] hierarchy level:

```
[edit services nat rule rule-name term term-name]  
  nat-type (full-cone | symmetric);
```

`nat-type` has two possible options:

- `full-cone`—Specifies that the term supports full-cone NAT.
- `symmetric`—Specifies that the term supports only traditional NAT; this is the default setting.

The following specifications and restrictions apply to full-cone NAT:

- As long as an internal host has a connection to an external host and uses source NAT, this feature allows any external host to connect back to the internal host over the public IP network.
- When the internal host terminates its connection to the external host, initiation of any new connections from external host to internal host over the public IP network is disallowed. Existing connections are not affected.
- Use of full-cone NAT enables the external-to-internal host connection to be independent from the internal-to-external host connection with regard to protocol and source and destination port.
- The aging mechanism for the external-to-internal host connection is similar to other host connections. Once the connection is established from the external host to the internal host, it is treated like any other network connection.

- Full-cone NAT is available with both source static and source dynamic NAT processing; for more information, see “Configuring Actions in NAT Rules” on page 137.
- It supports IPv4 addresses on Juniper Networks J-series Services Routers only. It is not supported on M-series or T-series routing platforms.
- It does not support Port Address Translation (PAT) or Network Address Port Translation (NAPT).
- It is not supported for use with twice NAT configurations.

For a configuration example, see “Example: Configuring Full-Cone NAT” on page 149.

Configuring Match Conditions in NAT Rules

To configure NAT match conditions, include the **from** statement at the [edit services nat rule *rule-name* term *term-name*] hierarchy level:

```
[edit services nat rule rule-name term term-name]
from {
  application-sets set-name;
  applications [ application-names ];
  destination-address (address | any-unicast) <except>;
  destination-address-range low minimum-value high maximum-value <except>;
  destination-prefix-list list-name <except>;
  source-address (address | any-unicast) <except>;
  source-address-range low minimum-value high maximum-value <except>;
  source-prefix-list list-name <except>;
}
```

To configure traditional NAT and twice NAT, you can use the destination address, a range of destination addresses, the source address, or a range of source addresses as a match condition, in the same way that you would configure a firewall filter; for more information, see the *JUNOS Policy Framework Configuration Guide*.

Alternatively, you can specify a list of source or destination prefixes by including the **prefix-list** statement at the [edit policy-options] hierarchy level and then including either the **destination-prefix-list** or **source-prefix-list** statement in the NAT rule. For an example, see “Examples: Configuring Stateful Firewall Rules” on page 112.

You can include application protocol definitions that you have configured at the [edit applications] hierarchy level; for more information, see “Applications Configuration Guidelines” on page 59:

- To apply one or more specific application protocol definitions, include the **applications** statement at the [edit services nat rule *rule-name* term *term-name* from] hierarchy level.
- To apply one or more sets of application protocol definitions that you have defined, include the **application-sets** statement at the [edit services nat rule *rule-name* term *term-name* from] hierarchy level.



NOTE: If you include one of the statements that specifies application protocols, the router derives port and protocol information from the corresponding configuration at the [edit applications] hierarchy level; you cannot specify these properties as match conditions.

You can configure ALGs for ICMP and trace route under stateful firewall, NAT, or class of service (CoS) rules when twice NAT is configured in the same service set. Twice NAT does not support any other ALGs.

By default, the twice NAT feature can affect IP, TCP, and UDP headers embedded in the payload of ICMP error messages. You can include the **protocol tcp** and **protocol udp** statements with the **application** statement for twice NAT configurations.

Configuring Actions in NAT Rules

To configure NAT actions, include the **then** statement at the [edit services nat rule *rule-name* term *term-name*] hierarchy level:

```
[edit services nat rule rule-name term term-name]
then {
  no-translation;
  syslog;
  translated {
    destination-pool nat-pool-name;
    destination-prefix destination-prefix;
    overload-pool overload-pool-name;
    overload-prefix overload-prefix;
    source-pool nat-pool-name;
    source-prefix source-prefix;
    translation-type (destination type | source type);
    translation-type {
      source type;
      destination type;
    }
  }
}
```

The **no-translation** statement allows you to specify addresses that you want to be excluded from NAT.

The **destination-pool**, **destination-prefix**, **source-pool**, and **source-prefix** statements specify addressing information that you define by including the **pool** statement at the [edit services nat] hierarchy level; for more information, see “Configuring Addresses and Ports for Use in NAT Rules” on page 130.

The **overload-pool** and **overload-prefix** statements specify a pool of addresses or an address prefix that can be used if the source pool becomes exhausted. If all the addresses in the source pool are in use, additional NAT sessions are supported using the overload pool. The overload pool must have NAPT configured.

For twice NAT, you can apply an overload pool for source addresses and combined source and destination addresses.

The **syslog** statement enables you to record an alert in the system logging facility.

The **translation-type** statement specifies what type of network address translation is used for source or destination traffic:

- **destination static**—Implement address translation for destination traffic without port mapping. This requires the size of the source address space to be the same or smaller than the size of the destination address space. You must specify a **destination-pool** name. The referenced pool can contain multiple addresses but no **port** configuration.
- **source dynamic**—Implement address translation for source traffic with NAPT. You must specify a **source-pool** name. The referenced pool must include a **port** or **address** configuration.

If port automatic or port range is specified, port translation is used. If a port is not defined, the port value defaults to 1.

The **source dynamic** option supports translating a large range of addresses to a smaller size pool. The requests from the source address range are assigned to the addresses in the pool until the pool is used up, and any additional requests are rejected. A NAT address assigned to a host is used for all concurrent sessions from that host. The address is released to the pool only after all the sessions for that host expire. This feature enables the router to share a few public IP addresses between several private hosts. Since all the private hosts might not simultaneously create sessions, they can share a few public IP addresses.

- **source static**—Implement address translation for source traffic without port mapping. The size of the pool address space must be greater than or equal to the source address space. You must specify a **source-pool** name. The referenced pool must contain exactly one address or prefix and no **port** configuration. You must include exactly one **source-address** value at the **[edit services nat rule rule-name term term-name from]** hierarchy level; if it is a prefix, the size must be less than or equal to the pool prefix size. Any addresses in the pool that are not matched in the **source-address** value remain unused, because a pool cannot be shared among multiple terms or rules.

For traditional NAT, you can configure either **translation-type destination** or **translation-type source**, but not both. To configure twice NAT, you specify both a **translation-type destination** and a **translation-type source**.



NOTE: You can statically assign NAT addresses from a dynamic NAT pool. This capability enables you to advertise one subnet that represents the NAT pool and use an address within that subnet for static rules. Statically assigned addresses are not reused for dynamic assignment. Statically assigned addresses from a dynamic pool can only be used for source static NAT and not for destination static NAT.



NOTE: When configuring NAT, if you specify the following addresses that do not match the NAT flow or NAT rule, the corresponding traffic is dropped:

- Addresses specified in the `from destination-address` statement, when you are using destination translation
- Addresses specified in the source NAT pool when you are using source translation

For more information on NAT methods, see RFC 2663, *IP Network Address Translator (NAT) Terminology and Considerations*.

Configuring NAT Rule Sets

The `rule-set` statement defines a collection of NAT rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the `rule-set` statement at the `[edit services nat]` hierarchy level with a `rule` statement for each rule:

```
rule-set rule-set-name {
    rule rule-name;
}
```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

Examples: Configuring NAT Rules

This section provides the following configuration examples:

- Example: Configuring Dynamic Source Translation on page 140
- Example: Configuring Static Source Translation on page 140
- Example: Configuring Dynamic and Static Source Translation on page 140
- Example: Configuring an Oversubscribed Pool with No Fallback on page 141
- Example: Configuring an Oversubscribed Pool with Fallback to NAPT on page 142
- Example: Configuring Static Source Translation with Multiple Prefixes and Address Ranges on page 142
- Example: Assigning Addresses from a Dynamic Pool for Static Use on page 143
- Example: Configuring NAT Rules Without Defining a Pool on page 144
- Example: Preventing Translation of Specific Addresses on page 144
- Example: Configuring NAT for Multicast Traffic on page 145
- Example: Configuring Twice NAT on page 149
- Example: Configuring Full-Cone NAT on page 149

For additional examples that combine NAT configuration with other services and with virtual private network (VPN) routing and forwarding (VRF) tables, see “Examples: Services Interfaces Configuration” on page 49.

Example: Configuring Dynamic Source Translation

The following example configures dynamic source translation:

```
[edit services nat]
pool public {
  address-range low 192.16.2.1 high 192.16.2.32;
  port automatic;
}
rule Private-Public {
  match-direction input;
  term Translate {
    then {
      translated {
        source-pool public;
        translation-type source dynamic;
      }
    }
  }
}
```

Example: Configuring Static Source Translation

The following configuration sets up one-to-one mapping between a private subnet and a public subnet:

```
[edit services nat]
pool mypool {
  address 192.16.1.0/28; # public subnet
}
rule src-nat {
  match-direction input;
  term t1 {
    from {
      source-address 10.150.1.0/28; # private subnet
    }
    then {
      translated {
        source-pool mypool;
        translation-type source static;
      }
    }
  }
}
```

Example: Configuring Dynamic and Static Source Translation

In the following configuration, **term1** configures source address translation for traffic from any private address to any public address. The translation is applied for all services. **term2** performs destination address translation for Hypertext Transfer

Protocol (HTTP) traffic from any public address to the server's virtual IP address. The virtual server IP address is translated to an internal IP address.

```
[edit services nat]
rule my-nat-rule {
  match-direction input;
  term my-term1 {
    from {
      source-address private;
      destination-address public;
    }
    then {
      translated {
        source-pool my-prefix-list; # pick address from a pool
        translation-type source dynamic; # dynamic NAT with port translation
      }
    }
  }
  term my-term2 {
    from {
      destination-address 192.168.137.3; # my server's virtual address
      application http;
    }
    then {
      translated {
        destination-pool nat-pool-name;
        translation-type destination static; # static destination NAT
      }
    }
  }
}
```

Example: Configuring an Oversubscribed Pool with No Fallback

The following configuration shows dynamic address translation from a large prefix to a small pool, translating a /24 subnet to a pool of 10 addresses. Sessions from the first 10 host sessions are assigned an address from the pool on a first-come, first-served basis, and any additional requests are rejected. Each host with an assigned NAT addresses can participate in multiple sessions.

```
[edit nat services]
pool my-pool {
  address-range low 10.10.10.1 high 10.10.10.10;
}
rule src-nat {
  match-direction input;
  term t1 {
    from {
      source-address 192.168.1.0/24;
    }
    then {
      translated {
        translation-type source dynamic;
        source-pool my-pool;
      }
    }
  }
}
```

```

    }
  }
}

```

Example: Configuring an Oversubscribed Pool with Fallback to NAT

The following configuration shows dynamic address translation from a large prefix to a small pool, translating a /24 subnet to a pool of 10 addresses. When the addresses in the source pool (**src-pool**) are exhausted, network address translation is provided by the NATP overload pool (**pat-pool**).

```

[edit services nat]
pool src-pool {
  address-range low 192.16.2.1 high 192.16.2.10;
}
pool pat-pool {
  address-range low 192.2.11 high 192.16.2.12;
  port automatic;
}
rule myrule {
  match-direction input;
  term myterm {
    from {
      source-address 10.150.1.0/24;
    }
    then {
      translated {
        source-pool src-pool;
        overload-pool pat-pool;
        translation-type source dynamic;
      }
    }
  }
}
}

```

Example: Configuring Static Source Translation with Multiple Prefixes and Address Ranges

The following configuration creates a static pool with an address prefix and an address range and uses static source NAT translation.

```

[edit services nat]
pool p1 {
  address 30.30.30.252/30;
  address-range low 20.20.20.1 high 20.20.20.2;
}
rule r1 {
  match-direction input;
  term {
    from {
      source-address {
        10.10.10.252/30;
      }
    }
    then {

```

```

        translated {
            source-pool p1;
            translation-type source static;
        }
    }
}

```

Example: Assigning Addresses from a Dynamic Pool for Static Use

The following configuration statically assigns a subset of addresses that are configured as part of a dynamic pool (**dynamic-pool**) to two separate static pools (**static-pool** and **static-pool2**).

```

[edit services nat]
pool dynamic-pool {
    address 20.20.10.0/24;
}
pool static-pool {
    address-range low 20.20.10.10 high 10.20.10.12;
}
pool static-pool2 {
    address 20.20.10.15/32;
}
rule src-nat {
    match-direction input;
    term t1 {
        from {
            source-address 30.30.30.0/24;
        }
        then {
            translation-type source dynamic;
            source-pool dynamic-pool;
        }
    }
    term t2 {
        from {
            source-address 10.10.10.2;
        }
        then {
            translation-type source static;
            source-pool static-pool;
        }
    }
    term t3 {
        from {
            source-address 10.10.10.10;
        }
        then {
            translation-type source static;
            source-pool static-pool2;
        }
    }
}

```

Example: Configuring NAT Rules Without Defining a Pool

The following configuration performs network address translation using the source prefix 20.20.10.0/24 without defining a pool.

```
[edit services nat]
rule src-nat {
  match-direction input;
  term t1 {
    then {
      translation-type source dynamic;
      source-prefix 20.20.10.0/24;
    }
  }
}
```

The following configuration performs network address translation using the destination prefix 20.20.10.0/32 without defining a pool.

```
[edit services nat]
rule src-nat {
  match-direction input;
  term t1 {
    from {
      destination-address 10.10.10.10/32;
    }
    then {
      translation-type destination static;
      destination-prefix 20.20.10.0/32;
    }
  }
}
```

Example: Preventing Translation of Specific Addresses

The following configuration specifies that network address translation is not performed on incoming traffic from the source address 192.168.20.24/32. Dynamic NAT is performed on all other incoming traffic.

```
[edit services nat]
pool my-pool {
  address-range low 10.10.10.1 high 10.10.10.16;
  port-automatic;
}
rule src-nat {
  match-direction input;
  term t0 {
    from {
      source-address 192.168.20.24/32;
    }
    then {
      no-translation;
    }
  }
}
```



```


    }
    term t1 {
    then {
    translated {
    translation-type source dynamic;
    source-pool my-pool;
    }
    }
    }
}

```

Example: Configuring NAT for Multicast Traffic

Figure 2 on page 145 illustrates the network setup for the following configuration, which allows IP multicast traffic to be sent to the Adaptive Services (AS) or MultiServices PIC.

Figure 2: Configuring NAT for Multicast Traffic



Rendezvous Point Configuration

On the rendezvous point (RP), all incoming traffic from the multicast source at 192.168.254.0/27 is sent to the static NAT pool `mcast_pool`, where its source is translated to 20.20.20.0/27. The service set `nat_ss` is a next-hop service set that allows IP multicast traffic to be sent to the AS or MultiServices PIC. The inside interface on the PIC is `sp-1/1/0.1` and the outside interface is `sp-1/1/0.2`.

```

[edit services]
nat {
  pool mcast_pool {
    address 20.20.20.0/27;
  }
  rule nat_rule_1 {
    match-direction input;
    term 1 {
      from {
        source-address 192.168.254.0/27;
      }
    }
    then {
      translated {
        source-pool mcast_pool;
        translation-type source static;
      }
      syslog;
    }
  }
}

```

```

}
service-set nat_ss {
  allow-multicast;
  nat-rules nat_rule_1;
  next-hop-service {
    inside-service-interface sp-1/1/0.1;
    outside-service-interface sp-1/1/0.2;
  }
}

```

The Gigabit Ethernet interface **ge-0/3/0** carries traffic out of the RP to Router 1. The adaptive services interface **sp-1/1/0** has two logical interfaces: **unit 1** is the inside interface for next-hop services and **unit 2** is the outside interface for next-hop services. Multicast source traffic comes in on the Fast Ethernet interface **fe-1/2/1**, which has the firewall filter **fbf** applied to incoming traffic.

```

[edit interfaces]
ge-0/3/0 {
  unit 0 {
    family inet {
      address 10.10.1.1/30;
    }
  }
}
sp-1/1/0 {
  unit 0 {
    family inet;
  }
  unit 1 {
    family inet;
    service-domain inside;
  }
  unit 2 {
    family inet;
    service-domain outside;
  }
}
fe-1/2/1 {
  unit 0 {
    family inet {
      filter {
        input fbf;
      }
      address 192.168.254.27/27;
    }
  }
}

```

Multicast packets can only be directed to the AS or MultiServices PIC using a next-hop service set. In the case of NAT, you must also configure a VRF. Therefore, the routing instance **stage** is created as a “dummy” forwarding instance. To direct incoming packets to **stage**, you configure filter-based forwarding through a firewall filter called **fbf**, which is applied to the incoming interface **fe-1/2/1**. A lookup is performed in **stage.inet.0**, which has a multicast static route that is installed with the next hop

pointing to the PIC's inside interface. All multicast traffic matching this route is sent to the PIC.

```
[edit firewall]
filter fbf {
  term 1 {
    then {
      routing-instance stage;
    }
  }
}
```

The routing instance **stage** forwards IP multicast traffic to the inside interface **sp-1/1/0.1** on the AS or MultiServices PIC:

```
[edit]
routing-instances stage {
  instance-type forwarding;
  routing-options {
    static {
      route 224.0.0.0/4 next-hop sp-1/1/0.1;
    }
  }
}
```

You enable OSPF and Protocol Independent Multicast (PIM) on the Fast Ethernet and Gigabit Ethernet logical interfaces over which IP multicast traffic enters and leaves the RP. You also enable PIM on the outside interface (**sp-1/1/0.2**) of the next-hop service set.

```
[edit protocols]
ospf {
  area 0.0.0.0 {
    interface fe-1/2/1.0 {
      passive;
    }
    interface lo0.0;
    interface ge-0/3/0.0;
  }
}
pim {
  rp {
    local {
      address 10.255.14.160;
    }
  }
  interface fe-1/2/1.0;
  interface lo0.0;
  interface ge-0/3/0.0;
  interface sp-1/1/0.2;
}
```

As with any filter-based forwarding configuration, in order for the static route in the forwarding instance **stage** to have a reachable next hop, you must configure routing table groups so that all interface routes are copied from **inet.0** to the routing table in

the forwarding instance. You configure routing tables `inet.0` and `stage.inet.0` as members of `fbf_rib_group`, so that all interface routes are imported into both tables.

```
[edit routing-options]
interface-routes {
  rib-group inet fbf_rib_group;
}
rib-groups fbf_rib_group {
  import-rib [ inet.0 stage.inet.0 ];
}
multicast {
  rpf-check-policy no_rpf;
}
```

Reverse path forwarding (RPF) checking must be disabled for the multicast group on which source NAT is applied. You can disable RPF checking for specific multicast groups by configuring a policy similar to the one in the example that follows. In this case, the `no_rpf` policy disables RPF check for multicast groups belonging to `224.0.0.0/4`.

```
[edit policy-options]
policy-statement no_rpf {
  term 1 {
    from {
      route-filter 224.0.0.0/4 orlonger;
    }
    then reject;
  }
}
```

Router 1 Configuration

The Internet Group Management Protocol (IGMP), OSPF, and PIM configuration on Router 1 is as follows. Because of IGMP static group configuration, traffic is forwarded out `fe-3/0/0.0` to the multicast receiver without receiving membership reports from host members.

```
[edit protocols]
igmp {
  interface fe-3/0/0.0 {
  }
}
ospf {
  area 0.0.0.0 {
    interface fe-3/0/0.0 {
      passive;
    }
    interface lo0.0;
    interface ge-7/2/0.0;
  }
  pim {
    rp {
      static {
        address 10.255.14.160;
      }
    }
  }
}
```

```

    }
    interface fe-3/0/0.0;
    interface lo0.0;
    interface ge-7/2/0.0;
  }
}

```

The routing option creates a static route to the NAT pool, `mcast_pool`, on the RP.

```

[edit routing-options]
static {
  route 20.20.20.0/27 next-hop 10.10.1.1;
}

```

Example: Configuring Twice NAT

In the following configuration, `term1` configures source address translation and destination address translation for traffic from a specific destination address to a source address in a range of source addresses. Both destination and source pools are configured.

```

[edit services nat]
rule twice-nat {
  match-direction input;
  term my-term1 {
    from {
      destination-address {
        41.41.41.41/32;
      }
      source-address-range {
        low 10.58.254.34 high 10.58.254.35;
      }
    }
    then {
      translated {
        source-pool src-pool;
        destination-pool dst_pool;
        translation-type {
          source static;
          destination static;
        }
      }
    }
  }
}

```

Example: Configuring Full-Cone NAT

The following configuration example shows full-cone NAT with source static processing.

```

[edit services]
nat {
  pool static_nat_range {

```

```
        address-range low 10.200.253.1 high 10.200.253.5;
    }
    rule static_nat_rule {
        term sample-term {
            nat-type full-cone;
            from {
                source-address-range {
                    low 10.100.136.1 high 10.100.136.5;
                }
            }
            then {
                translated {
                    source-pool static_nat_range;
                    translation-type {
                        source static;
                    }
                }
            }
        }
    }
}
```

Chapter 9

Summary of Network Address Translation Configuration Statements

The following sections explain each of the Network Address Translation (NAT) statements. The statements are organized alphabetically.

address

Syntax	address <i>ip-prefix</i> </ <i>prefix-length</i> >;
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4. <i>prefix</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the NAT pool prefix value.
Options	<i>prefix</i> —Specify an IPv4 or IPv6 prefix value.
Usage Guidelines	See “Configuring Addresses and Ports for Use in NAT Rules” on page 130.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

address-range

Syntax	<code>address-range low <i>minimum-value</i> high <i>maximum-value</i>;</code>
Hierarchy Level	<code>[edit services nat pool <i>nat-pool-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the NAT pool address range.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range.
Usage Guidelines	See “Configuring Addresses and Ports for Use in NAT Rules” on page 130.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

application-sets

Syntax	<code>applications-sets <i>set-name</i>;</code>
Hierarchy Level	<code>[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more target application sets.
Options	<i>set-name</i> —Name of the target application set.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

applications

Syntax	<code>applications [<i>application-names</i>];</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more application protocols to which the NAT services apply.
Options	<i>application-name</i> —Name of the target application.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address

Syntax	<code>destination-address (<i>address</i> any-unicast) <except>;</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4. any-unicast and except options introduced in JUNOS Release 7.6. address option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address for rule matching.
Options	<i>address</i> —Destination IPv4 or IPv6 address or prefix value. any-unicast—Any unicast packet. except—(Optional) Prevent the specified address, prefix, or unicast packets from being translated.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address-range

Syntax	destination-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.6. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range. except—(Optional) Prevent the specified address range from being translated.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-pool

Syntax	destination-pool <i>nat-pool-name</i> ;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the destination address pool for translated traffic.
Options	<i>nat-pool-name</i> —Destination pool name.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix

Syntax	<code>destination-prefix <i>destination-prefix</i>;</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced in JUNOS Release 7.6. <i>destination-prefix</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination prefix for translated traffic.
Options	<i>destination-prefix</i> —IPv4 or IPv6 destination prefix value.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix-list

Syntax	<code>destination-prefix-list <i>list-name</i> <except>;</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the destination prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Destination prefix list. except—(Optional) Exclude the specified prefix list from rule matching.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

from

Syntax from {
 application-sets *set-name*;
 applications [*application-names*];
 destination-address (*address* | any-unicast) <except>;
 destination-address-range low *minimum-value* high *maximum-value* <except>;
 source-address *address* (*address* | any-unicast) <except>;
 source-address-range low *minimum-value* high *maximum-value* <except>;
 }

Hierarchy Level [edit services nat rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify input conditions for the NAT term.

Options For information on match conditions, see the description of firewall filter match conditions in the *JUNOS Policy Framework Configuration Guide*.

The remaining statements are explained separately.

Usage Guidelines See “Configuring NAT Rules” on page 133.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

hint

Syntax	hint [<i>hint-strings</i>];
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i> pgcp]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Configure a hint that enables the BGF to choose a NAT pool by direction rather than by virtual interface. The BGF matches the configured hint with a termination hint located in the Direction field of a nonstandard termination ID.
Default	When no hint is configured, the BGF can choose any NAT pool associated with the virtual interface.
Options	<i>hint-string</i> —Alphanumeric string of up to 3 characters that the BGF uses to match with a termination hint located in the Direction field of a nonstandard termination ID. You can also specify underscores (_) and hyphens (-) within the string. To specify a list of hints, use the format: [hint xx hint yy].
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

ipv6-multicast-interfaces

Syntax	ipv6-multicast-interfaces (all <i>interface-name</i>) { disable; }
Hierarchy Level	[edit services nat]
Release Information	Statement introduced in JUNOS Release 9.1.
Description	Enable multicast filters on Ethernet interfaces when IPv6 NAT is used for neighbor discovery.
Options	all—Enable filters on all interfaces. disable—Disable filters on the specified interfaces. <i>interface-name</i> —Enable filters on a specific interface only.
Usage Guidelines	See “Configuring IPv6 Multicast Filters” on page 133.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

match-direction

Syntax	match-direction (input output);
Hierarchy Level	[edit services nat rule <i>rule-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the direction in which the rule match is applied.
Options	input—Apply the rule match on input. output—Apply the rule match on output.
Usage Guidelines	See “Configuring NAT Rules” on page 133.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

nat-type

Syntax	nat-type (full-cone symmetric);
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i>]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Specify whether the term supports full-cone or traditional (symmetric) NAT.
Default	symmetric
Options	full-cone—Support full-cone NAT processing, in which all requests from the same internal IP address and port are mapped to the same external IP address and port. symmetric—Support traditional NAT address matching only.
Usage Guidelines	See “Configuring NAT Type for Terms in NAT Rules” on page 135
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-translation

Syntax	no-translation;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify that traffic is not to be translated.
Options	none
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

overload-pool

Syntax	overload-pool <i>overload-pool-name</i> ;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify an address pool that can be used if the source pool becomes exhausted.
Options	<i>overload-pool-name</i> —Name of the overload pool.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

overload-prefix

Syntax	<code>overload-prefix <i>overload-prefix</i>;</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify the prefix that can be used if the source pool becomes exhausted.
Options	<i>overload-prefix</i> —Prefix value.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

pgcp

Syntax	<pre>pgcp { hint [<i>hint-strings</i>]; ports-per-session <i>ports</i>; remotely-controlled; transport [<i>transport-protocols</i>]; }</pre>
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4. <code>remotely-controlled</code> and <code>ports-per-session</code> statements added in JUNOS Release 8.5. <code>hint</code> statement added in JUNOS Release 9.0.
Description	Specify that the NAT pool is used exclusively by the BGF.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

pool

Syntax `pool nat-pool-name {
 address ip-prefix</prefix-length>;
 address-range low minimum-value high maximum-value;
 pgcp {
 hint [hint-strings];
 ports-per-session ports;
 remotely-controlled;
 transport [transport-protocols];
 }
 port (automatic | range low minimum-value high maximum-value);
 }`

Hierarchy Level [edit services nat]

Release Information Statement introduced before JUNOS Release 7.4.
 pgcp statement added in JUNOS Release 8.4.
 remotely-controlled and ports-per-session statements added in JUNOS Release 8.5.
 hint statement added in JUNOS Release 9.0.

Description Specify the NAT name and properties.

Options *nat-pool-name*—Identifier for the NAT address pool.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Addresses and Ports for Use in NAT Rules” on page 130.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

port

Syntax	port (automatic range low <i>minimum-value</i> high <i>maximum-value</i>) { random-allocation; }
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i>]
Release Information	port statement introduced before JUNOS Release 7.4. random-allocation statement introduced in JUNOS Release 9.3.
Description	Specify the NAT pool port or range. You can configure an automatically assigned port or specify a range with minimum and maximum values.
Options	automatic—Router-assigned port. <i>minimum-value</i> —Lower boundary for the port range. <i>maximum-value</i> —Upper boundary for the port range. random-allocation—By default, the JUNOS software allocates NAT ports sequentially. To configure random port allocation, include the random-allocation option.
Usage Guidelines	See “Configuring Addresses and Ports for Use in NAT Rules” on page 130.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ports-per-session

Syntax	ports-per-session <i>ports</i> ;
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i> pgcp]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the number of ports required to support Real-Time Transport Protocol (RTP), Real-Time Control Protocol (RTCP), Real-Time Streaming Protocol (RTSP), forward error correction (FEC) for voice and video flows on the MultiServices PIC.
Options	<i>number-of-ports</i> —Number of ports to enable: 2 or 4 for combined voice and video services. Default: 2
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

remotely-controlled

Syntax	remotely-controlled;
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i> pgcp]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Configure the addresses and ports in a NAT pool to be remotely controlled by the gateway controller.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

rule

Syntax

```
rule rule-name {
  match-direction (input | output);
  term term-name {
    nat-type (full-cone | symmetric);
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address (address | any-unicast) <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      source-address (address | any-unicast) <except>;
      source-address-range low minimum-value high maximum-value <except>;
    }
    then {
      no-translation;
      translated {
        destination-pool nat-pool-name;
        destination-prefix destination-prefix;
        overload-pool overload-pool;
        overload-prefix overload-prefix;
        source-pool nat-pool-name;
        source-prefix source-prefix;
        translation-type (destination type | source type);
        translation-type {
          source type;
          destination type;
        }
      }
      syslog;
    }
  }
}
```

Hierarchy Level [edit services nat],
[edit services nat rule-set rule-set-name]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the rule the router uses when applying this service.

Options *rule-name*—Identifier for the collection of terms that comprise this rule.

Usage Guidelines See “Configuring NAT Rules” on page 133.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rule-set

Syntax	<code>rule-set <i>rule-set-name</i> { [rule <i>rule-names</i>]; }</code>
Hierarchy Level	[edit services nat]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the rule set the router uses when applying this service.
Options	<i>rule-set-name</i> —Identifier for the collection of rules that constitute this rule set.
Usage Guidelines	See “Configuring NAT Rule Sets” on page 139.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	<code>services nat { ... }</code>
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the service rules to be applied to traffic.
Options	<i>nat</i> —Identifies the NAT set of rules statements.
Usage Guidelines	See “Network Address Translation Services Configuration Guidelines” on page 129.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address

Syntax	source-address (<i>address</i> any-unicast) <except>;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4. any-unicast and except options introduced in JUNOS Release 7.6. address option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the source address for rule matching.
Options	address—Source IPv4 or IPv6 address or prefix value. any-unicast—Any unicast packet. except—(Optional) Prevent the specified address or unicast packets from being translated.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address-range

Syntax	source-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.6. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the source address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range. except—(Optional) Prevent the specified address range from being translated.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-pool

Syntax	<code>source-pool nat-pool-name;</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the source address pool for translated traffic.
Options	<i>nat-pool-name</i> —Source pool name.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix

Syntax	<code>source-prefix source-prefix;</code>
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced in JUNOS Release 7.6. <i>source-prefix</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the source prefix for translated traffic.
Options	<i>source-prefix</i> —IPv4 or IPv6 source prefix value.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix-list

Syntax	source-prefix-list <i>list-name</i> <except>;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the source prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Destination prefix list. except—(Optional) Exclude the specified prefix list from rule matching.
Usage Guidelines	See “Configuring Match Conditions in NAT Rules” on page 136.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

syslog

Syntax	syslog;
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable system logging. The system log information from the Adaptive Services or MultiServices PIC is passed to the kernel for logging in the <i>/var/log</i> directory.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

term

Syntax `term term-name {`
 `nat-type (full-cone | symmetric);`
 `from {`
 `application-sets set-name;`
 `applications [application-names];`
 `destination-address (address | any-unicast) <except>;`
 `destination-address-range low minimum-value high maximum-value <except>;`
 `source-address (address | any-unicast) <except>;`
 `source-address-range low minimum-value high maximum-value <except>;`
 `}`
 `then {`
 `no-translation;`
 `translated {`
 `destination-pool nat-pool-name;`
 `destination-prefix destination-prefix;`
 `overload-pool overload-pool;`
 `overload-prefix overload-prefix;`
 `source-pool nat-pool-name;`
 `source-prefix source-prefix;`
 `translation-type (destination type | source type);`
 `translation-type {`
 `source type;`
 `destination type;`
 `}`
 `}`
 `syslog;`
 `}`
 `}`

Hierarchy Level [edit services nat rule *rule-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the NAT term properties.

Options *term-name*—Identifier for the term.

Usage Guidelines See “Configuring NAT Rules” on page 133.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

then

Syntax then {
 no-translation;
 translated {
 destination-pool *nat-pool-name*;
 destination-prefix *destination-prefix*;
 overload-pool *overload-pool-name*;
 overload-prefix *overload-prefix*;
 source-pool *nat-pool-name*;
 source-prefix *source-prefix*;
 translation-type (destination *type* | source *type*);
 translation-type {
 source *type*;
 destination *type*;
 }
 }
 syslog;
 }

Hierarchy Level [edit services nat rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the NAT term actions.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring NAT Rules” on page 133.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

translated

Syntax translated {
 destination-pool *nat-pool-name*;
 source-pool *nat-pool-name*;
 translation-type (destination *type* | source *type*);
 translation-type {
 source *type*;
 destination *type*;
 }
 }

Hierarchy Level [edit services nat rule *rule-name* term *term-name* then]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define properties for translated traffic.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring Actions in NAT Rules” on page 137.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

translation-type

See the following sections:

- translation-type (Traditional NAT) on page 172
- translation-type (Twice NAT) on page 172

translation-type (Traditional NAT)

Syntax	translation-type (destination type source type)
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the NAT types for traditional NAT.
Options	<i>type</i> —You can specify source dynamic, source static, or destination static.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

translation-type (Twice NAT)

Syntax	translation-type { source type; destination type; }
Hierarchy Level	[edit services nat rule <i>rule-name</i> term <i>term-name</i> then translated]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify the NAT types for twice NAT.
Options	<i>type</i> —You must specify destination static and either source dynamic or source static.
Usage Guidelines	See “Configuring Actions in NAT Rules” on page 137.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

transport

Syntax	transport [<i>transport-protocols</i>];
Hierarchy Level	[edit services nat pool <i>nat-pool-name</i> pgcp]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the BGF to select a NAT pool based on transport protocol type.
Options	[<i>transport-protocol</i>]—One or more transport protocols. Values: rtp-avp, tcp, udp Syntax: One or more protocols. If you specify more than one protocol, you must enclose all protocols in brackets.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

Chapter 10

Intrusion Detection Service Configuration Guidelines

The Adaptive Services (AS) or MultiServices PIC supports a limited set of intrusion detection services (IDS) to perform attack detection. You can use IDS to perform the following tasks:

- Detect various types of denial-of-service (DoS) and directed denial-of-service (DDoS) attacks.
- Detect attempts at network scanning and probing.
- Detect anomalies in traffic patterns, such as sudden bursts or a decline in bandwidth.
- Prevent some types of attacks.
- Redirect attack traffic to a collector for analysis.
- Specify thresholds for limiting the number of flows, the packet rate, and the session rate.

IDS enables you to focus attack detection and remedial actions on specific hosts or networks that you specify in the IDS terms. Signature detection is not supported.

To configure IDS, include the `ids` statement at the `[edit services]` hierarchy level:

```
[edit services]
ids {
  rule rule-name {
    match-direction (input | output | input-output);
    term term-name {
      rule {
        application-sets set-name;
        applications [ application-names ];
        destination-address (address | any-unicast) <except>;
        destination-address-range low minimum-value high maximum-value <except>;
        destination-prefix-list list-name <except>;
        source-address (address | any-unicast) <except>;
        source-address-range low minimum-value high maximum-value <except>;
        source-prefix-list list-name <except>;
      }
      then {
        aggregation {
          destination-prefix prefix-value | destination-prefix-ipv6 prefix-value;

```

```

        source-prefix prefix-value | source-prefix-ipv6 prefix-value;
    }
    (force-entry | ignore-entry);
    logging {
        syslog;
        threshold rate;
    }
    session-limit {
        by-destination {
            hold-time seconds;
            maximum number;
            packets number;
            rate number;
        }
        by-pair {
            hold-time seconds;
            maximum number;
            packets number;
            rate number;
        }
        by-source {
            hold-time seconds;
            maximum number;
            packets number;
            rate number;
        }
    }
    syn-cookie {
        mss value;
        threshold rate;
    }
}
}
}
rule-set rule-set-name {
    [ rule rule-names ];
}
}

```



NOTE: The JUNOS software uses stateful firewall settings as a basis for performing IDS. You must commit a stateful firewall configuration in the same service set for IDS to function properly.

This chapter contains the following sections:

- Configuring IDS Rules on page 177
- Configuring IDS Rule Sets on page 183
- Examples: Configuring IDS Rules on page 184

Configuring IDS Rules

IDS rules identify traffic for which you want the router software to count events. Because IDS is based on stateful firewall properties, you must configure at least one stateful firewall rule and include it in the service set with the IDS rules; for more information, see “Stateful Firewall Services Configuration Guidelines” on page 107.

To configure an IDS rule, include the `rule rule-name` statement at the `[edit services ids]` hierarchy level:

```
[edit services ids]
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address (address | any-unicast) <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      destination-prefix-list list-name <except>;
      source-address (address | any-unicast) <except>;
      source-address-range low minimum-value high maximum-value <except>;
      source-prefix-list list-name <except>;
    }
    then {
      aggregation {
        destination-prefix prefix-value | destination-prefix-ipv6 prefix-value;
        source-prefix prefix-value | source-prefix-ipv6 prefix-value;
      }
      (force-entry | ignore-entry);
      logging {
        syslog;
        threshold rate;
      }
      session-limit {
        by-destination {
          hold-time seconds;
          maximum number;
          packets number;
          rate number;
        }
        by-pair {
          hold-time seconds;
          maximum number;
          packets number;
          rate number;
        }
        by-source {
          hold-time seconds;
          maximum number;
          packets number;
          rate number;
        }
      }
    }
  }
}
```

```

    }
    syn-cookie {
        mss value;
        threshold rate;
    }
}
}
}

```

Each IDS rule consists of a set of terms, similar to a filter configured at the [edit firewall] hierarchy level. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software.

The following sections describe IDS rule content in more detail:

- Configuring Match Direction for IDS Rules on page 178
- Configuring Match Conditions in IDS Rules on page 179
- Configuring Actions in IDS Rules on page 180

Configuring Match Direction for IDS Rules

Each rule must include a **match-direction** statement that specifies whether the match is applied on the input or output side of the interface. To configure where the match is applied, include the **match-direction** (**input** | **input-output** | **output**) statement at the [edit services ids rule *rule-name*] hierarchy level:

```

[edit services ids rule rule-name]
match-direction (input | output | input-output);

```

If you configure **match-direction input-output**, bidirectional rule creation is allowed.

The match direction is used with respect to the traffic flow through the AS or MultiServices PIC. When a packet is sent to the PIC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the AS or MultiServices PIC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the PIC, the packet direction is output. For more information on inside and outside interfaces, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

On the AS or MultiServices PIC, a flow lookup is performed. If no flow is found, rule processing is performed. All rules in the service set are considered. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that match the packet direction are considered.

Configuring Match Conditions in IDS Rules

To configure IDS match conditions, include the `from` statement at the `[edit services ids rule rule-name term term-name]` hierarchy level:

```
[edit services ids rule rule-name term term-name]
from {
  application-sets set-name;
  applications [ application-names ];
  destination-address (address | any-unicast) <except>;
  destination-address-range low minimum-value high maximum-value <except>;
  destination-prefix-list list-name <except>;
  source-address (address | any-unicast) <except>;
  source-address-range low minimum-value high maximum-value <except>;
  source-prefix-list list-name <except>;
}
```

If you omit the `from` statement, the software accepts all events and places them in the IDS cache for processing.

The source address and destination address can be either IPv4 or IPv6. You can use the destination address, a range of destination addresses, a source address, or a range of source addresses as a match condition, in the same way that you would configure a firewall filter; for more information, see the *JUNOS Policy Framework Configuration Guide*.

Alternatively, you can specify a list of source or destination prefixes by including the `prefix-list` statement at the `[edit policy-options]` hierarchy level and then including either the `destination-prefix-list` or `source-prefix-list` statement in the IDS rule. For an example, see “Examples: Configuring Stateful Firewall Rules” on page 112.

You can also include application protocol definitions that you have configured at the `[edit applications]` hierarchy level; for more information, see “Applications Configuration Guidelines” on page 59.

- To apply one or more specific application protocol definitions, include the `applications` statement at the `[edit services ids rule rule-name term term-name from]` hierarchy level.
- To apply one or more sets of application protocol definitions that you have defined, include the `application-sets` statement at the `[edit services ids rule rule-name term term-name from]` hierarchy level.



NOTE: If you include one of the statements that specifies application protocols, the router derives port and protocol information from the corresponding configuration at the `[edit applications]` hierarchy level; you cannot specify these properties as match conditions.

If a match occurs on an application, the application protocol is displayed separately in the `show services ids` command output. For more information, see the *JUNOS System Basics and Services Command Reference*.

Configuring Actions in IDS Rules

To configure IDS actions, include the `then` statement at the `[edit services ids rule rule-name term term-name]` hierarchy level:

```
[edit services ids rule rule-name term term-name]
then {
  aggregation {
    destination-prefix prefix-value | destination-prefix-ipv6 prefix-value;
    source-prefix prefix-value | source-prefix-ipv6 prefix-value;
  }
  (force-entry | ignore-entry);
  logging {
    syslog;
    threshold rate;
  }
  session-limit {
    by-destination {
      hold-time seconds;
      maximum number;
      packets number;
      rate number;
    }
    by-pair {
      hold-time seconds;
      maximum number;
      packets number;
      rate number;
    }
    by-source {
      hold-time seconds;
      maximum number;
      packets number;
      rate number;
    }
  }
  syn-cookie {
    mss value;
    threshold rate;
  }
}
```

You can configure the following possible actions:

- **aggregation**—The router aggregates traffic labeled with the specified source or destination prefixes before passing the events to IDS processing. This is helpful if you want to examine all the traffic connected with a particular source or destination host. To collect traffic with some other marker, such as a particular application or port, configure that value in the match conditions.

To configure aggregation prefixes, include the **aggregation** statement at the [edit services ids rule *rule-name* term *term-name* then] hierarchy level and specify values for **source-prefix**, **destination-prefix** **source-prefix-ipv6**, or **destination-prefix-ipv6**:

```
[edit services ids rule rule-name term term-name then]
  aggregation {
    destination-prefix prefix-value | destination-prefix-ipv6 prefix-value;
    source-prefix prefix-value | source-prefix-ipv6 prefix-value;
  }
```

The value of **source-prefix** and **destination-prefix** must be an integer between 1 and 32. The value of **source-prefix-ipv6** and **destination-prefix-ipv6** must be an integer between 1 and 128.

- **(force-entry | ignore-entry)**—**force-entry** provides a permanent spot in IDS caches for subsequent events after one event is registered. By default, the IDS software does not record information about “good” packets that do not exhibit suspicious behavior. You can use the **force-entry** statement to record all traffic from a suspect host, even traffic that would not otherwise be counted.

ignore-entry ensures that all IDS events are ignored. You can use this statement to disregard all traffic from a host you trust, including any temporary anomalies that IDS would otherwise count as events.

To configure an entry behavior different from the default, include the **force-entry** or **ignore-entry** statement at the [edit services ids rule *rule-name* term *term-name* then] hierarchy level:

```
[edit services ids rule rule-name term term-name then]
  (force-entry | ignore-entry);
```

- **logging**—The event is logged in the system log file.

To configure logging, include the **logging** statement at the [edit services ids rule *rule-name* term *term-name* then] hierarchy level:

```
[edit services ids rule rule-name term term-name then]
  logging {
    syslog;
    threshold rate;
  }
```

You can optionally include a threshold rate to trigger the generation of system log messages. The threshold rate is specified in events per second. IDS logs are generated once every 60 seconds for each anomaly that is reported. The logs are generated as long as the events continue.

- **session-limit**—The router limits open sessions when the specified threshold is reached.

To configure a threshold, include the **session-limit** statement at the [edit services ids rule *rule-name* term *term-name* then] hierarchy level:

```
[edit services ids rule rule-name term term-name then]
  session-limit {
```

```

by-destination {
    hold-time seconds;
    maximum number;
    packets number;
    rate number;
}
by-pair {
    hold-time seconds;
    maximum number;
    packets number;
    rate number;
}
by-source {
    hold-time seconds;
    maximum number;
    packets number;
    rate number;
}
}

```

You configure the thresholds for flow limitation based on traffic direction:

- To limit the number of outgoing sessions from one internal host or subnet, configure the **by-source** statement.
- To limit the number of sessions between a pair of IP addresses, subnets, or applications, configure the **by-pair** statement.
- To limit the number of incoming sessions to one external public IP address or subnet, configure the **by-destination** statement.

For each direction, you can configure the following threshold values:

- **hold-time *seconds***—When the **rate** or **packets** measurement reaches the threshold value, stop all new flows for the specified number of seconds. Once **hold-time** is in effect, the traffic is blocked for the specified time even if the rate subsides below the specified limit. By default, **hold-time** has a value of 0; the range is 0 through 60 seconds.
- **maximum *number***—Maximum number of open sessions per IP address or subnet per application. The range is 1 through 32,767.
- **packets *number***—Maximum number of packets per second (pps) per IP address or subnet per application. The range is 4 through 2,147,483,647.
- **rate *number***—Maximum number of sessions per second per IP address or subnet per application. The range is 4 through 32,767.

If you include more than one source address in the match conditions configured at the [edit services ids rule *rule-name* term *term-name* from] hierarchy level, limits are applied for each source address independently. For example, the following configuration allows 20 connections from each source address (10.1.1.1 and 10.1.1.2), not 20 connections total. The same logic applies to the **applications** and **destination-address** match conditions.

```
[edit services ids rule rule-name term term-name]
```

```

from {
  source-address 10.1.1.1;
  source-address 10.1.1.2;
}
then {
  session-limit by-source {
    maximum 20;
  }
}

```



NOTE: IDS limits are applied to packets that are accepted by stateful firewall rules. They are not applied to packets discarded or rejected by stateful firewall rules. For example, if the stateful firewall accepts 75 percent of the incoming traffic and the remaining 25 percent is rejected or discarded, the IDS limit applies only to 75 percent of the traffic.

- **syn-cookie**—The router activates SYN-cookie defensive mechanisms.

To configure SYN-cookie values, include the **syn-cookie** statement at the [edit services ids rule *rule-name* term *term-name* then] hierarchy level:

```

[edit services ids rule rule-name term term-name then]
syn-cookie {
  mss value;
  threshold rate;
}

```

If you enable SYN-cookie defenses, you must include both a threshold rate to trigger SYN-cookie activity and a Transmission Control Protocol (TCP) maximum segment size (MSS) value for TCP delayed binding. The threshold rate is specified in SYN attacks per second. By default, the TCP MSS value is 1500; the range is from 128 through 8192.

Configuring IDS Rule Sets

The **rule-set** statement defines a collection of IDS rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the **rule-set** statement at the [edit services ids] hierarchy level with a **rule** statement for each rule:

```

[edit services ids]
rule-set rule-set-name {
  rule rule-name;
}

```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

Examples: Configuring IDS Rules

The following configuration adds a permanent entry to the IDS anomaly table when it encounters a flow with the destination address 10.410.6.2:

```
[edit services ids]
rule simple_ids {
  term 1 {
    from {
      destination-address 10.410.6.2/32;
    }
    then {
      force-entry;
      logging {
        threshold 1;
        syslog;
      }
    }
  }
  term default {
    then {
      aggregation {
        source-prefix 24;
      }
    }
  }
}
match-direction input;
```

The IDS configuration works in conjunction with the stateful firewall mechanism and relies heavily on the anomalies reported by the stateful firewall. The following configuration example shows this relationship:

```
[edit services ids]
rule simple_ids {
  term 1 {
    from {
      source-address 10.30.20.2/32;
      destination-address {
        10.30.10.2/32;
        10.30.1.2/32 except;
      }
      applications appl-ftp;
    }
    then {
      force-entry;
      logging {
        threshold 5;
        syslog;
      }
      syn-cookie {
        threshold 10;
      }
    }
  }
}
```



```

    }
    match-direction input;
}

```

The following example shows configuration of flow limits:

```

[edit services ids]
rule ids-all {
  match-direction input;
  term t1 {
    from {
      application-sets alg-set;
    }
    then {
      aggregation {
        destination-prefix 30; /* IDS action aggregation */
      }
      logging {
        threshold 10;
      }
      session-limit {
        by-destination {
          hold-time 0;
          maximum 10;
          packets 200;
          rate 100;
        }
        by-pair {
          hold-time 0;
          maximum 10;
          packets 200;
          rate 100;
        }
        by-source {
          hold-time 5;
          maximum 10;
          packets 200;
          rate 100;
        }
      }
    }
  }
}

```


Chapter 11

Summary of Intrusion Detection Service Configuration Statements

The following sections explain each of the intrusion detection service (IDS) statements. The statements are organized alphabetically.

aggregation

Syntax aggregation {
 destination-prefix *prefix-value* | destination-prefix-ipv6 *prefix-value*;
 source-prefix *prefix-value* | source-prefix-ipv6 *prefix-value*;
}

Hierarchy Level [edit services ids rule *rule-name* term *term-name* then]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the type of data to be aggregated.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring Actions in IDS Rules” on page 180.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

application-sets

Syntax	<code>application-sets set-name;</code>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more target application sets.
Options	<i>set-name</i> —Name of the target application set.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

applications

Syntax	<code>applications [application-names];</code>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more applications to which IDS applies.
Options	<i>application-name</i> —Name of the target application.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

by-destination

Syntax by-destination {
 hold-time *seconds*;
 maximum *number*;
 packets *number*;
 rate *number*;
 }

Hierarchy Level [edit services ids rule *rule-name* term *term-name* then session-limit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Apply limit to sessions based on numbers generated from the configured destination (IP or subnet) or application.

Options hold-time *seconds*—Length of time for which to stop all new flows once the rate of events exceeds the threshold set by one or more of the **maximum**, **packets**, or **rate** statements.

maximum *number*—Maximum number of open sessions per application or IP address.

packets *number*—Maximum peak packets per second per application or IP address.

rate *number*—Maximum number of sessions per second per application or IP address.

Usage Guidelines See “Configuring Actions in IDS Rules” on page 180.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

by-pair

Syntax `by-pair {
 hold-time seconds;
 maximum number;
 packets number;
 rate number;
 }`

Hierarchy Level [edit services ids rule *rule-name* term *term-name* then session-limit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Apply limit to paired stateful firewall and NAT flows (forward and reverse).

Options `hold-time seconds`—Length of time for which to stop all new flows once the rate of events exceeds the threshold set by one or more of the `maximum`, `packets`, or `rate` statements.

`maximum number`—Maximum number of open sessions per application or IP address.

`packets number`—Maximum peak packets per second per application or IP address.

`rate number`—Maximum number of sessions per second per application or IP address.

Usage Guidelines See “Configuring Actions in IDS Rules” on page 180.

Required Privilege Level `interface`—To view this statement in the configuration.
 `interface-control`—To add this statement to the configuration.

by-source

Syntax `by-source {
 hold-time seconds;
 maximum number;
 packets number;
 rate number;
 }`

Hierarchy Level `[edit services ids rule rule-name term term-name then session-limit]`

Release Information Statement introduced before JUNOS Release 7.4.

Description Apply limit to sessions based on numbers generated from the configured source (IP or subnet) or application.

Options `hold-time seconds`—Length of time for which to stop all new flows once the rate of events exceeds the threshold set by one or more of the `maximum`, `packets`, or `rate` statements.

`maximum number`—Maximum number of open sessions per application or IP address.

`packets number`—Maximum peak packets per second per application or IP address.

`rate number`—Maximum number of sessions per second per application or IP address.

Usage Guidelines See “Configuring Actions in IDS Rules” on page 180.

Required Privilege Level `interface`—To view this statement in the configuration.
 `interface-control`—To add this statement to the configuration.

destination-address

Syntax	destination-address (<i>address</i> any-unicast) <except>;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4. <i>address</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address for rule matching.
Options	<i>address</i> —Destination IPv4 or IPv6 address or prefix value. any-unicast—Any unicast packet. except—(Optional) Exempt the specified address, prefix, or unicast packets from rule matching.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address-range

Syntax	destination-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.6. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range. except—(Optional) Exempt the specified address range from rule matching.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix

Syntax	<code>destination-prefix <i>prefix-value</i>;</code>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then aggregation]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the prefix value for destination IPv4 address aggregation.
Options	<i>prefix-value</i> —Integer value. Range: 1 through 32
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix-ipv6

Syntax	<code>destination-prefix-ipv6 <i>prefix</i>;</code>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then aggregation]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Specify the prefix value for destination IPv6 address aggregation.
Options	<i>prefix-value</i> —Integer value. Range: 1 through 128
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix-list

Syntax	<code>destination-prefix-list <i>list-name</i> <except>;</code>
Hierarchy Level	<code>[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]</code>
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the destination prefix list for rule matching. You configure the prefix list by including the <code>prefix-list</code> statement at the <code>[edit policy-options]</code> hierarchy level.
Options	<p><i>list-name</i>—Destination prefix list.</p> <p><code>except</code>—(Optional) Exclude the specified prefix list from rule matching.</p>
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

force-entry

Syntax	<code>(force-entry ignore-entry);</code>
Hierarchy Level	<code>[edit services ids rule <i>rule-name</i> term <i>term-name</i> then]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Specify handling of entries in the IDS events cache:</p> <ul style="list-style-type: none"> ■ <code>force-entry</code>—Ensure that the entry has a permanent place in the IDS cache after one event is registered. ■ <code>ignore-entry</code>—Ensure that all IDS events are ignored.
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

from

Syntax from {
 application-sets *set-name*;
 applications [*application-names*];
 destination-address (*address* | any-unicast) <except>;
 destination-address-range low *minimum-value* high *maximum-value* <except>;
 source-address (*address* | any-unicast) <except>;
 source-address-range low *minimum-value* high *maximum-value* <except>;
 }

Hierarchy Level [edit services ids rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify input conditions for the IDS term.

Options For information on match conditions, see the description of firewall filter match conditions in the *JUNOS Policy Framework Configuration Guide*.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Match Conditions in IDS Rules” on page 179.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

ignore-entry

See force-entry

logging

Syntax	logging { syslog; threshold <i>rate</i> ; }
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set logging values for this IDS term.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

match-direction

Syntax	match-direction (input output input-output);
Hierarchy Level	[edit services ids rule <i>rule-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the direction in which the rule match is applied.
Options	input—Apply the rule match on input. output—Apply the rule match on output. input-output—Apply the rule match bidirectionally.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

mss

Syntax	<code>mss value;</code>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then syn-cookie]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the maximum segment size (MSS) value used in Transmission Control Protocol (TCP) delayed binding.
Options	<i>value</i> —MSS value. Default: 1500 Range: 128 through 8192
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

rule

Syntax

```
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address (address | any-unicast) <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      source-address (address | any-unicast) <except>;
      source-address-range low minimum-value high maximum-value <except>;
    }
    then {
      aggregation {
        destination-prefix prefix-value | destination-prefix-ipv6 prefix-value;
        source-prefix prefix-value | source-prefix-ipv6 prefix-value;
      }
      (force-entry | ignore-entry);
      logging {
        syslog;
        threshold rate;
      }
      session-limit {
        by-destination {
          hold-time seconds;
          maximum number;
          packets number;
          rate number;
        }
        by-pair {
          hold-time seconds;
          maximum number;
          packets number;
          rate number;
        }
        by-source {
          hold-time seconds;
          maximum number;
          packets number;
          rate number;
        }
      }
      syn-cookie {
        mss value;
        threshold rate;
      }
    }
  }
}
```

Hierarchy Level [edit services ids],

[edit services ids rule-set *rule-set-name*]

Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the rule the router uses when applying this service.
Options	<i>rule-name</i> —Identifier for the collection of terms that constitute this rule.
Usage Guidelines	See “Configuring IDS Rules” on page 177.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

rule-set

Syntax	rule-set <i>rule-set-name</i> { [rule <i>rule-names</i>]; }
Hierarchy Level	[edit services ids]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the rule set the router uses when applying this service.
Options	<i>rule-set-name</i> —Identifier for the collection of rules that constitute this rule set.
Usage Guidelines	See “Configuring IDS Rule Sets” on page 183.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	services ids { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the service rules to be applied to traffic.
Options	ids—Identifies the IDS set of rules statements.
Usage Guidelines	See “Intrusion Detection Service Configuration Guidelines” on page 175.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

session-limit

Syntax

```
session-limit {
  by-destination {
    hold-time seconds;
    maximum number;
    packets number;
    rate number;
  }
  by-pair {
    hold-time seconds;
    maximum number;
    packets number;
    rate number;
  }
  by-source {
    hold-time seconds;
    maximum number;
    packets number;
    rate number;
  }
}
```

Hierarchy Level [edit services ids rule *rule-name* term *term-name* then]

Release Information Statement introduced before JUNOS Release 7.4.

Description Enable flow limitation by configuring thresholds on source, destination, or stateful firewall and network address translation (NAT) paired traffic flows.

Options The remaining statements are described separately.

Usage Guidelines See “Configuring Actions in IDS Rules” on page 180.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

source-address

Syntax	source-address (<i>address</i> any-unicast) <except>;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4. <i>address</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the source address for rule matching.
Options	<i>address</i> —Source IPv4 or IPv6 address or prefix value. any-unicast—Any unicast packet. except—(Optional) Exempt the specified address, prefix, or unicast packets from rule matching.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address-range

Syntax	source-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.6. <i>minimum-value</i> and <i>maximum-value</i> options enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the source address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range. except—(Optional) Exempt the specified address range from rule matching.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix

Syntax	source-prefix <i>prefix-value</i> ;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then aggregation]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the prefix value for source IPv4 address aggregation.
Options	<i>prefix-value</i> —Integer value. Range: 1 through 32
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix-ipv6

Syntax	source-prefix-ipv6 <i>prefix-value</i> ;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then aggregation]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Specify the prefix value for source IPv6 address aggregation.
Options	<i>prefix-value</i> —Integer value. Range: 1 through 128
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix-list

Syntax	source-prefix-list <i>list-name</i> <except>;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the source prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Destination prefix list. except—(Optional) Exclude the specified prefix list from rule matching.
Usage Guidelines	See “Configuring Match Conditions in IDS Rules” on page 179.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

syn-cookie

Syntax	<pre>syn-cookie { mss <i>value</i>; threshold <i>rate</i>; }</pre>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable SYN-cookie defenses against SYN attacks. By default, SYN-cookie techniques are not applied.
Options	The remaining statements are described separately.
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

syslog

Syntax	syslog;
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then logging]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable system logging. The system log information from the Adaptive Services or MultiServices Physical Interface Card (PIC) is passed to the kernel for logging in the /var/log directory.
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

term

```

Syntax  term term-name {
            from {
                application-sets set-name;
                applications [ application-names ];
                destination-address (address | any-unicast) <except>;
                destination-address-range low minimum-value high maximum-value <except>;
                source-address (address | any-unicast) <except>;
                source-address-range low minimum-value high maximum-value <except>;
            }
            then {
                aggregation {
                    destination-prefix prefix-value | destination-prefix-ipv6 prefix-value;
                    source-prefix prefix-value | source-prefix-ipv6 prefix-value;
                }
                (force-entry | ignore-entry);
                logging {
                    syslog;
                    threshold rate;
                }
                session-limit {
                    by-destination {
                        hold-time seconds;
                        maximum number;
                        packets number;
                        rate number;
                    }
                    by-pair {
                        hold-time seconds;
                        maximum number;
                        packets number;
                        rate number;
                    }
                    by-source {
                        hold-time seconds;
                        maximum number;
                        packets number;
                        rate number;
                    }
                }
                syn-cookie {
                    mss value;
                    threshold rate;
                }
            }
        }

```

Hierarchy Level [edit services ids rule *rule-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the IDS term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Usage Guidelines See “Configuring IDS Rules” on page 177.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

then

```

Syntax  then {
            aggregation {
                destination-prefix prefix-number | destination-prefix-ipv6 prefix-value;
                source-prefix prefix-number | source-prefix-ipv6 prefix-value;
            }
            (force-entry | ignore-entry);
            logging {
                syslog;
                threshold rate;
            }
            session-limit {
                by-destination {
                    hold-time seconds;
                    maximum number;
                    packets number;
                    rate number;
                }
                by-pair {
                    hold-time seconds;
                    maximum number;
                    packets number;
                    rate number;
                }
                by-source {
                    hold-time seconds;
                    maximum number;
                    packets number;
                    rate number;
                }
            }
            syn-cookie {
                mss value;
                threshold rate;
            }
        }

```

Hierarchy Level [edit services ids rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the IDS term actions.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring IDS Rules” on page 177.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

threshold

Syntax	<code>threshold rate;</code>
Hierarchy Level	[edit services ids rule <i>rule-name</i> term <i>term-name</i> then logging], [edit services ids rule <i>rule-name</i> term <i>term-name</i> then syn-cookie]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the threshold for logging or applying SYN-cookie defenses.
Options	<i>rate</i> —Logging threshold number of events per second. <i>rate</i> —SYN-cookie defense number of SYN attacks per second.
Usage Guidelines	See “Configuring Actions in IDS Rules” on page 180.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 12

IPsec Services Configuration Guidelines

To configure IP Security (IPsec) services, include the following statements at the [edit services ipsec-vpn] hierarchy level:

```
[edit services ipsec-vpn]
clear-ike-sas-on-pic-restart;
clear-ipsec-sas-on-pic-restart;
ike {
  proposal proposal-name {
    authentication-algorithm (md5 | sha1 | sha-256);
    authentication-method (dsa-signatures | pre-shared-keys | rsa-signatures);
    description description;
    dh-group (group1 | group2);
    encryption-algorithm algorithm;
    lifetime-seconds seconds;
  }
  policy policy-name {
    description description;
    local-certificate identifier;
    local-id (ipv4_addr ipv4-address | ipv6_addr ipv6-address | key-id identifier);
    mode (aggressive | main);
    pre-shared-key (ascii-text key | hexadecimal key);
    proposals [ proposal-names ];
    remote-id {
      any-remote-id;
      ipv4_addr [ values ];
      ipv6_addr [ values ];
      key_id [ values ];
    }
  }
}
ipsec {
  proposal proposal-name {
    authentication-algorithm (hmac-md5-96 | hmac-sha1-96);
    description description;
    encryption-algorithm algorithm;
    lifetime-seconds seconds;
    protocol (ah | esp | bundle);
  }
  policy policy-name {
    description description;
    perfect-forward-secrecy {
      keys (group1 | group2);
    }
  }
}
```

```

        proposals [ proposal-names ];
    }
}
rule rule-name {
    match-direction (input | output);
    term term-name {
        from {
            destination-address address;
            ipsec-inside-interface interface-name;
            source-address address;
        }
        then {
            backup-remote-gateway address;
            clear-dont-fragment-bit;
            dynamic {
                ike-policy policy-name;
                ipsec-policy policy-name;
            }
            initiate-dead-peer-detection;
            manual {
                direction (inbound | outbound | bidirectional) {
                    authentication {
                        algorithm (hmac-md5-96 | hmac-sha1-96);
                        key (ascii-text key | hexadecimal key);
                    }
                    auxiliary-spi spi-value;
                    encryption {
                        algorithm algorithm;
                        key (ascii-text key | hexadecimal key);
                    }
                    protocol (ah | bundle | esp);
                    spi spi-value;
                }
            }
            no-anti-replay;
            remote-gateway address;
            syslog;
            tunnel-mtu bytes;
        }
    }
}
rule-set rule-set-name {
    [ rule rule-names ];
}
traceoptions {
    file {
        files number;
        size bytes;
    }
    flag flag;
}

```

This chapter includes the following sections:

- Minimum Security Association Configurations on page 211
- Configuring Security Associations on page 212
- Configuring IKE Proposals on page 218
- Configuring IKE Policies on page 221
- Configuring IPsec Proposals on page 227
- Configuring IPsec Policies on page 229
- Configuring IPsec Rules on page 231
- Configuring IPsec Rule Sets on page 237
- Configuring Dynamic Endpoints for IPsec Tunnels on page 237
- Tracing IPsec Operations on page 243
- Examples: Configuring IPsec Services on page 244

Minimum Security Association Configurations

The following sections show the minimum configurations necessary to set up security associations (SAs) for IPsec services:

- Minimum Manual SA Configuration on page 211
- Minimum Dynamic SA Configuration on page 211

Minimum Manual SA Configuration

To define a manual SA configuration, you must include at least the following statements at the `[edit services ipsec-vpn rule rule-name term term-name then manual]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual]
direction (inbound | outbound | bidirectional) {
  authentication {
    algorithm (hmac-md5-96 | hmac-sha1-96);
    key (ascii-text key | hexadecimal key);
  }
  encryption {
    algorithm algorithm;
    key (ascii-text key | hexadecimal key);
  }
  protocol (ah | esp | bundle);
  spi spi-value;
}
```

Minimum Dynamic SA Configuration

To define a dynamic SA configuration, you must include at least the following statements at the `[edit services ipsec-vpn]` hierarchy level:

```
[edit services ipsec-vpn]
```

```

ike {
  proposal proposal-name {
    authentication-algorithm (md5 | sha1 | sha-256);
    authentication-method pre-shared-keys;
    dh-group (group1 | group2);
    encryption-algorithm algorithm;
  }
  policy policy-name {
    proposals [ ike-proposal-names ];
    pre-shared-key (ascii-text key | hexadecimal key);
  }
}
ipsec {
  policy policy-name {
    proposals [ ipsec-proposal-names ];
  }
  proposal proposal-name {
    authentication-algorithm (hmac-md5-96 | hmac-sha1-96);
    encryption-algorithm algorithm;
    protocol (ah | esp | bundle);
  }
}

```

You must also include the `ipsec-policy` statement at the `[edit services ipsec-vpn rule rule-name term term-name then dynamic]` hierarchy level.

Configuring Security Associations

To use IPsec services, you create an SA between hosts. An SA is a simplex connection that allows two hosts to communicate with each other securely by means of IPsec. You can configure two types of SAs:

- **Manual**—Requires no negotiation; all values, including the keys, are static and specified in the configuration. As a result, each peer must have the same configured options for communication to take place. For information about how to configure a manual SA, see “Configuring Manual Security Associations” on page 213.
- **Dynamic**—Specifies proposals to be negotiated with the tunnel peer. The keys are generated as part of the negotiation and therefore do not need to be specified in the configuration. The dynamic SA includes one or more **proposal** statements, which allow you to prioritize a list of protocols and algorithms to be negotiated with the peer. For information about how to configure a dynamic SA, see “Configuring Dynamic Security Associations” on page 217.

This section includes the following topics:

- Configuring Manual Security Associations on page 213
- Configuring Dynamic Security Associations on page 217
- Clearing Security Associations on page 218



NOTE: Both OSPFv2 and OSPFv3 support IPsec authentication. However, dynamic or tunnel mode IPsec SAs are not supported for OSPFv3. If you add SAs into OSPFv3 by including the `ipsec-sa` statement at the `[edit protocols ospf3 area area-number interface interface-name]` hierarchy level, your configuration fails to commit. For more information about OSPF authentication and other OSPF properties, see the *JUNOS Routing Protocols Configuration Guide*.

Configuring Manual Security Associations

Manual SAs require no negotiation; all values, including the keys, are static and specified in the configuration. As a result, each peer must have the same configured options for communication to take place.

To configure a manual IPsec security association, include statements at the `[edit services ipsec-vpn rule rule-name term term-name then manual]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual]
direction (inbound | outbound | bidirectional) {
  authentication {
    algorithm (hmac-md5-96 | hmac-sha1-96);
    key (ascii-text key | hexadecimal key);
  }
  auxiliary-spi auxiliary-spi-value;
  encryption {
    algorithm algorithm;
    key (ascii-text key | hexadecimal key);
  }
  protocol (ah | esp | bundle);
  spi spi-value;
}
```

To configure manual SA statements, do the following:

- Configuring the Direction for IPsec Processing on page 213
- Configuring the Protocol for a Manual IPsec SA on page 214
- Configuring the Security Parameter Index on page 215
- Configuring the Auxiliary Security Parameter Index on page 215
- Configuring Authentication for a Manual IPsec SA on page 215
- Configuring Encryption for a Manual IPsec SA on page 216

Configuring the Direction for IPsec Processing

The `direction` statement specifies inbound or outbound IPsec processing. If you want to define different algorithms, keys, or security parameter index (SPI) values for each direction, you configure the `inbound` and `outbound` options. If you want the same attributes in both directions, use the `bidirectional` option.

To configure the direction of IPsec processing, include the `direction` statement at the `[edit services ipsec-vpn rule rule-name term term-name then manual]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual]
  direction (inbound | outbound | bidirectional) {
    ...
  }
```

Example: Using Different Configuration for the Inbound and Outbound Directions

Define different algorithms, keys, and security parameter index values for each direction:

```
[edit services ipsec-vpn rule rule-name term term-name then manual]
direction inbound {
  protocol esp;
  spi 16384;
  encryption {
    algorithm 3des-cbc;
    key ascii-text 23456789012345678901234;
  }
}
direction outbound {
  protocol esp;
  spi 24576;
  encryption {
    algorithm 3des-cbc;
    key ascii-text 12345678901234567890abcd;
  }
}
```

Example: Using the Same Configuration for the Inbound and Outbound Directions

Define one set of algorithms, keys, and security parameter index values that is valid in both directions:

```
[edit services ipsec-vpn rule rule-name term term-name then manual]
direction bidirectional {
  protocol ah;
  spi 20001;
  authentication {
    algorithm hmac-md5-96;
    key ascii-text 123456789012abcd;
  }
}
```

Configuring the Protocol for a Manual IPsec SA

IPsec uses two protocols to protect IP traffic: Encapsulating Security Payload (ESP) and authentication header (AH). The AH protocol is used for strong authentication. A third option, **bundle**, uses AH authentication and ESP encryption; it does not use ESP authentication because AH provides stronger authentication of IP packets.

To configure the IPsec protocol, include the **protocol** statement and specify the **ah**, **esp**, or **bundle** option at the `[edit services ipsec-vpn rule rule-name term term-name then manual direction direction]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual direction direction
]
protocol (ah | bundle | esp);
```

Configuring the Security Parameter Index

An SPI is an arbitrary value that uniquely identifies which SA to use at the receiving host. The sending host uses the SPI to identify and select which SA to use to secure every packet. The receiving host uses the SPI to identify and select the encryption algorithm and key used to decrypt packets.



NOTE: Each manual SA must have a unique SPI and protocol combination. Use the auxiliary SPI when you configure the **protocol** statement to use the **bundle** option.

To configure the SPI, include the **spi** statement and specify a value (from 256 through 16,639) at the [edit services ipsec-vpn rule *rule-name* term *term-name* then manual direction *direction*] hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual direction direction
]
spi spi-value;
```

Configuring the Auxiliary Security Parameter Index

Use the auxiliary SPI when you configure the **protocol** statement to use the **bundle** option.



NOTE: Each manual SA must have a unique SPI and protocol combination.

To configure the auxiliary SPI, include the **auxiliary-spi** statement and specify a value (from 256 through 16,639) at the [edit services ipsec-vpn rule *rule-name* term *term-name* then manual direction *direction*] hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual direction direction
]
auxiliary-spi auxiliary-spi-value;
```

Configuring Authentication for a Manual IPsec SA

To configure an authentication algorithm, include the **authentication** statement and specify an authentication algorithm and a key at the [edit services ipsec-vpn rule *rule-name* term *term-name* then manual direction *direction*] hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual direction direction
]
authentication {
  algorithm (hmac-md5-96 | hmac-sha1-96);
  key (ascii-text key | hexadecimal key);
}
```

The algorithm can be one of the following:

- **hmac-md5-96**—Hash algorithm that authenticates packet data. It produces a 128-bit authenticator value and a 96-bit digest.
- **hmac-sha1-96**—Hash algorithm that authenticates packet data. It produces a 160-bit authenticator value and a 96-bit digest.

The key can be one of the following:

- **ascii-text**—ASCII text key. With the **hmac-md5-96** option, the key contains 16 ASCII characters. With the **hmac-sha1-96** option, the key contains 20 ASCII characters.
- **hexadecimal**—Hexadecimal key. With the **hmac-md5-96** option, the key contains 32 hexadecimal characters. With the **hmac-sha1-96** option, the key contains 40 hexadecimal characters.

Configuring Encryption for a Manual IPSec SA

To configure IPsec encryption, include the encryption statement and specify an algorithm and key at the [edit services ipsec-vpn rule *rule-name* term *term-name* then manual direction *direction*] hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then manual direction direction
]
  encryption {
    algorithm algorithm;
    key (ascii-text key | hexadecimal key);
  }
```

The algorithm can be one of the following:

- **des-cbc**—Encryption algorithm that has a block size of 8 bytes; its key size is 64 bits long.
- **3des-cbc**—Encryption algorithm that has a block size of 24 bytes; its key size is 192 bits long.
- **aes-128-cbc**—Advanced Encryption Standard (AES) 128-bit encryption algorithm.
- **aes-192-cbc**—Advanced Encryption Standard (AES) 192-bit encryption algorithm.
- **aes-256-cbc**—Advanced Encryption Standard (AES) 256-bit encryption algorithm.



NOTE: For a list of Data Encryption Standard (DES) encryption algorithm weak and semiweak keys, see RFC 2409, *The Internet Key Exchange (IKE)*. The AES encryption algorithms use a software implementation that has much lower throughput, so DES remains the recommended option. For reference information on AES encryption, see RFC 3602, *The AES-CBC Cipher Algorithm and Its Use with IPsec*.

For **3des-cbc**, the first 8 bytes should differ from the second 8 bytes, and the second 8 bytes should be the same as the third 8 bytes.

If you configure an authentication proposal but do not include the **encryption** statement, the result is NULL encryption. Certain applications expect this result. If you configure no specific authentication or encryption values, the JUNOS software uses the default values of **sha1** for the authentication and **3des-cbc** for the encryption.

The key can be one of the following:

- **ascii-text**—ASCII text key. With the **des-cbc** option, the key contains 8 ASCII characters. With the **3des-cbc** option, the key contains 24 ASCII characters.
- **hexadecimal**—Hexadecimal key. With the **des-cbc** option, the key contains 16 hexadecimal characters. With the **3des-cbc** option, the key contains 48 hexadecimal characters.



NOTE: You cannot configure encryption when you use the AH protocol.

Configuring Dynamic Security Associations

You configure dynamic SAs with a set of proposals that are negotiated by the security gateways. The keys are generated as part of the negotiation and therefore do not need to be specified in the configuration. The dynamic SA includes one or more proposals, which allow you to prioritize a list of protocols and algorithms to be negotiated with the peer.

To enable a dynamic SA, follow these steps:

1. Configure Internet Key Exchange (IKE) proposals and IKE policies associated with these proposals.
2. Configure IPsec proposals and an IPsec policy associated with these proposals.
3. Associate an SA with an IPsec policy by configuring the **dynamic** statement.

For more information about IKE policies and proposals, see “Configuring IKE Policies” on page 221 and “Configuring IKE Proposals” on page 218. For more information about IPsec policies and proposals, see “Configuring IPsec Policies” on page 229.

To configure a dynamic SA, include the **dynamic** statement and specify an IPsec policy name at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy

level. The `ike-policy` statement is optional unless you use the preshared key authentication method.

```
[edit services ipsec-vpn rule rule-name term term-name then]
dynamic {
  ike-policy policy-name;
  ipsec-policy policy-name;
}
```



NOTE: If you want to establish a dynamic SA, the attributes in at least one configured IPsec and IKE proposal must match those of its peer.

Clearing Security Associations

You can set up the router software to clear IKE or IPsec SAs automatically when the corresponding services PIC restarts or is taken offline. To configure this property, include the `clear-ike-sas-on-pic-restart` or `clear-ipsec-sas-on-pic-restart` statement at the `[edit services ipsec-vpn]` hierarchy level:

```
[edit services ipsec-vpn]
clear-ike-sas-on-pic-restart;
clear-ipsec-sas-on-pic-restart;
```

After you add this statement to the configuration, all the IKE or IPsec SAs corresponding to the tunnels in the PIC will be cleared when the PIC restarts or goes offline.

Configuring IKE Proposals

Dynamic SAs require IKE configuration. With dynamic SAs, you configure IKE first, and then the SA. IKE creates the dynamic SAs and negotiates them for IPsec. The IKE configuration defines the algorithms and keys used to establish the secure IKE connection with the peer security gateway.

You can configure one or more IKE proposals. Each proposal is a list of IKE attributes to protect the IKE connection between the IKE host and its peer.

To configure an IKE proposal, include the `proposal` statement and specify a name at the `[edit services ipsec-vpn ike]` hierarchy level:

```
[edit services ipsec-vpn ike]
proposal proposal-name {
  authentication-algorithm (md5 | sha1 | sha-256);
  authentication-method (dsa-signatures | pre-shared-key | rsa-signatures);
  dh-group (group1 | group2);
  encryption-algorithm algorithm;
  lifetime-seconds seconds;
}
```

This section includes the following topics:

- Configuring the Authentication Algorithm for an IKE Proposal on page 219
- Configuring the Authentication Method for an IKE Proposal on page 219
- Configuring the Diffie-Hellman Group for an IKE Proposal on page 220
- Configuring the Encryption Algorithm for an IKE Proposal on page 220
- Configuring the Lifetime for an IKE SA on page 221
- Example: Configuring an IKE Proposal on page 221

Configuring the Authentication Algorithm for an IKE Proposal

To configure the authentication algorithm for an IKE proposal, include the `authentication-algorithm` statement at the `[edit services ipsec-vpn ike proposal proposal-name]` hierarchy level:

```
[edit services ipsec-vpn ike proposal proposal-name]
authentication-algorithm (md5 | sha1 | sha-256);
```

The authentication algorithm can be one of the following:

- `md5`—Produces a 128-bit digest.
- `sha1`—Produces a 160-bit digest.
- `sha-256`—Produces a 256-bit digest.



NOTE: For reference information on Secure Hash Algorithms (SHAs), see Internet draft `draft-eastlake-sha2-02.txt`, *Secure Hash Algorithms (SHA and HMAC-SHA)* (expires July 2006).

Configuring the Authentication Method for an IKE Proposal

To configure the authentication method for an IKE proposal, include the `authentication-method` statement at the `[edit services ipsec-vpn ike proposal proposal-name]` hierarchy level:

```
[edit services ipsec-vpn ike proposal proposal-name]
authentication-method (dsa-signatures | pre-shared-keys | rsa-signatures);
```

The authentication method can be one of the following:

- `dsa-signatures`—Digital Signature Algorithm
- `pre-shared-keys`—A key derived from an out-of-band mechanism; the key authenticates the exchanges
- `rsa-signatures`—Public key algorithm (supports encryption and digital signatures)

Configuring the Diffie-Hellman Group for an IKE Proposal

Diffie-Hellman is a public-key cryptography scheme that allows two parties to establish a shared secret over an insecure communications channel. It is also used within IKE to establish session keys.

To configure the Diffie-Hellman group for an IKE proposal, include the **dh-group** statement at the [edit services ipsec-vpn ike proposal *proposal-name*] hierarchy level:

```
[edit services ipsec-vpn ike proposal proposal-name]  
dh-group (group1 | group2);
```

The group can be one of the following:

- **group1**—Specifies that IKE use the 768-bit Diffie-Hellman prime modulus group when performing the new Diffie-Hellman exchange.
- **group2**—Specifies that IKE use the 1024-bit Diffie-Hellman prime modulus group when performing the new Diffie-Hellman exchange.

group2 provides more security but requires more processing time.

Configuring the Encryption Algorithm for an IKE Proposal

To configure the encryption algorithm for an IKE proposal, include the **encryption-algorithm** statement at the [edit services ipsec-vpn ike proposal *proposal-name*] hierarchy level:

```
[edit services ipsec-vpn ike proposal proposal-name]  
encryption-algorithm algorithm;
```

The encryption algorithm can be one of the following:

- **3des-cbc**—Cipher block chaining encryption algorithm with a key size of 24 bytes; its key size is 192 bits long.
- **des-cbc**—Cipher block chaining encryption algorithm with a key size of 8 bytes; its key size is 56 bits long.
- **aes-128-cbc**—Advanced Encryption Standard (AES) 128-bit encryption algorithm.
- **aes-192-cbc**—Advanced Encryption Standard (AES) 192-bit encryption algorithm.
- **aes-256-cbc**—Advanced Encryption Standard (AES) 256-bit encryption algorithm.



NOTE: For a list of Data Encryption Standard (DES) encryption algorithm weak and semiweak keys, see RFC 2409, *The Internet Key Exchange (IKE)*. The AES encryption algorithms use a software implementation that has much lower throughput, so DES remains the recommended option.

For **3des-cbc**, the first 8 bytes should differ from the second 8 bytes, and the second 8 bytes should be the same as the third 8 bytes.

If you configure an authentication proposal but do not include the **encryption** statement, the result is NULL encryption. Certain applications expect this result. If you configure no specific authentication or encryption values, the JUNOS software uses the default values of **sha1** for the authentication and **3des-cbc** for the encryption.

Configuring the Lifetime for an IKE SA

The **lifetime-seconds** statement sets the lifetime of an IKE SA. When the IKE SA expires, it is replaced by a new SA (and SPI) or the IPsec connection is terminated.

To configure the lifetime for an IKE SA, include the **lifetime-seconds** statement at the **[edit services ipsec-vpn ike proposal *proposal-name*]** hierarchy level:

```
[edit services ipsec-vpn ike proposal proposal-name]  
lifetime-seconds seconds;
```

By default, the IKE SA lifetime is 3600 seconds. The range is from 180 through 86,400 seconds.



NOTE: For IKE proposals, there is only one SA lifetime value, specified by the JUNOS software. IPsec proposals use a different mechanism; for more information, see “Configuring the Lifetime for an IPsec SA” on page 228.

Example: Configuring an IKE Proposal

Configure an IKE proposal:

```
[edit services ipsec-vpn ike]  
proposal ike-proposal {  
  authentication-method pre-shared-keys;  
  dh-group group1;  
  authentication-algorithm sha1;  
  encryption-algorithm 3des-cbc;  
}
```

Configuring IKE Policies

An IKE policy defines a combination of security parameters (IKE proposals) to be used during IKE negotiation. It defines a peer address and the proposals needed for that connection. Depending on which authentication method is used, it defines the

preshared key for the given peer or the local certificate. During the IKE negotiation, IKE looks for an IKE policy that is the same on both peers. The peer that initiates the negotiation sends all its policies to the remote peer, and the remote peer tries to find a match.

A match is made when both policies from the two peers have a proposal that contains the same configured attributes. If the lifetimes are not identical, the shorter lifetime between the two policies (from the host and peer) is used. The configured preshared key must also match its peer.

You can create multiple, prioritized proposals at each peer to ensure that at least one proposal matches a remote peer's proposal.

First, you configure one or more IKE proposals; then you associate these proposals with an IKE policy. You can also prioritize a list of proposals used by IKE in the **policy** statement by listing the proposals you want to use, from first to last.

To configure an IKE policy, include the **policy** statement and specify a policy name at the `[edit services ipsec-vpn ike]` hierarchy level:

```
[edit services ipsec-vpn ike]
policy policy-name {
  description description;
  local-certificate identifier;
  local-id (ipv4_addr ipv4-address | ipv6_addr ipv6-address | key-id identifier);
  mode (aggressive | main);
  pre-shared-key (ascii-text key | hexadecimal key);
  proposals [ proposal-names ];
  remote-id {
    any-remote-id;
    ipv4_addr [ values ];
    ipv6_addr [ values ];
    key_id [ values ];
  }
}
```

This section includes the following topics:

- Configuring the Mode for an IKE Policy on page 223
- Configuring the Proposals in an IKE Policy on page 223
- Configuring the Preshared Key for an IKE Policy on page 223
- Configuring the Local Certificate for an IKE Policy on page 224
- Configuring the Description for an IKE Policy on page 225
- Configuring Local and Remote IDs for IKE Phase 1 Negotiation on page 225
- Example: Configuring an IKE Policy on page 226

For an example of an IKE policy configuration, see “Example: Configuring an IKE Policy” on page 226.

Configuring the Mode for an IKE Policy

IKE policy has two modes: aggressive and main. By default, main mode is enabled. Main mode uses six messages, in three exchanges, to establish the IKE SA. (These three steps are IKE SA negotiation, a Diffie-Hellman exchange, and authentication of the peer.) Main mode also allows a peer to hide its identity.

Aggressive mode also establishes an authenticated IKE SA and keys. However, aggressive mode uses half the number of messages, has less negotiation power, and does not provide identity protection. The peer can use the aggressive or main mode to start IKE negotiation; the remote peer accepts the mode sent by the peer.

To configure the mode for an IKE policy, include the `mode` statement and specify aggressive or main at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
[edit services ipsec-vpn ike policy policy-name]
mode (aggressive | main);
```

Configuring the Proposals in an IKE Policy

The IKE policy includes a list of one or more proposals associated with an IKE policy.

To configure the proposals in an IKE policy, include the `proposals` statement and specify one or more proposal names at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
proposals [ proposal-names ];
```

Configuring the Preshared Key for an IKE Policy

When you include the `authentication-method pre-shared-keys` statement at the `[edit services ipsec-vpn ike proposal proposal-name]` hierarchy level, IKE policy preshared keys authenticate peers; for more information, see “Configuring the Authentication Method for an IKE Proposal” on page 219. You must manually configure a preshared key, which must match that of its peer. The preshared key can be an ASCII text (alphanumeric) key or a hexadecimal key.

To configure the preshared key in an IKE policy, include the `pre-shared-key` statement and a key at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
[edit services ipsec-vpn ike policy policy-name]
pre-shared-key (ascii-text key | hexadecimal key);
```

The key can be one of the following:

- **ascii-text**—ASCII text key. With the `des-cbc` option, the key contains 8 ASCII characters. With the `3des-cbc` option, the key contains 24 ASCII characters.
- **hexadecimal**—Hexadecimal key. With the `des-cbc` option, the key contains 16 hexadecimal characters. With the `3des-cbc` option, the key contains 48 hexadecimal characters.

Configuring the Local Certificate for an IKE Policy

When you include the `authentication-method rsa-signatures` statement at the `[edit services ipsec-vpn ike proposal proposal-name]` hierarchy level, public key infrastructure (PKI) digital certificates authenticate peers; for more information, see “Configuring the Authentication Method for an IKE Proposal” on page 219. You must identify a local certificate that is sent to the peer during the IKE authentication phase.

To configure the local certificate for an IKE policy, include the `local-certificate` statement at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
[edit services ipsec-vpn ike policy policy-name]
local-certificate identifier;
```

The `local-certificate` statement specifies the identifier used to obtain the end entity’s certificate from the certification authority. Configuring it in an IKE policy allows you the flexibility of using a separate certificate with each remote peer if that is needed. You must also specify the identity of the certification authority by configuring the `ca-profile` statement at the `[edit security pki]` hierarchy level; for more information, see the *JUNOS System Basics Configuration Guide*. For complete examples of digital certificate configuration, see the *JUNOS Feature Guide*.

You can use the configured profiles to establish a set of trusted certification authorities for use with a particular service set. This enables you to configure separate service sets for individual clients to whom you are providing IP services; the distinct service sets provide logical separation of one set of IKE sessions from another, using different local gateway addresses, or *virtualization*. To configure the set of trusted certification authorities, include the `trusted-ca` statement at the `[edit services service-set service-set-name ipsec-vpn-options]` hierarchy level:

```
[edit services service-set service-set-name ipsec-vpn-options]
trusted-ca ca-profile;
```

For more information, see “Configuring IPsec Service Sets” on page 448.

Configuring a Certificate Revocation List

A certificate revocation list (CRL) contains a list of digital certificates that have been cancelled before their expiration date. When a participating peer uses a digital certificate, it checks the certificate signature and validity. It also acquires the most recently issued CRL and checks that the certificate serial number is not on that CRL.



NOTE: By default, certificate revocation list verification is enabled. You can disable CRL verification by including the `disable` statement at the `[edit security pki ca-profile ca-profile-name revocation-check]` hierarchy level.

By default, if the router either cannot access the Lightweight Directory Access Protocol (LDAP) URL or retrieve a valid certificate revocation list, certificate verification fails and the IPsec tunnel is not established. To override this behavior and permit the authentication of the IPsec peer when the CRL is not downloaded, include the `disable on-download-failure` statement at the `[edit security pki ca-profile ca-profile-name revocation-check crl]` hierarchy level.

To use the CA certificate revocation list, you include statements at the `[edit security pki ca-profile ca-profile-name revocation-check]` hierarchy level. For details, see the *JUNOS System Basics Configuration Guide*.

Configuring the Description for an IKE Policy

To specify an optional text description for an IKE policy, include the `description` statement at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
[edit services ipsec-vpn ike policy policy-name]
description description;
```

Configuring Local and Remote IDs for IKE Phase 1 Negotiation

You can optionally specify local identifiers for use in IKE phase 1 negotiation. If the `local-id` statement is omitted, the local gateway address is used.

To specify one or more local IDs, include the `local-id` statement at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
[edit services ipsec-vpn ike policy policy-name]
local-id (ipv4_addr ipv4-address | ipv6_addr ipv6-address | key-id identifier);
```

You can also specify remote gateway identifiers for which the IKE policy is used. The remote gateway address in which this policy is defined is added by default.

To specify one or more remote IDs, include the `remote-id` statement at the `[edit services ipsec-vpn ike policy policy-name]` hierarchy level:

```
[edit services ipsec-vpn ike policy policy-name]
remote-id {
  any-remote-id;
  ipv4_addr [ values ];
  ipv6_addr [ values ];
  key_id [ values ];
}
```

The `any-remote-id` option allows any remote address to connect. This option is supported only in dynamic endpoints configurations and cannot be configured along

with specific values. For more information about dynamic endpoint configurations, see “Configuring Dynamic Endpoints for IPsec Tunnels” on page 237.

Example: Configuring an IKE Policy

Define two IKE policies: policy 10.1.1.2 and policy 10.1.1.1. Each policy is associated with proposal-1 and proposal-2.

```
[edit services ipsec-vpn]
ike {
  proposal proposal-1 {
    authentication-method pre-shared-keys;
    dh-group group1;
    authentication-algorithm sha1;
    encryption-algorithm 3des-cbc;
    lifetime-seconds 1000;
  }
  proposal proposal-2 {
    authentication-method pre-shared-keys;
    dh-group group2;
    authentication-algorithm md5;
    encryption-algorithm des-cbc;
    lifetime-seconds 10000;
  }
  proposal proposal-3 {
    authentication-method rsa-signatures;
    dh-group group2;
    authentication-algorithm md5;
    encryption-algorithm des-cbc;
    lifetime-seconds 10000;
  }
  policy 10.1.1.2 {
    mode main;
    proposals [ proposal-1 proposal-2 ];
    pre-shared-key ascii-text example-pre-shared-key;
  }
  policy 10.1.1.1 {
    local-certificate certificate-file-name;
    local-key-pair private-public-key-file;
    mode aggressive;
    proposals [ proposal-2 proposal-3 ];
    pre-shared-key hexadecimal 0102030abbcd;
  }
}
```



NOTE: Updates to the current IKE proposal and policy configuration are not applied to the current IKE SA; updates are applied to new IKE SAs.

If you want the new updates to take immediate effect, you must clear the existing IKE security associations so that they will be reestablished with the changed configuration. For information about how to clear the current IKE security association, see the *JUNOS System Basics and Services Command Reference*.

Configuring IPsec Proposals

An IPsec proposal lists protocols and algorithms (security services) to be negotiated with the remote IPsec peer.

To configure an IPsec proposal, include the **proposal** statement and specify an IPsec proposal name at the [edit services ipsec-vpn ipsec] hierarchy level:

```
[edit services ipsec-vpn ipsec]
proposal proposal-name {
  authentication-algorithm (hmac-md5-96 | hmac-sha1-96);
  description description;
  encryption-algorithm algorithm;
  lifetime-seconds seconds;
  protocol (ah | esp | bundle);
}
```

This section discusses the following topics:

- Configuring the Authentication Algorithm for an IPsec Proposal on page 227
- Configuring the Description for an IPsec Proposal on page 227
- Configuring the Encryption Algorithm for an IPsec Proposal on page 228
- Configuring the Lifetime for an IPsec SA on page 228
- Configuring the Protocol for a Dynamic SA on page 229

Configuring the Authentication Algorithm for an IPsec Proposal

To configure the authentication algorithm for an IPsec proposal, include the **authentication-algorithm** statement at the [edit services ipsec-vpn ipsec proposal *proposal-name*] hierarchy level:

```
[edit services ipsec-vpn ipsec proposal proposal-name]
authentication-algorithm (hmac-md5-96 | hmac-sha1-96);
```

The authentication algorithm can be one of the following:

- **hmac-md5-96**—Hash algorithm that authenticates packet data. It produces a 128-bit digest. Only 96 bits are used for authentication.
- **hmac-sha1-96**—Hash algorithm that authenticates packet data. It produces a 160-bit digest. Only 96 bits are used for authentication.

Configuring the Description for an IPsec Proposal

To specify an optional text description for an IPsec proposal, include the **description** statement at the [edit services ipsec-vpn ipsec proposal *proposal-name*] hierarchy level:

```
[edit services ipsec-vpn ipsec proposal proposal-name]
description description;
```

Configuring the Encryption Algorithm for an IPsec Proposal

To configure encryption algorithm for an IPsec proposal, include the `encryption-algorithm` statement at the `[edit services ipsec-vpn ipsec proposal proposal-name]` hierarchy level:

```
[edit services ipsec-vpn ipsec proposal proposal-name]
  encryption-algorithm algorithm;
```

The encryption algorithm can be one of the following:

- **3des-cbc**—Encryption algorithm that has a block size of 24 bytes; its key size is 192 bits long.
- **des-cbc**—Encryption algorithm that has a block size of 8 bytes; its key size is 48 bits long.
- **aes-128-cbc**—Advanced Encryption Standard (AES) 128-bit encryption algorithm.
- **aes-192-cbc**—Advanced Encryption Standard (AES) 192-bit encryption algorithm.
- **aes-256-cbc**—Advanced Encryption Standard (AES) 256-bit encryption algorithm.



NOTE: For a list of Data Encryption Standard (DES) encryption algorithm weak and semiweak keys, see RFC 2409, *The Internet Key Exchange (IKE)*. The AES encryption algorithms use a software implementation that has much lower throughput, so DES remains the recommended option.

For **3des-cbc**, the first 8 bytes should differ from the second 8 bytes, and the second 8 bytes should be the same as the third 8 bytes.

If you configure an authentication proposal but do not include the **encryption** statement, the result is NULL encryption. Certain applications expect this result. If you configure no specific authentication or encryption values, the JUNOS software uses the default values of **sha1** for the authentication and **3des-cbc** for the encryption.

Configuring the Lifetime for an IPsec SA

When a dynamic IPsec SA is created, two types of lifetimes are used: hard and soft. The hard lifetime specifies the lifetime of the SA. The soft lifetime, which is derived from the hard lifetime, informs the IPsec key management system that the SA is about to expire. This allows the key management system to negotiate a new SA before the hard lifetime expires.

To configure the hard lifetime value, include the `lifetime-seconds` statement and specify the number of seconds at the `[edit services ipsec-vpn ipsec proposal proposal-name]` hierarchy level:

```
[edit services ipsec-vpn ipsec proposal proposal-name]
  lifetime-seconds seconds;
```

The default lifetime is 28,800 seconds. The range is from 180 through 86,400 seconds.

The soft lifetime values are as follows:

- Initiator: Soft lifetime = Hard lifetime – 135 seconds.
- Responder: Soft lifetime = Hard lifetime – 90 seconds.

Configuring the Protocol for a Dynamic SA

The **protocol** statement sets the protocol for a dynamic SA. IPsec uses two protocols to protect IP traffic: ESP and AH. The ESP protocol can support authentication, encryption, or both. The AH protocol is used for strong authentication. AH also authenticates the IP packet. The **bundle** option uses AH authentication and ESP encryption; it does not use ESP authentication because AH provides stronger authentication of IP packets.

To configure the protocol for a dynamic SA, include the **protocol** statement and specify the **ah**, **esp**, or **bundle** option at the [edit services ipsec-vpn ipsec proposal *proposal-name*] hierarchy level:

```
[edit services ipsec-vpn ipsec proposal proposal-name]
protocol (ah | esp | bundle);
```

Configuring IPsec Policies

An IPsec policy defines a combination of security parameters (IPsec proposals) used during IPsec negotiation. It defines Perfect Forward Secrecy (PFS) and the proposals needed for the connection. During the IPsec negotiation, IPsec looks for a proposal that is the same on both peers. The peer that initiates the negotiation sends all its policies to the remote peer, and the remote peer tries to find a match.

A match is made when both policies from the two peers have a proposal that contains the same configured attributes. If the lifetimes are not identical, the shorter lifetime between the two policies (from the host and peer) is used.

You can create multiple, prioritized IPsec proposals at each peer to ensure that at least one proposal matches a remote peer's proposal.

First, you configure one or more IPsec proposals; then you associate these proposals with an IPsec policy. You can prioritize a list of proposals used by IPsec in the **policy** statement by listing the proposals you want to use, from first to last.

To configure an IPsec policy, include the **policy** statement, and specify the policy name and one or more proposals to associate with the policy, at the [edit services ipsec-vpn ipsec] hierarchy level:

```
[edit services ipsec-vpn ipsec]
policy policy-name {
  description description;
  perfect-forward-secrecy {
    keys (group1 | group2);
  }
}
```

```

    proposals [ proposal-names ];
}

```

This section includes the following topics related to configuring an IPsec policy:

- Configuring the Description for an IPsec Policy on page 230
- Configuring Perfect Forward Secrecy on page 230
- Configuring the Proposals in an IPsec Policy on page 230
- Example: Configuring an IPsec Policy on page 231

Configuring the Description for an IPsec Policy

To specify an optional text description for an IPsec policy, include the **description** statement at the [edit services ipsec-vpn ipsec policy *policy-name*] hierarchy level:

```

[edit services ipsec-vpn ipsec policy policy-name]
description description;

```

Configuring Perfect Forward Secrecy

PFS provides additional security by means of a Diffie-Hellman shared secret value. With PFS, if one key is compromised, previous and subsequent keys are secure because they are not derived from previous keys. This statement is optional.

To configure PFS, include the **perfect-forward-secrecy** statement and specify a Diffie-Hellman group at the [edit services ipsec-vpn ipsec policy *policy-name*] hierarchy level:

```

[edit services ipsec-vpn ipsec policy policy-name]
perfect-forward-secrecy {
    keys (group1 | group2);
}

```

The key can be one of the following:

- **group1**—Specifies that IKE use the 768-bit Diffie-Hellman prime modulus group when performing the new Diffie-Hellman exchange.
- **group2**—Specifies that IKE use the 1024-bit Diffie-Hellman prime modulus group when performing the new Diffie-Hellman exchange.

group2 provides more security than **group1**, but requires more processing time.

Configuring the Proposals in an IPsec Policy

The IPsec policy includes a list of one or more proposals associated with an IPsec policy.

To configure the proposals in an IPsec policy, include the **proposals** statement and specify one or more proposal names at the [edit services ipsec-vpn ipsec policy *policy-name*] hierarchy level:

```
[edit services ipsec-vpn ipsec policy policy-name]
proposals [ proposal-names ];
```

Example: Configuring an IPsec Policy

Define an IPsec policy, dynamic policy-1, that is associated with two proposals (dynamic-1 and dynamic-2):

```
[edit services ipsec-vpn ipsec]
proposal dynamic-1 {
  protocol esp;
  authentication-algorithm hmac-md5-96;
  encryption-algorithm 3des-cbc;
  lifetime-seconds 6000;
}
proposal dynamic-2 {
  protocol esp;
  authentication-algorithm hmac-sha1-96;
  encryption-algorithm 3des-cbc;
  lifetime-seconds 6000;
}
policy dynamic-policy-1 {
  perfect-forward-secrecy {
    keys group1;
  }
  proposals [ dynamic-1 dynamic-2 ];
}
```



NOTE: Updates to the current IPsec proposal and policy configuration are not applied to the current IPsec SA; updates are applied to new IPsec SAs.

If you want the new updates to take immediate effect, you must clear the existing IPsec security associations so that they will be reestablished with the changed configuration. For information about how to clear the current IPsec security association, see the *JUNOS System Basics and Services Command Reference*.

Configuring IPsec Rules

To configure an IPsec rule, include the **rule** statement and specify a rule name at the [edit services ipsec-vpn] hierarchy level:

```
[edit services ipsec-vpn]
rule rule-name {
  match-direction (input | output);
  term term-name {
    from {
      destination-address address;
      ipsec-inside-interface interface-name;
      source-address address;
    }
    then {
```

```

        backup-remote-gateway address;
        clear-dont-fragment-bit;
        dynamic {
            ike-policy policy-name;
            ipsec-policy policy-name;
        }
        initiate-dead-peer-detection;
        manual {
            direction (inbound | outbound | bidirectional) {
                authentication {
                    algorithm (hmac-md5-96 | hmac-sha1-96);
                    key (ascii-text key | hexadecimal key);
                }
                auxiliary-spi spi-value;
                encryption {
                    algorithm algorithm;
                    key (ascii-text key | hexadecimal key);
                }
                protocol (ah | bundle | esp);
                spi spi-value;
            }
        }
        no-anti-replay;
        remote-gateway address;
        syslog;
        tunnel-mtu bytes;
    }
}

```

Each IPsec rule consists of a set of terms, similar to a firewall filter. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software.

The following sections explain how to configure the components of IPsec rules:

- [Configuring Match Direction for IPsec Rules on page 232](#)
- [Configuring Match Conditions in IPsec Rules on page 233](#)
- [Configuring Actions in IPsec Rules on page 234](#)

Configuring Match Direction for IPsec Rules

Each rule must include a **match-direction** statement that specifies whether the match is applied on the input or output side of the interface. To configure where the match is applied, include the **match-direction (input | output)** statement at the **[edit services ipsec-vpn rule *rule-name*]** hierarchy level:

```

[edit services ipsec-vpn rule rule-name]
match-direction (input | output);

```


The match direction is used with respect to the traffic flow through the AS or MultiServices PIC. When a packet is sent to the PIC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the AS or MultiServices PIC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the PIC, the packet direction is output. For more information on inside and outside interfaces, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

On the AS or MultiServices PIC, a flow lookup is performed. If no flow is found, rule processing is performed. All rules in the service set are considered. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that match the packet direction are considered.

Configuring Match Conditions in IPsec Rules

To configure the match conditions in an IPsec rule, include the **from** statement at the [edit services ipsec-vpn rule *rule-name* term *term-name*] hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name]
from {
    destination-address address;
    ipsec-inside-interface interface-name;
    source-address address;
}
```

You can use either the source address or the destination address as a match condition, in the same way that you would configure a firewall filter; for more information, see the *JUNOS Policy Framework Configuration Guide*.

IPsec services support both IPv4 and IPv6 address formats. If you do not specifically configure either the source address or destination address, the default value 0.0.0.0/0 (IPv4 ANY) is used. To use IPv6 ANY (0::0/128) as either source or destination address, you must configure it explicitly.

For next-hop-style service sets only, the **ipsec-inside-interface** statement allows you to assign a logical interface to the tunnels established as a result of this match condition. The **inside-service-interface** statement that you can configure at the [edit services service-set *name* next-hop-service] hierarchy level allows you to specify .1 and .2 as inside and outside interfaces. However, you can configure multiple adaptive services logical interfaces with the **service-domain inside** statement and use one of them to configure the **ipsec-inside-interface** statement. For more information, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444 and “Service Interface Configuration Guidelines” on page 475.

The JUNOS software evaluates the criteria you configure in the **from** statement. If multiple link-type tunnels are configured within the same next-hop-style service set, the **ipsec-inside-interface** value enables the rule lookup module to distinguish a

particular tunnel from other tunnels in case the source and destination addresses for all of them are 0.0.0.0/0 (ANY-ANY).



NOTE: When you configure the `ipsec-inside-interface` statement, interface-style service sets are not supported.

Configuring Actions in IPsec Rules

To configure actions in an IPsec rule, include the `then` statement at the `[edit services ipsec-vpn rule rule-name term term-name]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name]
then {
  backup-remote-gateway address;
  clear-dont-fragment-bit;
  dynamic {
    ike-policy policy-name;
    ipsec-policy policy-name;
  }
  initiate-dead-peer-detection;
  manual {
    direction (inbound | outbound | bidirectional) {
      authentication {
        algorithm (hmac-md5-96 | hmac-sha1-96);
        key (ascii-text key | hexadecimal key);
      }
      auxiliary-spi spi-value;
      encryption {
        algorithm algorithm;
        key (ascii-text key | hexadecimal key);
      }
      protocol (ah | bundle | esp);
      spi spi-value;
    }
  }
  no-anti-replay;
  remote-gateway address;
  syslog;
  tunnel-mtu bytes;
}
```

The principal IPsec actions are to configure a dynamic or manual SA:

- You configure a dynamic SA by including the `dynamic` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level and referencing policies you have configured at the `[edit services ipsec-vpn ipsec]` and `[edit services ipsec-vpn ike]` hierarchy levels; for more information, see “Configuring Dynamic Security Associations” on page 217.
- You configure a manual SA by including the `manual` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level; for more information, see “Configuring Manual Security Associations” on page 213.

You can configure the following additional properties:

- Enabling IPsec Packet Fragmentation on page 235
- Configuring Destination Addresses for Dead Peer Detection on page 235
- Disabling IPsec Anti-Replay on page 236
- Enabling System Log Messages on page 237
- Specifying the MTU for IPsec Tunnels on page 237

Enabling IPsec Packet Fragmentation

To enable fragmentation of IP version 4 (IPv4) packets in IPsec tunnels, include the `clear-dont-fragment-bit` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
clear-dont-fragment-bit;
```

Setting the `clear-dont-fragment-bit` statement clears the Don't Fragment (DF) bit in the packet header, regardless of the packet size. If the packet size exceeds the tunnel maximum transmission unit (MTU) value, the packet is fragmented before encapsulation. For IPsec tunnels, the default MTU value is 1500 regardless of the interface MTU setting.

Configuring Destination Addresses for Dead Peer Detection

To specify the remote address to which the IPsec traffic is directed, include the `remote-gateway` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
remote-gateway address;
```

To specify a backup remote address, include the `backup-remote-gateway` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
backup-remote-gateway address;
```

These two statements support both IPv4 and IPv6 address formats.

Configuring the `backup-remote-gateway` statement enables the dead peer detection (DPD) protocol, which monitors the tunnel state and remote peer availability. When the primary tunnel defined by the `remote-gateway` statement is active, the backup tunnel is in standby mode. If the DPD protocol determines that the primary remote gateway address is no longer reachable, a new tunnel is established to the backup address.



NOTE: Configuration of the `backup-remote-gateway` statement is not supported on J-series Services Routers. These routers cannot send DPD Hello messages but can respond to Hello messages sent by the peer.

If there is no incoming traffic from a peer during a defined interval of 10 seconds, the router detects a tunnel as inactive. A global timer polls all tunnels every 10 seconds and the Adaptive Services (AS) or MultiServices Physical Interface Card (PIC) sends a message listing any inactive tunnels. If a tunnel becomes inactive, the router takes the following steps to failover to the backup address:

1. The adaptive services message triggers the DPD protocol to send a hello message to the peer.
2. If no acknowledgment is received, two retries are sent at 2-second intervals, and then the tunnel is declared dead.
3. Failover takes place if the tunnel is declared dead or there is an IPsec Phase 1 negotiation timeout. The primary tunnel is put in standby mode and the backup becomes active.
4. If the negotiation to the backup tunnel times out, the router switches back to the primary tunnel. If both peers are down, it tries the failover six times. It then stops failing over and reverts to the original configuration, with the primary tunnel active and the backup in standby mode.

You can also enable triggering of DPD Hello messages without configuring a backup remote gateway by including the `initiate-dead-peer-detection` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
initiate-dead-peer-detection;
```

The monitoring behavior is the same as described for the `backup-remote-gateway` statement. This configuration enables the router to initiate DPD Hellos when a backup IPsec gateway does not exist and clean up the IKE and IPsec SAs in case the IKE peer is not reachable.

If the DPD protocol determines that the primary remote gateway address is no longer reachable, a new tunnel is established to the backup address. However, when you configure `initiate-dead-peer-detection` without a backup remote gateway address and the DPD protocol determines that the primary remote gateway address is no longer reachable, the tunnel is declared dead and IKE and IPsec SAs are cleaned up.

For more information on the DPD protocol, see RFC 3706, *A Traffic-Based Method of Detecting Dead Internet Key Exchange (IKE) Peers*.

Disabling IPsec Anti-Replay

To disable the IPsec anti-replay feature, include the `no-anti-replay` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
no-anti-replay;
```

By default, anti-replay service is enabled. Occasionally this can cause interoperability issues with other vendors' equipment.

Enabling System Log Messages

To record an alert in the system logging facility, include the `syslog` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
syslog;
```

Specifying the MTU for IPsec Tunnels

To configure a specific maximum transmission unit (MTU) value for IPsec tunnels, include the `tunnel-mtu` statement at the `[edit services ipsec-vpn rule rule-name term term-name then]` hierarchy level:

```
[edit services ipsec-vpn rule rule-name term term-name then]
tunnel-mtu bytes;
```



NOTE: The `tunnel-mtu` setting is the only place you need to configure an MTU value for IPsec tunnels. Inclusion of an `mtu` setting at the `[edit interfaces sp-fpc/pic/port unit logical-unit-number family inet]` hierarchy level is not supported.

Configuring IPsec Rule Sets

The `rule-set` statement defines a collection of IPsec rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the `rule-set` statement at the `[edit services ipsec-vpn]` hierarchy level with a `rule` statement for each rule:

```
[edit services ipsec-vpn]
rule-set rule-set-name {
    rule rule-name;
}
```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

Configuring Dynamic Endpoints for IPsec Tunnels

IPsec tunnels can also be established using *dynamic peer* security gateways, in which the remote ends of tunnels do not have a statically assigned IP address. Since the remote address is not known and might be pulled from an address pool each time the remote host reboots, establishment of the tunnel relies on using IKE `main` mode with either preshared global keys or digital certificates that accept any remote identification value. For more information on IKE policy modes, see “Configuring

the Mode for an IKE Policy” on page 223. Both policy-based and link-type tunnels are supported:

- Policy-based tunnels used shared mode.
- Link-type or routed tunnels use dedicated mode. Each tunnel allocates a service interface from a pool of interfaces configured for the dynamic peers. Routing protocols can be configured to run on these service interfaces to learn routes over the IPsec tunnel that is used as a link in this scenario.

This section includes the following topics:

- Authentication Process on page 238
- Implicit Dynamic Rules on page 239
- Reverse Route Insertion on page 239
- Configuring an IKE Access Profile on page 240
- Referencing the IKE Access Profile in a Service Set on page 241
- Configuring the Interface Identifier on page 242
- Default IKE and IPsec Proposals on page 242

Authentication Process

The remote (dynamic peer) initiates the negotiations with the local (Juniper Networks) router. The local router uses the default IKE and IPsec policies to match the proposals sent by the remote peer to negotiate the SA values. Implicit proposals contain a list of all the supported transforms that the local router expects from all the dynamic peers.

If preshared key authentication is used, the preshared key is global for a service set. When seeking the preshared key for the peer, the local router matches the peer’s source address against any explicitly configured preshared keys in that service set. If a match is not found, the local router uses the global preshared key for authentication. This key is the one configured in the IKE access profile referenced by the service set.

Phase 2 of the authentication matches the *proxy identities* of the protected hosts and networks sent by the peer against a list of configured proxy identities. The accepted proxy identity is used to create the dynamic rules for encrypting the traffic. You can configure proxy identities by including the **allowed-proxy-pair** statement in the IKE access profile. If no entry matches, the negotiation is rejected.

If you do not configure the **allowed-proxy-pair** statement, the default value “ANY(0.0.0.0/0)-ANY” is applied, and the local router accepts any proxy identities sent by the peer. Both IPv4 and IPv6 addresses are accepted, but you must configure all IPv6 addresses manually.

Once the phase 2 negotiation completes successfully, the router builds the dynamic rules and inserts the reverse route into the routing table using the accepted proxy identity.

Implicit Dynamic Rules

After successful negotiation with the dynamic peer, the key management process (kmd) creates a dynamic rule for the accepted phase 2 proxy and applies it on the local AS or MultiServices PIC. The source and destination addresses are specified by the accepted proxy. This rule is used to encrypt traffic directed to one of the end hosts in the phase 2 proxy identity.

The dynamic rule includes an **ipsec-inside-interface** value, which is the interface name assigned to the dynamic tunnel. The **source-address** and **destination-address** values are accepted from the proxy ID. The **match-direction** value is **input** for next-hop-style service sets.



NOTE: You do not configure this rule; it is created by the key management process (kmd).

Rule lookup for static tunnels is unaffected by the presence of a dynamic rule; it is performed in the order configured. When a packet is received for a service set, static rules are always matched first.

Dynamic rules are matched after the rule match for static rules has failed.

Response to dead peer detection (DPD) hello messages takes place the same way with dynamic peers as with static peers. Initiating DPD hello messages from dynamic peers is not supported. For more information on DPD, see “Configuring Destination Addresses for Dead Peer Detection” on page 235.

Reverse Route Insertion

Static routes are automatically inserted into the route table for those networks and hosts protected by a remote tunnel endpoint. These protected hosts and networks are known as remote proxy identities.

Each route is created based on the remote proxy network and mask sent by the peer and is inserted in the relevant route table after successful phase 1 and phase 2 negotiations.

The route preference for each static reverse route is 1. This value is necessary to avoid conflict with similar routes that might be added by the routing protocol process (rpd).

No routes are added if the accepted remote proxy address is the default (0.0.0.0/0). In this case you can run routing protocols over the IPsec tunnel to learn routes and add static routes for the traffic you want to be protected over this tunnel.

For next-hop style service sets, the reverse routes include next hops pointing to the locations specified by the **inside-service-interface** statement.

The route table in which to insert these routes depends on where the **inside-service-interface** location is listed. If these interfaces are present in a VPN routing

and forwarding (VRF) instance, then routes are added to the corresponding VRF table; otherwise, the routes are added to `inet.0`.



NOTE: Reverse route insertion takes place only for tunnels to dynamic peers. These routes are added only for next-hop style service sets.

Configuring an IKE Access Profile

You can configure only one tunnel profile per service set for all dynamic peers. The configured preshared key in the profile is used for IKE authentication of all dynamic peers terminating in that service set. Alternatively, you can include the `ike-policy` statement to reference an IKE policy you define with either specific identification values or a wildcard (the `any-remote-id` option). You configure the IKE policy at the `[edit services ipsec-vpn ike]` hierarchy level; for more information, see “Configuring IKE Policies” on page 221.

The IKE tunnel profile specifies all the information needed to complete the IKE negotiation. Each protocol has its own statement hierarchy within the client statement to configure protocol-specific attribute value pairs, but only one client configuration is allowed for each profile. The following is the configuration at the `[edit access]` hierarchy level; for more information on access profiles, see the *JUNOS System Basics Configuration Guide*.

```
[edit access]
profile profile-name {
  client * {
    ike {
      allowed-proxy-pair {
        remote remote-proxy-address local local-proxy-address;
      }
      pre-shared-key (ascii-text key-string | hexadecimal key-string);
      ike-policy policy-name;
      interface-id <string-value>;
    }
  }
}
```



NOTE: For dynamic peers, the JUNOS software supports the IKE main mode with either the preshared key method of authentication or an IKE access profile that uses a local digital certificate.

- In preshared key mode, the IP address is used to identify a tunnel peer to get the preshared key information. The `client` value `*` (wildcard) means that configuration within this profile is valid for all dynamic peers terminating within the service set accessing this profile.
- In digital certificate mode, the IKE policy defines which remote identification values are allowed; for more information, see “Configuring IKE Policies” on page 221.

The following statements make up the IKE profile:

- **allowed-proxy-pair**—During phase 2 IKE negotiation, the remote peer supplies its network address (**remote**) and its peer's network address (**local**). Since multiple dynamic tunnels are authenticated through the same mechanism, this statement must include the list of possible combinations. If the dynamic peer does not present a valid combination, the phase 2 IKE negotiation fails.

By default, **remote 0.0.0.0/0 local 0.0.0.0/0** is used if no values are configured. Both IPv4 and IPv6 address formats are supported in this configuration, but there are no default IPv6 addresses. You must specify even **0::0/0**.

- **pre-shared-key**—Key used to authenticate the dynamic peer during IKE phase 1 negotiation. This key is known to both ends through an out-of-band secure mechanism. You can configure the value either in **hexadecimal** or **ascii-text** format. It is a mandatory value.
- **ike-policy**—Policy that defines the remote identification values corresponding to the allowed dynamic peers; can contain a wildcard value **any-remote-id** for use in dynamic endpoint configurations only.
- **interface-id**—Interface identifier, a mandatory attribute used to derive the logical service interface information for the session.

Referencing the IKE Access Profile in a Service Set

To complete the configuration, you need to reference the IKE access profile configured at the **[edit access]** hierarchy level. To do this, include the **ike-access-profile** statement at the **[edit services service-set name ipsec-vpn-options]** hierarchy level:

```
[edit services service-set name]
ipsec-vpn-options {
    local-gateway address;
    ike-access-profile profile-name;
}
next-hop-service {
    inside-service-interface interface-name;
    outside-service-interface interface-name;
}
}
```

The **ike-access-profile** statement must reference the same name as the **profile** statement you configured for IKE access at the **[edit access]** hierarchy level. You can reference only one access profile in each service set. This profile is used to negotiate IKE and IPsec security associations with dynamic peers only.



NOTE: If you configure an IKE access profile in a service set, no other service set can share the same **local-gateway** address.

Also, you must configure a separate service set for each VRF. All interfaces referenced by the **ipsec-inside-interface** statement within a service set must belong to the same VRF.

Configuring the Interface Identifier

You can configure an interface identifier for a group of dynamic peers, which specifies which adaptive services logical interface(s) take part in the dynamic IPsec negotiation. By assigning the same interface identifier to multiple logical interfaces, you can create a pool of interfaces for this purpose. To configure an interface identifier, include the `ipsec-interface-id` statement and the `dedicated` or `shared` statement at the `[edit interfaces interface-name unit logical-unit-number dial-options]` hierarchy level:

```
[edit interfaces interface-name unit logical-unit-number dial-options]
ipsec-interface-id identifier;
(dedicated | shared);
```

Specifying the interface identifier in the `dial-options` statement makes this logical interface part of the pool identified by the `ipsec-interface-id` statement.



NOTE: Only one interface identifier can be specified at a time. You can include the `ipsec-interface-id` statement or the `l2tp-interface-id` statement, but not both.

If you configure `shared` mode, it enables one logical interface to be shared across multiple tunnels. The `dedicated` statement specifies that the logical interface is used in a dedicated mode, which is necessary when you are configuring an IPsec link-type tunnel. You must include the `dedicated` statement when you specify an `ipsec-interface-id` value.

Default IKE and IPsec Proposals

The software includes implicit default IKE and IPsec proposals to match the proposals sent by the dynamic peers. The values are shown in; if more than one value is shown, the first value is the default. For more information on IKE proposals, see “Configuring IKE Proposals” on page 218; for more information on IPsec proposals, see “Configuring IPsec Proposals” on page 227.



NOTE: RSA certificates are not supported with dynamic endpoint configuration.

Table 12: Default IKE and IPsec Proposals for Dynamic Negotiations

Statement Name	Values
Implicit IKE Proposal	
authentication-method	pre-shared keys
dh-group	group1, group2
authentication-algorithm	sha1, md5, sha-256
encryption-algorithm	3des-cbc, des-cbc, aes-128, aes-192, aes-256

Table 12: Default IKE and IPsec Proposals for Dynamic Negotiations (*continued*)

Statement Name	Values
lifetime-seconds	3600 seconds
Implicit IPsec Proposal	
protocol	esp, ah, bundle
authentication-algorithm	hmac-sha1-96, hmac-md5-96
encryption-algorithm	3des-cbc, des-cbc, aes-128, aes-192, aes-256
lifetime-seconds	28,800 seconds (8 hours)

Tracing IPsec Operations

Trace operations track IPsec events and record them in a log file in the `/var/log` directory. By default, this file is named `/var/log/kmd`.

To trace IPsec operations, include the `traceoptions` statement at the `[edit services ipsec-vpn]` hierarchy level:

```
[edit services ipsec-vpn]
traceoptions {
  file <filename> <files number> <match regular-expression> <size bytes>
    <world-readable | no-world-readable>;
  flag flag;
  no-remote-trace;
}
```

You can specify the following IPsec tracing flags:

- `all`—Trace everything.
- `certificates`—Trace certificates events.
- `database`—Trace security associations database events.
- `general`—Trace general events.
- `ike`—Trace IKE module processing.
- `parse`—Trace configuration processing.
- `policy-manager`—Trace policy manager processing.
- `routing-socket`—Trace routing socket messages.
- `snmp`—Trace SNMP operations.
- `timer`—Trace internal timer events.

Examples: Configuring IPsec Services

See the following sections:

- Example: Configuring Statically Assigned Tunnels on page 244
- Example: Configuring Dynamically Assigned Tunnels on page 247

Example: Configuring Statically Assigned Tunnels

Following is the configuration of the provider edge (PE) router, demonstrating the usage of next-hop service sets and dynamic SA configuration:

```
[edit interfaces]
so-0/0/0 {
  no-keepalives;
  encapsulation cisco-hdlc;
  unit 0 {
    family inet {
      address 10.6.6.6/32;
    }
  }
}
so-2/2/0 {
  description "teller so-0/2/0";
  no-keepalives;
  encapsulation cisco-hdlc;
  unit 0 {
    family inet {
      address 10.21.1.1/16;
    }
  }
}
sp-3/1/0 {
  unit 0 {
    family inet {
      address 10.7.7.7/32;
    }
  }
  unit 1 {
    family inet;
    service-domain inside;
  }
  unit 2 {
    family inet;
    service-domain outside;
  }
}
[edit policy-options]
policy-statement vpn-export {
  then {
    community add vpn-comm;
    accept;
  }
}
```

```

}
policy-statement vpn-import {
  term a {
    from community vpn-comm;
    then accept;
  }
}
community vpn-comm members target:100:20;
[edit routing-instances]
vrf {
  instance-type vrf;
  interface sp-3/1/0.1; # Inside sp interface
  interface so-0/0/0.0;
  route-distinguisher 192.168.0.1:1;
  vrf-import vpn-import;
  vrf-export vpn-export;
  routing-options {
    static {
      route 10.0.0.0/0 next-hop so-0/0/0.0;
      route 10.11.11.1/32 next-hop so-0/0/0.0;
      route 10.8.8.1/32 next-hop sp-3/1/0.1;
    }
  }
}
[edit services]
ipsec-vpn {
  rule rule-1 {
    term term-1 {
      then {
        remote-gateway 10.21.2.1;
        dynamic {
          ike-policy ike-policy;
        }
      }
    }
    match-direction input;
  }
  ike {
    policy ike-policy {
      pre-shared-key ascii-text "$9$ExmcSeMWxdVYBI";
    }
  }
}
service-set service-set-1 {
  ipsec-vpn {
    local-gateway 10.21.1.1;
  }
  ipsec-vpn-rules rule-1;
  next-hop-service {
    inside-service-interface sp-3/1/0.1;
    outside-service-interface sp-3/1/0.2;
  }
}

```

Following is an example for configuring multiple link-type tunnels to static peers using a single next-hop style service set:

```

services ipsec-vpn {
  rule demo-rule {
    term term-0 {
      from {
        ipsec-inside-interface sp-0/0/0.1;
      }
      then {
        remote-gateway 10.2.2.2;
        dynamic {
          ike-policy demo-ike-policy;
        }
      }
    }
    term term-1 {
      from {
        ipsec-inside-interface sp-0/0/0.3;
      }
      then {
        remote-gateway 10.3.3.3;
        dynamic {
          ike-policy demo-ike-policy;
        }
      }
    }
  }
  match-direction input;
}
services {
  service-set demo-service-set {
    next-hop-service {
      inside-service-interface sp-0/0/0.1;
      outside-service-interface sp-0/0/0.2;
    }
    ipsec-vpn-options {
      local-gateway 10.1.1.1;
    }
    ipsec-rules demo-rule;
  }
}
interfaces sp-0/0/0 {
  unit 0 {
    family inet;
  }
  unit 1 {
    family inet;
    service-domain inside;
  }
  unit 2 {
    family inet;
    service-domain outside;
  }
  unit 3 {
    family inet;
    service-domain inside;
  }
  unit 4 {

```

```

    family inet;
    service-domain inside;
  }
}


```

Example: Configuring Dynamically Assigned Tunnels

The following examples are based on this network configuration (see Figure 3 on page 247):

- A local network N-1 behind security gateway SG-1, a Juniper Networks router terminating static as well as dynamic peer endpoints. The tunnel termination address on SG-1 is 10.1.1.1 and the local network address is 172.16.1.0/24.
- Two remote peer routers that obtain addresses from an ISP pool and run RFC-compliant IKE. Remote network N-2 has address 172.16.2.0/24 and resides behind security gateway SG-2 with tunnel termination address 10.2.2.2. Remote network N-3 has address 172.16.3.0/24 and resides behind security gateway SG-3 with tunnel termination address 10.3.3.3.

Figure 3: IPsec Dynamic Endpoint Tunneling Topology



The examples in this section show the following configurations:

- Configuring a Next-Hop Style Service Set with Link-Type Tunnels on page 247
- Configuring a Next-Hop Style Service-Set with Policy-Based Tunnels on page 249



NOTE: All the configurations are given for the Juniper Networks router terminating dynamic endpoint connections.

Configuring a Next-Hop Style Service Set with Link-Type Tunnels

```

access {
  profile demo-access-profile client * {
    ike {
      allowed-proxy-pair {
        remote 0.0.0.0/0 local 0.0.0.0/0; # ANY to ANY
      }
      pre-shared-key {
        ascii-text keyfordynamicpeers;
      }
      interface-id demo-ipsec-interface-id;
    }
  }
}

```

```

    }
  }
  services {
    service-set demo-service-set {
      next-hop-service {
        inside-service-interface sp-1/0/0.1;
        outside-service-interface sp-1/0/0.2;
      }
      ipsec-vpn-options {
        local-gateway 10.1.1.1;
        ike-access-profile demo-ike-access-profile;
      }
    }
  }
}

```



NOTE: Including the `ike-access-profile` statement enables the software to incorporate implicit proposals for dynamic endpoint authentication. You do not need to configure IKE or IPsec proposals explicitly.

```

interfaces {
  sp-0/0/0 {
    unit 0 {
      family inet;
    }
    unit 1 {
      family inet;
      service-domain inside;
    }
    unit 2 {
      family inet;
      service-domain outside;
    }
    unit 3 {
      family inet;
      service-domain inside;
      dial-options {
        ipsec-interface-id demo-ipsec-interface-id;
        dedicated;
      }
    }
    unit 4 {
      family inet;
      service-domain inside;
      dial-options {
        ipsec-interface-id demo-ipsec-interface-id;
        dedicated;
      }
    }
  }
}

```


The following results are obtained:

- Reverse routes inserted after successful negotiation:

None
- Routes learned by routing protocol:

172.16.2.0/24

172.16.3.0/24
- Dynamic implicit rules created after successful negotiation:


```
rule: junos-dynamic-rule-0
term: term-0
  local-gateway-address : 10.1.1.1 #Tunnel termination address on SG-1
  remote-gateway-address: 10.2.2.2 #Tunnel termination address on SG-2
  source-address : 0.0.0.0/0
  destination-address : 0.0.0.0/0
  ipsec-inside-interface: sp-0/0/0.3
term: term-1
  local-gateway-address : 10.1.1.1 #Tunnel termination address on SG-1
  remote-gateway-address: 10.3.3.3 #Tunnel termination address on SG-3
  source-address : 0.0.0.0/0
  destination-address : 0.0.0.0/0
  ipsec-inside-interface: sp-0/0/0.4
  match-direction: input
```

Configuring a Next-Hop Style Service-Set with Policy-Based Tunnels

```
access {
  profile demo-access-profile client * {
    ike {
      allowed-proxy-pair {
        remote 172.16.2.0/24 local 172.16.1.0/24; #N-2 <==> #N-1
        remote 172.16.3.0/24 local 172.16.1.0/24; #N-3 <==> #N-1
      }
      pre-shared-key {
        ascii-text keyfordynamicpeers;
      }
      interface-id demo-ipsec-interface-id;
    }
  }
}
services {
  service-set demo-service-set {
    next-hop-service {
      inside-service-interface sp-1/0/0.1;
      outside-service-interface sp-1/0/0.2;
    }
    ipsec-vpn-options {
      local-gateway 10.1.1.1;
    }
    ike-access-profile demo-ike-access-profile;
  }
}
```



NOTE: Including the `ike-access-profile` statement enables the software to incorporate implicit proposals for dynamic endpoint authentication. You do not need to configure IKE or IPsec proposals explicitly.

```

interfaces {
  sp-0/0/0 {
    unit 0 {
      family inet;
    }
    unit 1 {
      family inet;
      service-domain inside;
    }
    unit 2 {
      family inet;
      service-domain outside;
    }
    unit 3 {
      family inet;
      service-domain inside;
      dial-options {
        ipsec-interface-id demo-ipsec-interface-id;
        mode shared;
      }
    }
  }
}
# VRF configuration, if not inet.0
routing-instances {
  demo-vrf {
    instance-type vrf;
    interface sp-0/0/0.1;
    interface sp-0/0/0.3;
    .....
  }
}

```

The following results are obtained:

- Reverse routes injected after successful negotiation:

```

demo-vrf.inet.0: .... # Routing instance
172.11.0.0/24 *[Static/1]..
> via sp-0/0/0.3
172.12.0.0/24 *[Static/1]..
> via sp-0/0/0.3

```

- Dynamic implicit rules created after successful negotiation:

```

rule: junos-dynamic-rule-0
term: term-0
local-gateway-address : 10.1.1.1 #Tunnel termination address on SG-1
remote-gateway-address: 10.2.2.2 #Tunnel termination address on SG-2
source-address : 172.16.1.0/24

```

```
        destination-address : 172.16.2.0/24
    ipsec-inside-interface: sp-0/0/0.3
term: term-1
    local-gateway-address : 10.1.1.1 #Tunnel termination address on SG-1
    remote-gateway-address: 10.3.3.3 #Tunnel termination address on SG-3
    source-address : 172.16.1.0/24
    destination-address : 172.16.3.0/24
    ipsec-inside-interface: sp-0/0/0.3
match-direction: input
```


Chapter 13

Summary of IPsec Services Configuration Statements

The following sections explain each of the IP Security (IPsec) services statements. The statements are organized alphabetically.

authentication

Syntax authentication {
 algorithm (hmac-md5-96 | hmac-sha1-96);
 key (ascii-text key | hexadecimal key);
}

Hierarchy Level [edit services ipsec-vpn rule *rule-name* term *term-name* then manual direction *direction*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure IPsec authentication parameters for a manual security association (SA).

Options algorithm—Hash algorithm that authenticates packet data. The algorithm can be one of the following:

- hmac-md5-96—Produces a 128-bit digest.
- hmac-sha1-96—Produces a 160-bit digest.

key—Type of authentication key. The key can be one of the following:

- ascii-text key—ASCII text key. For hmac-md5-96, the key is 16 ASCII characters; for hmac-sha1-96, the key is 20 ASCII characters.
- hexadecimal key—Hexadecimal key. For hmac-md5-96, the key is 32 hexadecimal characters; for hmac-sha1-96, the key is 40 hexadecimal characters.

Usage Guidelines See “Configuring Authentication for a Manual IPsec SA” on page 215.

Required Privilege Level admin—To view this statement in the configuration.
admin-control—To add this statement to the configuration.

authentication-algorithm

See the following sections:

- authentication-algorithm (IKE) on page 254
- authentication-algorithm (IPsec) on page 254

authentication-algorithm (IKE)

Syntax	authentication-algorithm (md5 sha1 sha-256);
Hierarchy Level	[edit services ipsec-vpn ike proposal <i>proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4. sha-256 option added in JUNOS Release 7.6.
Description	Configure the Internet Key Exchange (IKE) hash algorithm that authenticates packet data.
Options	md5—Produces a 128-bit digest. sha1—Produces a 160-bit digest. sha-256—Produces a 256-bit digest.
Usage Guidelines	See “Configuring the Authentication Algorithm for an IKE Proposal” on page 219.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

authentication-algorithm (IPsec)

Syntax	authentication-algorithm (hmac-md5-96 hmac-sha1-96);
Hierarchy Level	[edit services ipsec-vpn ipsec proposal <i>ipsec-proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the IPsec hash algorithm that authenticates packet data.
Options	hmac-md5-96—Produces a 128-bit digest. hmac-sha1-96—Produces a 160-bit digest.
Usage Guidelines	See “Configuring the Authentication Algorithm for an IPsec Proposal” on page 227.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.


authentication-method

Syntax	authentication-method (dsa-signatures pre-shared-keys rsa-signatures);
Hierarchy Level	[edit services ipsec-vpn ike proposal <i>proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure an IKE authentication method.
Options	<p>dsa-signatures—Digital signature algorithm (DSA).</p> <p>rsa-signatures—Public key algorithm (supports encryption and digital signatures).</p> <p>pre-shared-keys—A key derived from an out-of-band mechanism; the key authenticates the exchange.</p>
Usage Guidelines	See “Configuring the Authentication Method for an IKE Proposal” on page 219.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

auxiliary-spi

Syntax	auxiliary-spi <i>spi-value</i> ;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then manual direction <i>direction</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure an auxiliary Security Parameter Index (SPI) for a manual SA. Use the auxiliary SPI when you configure the protocol statement to use the bundle option.
Options	<p><i>spi-value</i>—An arbitrary value that uniquely identifies which SA to use at the receiving host (the destination address in the packet).</p> <p>Range: 256 through 16,639</p>
Usage Guidelines	See “Configuring the Auxiliary Security Parameter Index” on page 215. For information about SPI, see “Configuring the Security Parameter Index” on page 215 and spi .
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

backup-remote-gateway

Syntax	backup-remote-gateway <i>address</i> ;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the backup remote address to which the IPsec traffic is directed when the primary remote gateway is down. Configuring this statement also enables the dead peer detection (DPD) protocol.
<hr/>	
	NOTE: Configuration of the backup-remote-gateway statement is not supported on J-series Services Routers. These routers cannot send DPD Hello messages but can respond to Hello messages sent by the peer.
<hr/>	
Options	<i>address</i> —Backup remote IPv4 or IPv6 address.
Usage Guidelines	See “Configuring Destination Addresses for Dead Peer Detection” on page 235.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

clear-dont-fragment-bit

Syntax	clear-dont-fragment-bit;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Clear the Don't Fragment (DF) bit on all IP version 4 (IPv4) packets entering the IPsec tunnel. If the encapsulated packet size exceeds the tunnel maximum transmission unit (MTU), the packet is fragmented before encapsulation.
Usage Guidelines	See “Configuring Actions in IPsec Rules” on page 234.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

clear-ike-sas-on-pic-restart

Syntax	clear-ike-sas-on-pic-restart;
Hierarchy Level	[edit services ipsec-vpn]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Clear IKE security associations (SAs) when the corresponding PIC restarts or is taken offline.
Usage Guidelines	See “Clearing Security Associations” on page 218.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

clear-ipsec-sas-on-pic-restart

Syntax	clear-ipsec-sas-on-pic-restart;
Hierarchy Level	[edit services ipsec-vpn]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Clear IPsec security associations (SAs) when the corresponding PIC restarts or is taken offline.
Usage Guidelines	See “Clearing Security Associations” on page 218.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

description

Syntax	<code>description <i>description</i>;</code>
Hierarchy Level	[edit services ipsec-vpn ike policy <i>policy-name</i>], [edit services ipsec-vpn ike proposal <i>proposal-name</i>], [edit services ipsec-vpn ipsec policy <i>policy-name</i>], [edit services ipsec-vpn ipsec proposal <i>proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the text description for an IKE or IPsec policy or proposal.
Usage Guidelines	See “Configuring the Description for an IKE Policy” on page 225, “Configuring the Description for an IPsec Proposal” on page 227, and “Configuring the Description for an IPsec Policy” on page 230.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

destination-address

Syntax	<code>destination-address <i>address</i>;</code>
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the destination address for rule matching.
Options	<i>address</i> —Destination IP address.
Usage Guidelines	See “Configuring Match Conditions in IPsec Rules” on page 233.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

dh-group

Syntax	dh-group (group1 group2);
Hierarchy Level	[edit services ipsec-vpn ike proposal <i>proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the IKE Diffie-Hellman prime modulus group to use for performing the new Diffie-Hellman exchange.
Options	group1—768-bit. group2—1024-bit.
Usage Guidelines	See “Configuring the Diffie-Hellman Group for an IKE Proposal” on page 220.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

direction

Syntax	<pre> direction (inbound outbound bidirectional) { protocol (ah bundle esp); spi <i>spi-value</i>; auxiliary-spi <i>spi-value</i>; authentication { algorithm (hmac-md5-96 hmac-sha1-96); key (ascii-text <i>key</i> hexadecimal <i>key</i>); } encryption { algorithm <i>algorithm</i>; key (ascii-text <i>key</i> hexadecimal <i>key</i>); } }</pre>
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then manual]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the direction in which manual SAs are applied.
Options	<p>bidirectional—Apply the SA in both directions.</p> <p>inbound—Apply the SA on inbound traffic.</p> <p>outbound—Apply the SA on outbound traffic.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Match Direction for IPsec Rules” on page 232.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

dynamic

Syntax	dynamic { ike-policy <i>policy-name</i> ; ipsec-policy <i>policy-name</i> ; }
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define a dynamic IPsec SA.
Options	<p>ike-policy <i>policy-name</i>—Name of the IKE policy. This statement is optional for the non-preshared-key authentication method. For digital signature-based authentication, this statement is optional and the default policy is used if none is supplied.</p> <p>ipsec-policy <i>policy-name</i>—Name of the IPsec policy. This statement is optional and the default policy is used if none is supplied.</p>
Usage Guidelines	See “Configuring Dynamic Security Associations” on page 217.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

encryption

Syntax encryption {
 algorithm *algorithm*;
 key (ascii-text *key* | hexadecimal *key*);
 }

Hierarchy Level [edit services ipsec-vpn rule *rule-name* term *term-name* then manual direction *direction*]

Release Information Statement introduced before JUNOS Release 7.4.
 aes-128-cbc, aes-192-cbc, and aes-256-cbc options added in JUNOS Release 7.6.

Description Configure an encryption algorithm and key for manual SA.

Options algorithm—Type of encryption algorithm. The algorithm can be one of the following:

- des-cbc—Has a block size of 8 bytes (64 bits); the key size is 48 bits long.
- 3des-cbc—Has a block size of 8 bytes (64 bits); the key size is 192 bits long.
- aes-128-cbc—Advanced Encryption Standard (AES) 128-bit encryption algorithm.
- aes-192-cbc—Advanced Encryption Standard (AES) 192-bit encryption algorithm.
- aes-256-cbc—Advanced Encryption Standard (AES) 256-bit encryption algorithm.



NOTE: For 3des-cbc, the first 8 bytes should differ from the second 8 bytes, and the second 8 bytes should be the same as the third 8 bytes.

key—Type of encryption key. The key can be one of the following:

- ascii-text—ASCII text key. Following are the key lengths, in ASCII characters, for the different encryption options:
 - des-cbc option, 8 ASCII characters
 - 3des-cbc option, 24 ASCII characters
 - aes-128-cbc option, 16 ASCII characters
 - aes-192-cbc option, 24 ASCII characters
 - aes-256-cbc option, 32 ASCII characters
- hexadecimal—Hexadecimal key. Following are the key lengths, in hexadecimal characters, for the different encryption options:
 - des-cbc option, 16 hexadecimal characters
 - 3des-cbc option, 48 hexadecimal characters
 - aes-128-cbc option, 32 hexadecimal characters
 - aes-192-cbc option, 48 hexadecimal characters

- aes-256-cbc option, 64 hexadecimal characters

Usage Guidelines	See “Configuring Encryption for a Manual IPSec SA” on page 216.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.

encryption-algorithm

Syntax	encryption-algorithm <i>algorithm</i> ;
Hierarchy Level	[edit services ipsec-vpn ike proposal <i>proposal-name</i>], [edit services ipsec-vpn ipsec proposal <i>proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4. aes-128-cbc, aes-192-cbc, and aes-256-cbc options added in JUNOS Release 7.6.
Description	Configure an IKE or IPsec encryption algorithm.
Options	3des-cbc—Has a block size of 24 bytes; the key size is 192 bits long. des-cbc—Has a block size of 8 bytes; the key size is 48 bits long. aes-128-cbc—Advanced Encryption Standard (AES) 128-bit encryption algorithm. aes-192-cbc—Advanced Encryption Standard (AES) 192-bit encryption algorithm. aes-256-cbc—Advanced Encryption Standard (AES) 256-bit encryption algorithm.
Usage Guidelines	See “Configuring the Encryption Algorithm for an IKE Proposal” on page 220 and “Configuring the Encryption Algorithm for an IPsec Proposal” on page 228.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

from

Syntax from {
 destination-address *address*;
 ipsec-inside-interface *interface-name*;
 source-address *address*;
 }

Hierarchy Level [edit services ipsec-vpn rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify input conditions for the IPsec term.

Options For information on match conditions, see the description of firewall filter match conditions in the *JUNOS Policy Framework Configuration Guide*.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Match Direction for IPsec Rules” on page 232.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

ike

```

Syntax   ike {
            proposal proposal-name {
                authentication-algorithm (md5 | sha1 | sha-256);
                authentication-method (dsa-signatures | pre-shared-keys | rsa-signatures);
                description description;
                dh-group (group1 | group2);
                encryption-algorithm algorithm;
                lifetime-seconds seconds;
            }
            policy policy-name {
                description description;
                local-certificate identifier;
                local-id (ipv4_addr ipv4-address | ipv6_addr ipv6-address | key-id identifier);
                mode (aggressive | main);
                pre-shared-key (ascii-text key | hexadecimal key);
                proposals [ proposal-names ];
                remote-id {
                    any-remote-id;
                    ipv4_addr [ values ];
                    ipv6_addr [ values ];
                    key_id [ values ];
                }
            }
        }

```

Hierarchy Level [edit services ipsec-vpn]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure IKE.

The statements are explained separately.

Usage Guidelines See “Configuring IKE Proposals” on page 218 and “Configuring IKE Policies” on page 221.

Required Privilege Level system—To view this statement in the configuration.
 system-control—To add this statement to the configuration.

initiate-dead-peer-detection

Syntax	initiate-dead-peer-detection;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Enable triggering of dead peer detection (DPD) Hello messages to the remote peer for the specified tunnel.
Usage Guidelines	See “Configuring Destination Addresses for Dead Peer Detection” on page 235.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Topics	backup-remote-gateway

ipsec

Syntax	<pre> ipsec { proposal <i>proposal-name</i> { authentication-algorithm (hmac-md5-96 hmac-sha1-96); description <i>description</i>; encryption-algorithm <i>algorithm</i>; lifetime-seconds <i>seconds</i>; protocol (ah esp bundle); } policy <i>policy-name</i> { description <i>description</i>; perfect-forward-secrecy { keys (group1 group2); } proposals [<i>proposal-names</i>]; } } </pre>
Hierarchy Level	[edit services ipsec-vpn]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Configure IPsec.</p> <p>The statements are explained separately.</p>
Usage Guidelines	See “Configuring Security Associations” on page 212.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.

ipsec-inside-interface

Syntax	<code>ipsec-inside-interface <i>interface-name</i>;</code>
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Specify the interface name for next-hop-style service sets. This value is also implicitly generated in dynamic endpoint tunneling.
Options	<i>interface-name</i> —Service interface for internal network.
Usage Guidelines	See “Configuring Match Conditions in IPsec Rules” on page 233 or “Configuring Dynamic Endpoints for IPsec Tunnels” on page 237.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

lifetime-seconds

Syntax	<code>lifetime-seconds <i>seconds</i>;</code>
Hierarchy Level	[edit services ipsec-vpn ike proposal <i>proposal-name</i>], [edit services ipsec-vpn ipsec proposal <i>proposal-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the lifetime of an IKE or IPsec SA. This statement is optional.
Options	<i>seconds</i> —Lifetime Default: 3600 seconds (IKE); 28,800 seconds (IPsec) Range: 180 through 86,400
Usage Guidelines	See “Configuring the Lifetime for an IKE SA” on page 221 and “Configuring the Lifetime for an IPsec SA” on page 228.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.

local-certificate

Syntax	<code>local-certificate <i>identifier</i>;</code>
Hierarchy Level	<code>[edit services ipsec-vpn ike policy <i>policy-name</i>]</code>
Release Information	Statement introduced in JUNOS Release 7.5.
Description	Name of the certificate that needs to be sent to the peer during the IKE authentication phase.
Options	<i>identifier</i> —Name of certificate.
Usage Guidelines	See “Configuring the Local Certificate for an IKE Policy” on page 224.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.

local-id

Syntax	<code>local-id (ipv4_addr <i>ipv4-address</i> ipv6_addr <i>ipv6-address</i> key-id <i>identifier</i>);</code>
Hierarchy Level	<code>[edit services ipsec-vpn ike policy <i>policy-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4. ipv6_addr option added in JUNOS Release 7.6.
Description	Specify local identifiers for IKE Phase 1 negotiation. This statement is optional.
Options	ipv4_addr <i>ipv4-address</i> —IPv4 address identification value. ipv6_addr <i>ipv6-address</i> —IPv6 address identification value. key_id <i>identifier</i> —Key identification value.
Usage Guidelines	See “Configuring Local and Remote IDs for IKE Phase 1 Negotiation” on page 225.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.

manual

Syntax manual {
 direction (inbound | outbound | bidirectional) {
 authentication {
 algorithm (hmac-md5-96 | hmac-sha1-96);
 key (ascii-text *key* | hexadecimal *key*);
 }
 auxiliary-spi *spi-value*;
 encryption {
 algorithm *algorithm*;
 key (ascii-text *key* | hexadecimal *key*);
 }
 spi *spi-value*;
 protocol (ah | esp | bundle);
 }
 }

Hierarchy Level [edit services ipsec-vpn rule *rule-name* term *term-name* then]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define a manual IPsec SA.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Manual Security Associations” on page 213.

Required Privilege Level admin—To view this statement in the configuration.
 admin-control—To add this statement to the configuration.

match-direction

Syntax match-direction (input | output);

Hierarchy Level [edit services ipsec-vpn rule *rule-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the direction in which the rule match is applied.

Options input—Apply the rule match on input.

 output—Apply the rule match on output.

Usage Guidelines See “Configuring Match Direction for IPsec Rules” on page 232.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

mode

Syntax	mode (aggressive main);
Hierarchy Level	[edit services ipsec-vpn ike policy <i>policy-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define an IKE policy mode.
Default	main
Options	<p>aggressive—Takes half the number of messages of main mode, has less negotiation power, and does not provide identity protection.</p> <p>main—Uses six messages, in three peer-to-peer exchanges, to establish the IKE SA. These three steps include the IKE SA negotiation, a Diffie-Hellman exchange, and authentication of the peer. Also provides identity protection.</p>
Usage Guidelines	See “Configuring the Mode for an IKE Policy” on page 223.
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>

no-anti-replay

Syntax	no-anti-replay;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Disable IPsec antireplay service, which occasionally causes interoperability issues for security associations.
Usage Guidelines	See “Disabling IPSec Anti-Replay” on page 236.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

perfect-forward-secrecy

Syntax	perfect-forward-secrecy { keys (group1 group2); }
Hierarchy Level	[edit services ipsec-vpn ipsec policy <i>policy-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define Perfect Forward Secrecy (PFS). Creates single-use keys. This statement is optional.
Options	<p>keys—Type of Diffie-Hellman prime modulus group that IKE uses when performing the new Diffie-Hellman exchange. The key can be one of the following:</p> <ul style="list-style-type: none">■ group1—768-bit.■ group2—1024-bit.
Usage Guidelines	See “Configuring Perfect Forward Secrecy” on page 230.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

policy

See the following sections:

- policy (IKE) on page 272
- policy (IPsec) on page 273

policy (IKE)

Syntax `policy policy-name {
 description description;
 local-certificate identifier;
 local-id (ipv4_addr ipv4-address | ipv6_addr ipv6-address | key-id identifier);
 mode (aggressive | main);
 pre-shared-key (ascii-text key | hexadecimal key);
 proposals [proposal-names];
 remote-id {
 any-remote-id;
 ipv4_addr [values];
 ipv6_addr [values];
 key_id [values];
 }
 }`

Hierarchy Level [edit services ipsec-vpn ike]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define an IKE policy.

Options *policy-name*—IKE policy name.

The remaining statements are explained separately.

Usage Guidelines See “Configuring IKE Policies” on page 221.

Required Privilege Level admin—To view this statement in the configuration.
 admin-control—To add this statement to the configuration.

policy (IPsec)

Syntax	<pre> policy <i>policy-name</i> { description <i>description</i>; perfect-forward-secrecy { keys (group1 group2); } proposals [<i>proposal-names</i>]; }</pre>
Hierarchy Level	[edit services ipsec-vpn ipsec]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define an IPsec policy.
Options	<p><i>policy-name</i>—IPsec policy name.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring IPsec Policies” on page 229.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

pre-shared-key

Syntax	pre-shared-key (ascii-text <i>key</i> hexadecimal <i>key</i>);
Hierarchy Level	[edit services ike policy <i>policy-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define a preshared key for an IKE policy.
Options	<p><i>key</i>—Value of preshared key. The key can be one of the following:</p> <ul style="list-style-type: none"> ■ <i>ascii-text</i>—ASCII text key. ■ <i>hexadecimal</i>—Hexadecimal key.
Usage Guidelines	See “Configuring IKE Policies” on page 221.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

proposal

See the following sections:

- [proposal \(IKE\) on page 274](#)
- [proposal \(IPsec\) on page 275](#)

proposal (IKE)

Syntax `proposal proposal-name {
authentication-algorithm (md5 | sha1 | sha-256);
authentication-method (dsa-signatures | pre-shared-keys | rsa-signatures);
description description;
dh-group (group1 | group2);
encryption-algorithm algorithm;
lifetime-seconds seconds;
}`

Hierarchy Level [edit services ipsec-vpn ike]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define an IKE proposal for a dynamic SA.

Options *proposal-name*—IKE proposal name.

The remaining statements are explained separately.

Usage Guidelines See “Configuring IKE Proposals” on page 218.

Required Privilege Level admin—To view this statement in the configuration.
admin-control—To add this statement to the configuration.

proposal (IPsec)

Syntax	<pre>proposal <i>proposal-name</i> { authentication-algorithm (hmac-md5-96 hmac-sha1-96); description <i>description</i>; encryption-algorithm <i>algorithm</i>; lifetime-seconds <i>seconds</i>; protocol (ah esp bundle); }</pre>
Hierarchy Level	[edit services ipsec-vpn ipsec]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define an IPsec proposal for a dynamic SA.
Options	<p><i>proposal-name</i>—IPsec proposal name.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring IPsec Proposals” on page 227.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

proposals

Syntax	proposals [<i>proposal-names</i>];
Hierarchy Level	<pre>[edit services ipsec-vpn ike policy <i>policy-name</i>], [edit services ipsec-vpn ipsec policy <i>policy-name</i>]</pre>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define a list of proposals to include in the IKE or IPsec policy.
Options	<i>proposal-names</i> —List of IKE or IPsec proposal names.
Usage Guidelines	See “Configuring the Proposals in an IKE Policy” on page 223 and “Configuring the Proposals in an IPsec Policy” on page 230.
Required Privilege Level	<p>admin—To view this statement in the configuration.</p> <p>admin-control—To add this statement to the configuration.</p>

protocol

Syntax	protocol (ah esp bundle);
Hierarchy Level	[edit services ipsec-vpn ipsec proposal <i>proposal-name</i>], [edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then manual direction <i>direction</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define an IPsec protocol for a dynamic or manual SA.
Options	ah—Authentication Header protocol. esp—Encapsulating Security Payload protocol. bundle—AH and ESP protocol.
Usage Guidelines	See “Configuring the Protocol for a Manual IPsec SA” on page 214.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

remote-gateway

Syntax	remote-gateway <i>address</i> ;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the remote address to which the IPsec traffic is directed.
Options	<i>address</i> —Remote IPv4 or IPv6 address.
Usage Guidelines	See “Configuring Actions in IPsec Rules” on page 234.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

remote-id

Syntax remote-id {
 any-remote-id;
 ipv4_addr [*values*];
 ipv6_addr [*values*];
 key_id [*values*];
 }

Hierarchy Level [edit services ipsec-vpn ike policy *policy-name*]

Release Information Statement introduced before JUNOS Release 7.4.
 ipv6_addr option added in JUNOS Release 7.6.
 any-remote-id option added in JUNOS Release 8.2.

Description Define the remote identification values to which the IKE policy applies.

Options any-remote-id—Allow any remote address to connect. This option is supported only in dynamic endpoints configurations and cannot be configured along with specific values.

ipv4_addr [*values*]—Define one or more IPv4 address identification values.

ipv6_addr [*values*]—Define one or more IPv6 address identification values.

key_id [*values*]—Define one or more key identification values.

Usage Guidelines See “Configuring Local and Remote IDs for IKE Phase 1 Negotiation” on page 225.

Required Privilege Level admin—To view this statement in the configuration.
 admin-control—To add this statement to the configuration.

rule

Syntax

```
rule rule-name {
  match-direction (input | output);
  term term-name {
    from {
      destination-address address;
      ipsec-inside-interface interface-name;
      source-address address;
    }
    then {
      backup-remote-gateway address;
      clear-dont-fragment-bit;
      dynamic {
        ike-policy policy-name;
        ipsec-policy policy-name;
      }
      initiate-dead-peer-detection;
      manual {
        direction (inbound | outbound | bidirectional) {
          authentication {
            algorithm (hmac-md5-96 | hmac-sha1-96);
            key (ascii-text key | hexadecimal key);
          }
          auxiliary-spi spi-value;
          encryption {
            algorithm algorithm;
            key (ascii-text key | hexadecimal key);
          }
          protocol (ah | bundle | esp);
          spi spi-value;
        }
      }
      no-anti-replay;
      remote-gateway address;
      syslog;
      tunnel-mtu bytes;
    }
  }
}
```

Hierarchy Level [edit services ipsec-vpn],
[edit services ipsec-vpn rule-set *rule-set-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the rule the router uses when applying this service.

Options *rule-name*—Identifier for the collection of terms that comprise this rule.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Match Direction for IPsec Rules” on page 232.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rule-set

Syntax `rule-set rule-set-name {
[rule rule-names];
}`

Hierarchy Level [edit services ipsec-vpn]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the rule set the router uses when applying this service.

Options *rule-set-name*—Identifier for the collection of rules that constitute this rule set.

Usage Guidelines See “Configuring IPsec Rule Sets” on page 237.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

services

Syntax `services ipsec-vpn { ... }`

Hierarchy Level [edit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the service rules to be applied to traffic.

Options ipsec-vpn—IPsec set of rules statements.


Usage Guidelines See “IPsec Services Configuration Guidelines” on page 209.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

source-address

Syntax	source-address <i>address</i> ;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the source address for rule matching.
Options	<i>address</i> —Source IP address.
Usage Guidelines	See “Configuring Match Conditions in IPsec Rules” on page 233.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

spi

Syntax	spi <i>spi-value</i> ;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then manual direction <i>direction</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the SPI for an SA.
Options	<i>spi-value</i> —An arbitrary value that uniquely identifies which SA to use at the receiving host (the destination address in the packet). Range: 256 through 16,639
	NOTE: Use the auxiliary SPI when you configure the protocol statement to use the bundle option.
Usage Guidelines	See “Configuring the Security Parameter Index” on page 215.
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.

syslog

Syntax	syslog;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable system logging. The system log information for the Adaptive Services or MultiServices Physical Interface Card (PIC) is passed to the kernel for logging in the /var/log directory.
Usage Guidelines	See “Configuring Actions in IPsec Rules” on page 234.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

term

Syntax `term term-name {`
 `from {`
 `destination-address address;`
 `ipsec-inside-interface interface-name;`
 `source-address address;`
 `}`
 `then {`
 `backup-remote-gateway address;`
 `clear-dont-fragment-bit;`
 `dynamic {`
 `ike-policy policy-name;`
 `ipsec-policy policy-name;`
 `}`
 `initiate-dead-peer-detection;`
 `manual {`
 `direction (inbound | outbound | bidirectional) {`
 `authentication {`
 `algorithm (hmac-md5-96 | hmac-sha1-96);`
 `key (ascii-text key | hexadecimal key);`
 `}`
 `auxiliary-spi spi-value;`
 `encryption {`
 `algorithm algorithm;`
 `key (ascii-text key | hexadecimal key);`
 `}`
 `protocol (ah | bundle | esp);`
 `spi spi-value;`
 `}`
 `no-anti-replay;`
 `remote-gateway address;`
 `syslog;`
 `tunnel-mtu bytes;`
 `}`
`}`

Hierarchy Level [edit services ipsec-vpn rule *rule-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the IPsec term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Match Direction for IPsec Rules” on page 232.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

then

```

Syntax  then {
            backup-remote-gateway address;
            clear-dont-fragment-bit;
            dynamic {
                ike-policy policy-name;
                ipsec-policy policy-name;
            }
            initiate-dead-peer-detection;
            manual {
                direction (inbound | outbound | bidirectional) {
                    authentication {
                        algorithm (hmac-md5-96 | hmac-sha1-96);
                        key (ascii-text key | hexadecimal key);
                    }
                    auxiliary-spi spi-value;
                    encryption {
                        algorithm algorithm;
                        key (ascii-text key | hexadecimal key);
                    }
                    protocol (ah | bundle | esp);
                    spi spi-value;
                }
            }
            no-anti-replay;
            remote-gateway address;
            syslog;
            tunnel-mtu bytes;
        }

```

Hierarchy Level [edit services ipsec-vpn rule *rule-name* term *term-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the IPsec term actions.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring Match Direction for IPsec Rules” on page 232.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

traceoptions

Syntax traceoptions {
 file <filename> <files *number*> <match *regular-expression*> <size *bytes*>
 <world-readable | no-world-readable>;
 flag *flag*;
 no-remote-trace;
 }

Hierarchy Level [edit services ipsec-vpn]

Release Information Statement introduced in JUNOS Release 7.5.

Description Configure IPsec tracing operations. By default, messages are written to /var/log/kmd.

Options files *number*—Maximum number of trace data files.

Range: 2 through 1000

flag *flag*—Tracing operation to perform:

- all—Trace everything.
- certificates—Trace certificates that apply to the IPsec service set.
- database—Trace security associations database events.
- general—Trace general events.
- ike—Trace IKE module processing.
- parse—Trace configuration processing.
- policy-manager—Trace policy manager processing.
- routing-socket—Trace routing socket messages.
- snmp—Trace SNMP operations.
- timer—Trace internal timer events.

size *bytes*—Maximum trace file size.

Usage Guidelines See “Tracing IPsec Operations” on page 243.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

tunnel-mtu

Syntax	tunnel-mtu <i>bytes</i> ;
Hierarchy Level	[edit services ipsec-vpn rule <i>rule-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	Maximum transmission unit (MTU) size for IPsec tunnels. The default MTU size depends on the device type.
Options	<i>bytes</i> —MTU size. Range: 0 through 5012 bytes
Usage Guidelines	See “Specifying the MTU for IPsec Tunnels” on page 237.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	mtu

Chapter 14

Layer 2 Tunneling Protocol Services Configuration Guidelines

The Layer 2 Tunneling Protocol (L2TP) enables you to set up client services for establishing Point-to-Point Protocol (PPP) tunnels across a network and negotiating Multilink PPP if it is implemented. Multiple L2TP PPP sessions can share the same remote peer IP address, which enables you to set up redundant sessions between the same links.

- If you configure Multilink PPP, the same remote IP address can be shared across multiple bundles, because the IP address negotiation takes place on the bundle rather than on each session.
- If Multilink PPP is not configured, multiple sessions can share the same remote IP address.

The last session or bundle to come up accomplishes the traffic transfer. When this session or bundle goes down, the traffic switches to the next-to-last session or bundle to come up. For example, if four sessions or bundles labeled A, B, C, and D share the same remote IP address and come up in alphabetical order, D initially handles the data transfer. If D goes down, traffic switches over to C, and so forth. If another session or bundle E subsequently comes up and has the same address, the traffic switches over to it.

To configure L2TP services, include the `l2tp` statement at the `[edit services]` hierarchy level:

```
[edit services]
l2tp {
  tunnel-group group-name {
    hello-interval seconds;
    hide-avps;
    l2tp-access-profile profile-name;
    local-gateway address address;
    maximum-send-window packets;
    ppp-access-profile profile-name;
    receive-window packets;
    retransmit-interval seconds;
    service-interface interface-name;
  }
  syslog {
    host hostname {
      services severity-level;
      facility-override facility-name;
    }
  }
}
```

```

        log-prefix prefix-value;
    }
}
tunnel-timeout seconds;
}
traceoptions {
    debug-level level;
    filter {
        protocol name;
    }
    flag flag;
    interfaces interface-name {
        debug-level level;
        flag flag;
    }
}
}

```



NOTE: L2TP configurations are supported only on M7i, M10i, and M120 routing platforms.

You configure other components of this feature at the [edit access] and [edit interfaces] hierarchy levels. Those configurations are summarized in this chapter; for more information, see the *JUNOS System Basics Configuration Guide* or the *JUNOS Network Interfaces Configuration Guide*.

This chapter contains the following sections:

- L2TP Services Configuration Overview on page 289
- L2TP Minimum Configuration on page 290
- Configuring L2TP Tunnel Groups on page 292
- Configuring the Identifier for Logical Interfaces that Provide L2TP Services on page 296
- AS PIC Redundancy for L2TP Services on page 298
- Tracing L2TP Operations on page 299
- Examples: Configuring L2TP Services on page 300

L2TP Services Configuration Overview

The statements for configuring L2TP services are found at the following hierarchy levels:

- [edit services l2tp tunnel-group *group-name*]

The L2TP **tunnel-group** statement identifies an L2TP instance or L2TP server. Associated statements specify the local gateway address on which incoming tunnels and sessions are accepted, the Adaptive Services (AS) Physical Interface Card (PIC) that processes data for the sessions in this tunnel group, references to L2TP and PPP access profiles, and other attributes for configuring window sizes and timer values.

- [edit interfaces *sp-fpc/pic/port* unit *logical-unit-number* dial-options]

The **dial-options** statement includes configuration for the **l2tp-interface-id** statement and the **shared/dedicated** flag. The interface identifier associates a user session with a logical interface. Sessions can use either shared or dedicated logical interfaces. To run routing protocols, a session must use a dedicated logical interface.

- [edit access profile *profile-name* client *name* l2tp]

Tunnel profiles are defined at the [edit access] hierarchy level. Tunnel clients are defined with authentication, multilink negotiation and fragmentation, and other L2TP attributes in these profiles.

- [edit access profile *profile-name* client *name* ppp]

User profiles are defined at the [edit access] hierarchy level. User clients are defined with authentication and other PPP attributes in these profiles. These client profiles are used when local authentication is specified.

- [edit access radius-server *address*]

When you configure **authentication-order radius** at the [edit access profile *profile-name*] hierarchy level, you must configure a RADIUS service at the [edit access radius-server] hierarchy level.



NOTE: For more information about configuring properties at the [edit access] hierarchy level, see the *JUNOS System Basics Configuration Guide*.

L2TP Minimum Configuration

To configure L2TP services, you must perform at least the following tasks:

- Define a tunnel group at the `[edit services l2tp]` hierarchy level with the following attributes:
 - `l2tp-access-profile`—Profile name for the L2TP tunnel.
 - `ppp-access-profile`—Profile name for the L2TP user.
 - `local-gateway`—Address for the L2TP tunnel.
 - `service-interface`—AS PIC interface for the L2TP service.
 - Optionally, you can configure `traceoptions` for debugging purposes.

The following example shows a minimum configuration for a tunnel group with trace options:

```
[edit services l2tp]
tunnel-group finance-lns-server {
  l2tp-access-profile westcoast_bldg_1_tunnel;
  ppp-access-profile westcoast_bldg_1;
  local-gateway {
    address 10.21.255.129;
  }
  service-interface sp-1/3/0;
}
traceoptions {
  flag all;
  filter {
    protocol udp;
    protocol l2tp;
    protocol ppp;
    protocol radius;
  }
}
```

- At the `[edit interfaces]` hierarchy level:
 - Identify the physical interface at which L2TP tunnel packets enter the router, for example `ge-0/3/0`.
 - Configure the AS PIC interface with `unit 0 family inet` defined for IP service, and configure another logical interface with `family inet` and the `dial-options` statement.

The following example shows a minimum interfaces configuration for L2TP:

```
[edit interfaces]
ge-0/3/0 {
  unit 0 {
    family inet {
      address 10.58.255.129/28;
    }
  }
}
```

```

    }
  }
}
sp-1/3/0 {
  unit 0 {
    family inet;
  }
  unit 20 {
    dial-options {
      l2tp-interface-id test;
      shared;
    }
    family inet;
  }
}

```

- At the [edit access] hierarchy level:
 - Configure a tunnel profile. Each client specifies a unique L2TP Access Concentrator (LAC) name with an **interface-id** value that matches the one configured on the AS PIC interface unit; **shared-secret** is authentication between the LAC and the L2TP Network Server (LNS).
 - Configure a user profile. If RADIUS is used as the authentication method, it needs to be defined.
 - Define the RADIUS server with an IP address, port, and authentication data shared between the router and the RADIUS server.



NOTE: When the L2TP Network Server (LNS) is configured with RADIUS authentication, the default behavior is to accept the preferred RADIUS-assigned IP address. Previously, the default behavior was to accept and install the nonzero peer IP address that came into the IP-Address option of the IPCP Configuration Request packet.

- Optionally, you can define a group profile for common attributes, for example **keepalive 0** to turn off keepalive messages.

The following example shows a minimum profiles configuration for L2TP:

```

[edit access]
group-profile westcoast_users {
  ppp {
    keepalive 0;
  }
}
profile westcoast_bldg_1_tunnel {
  client production {
    l2tp {
      interface-id test;
      shared-secret "$9$n8HX6A01RhivL1R"; # SECRET-DATA
    }
    user-group-profile westcoast_users;
  }
}

```

```

    }
  }
  profile westcoast_bldg_1 {
    authentication-order radius;
  }
  radius-server {
    192.168.65.63 {
      port 1812;
      secret "$9$Vyb4ZHKPQ39mf9pORlexNdbgoZUjqP5"; # SECRET-DATA
    }
  }
}

```

Configuring L2TP Tunnel Groups

To establish L2TP service on a router, you need to identify an L2TP tunnel group and specify a number of values that define which access profiles, interface addresses, and other properties to use in creating a tunnel. To identify the tunnel group, include the `tunnel-group` statement at the `[edit services l2tp]` hierarchy level:

```

tunnel-group group-name {
  hello-interval seconds;
  hide-avps;
  l2tp-access-profile profile-name;
  local-gateway address address;
  maximum-send-window packets;
  ppp-access-profile profile-name;
  receive-window packets;
  retransmit-interval seconds;
  service-interface interface-name;
  syslog {
    host hostname {
      services severity-level;
      facility-override facility-name;
      log-prefix prefix-value;
    }
  }
  tunnel-timeout seconds;
}

```



NOTE: If you delete a tunnel group or mark it inactive, all L2TP sessions in that tunnel group are terminated. If you change the value of the `local-gateway address` or the `service-interface` statement, all L2TP sessions using those settings are terminated. If you change or delete other statements at the `[edit services l2tp tunnel-group group-name]` hierarchy level, new tunnels you establish will use the updated values but existing tunnels and sessions are not affected.

The following sections explain how to configure L2TP tunnel groups:

- Configuring Access Profiles for L2TP Tunnel Groups on page 293
- Configuring the Local Gateway Address and PIC on page 293

- Configuring Window Size for L2TP Tunnels on page 294
- Configuring Timers for L2TP Tunnels on page 294
- Hiding Attribute-Value Pairs for L2TP Tunnels on page 295
- Configuring System Logging of L2TP Tunnel Activity on page 295

Configuring Access Profiles for L2TP Tunnel Groups

To validate L2TP connections and session requests, you set up access profiles by configuring the `profile` statement at the `[edit access]` hierarchy level. You need to configure two types of profiles:

- L2TP tunnel access profile, which validates all L2TP connection requests to the specified local gateway address
- PPP access profile, which validates all PPP session requests through L2TP tunnels established to the local gateway address

For more information on configuring the profiles, see the *JUNOS System Basics Configuration Guide*. A profile example is included in “Examples: Configuring L2TP Services” on page 300.

To associate the profiles with a tunnel group, include the `l2tp-access-profile` and `ppp-access-profile` statements at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
l2tp-access-profile profile-name;
ppp-access-profile profile-name;
```

Configuring the Local Gateway Address and PIC

When you configure an L2TP group, you must also define a local address for the L2TP tunnel connections and the AS PIC that processes the requests:

- To configure the local gateway IP address, include the `local-gateway` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
local-gateway address address;
```

- To configure the AS PIC, include the `service-interface` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
service-interface sp-fpc/pic/port;
```

You can optionally specify the logical unit number along with the service interface. If specified, the unit is used as a logical interface representing PPP sessions negotiated using this profile.



NOTE: If you change the local gateway address or the service interface configuration, all L2TP sessions using those settings are terminated.

Dynamic class-of-service (CoS) functionality is supported on L2TP LNS sessions or L2TP sessions with ATM VCs, as long as the L2TP session is configured to use an IQ2 PIC on the egress interface. For more information, see the *JUNOS Class of Service Configuration Guide*.

Configuring Window Size for L2TP Tunnels

You can configure the maximum window size for packet processing at each end of the L2TP tunnel:

- The receive window size limits the number of concurrent packets the server processes. By default, the maximum is 16 packets. To change the window size, include the `receive-window` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
receive-window packets;
```

- The maximum-send window size limits the other end's receive window size. The information is transmitted in the receive window size attribute-value pair. By default, the maximum is 32 packets. To change the window size, include the `maximum-send-window` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
maximum-send-window packets;
```

Configuring Timers for L2TP Tunnels

You can configure the following timer values that regulate L2TP tunnel processing:

- Hello interval—If the server does not receive any messages within a specified time interval, the router software sends a hello message to the tunnel's remote peer. By default, the interval length is 60 seconds. If you configure a value of 0, no hello messages are sent. To configure a different value, include the `hello-interval` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
hello-interval seconds;
```

- Retransmit interval—By default, the retransmit interval length is 30 seconds. To configure a different value, include the `retransmit-interval` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
retransmit-interval seconds;
```

- Tunnel timeout—If the server cannot send any data through the tunnel within a specified time interval, it assumes that the connection with the remote peer has been lost and deletes the tunnel. By default, the interval length is 120 seconds. To configure a different value, include the `tunnel-timeout` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
tunnel-timeout seconds;
```

Hiding Attribute-Value Pairs for L2TP Tunnels

Once an L2TP tunnel has been established and the connection authenticated, information is encoded by means of attribute-value pairs. By default, this information is not hidden. To hide the attribute-value pairs once the shared secret is known, include the `hide-avps` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
hide-avps;
```

Configuring System Logging of L2TP Tunnel Activity

You can specify properties that control how system log messages are generated for L2TP services.

To configure interface-wide default system logging values, include the `syslog` statement at the `[edit services l2tp tunnel-group group-name]` hierarchy level:

```
syslog {
  host hostname {
    services severity-level;
    facility-override facility-name;
    log-prefix prefix-value;
  }
}
```

Configure the `host` statement with a hostname that specifies the system log target server. The hostname `local` directs system log messages to the Routing Engine. For external system log servers, the hostname must be included in `inet.0`. You can specify only one system logging hostname.

Table 13 on page 295 lists the severity levels that you can specify in configuration statements at the `[edit services l2tp tunnel-group group-name syslog host hostname]` hierarchy level. The levels from `emergency` through `info` are in order from highest severity (greatest effect on functioning) to lowest.

Table 13: System Log Message Severity Levels

Severity Level	Description
any	Includes all severity levels
emergency	System panic or other condition that causes the routing platform to stop functioning
alert	Conditions that require immediate correction, such as a corrupted system database
critical	Critical conditions, such as hard drive errors
error	Error conditions that generally have less serious consequences than errors in the emergency, alert, and critical levels

Table 13: System Log Message Severity Levels (*continued*)

Severity Level	Description
warning	Conditions that warrant monitoring
notice	Conditions that are not errors but might warrant special handling
info	Events or nonerror conditions of interest

We recommend setting the system logging severity level to **error** during normal operation. To monitor PIC resource usage, set the level to **warning**. To gather information about an intrusion attack when an intrusion detection system error is detected, set the level to **notice** for a specific service set. To debug a configuration or log Network Address Translation (NAT) events, set the level to **info**.

For more information about system log messages, see the *JUNOS System Log Messages Reference*.

To use one particular facility code for all logging to the specified system log host, include the **facility-override** statement at the [edit services l2tp tunnel-group *group-name* syslog host *hostname*] hierarchy level:

```
facility-override facility-name;
```

The supported facilities include: **authorization**, **daemon**, **ftp**, **kernel**, **user**, and **local0** through **local7**.

To specify a text prefix for all logging to this system log host, include the **log-prefix** statement at the [edit services l2tp tunnel-group *group-name* syslog host *hostname*] hierarchy level:

```
log-prefix prefix-text;
```

Configuring the Identifier for Logical Interfaces that Provide L2TP Services

You can configure L2TP services on adaptive services interfaces on M7i, M10i, and M120 routers only. You must configure the logical interface to be dedicated or shared. If a logical interface is dedicated, it can represent only one session at a time. A shared logical interface can have multiple sessions.

To configure the logical interface, include the **l2tp-interface-id** statement at the [edit interfaces *interface-name* unit *logical-unit-number* dial-options] hierarchy level:

```
l2tp-interface-id name;  
(dedicated | shared);
```

The **l2tp-interface-id** name configured on the logical interface must be replicated at the [edit access profile *name*] hierarchy level:

- For a user-specific identifier, include the **l2tp-interface-id** statement at the [edit access profile *name* ppp] hierarchy level.

- For a group identifier, include the `l2tp-interface-id` statement at the `[edit access profile name l2tp]` hierarchy level.

You can configure multiple logical interfaces with the same interface identifier, to be used as a pool for several users. For more information on configuring access profiles, see the *JUNOS System Basics Configuration Guide*.



NOTE: If you delete the `dial-options` statement settings configured on a logical interface, all L2TP sessions running on that interface are terminated.

Example: Configuring Multilink PPP on a Shared Logical Interface

Multilink PPP is supported on either shared or dedicated logical interfaces. The following example can be used to configure many multilink bundles on a single shared interface:

```

interfaces {
  sp-1/3/0 {
    traceoptions {
      flag all;
    }
    unit 0 {
      family inet;
    }
    unit 20 {
      dial-options {
        l2tp-interface-id test;
        shared;
      }
      family inet;
    }
  }
}
access {
  profile t {
    client test {
      l2tp {
        interface-id test;
        multilink;
        shared-secret "$9$n8HX6A01RhivL1R"; # SECRET-DATA
      }
    }
  }
  profile u {
    authentication-order radius;
  }
  radius-server {
    192.168.65.63 {
      port 1812;
      secret "$9$Vyb4ZHkPQ39mf9pORlexNdbgoZUjqP5"; # SECRET-DATA
    }
  }
}

```

```

}
services {
  l2tp {
    tunnel-group 1 {
      l2tp-access-profile t;
      ppp-access-profile u;
      local-gateway {
        address 10.70.1.1;
      }
      service-interface sp-1/3/0;
    }
    traceoptions {
      flag all;
      debug-level packet-dump;
      filter {
        protocol l2tp;
        protocol ppp;
        protocol radius;
      }
    }
  }
}

```

AS PIC Redundancy for L2TP Services

L2TP services support AS PIC redundancy. To configure redundancy, you specify a redundancy services PIC (**rsp**) interface in which the primary AS PIC is active and a secondary AS PIC is on standby. If the primary AS PIC fails, the secondary PIC becomes active, and all service processing is transferred to it. If the primary AS PIC is restored, it remains in standby and does not preempt the secondary AS PIC; you need to manually restore the services to the primary PIC. To determine which PIC is currently active, issue the **show interfaces redundancy** command.



NOTE: On L2TP, the only service option supported is *warm standby*, in which one backup PIC supports multiple working PICs. Recovery times are not guaranteed, because the configuration must be completely restored on the backup PIC after a failure is detected. The tunnels and sessions are torn down upon switchover and need to be restarted by the LAC and PPP client, respectively. However, configuration is preserved and available on the new active PIC, although the protocol state needs to be reestablished.

As with the other AS PIC services that support warm standby, you can issue the **request interfaces (revert | switchover)** command to manually switch between primary and secondary L2TP interfaces.

For more information, see “Configuring AS or MultiServices PIC Redundancy” on page 483. For an example configuration, see “Examples: Configuring L2TP Services” on page 300. For information on operational mode commands, see the *JUNOS Interfaces Command Reference*.

Tracing L2TP Operations

Tracing operations track all AS PIC operations and record them in a log file in the `/var/log` directory. By default, this file is named `/var/log/l2tpd`.

To trace L2TP operations, include the `traceoptions` statement at the `[edit services l2tp]` hierarchy level:

```
traceoptions {
  debug-level level;
  filter {
    protocol name;
  }
  flag flag;
  interfaces interface-name {
    debug-level level;
    flag flag;
  }
}
```

You can specify the following L2TP tracing flags:

- `all`—Trace everything.
- `configuration`—Trace configuration events.
- `protocol`—Trace routing protocol events.
- `routing-socket`—Trace routing socket events.
- `rpd`—Trace routing protocol process events.

You can specify a trace level for PPP, L2TP, RADIUS, and User Datagram Protocol (UDP) tracing. To configure a trace level, include the `debug-level` statement at the `[edit services l2tp traceoptions]` hierarchy level and specify one of the following values:

- `detail`—Detailed debug information
- `error`—Errors only
- `packet-dump`—Packet decoding information

You can filter by protocol. To configure filters, include the `filter protocol` statement at the `[edit services l2tp traceoptions]` hierarchy level and specify one or more of the following protocol values:

- `ppp`
- `l2tp`
- `radius`
- `udp`

To implement filtering by protocol name, you must also configure either `flag protocol` or `flag all`.

You can also configure traceoptions for L2TP on a specific adaptive services interface. To configure per-interface tracing, include the `interfaces` statement at the `[edit services l2tp traceoptions]` hierarchy level:

```
interfaces interface-name {
  debug-level level;
  flag flag;
}
```



NOTE: Implementing traceoptions consumes CPU resources and affects the packet processing performance.

You can specify the `debug-level` and `flag` statements for the interface, but the options are slightly different from the general L2TP traceoptions. You specify the debug level as `detail`, `error`, or `extensive`, which provides complete PIC debug information. The following flags are available:

- `all`—Trace everything.
- `ipc`—Trace L2TP Inter-Process Communication (IPC) messages between the PIC and the Routing Engine.
- `packet-dump`—Dump each packet's content based on debug level.
- `protocol`—Trace L2TP, PPP, and multilink handling.
- `system`—Trace packet processing on the PIC.

Examples: Configuring L2TP Services

Configure L2TP with multiple group and user profiles and a pool of logical interfaces for concurrent tunnel sessions:

```
[edit access]
address-pool customer_a {
  address 10.1.1.1/32;
}
address-pool customer_b {
  address-range low 10.2.2.1 high 10.2.3.2;
}
group-profile sunnyvale_users {
  ppp {
    framed-pool customer_a;
    idle-timeout 15;
    primary-dns 192.168.65.1;
    secondary-dns 192.168.65.2;
    primary-wins 192.168.65.3;
    secondary-wins 192.168.65.4;
    interface-id west;
  }
}
group-profile eastcoast_users {
  ppp {
    framed-pool customer_b;
```

```

        idle-timeout 20;
        primary-dns 192.168.65.5;
        secondary-dns 192.168.65.6;
        primary-wins 192.168.65.7;
        secondary-wins 192.168.65.8;
        interface-id east;
    }
}
group-profile sunnyvale_tunnel {
    l2tp {
        maximum-sessions-per-tunnel 100;
        interface-id west_shared;
    }
}
group-profile east_tunnel {
    l2tp {
        maximum-sessions-per-tunnel 125;
        interface-id east_shared;
    }
}
profile sunnyvale_bldg_1 {
    client white {
        chap-secret "$9$3s2690leK8X7VKM7VwgaJn/Ctu1hclv87Ct87"; #
            SECRET-DATA

        ppp {
            idle-timeout 22;
            primary-dns 192.168.65.1;
            framed-ip-address 10.12.12.12/32;
            interface-id east;
        }
        group-profile sunnyvale_users;
    }
    client blue {
        chap-secret "$9$eq1KWxbwgZUHNdjqmTF3u01Rhr-dsoJDNd"; #
            SECRET-DATA
        group-profile sunnyvale_users;
    }
    authentication-order password;
}
profile sunnyvale_bldg_1_tunnel {
    client test {
        l2tp {
            shared-secret "$9$r3HKvLg4ZUDkX7JGjif5p0BIRS8LN"; # SECRET-DATA
            maximum-sessions-per-tunnel 75;
            interface-id west_shared;
            ppp-authentication chap;
        }
        group-profile sunnyvale_tunnel;
    }
}
client production {
    l2tp {
        shared-secret
            "$9$R2QEnv8X-goGylVwg4jiTz36/t0BEleWFnRhrlXxbs2aJDHqf3nCP5";
        ppp-authentication chap;
    }
    group-profile sunnyvale_tunnel;
}

```

```

    }
  }
[edit services]
l2tp {
  tunnel-group finance-lns-server {
    l2tp-access-profile sunnyvale_bldg_1_tunnel;
    ppp-access-profile sunnyvale_bldg_1;
    local-gateway {
      address 10.1.117.3;
    }
    service-interface sp-1/3/0;
    receive-window 1500;
    maximum-send-window 1200;
    retransmit-interval 5;
    hello-interval 15;
    tunnel-timeout 55;
  }
  traceoptions {
    flag all;
  }
}
[edit interfaces sp-1/3/0]
unit0 {
  family inet;
}
unit 10 {
  dial-options {
    l2tp-interface-id foo-user;
    dedicated;
  }
  family inet;
}
unit 11 {
  dial-options {
    l2tp-interface-id east;
    dedicated;
  }
  family inet;
}
unit 12 {
  dial-options {
    l2tp-interface-id east;
    dedicated;
  }
  family inet;
}
unit 21 {
  dial-options {
    l2tp-interface-id west;
    dedicated;
  }
  family inet;
}
unit 30 {
  dial-options {
    l2tp-interface-id west_shared;

```

```

        shared;
    }
    family inet;
}
unit 40 {
    dial-options {
        l2tp-interface-id east_shared;
        shared;
    }
    family inet;
}

```

Configure L2TP redundancy:

```

interfaces {
    rsp0 {
        redundancy-options {
            primary sp-0/0/0;
            secondary sp-1/3/0;
        }
        unit 0 {
            family inet;
        }
        unit 11 {
            dial-options {
                l2tp-interface-id east_shared;
                shared;
            }
            family inet;
        }
    }
}

```


Chapter 15

Summary of Layer 2 Tunneling Protocol Configuration Statements

The following sections explain each of the Layer 2 Tunneling Protocol (L2TP) statements. The statements are organized alphabetically.

facility-override

Syntax	<code>facility-override <i>facility-name</i>;</code>
Hierarchy Level	[edit services tunnel-group <i>group-name</i> syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Override the default facility for system log reporting.
Options	<i>facility-name</i> —Name of the facility that overrides the default assignment. Valid entries include: authorization daemon ftp kernel local0 through local7 user
Usage Guidelines	See “Configuring System Logging of L2TP Tunnel Activity” on page 295.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

hello-interval

Syntax	hello-interval <i>seconds</i> ;
Hierarchy Level	[edit services l2tp tunnel-group <i>name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the keepalive timer for L2TP tunnels.
Options	<i>seconds</i> —Interval, in seconds, after which the server sends a hello message if no messages are received. A value of 0 means that no hello messages are sent. Default: 60 seconds
Usage Guidelines	See “Configuring Timers for L2TP Tunnels” on page 294.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

hide-avps

Syntax	hide-avps;
Hierarchy Level	[edit services l2tp tunnel-group <i>name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Hide L2TP attribute-value pairs if the secret shared between the two ends of the tunnel is known.
Default	Attribute-value pairs that can be hidden are exposed, even if the secret information is known.
Usage Guidelines	See “Hiding Attribute-Value Pairs for L2TP Tunnels” on page 295.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

host

Syntax	host <i>hostname</i> { services <i>severity-level</i> ; facility-override <i>facility-name</i> ; log-prefix <i>prefix-value</i> ; }
Hierarchy Level	[edit services tunnel-group <i>group-name</i> syslog]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the hostname for the system logging utility.
Options	<i>hostname</i> —Name of the system logging utility host machine. This can be the local Routing Engine or an external server address. The remaining statements are explained separately.
Usage Guidelines	See “Configuring System Logging of L2TP Tunnel Activity” on page 295.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

l2tp-access-profile

Syntax	l2tp-access-profile <i>profile-name</i> ;
Hierarchy Level	[edit services l2tp tunnel-group <i>name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the profile used to validate all L2TP connection requests to the local gateway address.
Options	<i>profile-name</i> —Identifier for the L2TP connection profile.
Usage Guidelines	See “Configuring Access Profiles for L2TP Tunnel Groups” on page 293.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

local-gateway address

Syntax	local-gateway address <i>address</i> ;
Hierarchy Level	[edit services l2tp tunnel-group <i>name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the local IP address for L2TP tunnel.
Options	<i>address</i> —Local IP address.
Usage Guidelines	See “Configuring the Local Gateway Address and PIC” on page 293.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

log-prefix

Syntax	log-prefix <i>prefix-value</i> ;
Hierarchy Level	[edit services tunnel-group <i>group-name</i> syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the system logging prefix value.
Options	<i>prefix-value</i> —System logging prefix value.
Usage Guidelines	See “Configuring System Logging of L2TP Tunnel Activity” on page 295.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

maximum-send-window

Syntax	<code>maximum-send-window <i>packets</i>;</code>
Hierarchy Level	<code>[edit services l2tp tunnel-group <i>name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the size of the send window for L2TP tunnels, which limits the remote end's receive window size.
Options	<i>packets</i> —Maximum number of packets the send window can hold at one time. Default: 32
Usage Guidelines	See “Configuring Window Size for L2TP Tunnels” on page 294.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ppp-access-profile

Syntax	<code>ppp-access-profile <i>profile-name</i>;</code>
Hierarchy Level	<code>[edit services l2tp tunnel-group <i>name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the profile used to validate all Point-to-Point Protocol (PPP) session requests through L2TP tunnels established to the local gateway address.
Options	<i>profile-name</i> —Identifier for the PPP profile.
Usage Guidelines	See “Configuring Access Profiles for L2TP Tunnel Groups” on page 293.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

receive-window

Syntax	<code>receive-window <i>packets</i>;</code>
Hierarchy Level	<code>[edit services l2tp tunnel-group <i>name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the size of the receive window for L2TP tunnels, which limits the number of packets the server processes concurrently.
Options	<i>packets</i> —Maximum number of packets the receive window can hold at one time. Default: 16
Usage Guidelines	See “Configuring Window Size for L2TP Tunnels” on page 294.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

retransmit-interval

Syntax	<code>retransmit-interval <i>seconds</i>;</code>
Hierarchy Level	<code>[edit services l2tp tunnel-group <i>name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the maximum retransmit interval for L2TP tunnels.
Options	<i>seconds</i> —Interval, in seconds, after which the server retransmits data if no acknowledgment is received. Default: 30 seconds
Usage Guidelines	See “Configuring Timers for L2TP Tunnels” on page 294.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service-interface

Syntax	<code>service-interface sp-fpc/pic/port;</code>
Hierarchy Level	[edit services l2tp tunnel-group <i>name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the adaptive services interface responsible for handling L2TP processing.
Options	<code>sp-fpc/pic/port</code> —AS or MultiServices PIC interface used for L2TP processing.
Usage Guidelines	See “Configuring the Local Gateway Address and PIC” on page 293.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

See the following sections:

- services (Hierarchy) on page 312
- services (L2TP System Logging) on page 313

services (*Hierarchy*)

Syntax services l2tp { ... }

Hierarchy Level [edit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the service properties to be applied to traffic.

Options l2tp—Identifies the L2TP set of services statements.

Usage Guidelines See “Layer 2 Tunneling Protocol Services Configuration Guidelines” on page 287.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

services (L2TP System Logging)

Syntax	<code>services severity-level;</code>
Hierarchy Level	[edit services tunnel-group <i>group-name</i> syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the system logging severity level.
Options	<p><i>severity-level</i>—Assigns a severity level to the facility. Valid entries include:</p> <ul style="list-style-type: none"> ■ <i>alert</i>—Conditions that should be corrected immediately. ■ <i>any</i>—Matches any level. ■ <i>critical</i>—Critical conditions. ■ <i>emergency</i>—Panic conditions. ■ <i>error</i>—Error conditions. ■ <i>info</i>—Informational messages. ■ <i>notice</i>—Conditions that require special handling. ■ <i>warning</i>—Warning messages.
Usage Guidelines	See “Configuring System Logging of L2TP Tunnel Activity” on page 295.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

syslog

Syntax syslog {
 host *hostname* {
 services *severity-level*;
 facility-override *facility-name*;
 log-prefix *prefix-value*;
 }
 }

Hierarchy Level [edit services l2tp tunnel-group *group-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure the generation of system log messages for L2TP services. System log information is passed to the kernel for logging in the `/var/log/l2tpd` directory.

Options The remaining statements are described separately.

Usage Guidelines See “Configuring System Logging of L2TP Tunnel Activity” on page 295.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

traceoptions

Syntax traceoptions {
 debug-level *level*;
 filter {
 protocol *name*;
 }
 flag *flag*;
 interfaces *interface-name* {
 debug-level *level*;
 flag *flag*;
 }
 }

Hierarchy Level [edit services l2tp]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure L2TP tracing operations. The messages are output to /var/log/l2tpd.

Options debug-level *level*—Trace level for PPP, L2TP, RADIUS, and User Datagram Protocol (UDP):

- detail—Detailed debug information.
- error—Errors only.
- packet-dump—Packet decoding information.

filter protocol *name*—Additional filter for the specified protocol:

- l2tp
- ppp
- radius
- udp

flag *flag*—Tracing operation to perform:

- all—Trace everything.
- configuration—Trace configuration events.
- protocol—Trace routing protocol events.
- routing-socket—Trace routing socket events.
- rpd—Trace routing protocol process events.

interfaces *interface-name*—Apply L2TP traceoptions to a specific adaptive services interface.

- debug-level *level*—Trace level for the interface:

- detail—Detailed debug information.
- error—Errors only.
- extensive—All PIC debug information.
- flag *flag*—Tracing operations for the interface:
 - all—Trace everything.
 - ipc—Trace L2TP Inter-Process Communication (IPC) messages between the PIC and the Routing Engine.
 - packet-dump—Dump each packet content based on debug level.
 - protocol—Trace L2TP, PPP, and multilink handling.
 - system—Trace packet processing on the PIC.

Usage Guidelines See “Tracing L2TP Operations” on page 299.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

tunnel-group

Syntax tunnel-group *group-name* {
 hello-interval *seconds*;
 hide-avps;
 l2tp-access-profile *profile-name*;
 local-gateway address *address*;
 maximum-send-window *packets*;
 ppp-access-profile *profile-name*;
 receive-window *packets*;
 retransmit-interval *seconds*;
 service-interface *interface-name*;
 syslog {
 host *hostname* {
 services *severity-level*;
 facility-override *facility-name*;
 log-prefix *prefix-value*;
 }
 }
 tunnel-timeout *seconds*;
 }

Hierarchy Level [edit services l2tp]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the L2TP tunnel properties.

Options *group-name*—Identifier for the tunnel group.

The remaining statements are explained separately.

Usage Guidelines See “Configuring L2TP Tunnel Groups” on page 292.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

tunnel-timeout

Syntax	tunnel-timeout <i>seconds</i> ;
Hierarchy Level	[edit services l2tp tunnel-group <i>name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the maximum downtime for an L2TP tunnel, after which the tunnel is terminated because the connection is presumed to have been lost.
Options	<i>seconds</i> —Interval after which the tunnel is terminated if no data can be sent. Default: 120 seconds
Usage Guidelines	See “Configuring Timers for L2TP Tunnels” on page 294.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 16

Link Services IQ Interfaces Configuration Guidelines

You can configure link services intelligent queuing (IQ) (LSQ or lsq-) interfaces on the Adaptive Services (AS) PIC, the internal Adaptive Services Module in the M7i platform, the Link Services II PIC, and the MultiServices PIC. LSQ interfaces are similar to link services interfaces, which are described in “Multilink and Link Services Logical Interface Configuration Overview” on page 979. The important difference is that LSQ interfaces fully support JUNOS class of service (CoS) components.

The AS or MultiServices PIC has a limit of 1023 logical interfaces. Each logical interface is a Multilink Point-to-Point Protocol (MLPPP) bundle, an FRF.15 bundle, or an FRF.16 DLCI.

This chapter describes the Layer 2 service package and the CoS and failure recovery capabilities of LSQ interfaces. For detailed information about Layer 3 services, see other chapters in this manual and the *JUNOS Feature Guide*.



NOTE: The Link Services II PIC offers the same functionality as the Layer 2 service package on AS or MultiServices PICs.

This chapter contains the following sections:

- Layer 2 Service Package Capabilities and Interfaces on page 320
- Configuring LSQ Interface Redundancy Across Multiple Routers Using SONET APS on page 322
- Configuring LSQ Interface Redundancy in a Single Router Using SONET APS on page 324
- Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces on page 324
- Configuring CoS Scheduling Queues on Logical LSQ Interfaces on page 332
- Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces on page 336
- Reserving Bundle Bandwidth for Link-Layer Overhead on LSQ Interfaces on page 338
- Configuring Multiclass MLPPP on LSQ Interfaces on page 338
- Oversubscribing Interface Bandwidth on LSQ Interfaces on page 340
- Configuring Guaranteed Minimum Rate on LSQ Interfaces on page 343

- Configuring Link Services and CoS on Services PICs on page 347
- Configuring Link Services and CoS on J-series Services Routers on page 350
- Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using MLPPP on page 351
- Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using FRF.16 on page 356
- Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using MLPPP and LFI on page 362
- Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using FRF.12 on page 366
- Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using FRF.15 on page 373
- Configuring LSQ Interfaces for T3 Links Configured for Compressed RTP over MLPPP on page 374
- Configuring LSQ Interfaces as T3 or OC3 Bundles Using FRF.12 on page 375
- Configuring LSQ Interfaces for ATM2 IQ Interfaces Using MLPPP on page 377

Layer 2 Service Package Capabilities and Interfaces

As described in “Enabling Service Packages” on page 35, you can configure the AS or MultiServices PIC and the internal ASM in the M7i platform to use either the Layer 2 or the Layer 3 service package.

When you enable the Layer 2 service package, the AS or MultiServices PIC supports *link services*. On the AS or MultiServices PIC and the ASM, link services include the following:

- JUNOS CoS components—The section “Configuring CoS Scheduling Queues on Logical LSQ Interfaces” on page 332 describes how the JUNOS CoS components work on link services IQ (lsq) interfaces. For detailed information about JUNOS CoS components, see the *JUNOS Class of Service Configuration Guide*.
- Data compression using the compressed Real-Time Transport Protocol (CRTP) for use in voice over IP (VoIP) transmission.



NOTE: On LSQ interfaces, all multilink traffic for a single bundle is sent to a single processor. If CRTP is enabled on the bundle, it adds overhead to the CPU. Because T3 network interfaces support only one link per bundle, make sure you configure a fragmentation map for compressed traffic on these interfaces and specify the **no-fragmentation** option. For more information, see “Configuring Delay-Sensitive Packet Interleaving” on page 396 and “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

- Link fragment interleaving (LFI) on Frame Relay links using FRF.12 end-to-end fragmentation—The standard for FRF.12 is defined in the specification FRF.12, *Frame Relay Fragmentation Implementation Agreement*.
- LFI on Multilink Point-to-Point Protocol (MLPPP) links.

- Multilink Frame Relay (MLFR) end-to-end (FRF.15)—The standard for FRF.15 is defined in the specification FRF.15, *End-to-End Multilink Frame Relay Implementation Agreement*.
- Multilink Frame Relay (MLFR) UNI NNI (FRF.16)—The standard for FRF.16 is defined in the specification FRF.16.1, *Multilink Frame Relay UNI/NNI Implementation Agreement*.
- MLPPP—The standard for MLPPP is defined in the specification RFC 1990, *The PPP Multilink Protocol (MP)*.
- Multiclass extension to MLPPP—The standard is defined in the specification RFC 2686, *The Multi-Class Extension to Multi-Link PPP*.

For the LSQ interface on the AS or MultiServices PIC, the configuration syntax is almost the same as for Multilink and Link Services PICs. The primary difference is the use of the interface-type descriptor **lsq** instead of **ml** or **ls**. When you enable the Layer 2 service package on the AS or MultiServices PIC, the following interfaces are automatically created:

```
gr-fpc/pic/port
ip-fpc/pic/port
lsq-fpc/pic/port
lsq-fpc/pic/port:0
...
lsq-fpc/pic/port:N
mt-fpc/pic/port
pd-fpc/pic/port
pe-fpc/pic/port
sp-fpc/pic/port
vt-fpc/pic/port
```

Interface types **gr**, **ip**, **mt**, **pd**, **pe**, and **vt** are standard tunnel interfaces that are available on the AS or MultiServices PIC whether you enable the Layer 2 or the Layer 3 service package. These tunnel interfaces function the same way for both service packages, except that the Layer 2 service package does not support some tunnel functions, as shown in Table 5 on page 24. For more information about tunnel interfaces, see “Tunnel Interfaces Configuration Guidelines” on page 1093.



NOTE: Interface type **sp** is created because it is needed by the JUNOS software. For the Layer 2 service package, the **sp** interface is not configurable, but you should not disable it.

Interface type **lsq-fpc/pic/port** is the physical link services IQ interface (**lsq**). Interface types **lsq-fpc/pic/port:0** through **lsq-fpc/pic/port:N** represent FRF.16 bundles. These interface types are created when you include the **mlfr-uni-nni-bundles** statement at the [edit chassis fpc slot-number pic pic-number] hierarchy level. For more information, see “Configuring CoS Scheduling Queues on Logical LSQ Interfaces” on page 332.



NOTE: On DS0, E1, or T1 interfaces in LSQ bundles, you can configure the **bandwidth** statement, but the routing platform does not use the bandwidth value if the interfaces are included in an MLPPP or MLFR bundle. The bandwidth is calculated internally according to the time slots, framing, and byte-encoding of the interface. For more information about these properties, see the *JUNOS Network Interfaces Configuration Guide*.

Configuring LSQ Interface Redundancy Across Multiple Routers Using SONET APS

Link services IQ (lsq-) interfaces that are paired with SONET PICs can use the Automatic Protection Switching (APS) configuration already available on SONET networks to provide failure recovery. SONET APS provides stateless failure recovery, if it is configured on SONET interfaces in separate chassis and each SONET PIC is paired with an AS or MultiServices PIC in the same chassis. If one of the following conditions for APS failure is met, the associated SONET PIC triggers recovery to the backup circuit and its associated AS or MultiServices PIC. The failure conditions are:

- Failure of Link Services IQ PIC
- Failure of FPC that hosts the Link Services IQ PIC
- Failure of Packet Forwarding Engine
- Failure of chassis

The guidelines for configuring SONET APS are described in the *JUNOS Network Interfaces Configuration Guide*.

The following sections describe how to configure failover properties:

- Configuring the Association between LSQ and SONET Interfaces on page 322
- Configuring SONET APS Interoperability with Cisco Systems FRF.16 on page 323
- Restrictions on APS Redundancy for LSQ Interfaces on page 324

Configuring the Association between LSQ and SONET Interfaces

To configure the association between AS or MultiServices PICs hosting link services IQ interfaces and the SONET interfaces, include the **lsq-failure-options** statement at the [edit interfaces] hierarchy level:

```
lsq-fpc/pic/port {
  lsq-failure-options {
    no-termination-request;
    [ trigger-link-failure interface-name ];
  }
}
```

For example, consider the following network scenario:

- Primary router includes interfaces **oc3-0/2/0** and **lsq-1/1/0**.
- Backup router includes interfaces **oc3-2/2/0** and **lsq-3/2/0**.

Configure SONET APS, with `oc3-0/2/0` as the working circuit and `oc3-2/2/0` as the protect circuit. Include the `trigger-link-failure` statement to extend failure to the LSQ PICs:

```
interfaces lsq-1/1/0 {
  lsq-failure-options {
    trigger-link-failure oc3-0/2/0;
  }
}
```



NOTE: You must configure the `lsq-failure-options` statement on the primary router only. The configuration is not supported on the backup router.

To inhibit the router from sending PPP termination-request messages to the remote host if the Link Services IQ PIC fails, include the `no-termination-request` statement at the `[edit interfaces lsq-fpc/pic/port lsq-failure-options]` hierarchy level:

```
[edit interfaces lsq-fpc/pic/port lsq-failure-options]
no-termination-request;
```

This functionality is supported on link PICs as well. To inhibit the router from sending PPP termination-request messages to the remote host if a link PIC fails, include the `no-termination-request` statement at the `[edit interfaces interface-name ppp-options]` hierarchy level.

```
[edit interfaces interface-name ppp-options]
no-termination-request;
```

The `no-termination-request` statement is supported only with MLPPP and SONET APS configurations and works with PPP, PPP over Frame Relay, and MLPPP interfaces only, on the following PICs:

- Channelized OC3 IQ PICs
- Channelized OC12 IQ PICs
- Channelized STM1 IQ PICs
- Channelized STM4 IQ PICs

Configuring SONET APS Interoperability with Cisco Systems FRF.16

Juniper Networks routers configured with APS might not interoperate correctly with Cisco FRF.16. To enable interoperation, include the `cisco-interoperability` statement at the `[edit interfaces lsq-fpc/pic/port mlfr-uni-nni-bundle-options]` hierarchy level:

```
[edit interfaces lsq-fpc/pic/port mlfr-uni-nni-bundle-options]
cisco-interoperability send-lip-remove-link-for-link-reject;
```

The `send-lip-remove-link-for-link-reject` option prompts the router to send a Link Integrity Protocol remove link when it receives an add-link rejection message.

Restrictions on APS Redundancy for LSQ Interfaces

The following restrictions apply to LSQ failure recovery:

- It applies only to Link Services IQ PICs installed in M-series routing platforms, except for M320 routers.
- You must configure the **failure-options** statement on physical LSQ interfaces, not on MLFR channelized units.
- The Link Services IQ PICs must be associated with SONET link PICs. The paired PICs can be installed on different routers or in the same router; in other words, both interchassis and intrachassis recovery are supported
- Failure recovery is stateless; as a result, route flapping and loss of link state is expected in interchassis recovery, requiring PPP renegotiation. In intrachassis recovery, no impact on traffic is anticipated with Routing Engine failover, but PIC failover results in PPP renegotiation.
- The switchover is not revertive: when the original hardware is restored to service, traffic does not automatically revert back to it.
- Normal APS switchover and PIC-triggered APS switchover can be distinguished only by checking the system log messages.



NOTE: When an AS PIC experiences persistent back pressure as a result of high traffic volume for 3 seconds, the condition triggers an automatic core dump and reboot of the PIC to help clear the blockage. A system log message at level LOG_ERR is generated. This mechanism applies to both Layer 2 and Layer 3 service packages.

Configuring LSQ Interface Redundancy in a Single Router Using SONET APS

Stateless switchover from one Link Services IQ PIC to another within the same router can be configured by using the SONET APS mechanism described in “Configuring LSQ Interface Redundancy Across Multiple Routers Using SONET APS” on page 322. Each Link Services IQ PIC must be associated with a specified SONET link PIC within the same router.



NOTE: For complete intrachassis recovery, including recovery from Routing Engine failover, graceful Routing Engine switchover (GRES) must be enabled on the router. For more information, see the *JUNOS System Basics Configuration Guide*.

Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces

You can configure failure recovery on M-series and T-series routing platforms that have multiple AS or MultiServices PICs with **lsq** interfaces by specifying a virtual LSQ redundancy (**rlsq**) interface in which the primary Link Services IQ PIC is active and a secondary PIC is on standby. If the primary PIC fails, the secondary PIC becomes

active, and all LSQ processing is transferred to it. To determine which PIC is currently active, issue the **show interfaces redundancy** command.



NOTE: This configuration does not require the use of SONET APS for failover. Network interfaces that do not support SONET can be used, such as T1 or E1 interfaces.

The following sections provide more information:

- Configuring Redundant Paired LSQ Interfaces on page 325
- Restrictions on Redundant LSQ Interfaces on page 326
- Configuring Link State Replication for Redundant Link PICs on page 327
- Examples: Configuring Redundant LSQ Interfaces for Failure Recovery on page 328

Configuring Redundant Paired LSQ Interfaces

The physical interface type **rlsq** specifies the pairings between primary and secondary **lsq** interfaces to enable redundancy. To configure a backup **lsq** interface, include the **redundancy-options** statement at the **[edit interfaces rlsqnumber]** hierarchy level:

```
[edit interfaces rlsqnumber]
redundancy-options {
  (hot-standby | warm-standby);
  primary lsq-fpc/pic/port;
  secondary lsq-fpc/pic/port;
}
```

For the **rlsq** interface, *number* can be from 0 through 1023. If the primary **lsq** interface fails, traffic processing switches to the secondary interface. The secondary interface remains active even after the primary interface recovers. If the secondary interface fails and the primary interface is active, processing switches to the primary interface.

The **hot-standby** option is used with one-to-one redundancy configurations, in which one working PIC is supported by one backup PIC. It sets the requirement for the failure detection and recovery time to be less than 5 seconds. The behavior is revertive, but you can manually switch between the primary and secondary PICs by issuing the **request interfaces (revert | switchover) rlsqnumber** operational mode command.

The **warm-standby** option is used with redundancy configurations in which one backup PIC supports multiple working PICs. Recovery times are not guaranteed, because the configuration must be completely restored on the backup PIC after a failure is detected.



NOTE: The **hot-standby** option is supported only with MLPPP and CRTP configurations. The **warm-standby** option is also supported with LSQ FRF.15 and FRF.16 bundle configurations and with L2TP and flow monitoring services.

Restrictions on Redundant LSQ Interfaces

Link Services IQ PIC failure occurs under the following conditions:

- The primary PIC fails to boot. In this case, the **rlsq** interface does not come up and manual intervention is necessary to reboot or replace the PIC, or to rename the primary PIC to the secondary one in the **rlsq** configuration.
- The primary PIC becomes active and then fails. The secondary PIC automatically takes over processing.
- A failover to the secondary PIC takes place. The secondary PIC then fails. If the primary PIC has been restored to active state, processing switches to it.
- The FPC that contains the Link Services IQ PIC fails.

The following constraints apply to redundant LSQ configurations:

- We recommend that primary and secondary PICs be configured in two different FPCs (in chassis other than M10i routers).
- You cannot configure a Link Services IQ PIC with explicit bundle configurations and as a constituent of an **rlsq** interface.
- Redundant LSQ configurations provide full GRES support. (You must configure GRES at the **[edit chassis]** hierarchy level; see the *JUNOS System Basics Configuration Guide*.)
- If you configure the **redundancy-options** statement with the **hot-standby** option, the configuration must include one **primary** interface value and one **secondary** interface value. If you configure the **warm-standby** option, you can include multiple instances of the **primary** interface.
- Since the same interface name is used for **hot-standby** and **warm-standby**, if you modify the configuration to change this attribute, it is recommended that you first deactivate the interface, commit the new configuration, and then reactivate the interface.
- You cannot make changes to an active **redundancy-options** configuration. You must deactivate the **rlsqnumber** interface configuration, change it, and reactivate it.
- The **rlsqnumber** configuration becomes active only if the primary interface is active. When the configuration is first activated, the primary interface must be active; if not, the **rlsq** interface waits until the primary interface comes up.
- You cannot modify the configuration of **lsq** interfaces after they have been included in an active **rlsq** interface.
- All the operational mode commands that apply to **rsp** interfaces also apply to **rlsq** interfaces. You can issue **show** commands for the **rlsq** interface or the primary and secondary **lsq** interfaces. However, statistics on the link interfaces are not carried over following a Routing Engine switchover.
- The **rlsq** interfaces also support the **lsq-failure-options** configuration, discussed in “Configuring LSQ Interface Redundancy Across Multiple Routers Using SONET APS” on page 322. If the primary and secondary Link Services IQ PICs fail and

the `lsq-failure-options` statement is configured, the configuration triggers a SONET APS switchover.

- Redundant LSQ configurations that require MLPPP Multilink Frame Relay (FRF.15 and FRF.16) are supported only with the **warm-standby** option.
- Redundant LSQ support is extended to ATM network interfaces.
- Channelized interfaces are used with FRF-16 bundles, for example `rlsq0:0`. The `rlsq` number and its constituents, the **primary** and **secondary** interfaces, must match for the configuration to be valid: either all must be channelized, or none. For an example of an FRF.16 configuration, see “Configuring LSQ Interface Redundancy for an FRF.16 Bundle” on page 332.



NOTE: Adaptive Services and MultiServices PICs in layer-2 mode (running Layer 2 services) are not rebooted when a MAC flow-control situation is detected.

Configuring Link State Replication for Redundant Link PICs

Link state replication, also called *interface preservation*, is an addition to the SONET Automatic Protection Switching (APS) functionality that helps promote redundancy of the link PICs used in LSQ configurations.

Link state replication provides the ability to add two sets of links, one from the active (working) SONET PIC and the other from the backup (protect) SONET PIC to the same bundle. If the active SONET PIC fails, links from the standby PIC are used without causing a link renegotiation. All the negotiated state is replicated from the active links to the standby links to prevent link renegotiation. For more information about SONET APS configurations, see the *JUNOS Network Interfaces Configuration Guide*.

To configure link state replication, include the **preserve-interface** statement at the `[edit interfaces interface-name sonet-options aps]` hierarchy level on both network interfaces:

```
edit interfaces interface-name sonet-options aps]
  preserve-interface;
```

The following constraints apply to link PIC redundancy:

- APS functionality must be available on the SONET PICs and the interface configurations must be identical on both ends of the link. Any configuration mismatch causes the commit operation to fail.
- This feature is supported only with LSQ and SONET APS-enabled link PICs, including Channelized OC3, Channelized OC12, and Channelized STM1 intelligent queuing (IQ) PICs.
- Link state replication supports MLPPP and PPP over Frame Relay (**frame-relay-ppp**) encapsulation, and fully supports GRES.
- Enabling the interface or protocol traceoptions with a large number of MLPPP links can trigger Link Control Protocol (LCP) renegotiation during the link switchover time.



NOTE: This renegotiation is more likely to take place for configurations with back-to-back Juniper Networks routers than in networks in which a Juniper Networks router is connected to an add/drop multiplexer (ADM).

- In general, networks that connect a Juniper Networks router to an ADM allow faster MLPPP link switchover than those with back-to-back Juniper Networks routers. The MLPPP link switchover time difference may be significant, especially for networks with a large number of MLPPP links.
- An aggressive LCP keepalive timeout configuration can lead to LCP renegotiation during the MLPPP link switchover. By default, the LCP keepalive timer interval is 10 seconds and the consecutive link down count is 3. The MLPPP links start LCP negotiation only after a timeout of 30 seconds. Lowering these configuration values may trigger one or more of the MLPPP links to renegotiate during the switchover time.



NOTE: LCP renegotiation is more likely to take place for configurations with back-to-back Juniper Networks routers than in networks in which a Juniper Networks router is connected to an ADM.

As an example, the following configuration shows the link state replication configuration between the ports `coc3-1/0/0` and `coc3-2/0/0`.

```

interfaces {
  coc3-1/0/0 {
    sonet-options {
      aps {
        preserve-interface;
        working-circuit aps-group-1;
      }
    }
  }
  coc3-2/0/0 {
    sonet-options {
      aps {
        preserve-interface;
        protect-circuit aps-group-1;
      }
    }
  }
}

```

Examples: Configuring Redundant LSQ Interfaces for Failure Recovery

Configuring LSQ Interface Redundancy for MLPPP

The following configuration shows that `lsq-1/1/0` and `lsq-1/3/0` work as a pair and the redundancy type is `hot-standby`, which sets the requirement for the failure detection and recovery time to be less than 5 seconds:

```

interfaces rlsq0 {

```



```

redundancy-options {
    primary lsq-1/1/0;
    secondary lsq-1/3/0;
    hot-standby; #either hot-standby or warm-standby is supported
}

```

The following example shows a related MLPPP configuration:



NOTE: MLPPP protocol configuration is required for this configuration.

```

interfaces {
    t1-1/1/2/0 {
        unit 0 {
            family mlppp {
                bundle rlsq0.0;
            }
        }
    }
    rlsq0 {
        unit 0 {
            family inet {
                address 30.1.1.2/24;
            }
        }
    }
}

```

The following example shows a related CoS configuration:

```

class-of-service {
    interfaces {
        rlsq0 {
            unit * {
                fragmentation-maps fr-map1;
            }
        }
    }
}

```

The following example shows a complete link state replication configuration for MLPPP. This example uses two bundles, each with four T1 links. The first four T1 links (t1-*:1 through t1-*:4) form the first bundle and the last four T1 links (t1-*:5 through t1-*:8) form the second bundle. To minimize the duplication in the configuration, this example uses the **[edit groups]** statement; for more information, see the *JUNOS System Basics Configuration Guide*. This type of configuration is not required; it simplifies the task and minimizes duplication.

```

groups {
    ml-partition-group {
        interfaces {
            <coc3-*> {
                partition 1 oc-slice 1 interface-type coc1;
            }
        }
    }
}

```

```

    }
    <coc1-*> {
        partition 1-8 interface-type t1;
    }
}
ml-bundle-group-1 {
    interfaces {
        <t1-*:"[1-4]"> {
            encapsulation ppp;
            unit 0 {
                family mlppp {
                    bundle lsq-0/1/0.0;
                }
            }
        }
    }
}
ml-bundle-group-2 {
    interfaces {
        <t1-*:"[5-8]"> {
            encapsulation ppp;
            unit 0 {
                family mlppp {
                    bundle lsq-0/1/0.1;
                }
            }
        }
    }
}
}
interfaces {
    lsq-0/1/0 {
        unit 0 {
            encapsulation multilink-ppp;
            family inet {
                address 1.1.1.1/32 {
                    destination 1.1.1.2;
                }
            }
        }
        unit 1 {
            encapsulation multilink-ppp;
            family inet {
                address 1.1.2.1/32 {
                    destination 1.1.2.2;
                }
            }
        }
    }
}
coc3-1/0/0 {
    apply-groups ml-partition-group;
    sonet-options {
        aps {
            preserve-interface;
            working-circuit aps-group-1;
        }
    }
}

```

```

    }
  }
}
coc1-1/0/0:1 {
  apply-groups ml-partition-group;
}
t1-1/0/0:1:1 {
  apply-groups ml-bundle-group-1;
}
t1-1/0/0:1:2 {
  apply-groups ml-bundle-group-1;
}
t1-1/0/0:1:3 {
  apply-groups ml-bundle-group-1;
}
t1-1/0/0:1:4 {
  apply-groups ml-bundle-group-1;
}
t1-1/0/0:1:5 {
  apply-groups ml-bundle-group-2;
}
t1-1/0/0:1:6 {
  apply-groups ml-bundle-group-2;
}
t1-1/0/0:1:7 {
  apply-groups ml-bundle-group-2;
}
t1-1/0/0:1:8 {
  apply-groups ml-bundle-group-2;
}
coc3-2/0/0 {
  apply-groups ml-partition-group;
  sonet-options {
    aps {
      preserve-interface;
      protect-circuit aps-group-1;
    }
  }
}
coc1-2/0/0:1 {
  apply-groups ml-partition-group;
}
t1-2/0/0:1:1 {
  apply-groups ml-bundle-group-1;
}
t1-2/0/0:1:2 {
  apply-groups ml-bundle-group-1;
}
t1-2/0/0:1:3 {
  apply-groups ml-bundle-group-1;
}
t1-2/0/0:1:4 {
  apply-groups ml-bundle-group-1;
}
t1-2/0/0:1:5 {
  apply-groups ml-bundle-group-2;
}

```

```

    }
    t1-2/0/0:1:6 {
        apply-groups ml-bundle-group-2;
    }
    t1-2/0/0:1:7 {
        apply-groups ml-bundle-group-2;
    }
    t1-2/0/0:1:8 {
        apply-groups ml-bundle-group-2;
    }
}

```

Configuring LSQ Interface Redundancy for an FRF.15 Bundle

The following example shows a configuration for an FRF.15 bundle:

```

interfaces rlsq0 {
    redundancy-options {
        primary lsq-1/2/0;
        secondary lsq-1/3/0;
        warm-standby;
    }
    unit 0 {
        encapsulation multilink-frame-relay-end-to-end;
        family inet {
            address 30.1.1.1/24;
        }
    }
}

```

Configuring LSQ Interface Redundancy for an FRF.16 Bundle

The following example shows a configuration for an FRF.16 bundle:

```

interfaces rlsq0:0 {
    dce;
    encapsulation multilink-frame-relay-uni-nni;
    redundancy-options {
        primary lsq-1/2/0:0;
        secondary lsq-1/3/0:0;
        warm-standby;
    }
    unit 0 {
        dlci 1000;
        family inet {
            address 50.1.1.1/24;
        }
    }
}

```

Configuring CoS Scheduling Queues on Logical LSQ Interfaces

For link services IQ (lsq-) interfaces, you can specify a scheduler map for each logical unit. A logical unit represents either an MLPPP bundle or a DLCI configured on a FRF.16 bundle. The scheduler is applied to the traffic sent to an AS or MultiServices PIC running the Layer 2 link services package.

If you configure a scheduler map on a bundle, you must include the **per-unit-scheduler** statement at the `[edit interfaces lsq-fpc/pic/port]` hierarchy level. If you configure a scheduler map on an FRF.16 DLCI, you must include the **per-unit-scheduler** statement at the `[edit interfaces lsq-fpc/pic/port:channel]` hierarchy level. For more information, see the *JUNOS Class of Service Configuration Guide*.

If you need latency guarantees for multiclass or LFI traffic, you must use channelized IQ PICs for the constituent links. With non-IQ PICs, because queueing is not done at the channelized interface level on the constituent links, latency-sensitive traffic might not receive the type of service that it should. Constituent links from the following PICs support latency guarantees:

- Channelized E1 IQ PIC
- Channelized OC3 IQ PIC
- Channelized OC12 IQ PIC
- Channelized STM1 IQ PIC
- Channelized T3 IQ PIC

For scheduling queues on a logical interface, you can configure the following scheduler map properties at the `[edit class-of-service schedulers]` hierarchy level:

- **buffer-size**—The queue size; for more information, see “Configuring Scheduler Buffer Size” on page 334.
- **priority**—The transmit priority (low, high, strict-high); for more information, see “Configuring Scheduler Priority” on page 334.
- **shaping-rate**—The subscribed transmit rate; for more information, see “Configuring Scheduler Shaping Rate” on page 334.
- **drop-profile-map**—The random early detection (RED) drop profile; for more information, see “Configuring Drop Profiles” on page 335.

When you configure MLPPP and FRF.12 on M-series and T-series routing platforms, you should configure a single scheduler with non-zero percent transmission rates and buffer sizes for queues 0 through 3, and assign this scheduler to the link services IQ interface (**lsq**) and to each constituent link.

When you configure FRF.16 on M-series and T-series routing platforms, you can assign a single scheduler map to the link services IQ interface (**lsq**) and to each link services IQ DLCI, or you can assign different scheduler maps to the various DLCIs of the bundle, as shown in “Example: Configuring an LSQ Interface as an NxT1 Bundle Using FRF.16” on page 359. For the constituent links of an FRF.16 bundle, you do not need to configure a custom scheduler. Because LFI and multiclass are not supported for FRF.16, the traffic from each constituent link is transmitted from queue 0. This means you should allow most of the bandwidth to be used by queue 0. The default scheduler transmission rate and buffer size percentages for queues 0 through 3 are 95, 0, 0, and 5 percent, respectively. This default scheduler sends all user traffic to queue 0 and all network-control traffic to queue 3, and therefore it is well suited to the behavior of FRF.16. You can configure a custom scheduler that explicitly replicates the 95, 0, 0, and 5 percent queueing behaviors, and apply it to the constituent links.



NOTE: On T-series and M320 platforms, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 5, 0, 0, 0, and 0 percent.

For link services IQ interfaces (**lsq**), these scheduling properties work as they do in other PICs, except as noted in the following sections.



NOTE: On T-series and M320 platforms, **lsq** interfaces do not support DiffServ code point (DSCP) and DSCP-IPv6 rewrite markers.

Configuring Scheduler Buffer Size

You can configure the scheduler buffer size in three ways: as a temporal value, as a percentage, and as a remainder. On a single logical interface (MLPPP or a FRF.16 DLCI), each queue can have a different buffer size.

If you specify a temporal value, the queuing algorithm starts dropping packets when it queues more than a computed number of bytes. This number is computed by multiplying logical interface speed by the temporal value. For MLPPP bundles, logical interface speed is equal to the bundle bandwidth, which is the sum of constituent link speeds minus link-layer overhead. For MLFR FRF.16 DLCIs, logical interface speed is equal to bundle bandwidth multiplied by the DLCI shaping rate. In all cases, the maximum temporal value is limited to 200 milliseconds.

Buffer size percentages are implicitly converted into temporal values by multiplying the percentage by 200 milliseconds. For example, buffer size specified as **buffer-size percent 20** is the same as a 40-millisecond temporal delay. The link services IQ implementation guarantees 200 milliseconds of buffer delay for all interfaces with T1 and higher speeds. For slower interfaces, it guarantees one second of buffer delay.

The queueing algorithm evenly distributes leftover bandwidth among all queues that are configured with the **buffer-size remainder** statement. The queueing algorithm guarantees enough space in the transmit buffer for two MTU-sized packets.

Configuring Scheduler Priority

The transmit priority of each queue is determined by the scheduler and the forwarding class. Each queue receives a guaranteed amount of bandwidth specified with the scheduler **transmit-rate** statement.

Configuring Scheduler Shaping Rate

You use the shaping rate to set the percentage of total bundle bandwidth that is dedicated to a DLCI. For link services IQ DLCIs, only percentages are accepted, which allows adjustments in response to dynamic changes in bundle bandwidth—for example, when a link goes up or down. This means that absolute shaping rates are not supported on FRF.16 bundles. Absolute shaping rates are allowed for MLPPP and MLFR bundles only.

For scheduling between DLCIs in a MLFR FRF.16 bundle, you can configure a shaping rate for each DLCI. A shaping rate is expressed as a percentage of the aggregate bundle bandwidth. Shaping rate percentages for all DLCIs within a bundle can add up to 100 percent or less. Leftover bandwidth is distributed equally to DLCIs that do not have the `shaping-rate` statement included at the `[edit class-of-service interfaces lsq-fpc/pic/port:channel unit logical-unit-number]` hierarchy level. If none of the DLCIs in an MLFR FRF.16 bundle specify a DLCI scheduler, the total bandwidth is evenly divided across all DLCIs.



NOTE: For FRF.16 bundles on link services IQ interfaces, only shaping rates based on percentage are supported.

Configuring Drop Profiles

You can configure random early detection (RED) on LSQ interfaces as in other CoS scenarios. To configure RED, include one or more drop profiles and attach them to a scheduler for a particular forwarding class. For more information about RED profiles, see the *JUNOS Class of Service Configuration Guide*.

The LSQ implementation performs tail RED. It supports a maximum of 256 drop profiles per PIC. Drop profiles are configurable on a per-queue, per-loss-priority, and per-TCP-bit basis.

You can attach scheduler maps with configured RED drop profiles to any LSQ logical interface: an MLPPP bundle, an FRF.15 bundle, or an FRF.16 DLCI. Different queues (forwarding classes) on the same logical interface can have different associated drop profiles.

The following example shows how to configure a RED profile on an LSQ interface:

```
[edit]
class-of-service {
  drop-profiles {
    drop-low {
      # Configure suitable drop profile for low loss priority
      ...
    }
    drop-high {
      # Configure suitable drop profile for high loss priority
      ...
    }
  }
  scheduler-maps {
    schedmap {
      # Best-effort queue will use be-scheduler
      # Other queues may use different schedulers
      forwarding-class be scheduler be-scheduler;
      ...
    }
  }
  schedulers {
    be-scheduler {
```

```

        # Configure two drop profiles for low and high loss priority
        drop-profile-map loss-priority low protocol any drop-profile drop-low;
        drop-profile-map loss-priority high protocol any drop-profile drop-high;
        # Other scheduler parameters (buffer-size, priority,
        # and transmit-rate) are already supported.
        ...
    }
}
interfaces {
    lsq-1/3/0.0 {
        # Attach a scheduler map (that includes RED drop profiles)
        # to a LSQ logical interface.
        scheduler-map schedmap;
    }
}
}

```



NOTE: The RED profiles should be applied only on the LSQ bundles and not on the egress links that constitute the bundle.

Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces

For link services IQ (lsq-) interfaces, you can specify fragmentation properties for specific forwarding classes. Traffic on each forwarding class can be either multilink encapsulated (fragmented and sequenced) or nonencapsulated (hashed with no fragmentation). By default, traffic in all forwarding classes is multilink encapsulated.

When you do not configure fragmentation properties for the queues on MLPPP interfaces, the fragmentation threshold you set at the [edit interfaces *interface-name* unit *logical-unit-number* fragment-threshold] hierarchy level is the fragmentation threshold for all forwarding classes within the MLPPP interface. For MLFR FRF.16 interfaces, the fragmentation threshold you set at the [edit interfaces *interface-name* mlfr-uni-nni-bundle-options fragment-threshold] hierarchy level is the fragmentation threshold for all forwarding classes within the MLFR FRF.16 interface.

If you do not set a maximum fragment size anywhere in the configuration, packets are still fragmented if they exceed the smallest maximum transmission unit (MTU) or maximum received reconstructed unit (MRRU) of all the links in the bundle. A nonencapsulated flow uses only one link. If the flow exceeds a single link, then the forwarding class must be multilink encapsulated, unless the packet size exceeds the MTU/MRRU.

Even if you do not set a maximum fragment size anywhere in the configuration, you can configure the MRRU by including the mrru statement at the [edit interfaces *lsq-fpc/pic/port* unit *logical-unit-number*] or [edit interfaces *interface-name* mlfr-uni-nni-bundle-options] hierarchy level. The MRRU is similar to the MTU, but is specific to link services interfaces. By default the MRRU size is 1500 bytes, and you can configure it to be from 1500 through 4500 bytes. For more information, see “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.

To configure fragmentation properties on a queue, include the **fragmentation-maps** statement at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
fragmentation-maps {
  map-name {
    forwarding-class class-name {
      (fragment-threshold bytes | no-fragmentation);
      multilink-class number;
    }
  }
}
```

To set a per-forwarding class fragmentation threshold, include the **fragment-threshold** statement in the fragmentation map. This statement sets the maximum size of each multilink fragment.

To set traffic on a queue to be nonencapsulated rather than multilink encapsulated, include the **no-fragmentation** statement in the fragmentation map. This statement specifies that an extra fragmentation header is not prepended to the packets received on this queue and that static link load balancing is used to ensure in-order packet delivery.

For a given forwarding class, you can include either the **fragment-threshold** or **no-fragmentation** statement; they are mutually exclusive.

You use the **multilink-class** statement to map a forwarding class into a multiclass MLPPP (MCML). For a given forwarding class, you can include either the **multilink-class** or **no-fragmentation** statement; they are mutually exclusive. For more information about MCML, see “Configuring Multiclass MLPPP on LSQ Interfaces” on page 338.

To associate a fragmentation map with a multilink PPP interface or MLFR FRF.16 DLCI, include the **fragmentation-map** statement at the [edit class-of-service interfaces *interface-name* unit *logical-unit-number*] hierarchy level:

```
[edit class-of-service interfaces]
lsq-fpc/pic/port {
  unit logical-unit-number { # Multilink PPP
    fragmentation-map map-name;
  }
  lsq-fpc/pic/port:channel { # MLFR FRF.16
    unit logical-unit-number {
      fragmentation-map map-name;
    }
  }
}
```

For configuration examples, see the following topics:

- Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using MLPPP on page 351
- Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using FRF.16 on page 356
- Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using MLPPP and LFI on page 362
- Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using FRF.12 on page 366

- Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using FRF.15 on page 373
- Configuring LSQ Interfaces for T3 Links Configured for Compressed RTP over MLPPP on page 374
- Configuring LSQ Interfaces as T3 or OC3 Bundles Using FRF.12 on page 375
- Configuring LSQ Interfaces for ATM2 IQ Interfaces Using MLPPP on page 377

For Link Services PIC link services (ls-) interfaces, fragmentation maps are not supported. Instead, you enable LFI by including the `interleave-fragments` statement at the `[edit interfaces interface-name unit logical-unit-number]` hierarchy level. For more information, see “Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces” on page 988.

Reserving Bundle Bandwidth for Link-Layer Overhead on LSQ Interfaces

Link-layer overhead can cause packet drops on constituent links because of bit stuffing on serial links. Bit stuffing is used to prevent data from being interpreted as control information.

By default, 4 percent of the total bundle bandwidth is set aside for link-layer overhead. In most network environments, the average link-layer overhead is 1.6 percent. Therefore, we recommend 4 percent as a safeguard. For more information, see RFC 4814, *Hash and Stuffing: Overlooked Factors in Network Device Benchmarking*.

For link services IQ (lsq-) interfaces, you can configure the percentage of bundle bandwidth to be set aside for link-layer overhead. To do this, include the `link-layer-overhead` statement:

```
link-layer-overhead percent;
```

You can include this statement at the following hierarchy levels:

- `[edit interfaces interface-name mlfr-uni-nni-bundle-options]`
- `[edit interfaces interface-name unit logical-unit-number]`
- `[edit logical-systems logical-system-name interfaces interface-name unit logical-unit-number]`

You can configure the value to be from 0 percent through 50 percent.

Configuring Multiclass MLPPP on LSQ Interfaces

For link services IQ (lsq-) interfaces with MLPPP encapsulation, you can configure multiclass MLPPP (MCML). If you do not configure MCML, fragments from different classes cannot be interleaved. All fragments for a single packet must be sent before the fragments from another packet are sent. Nonfragmented packets can be interleaved between fragments of another packet to reduce latency seen by nonfragmented packets. In effect, latency-sensitive traffic is encapsulated as regular PPP traffic, and bulk traffic is encapsulated as multilink traffic. This model works as long as there is a single class of latency-sensitive traffic, and there is no high-priority traffic that takes precedence over latency-sensitive traffic. This approach to LFI, used

on the Link Services PIC, supports only two levels of traffic priority, which is not sufficient to carry the four-to-eight forwarding classes that are supported by M-series and T-series routing platforms. For more information about the Link Services PIC support of LFI, see “Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces” on page 988.

For link services IQ interfaces only, you can configure MCML, as defined in RFC 2686, *The Multi-Class Extension to Multi-Link PPP*. MCML makes it possible to have multiple classes of latency-sensitive traffic that are carried over a single multilink bundle with bulk traffic. In effect, MCML allows different classes of traffic to have different latency guarantees. With MCML, you can map each forwarding class into a separate multilink class, thus preserving priority and latency guarantees.



NOTE: Configuring both LFI and MCML on the same bundle is not necessary, nor is it supported, because multiclass MLPPP represents a superset of functionality. When you configure multiclass MLPPP, LFI is automatically enabled.

The JUNOS software implementation of MCML does not support compression of common header bytes, which is referred to in RFC 2686 as “prefix elision.”

MCML greatly simplifies packet ordering issues that occur when multiple links are used. Without MCML, all voice traffic belonging to a single flow is hashed to a single link to avoid packet ordering issues. With MCML, you can assign voice traffic to a high-priority class, and you can use multiple links. For more information about voice services support on link services IQ interfaces (lsq), see “Configuring Services Interfaces for Voice Services” on page 394.

To configure MCML on a link services IQ interface, you must specify how many multilink classes should be negotiated when a link joins the bundle, and you must specify the mapping of a forwarding class into an MCML class.

To specify how many multilink classes should be negotiated when a link joins the bundle, include the `multilink-max-classes` statement:

```
multilink-max-classes number;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

The number of multilink classes can be 1 through 8. The number of multilink classes for each forwarding class must not exceed the number of multilink classes to be negotiated.

To specify the mapping of a forwarding class into a MCML class, include the `multilink-class` statement at the [edit class-of-service fragmentation-maps *map-name* forwarding-class *class-name*] hierarchy level:

```
[edit class-of-service fragmentation-maps map-name forwarding-class class-name]
```

```
multilink-class number;
```

The multilink class index number can be 0 through 7. The `multilink-class` statement and `no-fragmentation` statements are mutually exclusive.

To view the number of multilink classes negotiated, issue the `show interfaces lsq-fpc/pic/port.logical-unit-number detail` command.

Oversubscribing Interface Bandwidth on LSQ Interfaces

The term *oversubscribing interface bandwidth* means configuring shaping rates (peak information rates [PIRs]) so that their sum exceeds the interface bandwidth.

On Channelized IQ PICs, Gigabit Ethernet IQ PICs, and FRF.16 link services IQ (lsq-) interfaces on AS and MultiServices PICs, you can oversubscribe interface bandwidth. The logical interfaces (and DLCIs within an FRF.16 bundle) can be oversubscribed when there is leftover bandwidth. The oversubscription is limited to the configured PIR. Any unused bandwidth is distributed equally among oversubscribed logical interfaces or DLCIs.

For networks that are not likely to experience congestion, oversubscribing interface bandwidth improves network utilization, thereby allowing more customers to be provisioned on a single interface. If the actual data traffic does not exceed the interface bandwidth, oversubscription allows you to sell more bandwidth than the interface can support.

We recommend avoiding oversubscription in networks that are likely to experience congestion. Be careful not to oversubscribe a service by too much, because this can cause degradation in the performance of the routing platform during congestion. When you configure oversubscription, some output queues can be starved if the actual data traffic exceeds the physical interface bandwidth. You can prevent degradation by using statistical multiplexing to ensure that the actual data traffic does not exceed the interface bandwidth.

To configure oversubscription of an interface, perform the following steps:

1. Include the `shaping-rate` statement at the [edit class-of-service traffic-control-profiles *profile-name*] hierarchy level:

```
[edit class-of-service traffic-control-profiles profile-name]  
  shaping-rate (percent percentage | rate);
```

On LSQ interfaces, you can configure the shaping rate as a percentage.

On IQ and IQ2 interfaces, you can configure the shaping rate as an absolute rate from 1000 through 160,000,000,000 bits per second.

Alternatively, you can configure a shaping rate for a logical interface and oversubscribe the physical interface by including the `shaping-rate` statement at the [edit class-of-service interfaces *interface-name* unit *logical-unit-number*] hierarchy level. However, with this configuration approach, you cannot independently control the delay-buffer rate, as described in Step 2.



NOTE: For channelized and Gigabit Ethernet IQ interfaces, the **shaping-rate** and **guaranteed-rate** statements are mutually exclusive. You cannot configure some logical interfaces to use a shaping rate and others to use a guaranteed rate. This means there are no service guarantees when you configure a PIR. For these interfaces, you can configure either a PIR or a committed information rate (CIR), but not both.

This restriction does not apply to Gigabit Ethernet IQ2 PICs or link services IQ (LSQ) interfaces on AS or MultiServices PICs. For LSQ and Gigabit Ethernet IQ2 interfaces, you can configure both a PIR and a CIR on an interface. For more information about CIRs, see “Configuring Guaranteed Minimum Rate on LSQ Interfaces” on page 343.

2. Optionally, you can base the delay buffer calculation on a delay-buffer rate. To do this, include the **delay-buffer-rate** statement at the [edit class-of-service traffic-control-profiles *profile-name*] hierarchy level:

```
[edit class-of-service traffic-control-profiles profile-name]
  delay-buffer-rate (percent percentage | rate);
```

The delay-buffer rate overrides the shaping rate as the basis for the delay-buffer calculation. In other words, the shaping rate or scaled shaping rate is used for delay-buffer calculations only when the delay-buffer rate is not configured.

For LSQ interfaces, if you do not configure a delay-buffer rate, the guaranteed rate (CIR) is used to assign buffers. If you do not configure a guaranteed rate, the shaping rate (PIR) is used in the undersubscribed case, and the scaled shaping rate is used in the oversubscribed case.

On LSQ interfaces, you can configure the delay-buffer rate as a percentage.

On IQ and IQ2 interfaces, you can configure the delay-buffer rate as an absolute rate from 1000 through 160,000,000,000 bits per second.

The actual delay buffer is based on the calculations described in the *JUNOS Class of Service Configuration Guide*. For an example showing how the delay-buffer rates are applied, see “Example: Oversubscribing an LSQ Interface” on page 343.

Configuring large buffers on relatively low-speed links can cause packet aging. To help prevent this problem, the software requires that the sum of the delay-buffer rates be less than or equal to the port speed.

This restriction does not eliminate the possibility of packet aging, so you should be cautious when using the **delay-buffer-rate** statement. Though some amount of extra buffering might be desirable for burst absorption, delay-buffer rates should not far exceed the service rate of the logical interface.

If you configure delay-buffer rates so that the sum exceeds the port speed, the configured delay-buffer rate is not implemented for the last logical interface that you configure. Instead, that logical interface receives a delay-buffer rate of zero, and a warning message is displayed in the CLI. If bandwidth becomes available (because another logical interface is deleted or deactivated, or the port speed is

increased), the configured delay-buffer-rate is reevaluated and implemented if possible.

If you do not configure a delay-buffer rate or a guaranteed rate, the logical interface receives a delay-buffer rate in proportion to the shaping rate and the remaining delay-buffer rate available. In other words, the delay-buffer rate for each logical interface with no configured delay-buffer rate is equal to:

$$(\text{remaining delay-buffer rate} * \text{shaping rate}) / (\text{sum of shaping rates})$$

The remaining delay-buffer rate is equal to:

$$(\text{interface speed}) - (\text{sum of configured delay-buffer rates})$$

3. To assign a scheduler map to the logical interface, include the **scheduler-map** statement at the [edit class-of-service traffic-control-profiles *profile-name*] hierarchy level:

```
[edit class-of-service traffic-control-profiles profile-name]
scheduler-map map-name;
```

For information about configuring schedulers and scheduler maps, see the *JUNOS Class of Service Configuration Guide*.

4. Optionally, you can enable large buffer sizes to be configured. To do this, include the **q-pic-large-buffer** statement at the [edit chassis fpc *slot-number* pic *pic-number*] hierarchy level:

```
[edit chassis fpc slot-number pic pic-number]
q-pic-large-buffer;
```

If you do not include this statement, the delay-buffer size is more restricted. We recommend restricted buffers for delay-sensitive traffic, such as voice traffic. For more information, see the *JUNOS Class of Service Configuration Guide*.

5. To enable scheduling on logical interfaces, include the **per-unit-scheduler** statement at the [edit interfaces *interface-name*] hierarchy level:

```
[edit interfaces interface-name ]
per-unit-scheduler;
```

When you include this statement, the maximum number of VLANs supported is 767 on a single-port Gigabit Ethernet IQ PIC. On a two-port Gigabit Ethernet IQ PIC, the maximum number is 383.

6. To apply the traffic-scheduling profile to the logical interface, include the **output-traffic-control-profile** statement at the [edit class-of-service interfaces *interface-name* unit *logical-unit-number*] hierarchy level:

```
[edit class-of-service interfaces interface-name unit logical-unit-number]
output-traffic-control-profile profile-name;
```

You cannot include the **output-traffic-control-profile** statement in the configuration if any of the following statements are included in the logical interface configuration: **scheduler-map**, **shaping-rate**, **adaptive-shaper**, or **virtual-channel-group**.

For a table that shows how the bandwidth and delay buffer are allocated in various configurations, see the *JUNOS Class of Service Configuration Guide*.

Example: Oversubscribing an LSQ Interface

Apply a traffic-control profile to a logical interface representing a DLCI on an FRF.16 bundle.

```

interfaces {
  lsq-1/3/0:0 {
    per-unit-scheduler;
    unit 0 {
      dlc1 100;
    }
    unit 1 {
      dlc1 200;
    }
  }
}
class-of-service {
  traffic-control-profiles {
    tc_0 {
      shaping-rate percent 100;
      guaranteed-rate percent 60;
      delay-buffer-rate percent 80;
    }
    tc_1 {
      shaping-rate percent 80;
      guaranteed-rate percent 40;
    }
  }
  interfaces {
    lsq-1/3/0 {
      unit 0 {
        output-traffic-control-profile tc_0;
      }
      unit 1 {
        output-traffic-control-profile tc_1;
      }
    }
  }
}

```

Configuring Guaranteed Minimum Rate on LSQ Interfaces

On Gigabit Ethernet IQ PICs, Channelized IQ PICs, and FRF.16 link services IQ (LSQ) interfaces on AS and MultiServices PICs, you can configure guaranteed bandwidth, also known as a committed information rate (CIR). This allows you to specify a guaranteed rate for each logical interface. The guaranteed rate is a minimum. If excess physical interface bandwidth is available for use, the logical interface receives more than the guaranteed rate provisioned for the interface.

You cannot provision the sum of the guaranteed rates to be more than the physical interface bandwidth, or the bundle bandwidth for LSQ interfaces. If the sum of the guaranteed rates exceeds the interface or bundle bandwidth, the commit operation does not fail, but the software automatically decreases the rates so that the sum of the guaranteed rates is equal to the available bundle bandwidth.

To configure a guaranteed minimum rate, perform the following steps:

1. Include the **guaranteed-rate** statement at the **[edit class-of-service traffic-control-profiles *profile-name*]** hierarchy level:

```
[edit class-of-service traffic-control-profiles profile-name]  
guaranteed-rate (percent percentage | rate);
```

On LSQ interfaces, you can configure the guaranteed rate as a percentage.

On IQ and IQ2 interfaces, you can configure the guaranteed rate as an absolute rate from 1000 through 160,000,000,000 bits per second.



NOTE: For channelized and Gigabit Ethernet IQ interfaces, the **shaping-rate** and **guaranteed-rate** statements are mutually exclusive. You cannot configure some logical interfaces to use a shaping rate and others to use a guaranteed rate. This means there are no service guarantees when you configure a PIR. For these interfaces, you can configure either a PIR or a committed information rate (CIR), but not both.

This restriction does not apply to Gigabit Ethernet IQ2 PICs or link services IQ (LSQ) interfaces on AS or MultiServices PICs. For LSQ and Gigabit Ethernet IQ2 interfaces, you can configure both a PIR and a CIR on an interface. For more information about CIRs, see the *JUNOS Class of Service Configuration Guide*.

2. Optionally, you can base the delay buffer calculation on a delay-buffer rate. To do this, include the **delay-buffer-rate** statement at the **[edit class-of-service traffic-control-profiles *profile-name*]** hierarchy level:

```
[edit class-of-service traffic-control-profiles profile-name]  
delay-buffer-rate (percent percentage | rate);
```

On LSQ interfaces, you can configure the delay-buffer rate as a percentage.

On IQ and IQ2 interfaces, you can configure the delay-buffer rate as an absolute rate from 1000 through 160,000,000,000 bits per second.

The actual delay buffer is based on the calculations described in tables in the *JUNOS Class of Service Configuration Guide*. For an example showing how the delay-buffer rates are applied, see “Example: Configuring Guaranteed Minimum Rate” on page 346.

If you do not include the **delay-buffer-rate** statement, the delay-buffer calculation is based on the guaranteed rate, the shaping rate if no guaranteed rate is configured, or the scaled shaping rate if the interface is oversubscribed.

If you do not specify a shaping rate or a guaranteed rate, the logical interface receives a minimal delay-buffer rate and minimal bandwidth equal to 4 MTU-sized packets.

You can configure a rate for the delay buffer that is higher than the guaranteed rate. This can be useful when the traffic flow might not require much bandwidth in general, but in some cases can be bursty and therefore needs a large buffer.

Configuring large buffers on relatively low-speed links can cause packet aging. To help prevent this problem, the software requires that the sum of the delay-buffer rates be less than or equal to the port speed. This restriction does not eliminate the possibility of packet aging, so you should be cautious when using the `delay-buffer-rate` statement. Though some amount of extra buffering might be desirable for burst absorption, delay-buffer rates should not far exceed the service rate of the logical interface.

If you configure delay-buffer rates so that the sum exceeds the port speed, the configured delay-buffer rate is not implemented for the last logical interface that you configure. Instead, that logical interface receives a delay-buffer rate of 0, and a warning message is displayed in the CLI. If bandwidth becomes available (because another logical interface is deleted or deactivated, or the port speed is increased), the configured delay-buffer-rate is reevaluated and implemented if possible.

If the guaranteed rate of a logical interface cannot be implemented, that logical interface receives a delay-buffer rate of 0, even if the configured delay-buffer rate is within the interface speed. If at a later time the guaranteed rate of the logical interface can be met, the configured delay-buffer rate is reevaluated and if the delay-buffer rate is within the remaining bandwidth, it is implemented.

If any logical interface has a configured guaranteed rate, all other logical interfaces on that port that do not have a guaranteed rate configured receive a delay-buffer rate of 0. This is because the absence of a guaranteed rate configuration corresponds to a guaranteed rate of 0 and, consequently, a delay-buffer rate of 0.

3. To assign a scheduler map to the logical interface, include the `scheduler-map` statement at the `[edit class-of-service traffic-control-profiles profile-name]` hierarchy level:

```
[edit class-of-service traffic-control-profiles profile-name]
  scheduler-map map-name;
```

For information about configuring schedulers and scheduler maps, see the *JUNOS Class of Service Configuration Guide*.

4. To enable large buffer sizes to be configured, include the `q-pic-large-buffer` statement at the `[edit chassis fpc slot-number pic pic-number]` hierarchy level:

```
[edit chassis fpc slot-number pic pic-number]
  q-pic-large-buffer;
```

If you do not include this statement, the delay-buffer size is more restricted. For more information, see the *JUNOS Class of Service Configuration Guide*.

- To enable scheduling on logical interfaces, include the `per-unit-scheduler` statement at the `[edit interfaces interface-name]` hierarchy level:

```
[edit interfaces interface-name ]
per-unit-scheduler;
```

When you include this statement, the maximum number of VLANs supported is 767 on a single-port Gigabit Ethernet IQ PIC. On a two-port Gigabit Ethernet IQ PIC, the maximum number is 383.

- To apply the traffic-scheduling profile to the logical interface, include the `output-traffic-control-profile` statement at the `[edit class-of-service interfaces interface-name unit logical-unit-number]` hierarchy level:

```
[edit class-of-service interfaces interface-name unit logical-unit-number]
output-traffic-control-profile profile-name;
```

Example: Configuring Guaranteed Minimum Rate

Two logical interface units, 0 and 1, are provisioned with a guaranteed minimum of 750 Kbps and 500 Kbps, respectively. For logical unit 1, the delay buffer is based on the guaranteed rate setting. For logical unit 0, a delay-buffer rate of 500 Kbps is specified. The actual delay buffers allocated to each logical interface are 2 seconds of 500 Kbps. The 2-second value is based on the following calculation:

$\text{delay-buffer-rate} < [8 \times 64 \text{ Kbps}]: 2 \text{ seconds of delay-buffer-rate}$

For more information about this calculation, see the *JUNOS Class of Service Configuration Guide*.

```
chassis {
  fpc 3 {
    pic 0 {
      q-pic-large-buffer;
    }
  }
}
interfaces {
  t1-3/0/1 {
    per-unit-scheduler;
  }
}
class-of-service {
  traffic-control-profiles {
    tc-profile3 {
      guaranteed-rate 750k;
      scheduler-map sched-map3;
      delay-buffer-rate 500k; # 500 Kbps is less than 8 x 64 Kbps
    }
    tc-profile4 {
      guaranteed-rate 500k; # 500 Kbps is less than 8 x 64 Kbps
      scheduler-map sched-map4;
    }
  }
}
```

```

interface t1-3/0/1 {
    unit 0 {
        output-traffic-control-profile tc-profile3;
    }
    unit 1 {
        output-traffic-control-profile tc-profile4;
    }
}

```

Configuring Link Services and CoS on Services PICs

To configure link services and CoS on an AS or MultiServices PIC, you must perform the following steps:

1. Enable the Layer 2 service package. You enable service packages per PIC, not per port. When you enable the Layer 2 service package, the entire PIC uses the configured package. To enable the Layer 2 service package, include the `service-package` statement at the `[edit chassis fpc slot-number pic pic-number adaptive-services]` hierarchy level, and specify `layer-2`:

```

[edit chassis fpc slot-number pic pic-number adaptive-services]
service-package layer-2;

```

For more information about AS or MultiServices PIC service packages, see “Enabling Service Packages” on page 35 and “Layer 2 Service Package Capabilities and Interfaces” on page 320.

2. Configure a multilink PPP or FRF.16 bundle by combining constituent links into a virtual link, or bundle.

Configuring an MLPPP Bundle

To configure an MLPPP bundle, configure constituent links and bundle properties by including the following statements in the configuration:

```

[edit interfaces interface-name unit logical-unit-number]
encapsulation ppp;
family mlppp {
    bundle lsq-fpc/pic/port.logical-unit-number;
}
[edit interfaces lsq-fpc/pic/port unit logical-unit-number]
drop-timeout milliseconds;
encapsulation multilink-ppp;
fragment-threshold bytes;
link-layer-overhead percent;
minimum-links number;
mrru bytes;
short-sequence;
family inet {
    address address;
}

```

For more information about these statements, see the “Link and Multilink Services Configuration Guidelines” on page 975.

Configuring an MLFR FRF.16 Bundle

To configure an MLFR FRF.16 bundle, configure constituent links and bundle properties by including the following statements in the configuration:

```
[edit chassis fpc slot-number pic slot-number]
mlfr-uni-nni-bundles number;
[edit interfaces interface-name ]
encapsulation multilink-frame-relay-uni-nni;
unit logical-unit-number {
  family mlfr-uni-nni {
    bundle lsq-fpc/pic/port:channel;
  }
}
```

For more information about the `mlfr-uni-nni-bundles` statement, see the *JUNOS System Basics Configuration Guide*. MLFR FRF.16 uses channels as logical units.

For MLFR FRF.16, you must configure one end as data circuit-terminating equipment (DCE) by including the following statements at the `[edit interfaces lsq-fpc/pic/port:channel]` hierarchy level.

```
encapsulation multilink-frame-relay-uni-nni;
dce;
mlfr-uni-nni-options {
  acknowledge-retries number;
  acknowledge-timer milliseconds;
  action-red-differential-delay (disable-tx | remove-link);
  drop-timeout milliseconds;
  fragment-threshold bytes;
  hello-timer milliseconds;
  link-layer-overhead percent;
  lmi-type (ansi | itu);
  minimum-links number;
  mrru bytes;
  n391 number;
  n392 number;
  n393 number;
  red-differential-delay milliseconds;
  t391 number;
  t392 number;
  yellow-differential-delay milliseconds;
}
unit logical-unit-number {
  dlci dlci-identifier;
  family inet {
    address address;
  }
}
```

For more information about MLFR UNI NNI properties, see “Link and Multilink Services Configuration Guidelines” on page 975.

3. To configure CoS components for each multilink bundle, enable per-unit scheduling on the interface, configure a scheduler map, apply the scheduler to each queue, configure a fragmentation map, and apply the fragmentation map to each bundle. Include the following statements:

```

[edit interfaces]
lsq-fpc/pic/port {
    per-unit-scheduler; # Enables per-unit scheduling on the bundle
}
[edit class-of-service]
interfaces {
    lsq-fpc/pic/port { # Multilink PPP
        unit logical-unit-number {
            scheduler-map map-name; # Applies scheduler map to each queue
        }
    }
    lsq-fpc/pic/port:channel { # MLFR FRF.16
        unit logical-unit-number {
            # Scheduler map provides scheduling information for
            # the queues within a single DLCI.
            scheduler-map map-name;
            shaping-rate percent percent;
        }
    }
    forwarding-classes {
        queue queue-number class-name priority (high | low);
    }
    scheduler-maps {
        map-name {
            forwarding-class class-name scheduler scheduler-name;
        }
    }
    schedulers {
        scheduler-name {
            buffer-size (percent percentage | remainder | temporal microseconds);
            priority priority-level;
            transmit-rate (percent percentage | rate | remainder) <exact>;
        }
    }
    fragmentation-maps {
        map-name {
            forwarding-class class-name {
                fragment-threshold bytes;
                no-fragmentation;
            }
        }
    }
}

```

Associate a fragmentation map with a multilink PPP interface or MLFR FRF.16 DLCI by including the following statements at the [edit class-of-service] hierarchy level:

```

interfaces {
    lsq-fpc/pic/port {
        unit logical-unit-number { # Multilink PPP
            fragmentation-map map-name;
        }
    }
    lsq-fpc/pic/port:channel { # MLFR FRF.16
        unit logical-unit-number {
            fragmentation-map map-name;
        }
    }
}

```

Configuring Link Services and CoS on J-series Services Routers

Unlike M-series and T-series platforms, J-series Services Routers support per-bundle queuing on link services (ls-) interfaces. Link services interfaces for J-series Services Routers function like link services IQ (lsq-) interfaces on other routing platforms, with the following exceptions, as follows:

- Queue 2 is reserved for voice traffic (LFI) on J-series Services Routers, while all other queues perform fragmentation.
- On J-series Services Routers link services (ls-) interfaces, you can configure compressed Real-Time Transport Protocol (CRTP) without needing to configure MLPPP. For more information, see “Voice Services Configuration Guidelines” on page 393.
- Traffic from the ls- interface on queue 0, queue 1, and queues 4 through 7 is mapped onto queue 0 of the constituent link.
- The queue 0 buffer size percentage on the constituent links should be configured as a sum of the buffer size percentages for the ls- interface queues (queue 0, queue 1, and queues 4 through 7).

For FRF.16 and MLPPP, link services interfaces on the J-series Services Router work the same way as link services IQ interfaces (lsq) on M-series and T-series platforms.

The following is a sample configuration for a link services interface on a J-series Services Router:

```

interfaces {
  ls-0/0/0 {
    per-unit-scheduler;
    unit 0 {
      encapsulation multilink-ppp;
      fragment-threshold 128;
      interleave-fragments;
      family inet {
        address 10.0.0.10/24;
      }
    }
  }
  fe-0/0/1 {
    unit 0 {
      family inet {
        address 192.1.1.1/24;
      }
    }
  }
  se-1/0/0 {
    per-unit-scheduler;
    serial-options {
      clocking-mode dce;
      clocking-rate 2.0mhz;
    }
    unit 0 {

```

```

        family mlppp {
            bundle ls-0/0/0.0;
        }
    }
}
se-1/0/1 {
    per-unit-scheduler;
    serial-options {
        clocking-mode dce;
        clocking-rate 2.0mhz;
    }
    unit 0 {
        family mlppp {
            bundle ls-0/0/0.0;
        }
    }
}
}

```

For more information about M-series and T-series link services (ls-) interfaces, see “Link and Multilink Services Configuration Guidelines” on page 975. For more information about J-series Services Router configuration and examples, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using MLPPP

To configure an NxT1 bundle using MLPPP, you aggregate *N* different T1 links into a bundle. The NxT1 bundle is called a logical interface, because it can represent, for example, a routing adjacency. To aggregate T1 links into a an MLPPP bundle, include the `bundle` statement at the [edit interfaces *t1-fpc/pic/port* unit *logical-unit-number* family mlppp] hierarchy level:

```
[edit interfaces t1-fpc/pic/port unit logical-unit-number family mlppp]
bundle lsq-fpc/pic/port.logical-unit-number;
```



NOTE: Link services IQ interfaces support both T1 and E1 physical interfaces. These instructions apply to T1 interfaces, but the configuration for E1 interfaces is similar.

To configure the link services IQ interface properties, include the following statements at the [edit interfaces *lsq-fpc/pic/port* unit *logical-unit-number*] hierarchy level:

```
[edit interfaces lsq-fpc/pic/port unit logical-unit-number]
drop-timeout milliseconds;
encapsulation multilink-ppp;
fragment-threshold bytes;
link-layer-overhead percent;
minimum-links number;
mrru bytes;
short-sequence;
family inet {
    address address;
}

```

The logical link services IQ interface represents the MLPPP bundle. For the MLPPP bundle, there are four associated queues on M-series platforms and eight associated queues on M320 and T-series platforms. A scheduler removes packets from the queues according to a scheduling policy. Typically, you designate one queue to have strict priority, and the remaining queues are serviced in proportion to weights you configure.

For MLPPP, assign a single scheduler map to the link services IQ interface (**lsq**) and to each constituent link. The default schedulers for M-series and T-series platforms, which assign 95, 0, 0, and 5 percent bandwidth for the transmission rate and buffer size of queues 0, 1, 2, and 3, are not adequate when you configure LFI or multiclass traffic. Therefore, for MLPPP, you should configure a single scheduler with nonzero percent transmission rates and buffer sizes for queues 0 through 3, and assign this scheduler to the link services IQ interface (**lsq**) and to each constituent link, as shown in “Example: Configuring an LSQ Interface as an NxT1 Bundle Using MLPPP” on page 354.



NOTE: For M320 and T-series platforms, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 5, 0, 0, 0, and 0 percent.

If the bundle has more than one link, you must include the **per-unit-scheduler** statement at the [edit interfaces **lsq-fpc/pic/port**] hierarchy level:

```
[edit interfaces lsq-fpc/pic/port]
per-unit-scheduler;
```

To configure and apply the scheduling policy, include the following statements at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
interfaces {
  t1-fpc/pic/port unit logical-unit-number {
    scheduler-map map-name;
  }
}
forwarding-classes {
  queue queue-number class-name;
}
scheduler-maps {
  map-name {
    forwarding-class class-name scheduler scheduler-name;
  }
}
schedulers {
  scheduler-name {
    buffer-size (percent percentage | remainder | temporal microseconds);
    priority priority-level;
    transmit-rate (rate | percent percentage | remainder) <exact>;
  }
}
```

For link services IQ interfaces, a strict-high-priority queue might starve the other three queues because traffic in a strict-high priority queue is transmitted before any

other queue is serviced. This implementation is unlike the standard JUNOS CoS implementation in which a strict-high-priority queue does round-robin with high-priority queues, as described in the *JUNOS Class of Service Configuration Guide*.

After the scheduler removes a packet from a queue, a certain action is taken. The action depends on whether the packet came from a multilink encapsulated queue (fragmented and sequenced) or a nonencapsulated queue (hashed with no fragmentation). Each queue can be designated as either multilink encapsulated or nonencapsulated, independently of the other. By default, traffic in all forwarding classes is multilink encapsulated. To configure packet fragmentation handling on a queue, include the **fragmentation-maps** statement at the [edit class-of-service] hierarchy level:

```
fragmentation-maps {
  map-name {
    forwarding-class class-name {
      fragment-threshold bytes;
      multilink-class number;
      no-fragmentation;
    }
  }
}
```

For NxT1 bundles using MLPPP, the byte-wise load balancing used in multilink-encapsulated queues is superior to the flow-wise load balancing used in nonencapsulated queues. All other considerations are equal. Therefore, we recommend that you configure all queues to be multilink encapsulated. You do this by including the **fragment-threshold** statement in the configuration. If you choose to set traffic on a queue to be nonencapsulated rather than multilink encapsulated, include the **no-fragmentation** statement in the fragmentation map. You use the **multilink-class** statement to map a forwarding class into a multiclass MLPPP (MCML). For more information about MCML, see “Configuring Multiclass MLPPP on LSQ Interfaces” on page 338. For more information about fragmentation maps, see “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

When a packet is removed from a multilink-encapsulated queue, the software gives the packet an MLPPP header. The MLPPP header contains a sequence number field, which is filled with the next available sequence number from a counter. The software then places the packet on one of the *N* different T1 links. The link is chosen on a packet-by-packet basis to balance the load across the various T1 links.

If the packet exceeds the minimum link MTU, or if a queue has a fragment threshold configured at the [edit class-of-service fragmentation-maps *map-name* forwarding-class *class-name*] hierarchy level, the software splits the packet into two or more fragments, which are assigned consecutive multilink sequence numbers. The outgoing link for each fragment is selected independently of all other fragments.

If you do not include the **fragment-threshold** statement in the fragmentation map, the fragmentation threshold you set at the [edit interfaces *interface-name* unit *logical-unit-number*] hierarchy level is the default for all forwarding classes. If you do not set a maximum fragment size anywhere in the configuration, packets are fragmented if they exceed the smallest MTU of all the links in the bundle.

Even if you do not set a maximum fragment size anywhere in the configuration, you can configure the maximum received reconstructed unit (MRRU) by including the `mrru` statement at the `[edit interfaces lsq-fpc/pic/port unit logical-unit-number]` hierarchy level. The MRRU is similar to the MTU, but is specific to link services interfaces. By default the MRRU size is 1500 bytes, and you can configure it to be from 1500 through 4500 bytes. For more information, see “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.

When a packet is removed from a nonencapsulated queue, it is transmitted with a plain PPP header. Because there is no MLPPP header, there is no sequence number information. Therefore, the software must take special measures to avoid packet reordering. To avoid packet reordering, the software places the packet on one of the N different T1 links. The link is determined by hashing the values in the header. For IP, the software computes the hash based on source address, destination address, and IP protocol. For MPLS, the software computes the hash based on up to five MPLS labels, or four MPLS labels and the IP header.

For UDP and TCP the software computes the hash based on the source and destination ports, as well as source and destination IP addresses. This guarantees that all packets belonging to the same TCP/UDP flow always pass through the same T1 link, and therefore cannot be reordered. However, it does not guarantee that the load on the various T1 links is balanced. If there are many flows, the load is usually balanced.

The N different T1 interfaces link to another router, which can be from Juniper Networks or another vendor. The router at the far end gathers packets from all the T1 links. If a packet has an MLPPP header, the sequence number field is used to put the packet back into sequence number order. If the packet has a plain PPP header, the software accepts the packet in the order in which it arrives and makes no attempt to reassemble or reorder the packet.

Example: Configuring an LSQ Interface as an NxT1 Bundle Using MLPPP

```
[edit chassis]
fpc 1 {
  pic 3 {
    adaptive-services {
      service-package layer-2;
    }
  }
}
[edit interfaces]
t1-0/0/0 {
  encapsulation ppp;
  unit 0 {
    family mlppp {
      bundle lsq-1/3/0.1; # This adds t1-0/0/0 to the specified bundle.
    }
  }
}
t1-0/0/1 {
  encapsulation ppp;
  unit 0 {
    family mlppp {
      bundle lsq-1/3/0.1;
```

```

    }
  }
}
lsq-1/3/0 {
  unit 1 { # This is the virtual link that concatenates multiple T1s.
    encapsulation multilink-ppp;
    drop-timeout 1000;
    fragment-threshold 128;
    link-layer-overhead 0.5;
    minimum-links 2;
    mrru 4500;
    short-sequence;
    family inet {
      address 10.2.3.4/24;
    }
  }
}
[edit interfaces]
lsq-1/3/0 {
  per-unit-scheduler;
}
[edit class-of-service]
interfaces {
  lsq-1/3/0 { # multilink PPP constituent link
    unit 0 {
      scheduler-map sched-map1;
    }
  }
  t1-0/0/0 { # multilink PPP constituent link
    unit 0 {
      scheduler-map sched-map1;
    }
  }
  t1-0/0/1 { # multilink PPP constituent link
    unit 0 {
      scheduler-map sched-map1;
    }
  }
  forwarding-classes {
    queue 0 be;
    queue 1 ef;
    queue 2 af;
    queue 3 nc;
  }
  scheduler-maps {
    sched-map1 {
      forwarding-class af scheduler af-scheduler;
      forwarding-class be scheduler be-scheduler;
      forwarding-class ef scheduler ef-scheduler;
      forwarding-class nc scheduler nc-scheduler;
    }
  }
  schedulers {
    af-scheduler {
      transmit-rate percent 30;
      buffer-size percent 30;
      priority low;
    }
    be-scheduler {

```

```

        transmit-rate percent 25;
        buffer-size percent 25;
        priority low;
    }
    ef-scheduler {
        transmit-rate percent 40;
        buffer-size percent 40;
        priority strict-high; # voice queue
    }
    nc-scheduler {
        transmit-rate percent 5;
        buffer-size percent 5;
        priority high;
    }
}
fragmentation-maps {
    fragmap-1 {
        forwarding-class be {
            fragment-threshold 180;
        }
        forwarding-class ef {
            fragment-threshold 100;
        }
    }
}
[edit interfaces]
lsq-1/3/0 {
    unit 0 {
        fragmentation-map fragmap-1;
    }
}

```

Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using FRF.16

To configure an NxT1 bundle using FRF.16, you aggregate *N* different T1 links into a bundle. The NxT1 bundle carries a potentially large number of Frame Relay PVCs, identified by their DLCIs. Each DLCI is called a logical interface, because it can represent, for example, a routing adjacency.

To aggregate T1 links into an FRF.16 bundle, include the `mlfr-uni-nni-bundles` statement at the `[edit chassis fpc slot-number pic slot-number]` hierarchy level and include the `bundle` statement at the `[edit interfaces t1-fpc/pic/port unit logical-unit-number family mlfr-uni-nni]` hierarchy level:

```

[edit chassis fpc slot-number pic slot-number]
mlfr-uni-nni-bundles number;

```

```

[edit interfaces t1-fpc/pic/port unit logical-unit-number family mlfr-uni-nni]
bundle lsq-fpc/pic/port:channel;

```



NOTE: Link services IQ interfaces support both T1 and E1 physical interfaces. These instructions apply to T1 interfaces, but the configuration for E1 interfaces is similar.

To configure the link services IQ interface properties, include the following statements at the [edit interfaces lsq-*fpc/pic/port:channel*] hierarchy level:

```
[edit interfaces lsq-fpc/pic/port:channel]
encapsulation multilink-frame-relay-uni-nni;
dce;
mlfr-uni-nni-options {
  acknowledge-retries number;
  acknowledge-timer milliseconds;
  action-red-differential-delay (disable-tx | remove-link);
  drop-timeout milliseconds;
  fragment-threshold bytes;
  hello-timer milliseconds;
  link-layer-overhead percent;
  lmi-type (ansi | itu);
  minimum-links number;
  mrru bytes;
  n391 number;
  n392 number;
  n393 number;
  red-differential-delay milliseconds;
  t391 number;
  t392 number;
  yellow-differential-delay milliseconds;
}
unit logical-unit-number {
  dlcid dlci-identifier;
  family inet {
    address address;
  }
}
```

The link services IQ channel represents the FRF.16 bundle. Four queues are associated with each DLCI. A scheduler removes packets from the queues according to a scheduling policy. On the link services IQ interface, you typically designate one queue to have strict priority. The remaining queues are serviced in proportion to weights you configure.

For link services IQ interfaces, a strict-high-priority queue might starve the other three queues because traffic in a strict-high-priority queue is transmitted before any other queue is serviced. This implementation is unlike the standard JUNOS CoS implementation in which a strict-high-priority queue does round-robin with high-priority queues, as described in the *JUNOS Class of Service Configuration Guide*.

If the bundle has more than one link, you must include the **per-unit-scheduler** statement at the [edit interfaces lsq-*fpc/pic/port:channel*] hierarchy level:

```
[edit interfaces lsq-fpc/pic/port:channel]
per-unit-scheduler;
```

For FRF.16, you can assign a single scheduler map to the link services IQ interface (lsq) and to each link services IQ DLCI, or you can assign different scheduler maps to the various DLCIs of the bundle, as shown in “Configuring LSQ Interfaces as NxT1 or NxT1 Bundles Using FRF.16” on page 356.

For the constituent links of an FRF.16 bundle, you do not need to configure a custom scheduler. Because LFI and multiclass are not supported for FRF.16, the traffic from each constituent link is transmitted from queue 0. This means you should allow most of the bandwidth to be used by queue 0. For M-series and T-series platforms, the default schedulers' transmission rate and buffer size percentages for queues 0 through 3 are 95, 0, 0, and 5 percent. These default schedulers send all user traffic to queue 0 and all network-control traffic to queue 3, and therefore are well suited to the behavior of FRF.16. If desired, you can configure a custom scheduler that explicitly replicates the 95, 0, 0, and 5 percent queuing behavior, and apply it to the constituent links.



NOTE: For M320 and T-series platforms, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 5, 0, 0, 0, and 0 percent.

To configure and apply the scheduling policy, include the following statements at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
interfaces {
  lsq-fpc/pic/port:channel {
    unit logical-unit-number {
      scheduler-map map-name;
    }
  }
}
forwarding-classes {
  queue queue-number class-name;
}
scheduler-maps {
  map-name {
    forwarding-class class-name scheduler scheduler-name;
  }
}
schedulers {
  scheduler-name {
    buffer-size (percent percentage | remainder | temporal microseconds);
    priority priority-level;
    transmit-rate (rate | percent percentage | remainder) <exact>;
  }
}
```

To configure packet fragmentation handling on a queue, include the `fragmentation-maps` statement at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
fragmentation-maps {
  map-name {
    forwarding-class class-name {
      fragment-threshold bytes;
    }
  }
}
```

For FRF.16 traffic, only multilink encapsulated (fragmented and sequenced) queues are supported. This is the default queuing behavior for all forwarding classes. FRF.16 does not allow for nonencapsulated traffic because the protocol requires that all packets carry the fragmentation header. If a large packet is split into multiple fragments, the fragments must have consecutive sequential numbers. Therefore, you cannot include the `no-fragmentation` statement at the [edit class-of-service fragmentation-maps *map-name* forwarding-class *class-name*] hierarchy level for FRF.16 traffic. For FRF.16, if you want to carry voice or any other latency-sensitive traffic, you should not use slow links. At T1 speeds and above, the serialization delay is small enough so that you do not need to use explicit LFI.

When a packet is removed from a multilink-encapsulated queue, the software gives the packet an FRF.16 header. The FRF.16 header contains a sequence number field, which is filled with the next available sequence number from a counter. The software then places the packet on one of the *N* different T1 links. The link is chosen on a packet-by-packet basis to balance the load across the various T1 links.

If the packet exceeds the minimum link MTU, or if a queue has a fragment threshold configured at the [edit class-of-service fragmentation-maps *map-name* forwarding-class *class-name*] hierarchy level, the software splits the packet into two or more fragments, which are assigned consecutive multilink sequence numbers. The outgoing link for each fragment is selected independently of all other fragments.

If you do not include the `fragment-threshold` statement in the fragmentation map, the fragmentation threshold you set at the [edit interfaces *interface-name* unit *logical-unit-number*] or [edit interfaces *interface-name* mlfr-uni-nni-bundle-options] hierarchy level is the default for all forwarding classes. If you do not set a maximum fragment size anywhere in the configuration, packets are fragmented if they exceed the smallest MTU of all the links in the bundle.

Even if you do not set a maximum fragment size anywhere in the configuration, you can configure the maximum received reconstructed unit (MRRU) by including the `mrru` statement at the [edit interfaces *lsq-fpc/pic/port* unit *logical-unit-number*] or [edit interfaces *interface-name* mlfr-uni-nni-bundle-options] hierarchy level. The MRRU is similar to the MTU but is specific to link services interfaces. By default, the MRRU size is 1500 bytes, and you can configure it to be from 1500 through 4500 bytes. For more information, see “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.

The *N* different T1 interfaces link to another router, which can be from Juniper Networks or another vendor. The router at the far end gathers packets from all the T1 links. Because each packet has an FRF.16 header, the sequence number field is used to put the packet back into sequence number order.

Example: Configuring an LSQ Interface as an NxT1 Bundle Using FRF.16

Configure an NxT1 bundle using FRF.16 with multiple CoS scheduler maps:

```
[edit chassis fpc 1 pic 3]
adaptive-services {
  service-package layer-2;
}
mlfr-uni-nni-bundles 2; # Creates channelized LSQ interfaces/FRF.16 bundles.
```

```

[edit interfaces]
t1-0/0/0 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle lsq-1/3/0:1;
    }
  }
}
t1-0/0/1 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle lsq-1/3/0:1;
    }
  }
}
lsq-1/3/0:1 { # Bundle link consisting of t1-0/0/0 and t1-0/0/1
  per-unit-scheduler;
  encapsulation multilink-frame-relay-uni-nni;
  dce; # One end needs to be configured as DCE.
  mlfr-uni-nni-bundle-options {
    drop-timeout 180;
    fragment-threshold 64;
    hello-timer 180;
    minimum-links 2;
    mrru 3000;
    link-layer-overhead 0.5;
  }
  unit 0 {
    dlci 26; # Each logical unit maps a single DLCI.
    family inet {
      address 10.2.3.4/24;
    }
  }
  unit 1 {
    dlci 42;
    family inet {
      address 10.20.30.40/24;
    }
  }
  unit 2 {
    dlci 69;
    family inet {
      address 10.20.30.40/24;
    }
  }
}
[edit class-of-service]
scheduler-maps {
  sched-map-lsq0 {
    forwarding-class af scheduler af-scheduler-lsq0;
    forwarding-class be scheduler be-scheduler-lsq0;
    forwarding-class ef scheduler ef-scheduler-lsq0;
    forwarding-class nc scheduler nc-scheduler-lsq0;
  }
  sched-map-lsq1 {

```



```

        forwarding-class af scheduler af-scheduler-lsq1;
        forwarding-class be scheduler be-scheduler-lsq1;
        forwarding-class ef scheduler ef-scheduler-lsq1;
        forwarding-class nc scheduler nc-scheduler-lsq1;
    }
}
schedulers {
    af-scheduler-lsq0 {
        transmit-rate percent 60;
        buffer-size percent 60;
        priority low;
    }
    be-scheduler-lsq0 {
        transmit-rate percent 30;
        buffer-size percent 30;
        priority low;
    }
    ef-scheduler-lsq0 {
        transmit-rate percent 5;
        buffer-size percent 5;
        priority strict-high;
    }
    nc-scheduler-lsq0 {
        transmit-rate percent 5;
        buffer-size percent 5;
        priority high;
    }
    af-scheduler-lsq1 {
        transmit-rate percent 50;
        buffer-size percent 50;
        priority low;
    }
    be-scheduler-lsq1 {
        transmit-rate percent 30;
        buffer-size percent 30;
        priority low;
    }
    ef-scheduler-lsq1 {
        transmit-rate percent 15;
        buffer-size percent 15;
        priority strict-high;
    }
    nc-scheduler-lsq1 {
        transmit-rate percent 5;
        buffer-size percent 5;
        priority high;
    }
}
interfaces {
    lsq-1/3/0:1 { # MLFR FRF.16
        unit 0 {
            scheduler-map sched-map-lsq0;
        }
        unit 1 {
            scheduler-map sched-map-lsq1;
        }
    }
}

```

```
}
```

Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using MLPPP and LFI

When you configure a single fractional T1 interface, it is called a logical interface, because it can represent, for example, a routing adjacency.

The logical link services IQ interface represents the MLPPP bundle. Four queues are associated with the logical interface. A scheduler removes packets from the queues according to a scheduling policy. Typically, you designate one queue to have strict priority, and the remaining queues are serviced in proportion to weights you configure.

To configure a single fractional T1 interface using MLPPP and LFI, you associate one DS0 (fractional T1) interface with a link services IQ interface. To associate a fractional T1 interface with a link services IQ interface, include the **bundle** statement at the [edit interfaces *ds-fpc/pic/port:channel* unit *logical-unit-number* family *mlppp*] hierarchy level:

```
[edit interfaces ds-fpc/pic/port:channel unit logical-unit-number family mlppp]
bundle lsq-fpc/pic/port.logical-unit-number;
```



NOTE: Link services IQ interfaces support both T1 and E1 physical interfaces. These instructions apply to T1 interfaces, but the configuration for E1 interfaces is similar.

To configure the link services IQ interface properties, include the following statements at the [edit interfaces *lsq-fpc/pic/port* unit *logical-unit-number*] hierarchy level:

```
[edit interfaces lsq-fpc/pic/port unit logical-unit-number]
drop-timeout milliseconds;
encapsulation multilink-ppp;
fragment-threshold bytes;
link-layer-overhead percent;
minimum-links number;
mrru bytes;
short-sequence;
family inet {
    address address;
}
```

For MLPPP, assign a single scheduler map to the link services IQ (*lsq*) interface and to each constituent link. The default schedulers for M-series and T-series platforms, which assign 95, 0, 0, and 5 percent bandwidth for the transmission rate and buffer size of queues 0, 1, 2, and 3, are not adequate when you configure LFI or multiclass traffic. Therefore, for MLPPP, you should configure a single scheduler with nonzero percent transmission rates and buffer sizes for queues 0 through 3, and assign this scheduler to the link services IQ (*lsq*) interface and to each constituent link and to each constituent link, as shown in “Example: Configuring an LSQ Interface for a Fractional T1 Interface Using MLPPP and LFI” on page 364.



NOTE: For M320 and T-series platforms, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 5, 0, 0, 0, and 0 percent.

To configure and apply the scheduling policy, include the following statements at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
interfaces {
  ds-fpc/pic/port.channel {
    scheduler-map map-name;
  }
}
forwarding-classes {
  queue queue-number class-name;
}
scheduler-maps {
  map-name {
    forwarding-class class-name scheduler scheduler-name;
  }
}
schedulers {
  scheduler-name {
    buffer-size (percent percentage | remainder | temporal microseconds);
    priority priority-level;
    transmit-rate (rate | percent percentage | remainder) <exact>;
  }
}
```

For link services IQ interfaces, a strict-high-priority queue might starve all the other queues because traffic in a strict-high priority queue is transmitted before any other queue is serviced. This implementation is unlike the standard JUNOS CoS implementation in which a strict-high-priority queue receives infinite credits and does round-robin with high-priority queues, as described in the *JUNOS Class of Service Configuration Guide*.

After the scheduler removes a packet from a queue, a certain action is taken. The action depends on whether the packet came from a multilink encapsulated queue (fragmented and sequenced) or a nonencapsulated queue (hashed with no fragmentation). Each queue can be designated as either multilink encapsulated or nonencapsulated, independently of the other. By default, traffic in all forwarding classes is multilink encapsulated. To configure packet fragmentation handling on a queue, include the **fragmentation-maps** statement at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
fragmentation-maps {
  map-name {
    forwarding-class class-name {
      fragment-threshold bytes;
      no-fragmentation;
    }
  }
}
```

If you require the queue to transmit small packets with low latency, configure the queue to be nonencapsulated by including the `no-fragmentation` statement. If you require the queue to transmit large packets with normal latency, configure the queue to be multilink encapsulated by including the `fragment-threshold` statement. If you require the queue to transmit large packets with low latency, we recommend using a faster link and configuring the queue to be nonencapsulated. For more information about fragmentation maps, see “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

When a packet is removed from a multilink-encapsulated queue, it is fragmented. If the packet exceeds the minimum link MTU, or if a queue has a fragment threshold configured at the `[edit class-of-service fragmentation-maps map-name forwarding-class class-name]` hierarchy level, the software splits the packet into two or more fragments, which are assigned consecutive multilink sequence numbers.

If you do not include the `fragment-threshold` statement in the fragmentation map, the fragmentation threshold you set at the `[edit interfaces interface-name unit logical-unit-number]` hierarchy level is the default for all forwarding classes. If you do not set a maximum fragment size anywhere in the configuration, packets are fragmented if they exceed the smallest MTU of all the links in the bundle.

Even if you do not set a maximum fragment size anywhere in the configuration, you can configure the maximum received reconstructed unit (MRRU) by including the `mrru` statement at the `[edit interfaces lsq-fpc/pic/port unit logical-unit-number]` hierarchy level. The MRRU is similar to the MTU, but is specific to link services interfaces. By default the MRRU size is 1500 bytes, and you can configure it to be from 1500 through 4500 bytes. For more information, see “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.

When a packet is removed from a multilink-encapsulated queue, the software gives the packet an MLPPP header. The MLPPP header contains a sequence number field, which is filled with the next available sequence number from a counter. The software then places the packet on the fractional T1 link. Traffic from another queue might be interleaved between two fragments of the packet.

When a packet is removed from a nonencapsulated queue, it is transmitted with a plain PPP header. The packet is then placed on the fractional T1 link as soon as possible. If necessary, the packet is placed between the fragments of a packet from another queue.

The fractional T1 interface links to another router, which can be from Juniper Networks or another vendor. The router at the far end gathers packets from the fractional T1 link. If a packet has an MLPPP header, the software assumes the packet is a fragment of a larger packet, and the fragment number field is used to reassemble the larger packet. If the packet has a plain PPP header, the software accepts the packet in the order in which it arrives, and the software makes no attempt to reassemble or reorder the packet.

Example: Configuring an LSQ Interface for a Fractional T1 Interface Using MLPPP and LFI

Configure a single fractional T1 logical interface:

```
[edit interfaces]
```

```

lsq-0/2/0 {
    per-unit-scheduler;
    unit 0 {
        encapsulation multilink-ppp;
        link-layer-overhead 0.5;
        family inet {
            address 10.40.1.1/30;
        }
    }
}
ct3-1/0/0 {
    partition 1 interface-type ct1;
}
ct1-1/0/0:1 {
    partition 1 timeslots 1-2 interface-type ds;
}
ds-1/0/0:1:1 {
    encapsulation ppp;
    unit 0 {
        family mlppp {
            bundle lsq-0/2/0.0;
        }
    }
}
[edit class-of-service]
interfaces {
    ds-1/0/0:1:1 { # multilink PPP constituent link
        unit 0 {
            scheduler-map sched-map1;
        }
    }
}
forwarding-classes {
    queue 0 be;
    queue 1 ef;
    queue 2 af;
    queue 3 nc;
}
scheduler-maps {
    sched-map1 {
        forwarding-class af scheduler af-scheduler;
        forwarding-class be scheduler be-scheduler;
        forwarding-class ef scheduler ef-scheduler;
        forwarding-class nc scheduler nc-scheduler;
    }
}
schedulers {
    af-scheduler {
        transmit-rate percent 20;
        buffer-size percent 20;
        priority low;
    }
    be-scheduler {
        transmit-rate percent 20;
        buffer-size percent 20;
        priority low;
    }
}

```

```

ef-scheduler {
    transmit-rate percent 50;
    buffer-size percent 50;
    priority strict-high; # voice queue
}
nc-scheduler {
    transmit-rate percent 10;
    buffer-size percent 10;
    priority high;
}
}
fragmentation-maps {
    fragmap-1 {
        forwarding-class be {
            fragment-threshold 180;
        }
        forwarding-class ef {
            fragment-threshold 100;
        }
    }
}
[edit interfaces]
lsq-0/2/0 {
    unit 0 {
        fragmentation-map fragmap-1;
    }
}

```

Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using FRF.12

To configure a single fractional T1 interface using FRF.16, you associate a DS0 interface with a link services IQ (lsq) interface. When you configure a single fractional T1, the fractional T1 carries a potentially large number of Frame Relay PVCs identified by their DLCIs. Each DLCI is called a logical interface, because it can represent, for example, a routing adjacency. To associate the DS0 interface with a link services IQ interface, include the `bundle` statement at the `[edit interfaces ds-fpc/pic/port:channel unit logical-unit-number family mlfr-end-to-end]` hierarchy level:

```

[edit interfaces ds-fpc/pic/port:channel unit logical-unit-number family mlfr-end-to-end]
bundle lsq-fpc/pic/port.logical-unit-number;

```



NOTE: Link services IQ interfaces support both T1 and E1 physical interfaces. These instructions apply to T1 interfaces, but the configuration for E1 interfaces is similar.

To configure the link services IQ interface properties, include the following statements at the `[edit interfaces lsq-fpc/pic/port unit logical-unit-number]` hierarchy level:

```

[edit interfaces lsq-fpc/pic/port unit logical-unit-number]
drop-timeout milliseconds;
encapsulation multilink-frame-relay-end-to-end;
fragment-threshold bytes;
link-layer-overhead percent;

```

```

minimum-links number;
mrru bytes;
short-sequence;
family inet {
    address address;
}

```

The logical link services IQ interface represents the FRF.12 bundle. Four queues are associated with each logical interface. A scheduler removes packets from the queues according to a scheduling policy. Typically, you designate one queue to have strict priority, and the remaining queues are serviced in proportion to weights you configure.

For FRF.12, assign a single scheduler map to the link services IQ interface (*lsq*) and to each constituent link. For M-series and T-series platforms, the default schedulers, which assign 95, 0, 0, and 5 percent bandwidth for the transmission rate and buffer size of queues 0, 1, 2, and 3, are not adequate when you configure LFI or multiclass traffic. Therefore, for FRF.12, you should configure schedulers with nonzero percent transmission rates and buffer sizes for queues 0 through 3, and assign them to the link services IQ interface (*lsq*) and to each constituent link, as shown in “Examples: Configuring an LSQ Interface for a Fractional T1 Interface Using FRF.12” on page 369.



NOTE: For M320 and T-series platforms, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 5, 0, 0, 0, and 0 percent.

To configure and apply the scheduling policy, include the following statements at the [edit class-of-service] hierarchy level:

```

[edit class-of-service]
interfaces {
    ds-fpc/pic/port.channel {
        scheduler-map map-name;
    }
}
forwarding-classes {
    queue queue-number class-name;
}
scheduler-maps {
    map-name {
        forwarding-class class-name scheduler scheduler-name;
    }
}
schedulers {
    scheduler-name {
        buffer-size (percent percentage | remainder | temporal microseconds);
        priority priority-level;
        transmit-rate (rate | percent percentage | remainder) <exact>;
    }
}

```

For link services IQ interfaces, a strict-high-priority queue might starve the other three queues because traffic in a strict-high-priority queue is transmitted before any other queue is serviced. This implementation is unlike the standard JUNOS CoS

implementation in which a strict-high-priority queue does round-robin with high-priority queues, as described in the *JUNOS Class of Service Configuration Guide*.

After the scheduler removes a packet from a queue, a certain action is taken. The action depends on whether the packet came from a multilink encapsulated queue (fragmented and sequenced) or a nonencapsulated queue (hashed with no fragmentation). Each queue can be designated as either multilink encapsulated or nonencapsulated, independently of the other. By default, traffic in all forwarding classes is multilink encapsulated. To configure packet fragmentation handling on a queue, include the **fragmentation-maps** statement at the [edit class-of-service] hierarchy level:

```
[edit class-of-service]
fragmentation-maps {
  map-name {
    forwarding-class class-name {
      fragment-threshold bytes;
      no-fragmentation;
    }
  }
}
```

If you require the queue to transmit small packets with low latency, configure the queue to be nonencapsulated by including the **no-fragmentation** statement. If you require the queue to transmit large packets with normal latency, configure the queue to be multilink encapsulated by including the **fragment-threshold** statement. If you require the queue to transmit large packets with low latency, we recommend using a faster link and configuring the queue to be nonencapsulated. For more information about fragmentation maps, see “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

When a packet is removed from a multilink-encapsulated queue, it is fragmented. If the packet exceeds the minimum link MTU, or if a queue has a fragment threshold configured at the [edit class-of-service fragmentation-maps *map-name* forwarding-class *class-name*] hierarchy level, the software splits the packet into two or more fragments, which are assigned consecutive multilink sequence numbers.

If you do not include the **fragment-threshold** statement in the fragmentation map, the fragmentation threshold you set at the [edit interfaces *interface-name* unit *logical-unit-number*] hierarchy level is the default for all forwarding classes. If you do not set a maximum fragment size anywhere in the configuration, packets are fragmented if they exceed the smallest MTU of all the links in the bundle.

Even if you do not set a maximum fragment size anywhere in the configuration, you can configure the maximum received reconstructed unit (MRRU) by including the **mrru** statement at the [edit interfaces *lsq-fpc/pic/port* unit *logical-unit-number*] hierarchy level. The MRRU is similar to the MTU but is specific to link services interfaces. By default, the MRRU size is 1500 bytes, and you can configure it to be from 1500 through 4500 bytes. For more information, see “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.

When a packet is removed from a multilink-encapsulated queue, the software gives the packet an FRF.12 header. The FRF.12 header contains a sequence number field, which is filled with the next available sequence number from a counter. The software

then places the packet on the fractional T1 link. Traffic from another queue might be interleaved between two fragments of the packet.

When a packet is removed from a nonencapsulated queue, it is transmitted with a plain Frame Relay header. The packet is then placed on the fractional T1 link as soon as possible. If necessary, the packet is placed between the fragments of a packet from another queue.

The fractional T1 interface links to another router, which can be from Juniper Networks or another vendor. The router at the far end gathers packets from the fractional T1 link. If a packet has an FRF.12 header, the software assumes the packet is a fragment of a larger packet, and the fragment number field is used to reassemble the larger packet. If the packet has a plain Frame Relay header, the software accepts the packet in the order in which it arrives, and the software makes no attempt to reassemble or reorder the packet.

A whole packet from a nonencapsulated queue can be placed between fragments of a multilink-encapsulated queue. However, fragments from one multilink-encapsulated queue cannot be interleaved with fragments from another multilink-encapsulated queue. This is the intent of the specification FRF.12, *Frame Relay Fragmentation Implementation Agreement*. If fragments from two different queues were interleaved, the header fields might not have enough information to separate the fragments.

Examples: Configuring an LSQ Interface for a Fractional T1 Interface Using FRF.12

FRF.12 with Fragmentation and Without LFI

This example shows a 128 KB DS0 interface. There is one traffic stream on ge-0/0/0, which is classified into queue 0 (be). Packets are fragmented in the link services IQ (lsq-) interface according to the threshold configured in the fragmentation map.

```
[edit chassis]
fpc 0 {
  pic 3 {
    adaptive-services {
      service-package layer-2;
    }
  }
}
[edit interfaces]
ge-0/0/0 {
  unit 0 {
    family inet {
      address 20.1.1.1/24 {
        arp 20.1.1.2 mac 00.90.1b.12.34.56;
      }
    }
  }
}
ce1-0/2/0 {
  partition 1 timeslots 1-2 interface-type ds;
}
ds-0/2/0:1 {
  no-keepalives;
  dce;
  encapsulation frame-relay;
```

```

    unit 0 {
        dlc1 100;
        family mlfr-end-to-end {
            bundle lsq-0/3/0.0;
        }
    }
}
lsq-0/3/0 {
    per-unit-scheduler;
    unit 0 {
        encapsulation multilink-frame-relay-end-to-end;
        family inet {
            address 10.200.0.78/30;
        }
    }
}
fxp0 {
    unit 0 {
        family inet {
            address 172.16.1.162/24;
        }
    }
}
lo0 {
    unit 0 {
        family inet {
            address 10.0.0.1/32;
        }
    }
}
[edit class-of-service]
forwarding-classes {
    queue 0 be;
    queue 1 ef;
    queue 2 af;
    queue 3 nc;
}
interfaces {
    lsq-0/3/0 {
        unit 0 {
            fragmentation-map map1;
        }
    }
}
fragmentation-maps {
    map1 {
        forwarding-class {
            be {
                fragment-threshold 160;
            }
        }
    }
}
}

```

**FRF.12 with
Fragmentation and LFI**

This example shows a 512 KB DS0 bundle and four traffic streams on **ge-0/0/0** that are classified into four queues. The fragment size is 160 for queue 0, queue 1, and queue 2. The voice stream on queue 3 has LFI configured.

```
[edit chassis]
fpc 0 {
  pic 3 {
    adaptive-services {
      service-package layer-2;
    }
  }
}
[edit interfaces]
ge-0/0/0 {
  unit 0 {
    family inet {
      address 20.1.1.1/24 {
        arp 20.1.1.2 mac 00.90.1b.12.34.56;
      }
    }
  }
  ce1-0/2/0 {
    partition 1 timeslots 1-8 interface-type ds;
  }
  ds-0/2/0:1 {
    no-keepalives;
    dce;
    encapsulation frame-relay;
    unit 0 {
      dlci 100;
      family mlfrr-end-to-end {
        bundle lsq-0/3/0.0;
      }
    }
  }
}
lsq-0/3/0 {
  per-unit-scheduler;
  unit 0 {
    encapsulation multilink-frame-relay-end-to-end;
    family inet {
      address 10.200.0.78/30;
    }
  }
}
[edit class-of-service]
classifiers {
  inet-precedence ge-interface-classifier {
    forwarding-class be {
      loss-priority low code-points 000;
    }
    forwarding-class ef {
      loss-priority low code-points 010;
    }
    forwarding-class af {
      loss-priority low code-points 100;
    }
  }
}
```

```

    }
    forwarding-class nc {
        loss-priority low code-points 110;
    }
}
forwarding-classes {
    queue 0 be;
    queue 1 ef;
    queue 2 af;
    queue 3 nc;
}
interfaces {
    lsq-0/3/0 {
        unit 0 {
            scheduler-map sched2;
            fragmentation-map map2;
        }
    }
    ds-0/2/0:1 {
        scheduler-map link-map2;
    }
    ge-0/0/0 {
        unit 0 {
            classifiers {
                inet-precedence ge-interface-classifier;
            }
        }
    }
}
scheduler-maps {
    sched2 {
        forwarding-class be scheduler economy;
        forwarding-class ef scheduler business;
        forwarding-class af scheduler stream;
        forwarding-class nc scheduler voice;
    }
    link-map2 {
        forwarding-class be scheduler link-economy;
        forwarding-class ef scheduler link-business;
        forwarding-class af scheduler link-stream;
        forwarding-class nc scheduler link-voice;
    }
}
fragmentation-maps {
    map2 {
        forwarding-class {
            be {
                fragment-threshold 160;
            }
            ef {
                fragment-threshold 160;
            }
            af {
                fragment-threshold 160;
            }
        }
    }
}

```

```

        nc {
            no-fragmentation;
        }
    }
}
schedulers {
    economy {
        transmit-rate percent 26;
        buffer-size percent 26;
    }
    business {
        transmit-rate percent 26;
        buffer-size percent 26;
    }
    stream {
        transmit-rate percent 35;
        buffer-size percent 35;
    }
    voice {
        transmit-rate percent 13;
        buffer-size percent 13;
    }
    link-economy {
        transmit-rate percent 26;
        buffer-size percent 26;
    }
    link-business {
        transmit-rate percent 26;
        buffer-size percent 26;
    }
    link-stream {
        transmit-rate percent 35;
        buffer-size percent 35;
    }
    link-voice {
        transmit-rate percent 13;
        buffer-size percent 13;
    }
}
}
}

```

Configuring LSQ Interfaces as NxT1 or Nx E1 Bundles Using FRF.15

This example configures an NxT1 bundle using FRF.15 on a link services IQ interface. FRF.15 is similar to FRF.12, as described in “Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using FRF.12” on page 366. The difference is that FRF.15 supports multiple physical links in a bundle, whereas FRF.12 supports only one physical link per bundle. For the JUNOS software implementation of FRF.15, you can configure one DLCI per physical link.



NOTE: Link services IQ interfaces support both T1 and E1 physical interfaces. This example refers to T1 interfaces, but the configuration for E1 interfaces is similar.

```
[edit interfaces]
lsq-1/3/0 {
  per-unit-scheduler;
  unit 0 {
    encapsulation multilink-frame-relay-end-to-end;
  }
}
unit 1 {
  encapsulation multilink-frame-relay-end-to-end;
}
# First physical link
t1-1/1/0:1 {
  encapsulation frame-relay;
  unit 0 {
    dlci 69;
    family mlfr-end-to-end {
      bundle lsq-1/3/0.0;
    }
  }
}
# Second physical link
t1-1/1/0:2 {
  encapsulation frame-relay;
  unit 0 {
    dlci 13;
    family mlfr-end-to-end {
      bundle lsq-1/3/0.0;
    }
  }
}
```

Configuring LSQ Interfaces for T3 Links Configured for Compressed RTP over MLPPP

This example bundles a single T3 interface on a link services IQ interface with MLPPP encapsulation. Binding a single T3 interface to a multilink bundle allows you to configure compressed RTP (CRTP) on the T3 interface.

This scenario applies to MLPPP bundles only. The JUNOS software does not currently support CRTP over Frame Relay. For more information, see “Voice Services Configuration Guidelines” on page 393.

There is no need to configure LFI at DS3 speeds, because the packet serialization delay is negligible.

```
[edit interfaces]
t3-0/0/0 {
  unit 0 {
    family mlppp {
      bundle lsq-1/3/0.1;
    }
  }
}
```

```

    }
  }
}
lsq-1/3/0.1 {
  encapsulation multilink-ppp;
}
compression {
  rtp {
    # cRTP parameters go here
    #
    port minimum 2000 maximum 64009;
  }
}

```

This configuration uses a default fragmentation map, which results in all forwarding classes (queues) being sent out with a multilink header.

To eliminate multilink headers, you can configure a fragmentation map in which all queues have the `no-fragmentation` statement at the [edit class-of-service fragmentation-maps *map-name* forwarding-class *class-name*] hierarchy level, and attach the fragmentation map to the `lsq-1/3/0.1` interface, as shown here:

```

[edit class-of-service]
fragmentation-maps {
  fragmap {
    forwarding-class {
      be {
        no-fragmentation;
      }
      af {
        no-fragmentation;
      }
      ef {
        no-fragmentation;
      }
      nc {
        no-fragmentation;
      }
    }
  }
}
interfaces {
  lsq-1/3/0.1 {
    fragmentation-map fragmap;
  }
}

```

Configuring LSQ Interfaces as T3 or OC3 Bundles Using FRF.12

This example configures a clear-channel T3 or OC3 interface with multiple logical interfaces (DLCIs) on the link. In this scenario, each DLCI represents a customer. DLCIs are shaped at the egress PIC to a particular speed (*NxDS0*). This allows you to configure LFI using FRF.12 End-to-End Protocol on Frame Relay DLCIs.

To do this, first configure logical interfaces (DLCIs) on the physical interface. Then bundle the DLCIs, so that there is only one DLCI per bundle.

The physical interface must be capable of per-DLCI scheduling, which allows you to attach shaping rates to each DLCI. For more information, see the *JUNOS Network Interfaces Configuration Guide*.

To prevent fragment drops at the egress PIC, you must assign a shaping rate to the link services IQ logical interfaces and to the egress DLCIs. Shaping rates on DLCIs specify how much bandwidth is available for each DLCI. The shaping rate on link services IQ interfaces should match the shaping rate assigned to the DLCI that is associated with the bundle.

Egress interfaces also must have a scheduler map attached. The queue that carries voice should be strict-high-priority, while all other queues should be low-priority. This makes LFI possible.

This example shows voice traffic in the **ef** queue. The voice traffic is interleaved with bulk data. Alternatively, you can use multiclass MLPPP to carry multiple classes of traffic in different multilink classes, as described in “Configuring Multiclass MLPPP on LSQ Interfaces” on page 338.

```
[edit interfaces]
t3-0/0/0 {
  per-unit-scheduler;
  encapsulation frame-relay;
  unit 0 {
    dlcI 69;
    family mlfr-end-to-end {
      bundle lsq-1/3/0.0;
    }
  }
  unit 1 {
    dlcI 42;
    family mlfr-end-to-end {
      bundle lsq-1/3/0.1;
    }
  }
}
lsq-1/3/0 {
  unit 0 {
    encapsulation multilink-frame-relay-end-to-end;
  }
  fragment-threshold 320; # Multilink packets must be fragmented
}
unit 1 {
  encapsulation multilink-frame-relay-end-to-end;
}
fragment-threshold 160;
[edit class-of-service]
scheduler-maps {
  sched { # Scheduling parameters that apply to bundles on AS or MultiServices PICs.
    ...
  }
}
pic-sched {
```



```

# Scheduling parameters for egress DLCIs.
# The voice queue should be strict-high priority.
# All other queues should be low priority.
...
}
fragmentation-maps {
  fragmap {
    forwarding-class {
      ef {
        no-fragmentation;
      }
      # Voice is carried in the ef queue.
      # It is interleaved with bulk data.
    }
  }
}
interfaces {
  t3-0/0/0 {
    unit 0 {
      shaping-rate 512k;
      scheduler-map pic-sched;
    }
    unit 1 {
      shaping-rate 128k;
      scheduler-map pic-sched;
    }
  }
}
lsq-1/3/0 { # Assign fragmentation and scheduling to LSQ interfaces.
  unit 0 {
    shaping-rate 512k;
    scheduler-map sched;
    fragmentation-map fragmap;
  }
  unit 1 {
    shaping-rate 128k;
    scheduler-map sched;
    fragmentation-map fragmap;
  }
}
}

```

For more information about how FRF.12 works with links services IQ interfaces, see “Configuring LSQ Interfaces for Single Fractional T1 or E1 Interfaces Using FRF.12” on page 366.

Configuring LSQ Interfaces for ATM2 IQ Interfaces Using MLPPP

This example configures an ATM2 IQ interface with MLPPP bundled with link services IQ interfaces. This allows you to configure LFI on ATM virtual circuits.

For this type of configuration, the ATM2 IQ interface must have LLC encapsulation.

The following ATM PICs are supported in this scenario:

- 2-port OC-3/STM1 ATM2 IQ

■ 4-port DS3 ATM2 IQ

Virtual circuit multiplexed PPP over AAL5 is not supported. Frame Relay is not supported. Bundling of multiple ATM VCs into a single logical interface is not supported.

Unlike DS3 and OC3 interfaces, there is no need to create a separate scheduler map for the ATM PIC. For ATM, you define CoS components at the `[edit interfaces at-fpc/pic/port atm-options]` hierarchy level, as described in the *JUNOS Network Interfaces Configuration Guide*.



NOTE: Do not configure RED profiles on ATM logical interfaces that are bundled. Drops do not occur at the ATM interface.

In this example, two ATM VCs are configured and bundled into two link services IQ bundles. A fragmentation map is used to interleave voice traffic with other multilink traffic. Because MLPPP is used, each link services IQ bundle can be configured for CRTP.

```
[edit interfaces]
at-1/2/0 {
  atm-options {
    vpi 0;
    pic-type atm2;
  }
  unit 0 {
    vci 0.69;
    encapsulation atm-mlppp-llc;
    family mlppp {
      bundle lsq-1/3/0.10;
    }
  }
  unit 1 {
    vci 0.42;
    encapsulation atm-mlppp-llc;
    family mlppp {
      bundle lsq-1/3/0.11;
    }
  }
}
lsq-1/3/0 {
  unit 10 {
    encapsulation multilink-ppp;
  }
  # Large packets must be fragmented.
  # You can specify fragmentation for each forwarding class.
  fragment-threshold 320;
  compression {
    rtp {
      port minimum 2000 maximum 64009;
    }
  }
}
```

```

unit 11 {
    encapsulation multilink-ppp;
}
fragment-threshold 160;
[edit class-of-service]
scheduler-maps {
    sched { # Scheduling parameters that apply to LSQ bundles on AS or MultiServices
            PICs.
        ...
    }
    fragmentation-maps {
        fragmap {
            forwarding-class {
                ef {
                    no-fragmentation;
                }
            }
        }
    }
}
interfaces { # Assign fragmentation and scheduling parameters to LSQ interfaces.
lsq-1/3/0 {
    unit 0 {
        shaping-rate 512k;
        scheduler-map sched;
        fragmentation-map fragmap;
    }
    unit 1 {
        shaping-rate 128k;
        scheduler-map sched;
        fragmentation-map fragmap;
    }
}
}

```


Chapter 17

Summary of Link Services IQ Configuration Statements

The following sections explain each of the Link Services Intelligent Queuing (IQ) statements. The statements are organized alphabetically.

cisco-interoperability

Syntax	cisco-interoperability send-lip-remove-link-for-link-reject;
Hierarchy Level	[edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	FRF.16 interoperability settings.
Options	send-lip-remove-link-for-link-reject—Send Link Integrity Protocol remove link when an add-link rejection message is received.
Usage Guidelines	See “Configuring SONET APS Interoperability with Cisco Systems FRF.16” on page 323.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

forwarding-class

Syntax	forwarding-class <i>class-name</i> { (fragment-threshold <i>bytes</i> no-fragmentation); multilink-class <i>number</i> ; }
Hierarchy Level	[edit class-of-service fragmentation-maps]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, define a forwarding class name and associated fragmentation properties within a fragmentation map. The fragment-threshold and no-fragmentation statements are mutually exclusive.
Default	If you do not include this statement, the traffic in forwarding class <i>class-name</i> is fragmented.
Options	<i>class-name</i> —Name of the forwarding class. The remaining statements are explained separately.
Usage Guidelines	See “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

fragment-threshold

Syntax	fragment-threshold <i>bytes</i> ;
Hierarchy Level	[edit class-of-service fragmentation-maps forwarding-class <i>class-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, set the fragmentation threshold for an individual forwarding class.
Default	If you do not include this statement, the fragmentation threshold you set at the [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>] or [edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options] hierarchy level is the default for all forwarding classes. If you do not set a maximum fragment size anywhere in the configuration, packets are fragmented if they exceed the smallest maximum transmission unit (MTU) of all the links in the bundle.
Options	<i>bytes</i> —Maximum size, in bytes, for multilink packet fragments. Any nonzero value must be a multiple of 64 bytes. Range: 128 through 16,320 bytes
Usage Guidelines	See “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

fragmentation-map

Syntax	fragmentation-map <i>map-name</i> ;
Hierarchy Level	[edit class-of-service interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, associate a fragmentation map with a multilink PPP interface or MLFR FRF.16 DLCI.
Default	If you do not include this statement, traffic in all forwarding classes is fragmented.
Options	<i>map-name</i> —Name of the fragmentation map.
Usage Guidelines	See “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

fragmentation-maps

Syntax fragmentation-maps {
 map-name {
 forwarding-class *class-name* {
 (fragment-threshold *bytes* | no-fragmentation);
 multilink-class *number*;
 }
 }
 }

Hierarchy Level [edit class-of-service]

Release Information Statement introduced before JUNOS Release 7.4.

Description For link services IQ (lsq) interfaces only, define fragmentation properties for individual forwarding classes.

Default If you do not include this statement, traffic in all forwarding classes is fragmented.

Options *map-name*—Name of the fragmentation map.

The remaining statements are explained separately.

Usage Guidelines See “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

hot-standby

Syntax hot-standby;

Hierarchy Level [edit interfaces *rlsqnumber* redundancy-options]

Release Information Statement introduced in JUNOS Release 7.6.

Description For one-to-one AS or MultiServices PIC redundancy configurations, specify that the failure detection and recovery must take place in less than 5 seconds.

Usage Guidelines See “Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces” on page 324.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

link-layer-overhead

Syntax	link-layer-overhead <i>percent</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, configure the percentage of total bundle bandwidth to be set aside for link-layer overhead. Link-layer overhead accounts for the bit stuffing on serial links. Bit stuffing is used to prevent data from being interpreted as control information. Overhead resulting from link-layer encapsulation and framing is computed automatically.
Options	<i>percent</i> —Percentage of total bundle bandwidth to be set aside for link-layer overhead. Range: 0 through 50 percent Default: 0 percent
Usage Guidelines	See “Configuring CoS Scheduling Queues on Logical LSQ Interfaces” on page 332.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

lsq-failure-options

Syntax	lsq-failure-options { no-termination-request; trigger-link-failure <i>interface-name</i> ; }
Hierarchy Level	[edit interfaces lsq- <i>fpc/pic/port</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, define the failure recovery option settings.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring the Association between LSQ and SONET Interfaces” on page 322.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

multilink-class

Syntax	<code>multilink-class <i>number</i>;</code>
Hierarchy Level	[edit class-of-service fragmentation-maps forwarding-class <i>class-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, map a forwarding class into a multiclass MLPPP (MCML). The multilink-class statement and no-fragmentation statements are mutually exclusive.
Options	<i>number</i> —The multilink class assigned to this forwarding class. Range: 0 through 7 Default: None
Usage Guidelines	See “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336 and “Configuring Multiclass MLPPP on LSQ Interfaces” on page 338.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	multilink-max-classes on page 306

multilink-max-classes

Syntax	<code>multilink-max-classes <i>number</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services IQ (lsq) interfaces only, configure the number of multilink classes to be negotiated when a link joins the bundle.
Options	<i>number</i> —The number of multilink classes to be negotiated when a link joins the bundle. Range: 1 through 8 Default: None
Usage Guidelines	See “Configuring Multiclass MLPPP on LSQ Interfaces” on page 338.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-fragmentation

Syntax	no-fragmentation;
Hierarchy Level	[edit class-of-service fragmentation-maps forwarding-class <i>class-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>For link services IQ (lsq) interfaces only, set traffic on a particular forwarding class to be interleaved, rather than fragmented. This statement specifies that no extra fragmentation header is prepended to the packets received on this queue and that static-link load balancing is used to ensure in-order packet delivery.</p> <p>Static-link load balancing is done based on packet payload. For IP version 4 (IPv4) and IP version 6 (IPv6) traffic, the link is chosen based on a hash computed from the source address, destination address, and protocol. If the IP payload is Transmission Control Protocol (TCP) or User Datagram Protocol (UDP) traffic, the hash also includes source port and destination port. For MPLS traffic, the hash includes all MPLS labels and fields in the payload, whether the MPLS payload is IPv4 or IPv6.</p>
Default	If you do not include this statement, the traffic in forwarding class <i>class-name</i> is fragmented.
Usage Guidelines	See “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-termination-request

Syntax	no-termination-request;
Hierarchy Level	[edit interfaces <i>interface-name</i> ppp-options], [edit interfaces lsq-fpc/pic/port lsq-failure-options]
Release Information	Statement introduced in JUNOS Release 7.4. Support at the [edit interfaces <i>interface-name</i> ppp-options] hierarchy level added in JUNOS Release 8.3.
Description	Inhibit PPP termination-request messages to the remote host if the primary circuit fails.
Usage Guidelines	See “Configuring the Association between LSQ and SONET Interfaces” on page 322.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

per-unit-scheduler

Syntax	per-unit-scheduler;
Hierarchy Level	[edit interfaces <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For channelized OC12 IQ, channelized T3 IQ, channelized E1 IQ, E3 IQ, and Gigabit Ethernet IQ interfaces only, enable association of scheduler map names with logical interfaces.
Usage Guidelines	See “Configuring Link Services and CoS on Services PICs” on page 347.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

preserve-interface

Syntax	preserve-interface;
Hierarchy Level	[edit interfaces <i>interface-name</i> sonet-options aps]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	<p>Provide link PIC replication, providing MLPPP link redundancy at the port level. This feature is supported with SONET APS and the following link PICs:</p> <ul style="list-style-type: none"> ■ Channelized OC3 IQ PIC ■ Channelized OC12 IQ PIC ■ Channelized STM1 IQ PIC <p>Link PIC replication provides the ability to add two sets of links, one from the active SONET PIC and the other from the standby SONET PIC, to the same bundle. If the active SONET PIC fails, links from the standby PIC are used without triggering link renegotiation. All the negotiated state is replicated from the active links to the standby links to prevent link renegotiation.</p>
Usage Guidelines	See “Configuring Link State Replication for Redundant Link PICs” on page 327.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

primary

Syntax	<code>primary interface-name;</code>
Hierarchy Level	[edit interfaces rlsqnumber redundancy-options]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify the primary Link Services IQ PIC interface.
Options	<i>interface-name</i> —The identifier for the Link Services IQ PIC interface, which must be of the form <i>lsq-fpc/pic/port</i> .
Usage Guidelines	See “Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces” on page 324.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

redundancy-options

Syntax	<pre> redundancy-options { (hot-standby warm-standby); primary lsq-fpc/pic/port; secondary lsq-fpc/pic/port; } </pre>
Hierarchy Level	[edit interfaces rlsqnumber]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify the primary and secondary (backup) Link Services IQ PIC interfaces.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces” on page 324.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

secondary

Syntax	<code>secondary interface-name;</code>
Hierarchy Level	[edit interfaces <i>rlsnumber</i> redundancy-options]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify the secondary (backup) Link Services IQ PIC interface.
Options	<i>interface-name</i> —The identifier for the Link Services IQ PIC interface, which must be of the form <i>lsq-fpc/pic/port</i> .
Usage Guidelines	See “Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces” on page 324.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

trigger-link-failure

Syntax	<code>trigger-link-failure interface-name;</code>
Hierarchy Level	[edit interfaces <i>lsq-fpc/pic/port</i> lsq-failure-options]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	List of SONET interfaces connected to the LSQ interface that can implement Automatic Protection Switching (APS) if the Link Services IQ PIC fails.
Options	<i>interface-name</i> —Name of SONET interface.
Usage Guidelines	See “Configuring the Association between LSQ and SONET Interfaces” on page 322.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

warm-standby

Syntax	warm-standby;
Hierarchy Level	[edit interfaces <i>rls<number></number> redundancy-options]</i>
Release Information	Statement introduced in JUNOS Release 8.0.
Description	For AS or MultiServices PIC redundancy configurations, specify that the failure detection and recovery involves one backup PIC supporting multiple working PICs. Recovery time is not guaranteed.
Usage Guidelines	See “Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces” on page 324.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 18

Voice Services Configuration Guidelines

The Adaptive Services (AS) and MultiServices PICs support the compressed Real-Time Transport Protocol (CRTP) on the **lsq-fpc/pic/port** interface type. This enables voice over IP (VoIP) traffic to use low-speed links more effectively, by compressing the 40-byte IP/User Datagram Protocol (UDP)/RTP header down to from 2 to 4 bytes in most cases.



NOTE: J-series Services Routers use the link services (ls) interface to configure CRTP with MLPPP or PPP logical interface encapsulation. For more information, see “Configuring Compressed RTP on J-series Services Routers” on page 990.

J-series Services Routers also support VoIP routing through the Avaya TGM550 media gateway module. This is a separate product from the adaptive services suite and is not supported on M-series and T-series routing platforms. For more information, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

For link services IQ interfaces (lsq) only, you can configure CRTP with multiclass MLPPP (MCML). MCML greatly simplifies packet ordering issues that occur when multiple links are used. Without MCML, all voice traffic belonging to a single flow is hashed to a single link in order to avoid packet ordering issues. With MCML, you can assign voice traffic to a high-priority class, and you can use multiple links. For more information about MCML support on link services IQ interfaces, see “Configuring Link Services and CoS on Services PICs” on page 347.

Link services IQ interfaces use a bundle configuration. For more information, see “Link Services IQ Interfaces Configuration Guidelines” on page 319 and “Multilink and Link Services Logical Interface Configuration Overview” on page 979.



NOTE: On LSQ interfaces, all multilink traffic for a single bundle is sent to a single processor. If CRTP is enabled on the bundle, it adds overhead to the CPU. Because T3 network interfaces support only one link per bundle, make sure you configure a fragmentation map for compressed traffic on these interfaces and specify the **no-fragmentation** option. For more information, see “Configuring Delay-Sensitive Packet Interleaving” on page 396 and “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

Voice services do not require a separate service rules configuration, but you need to configure both services interfaces and network interfaces, as described in the following topics:

- Configuring Services Interfaces for Voice Services on page 394
- Configuring Encapsulation for Voice Services on page 397
- Configuring Network Interfaces for Voice Services on page 397
- Configuring VoIP Routing on J-series Services Routers on page 398
- Examples: Configuring Voice Services on page 402

Configuring Services Interfaces for Voice Services

You define voice service properties such as compression by configuring statements and values for a voice services interface, specified by the interface type **lsq** (**ls**- on J-series Services Routers). You can include the following statements:

```
encapsulation mlppp;
family inet {
    address address;
}
compression {
    rtp {
        f-max-period number;
        maximum-contexts number <force>;
        port {
            minimum port-number;
            maximum port-number;
        }
        queues [ queue-numbers ];
    }
}
fragment-threshold bytes;
```

You can include these statements at the following hierarchy levels:

- [edit interfaces (**lsq** | **ls**)-*fpc/pic/port* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces (**lsq** | **ls**)-*fpc/pic/port* unit *logical-unit-number*]

The following sections provide detailed instructions for configuring for voice services on services interfaces:

- Configuring the Logical Interface Address for the MLPPP Bundle on page 394
- Configuring Compression of Voice Traffic on page 395
- Configuring Delay-Sensitive Packet Interleaving on page 396
- Example: Configuring Compression of Voice Traffic on page 396

Configuring the Logical Interface Address for the MLPPP Bundle

To configure the logical address for the MLPPP bundle, include the **address** statement:

```
address address {
  ...
}
```

You can configure this statement at the following hierarchy levels:

- [edit interfaces (lsq | ls)-fpc/pic/port unit *logical-unit-number* family inet]
- [edit logical-systems *logical-system-name* interfaces (lsq | ls)-fpc/pic/port unit *logical-unit-number* family inet]

address specifies an IP address for the interface. AS and MultiServices PICs support only IP version 4 (IPv4) addresses, which are therefore configured under the *family inet* statement.

For information on other addressing properties you can configure that are not specific to service interfaces, see the *JUNOS Network Interfaces Configuration Guide*.

Configuring Compression of Voice Traffic

You can specify how a services interface handles voice traffic compression by including the *compression* statement:

```
compression {
  rtp {
    f-max-period number;
    maximum-contexts number <force>;
    port {
      minimum port-number;
      maximum port-number;
    }
    queues [ queue-numbers ];
  }
}
```

You can include this statement at the following hierarchy levels:

- [edit interfaces (lsq | ls)-fpc/pic/port unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces (lsq | ls)-fpc/pic/port unit *logical-unit-number*]

The following statements configure the indicated compression properties:

- **f-max-period *number***—Sets the maximum number of compressed packets to insert between the transmission of full headers. If you do not include the statement, the default is 255 packets.
- **maximum-contexts *number* <force>**—Specifies the maximum number of RTP contexts to accept during negotiation. The optional **force** statement requires the PIC to use the value specified for maximum RTP contexts, regardless of the negotiated value. This option enables interoperability with JUNOS software releases that base the RTP context value on link speed.
- **port, minimum *port-number*, and maximum *port-number***—Specify the lower and upper boundaries for a range of UDP destination port values on which RTP

compression takes effect. Values for *port-number* can range from 0 through 65,535. RTP compression is applied to traffic transiting the ports within the specified range.

- **queues [*queue-numbers*]**—Specifies one or more of queues q0, q1, q2, and q3 . RTP compression is applied to the traffic in the specified queues.



NOTE: If you specify both a port range and one or more queues, compression takes place if either condition is met.

Configuring Delay-Sensitive Packet Interleaving

When you configure CRTP, the software automatically enables link fragmentation and interleaving (LFI). LFI reduces excessive delays by fragmenting long packets into smaller packets and interleaving them with real-time frames. This allows real-time and non-real-time data frames to be carried together on lower-speed links without causing excessive delays to the real-time traffic. When the peer interface receives the smaller fragments, it reassembles the fragments into their original packet. For example, short delay-sensitive packets, such as packetized voice, can race ahead of larger delay-insensitive packets, such as common data packets.

By default, LFI is always active when you include the **compression rtp** statement at the [edit interfaces *interface-name* unit *logical-unit-number*] hierarchy level. You control the operation of LFI indirectly by setting the **fragment-threshold** statement on the same logical interface. For example, if you include the **fragment-threshold 256** statement at the [edit interfaces *interface-name* unit *logical-unit-number*] hierarchy level, all IP packets larger than 256 bytes are fragmented.

Example: Configuring Compression of Voice Traffic

Configure compression on a T1 interface with MLPPP encapsulation. Configure fragmentation for all IP packets larger than 128 bytes.

```
[edit interfaces]
t1-1/0/0 {
  unit 0 {
    family mlppp {
      bundle lsq-1/1/0.1;
    }
  }
}
lsq-1/1/0 {
  encapsulation mlppp;
  unit 1 {
    compression {
      rtp {
        port minimum 2000 maximum 64009;
      }
    }
  }
  family inet {
    address 30.1.1.2/24;
```

```

    }
    fragment-threshold 128;
  }
}

```

Configuring Encapsulation for Voice Services

Voice services interfaces support the following logical interface encapsulation types:

- Multilink Point-to-Point Protocol (MLPPP), which is the default encapsulation
- ATM2 IQ MLPPP over AAL5 LLC
- Frame Relay PPP

For general information on encapsulation, see the *JUNOS Network Interfaces Configuration Guide*. You can also configure physical interface encapsulation on voice services interfaces.

To configure voice services encapsulation, include the **encapsulation** statement:

```
encapsulation type;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For voice services interfaces, the valid values for the **type** variable are **atm-mlppp-llc**, **frame-relay-ppp** or **multilink-ppp**.

You must also configure the physical interface with the corresponding encapsulation type, either Frame Relay or PPP. LSQ interfaces are supported by the following physical interface types: ATM2 IQ, DS3, E1, E3, OC3, OC12, STM1, and T1, including the channelized versions of these interfaces. For examples, see “Examples: Configuring Voice Services” on page 402.



NOTE: The only protocol type supported with **frame-relay-ppp** encapsulation is family **mlppp**.

Configuring Network Interfaces for Voice Services

To complete a voice services interface configuration, you need to configure the physical network interface with either MLPPP encapsulation and a voice services bundle or PPP encapsulation and a compression interface, as described in the following sections:

- Configuring Voice Services Bundles with MLPPP Encapsulation on page 398
- Configuring the Compression Interface with PPP Encapsulation on page 398

Configuring Voice Services Bundles with MLPPP Encapsulation

For voice services interfaces, you configure the link bundle as a channel. The physical interface is usually connected to networks capable of supporting MLPPP; the interface types supported for voice traffic are T1, E1, T3, E3, OC3, OC12, and STM1, including channelized versions of these interfaces.

To configure a physical interface link for MLPPP, include the following statement:

```
bundle interface-name;
```

You can configure this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number* family mlppp]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* family mlppp]

When you configure `family mlppp`, no other protocol configuration is allowed. For more information on link bundles, see “Configuring the Links in a Multilink or Link Services Bundle” on page 978.

Configuring the Compression Interface with PPP Encapsulation

To configure the physical interface for PPP encapsulation, you also need to specify the services interface to be used for voice compression: a Link Services IQ (lsq-) interface on M-series and T-series routers or a Link Services (ls-) interface on J-series Services Routers.

To configure the compression interface, include the `compression-device` statement:

```
compression-device interface-name;
```

You can configure this statement at the following hierarchy levels:

- [edit interfaces (lsq | ls)-fpc/pic/port unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces (lsq | ls)-fpc/pic/port unit *logical-unit-number*]

Configuring VoIP Routing on J-series Services Routers

J4350 and J6350 Services Routers support voice over IP (VoIP) routing with the Avaya IG550 Integrated Gateway. The following sections provide an overview of the product and the JUNOS configuration tasks for setting it up:

- Functional Components on page 399
- Configuring the VoIP Interface on page 399
- Configuring the Media Gateway Controller List on page 400
- Configuring Dynamic Call Admission Control on page 401

For more information, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

Functional Components

The Avaya IG550 Integrated Gateway consists of the following VoIP modules that can be installed in the PCI Express slots on the J4350 and J6350 Services Routers for providing VoIP connectivity:

- TGM550—Avaya Telephony Gateway Module (TGM) with two analog telephone ports, two analog trunk ports, and one serial port for console access.
- TIM510—Avaya DS1 Telephony Interface Module (TIM) with one T1 or E1 trunk port.
- TIM514—Avaya Analog TIM with four analog telephone ports and four analog trunk ports.
- TIM521—Avaya BRI TIM with four RJ-45 ports for ISDN BRI trunk connections.

The TGM550 works with the TIM510, TIM514, and TIM521 media modules to connect IP and legacy analog telephones and trunks over IP networks.

The telephony services on the TGM550 are controlled by a Media Gateway Controller (MGC)—an Avaya media server running Avaya Communication Manager (CM) call processing software. The TGM550 is managed by an MGC located at headquarters or in a branch office. When the primary MGC is located at a remote location, the TGM550 uses standard local survivability (SLS) for partial MGC backup if the connection to the primary MGC is lost. This enables the J4350 and J6350 Services Routers to provide reliable telephony services to branch offices.

Configuring the VoIP Interface

The TGM PIC represents a single-port interface named `vp-slot/0/0`, where `slot` is the slot number. For example, a TGM PIC installed in slot 1 is named `vp-1/0/0`. To configure the interface, include the following statements:

```
[edit]
interfaces vp-slot/0/0 {
  unit 0 {
    family inet {
      address address {
        destination address;
      }
    }
  }
}
```

You can configure only one logical unit (unit 0) on the VoIP interface. You must configure a point-to-point connection between the VoIP interface and the TGM550. To configure the point-to-point connection, specify `/32` as the subnet mask in the IPv4 address of the VoIP interface.

The following is a sample configuration:

```

interfaces vp-3/0/0 {
  unit 0 {
    family inet {
      address 10.10.10.1/32 {
        destination 10.10.10.2;
      }
    }
  }
}

```

Configuring the Media Gateway Controller List

To provide telephony services, the TGM550 must be registered with a Media Gateway Controller (MGC) running the Avaya Communication Manager software. You can configure the IP addresses for up to four MGCs to which the TGM550 can connect if a link fails.

The MGC list consists of the IP addresses and the order in which to reestablish the H.248 link. The first MGC on the list is the primary MGC. The TGM550 searches for the primary MGC first. If it cannot connect to the primary MGC or loses its connection to the primary MGC, it attempts to connect to the next MGC on the list, and so on.



NOTE: The MGC list is stored in the TGM 550. It is not written to the JUNOS configuration file.

You configure the MGC list by issuing operational mode commands. To configure the MGC list, perform the following steps:

1. Enter operational mode in the CLI.
2. To configure the IP addresses of the Media Gateway Controllers, enter the following command:

```

user@host> request tgm fpc slot slot-number tgm-configuration
"mgclist=ipaddress1,ipaddress2,ipaddress3,ipaddress4"

```

For example, to configure the primary MGC with the IP address 172.16.0.0 and the secondary and tertiary MGCs with the IP addresses 10.10.10.30 and 10.10.10.40 for the TGM550 installed on slot 2 of the chassis, enter:

```

user@host> request chassis fpc slot 2 tgm-configuration
"mgclist=172.16.0.0,10.10.10.30,10.10.10.40"

```

3. Log in to the TGM550. For information about logging in to the TGM550, see the *J-series Services Router Advanced WAN Access Configuration Guide*.
4. Ping the IP addresses of the configured MGCs to ensure that the IP addresses are correct. For example, to ping the IP address of the primary MGC, enter:

```

user@host> # ping 172.16.0.0

```

5. To verify that the MGC list is configured correctly, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

Configuring Dynamic Call Admission Control

For Fast Ethernet and Gigabit Ethernet interfaces, ISDN BRI interfaces, and serial interfaces with PPP or Frame Relay encapsulation on J4350 and J6350 Services Routers supporting VoIP through the TGM550 media gateway module, you can configure dynamic call admission control (CAC). Dynamic CAC provides enhanced control over WAN bandwidth. When dynamic CAC is configured on an interface responsible for providing call bandwidth, the TGM550 informs the Media Gateway Controller (MGC) of the bandwidth limit available for voice packets on the interface and requests the MGC to block new calls when the bandwidth is exhausted.

Dynamic CAC is useful in situations where a primary link becomes unavailable and a backup link with less bandwidth takes its place. Without dynamic CAC, the MGC cannot detect the switchover to the backup link or the resulting changes in network topology and available bandwidth. The MGC would continue to admit calls at the bandwidth of the primary link, causing network congestion and possible jitter, delay, and loss of calls.

To configure dynamic CAC, you define the bearer bandwidth limit (BBL) and activation priority on each WAN interface responsible for providing call bandwidth.

The Gigabit Ethernet interface is used as the primary link for providing call bandwidth because it has the highest activation priority value. When the Gigabit Ethernet interface is active, the TGM550 reports its BBL value of 3000 Kbps to the MGC. If the Gigabit Ethernet interface fails, the TGM550 automatically switches over to the T1 interface because it has the next highest activation priority. The TGM550 now reports the BBL value of the T1 interface to the MGC. If the T1 interface also fails, the TGM550 switches over to the ISDN BRI interface and reports the BBL value of the ISDN BRI interface to the MGC. Configuring dynamic CAC on multiple WAN interfaces allows the MGC to automatically control the call bandwidth when interfaces responsible for providing call bandwidth are unavailable.

To configure dynamic CAC, include the following configuration statements:

```
unit 0 {
  dynamic-call-admission-control {
    activation-priority value;
    bearer-bandwidth-limit value;
  }
}
```

You must configure dynamic CAC on logical unit 0. You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name*]
- [edit logical-systems *logical-system-name* interfaces *interface-name*]

kilobits-per-second is the dynamic CAC BBL—the maximum bandwidth available for voice traffic on the interface. The TGM550 reports the BBL to the MGC. When the call bandwidth exceeds the BBL, the MGC blocks new calls and alerts the user with a busy tone. The default BBL is –1, which indicates that the complete interface bandwidth is available for voice traffic. Configure **bb1 0** to report zero bandwidth for

bearer traffic to the MGC or to use the interface for signaling purposes only. The range is from 0 through 9999 Kbps.

priority is the dynamic CAC activation priority value that specifies the order in which interfaces are used for providing call bandwidth. The interface with the highest activation priority value is used as the primary link for providing call bandwidth. If the primary link becomes unavailable, the TGM550 switches over to the next active interface with the highest activation priority value, and so on. The activation priority value range is 0 through 255. The default is 50.



NOTE: Dynamic CAC works in conjunction with the Avaya Communication Manager (CM) Call Admission Control: Bandwidth Limitation (CAC-BL) feature. If you configure dynamic CAC on WAN interfaces, you must also configure CAC-BL on the Avaya CM. For more information about configuring CAC-BL, see the *Administrator Guide for Avaya Communication Manager*.

The following is a configuration example:

```
interfaces ge-0/0/3 {
  unit 0 {
    dynamic-call-admission-control {
      activation-priority 150;
      bearer-bandwidth-limit 1000;
    }
  }
}
```

Examples: Configuring Voice Services

Configure voice services using a T1 physical interface and MLPPP bundle encapsulation:

```
[edit interfaces]
t1-0/2/0:1 {
  encapsulation ppp;
  unit 0 {
    family mlppp {
      bundle lsq-1/3/0.1;
    }
  }
}
lsq-1/3/0 {
  unit 1 {
    encapsulation mlppp;
    family inet {
      address 10.5.5.2/30;
    }
    compression {
      rtp {
        f-max-period 100;
        queues [ q1 q2 ];
        port {
          minimum 16384;
          maximum 32767;
        }
      }
    }
  }
}
```

```

    }
  }
}
fragment-threshold 128;
}
}

```

Configure voice services using Frame Relay encapsulation without bundling:

```

[edit interfaces]
t1-1/0/0 {
  encapsulation frame-relay;
  unit 0 {
    dlci 100;
    encapsulation frame-relay-ppp;
    compression-device lsq-2/0/0.0;
  }
}
lsq-2/0/0 {
  unit 0 {
    compression {
      rtp {
        f-max-period 100;
        queues [ q1 q2 ];
        port {
          minimum 16000;
          maximum 32000;
        }
      }
    }
  }
  family inet {
    address 10.1.1.1/32;
  }
}
}

```

Configure voice services using an ATM2 physical interface (the corresponding class-of-service configuration is provided for illustration):

```

[edit interfaces]
at-1/2/0 {
  atm-options {
    vpi 0;
    pic-type atm2; # only ATM2 PICs are supported
  }
  unit 0 {
    vci 0.69;
    encapsulation atm-mlppp-llc;
    family mlppp {
      bundle lsq-1/3/0.10;
    }
  }
  unit 1 {
    vci 0.42;
    encapsulation atm-mlppp-llc;
    family mlppp {
      bundle lsq-1/3/0.11;
    }
  }
}

```

```

    }
  }
}
lsq-1/3/0 {
  unit 10 {
    encapsulation multilink-ppp;
  }
  # Large packets need to be fragmented.
  # Fragmentation can also be specified per forwarding class.
  fragment-threshold 320;
  compression {
    rtp {
      port minimum 2000 maximum 64009;
    }
  }
}
unit 11 {
  encapsulation multilink-ppp;
}
fragment-threshold 160;
[edit class-of-service]
scheduler-maps {
  sched {
    # Scheduling parameters apply to bundles on the AS or MultiServices PIC.
    # Unlike DS3/SONET interfaces, there is no need to create
    # a separate scheduler map for the ATM PIC. ATM defines
    # CoS constructs under the [edit interfaces at-fpc/pic/port] hierarchy.
    ...
  }
}
fragmentation-maps {
  fragmap {
    forwarding-class {
      ef {
        # In this example, voice is carried in the ef queue.
        # It is interleaved with bulk data.
        # Alternatively, you could use multiclass MLPPP to
        # carry multiple classes of traffic in different
        # multilink classes.
        no-fragmentation;
      }
    }
  }
}
}
interfaces {
  # Assign fragmentation and scheduling parameters to LSQ interfaces.
  lsq-1/3/0 {
    unit 0 {
      shaping-rate 512k;
      scheduler-map sched;
      fragmentation-map fragmap;
    }
    unit 1 {
      shaping-rate 128k;
      scheduler-map sched;
      fragmentation-map fragmap;
    }
  }
}

```

```
}  
}  
}
```


Chapter 19

Summary of Voice Services Configuration Statements

The following sections explain each of the voice services statements. The statements are organized alphabetically.

activation-priority

Syntax	<code>activation-priority <i>priority</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> dynamic-call-admission-control], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> dynamic-call-admission-control]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	This statement is used only in conjunction with J4350 and J6350 Services Routers that support voice over IP with the TGM550 media gateway module. For Fast Ethernet and Gigabit Ethernet interfaces, ISDN BRI interfaces, and serial interfaces with PPP or Frame Relay encapsulation, configure the dynamic call admission control (dynamic CAC) activation priority value.
Options	<i>priority</i> —The activation priority at which the interface is used for providing call bandwidth. The interface with the highest activation priority value is the primary link for providing call bandwidth. If the primary link becomes unavailable, the TGM550 switches over to the next active interface with the highest activation priority value, and so on. Range: 0 through 255 Default: 50
Usage Guidelines	See “Configuring Dynamic Call Admission Control” on page 401.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>J-series Services Router Advanced WAN Access Configuration Guide</i>

address

Syntax	address <i>address</i> { ... }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the interface address.
Options	<i>address</i> —Address of the interface.
Usage Guidelines	See “Configuring the Logical Interface Address for the MLPPP Bundle” on page 394; for a general discussion of address statement options, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other statements that do not affect services interfaces.

bearer-bandwidth-limit

Syntax	<code>bearer-bandwidth-limit <i>kilobits-per-second</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> dynamic-call-admission-control], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> dynamic-call-admission-control]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	This statement is used only in conjunction with J4350 and J6350 Services Routers that support voice over IP with the TGM550. For Fast Ethernet and Gigabit Ethernet interfaces, ISDN BRI interfaces, and serial interfaces with PPP or Frame Relay encapsulation, configure the bearer bandwidth limit (BBL). The BBL is used for dynamic call admission control (dynamic CAC) to provide enhanced control over WAN bandwidth.
Options	<i>kilobits-per-second</i> —The bearer bandwidth limit to be reported to a TGM550, in kilobits per second (Kbps). Range: 0 through 9999 Kbps Default: –1 (dynamic CAC is not enabled on the interface)
Usage Guidelines	See “Configuring Dynamic Call Admission Control” on page 401.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>J-series Services Router Advanced WAN Access Configuration Guide</i>

bundle

Syntax	<code>bundle (<i>lsq-fpc/pic/port</i> ...);</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family mlppp]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Associate the voice services interface with the logical interface it is joining.
Options	<i>lsq-fpc/pic/port</i> —Name of the voice services interface you are linking.
Usage Guidelines	See “Configuring Voice Services Bundles with MLPPP Encapsulation” on page 398.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

compression

Syntax	<pre> compression { rtp { f-max-period <i>number</i>; maximum-contexts <i>number</i> <force>; port { minimum <i>port-number</i>; maximum <i>port-number</i>; } queues [<i>queue-numbers</i>]; } }</pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the compression properties for voice services traffic. The remaining statements are described separately.
Usage Guidelines	See “Configuring Compression of Voice Traffic” on page 395.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

compression-device

Syntax	compression-device <i>interface-name</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	Specify the compression interface for voice services traffic.
Usage Guidelines	See “Configuring the Compression Interface with PPP Encapsulation” on page 398.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

dynamic-call-admission-control

Syntax	dynamic-call-admission-control { activation-priority <i>priority</i> ; bearer-bandwidth-limit <i>kilobits-per-second</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	<p>This statement is used only in conjunction with J4350 and J6350 Services Routers that support voice over IP with the TGM550. For Fast Ethernet and Gigabit Ethernet interfaces, ISDN BRI interfaces, and serial interfaces with PPP or Frame Relay encapsulation, configure dynamic call admission control (CAC). Dynamic CAC provides enhanced control over WAN bandwidth. When dynamic CAC is configured on an interface responsible for providing call bandwidth, the TGM550 informs the Media Gateway Controller (MGC) of the bandwidth limit available for voice packets on the interface and requests that the MGC block new calls when the bandwidth is exhausted.</p> <p>Dynamic CAC must be configured on each J-series Services Router interface responsible for providing call bandwidth.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Dynamic Call Admission Control” on page 401.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>J-series Services Router Advanced WAN Access Configuration Guide</i>

encapsulation

Syntax	encapsulation <i>type</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the logical link-layer encapsulation type.
Options	<p>atm-mlppp-llc—For ATM2 IQ physical interfaces only, use Multilink Point-to-Point Protocol (MLPPP) over AAL5 LLC encapsulation.</p> <p>frame-relay-ppp—For Frame Relay circuits, use Frame Relay PPP encapsulation.</p> <p>multilink-ppp—By default, voice services logical interfaces use MLPPP encapsulation.</p>
Usage Guidelines	See “Configuring Encapsulation for Voice Services” on page 397; for information about encapsulation statement options used with other interface types, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

f-max-period

Syntax	f-max-period <i>number</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression rtp], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression rtp]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the maximum number of compressed packets allowed between the transmission of full headers in a compressed Real-time Transport Protocol (RTP) traffic stream.
Options	<p><i>number</i>—Maximum number of packets.</p> <p>Default: 256</p>
Usage Guidelines	See “Configuring Compression of Voice Traffic” on page 395.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

family

Syntax family (inet | mlppp | ...) {
 address *address* {
 ...
 }
 bundle *interface-name*;
 }

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure protocol family information for the logical interface.

Options *family*—Protocol family:

- inet—IP version 4
- mlppp—MLPPP

The remaining statements are explained separately.

Usage Guidelines See “Configuring Network Interfaces for Voice Services” on page 397; for a general discussion of **family** statement options, see the *JUNOS Network Interfaces Configuration Guide*.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

fragment-threshold

Syntax	fragment-threshold <i>bytes</i> ;
Hierarchy Level	[edit interfaces <i>lsq-fpc/pic/port</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>lsq-fpc/pic/port</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For voice services interfaces, set the fragmentation threshold, in bytes.
Options	<i>bytes</i> —Maximum size, in bytes, for multilink packet fragments. The value must be a multiple of 64 bytes, because zero is also a multiple of 64 bytes. Range: 128 through 16,320 bytes Default: 0 bytes (no fragmentation)
Usage Guidelines	See “Configuring Delay-Sensitive Packet Interleaving” on page 396.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interfaces

Syntax	interfaces { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure interfaces on the router.
Default	The management and internal Ethernet interfaces are automatically configured. You must configure all other interfaces.
Usage Guidelines	See the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

maximum-contexts

Syntax	maximum-contexts <i>number</i> <force>;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression rtp], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression rtp]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	Specify the maximum number of RTP contexts to accept during negotiation.
Options	<i>number</i> —Maximum number of contexts. <i>force</i> —(Optional) Requires the PIC to use the value specified for maximum RTP contexts, regardless of the negotiated value. This option allows the software to interoperate with JUNOS releases that base the RTP context value on link speed.
Usage Guidelines	See “Configuring Compression of Voice Traffic” on page 395.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

port

Syntax	port { minimum <i>port-number</i> ; maximum <i>port-number</i> ; }
Hierarchy Level	[edit interfaces <i>lsq-fpc/pic/port</i> unit <i>logical-unit-number</i> compression rtp], [edit logical-systems <i>logical-system-name</i> interfaces <i>lsq-fpc/pic/port</i> unit <i>logical-unit-number</i> compression rtp]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For voice services interfaces only, specify a range of User Datagram Protocol (UDP) destination port numbers in which RTP compression takes place.
Options	<i>minimum port-number</i> —Specify the minimum port number. Range: 0 through 65,535 <i>maximum port-number</i> —Specify the maximum port number. Range: 0 through 65,535
Usage Guidelines	See “Configuring Compression of Voice Traffic” on page 395.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

queues

Syntax	<code>queues [<i>queue-numbers</i>];</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression rtp], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression rtp]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For voice services interfaces only, assign queue numbers on which RTP compression takes place.
Options	<code>queues <i>queue-numbers</i></code> —Assign one or more of the following queues: q0, q1, q2, and q3.
Usage Guidelines	See “Configuring Compression of Voice Traffic” on page 395.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

rtp

Syntax	<pre> rtp { f-max-period <i>number</i>; maximum-contexts <i>number</i> <force>; port { minimum <i>port-number</i>; maximum <i>port-number</i>; } queues [<i>queue-numbers</i>]; } </pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> compression]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the RTP properties for voice services traffic. The remaining statements are described separately.
Usage Guidelines	See “Configuring Compression of Voice Traffic” on page 395.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

unit

Syntax unit *logical-unit-number* {
 compression {
 rtp {
 f-max-period *number*;
 maximum-contexts *number* <force>;
 port {
 minimum *port-number*;
 maximum *port-number*;
 }
 queues [*queue-numbers*];
 }
 }
 compression-device *interface-name*;
 dynamic-call-admission-control {
 activation-priority *priority*;
 bearer-bandwidth-limit *kilobits-per-second*;
 }
 encapsulation type;
 family family {
 address *address* {
 ...
 }
 bundle (lsq-fpc/pic/port | ...);
 }
 }

Hierarchy Level [edit interfaces *interface-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.

Options *logical-unit-number*—Number of the logical unit.
 Range: 0 through 16,384

The remaining statements are explained separately.

Usage Guidelines See “Configuring Services Interfaces for Voice Services” on page 394; for a general discussion of logical interface properties, see the *JUNOS Network Interfaces Configuration Guide*.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

Chapter 20

Class-of-Service Configuration Guidelines

To configure class of service (CoS) features on Adaptive Services (AS) and MultiServices PICs, include the `cos` statement at the `[edit services]` hierarchy level:

```
cos {
  application-profile profile-name {
    sip-text {
      dscp (alias | bits);
      forwarding-class class-name;
    }
    sip-video {
      dscp (alias | bits);
      forwarding-class class-name;
    }
    sip-voice {
      dscp (alias | bits);
      forwarding-class class-name;
    }
  }
  rule rule-name {
    match-direction (input | output | input-output);
    term term-name {
      from {
        application-sets set-name;
        applications [ application-names ];
        destination-address address;
        destination-prefix-list list-name <except>;
        source-address address;
        source-prefix-list list-name <except>;
      }
      then {
        application-profile profile-name;
        dscp (alias | bits);
        forwarding-class class-name;
        syslog;
        (reflexive | reverse) {
          application-profile profile-name;
          dscp (alias | bits);
          forwarding-class class-name;
          syslog;
        }
      }
    }
  }
}
```

```

    rule-set rule-set-name {
        [ rule rule-names ];
    }
}

```



NOTE: CoS behavior aggregate (BA) classification is not supported on services interfaces.

This chapter contains the following sections:

- Restrictions and Cautions for CoS Configuration on Services Interfaces on page 420
- Configuring CoS Rules on page 420
- Configuring CoS Rule Sets on page 425
- Examples: Configuring CoS on Services Interfaces on page 426

Restrictions and Cautions for CoS Configuration on Services Interfaces

The following restrictions and cautions apply to CoS configuration on services interfaces:

- The adaptive services interface does not support scheduling, only DiffServ marking and queue assignment. You must configure scheduling at the [edit *class-of-service*] hierarchy level on the output interface or fabric.
- In the default configuration, queues 1 and 2 receive 0 percent bandwidth. If packets will be assigned to these queues, you must configure a scheduling map.
- You must issue a **commit full** command before using custom forwarding-class names in the configuration.
- Only the JUNOS standard DiffServ names can be used in the configuration. Custom names are not recognized.
- On M-series routers, you can configure rewrite rules that change packet headers and attach the rules to output interfaces. These rules might overwrite the DSCP marking configured on an AS or MultiServices PIC. It is important to keep this adverse effect in mind and use care when creating system-wide configurations.

For example, knowing that the AS or MultiServices PIC can mark packets with any ToS or DSCP value and the output interface is restricted to only eight DSCP values, rewrite rules on the output interface condense the mapping from 64 to 8 values with overall loss of granularity. In this case, you have the following options:

- Remove the rewrite rules from the output interface.
- Configure the output interface to include the most important mappings.

Configuring CoS Rules

To configure a CoS rule, include the rule *rule-name* statement at the [edit *services cos*] hierarchy level:

```
[edit services cos]
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address address;
      destination-prefix-list list-name <except>;
      source-address address;
      source-prefix-list list-name <except>;
    }
    then {
      application-profile profile-name;
      dscp (alias | bits);
      forwarding-class class-name;
      syslog;
      (reflexive | reverse) {
        application-profile profile-name;
        dscp (alias | bits);
        forwarding-class class-name;
        syslog;
      }
    }
  }
}
```

Each CoS rule consists of a set of terms, similar to a filter configured at the [edit firewall] hierarchy level. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software.

The following sections explain how to configure the components of CoS rules:

- Configuring Match Direction for CoS Rules on page 421
- Configuring Match Conditions In CoS Rules on page 422
- Configuring Actions in CoS Rules on page 423
- Example: Configuring CoS Rules on page 425

Configuring Match Direction for CoS Rules

Each rule must include a **match-direction** statement that specifies the direction in which the rule match is applied. To configure where the match is applied, include the **match-direction** statement at the [edit services cos rule *rule-name*] hierarchy level:

```
match-direction (input | output | input-output);
```

If you configure **match-direction input-output**, bidirectional rule creation is allowed.

The match direction is used with respect to the traffic flow through the AS or MultiServices PIC. When a packet is sent to the PIC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the AS or MultiServices PIC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the AS or MultiServices PIC, the packet direction is output. For more information on inside and outside interfaces, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

On the AS or MultiServices PIC, a flow lookup is performed. If no flow is found, rule processing is performed. All rules in the service set are considered. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that matches the packet direction are considered.

Configuring Match Conditions In CoS Rules

To configure CoS match conditions, include the **from** statement at the [edit services cos rule *rule-name* term *term-name*] hierarchy level:

```
from {
  application-sets set-name;
  applications [ application-names ];
  destination-address address;
  destination-prefix-list list-name <except>;
  source-address address;
  source-prefix-list list-name <except>;
}
```

The source address and destination address can be either IPv4 or IPv6. You can use either the source address or the destination address as a match condition, in the same way that you would configure a firewall filter; for more information, see the *JUNOS Policy Framework Configuration Guide*.

Alternatively, you can specify a list of source or destination prefixes by configuring the **prefix-list** statement at the [edit policy-options] hierarchy level and then including either the **destination-prefix-list** or **source-prefix-list** statement in the CoS rule. For an example, see “Examples: Configuring Stateful Firewall Rules” on page 112.

If you omit the **from** term, the router accepts all traffic and the default protocol handlers take effect:

- User Datagram Protocol (UDP), Transmission Control Protocol (TCP), and Internet Control Message Protocol (ICMP) create a bidirectional flow with a predicted reverse flow.
- IP creates a unidirectional flow.

You can also include application protocol definitions you have configured at the [edit applications] hierarchy level; for more information, see “Applications Configuration Guidelines” on page 59.

- To apply one or more specific application protocol definitions, include the `applications` statement at the [edit services cos rule *rule-name* term *term-name* from] hierarchy level.
- To apply one or more sets of application protocol definitions you have defined, include the `application-sets` statement at the [edit services cos rule *rule-name* term *term-name* from] hierarchy level.



NOTE: If you include one of the statements that specifies application protocols, the router derives port and protocol information from the corresponding configuration at the [edit applications] hierarchy level; you cannot specify these properties as match conditions.

Configuring Actions in CoS Rules

To configure CoS actions, include the `then` statement at the [edit services cos rule *rule-name* term *term-name*] hierarchy level:

```
[edit services cos rule rule-name term term-name]
then {
  application-profile profile-name;
  dscp (alias | bits);
  forwarding-class class-name;
  syslog;
  (reflexive | reverse) {
    application-profile profile-name;
    dscp (alias | bits);
    forwarding-class class-name;
    syslog;
  }
}
```

The principal CoS actions are as follows:

- `dscp`—Causes the packet to be marked with the specified DiffServ code point (DSCP) value or alias.
- `forwarding-class`—Causes the packet to be assigned to the specified forwarding class.

For detailed information about DSCP values and forwarding classes, see “Examples: Configuring CoS on Services Interfaces” on page 426 or the *JUNOS Class of Service Configuration Guide*.

You can optionally set the configuration to record information in the system logging facility by including the `syslog` statement at the [edit services cos rule *rule-name* term *term-name* then] hierarchy level. This statement overrides any `syslog` setting included in the service set or interface default configuration.

For information about some additional CoS actions, see the following sections:

- Configuring Application Profiles for Use as CoS Rule Actions on page 424
- Configuring Reflexive and Reverse CoS Rule Actions on page 424

Configuring Application Profiles for Use as CoS Rule Actions

You can optionally define one or more application profiles for inclusion in CoS actions. To configure application profiles, include the `application-profile` statement at the `[edit services cos]` hierarchy level:

```
[edit services cos]
application-profile profile-name {
  sip-text {
    dscp (alias | bits);
    forwarding-class class-name;
  }
  sip-video {
    dscp (alias | bits);
    forwarding-class class-name;
  }
  sip-voice {
    dscp (alias | bits);
    forwarding-class class-name;
  }
}
```

The `application-profile` statement includes three fixed components, `sip-text`, `sip-video`, and `sip-voice`. You can set the appropriate `dscp` and `forwarding-class` values for each component within the application profile.

You can apply the application profile to a CoS configuration by including it at the `[edit services cos rule rule-name term term-name then]` hierarchy level.

Configuring Reflexive and Reverse CoS Rule Actions

CoS services are unidirectional. It might be necessary to specify different treatments for flows in opposite directions.

Regardless of whether a packet matches the input, output or input-output direction, flows in both directions are created. A forward, reverse, or forward-and-reverse CoS action is associated with each flow. Bear in mind that the flow in the opposite direction might end up having a CoS action associated with it that you have not specifically configured.

To control the direction in which service is applied, as distinct from the direction in which the rule match is applied, you can configure the (`reflexive` | `reverse`) statement at the `[edit services cos rule rule-name term term-name then]` hierarchy level:

```
[edit services cos rule rule-name term term-name then]
(reflexive | reverse) {
  application-profile profile-name;
  dscp (alias | bits);
  forwarding-class class-name;
```



```

    syslog;
}

```

The two actions are mutually exclusive:

- **reflexive** causes the equivalent opposing CoS action to be applied to flows in the opposite direction.
- **reverse** allows you to define the CoS behavior for flows in the reverse direction.

If you omit the statement, data flows inherit the CoS behavior of the forward control flow.

Example: Configuring CoS Rules

The following example show a CoS configuration containing two rules, one for input matching on a specified application set and the other for output matching on a specified source address:

```

[edit services]
cos {
  rule my-cos-rule {
    match-direction input-output;
    term term1 {
      from {
        source-address 10.1.3.2/32;
        applications sip;
      }
      then {
        dscp ef;
        syslog;
      }
    }
    term term2 {
      from {
        destination-address 10.2.3.2;
        applications http;
      }
      then {
        dscp af21;
      }
    }
  }
}

```

Configuring CoS Rule Sets

The **rule-set** statement defines a collection of CoS rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then you specify the order of the rules by including the **rule-set** statement at the **[edit services cos]** hierarchy level with a **rule** statement for each rule:

```

rule-set rule-set-name {

```

```

    rule rule-name;
}

```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

Examples: Configuring CoS on Services Interfaces

To make settings consistent across Juniper Networks routers, you configure many CoS settings at the [edit class-of-service] hierarchy level to be used on services interfaces. When you commit this configuration along with what you configure at the [edit services cos] hierarchy level, these properties are applied to the AS or MultiServices PIC.

The following configuration examples at the [edit class-of-service] hierarchy level can be applied on services interfaces. For more information, see the *JUNOS Class of Service Configuration Guide*.



NOTE: The first two configurations, mapping forwarding-class name to forwarding-class ID and mapping forwarding-class name to queue number, are mutually exclusive.

Mapping Forwarding-Class Name to Forwarding-Class ID

Map forwarding-class names to forwarding-class IDs:

```

[edit class-of-service]
forwarding-classes {
  forwarding-class fc0 0;
  forwarding-class fc1 0;
  forwarding-class fc2 1;
  forwarding-class fc3 1;
  forwarding-class fc4 2;
  forwarding-class fc5 2;
  forwarding-class fc6 3;
  forwarding-class fc7 3;
  forwarding-class fc8 4;
  forwarding-class fc9 4;
  forwarding-class fc10 5;
  forwarding-class fc11 5;
  forwarding-class fc12 6;
  forwarding-class fc13 6;
  forwarding-class fc14 7;
  forwarding-class fc15 7;
}

```

Mapping Forwarding-Class Name to Queue Number

Map forwarding-class names to queue numbers:

```

[edit class-of-service]
forwarding-classes {
  queue 0 be;
  queue 1 ef;
}

```

```

queue 2 af;
queue 3 nc;
queue 4 ef1;
queue 5 ef2;
queue 6 af1;
queue 7 nc1;
}

```

Mapping Diffserv Code Point Aliases to DSCP Bits

Map alias names to DSCP bit values. The aliases then can be used instead of the DSCP bits in adaptive services configurations.

```

[edit class-of-service]
code-point-aliases {
  (dscp | dscp-ipv6 | exp | ieee-802.1 | inet-precedence) {
    alias | bits;
  }
}

```

Here is an example:

```

code-point-aliases {
  dscp {
    my1 110001;
    my2 101110;
    be 000001;
    cs7 110000;
  }
}

```


Chapter 21

Summary of Class-of-Service Configuration Statements

The following sections explain each of the class-of-service (CoS) statements. The statements are organized alphabetically.

application-profile

Syntax application-profile *profile-name* {
 sip-text {
 dscp (*alias* | *bits*);
 forwarding-class *class-name*;
 }
 sip-video {
 dscp (*alias* | *bits*);
 forwarding-class *class-name*;
 }
 sip-voice {
 dscp (*alias* | *bits*);
 forwarding-class *class-name*;
 }
 }

Hierarchy Level [edit services cos],
 [edit services cos rule *rule-name* term *term-name* then],
 [edit services cos rule *rule-name* term *term-name* then (reflexive | reverse)]

Release Information Statement introduced in JUNOS Release 8.1.

Description Define a CoS application profile.

Options *profile-name*—Identifier for the application profile.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Application Profiles for Use as CoS Rule Actions” on page 424.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

application-sets

Syntax	<code>applications-sets <i>set-name</i>;</code>
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Define one or more target application sets.
Options	<i>set-name</i> —Name of the target application set.
Usage Guidelines	See “Configuring Match Conditions In CoS Rules” on page 422.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

applications

Syntax	<code>applications [<i>application-name</i>];</code>
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Define one or more applications to which the CoS services apply.
Options	<i>application-name</i> —Name of the target application.
Usage Guidelines	See “Configuring Match Conditions In CoS Rules” on page 422.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address

Syntax	destination-address (<i>address</i> any-unicast) <except>;
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.1. <i>address</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.
Description	Specify the destination address for rule matching.
Options	<i>address</i> —Destination IPv4 or IPv6 address or prefix value.
Usage Guidelines	See “Configuring Match Conditions In CoS Rules” on page 422.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix-list

Syntax	destination-prefix-list <i>list-name</i> <except>;
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the destination prefix list for rule matching. You configure the prefix list by including the <i>prefix-list</i> statement at the [edit <i>policy-options</i>] hierarchy level.
Options	<i>list-name</i> —Destination prefix list. except—(Optional) Exclude the specified prefix list from rule matching.
Usage Guidelines	See “Configuring Match Conditions In CoS Rules” on page 422.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

dscp

Syntax	<code>dscp (<i>alias</i> <i>bits</i>);</code>
Hierarchy Level	[edit services cos application-profile <i>profile-name</i> (sip-text sip-video sip-voice)], [edit services cos rule <i>rule-name</i> term <i>term-name</i> then], [edit services cos rule <i>rule-name</i> term <i>term-name</i> then (reflexive reverse)]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Define the Differentiated Services code point (DSCP) mapping that is applied to the packets.
Options	<i>alias</i> —Name assigned to a set of CoS markers. <i>bits</i> —Mapping value in the packet header.
Usage Guidelines	See “Configuring Actions in CoS Rules” on page 423.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

forwarding-class

Syntax	<code>forwarding-class <i>class-name</i>;</code>
Hierarchy Level	[edit services cos application-profile <i>profile-name</i> (sip-text sip-video sip-voice)], [edit services cos rule <i>rule-name</i> term <i>term-name</i> then], [edit services cos rule <i>rule-name</i> term <i>term-name</i> then (reflexive reverse)]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Define the forwarding class to which packets are assigned.
Options	<i>class-name</i> —Name of the target application.
Usage Guidelines	See “Configuring Actions in CoS Rules” on page 423.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

from

Syntax	<pre> from { application-sets <i>set-name</i>; applications [<i>application-names</i>]; destination-address <i>address</i>; destination-prefix-list <i>list-name</i> <except>; source-address <i>address</i>; source-prefix-list <i>list-name</i> <except>; } </pre>
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i>]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Specify input conditions for a CoS term.
Options	<p>For information on match conditions, see the description of firewall filter match conditions in the <i>JUNOS Policy Framework Configuration Guide</i>.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring CoS Rules” on page 420.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

match-direction

Syntax	match-direction (input output input-output);
Hierarchy Level	[edit services cos rule <i>rule-name</i>]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Specify the direction in which the rule match is applied.
Options	<p>input—Apply the rule match on the input side of the interface.</p> <p>output—Apply the rule match on the output side of the interface.</p> <p>input-output—Apply the rule match bidirectionally.</p>
Usage Guidelines	See “Configuring CoS Rules” on page 420.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

(reflexive | reverse)

Syntax (reflexive | reverse) {
 application-profile *profile-name*;
 dscp (*alias* | *bits*);
 forwarding-class *class-name*;
 syslog;
 }

Hierarchy Level [edit services cos rule *rule-name* term *term-name* then]

Release Information Statement introduced in JUNOS Release 8.1.

Description reflexive—Applies the equivalent opposing CoS action to flows in the opposite direction.

reverse—Allows you to define CoS behavior for flows in the reverse direction.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Reflexive and Reverse CoS Rule Actions” on page 424.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

rule

Syntax

```
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address address;
      destination-prefix-list list-name <except>;
      source-address address;
      source-prefix-list list-name <except>;
    }
    then {
      application-profile profile-name;
      dscp (alias | bits);
      forwarding-class class-name;
      syslog;
      (reflexive | reverse) {
        application-profile profile-name;
        dscp (alias | bits);
        forwarding-class class-name;
        syslog;
      }
    }
  }
}
```

Hierarchy Level [edit services cos],
[edit services cos rule-set *rule-set-name*]

Release Information Statement introduced in JUNOS Release 8.1.

Description Specify the rule the router uses when applying this service.

Options *rule-name*—Identifier for the collection of terms that constitute this rule.

The remaining statements are explained separately.

Usage Guidelines See “Configuring CoS Rules” on page 420.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rule-set

Syntax	<code>rule-set <i>rule-set-name</i> { [rule <i>rule-name</i>]; }</code>
Hierarchy Level	[edit services cos]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Specify the rule set the router uses when applying this service.
Options	<i>rule-set-name</i> —Identifier for the collection of rules that constitute this rule set.
Usage Guidelines	See “Configuring CoS Rule Sets” on page 425.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	<code>services cos { ... }</code>
Hierarchy Level	[edit]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Define the service rules to be applied to traffic.
Options	<i>cos</i> —Identifier for the class-of-service set of rules statements.
Usage Guidelines	See “Class-of-Service Configuration Guidelines” on page 419.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

sip-text

Syntax	<pre>sip-text { dscp (<i>alias</i> <i>bits</i>); forwarding-class <i>class-name</i>; }</pre>
Hierarchy Level	[edit services cos application-profile <i>profile-name</i>]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	<p>Enable a predefined application profile for handling text data packets.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Application Profiles for Use as CoS Rule Actions” on page 424.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

sip-video

Syntax	<pre>sip-video { dscp (<i>alias</i> <i>bits</i>); forwarding-class <i>class-name</i>; }</pre>
Hierarchy Level	[edit services cos application-profile <i>profile-name</i>]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	<p>Enable a predefined application profile for handling video data packets.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Application Profiles for Use as CoS Rule Actions” on page 424.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

sip-voice

Syntax	<pre>sip-voice { dscp (<i>alias</i> <i>bits</i>); forwarding-class <i>class-name</i>; }</pre>
Hierarchy Level	[edit services cos application-profile <i>profile-name</i>]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	<p>Enable a predefined application profile for handling voice data packets.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Application Profiles for Use as CoS Rule Actions” on page 424.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

source-address

Syntax	source-address <i>address</i> ;
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	<p>Statement introduced in JUNOS Release 8.1.</p> <p><i>address</i> option enhanced to support IPv4 and IPv6 addresses in JUNOS Release 8.5.</p>
Description	Source address for rule matching.
Options	<i>address</i> —Source IPv4 or IPv6 address or prefix value.
Usage Guidelines	See “Configuring Match Conditions In CoS Rules” on page 422.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

source-prefix-list

Syntax	source-prefix-list <i>list-name</i> <except>;
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	Specify the source prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Destination prefix list. except—(Optional) Exclude the specified prefix list from rule matching.
Usage Guidelines	See “Configuring Match Conditions In CoS Rules” on page 422.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

syslog

Syntax	syslog;
Hierarchy Level	[edit services cos rule <i>rule-name</i> term <i>term-name</i> then], [edit services cos rule <i>rule-name</i> term <i>term-name</i> then (reflexive reverse)]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Enable system logging. The system log information from the Adaptive Services or MultiServices PIC is passed to the kernel for logging in the <i>/var/log</i> directory. This setting overrides any syslog statement setting included in the service set or interface default configuration.
Usage Guidelines	See “Configuring Actions in CoS Rules” on page 423.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

term

Syntax

```
term term-name {
  from {
    application-sets set-name;
    applications [ application-names ];
    destination-address address;
    destination-prefix-list list-name <except>;
    source-address address;
    source-prefix-list list-name <except>;
  }
  then {
    application-profile profile-name;
    dscp (alias | bits);
    forwarding-class class-name;
    syslog;
    (reflexive | reverse) {
      application-profile profile-name;
      dscp (alias | bits);
      forwarding-class class-name;
      syslog;
    }
  }
}
```

Hierarchy Level [edit services cos rule *rule-name*]

Release Information Statement introduced in JUNOS Release 8.1.

Description Define the CoS term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Usage Guidelines See “Configuring CoS Rules” on page 420.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

then

Syntax then {
 application-profile *profile-name*;
 dscp (*alias* | *bits*);
 forwarding-class *class-name*;
 syslog;
 (reflexive | reverse) {
 application-profile *profile-name*;
 dscp (*alias* | *bits*);
 forwarding-class *class-name*;
 syslog;
 }
 }

Hierarchy Level [edit services cos rule *rule-name* term *term-name*]

Release Information Statement introduced in JUNOS Release 8.1.

Description Define the CoS term actions.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Actions in CoS Rules” on page 423.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Policy Framework Configuration Guide*

Chapter 22

Service Set Configuration Guidelines

A *service set* is a collection of services to be performed by an Adaptive Services (AS) or MultiServices PIC. To configure service sets, include the following statements at the [edit services] hierarchy level:

```
[edit services]
service-set service-set-name {
  (ids-rules rule-names | ids-rule-sets rule-set-name);
  (ipsec-vpn-rules rule-names | ipsec-vpn-rule-sets rule-set-name);
  (nat-rules rule-names | nat-rule-sets rule-set-name);
  (pgcp-rules rule-names | pgcp-rule-sets rule-set-name);
  (stateful-firewall-rules rule-names | stateful-firewall-rule-sets rule-set-name);
  allow-multicast;
  extension-service service-name {
    provider-specific rules;
  }
  interface-service {
    service-interface interface-name;
  }
  ipsec-vpn-options {
    ike-access-profile profile-name;
    local-gateway address;
    trusted-ca [ ca-profile-names ];
  }
  max-flows number;
  next-hop-service {
    inside-service-interface interface-name.unit-number;
    outside-service-interface interface-name.unit-number;
    service-interface-pool name;
  }
  syslog {
    host hostname {
      services severity-level;
      facility-override facility-name;
      log-prefix prefix-value;
    }
  }
}
adaptive-services-pics {
  traceoptions {
    file filename <files number> <match regex> <size size> <(world-readable |
      no-world-readable)>;
    flag flag;
  }
}
```

```

}
logging {
  traceoptions {
    file filename <files number> <match regex> <size size> <(world-readable |
      no-world-readable)>;
    flag flag;
  }
}

```

This chapter contains the following sections:

- Configuring Service Sets to be Applied to Services Interfaces on page 444
- Configuring Service Rules on page 448
- Configuring IPsec Service Sets on page 448
- Configuring Service Set Limitations on page 451
- Configuring System Logging for Service Sets on page 451
- Enabling Services PICs to Accept Multicast Traffic on page 453
- Tracing Services PIC Operations on page 453
- Example: Configuring Service Sets on page 456

Configuring Service Sets to be Applied to Services Interfaces

You configure a services interface to specify the adaptive services interface on which the service is to be performed. Services interfaces are used with either of the service set types described in the following sections.

- Configuring Interface Service Sets on page 444
- Configuring Next-Hop Service Sets on page 445
- Determining Traffic Direction on page 446

Configuring Interface Service Sets

An interface service set is used as an action modifier across an entire interface. To configure the services interface, include the **interface-service** statement at the [edit services service-set *service-set-name*] hierarchy level:

```

[edit services service-set service-set-name]
interface-service {
  service-interface interface-name;
}

```

Only the device name is needed, because the router software manages logical unit numbers automatically. The services interface must be an adaptive services interface for which you have configured unit 0 family inet at the [edit interfaces *interface-name*] hierarchy level.

When you have defined and grouped the service rules by configuring the service-set definition, you can apply services to one or more interfaces installed on the router. When you apply the service set to an interface, it automatically ensures that packets are directed to the PIC.

To associate a defined service set with an interface, include a **service-set** statement with the **input** or **output** statement at the [edit interfaces *interface-name* unit *logical-unit-number* family inet service] hierarchy level:

```
[edit interfaces interface-name unit logical-unit-number family inet service]
input {
  service-set service-set-name <service-filter filter-name>;
  post-service-filter filter-name;
}
output {
  service-set service-set-name <service-filter filter-name>;
}
```

If a packet is entering the interface, the match direction is **input**. If a packet is leaving the interface, the match direction is **output**. The service set retains the input interface information even after services are applied, so that functions such as filter-class forwarding and destination class usage (DCU) that depend on input interface information continue to work.

You configure the same service set on the input and output sides of the interface. You can optionally include filters associated with each service set to refine the target and additionally process the traffic. If you include the **service-set** statement without a **service-filter** definition, the router software assumes the match condition is true and selects the service set for processing automatically.

You can include more than one service set definition on each side of the interface. If you include multiple service sets, the router software evaluates them in the order in which they appear in the configuration. The system executes the first service set for which it finds a match in the service filter and ignores the subsequent definitions. A maximum of six service sets can be applied to an interface. When you apply multiple service sets to an interface, you must also configure and apply a service filter to the interface.

An additional statement allows you to specify a filter for processing the traffic after the input service set is executed. To configure this type of filter, include the **post-service-filter** statement at the [edit interfaces *interface-name* unit *logical-unit-number* family inet service input] hierarchy level:

```
post-service-filter filter-name;
```

For an example, see “Example: Configuring Service Sets” on page 456.

Configuring Next-Hop Service Sets

A next-hop service set is a route-based method of applying a particular service. Only packets destined for a specific next hop are serviced by the creation of explicit static routes. This configuration is useful when services need to be applied to an entire virtual private network (VPN) routing and forwarding (VRF) table, or when routing decisions determine that services need to be performed.

When a next-hop service is configured, the AS or MultiServices PIC is considered to be a two-legged module with one leg configured to be the inside interface (inside the network) and the other configured as the outside interface (outside the network).

To configure the domain, include the **service-domain** statement at the **[edit interfaces *interface-name* unit *logical-unit-number*]** hierarchy level:

```
service-domain (inside | outside);
```

The **service-domain** setting must match the configuration for the next-hop service inside and outside interfaces. To configure the inside and outside interfaces, include the **next-hop-service** statement at the **[edit services *service-set* *service-set-name*]** hierarchy level. The interfaces you specify must be logical interfaces on the same AS PIC. You cannot configure **unit 0** for this purpose, and the logical interface you choose must not be used by another service set.

```
next-hop-service {
  inside-service-interface interface-name.unit-number;
  outside-service-interface interface-name.unit-number;
}
```

Traffic on which the service is applied is forced to the inside interface using a static route. For example:

```
routing-options {
  static {
    route 10.1.2.3 next-hop sp-1/1/0.1;
  }
}
```

After the service is applied, traffic exits by way of the outside interface. A lookup is then performed in the Packet Forwarding Engine (PFE) to send the packet out of the AS or MultiServices PIC.

The reverse traffic enters the outside interface, is serviced, and sent to the inside interface. The inside interface forwards the traffic out of the AS or MultiServices PIC.

Determining Traffic Direction

When you configure next-hop service sets, the AS PIC functions as a two-part interface, in which one part is the *inside* interface and the other part is the *outside* interface. The following sequence of actions takes place:

1. To associate the two parts with logical interfaces, you configure two logical interfaces with the **service-domain** statement, one with the **inside** value and one with the **outside** value, to mark them as either an inside or outside service interface.
2. The router forwards the traffic to be serviced to the inside interface, using the next-hop lookup table.
3. After the service is applied, the traffic exits from the outside interface. A route lookup is then performed on the packets to be sent out of the router.
4. When the reverse traffic returns on the outside interface, the applied service is undone; for example, IPsec traffic is decrypted or NAT addresses are unmasked. The serviced packets then emerge on the inside interface, the router performs a route lookup, and the traffic exits the router.

A service rule's match direction, whether input, output, or input/output, is applied with respect to the traffic flow through the AS PIC, not through a specific inside or outside interface.

When a packet is sent to an AS PIC, packet direction information is carried along with it. This is true for both interface style and next-hop style service sets.

Interface Style Service Sets

Packet direction is determined by whether a packet is entering or leaving any Packet Forwarding Engine interface (with respect to the forwarding plane) on which the **interface-service** statement is applied. This is similar to the input and output direction for stateless firewall filters.

The match direction can also depend on the network topology. For example, you might route all the external traffic through one interface that is used to protect the other interfaces on the router, and configure various services on this interface specifically. Alternatively, you might use one interface for priority traffic and configure special services on it, but not care about protecting traffic on the other interfaces.

Next-Hop Style Service Sets

Packet direction is determined by the AS PIC interface used to route packets to the AS PIC. If you use the **inside-interface** statement to route traffic, then the packet direction is **input**. If you use the **outside-interface** statement to direct packets to the AS PIC, then the packet direction is **output**.

The interface to which you apply the service sets affects the match direction. For example, apply the following configuration:

```
sp-1/1/0 unit 1 service-domain inside;
sp-1/1/0 unit 2 service-domain outside;
```

If you configure **match-direction input**, you include the following statements:

```
[edit]
services service-set test1 next-hop-service inside-service-interface sp-1/0/0.1;
services service-set test1 next-hop-service outside-service-interface sp-1/0/0.2;
services ipsec-vpn rule test-ipsec-rule match-direction input;
routing-options static route 10.0.0.0/24 next-hop sp-1/1/0.1;
```

If you configure **match-direction output**, you include the following statements:

```
[edit]
services service-set test2 next-hop-service inside-service-interface sp-1/0/0.1;
services service-set test2 next-hop-service outside-service-interface sp-1/0/0.2;
services ipsec-vpn rule test-ipsec-rule match-direction output;
routing-options static route 10.0.0.0/24 next-hop sp-1/1/0.2;
```

The essential difference between the two configurations is the change in the match direction and the static routes' next hop, pointing to either the AS PIC's inside or outside interface.

Configuring Service Rules

You specify the collection of rules and rule sets that constitute the service set. The router performs rule sets in the order in which they appear in the configuration. You can include only one rule set for each service type. You configure the rule names and content for each service type at the `[edit services name]` hierarchy level for each type:

- You configure intrusion detection service (IDS) rules at the `[edit services ids]` hierarchy level; for more information, see “Intrusion Detection Service Configuration Guidelines” on page 175.
- You configure IP Security (IPsec) rules at the `[edit services ipsec-vpn]` hierarchy level; for more information, see “IPsec Services Configuration Guidelines” on page 209.
- You configure Network Address Translation (NAT) rules at the `[edit services nat]` hierarchy level; for more information, see “Network Address Translation Services Configuration Guidelines” on page 129.
- You configure Packet Gateway Control Protocol (PGCP) rules at the `[edit services pgcp]` hierarchy level; for more information, see “PGCP Configuration Guidelines for the BGF Feature” on page 507.
- You configure stateful firewall rules at the `[edit services stateful-firewall]` hierarchy level; for more information, see “Stateful Firewall Services Configuration Guidelines” on page 107.

To configure the rules and rule sets that constitute a service set, include the following statements at the `[edit services service-set service-set-name]` hierarchy level:

```
([ ids-rules rule-names ] | ids-rule-sets rule-set-name);
([ ipsec-vpn-rules rule-names ] | ipsec-vpn-rule-sets rule-set-name);
([ nat-rules rule-names ] | nat-rule-sets rule-set-name);
([ pgcp-rules rule-names ] | pgcp-rule-sets rule-set-name);
([ stateful-firewall-rules rule-names ] | stateful-firewall-rule-sets rule-set-name);
```

For each service type, you can include one or more individual rules, or one rule set.

If you configure a service set with IPsec rules, it must not contain rules for any other services. You can, however, configure another service set containing rules for the other services and apply both service sets to the same interface.

Configuring IPsec Service Sets

IPsec service sets require additional specifications that you configure at the `[edit services service-set service-set-name ipsec-vpn-options]` hierarchy level:

```
ike-access-profile profile-name;
local-gateway address;
trusted-ca [ ca-profile-names ];
```


Configuration of these statements is described in the following sections:

- Configuring the Local Gateway Address for IPsec Service Sets on page 449
- Configuring IKE Access Profiles for IPsec Service Sets on page 450
- Configuring Certification Authorities for IPsec Service Sets on page 450

Configuring the Local Gateway Address for IPsec Service Sets

If you configure an IPsec service set, you must also configure a local IPv4 or IPv6 address by including the `local-gateway` statement:

- If the Internet Key Exchange (IKE) gateway IP address is in `inet.0` (the default situation), you configure the following statement:

```
local-gateway address;
```

- If the IKE gateway IP address is in a VPN routing and forwarding (VRF) instance, you configure the following statement:

```
local-gateway address routing-instance instance-name;
```

You can configure all the link-type tunnels that share the same local gateway address in a single next-hop-style service set. The value you specify for the `inside-service-interface` statement at the `[edit services service-set service-set-name]` hierarchy level should match the `ipsec-inside-interface` value, which you configure at the `[edit services ipsec-vpn rule rule-name term term-name from]` hierarchy level. For more information about IPsec configuration, see “Configuring IPsec Rules” on page 231.

IKE Addresses in VRF Instances

You can configure Internet Key Exchange (IKE) gateway IP addresses that are present in a VPN routing and forwarding (VRF) instance as long as the peer is reachable through the VRF instance.

For next-hop service sets, the key management process (kmd) places the IKE packets in the routing instance that contains the `outside-service-interface` value you specify, as in this example:

```
routing-instances vrf-nxthop {
  instance-type vrf;
  interface sp-1/1/0.2;
  ...
}
services service-set service-set-1 {
  next-hop-service {
    inside-service-interface sp-1/1/0.1;
    outside-service-interface sp-1/1/0.2;
  }
  ...
}
```

For interface service sets, the **service-interface** statement determines the VRF, as in this example:

```
routing-instances vrf-intf {
  instance-type vrf;
  interface sp-1/1/0.3;
  interface ge-1/2/0.1; # interface on which service set is applied
  ...
}
services service-set service-set-2 {
  interface-service {
    service-interface sp-1/1/0.3;
  }
  ...
}
```

Configuring IKE Access Profiles for IPsec Service Sets

For dynamic endpoint tunneling only, you need to reference the IKE access profile configured at the [edit access] hierarchy level. To do this, include the **ike-access-profile** statement:

```
ike-access-profile profile-name;
```

The **ike-access-profile** statement must reference the same name as the **profile** statement you configured for IKE access at the [edit access] hierarchy level. You can reference only one access profile in each service set. This profile is used to negotiate IKE and IPsec security associations with dynamic peers only.



NOTE: If you configure an IKE access profile in a service set, no other service set can share the same **local-gateway** address.

Also, you must configure a separate service set for each VRF. All interfaces referenced by the **ipsec-inside-interface** statement within a service set must belong to the same VRF.

Configuring Certification Authorities for IPsec Service Sets

You can specify one or more trusted certification authorities by including the **trusted-ca** statement:

```
trusted-ca [ ca-profile-names ];
```

When you configure public key infrastructure (PKI) digital certificates in the IPsec configuration, each service set can have its own set of trusted certification authorities. The names you specify for the **trusted-ca** statement must match profiles configured at the [edit security pki] hierarchy level; for more information, see the *JUNOS System Basics Configuration Guide*. For more information about IPsec digital certificate configuration, see “Configuring IPsec Rules” on page 231.

Configuring Service Set Limitations

You can set the following limitations on service set capacity:

- You can limit the maximum number of flows allowed per service set. To configure the maximum value, include the **max-flows** statement at the **[edit services service-set service-set-name]** hierarchy level:

```
max-flows number;
```

The **max-flows** statement permits you to assign a single flow limit value. For IDS service sets only, you can specify various types of flow limits with a finer degree of control. For more information, see the description of the **session-limit** statement in “Intrusion Detection Service Configuration Guidelines” on page 175.

- You can limit the maximum segment size (MSS) allowed by the Transmission Control Protocol (TCP). To configure the maximum value, include the **tcp-mss** statement at the **[edit services service-set service-set-name]** hierarchy level:

```
tcp-mss number;
```

The TCP protocol negotiates an MSS value during session connection establishment between two peers. The MSS value negotiated is primarily based on the MTU of the interfaces to which the communicating peers are directly connected to. However in the network, due to variation in link MTU on the path taken by the TCP packets, some packets which are still well within the MSS value may be fragmented when the concerned packet's size exceeds the link's MTU.

If the router receives a TCP packet with the SYN bit and MSS option set and the MSS option specified in the packet is larger than the MSS value specified by the **tcp-mss** statement, the router replaces the MSS value in the packet with the lower value specified by the **tcp-mss** statement. The range for the **tcp-mss mss-value** parameter is from **536** through **65535**.

To view statistics of SYN packets received and SYN packets whose MSS value, is modified, issue the **show services service-sets statistics tcp-mss operational** mode command. For more information on this topic, see the *JUNOS System Basics Configuration Guide*.

Configuring System Logging for Service Sets

You specify properties that control how system log messages are generated for the service set. These values override the values configured at the **[edit interfaces interface-name services-options]** hierarchy level.

To configure service-set-specific system logging values, include the **syslog** statement at the **[edit services service-set service-set-name]** hierarchy level:

```
syslog {
  host hostname {
    services severity-level;
    facility-override facility-name;
```

```

        log-prefix prefix-value;
    }
}

```

Configure the **host** statement with a hostname that specifies the system log target server. The hostname **local** directs system log messages to the Routing Engine. The hostname must be included in **inet.0**. You can specify only one system log host.

Table 14 on page 452 lists the severity levels that you can specify in configuration statements at the [edit **services service-set service-set-name syslog host hostname**] hierarchy level. The levels from **emergency** through **info** are in order from highest severity (greatest effect on functioning) to lowest.

Table 14: System Log Message Severity Levels

Severity Level	Description
any	Includes all severity levels
emergency	System panic or other condition that causes the routing platform to stop functioning
alert	Conditions that require immediate correction, such as a corrupted system database
critical	Critical conditions, such as hard drive errors
error	Error conditions that generally have less serious consequences than errors in the emergency, alert, and critical levels
warning	Conditions that warrant monitoring
notice	Conditions that are not errors but might warrant special handling
info	Events or nonerror conditions of interest

We recommend setting the system logging severity level to **error** during normal operation. To monitor PIC resource usage, set the level to **warning**. To gather information about an intrusion attack when an intrusion detection system error is detected, set the level to **notice** for a specific service set. To debug a configuration or log NAT functionality, set the level to **info**.

For more information about system log messages, see the *JUNOS System Log Messages Reference*.

To use one particular facility code for all logging to the specified system log host, include the **facility-override** statement at the [edit **services service-set service-set-name syslog host hostname**] hierarchy level:

```

    facility-override facility-name;

```

The supported facilities are: **authorization**, **daemon**, **ftp**, **kernel**, **user**, and **local0** through **local7**.

To specify a text prefix for all logging to this system log host, include the `log-prefix` statement at the `[edit services service-set service-set-name syslog host hostname]` hierarchy level:

```
log-prefix prefix-value;
```

Enabling Services PICs to Accept Multicast Traffic

To allow multicast traffic to be sent to the Adaptive Services or MultiServices PIC, include the `allow-multicast` statement at the `[edit services service-set service-set-name]` hierarchy level. If this statement is not included, multicast traffic is dropped by default. This statement applies only to multicast traffic using a next-hop service set; interface service set configuration is not supported. Only unidirectional flows are created for multicast packets. For a configuration example, see “Example: Configuring NAT for Multicast Traffic” on page 145.

Tracing Services PIC Operations

Tracing operations track all adaptive services operations and record them in a log file. The logged error descriptions provide detailed information to help you solve problems faster.

By default, no events are traced. If you include the `traceoptions` statement at the `[edit services adaptive-services-pics]` or `[edit services logging]` hierarchy level, the default tracing behavior is the following:

- Important events are logged in a file called `serviced` located in the `/var/log` directory.
- When the file `serviced` reaches 128 kilobytes (KB), it is renamed `serviced.0`, then `serviced.1`, and so on, until there are three trace files. Then the oldest trace file (`serviced.2`) is overwritten. (For more information about how log files are created, see the *JUNOS System Log Messages Reference*.)
- Log files can be accessed only by the user who configures the tracing operation.

You cannot change the directory (`/var/log`) in which trace files are located. However, you can customize the other trace file settings by including the following statements:

```
file filename <files number> <match regular-expression> <size size> <world-readable |
no-world-readable>;
flag {
  all;
  command-queued;
  config;
  handshake;
  init;
  interfaces;
  mib;
  removed-client;
  show;
}
```

You include these statements at the [edit services adaptive-services-pics traceoptions] or [edit services logging traceoptions] hierarchy level.

These statements are described in the following sections:

- Configuring the Adaptive Services Log Filename on page 454
- Configuring the Number and Size of Adaptive Services Log Files on page 454
- Configuring Access to the Log File on page 454
- Configuring a Regular Expression for Lines to Be Logged on page 455
- Configuring the Trace Operations on page 455

Configuring the Adaptive Services Log Filename

By default, the name of the file that records trace output is **serviced**. You can specify a different name by including the **file** statement at the [edit services adaptive-services-pics traceoptions] or [edit services logging traceoptions] hierarchy level:

```
file filename;
```

Configuring the Number and Size of Adaptive Services Log Files

By default, when the trace file reaches 128 kilobytes (KB) in size, it is renamed **filename.0**, then **filename.1**, and so on, until there are three trace files. Then the oldest trace file (**filename.2**) is overwritten.

You can configure the limits on the number and size of trace files by including the following statements at the [edit services adaptive-services-pics traceoptions] or [edit services logging traceoptions] hierarchy level:

```
file <filename> files number size size;
```

For example, set the maximum file size to 2 MB, and the maximum number of files to 20. When the file that receives the output of the tracing operation (**filename**) reaches 2 MB, **filename** is renamed **filename.0**, and a new file called **filename** is created. When the new **filename** reaches 2 MB, **filename.0** is renamed **filename.1** and **filename** is renamed **filename.0**. This process repeats until there are 20 trace files. Then the oldest file (**filename.19**) is overwritten by the newest file (**filename.0**).

The number of files can be from 2 through 1000 files. The file size of each file can be from 10 KB through 1 gigabyte (GB).

Configuring Access to the Log File

By default, log files can be accessed only by the user who configures the tracing operation.

To specify that any user can read all log files, include the **file world-readable** statement at the [edit services adaptive-services-pics traceoptions] or [edit services logging traceoptions] hierarchy level:

```
file <filename> world-readable;
```

To explicitly set the default behavior, include the `file no-world-readable` statement at the `[edit services adaptive-services-pics traceoptions]` or `[edit services logging traceoptions]` hierarchy level:

```
file <filename> no-world-readable;
```

Configuring a Regular Expression for Lines to Be Logged

By default, the trace operation output includes all lines relevant to the logged events.

You can refine the output by including the `match` statement at the `[edit services adaptive-services-pics traceoptions file filename]` or `[edit services logging traceoptions]` hierarchy level and specifying a regular expression (regex) to be matched:

```
file <filename> match regular-expression;
```

Configuring the Trace Operations

By default, if the `traceoptions` configuration is present, only important events are logged. You can configure the trace operations to be logged by including the following statements at the `[edit services adaptive-services-pics traceoptions]` or `[edit services logging traceoptions]` hierarchy level:

```
flag {
  all;
  configuration;
  routing-protocol;
  routing-socket;
  snmp;
}
```

Table 15 on page 455 describes the meaning of the adaptive services tracing flags.

Table 15: Adaptive Services Tracing Flags

Flag	Description	Default Setting
all	Trace all operations.	Off
command-queued	Trace command enqueue events.	Off
config	Log reading of the configuration at the <code>[edit services]</code> hierarchy level.	Off
handshake	Trace handshake events.	Off
init	Trace initialization events.	Off
interfaces	Trace interface events.	Off
mib	Trace GGSN SNMP MIB events.	Off

Table 15: Adaptive Services Tracing Flags *(continued)*

Flag	Description	Default Setting
removed-client	Trace client cleanup events.	Off
show	Trace CLI command servicing.	Off

To display the end of the log, issue the `show log serviced | last` operational mode command:

```
[edit]
user@host# run show log serviced | last
```

Example: Configuring Service Sets

Apply two service sets, `my-input-service-set` and `my-output-service-set`, on an interface-wide basis. All traffic has `my-input-service-set` applied to it. After the service set is applied, additional filtering is done using `my_post_service_input_filter`.

```
[edit interfaces fe-0/1/0]
unit 0 {
  family inet {
    service {
      input {
        service-set my-input-service-set;
        post-service-filter my_post_service_input_filter;
      }
      output {
        service-set my-output-service-set;
      }
    }
  }
}
```


Chapter 23

Summary of Service Set Configuration Statements

The following sections explain each of the service set configuration statements. The statements are organized alphabetically.

adaptive-services-pics

Syntax adaptive-services-pics {
 traceoptions {
 file *filename* <files *number*> <match *regular-expression*> <size *size*> <world-readable |
 no-world-readable>;
 flag *flag*;
 no-remote-trace;
 }
}

Hierarchy Level [edit services]

Release Information Statement introduced before JUNOS Release 7.4. The `file` option was added in Release 8.0.

Description Define global services properties.

Options The remaining statement is explained separately.

Usage Guidelines See “Tracing Services PIC Operations” on page 453.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

allow-multicast

Syntax	allow-multicast;
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Allow multicast traffic to be sent to the Adaptive Services or MultiServices PIC.
Usage Guidelines	See “Enabling Services PICs to Accept Multicast Traffic” on page 453.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

facility-override

Syntax	facility-override <i>facility-name</i> ;
Hierarchy Level	[edit services service-set <i>service-set-name</i> syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Override the default facility for system log reporting.
Options	<i>facility-name</i> —Name of the facility that overrides the default assignment. Valid entries are: <ul style="list-style-type: none"> authorization daemon ftp kernel local0 through local7 user
Usage Guidelines	See “Configuring System Logging for Service Sets” on page 451.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

host

Syntax	<pre>host <i>hostname</i> { facility-override <i>facility-name</i>; interface-service <i>prefix-value</i>; services <i>severity-level</i>; }</pre>
Hierarchy Level	[edit services service-set <i>service-set-name</i> syslog]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the hostname for the system logging utility.
Options	<p><i>hostname</i>—Name of the system logging utility host machine.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring System Logging for Service Sets” on page 451.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

ids-rules

Syntax	(ids-rules <i>rule-name</i> ids-rule-sets <i>rule-set-name</i>);
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the intrusion detection service (IDS) rules or rule set included in this service set. You can configure multiple rules, but only one rule set for each service.
Options	<p><i>rule-name</i>—Identifier for the collection of terms that constitute this rule.</p> <p><i>rule-set-name</i>—Identifier for the set of rules to be included.</p>
Usage Guidelines	See “Configuring Service Rules” on page 448.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

ike-access-profile

Syntax	<code>ike-access-profile <i>profile-name</i>;</code>
Hierarchy Level	<code>[edit services service-set <i>service-set-name</i> ipsec-vpn-options]</code>
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Define the access profile for the IPsec traffic on dynamic tunnels.
Options	<i>profile-name</i> —Identifier for access profile, which must match the name configured at the <code>[edit access profile <i>name</i> client * ike]</code> hierarchy level.
Usage Guidelines	See “Configuring Dynamic Endpoints for IPsec Tunnels” on page 237 or “Configuring IPsec Service Sets” on page 448.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

interface-service

Syntax	<code>interface-service { <i>service-interface name</i>; }</code>
Hierarchy Level	<code>[edit services service-set <i>service-set-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the device name for the interface service Physical Interface Card (PIC).
Options	<i>service-interface name</i> —Name of the service device associated with the interface-wide service set.
Usage Guidelines	See “Configuring Service Sets to be Applied to Services Interfaces” on page 444.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ipsec-vpn-options

Syntax	ipsec-vpn-options { ike-access-profile <i>profile-name</i> ; local-gateway <i>address</i> ; trusted-ca [<i>ca-profile-names</i>]; }
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify IP Security (IPsec) service options.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring Service Rules” on page 448.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ipsec-vpn-rules

Syntax	(ipsec-vpn-rules <i>rule-name</i> ipsec-vpn-rule-sets <i>rule-set-name</i>);
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the IPsec rules or rule set included in this service set. You can configure multiple rules, but only one rule set for each service.
Options	<i>rule-name</i> —Identifier for the collection of terms that constitute this rule. <i>rule-set-name</i> —Identifier for the set of rules to be included.
Usage Guidelines	See “Configuring Service Rules” on page 448.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

local-gateway

Syntax	<code>local-gateway <i>address</i>;</code>
Hierarchy Level	<code>[edit services service-set <i>service-set-name</i> ipsec-vpn-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the local IPv4 or IPv6 address for the IPsec traffic.
Options	<i>address</i> —Local address.
Usage Guidelines	See “Configuring Service Rules” on page 448.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.

log-prefix

Syntax	<code>log-prefix <i>prefix-value</i>;</code>
Hierarchy Level	<code>[edit services service-set <i>service-set-name</i> syslog host <i>hostname</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the system logging prefix value.
Options	<i>prefix-value</i> —System logging prefix value.
Usage Guidelines	See “Configuring System Logging for Service Sets” on page 451.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

logging

Syntax	<pre>logging { traceoptions { file <i>filename</i> <files <i>number</i>> <match <i>regular-expression</i>> <size <i>size</i>> <world-readable no-world-readable>; flag <i>flag</i>; no-remote-trace; } }</pre>
Hierarchy Level	[edit services]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Define global services properties.
Options	The remaining statement is explained separately.
Usage Guidelines	See “Tracing Services PIC Operations” on page 453.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

max-flows

Syntax	<code>max-flows <i>number</i>;</code>
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Maximum number of flows allowed for the service set.
Options	<i>number</i> —Maximum number of flows.
Usage Guidelines	See “Configuring Service Set Limitations” on page 451.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

nat-rules

Syntax	(nat-rules <i>rule-name</i> nat-rule-sets <i>rule-set-name</i>);
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the Network Address Translation (NAT) rules or rule set included in this service set. You can configure multiple rules, but only one rule set for each service.
Options	<i>rule-name</i> —Identifier for the collection of terms that constitute this rule. <i>rule-set-name</i> —Identifier for the set of rules to be included.
Usage Guidelines	See “Configuring Service Rules” on page 448.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

next-hop-service

Syntax	<pre> next-hop-service { inside-service-interface <i>interface-name.unit-number</i>; outside-service-interface <i>interface-name.unit-number</i>; service-interface-pool <i>name</i>; } </pre>
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4. service-interface-pool option added in JUNOS Release 9.3.
Description	Specify interface names or a service interface pool for the forwarding next-hop service set. You cannot specify both a service interface pool and an inside or outside interface.
Options	<p>inside-service-interface <i>interface-name.unit-number</i>—Name and logical unit number of the service interface associated with the service set applied inside the network.</p> <p>outside-service-interface <i>interface-name.unit-number</i>—Name and logical unit number of the service interface associated with the service set applied outside the network.</p> <p>service-interface-pool <i>name</i>—Name of the pool of logical interfaces configured at the [edit services service-interface-pools pool <i>pool-name</i>] hierarchy level. You can configure a service interface pool only if the service set has a PGCP rule configured. The service set cannot contain any other type of rule.</p>
Usage Guidelines	See “Configuring Service Sets to be Applied to Services Interfaces” on page 444.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

pgcp-rules

Syntax	(pgcp-rules <i>rule-name</i> pgcp-rules-sets <i>rule-set-name</i>);
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Specify the Packet Gateway Control Protocol (PGCP) rules or rule set included in this service set. You can configure multiple rules but only one rule set for each service.
Options	<i>rule-name</i> —Identifier for the collection of terms that constitute this rule. <i>rule-set-name</i> —Identifier for the set of rules to be included.
Usage Guidelines	See “Configuring Service Sets to be Applied to Services Interfaces” on page 444.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service-interface

Syntax	service-interface <i>interface-name</i> ;
Hierarchy Level	[edit services service-set <i>service-set-name</i> interface-service]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the name for the adaptive services interface associated with an interface-wide service set.
Options	<i>interface-name</i> —Identifier of the service interface.
Usage Guidelines	See “Configuring Service Sets to be Applied to Services Interfaces” on page 444.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service-set

Syntax	<pre> service-set service-set-name { allow-multicast; extension-service service-name { provider-specific-rules-configuration; } (ids-rules rule-name ids-rule-sets rule-set-name); interface-service { service-interface interface-name; } ipsec-vpn-options { ike-access-profile profile-name; local-gateway address; trusted-ca [ca-profile-names]; } (ipsec-vpn-rules rule-name ipsec-vpn-rule-sets rule-set-name); max-flows number; (nat-rules rule-name nat-rule-sets rule-set-name); next-hop-service { inside-service-interface interface-name.unit-number; outside-service-interface interface-name.unit-number; service-interface-pool name; } (pgcp-rules rule-name pgcp-rule-sets rule-set-name); (stateful-firewall-rules rule-name stateful-firewall-rule-sets rule-set-name); syslog { host hostname { facility-override facility-name; log-prefix prefix-value; services severity-level; } } } </pre>
Hierarchy Level	[edit services]
Release Information	Statement introduced before JUNOS Release 7.4. The <code>pgcp-rules</code> and <code>pgcp-rule-sets</code> options were added in Release 8.4.
Description	Define the service set.
Options	<p><code>service-set-name</code>—Identifies the service set.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Service Set Configuration Guidelines” on page 443.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

services

See the following sections:

- services (Hierarchy) on page 468
- services (System Logging) on page 469

services (*Hierarchy*)

Syntax services { ... }

Hierarchy Level [edit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the service rules to be applied to traffic.

Usage Guidelines See “Service Set Configuration Guidelines” on page 443.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

services (System Logging)

Syntax	<code>services severity-level;</code>
Hierarchy Level	<code>[edit services service-set service-set-name syslog host hostname]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the severity level for system logging messages.
Options	<p><i>severity-level</i>—Assigns a severity level to the facility. Valid entries are:</p> <ul style="list-style-type: none"> ■ <i>alert</i>—Conditions that should be corrected immediately. ■ <i>any</i>—Matches any level. ■ <i>critical</i>—Critical conditions. ■ <i>emergency</i>—Panic conditions. ■ <i>error</i>—Error conditions. ■ <i>info</i>—Informational messages. ■ <i>notice</i>—Conditions that require special handling. ■ <i>warning</i>—Warning messages.
Usage Guidelines	See “Configuring System Logging for Service Sets” on page 451.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

stateful-firewall-rules

Syntax	(stateful-firewall-rules <i>rule-names</i> stateful-firewall-rule-sets <i>rule-set-name</i>);
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the stateful firewall rules or rule set included in this service set. You can configure multiple rules, but only one rule set for each service.
Options	<i>rule-name</i> —Identifier for the collection of terms that make up this rule. <i>rule-set-name</i> —Identifier for the set of rules to be included.
Usage Guidelines	See “Configuring Service Rules” on page 448.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

syslog

Syntax	<pre> syslog { host <i>hostname</i> { services <i>severity-level</i>; facility-override <i>facility-name</i>; interface-service <i>prefix-value</i>; } } </pre>
Hierarchy Level	[edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure generation of system log messages for the service set. The system log information is passed to the kernel for logging in the <code>/var/log</code> directory. These settings override the values defined at the [edit interfaces <i>interface-name</i> services-options] hierarchy level; for more information on configuring those values, see “Configuring System Logging for Services Interfaces” on page 479.
Options	The remaining statements are described separately.
Usage Guidelines	See “Configuring System Logging for Service Sets” on page 451.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

tcp-mss

Syntax	<code>tcp-mss <i>number</i>;</code>
Hierarchy Level	<code>[edit services service-set <i>service-set-name</i>]</code>
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the TCP Maximum Segment Size (MSS) allowed for the service set.
Options	<i>number</i> —MSS value.
Usage Guidelines	See “Configuring Service Set Limitations” on page 451.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

traceoptions

Syntax	<pre> traceoptions { file <i>filename</i> <files <i>number</i>> <match <i>regular-expression</i>> <size <i>size</i>> <world-readable no-world-readable>; flag <i>flag</i>; no-remote-trace; } </pre>
Hierarchy Level	<pre> [edit services adaptive-services-pics], [edit services logging] </pre>
Release Information	Statement introduced before JUNOS Release 7.4. file option added in Release 8.0.
Description	Configure Adaptive Services or MultiServices PIC tracing operations. The messages are output to <code>/var/log/serviced</code> .
Options	<p>file <i>filename</i>—Name of the file to receive the output of the tracing operation. All files are placed in the directory <code>/var/log</code>.</p> <p>files <i>number</i>—(Optional) Maximum number of trace files. When a trace file named <i>trace-file</i> reaches its maximum size, it is renamed <i>trace-file.0</i>, then <i>trace-file.1</i>, and so on, until the maximum number of trace files is reached. Then the oldest trace file is overwritten.</p> <p>If you specify a maximum number of files, you also must specify a maximum file size with the size option. Range: 2 through 1000 files Default: 3 files</p> <p>flag <i>flag</i>—Tracing operation to perform:</p> <ul style="list-style-type: none"> ■ all—Trace everything. ■ command-queued—Trace command enqueue events. ■ config—Trace configuration events. ■ handshake—Trace handshake events. ■ init—Trace initialization events. ■ interfaces—Trace interface events. ■ mib—Trace GGSN SNMP MIB events. ■ removed-client—Trace client cleanup events. ■ show—Trace CLI command servicing.

match *regex*—(Optional) Match output to a defined regular expression (*regex*).

Default: If you do not include this option, the trace operation output includes all lines relevant to the logged events.

no-world-readable—(Optional) Prevent any user from reading the log file.

size *size*—(Optional) Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named *trace-file* reaches this size, it is renamed *trace-file.0*. When the *trace-file* again reaches its maximum size, *trace-file.0* is renamed *trace-file.1* and *trace-file* is renamed *trace-file.0*. This renaming scheme continues until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

If you specify a maximum file size, you also must specify a maximum number of trace files with the **files** option.

Syntax: *xk* to specify KB, *xm* to specify MB, or *xg* to specify GB

Range: 10 KB through 1 GB

Default: 128 KB

world-readable—(Optional) Allow any user to read the log file.

Usage Guidelines See “Tracing Services PIC Operations” on page 453.

Required Privilege Level *interface*—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

trusted-ca

Syntax `trusted-ca ca-profile-name;`

Hierarchy Level `[edit services service-set service-set-name ipsec-vpn-options]`

Release Information Statement introduced in JUNOS Release 7.5.

Description Identify one or more trusted IPsec certification authorities.

Options *ca-profile-name*—Name of certification authority profile, which is configured at the `[edit security pki]` hierarchy level.

Usage Guidelines See “Configuring IPsec Service Sets” on page 448.

Required Privilege Level *admin*—To view this statement in the configuration.
admin-control—To add this statement to the configuration.

Chapter 24

Service Interface Configuration Guidelines

For the interfaces on a router to function, you must configure them, specifying properties such as the interface location (that is, which slot the Flexible PIC Concentrator [FPC] is installed in and which location on the FPC the Physical Interface Card [PIC] is installed in), the interface type (such as SONET/SDH or Asynchronous Transfer Mode [ATM]), encapsulation, and interface-specific properties. You can configure the interfaces that are currently present in the router, and you can also configure interfaces that are not currently present but that you might add in the future. When a configured interface appears, the JUNOS software detects its presence and applies the appropriate configuration to it. For more information on the general configuration of interfaces, see the *JUNOS Network Interfaces Configuration Guide*.

You can configure two different sets of properties at the interface level:

- Properties that apply to an entire Adaptive Services (AS) or MultiServices PIC interface on a global level, including default values for system logging and timeout properties.
- Assignment of service sets and filters to a network interface.

To configure default properties for the adaptive services interface, include the `sp-fpc/pic/port` or `rspnumber` statement at the `[edit interfaces]` hierarchy level:

```
(sp-fpc/pic/port | rspnumber) {
  services-options {
    inactivity-timeout seconds;
    open-timeout seconds;
    syslog {
      host hostname {
        services severity-level;
        facility-override facility-name;
        log-prefix prefix-value;
      }
    }
  }
}
```

To apply services on network interfaces, include the `unit` statement at the `[edit interfaces interface-name]` hierarchy level:

```
unit logical-unit-number {
```

```

clear-dont-fragment-bit;
encapsulation type;
family inet {
    address address {
        ...
    }
    mtu bytes;
    service {
        input {
            [ service-set service-set-name <service-filter filter-name> ];
            post-service-filter filter-name;
        }
        output {
            [ service-set service-set-name <service-filter filter-name> ];
        }
    }
    service-domain (inside | outside);
}
}

```

To configure AS or MultiServices PIC redundancy, include the **redundancy-options** statement at the [edit interfaces *rsp number*] hierarchy level:

```

rspnumber {
    redundancy-options {
        primary sp-fpc/pic/port;
        secondary sp-fpc/pic/port;
    }
}

```

This chapter contains the following sections:

- Services Interface Naming Overview on page 476
- Configuring the Address and Domain for Services Interfaces on page 478
- Configuring Default Timeout Settings for Services Interfaces on page 478
- Configuring System Logging for Services Interfaces on page 479
- Enabling Fragmentation on GRE Tunnels on page 480
- Applying Filters and Services to Interfaces on page 481
- Configuring AS or MultiServices PIC Redundancy on page 483
- Examples: Configuring Services Interfaces on page 486

Services Interface Naming Overview

Each interface has an interface name, which specifies the media type, the slot the FPC is located in, the location on the FPC that the PIC is installed in, and the PIC port. The interface name uniquely identifies an individual network connector in the system. You use the interface name when configuring interfaces and when enabling various functions and properties, such as routing protocols, on individual interfaces. The system uses the interface name when displaying information about the interface, for example, in the **show interfaces** command.

The interface name is represented by a physical part, a logical part, and a channel part in the following format:

physical<:channel>.logical

The channel part of the name is optional for all interfaces except channelized DS3, E1, OC12, and STM1 interfaces.

The physical part of an interface name identifies the physical device, which corresponds to a single physical network connector. This part of the interface name has the following format:

type-fpc/pic/port

type is the media type, which identifies the network device. For service interfaces, it can be one of the following:

- **cp**—Flow collector interface.
- **es**—Encryption interface.
- **gr**—Generic routing encapsulation tunnel interface.
- **gre**—This interface is internally generated and not configurable.
- **ip**—IP-over-IP encapsulation tunnel interface.
- **ipip**—This interface is internally generated and not configurable.
- **ls**—Link services interface.
- **lsq**—Link services intelligent queuing (IQ) interface; also used for voice services.
- **ml**—Multilink interface.
- **mo**—Monitoring services interface. The logical interface **mo-fpc/pic/port.16383** is an internally generated, nonconfigurable interface for routing platform control traffic.
- **mt**—Multicast tunnel interface. This interface is automatically generated, but you can configure properties on it if needed.
- **mtun**—This interface is internally generated and not configurable.
- **rlsq**—Redundancy LSQ interface.
- **rsp**—Redundancy adaptive services interface.
- **sp**—Adaptive services interface. The logical interface **sp-fpc/pic/port.16383** is an internally generated, nonconfigurable interface for routing platform control traffic.
- **tap**—This interface is internally generated and not configurable.
- **vp**—Voice over IP (VoIP) interface, configured on J-series Services Routers only.
- **vt**—Virtual loopback tunnel interface.

Configuring the Address and Domain for Services Interfaces

On the AS or MultiServices PIC, you configure a source address for system log messages by including the `address` statement at the `[edit interfaces interface-name unit logical-unit-number family inet]` hierarchy level:

```
address address {
  ...
}
```

Assign an IP address to the interface by configuring the `address` value. The AS or MultiServices PIC generally supports only IP version 4 (IPv4) addresses configured using the `family inet` statement, but IPsec services support IP version 6 (IPv6) addresses as well, configured using the `family inet6` statement.

For information on other addressing properties you can configure that are not specific to service interfaces, see the *JUNOS Network Interfaces Configuration Guide*.

The `service-domain` statement specifies whether the interface is used within the network or to communicate with remote devices. The software uses this setting to determine which default stateful firewall rules to apply, and to determine the default direction for service rules. To configure the domain, include the `service-domain` statement at the `[edit interfaces interface-name unit logical-unit-number]` hierarchy level:

```
service-domain (inside | outside);
```

If you are configuring the interface in a next-hop service-set definition, the `service-domain` setting must match the configuration for the `inside-service-interface` and `outside-service-interface` statements; for more information, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

Configuring Default Timeout Settings for Services Interfaces

You can specify global default settings for certain timers that apply for the entire interface. There are two statements of this type:

- `inactivity-timeout`—Sets the inactivity timeout period for established flows, after which they are no longer valid.
- `open-timeout`—Sets the timeout period for Transmission Control Protocol (TCP) session establishment, for use with SYN-cookie defenses against network intrusion.

To configure a setting for the inactivity timeout period, include the `inactivity-timeout` statement at the `[edit interfaces interface-name services-options]` hierarchy level:

```
[edit interfaces interface-name services-options]
inactivity-timeout seconds;
```

The default value is 30 seconds. The range of possible values is from 4 through 86,400 seconds. Any value you configure in the application protocol definition

overrides the value specified here; for more information, see “Configuring Application Protocol Properties” on page 60.

To configure a setting for the TCP session establishment timeout period, include the `open-timeout` statement at the `[edit interfaces interface-name services-options]` hierarchy level:

```
[edit interfaces interface-name services-options]
open-timeout seconds;
```

The default value is 30 seconds. The range of possible values is from 4 through 86,400 seconds. Any value you configure in the intrusion detection service (IDS) definition overrides the value specified here; for more information, see “Intrusion Detection Service Configuration Guidelines” on page 175.

Configuring System Logging for Services Interfaces

You specify properties that control how system log messages are generated for the interface as a whole. If you configure different values for the same properties at the `[edit services service-set service-set-name]` hierarchy level, the service-set values override the values configured for the interface. For more information on configuring service-set properties, see “Configuring System Logging for Service Sets” on page 451.

To configure interface-wide default system logging values, include the `syslog` statement at the `[edit interfaces interface-name services-options]` hierarchy level:

```
syslog {
  host hostname {
    services severity-level;
    facility-override facility-name;
    log-prefix prefix-value;
  }
}
```

Configure the `host` statement with a hostname that specifies the system log target server. The hostname `local` directs system log messages to the Routing Engine. For external system log servers, the hostname must be included in `inet.0`. You can specify only one system logging hostname.

Table 16 on page 479 lists the severity levels that you can specify in configuration statements at the `[edit interfaces interface-name services-options syslog host hostname]` hierarchy level. The levels from `emergency` through `info` are in order from highest severity (greatest effect on functioning) to lowest.

Table 16: System Log Message Severity Levels

Severity Level	Description
any	Includes all severity levels
emergency	System panic or other condition that causes the routing platform to stop functioning

Table 16: System Log Message Severity Levels (*continued*)

Severity Level	Description
alert	Conditions that require immediate correction, such as a corrupted system database
critical	Critical conditions, such as hard drive errors
error	Error conditions that generally have less serious consequences than errors in the emergency, alert, and critical levels
warning	Conditions that warrant monitoring
notice	Conditions that are not errors but might warrant special handling
info	Events or nonerror conditions of interest

We recommend setting the system logging severity level to **error** during normal operation. To monitor PIC resource usage, set the level to **warning**. To gather information about an intrusion attack when an intrusion detection system error is detected, set the level to **notice** for a specific interface. To debug a configuration or log Network Address Translation (NAT) functionality, set the level to **info**.

For more information about system log messages, see the *JUNOS System Log Messages Reference*.

To use one particular facility code for all logging to the specified system log host, include the **facility-override** statement at the [edit interfaces *interface-name* services-options syslog host *hostname*] hierarchy level:

```
facility-override facility-name;
```

The supported facilities include **authorization**, **daemon**, **ftp**, **kernel**, **user**, and **local0** through **local7**.

To specify a text prefix for all logging to this system log host, include the **log-prefix** statement at the [edit interfaces *interface-name* services-options syslog host *hostname*] hierarchy level:

```
log-prefix prefix-value;
```

Enabling Fragmentation on GRE Tunnels

To enable fragmentation of IPv4 packets in generic routing encapsulation (GRE) tunnels, include the **clear-dont-fragment-bit** statement and a maximum transmission unit (MTU) setting for the tunnel as part of an existing GRE configuration at the [edit interfaces] hierarchy level:

```
[edit interfaces]
gr-fpc/pic/port {
  unit logical-unit-number {
    clear-dont-fragment-bit;
```



```

...
family inet {
    mtu 1000;
    ...
}
}

```

This statement clears the Don't Fragment (DF) bit in the packet header, regardless of the packet size. If the packet size exceeds the tunnel MTU value, the packet is fragmented before encapsulation. The maximum MTU size configurable on the AS or MultiServices PIC is 9192 bytes.

Fragmentation is enabled only on IPv4 packets being encapsulated in IPv4-based GRE tunnels.



NOTE: This configuration is supported only on GRE tunnels on AS or MultiServices interfaces. If you commit **gre-fragmentation** as the encapsulation type on a standard Tunnel PIC interface, the following console log message appears when the PIC comes online:

```
gr-fpc/pic/port: does not support this encapsulation
```

Applying Filters and Services to Interfaces

When you have defined and grouped the service rules by configuring the service-set definition, you can apply services to one or more interfaces on the router. To associate a defined service set with an interface, include the **service-set** statement with the **input** or **output** statement at the [edit interfaces *interface-name* unit *logical-unit-number* family inet service] hierarchy level:

```

[edit interfaces interface-name unit logical-unit-number family inet service]
input {
    service-set service-set-name <service-filter filter-name>;
    post-service-filter filter-name;
}
output {
    service-set service-set-name <service-filter filter-name>;
}

```



NOTE: When you enable services on an interface, reverse-path forwarding is not supported. You cannot configure services on the management interface (fxp0) or the loopback interface (lo0).

You can configure different service sets on the input and output sides of the interface. However, for service sets with bidirectional service rules, you must include the same service set definition in both the **input** and **output** statements. Any service set you include in the **service** statement must be configured with the **interface-service**

statement at the `[edit services service-set service-set-name]` hierarchy level; for more information, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.



NOTE: If you configure an interface with an input firewall filter that includes a reject action and with a service set that includes stateful firewall rules, the router executes the input firewall filter before the stateful firewall rules are run on the packet. As a result, when the Packet Forwarding Engine sends an Internet Control Message Protocol (ICMP) error message out through the interface, the stateful firewall rules might drop the packet because it was not seen in the input direction.

Possible workarounds are to include a forwarding-table filter to perform the reject action, because this type of filter is executed after the stateful firewall in the input direction, or to include an output service filter to prevent the locally generated ICMP packets from going to the stateful firewall service.

Configuring Service Filters

You can optionally include filters associated with each service set to refine the target and additionally process the traffic. If you include the `service-set` statement without a `service-filter` definition, the router software assumes that the match condition is true and selects the service set for processing automatically.

To configure service filters, include the `firewall` statement at the `[edit]` hierarchy level:

```
firewall {
  family inet {
    service-filter filter-name {
      term term-name {
        from {
          match-conditions;
        }
        then {
          action;
          action-modifiers;
        }
      }
    }
  }
}
```



NOTE: You must specify `inet` as the address family to configure a service filter.

You configure service filters in a similar way to firewall filters. Service filters have the same match conditions as firewall filters, but the following specific actions:

- `count`—Add the packet to a counter total.
- `log`—Log the packet.

- **port-mirror**—Port-mirror the packet.
- **sample**—Sample the packet.
- **service**—Forward the packet for service processing.
- **skip**—Omit the packet from service processing.

For more information about configuring firewall filters, see the *JUNOS Policy Framework Configuration Guide*.

You can also include more than one service set definition on each side of the interface. If you include multiple service sets, the router software evaluates them in the order specified in the configuration. It executes the first service set for which it finds a match in the service filter and ignores the subsequent definitions.

An additional statement allows you to specify a filter for processing the traffic after the input service set is executed. To configure this type of filter, include the **post-service-filter** statement at the [edit interfaces *interface-name* unit *logical-unit-number* family inet service input] hierarchy level:

```
post-service-filter filter-name;
```



NOTE: The software performs postservice filtering only when it has selected and executed a service set. If the traffic does not meet the match criteria for any of the configured service sets, the postservice filter is ignored.

For an example of applying a service set to an interface, see “Examples: Configuring Services Interfaces” on page 486.

For more information on applying filters to interfaces, see the *JUNOS Network Interfaces Configuration Guide*. For general information on filters, see the *JUNOS Policy Framework Configuration Guide*.



NOTE: After NAT processing is applied to packets, they are not subject to output service filters. The service filters affect only untranslated traffic.

Configuring AS or MultiServices PIC Redundancy

You can configure AS or MultiServices PIC redundancy on M-series and T-series routing platforms, except TX Matrix platforms, that have multiple AS or MultiServices PICs. To configure redundancy, you specify a redundancy services PIC (**rsp**) interface in which the primary PIC is active and a secondary PIC is on standby. If the primary PIC fails, the secondary PIC becomes active, and all service processing is transferred to it. If the primary AS or MultiServices PIC is restored, it remains on standby and does not preempt the secondary PIC; you need to manually restore the services to the primary PIC. To determine which PIC is currently active, issue the **show interfaces redundancy** command.

Failover to the secondary PIC occurs under the following conditions:

- The primary PIC, FPC, or Packet Forwarding Engine goes down, resets, or is physically removed from the router.
- The PIC or FPC is taken offline using the `request chassis pic fpc-slot slot-number pic-slot slot-number offline` or `request chassis fpc slot slot-number offline` command. For more information, see the *JUNOS System Basics and Services Command Reference*.
- The driver watchdog timer expires.
- The `request interface switchover` command is issued. For more information, see the *JUNOS Interfaces Command Reference*.



NOTE: Adaptive Services and MultiServices PICs in Layer-2 mode (running Layer 2 services) are not rebooted when a MAC flow-control situation is detected.

The physical interface type `rsp` specifies the pairings between primary and secondary `sp` interfaces to enable redundancy. To configure an AS or MultiServices PIC as the backup, include the `redundancy-options` statement at the `[edit interfaces rspnumber]` hierarchy level:

```
[edit interfaces rspnumber]
redundancy-options {
  primary sp-fpc/pic/port;
  secondary sp-fpc/pic/port;
}
```



NOTE: You can include a similar redundancy configuration for Link Services IQ (LSQ) PICs at the `[edit interfaces rlsqnumber]` hierarchy level. For more information, see “Configuring LSQ Interface Redundancy in a Single Router Using Virtual Interfaces” on page 324.

The following constraints apply to redundant AS or MultiServices PIC configurations:

- The services supported in redundancy configurations include stateful firewall, NAT, IDS, and IPsec. Services mounted on the AS or MultiServices PIC that use interface types other than **sp** interfaces, such as tunneling and voice services, are not supported. For information on flow monitoring redundancy, see “Configuring Services Interface Redundancy with Flow Monitoring” on page 843.



NOTE: For IPsec functionality, the router no longer needs to renegotiate security associations (SAs) during warm standby PIC switchover. Instead, the warm standby feature has been made stateful by periodically setting a checkpoint between the working state of the PIC and the Routing Engine, which should lessen the downtime during switchover. If you prefer to retain the earlier behavior, you can include the **clear-ipsec-sas-on-pic-restart** statement at the **[edit services ipsec-vpn]** hierarchy level. If you enable this capability, the router renegotiates the IPsec SAs on warm standby PIC switchover. For more information, see “Clearing Security Associations” on page 218.

- We recommend that you pair the same model type in RSP configurations, such as two ASMs or two AS2 PICs. If you pair unlike models, the two PICs may perform differently.
- You can specify an AS or MultiServices PIC (**sp** interface) as the primary for only one **rsp** interface.
- An **sp** interface can be a secondary for multiple **rsp** interfaces. However, the same **sp** interface cannot be configured as a primary interface in one **rsp** configuration and as a secondary in another configuration.
- When the secondary PIC is active, if another primary PIC that is paired with it in an **rsp** configuration fails, no failover takes place.
- When you configure an AS or MultiServices PIC within a redundant configuration, the **sp** interface cannot have any configured services. Apply the configurations at the **[edit interfaces rspnumber]** hierarchy level, using, for example, the **unit** and **services-options** statements. Exceptions include the **multiservice-options** statement used in flow monitoring configurations, which can be configured separately for the primary and secondary **sp** interfaces, and the **traceoptions** statement.
- All the operational mode commands that apply to **sp** interfaces also apply to **rsp** interfaces. You can issue **show** commands for the **rsp** interface or the primary and secondary **sp** interfaces.
- If a secondary PIC fails while it is in use, the **rsp** interface returns to the “not present” state. If the primary PIC comes up later, service is restored to it.

For a sample configuration, see “Examples: Configuring Services Interfaces” on page 486.

Examples: Configuring Services Interfaces

Apply the `my-service-set` service set on an interface-wide basis. All traffic that is accepted by `my_input_filter` has `my-input-service-set` applied to it. After the service set is applied, additional filtering is done using the `my_post_service_input_filter` filter.

```
[edit interfaces fe-0/1/0]
unit 0 {
  family inet {
    filter {
      input my_input_filter;
      output my_output_filter;
    }
    service {
      input {
        service-set my-input-service-set;
        post-service-filter my_post_service_input_filter;
      }
      output {
        service-set my-output-service-set;
      }
    }
  }
}
```

Configure two redundancy interfaces, `rsp0` and `rsp1`, and associated services.

```
[edit interfaces]
rsp0 {
  redundancy-options {
    primary sp-0/0/0;
    secondary sp-1/3/0;
  }
  unit 0 {
    family inet;
  }
  unit 30 {
    family inet;
    service-domain inside;
  }
  unit 31 {
    family inet;
    service-domain outside;
  }
}
rsp1 {
  redundancy-options {
    primary sp-0/1/0;
    secondary sp-1/3/0;
  }
  unit 0 {
    family inet;
  }
  unit 20 {
    family inet;
  }
}
```

```
        service-domain inside;
    }
    unit 21 {
        family inet;
        service-domain outside;
    }
}
[edit services]
service-set null-sfw-with-nat {
    stateful-firewall-rules allow-all;
    nat-rules rule1;
    next-hop-service {
        inside-service-interface rsp0.30;
        outside-service-interface rsp0.31;
    }
}
[edit routing-instances]
vpna {
    interface rsp0.0;
}
```


Chapter 25

Summary of Service Interface Configuration Statements

The following sections explain each of the service interface configuration statements. The statements are organized alphabetically.

address

Syntax `address address {`
 `...`
 `}`

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number* family *family*],
 [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*
 family *family*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure the interface address.

Options *address*—Address of the interface.

Usage Guidelines See “Configuring the Address and Domain for Services Interfaces” on page 478; for a general discussion of **address** statement options, see the *JUNOS Network Interfaces Configuration Guide*.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

clear-dont-fragment-bit

Syntax	clear-dont-fragment-bit;
Hierarchy Level	[edit interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Clear the Don't Fragment (DF) bit on all IP version 4 (IPv4) packets entering the generic routing encapsulation (GRE) tunnel on Adaptive Services (AS) or MultiServices interfaces. If the encapsulated packet size exceeds the tunnel maximum transmission unit (MTU), the packet is fragmented before encapsulation.
Usage Guidelines	See "Enabling Fragmentation on GRE Tunnels" on page 480.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

dial-options

Syntax	dial-options { ipsec-interface-id <i>name</i> ; l2tp-interface-id <i>name</i> ; (shared dedicated); }
Hierarchy Level	[edit interfaces <i>sp-fpc/pic/port</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>sp-fpc/pic/port</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the options for configuring logical interfaces for group and user sessions in L2TP or IPsec dynamic endpoint tunneling.
Options	<p>ipsec-interface-id <i>name</i>—Interface identifier for group of dynamic peers. This identifier must be replicated at the [edit access profile <i>name</i> client * ike] hierarchy level.</p> <p>l2tp-interface-id <i>name</i>—Interface identifier that must be replicated at the [edit access profile <i>name</i>] hierarchy level.</p> <p>(shared dedicated)—Specifies whether a logical interface can host one (dedicated) or multiple (shared) sessions at one time.</p>
Usage Guidelines	See “Configuring the Identifier for Logical Interfaces that Provide L2TP Services” on page 296 (for L2TP configurations) or “Configuring Dynamic Endpoints for IPsec Tunnels” on page 237 (for IPsec configurations).
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

facility-override

Syntax	<code>facility-override <i>facility-name</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> services-options syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Override the default facility for system log reporting.
Options	<p><i>facility-name</i>—Name of the facility that overrides the default assignment. Valid entries include:</p> <ul style="list-style-type: none"> authorization daemon ftp kernel local0 through local7 user
Usage Guidelines	See “Configuring System Logging for Services Interfaces” on page 479.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

family

Syntax	<pre> family inet { address address { ... } service { input { [service-set service-set-name <service-filter filter-name>]; post-service-filter filter-name; } output { [service-set service-set-name <service-filter filter-name>]; } } } </pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure protocol family information for the logical interface.
Options	<p><i>family</i>—Protocol family. Valid settings for service interfaces include inet (IPv4) and mpls.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring the Address and Domain for Services Interfaces” on page 478 or; for a general discussion of <i>family</i> statement options, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other statements that do not affect services interfaces.

host

Syntax	host <i>hostname</i> { services <i>severity-level</i> ; facility-override <i>facility-name</i> ; log-prefix <i>prefix-value</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> services-options syslog]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the hostname for the system logging utility.
Options	<i>hostname</i> —Name of the system logging utility host machine. This can be the local Routing Engine or an external server address. The remaining statements are explained separately.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

inactivity-timeout

Syntax	inactivity-timeout <i>seconds</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> services-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the inactivity timeout period for established flows. The timeout value configured in the application protocol definition overrides this value.
Options	<i>seconds</i> —Timeout period. Default: 30 seconds Range: 4 through 86,400 seconds
Usage Guidelines	See “Configuring Default Timeout Settings for Services Interfaces” on page 478.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

input

Syntax	input { service-set <i>service-set-name</i> <service-filter <i>filter-name</i> >; post-service-filter <i>filter-name</i> ; }
Hierarchy Level	[edit interface <i>interface-name</i> unit <i>logical-unit-number</i> family inet service], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the input service sets and filters to be applied to traffic.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interfaces

Syntax	interfaces { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure interfaces on the router.
Default	The management and internal Ethernet interfaces are automatically configured. You must configure all other interfaces.
Usage Guidelines	For a complete description, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

log-prefix

Syntax	<code>log-prefix <i>prefix-value</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> services-options syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the system logging prefix value.
Options	<i>prefix-value</i> —System logging prefix value.
Usage Guidelines	See “Configuring System Logging for Services Interfaces” on page 479.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

open-timeout

Syntax	<code>open-timeout <i>seconds</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> services-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure a timeout period for Transmission Control Protocol (TCP) session establishment.
Options	<i>seconds</i> —Timeout period. Default: 30 seconds Range: 4 through 86,400 seconds
Usage Guidelines	See “Configuring Default Timeout Settings for Services Interfaces” on page 478.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

output

Syntax	output { [service-set <i>service-set-name</i> <service-filter <i>filter-name</i> >]; }
Hierarchy Level	[edit interface <i>interface-name</i> unit <i>logical-unit-number</i> family inet service], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the output service sets and filters to be applied to traffic.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

post-service-filter

Syntax	post-service-filter <i>filter-name</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service input], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service input]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the filter to be applied to traffic after service processing. The filter is applied only if a service set is configured and selected. You can configure a postservice filter on the input side of the interface only.
Options	<i>filter-name</i> —Identifier for the post-service filter.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

primary

Syntax	<code>primary interface-name;</code>
Hierarchy Level	[edit interfaces (rsp0 rsp1) redundancy-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the primary adaptive services interface.
Options	<i>interface-name</i> —The identifier for the AS or MultiServices PIC interface, which must be of the form <i>sp-fpc/pic/port</i> .
Usage Guidelines	See “Configuring AS or MultiServices PIC Redundancy” on page 483.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

redundancy-options

Syntax	<pre> redundancy-options { primary sp-fpc/pic/port; secondary sp-fpc/pic/port; } </pre>
Hierarchy Level	[edit interfaces (rsp0 rsp1)]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the primary and secondary (backup) adaptive services interfaces.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring AS or MultiServices PIC Redundancy” on page 483.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

secondary

Syntax	<code>secondary interface-name;</code>
Hierarchy Level	[edit interfaces (rsp0 rsp1) redundancy-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the secondary (backup) adaptive services interface.
Options	<i>interface-name</i> —The identifier for the adaptive services interface, which must be of the form <i>sp-fpc/pic/port</i> .
Usage Guidelines	See “Configuring AS or MultiServices PIC Redundancy” on page 483.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service

Syntax	<pre> service { input { [service-set service-set-name <service-filter filter-name>]; post-service-filter filter-name; } output { [service-set service-set-name <service-filter filter-name>]; } } </pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the service sets and filters to be applied to an interface.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service-domain

Syntax	service-domain (inside outside);
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the service interface domain. If you specify this interface using the <code>next-hop-service</code> statement at the [edit services service-set <i>service-set-name</i>] hierarchy level, the interface domain must match that specified with the <code>inside-service-interface</code> and <code>outside-service-interface</code> statements.
Options	inside—Interface used within the network. outside—Interface used outside the network.
Usage Guidelines	See “Configuring the Address and Domain for Services Interfaces” on page 478.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service-filter

Syntax	service-filter <i>filter-name</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service (input output)], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service (input output)]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the filter to be applied to traffic before it is accepted for service processing. Configuration of a service filter is optional; if you include the <code>service-set</code> statement without a <code>service-filter</code> definition, the router software assumes that the match condition is true and selects the service set for processing automatically.
Options	<i>filter-name</i> —Identifies the filter to be applied in service processing.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

service-set

Syntax	<code>service-set <i>service-set-name</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service (input output)], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet service (input output)]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define one or more service sets to be applied to an interface. If you define multiple service sets, the router software evaluates the filters in the order in which they appear in the configuration.
Options	<i>service-set-name</i> —Identifies the service set.
Usage Guidelines	See “Applying Filters and Services to Interfaces” on page 481.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	<code>services severity-level;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> services-options syslog host <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the system logging severity level.
Options	<p><i>severity-level</i>—Assigns a severity level to the facility. Valid entries include:</p> <ul style="list-style-type: none"> ■ <i>alert</i>—Conditions that should be corrected immediately. ■ <i>any</i>—Matches any level. ■ <i>critical</i>—Critical conditions. ■ <i>emergency</i>—Panic conditions. ■ <i>error</i>—Error conditions. ■ <i>info</i>—Informational messages. ■ <i>notice</i>—Conditions that require special handling. ■ <i>warning</i>—Warning messages.
Usage Guidelines	See “Configuring System Logging for Services Interfaces” on page 479.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

services-options

Syntax

```
services-options {
  inactivity-timeout seconds;
  open-timeout seconds;
  syslog {
    host hostname {
      facility-override facility-name;
      log-prefix prefix-value;
      services severity-level;
    }
  }
}
```

Hierarchy Level [edit interfaces *interface-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the service options to be applied on an interface.

Options The remaining statements are explained separately.

Usage Guidelines See “Service Interface Configuration Guidelines” on page 475.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

syslog

Syntax `syslog {
 host hostname {
 services severity-level;
 facility-override facility-name;
 log-prefix prefix-value;
 }
 }`

Hierarchy Level [edit interfaces *interface-name* services-options]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure generation of system log messages for the service set. System log information is passed to the kernel for logging in the `/var/log` directory. Any values configured in the service set definition override these values.

Options The remaining statements are described separately.

Usage Guidelines See “Configuring System Logging for Services Interfaces” on page 479.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

unit

Syntax `unit logical-unit-number {
 family inet {
 address address {
 }
 service {
 input {
 [service-set service-set-name <service-filter filter-name>];
 post-service-filter filter-name;
 }
 output {
 [service-set service-set-name <service-filter filter-name>];
 }
 }
 service-domain (inside | outside);
 }
 }`

Hierarchy Level [edit interfaces *interface-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.

Options *logical-unit-number*—Number of the logical unit.
 Range: 0 through 16,384

The remaining statements are explained separately.

Usage Guidelines See “Service Interface Configuration Guidelines” on page 475; for a general discussion of logical interface properties, see the *JUNOS Network Interfaces Configuration Guide*.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

Chapter 26

PGCP Configuration Guidelines for the BGF Feature

To configure the border gateway function (BGF), include the `pgcp` statement at the `[edit services]` hierarchy level:

```
[edit services]
pgcp {
  gateway gateway-name {
    cleanup-timeout seconds;
    gateway-address gateway-address;
    fast-update-filters {
      maximum-terms number-of-terms;
      maximum-fuf-percentage percentage;
    }
    gateway-controller gateway-controller-name {
      controller-address ip-address;
      controller-port port-number;
      interim-ah-scheme {
        algorithm algorithm;
      }
    }
  }
  gateway-port gateway-port;
  graceful-restart {
    maximum-synchronization-mismatches number-of-mismatches;
    maximum-synchronization-time seconds;
  }
  data-inactivity-detection {
    inactivity-delay;
    latch-deadlock-delay seconds;
    no-rtcp-check;
    send-notification-on-delay;
    inactivity-duration seconds;
    stop-detection-on-drop;
    report-service-change {
      service-change-type (forced-906) | forced-910;
    }
  }
  h248-options {
    audit-observed-events-returns;
    encoding {
      no-dscp-bit-mirroring;
      use-lower-case
    }
  }
}
```

```

service-change {
  control-association-indications {
    disconnect {
      controller-failure (failover-909 | restart-902);
      reconnect (disconnected-900 | restart-902);
    }
    down {
      administrative (forced-905 | forced-908 | none);
      failure (forced-904 | forced-908 | none);
      graceful (graceful-905 | none);
    }
    up {
      cancel-graceful (none | restart-918);
      failover-cold (failover-920 | restart-901);
      failover-warm (failover-919 | restart-902);
    }
  }
  virtual-interface-indications {
    virtual-interface-down {
      administrative (forced-905 | forced-906 | none);
      failure (forced-904 | forced-906 | none);
      graceful (graceful-905 | none);
      link-loss (forced-906 | none);
    }
    virtual-interface-up {
      cancel-graceful (none | restart-918);
      warm (none | restart-900);
    }
  }
  context-indications {
    state-loss (forced-910 | forced-915 | none);
  }
  use-wildcard-response;
}
}
h248-properties {
  application-data-inactivity-detection {
    ip-flow-stop-detection (regulated-notify | immediate-notify);
  }
  base-root {
    mg-provisional-response-timer-value {
      default milliseconds;
      maximum milliseconds;
      minimum milliseconds;
    }
    mgc-provisional-response-timer-value {
      default milliseconds;
      maximum milliseconds;
      minimum milliseconds;
    }
    mg-originated-pending-limit {
      default number-of-messages;
      maximum number-of-messages;
      minimum number-of-messages;
    }
    mgc-originated-pending-limit {

```

```

        default number-of-messages;
        maximum number-of-messages;
        minimum number-of-messages;
    }
    normal-mg-execution-time {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
    normal-mgc-execution-time {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
}
diffserv {
    dscp {
        default (dscp-value | alias | do-not-change);
    }
}
event-timestamp-notification {
    request-timestamp (requested | suppressed | autonomous);
}
{
    hanging-termination-detection {
        timerx seconds;
    }
}
notification-behavior {
    notification-regulation default (once | 0 - 100);
}
segmentation {
    mg-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
    mgc-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
}
mg-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
}
mgc-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
}
}
traffic-management {
    peak-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
    }
}

```

```

        rtcp {
            fixed-value bytes-per-second;
            percentage percentage;
        }
    }
    sustained-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
        rtcp {
            fixed-value bytes-per-second;
            percentage percentage;
        }
    }
    max-burst-size {
        default bytes;
        maximum bytes;
        minimum bytes;
        rtcp {
            fixed-value bytes;
            percentage percentage;
        }
    }
}
inactivity-timer {
    inactivity-timeout {
        detect;
        maximum-inactivity-time {
            default 10-millisecond-units;
            maximum 10-millisecond-units;
            minimum 10-millisecond-units;
        }
    }
}
}
h248-timers {
    initial-average-ack-delay milliseconds;
    maximum-net-propagation-delay milliseconds;
    maximum-waiting-delay milliseconds;
    tmax-retransmission-delay milliseconds;
}
max-concurrent-calls number-of-calls;
monitor {
    media {
        rtcp;
        rtp;
    }
}
service-state (in-service | out-of-service-forced | out-of-service-graceful);
session-mirroring {
    delivery-function delivery-function-name {
        destination-address destination-address;
        destination-port destination-port;
        network-operator-id network-operator-id;
        source-address source-address;
        source-port source-port;
    }
}

```

```

    }
    disable-session-mirroring;
  }
}
media-service media-service-name {
  nat-pool nat-pool-name;
}
rule rule-name {
  gateway gateway-name;
  media-service media-service-name;
}
rule-set rule-set-name {
  rule rule-name1;
  rule rule-name2;
  rule rule-name3;
}
session-mirroring {
  delivery-function delivery-function-name {
    destination-address destination-address;
    destination-port destination-port;
    network-operator-id network-operator-id;
    source-address source-address;
    source-port source-port;
  }
  disable-session-mirroring;
}
traceoptions {
  file {
    filename filename;
    files number-of-files;
    match regular-expression;
    size maximum-size;
    world-readable | no-world-readable;
  }
  flag {
    bgf-core {
      default trace-level;
      firewall trace-level;
      gate-logic trace-level;
      pic-broker trace-level;
      policy trace-level;
      statistics trace-level;
    }
    default trace-level;
    h248-stack {
      default trace-level;
      messages;
      control-association trace-level;
      media-gateway trace-level;
    }
    sbc-utils {
      common trace-level;
      configuration trace-level;
      device-monitor trace-level;
      ipc trace-level;
      memory-management trace-level;
    }
  }
}

```

```

        message trace-level;
        minimum trace-level;
        user-interface trace-level;
    }
}
virtual-interface number {
    media-service media-service-name;
    interface interface-identifier;
    routing-instance instance-name {
        service-interface interface-name.unit-number;
    }
    service-state (in-service | out-of-service-forced | out-of-service-graceful);
}
}

```

For information about using the PGCP statements to configure the BGF feature, see the *JUNOS Multiplay Solutions Guide*.

Chapter 27

Summary of PGCP Configuration Statements

The following sections explain each of the PGCP statements, which are used to configure the BGF feature. The statements are organized alphabetically.

administrative

See the following sections:

- administrative (Control Association) on page 514
- administrative (Virtual Interface) on page 515

administrative (Control Association)

Syntax administrative (forced-905 | forced-908 | none);

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-options service-change control-association-indications down]

Release Information Statement introduced in JUNOS Release 9.3.

Description Specify the method and reason that the virtual BGF includes in Unregistration Messages in ServiceChange commands that it sends to the gateway controller when a control association transitions to Out-of-Service because of an administrative operation.

Default If you do not specify an option, the virtual BGF includes FO/905 (forced-905).

Options forced-905—Termination is being taken out of service. The virtual BGF is transitioning to Out-of-Service because of an administrative operation.

forced-908—Termination is being taken out of service. The virtual BGF is transitioning to Out-of-Service because of an administrative operation or error.

none—The virtual BGF does not send a ServiceChange command to the gateway controller.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

administrative (Virtual Interface)

Syntax	administrative (forced-905 forced-906 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications virtual-interface-down]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Service-Interruption ServiceChange commands that it sends to the gateway controller when a virtual interface changes to Out-of-Service because of an administrative operation.
Default	If you do not specify an option, the virtual BGF includes FO/905 (forced-905).
Options	<p>forced-905—Termination is being taken out of service. The virtual interface is transitioning to Out-of-Service because of an administrative operation.</p> <p>forced-906—Loss of lower-layer connectivity. The virtual interface is transitioning to Out-of-Service because of a loss of layer 2 connectivity caused by the logical or physical interface being administratively disabled.</p> <p>none—Virtual BGF does not send a ServiceChange command.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

algorithm

Syntax	algorithm <i>algorithm</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> gateway-controller <i>gateway-controller-name</i> interim-ah-scheme]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Specify the algorithm for the interim AH scheme. Once you set the algorithm for the interim AH scheme, to disable the interim AH scheme, you need to remove the algorithm and restart the PGCP service.
Options	<p>algorithm—Algorithm used for the interim AH scheme. HMAC null is currently the only algorithm supported.</p> <p>Values: hmac-null</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

application-data-inactivity-detection

Syntax	application-data-inactivity { ip-flow-stop-detection (regulated-notify immediate-notify); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Activate or deactivate regulated notification of media inactivity events.
Options	The statement is explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

audit-observed-events-returns

Syntax	audit-observed-events-returns;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Enable a history of media inactivity events to be viewed by the gateway controller.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

base-root

Syntax

```
base-root {
  mg-provisional-response-timer-value {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
  }
  mgc-provisional-response-timer-value {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
  }
  mg-originated-pending-limit {
    default number-of-messages;
    maximum number-of-messages;
    minimum number-of-messages;
  }
  mgc-originated-pending-limit {
    default number-of-messages;
    maximum number-of-messages;
    minimum number-of-messages;
  }
  normal-mg-execution-time {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
  }
  normal-mgc-execution-time {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
  }
}
```

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-properties]

Release Information Statement introduced in JUNOS Release 8.5.

Description Configure default values for properties in the base root package defined in Annex E of *Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005*.

Options The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

bgf-core

Syntax bgf-core {
 default *trace-level*;
 firewall *trace-level*;
 gate-logic *trace-level*;
 pic-broker *trace-level*;
 policy *trace-level*;
 statistics *trace-level*;
 }

Hierarchy Level [edit services pgcp gateway *gateway-name* traceoptions flag]

Release Information Statement introduced in JUNOS Release 9.5.

Description Configure trace level options for the BGF core component of the virtual BGF.

Options default *trace-level*—Default trace level for all **bgf-core** messages.

firewall trace-level—Trace level for the **firewall** subcomponent, which controls firewall filters, connections, and all relevant firewall activities.

gate-logic trace-level—Trace level for the **gate-logic** subcomponent, which controls gate common logic, gate lookup, and gate manager activities.

pic-broker trace-level—Trace level for the **pic-broker** subcomponent, which controls gates on the PIC.

policy trace-level—Trace level for the **policy** subcomponent, which controls media function and socket policy.

statistics trace-level—Trace level for the **statistics** subcomponent, which provides pgcpd statistics.

trace-level—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the *trace-level*:

- **debug**—Logging of all code flow of control.
- **trace**—Logging of program trace START and EXIT macros.
- **info**—Summary logs for normal operations, such as the policy decisions made for a call.
- **warning**—Failure recovery or failure of an external entity.
- **error**—Failure with a short-term effect, such as failed processing of a single call.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

cancel-graceful

See the following sections:

- `cancel-graceful` (Control Association) on page 519
- `cancel-graceful` (Virtual Interface) on page 520

cancel-graceful (Control Association)

Syntax `cancel-graceful (none | restart-918);`

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-options service-change control-association-indications up]

Release Information Statement introduced in JUNOS Release 9.3.

Description Specify the method and reason that the virtual BGF includes in Notification ServiceChange commands that it sends to the gateway controller when the control association transitions from the Draining state to the Forwarding state.

Default If you do not specify an option, the virtual BGF does not send a ServiceChange command.

Options `none`—The virtual BGF does not send a ServiceChange command to the gateway controller.

`restart-918`—The control association has returned to the Forwarding state.

Required Privilege Level `interface`—To view this statement in the configuration.
`interface-control`—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

cancel-graceful (Virtual Interface)

Syntax	cancel-graceful (none restart-918);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications virtual-interface-up]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Notification ServiceChange commands that it sends to the gateway controller when the virtual interface transitions from In-Service to Out-of-Service-Graceful.
Default	If you do not specify an option, the virtual BGF does not send a ServiceChange command.
Options	<p>none—Virtual BGF does not send a ServiceChange command.</p> <p>restart-918—Cancel graceful. The virtual interface has entered the Draining state.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

cleanup-timeout

Syntax	cleanup-timeout <i>seconds</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the number of seconds before the virtual BGF automatically deletes all gates following a disconnection from the gateway controller.
Options	<p><i>seconds</i>—Interval before inactivity detection starts.</p> <p>Range: 0 through 65,535 seconds</p> <p>Default: 3600 seconds</p>
Required Privilege Level	<p>interface-level—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

context-indications

Syntax	context-indications { state-loss (forced-910 forced-915 none); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Service-Interruption ServiceChange commands that it sends to the gateway controller when the gates of a context no longer provide their configured services. When the virtual BGF sends a Service-Interruption message, both terminations in the context become Out-of-Service.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

control-association-indications

Syntax	<pre>control-association-indications { disconnect { controller-failure (failover-909 restart-902); reconnect (disconnected-900 restart-902); } down { administrative (forced-905 forced-908 none); failure (forced-904 forced-908 none); graceful (graceful-905 none); } up { cancel-graceful (none restart-918); failover-cold (failover-920 restart-901); failover-warm (failover-919 restart-902); } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in ServiceChange commands that it sends to the gateway controller when the state of the control association changes.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

controller-address

Syntax	controller-address <i>ip-address</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> gateway-controller <i>gateway-controller-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure an IP address for the gateway controller.
Options	<i>ip-address</i> —IP address of the gateway controller.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

controller-failure

Syntax	controller-failure (failover-909 restart-902);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications disconnect]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Registration Request ServiceChange commands when it attempts to reregister with the gateway controller or register with a new gateway controller after the control association is disconnected.
Default	If you do not specify an option, the virtual BGF includes RS/902 (restart-902).
Options	<p>failover-909—Gateway controller impending failure. The virtual BGF is reregistering with a new gateway controller following a disconnection of the virtual BGF and gateway controller.</p> <p>restart-902—Warm boot. The virtual BGF is attempting to reregister with existing states after a gateway controller failure.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

controller-port

Syntax	controller-port <i>port-number</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> gateway-controller <i>gateway-controller-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the port number of the gateway controller listening port. The virtual BGF sends H.248 messages to this port.
Options	<i>port-number</i> —Port number of the gateway controller.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

data-inactivity-detection

Syntax	<pre> data-inactivity-detection { inactivity-delay <i>seconds</i>; inactivity-duration <i>seconds</i>; latch-deadlock-delay <i>seconds</i>; no-rtcp-check; send-notification-on-delay; stop-detection-on-drop; report-service-change { service-change-type (forced-906) forced-910; } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure data inactivity detection to detect latch deadlocks or other media inactivity on a gate.
Options	The statements are described separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

default

Syntax	default <i>trace-level</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> traceoptions flag]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure the minimum trace level for all selected pgcp trace options. This option overrides individual trace options that are set at a lower level.
Default	warning
Options	<p><i>trace-level</i>—Enter one of the following trace levels as the <i>trace-level</i>:</p> <ul style="list-style-type: none"> ■ debug—Logging of all code flow of control. ■ trace—Logging of program trace START and EXIT macros. ■ info—Summary logs for normal operations, such as the policy decisions made for a call. ■ warning—Failure recovery or failure of an external entity. ■ error—Failure with a short-term effect, such as failed processing of a single call.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

delivery-function

Syntax	delivery-function <i>delivery-function-name</i> { destination-address <i>destination-address</i> ; destination-port <i>destination-port</i> ; network-operator-id <i>network-operator-id</i> ; source-address <i>source-address</i> ; source-port <i>source-port</i> ; }
Hierarchy Level	[edit services pgcp session-mirroring] [edit services pgcp gateway <i>gateway-name</i> session-mirroring]
Release Information	Statement introduced in JUNOS Release 9.2
Description	Configure the delivery function that receives the session mirroring information. You can configure only one delivery function.
Options	<i>delivery-function-name</i> —Name of the delivery function that receives the session mirroring information.
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

destination-address

Syntax	destination-address <i>destination-address</i> ;
Hierarchy Level	[edit services pgcp session-mirroring delivery-function <i>delivery-function-name</i>] [edit services pgcp gateway <i>gateway-name</i> session-mirroring delivery-function <i>delivery-function-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the address of the delivery function server to which the BGF sends session-mirroring information.
Options	<i>destination-address</i> —Address of the server to which the BGF sends session-mirroring information.
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

destination-port

Syntax	<code>destination-port destination-port;</code>
Hierarchy Level	[edit services pgcp session-mirroring delivery-function <i>delivery-function-name</i>] [edit services pgcp gateway <i>gateway-name</i> session-mirroring delivery-function <i>delivery-function-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the port on the delivery function server that receives session-mirroring information.
Options	<i>destination-port</i> —Port on the delivery function server that receives session-mirroring information. Range: 1 through 65535
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

detect

Syntax	<code>detect;</code>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties inactivity-timer inactivity-timeout]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify whether the BGF detects inactivity timeout events received from the BGF by default.
Default	The BGF does not detect inactivity timeout events by default.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

diffserv

Syntax	<pre>diffserv { dscp { default (dscp-value alias do-not-change); } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Configure default values for properties in the Differentiated Services (DiffServ) package defined in Annex A.2 of <i>Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005</i> .
Options	Statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

disable-session-mirroring

Syntax	disable-session-mirroring;
Hierarchy Level	[edit services pgcp session-mirroring] [edit services pgcp gateway <i>gateway-name</i> session-mirroring]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Disable or enable session mirroring on the BGF. To disable session mirroring, enter <code>set disable-session-mirroring</code> . To enable session mirroring, enter <code>delete disable-session-mirroring</code> .
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

disconnect

Syntax	disconnect { controller-failure (failover-909 restart-902) reconnect (disconnected-900 restart-902) }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Registration Request ServiceChange commands when it attempts to reregister with the gateway controller or register with a new gateway controller after the control association is disconnected.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

down

Syntax	down { administrative (forced-905 forced-908 none); failure (forced-904 forced-908 none); graceful (graceful-905 none); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Unregistration Messages in ServiceChange commands that it sends to the gateway controller when a control association transitions to Out-of-Service because of a failure. The failure can be the result of a services PIC or DPC, or because the services PIC or DPC was powered off or removed.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

dscp

Syntax	dscp { default (<i>dscp-value</i> <i>alias</i> do-not-change); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties diffserv]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Configure default values for DSCP marking that the virtual BGF uses for outgoing traffic when the DSCP value is not already defined by the gateway controller.
Default	The default DSCP value that the virtual BGF uses is zero (0x00).
Options	<p><i>dscp-value</i>—Specify a string of eight bits or a 1-byte hexadecimal value using the format: 0xXX. Currently, only six bits are used by the packet.</p> <p><i>alias</i>—Specify a standard DSCP name. The standard name is translated to an 8-bit string with the two least significant bits (LSBs) as zeros; for example, EF=10111000.</p> <p>do-not-change—Specify that no DSCP action be performed on the PIC or DPC. The egress value on the gate is the same as the ingress DSCP value.</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

encoding

Syntax	encoding { no-dscp-bit-mirroring; use-lower-case; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options]
Release Information	Statement introduced in JUNOS Release 9.3. use-lower-case option introduced in Release 9.5.
Description	Change encoding defaults.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

event-timestamp-notification

Syntax	event-timestamp-notification { request-timestamp (requested suppressed autonomous); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Enable or disable the gateway controller to access time stamp information for media inactivity event notifications.
Options	The statement is explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

failover-cold

Syntax	failover-cold (failover-920 restart-901);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications up]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Registration ServiceChange commands when it attempts to register with a new gateway controller following a cold failover.
Default	If you do not specify an option, the virtual BGF includes RS/901 (restart-901).
Options	failover-920—Cold failover. The virtual BGF is registering following a graceful Routing Engine switchover. The installed state is reset. restart-901—Cold boot. The virtual BGF is transitioning to In-Service. The previously installed state is not retained.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

failover-warm

Syntax	failover-warm (failover-919 restart-902);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications up]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Registration ServiceChange commands when it attempts to register with a new gateway controller following a warm failover.
Default	If you do not specify an option, the virtual BGF includes RS/902 (restart-902).
Options	<p>failover-919—Gateway controller impending failure. The virtual BGF is registering with a new gateway controller after the virtual BGF and the gateway controller were disconnected.</p> <p>restart-902—Warm boot. The virtual BGF is transitioning to In-Service. The previously installed state is retained.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

failure

See the following sections:

- [failure \(Control Association\)](#) on page 533
- [failure \(Virtual Interface\)](#) on page 534

failure (Control Association)

Syntax	failure (forced-904 forced-908 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications virtual-interface-down]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Unregistration or Notification Messages in ServiceChange commands when a control association transitions to Out-of-Service.
Default	If you do not specify an option, the virtual BGF sends ServiceChange command forced-904 to the gateway controller.
Options	<p>forced-904—Termination malfunctioning. The virtual BGF is transitioning to Out-of-Service because of a failure.</p> <p>forced-908—The virtual BGF is transitioning to Out-of-Service due to administrator action or a failure.</p> <p>none—The virtual BGF does not send a ServiceChange command to the gateway controller.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

failure (Virtual Interface)

Syntax	failure (forced-904 forced-906 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications virtual-interface-down]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Service-Interruption ServiceChange commands that it sends to the gateway controller when a virtual interface transitions to Out-of-Service because of a failure.
Default	If you do not specify an option, the virtual BGF includes FO/904 (forced-904).
Options	<p>forced-904—Termination malfunctioning. The virtual interface is transitioning to Out-of-Service because of an internal failure.</p> <p>forced-906—Loss of lower-layer connectivity. The virtual interface is transitioning to Out-of-Service because of a loss of layer 2 connectivity on the logical or physical interface.</p> <p>none—Virtual BGF does not send a ServiceChange command.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

fast-update-filters

Syntax	fast-update-filters { maximum-terms <i>number-of-terms</i> ; maximum-fuf-percentage <i>percentage-of-gates</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.1.
Description	Limit the number of FUF terms installed on the Packet Forwarding Engine for a virtual BGF to improve performance when the software is collecting statistics on packets that are dropped because they exceed the rate limits set in fast update filters (FUFs).
Options	The statements are explained separately.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

file

Syntax	file <filename> <files files> <match <i>regular-expression</i> > <size <i>maximum-file-size</i> > <world-readable no-world-readable>;
Hierarchy Level	[edit services pgcp traceoptions]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure the trace file for tracing BGF components.
Options	<p>filename <i>filename</i>—Name of the file to which the tracing messages are written. Default: bsg_trace</p> <p>files <i>number-of-files</i>—Number of trace files. The tracing mechanism can rotate between any given number of files, allowing for trace message inspection without interfering with the normal work of the application. Default: 3</p> <p>match <i>regular expression</i>—Regular expression to match with incoming messages. Messages that do not match the regular expression are not written to the trace file.</p> <p>size <i>maximum-trace-file-size</i>—Size parameter (in bytes) to trigger rotation of files. The trace mechanism rotates files based on the current file size. When the size is bigger than the maximum configured size, the files are rotated. Default: 1048576</p> <p>world-readable no-world-readable—Allow all users to use the log file or disallow all users from using the log file.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

flag

```

Syntax  flag {
            default trace-level;
            bgf-core {
                default trace-level;
                firewall trace-level;
                gate-logic trace-level;
                pic-broker trace-level;
                policy trace-level;
                statistics trace-level;
            }
            h248-stack {
                default trace-level;
                messages;
                control-association trace-level;
                media-gateway trace-level;
            }
            sbc-utils {
                common trace-level;
                configuration trace-level;
                device-monitor trace-level;
                ipc trace-level;
                memory-management trace-level;
                message trace-level;
                minimum trace-level;
                user-interface trace-level;
            }
        }

```

Hierarchy Level [edit services pgcp gateway *gateway-name* traceoptions]

Release Information Statement introduced in JUNOS Release 9.5.

Description Configure trace options for components of the BGF.

Options The options are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

gateway

```

Syntax  pgcp {
    gateway gateway-name {
        cleanup-timeout seconds;
        gateway-address gateway-address;
        gateway-controller gateway-controller-name {
            local-controller | remote-controller;
            controller-address ip-address;
            controller-port port-number;
            interim-ah-scheme {
                algorithm algorithm;
            }
        }
    }
    gateway-port gateway-port;
    service-state (in-service | out-of-service-forced | out-of-service-graceful);
    graceful-restart {
        maximum-synchronization-mismatches number-of-mismatches;
        maximum-synchronization-time seconds;
    }
    data-inactivity-detection {
        inactivity-delay seconds;
        latch-deadlock-delay seconds;
        send-notification-on-delay;
        inactivity-duration seconds;
        no-rtcp-check;
        stop-detection-on-drop;
        report-service-change {
            service-change-type (forced-906 | forced-910);
        }
    }
    h248-properties {
        application-data-inactivity-detection {
            ip-flow-stop-detection (regulated-notify | immediate-notify);
        }
    }
    base-root {
        mg-provisional-response-timer-value {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
        mgc-provisional-response-timer-value {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
        mg-originated-pending-limit {
            default number-of-messages;
            maximum number-of-messages;
            minimum number-of-messages;
        }
        mgc-originated-pending-limit {
            default number-of-messages;
        }
    }
}

```

```

        maximum number-of-messages;
        minimum number-of-messages;
    }
    normal-mg-execution-time {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
    normal-mgc-execution-time {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
}
diffserv {
    dscp {
        default (dscp-value | alias | do-not-change);
    }
}
event-timestamp-notification {
    request-timestamp (requested | suppressed | autonomous);
}
hanging-termination-detection {
    timerx seconds;
}
notification-behavior {
    notification-regulation default (once | 0–100);
}
segmentation {
    mg-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
    mgc-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
}
mg-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
}
mgc-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
}
}
traffic-management {
    peak-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
    }
    rtcp {

```

```

        fixed-value bytes-per-second;
        percentage percentage;
    }
}
sustained-data-rate {
    default bytes-per-second;
    maximum bytes-per-second;
    minimum bytes-per-second;
    rtcp {
        fixed-value bytes-per-second;
        percentage percentage;
    }
}
max-burst-size {
    default bytes;
    maximum bytes;
    minimum bytes;
    rtcp {
        fixed-value bytes;
        percentage percentage;
    }
}
}
}
inactivity-timer {
    inactivity-timeout {
        detect;
        maximum-inactivity-time {
            default 10-millisecond-units;
            maximum 10-millisecond-units;
            minimum 10-millisecond-units;
        }
    }
}
}
}
h248-options {
    audit-observed-events-returns;
    encoding {
        no-dscp-bit-mirroring;
        use-lower-case
    }
}
service-change {
    control-association-indications {
        disconnect {
            controller-failure (failover-909 | restart-902);
            reconnect (disconnected-900 | restart-902);
        }
        down {
            administrative (forced-905 | forced-908 | none);
            failure (forced-904 | forced-908 | none);
            graceful (graceful-905 | none );
        }
        up {
            cancel-graceful (none | restart-918);
            failover-cold (failover-920 | restart-901);
            failover-warm (failover-919 | restart-902);
        }
    }
}

```

```

    }
    virtual-interface-indications {
        virtual-interface-down {
            administrative (forced-905 | forced-906 | none);
            failure (forced-904 | forced-906 | none);
            graceful (graceful-905 | none);
            link-loss (forced-906 | none);
        }
        virtual-interface-up {
            cancel-graceful (Virtual Interface) (none | restart-918);
            warm (none | restart-900);
        }
    }
    context-indications {
        state-loss (forced-910 | forced-915 | none);
    }
    use-wildcard-response;
}
}
h248-timers {
    initial-average-ack-delay milliseconds;
    maximum-net-propagation-delay milliseconds;
    maximum-waiting-delay milliseconds;
    tmax-retransmission-delay milliseconds;
}
max-concurrent-calls number-of-calls;
monitor {
    media {
        rtcp;
        rtp;
    }
}
service-state (in-service | out-of-service-forced | out-of-service-graceful);
session-mirroring {
    delivery-function delivery-function-name {
        destination-address destination-address;
        destination-port destination-port;
        network-operator-id network-operator-id;
        source-address source-address;
        source-port source-port;
    }
    disable-session-mirroring;
}
}
}

```

Hierarchy Level [edit services pgcp]

Release Information	Statement introduced in JUNOS Release 8.4. graceful-restart option introduced in JUNOS Release 8.5. h248-options option introduced in JUNOS Release 8.5. h248-properties option introduced in JUNOS Release 8.5. monitor option introduced in JUNOS Release 9.0. session-mirroring option introduced in JUNOS Release 9.2. data-inactivity-detection option introduced in JUNOS Release 9.3. overload-control option introduced in JUNOS Release 9.3.
Description	Configure a virtual BGF on the router.
Options	<i>gateway-name</i> —Identifier of the virtual BGF. You can configure an IP address as the gateway name. However, the IP address is not used in the operation of the virtual BGF. The remaining statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

gateway-address

Syntax	<code>gateway-address gateway-address;</code>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the IP address of the virtual BGF.
Options	<i>gateway-address</i> —IP address of the virtual BGF that you are configuring on the router.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

gateway-controller

Syntax `gateway-controller gateway-controller-name {
 local-controller | remote-controller;
 <controller-address ip-address;>
 <controller-port port-number;>
 interim-ah-scheme {
 algorithm algorithm;
 }
}`

Hierarchy Level [edit services pgcp gateway gateway-name]

Release Information Statement introduced in JUNOS Release 8.4.
 local-controller option introduced in JUNOS Release 9.4.
 remote-controller option introduced in JUNOS Release 9.4.

Description Configure a gateway controller.

Options *gateway-controller-name*—Name of the gateway controller or BSG. You can configure an IP address as the gateway controller name. However, the IP address is not used for the connection to the gateway controller.

local-controller | remote-controller—Indicates the type of gateway controller.

- remote-controller. Configure the gateway controller as a remote controller if you are using an external gateway controller. You must specify **controller-address** and **controller-port**.
- local-controller. Configure the gateway controller as a local controller if you are using a border signaling gateway (BSG).

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

gateway-port

Syntax	<code>gateway-port gateway-port;</code>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure a port number for the virtual BGF.
Options	<i>gateway-port</i> —Port number of the virtual BGF that you are configuring on the router. Range: 0 through 65,535 Default: 2944
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

graceful

See the following sections:

- graceful (Control Association) on page 544
- graceful (Virtual Interface) on page 545

graceful (Control Association)

Syntax	graceful (graceful-905 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications down]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Notification ServiceChange commands that it sends to the gateway controller when the control association transitions from In-Service to Out-of-Service-Graceful.
Default	If you do not specify an option, the virtual BGF does not send a ServiceChange command.
Options	<p>graceful-905—Termination is being taken out of service. The control association has entered the Draining state.</p> <p>none—The virtual BGF does not send a ServiceChange command to the gateway controller.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

graceful (Virtual Interface)

Syntax	graceful (graceful-905 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications virtual-interface-down]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Notification ServiceChange commands that it sends to the gateway controller when the virtual interface transitions from In-Service to Out-of-Service-Graceful.
Default	If you do not specify an option, the virtual BGF does not send a ServiceChange command.
Options	graceful-905—Termination is being taken out of service. The interface has entered the Draining state. none—Virtual BGF does not send a ServiceChange command.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

graceful-restart

Syntax	graceful-restart { maximum-synchronization-mismatches <i>seconds</i> ; maximum-synchronization-time <i>seconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Configure graceful restart properties that are used during synchronization between the pgcpd process and the MultiServices PIC or DPC.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

h248-options

Syntax

```
h248-options {
  audit-observed-events-returns;
  encoding {
    no-dscp-bit-mirroring;
    use-lower-case;
  }
  service-change {
    control-association-indications {
      disconnect {
        controller-failure (failover-909 | restart-902);
        reconnect (disconnected-900 | restart-902);
      }
      down {
        administrative (forced-905 | forced-908 | none);
        failure (forced-904 | forced-908 | none);
        graceful (graceful-905 | none);
      }
      up {
        cancel-graceful (none | restart-918);
        failover-cold (failover-920 | restart-901);
        failover-warm (failover-919 | restart-902);
      }
    }
  }
  virtual-interface-indications {
    virtual-interface-down {
      administrative (forced-905 | forced-906 | none);
      failure (forced-904 | forced-906 | none);
      graceful (graceful-905 | none);
      link-loss (forced-906 | none);
    }
    virtual-interface-up {
      cancel-graceful (none | restart-918);
      warm (none | restart-900);
    }
  }
  context-indications {
    state-loss (forced-910 | forced-915 | none);
  }
  use-wildcard-response;
}
```

Hierarchy Level [edit services pgcp gateway *gateway-name*]

Release Information

- Statement introduced in JUNOS Release 8.5.
- `audit-observed-events-returns` option introduced in JUNOS Release 9.3.
- `encoding` option introduced in JUNOS Release 9.3.
- `service-change` options introduced in JUNOS Release 9.3.
- `use-lower-case` option introduced in JUNOS Release 9.5.

Description	Configure options that affect virtual BGF H.248 behavior.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

h248-properties

```

Syntax h248-properties {
    application-data-inactivity-detection {
        ip-flow-stop-detection (regulated-notify | immediate-notify)
    }
    base-root {
        mg-provisional-response-timer-value {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
        mgc-provisional-response-timer-value {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
        mg-originated-pending-limit {
            default number-of-messages;
            maximum number-of-messages;
            minimum number-of-messages;
        }
        mgc-originated-pending-limit {
            default number-of-messages;
            maximum number-of-messages;
            minimum number-of-messages;
        }
        normal-mg-execution-time {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
        normal-mgc-execution-time {
            default milliseconds;
            maximum milliseconds;
            minimum milliseconds;
        }
    }
    diffserv {
        dscp {
            default (dscp-value | alias | do-not-change);
        }
    }
    event-timestamp-notification {
        request-timestamp (requested | suppressed | autonomous)
    }
    hanging-termination-detection {
        timerx seconds;
    }
    segmentation {
        mg-segmentation-timer {
            default milliseconds;
            maximum milliseconds;
        }
    }
}

```

```

        minimum milliseconds;
    }
    mgc-segmentation-timer {
        default milliseconds;
        maximum milliseconds;
        minimum milliseconds;
    }
    mg-maximum-pdu-size {
        default bytes;
        maximum bytes;
        minimum bytes;
    }
    mgc-maximum-pdu-size {
        default bytes;
        maximum bytes;
        minimum bytes;
    }
}
traffic-management {
    peak-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
        rtcp {
            fixed-value bytes-per-second;
            percentage percentage;
        }
    }
    sustained-data-rate {
        default bytes-per-second;
        maximum bytes-per-second;
        minimum bytes-per-second;
        rtcp {
            fixed-value bytes-per-second;
            percentage percentage;
        }
    }
    max-burst-size {
        default bytes;
        rtcp {
            fixed-value bytes;
            percentage percentage;
        }
    }
    inactivity-timer {
        inactivity-timeout {
            detect;
            maximum-inactivity-time {
                default 10-millisecond-units;
                maximum 10-millisecond-units;
                minimum 10-millisecond-units;
            }
        }
    }
}
}

```

Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.5. diffserv option introduced in JUNOS Release 9.0. inactivity-timer option introduced in JUNOS Release 9.2. traffic-management option introduced in JUNOS Release 9.2. application-data-inactivity-detection option introduced in JUNOS Release 9.3. event-timestamp-notification option introduced in JUNOS Release 9.3.
Description	Configure default values for H.248 properties.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

h248-stack

Syntax	<pre>h248-stack { default <i>trace-level</i>; messages <i>trace-level</i>; control-association <i>trace-level</i>; media-gateway <i>trace-level</i>; }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> traceoptions flag]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure trace level options for the H.248 stack component of the virtual BGF.
Options	<p>default <i>trace-level</i>—Default trace level for all h248-stack messages.</p> <p>messages—When this option is set, H.248 messages are written to the log file.</p> <p>control-association <i>trace-level</i>—Trace level for traces relevant to H.248 control association.the.</p> <p>media-gateway <i>trace-level</i>—Trace level for libpgcp.</p> <p><i>trace-level</i>—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the <i>trace-level</i>:</p> <ul style="list-style-type: none"> ■ debug—Logging of all code flow of control. ■ trace—Logging of program trace START and EXIT macros. ■ info—Summary logs for normal operations, such as the policy decisions made for a call. ■ warning—Failure recovery or failure of an external entity. ■ error—Failure with a short-term effect, such as failed processing of a single call.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

h248-timers

Syntax	h248-timers { initial-average-ack-delay <i>milliseconds</i> ; maximum-net-propagation-delay <i>milliseconds</i> ; maximum-waiting-delay <i>milliseconds</i> ; tmax-retransmission-delay <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure H.248 timers for the PGCP connection.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

hanging-termination-detection

Syntax	hanging-termination-detection { timerx <i>seconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Enable and configure hanging termination detection.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

inactivity-delay

Syntax	<code>inactivity-delay seconds;</code>
Hierarchy Level	<code>[edit services pgcp gateway <i>gateway-name</i> data-inactivity-detection]</code>
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the time after which the virtual BGF begins checking for data packets on terminations that do not include a latch event.
Options	<i>seconds</i> —Time interval before checking for media inactivity. Range: 0 through 3600 Default: 5
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

inactivity-duration

Syntax	<code>inactivity-duration seconds;</code>
Hierarchy Level	<code>[edit services pgcp gateway <i>gateway-name</i> data-inactivity-detection]</code>
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the time interval that determines inactivity. When the virtual BGF determines that the time since the last packet was received exceeds this duration, the virtual BGF generates an inactivity notification or service change request. The duration timer is the same for terminations with latch events and for terminations without latch events.
Options	<i>seconds</i> —Time during which no packets are received. Range: 5 through 86400 Default: 30
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

inactivity-timer

Syntax	<pre> inactivity-timer { inactivity-timeout { detect; maximum-inactivity-time { default 10-millisecond-units; maximum 10-millisecond-units; minimum 10-millisecond-units; } } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the inactivity timer package, which allows the BGF to use message inactivity to detect that its active gateway controller has failed.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

inactivity-timeout

Syntax	<pre> inactivity-timeout { detect; maximum-inactivity-time { default 10-millisecond-units; maximum 10-millisecond-units; minimum 10-millisecond-units; } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties inactivity-timer]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the inactivity timeout event. The inactivity timeout event is used to detect that the inactivity timer has expired.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

initial-average-ack-delay

Syntax	initial-average-ack-delay <i>milliseconds</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-timers]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the value of the average acknowledgment delay (AAD) that the virtual BGF uses before the first AAD is measured. The AAD is explained in Annex D of <i>Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005</i> .
Options	<i>milliseconds</i> —Assumed initial average delay. Range: 0 through 65,535 Default: 4000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

interface

Syntax	interface <i>interface-name</i> ;
Hierarchy Level	[edit services pgcp virtual-interface <i>interface-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Map the virtual interface to a service interface or a physical (media) interface or both. If you do not require ingress filtering, you do not need to specify a physical interface. We recommend that you do not configure a physical interfaces unless it is necessary.
Options	<i>interface-name</i> —Interface name. Include the logical portion of the name, which corresponds to the logical unit number.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

interim-ah-scheme

Syntax	interim-ah-scheme { algorithm hmac-null; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> gateway-controller <i>gateway-controller-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Set up the BGF to use the interim AH scheme.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

ip-flow-stop-detection

Syntax	ip-flow-stop-detection (regulated-notify immediate-notify);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties application-data-inactivity-detection]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure regulated or non-regulated (immediate) notification of media inactivity events.
Options	regulated-notify—Activate regulated notification of media inactivity events. immediate-notify—Activate non-regulated notification of media inactivity events.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

latch-deadlock-delay

Syntax	latch-deadlock-delay <i>seconds</i>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> data-inactivity-detection]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the time after which the virtual BGF begins checking for data packets on terminations that include a latch event.
Options	<i>seconds</i> —Time interval before checking for data packets. Range: 0 through 3600
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

link-loss

Syntax	link-loss (forced-906 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications virtual-interface-down]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Service-Interruption ServiceChange commands that it sends to the gateway controller when the virtual interface transitions to Out-of-Service because of a link loss.
Default	If you do not specify an option, the virtual BGF includes FO/906 (forced-906).
Options	<i>forced-906</i> —Loss of lower-layer connectivity. The virtual interface is transitioning to Out-of-Service because of a loss of layer 2 connectivity on the logical or physical interface. <i>none</i> —Virtual BGF does not send a ServiceChange command.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

max-burst-size

See the following sections:

- max-burst-size (All Streams) on page 558
- max-burst-size (RTCP Streams) on page 559

max-burst-size (All Streams)

Syntax max-burst-size {
 default *bytes*;
 maximum *bytes*;
 minimum *bytes*;
 }

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-properties traffic-management]

Release Information Statement introduced in JUNOS Release 9.2.
 maximum and minimum options introduced in JUNOS Release 9.5.

Description Configure the maximum burst size for gate streams of any protocol, including RTP.

Default The virtual BGF uses the default value of 1000 bytes if the Policy command in H.248 messages in ON and both of the following apply:

- The maximum burst size is not set in the H.248 message.
- There is no CLI configuration for maximum burst size.

Options default *bytes*—Default maximum burst size.
Range: 20 through 4,294,967,295

maximum *bytes*—Maximum burst size.
Range: 20 through 4,294,967,295

minimum *bytes*—Minimum maximum burst size.
Range: 20 through 4,294,967,295

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

max-burst-size (RTCP Streams)

Syntax max-burst-size {
 rtcp {
 fixed-value *bytes*;
 percentage *percentage*;
 }
 }

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-properties traffic-management]

Release Information Statement introduced in JUNOS Release 9.2.

Description Configure the maximum burst size for for RTP/RTCP gate streams. You can configure this rate as a fixed value or as a percentage of the RTP gate's rate.

Default The virtual BGF uses the default value of 100 percent of the RTP gate's maximum burst size if the Policy command in H.248 messages in ON and both of the following apply:

- The maximum burst size is not set in the H.248 message.
- There is no CLI configuration for maximum burst size.

Options fixed-value —Value entered is a fixed number of bytes per second.

bytes-per-second—maximum burst size.

Range: 20 through 4,294,967,295

percentage —Value entered is a percentage of the RTP gate's rate.

percentage—Maximum burst size as a percentage of the RTP gate's rate.

Range: 1 through 1000

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

max-concurrent-calls

Syntax	max-concurrent-calls <i>number-of-calls</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	<p>Configure the maximum number of concurrent calls on the virtual BGF. If you configure multiple virtual BGFs for one service PIC or DPC, you can use this statement to achieve a fair distribution of resources between the virtual BGFs. For example, the MultiServices 500 PIC is capable of 10,000 concurrent calls, and you can divide this number between its associated virtual BGFs.</p> <p>You can overbook concurrent calls to avoid resource idleness. The configured total of all virtual BGF maximum concurrent calls can be greater than the PIC or DPC limit. For example, bgf-1 and bgf-2 are connected to single PIC. If you configure 6000 maximum concurrent calls on bgf-1 and 8000 on bgf-2, bgf-1 can open up to 6000 concurrent calls, and bgf-2 can open up to 8000 concurrent calls. However, when the total number of calls reaches 10,000, neither of the virtual BGFs will be able to open a new context.</p> <p>If the resources on the PIC are exhausted and no more calls are allowed, the virtual BGF sends an H.248 error message to the gateway controller in response to new call requests.</p>
Options	<i>number-of-calls</i> —Maximum number of concurrent calls on the virtual BGF. Range: 0 through 10,000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-fuf-percentage

Syntax	maximum-fuf-percentage <i>percentage</i>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> fast-update-filters]
Release Information	Statement introduced in JUNOS Release 9.1.
Description	Along with the <code>maximum-terms</code> statement, limit the number of FUF terms installed on the Packet Forwarding Engine for a virtual BGF. This limit is the maximum value of the <code>maximum-terms</code> and <code>maximum-fuf-percentage</code> statements.
Options	<p><i>percentage</i>—Maximum percentage of gates with FUF filters relative to all gates currently installed for the virtual BGF.</p> <p>Range: 0 through 100</p> <p>Default: 10</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-inactivity-time

Syntax	<pre>maximum-inactivity-time { default 10-millisecond-units; maximum 10-millisecond-units; minimum 10-millisecond-units; }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties inactivity-timer inactivity-timeout]
Release Information	Statement introduced in JUNOS Release 9.2. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Specify default, maximum, and minimum values for the maximum inactivity time. The default value is used if the gateway controller requests that the BGF detect the inactivity timeout event, but the gateway controller does not set a value for the maximum inactivity time. The maximum and minimum values are used to set limits for the maximum inactivity time set by the gateway controller. The BGF issues an error message if the value received from the gateway controller violates the configured minimum or maximum. If the BGF does not receive a message from the gateway controller before the maximum inactivity time expires, it sends a Notify message to the gateway controller. This timer resets each time the BGF receives a message from the gateway controller.
Options	<p>default <i>10-millisecond-units</i>—Default value for the maximum inactivity time. Range: 100 through 65,535 (10-millisecond units) Default: 12,000</p> <p>maximum <i>10-millisecond-units</i>—Maximum value for the maximum inactivity time. Range: 100 through 65,535 (10-millisecond units) Default: 12,000</p> <p>minimum <i>10-millisecond-units</i>—Minimum value for the maximum inactivity time. Range: 100 through 65,535 (10-millisecond units) Default: 12,000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-net-propagation-delay

Syntax	maximum-net-propagation-delay <i>milliseconds</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-timers]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the assumed maximum network propagation delay time. This value is used to calculate the LONG-TIMER as explained in Annex D of <i>Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005</i> .
Options	<i>milliseconds</i> —Duration of the maximum network propagation delay time. Range: 0 through 65,535 milliseconds Default: 40,000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-synchronization-mismatches

Syntax	maximum-synchronization-mismatches <i>number-of-mismatches</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> graceful-restart]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Configure the maximum number of mismatches allowed during the synchronization procedure between the pgcpd process and the PIC or DPC. If the number of mismatches exceeds this number, the pgcpd process clears the state of the PIC or DPC and the state of the pgcpd process.
Options	<i>number-of-mismatches</i> —Maximum number of mismatches allowed during the synchronization procedure with the PIC or DPC. Range: 0 through 3000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-synchronization-time

Syntax	maximum-synchronization-time <i>seconds</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> graceful-restart]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Configure the time within which the pgcpd process and the PIC or DPC should complete the synchronization process. If the synchronization process is not complete when this time expires, the pgcpd process clears the state of the PIC or DPC and the state of the pgcpd process.
Options	<i>seconds</i> —Maximum time allowed for the synchronization procedure with the PIC or DPC. Range: 0 through 300
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-terms

Syntax	maximum-terms <i>number-of-terms</i>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> fast-update-filters]
Release Information	Statement introduced in JUNOS Release 9.1.
Description	Along with the maximum-fuf-percentage statement, limit the number of FUF terms installed on the Packet Forwarding Engine for a virtual BGF. This limit is the maximum value of the maximum-terms and maximum-fuf-percentage statements.
Options	<i>number-of-terms</i> —Maximum number of FUF terms installed for the virtual BGF. Range: 0 through 20000 Default: 20000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

maximum-waiting-delay

Syntax	maximum-waiting-delay <i>milliseconds</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-timers]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Define a maximum waiting delay (MWD) value. When the virtual BGF loses its connection to a gateway controller, it attempts to reconnect to the gateway controller. If the virtual BGF cannot reconnect to the gateway controller, it traverses its list of gateway controllers and attempts to connect to one of the gateway controllers. If the virtual BGF finishes traversing its list of gateway controllers, and has not connected to a gateway controller, the virtual BGF waits for a random value between 0 and MWD milliseconds before it begins another attempt to connect to a gateway controller. See section 9.2 of <i>Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005</i> .
Options	<i>milliseconds</i> —Maximum time the virtual BGF waits before contacting a new gateway controller when the connection to the controlling gateway controller is lost. Range: 1 through 36,000 milliseconds Default: 3000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

media

Syntax	media { rtcp; rtp; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> monitor]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Enable Real-Time Control Protocol (RTCP) and Real-Time Transport Protocol (RTP) application-level gateways (ALGs) for media flows and monitor packets.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

media-service

Syntax	<pre>media-service <i>media-service-name</i> { nat-pool <i>nat-pool-name</i>; }</pre>
Hierarchy Level	[edit services pgcp]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure media services for the BGF configuration. Media services are applied to PGCP packets.
Options	<p><i>media-service-name</i>—Identifier for the media service name.</p> <p>The remaining statements are explained separately.</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mg-maximum-pdu-size

Syntax	mg-maximum-pdu-size { default <i>bytes</i> ; maximum <i>bytes</i> ; minimum <i>bytes</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties segmentation]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MG maximum PDU size property of the segmentation package.
Options	<p>default <i>bytes</i>—Default maximum size of messages that the gateway controller sends to the BGF. Range: 512 through 65,507</p> <p>maximum <i>bytes</i>—Maximum maximum size of messages that the gateway controller sends to the BGF. Range: 512 through 65,507</p> <p>minimum <i>bytes</i>—Minimum maximum size of messages that the gateway controller sends to the BGF. Range: 512 through 65,507</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mg-originated-pending-limit

Syntax	mg-originated-pending-limit { default <i>number-of-messages</i> ; maximum <i>number-of-messages</i> ; minimum <i>number-of-messages</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties base-root]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MG originated pending limit property of the base root package.
Options	<p>default <i>number-of-messages</i>—Default number of transaction pending messages that the gateway controller can receive from the virtual BGF. Range: 1 through 512</p> <p>maximum <i>number-of-messages</i>—Maximum number of transaction pending messages that the gateway controller can receive from the virtual BGF. Range: 1 through 512</p> <p>minimum <i>number-of-messages</i>—Minimum number of transaction pending messages that the gateway controller can receive from the virtual BGF. Range: 1 through 512</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mg-provisional-response-timer-value

Syntax	mg-provisional-response-timer-value { default <i>milliseconds</i> ; maximum <i>milliseconds</i> ; minimum <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties base-root]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MG provisional response timer property of the base root package.
Options	<p>default <i>milliseconds</i>—Default time within which the gateway controller waits for a pending response from the virtual BGF if a transaction cannot be completed. Range: 500 through 3000</p> <p>maximum <i>milliseconds</i>—Maximum time within which the gateway controller waits for a pending response from the virtual BGF if a transaction cannot be completed. Range: 500 through 3000</p> <p>minimum <i>milliseconds</i>—Minimum time within which the gateway controller waits for a pending response from the virtual BGF if a transaction cannot be completed. Range: 500 through 3000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mg-segmentation-timer

Syntax	mg-segmentation-timer { default <i>milliseconds</i> ; maximum <i>milliseconds</i> ; minimum <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties segmentation]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MG segmentation timer value property of the segmentation package.
Options	<p>default <i>milliseconds</i>—Default time within which the gateway controller waits to receive outstanding message segments from the virtual BGF after it receives the SegmentationCompleteToken. Range: 500 through 30,000</p> <p>maximum <i>milliseconds</i>—Maximum time within which the gateway controller waits to receive outstanding message segments from the virtual BGF after it receives the SegmentationCompleteToken. Range: 500 through 30,000</p> <p>minimum <i>milliseconds</i>—Minimum time within which the gateway controller waits to receive outstanding message segments from the virtual BGF after it receives the SegmentationCompleteToken. Range: 500 through 30,000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mgc-maximum-pdu-size

Syntax	mgc-maximum-pdu-size { default <i>bytes</i> ; maximum <i>bytes</i> ; minimum <i>bytes</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties segmentation]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, minimum, and maximum values for the MGC maximum PDU size property of the segmentation package.
Options	<p>default <i>bytes</i>—Default maximum size of messages that the virtual BGF sends to the gateway controller. Range: 512 through 65,507</p> <p>maximum <i>bytes</i>—Maximum size of messages that the virtual BGF sends to the gateway controller. Range: 512 through 65,507</p> <p>minimum <i>bytes</i>—Minimum maximum size of messages that the virtual BGF sends to the gateway controller. Range: 512 through 65,507</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mgc-originated-pending-limit

Syntax	mgc-originated-pending-limit { default <i>number-of-messages</i> ; maximum <i>number-of-messages</i> ; minimum <i>number-of-messages</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties base-root]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MGC originated pending limit property of the base root package.
Options	<p>default <i>number-of-messages</i>—Default number of transaction pending messages that the virtual BGF can receive from the gateway controller. Range: 1 through 512</p> <p>maximum <i>number-of-messages</i>—Maximum number of transaction pending messages that the virtual BGF can receive from the gateway controller. Range: 1 through 512</p> <p>minimum <i>number-of-messages</i>—Minimum number of transaction pending messages that the virtual BGF can receive from the gateway controller. Range: 1 through 512</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mgc-provisional-response-timer-value

Syntax	mgc-provisional-response-timer-value { default <i>milliseconds</i> ; maximum <i>milliseconds</i> ; minimum <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties base-root]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MGC provisional response timer value property of the base root package.
Options	<p>default <i>milliseconds</i>—Default time within which the virtual BGF waits for a pending response from the gateway controller if a transaction cannot be completed. Range: 500 through 3,000</p> <p>maximum <i>milliseconds</i>—Maximum time within which the virtual BGF waits for a pending response from the gateway controller if a transaction cannot be completed. Range: 500 through 3,000</p> <p>minimum <i>milliseconds</i>—Minimum time within which the virtual BGF waits for a pending response from the gateway controller if a transaction cannot be completed. Range: 500 through 3,000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

mgc-segmentation-timer

Syntax	mgc-segmentation-timer { default <i>milliseconds</i> ; maximum <i>milliseconds</i> ; minimum <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties segmentation]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the MGC segmentation timer value property of the segmentation package.
Options	<p>default <i>milliseconds</i>—Default time within which the virtual BGF waits to receive outstanding message segments from the gateway controller after it receives the SegmentationCompleteToken. Range: 500 through 30,000</p> <p>maximum <i>milliseconds</i>—Default time within which the virtual BGF waits to receive outstanding message segments from the gateway controller after it receives the SegmentationCompleteToken. Range: 500 through 30,000</p> <p>minimum <i>milliseconds</i>—Default time within which the virtual BGF waits to receive outstanding message segments from the gateway controller after it receives the SegmentationCompleteToken. Range: 500 through 30,000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

monitor

Syntax	monitor { media { rtcp; rtp; } }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Enable Real-Time Control Protocol (RTCP) and Real-Time Transport Protocol (RTP) application-level gateways (ALGs) for media flows and monitor packets.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

nat-pool

Syntax	nat-pool <i>nat-pool-name</i> ;
Hierarchy Level	[edit services pgcp media-service <i>media-service-name</i>]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Specify a Network Address Translation (NAT) pool for the media service. You can specify only one pool for each media service.
Options	<i>nat-pool-name</i> —Identifier for the NAT address pool.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

network-operator-id

Syntax	<code>network-operator-id <i>network-operator-id</i>;</code>
Hierarchy Level	[edit services pgcp session-mirroring delivery-function <i>deliver-function-name</i>] [edit services pgcp gateway <i>gateway-name</i> session-mirroring delivery-function <i>deliver-function-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the network operator ID. The BGF includes the network operator ID in the header of mirrored packets that it sends to the delivery function. It is used to identify the operator.
Options	<i>network-operator-id</i> —The network operator ID can be up to five characters.
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

no-rtcp-check

Syntax	<code>no-rtcp-check;</code>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties data-inactivity-detection]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Prevent checking for inactivity on RTCP streams.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

normal-mg-execution-time

Syntax	normal-mg-execution-time { default <i>milliseconds</i> ; maximum <i>milliseconds</i> ; minimum <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties base-root]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the normal MG execution time property of the base root package.
Options	<p>default <i>milliseconds</i>—Default interval within which the gateway controller waits for a response to transactions from the virtual BGF. Range: 500 through 29,000</p> <p>maximum <i>milliseconds</i>—Maximum interval within which the gateway controller waits for a response to transactions from the virtual BGF. Range: 500 through 29,000</p> <p>minimum <i>milliseconds</i>—Minimum interval within which the gateway controller waits for a response to transactions from the virtual BGF. Range: 500 through 29,000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

normal-mgc-execution-time

Syntax	normal-mgc-execution-time { default <i>milliseconds</i> ; maximum <i>milliseconds</i> ; minimum <i>milliseconds</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties base-root]
Release Information	Statement introduced in JUNOS Release 8.5. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Set default, maximum, and minimum values for the normal MGC execution time property of the base root package.
Options	<p>default <i>milliseconds</i>—Default interval within which the virtual BGF waits for a response to transactions from the gateway controller. Range: 500 through 29,000</p> <p>maximum <i>milliseconds</i>—Maximum interval within which the virtual BGF waits for a response to transactions from the gateway controller. Range: 500 through 29,000</p> <p>minimum <i>milliseconds</i>—Minimum interval within which the virtual BGF waits for a response to transactions from the gateway controller. Range: 500 through 29,000</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

notification-behavior

Syntax	notification-behavior { notification-regulation default (once 0 – 100); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the default frequency for regulated media inactivity notifications sent by the BGF.
Options	The statement is explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

notification-rate-limit

Syntax	notification-rate-limit <i>rate</i> ;
Hierarchy Level	[edit services pgcp]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the maximum notifications sent per second by the PIC or DPC.
Options	<i>rate</i> —Maximum number of notifications per second the PIC or DPC sends to a gateway controller. Range: 10 through 10,000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

notification-regulation

Syntax	notification-regulation (once 0 – 100);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties notification-behavior]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the default frequency for sending media inactivity notifications for regulated events.
Options	<p>once—Send only one media inactivity notification for a regulated event to the gateway controller.</p> <p>0 – 100—The percentage of media inactivity notifications for regulated events to send to the gateway controller.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

no-dscp-bit-mirroring

Syntax	no-dscp-bit-mirroring;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options encoding]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Disable mirroring of DSCP bits.
Default	DSCP bits are mirrored by default.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

overload-control

Syntax	overload-control { queue-limit-percentage <i>percentage</i> ; reject-all-commands-threshold <i>percentage</i> ; reject-new-calls-threshold <i>percentage</i> ; }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.3. <i>reject-all-commands-threshold</i> and <i>reject-new-calls-threshold</i> options introduced in JUNOS Release 9.5.
Description	Configure the BGF to send overload messages to the gateway controller based on the status of its work queue. The overload messages cause the gateway controller to lower the rate at which it admits packets for processing.
Options	The statement is described separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

peak-data-rate

See the following sections:

- [peak-data-rate \(All Streams\)](#) on page 582
- [peak-data-rate \(RTCP\)](#) on page 583

peak-data-rate (All Streams)

Syntax `peak-data-rate {
 default bytes-per-second;
 maximum bytes-per-second;
 minimum bytes-per-second;
}`

Hierarchy Level [edit services services pgcp gateway *gateway-name* h248-properties traffic-management]

Release Information Statement introduced in JUNOS Release 9.2.
maximum and minimum options introduced in JUNOS Release 9.5.

Description Configure the peak data rate for gate streams of any protocol.

Default The BGF uses the default value of 10,000 bytes per second if the Policy command in H.248 messages is ON and both of the following apply:

- The peak data rate is not set in the H.248 message.
- There is no CLI configuration for peak data rate.

Options default *bytes-per-second*—Default peak data rate.
Range: 125 through 4,294,967,295

maximum *bytes-per-second*—Maximum peak data rate.
Range: 125 through 4,294,967,295

minimum *bytes-per-second*—Minimum peak data rate.
Range: 125 through 4,294,967,295

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

peak-data-rate (RTCP)

Syntax `peak-data-rate {
 rtcp {
 fixed-value bytes;
 percentage percentage;
 }
 }`

Hierarchy Level `[edit services services pgcp gateway gateway-name h248-properties traffic-management]`

Release Information Statement introduced in JUNOS Release 9.2.

Description Configure the peak data rate for RTP/RTCP gate streams. You can configure this rate as a fixed value or as a percentage of the RTP gate's rate.

Default The PG uses the default value of 5 percent of the RTP gate's rate if the Policy command in H.248 messages in ON and both of the following apply:

- The peak data rate is not set in the H.248 message.
- There is no CLI configuration for peak data rate.

Options `fixed-value` —Value entered is a fixed number of bits per second.

bytes-per-second—Peak data rate.

Range: 125 through 4,294,967,295

`percentage` *bytes-per-second*—Value entered is a percentage of the RTP's gate rate..

percentage—Value entered is a percentage of the RTP's gate rate..

Range: 0 through 1000

Required Privilege Level `interface`—To view this statement in the configuration.
 `interface-control`—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

queue-limit-percentage

Syntax	queue-limit-percentage <i>percentage</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> overload-control]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the queue limit percentage (percentage of the maximum work queue size currently in use) that indicates overload. When the gateway controller activates overload control, the BGF generates an overload notification for each transaction on a gate that contains an ADD if the work queue utilization has reach this limit. When 100 percent of the queue is in use, transactions are dropped with error 510 (insufficient resources).
Options	<i>percentage</i> —Percentage of the overload control work queue in use that triggers creation of an overload notification. Range: 25 through 100 Default: 80
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

reconnect

Syntax	reconnect (disconnected-900 restart-902);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications disconnect]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Registration Request ServiceChange commands when it attempts to reregister with the gateway controller or register with a new gateway controller after the control association is disconnected.
Default	If you do not specify an option, the virtual BGF includes DC/900 (disconnected-900).
Options	<p>disconnected-900—Service restored. The virtual BGF is registering with the last controlling gateway controller following a disconnection of the virtual BGF and gateway controller.</p> <p>restart-902—Warm boot. The virtual BGF is transitioning to In-Service, and the previously installed state is retained.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

reject-all-commands-threshold

Syntax	reject-all-commands-threshold <i>percentage</i> ;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> overload-control]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the maximum percentage of the work queue that can be in use before the virtual BGF rejects all non-emergency transactions other than SUBTRACT transactions.
Options	<i>percentage</i> —Percentage of work queue space used that serves as a threshold for overload control.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

reject-new-calls-threshold

Syntax	<code>reject-new-calls-threshold <i>percentage</i>;</code>
Hierarchy Level	<code>[edit services pgcp gateway <i>gateway-name</i> overload-control]</code>
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the maximum percentage of the work queue that can be in use before the virtual BGF rejects all non-emergency ADD transactions.
Options	<i>percentage</i> —Percentage of work queue space used that serves as a threshold for overload control.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

report-service-change

Syntax	<code>report-service-change { <i>service-change-type</i> (forced-906 forced-910); }</code>
Hierarchy Level	<code>[edit services pgcp gateway <i>gateway-name</i> data-inactivity-detection]</code>
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Change the service state of inactive terminations to prevent continued sending of inactivity notifications.
Options	The statement is described separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

request-timestamp

Syntax	request-timestamp (requested suppressed autonomous);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties event-timestamp]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify whether time stamp information is made available to the gateway controller or is suppressed.
Options	<p>requested—Enables gateway controller access to time stamp information for notifications.</p> <p>suppressed—Disables gateway controller access to time stamp information for notifications.</p> <p>autonomous—Equivalent to suppressed.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

routing-instance

Syntax	<pre>routing-instance <i>instance-name</i> { service-interface <i>interface-name.unit-number</i>; }</pre>
Hierarchy Level	[edit services pgcp virtual-interface <i>interface-name</i>]
Release Information	<p>Statement introduced in JUNOS Release 8.4.</p> <p>service-interface option introduced in JUNOS Release 9.3.</p>
Description	Map the virtual router interface to a VPN routing and forwarding (VRF) routing instance configured on the router.
Options	<p><i>instance-name</i>—Name of a routing instance that has been configured at the [edit routing-instance] hierarchy level.</p> <p>The remainder of the statements are explained separately.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

rtp

Syntax	rtp;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> monitor media]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Enable Real-Time Transport Protocol (RTP) application-level gateway (ALG) on media flows created when the gateway controller installs media gates on the virtual BGF.
Required Privilege Level	interface-level—To view this statement in the configuration. interface-level—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

rtcp

Syntax	rtcp;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> monitor media]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Enable Real-Time Control Protocol (RTCP) application-level gateway (ALG) on media flows created when the gateway controller installs media gates on the virtual BGF.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

rule

Syntax	<pre>rule rule-name { gateway gateway-name; media-service media-service-name; }</pre>
Hierarchy Level	[edit services pgcp], [edit services service-set service-set-name]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Specify the rule that the router uses when it applies the media service.
Options	<i>rule-name</i> —Identifier for the rule. The remaining statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

rule-set

Syntax	<pre>rule-set rule-set-name { [rule rule-name] }</pre>
Hierarchy Level	[edit services pgcp], [edit services service-set service-set-name]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Specify the rule set the router uses when applying this service.
Options	<i>rule-set-name</i> —Identifier for the collection of rules that make up this rule set.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

sbc-utils

Syntax sbc-utils {
 common *trace-level*;
 configuration *trace-level*;
 device-monitor *trace-level*;
 ipc *trace-level*;
 memory-management *trace-level*;
 message *trace-level*;
 minimum *trace-level*;
 user-interface *trace-level*;
 }

Hierarchy Level [edit services pgcp gateway *gateway-name* traceoptions flag]

Release Information Statement introduced in JUNOS Release 9.5.

Description Configure trace options for the Signaling Border Controller (SBC) utilities component of the virtual BGF.

Default warning

Options minimum *trace-level*—Minimum trace level for all **sbc-util** messages.

common *trace-level*—Trace level for the common component of SBC utilities.

configuration *trace-level*—Trace level for the configuration component of SBC utilities.

device-monitor *trace-level*—Trace level for the device monitor component of SBC utilities.

ipc *trace-level*—Trace level for the IPC component of SBC utilities.

memory-management *trace-level*—Trace level for the memory management component of SBC utilities.

message *trace-level*—Trace level for the message component of SBC utilities.

user-interface *trace-level*—Trace level for the user interface component of SBC utilities.

trace-level—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the *trace-level*:

- debug—Logging of all code flow of control.
- trace—Logging of program trace START and EXIT macros.
- info—Summary logs for normal operations, such as the policy decisions made for a call.
- warning—Failure recovery or failure of an external entity.
- error—Failure with a short-term effect, such as failed processing of a single call.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

segmentation

Syntax

```
segmentation {
  mg-segmentation-timer {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
  }
  mgc-segmentation-timer {
    default milliseconds;
    maximum milliseconds;
    minimum milliseconds;
  }
  mg-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
  }
  mgc-maximum-pdu-size {
    default bytes;
    maximum bytes;
    minimum bytes;
  }
}
```

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-properties]

Release Information Statement introduced in JUNOS Release 8.5.

Description Configure default values for properties in the segmentation package defined in Annex E of *Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005*.

Options The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

send-notification-on-delay

Syntax send-notification-on-delay;

Hierarchy Level [edit services pgcp gateway *gateway-name* data-inactivity-detection]

Release Information Statement introduced in JUNOS Release 9.3.

Description Send an inactivity notification immediately when no media packets are detected during a delay period that precedes checking for media inactivity. By default, notifications are sent after both the delay period and an additional period of inactivity have elapsed without any media packets being detected.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics inactivity-delay

latch-deadlock-delay

JUNOS Multiplay Solutions Guide

service-change

Syntax

```

service-change {
  control-association-indications {
    disconnect {
      controller-failure (failover-909 | restart-902);
      reconnect (disconnected-900 | restart-902);
    }
    down {
      administrative (forced-905 | forced-908 | none);
      failure (forced-904 | forced-908 | none);
      graceful (graceful-905 | none);
    }
    up {
      cancel-graceful (none | restart-918);
      failover-cold (failover-920 | restart-901);
      failover-warm (failover-919 | restart-902);
    }
  }
  virtual-interface-indications {
    virtual-interface-down {
      administrative (forced-905 | forced-906 | none);
      failure (forced-904 | forced-906 | none);
      graceful (graceful-905 | none);
      link-loss (forced-906 | none);
    }
    virtual-interface-up {
      cancel-graceful (none | restart-918);
      warm (none | restart-900);
    }
  }
  context-indications {
    state-loss (forced-910 | forced-915 | none);
  }
}

```

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-options]

Release Information Statement introduced in JUNOS Release 9.3.

Description Specify the method and reason that the virtual BGF includes in ServiceChange commands that it sends to the gateway controller when the state of a control association, virtual interface, or context changes.

Options The options are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

service-change-type

Syntax	service-change-type (forced-906 forced-910)
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> data-inactivity-detection report-service-change]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason used in changing the service state of the termination to active in order to curtail sending of inactivity messages.
Options	<p>forced-906—Service is terminated using a forced termination method with reason code 906 (loss of lower layer connectivity).</p> <p>forced-910—Service is terminated using a forced termination with reason code 910 (media capability failure).</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-interface

Syntax	service-interface <i>interface-name.unit-number</i> ;
Hierarchy Level	[edit services pgcp virtual-interface <i>virtual-interface-name</i> routing-instance]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the logical service interface. The NAT routes point to this service interface. This service interface must match the service interface configured in the routing instance.
Options	<i>interface-name.unit-number</i> —Name and logical interface number of the service interface.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-state

See the following sections:

- service-state (Virtual BGF) on page 595
- service-state (Virtual Interface) on page 596

service-state (Virtual BGF)

Syntax	service-state (in-service out-of-service-forced out-of-service-graceful);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Set the service state of the virtual BGF.
Options	<p>in-service—The virtual BGF is operational and available for traffic. When the virtual BGF is in service, it attempts to connect to the gateway controller and accepts all PGCP commands from the gateway controller.</p> <p>out-of-service-forced—Force the virtual BGF out of service. When the virtual BGF is forced out of service, it immediately removes all gates and disconnects from the gateway controller. The virtual BGF does not attempt to establish a new connection.</p> <p>out-of-service-graceful—Cause the virtual BGF to go out of service by entering a draining mode and waiting for all terminations to be subtracted before going out of service. During the draining, the BGF accepts only subtract commands from the gateway controller.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-state (Virtual Interface)

Syntax	service-state (in-service out-of-service-forced out-of-service-graceful);
Hierarchy Level	[edit services pgcp virtual-interface]
Release Information	Statement introduced in JUNOS Release 9.0.
Description	Set the service state of the virtual interface.
Options	<p>in-service—Virtual interface is operational and available for traffic. When the virtual interface is in service, it is connected to the physical interface and accepts all Voice calls. This is the default.</p> <p>out-of-service-forced—Force the virtual interface out of service. When the virtual interface is forced out of service, it immediately removes all calls and disconnects from the physical interface. The virtual interface does not attempt to establish a new connection.</p> <p>out-of-service-graceful—Cause the virtual interface goes out of service by entering a draining mode and waiting for all terminations to be subtracted before going out of service. During the draining, the virtual interface accepts only subtract commands from the gateway controller.</p>
Required Privilege Level	<p>interface-level—To view this statement in the configuration.</p> <p>interface-level—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

services

Syntax	services pgcp { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Define service rules to be applied to traffic.
Options	pgcp—Identifier for the PGCP set of rules statements.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

session-mirroring

Syntax	<pre> session-mirroring { delivery-function <i>delivery-function-name</i> { destination-address <i>destination-address</i>; destination-port <i>destination-port</i>; network-operator-id <i>network-operator-id</i>; source-address <i>source-address</i>; source-port <i>source-port</i>; } disable-session-mirroring; }</pre>
Hierarchy Level	[edit services pgcp] [edit services pgcp gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the session mirroring feature.
Options	The statements are explained separately.
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

source-address

Syntax	<pre> source-address <i>source-address</i>;</pre>
Hierarchy Level	[edit services pgcp session-mirroring delivery-function <i>deliver-function-name</i>] [edit services pgcp gateway <i>gateway-name</i> session-mirroring delivery-function <i>deliver-function-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the source address that is applied to mirrored packets.
Options	<i>source-address</i> —Address of the interface on which the BGF sends session-mirroring data to the delivery function.
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

source-port

Syntax	source-port <i>source-port</i> ;
Hierarchy Level	[edit services pgcp session-mirroring delivery-function <i>deliver-function-name</i>] [edit services pgcp gateway <i>gateway-name</i> session-mirroring delivery-function <i>deliver-function-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure the source port applied to the mirrored packets.
Options	<i>source-port</i> —Port on which the BGF sends session-mirroring data to the delivery function. Range: 1 through 65,535
Required Privilege Level	pgcp-session-mirroring—To view this statement in the configuration. pgcp-session-mirroring-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

state-loss

Syntax	state-loss (forced-910 forced-915 none);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change context-indications]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Service-Interruption ServiceChange commands that it sends to the gateway controller after a state loss on a specific context.
Default	If you do not specify an option, the virtual BGF includes FO/915 (forced-915).
Options	forced-910 —State loss because of a media failure. A mismatch between the pgcpd process and the MultiServices PIC or DPC states was detected on one or more of the context's gates. forced-915 —State loss. A mismatch between the pgcpd process and the MultiServices PIC or DPC states was detected on one or more of the context's gates. none —Virtual BGF does not send a ServiceChange command to the gateway controller.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

stop-detection-on-drop

Syntax	stop-detection-on-drop;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> data-inactivity-detection]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure the BGF to stop inactivity detection when a gate action is set to drop. When the call is resumed, the BGF starts the delay time and resumes data inactivity detection.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

sustained-data-rate

See the following sections:

- [sustained-data-rate](#) on page 600
- [sustained-data-rate \(RTCP Streams\)](#) on page 601

sustained-data-rate

Syntax `sustained-data-rate {
 default bytes-per-second;
 maximum bytes-per-second;
 minimum bytes-per-second;
 rtcp {
 fixed-value bytes-per-second;
 percentage percentage;
 }
}`

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-properties traffic-management]

Release Information Statement introduced in JUNOS Release 9.2.
 maximum and minimum options introduced in JUNOS Release 9.5.

Description Configure the sustained data rate for streams of any protocol, including RTP.

Default The BGF uses the default value of 10,000 bytes per second if the Policy command in H.248 messages in ON and both of the following apply:

- The sustained data rate is not set in the H.248 message.
- There is no CLI configuration for sustained data rate.

Options `default bytes-per-second`—Default value for sustained data rate.

Range: 125 through 4,294,967,295

`maximum bytes-per-second`—Maximum value for sustained data rate.

Range: 125 through 4,294,967,295

`minimum bytes-per-second`—Minimum value for sustained data rate.

Range: 125 through 4,294,967,295

Required Privilege Level `interface`—To view this statement in the configuration.
`interface-control`—To add this statement to the configuration.

Related Topics [JUNOS Multiplay Solutions Guide](#)

sustained-data-rate (RTCP Streams)

Syntax	<pre>sustained-data-rate { rtcp { fixed-value <i>bytes-per-second</i>; percentage <i>percentage</i>; } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-properties traffic-management]
Release Information	Statement introduced in JUNOS Release 9.2. maximum and minimum options introduced in JUNOS Release 9.5.
Description	Configure the sustained data rate for RTP/RTCP gate streams. You can configure this rate as a fixed value or as a percentage of RTP's sustained data rate..
Default	<p>The virtual BGF uses the default value of 5 percent of the RTP gates's rate if the Policy command in H.248 messages in ON and both of the following apply:</p> <ul style="list-style-type: none"> ■ The sustained data rate is not set in the H.248 message. ■ There is no CLI configuration for sustained data rate.
Options	<p>fixed-value —Value entered is a fixed number of bits per second.</p> <p><i>bytes-per-second</i>—Sustained data rate. Range: 125 through 4,294,967,295</p> <p>percentage <i>bytes-per-second</i>—Value entered is a percentage of the RTP's gate rate..</p> <p><i>percentage</i>—Value entered is a percentage of the RTP's gate rate.. Range: 0 through 1000</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

timerx

Syntax	<code>timerx seconds;</code>
Hierarchy Level	<code>[edit services pgcp gateway gateway-name h248-properties hanging-termination-detection]</code>
Release Information	Statement introduced in JUNOS Release 9.2.
Description	<p>Activate and configure hanging termination detection. Setting this timer to a value other than zero (0) activates hanging termination detection. If no messages are exchanged between the BGF and the gateway controller for a termination before this time expires, the BGF sends a notification to the gateway controller. The timer resets when the BGF and the gateway controller exchange a message for the termination. The timer value that you set is the default value, and can be overridden by H.248 messages sent from the gateway controller.</p> <p>Your configuration takes effect on new and modified terminations.</p>
Options	<p>seconds—Number of seconds between the last message exchanged for this termination and when the BGF sends a notification to the gateway controller. Setting the timer to zero (0) deactivates hanging termination detection.</p> <p>Range: 0 through 2,147,480</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

tmax-retransmission-delay

Syntax	<code>tmax-retransmission-delay milliseconds;</code>
Hierarchy Level	<code>[edit services pgcp gateway gateway-name h248-timers]</code>
Release Information	Statement introduced in JUNOS Release 8.4.
Description	Configure the maximum time that a transaction can be kept alive. T-Max is explained in Annex D of <i>Gateway control protocol v3, ITU-T Recommendation H.248.1, September 2005</i> .
Options	<p>milliseconds—Duration of the delay before the BGF considers the gateway controller to be down.</p> <p>Range: 0 through 65,535</p> <p>Default: 25000</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

traceoptions

Syntax

```

traceoptions {
  file {
    filename <filename>;
    files number-of-files;
    match regular-expression;
    size maximum-size;
    world-readable | no-world-readable;
  }
  flag {
    bgf-core {
      default trace-level;
      firewall trace-level;
      gate-logic trace-level;
      pic-broker trace-level;
      policy trace-level;
      statistics trace-level;
    }
    default trace-level;
    h248-stack {
      default trace-level;
      messages;
      control-association trace-level;
      media-gateway trace-level;
    }
    sbc-utils {
      common trace-level;
      configuration trace-level;
      device-monitor trace-level;
      ipc trace-level;
      memory-management trace-level;
      message trace-level;
      minimum trace-level;
      user-interface trace-level;
    }
  }
}

```

Hierarchy Level [edit services pgcp]

Release Information Statement introduced in JUNOS Release 8.4.
Statement extensively revised in JUNOS Release 9.5.

Description Configure PGCP tracing operations. The messages are output to /var/log/pgcpd.

Options The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

traffic-management

Syntax

```

traffic-management {
  peak-data-rate {
    default bytes-per-second;
    maximum bytes-per-second;
    minimum bytes-per-second;
    rtcp {
      fixed-value bytes-per-second;
      percentage percentage;
    }
  }
  sustained-data-rate {
    default bytes-per-second;
    maximum bytes-per-second;
    minimum bytes-per-second;
    rtcp {
      fixed-value bytes-per-second;
      percentage percentage;
    }
  }
  max-burst-size {
    default bytes;
    maximum bytes;
    minimum bytes;
    rtcp {
      fixed-value bytes;
      percentage percentage;
    }
  }
}

```

Hierarchy Level [edit services pgcp gateway *gateway-name* h248-properties]

Release Information Statement introduced in JUNOS Release 9.2.

Description Configure traffic management of the gate stream and the RTCP stream. The parameters for the RTCP stream take effect only when the gate is an RTP/RTCP gate.

Options The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

up

Syntax	up { cancel-graceful (none restart-918); failover-cold (failover-920 restart-901); failover-warm (failover-919 restart-902); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change control-association-indications]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Notification Messages or Registration commands in ServiceChange commands when a control association transitions to In-Service.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

use-lower-case

Syntax	use-lower-case;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure upper-case encoding for H.248 messages.
Default	By default H.248 messages are encoded in upper case.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

use-wildcard-response

Syntax	use-wildcard-response;
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Enable the virtual BGF to issue service change commands as wildcard-response commands, which trigger a short response from the gateway controller. If you do not enable the use of wildcard responses for service change commands, the gateway controller will generate an individual response for every termination that matches the service change command.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

virtual-interface

Syntax	virtual-interface <i>number</i> { media-service <i>media-service-name</i> ; interface <i>interface-identifier</i> ; routing-instance <i>instance-name</i> { service-interface <i>interface-name.unit-number</i> ; } service-state (in-service out-of-service-forced out-of-service-graceful); }
Hierarchy Level	[edit services pgcp]
Release Information	Statement introduced in JUNOS Release 8.4. service-state option introduced in JUNOS Release 9.0. service-interface option introduced in JUNOS Release 9.3.
Description	Configure a virtual interface for the BGF.
Options	<i>number</i> —Identifier for the interface. Range: 0 through 1023 The remainder of the statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

virtual-interface-down

Syntax	virtual-interface-down { administrative (forced-905 forced-906 none); failure (forced-904 forced-906 none); graceful (graceful-905 none); link-loss (forced-906 none); }
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in ServiceChange commands that it sends to the gateway controller when the state of the virtual interface changes to Out-of-Service.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

virtual-interface-indications

Syntax	<pre>virtual-interface-indications { virtual-interface-down { administrative (forced-905 forced-906 none); failure (forced-904 forced-906 none); graceful (graceful-905 none); link-loss (forced-906 none); } virtual-interface-up { cancel-graceful (none restart-918); warm(none restart-900); } }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in ServiceChange commands that it sends to the gateway controller when the state of the virtual interface changes.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

virtual-interface-up

Syntax	<pre>virtual-interface-up { cancel-graceful (none restart-918); warm (none restart-900); }</pre>
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the ServiceChange command that the virtual BGF sends to the gateway controller when the state of the virtual interface changes to In-Service.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

warm

Syntax	warm (none restart-900);
Hierarchy Level	[edit services pgcp gateway <i>gateway-name</i> h248-options service-change virtual-interface-indications virtual-interface-up]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the method and reason that the virtual BGF includes in Service-Restoration ServiceChange commands that it sends to the gateway controller when a virtual interface transitions to In-Service.
Default	If you do not specify an option, the virtual BGF includes RS/900 (restart-900).
Options	<p>none—Virtual BGF does not send a ServiceChange command.</p> <p>restart-900—Service restored. The virtual interface has become In-Service and is in the Forwarding state.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

Chapter 28

Service Interface Pools Configuration Guidelines

To configure service interface pools, include the `service-interface-pools` statement at the `[edit services]` hierarchy level:

```
[edit services]
service-interface-pools {
  pool pool-name {
    interface interface-name.unit-number;
  }
}
```

This chapter discusses the following topics that provide information about configuring service interface pools:

- [Configuring Service Interface Pools on page 611](#)

Configuring Service Interface Pools

To configure a service interface pool, include the following statements at the `[edit services service-interface-pools]` hierarchy level:

```
[edit services service-interface-pools]
pool pool-name {
  interface interface-name.unit-number;
}
```


Chapter 29

Summary of Service Interface Pools Statements

The following sections explain each of the service interface pools statements. The statements are organized alphabetically.

interface

Syntax `interface interface-name.unit-number;`

Hierarchy Level `[edit services service-interface-pools pool pool-name]`

Release Information Statement introduced in JUNOS Release 9.3.

Description Add logical service interfaces to the pool of service interfaces.

Options *interface-name.unit-number*—Name and logical unit number of the service interface.

- All interfaces in a pool must belong to the same service PIC or DPC.
- All interfaces assigned to the same service must be in the same pool.
- Logical interfaces cannot be in more than one pool.
- All interfaces must have either **family inet** or **family inet6** configured.
- Logical unit 0 cannot be configured in a service interface pool.
- You can configure up to 1000 logical interfaces in a service interface pool.

Required Privilege Level `interface`—To view this statement in the configuration.
`interface-control`—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

pool

Syntax	<code>pool <i>pool-name</i> { interface <i>interface-name.unit-number</i>; }</code>
Hierarchy Level	[edit services service-interface-pools]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure a service interface pool for VPN aggregation for the BGF feature.
Options	<i>pool-name</i> —Name of the service interface pool. The remaining options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-interface-pools

Syntax	<code>service-interface-pools { pool <i>pool-name</i> { interface <i>interface-name.unit-number</i>; } }</code>
Hierarchy Level	[edit services]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Configure service interface pools used for VPN aggregation.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

Chapter 30

Border Signaling Gateway Configuration Guidelines

To configure border signaling gateways (BSG), include the `border-signaling-gateway` statement at the `[edit services]` hierarchy level:

```
[edit services]
border-signaling-gateway {
  gateway gateway-name {
    embedded-spdp {
      service-class service-class-name {
        term term-name {
          from {
            media-type (any-media | audio | video);
          }
          then {
            committed-burst-size bytes;
            committed-information-rate bytes-per-second;
            dscp (alias | do-not-change | dscp-value);
            reject;
          }
        }
      }
    }
  }
  service-interface name;
  service-point service-point-name {
    service-point-type service-point-type;
    transport-details port port-number ip-address ip-address [tdp |udp];
    service-interface interface-name.unit-number;
    service-policies {
      new-call-usage-policies [ policy-and-policy-set-names ];
      new-transaction-policies [ policy-and-policy-set-names ];
    }
  }
}
sip {
  new-call-usage-policy policy-name {
    term term-name {
      from {
        contact [ contact-fields ];
        method {
          method-invite;
        }
      }
      request-uri [ uri-fields ];
    }
  }
}
```

```

        source-address [ ip-addresses ];
    }
    then {
        (accept | reject);
        media-policy {
            no-anchoring;
            service-class service-class-name;
        }
        trace;
    }
}
}
new-call-usage-policy-set policy-set-name {
    policy-name [ policy-names ];
}
new-transaction-policy policy-name {
    term term-name {
        from {
            contact [ contact-fields ];
            method {
                method-invite;
                method-message;
                method-options;
                method-publish;
                method-refer;
                method-register;
                method-subscribe;
            }
            request-uri [ uri-fields ];
            source-address [ ip-addresses ];
        }
        then {
            (accept | reject);
            route {
                egress-service-point service-point-name;
                next-hop (request-uri | address ipv4-address <port port-number>
                    <transport-protocol (udp|tcp)>);
            }
            trace;
        }
    }
}
}
new-transaction-policy-set policy-set-name {
    policy-name [ policy-name ];
}
timers {
    inactive-call seconds;
    timer-c seconds;
}
}
traceoptions {
    file {
        filename filename;
        files number-of-files;
        match regular-expression;
        size maximum-trace-file-size;
    }
}

```



```

}
flag {
  datastore {
    data trace-level;
    db trace-level;
    handle trace-level;
    minimum trace-level;
  }
  framework {
    action trace-level;
    event trace-level;
    executor trace-level;
    freezer trace-level;
    minimum trace-level;
    memory-pool trace-level;
  }
  minimum trace-level;
  sbc-utils {
    common trace-level;
    configuration trace-level;
    device-monitor trace-level;
    ipc trace-level;
    memory-management trace-level;
    message trace-level;
    minimum trace-level;
    user-interface trace-level;
  }
  session-trace trace-level;
  signaling {
    b2b trace-level;
    b2b-wrapper trace-level;
    minimum trace-level;
    policy trace-level;
    sip-stack-wrapper trace-level;
    topology-hiding trace-level;
    ua trace-level;
  }
  sip-stack {
    dev-logging;
    event-tracing;
    ips-tracing;
    pd-log-detail (full | summary);
    pd-log-level (audit | exception | problem);
    per-tracing;
    verbose-logging;
  }
}
}
}
}
}

```

For information about configuring the border signaling gateway, see the *JUNOS Multiplay Solutions Guide*.

Chapter 31

Summary of Border Signaling Gateway Configuration Statements

The following sections explain each of the border signaling gateway statements. The statements are organized alphabetically.

admission-control

admission-control (Border Signaling Gateway)

Syntax admission-control *controller-name* {
 dialogs {
 maximum-concurrent *number*;
 committed-attempts-rate *dialogs-per-second*;
 committed-burst-size *number-of-dialogs*;
 }
 transactions {
 maximum-concurrent *number*;
 committed-attempts-rate *transactions-per-second*;
 committed-burst-size *number-of-transactions*;
 }
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Configure an admission controller for a BSG.

Options *controller-name*—Name of the admission controller.



NOTE: You can define a maximum of 100 controllers for a BSG.

Other options are described separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

admission-control (New Call Usage Policy)

Syntax admission-control *controller-name*

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip new-call-usage-policy *policy-name* term *term-name* then]

Release Information Statement introduced in JUNOS Release 9.5.

Description Specifies the CAC admission controller used for this policy.

Options *controller-name*—Name of the admission controller used for this policy.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

committed-burst-size

Syntax	committed-burst-size <i>bytes</i> ;
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> embedded-spdf service-class <i>service-class-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the maximum number of bytes allowed for incoming packets to burst above the committed information rate.
Options	<i>bytes</i> —Number of bytes. Range: 20 through 4,294,967,295 Default: 10,000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

committed-information-rate

Syntax	committed-information-rate <i>bytes-per-second</i> ;
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> embedded-spdf service-class <i>service-class-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the maximum bandwidth that can be allocated to a packet that is flowing under normal line conditions.
Options	<i>bytes-per-second</i> —Number of bytes per second. Range: 125 through 4,294,967,295 Default: 2000
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

datastore

Syntax `datastore {
 data trace-level;
 db trace-level;
 handle trace-level;
 minimum trace-level;
 }`

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* traceoptions flag]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure trace level options for the datastore component of the BSG.

Options `data trace-level`—Trace level for the **data** subcomponent.

`db trace-level`—Trace level for the wrapper layer around the database.

`handle trace-level`—Trace level for the access API for the database.

`minimum trace-level`—Minimum trace level for all **datastore** messages.

trace-level—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the *trace-level*:

- `debug`—Logging of all code flow of control.
- `trace`—Logging of program trace START and EXIT macros.
- `info`—Summary logs for normal operations, such as the policy decisions made for a call.
- `warning`—Failure recovery or failure of an external entity.
- `error`—Failure with a short-term effect, such as failed processing of a single call.

Required Privilege Level `interface`—To view this statement in the configuration.
 `interface-control`—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

dialogs

Syntax	dialogs { maximum-concurrent <i>number</i> ; committed-attempts-rate <i>dialogs-per-second</i> ; committed-burst-size <i>number-of-dialogs</i> ; }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> admission-control]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure admission control settings for dialogs.
Options	<p>maximum-concurrent <i>number</i>—Maximum number of concurrent dialogs. 0 causes all calls to be rejected. Values: 0 through 100,000 Default: 100000</p> <p>committed-attempts-rate <i>dialogs-per-second</i>—.Maximum number of attempts per second to initiate a dialog. Values: 0 though 100 Default: 100</p> <p>committed-burst-size <i>number-of-dialogs</i>—Maximum number of dialogs allowed to burst above the committed-rate and still be accepted.</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

dscp

Syntax	<code>dscp (dscp-value alias do-not-change);</code>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> embedded-spdf service-class <i>service-class-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure values for DSCP marking that the BSG uses for traffic that matches the service class term.
Options	<p><i>dscp-value</i>—String of eight bits or a 1-byte hexadecimal value using the format: 0xXX.</p> <p><i>alias</i>—Standard DSCP name. Use the ? in the CLI to see a list of aliases.</p> <p><i>do-not-change</i>—Do not override the DSCP value in the packet.</p> <p>Default: be</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

egress-service-point

Syntax	<code>egress-service-point service-point-name;</code>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip new-transaction-policy <i>policy-name</i> term <i>term-name</i> then route]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the exit point of SIP requests from the BSG.
Options	<i>service-point-name</i> —Name of the service point that you want to use as the egress service point. This is a service point that you configure with the service-point statement.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

embedded-spdf

Syntax

```

embedded-spdf {
  service-class service-class-name {
    term term-name {
      from {
        media-type (any-media | audio | video);
      }
      then {
        committed-burst-size bytes;
        committed-information-rate bytes-per-second;
        dscp (dscp-value | alias | do-not-change);
        reject;
      }
    }
  }
}

```

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name*]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure an SPDF (session policy decision function). Each BSG instance consists of a single embedded SPDF that includes one or more service classes.

Options The options are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

file

Syntax	file <filename> <files files> <match <i>regular-expression</i> > <size <i>maximum-file-size</i> > <world-readable no-world-readable>;
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> traceoptions]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the trace file for tracing BSG components.
Options	<p>filename <i>filename</i>—Name of the file to which the tracing messages are written. Default: bsg_trace</p> <p>files <i>number-of-files</i>—Number of trace files. The tracing mechanism can rotate between any given number of files, allowing for trace message inspection without interfering with the normal work of the application. Default: 3</p> <p>match <i>regular expression</i>—Regular expression to match with incoming messages. Messages that do not match the regular expression are not written to the trace file.</p> <p>size <i>maximum-trace-file-size</i>—Size parameter (in bytes) to trigger rotation of files. The trace mechanism rotates files based on the current file size. When the size is bigger than the maximum configured size, the files are rotated.</p> <p>world-readable no-world-readable—Allow all users to use the log file or disallow all users from using the log file. Default: 1048576</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

flag

```

Syntax  flag {
    datastore {
        data trace-level;
        db trace-level;
        handle trace-level;
        minimum trace-level;
    }
    framework {
        action trace-level;
        event trace-level;
        executor trace-level;
        freezer trace-level;
        minimum trace-level;
        memory-pool trace-level;
    }
    minimum trace-level;
    sbc-utils {
        common trace-level;
        configuration trace-level;
        device-monitor trace-level;
        ipc trace-level;
        memory-management trace-level;
        message trace-level;
        minimum trace-level;
        user-interface trace-level;
    }
    session-trace trace-level;
    signaling {
        b2b trace-level;
        b2b-wrapper trace-level;
        minimum trace-level;
        policy trace-level;
        sip-stack-wrapper trace-level;
        topology-hiding trace-level;
        ua trace-level;
    }
    sip-stack {
        dev-logging;
        event-tracing;
        ips-tracing;
        pd-log-detail (full | summary);
        pd-log-level (audit | exception | problem);
        per-tracing;
        verbose-logging;
    }
}

```

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* traceoptions]

Release Information Statement introduced in JUNOS Release 9.4.

Description	Configure trace options for components of the BSG.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

framework

Syntax	<pre>framework { action <i>trace-level</i>; event <i>trace-level</i>; executor <i>trace-level</i>; freezer <i>trace-level</i>; minimum <i>trace-level</i>; memory-pool <i>trace-level</i>; }</pre>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> traceoptions flag]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure trace options for the BSG component that provides an infrastructure that enables incremental functionality implementation.
Options	<p>action <i>trace-level</i>—Trace level for the framework subcomponent that creates, initiates, and manipulates event actions.</p> <p>event <i>trace-level</i>—Trace level for the framework subcomponent that creates, modifies, and terminates event members.</p> <p>executor <i>trace-level</i>—Trace level for the framework subcomponent that executes configured actions for an event, handles any error states, delays processing, and so on.</p> <p>freezer <i>trace-level</i>—Trace level for the framework subcomponent that delays the execution of an event until certain conditions are met.</p> <p>minimum <i>trace-level</i>—Minimum trace level for all framework messages.</p> <p>memory-pool <i>trace-level</i>—Trace level for the framework subcomponent that creates, deletes, and manipulates memory pools and pool managers, and controls the check-in and check-out of memory objects to and from memory pools.</p> <p><i>trace-level</i>—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the <i>trace-level</i>:</p> <ul style="list-style-type: none"> ■ debug—Logging of all code flow of control. ■ trace—Logging of program trace START and EXIT macros. ■ info—Summary logs for normal operations, such as the policy decisions made for a call. ■ warning—Failure recovery or failure of an external entity. ■ error—Failure with a short-term effect, such as failed processing of a single call.
Required Privilege Level	interface—To view this statement in the configuration.

interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

from

See the following sections:

- from (New Call Usage Policy) on page 632
- from (New Transaction Policy) on page 633
- from (Service Class) on page 634

from (New Call Usage Policy)

Syntax	<pre> from { contact { regular-expression [<i>regular-expression</i>]; } method { method-invite; } request-uri { regular-expression [<i>regular-expression</i>]; } source-address [<i>ip-addresses</i>]; } </pre>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip new-call-usage-policy <i>policy-name</i> term <i>term-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4. regular-expression options introduced in JUNOS Release 9.5.
Description	Configure match conditions for a new call usage policy.
Options	<p>contact—Match the contents of the contact field. Contact field matching is based on regular expressions.</p> <p>regular expression [<i>regular-expression</i>]—Regular expression used to match the contents of the contact field. Syntax: To specify more than one regular expression, enclose the regular expressions in brackets.</p> <p>method-invite—Match the policy to SIP INVITE methods.</p> <p>request-uri—Match the contents of the uniform resource identifier (URI) in the SIP message request. Request URI matching is based on regular expressions.</p> <p>regular expression [<i>regular-expression</i>]—Regular expression used to match the contents of the request URI field. Syntax: To specify more than one regular expression, enclose the regular expressions in brackets.</p> <p>source-address—Match the source address of the SIP request.</p> <p>[<i>ip-addresses</i>]—IP addresses that you want to match. Syntax: To specify more than one IP address, enclose the IP addresses in brackets.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

from (New Transaction Policy)

Syntax	<pre> from { contact { regular-expression [<i>regular-expression</i>]; } method { method-invite; method-message; method-options; method-publish; method-refer; method-register; method-subscribe; } request-uri { regular-expression [<i>regular-expression</i>]; } source-address [<i>ip-addresses</i>]; } </pre>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip new-transaction-policy <i>policy-name</i> term <i>term-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4. regular-expression options introduced in JUNOS Release 9.5.
Description	Configure match conditions for a new transaction policy.
Options	<p>contact—Match the contents of the contact field. Contact field matching is based on regular expressions.</p> <p>regular expression [<i>regular-expression</i>]—Regular expression used to match the contents of the contact field. Syntax: To specify more than one regular expression, enclose the regular expressions in brackets.</p> <p>method—Match the type of SIP method. Syntax: To specify multiple SIP methods, use separate set statements.</p> <p>request-uri—Match the contents of the uniform resource identifier (URI) in the SIP message request. Request URI matching is based on regular expressions.</p> <p>regular expression [<i>regular-expression</i>] —Regular expression used to match the contents of the request URI field. Syntax: To specify more than one regular expression, enclose the regular expressions in brackets.</p> <p>source-address—Match the source address of the SIP request.</p> <p>[<i>ip-addresses</i>]—IP addresses that you want to match. Syntax: To specify more than one IP address, enclose the IP addresses in brackets.</p>

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

from (Service Class)

Syntax from {
 media-type (any-media | audio | video);
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* embedded-spdf
 service-class *service-class-name* term *term-name*]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure match conditions for a service class.

Options The options are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

gateway

```

Syntax gateway gateway-name {
    admission-control controller-name{
        dialogs {
            maximum-concurrent number;
            committed-attempts-rate dialogs-per-second;
            committed-burst-size number-of-dialogs;
        }
        transactions {
            maximum-concurrent number;
            committed-attempts-rate transactions-per-second;
            committed-burst-size number-of-transactions;
        }
    }
    embedded-spdf {
        service-class service-class-name {
            term term-name {
                from {
                    media-type (any-media | audio | video);
                }
                then {
                    committed-burst-size bytes;
                    committed-information-rate bytes-per-second;
                    dscp (alias | do-not-change | dscp-value);
                    reject;
                }
            }
        }
    }
    service-interface name;
    service-point service-point-name {
        service-point-type service-point-type;
        transport-details port port-number ip-address ip-address [tdp | udp];
        service-interface interface-name.unit-number;
        service-policies {
            new-call-usage-policies [ policy-and-policy-set-names ];
            new-transaction-policies [ policy-and-policy-set-names ];
        }
    }
    sip {
        new-call-usage-policy policy-name {
            term term-name {
                from {
                    contact [ contact-fields ];
                    method {
                        method-invite;
                    }
                    request-uri [ uri-fields ];
                    source-address [ ip-addresses ];
                }
                then {
                    (accept | reject);
                    media-policy {

```

```

        no-anchoring;
        service-class service-class-name;
    }
    trace;
}
}
}
new-call-usage-policy-set policy-set-name {
    policy-name [ policy-names ];
}
new-transaction-policy policy-name {
    term term-name {
        from {
            contact [ contact-fields ];
            method {
                method-invite;
                method-message;
                method-options;
                method-publish;
                method-refer;
                method-register;
                method-subscribe;
            }
            request-uri [ uri-fields ];
            source-address [ ip-addresses ];
        }
        then {
            (accept | reject);
            route {
                egress-service-point service-point-name;
                next-hop (request-uri | (address ipv4-address <port port-number>
                    <transport-protocol (udp | tcp)>);
            }
            trace;
        }
    }
}
new-transaction-policy-set policy-set-name {
    policy-name [ policy-names ];
}
timers {
    inactive-call seconds;
    timer-c seconds;
}
}
traceoptions {
    file <filename> <files files> <match regular-expression> <size maximum-file-size>
        <world-readable | no-world-readable>;
    flag {
        datastore {
            data trace-level;
            db trace-level;
            handle trace-level;
            minimum trace-level;
        }
        framework {

```

```

        action trace-level;
        event trace-level;
        executor trace-level;
        freezer trace-level;
        minimum trace-level;
        memory-pool trace-level;
    }
    minimum trace-level;
    sbc-utils {
        common trace-level;
        configuration trace-level;
        device-monitor trace-level;
        ipc trace-level;
        memory-management trace-level;
        message trace-level;
        minimum trace-level;
        user-interface trace-level;
    }
    session-trace trace-level;
    signaling {
        b2b trace-level;
        b2b-wrapper trace-level;
        minimum trace-level;
        policy trace-level;
        sip-stack-wrapper trace-level;
        topology-hiding trace-level;
        ua trace-level;
    }
    sip-stack {
        dev-logging;
        event-tracing;
        ips-tracing;
        pd-log-detail (full | summary);
        pd-log-level (audit | exception | problem);
        per-tracing;
        verbose-logging;
    }
}
}
}

```

Hierarchy Level	[edit services border-signaling-gateway]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure a border signaling gateway instance.
Options	<p><i>gateway-name</i>—Identifier for the BSG.</p> <p>The remaining statements are explained separately.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

media-policy

Syntax	media-policy { no-anchoring; service-class <i>service-class-name</i> ; }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip new-call-usage-policy <i>policy-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 9.4. no-anchoring statement introduced in JUNOS Release 9.5. service-class statement introduced in JUNOS Release 9.5.
Description	Configure the service class to be applied to traffic that matches the new call usage policy.
Options	no-anchoring—Disable or enable media anchoring for the policy. service-class <i>service-class-name</i> —Name of the service class to be applied to traffic that matches the new call usage policy. You must have configured the service class using the service-class statement at the [edit services border-signaling-gateway <i>gateway gateway-name</i> embedded-spdf] hierarchy level.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

media-type

Syntax	media-type (any-media audio video);
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> service-class <i>service-class-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the type of media that the service class matches.
Options	any-media—Match all media types. audio—Match audio traffic. video—Match video traffic.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

minimum

Syntax	<code>minimum trace-level;</code>
Hierarchy Level	<code>[edit services border-signaling-gateway gateway gateway-name traceoptions flag flag]</code>
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the minimum trace level for all selected BSG trace options. This option overrides individual trace options that are set at a lower level.
Default	warning
Options	<p><i>trace-level</i>—Enter one of the following trace levels as the <i>trace-level</i>:</p> <ul style="list-style-type: none"> ■ debug—Logging of all code flow of control. ■ trace—Logging of program trace START and EXIT macros. ■ info—Summary logs for normal operations, such as the policy decisions made for a call. ■ warning—Failure recovery or failure of an external entity. ■ error—Failure with a short-term effect, such as failed processing of a single call.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

new-call-usage-policies

Syntax	<code>new-call-usage-policies [policy-and-policy-set-names];</code>
Hierarchy Level	<code>[edit services border-signaling-gateway gateway gateway-name service-point service-point-name service-policies]</code>
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Assign new call usage policies or policy sets to the service point. All the packets arriving at the service point are matched to these policies.
Options	<p><code>[policy-and-policy-set-names]</code>—Names of new call usage policies or policy sets.</p> <p>Syntax: If you specify more than one policy or policy set, you must enclose all policy names in brackets.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

new-call-usage-policy

Syntax `new-call-usage-policy policy-name {
 term term-name {
 from {
 contact [contact-fields];
 method {
 method-invite;
 }
 request-uri [uri-fields];
 source-address [ip-addresses];
 }
 then {
 (accept | reject);
 media-policy {
 no-anchoring;
 service-class service-class-name;
 }
 trace;
 }
 }
 }`

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure a new call usage policy. A call is a usage that begins with a new INVITE. Dialogs can have many different usages.

Options *policy-name*—Identifier for the new call usage policy.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

new-call-usage-policy-set

Syntax	new-call-usage-policy-set <i>policy-set-name</i> { policy-name [<i>policy-names</i>]; }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Create a set of new call usage policies, which you can then apply to a service point. The order in which you add policies to the set determines the order in which the BSG processes the policies. The first matching policy determines which actions are taken.
Options	<p><i>policy-set-name</i>—Identifier for the new call usage policy set.</p> <p><i>policy-names</i>—Names of one or more new call usage policies that you want to add to the set.</p> <p>Syntax: To specify a list of policies, enclose the policy names in brackets.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

new-transaction-policies

Syntax	new-transaction-policies [<i>policy-and-policy-set-names</i>];
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> service-point <i>service-point-name</i> service-policies]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Assign new transaction policies or policy sets to the service point. All packets arriving at the service point are matched to these policies.
Options	<p>[<i>policy-and-policy-set-names</i>]—Names of new call usage policies or policy sets.</p> <p>Syntax: To specify more than one policy or policy set, enclose the policy names in brackets.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

new-transaction-policy

Syntax `new-transaction-policy policy-name {
 term term-name {
 from {
 contact [contact-fields];
 method {
 method-invite;
 method-message;
 method-options;
 method-publish;
 method-refer;
 method-register;
 method-subscribe;
 }
 request-uri [uri-fields];
 source-address [ip-addresses];
 }
 then {
 (accept | reject);
 route {
 egress-service-point service-point-name;
 next-hop (request-uri | address ipv4-address <port port-number>
 <transport-protocol (udp|tcp)>);
 }
 trace;
 }
 }
 }`

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip]

Release Information Statement introduced in JUNOS Release 9.4.

Description Specify new transaction policies for out-of-dialog transactions including dialog-opening transactions. Transaction policies are useful when the policy does not need to differentiate between events. For example, you can use new transaction policies to route all transactions according to the same rules.

Options *policy-name*—Identifier for the new transaction policy.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

new-transaction-policy-set

Syntax	new-transaction-policy-set <i>policy-set-name</i> { policy-name [<i>policy-names</i>]; }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Create a set of new transaction policies, which you can then apply to a service point. The order in which you add policies to the set determines the order in which the BSG processes the policies. The first matching policy determines which actions are taken.
Options	<p><i>policy-set-name</i>—Identifier for the new transaction policy set.</p> <p>[<i>policy-names</i>]—Names of one or more new transaction policies that you want to add to the set.</p> <p>Syntax: To specify a list of policies, enclose the policy names in brackets.</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

next-hop

Syntax	next-hop (request-uri address <i>ipv4-address</i> <port <i>port-number</i> > <transport-protocol (udp tcp)>);
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip new-transaction-policy <i>policy-name</i> term <i>term-name</i> then route]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Specify the SIP entity towards which SIP requests are sent.
Options	<p>request-uri—All requests and responses on the dialog are routed according to SIP. The software resolves the uniform resource identifier (URI) in the SIP message request into the IP address, port, and transport protocol of the next hop to contact.</p> <p>address <i>ipv4-address</i>—Destination IPv4 address of the next hop to contact. This static address applies to all incoming requests on the dialog.</p> <p>port—(Optional) Destination port of the next hop to contact. Default: 5060</p> <p>transport-protocol (udp tcp)—(Optional) Transport protocol for routing to the next hop. Default: udp</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

route

Syntax	route { egress-service-point <i>service-point-name</i> ; next-hop { (request-uri address <i>ipv4-address</i> <port <i>port-number</i> > <transport-protocol (tcp udp)>); } }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip new-transaction-policy <i>policy-name</i> term <i>term-name</i> then]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure the next-hop destination and egress service point for a new transaction policy.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

sbc-utils

Syntax sbc-utils {
 common *trace-level*;
 configuration *trace-level*;
 device-monitor *trace-level*;
 ipc *trace-level*;
 memory-management *trace-level*;
 message *trace-level*;
 minimum *trace-level*;
 user-interface *trace-level*;
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* traceoptions flag]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure trace options for the Signaling Border Controller (SBC) utilities component of the BSG.

Default warning

Options common *trace-level*—Trace level for the common component of SBC utilities.

 configuration *trace-level*—Trace level for the configuration component of SBC utilities.

 device-monitor *trace-level*—Trace level for the device monitor component of SBC utilities.

 ipc *trace-level*—Trace level for the IPC component of SBC utilities.

 memory-management *trace-level*—Trace level for the memory management component of SBC utilities.

 message *trace-level*—Trace level for the message component of SBC utilities.

 minimum *trace-level*—Minimum trace level for all sbc-util messages.

 user-interface *trace-level*—Trace level for the user interface component of SBC utilities.

trace-level—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the *trace-level*:

- debug—Logging of all code flow of control.
- trace—Logging of program trace START and EXIT macros.
- info—Summary logs for normal operations, such as the policy decisions made for a call.
- warning—Failure recovery or failure of an external entity.
- error—Failure with a short-term effect, such as failed processing of a single call.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

service-class

Syntax

```
service-class service-class-name {
    term term-name {
        from {
            media-type (any-media | audio | video);
        }
        then {
            committed-burst-size bytes;
            committed-information-rate bytes-per-second;
            dscp (alias | do-not-change | dscp-value);
            reject;
        }
    }
}
```

Hierarchy Level [edit services border-signaling-gateway gateway gateway-name embedded-spdf]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure service classes for the embedded SPDF. Service classes contain rules that pertain to the treatment of bandwidth for various media types. Each rule (or term) consists of a **from** statement and a **then** statement. The **from** statement matches traffic based on the media type. The **then** statement is a set of one or more actions that are applied if a call matches the from statement.

Options *service-class-name*—Identifier for the service class.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

service-interface

See the following sections:

- service-interface (Gateway) on page 648
- service-interface (Service Point) on page 648

service-interface (Gateway)

Syntax	<code>service-interface interface-name.unit-number;</code>
Hierarchy Level	<code>[edit services border-signaling-gateway gateway gateway-name]</code>
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Assign the BSG to a MultiServices PIC or DPC. The PIC or DPC must have been configured at the <code>[edit interfaces]</code> hierarchy. You can assign only one BSG to a MultiServices PIC or DPC.
Options	<code>interface-name.unit-number</code> —Name and logical unit number of the MultiServices PIC or DPC.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-interface (Service Point)

Syntax	<code>service-interface name;</code>
Hierarchy Level	<code>[edit services border-signaling-gateway gateway gateway-name service-point service-point-name]</code>
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Assign the service point to a service interface. The policies attached to the service point are matched against incoming requests received on this service interface.
Options	<code>name</code> —Name of the service interface. The interface must have been configured at the <code>[edit interfaces]</code> hierarchy. Default: 0
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-point

Syntax	<pre> service-point <i>service-point-name</i> { transport-details port <i>port-number</i> ip-address <i>ip-address</i> [tdp udp]; service-interface <i>interface-name.unit-number</i>; service-point-type <i>service-point-type</i>; service-policies { new-call-usage-policies [<i>policy-and-policy-set-names</i>]; new-transaction-policies [<i>policy-and-policy-set-names</i>]; } } </pre>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	<p>Configure a service point. Service points identify a service interface and transport parameters for incoming requests. You attach policies to the service point, and all requests that arrive at the service point are handled by these policies. Each BSG can have five service points.</p> <p>You can also configure a service point to be used as an egress service point to which SIP requests are routed.</p>
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-point-type

Syntax	service-point-type <i>service-point-type</i> ;
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> service-point <i>service-point-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Create the type of VoIP protocol for this service point.
Options	<i>service-point-type</i> —VoIP protocol. Currently the only protocol type supported is SIP. Values: sip
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

service-policies

Syntax	service-policies { new-call-usage-policies [<i>policy-and-policy-set-names</i>]; new-transaction-policies [<i>policy-and-policy-set-names</i>]; }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> service-point <i>service-point-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Specify the policies and policy sets that are applied to the service point.
Options	The options are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

services

Syntax	services border-signaling-gateway { ... }
Hierarchy Level	[edit]
Description	Define service rules to be applied to traffic.
Options	border-signaling-gateway—Identifier for the BSG set of statements.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

session-trace

Syntax	session-trace handle <i>trace-level</i> ;
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> traceoptions flag]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure tracing for transactions matching policies that have their trace flag turned on. The tracing level is effective for dialog-creating messages (such as INVITE) and out-of-dialog messages. When these message types are accepted in the policy and the policy is set to trace messages, the policy marks the dialog (and the sibling dialog) for session tracing.
Default	warning
Options	<p>minimum <i>trace-level</i>—The minimum trace level for all session-trace messages.</p> <p><i>trace-level</i>—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the <i>trace-level</i>:</p> <ul style="list-style-type: none"> ■ debug—Logging of all code flow of control. ■ trace—Logging of program trace START, EXIT macros. ■ info—Summary logs for normal operations e.g. the policy decisions made for a call. ■ warning—Failure-recovery or failure of an external entity. ■ error—Failure with short-term effect, such as failed processing of a single call.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

signaling

Syntax signaling {
 b2b *trace-level*;
 b2b-wrapper *trace-level*;
 minimum *trace-level*;
 policy *trace-level*;
 sip-stack-wrapper *trace-level*;
 topology-hiding *trace-level*;
 ua *trace-level*;
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* traceoptions flag]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure trace options for the signaling component of the BSG.

Default warning

Options *b2b trace-level*—Trace options for the signaling component that implements the b2b logic (translating between dialogs, associating dialogs, creating new downstream dialogs, and so on).

b2b-wrapper trace-level—Trace options for entry and exit to the BSG signaling application.

minimum trace-level—Minimum trace level for all **signaling** messages.

policy trace-level—Trace options for the signaling component that applies policies for call admission, routing decisions, security settings, and so on.

sip-stack-wrapper trace-level—Trace options for the glue layer that receives events from the SIP stack and forwards them to the application and, conversely, receives events from the application and forwards them to the SIP stack.

topology-hiding trace-level—Trace options for the signaling component that hides the network topology of a network by CONTACT replacement and removal or modification of certain headers.

ua trace-level—Trace options for the signaling subcomponent that handles RECEIVE messages.

trace-level—Trace level options are related to the severity of the event being traced. When you choose a trace level, messages at that level and higher levels are captured. Enter one of the following trace levels as the *trace-level*:

- **debug**—Logging of all code flow of control.
- **trace**—Logging of program trace START, EXIT macros.
- **info**—Summary logs for normal operations e.g. the policy decisions made for a call.

- warning—Failure-recovery or failure of an external entity.
- error—Failure with short-term effect, such as failed processing of a single call.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

sip

```

Syntax  sip {
    new-call-usage-policy policy-name {
    term term-name {
        from {
            contact [ contact-fields ];
            method {
                method-invite;
            }
            request-uri [ uri-fields ];
            source-address [ ip-addresses ];
        }
        then {
            (accept | reject);
            media-policy {
                no-anchoring;
                service-class service-class-name;
            }
            trace;
        }
    }
    new-call-usage-policy-set policy-set-name {
        policy-name [ policy-names ];
    }
    new-transaction-policy policy-name {
    term term-name {
        from {
            contact [ contact-fields ];
            method {
                method-invite;
                method-message;
                method-options;
                method-publish;
                method-refer;
                method-register;
                method-subscribe;
            }
            request-uri [ uri-fields ];
            source-address [ ip-addresses ];
        }
        then {
            (accept | reject);
            route {
                egress-service-point service-point-name;
                next-hop (request-uri | address ipv4-address | <port port-number>
                    <transport-protocol (udp | tcp)>);
            }
            trace;
        }
    }
    }
    new-transaction-policy-set policy-set-name {

```

```
    policy-name [ policy-names ];  
  }  
  timers {  
    inactive-callseconds;  
    timer-c seconds;  
  }  
}
```

Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure SIP policies and timers.
Options	The statements are explained separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

sip-stack

Syntax

```
sip-stack {
  dev-logging;
  event-tracing;
  ips-tracing;
  pd-log-detail (full | summary);
  pd-log-level (audit | exception | problem);
  per-tracing;
  verbose-logging;
}
```

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* traceoptions flag]

Release Information Statement introduced in JUNOS Release 9.4.

Description Set trace options for the SIP stack component of the BSG.

Options dev-logging—Configure development tracing for the stack.

event-tracing—Activate or deactivate the stack's event tracing.

ips-tracing—Activate or deactivate the stack's IPS tracing.

pd-log-detail—Specify the amount of detail to be sent to the log file.

- full—All available information is sent to the log file.
- summary—The type of logging, the identifier and the first line of the log message are sent to the log file.

pd-log-level—Specifies which types of PD logs are printed to the log file. This can be set to:

- problem—Problem log messages are sent to the log file.
- exception—Exception and problem log messages are sent to the log file.
- audit—All log messages are sent to the log file.

This option determines the levels of log messages to be sent to the log file. Selecting a level causes messages at that level and any higher levels to be sent to the log file. For example, setting this option to **exception** causes both exception and problem logs to be sent to the log file. Setting it to **audit** causes all logs to be sent to the log file. The default value is **audit**.

per-tracing—Activate or deactivate the stack's performance tracing.

verbose-logging—Configure verbose tracing for the stack.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

term

See the following sections:

- [term \(New Call Usage Policy\) on page 658](#)
- [term \(New Transaction Policy\) on page 659](#)
- [term \(Service Class\) on page 660](#)

term (New Call Usage Policy)

Syntax

```
term term-name {
  from {
    contact [ contact-fields ];
    method {
      method-invite;
    }
    request-uri [ uri-fields ];
    source-address [ ip-addresses ];
  }
  then {
    (accept | reject);
    media-policy {
      no-anchoring;
      service-class service-class-name;
    }
    trace;
  }
}
```

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip new-call-usage-policy *policy-name*]

Release Information Statement introduced in JUNOS Release 9.4.

Description Define the new call usage policy term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

term (New Transaction Policy)

Syntax term *term-name* {
 from {
 contact [*contact-fields*];
 method {
 method-invite;
 method-message;
 method-options;
 method-publish;
 method-refer;
 method-register;
 method-subscribe;
 }
 request-uri [*uri-fields*];
 source-address [*ip-addresses*];
 }
 then {
 (accept | reject);
 route {
 next-hop (request-uri | address *ipv4-address* | <port *port-number*> |
 <transport-protocol (udp|tcp)>);
 egress-service-point *service-point-name*;
 }
 trace;
 }
 }
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip new-transaction-policy
 policy-name

Release Information Statement introduced in JUNOS Release 9.4.

Description Define the new transaction policy term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

term (Service Class)

Syntax `term term-name {
 from {
 media-type (any-media | audio | video);
 }
 then {
 committed-information-rate bytes-per-second;
 committed-burst-size bytes;
 dscp (alias | 6-bit-pattern | decimal-value | hexadecimal-value);
 reject;
 }
 }`

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* embedded-spdf
 service-class *service-class-name*]

Release Information Statement introduced in JUNOS Release 9.4.

Description Specify the service class term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

then

See the following sections:

- then (New Call Usage Policy) on page 661
- then (New Transaction Policy) on page 662
- then (Service Class) on page 663

then (New Call Usage Policy)

Syntax then {
 (accept | reject);
 media-policy {
 no-anchoring;
 service-class *service-class-name*;
 }
 trace;
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip new-call-usage-policy *policy-name* term *term-name*]

Release Information Statement introduced in JUNOS Release 9.4.

Description Define the actions performed on incoming requests that match the new call usage policy.

Options accept—Accept the traffic and send it to its destination.

 reject—Do not accept the traffic and return a rejection message. Rejected traffic can be logged or sampled.

 trace—Trace messages are accepted by this policy.

 The remaining option is explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

then (New Transaction Policy)

Syntax then {
 (accept | reject);
 admission-control *controller-name*;
 route {
 next-hop (request-uri | address *ipv4-address* | <port *port-number*> | <transport-protocol
 (udp|tcp)>);
 egress-service-point *service-point-name*;
 }
 trace;
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip new-transaction-policy
 policy-name term *term-name*]

Release Information Statement introduced in JUNOS Release 9.4.

Description Define the actions performed on incoming requests that match this policy.

Options **accept**—Accept the traffic and send it to its destination.

admission-control *controller-name*—Accept or reject the traffic based on admission control configured for *controller-name*.

reject—Do not accept the traffic and return a rejection message. You can log or sample rejected traffic.

trace—Trace messages are accepted by this policy.

The remaining options are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

then (Service Class)

Syntax	then { committed-burst-size <i>bytes</i> ; committed-information-rate <i>bytes-per-second</i> ; dscp (<i>dscp-value</i> <i>alias</i> do-not-change); reject; }
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> embedded-spdf service-class <i>service-class-name</i> term <i>term-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Define the actions performed on traffic that matches the service class.
Options	reject—Do not accept the traffic and return a rejection message. Rejected traffic can be logged or sampled. The remaining options are described separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

timer-c

Syntax	timer-c <i>seconds</i> ;
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> sip timers]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure Timer C, an INVITE transaction timeout. The timer tracks the duration of time waiting for a final response to an INVITE request, ensuring that resources are released if the timer expires. When Timer C expires, a CANCEL is sent to the caller and a 408 error message (Request timeout) is sent to the call recipient.
Options	<i>seconds</i> —Duration of the timeout period. Range: 180 to 300 seconds Default: 180 seconds
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

timers

Syntax timers {
 inactive-call *seconds*;
 timer-c *seconds*;
 }

Hierarchy Level [edit services border-signaling-gateway gateway *gateway-name* sip]

Release Information Statement introduced in JUNOS Release 9.4.

Description Configure timers used to issue SIP timeouts.

Options The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Multiplay Solutions Guide*

traceoptions

```

Syntax  traceoptions {
    file <filename> <files files> <match regular-expression> <size maximum-file-size>
    <world-readable | no-world-readable>;
    flag {
        datastore {
            data trace-level;
            db trace-level;
            handle trace-level;
            minimum trace-level;
        }
        framework {
            action trace-level;
            event trace-level;
            executor trace-level;
            freezer trace-level;
            minimum trace-level;
            memory-pool trace-level;
        }
        minimum trace-level;
        sbc-utils {
            common trace-level;
            configuration trace-level;
            device-monitor trace-level;
            ipc trace-level;
            memory-management trace-level;
            message trace-level;
            minimum trace-level;
            user-interface trace-level;
        }
        session-trace trace-level;
        signaling {
            b2b trace-level;
            b2b-wrapper trace-level;
            minimum trace-level;
            policy trace-level;
            sip-stack-wrapper trace-level;
            topology-hiding trace-level;
            ua trace-level;
        }
        sip-stack {
            dev-logging;
            event-tracing;
            ips-tracing;
            pd-log-detail (full | summary);
            pd-log-level (audit | exception | problem);
            per-tracing;
            verbose-logging;
        }
    }
}

```

Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Configure border signaling gateway tracing operations. The messages are output to <code>/var/log/</code> .
Options	Options are described separately.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

transactions

Syntax	<pre>transactions { maximum-concurrent <i>number</i>; committed-attempts-rate <i>transactions-per-second</i>; committed-burst-size <i>number-of-transactions</i>; }</pre>
Hierarchy Level	[edit services border-signaling-gateway gateway <i>gateway-name</i> admission-control]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure admission control settings for out-of-dialog-transactions.
Options	<p>maximum-concurrent <i>number</i>—Maximum number of concurrent transactions. 0 causes all calls to be rejected. Values: 0 through 100,000 Default: 100000</p> <p>committed-attempts-rate <i>transactions-per-second</i>—Maximum number of attempts per second to initiate an out-of-dialog transaction. Values: 0 though 100 Default: 100</p> <p>committed-burst-size <i>number-of-transactions</i>—Maximum number of transactions allowed to burst above the committed-rate and still be accepted.</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

transport-details

Syntax	<code>transport-details port <i>port-number</i> ip-address <i>ip-address</i> [tdp udp]</code>
Hierarchy Level	<code>[edit services border-signaling-gateway gateway <i>gateway-name</i> service-point <i>service-point-name</i>]</code>
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure the transport parameters for a service point. The transport parameters consist of a combination of port number, IP address, and transport protocol. Policies are applied only to incoming requests that match the transport parameters. You can configure only one set of transport parameters for each service point.
Options	<p><i>port-number</i>—Port number on which you want to match incoming traffic. Range: 0 through 65,535 Default: 5060</p> <p><i>ip-address</i>—IP address on which you want to match incoming messages. If you do not define an IP address, the software uses the IP address of the service interface assigned to this service point. Values: udp or tcp Default: udp</p>
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Multiplay Solutions Guide</i>

Part 3

Dynamic Application Awareness

- Dynamic Application Awareness Overview on page 671
- Application Identification Configuration Guidelines on page 675
- Summary of Application Identification Configuration Statements on page 685
- Application-Aware Access List Configuration Guidelines on page 705
- Summary of AACL Configuration Statements on page 711
- Local Policy Decision Function Configuration Guidelines on page 723
- Summary of L-PDF Configuration Statements on page 727

Chapter 32

Dynamic Application Awareness Overview

This chapter describes several related features that support application-level filtering and per-subscriber, per-application group bandwidth control as an extension of Intrusion Detection and Prevention (IDP). In addition to IDP, the main components are application identification (APPID), application-aware access list (AACL) services, and local policy decision functionality for application-related services (L-PDF).



NOTE: IDP is also supported on J-series Services Routers. The other services are currently supported only on MX-series platforms equipped with MultiServices DPCs.

This chapter includes the following:

- IDP Overview on page 671
- APPID Overview on page 672
- AACL Overview on page 672
- L-PDF Overview on page 673

IDP Overview

The application identification set of services adds support for Intrusion Detection and Prevention (IDP) functionality using Deep Packet Inspection (DPI) technology to MX-series platforms equipped with MultiServices DPCs. IDP is already supported on J-series platforms and is described in J-series Services Router documentation. To configure IDP properties, include statements at the `[edit security idp]` hierarchy level. You configure IDP processes by including the `idp-policy` statement at the `[edit system processes]` hierarchy level. To specify an IDP profile, include the `idp-profile` statement at the `[edit services service-set]` hierarchy level. To configure SNMP IDP objects, include the `idp` statement at the `[edit snmp health-monitor]` hierarchy level. Operational commands for monitoring and regulating IDP activity use the `clear/request/show security idp` command syntax.



NOTE: On MX-series routers, the IDP **ip-action** statement is supported on TCP, UDP, and ICMP flows. When the ip-action **target** is **service**, the ip-action flow is applied if the traffic matches the values specified for source port, destination port, source address, and destination address. However, for ICMP flows, the destination port is 0, so that any ICMP flow matching source port, source address, and destination address would be blocked. For more information on the **ip-action** statement, see the *JUNOS Software CLI Reference for J-series Services Routers and SRX-series Services Gateways*.

APPID Overview

The APPID feature identifies applications as constituents of application groups in TCP/UDP traffic. To configure APPID, include statements at the **[edit services application-identification]** hierarchy level to specify parameter values for defining applications, enable or disable application rules, and gather the applications and rules into groups.

The following are related operational commands:

- **show/clear application-identification application-system-cache**
- **show/clear application-identification counters**

For more information on the CLI configuration, see the “Application Identification Configuration Guidelines” on page 675 and “Summary of Application Identification Configuration Statements” on page 685. For more information on the operational commands, see the *JUNOS System Basics and Services Command Reference*.

AACL Overview

The application-aware access list (AACL) service adds support for a new service that uses application names and groups as matching criteria for filtering traffic. AACL is a stateless, rules-based service that can be combined with application identification to enable policies to be applied to flows based on application and application group membership in addition to traditional packet matching rules. AACL is currently supported only on MultiServices DPCs running on MX-series platforms. It is configured in a similar way to other rules-based services such as NAT, CoS, and stateful firewall. To configure AACL, include rule specifications for match criteria and actions at the **[edit services aacl]** hierarchy level. You can chain AACL rules along with other service rules by including them in a service-set definition at the **[edit services service-set]** hierarchy level, as previously documented.

There is one pair of related operational commands, **show/clear application-aware-access-list statistics**.

For more information on the CLI configuration, see the “Application-Aware Access List Configuration Guidelines” on page 705 and “Summary of AACL Configuration Statements” on page 711. For more information on the operational command, see the *JUNOS System Basics and Services Command Reference*.

L-PDF Overview

Local policy decision functionality for application-related services adds support for a new process that regulates collection of statistics related to applications and application groups and tracking of information about dynamic subscribers and static interfaces. This functionality is collectively named the local policy decision function (L-PDF); in JUNOS Release 9.5 it is supported only on MX-series platforms equipped with MultiServices DPCs. The application identification (APPID) service defines the applications and how they are grouped. The application-aware access list (AACL) service defines the applications and application groups for which statistics are collected for a specific user or interface. The L-PDF configuration defines the way in which the statistics are output.

To configure properties for statistics output, include the **policy-decision-statistics-profile** statement at the **[edit accounting-options]** hierarchy level. A new **traceoptions** configuration is available at the **[edit system services local-policy-decision-function]** hierarchy level. To configure a dynamic profile to attach a specified service set to an interface, include the **service** statement at the **[edit dynamic-profiles *profile-name* interfaces *interface-name* unit *logical-unit-number* family inet]** hierarchy level. To attach a service set to a static interface, include the **service-set *service-set-name*** statement at the **[edit interfaces *interface-name* unit *logical-unit-number* family inet service (input | output)]** hierarchy level. For more information on service sets, see “Service Set Configuration Guidelines” on page 443.

The following related operational commands are supported:

- **show services local-policy-decision-function flows**
- **show/clear services local-policy-decision-function statistics**
- **show/clear services application-aware-access-list statistics**

For more information on the CLI configuration, see the “Local Policy Decision Function Configuration Guidelines” on page 723 and “Summary of L-PDF Configuration Statements” on page 727. For more information on the operational commands, see the *JUNOS System Basics and Services Command Reference*.

Chapter 33

Application Identification Configuration Guidelines

To configure application identification services (APPID), include the `application-identification` statement at the `[edit services]` hierarchy level:

```
[edit services]
application-identification {
  application application-name {
    disable;
    idle-timeout seconds;
    index number;
    session-timeout seconds;
    type type;
    type-of-service service-type;
    port-mapping {
      port-range {
        tcp (port | range);
        udp (port | range);
      }
      disable;
    }
  }
}
application-group group-name {
  application-groups {
    name [application-group-name];
  }
  applications {
    name [application-name];
  }
  index number;
  disable;
}
application-system-cache-timeout seconds;
max-checked-bytes bytes;
min-checked-bytes bytes;
no-application-identification;
no-application-system-cache;
no-clear-application-system-cache;
no-signature-based;
profile profile-name {
  [ rule-set rule-set-name ];
}
rule rule-name {
```

```

address address-name {
    destination {
        ip address</prefix-length>;
        port-range {
            tcp [ ports-and-port-ranges ];
            udp [ ports-and-port-ranges ];
        }
    }
    source {
        ip address</prefix-length>;
        port-range {
            tcp [ ports-and-port-ranges ];
            udp [ ports-and-port-ranges ];
        }
    }
    order number;
}
application application-name;
disable;
}
rule-set rule-set-name {
    rule application-rule-name;
}
}
tracoptions {
    file filename <files number> <match regex> <size size> <world-readable |
        no-world-readable>;
    flag flag;
    no-remote-trace;
}
}

```

This chapter contains the following sections:

- Defining an Application Identification on page 676
- Configuring APPID Rules on page 677
- Configuring Application Profiles on page 679
- Configuring Application Groups on page 679
- Configuring Global APPID Properties on page 680
- Configuring Automatic Download of Software Updates on page 680
- Tracing APPID Operations on page 681
- Examples: Configuring Application Identification Properties on page 683

Defining an Application Identification

To configure a specific IP address or port-based application identification, include the `application application-name` statement at the `[edit services application-identification]` hierarchy level:

```

application application-name {
    disable;
    idle-timeout seconds;
}

```

```

index number;
session-timeout seconds;
type type;
type-of-service service-type;
port-mapping {
    port-range {
        tcp [ ports-and-port-ranges ];
        udp [ ports-and-port-ranges ];
    }
    disable;
}
}

```

You can include the following general properties in the configuration:

- **application**—Application name, a required statement; maximum 31 characters. Predefined applications have the prefix **junos-** to avoid conflict with user-defined ones.
- **idle-timeout**—Amount of time that a session remains idle before it is deleted.
- **index**—Application index number in the range from 1 through 65,534, with integers 1 through 1024 reserved for predefined applications.
- **session-timeout**—Lifetime of a session.
- **type**—Well known applications, such as HTTP or FTP.
- **type-of-service**—Type of service, defined by service objective. There is no default value; options are **maximize-reliability**, **maximize-throughput**, **minimize-delay**, and **minimize-monetary-cost**.
- **disable**—Disable this application definition in the APPID service.

You can include the following port-mapping properties at the [edit services application-identification port-mapping] hierarchy level:

- **port-range**—TCP or UDP port number or numeric range, entered as [*minimum-value* – *maximum-value*]. For port-mapping configurations, this entry is required if the parent node exists.
- **disable**—Disable port-mapping properties for this application.

For a configuration example, see “Examples: Configuring Application Identification Properties” on page 683.

Configuring APPID Rules

This configuration specifies the properties for identifying an application for which a source or destination IP address and port is used for a known application, without the requirement of an application signature. For example, the Session Initiation Protocol (SIP) server initiates a session from its identified port, 5060. You can therefore specify the SIP server IP address and port 5060 in the port mapping configuration for the SIP application. The advantage of using this method is to provide efficiency and accuracy of application identification for your network.

To configure application rule properties, include the **rule** statement at the **[edit services application-identification]** hierarchy level:

```
rule rule-name {
  address address-name {
    destination {
      ip address</prefix-length>;
      port-range {
        tcp [ ports-and-port-ranges ];
        udp [ ports-and-port-ranges ];
      }
    }
    source {
      ip address</prefix-length>;
      port-range {
        tcp [ ports-and-port-ranges ];
        udp [ ports-and-port-ranges ];
      }
    }
    order number;
  }
  application application-name;
  disable;
}
```

You can include the following application rule properties:

- **address**—Address properties for APPID rule processing. This statement is mandatory; you must specify either destination or source properties.
- **destination**—Destination address and port information. The **ip** statement defines the IP address and netmask (IPv4 only), and the **port-range** statement defines the TCP or UDP port number or numeric range, entered as *[minimum-value – maximum-value]*.
- **source**—Source address and port information. The **ip** statement defines the IP address and netmask (IPv4 only), and the **port-range** statement defines the TCP or UDP port number or numeric range, entered as *[minimum-value – maximum-value]*.
- **order**—Application matching priority. For address configurations, the order number resolves the conflict when multiple address entries are matched for a specific session; the lower the number, the higher the priority. This statement is mandatory and must contain a unique value.
- **application**—Name of the application to be included in the rule.
- **disable**—Disable processing for this application rule.

The **rule-set** statement defines a collection of APPID rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the **rule-set** statement at the **[edit services application-identification]** hierarchy level with a **rule** statement for each rule:

```
rule-set rule-set-name {
```

```
rule application-rule-name;
}
```

For a configuration example, see “Examples: Configuring Application Identification Properties” on page 683.

Configuring Application Profiles

You can define an application profile for use in a service set. The profile consists of one or more rule sets, but only one profile can be included per service set.

To specify the application profile constituents, include the **profile** statement at the [edit services application-identification] hierarchy level:

```
profile profile-name {
  [ rule-set rule-set-name ];
}
```

You assign a profile name and include one or more predefined rule sets. For more information on rule sets, see “Configuring APPID Rules” on page 677. You can then include the profile in a service-set definition:

```
[edit services]
service-set service-set-name {
  profile profile-name;
}
```

For more information on service sets, see “Service Set Configuration Guidelines” on page 443.

Configuring Application Groups

You can define an application group to process a number of applications or subgroups at the same time. To configure application group properties, include the **application-group** statement at the [edit services application-identification] hierarchy level:

```
application-group group-name {
  application-groups {
    application-group-name;
  }
  applications {
    application-name;
  }
  index number;
  disable;
}
```

You can include the following application group properties:

- **applications**—List of applications to include in this application group. The **name** statement is mandatory and must include at least one entry.
- **application-groups**—List of application groups to include in a larger application group. The **name** statement is mandatory and must include at least one entry.
- **index**—Application group index number in the range from 1 through 65,534. This mandatory value must be unique.
- **disable**—Disable processing for this application group.

For a configuration example, see “Examples: Configuring Application Identification Properties” on page 683.

Configuring Global APPID Properties

You can define additional properties that apply on a global basis to APPID processing and are not part of a specific application, group, rule, or profile definition. To configure these global APPID properties, include the following statements at the [edit services application-identification] hierarchy level:

```
[edit services]
application-identification {
  application-system-cache-timeout seconds;
  max-checked-bytes bytes;
  min-checked-bytes bytes;
  no-application-identification;
  no-application-system-cache;
  no-clear-application-system-cache;
  no-signature-based;
}
```

The global application properties have the following effect:

- **application-system-cache-timeout**—Lifetime for system cache entries, in seconds.
- **max-checked-bytes**—The maximum number of bytes to be inspected in APPID processing, in the range from 0 through 100,000 bytes.
- **min-checked-bytes**—The minimum number of bytes to be inspected in APPID processing, in the range from 0 through 2000 bytes.
- **no-application-identification**—Disable all application identification methods.
- **no-application-system-cache**—Disable storing application identification results in the application system cache.
- **no-clear-application-system-cache**—Disable clearing the application system cache.
- **no-signature-based**—Disable signature-based application identification method.

Configuring Automatic Download of Software Updates

You can set up automatic downloading of software updates. To configure downloads, include the **download** statement at the [edit services application-identification] hierarchy level:


```

download {
  automatic {
    interval hour;
    start-time time;
  }
  url url;
}

```

You can include the following download statements:

- **download**—Define download properties.
- **automatic**—Set **start-time** value and **interval** in hours for automatic downloads. The default **start-time** is 0:00 and the range is from 0:00 through 24:00. The default **interval** is 24 and the range is from 1 through 168.
- **url**—Specify the download URL.

Tracing APPID Operations

Tracing operations track all adaptive services operations and record them in a log file. The logged error descriptions provide detailed information to help you solve problems faster.

By default, no events are traced. If you include the **traceoptions** statement at the [edit **services application-identification**] hierarchy level, the default tracing behavior is as follows:

- Important events are logged in a file called **serviced** located in the **/var/log** directory.
- When the file **serviced** reaches 128 kilobytes (KB), it is renamed **serviced.0**, then **serviced.1**, and so on, until there are three trace files. Then the oldest trace file (**serviced.2**) is overwritten. (For more information about how log files are created, see the *JUNOS System Log Messages Reference*.)
- Only the user who configures the tracing operation can access the log files.
- To display the end of the log, issue the **show log serviced | last** operational mode command:

```

[edit]
user@host# run show log serviced | last

```

You cannot change the directory (**/var/log**) in which trace files are located. However, you can customize the other trace file settings by including the following statements:

```

file filename <files number> <match regex> <size size> <(world-readable |
no-world-readable)>;
flag {
  all;
}

```

You configure these statements at the [edit **services application-identification traceoptions**] hierarchy level.

These statements are described in the following sections:

- Configuring the APPID Log Filename on page 682
- Configuring the Number and Size of APPID Log Files on page 682
- Configuring Access to the Log File on page 682
- Configuring a Regular Expression for Lines to Be Logged on page 683
- Configuring the Tracing Flags on page 683

Configuring the APPID Log Filename

By default, the name of the file that records trace output is **serviced**. You can specify a different name by including the **file** statement at the [edit services application-identification traceoptions] hierarchy level:

```
file filename;
```

Configuring the Number and Size of APPID Log Files

By default, when the trace file reaches 128 kilobytes (KB) in size, it is renamed **filename.0**, then **filename.1**, and so on, until there are three trace files. Then the oldest trace file (**filename.2**) is overwritten.

You can configure the limits on the number and size of trace files by including the following statements at the [edit services application-identification traceoptions] hierarchy level:

```
file files number size size;
```

For example, set the maximum file size to 2 MB, and the maximum number of files to 20. When the file that receives the output of the tracing operation (**filename**) reaches 2 MB, **filename** is renamed **filename.0**, and a new file called **filename** is created. When the new **filename** reaches 2 MB, **filename.0** is renamed **filename.1** and **filename** is renamed **filename.0**. This process repeats until there are 20 trace files. Then the oldest file (**filename.19**) is overwritten by the newest file (**filename.0**).

The number of files can be from 2 through 1000 files. The file size of each file can be from 10 KB through 1 gigabyte (GB).

Configuring Access to the Log File

By default, only the user who configures the tracing operation can access log files.

To specify that any user can read all log files, include the **file world-readable** statement at the [edit services application-identification traceoptions] hierarchy level:

```
file world-readable;
```

To explicitly set the default behavior, include the **file no-world-readable** statement at the [edit services application-identification traceoptions] hierarchy level:

```
file no-world-readable;
```

Configuring a Regular Expression for Lines to Be Logged

By default, the trace operation output includes all lines relevant to the logged events.

You can refine the output by including the `match` statement at the `[edit services application-identification traceoptions file filename]` hierarchy level and specifying a regular expression (regex) to be matched:

```
file filename match regex;
```

Configuring the Tracing Flags

By default, if the `traceoptions` configuration is present, only important events are logged. You can configure the trace operations to be logged by including the following statements at the `[edit services application-identification traceoptions]` hierarchy level:

```
flag {
  all;
}
```

Currently, the only supported flag is `all`, which instructs the router to trace all operations.

Examples: Configuring Application Identification Properties

The following examples show an address-based application identification configuration:

```
[edit services application-identification]
rule rule1 {
  application-name test2;
  address 1 {
    source {
      ip 10.110.1.1/16;
      port-range {
        tcp 1110-1150;
      }
    }
    destination {
      ip 10.11.1.1/16;
      port-range {
        tcp 111-1100;
      }
    }
  }
  order 1;
}
```

```
[edit services application-identification]
rule-set rs1 {
  rule rule1;
```

```

}
profile pf1 {
    rule-set rs1;
}
[edit services]
service-set sset1 {
    application-identification-profile pf1;
}

```

The following examples show application group configuration:

```

[edit services application-identification]
application-group junos:peer-to-peer {
    index 5;
    application-groups {
        junos:chat;
        junos:file-sharing;
        junos:voip;
    }
}

```

```

[edit services application-identification]
application-group junos:voip {
    index 14;
    applications {
        junos:h225ras;
        junos:h225sgn;
        junos:mgcp;
        junos:sip;
    }
}

```

Chapter 34

Summary of Application Identification Configuration Statements

The following sections explain each of the application identification configuration statements. The statements are organized alphabetically.

address

Syntax `address address-name {
 destination {
 ip address/netmask;
 port-range {
 tcp (port | range);
 udp (port | range);
 }
 }
 source {
 ip address/netmask;
 port-range {
 tcp (port | range);
 udp (port | range);
 }
 }
 order number;
 }
}`

Hierarchy Level [edit services application-identification application-rule *rule-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define address properties for application-identification rule processing. This statement is mandatory; you must specify either the destination or source properties.

Options *address-name*—Identifier for address information.

The remaining statements are explained separately.

Usage Guidelines See “Configuring APPID Rules” on page 677.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

application

application (Defining)

Syntax application *application-name* {
 disable;
 idle-timeout *seconds*;
 index *number*;
 session-timeout *seconds*;
 type *type*;
 type-of-service *service-type*;
 port-mapping {
 port-range {
 tcp (*port* | *range*);
 udp (*port* | *range*);
 }
 disable;
 }
 }

Hierarchy Level [edit services application-identification]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define the application and its properties.

The remaining statements are explained separately.

Options *application-name*—Identifier for the application. This is a mandatory value and has a maximum length of 32 characters.

Usage Guidelines See “Defining an Application Identification” on page 676.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

application (Including in Rule)

Syntax application *application-name*;

Hierarchy Level [edit services application-identification rule *rule-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Identify the application for inclusion in a rule.

Options *application-name*—Identifier for the application.

Usage Guidelines See “Configuring APPID Rules” on page 677.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.


application-group

Syntax	<pre> application-group <i>group-name</i> { application-groups { <i>application-group-name</i>; } applications { <i>application-name</i>; } index <i>number</i>; disable; }</pre>
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define the properties and contents of the application group.
Options	<p><i>group-name</i>—Unique identifier for the group.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring Application Groups” on page 679.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

application-groups

Syntax	<pre> application-groups { <i>application-group-name</i>; }</pre>
Hierarchy Level	[edit services application-identification application-group <i>group-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Identify the list of application groups for inclusion in a larger application group. The name statement is mandatory.
Options	<i>application-group-name</i> —Identifier for the application group. Maximum length is 32 characters.
Usage Guidelines	See “Configuring Application Groups” on page 679.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

application-system-cache-timeout

Syntax	<code>application-system-cache-timeout <i>time</i>;</code>
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Configure the lifetime for entries in the application system cache.
<hr/>	
	NOTE: This setting does not work as expected when the IDP session is not refreshed by new packets. No matter what timeout setting you configure, the application system cache continues to display stale entries until the session receives new packets.
<hr/>	
Options	<i>time</i> — Lifetime for system cache entries, in seconds.
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

applications

Syntax	<code>applications { <i>application-name</i>; }</code>
Hierarchy Level	[edit services application-identification application-group <i>group-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Identify the list of applications for inclusion in the application group.
Options	<i>application-name</i> —Identifier for the application. Maximum length is 32 characters.
Usage Guidelines	See “Configuring Application Groups” on page 679.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

automatic

Syntax	automatic { interval <i>hour</i> ; start-time <i>time</i> ; }
Hierarchy Level	[edit services application-identification download]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define automatic download properties.
Options	interval <i>hour</i> —Download interval in hours. The default is 24 and the range is from 1 through 168. start-time <i>time</i> —Start-time value. The default is 0:00 and the range is from 0:00 through 24:00.
Usage Guidelines	See “Configuring Automatic Download of Software Updates” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination

Syntax	destination { ip <i>address/netmask</i> ; port-range { tcp (<i>port</i> <i>range</i>); udp (<i>port</i> <i>range</i>); } }
Hierarchy Level	[edit services application-identification rule <i>rule-name</i> address <i>address-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define destination properties for application-identification rule processing.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring APPID Rules” on page 677.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

disable

- disable (APPID Application) on page 690
- disable (APPID Application Group) on page 690
- disable (APPID Port Mapping) on page 690

disable (APPID Application)

Syntax	disable;
Hierarchy Level	[edit services application-identification application <i>application-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable this application definition.
Usage Guidelines	See “Defining an Application Identification” on page 676.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

disable (APPID Application Group)

Syntax	disable;
Hierarchy Level	[edit services application-identification application-group <i>group-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable application group properties.
Usage Guidelines	See “Configuring Application Groups” on page 679.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

disable (APPID Port Mapping)

Syntax	disable;
Hierarchy Level	[edit services application-identification application <i>application-name</i> port-mapping]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable port-mapping properties for application identification.
Usage Guidelines	See “Defining an Application Identification” on page 676.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

download

Syntax	download { automatic { interval <i>hour</i> ; start-time <i>time</i> ; } url <i>url</i> ; }
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define application download properties.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring Automatic Download of Software Updates” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

idle-timeout

Syntax	idle-timeout <i>seconds</i> ;
Hierarchy Level	[edit services application-identification application <i>application-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define idle timeout for an application in seconds. When the timeout period expires, the session ends if no packets have been received.
Options	<i>seconds</i> —Idle timeout period. Default: 60 Range: 1 through 604,800
Usage Guidelines	See “Defining an Application Identification” on page 676.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

index

Syntax	<code>index <i>number</i>;</code>
Hierarchy Level	[edit services application-identification application <i>application-name</i>], [edit services application-identification application-group <i>group-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Assign an application or application-group index number. This is a mandatory value.
Options	<i>number</i> —Index number; must be a unique, unsigned value. Range: 0 through 65535
Usage Guidelines	See “Defining an Application Identification” on page 676 and “Configuring Application Groups” on page 679.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ip

Syntax	<code>ip <i>address</i></<i>prefix-length</i>>;</code>
Hierarchy Level	[edit services application-identification rule <i>rule-name</i> address destination], [edit services application-identification rule <i>rule-name</i> address source]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define an IP address and netmask for identifying the traffic destination or source.
Options	<i>address/netmask</i> —IP address and netmask.
Usage Guidelines	See “Configuring APPID Rules” on page 677.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

max-checked-bytes

Syntax	max-checked-bytes <i>bytes</i> ;
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the maximum number of bytes to be inspected.
Options	<i>bytes</i> —Maximum number of bytes. Range: 0 through 100,000
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

min-checked-bytes

Syntax	min-checked-bytes <i>bytes</i> ;
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the minimum number of bytes to be inspected.
Options	<i>bytes</i> —Minimum number of bytes. Range: 0 through 2000
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-application-identification

Syntax	no-application-identification;
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable all application identification methods.
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-application-system-cache

Syntax	no-application-system-cache;
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable storing application identification results in the application system cache.
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-clear-application-system-cache

Syntax	no-clear-application-system-cache;
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable clearing the application system cache.
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-signature-based

Syntax	no-signature-based;
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Disable the signature-based application identification method.
Usage Guidelines	See “Configuring Global APPID Properties” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

order

Syntax	order <i>number</i> ;
Hierarchy Level	[edit services application-identification rule <i>rule-name</i> address]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define application matching priority. For address configurations, the order number resolves the conflict when multiple address entries are matched for a specific session. The lower number has higher priority.
Options	<i>number</i> —Order number. This value is mandatory and must be unique.
Usage Guidelines	See “Configuring APPID Rules” on page 677.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

port-mapping

Syntax	<pre>port-mapping { port-range { tcp (port range); udp (port range); } disable; }</pre>
Hierarchy Level	[edit services application-identification application <i>application-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define port-mapping properties for application identification.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Defining an Application Identification” on page 676.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

port-range

Syntax	<pre>port-range { tcp [ports-and-port-ranges]; udp [ports-and-port-ranges]; }</pre>
Hierarchy Level	[edit services application-identification application <i>application-name</i> port-mapping], [edit services application-identification rule <i>rule-name</i> address destination], [edit services application-identification rule <i>rule-name</i> address source]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define TCP and UDP port numbers or numeric ranges. For port-mapping configurations, this entry is required if the parent node exists.
Options	<i>port</i> —Port number. <i>range</i> —Numeric port range. Enter this specification as [<i>minimum-value</i> – <i>maximum-value</i>].
Usage Guidelines	See “Defining an Application Identification” on page 676 and “Configuring APPID Rules” on page 677.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

profile

Syntax	<pre>profile <i>profile-name</i> { [rule-set <i>rule-set-name</i>]; }</pre>
Hierarchy Level	[edit services application-identification]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define members of application profile, which consists of one or more rule sets.
Options	<p><i>profile-name</i>—Identifier for application profile.</p> <p>The remaining statement is explained separately.</p>
Usage Guidelines	See “Configuring Application Profiles” on page 679.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

rule

- rule (Configuring) on page 698
- rule (Including in Rule Set) on page 699

rule (Configuring)

Syntax

```
rule rule-name {
  address {
    destination {
      ip address</prefix-length>;
      port-range {
        tcp [ ports-and-port-ranges ];
        udp [ ports-and-port-ranges ];
      }
    }
    source {
      ip address</prefix-length>;
      port-range {
        tcp [ ports-and-port-ranges ];
        udp [ ports-and-port-ranges ];
      }
    }
    order number;
  }
  application application-name;
}
```

Hierarchy Level [edit services application-identification]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define properties for application-identification rule processing.

Options *rule-name*—Unique identifier for the rule.

The remaining statements are explained separately.

Usage Guidelines See “Configuring APPID Rules” on page 677.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rule (Including in Rule Set)

Syntax	<code>rule rule-name;</code>
Hierarchy Level	<code>[edit services application-identification rule-set rule-set-name]</code>
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Identify rules for inclusion in application rule set.
Options	<i>rule-name</i> —Unique identifier for the rule.
Usage Guidelines	See “Configuring APPID Rules” on page 677.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

rule-set

Syntax	<code>rule-set rule-set-name { rule application-rule-name; }</code>
Hierarchy Level	<code>[edit services application-identification], [edit services application-identification profile]</code>
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define members of rule set.
Options	<i>rule-set-name</i> —Unique identifier for the rule set. The remaining statements are explained separately.
Usage Guidelines	See “Configuring APPID Rules” on page 677.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	services application-identification { ... }
Hierarchy Level	[edit]
Release Information	services statement introduced before JUNOS Release 7.4. application-identification statement introduced in JUNOS Release 9.5.
Description	Define the services to be applied to traffic.
Options	application-identification—The values configured for application-identification properties. The statements are explained separately.
Usage Guidelines	See “Application Identification Configuration Guidelines” on page 675.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

session-timeout

Syntax	session-timeout <i>seconds</i> ;
Hierarchy Level	[edit services application-identification application <i>application-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define session lifetime for the specified application in seconds.
Options	<i>seconds</i> —Duration of session. Default: 3600 Range: 1 through 604,800
Usage Guidelines	See “Defining an Application Identification” on page 676.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source

Syntax source {
 ip *address/netmask*;
 port-range {
 tcp (*port* | *range*);
 udp (*port* | *range*);
 }
 }

Hierarchy Level [edit services application-identification rule *rule-name* address *address-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define source properties for application-identification rule processing.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring APPID Rules” on page 677.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

traceoptions

Syntax traceoptions {
 file *filename* <files *number*> <match *regex*> <size *size*> <world-readable |
 no-world-readable>;
 flag *flag*;
 no-remote-trace;
 }

Hierarchy Level [edit services application-identification]

Release Information Statement introduced in JUNOS Release 9.5.

Description Configure application identification tracing options.

To specify more than one tracing operation, include multiple **flag** statements.

Options file *filename*—Name of the file to receive the output of the tracing operation. Enclose the name within quotation marks. All files are placed in the directory `/var/log`.

files *number*—(Optional) Maximum number of trace files. When a trace file named *trace-file* reaches its maximum size, it is renamed *trace-file.0*, then *trace-file.1*, and so on, until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

Range: 2 through 1000 files

Default: 2 files

If you specify a maximum number of files, you also must specify a maximum file size with the **size** option.

flag—Tracing operation to perform. **all** is the only valid completion.

■ **all**—Trace all events.

match *regex*—(Optional) Regular expression for lines to be logged.

no-world-readable—(Optional) Disallow any user to read the log file.

size *size*—(Optional) Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named *trace-file* reaches this size, it is renamed *trace-file.0*. When the *trace-file* again reaches its maximum size, *trace-file.0* is renamed *trace-file.1* and *trace-file* is renamed *trace-file.0*. This renaming scheme continues until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

Syntax: **xk** to specify KB, **xm** to specify MB, or **xg** to specify GB

Range: 10240 through 1073741824 or the maximum file size supported on your system

If you specify a maximum file size, you also must specify a maximum number of trace files with the **files** option.

world-readable—(Optional) Allow any user to read the log file.

Usage Guidelines See “Tracing APPID Operations” on page 681.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

type

Syntax type type;

Hierarchy Level [edit services application-identification application *application-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define type of application, such as HTTP or FTP.

Options type—Application type. This is a mandatory value and has a maximum length of 32 characters.

Usage Guidelines See “Defining an Application Identification” on page 676.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

type-of-service

Syntax type-of-service service-type;

Hierarchy Level [edit services application-identification application *application-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define the type of service by service objective. There is no default value.

Options The following *service-type* options are available:

- maximize-reliability—Service designed for maximum reliability in packet transmission.
- maximize-throughput—Service designed for maximum throughput.
- minimize-delay—Service designed for minimum delay in packet transmission.
- minimize-monetary-cost—Service designed for minimum monetary cost.

Usage Guidelines See “Defining an Application Identification” on page 676.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

url

Syntax	<code>url url;</code>
Hierarchy Level	[edit services application-identification download]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define the URL for application package downloads.
Options	<i>url</i> —Download URL.
Usage Guidelines	See “Configuring Automatic Download of Software Updates” on page 680.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 35

Application-Aware Access List Configuration Guidelines

To configure application-aware access list (AACL) services, include the `aacl` statements at the `[edit services]` hierarchy level:

```
[edit services]
aac1 {
  rule rule-name {
    match-direction (input | output | input-output);
    term term-name {
      from {
        application-group-any;
        application-groups [ application-group-names ];
        applications [ application-names ];
        destination-address address <any-unicast>;
        destination-address-range low minimum-value high maximum-value;
        destination-prefix-list list-name;
        source-address address <any-unicast>;
        source-address-range low minimum-value high maximum-value;
        source-prefix-list list-name;
      }
      then {
        (accept | discard);
        (count application-group-name | forwarding-class class-name);
      }
    }
  }
  rule-set rule-set-name {
    [ rule rule-names ];
  }
}
```

This chapter contains the following sections:

- Configuring AACL Rules on page 706
- Configuring AACL Rule Sets on page 709
- Example: Configuring AACL Rules on page 709

Configuring AACL Rules

To configure an AACL rule, include the `rule rule-name` statement at the `[edit services aacl]` hierarchy level:

```
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-group-any;
      application-groups [ application-group-names ];
      applications [ application-names ];
      destination-address address <any-unicast>;
      destination-address-range low minimum-value high maximum-value;
      destination-prefix-list list-name;
      source-address address <any-unicast>;
      source-address-range low minimum-value high maximum-value;
      source-prefix-list list-name;
    }
    then {
      (accept | discard);
      (count application-group-name | forwarding-class class-name);
    }
  }
}
```

Each AACL rule consists of a set of terms, similar to a filter configured at the `[edit firewall]` hierarchy level. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software.

The following sections explain how to configure the components of AACL rules:

- Configuring Match Direction for AACL Rules on page 706
- Configuring Match Conditions in AACL Rules on page 707
- Configuring Actions in AACL Rules on page 708

Configuring Match Direction for AACL Rules

Each rule must include a `match-direction` statement that specifies the direction in which the rule match is applied. To configure where the match is applied, include the `match-direction` statement at the `[edit services aacl rule rule-name]` hierarchy level:

```
match-direction (input | output | input-output);
```

If you configure `match-direction input-output`, bidirectional rule creation is allowed.

The match direction is used with respect to the traffic flow through the services PIC or DPC. When a packet is sent to the PIC or DPC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the services PIC or DPC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the PIC or DPC, the packet direction is output. For more information on inside and outside interfaces, see “Configuring Service Sets to be Applied to Services Interfaces” on page 444.

On the PIC or DPC, a flow lookup is performed. If no flow is found, rule processing is performed. All rules in the service set are considered. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that matches the packet direction are considered.

Configuring Match Conditions in ACL Rules

To configure ACL match conditions, include the **from** statement at the [edit services acl rule *rule-name* term *term-name*] hierarchy level:

```
from {
  application-group-any;
  application-groups [ application-group-names ];
  applications [ application-names ];
  destination-address address <any-unicast>;
  destination-address-range low minimum-value high maximum-value;
  destination-prefix-list list-name;
  source-address address <any-unicast>;
  source-address-range low minimum-value high maximum-value;
  source-prefix-list list-name;
}
```

Only IPv4 source and destination addresses are supported. You can use either the source address or the destination address as a match condition, in the same way that you configure a firewall filter; for more information, see the *JUNOS Policy Framework Configuration Guide*.

Alternatively, you can specify a list of source or destination prefixes by configuring the **prefix-list** statement at the [edit policy-options] hierarchy level and then including either the **destination-prefix-list** or the **source-prefix-list** statement in the ACL rule. For an example, see “Example: Configuring ACL Rules” on page 709.

If you omit the **from** term, the ACL rule accepts all traffic and the default protocol handlers take effect:

- User Datagram Protocol (UDP), Transmission Control Protocol (TCP), and Internet Control Message Protocol (ICMP) create a bidirectional flow with a predicted reverse flow.
- IP creates a unidirectional flow.

You can also include application and application group definitions you have configured at the [edit services application-identification] hierarchy level; for more information, see “Application Identification Configuration Guidelines” on page 675.

- To apply one or more specific application protocol definitions, include the `applications` statement at the [edit services aacl rule *rule-name* term *term-name* from] hierarchy level.
- To apply one or more sets of application group definitions you have defined, include the `application-groups` statement at the [edit services aacl rule *rule-name* term *term-name* from] hierarchy level.



NOTE: If you include one of the statements that specifies application protocols, the router derives port and protocol information from the corresponding configuration at the [edit services application-identification] hierarchy level; you cannot specify these properties as match conditions.

- To consider any application group defined in the database as a match, include the `application-group-any` statement at the [edit services aacl rule *rule-name* term *term-name* from] hierarchy level.

Configuring Actions in AACL Rules

To configure AACL actions, include the `then` statement at the [edit services aacl rule *rule-name* term *term-name*] hierarchy level:

```
then {
  (accept | discard);
  (count (application | application-group | application-group-any | none) | forwarding-class
    class-name);
}
```

You must include one of the following actions:

- **accept**—The packet is accepted and sent on to its destination.
- **discard**—The packet is not accepted and is not processed further.

When you select **accept** as the action, you can optionally configure one or both of the following action modifiers. No action modifiers are allowed with the **discard** action.

- `count (application | application-group | application-group-any | none)`—For all accepted packets that match the rules, record a packet count using AACL statistics practices. You can specify one of the following options; there is no default setting:
 - **application**—Count the application that matched in the `from` clause.
 - **application-group**—Count the application group that matched in the `from` clause.

- `application-group-any`—Count all application groups that match from `application-group-any` under the `any` group name.
- `none`—Same as not specifying `count` as an action.
- `forwarding-class class-name`—Specify the packets' forwarding-class name.

Configuring AACL Rule Sets

The `rule-set` statement defines a collection of AACL rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the `rule-set` statement at the `[edit services aacl]` hierarchy level with a `rule` statement for each rule:

```
rule-set rule-set-name {
  rule rule-name;
}
```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

Example: Configuring AACL Rules

The following example shows an AACL configuration containing a rule with three terms using a variety of match conditions and actions:

```
[edit services aacl]
rule aacl-test {
  match-direction input;
  term term1 {
    from {
      source-address 10.0.1.1
      application test1;
    }
    then {
      accept;
    }
  }
  term term2 {
    from {
      source-address {
        any-unicast;
      }
      application test1;
    }
    then {
      discard;
    }
  }
}
```

```
term term3 {  
  from {  
    source-address {  
      any-unicast;  
    }  
    application test1 test2;  
  }  
  then {  
    accept;  
    count application;  
  }  
}
```

Chapter 36

Summary of AACL Configuration Statements

The following sections explain each of the application-aware access list (AACL) services statements. The statements are organized alphabetically.

applications

Syntax	<code>applications [<i>application-names</i>];</code>
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Identify one or more applications defined in the application identification configuration for inclusion as a match condition.
Options	<i>application-names</i> —Identifiers of the applications.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

application-groups

Syntax	application-groups [<i>application-group-names</i>];
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Identify one or more application groups defined in the application identification configuration for inclusion as a match condition.
Options	<i>application-group-names</i> —Identifiers of the application groups.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

application-group-any

Syntax	application-group-any;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Indicates that any application group defined in the database is considered a match.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address

Syntax	destination-address <i>address</i> ;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the destination address for rule matching.
Options	<i>address</i> —Destination IPv4 address or prefix value.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-address-range

Syntax	destination-address-range low <i>minimum-value</i> high <i>maximum-value</i> ;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the destination address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 address range. <i>maximum-value</i> —Upper boundary for the IPv4 address range.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-prefix-list

Syntax	destination-prefix-list <i>list-name</i> ;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the destination prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Destination prefix list.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

from

Syntax	from { application-group-any; application-groups [<i>application-group-names</i>]; applications [<i>application-names</i>]; destination-address <i>address</i> <any-unicast>; destination-address-range low <i>minimum-value</i> high <i>maximum-value</i> ; destination-prefix-list <i>list-name</i> ; source-address <i>address</i> <any-unicast>; source-address-range low <i>minimum-value</i> high <i>maximum-value</i> ; source-prefix-list <i>list-name</i> ; }
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i>]
Release Information	Statement introduced before JUNOS Release 9.5.
Description	Specify match conditions for the AACL term.
Options	For information on match conditions, see the description of firewall filter match conditions in the <i>JUNOS Policy Framework Configuration Guide</i> . The remaining statements are explained separately.
Usage Guidelines	See “Configuring AACL Rules” on page 706.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

match-direction

Syntax	match-direction (input output input-output);
Hierarchy Level	[edit services aacl rule <i>rule-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the direction in which the rule match is applied.
Options	<p>input—Apply the rule match on the input side of the interface.</p> <p>output—Apply the rule match on the output side of the interface.</p> <p>input-output—Apply the rule match bidirectionally.</p>
Usage Guidelines	See “Configuring Match Direction for ACL Rules” on page 706.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

rule

Syntax

```
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-group-any;
      application-groups [ application-group-names ];
      applications [ application-names ];
      destination-address address <any-unicast>;
      destination-address-range low minimum-value high maximum-value;
      destination-prefix-list list-name;
      source-address address <any-unicast>;
      source-address-range low minimum-value high maximum-value;
      source-prefix-list list-name;
    }
    then {
      (accept | discard);
      (count (application | application-group | application-group-any | none) |
        forwarding-class class-name);
    }
  }
}
```

Hierarchy Level [edit services aacl],
[edit services aacl rule-set *rule-set-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Specify the rule the router uses when applying this service.

Options *rule-name*—Identifier for the collection of terms that constitute this rule.

The remaining statements are explained separately.

Usage Guidelines See “Configuring AACL Rules” on page 706.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

rule-set

Syntax	<code>rule-set <i>rule-set-name</i> { [rule <i>rule-names</i>]; }</code>
Hierarchy Level	[edit services aacl]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the rule set the router uses when applying this service.
Options	<i>rule-set-name</i> —Identifier for the collection of rules that constitute this rule set.
Usage Guidelines	See “Configuring AACL Rule Sets” on page 709.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	<code>services aacl { ... }</code>
Hierarchy Level	[edit]
Release Information	aacl statement introduced in JUNOS Release 9.5.
Description	Define the services to be applied to traffic.
Options	aacl—The values configured for application-aware-access-list matching rules. The statements are explained separately.
Usage Guidelines	See “Application-Aware Access List Configuration Guidelines” on page 705.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address

Syntax	source-address <i>address</i> ;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the source address for rule matching.
Options	<i>address</i> —Source IPv4 address or prefix value.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address-range

Syntax	source-address-range low <i>minimum-value</i> high <i>maximum-value</i> ;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the source address range for rule matching.
Options	<i>minimum-value</i> —Lower boundary for the IPv4 address range. <i>maximum-value</i> —Upper boundary for the IPv4 address range.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-prefix-list

Syntax	source-prefix-list <i>list-name</i> ;
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i> from]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the source prefix list for rule matching. You configure the prefix list by including the prefix-list statement at the [edit policy-options] hierarchy level.
Options	<i>list-name</i> —Source prefix list.
Usage Guidelines	See “Configuring Match Conditions in AACL Rules” on page 707.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

term

Syntax `term term-name {`
 `from {`
 `application-group-any;`
 `application-groups [application-group-names];`
 `applications [application-names];`
 `destination-address address <any-unicast>;`
 `destination-address-range low minimum-value high maximum-value;`
 `destination-prefix-list list-name;`
 `source-address address <any-unicast>;`
 `source-address-range low minimum-value high maximum-value;`
 `source-prefix-list list-name;`
 `}`
 `then {`
 `(accept | discard);`
 `(count (application | application-group | application-group-any | none) | forwarding-class`
 `class-name);`
 `}`
 `}`

Hierarchy Level [edit services aacl rule *rule-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define the AACL term properties.

Options *term-name*—Identifier for the term.

The remaining statements are explained separately.

Usage Guidelines See “Configuring AACL Rules” on page 706.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

then

Syntax	<pre> then { (accept discard); (count (application application-group application-group-any none) forwarding-class class-name); } </pre>
Hierarchy Level	[edit services aacl rule <i>rule-name</i> term <i>term-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Define the ACL term actions. You can configure the router to accept or discard the targeted traffic. The action modifiers (count and forwarding-class) are optional.
Options	<p>You can configure one of the following actions:</p> <ul style="list-style-type: none"> ■ accept—Accept the packets and all subsequent packets in flows that match the rules. ■ discard—Discard the packet and all subsequent packets in flows that match the rules. <p>When you select accept as the action, you can optionally configure one or both of the following action modifiers. No action modifiers are allowed with the discard action.</p> <ul style="list-style-type: none"> ■ count (application application-group application-group-any none)—For all accepted packets that match the rules, record a packet count using ACL statistics practices. You can specify one of the following options; there is no default setting: <ul style="list-style-type: none"> ■ application—Count the application that matched in the from clause. ■ application-group—Count the application group that matched in the from clause. ■ application-group-any—Count all application groups that match from application-group-any under the any group name. ■ none—Same as not specifying count as an action. ■ forwarding-class <i>class-name</i>—Specify the packets' forwarding-class name.
Usage Guidelines	See “Configuring ACL Rules” on page 706.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Policy Framework Configuration Guide</i>

Chapter 37

Local Policy Decision Function Configuration Guidelines

This chapter includes the following sections:

- Configuring L-PDF Profiles on page 723
- Applying L-PDF Profiles to Service Sets on page 724
- Tracing L-PDF Operations on page 725

Configuring L-PDF Profiles

The local policy decision function (L-PDF) enables you to configure properties for statistics output. To do this, you create a policy decision statistics profile, which configures the files to which statistics records are exported and the format that is exported. You specify the profile by including the following configuration at the [edit accounting-options] hierarchy level:

```
[edit accounting-options]
policy-decision-statistics-profile profile-name {
  aac-fields [ field-name ];
  file filename;
  files file-number;
  size bytes;
}
```

You specify a profile name to identify the profile and other properties as needed. The `aac-fields` statement specifies which statistics to collect in an accounting-data log file. This log file is located on the `/var/log` directory on the router. You specify the log file by including the `file filename` statement. The filename is prefixed by the `aac_statistics_` prefix; for example, if you specify the filename `lpdfd`, the log file will be `/var/log/aac_statistics_lpdfd`.

The `aac-fields` statement supports the following options:

- `address`—IP Address
- `application`—Application name
- `application-group`—Application group name
- `input-bytes`—Number of input bytes
- `input-interface`—Input interface name

- input-packets—Number of input packets
- mask—Netmask
- output-bytes—Number of output bytes
- output-packets—Number of output packets
- subscriber-name—Subscriber name
- timestamp—Timestamp
- vrf-name—VPN routing and forwarding (VRF) name

For more information on configuring profiles, see the *JUNOS Network Management Configuration Guide*.

Applying L-PDF Profiles to Service Sets

You can optionally apply policy decision statistics profiles as part of a service-set definition. To do this, you include the `policy-decision-statistics-profile` statement at the `[edit services service-set service-set-name]` hierarchy level:

```
policy-decision-statistics-profile [ profile-name ];
```

You can include only one profile name in the specification for the `application-aware access-list` statement.

The following example shows a sample configuration for attachment of an L-PDF statistics profile:

```
services {
  service-set test_aacl_sset {
    aacl-rules aacl_rule;
    policy-decision-statistics-profile {
      pdf_stats_prof;
    }
    interface-service {
      service-interface ms-0/3/0.0;
    }
  }
}
```

The following example shows a sample configuration for attachment of a service set to a static interface:

```
interfaces {
  fe-0/0/0 {
    vlan-tagging;
    unit 1 {
      vlan-id 1;
      family inet {
        service {
          input {
            service-set test_aacl_sset;
          }
        }
      }
    }
  }
}
```

```

        output {
            service-set test_aacl_sset;
        }
    }
    address 10.1.1.1/24;
}
}
}
}

```

Tracing L-PDF Operations

Tracing operations track L-PDF operations and record them in a log file. The logged error descriptions provide detailed information to help you solve problems faster.

By default, no events are traced. If you include the **traceoptions** statement at the **[edit system services local-policy-decision-function]** hierarchy level, you can customize the trace file settings:

```

traceoptions {
    file filename <files number> <size size>;
    flag flag;
}

```

The flags track the following information:

- **all**—Everything
- **configuration**—Configuration traces
- **database**—Database traces
- **general**—Miscellaneous traces
- **gres**—Graceful Routing Engine switchover (GRES) traces
- **rtsock**—Routing socket traces
- **statistics**—Statistics traces
- **subscriber**—Subscriber traces

Chapter 38

Summary of L-PDF Configuration Statements

The following sections explain each of the local policy decision function (L-PDF) statements. The statements are organized alphabetically.

aac1-fields

Syntax aac1-fields {
 [*field-name*];
 }

Hierarchy Level [edit accounting-options policy-decision-statistics-profile *profile-name*]

Release Information Statement introduced in JUNOS Release 9.5.

Description Define the statistics to collect in an accounting-data log file.

Options *field-name*—Name of the field:

- address—IP address
- application—Application name
- application-group—Application group name
- input-bytes—Number of input bytes
- input-interface—Input interface name
- input-packets—Number of input packets
- mask—Netmask
- output-bytes—Number of output bytes
- output-packets—Number of output packets
- subscriber-name—Subscriber name
- timestamp—Timestamp
- vrf-name—VPN routing and forwarding (VRF) name

Usage Guidelines See “Configuring L-PDF Profiles” on page 723.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

policy-decision-statistics-profile

Syntax	<pre> policy-decision-statistics-profile <i>profile-name</i> { aacl-fields { <i>field-name</i>; } file <i>filename</i>; files <i>file-number</i>; size <i>bytes</i>; } </pre>
Hierarchy Level	[edit accounting-options], [edit services service-set <i>service-set-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Create a policy decision statistics profile, which configures the files to which statistics records are exported and the format that is exported.
Options	<p>file <i>filename</i>—Name of the file to receive the accounting-data output. Enclose the name within quotation marks. All files are placed in the directory <code>/var/log</code>.</p> <p>files <i>number</i>—(Optional) Maximum number of accounting files. Range: 2 through 1000 files Default: 2 files</p> <p>If you specify a maximum number of files, you also must specify a maximum file size with the size option.</p> <p><i>profile-name</i>—Name of the policy decision statistics profile.</p> <p>size <i>size</i>—(Optional) Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). Syntax: <i>xk</i> to specify KB, <i>xm</i> to specify MB, or <i>xg</i> to specify GB Range: 10240 through 1073741824 or the maximum file size supported on your system</p> <p>If you specify a maximum file size, you also must specify a maximum number of trace files with the files option.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring L-PDF Profiles” on page 723.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	For more information on profiles, see the <i>JUNOS Network Management Configuration Guide</i> .

traceoptions

Syntax traceoptions {
 file *filename* <files *number*> <size *size*>;
 flag *flag*;
 }

Hierarchy Level [edit services local-policy-decision-function]

Release Information Statement introduced in JUNOS Release 9.5.

Description Configure local policy decision function (L-PDF) tracing options.

Options file *filename*—Name of the file to receive the output of the tracing operation. Enclose the name within quotation marks. All files are placed in the directory */var/log*.

files *number*—(Optional) Maximum number of trace files. When a trace file named *trace-file* reaches its maximum size, it is renamed *trace-file.0*, then *trace-file.1*, and so on, until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

Range: 2 through 1000 files

Default: 2 files

If you specify a maximum number of files, you also must specify a maximum file size with the *size* option.

flag—Tracing operation to perform. To specify more than one flag, include multiple *flag* statements.

- all—Everything
- configuration—Configuration traces
- database—Database traces
- general—Miscellaneous traces
- gres—Graceful Routing Engine switchover (GRES) traces
- rtsock—Routing socket traces
- statistics—Statistics traces
- subscriber—Subscriber traces

size *size*—(Optional) Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named *trace-file* reaches this size, it is renamed *trace-file.0*. When the *trace-file* again reaches its maximum size, *trace-file.0* is renamed *trace-file.1* and *trace-file* is renamed *trace-file.0*. This renaming scheme continues until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

Syntax: *xk* to specify KB, *xm* to specify MB, or *xg* to specify GB

Range: 10240 through 1073741824 or the maximum file size supported on your system

If you specify a maximum file size, you also must specify a maximum number of trace files with the **files** option.

Usage Guidelines See “Tracing L-PDF Operations” on page 725.

Required Privilege Level routing and trace—To view this statement in the configuration.
routing-control and trace-control—To add this statement to the configuration.

Part 4

Data Link Switching

- Data Link Switching Overview on page 735
- Data Link Switching Configuration Guidelines on page 737
- Summary of Data Link Switching Configuration Statements on page 749

Chapter 39

Data Link Switching Overview

The data link switching (DLSw) protocol allows you to tunnel System Network Architecture (SNA) Logical Link Control (LLC2) traffic over an IP network.



NOTE: DLSw configuration is supported for the J-series Services Router only.

This chapter includes the following:

- Overview on page 735
- DLSw Standards on page 735

Overview

DLSw enables you to allow SNA clients to communicate with SNA applications on a mainframe through an IP network. The IP network between an SNA client and an SNA application becomes transparent with DLSw. DLSw is configured on peer IP routers.

A DLSw connection is a Transport Control Protocol (TCP) connection that carries control and information frames between two DLSw peers within the IP network. After a connection is established, a DLSw circuit can be created for transporting SNA traffic.

DLSw Standards

DLSw is defined in the following documents:

- RFC 1795, *Data Link Switching: Switch-to-Switch Protocol AIW DLSw RIG: DLSw Closed Pages, DLSw Standard Version 1*
- RFC 2166, *APPN Implementer's Workshop Closed Pages Document DLSw v2.0 Enhancements*

Chapter 40

Data Link Switching Configuration Guidelines

The data link switching (DLSw) protocol allows you to tunnel System Network Architecture (SNA) Logical Link Control (LLC2) traffic over an IP network.



NOTE: DLSw configuration is supported on J-series Services Routers only.

To configure DLSw properties on a J-series Services Router, you include the following statements at the [edit protocols] hierarchy level:

```
dls {
  connection-idle-timeout time;
  explorer-wait-time seconds;
  load-balance circuit-weight;
  local-peer peer-address;
  multicast-address address;
  promiscuous;
  reachability-cache-timeout seconds;
  receive-initial-pacing number;
  remote-peer peer-address {
    circuit-weight weight;
    cost cost;
  }
  dls-cos {
    destination-interface interface-name;
    type-of-service number;
  }
  traceoptions {
    file filename <files number> <size size> <world-readable | no-world-readable>;
    flag flag;
  }
}
```

This chapter discusses the following topics that provide information about configuring DLSw:

- Configuring DLSw on page 738
- Configuring Logical Link Control on Interfaces on page 743
- Configuring DLSw Ethernet Redundancy Using LLC2 Properties on page 744

Configuring DLSw

This section includes the following sections:

- Minimum DLSw Configuration on page 738
- Configuring the Remote Peer on page 738
- Configuring Load Balancing on page 738
- Configuring DLSw Timers on page 739
- Configuring the Local Peer on page 740
- Configuring the Initial Pacing Window on page 740
- Configuring the Idle Timeout on page 741
- Configuring the Multicast Address on page 741
- Configuring Class of Service on page 741
- Tracing DLSw Protocol Traffic on page 743

Minimum DLSw Configuration

To enable DLSw on a router, you must include at least the following statements at the [edit protocols dlsw] hierarchy level:

```
local-peer peer-address;  
promiscuous;
```

Specify the **promiscuous** statement to allow the router to accept all incoming peer connections.

Configuring the Remote Peer

You can specify one or more remote peers to initiate a DLSw connection. Configuring the remote peer initiates the connection and also accepts connection from that remote peer only, if promiscuous mode is not configured.

To configure a specific DLSw remote peer, include the **remote-peer** statement at the [edit protocols dlsw] hierarchy level:

```
remote-peer peer-address;
```

You can configure more than one remote peer.

Configuring Load Balancing

When more than one remote peer provides alternative paths to a destination, you can specify preferences among the available routers or enable load balancing for alternatives that have the same lowest cost value. The DLSw router maintains a cache of paired media access control (MAC) address and IP address entries to determine whether an SNA host can be reached by means of any of the peers it knows about.

There are separate caches for local and remote peers, called the *local reachability cache* and the *remote reachability cache*.

To configure DLSw load balancing, include the **load-balance** statement at the **[edit protocols dlsw]** hierarchy level:

```
load-balance circuit-weight;
```

By default, load balancing is disabled. Load balancing uses the circuit-weight algorithm to make its determinations. This requires that, if there are multiple routes to a destination that share the same lowest cost value, the number of circuits traversing each peer is balanced according to the circuit weight you configure for each peer:

- To configure the *circuit cost*, or how much preference is attached to establishing a circuit using a peer, include the **cost** statement at the **[edit protocols dlsw remote-peer peer-address]** hierarchy level:

```
cost cost;
```

By default, the **cost** value is 100. The range is from 0 through 127. The lower the configured **cost** value, the higher the preference.

- To configure the *circuit weight*, or the extent to which a peer should participate in establishing circuits, include the **circuit-weight** statement at the **[edit protocols dlsw remote-peer peer-address]** hierarchy level:

```
circuit-weight weight;
```

By default, the **circuit-weight** value is 1. The range is from 1 through 127. The higher the configured **circuit-weight** value, the greater the percentage of total circuits established with this remote peer.

Configuring DLSw Timers

You can also configure two timer values that influence how circuits on the DLSw router are established:

- *Explorer timeout* is the maximum time the DLSw router waits for its peers to respond to its explorer requests. To configure a timeout period, include the **explorer-wait-time** statement at the **[edit protocols dlsw]** hierarchy level:

```
explorer-wait-time seconds;
```

By default, the **explorer-wait-time** value is 10 seconds. The range is from 5 through 60 seconds.

- *Reachability cache timeout* is the maximum time an entry remains in the reachability cache before it is deleted. To configure a timeout period, include the **reachability-cache-timeout** statement at the **[edit protocols dlsw]** hierarchy level:

```
reachability-cache-timeout seconds;
```

By default, the **reachability-cache-timeout** value is 900 seconds. The range is from 0 through 3600 seconds. A lower value helps detect new routes that might have become available during the timeout period.

Configuring the Local Peer

You can specify a local peer from which you will accept connection requests specifically. To configure a DLSw local peer, include the **local-peer** statement at the [edit protocols dlsw] hierarchy level:

```
local-peer peer-address;
```

Examples: Configuring DLSw Peers

Configure the router when it is closer to the client and expects to initiate connections to peers:

```
dlsw {
  local-peer peer-address;
  remote-peer peer-address;
}
```

Configure the router when it is closer to the server and does not expect to initiate connections:

```
dlsw {
  local-peer peer-address;
  promiscuous;
}
```

Configure specific peers and accept incoming connections only from those peers:

```
dlsw {
  local-peer peer-address;
  promiscuous;
}
```

Configure so that for some applications you initiate connections, and for other applications you receive connections from other peers:

```
dlsw {
  local-peer peer-address;
  remote-peer peer-address;
  promiscuous;
}
```

Configuring the Initial Pacing Window

To configure the DLSw initial pacing window size, include the **receive-initial-pacing** statement at the [edit protocols dlsw] hierarchy level:

```
receive-initial-pacing number;
```

Specify the number value to configure the initial value of the receive pacing window size for the sending peer.

Configuring the Idle Timeout

To configure an idle timeout period, include the `connection-idle-timeout` statement at the `[edit protocols dls]` hierarchy level:

```
connection-idle-timeout time;
```

Specify the `connection-idle-timeout` statement to configure the idle time period after which the connection is torn down.

Configuring the Multicast Address

To configure the multicast address for DLSw, include the `multicast-address` statement at the `[edit protocols dls]` hierarchy level:

```
multicast-address address;
```

Configuring Class of Service

Class of service (CoS) can be used to classify DLSw packets, which are sent to a logical tunnel interface that loops the packets into the Packet Forwarding Engine. The Packet Forwarding Engine classifies and queues the packets based on the configured type-of-service (ToS) value.

To configure CoS for DLSw, include the `dls-cos` statement at the `[edit protocols dls]` hierarchy level:

```
dls-cos {
  destination-interface interface-name;
  type-of-service number;
}
```

To enable traffic through a specified destination interface, specify the `destination-interface` statement. To configure the ToS value, specify the `type-of-service` statement.

To configure the Differentiated Services code point (DSCP) for DLSw, include the `dscp` statement at the `[edit class-of-service interfaces interface-name unit unit-number classifiers]` hierarchy level:

```
dscp {
  default;
}
```

For information on configuring class-of-service properties, see the *JUNOS Class of Service Configuration Guide*.

Example: Configuring CoS for a DLSw Connection

Configure the `lt-0/0/0` interface:

```
[edit]
```

```

interfaces lt-0/0/0 {
  unit 0 {
    encapsulation frame-relay;
    dlci 100;
    peer-unit 1;
    family inet;
  }
  unit 1 {
    encapsulation frame-relay;
    dlci 100;
    peer-unit 0;
    family inet;
  }
}

```

Enable the DLSw protocol:

```

[edit protocols]
dls {
  local-peer 1.1.1.1;
  remote-peer 1.1.1.2;
  dls-cos {
    type-of-service 192;
    destination-interface lt-0/0/0.0;
  }
}

```

Configure the CoS parameters on the lt-0/0/0 interface:

```

[edit class-of-service]
classifiers {
  inet-precedence ipPREC {
    forwarding-class best-effort {
      loss-priority low code-points 000;
      loss-priority high code-points 001;
    }
    forwarding-class expedited-forwarding {
      loss-priority low code-points 010;
      loss-priority high code-points 011;
    }
    forwarding-class assured-forwarding {
      loss-priority low code-points 100;
      loss-priority high code-points 101;
    }
    forwarding-class network-control {
      loss-priority low code-points 110;
      loss-priority high code-points 111;
    }
  }
}
interfaces {
  lt-0/0/0 {
    unit 1 {
      classifiers {
        dscp default;
      }
    }
  }
}

```

```
    }
  }
}
```

Tracing DLSw Protocol Traffic

To debug the DLSw protocol or trace DLSw protocol traffic, you can specify DLSw-specific options by including the `traceoptions` statement at the `[edit protocols dlsw]` hierarchy level:

```
traceoptions {
  file filename <files number> <size size> <world-readable | no-world-readable>;
  flag flag;
}
```

You can specify the following DLSw-specific trace options in the `flag` statement:

- `all`—Everything
- `memory`—Memory traces
- `packets`—Packet traces
- `parse`—Configuration parse traces
- `route-socket`—Route socket traces

Configuring Logical Link Control on Interfaces

You must configure logical link control (LLC) on an interface to enable a DLSw connection. To configure LLC on an interface, include the following statements on the DLSw interface:

```
interfaces interface-name {
  unit logical-unit-number {
    family llc2 {
      ack-max count;
      ack-delay-time time;
      idle-time time;
      local-window count;
      max-retry number;
      p-bit-timeout time;
      t1-time time;
      t2-timeout time;
      trej-time time;
    }
  }
}
```

For information on configuring LLC and interfaces, see the *JUNOS Network Interfaces Configuration Guide*.

Example: Configuring LLC Options on an Interface

Configure LLC options on an unnumbered interface:

```
[edit]
interfaces {
  fe-0/0/0 {
    unit 0 {
      family inet;
      address 10.10.10.2/24;
    }
    family llc2 {
      ack-delay-time 3000;
      ack-max 10;
      idle-time 102;
      local-window 15;
      max-retry 20;
      p-bit-timeout 100;
      t1-time 101;
      t2-time 101;
      max-retry 5;
      trej-time 4000;
    }
  }
}
```

Configuring DLSw Ethernet Redundancy Using LLC2 Properties

To achieve fault tolerance and load sharing, two or more redundant DLSw routers can be deployed on the same LAN segment using Ethernet redundancy support. These redundant routers provide alternate paths to the destinations and avoid a single point of failure.

When DLSw Ethernet redundancy is configured on a LAN segment, a master router is selected from a group of DLSw neighbors. The master router establishes the circuits.

To configure DLSw Ethernet redundancy, include the **redundancy-group** statement and define redundancy group options:

```
llc2 {
  redundancy-group group-number {
    advertise-interval seconds;
    map {
      local-mac mac-address remote-mac mac-address;
      preempt hold-time seconds;
      no-preempt;
      priority priority;
      track {
        dls {
          destination mac-address priority-cost priority;
          peer ip-address priority-cost priority;
        }
      }
      interface interface-name priority-cost priority;
    }
  }
}
```



```

    }
  }
}

```

You can include these statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number* family]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* family]

You can configure the following redundancy options:


- *group-number*—The group to which this router belongs. Specify the group number, in the range from 0 through 255.
- *advertise-interval*—The advertisement interval of DLSw peers on the network. All routers in the redundancy group must use the same advertisement interval. Specify the number of seconds, from 1 through 255. The default is 1 second.
- *map*—Map a local peer MAC address to a remote peer MAC address.
 - *local-mac*—The local peer MAC address to be mapped to a remote peer MAC address.
 - *mac-address*—MAC address. Specify the MAC address as six hexadecimal bytes in one of the following formats: *nnnn.nnnn.nnnn* or *nn.nn.nn.nn.nn.nn*. For example, 0011.2233.4455 or 00:11:22:33:44:55.
 - *remote-mac*—The remote destination MAC address to be mapped to a local peer MAC address.
- *preempt hold-time seconds*—Configure the time to wait before a higher-priority backup router can preempt the master router. Specify the number of seconds, from 0 through 3600. The default is not to implement DLSw preemption.
- *no-preempt*—Prohibit the preemption of the master router.
- *priority priority*—The router's priority for becoming the master router. The router with the highest priority within the redundancy group becomes the master. A larger value indicates a higher priority for being elected. Specify the priority from 1 through 255. The default is 100 (for backup routers).
- *track*—Enable the following tracking options for the remote peer and the destination peer:
 - *dls*—DLSw protocol.
 - *destination mac-address priority-cost priority*—The local MAC address and the priority. Specify the MAC address as six hexadecimal bytes in one of the following formats: *nnnn.nnnn.nnnn* or *nn.nn.nn.nn.nn.nn*. For example, 0011.2233.4455 or 00:11:22:33:44:55. The priority cost is the value subtracted from the priority value when remote peer connectivity is lost. Specify a value from 1 through 254.

- **peer ip-address priority-cost priority**—IP address of the remote peer. The priority cost is the value subtracted from the priority value when remote peer connectivity is lost. Specify a value from 1 through 254.
- **interface interface-name**—Interface name. Include the logical portion of the name, which corresponds to the logical unit number.

Example: Configuring DLSw Ethernet Redundancy

In Figure 4 on page 746, the local hosts share the same destination MAC address of 00:00:5E:00:01:01 and send DLSw traffic to the remote host with a MAC address of 00:02:00:00:00:01. Router 1 and Router 2 are configured for DLSw redundancy and map the local destination MAC address to the remote MAC address. Router 1 is also the designated master. If Router 1 becomes unavailable, Router 2 is the backup router.

Figure 4: DLSw Ethernet Redundancy Topology



To configure DLSw Ethernet redundancy, do the following:

Configuration on Router 1 Configure the redundancy group, redundancy group options, and the priority cost of each redundancy group option:

```
[edit]
interfaces {
  fe-0/0/0 {
    unit 0 {
      family llc2 {
        redundancy-group 1 {
          advertise-interval 1;
          map {
            local-mac 00:00:5e:00:01:01 remote-mac 00:02:00:00:00:01;
          }
          preempt hold-time 20;
          priority 200;
          track {
            dls {
              destination 00:02:00:00:00:01 priority-cost 50;
              peer 10.10.10.10 priority-cost 25;
            }
          }
          interface e1-0/0/2.0 priority-cost 40;
        }
      }
    }
  }
}
```

```

    }
  }
}

```

Configuration on Router 2 Configure the redundancy group, redundancy group options, and the priority cost of each redundancy group option:

```

[edit]
interfaces {
  fe-0/0/1 {
    unit 0 {
      family llc2 {
        redundancy-group 1 {
          map {
            local-mac 00:00:5e:00:01:01 remote-mac 00:02:00:00:00:01;
          }
          priority-cost 190;
          track {
            dls {
              destination 00:02:00:00:00:01 priority-cost 50;
              peer 10.10.10.10 priority-cost 25;
            }
            interface e1-0/0/2.0 priority-cost 40;
          }
        }
      }
    }
  }
}

```


Chapter 41

Summary of Data Link Switching Configuration Statements

The following sections explain each of the data link switching (DLSw) configuration statements. The statements are organized alphabetically.

advertise-interval

Syntax	advertise-interval <i>seconds</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	<p>For J-series Services Routers only. For Ethernet interfaces configured for DLSw Ethernet redundancy, configure the advertisement interval of DLSw neighbors on the network.</p> <p>All routers in the redundancy group must use the same advertisement interval.</p>
Options	<p><i>seconds</i>—Time interval between advertisement packets.</p> <p>Range: 1 through 255 seconds</p> <p>Default: 1 second</p>
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

circuit-weight

Syntax	<code>circuit-weight <i>weight</i>;</code>
Hierarchy Level	[edit protocols dlsw remote-peer <i>peer-address</i>]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Configure the extent to which this peer should participate in establishing circuits. The higher the circuit weight, the greater the percentage of total circuits established with this remote peer.
Options	<i>weight</i> —Value of this peer in establishing circuits. Range: 1 through 127 Default: 1
Usage Guidelines	See “Configuring Load Balancing” on page 738.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

connection-idle-timeout

Syntax	<code>connection-idle-timeout <i>time</i>;</code>
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure an idle timeout for the connection with the remote DLSw peer.
Options	<i>time</i> —Configure the time period for which the connection to the peer can remain idle before the connection is taken down, in seconds. Range: 0 through 60,000 seconds Default: 60 seconds
Usage Guidelines	See “Configuring the Idle Timeout” on page 741.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

cost

Syntax	<code>cost cost;</code>
Hierarchy Level	[edit protocols dlsw remote-peer <i>peer-address</i>]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Configure the preference for establishing circuits with this peer. The lower the cost, the higher the preference.
Options	<p><i>cost</i>—Preference for this peer in establishing circuits.</p> <p>Range: 0 through 127</p> <p>Default: 100</p>
Usage Guidelines	See “Configuring Load Balancing” on page 738.
Required Privilege Level	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>

destination

Syntax	<code>destination <i>mac-address</i> priority-cost <i>priority</i>;</code>
Hierarchy Level	<p>[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track dlsw],</p> <p>[edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track dlsw]</p>
Release Information	Statement introduced in JUNOS Release 7.5.
Description	For J-series Services Routers only. For Ethernet interfaces configured for DLSw Ethernet redundancy, enable tracking options for a destination MAC address.
Options	<p><i>mac-address</i>—Local MAC address. Specify the MAC address as six hexadecimal bytes in one of the following formats: <i>nnnn.nnnn.nnnn</i> or <i>nn.nn.nn.nn.nn.nn</i>. For example, 0011.2233.4455 or 00:11:22:33:44:55.</p> <p><i>priority-cost cost</i>—Cost value that is subtracted from the priority value when remote peer connectivity is lost. Specify a value from 1 through 254.</p>
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

destination-interface

Syntax	<code>destination-interface <i>interface-name</i>;</code>
Hierarchy Level	[edit protocols dls w dls w-cos]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure a destination interface for class-of-service (CoS) traffic classification.
Options	<i>interface-name</i> —Name of the destination interface.
Usage Guidelines	See “Configuring Class of Service” on page 741.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

dls w

Syntax	<code>dls w { destination <i>mac-address</i> priority-cost <i>priority</i>; peer <i>ip-address</i> priority-cost <i>priority</i>; }</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	For J-series Services Routers only. For Ethernet interfaces configured for DLSw, enable tracking options for a remote peer or destination MAC address. The statements are explained separately.
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

dlsw-cos

Syntax	dlsw-cos { destination-interface <i>interface-name</i> ; type-of-service <i>number</i> ; }
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure properties for outgoing DLSw traffic based on the type-of-service (ToS) classification.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Configuring Class of Service” on page 741.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

explorer-wait-time

Syntax	explorer-wait-time <i>seconds</i> ;
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Configure the interval during which the DLSw router waits for responses to its explorer requests.
Options	<i>seconds</i> —Time interval for explorer responses. Range: 5 through 60 seconds Default: 10 seconds
Usage Guidelines	See “Configuring DLSw Timers” on page 739.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

hold-time

Syntax	hold-time <i>seconds</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> preempt], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> preempt]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	Hold time before a higher-priority backup router preempts the master router.
Default	No DLSw preemption.
Options	<i>seconds</i> —Hold-time period. Range: 0 through 3600 seconds Default: 0 seconds (No DLSw preemption)
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interface

Syntax	<code>interface <i>interface-name</i> priority-cost <i>priority</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	For J-series Services Routers only. For Ethernet interfaces configured for DLSw Ethernet redundancy, enable tracking options for an interface.
Options	<i>interface-name</i> —Interface name. Include the logical portion of the name, which corresponds to the logical unit number. <i>peer ip-address</i> —IP address of the remote peer. <i>priority-cost cost</i> —Cost value that is subtracted from the priority value when remote peer connectivity is lost. Specify a value from 1 through 254.
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	<i>interface</i> —To view this statement in the configuration. <i>interface-control</i> —To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

load-balance

Syntax	<code>load-balance circuit-weight;</code>
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Enable load balancing based on circuit weight, in which the router picks among the available peers that have the same lowest cost value.
Default	By default, the <code>load-balance</code> statement is disabled.
Options	<i>circuit-weight</i> —Use the circuit-weight algorithm for load-balancing. (This is the only option available.)
Usage Guidelines	See “Configuring Load Balancing” on page 738.
Required Privilege Level	<i>routing</i> —To view this statement in the configuration. <i>routing-control</i> —To add this statement to the configuration.

local-mac

Syntax	<code>local-mac mac-address remote-mac mac-address;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> map], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> map]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	For J-series Services Routers only. For Ethernet interfaces configured for DLSw, specify the local MAC address to be mapped to a remote destination MAC address.
Options	<i>mac-address</i> —MAC address. Specify the MAC address as six hexadecimal bytes in one of the following formats: <i>nnnn.nnnn.nnnn</i> or <i>nn.nn.nn.nn.nn.nn</i> . For example, 0011.2233.4455 or 00:11:22:33:44:55.
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

local-peer

Syntax	<code>local-peer peer-address;</code>
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure the local peer.
Options	<i>peer-address</i> —IP address of the local DLSw peer.
Usage Guidelines	See “Configuring the Local Peer” on page 740.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

map

Syntax	map { local-mac <i>mac-address</i> remote-mac <i>mac-address</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	For J-series Services Routers only. For Ethernet interfaces configured for DLSw Ethernet redundancy, map a local peer MAC address to a remote peer MAC address. The statements are explained separately.
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

multicast-address

Syntax	multicast-address <i>address</i> ;
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure a multicast address for the DLSw connection and enable multicast functionality.
Options	<i>address</i> —Multicast address.
Usage Guidelines	See “Configuring the Multicast Address” on page 741.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

no-preempt

See preempt

peer

Syntax	<code>peer ip-address priority-cost priority;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track dlsw], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> track dlsw]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	For J-series Services Routers only. For Ethernet interfaces configured for DLSw, enable tracking options for a remote peer.
Options	<i>ip-address</i> —IP address of the remote peer. <i>priority-cost cost</i> —Cost value that is subtracted from the priority value when remote peer connectivity is lost. Specify a value from 1 through 254.
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

preempt

Syntax	(preempt no-preempt) { hold-time <i>seconds</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	Configure whether a backup router can preempt a master router: <ul style="list-style-type: none"> ■ preempt—Allow the master router to be preempted. ■ no-preempt—Prohibit the preemption of the master router. <p>The remaining statement is explained separately.</p>
Default	If you omit this statement, the backup router cannot preempt a master router.
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

priority

Syntax	<code>priority <i>priority</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet redundancy-group <i>group-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet redundancy-group <i>group-number</i>]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	When configuring DLSw Ethernet redundancy on Fast Ethernet and Gigabit Ethernet interfaces, configure a DLSw router's priority for becoming the master router. The router with the highest priority within the group becomes the master.
Options	<i>priority</i> —Router's priority for being elected master router in the VRRP group. A larger value indicates a higher priority for being elected. Range: 1 through 255 Default: 100 (for backup routers)
Usage Guidelines	See "Configuring DLSw Ethernet Redundancy Using LLC2 Properties" on page 744.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

promiscuous

Syntax	<code>promiscuous;</code>
Hierarchy Level	[edit protocols dlsw]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Enable the router to accept all incoming peer connections.
Usage Guidelines	See "Minimum DLSw Configuration" on page 738.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

protocols

Syntax	protocols dls { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the properties associated with a particular protocol.
Options	dls—Enable DLSw properties.
Usage Guidelines	See “Minimum DLSw Configuration” on page 738.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

reachability-cache-timeout

Syntax	reachability-cache-timeout <i>seconds</i> ;
Hierarchy Level	[edit protocols dls]
Release Information	Statement introduced in JUNOS Release 8.0.
Description	Configure the interval for retaining entries in the reachability cache.
Options	<i>seconds</i> —Lifetime of reachability cache entries. Range: 0 through 3600 seconds Default: 900 seconds
Usage Guidelines	See “Configuring DLSw Timers” on page 739.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

receive-initial-pacing

Syntax	receive-initial-pacing <i>number</i> ;
Hierarchy Level	[edit protocols dlsr]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure the size of the initial receive pacing window for incoming transport connections with the DLSr peer.
Options	<i>number</i> —The pacing window size. Range: 1 through 255 Default: 32
Usage Guidelines	See “Configuring the Initial Pacing Window” on page 740.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

redundancy-group

Syntax	<pre> redundancy-group <i>group-number</i> { advertise-interval <i>seconds</i>; map { local-mac <i>mac-address</i> remote-mac <i>mac-address</i>; } preempt hold-time <i>seconds</i>; no-preempt; priority <i>priority</i>; track { dls { peer <i>ip-address</i> priority-cost <i>priority</i>; destination <i>mac-address</i> priority-cost <i>priority</i>; } interface <i>interface-name</i> priority-cost <i>priority</i>; } }</pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	<p>For J-series Services Routers only. On Ethernet interfaces configured for DLSw, configure the router for DLSw redundancy.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>J-series Services Router Advanced WAN Access Configuration Guide</i>

remote-mac

See local-mac

remote-peer

Syntax	<pre>remote-peer <i>peer-address</i> { circuit-weight <i>weight</i>; cost <i>cost</i>; }</pre>
Hierarchy Level	[edit protocols dls w]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure the IP address of the remote DLSw peer.
Options	<p><i>peer-address</i>—IP address of the remote DLSw peer.</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Configuring the Remote Peer” on page 738.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

traceoptions

Syntax traceoptions {
 file *filename* <files *number*> <size *size*> <world-readable | no-world-readable>;
 flag *flag*;
 }

Hierarchy Level [edit protocols dlsu]

Release Information Statement introduced in JUNOS Release 7.4.

Description Configure DLSu protocol-level tracing options.

To specify more than one tracing operation, include multiple **flag** statements.

Default The default protocol-level tracing options are inherited from the routing protocols **traceoptions** statement included at the [edit routing-options] hierarchy level.

Options **disable**—(Optional) Disable the tracing operation. You can use this option to disable a single operation when you have defined a broad group of tracing operations, such as **all**.

file *name*—Name of the file to receive the output of the tracing operation. Enclose the name within quotation marks. All files are placed in the directory **/var/log**. We recommend that you place ES-IS tracing output in the file **esis-log**.

files *number*—(Optional) Maximum number of trace files. When a trace file named **trace-file** reaches its maximum size, it is renamed **trace-file.0**, then **trace-file.1**, and so on, until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

If you specify a maximum number of files, you also must specify a maximum file size with the **size** option.

Range: 2 through 1000 files

Default: 2 files

flag—Tracing operation to perform. To specify more than one flag, include multiple **flag** statements.

- **all**—Everything
- **memory**—Memory traces
- **packets**—Packet traces
- **parse**—Configuration parse traces
- **route-socket**—Route socket traces

flag-modifier—(Optional) Modifier for the tracing flag. You can specify one or more of these modifiers:

- **detail**—Detailed trace information
- **receive**—Packets being received
- **send**—Packets being transmitted

no-stamp—(Optional) Do not place timestamp information at the beginning of each line in the trace file.

Default: If you omit this option, timestamp information is placed at the beginning of each line of the tracing output.

no-world-readable—(Optional) Disallow any user to read the log file.

replace—(Optional) Replace an existing trace file if there is one.

Default: If you do not include this option, tracing output is appended to an existing trace file.

size size—(Optional) Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named *trace-file* reaches this size, it is renamed *trace-file.0*. When the *trace-file* again reaches its maximum size, *trace-file.0* is renamed *trace-file.1* and *trace-file* is renamed *trace-file.0*. This renaming scheme continues until the maximum number of trace files is reached. Then the oldest trace file is overwritten.

If you specify a maximum file size, you also must specify a maximum number of trace files with the **files** option.

Syntax: *xk* to specify KB, *xm* to specify MB, or *xg* to specify GB

Range: 10 KB through the maximum file size supported on your system

Default: 1 MB

world-readable—(Optional) Allow any user to read the log file.

Usage Guidelines See “Tracing DLSw Protocol Traffic” on page 743.

Required Privilege Level routing and trace—To view this statement in the configuration.
routing-control and trace-control—To add this statement to the configuration.

track

Syntax	<pre> track { dls { destination <i>mac-address</i> priority-cost <i>priority</i>; peer <i>ip-address</i> priority-cost <i>priority</i>; } interface <i>interface-name</i> priority-cost <i>priority</i>; } </pre>
Hierarchy Level	<p>[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i>]</p>
Release Information	Statement introduced in JUNOS Release 7.5.
Description	<p>For J-series Services Routers only. On Ethernet interfaces configured for DLSw Ethernet redundancy, enable tracking options for an interface, remote peer, or destination MAC address.</p> <p>The statements are explained separately.</p>
Options	<p>destination <i>mac-address</i>—Local MAC address. Specify the MAC address as six hexadecimal bytes in one of the following formats: <i>nnnn.nnnn.nnnn</i> or <i>nn.nn.nn.nn.nn.nn</i>. For example, 0011.2233.4455 or 00:11:22:33:44:55.</p> <p>dls—DLSw protocol.</p> <p>interface <i>interface-name</i>—Interface name. Include the logical portion of the name, which corresponds to the logical unit number.</p> <p>peer <i>ip-address</i>—IP address of the remote peer.</p> <p>priority-cost <i>cost</i>—Cost value that is subtracted from the priority value when remote peer connectivity is lost. Specify a value from 1 through 254.</p>
Usage Guidelines	See “Configuring DLSw Ethernet Redundancy Using LLC2 Properties” on page 744.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

type-of-service

Syntax	<code>type-of-service <i>number</i>;</code>
Hierarchy Level	[edit protocols dlsw dlsw-cos]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure the type-of-service (ToS) value used for CoS.
Options	<i>number</i> —Type-of-service value. Range: 0 through 255 Default: 0
Usage Guidelines	See “Configuring Class of Service” on page 741.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

Part 5

Encryption Services

- Encryption Overview on page 771
- Encryption Interfaces Configuration Guidelines on page 773
- Summary of Encryption Configuration Statements on page 783

Chapter 42

Encryption Overview

The IP Security (IPsec) architecture provides a security suite for the IP version 4 (IPv4) and IP version 6 (IPv6) network layers. The suite provides functionality such as authentication of origin, data integrity, confidentiality, replay protection, and nonrepudiation of source. It also defines mechanisms for key generation and exchange, management of security associations, and support for digital certificates.

IPsec defines a security association (SA) and key management framework that can be used with any network layer protocol. The SA specifies what protection policy to apply to traffic between two IP-layer entities. For more information, see the *JUNOS System Basics Configuration Guide*. The standards are defined in the following RFCs:

- RFC 2401, *Security Architecture for the Internet Protocol*
- RFC 2406, *IP Encapsulating Security Payload (ESP)*

Chapter 43

Encryption Interfaces Configuration Guidelines

To enable encryption interfaces, you can configure the following properties:

- Configuring Encryption Interfaces on page 773
- Configuring Filters for Traffic Transiting the ES PIC on page 775
- Configuring an ES Tunnel Interface for a Layer 3 VPN on page 780
- Configuring ES PIC Redundancy on page 780
- Configuring IPsec Tunnel Redundancy on page 781

Configuring Encryption Interfaces

When you configure the encryption interface, you associate the configured SA with a logical interface. This configuration defines the tunnel, including the logical unit, tunnel addresses, maximum transmission unit (MTU), optional interface addresses, and the name of the IPsec SA to apply to traffic. To configure an encryption interface, include the following statements at the [edit interfaces *es-fpc/pic/port* unit *logical-unit-number*] hierarchy level:

```
family inet {
  ipsec-sa ipsec-sa; # name of security association to apply to packet
  address address; # local interface address inside local VPN
  destination address; # destination address inside remote VPN
}
tunnel {
  source source-address;
  destination destination-address;
}
```

The addresses configured as the tunnel source and destination are the addresses in the outer IP header of the tunnel.



NOTE: You must configure the tunnel source address locally on the router, and the tunnel destination address must be a valid address for the security gateway terminating the tunnel.

The ES Physical Interface Card (PIC) is supported on M-series and T-series routing platforms.

The SA must be a valid tunnel-mode SA. The interface address and destination address listed are optional. The destination address allows the user to configure a static route to encrypt traffic. If a static route uses that destination address as the next hop, traffic is forwarded through the portion of the tunnel in which encryption occurs.

Specifying the Security Association Name for Encryption Interfaces

The security association is the set of properties that defines the protocols for encrypting Internet traffic. To configure encryption interfaces, you specify the SA name associated with the interface by including the `ipsec-sa` statement at the [edit interfaces *es-fpc/pic/port* unit *logical-unit-number* family inet] hierarchy level:

```
ipsec-sa sa-name;
```

For information about configuring the security association, see “Configuring Filters for Traffic Transiting the ES PIC” on page 775.

Configuring the MTU for Encryption Interfaces

The protocol MTU value for encryption interfaces must always be less than the default interface MTU value of 3900 bytes; the configuration fails to commit if you select a greater value. To set the MTU value, include the `mtu` statement at the [edit interfaces *interface-name* unit *logical-unit-number* family inet] hierarchy level:

```
mtu bytes;
```

For more information, see the *JUNOS Network Interfaces Configuration Guide*.

Example: Configuring an Encryption Interface

Configure an IPsec tunnel as a logical interface on the ES PIC. The logical interface specifies the tunnel through which the encrypted traffic travels. The `ipsec-sa` statement associates the security profile with the interface.

```
[edit interfaces]
es-0/0/0 {
  unit 0 {
    tunnel {
      source 10.5.5.5; # tunnel source address
      destination 10.6.6.6; # tunnel destination address
    }
    family inet {
      ipsec-sa manual-sa1; # name of security association to apply to packet
```

```

mtu 3800;
address 10.1.1.8/32 { # local interface address inside local VPN
destination 10.2.2.254; # destination address inside remote VPN
}
}
}

```

Configuring Filters for Traffic Transiting the ES PIC

This section contains the following topics:

- Traffic Overview on page 775
- Configuring the Security Association on page 776
- Configuring an Outbound Traffic Filter on page 777
- Applying the Outbound Traffic Filter on page 778
- Configuring an Inbound Traffic Filter on page 778
- Applying the Inbound Traffic Filter to the Encryption Interface on page 779

Traffic Overview


Traffic configuration defines the traffic that must flow through the tunnel. You configure outbound and inbound firewall filters, which identify and direct traffic to be encrypted and confirm that decrypted traffic parameters match those defined for the given tunnel. The outbound filter is applied to the LAN or WAN interface for the incoming traffic you want to encrypt. The inbound filter is applied to the ES PIC to check the policy for traffic coming in from the remote host. Because of the complexity of configuring a router to forward packets, no automatic checking is done to ensure that the configuration is correct.



NOTE: The valid firewall filters statements for IPsec are destination-port, source-port, protocol, destination-address, and source-address.

In Figure 5 on page 775, Gateway A protects the network 10.1.1.0/24, and Gateway B protects the network 10.2.2.0/24. The gateways are connected by an IPsec tunnel. For more information about firewalls, see the *JUNOS Policy Framework Configuration Guide*.

Figure 5: Example: IPsec Tunnel Connecting Security Gateways



The SA and ES interface for security Gateway A are configured as follows:

```

[edit security ipsec]
security-association manual-sa1 {
  manual {
    direction bidirectional {
      protocol esp;
      spi 2312;
      authentication {
        algorithm hmac-md5-96;
        key ascii-text 1234123412341234;
      }
      encryption {
        algorithm 3des-cbc;
        key ascii-text 123456789009876543211234;
      }
    }
  }
}
[edit interfaces es-0/1/0]
unit 0 {
  tunnel {
    source 10.5.5.5;
    destination 10.6.6.6;
  }
  family inet {
    ipsec-sa manual-sa1;
    address 10.1.1.8/32 {
      destination 10.2.2.254;
    }
  }
}

```

Configuring the Security Association

To configure the SA, include the `security-association` statement at the `[edit security]` hierarchy level:

```

security-association name {
  mode (tunnel | transport);
  manual {
    direction (inbound | outbound | bi-directional) {
      auxiliary-spi auxiliary-spi-value;
      spi spi-value;
      protocol (ah | esp | bundle);
      authentication {
        algorithm (hmac-md5-96 | hmac-sha1-96);
        key (ascii-text key | hexadecimal key);
      }
      encryption {
        algorithm (des-cbc | 3des-cbc);
        key (ascii-text key | hexadecimal key);
      }
    }
  }
  dynamic {
    replay-window-size (32 | 64);
    ipsec-policy policy-name;
  }
}

```



```

    }
  }
}

```

For more information about configuring an SA, see the *JUNOS System Basics Configuration Guide*. For information about applying the SA to an interface, see “Specifying the Security Association Name for Encryption Interfaces” on page 774.

Configuring an Outbound Traffic Filter

To configure the outbound traffic filter, include the **filter** statement at the [edit firewall] hierarchy level:

```

filter filter-name {
  term term-name {
    from {
      match-conditions;
    }
    then {
      action;
      action-modifiers;
    }
  }
}

```

For more information, see the *JUNOS Policy Framework Configuration Guide*.

Example: Configuring an Outbound Traffic Filter

Firewall filters for outbound traffic direct the traffic through the desired IPsec tunnel and ensure that the tunneled traffic goes out the appropriate interface (see Figure 5 on page 775). Here, an outbound firewall filter is created on security Gateway A; it identifies the traffic to be encrypted and adds it to the input side of the interface that carries the internal virtual private network (VPN) traffic:

```

[edit firewall]
filter ipsec-encrypt-policy-filter {
  term term1 {
    from {
      source-address { # local network
        10.1.1.0/24;
      }
      destination-address { # remote network
        10.2.2.0/24;
      }
    }
  }
}
then ipsec-sa manual-sa1; # apply SA name to packet
term default {
  then accept;
}

```



NOTE: The source address, port, and protocol on the outbound traffic filter must match the destination address, port, and protocol on the inbound traffic filter. The destination address, port, and protocol on the outbound traffic filter must match the source address, port, and protocol on the inbound traffic filter.

Applying the Outbound Traffic Filter

After you have configured the outbound firewall filter, you apply it by including the `filter` statement at the `[edit interfaces interface-name unit logical-unit-number family inet]` hierarchy level:

```
filter {
  input filter-name;
}
```

Example: Applying the Outbound Traffic Filter

Apply the outbound traffic filter. The outbound filter is applied on the Fast Ethernet interface at the `[edit interfaces fe-0/0/1 unit 0 family inet]` hierarchy level. Any packet matching the IPsec action term (term 1) on the input filter (`ipsec-encrypt-policy-filter`), configured on the Fast Ethernet interface, is directed to the ES PIC interface at the `[edit interfaces es-0/1/0 unit 0 family inet]` hierarchy level. So, if a packet arrives from the source address 10.1.1.0/24 and goes to the destination address 10.2.2.0/24, the Packet Forwarding Engine directs the packet to the ES PIC interface, which is configured with the `manual-sa1` SA. The ES PIC receives the packet, applies the `manual-sa1` SA, and sends the packet through the tunnel.

The router must have a route to the tunnel end point; add a static route if necessary.

```
[edit interfaces]
fe-0/0/1 {
  unit 0 {
    family inet {
      filter {
        input ipsec-encrypt-policy-filter;
      }
      address 10.1.1.254/24;
    }
  }
}
```

Configuring an Inbound Traffic Filter

To configure an inbound traffic filter, include the `filter` statement at the `[edit firewall]` hierarchy level:

```
filter filter-name {
  term term-name {
    from {
      match-conditions;
    }
  }
}
```

```

        then {
            action;
            action-modifiers;
        }
    }
}

```

For more information, see the *JUNOS Policy Framework Configuration Guide*.

Example: Configuring an Inbound Traffic Filter

Configure an inbound firewall filter. This filter performs the final IPsec policy check and is created on security gateway A. The policy check ensures that only packets that match the traffic configured for this tunnel are accepted.

```

[edit firewall]
filter ipsec-decrypt-policy-filter {
    term term1 { # perform policy check
        from {
            source-address { # remote network
                10.2.2.0/24;
            }
            destination-address { # local network
                10.1.1.0/24;
            }
        }
    }
}
then accept;

```

Applying the Inbound Traffic Filter to the Encryption Interface

After you create the inbound firewall filter, you can apply it to the ES PIC. To apply the filter to the ES PIC, include the `filter` statement at the `[edit interfaces es-fpc/pic/port unit logical-unit-number family inet filter]` hierarchy level:

```

filter {
    input filter;
}

```

The input filter is the name of the filter applied to received traffic. For a configuration example, see “Example: Configuring an Inbound Traffic Filter” on page 779. For more information about firewall filters, see the *JUNOS Policy Framework Configuration Guide*.

Example: Applying the Inbound Traffic Filter to the Encryption Interface

Apply the inbound firewall filter (`ipsec-decrypt-policy-filter`) to the decrypted packet to perform the final policy check. The IPsec `manual-sa1` SA is referenced at the `[edit interfaces es-1/2/0 unit 0 family inet]` hierarchy level and decrypts the incoming packet.

The Packet Forwarding Engine directs IPsec packets to the ES PIC. It uses the packet’s security parameter index (SPI), protocol, and destination address to look up the SA configured on one of the ES interfaces. The IPsec `manual-sa1` SA is referenced at the `[edit interfaces es-1/2/0 unit 0 family inet]` hierarchy level and is used to decrypt the

incoming packet. When the packets are processed (decrypted, authenticated, or both), the input firewall filter (**ipsec-decrypt-policy-filter**) is applied on the decrypted packet to perform the final policy check. **term1** defines the decrypted (and verified) traffic and performs the required policy check. For information about **term1**, see “Example: Configuring an Inbound Traffic Filter” on page 779.



NOTE: The inbound traffic filter is applied after the ES PIC has processed the packet, so the decrypted traffic is defined as any traffic that the remote gateway is encrypting and sending to this router. IKE uses this filter to determine the policy required for a tunnel. This policy is used during the negotiation with the remote gateway to find the matching SA configuration.

```
[edit interfaces]
es-1/2/0 {
  unit 0 {
    tunnel {
      source 10.5.5.5; # tunnel source address
      destination 10.6.6.6; # tunnel destination address
    }
    family inet {
      filter {
        input ipsec-decrypt-policy-filter;
      }
      ipsec-sa manual-sa1; # SA name applied to packet
      address 10.1.1.8/32 { # local interface address inside local VPN
        destination 10.2.2.254; # destination address inside remote VPN
      }
    }
  }
}
```

Configuring an ES Tunnel Interface for a Layer 3 VPN

To configure an ES tunnel interface for a Layer 3 VPN, you need to configure an ES tunnel interface on the provider edge (PE) router and on the customer edge (CE) router. You also need to configure IPsec on the PE and CE routers. For more information about configuring an ES tunnel for a Layer 3 VPN, see the *JUNOS VPNs Configuration Guide*.

Configuring ES PIC Redundancy

You can configure ES PIC redundancy on M-series and T-series routing platforms that have multiple ES PICs. With ES PIC redundancy, one ES PIC is active and another ES PIC is on standby. When the primary ES PIC has a servicing failure, the backup becomes active, inherits all the tunnels and SAs, and acts as the new next hop for IPsec traffic. Reestablishment of tunnels on the backup ES PIC does not require new Internet Key Exchange (IKE) negotiations. If the primary ES PIC comes online, it remains in standby and does not preempt the backup. To determine which PIC is currently active, use the **show ipsec redundancy** command.



NOTE: ES PIC redundancy is supported on M-series and T-series routing platforms.

To configure an ES PIC as the backup, include the **backup-interface** statement at the [edit interfaces *fpc/pic/port* es-options] hierarchy level:

```
backup-interface es-fpc/pic/port;
```


Example: Configuring ES PIC Redundancy

After you create the inbound firewall filter, apply it to the master ES PIC. Here, the inbound firewall filter (**ipsec-decrypt-policy-filter**) is applied on the decrypted packet to perform the final policy check. The IPsec **manual-sa1** SA is referenced at the [edit interfaces *es-1/2/0* unit 0 family inet] hierarchy level and decrypts the incoming packet. This example does not show SA and filter configuration. For information about SA and filter configuration, see the *JUNOS System Basics Configuration Guide*, the *JUNOS Policy Framework Configuration Guide*, and “Example: Configuring an Inbound Traffic Filter” on page 779.

```
[edit interfaces]
es-1/2/0 {
  es-options {
    backup-interface es-1/0/0;
  }
  unit 0 {
    tunnel {
      source 10.5.5.5;
      destination 10.6.6.6;
    }
    family inet {
      ipsec-sa manual-sa1;
      filter {
        input ipsec-decrypt-policy-filter;
      }
      address 10.1.1.8/32 {
        destination 10.2.2.254;
      }
    }
  }
}
```

Configuring IPsec Tunnel Redundancy

You can configure IPsec tunnel redundancy by specifying a backup destination address. The local router sends keepalives to determine the remote site’s reachability. When the peer is no longer reachable, a new tunnel is established. For up to 60 seconds during failover, traffic is dropped without notification being sent. Figure 6 on page 782 shows IPsec primary and backup tunnels.

Figure 6: IPsec Tunnel Redundancy

To configure IPsec tunnel redundancy, include the **backup-destination** statement at the [edit interfaces unit *logical-unit-number* tunnel] hierarchy level:

```
backup-destinationaddress;
destination address;
source address;
```



NOTE: Tunnel redundancy is supported on M-series and T-series routing platforms.

The primary and backup destinations must be on different routers.

The tunnels must be distinct from each other and policies must match.

For more information about tunnels, see “Tunnel Interfaces Configuration Guidelines” on page 1093.

Chapter 44

Summary of Encryption Configuration Statements

The following sections explain each of the encryption services statements. The statements are organized alphabetically.

address

Syntax `address address {
 destination address;
 }`

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number* family *family*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure the interface address.

Options *address*—Address of the interface.

The remaining statement is explained separately.

Usage Guidelines See “Configuring Encryption Interfaces” on page 773.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

backup-destination

Syntax	backup-destination <i>destination-address</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For tunnel interfaces, specify the remote address of the backup tunnel.
Options	<i>destination-address</i> —Address of the remote side of the connection.
Usage Guidelines	See “Configuring IPsec Tunnel Redundancy” on page 781.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	destination

backup-interface

Syntax	backup-interface <i>interface-name</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> es-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure a backup ES Physical Interface Card (PIC). When the primary ES PIC has a servicing failure, the backup becomes active, inherits all the tunnels and security associations (SAs), and acts as the new next hop for IPsec traffic.
Options	<i>interface-name</i> —Name of ES interface to serve as the backup.
Usage Guidelines	See “Configuring ES PIC Redundancy” on page 780.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination

Syntax	<code>destination <i>destination-address</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet address <i>address</i>], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For tunnel and encryption interfaces, specify the remote address.
Options	<i>destination-address</i> —Address of the remote side of the connection.
Usage Guidelines	See “Configuring Encryption Interfaces” on page 773, “Configuring Traffic Sampling” on page 801, and “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

es-options

Syntax	<code>es-options { <i>backup-interface interface-name</i>; }</code>
Hierarchy Level	[edit interfaces <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	On ES interfaces, configure ES interface-specific interface properties. The <i>backup-interface</i> statement is explained separately.
Usage Guidelines	See “Configuring ES PIC Redundancy” on page 780.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

family

Syntax	family inet { ipsec-sa <i>sa-name</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure protocol family information for the logical interface.
Options	<p><i>family</i>—Protocol family:</p> <ul style="list-style-type: none"> ■ <i>ccc</i>—Circuit cross-connect protocol suite ■ <i>inet</i>—IP version 4 suite ■ <i>inet6</i>—IP version 6 suite ■ <i>iso</i>—Open Systems Interconnection (OSI) International Organization for Standardization (ISO) protocol suite ■ <i>mlfr-end-to-end</i>—Multilink Frame Relay FRF.15 ■ <i>mlfr-uni-nni</i>—Multilink Frame Relay FRF.16 ■ <i>multilink-ppp</i>—Multilink Point-to-Point Protocol ■ <i>mpls</i>—MPLS ■ <i>tcc</i>—Translational cross-connect protocol suite ■ <i>tnp</i>—Trivial Network Protocol ■ <i>vpls</i>—Virtual private LAN service <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Encryption Interfaces Configuration Guidelines” on page 773; for a general discussion of family statement options, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other statements that do not affect services interfaces.

filter

Syntax	filter { input <i>filter-name</i> ; output <i>filter-name</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Define the filters to be applied on an interface.
Options	input <i>filter-name</i> —Identifier for the input filter. output <i>filter-name</i> —Identifier for the output filter.
Usage Guidelines	See “Configuring Filters for Traffic Transiting the ES PIC” on page 775.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interfaces

Syntax	interfaces { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure interfaces on the router.
Default	The management and internal Ethernet interfaces are automatically configured. You must configure all other interfaces.
Usage Guidelines	See the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ipsec-sa

Syntax	<code>ipsec-sa sa-name;</code>
Hierarchy Level	[edit interfaces <i>es-fpc/pic/port</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the IP Security (IPsec) SA name associated with the interface.
Options	<i>sa-name</i> —IPsec SA name.
Usage Guidelines	See “Encryption Interfaces Configuration Guidelines” on page 773.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS System Basics Configuration Guide</i>

source

Syntax	<code>source source-address;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet address <i>address</i>], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For tunnel and encryption interfaces, specify the source address.
Options	<i>source-address</i> —Address of the source side of the connection.
Usage Guidelines	See “Configuring Encryption Interfaces” on page 773, “Configuring Traffic Sampling” on page 801, and “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

tunnel

Syntax tunnel {
 backup-destination *destination-address*;
 destination *destination-address*;
 routing-instance {
 destination *routing-instance-name*;
 }
 source *source-address*;
 ttl *number*;
 }

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure a tunnel. You can use the tunnel for unicast and multicast traffic or just for multicast traffic. You can also use tunnels for encrypted traffic or virtual private networks (VPNs).

The statements are explained separately.

Usage Guidelines See “Encryption Interfaces Configuration Guidelines” on page 773 and “Tunnel Interfaces Configuration Guidelines” on page 1093.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS VPNs Configuration Guide*

unit

Syntax `unit logical-unit-number {
 family inet {
 ipsec-sa sa-name;
 }
 tunnel {
 backup-destination destination-address;
 destination destination-address;
 routing-instance {
 destination routing-instance-name;
 }
 source source-address;
 ttl number;
 }
 }`

Hierarchy Level [edit interfaces *interface-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.

Options *logical-unit-number*—Number of the logical unit.
 Range: 0 through 16,384

The remaining statements are explained separately.

Usage Guidelines See “Encryption Interfaces Configuration Guidelines” on page 773; for a general discussion of logical interface properties, see the *JUNOS Network Interfaces Configuration Guide*.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

Part 6

Flow Monitoring and Discard Accounting Services

- Flow Monitoring and Discard Accounting Overview on page 793
- Flow Monitoring and Discard Accounting Configuration Guidelines on page 797
- Summary of Flow-Monitoring Configuration Statements on page 845
- Flow Collection Configuration Guidelines on page 901
- Summary of Flow Collection Configuration Statements on page 913
- Dynamic Flow Capture Configuration Guidelines on page 931
- Flow-Tap Configuration Guidelines on page 943
- Summary of Dynamic Flow Capture and Flow-Tap Configuration Statements on page 951

Chapter 45

Flow Monitoring and Discard Accounting Overview

Using a Juniper Networks M-series or T-series routing platform, a selection of PICs (including the Monitoring Services PIC, Adaptive Services [AS] PIC, MultiServices PIC, or MultiServices DPC) and other networking hardware, you can monitor traffic flow and export the monitored traffic. Monitoring traffic allows you to do the following:

- Gather and export detailed information about IP version 4 (IPv4) traffic flows between source and destination nodes in your network.
- Sample all incoming IPv4 traffic on the monitoring interface and present the data in cflowd record format.
- Perform discard accounting on an incoming traffic flow.
- Encrypt or tunnel outgoing cflowd records, intercepted IPv4 traffic, or both.
- Direct filtered traffic to different packet analyzers and present the data in its original format (port mirror).



NOTE: Monitoring Services PICs, AS PICs, and MultiServices PICs must be mounted on an Enhanced Flexible PIC Concentrator (FPC) in an M-series or T-series routing platform.


MultiServices DPCs installed in MX-series routing platforms support the same functionality, with the exception of the passive monitoring and flow-tap features.

This section provides general information on the following topics:

- Passive Flow Monitoring on page 793
- Active Flow Monitoring on page 794

Passive Flow Monitoring

The routing platform used for passive monitoring does not route packets from the monitored interface, nor does it run any routing protocols related to those interfaces; it only receives traffic flows, collects intercepted traffic, and exports it to cflowd servers and packet analyzers. Figure 7 on page 794 shows a typical topology for the passive flow-monitoring application.

Figure 7: Passive Monitoring Application Topology

Traffic travels normally between Router 1 and Router 2. To redirect IPv4 traffic, you insert an optical splitter on the interface between these two routers. The optical splitter copies and redirects the traffic to the monitoring station, which is an M40e, M160, M320, or T-series routing platform. The optical cable connects only the receive port on the monitoring station, never the transmit port. This configuration allows the monitoring station to receive traffic from the router being monitored but never to transmit it back.

If you are monitoring traffic flow, the Internet Processor II application-specific integrated circuit (ASIC) in the router forwards a copy of the traffic to the Monitoring Services, Adaptive Services, or MultiServices PIC in the monitoring station. If more than one monitoring PIC is installed, the monitoring station distributes the load of the incoming traffic across the multiple PICs. The monitoring PICs generate flow records in cflowd version 5 format, and the records are then exported to the cflowd collector.

If you are performing lawful interception of traffic between the two routers, the Internet Processor II ASIC filters the incoming traffic and forwards it to the Tunnel Services PIC. Filter-based forwarding is then applied to direct the traffic to the packet analyzers.

Optionally, the intercepted traffic or the cflowd records can be encrypted by the ES PIC or IP Security (IPsec) services and then sent to a cflowd server or packet analyzer.

Active Flow Monitoring

Although the Monitoring Services PIC was designed initially for use as an offline passive flow monitoring tool, it can also be used in an active flow monitoring topology. In contrast, the AS or MultiServices PIC is designed exclusively for active flow monitoring. To use either the Monitoring Services PIC, AS PIC, or MultiServices PIC for active flow monitoring, you must install the PIC in an M-series or T-series router. The router participates in both the monitoring application and in the normal routing functionality of the network.

Specified packets can be filtered and sent to the monitoring interface. For the Monitoring Services PIC, the interface name contains the **mo-** prefix. For the AS or MultiServices PIC, the interface name contains the **sp-** prefix.



NOTE: If you upgrade from the Monitoring Services PIC to the Adaptive Services or MultiServices PIC for active flow monitoring, you must change the name of your monitoring interface from **mo-fpc/pic/port** to **sp-fpc/pic/port**.

The major active flow monitoring actions you can configure at the [edit forwarding-options] hierarchy level are as follows:

- Sampling, with the [edit forwarding-options sampling] hierarchy. This option sends a copy of the traffic stream to an AS or Monitoring Services PIC, which extracts limited information (such as the source and destination IP address) from some of the packets in a flow. The original packets are forwarded to the intended destination as usual.
- Discard accounting, with the [edit forwarding-options accounting] hierarchy. This option quarantines unwanted packets, creates cflowd records that describe the packets, and discards the packets instead of forwarding them.
- Port mirroring, with the [edit forwarding-options port-mirroring] hierarchy. This option makes one full copy of all packets in a flow and delivers the copy to a single destination. The original packets are forwarded to the intended destination.
- Multiple port mirroring, with the [edit forwarding-options next-hop-group] hierarchy. This option allows multiple copies of selected traffic to be delivered to multiple destinations. (Multiple port mirroring requires a Tunnel Services PIC.)

Unlike passive flow monitoring, you do not need to configure a monitoring group. Instead, you can send filtered packets to a monitoring services or adaptive services interface (**mo-** or **sp-**) by using sampling or discard accounting. Optionally, you can configure port mirroring or multiple port mirroring to direct packets to additional interfaces.

These active flow monitoring options provide a wide variety of actions that can be performed on network traffic flows. However, the following restrictions apply:


- The router can perform sampling or port mirroring at any one time.
- The router can perform forwarding or discard accounting at any one time.

Because the Monitoring Services, AS, and MultiServices PICs allow only one action to be performed at any one time, the following configuration options are available:

- Sampling and forwarding
- Sampling and discard accounting
- Port mirroring and forwarding
- Port mirroring and discard accounting
- Sampling and port mirroring on different sets of traffic

Figure 8 on page 796 shows a sample topology.

Figure 8: Active Monitoring Configuration Topology



In Figure 8 on page 796, traffic from Router 1 arrives on the monitoring router's Gigabit Ethernet **ge-2/3/0** interface. The exit interface on the monitoring router leading to destination Router 2 is **ge-3/0/0**, but this could be any interface type (such as SONET, Gigabit Ethernet, and so on). The export interface leading to the cflowd server is **fe-1/0/0**.

To enable active monitoring, configure a firewall filter on the interface **ge-2/3/0** with the following match conditions:

- Traffic matching certain firewall conditions is sent to the Monitoring Services PIC using filter-based forwarding. This traffic is quarantined and not forwarded to other routers.
- All other traffic is port-mirrored to the Monitoring Services PIC. Port mirroring copies each packet and sends the copies to the port-mirroring next hop (in this case, a Monitoring Services PIC). The original packets are forwarded out of the router as usual.

Chapter 46

Flow Monitoring and Discard Accounting Configuration Guidelines

To configure flow monitoring and accounting interfaces, include the following statements at the [edit interfaces] hierarchy level:

```
[edit interfaces]
mo-fpc/pic/port {
  unit logical-unit-number {
    family inet {
      accounting {
        destination-class-usage;
        source-class-usage direction;
      }
    }
    address address {
      destination address;
    }
    filter {
      group filter-group-number;
      input filter-name;
      output filter-name;
    }
    receive-options-packets;
    receive-ttl-exceeded;
    sampling direction;
  }
}
multiservice-options {
  (core-dump | no-core-dump);
  (syslog | no-syslog);
}
(at-fpc/pic/port | fe-fpc/pic/port | ge-fpc/pic/port) {
  passive-monitor-mode;
}
so-fpc/pic/port {
  unit logical-unit-number {
    passive-monitor-mode;
  }
}
```

To configure flow monitoring and accounting properties, include the following statements at the [edit forwarding-options] hierarchy level:

```

[edit forwarding-options]
accounting name {
  output {
    aggregate-export-interval seconds;
    cflowd hostname {
      aggregation {
        autonomous-system;
        destination-prefix;
        protocol-port;
        source-destination-prefix {
          caida-compliant;
        }
        source-prefix;
      }
      autonomous-system-type (origin | peer);
      port port-number;
      version format;
    }
    flow-active-timeout seconds;
    flow-inactive-timeout seconds;
    interface interface-name {
      engine-id number;
      engine-type number;
      source-address address;
    }
  }
}
monitoring name {
  family family {
    output {
      cflowd hostname port port-number;
      export-format format;
      flow-active-timeout seconds;
      flow-export-destination {
        collector-pic;
      }
      flow-inactive-timeout seconds;
      interface interface-name {
        engine-id number;
        engine-type number;
        input-interface-index number;
        output-interface-index number;
        source-address address;
      }
    }
  }
}
next-hop-group group-names {
  interface interface-name {
    next-hop address;
  }
}
port-mirroring {
  input {
    rate rate;
    run-length number;
  }
}

```

```

family (inet | inet6) {
  output {
    interface interface-name {
      next-hop address;
    }
    no-filter-check;
  }
}
traceoptions {
  file filename {
    files number;
    size bytes;
    (world-readable | no-world-readable);
  }
}
}
sampling {
  disable;
  input {
    family (inet | inet6 | mpls) {
      max-packets-per-second number;
      rate number;
      run-length number;
    }
  }
}
output {
  aggregate-export-interval seconds;
  cflowd hostname {
    aggregation {
      autonomous-system;
      destination-prefix;
      protocol-port;
      source-destination-prefix {
        caida-compliant;
      }
      source-prefix;
    }
    autonomous-system-type (origin | peer);
    version9 {
      template template-name;
    }
    (local-dump | no-local-dump);
    port port-number;
    source-address address;
    version format;
  }
}
file {
  disable;
  filename filename;
  files number;
  size bytes;
  (stamp | no-stamp);
  (world-readable | no-world-readable);
}
flow-active-timeout seconds;
flow-inactive-timeout seconds;

```

```

    interface interface-name {
        engine-id number;
        engine-type number;
        source-address address;
    }
}
traceoptions {
    file filename {
        files number;
        size bytes;
        (world-readable | no-world-readable);
    }
}
}

```



NOTE: For the complete [edit forwarding-options] hierarchy, see the *JUNOS Policy Framework Configuration Guide*. This section documents only the statements used in flow monitoring and accounting services.

To configure flow monitoring that uses cflowd version 9, include the following statements at the [edit services] hierarchy level:

```

[edit services]
flow-monitoring {
    version9 {
        template template-name {
            flow-active-timeout seconds;
            flow-inactive-timeout seconds;
            ipv4-template;
            ipv6-template;
            mpls-template {
                label-position [ positions ];
            }
            mpls-ipv4-template {
                label-position [ positions ];
            }
            option-refresh-rate packets packets seconds seconds;
            template-refresh-rate packets packets seconds seconds;
        }
    }
}

```

This chapter contains the following sections:

- Configuring Traffic Sampling on page 801
- Configuring Flow Monitoring on page 809
- Enabling Flow Aggregation on page 813
- Configuring Flow Aggregation to Use Version 5 or Version 8 cflowd on page 814
- Configuring Flow Aggregation to Use Version 9 Flow Templates on page 816
- Directing Replicated Flows to Multiple Flow Servers on page 822
- Logging cflowd Flows Before Export on page 824

- Configuring Port Mirroring on page 825
- Load Balancing Among Multiple Monitoring Interfaces on page 833
- Configuring Discard Accounting on page 837
- Enabling Passive Flow Monitoring on page 838
- Configuring Services Interface Redundancy with Flow Monitoring on page 843

Configuring Traffic Sampling

Traffic sampling enables you to copy traffic to a Physical Interface Card (PIC) that performs flow accounting while the router forwards the packet to its original destination. You can configure the router to perform sampling in either of two locations:

- On the Routing Engine, using the sampled process. To select this method, use a filter (input or output) with a matching term that contains the **then sample** statement.
- On the Monitoring Services, Adaptive Services, or MultiServices PIC.

The following sections provide configuration instructions for traffic sampling:

- Minimum Configuration for Traffic Sampling on page 801
- Configuring Traffic Sampling on page 802
- Disabling Traffic Sampling on page 803
- Configuring Traffic Sampling Output on page 803
- Tracing Traffic Sampling Operations on page 805
- Traffic Sampling Examples on page 806

Minimum Configuration for Traffic Sampling

To configure traffic sampling on a logical interface, you must perform at least the following tasks:

- Create a firewall filter to apply to the logical interfaces being sampled by including the **filter** statement at the [edit firewall family *family-name*] hierarchy level. In the filter **then** statement, you must specify the action modifier **sample** and the action **accept**.

```
filter filter-name {
  term term-name {
    then {
      sample;
      accept;
    }
  }
}
```

For more information about firewall filter actions and action modifiers, see the *JUNOS Policy Framework Configuration Guide*.

- Apply the filter to the interfaces on which you want to sample traffic by including the **address** and **filter** statements at the [edit interfaces *interface-name* unit *logical-unit-number* family *family-name*] hierarchy level:

```
address address {
    destination destination-address;
}
filter {
    input filter-name;
}
```

- Enable sampling and specify a nonzero sampling rate by including the **sampling** statement at the [edit forwarding-options] hierarchy level:

```
sampling {
    input {
        family inet {
            max-packets-per-second number;
            rate number;
        }
    }
}
```

Configuring Traffic Sampling

To configure traffic sampling on any logical interface, include the **input** statement at the [edit forwarding-options **sampling**] hierarchy level:

```
input {
    family inet {
        max-packets-per-second number;
        rate number;
        run-length number;
    }
}
```

When you use Routing Engine-based sampling, specify the threshold traffic value by including the **max-packets-per-second** statement. The value is the maximum number of packets to be sampled, beyond which the sampling mechanism begins dropping packets. The range is from 0 through 65,535. A value of 0 instructs the Packet Forwarding Engine not to sample any packets. The default value is 1000.




NOTE: When you configure active monitoring and specify a Monitoring Services, Adaptive Services, or MultiServices PIC in the **output** statement, the **max-packets-per-second** value is ignored.

Specify the sampling rate by setting the values for **rate** and **run-length** (see Figure 9 on page 803).

Figure 9: Configure Sampling Rate**Rate and Run-length**

Case #1 Rate =10, run-length =4



The **rate** statement specifies the ratio of packets to be sampled. For example, if you configure a rate of 10, x number of packets out of every 10 is sampled, where $x = \text{run-length} + 1$. By default, the rate is 0, which means that no traffic is sampled.

The **run-length** statement specifies the number of matching packets to sample following the initial one-packet trigger event. By default, the **run-length** is 0, which means that no more traffic is sampled after the trigger event. The range is from 0 through 20. Configuring a run length greater than 0 allows you to sample packets following those already being sampled.

If you do not include the **input** statement, sampling is disabled.

To collect the sampled packets in a file, include the **file** statement at the [edit forwarding-options sampling output] hierarchy level. For more information about the output file formats, see “Configuring Traffic Sampling Output” on page 803.

Disabling Traffic Sampling

To explicitly disable traffic sampling on the router, include the **disable** statement at the [edit forwarding-options sampling] hierarchy level:

```
disable;
```

Configuring Traffic Sampling Output

To configure traffic sampling output, include the following statements at the [edit forwarding-options sampling output] hierarchy level:

```
aggregate-export-interval seconds;
cflowd hostname {
  aggregation {
    autonomous-system;
    destination-prefix;
```

```

        protocol-port;
        source-destination-prefix {
            caida-compliant;
        }
        source-prefix;
    }
    autonomous-system-type (origin | peer);
    label-position {
        template template-name;
    }
    (local-dump | no-local-dump);
    port port-number;
    source-address address;
    version format;
}
file {
    disable;
    filename filename;
    files number;
    size bytes;
    (stamp | no-stamp);
    (world-readable | no-world-readable);
}
flow-active-timeout seconds;
flow-inactive-timeout seconds;
interface interface-name {
    engine-id number;
    engine-type number;
    source-address address;
}

```

To direct sampled traffic to a flow-monitoring interface, include the **interface** statement. The **engine-id** and **engine-type** statements specify the identity and type numbers of the interface; they are dynamically generated based on the Flexible PIC Concentrator (FPC), PIC, and slot numbers and the chassis type. The **source-address** statement specifies the traffic source.

To configure flow sampling version 9 output, you need to include the **template** statement at the [edit forwarding-options sampling output version9] hierarchy level. For information on cflowd, see “Enabling Flow Aggregation” on page 813.

The **aggregate-export-interval** statement is described in “Configuring Discard Accounting” on page 837, and the **flow-active-timeout** and **flow-inactive-timeout** statements are described in “Configuring Flow Monitoring” on page 809.

Traffic sampling results are automatically saved to a file in the `/var/tmp` directory. To collect the sampled packets in a file, include the **file** statement at the [edit forwarding-options sampling output] hierarchy level:

```

file {
    disable;
    filename filename;
    files number;
    size bytes;
    (stamp | no-stamp);
}

```

```
(world-readable | no-world-readable);
}
```

Traffic Sampling Output Format

Traffic sampling output is saved to an ASCII text file. The following is an example of the traffic sampling output that is saved to a file in the `/var/tmp` directory. Each line in the output file contains information for one sampled packet. You can optionally display a timestamp for each line.

The column headers are repeated after each group of 1000 packets.

```
# Apr  7 15:48:50
Time                Dest                Src Dest Src Proto TOS Pkt Intf  IP    TCP
                  addr                addr port port
Apr 7 15:48:54 192.168.9.194 192.168.9.195 0    0    1  0x0 84 8  0x0 0x0
Apr 7 15:48:55 192.168.9.194 192.168.9.195 0    0    1  0x0 84 8  0x0 0x0
Apr 7 15:48:56 192.168.9.194 192.168.9.195 0    0    1  0x0 84 8  0x0 0x0
Apr 7 15:48:57 192.168.9.194 192.168.9.195 0    0    1  0x0 84 8  0x0 0x0
Apr 7 15:48:58 192.168.9.194 192.168.9.195 0    0    1  0x0 84 8  0x0 0x0
```

To set the timestamp option for the file `my-sample`, enter the following:

```
[edit forwarding-options sampling output file]
user@host# set filename my-sample files 5 size 2m world-readable stamp;
```

Whenever you toggle the timestamp option, a new header is included in the file. If you set the `stamp` option, the `Time` field is displayed.

```
# Apr  7 15:48:50
# Time                Dest                Src Dest Src Proto TOS  Pkt Intf  IP    TCP
# addr                addr port port
# Feb  1 20:31:21
# Dest                Src Dest Src Proto TOS  Pkt Intf  IP    TCP
# addr                addr port port
# len num frag flags
# len num frag flags
```

Tracing Traffic Sampling Operations

Tracing operations track all traffic sampling operations and record them in a log file in the `/var/log` directory. By default, this file is named `/var/log/sampled`. The default file size is 128K, and 10 files are created before the first one gets overwritten.

To trace traffic sampling operations, include the `traceoptions` statement at the `[edit forwarding-options sampling]` hierarchy level:

```
traceoptions {
file filename <files number <size bytes> <world-readable | no-world-readable>;
```

Traffic Sampling Examples

The following sections provide examples of configuring traffic sampling:

- Example: Sampling a Single SONET Interface on page 806
- Example: Sampling All Traffic from a Single IP Address on page 807
- Example: Sampling All FTP Traffic on page 808

Example: Sampling a Single SONET Interface

The following configuration gathers statistical sampling information from a small percentage of all traffic on a single SONET/SDH interface and collects it in a file named `sonet-samples.txt`.

Create the filter:

```
[edit firewall family inet]
filter {
  input sample-sonet {
    then {
      sample;
      accept;
    }
  }
}
```

Apply the filter to the SONET/SDH interface:

```
[edit interfaces]
so-0/0/1 {
  unit 0 {
    family inet {
      filter {
        input sample-sonet;
      }
      address 10.127.68.254/32 {
        destination 172.16.74.7;
      }
    }
  }
}
```

Finally, configure traffic sampling:

```
[edit forwarding-options]
sampling {
  input {
    family inet {
      rate 100;
      run-length 2;
    }
  }
  output {
```

```

        file {
            filename sonet-samples.txt;
            files 40;
            size 5m;
        }
    }
}

```

Example: Sampling All Traffic from a Single IP Address

The following configuration gathers statistical information about every packet entering the router on a specific Gigabit Ethernet port originating from a single source IP address of 172.16.92.31, and collects it in a file named `samples-172-16-92-31.txt`.

Create the filter:

```

[edit firewall family inet]
filter one-ip {
    term get-ip {
        from {
            source-address 172.16.92.31;
        }
        then {
            sample;
            accept;
        }
    }
}

```

Apply the filter to the Gigabit Ethernet interface:

```

[edit interfaces]
ge-4/1/1 {
    unit 0 {
        family inet {
            filter {
                input one-ip;
            }
            address 10.45.92.254;
        }
    }
}

```

Finally, gather statistics on all the candidate samples; in this case, gather all statistics:

```

[edit forwarding-options]
sampling {
    input {
        family inet {
            rate 1;
        }
    }
    output {
        file {
            filename samples-172-16-92-31.txt;
        }
    }
}

```

```

        files 100;
        size 100k;
    }
}

```

Example: Sampling All FTP Traffic

The following configuration gathers statistical information about a moderate percentage of packets using the FTP data transfer protocol in the output path of a specific T3 interface, and collects the information in a file named **t3-ftp-traffic.txt**.

Create a filter:

```

[edit firewall family inet]
filter ftp-stats {
  term ftp-usage {
    from {
      destination-port [ftp ftp-data];
    }
    then {
      sample;
      accept;
    }
  }
}

```

Apply the filter to the T3 interface:

```

[edit interfaces]
t3-7/0/2 {
  unit 0 {
    family inet {
      filter {
        input ftp-stats;
      }
      address 10.35.78.254/32 {
        destination 10.35.78.4;
      }
    }
  }
}

```

Finally, gather statistics on 10 percent of the candidate samples:

```

[edit forwarding-options]
sampling {
  input {
    family inet {
      rate 10;
    }
  }
  output {
    file {
      filename t3-ftp-traffic.txt;
    }
  }
}

```



```

        files 50;
        size 1m;
    }
}

```

Configuring Flow Monitoring

The flow-monitoring application performs traffic flow monitoring and enables lawful interception of traffic between two routers. Traffic flows can either be passively monitored by an offline router or actively monitored by a router participating in the network.

To configure flow monitoring you need to do the following:

- Configuring Flow-Monitoring Interfaces on page 809
- Configuring Flow-Monitoring Properties on page 810
- Example: Configuring Flow Monitoring on page 812

Configuring Flow-Monitoring Interfaces

To enable flow monitoring on the Monitoring Services PIC, include the `mo-fpc/pic/port` statement at the [edit interfaces] hierarchy level:

```

mo-fpc/pic/port {
  unit logical-unit-number {
    family inet {
      address address {
        destination address;
      }
      filter {
        group filter-group-number;
        input filter-name;
        output filter-name;
      }
      sampling {
        [ input output ];
      }
    }
  }
  multiservice-options {
    (core-dump | no-core-dump);
    (syslog | no-syslog);
  }
}

```

Specify the physical and logical location of the flow-monitoring interface. You cannot use unit 0, because it is already used by internal processes. Specify the source and destination addresses. The `filter` statement allows you to associate an input or output filter or a filter group that you have already configured for this purpose. The `sampling` statement specifies the traffic direction: `input`, `output`, or both.

The **multiservice-options** statement allows you to configure properties related to flow-monitoring interfaces:

- Include the **core-dump** statement to enable storage of core files in `/var/tmp`.
- Include the **syslog** statement to enable storage of system logging information in `/var/log`.



NOTE: Boot images for monitoring services interfaces are specified at the `[edit chassis images pic]` hierarchy level. For more information, see the *JUNOS System Basics Configuration Guide*.

Configuring Flow-Monitoring Properties

To configure flow-monitoring properties, include the **monitoring** statement at the `[edit forwarding-options]` hierarchy level:

```
monitoring name {
  family inet {
    output {
      cflowd hostname port port-number;
      export-format format;
      flow-active-timeout seconds;
      flow-export-destination {
        collector-pic;
      }
      flow-inactive-timeout seconds;
      interface interface-name {
        engine-id number;
        engine-type number;
        input-interface-index number;
        output-interface-index number;
        source-address address;
      }
    }
  }
}
```

A monitoring instance is a named entity that specifies collector information under the **monitoring name** statement. The following sections describe the properties you can configure:

- Directing Traffic to Flow-Monitoring Interfaces on page 811
- Exporting Flows on page 811
- Configuring Time Periods when Flow Monitoring is Active and Inactive on page 811

Directing Traffic to Flow-Monitoring Interfaces

To direct traffic to a flow-monitoring interface, include the **interface** statement at the [edit forwarding-options monitoring *name* output] hierarchy level. By default, the JUNOS software automatically assigns values for the **engine-id** and **engine-type** statements:

- **engine-id**—Monitoring interface location.
- **engine-type**—Platform-specific monitoring interface type.

The **source-address** statement specifies the traffic source for transmission of cflowd information; you must configure it manually. If you provide a different **source-address** statement for each monitoring services output interface, you can track which interface processes a particular cflowd record.

By default, the **input-interface-index** value is the SNMP index of the input interface. You can override the default by including a specific value. The **input-interface-index** and **output-interface-index** values are exported in fields present in the cflowd version 5 flow format.



NOTE: On J-series Services Routers, cflowd sampling in the input direction of an interface reports the output interface index as 0.

Exporting Flows

To direct traffic to a flow collection interface, include the **flow-export-destination** statement. For more information about flow collection, see “Flow Collection Configuration Guidelines” on page 901.

To configure the cflowd version number, include the **export-format** statement at the [edit forwarding-options monitoring *name* output] hierarchy level. By default, version 5 is used. Version 8 enables the router software to aggregate the flow information using broader criteria and reduce cflowd traffic. Version 8 aggregation is performed periodically (every few seconds) on active flows and when flows are allowed to expire. Because the aggregation is performed periodically, active timeout events are ignored.

For more information on cflowd properties, see “Enabling Flow Aggregation” on page 813.

Configuring Time Periods when Flow Monitoring is Active and Inactive

To configure time periods for active flow monitoring and intervals of inactivity, include the **flow-active-timeout** and **flow-inactive-timeout** statements at the [edit forwarding-options monitoring *name* output] hierarchy level:

- The **flow-active-timeout** statement specifies the time interval between flow exports for active flows. If the interval between the time the last packet was received and the time the flow was last exported exceeds the configured value, the flow is exported.

This timer is needed to provide periodic updates when a flow has a long duration. The active timeout setting enables the router to retain the start time for the flow as a constant and send out periodic cflowd reports. This in turn allows the collector to register the start time and determine that a flow has survived for a duration longer than the configured active timeout.



NOTE: In active flow monitoring, the cflowd records are exported after a time period that is a multiple of 60 seconds and greater than or equal to the configured active timeout value. For example, if the active timeout value is 90 seconds, the cflowd records are exported at 120-second intervals. If the active timeout value is 150 seconds, the cflowd records are exported at 180-second intervals, and so forth.

- The **flow-inactive-timeout** statement specifies the interval of inactivity for a flow that triggers the flow export. If the interval between the current time and the time that the last packet for this flow was received exceeds the configured inactive timeout value, the flow is allowed to expire.

If the flow stops transmitting for longer than the configured inactive timeout value, the router purges it from the flow table and exports the cflowd record. As a result, the flow is forgotten as far as the PIC is concerned and if the same 5-tuple appears again, it is assigned a new start time and considered a new flow.

Both timers are necessary. The active timeout setting is needed to provide information for flows that constantly transmit packets for a long duration. The inactive timeout setting enables the router to purge flows that have become inactive and would waste tracking resources.



NOTE: The router must contain an Adaptive Services, MultiServices, or Monitoring Services PIC for the **flow-active-timeout** and **flow-inactive-timeout** statements to take effect.

Example: Configuring Flow Monitoring

The following is an example of flow-monitoring properties configured to support input SONET/SDH interfaces, output monitoring services interfaces, and export to cflowd for flow analysis. To complete the configuration, you also need to configure the interfaces and set up a virtual private network (VPN) routing and forwarding (VRF) instance. For a complete example, see the *JUNOS Feature Guide*. For information on cflowd, see “Enabling Flow Aggregation” on page 813.

```
[edit forwarding-options]
monitoring group1 {
  family inet {
    output {
      cflowd 192.168.245.2 port 2055;
      export-format cflowd-version-5;
      flow-active-timeout 60;
      flow-inactive-timeout 30;
      interface mo-4/0/0.1 {
```

```

        engine-id 1;
        engine-type 1;
        input-interface-index 44;
        output-interface-index 54;
        source-address 192.168.245.1;
    }
    interface mo-4/1/0.1 {
        engine-id 2;
        engine-type 1;
        input-interface-index 45;
        output-interface-index 55;
        source-address 192.168.245.1;
    }
    interface mo-4/2/0.1 {
        engine-id 3;
        engine-type 1;
        input-interface-index 46;
        output-interface-index 56;
        source-address 192.168.245.1;
    }
    interface mo-4/3/0.1 {
        engine-id 4;
        engine-type 1;
        input-interface-index 47;
        output-interface-index 57;
        source-address 192.168.245.1;
    }
}
}
}

```

Enabling Flow Aggregation

You can collect an aggregate of sampled flows and send the aggregate to a specified host that runs either the cflowd application available from CAIDA (<http://www.caida.org>) or the newer version 9 format defined in RFC 3954, *Cisco Systems NetFlow Services Export Version 9*. Before you can perform flow aggregation, the routing protocol process must export the autonomous system (AS) path and routing information to the sampling process. To do this, include the **route-record** statement at the [edit routing-options] hierarchy level (for routing instances, include the statement at the [edit routing-instances *routing-instance-name* routing-options] hierarchy level):

```

[edit routing-instances routing-instance-name routing-options]
route-record;

```

By default, flow aggregation is disabled.

By using flow aggregation, you can obtain various types of byte and packet counts of flows through a router. The application collects the sampled flows over a period of 1 minute. At the end of the minute, the number of samples to be exported are divided over the period of another minute and are exported over the course of the same minute.

You configure flow aggregation in different ways, depending on whether you want to export flow records in cflowd version 5 or 8 format, or the separate version 9 format. The latter allows you to sample MPLS as well as IPv4 and IPv6 traffic, and to combine configuration statements between the two formats.



NOTE: When PIC-based sampling is enabled, collection of flow statistics for sampled packets on flows in virtual private networks (VPNs) is also supported. No additional CLI configuration is required.

For configuration instructions for flow aggregation, see the following sections:

- Configuring Flow Aggregation to Use Version 5 or Version 8 cflowd on page 814
- Configuring Flow Aggregation to Use Version 9 Flow Templates on page 816
- Directing Replicated Flows to Multiple Flow Servers on page 822
- Logging cflowd Flows Before Export on page 824

Configuring Flow Aggregation to Use Version 5 or Version 8 cflowd

To enable the collection of cflowd version 5 or version 8 flow formats, include the cflowd statement:

```
cflowd hostname {
  aggregation {
    autonomous-system;
    destination-prefix;
    protocol-port;
    source-destination-prefix {
      caida-compliant;
    }
    source-prefix;
  }
  autonomous-system-type (origin | peer);
  (local-dump | no-local-dump);
  port port-number;
  version format;
}
```

You can include this statement at the following hierarchy levels:

- [edit forwarding-options sampling output]
- [edit forwarding-options accounting *name* output cflowd *hostname*]

You can also configure cflowd version 5 for flow-monitoring applications by including the cflowd statement at the [edit forwarding-options monitoring *name* family inet output] hierarchy level:

```
cflowd hostname {
  port port-number;
}
```

The following restrictions apply to cflowd flow formats:

- You can configure up to one version 5 and one version 8 flow format at the [edit forwarding-options accounting *name* output] hierarchy level.
- You can configure only one version 5 or one version 8 flow format at the [edit forwarding-options sampling output] hierarchy level for Routing Engine-based sampling. In contrast, PIC-based sampling allows you to specify one cflowd version 5 server and one version 8 server simultaneously. However, the two cflowd servers must have different IP addresses.
- You can configure up to eight version 5 flow formats at the [edit forwarding-options monitoring *name* output] hierarchy level. Version 8 flow formats and aggregation are not supported for flow-monitoring applications.
- Outbound Routing Engine traffic is not sampled. A firewall filter is applied as output on the egress interface, which samples packets and exports the data. For transit traffic, egress sampling works correctly. For internal traffic, the next hop is installed in the Packet Forwarding Engine but sampled packets are not exported.
- Flows are created on the monitoring PIC only after the route record resynchronization operation is complete, which is 60 seconds after the PIC comes up. Any packets sent to the PIC would be dropped until the synchronization process is complete.

In the **cflowd** statement, specify the name or identifier of the host that collects the flow aggregates. You must also include the User Datagram Protocol (UDP) port number on the host and the version, which gives the format of the exported cflowd aggregates. To collect cflowd records in a log file before exporting, include the **local-dump** statement.



NOTE: You can specify both host (cflowd) sampling and port mirroring in the same configuration; however, only one action takes effect at any one time. Port mirroring takes precedence. For more information, see “Configuring Port Mirroring” on page 825.

For cflowd version 8 only, you can specify aggregation of specific types of traffic by including the **aggregation** statement. This conserves memory and bandwidth by enabling cflowd to export targeted flows rather than all aggregated traffic. To specify a flow type, include the **aggregation** statement:

```
aggregation {
  autonomous-system;
  destination-prefix;
  protocol-port;
  source-destination-prefix {
    caida-compliant;
  }
  source-prefix;
}
```

You can include this statement at the following hierarchy levels:

- [edit forwarding-options sampling output cflowd *hostname*]
- [edit forwarding-options accounting *name* output cflowd *hostname*]

The **autonomous-system** statement configures aggregation by the AS number; this statement might require setting the separate cflowd **autonomous-system-type** statement to include either **origin** or **peer** AS numbers. The **origin** option specifies to use the origin AS of the packet source address in the Source Autonomous System cflowd field. The **peer** option specifies to use the peer AS through which the packet passed in the Source Autonomous System cflowd field. By default, cflowd exports the origin AS number.

The **destination-prefix** statement configures aggregation by the destination prefix only.

The **protocol-port** statement configures aggregation by the protocol and port number; requires setting the separate cflowd **port** statement.

The **source-destination-prefix** statement configures aggregation by the source and destination prefix. Version 2.1b1 of CAIDA's cflowd application does not record source and destination mask length values in compliance with CAIDA's *cflowd Configuration Guide*, dated August 30, 1999. If you configure the **caida-compliant** statement, the JUNOS software complies with Version 2.1b1 of cflowd. If you do not include the **caida-compliant** statement in the configuration, the JUNOS software records source and destination mask length values in compliance with the *cflowd Configuration Guide*.

The **source-prefix** statement configures aggregation by the source prefix only.

Collection of sampled packets in a local ASCII file is not affected by the cflowd statement.

Configuring Flow Aggregation to Use Version 9 Flow Templates

Use of version 9 allows you to define a flow record template suitable for IPv4 traffic, IPv6 traffic, MPLS traffic, or a combination of IPv4 and MPLS traffic. Templates and the fields included in the template are transmitted to the collector periodically, and the collector need not be aware of the router configuration.



NOTE: Version 9 requires that you install a services PIC, such as the Adaptive Services PIC or MultiServices PIC in the routing platform. On MX-series platforms, the MultiServices DPC fulfills this requirement. For more information on determining which services PIC is suitable for your routing platform, see Table 4 on page 36 or the appropriate hardware documentation.

The following sections contain additional information:

- Configuring the Traffic to be Sampled on page 817
- Configuring the Version 9 Template Properties on page 817
- Restrictions on page 818
- Fields Included in Each Template Type on page 819

- MPLS Sampling Behavior on page 820
- Verification on page 820
- Examples: Configuring Version 9 Flow Templates on page 821

Configuring the Traffic to be Sampled

To specify sampling of IPv4, IPv6, or MPLS traffic, include the appropriate configuration of the `family` statement at the `[edit forwarding-options sampling input]` hierarchy level:

```
[edit forwarding-options sampling input]
family (inet | inet6 | mpls) {
  max-packets-per-second number;
  rate number;
  run-length number;
```

You can include either `family inet` or `family mpls`.

Configuring the Version 9 Template Properties

To define the version 9 templates, include the following statements at the `[edit services flow-monitoring version9]` hierarchy level:

```
[edit services flow-monitoring version9]
template name {
  flow-active-timeout seconds;
  flow-inactive-timeout seconds;
  option-refresh-rate packets packets seconds seconds;
  template-refresh-rate packets packets seconds seconds;
  (ipv4-template | ipv6-template | mpls-ipv4-template | mpls-template) {
    label-position [ positions ];
  }
}
```

The following details apply to the configuration statements:

- You assign each template a unique name by including the `template name` statement.
- You then specify each template for the appropriate type of traffic by including the `ipv4-template`, `ipv6-template`, `mpls-ipv4-template`, or `mpls-template` statement.
- If the template is used for MPLS traffic, you can also specify up to three label positions for the MPLS header label data by including the `label-position` statement; the default values are `[1 2 3]`.
- Within the template definition, you can optionally include values for the `flow-active-timeout` and `flow-inactive-timeout` statements. These statements have specific default and range values when they are used in template definitions; the default is 60 seconds and the range is from 10 through 600 seconds. Values you specify in template definitions override the global timeout values configured at the `[edit forwarding-options sampling output cflowd]` hierarchy level.



NOTE: In active flow monitoring, the cflowd records are exported after a time period that is a multiple of 60 seconds and greater than or equal to the configured active timeout value. For example, if the active timeout value is 90 seconds, the cflowd records are exported at 120-second intervals. If the active timeout value is 150 seconds, the cflowd records are exported at 180-second intervals, and so forth.

- You can also include settings for the **option-refresh-rate** and **template-refresh-rate** statements within a template definition. For both of these properties, you can include a timer value (in seconds) or a packet count (in number of packets). For the **seconds** option, the default value is 60 and the range is from 10 through 600. For the **packets** option, the default value is 4800 and the range is from 1 through 480,000.
- To filter IPV6 traffic on a media interface, the following configuration is supported:

```

interfaces interface-name {
  unit 0 {
    family inet6 {
      sampling {
        input;
        output;
      }
    }
  }
}

```

Restrictions

The following restrictions apply to version 9 templates:

- You cannot apply the two different types of flow aggregation configuration (cflowd version 5/8 and flow aggregation version 9) at the same time.
- Flow export based on an **mpls-ipv4** template assumes that the IPv4 header follows the MPLS header. In the case of Layer 2 VPNs, the packet on the provider router (P router) would look like this:

MPLS | Layer 2 Header | IPv4

In this case, **mpls-ipv4** flows are not created on the PIC, because the IPv4 header does not directly follow the MPLS header. Packets are dropped on the PIC and are accounted as parser errors.

- Outbound Routing Engine traffic is not sampled. A firewall filter is applied as output on the egress interface, which samples packets and exports the data. For transit traffic, egress sampling works correctly. For internal traffic, the next hop is installed in the Packet Forwarding Engine but sampled packets are not exported.
- Flows are created on the monitoring PIC only after the route record resynchronization operation is complete, which is 60 seconds after the PIC comes up. Any packets sent to the PIC would be dropped until the synchronization process is complete.

Fields Included in Each Template Type

The following fields are common to all template types:

- Input interface
- Output interface
- Number of bytes
- Number of packets
- Flow start time
- Flow end time

The IPv4 template includes the following specific fields:

- IPv4 Source Address
- IPv4 Destination Address
- L4 Source Port
- L4 Destination Port
- IPv4 TOS
- IPv4 Protocol
- ICMP type and code
- TCP Flags
- IPv4 Next Hop Address

The IPv6 template includes the following specific fields:

- IPv6 Source Address and Mask
- IPv6 Destination Address and Mask
- L4 Source Port
- L4 Destination Port
- IPv6 TOS
- IPv6 Protocol
- TCP Flags
- Source MAC Address
- Destination MAC Address
- IP Protocol Version
- IPv6 Next Hop Address
- Egress Interface Information
- Source Autonomous System (AS) number
- Destination AS number

The MPLS template includes the following specific fields:

- MPLS Label #1
- MPLS Label #2
- MPLS Label #3
- MPLS EXP Information

The MPLS-IPv4 template includes all the fields found in the IPv4 and MPLS templates.

MPLS Sampling Behavior

This section describes the behavior when MPLS sampling is used on egress interfaces in various scenarios (label pop or swap) on provider routers (P routers). For more information on configuration and background specific to MPLS applications, see the *JUNOS MPLS Applications Configuration Guide*.

1. You configure MPLS sampling on an egress interface on the P router and configure an MPLS flow aggregation template. The route action is label *pop* because penultimate hop popping (PHP) is enabled.

Previously, IPv4 packets (only) would have been sent to the PIC for sampling even though you configured MPLS sampling. No flows should be created, with the result that the parser fails.

With the current capability of applying MPLS templates, MPLS flows are created.

2. As in the first case, you configure MPLS sampling on an egress interface on the P router and configure an MPLS flow aggregation template. The route action is label swap and the swapped label is 0 (explicit null).

Resulting behavior is that MPLS packets are sent to PIC. The flow being sampled corresponds to the label before the swap.

3. You configure a Layer 3 VPN network, in which a customer edge router (CE-1) sends traffic to a provider edge router (PE-A), through the P router, to a similar provider edge router (PE-B) and customer edge router (CE-2) on the remote end.

Resulting behavior is that you cannot sample MPLS packets on the PE-A to P router link.

Verification

To verify the configuration properties, you can use the **show services accounting aggregation template template-name name** operational mode command.

All other **show services accounting** commands also support version 9 templates, except for **show services accounting flow-detail** and **show services accounting aggregation aggregation-type**. For more information about operational mode commands, see the *JUNOS System Basics and Services Command Reference*.

Examples: Configuring Version 9 Flow Templates

The following is a sample version 9 template configuration:

```
services {
  flow-monitoring {
    version9 {
      template ip-template {
        flow-active-timeout 20;
        flow-inactive-timeout 120;
        ipv4-template;
      }
      template mpls-template-1 {
        mpls-template {
          label-position [1 3 4];
        }
      }
      template mpls-ipv4-template-1 {
        mpls-ipv4-template {
          label-position [1 5 7];
        }
      }
    }
  }
}
```

The following is a sample firewall filter configuration for MPLS traffic:

```
firewall {
  family mpls {
    filter mpls_sample {
      term default {
        then {
          accept;
          sample;
        }
      }
    }
  }
}
```

The following sample configuration applies the MPLS sampling filter on a networking interface and configures the AS PIC to accept both IPv4 and MPLS traffic:

```
interfaces {
  at-0/1/1 {
    unit 0 {
      family mpls {
        filter {
          input mpls_sample;
        }
      }
    }
  }
}
```

```

sp-7/0/0 {
  unit 0 {
    family inet;
    family mpls;
  }
}

```

The following example applies the MPLS version 9 template to the sampling output and sends it to the AS PIC:

```

forwarding-options {
  sampling {
    input {
      family mpls {
        rate 1;
      }
    }
    output {
      flow-active-timeout 60;
      flow-inactive-timeout 30;
      cflowd 1.2.3.4 {
        port 2055;
        version9 {
          template mpls-ipv4-template-1;
        }
      }
    }
    interface sp-7/0/0 {
      source-address 1.1.1.1;
    }
  }
}

```

Directing Replicated Flows to Multiple Flow Servers

You can configure replication of the sampled flow records for use by multiple flow servers. You can use either sampling based on the Routing Engine, using cflowd version 5 or version 8, or sampling based on the services PIC, using flow aggregation version 9, as described in the following sections:

- Directing Replicated Routing Engine–Based Sampling Flows to Multiple Servers on page 822
- Directing Replicated Version 9 Flow Aggregates to Multiple Servers on page 823

Directing Replicated Routing Engine–Based Sampling Flows to Multiple Servers

Routing Engine–based sampling supports up to eight flow servers for both cflowd version 5 and version 8 configurations. The total number of servers is limited to eight regardless of how many are configured for cflowd v5 or v8.

When you configure cflowd-based sampling, the export packets are replicated to all flow servers configured to receive them. If two servers are configured to receive v5 records, both the servers will receive records for a specified flow.



NOTE: With Routing Engine–based sampling, if multiple flow servers are configured with version 8 export format, all of them must use the same aggregation type. For example, all servers receiving version 8 export could be configured for source-destination aggregation type.

The following configuration example allows replication of export packets to two flow servers.

```
forwarding-options {
  sampling {
    input {
      family inet {
        rate 1;
      }
    }
    output {
      cflowd 10.10.3.2 {
        port 2055;
        version 5;
        source-address 192.168.164.119;
      }
      cflowd 172.17.20.62 {
        port 2055;
        version 5;
        source-address 192.168.164.119;
      }
    }
  }
}
```

Directing Replicated Version 9 Flow Aggregates to Multiple Servers

The export packets generated for a template are replicated to all the flow servers that are configured to receive information for that template. The maximum number of servers supported is eight.

This also implies that periodic updates required by version 9 (RFC 3954) are sent to each configured collector. The following updates are sent periodically as part of this requirement:

- Options data
- Template definition

The refresh period for options data and template definition is configured on a per-template basis at the [edit services flow-monitoring] hierarchy level.

The following configuration example allows replication of version 9 export packets to two flow servers.

```
forwarding-options {
  sampling {
    input {
```

```

        family inet {
            rate 1;
        }
    }
    output {
        cflowd 10.10.3.2 {
            port 2055;
            version9 {
                template {
                    ipv4;
                }
            }
        }
        cflowd 172.17.20.62 {
            port 2055;
            version9 {
                template {
                    ipv4;
                }
            }
        }
        flow-inactive-timeout 30;
        flow-active-timeout 60;
        interface sp-4/0/0 {
            source-address 10.10.3.4;
        }
    }
}

```

Logging cflowd Flows Before Export

To collect the cflowd flows in a log file before they are exported, include the **local-dump** statement at the [edit forwarding-options sampling output cflowd *hostname*] hierarchy level:

```

[edit forwarding-options sampling output cflowd hostname]
local-dump;

```

By default, the flows are collected in `/var/log/sampled`; to change the filename, include the **filename** statement at the [edit forwarding-options sampling traceoptions] hierarchy level. For more information about changing the filename, see “Configuring Traffic Sampling Output” on page 803.



NOTE: Because the **local-dump** statement adds extra overhead, you should use it only while debugging cflowd problems, not during normal operation.

The following is an example of the flow information. The AS number exported is the origin AS number. All flows that belong under a cflowd header are dumped, followed by the header itself:


```

Jun 27 18:35:43 v5 flow entry
Jun 27 18:35:43   Src addr: 192.53.127.1
Jun 27 18:35:43   Dst addr: 192.6.255.15
Jun 27 18:35:43   Nhop addr: 192.6.255.240
Jun 27 18:35:43   Input interface: 5
Jun 27 18:35:43   Output interface: 3
Jun 27 18:35:43   Pkts in flow: 15
Jun 27 18:35:43   Bytes in flow: 600
Jun 27 18:35:43   Start time of flow: 7230
Jun 27 18:35:43   End time of flow: 7271
Jun 27 18:35:43   Src port: 26629
Jun 27 18:35:43   Dst port: 179
Jun 27 18:35:43   TCP flags: 0x10
Jun 27 18:35:43   IP proto num: 6
Jun 27 18:35:43   TOS: 0xc0
Jun 27 18:35:43   Src AS: 7018
Jun 27 18:35:43   Dst AS: 11111
Jun 27 18:35:43   Src netmask len: 16
Jun 27 18:35:43   Dst netmask len: 0

```

[... 41 more version 5 flow entries; then the following header:]

```

Jun 27 18:35:43 cflowd header:
Jun 27 18:35:43   Num-records: 42
Jun 27 18:35:43   Version: 5
Jun 27 18:35:43   low seq num: 118
Jun 27 18:35:43   Engine id: 0
Jun 27 18:35:43   Engine type: 3

```

Configuring Port Mirroring

On routers containing an Internet Processor II application-specific integrated circuit (ASIC) or T-series Internet Processor, you can send a copy of an IP version 4 (IPv4) or IP version 6 (IPv6) packet from the router to an external host address or a packet analyzer for analysis. This is known as *port mirroring*.

Port mirroring is different from traffic sampling. In traffic sampling, a sampling key based on the IPv4 header is sent to the Routing Engine. There, the key can be placed in a file, or cflowd packets based on the key can be sent to a cflowd server. In port mirroring, the entire packet is copied and sent out through a next-hop interface.

You can configure simultaneous use of sampling and port mirroring, and set an independent sampling rate and run-length for port-mirrored packets. However, if a packet is selected for both sampling and port mirroring, only one action can be performed and port mirroring takes precedence. For example, if you configure an interface to sample every packet input to the interface and a filter also selects the packet to be port mirrored to another interface, only the port mirroring would take effect. All other packets not matching the explicit filter port-mirroring criteria continue to be sampled when forwarded to their final destination.

To prepare traffic for port mirroring, include the **filter** statement at the [edit firewall family inet] hierarchy level:

```
filter filter-name;
```

This filter at the [edit firewall family (inet | inet6)] hierarchy level selects traffic to be port-mirrored:

```
filter filter-name {
  term term-name {
    then {
      port-mirror;
      accept;
    }
  }
}
```

To configure port mirroring on a logical interface, configure the following statements at the [edit forwarding-options port-mirroring] hierarchy level:

```
[edit forwarding-options port-mirroring]
input {
  rate rate;
  run-length number;
}
family (inet | inet6) {
  output {
    interface interface-name {
      next-hop address;
    }
    no-filter-check;
  }
}
traceoptions {
  file filename <files number> <size bytes> <world-readable | no-world-readable>;
}
```

Specify the port-mirroring destination by including the `next-hop` statement at the [edit forwarding-options port-mirroring output interface *interface-name*] hierarchy level:

```
next-hop address;
```



NOTE: For IPv4 port mirroring to reach a next-hop destination, you must manually include a static Address Resolution Protocol (ARP) entry in the router configuration.

The `no-filter-check` statement is required when you send port-mirrored traffic to a Tunnel PIC that has a filter applied to it. en

The interface used to send the packets to the analyzer is the output interface configured above at the [edit forwarding-options port-mirroring family (inet | inet6) output] hierarchy level. You can use any physical interface type, including generic routing encapsulation (GRE) tunnel interfaces. The next-hop address specifies the destination address; this statement is mandatory for non point-to-point interfaces, such as Ethernet interfaces.



NOTE: You can configure next-hop-groups for the MX-series routers using either IP address or Layer 2 addresses for the next hops. Use the `group-type [inet | layer-2]` statement at `[edit forwarding-options next-hop-group next-hop-group-name]` hierarchy level to establish the next hop groups. You can also reference more than one port mirroring instance in a filter on MX-series routers. Use the `port-mirror-instance instance-name` statement at the `[edit firewall family family-name filter filter-name term term-name]` to refer to one of several port mirroring instances.

To configure the sampling rate or duration, include the `rate` or `run-length` statement at the `[edit forwarding-options port-mirroring input]` hierarchy level.

You can trace port-mirroring operations the same way you trace sampling operations. For more information, see “Tracing Traffic Sampling Operations” on page 805.

For more information about port mirroring, see the following sections:

- Configuring Tunnels on page 827
- Filter-Based Forwarding with Multiple Monitoring Interfaces on page 828
- Restrictions on page 828
- Configuring Port Mirroring on Services Interfaces on page 829
- Examples: Configuring Port Mirroring on page 830

Configuring Tunnels

In typical applications, you send the sampled packets to an analyzer or a workstation for analysis, rather than another router. If you must send this traffic over a network, you should use tunnels. For more information about tunnel interfaces, see “Tunnel Interfaces Configuration Guidelines” on page 1093.

If your router is equipped with a Tunnel PIC, you can forward duplicate packets to multiple interfaces by configuring a next-hop group. To configure a next-hop group, include the `next-hop-group` statement at the `[edit forwarding-options]` hierarchy level:

```
[edit forwarding-options]
next-hop-group group-names {
  interface interface-name {
    next-hop address;
  }
}
```

The `interface` statement specifies the interface that sends out sampled information. The `next-hop` statement specifies the next-hop addresses to which to send the sampled information.

Next-hop groups have the following restrictions:

- Next-hop groups are supported for IPv4 addresses only.
- Next-hop groups are supported on M-series routers only, except the M120 and the M320.

- Next-hop groups support up to 16 next-hop addresses.
- Up to 30 next-hop groups are supported.
- Each next-hop group must have at least two next-hop addresses.

Filter-Based Forwarding with Multiple Monitoring Interfaces

If port-mirrored packets are to be distributed to multiple monitoring or collection interfaces based on patterns in packet headers, it is helpful to configure a filter-based forwarding (FBF) filter on the port-mirroring egress interface.

When an FBF filter is installed as an output filter, a packet that is forwarded to the filter has already undergone at least one route lookup. After the packet is classified at the egress interface by the FBF filter, it is redirected to another routing table for additional route lookup. Obviously, the route lookup in the latter routing table (designated by an FBF routing instance) must result in a different next hop from those from the previous tables the packet has passed through, to avoid packet looping inside the Packet Forwarding Engine.

For more information about FBF configuration, see the *JUNOS Routing Protocols Configuration Guide*. For an example of FBF applied to an output interface, see “Examples: Configuring Port Mirroring” on page 830.

Restrictions

The following restrictions apply to port-mirroring configurations:

- The interface you configure for port mirroring should not participate in any kind of routing activity.
- The destination address you specify should not have a route to the ultimate traffic destination. For example, if the sampled IPv4 packets have a destination address of 10.68.9.10 and the port-mirrored traffic is sent to 10.68.20.15 for analysis, the device associated with the latter address should not know a route to 10.68.9.10. Also, it should not send the sampled packets back to the source address.
- IPv4 and IPv6 traffic is supported. For IPv6 port mirroring, you must configure the next-hop router with an IPv6 neighbor before mirroring the traffic, similar to an ARP request for IPv4 traffic. All the restrictions applied to IPv4 configurations should also apply to IPv6.
- On M120, M320, and T-series routing platforms, simultaneous IPv4 and IPv6 port mirroring is supported. Multiple next-hop mirroring is not supported.
- On M-series platforms other than the M120 and M320 routers, only one family protocol (either IPv4 or IPv6) is supported at a time.
- Port mirroring supports up to 16 next hops, but there is no next-hop group support for `inet6`.
- Only transit data is supported.
- You can configure multiple port-mirroring interfaces per router.

- You must include a firewall filter with both the **accept** action and the **port-mirror** action modifier on the inbound interface. Do not include the **discard** action, or port mirroring will not work.
- If the port-mirroring interface is a non-point-to-point interface, you must include an IP address under the **port-mirroring** statement to identify the other end of the link. This IP address must be reachable for you to see the sampled traffic. If the port-mirroring interface is an Ethernet interface, the router should have an Address Resolution Protocol (ARP) entry for it. The following sample configuration sets up a static ARP entry.
- You do not need to configure firewall filters on both inbound and outbound interfaces, but at least one is necessary on the inbound interface to provide the copies of the packets to send to an analyzer.

Configuring Port Mirroring on Services Interfaces

A special situation arises when you configure unit 0 of a services interface (AS or MultiServices PIC) to be the port-mirroring logical interface, as in the following example:

```
[edit forwarding-options]
port-mirroring {
  input {
    rate 1;
  }
  family inet {
    output {
      interface sp-1/0/0.0;
    }
  }
}
```

Since any traffic directed to unit 0 on a services interface is targeted for monitoring (cflowd packets are generated for it), the sample port-mirroring configuration indicates that the customer would like to have cflowd records generated for the port-mirrored traffic.

However, generation of cflowd records requires the following additional configuration; if it is missing, the port-mirrored traffic is simply dropped by the services interface without generating any cflowd packets.

```
[edit forwarding-options]
sampling {
  input {
    family inet {
      rate 1;
    }
  }
  output {
    cflowd 172.16.28.65 {
      port 1230;
    }
    interface sp-1/0/0 { # If the port-mirrored traffic requires monitoring, this
                        # interface must be same as that specified in the
```

```

                                # port-mirroring configuration.
        source-address 3.1.2.3;
    }
}

```



NOTE: Another way to configure `sp-1/0/0` to generate cflowd records is to use only the sampling configuration, but include a firewall filter `sample` action instead of a port-mirror action.

Examples: Configuring Port Mirroring

The following example sends port-mirrored traffic to multiple cflowd servers or packet analyzers:

```

[edit interfaces]
ge-1/0/0 { # This is the input interface where packets enter the router.
  unit 0 {
    family inet {
      filter {
        input mirror_pkts; # Here is where you apply the first filter.
      }
      address 10.11.0.1/24;
    }
  }
}
ge-1/1/0 { # This is an exit interface for HTTP packets.
  unit 0 {
    family inet {
      address 10.12.0.1/24;
    }
  }
}
ge-1/2/0 { # This is an exit interface for HTTP packets.
  unit 0 {
    family inet {
      address 10.13.0.1/24;
    }
  }
}
so-0/3/0 { # This is an exit interface for FTP packets.
  unit 0 {
    family inet {
      address 10.1.1.1/30;
    }
  }
}
so-4/3/0 { # This is an exit interface for FTP packets.
  unit 0 {
    family inet {
      address 10.2.2.2/30;
    }
  }
}

```

```

so-7/0/0 { # This is an exit interface for all remaining packets.
    unit 0 {
        family inet {
            address 10.5.5.5/30;
        }
    }
}
so-7/0/1 { # This is an exit interface for all remaining packets.
    unit 0 {
        family inet {
            address 10.6.6.6/30;
        }
    }
}
vt-3/3/0 { # The tunnel interface is where you send the port mirrored traffic.
    unit 0 {
        family inet;
    }
    unit 1 {
        family inet {
            filter {
                input collect_pkts; # This is where you apply the second firewall filter.
            }
        }
    }
}
[edit forwarding-options]
port-mirroring { # This is required when you configure next-hop groups.
    input {
        rate 1; # This rate port mirrors one packet for every one received (1:1 = all
                # packets).
    }
    family inet {
        output { # This sends traffic to a tunnel interface to prepare for multiport mirroring.
            interface vt-3/3/0.1;
            no-filter-check;
        }
    }
}
next-hop-group ftp-traffic { # Point-to-point interfaces require you to specify the interface
    # name only.
    interface so-4/3/0.0;
    interface so-0/3/0.0;
}
next-hop-group http-traffic { # You need to configure a next hop for multipoint interfaces
    # (Ethernet).
    interface ge-1/1/0.0 {
        next-hop 10.12.0.2;
    }
    interface ge-1/2/0.0 {
        next-hop 10.13.0.2;
    }
}
next-hop-group default-collect {
    interface so-7/0/0.0;
    interface so-7/0/1.0;
}

```

```

}
[edit firewall]
family inet {
  filter mirror_pkts { # Apply this filter to the input interface.
    term catch_all {
      then {
        count input_mirror_pkts;
        port-mirror; # This action sends traffic to be copied and port mirrored.
        accept;
      }
    }
  }
  filter collect_pkts { # Apply this filter to the tunnel interface.
    term ftp-term { # This term sends FTP traffic to an FTP next-hop group.
      from {
        protocol ftp;
      }
      then next-hop-group ftp-traffic;
    }
    term http-term {# This term sends HTTP traffic to an HTTP next-hop group.
      from {
        protocol http;
      }
      then next-hop-group http-traffic;
    }
    term default {# This term sends all remaining traffic to a final next-hop group.
      then next-hop-group default-collectors;
    }
  }
}

```

The following example demonstrates configuration of filter-based forwarding at the output interface. In this example, the packet flow follows this path:

1. A packet arrives at interface **fe-1/2/0.0** with source and destination addresses **10.50.200.1** and **10.50.100.1**, respectively.
2. The route lookup in routing table **inet.0** points to the egress interface **so-0/0/3.0**.
3. The output filter installed at **so-0/0/3.0** redirects the packet to routing table **fbf.inet.0**.
4. The packet matches the entry **10.50.100.0/25**, and finally leaves the router from interface **so-2/0/0.0**.

```

[edit interfaces]
so-0/0/3 {
  unit 0 {
    family inet {
      filter {
        output fbf;
      }
      address 10.50.10.2/25;
    }
  }
}
fe-1/2/0 {

```



```

unit 0 {
    family inet {
        address 10.50.50.2/25;
    }
}
so-2/0/0 {
    unit 0 {
        family inet {
            address 10.50.20.2/25;
        }
    }
}
[edit firewall]
filter fbf {
    term 0 {
        from {
            source-address {
                10.50.200.0/25;
            }
        }
        then routing-instance fbf;
    }
    term d {
        then count d;
    }
}
[edit routing-instances]
fbf {
    instance-type forwarding;
    routing-options {
        static {
            route 10.50.100.0/25 next-hop so-2/0/0.0;
        }
    }
}
[edit routing-options]
interface-routes {
    rib-group inet fbf-group;
}
static {
    route 10.50.100.0/25 next-hop 10.50.10.1;
}
rib-groups {
    fbf-group {
        import-rib [ inet.0 fbf.inet.0 ];
    }
}

```

Load Balancing Among Multiple Monitoring Interfaces

The active monitoring application was initially intended for port-mirroring packets on an interface on a normal network router to single or multiple destinations. By port-mirroring these packets to a tunnel interface and using filter-based forwarding

on the tunnel interface, port-mirrored packets can be load-balanced across set of interfaces. This method employs existing configuration statements for passive monitoring.

The configuration consists of the following parts; sample values are included for illustration only.

- Firewall filter configuration—Firewall filter PORT-MIRROR-TO-VT is used to port-mirror the packet to a Tunnel PIC, and filter **catch**, applied on the virtual tunnel (vt) interface, is used to send traffic to a filter-based routing instance.

```
[edit firewall]
filter PORT-MIRROR-TO-VT {
  term a {
    then {
      port-mirror;
      accept;
    }
  }
}
filter catch {
  term def {
    then {
      count counter;
      routing-instance fbf_instance;
    }
  }
}
```

For more information about firewall filters, see the *JUNOS Policy Framework Configuration Guide*.

- Interface configuration—Apply filter PORT-MIRROR-TO-VT to the interface on which traffic is to be monitored actively.

```
[edit interfaces]
ge-1/3/0 {
  unit 0 {
    family inet {
      filter {
        input PORT-MIRROR-TO-VT;
      }
      address 10.38.0.2/30;
    }
  }
}
vt-3/2/0 {
  unit 0 {
    family inet {
      filter {
        input catch;
      }
    }
  }
}
```

```

mo-6/1/0 {
  unit 0 {
    family inet;
  }
}
mo-6/2/0 {
  unit 0 {
    family inet;
  }
}
mo-6/3/0 {
  unit 0 {
    family inet;
  }
}
mo-7/1/0 {
  unit 0 {
    family inet;
  }
}
mo-7/2/0 {
  unit 0 {
    family inet;
  }
}
mo-7/3/0 {
  unit 0 {
    family inet;
  }
}

```

For more information on configuring interface properties, see the *JUNOS Network Interfaces Configuration Guide*.

- Routing instance configuration for filter-based forwarding:

```

[edit routing-instances fbf_instance]
instance-type forwarding;
routing-options {
  static {
    route 0.0.0.0/0 next-hop [ mo-7/1/0.0 mo-7/2/0.0 mo-7/3/0.0 mo-6/3/0.0
                             mo-6/2/0.0 mo-6/1/0.0 ];
  }
}

```

For more information on routing instance configuration, see the *JUNOS Routing Protocols Configuration Guide*.

- Routing table groups—Configure the routing table group to resolve the routes installed in the routing instances to directly connected next hops on the interface:

```

[edit routing-options]
interface-routes {
  rib-group inet common;
}

```

```

rib-groups {
  common {
    import-rib [ inet.0 fbf_instance.inet.0 ];
  }
}
forwarding-table {
  export pplb;
}

```

For more information on routing table groups, see the *JUNOS Routing Protocols Configuration Guide*.

- Policy for per-packet load balancing:

```

[edit policy-options]
policy-statement pplb {
  then {
    load-balance per-packet;
  }
}

```

For more information on routing policy groups, see the *JUNOS Policy Framework Configuration Guide*.

- Port mirroring and monitoring groups—Configure the monitoring services options, and also define hash-based load balancing:

```

[edit forwarding-options]
port-mirroring {
  input {
    rate 1;
  }
  family inet {
    output {
      interface vt-3/2/0.0;
      no-filter-check;
    }
  }
}
monitoring group1 {
  family inet {
    output {
      export-format cflowd-version-5;
      flow-active-timeout 60;
      flow-inactive-timeout 15;
      cflowd 10.36.252.1 port 2055;
      interface mo-6/1/0.0 {
        source-address 10.36.252.2;
      }
      interface mo-6/2/0.0 {
        source-address 10.36.252.2;
      }
      interface mo-6/3/0.0 {
        source-address 10.36.252.2;
      }
    }
  }
}

```

```

        interface mo-7/1/0.0 {
            source-address 10.36.252.2;
        }
        interface mo-7/2/0.0 {
            source-address 10.36.252.2;
        }
        interface mo-7/3/0.0 {
            source-address 10.36.252.2;
        }
    }
}
hash-key {
    family inet {
        layer-3;
    }
}

```

For more information on hash keys, see the *JUNOS Policy Framework Configuration Guide*.

Configuring Discard Accounting

Discard accounting is similar to traffic sampling, but varies from it in two ways:

- In discard accounting, the packet is intercepted by the monitoring PIC and is not forwarded to its destination.
- Traffic sampling allows you to limit the number of packets sampled by configuring the `max-packets-per-second`, `rate`, and `run-length` statements. Discard accounting does not provide these options, and a high packet count can potentially overwhelm the monitoring PIC.

To configure discard accounting, include the `accounting` statement at the `[edit forwarding-options]` hierarchy level:

```

accounting name {
    output {
        aggregate-export-interval seconds;
        cflowd hostname {
            aggregation {
                autonomous-system;
                destination-prefix;
                protocol-port;
                source-destination-prefix {
                    caida-compliant;
                }
                source-prefix;
            }
            autonomous-system-type (origin | peer);
            port port-number;
            version format;
        }
        flow-active-timeout seconds;
    }
}

```

```

    flow-inactive-timeout seconds;
    interface interface-name {
        engine-id number;
        engine-type number;
        source-address address;
    }
}

```

A discard instance is a named entity that specifies collector information under the **accounting *name*** statement. Discard instances are referenced in firewall filter **term** statements by including the **then discard accounting *name*** statement.

Most of the other statements are also found at the [edit forwarding-options sampling] hierarchy level. For information on cflowd, see “Enabling Flow Aggregation” on page 813. The **flow-active-timeout** and **flow-inactive-timeout** statements are described in “Configuring Flow Monitoring” on page 809.

To direct sampled traffic to a flow-monitoring interface, include the **interface** statement. The **engine-id** and **engine-type** statements specify the accounting interface used on the traffic, and the **source-address** statement specifies the traffic source.

You cannot use rate-limiting with discard accounting; however, you can specify the duration of the interval for exporting aggregated accounting information by including the **aggregate-export-interval** statement in the configuration. This enables you to put a boundary on the amount of traffic exported to a flow-monitoring interface.

Enabling Passive Flow Monitoring

You can monitor IPv4 traffic from another router if you have the following components installed in an M40e, M160, M320, or T-series routing platform:

- Monitoring Services, Adaptive Services, or MultiServices PICs to perform the service processing.
- SONET/SDH, Fast Ethernet, or Gigabit Ethernet PICs as transit interfaces.

On SONET/SDH interfaces, you enable passive flow monitoring by including the **passive-monitor-mode** statement at the [edit interfaces *so-fpc/pic/port* unit *logical-unit-number*] hierarchy level:

```

[edit interfaces so-fpc/pic/port unit logical-unit-number]
passive-monitor-mode;

```

On Asynchronous Transfer Mode (ATM), Fast Ethernet, or Gigabit Ethernet interfaces, you enable passive flow monitoring by including the **passive-monitor-mode** statement at the [edit interfaces *interface-name*] hierarchy level:

```

[edit interfaces interface-name]
passive-monitor-mode;

```

When you configure an interface in passive monitoring mode, the Packet Forwarding Engine silently drops packets coming from that interface and destined to the router itself. Passive monitoring mode also stops the Routing Engine from transmitting any packet from that interface. Packets received from the monitored interface can be forwarded to monitoring interfaces. If you include the **passive-monitor-mode** statement in the configuration:

- The ATM interface is always up, and the interface does not receive or transmit incoming control packets, such as Operation, Administration, and Maintenance (OAM) and Interim Local Management Interface (ILMI) cells.
- The SONET/SDH interface does not send keepalives or alarms, and does not participate actively on the network.
- Gigabit and Fast Ethernet interfaces can support both per-port passive monitoring and per-VLAN passive monitoring. The destination MAC filter on the receive port of the Ethernet interfaces is disabled.
- Ethernet encapsulation options are not allowed.

On monitoring services interfaces, you enable passive flow monitoring by including the **family** statement at the [edit interfaces *interface-name* unit *logical-unit-number*] hierarchy level, specifying the **inet** option:

```
[edit interfaces interface-name unit logical-unit-number]
family inet;
```

For the monitoring services interface, you can configure multiservice physical interface properties. For more information, see “Configuring Flow-Monitoring Interfaces” on page 809.

For conformity with cflowd record structure, you must include the **receive-options-packets** and **receive-ttl-exceeded** statements at the [edit interfaces *interface-name* unit *logical-unit-number* family inet] hierarchy level:

```
[edit interfaces interface-name unit logical-unit-number family inet]
receive-options-packets;
receive-ttl-exceeded;
```

For more information, see the following sections:

- Passive Flow Monitoring for MPLS Encapsulated Packets on page 839
- Example: Enabling Passive Flow Monitoring on page 841

Passive Flow Monitoring for MPLS Encapsulated Packets

On monitoring services interfaces, you can process MPLS packets that have not been assigned label values and have no corresponding entry in the **mpls.0** routing table. This allows you to assign a default route to unlabeled MPLS packets.

To configure a default label value for MPLS packets, include the **default-route** statement at the [edit protocols mpls interface *interface-name* label-map] hierarchy level:

```
[edit protocols mpls interface interface-name label-map]
default-route {
```

```

(next-hop (address | interface-name | address/interface-name)) | (reject | discard);
(pop | (swap <out-label>));
class-of-service value;
preference preference;
type type;
}

```

For more information about static labels, see the *JUNOS MPLS Applications Configuration Guide*.

Removing MPLS Labels from Incoming Packets

The JUNOS software can forward only IPv4 packets to a Monitoring Services, Adaptive Services, or MultiServices PIC. IPv4 packets with MPLS labels cannot be forwarded to a monitoring PIC. By default, if packets with MPLS labels are forwarded to the monitoring PIC, they are discarded. To monitor packets with MPLS labels, you must remove the MPLS labels as the packets arrive on the interface.

You can remove up to two MPLS labels from an incoming packet by including the `pop-all-labels` statement at the [edit interfaces *interface-name* (atm-options | fastether-options | gigether-options | sonet-options) mpls] hierarchy level:

```

[edit interfaces interface-name (atm-options | fastether-options | gigether-options |
sonet-options) mpls]
pop-all-labels {
    required-depth [ numbers ];
}

```

By default, the `pop-all-labels` statement takes effect for incoming packets with one or two labels. You can specify the number of MPLS labels that an incoming packet must have for the `pop-all-labels` statement to take effect by including the `required-depth` statement at the [edit interfaces *interface-name* (atm-options | fastether-options | gigether-options | sonet-options) mpls pop-all-labels] hierarchy level:

```

[edit interfaces interface-name (atm-options | fastether-options | gigether-options |
sonet-options) mpls pop-all-labels]
required-depth [ numbers ];

```

The required depth can be 1, 2, or [1 2]. If you include the `required-depth 1` statement, the `pop-all-labels` statement takes effect for incoming packets with one label only. If you include the `required-depth 2` statement, the `pop-all-labels` statement takes effect for incoming packets with two labels only. If you include the `required-depth [1 2]` statement, the `pop-all-labels` statement takes effect for incoming packets with one or two labels. A required depth of [1 2] is equivalent to the default behavior of the `pop-all-labels` statement.

When you remove MPLS labels from incoming packets, note the following:

- The `pop-all-labels` statement has no effect on IP packets with three or more MPLS labels.
- When you enable MPLS label removal, you must configure all ports on a PIC with the same label popping mode and required depth.

- You use the **pop-all-labels** statement to enable passive monitoring applications, not active monitoring.
- You cannot apply MPLS filters or accounting to the MPLS labels because the labels are removed as soon as the packet arrives on the interface.
- On ATM2 interfaces, you must use a label value greater than 4095, because the lower range of MPLS labels is reserved for label-switched interface (LSI) and virtual private LAN service (VPLS) support. For more information, see the *JUNOS VPNs Configuration Guide*.
- The following ATM encapsulation types are not supported on interfaces with MPLS label removal:
 - atm-ccc-cell-relay
 - atm-ccc-vc-mux
 - atm-mlppp-llc
 - atm-tcc-snap
 - atm-tcc-vc-mux
 - ether-over-atm-llc
 - ether-vpls-over-atm-llc

Example: Enabling Passive Flow Monitoring

The following example shows a complete configuration for enabling passive flow monitoring on an Ethernet interface.

In this example, the Gigabit Ethernet interface can accept all Ethernet packets. It strips VLAN tags (if there are any) and up to two MPLS labels blindly, and passes IPv4 packets to the monitoring interface. With this configuration, it can monitor IPv4, VLAN + IPv4, VLAN + MPLS + IPv4, and VLAN + MPLS + MPLS + IPv4 labeled packets.

The Fast Ethernet interface can accept only packets with VLAN ID 100. All other packets are dropped. With this configuration, it can monitor VLAN (ID = 100) + IPv4, VLAN (ID = 100) + MPLS + IPv4, and VLAN (ID = 100) + MPLS + MPLS + IPv4 labeled packets.

```
[edit firewall]
family inet {
  filter input-monitoring-filter {
    term def {
      then {
        count counter;
        accept;
      }
    }
  }
}
[edit interfaces]
ge-0/0/0 {
```

```

    passive-monitor-mode;
    gigether-options {
        mpls {
            pop-all-labels;
        }
    }
    unit 0 {
        family inet {
            filter {
                input input-monitoring-filter;
            }
        }
    }
}
fe-0/1/0 {
    passive-monitor-mode;
    vlan-tagging;
    fastether-options {
        mpls {
            pop-all-labels required-depth [ 1 2 ];
        }
    }
    unit 0 {
        vlan-id 100;
        family inet {
            filter {
                input input-monitoring-filter;
            }
        }
    }
}
mo-1/0/0 {
    unit 0 {
        family inet {
            receive-options-packets;
            receive-ttl-exceeded;
        }
    }
    unit 1 {
        family inet;
    }
}
[edit forwarding-options]
monitoring mon1 {
    family inet {
        output {
            export-format cflowd-version-5;
            cflowd 50.0.0.2 port 2055;
            interface mo-1/0/0.0 {
                source-address 50.0.0.1;
            }
        }
    }
}
[edit routing-instances]
monitoring-vrf {

```

```

instance-type vrf;
interface ge-0/0/0.0;
interface fe-0/1/0.0;
interface mo-1/0/0.1;
route-distinguisher 68:1;
vrf-import monitoring-vrf-import;
vrf-export monitoring-vrf-export;
routing-options {
    static {
        route 0.0.0.0/0 next-hop mo-1/0/0.1;
    }
}
[edit policy-options]
policy-statement monitoring-vrf-import {
    then {
        reject;
    }
}
policy-statement monitoring-vrf-export {
    then {
        reject;
    }
}

```

Configuring Services Interface Redundancy with Flow Monitoring

Active monitoring services configurations on AS or MultiServices PICs support redundancy. To configure redundancy, you specify a redundancy services PIC (**rsp**) interface in which the primary AS or MultiServices PIC is active and a secondary PIC is on standby. If the primary PIC fails, the secondary PIC becomes active, and all service processing is transferred to it. If the primary PIC is restored, it remains on standby and does not preempt the secondary PIC; you need to manually restore the services to the primary PIC. To determine which PIC is currently active, issue the **show interfaces redundancy** command.



NOTE: On flow-monitoring configurations, the only service option supported is *warm standby*, in which one backup PIC supports multiple working PICs. Recovery times are not guaranteed, because the configuration must be completely restored on the backup PIC after a failure is detected. However, configuration is preserved and available on the new active PIC.

As with the other services that support warm standby, you can issue the **request interfaces (revert | switchover)** command to switch manually between the primary and secondary flow monitoring interfaces.

For more information, see “Configuring AS or MultiServices PIC Redundancy” on page 483. For information on operational mode commands, see the *JUNOS Interfaces Command Reference*.

A sample configuration follows.

```

interface {
  rsp0 {
    redundancy-options {
      primary sp-0/0/0;
      secondary sp-1/3/0;
    }
    unit 0 {
      family inet;
    }
  }
}
interface {
  ge-0/2/0 {
    unit 0 {
      family inet {
        filter {
          input as_sample;
        }
      }
      address 10.58.255.49/28;
    }
  }
}
forwarding-options {
  sampling {
    input {
      family inet {
        rate 1;
        run-length 0;
        max-packets-per-second 65535;
      }
    }
    output {
      cflowd 10.10.10.2 {
        port 5000;
        version 5;
      }
      flow-active-timeout 60;
      interface rsp0 {
        source-address 10.10.10.1;
      }
    }
  }
}
firewall {
  filter as_sample {
    term t1 {
      then {
        sample;
        accept;
      }
    }
  }
}
}

```

Chapter 47

Summary of Flow-Monitoring Configuration Statements

The following sections explain each of the flow-monitoring configuration statements. The statements are organized alphabetically.

accounting

Syntax

```

accounting name {
  output {
    aggregate-export-interval seconds;
    cflowd hostname {
      aggregation {
        autonomous-system;
        destination-prefix;
        protocol-port;
        source-destination-prefix {
          caida-compliant;
        }
        source-prefix;
      }
      autonomous-system-type (origin | peer);
      port port-number;
      version format;
    }
    flow-active-timeout seconds;
    flow-inactive-timeout seconds;
    interface interface-name {
      engine-id number;
      engine-type number;
      source-address address;
    }
  }
}

```

Hierarchy Level [edit forwarding-options]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the discard accounting instance name and options.

The statements are explained separately.

Usage Guidelines See “Configuring Discard Accounting” on page 837.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

address

Syntax	address <i>address</i> { destination <i>address</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the interface address.
Options	<i>address</i> —Address of the interface. The remaining statement is explained separately.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809 or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other options not associated with flow monitoring.

aggregate-export-interval

Syntax	aggregate-export-interval <i>seconds</i> ;
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output], [edit forwarding-options sampling output]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the duration, in seconds, of the interval for exporting aggregate accounting information.
Options	<i>seconds</i> —Duration.
Usage Guidelines	See “Configuring Discard Accounting” on page 837.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

aggregation

Syntax	<pre>aggregation { autonomous-system; destination-prefix; protocol-port; source-destination-prefix { caida-compliant; } source-prefix; }</pre>
Hierarchy Level	[edit forwarding-options accounting output cflowd <i>hostname</i>], [edit forwarding-options sampling output cflowd <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For cflowd version 8 only, specify the type of data to be aggregated; cflowd records and sends only those flows that match the specified criteria.
Options	<p>autonomous-system—Aggregate by autonomous system (AS) number.</p> <p>caida-compliant—Record source and destination mask-length values in compliance with the Version 2.1b1 release of CAIDA's cflowd application. If this statement is not configured, the JUNOS software records source and destination mask length values in compliance with the <i>cflowd Configuration Guide</i>, dated August 30, 1999.</p> <p>destination-prefix—Aggregate by destination prefix.</p> <p>protocol-port—Aggregate by protocol and port number.</p> <p>source-destination-prefix—Aggregate by source and destination prefix.</p> <p>source-prefix—Aggregate by source prefix.</p>
Usage Guidelines	See "Enabling Flow Aggregation" on page 813.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

autonomous-system-type

Syntax	autonomous-system-type (origin peer);
Hierarchy Level	[edit forwarding-options sampling output cflowd <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the type of AS numbers that cflowd exports.
Default	origin
Options	<p>origin—Export origin AS numbers of the packet source address in the Source Autonomous System cflowd field.</p> <p>peer—Export peer AS numbers through which the packet passed in the Source Autonomous System cflowd field.</p>
Usage Guidelines	See “Enabling Flow Aggregation” on page 813.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

cflowd

See the following sections:

- cflowd (Discard Accounting and Sampling) on page 850
- cflowd (Flow Monitoring) on page 851

cflowd (Discard Accounting and Sampling)

Syntax `cflowd hostname {
 aggregation {
 autonomous-system;
 destination-prefix;
 protocol-port;
 source-destination-prefix {
 caida-compliant;
 }
 source-prefix;
 }
 autonomous-system-type (origin | peer);
 label-position {
 template template-name;
 }
 (local-dump | no-local-dump);
 port port-number;
 source-address address;
 version format;
}`

Hierarchy Level [edit forwarding-options accounting *name* output],
 [edit forwarding-options sampling output]

Release Information Statement introduced before JUNOS Release 7.4.

Description Collect an aggregate of sampled flows and send the aggregate to a specified host system that runs the collection utility cfdcollect.

You can configure up to one version 5 and one version 8 flow format at the [edit forwarding-options accounting *name* output] hierarchy level.

You can configure up to one version 5 and one version 8 flow format at the [edit forwarding-options sampling output] hierarchy level.

Options *hostname*—The IP address or identifier of the host system (the workstation running the cflowd utility).

The remaining statements are explained separately.

Usage Guidelines See “Enabling Flow Aggregation” on page 813.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

cflowd (Flow Monitoring)

Syntax	<code>cflowd hostname { port port-number; }</code>
Hierarchy Level	[edit forwarding-options monitoring <i>name</i> family inet output]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Collect an aggregate of sampled flows and send the aggregate to a specified host system that runs the collection utility <code>cfcollect</code>.</p> <p>You can configure up to eight version 5 flow formats at the [edit forwarding-options monitoring <i>name</i> output] hierarchy level. Version 8 flow formats are not supported for flow-monitoring applications.</p>
Options	<p><i>hostname</i>—The IP address or identifier of the host system (the workstation running the <code>cflowd</code> utility).</p> <p>The remaining statement is explained separately.</p>
Usage Guidelines	See “Enabling Flow Aggregation” on page 813.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

core-dump

Syntax	<code>(core-dump no-core-dump);</code>
Hierarchy Level	[edit interfaces <i>mo-fpc/pic/port</i> multiservice-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>A useful tool for isolating the cause of a problem. Core dumping is enabled by default. The directory <code>/var/tmp</code> contains core files. The JUNOS software saves the current core file (0) and the four previous core files, which are numbered from 1 through 4 (from newest to oldest):</p> <ul style="list-style-type: none"> ■ <code>core-dump</code>—Enable the core dumping operation. ■ <code>no-core-dump</code>—Disable the core dumping operation.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

destination

Syntax	<code>destination destination-address;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For tunnel interfaces, specify the remote address of the tunnel.
Options	<i>destination-address</i> —Address of the remote side of the connection.
Usage Guidelines	See “Configuring Unicast Tunnels” on page 1093, “Configuring Traffic Sampling” on page 801, and “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

disable

Syntax	<code>disable;</code>
Hierarchy Level	[edit forwarding-options sampling], [edit forwarding-options sampling output file]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Disable traffic accounting or sampling.
Usage Guidelines	See “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

engine-id

Syntax	<code>engine-id <i>number</i>;</code>
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output interface <i>interface-name</i>], [edit forwarding-options monitoring <i>name</i> output interface <i>interface-name</i>], [edit forwarding-options sampling output interface <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the engine ID number for flow monitoring and accounting services.
Options	<i>number</i> —Identity of accounting interface.
Usage Guidelines	See “Configuring Traffic Sampling” on page 801, “Configuring Flow Monitoring” on page 809, or “Configuring Discard Accounting” on page 837.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

engine-type

Syntax	<code>engine-type <i>number</i>;</code>
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output interface <i>interface-name</i>], [edit forwarding-options monitoring <i>name</i> output interface <i>interface-name</i>], [edit forwarding-options sampling output interface <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the engine type number for flow monitoring and accounting services.
Options	<i>number</i> —Platform-specific accounting interface type.
Usage Guidelines	See “Configuring Traffic Sampling” on page 801, “Configuring Flow Monitoring” on page 809, or “Configuring Discard Accounting” on page 837.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

export-format

Syntax	export-format <i>format</i> ;
Hierarchy Level	[edit forwarding-options monitoring <i>name</i> output]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Flow monitoring export format.
Options	<i>format</i> —Format of the flows. Values: 5 or 8 Default: 5
Usage Guidelines	See “Exporting Flows” on page 811.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	version

family

See the following sections:

- family (Interfaces) on page 855
- family (Monitoring) on page 856
- family (Port Mirroring) on page 857
- family (Sampling) on page 857

family (Interfaces)

Syntax family *family* {
 address *address* {
 destination *destination-address*;
 }
 filter {
 group *filter-group-number*;
 input *filter-name*;
 output *filter-name*;
 }
 sampling *direction*;
 receive-options-packets;
 receive-ttl-exceeded;
 }

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure protocol family information for the logical interface.

Options *family*—Protocol family; for flow monitoring and accounting services, only the IP version 4 (IPv4) protocol (*inet*) is supported.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Flow Monitoring” on page 809.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other options not used with services interfaces.

family (Monitoring)

Syntax

```
family inet {
  output {
    flow-active-timeout seconds;
    flow-inactive-timeout seconds;
    export-format format;
    cflowd hostname {
      aggregation {
        autonomous-system;
        destination-prefix;
        protocol-port;
        source-destination-prefix {
          caida-compliant;
        }
        source-prefix;
      }
      port port-number;
    }
    interface interface-name {
      engine-id number;
      engine-type number;
      input-interface-index number;
      output-interface-index number;
      source-address address;
    }
  }
}
```

Hierarchy Level [edit forwarding-options monitoring *name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify input and output interfaces and properties for flow monitoring. Only IPv4 (inet) is supported.

The statements are explained separately.

Usage Guidelines See “Configuring Flow Monitoring” on page 809.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

family (Port Mirroring)

Syntax family (inet | inet6) {
 output {
 interface *interface-name* {
 next-hop *address*;
 }
 no-filter-check;
 }

Hierarchy Level [edit forwarding-options port-mirroring]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure the protocol family to be sampled. Only IPv4 (inet) and IPv6 (inet6) are supported.

The statements are explained separately.

Usage Guidelines See “Configuring Port Mirroring” on page 825.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

family (Sampling)

Syntax family (inet | inet6 | mpls) {
 max-packets-per-second *number*;
 rate *number*;
 run-length *number*;
 }

Hierarchy Level [edit forwarding-options sampling input]

Release Information Statement introduced before JUNOS Release 7.4.
 mpls option introduced in Release 8.3.
 inet6 option introduced in Release 9.4.

Description Configure the protocol family to be sampled. IPv4 (inet) is supported for most purposes, but you can configure **family mpls** to collect and export MPLS label information or **family inet6** to collect and export IPv6 traffic using flow aggregation version 9.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Traffic Sampling” on page 801.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

file

See the following sections:

- file (Sampling) on page 858
- file (Trace Options) on page 858

file (Sampling)

Syntax file {
 disable;
 filename *filename*;
 files *number*;
 size *bytes*;
 (stamp | no-stamp);
 (world-readable | no-world-readable);
 }

Hierarchy Level [edit forwarding-options sampling output]

Release Information Statement introduced before JUNOS Release 7.4.

Description Collect the traffic samples in a file.

The statements are explained separately.

Usage Guidelines See “Configuring Traffic Sampling” on page 801.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

file (Trace Options)

Syntax file *filename* <files *number* <size *bytes*> <world-readable | no-world-readable>;

Hierarchy Level [edit forwarding-options port-mirroring traceoptions],
 [edit forwarding-options sampling traceoptions]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure information about the files that contain trace logging information.

Options *filename*—The name of the file containing the trace information.
Default: /var/log/sampled

The remaining statements are explained separately.

Usage Guidelines See “Tracing Traffic Sampling Operations” on page 805.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

filename

Syntax	filename <i>filename</i> ;
Hierarchy Level	[edit forwarding-options sampling output file]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the name of the output file.
Options	<i>filename</i> —Name of the file in which to place the traffic samples. All files are placed in the directory <i>/var/tmp</i> .
Usage Guidelines	See “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

files

Syntax	files <i>number</i> ;
Hierarchy Level	[edit forwarding-options port-mirroring traceoptions file], [edit forwarding-options sampling output file], [edit forwarding-options sampling traceoptions file]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the total number of files to be saved with samples or trace data.
Options	<i>number</i> —Maximum number of traffic sampling or trace log files. When a file named <i>sampling-file</i> reaches its maximum size, it is renamed <i>sampling-file.0</i> , then <i>sampling-file.1</i> , and so on, until the maximum number of traffic sampling files is reached. Then the oldest sampling file is overwritten. Range: 1 through 100 files Default: 5 files for sampling output; 10 files for trace log information
Usage Guidelines	See “Configuring Port Mirroring” on page 825 or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

filter

Syntax filter {
 input *filter-name*;
 output *filter-name*;
 group *filter-group-number*;
 }

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number* family inet]

Release Information Statement introduced before JUNOS Release 7.4.

Description Apply a firewall filter to an interface. You can also use filters for encrypted traffic.

Options group *filter-group-number*—Define an interface to be part of a filter group. The default filter group number is 0.

 input *filter-name*—Name of one filter to evaluate when packets are received on the interface.

 output *filter-name*—Name of one filter to evaluate when packets are transmitted on the interface.

Usage Guidelines See “Configuring Flow Monitoring” on page 809.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Policy Framework Configuration Guide* or the *JUNOS System Basics Configuration Guide*

flow-active-timeout

Syntax flow-active-timeout *seconds*;

Hierarchy Level [edit forwarding-options accounting *name* output],
[edit forwarding-options monitoring *name* output],
[edit forwarding-options sampling output],
[edit services flow-monitoring version9]

Release Information Statement introduced before JUNOS Release 7.4.

Description Interval after which an active flow is exported.



NOTE: The router must include an Adaptive Services, MultiServices, or Monitoring Services PIC for this statement to take effect.

Options *seconds*—Duration of the timeout period.
Range: 60 through 1800 seconds (for forwarding-options configurations); 10 through 600 seconds (for services configurations)
Default: 1800 seconds (for forwarding-options configurations); 60 seconds (for services configurations)



NOTE: In active flow monitoring, the cflowd records are exported after a time period that is a multiple of 60 seconds and greater than or equal to the configured active timeout value. For example, if the active timeout value is 90 seconds, the cflowd records are exported at 120-second intervals. If the active timeout value is 150 seconds, the cflowd records are exported at 180-second intervals, and so forth.


Usage Guidelines See “Configuring Time Periods when Flow Monitoring is Active and Inactive” on page 811 or “Configuring the Version 9 Template Properties” on page 817.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

flow-export-destination

Syntax	flow-export-destination { (cflowd-collector collector-pic); }
Hierarchy Level	[edit forwarding-options monitoring <i>group-name</i> family inet output]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure flow collection.
Options	cflowd-collector—cflowd collector. collector-pic—Collector PIC.
Usage Guidelines	See “Exporting Flows” on page 811.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

flow-inactive-timeout

Syntax	flow-inactive-timeout <i>seconds</i> ;
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output], [edit forwarding-options monitoring <i>name</i> output], [edit forwarding-options sampling output], [edit services flow-monitoring version9]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Interval of inactivity that marks a flow inactive.
<hr/>  NOTE: The router must include an Adaptive Services, MultiServices, or Monitoring Services PIC for this statement to take effect.	
Options	<i>seconds</i> —Duration of the timeout period. Range: 60 through 1800 seconds (for forwarding-options configurations); 10 through 600 seconds (for services configurations) Default: 1800 seconds (for forwarding-options configurations); 60 seconds (for services configurations)
Usage Guidelines	See “Configuring Time Periods when Flow Monitoring is Active and Inactive” on page 811 or “Configuring the Version 9 Template Properties” on page 817.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

flow-monitoring

Syntax

```

flow-monitoring {
  version9 {
    template template-name {
      flow-active-timeout seconds;
      flow-inactive-timeout seconds;
      ipv4-template;
      ipv6-template;
      mpls-template {
        label-position [ positions ];
      }
      mpls-ipv4-template {
        label-position [ positions ];
      }
      option-refresh-rate packets packets seconds seconds;
      template-refresh-rate packets packets seconds seconds;
    }
  }
}

```

Hierarchy Level [edit services]

Release Information Statement introduced in JUNOS Release 8.3.

Description Specify the active monitoring properties for flow aggregation version 9.

The statements are explained separately.

Usage Guidelines See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

forwarding-options

Syntax	forwarding-options { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Configure traffic forwarding.</p> <p>The statements that apply to services interfaces are explained separately. For other statements, see the <i>JUNOS Policy Framework Configuration Guide</i>.</p>
Usage Guidelines	See “Flow Monitoring and Discard Accounting Configuration Guidelines” on page 797.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

input

See the following sections:

- input (Port Mirroring) on page 865
- input (Sampling) on page 865

input (Port Mirroring)

Syntax input {
 rate *number*;
 run-length *number*;
 }

Hierarchy Level [edit forwarding-options port-mirroring]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure port mirroring on a logical interface.

The statements are explained separately.

Usage Guidelines See “Configuring Port Mirroring” on page 825.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

input (Sampling)

Syntax input {
 family (inet | inet6 | mpls) {
 max-packets-per-second *number*;
 rate *number*;
 run-length *number*;
 }
 }

Hierarchy Level [edit forwarding-options sampling]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure traffic sampling on a logical interface.

The statements are explained separately.

Usage Guidelines See “Configuring Traffic Sampling” on page 801.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

input-interface-index

Syntax	input-interface-index <i>number</i> ;
Hierarchy Level	[edit forwarding-options monitoring <i>name</i> output interface <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify a value for the input interface index that overrides the default supplied by SNMP.
Options	<i>number</i> —Input interface index value.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interface

See the following sections:

- interface (Accounting or Sampling) on page 867
- interface (Monitoring) on page 868
- interface (Port Mirroring) on page 868

interface (Accounting or Sampling)

Syntax interface *interface-name* {
 engine-id *number*;
 engine-type *number*;
 source-address *address*;
 }

Hierarchy Level [edit forwarding-options accounting *name* output],
 [edit forwarding-options sampling output]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the output interface for monitored traffic.

Options *interface-name*—Name of the interface.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Discard Accounting” on page 837 or “Configuring Traffic Sampling” on page 801.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

interface (Monitoring)

Syntax interface *interface-name* {
 engine-id *number*;
 engine-type *number*;
 input-interface-index *number*;
 output-interface-index *number*;
 source-address *address*;
 }

Hierarchy Level [edit forwarding-options monitoring *name* family inet output]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the output interface for monitored traffic.

Options *interface-name*—Name of the interface.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Flow Monitoring” on page 809.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

interface (Port Mirroring)

Syntax interface *interface-name* {
 next-hop *address*;
 }

Hierarchy Level [edit forwarding-options port-mirroring family (inet | inet6) output]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the output interface for sending copies of packets elsewhere to be analyzed.

Options *interface-name*—Name of the interface.

The remaining statements are explained separately.

Usage Guidelines See “Configuring Port Mirroring” on page 825.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

interfaces

Syntax	interfaces { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure interfaces on the router.
Default	The management and internal Ethernet interfaces are automatically configured. You must configure all other interfaces.
Usage Guidelines	See the <i>JUNOS Network Interfaces Configuration Guide</i> for general information.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ipv4-template

Syntax	ipv4-template;
Hierarchy Level	[edit services flow-monitoring version9 template <i>template-name</i>]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify that the flow aggregation version 9 template is used only for IPv4 records.
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ipv6-template

Syntax	ipv6-template;
Hierarchy Level	[edit services flow-monitoring version9 template <i>template-name</i>]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Specify that the flow aggregation version 9 template is used only for IPv6 records.
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

label-position

Syntax	label-position [<i>positions</i>];
Hierarchy Level	[edit services flow-monitoring version9 template <i>template-name</i> mpls-ipv4-template], [edit services flow-monitoring version9 template <i>template-name</i> mpls-template]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify positions for up to three labels in the template.
Default	[1 2 3]
Options	<i>positions</i> —Numbered positions for the labels.
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

local-dump

Syntax	(local-dump no-local-dump);
Hierarchy Level	[edit forwarding-options sampling output cflowd <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable collection of cflowd records in a log file.
Options	no-local-dump—Do not dump cflowd records to a log file before exporting. local-dump—Dump cflowd records to a log file before exporting.
Usage Guidelines	See “Enabling Flow Aggregation” on page 813.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

max-packets-per-second

Syntax max-packets-per-second *number*;

Hierarchy Level [edit forwarding-options sampling input family (inet | mpls)]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the traffic threshold that must be exceeded before packets are dropped. A value of 0 instructs the Packet Forwarding Engine not to sample any traffic.



NOTE: When you configure active monitoring and specify a Monitoring Services, Adaptive Services, or MultiServices PIC in the **output** statement, the **max-packets-per-second** value is ignored.

Options *number*—Maximum number of packets per second.

Range: 0 through 65,535

Default: 1000

Usage Guidelines See “Configuring Traffic Sampling” on page 801.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

monitoring

Syntax

```
monitoring name {
  family inet {
    output {
      cflowd hostname port-number;
      export-format cflowd-version-5;
      flow-active-timeout seconds;
      flow-export-destination {
        (cflowd-collector | collector-pic);
      }
      flow-inactive-timeout seconds;
      interface interface-name {
        number;
        engine-type number;
        input-interface-index number;
        output-interface-index number;
        source-address address;
      }
    }
  }
}
```

Hierarchy Level [edit forwarding-options]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the flow monitoring instance name and properties.

The statements are explained separately.

Usage Guidelines See “Configuring Flow Monitoring” on page 809.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

mpls-ipv4-template

Syntax	mpls-ipv4-template { label-position [<i>positions</i>]; }
Hierarchy Level	[edit services flow-monitoring version9 template <i>template-name</i>]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify the flow aggregation version 9 properties for templates that combine IPv4 and MPLS records. The remaining statement is explained separately.
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

mpls-template

Syntax	mpls-template { label-position [<i>positions</i>]; }
Hierarchy Level	[edit services flow-monitoring version9 template <i>template-name</i>]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify the flow aggregation version 9 properties for templates used only for MPLS records. The remaining statement is explained separately.
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

multiservice-options

Syntax	multiservice-options { (core-dump no-core-dump); (syslog no-syslog); }
Hierarchy Level	[edit interfaces <i>mo-fpc/pic/port</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For flow-monitoring interfaces only, configure multiservice-specific interface properties. The statements are explained separately.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

next-hop

Syntax	next-hop <i>address</i> ;
Hierarchy Level	[edit forwarding-options port-mirroring family (inet inet6) output interface <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the next-hop address for sending copies of packets to an analyzer.
Options	<i>address</i> —IP address of the next-hop router.
Usage Guidelines	See “Configuring Port Mirroring” on page 825.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

next-hop-group

Syntax `next-hop-group group-name {
 interface interface-name {
 next-hop address;
 }
 }`

Hierarchy Level [edit forwarding-options]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the next-hop address for sending copies of packets to an analyzer.

Options *addresses*—IP address of the next-hop router. Each next-hop group supports up to 16 next-hop addresses. Up to 30 next-hop groups are supported. Each next-hop group must have at least two next-hop addresses.

group-names—Name of next-hop group. Up to 30 next-hop groups are supported for the router. Each next-hop group must have at least two next-hop addresses.

interface-name—Name of interface used to reach the next-hop destination.

Usage Guidelines See “Configuring Port Mirroring” on page 825.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

no-core-dump

See core-dump

no-filter-check

Syntax	no-filter-check;
Hierarchy Level	[edit forwarding-options port-mirroring family (inet inet6) output]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Disable filter checking on the port-mirroring interface.</p> <p>This statement is required when you send port-mirrored traffic to a Tunnel PIC that has a filter applied to it.</p>
Usage Guidelines	See “Configuring Port Mirroring” on page 825.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-local-dump

See local-dump

no-stamp

See stamp

no-syslog

See syslog

no-world-readable

See world-readable

option-refresh-rate

Syntax	option-refresh-rate packets <i>packets</i> seconds <i>seconds</i> ;
Hierarchy Level	[edit services flow-monitoring version9], [edit services flow-monitoring version9 template <i>template-name</i>]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify the refresh rate, in either packets or seconds.
Options	<p><i>packets</i>—Refresh rate, in number of packets. Range: 1 through 480,000 Default: 4800</p> <p><i>seconds</i>—Refresh rate, in number of seconds. Range: 10 through 600 Default: 60</p>
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

output

See the following sections:

- output (Accounting) on page 878
- output (Monitoring) on page 879
- output (Port Mirroring) on page 879
- output (Sampling) on page 880

output (Accounting)

Syntax

```
output {
  aggregate-export-interval seconds;
  cflowd hostname {
    aggregation {
      autonomous-system;
      destination-prefix;
      protocol-port;
      source-destination-prefix {
        caida-compliant;
      }
      source-prefix;
    }
    autonomous-system-type (origin | peer);
    (local-dump | no-local-dump);
    port port-number;
    source-address address;
    version format;
  }
  flow-active-timeout seconds;
  flow-inactive-timeout seconds;
  interface interface-name {
    engine-id number;
    engine-type number;
    source-address address;
  }
}
```

Hierarchy Level [edit forwarding-options accounting *name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure cflowd, output interfaces, and flow properties.

The statements are explained separately.

Usage Guidelines See “Configuring Discard Accounting” on page 837.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

output (Monitoring)

Syntax output {
 cflowd *hostname* port *port-number*;
 export-format *format*;
 flow-active-timeout *seconds*;
 flow-export-destination {
 (cflowd-collector | collector-pic);
 }
 flow-inactive-timeout *seconds*;
 interface *interface-name* {
 engine-id *number*;
 engine-type *number*;
 input-interface-index *number*;
 output-interface-index *number*;
 source-address *address*;
 }
 }

Hierarchy Level [edit forwarding-options monitoring *name* family inet]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure cflowd, output interfaces, and flow properties.

The statements are explained separately.

Usage Guidelines See “Configuring Flow Monitoring” on page 809.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

output (Port Mirroring)

Syntax output {
 interface *interface-name* {
 next-hop *address*;
 }
 no-filter-check;
 }

Hierarchy Level [edit forwarding-options port-mirroring family (inet | inet6)]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure output interfaces and flow properties.

The statements are explained separately.

Usage Guidelines See “Configuring Port Mirroring” on page 825.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

output (Sampling)

Syntax

```
output {
  aggregate-export-interval seconds;
  cflowd hostname {
    aggregation {
      autonomous-system;
      destination-prefix;
      protocol-port;
      source-destination-prefix {
        caida-compliant;
      }
      source-prefix;
    }
    autonomous-system-type (origin | peer);
    label-position {
      template template-name;
    }
    (local-dump | no-local-dump);
    port port-number;
    source-address address;
    version format;
  }
  file {
    filename filename;
    files number;
    size bytes;
    (stamp | no-stamp);
    (world-readable | no-world-readable);
  }
  flow-active-timeout seconds;
  flow-inactive-timeout seconds;
  interface interface-name {
    engine-id number;
    engine-type number;
    source-address address;
  }
}
```

Hierarchy Level [edit forwarding-options sampling]

Release Information Statement introduced before JUNOS Release 7.4.


Description Configure cflowd, output files and interfaces, and flow properties.

The statements are explained separately.

Usage Guidelines See “Configuring Traffic Sampling” on page 801.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

output-interface-index

Syntax	output-interface-index <i>number</i> ;
Hierarchy Level	[edit forwarding-options monitoring <i>name</i> output interface <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify a value for the output interface index that overrides the default supplied by SNMP.
<hr/>	
	NOTE: On J-series platforms, cflowd sampling in the input direction of an interface reports the output interface index as 0.
<hr/>	
Options	<i>number</i> —Output interface index value.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

passive-monitor-mode

Syntax	passive-monitor-mode;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For Asynchronous Transfer Mode (ATM), SONET/SDH, Fast Ethernet, and Gigabit Ethernet interfaces only, monitor packet flows from another router. If you include this statement in the configuration, the SONET/SDH interface does not send keepalives or alarms, and does not participate actively on the network.
Usage Guidelines	See “Enabling Passive Flow Monitoring” on page 838.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	multiservice-options

pop-all-labels

Syntax	pop-all-labels { required-depth <i>number</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> atm-options mpls], [edit interfaces <i>interface-name</i> fastether-options mpls], [edit interfaces <i>interface-name</i> gigether-options mpls], [edit interfaces <i>interface-name</i> sonet-options mpls]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For passive monitoring on ATM, SONET/SDH, Fast Ethernet, and Gigabit Ethernet interfaces only, removes up to two MPLS labels from incoming IP packets. This statement has no effect on IP packets with more than two MPLS labels. Packets with MPLS labels cannot be processed by the monitoring PIC; if packets with MPLS labels are forwarded to the monitoring PIC, they are discarded. The remaining statement is explained separately.
Default	If you omit this statement, the MPLS labels are not removed, and the packet is not processed by the monitoring PIC.
Usage Guidelines	See “Passive Flow Monitoring for MPLS Encapsulated Packets” on page 839.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

port

Syntax	port <i>port-number</i> ;
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output cflowd <i>hostname</i>], [edit forwarding-options monitoring <i>name</i> family inet output cflowd <i>hostname</i>], [edit forwarding-options sampling output cflowd <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the User Datagram Protocol (UDP) port number on the cflowd host system.
Options	<i>port-number</i> —Any valid UDP port number on the host system.
Usage Guidelines	See “Enabling Flow Aggregation” on page 813.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

port-mirroring

Syntax

```

port-mirroring {
  input {
    rate rate;
    run-length number;
  }
  family inet {
    output {
      interface interface-name {
        next-hop address;
      }
      no-filter-check;
    }
  }
  traceoptions {
    file filename <files number <size bytes> <world-readable | no-world-readable>;
  }
}

```

Hierarchy Level [edit forwarding-options]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the input, output, and traceoptions properties for sending copies of packets to an analyzer.

The statements are explained separately.

Usage Guidelines See “Configuring Port Mirroring” on page 825.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

rate

Syntax	<code>rate number;</code>
Hierarchy Level	[edit forwarding-options port-mirroring input], [edit forwarding-options sampling input family (inet mpls)]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the ratio of the number of packets to be sampled. For example, if you specify a rate of 10, every tenth packet (1 packet out of 10) is sampled.
Options	<i>number</i> —Denominator of the ratio. Range: 1 through 65,535
Usage Guidelines	See “Configuring Port Mirroring” on page 825 or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

receive-options-packets

Syntax	<code>receive-options-packets;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	When you enable passive monitoring, this statement is required for conformity with cflowd records structure.
Usage Guidelines	See “Enabling Passive Flow Monitoring” on page 838.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

receive-ttl-exceeded

Syntax	receive-ttl-exceeded;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	When you enable passive monitoring, this statement is required for conformity with cflowd records structure.
Usage Guidelines	See “Enabling Passive Flow Monitoring” on page 838.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

required-depth

Syntax	required-depth <i>number</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> atm-options mpls pop-all-labels], [edit interfaces <i>interface-name</i> fastether-options mpls pop-all-labels], [edit interfaces <i>interface-name</i> gigeether-options mpls pop-all-labels], [edit interfaces <i>interface-name</i> sonet-options mpls pop-all-labels]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For passive monitoring on ATM, SONET/SDH, Fast Ethernet, and Gigabit Ethernet interfaces only, specify the number of MPLS labels an incoming packet must have for the pop-all-labels statement to take effect. If you include the required-depth 1 statement, the pop-all-labels statement takes effect for incoming packets with one label only. If you include the required-depth 2 statement, the pop-all-labels statement takes effect for incoming packets with two labels only.
Options	<i>number</i> —Number of MPLS labels on incoming IP packets. Range: 1 through 2 labels. Default: If you omit this statement, the pop-all-labels statement takes effect for incoming packets with one or two labels. The default is equivalent to including the required-depth [1 2] statement.
Usage Guidelines	See “Passive Flow Monitoring for MPLS Encapsulated Packets” on page 839.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

run-length

Syntax	<code>run-length <i>number</i>;</code>
Hierarchy Level	[edit forwarding-options port-mirroring input], [edit forwarding-options sampling input family (inet mpls)]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the number of samples following the initial trigger event. This allows you to sample packets following those already being sampled.
Options	<i>number</i> —Number of samples. Range: 0 through 20 Default: 0
Usage Guidelines	See “Configuring Port Mirroring” on page 825 or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

sampling

See the following sections:

- [sampling \(Forwarding Options\) on page 888](#)
- [sampling \(Interfaces\) on page 889](#)

sampling (Forwarding Options)

```

Syntax  sampling {
            disable;
            input {
                family (inet | inet6 | mpls) {
                    max-packets-per-second number;
                    rate number;
                    run-length number;
                }
            }
            output {
                aggregate-export-interval seconds;
                cflowd hostname {
                    aggregation {
                        autonomous-system;
                        destination-prefix;
                        protocol-port;
                        source-destination-prefix {
                            caida-compliant;
                        }
                        source-prefix;
                    }
                    autonomous-system-type (origin | peer);
                    label-position {
                        template template-name;
                    }
                    (local-dump | no-local-dump);
                    port port-number;
                    source-address address;
                    version format;
                }
                file {
                    disable;
                    filename filename;
                    files number;
                    size bytes;
                    (stamp | no-stamp);
                    (world-readable | no-world-readable);
                }
                flow-active-timeout seconds;
                flow-inactive-timeout seconds;
                interface interface-name {
                    engine-id number;
                    engine-type number;
                    source-address address;
                }
            }
            traceoptions {
                file filename <files number <size bytes> <world-readable | no-world-readable>;
            }
        }

```

Hierarchy Level [edit forwarding-options]

Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure traffic sampling. The statements are explained separately.
Usage Guidelines	See “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

sampling (Interfaces)

Syntax	sampling <i>direction</i> ;
Hierarchy Level	[edit interfaces <i>mo-fpc/pic/port</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the direction of traffic to be sampled.
Options	input—Configure at least one expected ingress point. output—Configure at least one expected egress point. input output—On a single interface, configure at least one expected ingress point and one expect egress point.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	services { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure router services. The underlying statements are explained separately.
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

size

Syntax	<code>size bytes;</code>
Hierarchy Level	[edit forwarding-options port-mirroring traceoptions file], [edit forwarding-options sampling output file], [edit forwarding-options sampling traceoptions file]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Specify the maximum size of each file containing sample or log data. The file size is limited by the number of files to be created and the available hard disk space.</p> <p>When a traffic sampling file named sampling-file reaches the maximum size, it is renamed sampling-file.0. When the sampling-file again reaches its maximum size, sampling-file.0 is renamed sampling-file.1 and sampling-file is renamed sampling-file.0. This renaming scheme continues until the maximum number of traffic sampling files is reached. Then the oldest traffic sampling file is overwritten.</p>
Options	<p>bytes—Maximum size of each traffic sampling file or trace log file, in kilobytes (KB), megabytes (MB), or gigabytes (GB).</p> <p>Syntax: <code>xk</code> to specify KB, <code>xm</code> to specify MB, or <code>xg</code> to specify GB</p> <p>Range: 10 KB through the maximum file size supported on your router</p> <p>Default: 1 MB for sampling data; 128 KB for log information</p>
Usage Guidelines	See “Configuring Port Mirroring” on page 825 or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

source-address

Syntax	source-address <i>address</i> ;
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output interface <i>interface-name</i>], [edit forwarding-options monitoring <i>name</i> family inet output interface <i>interface-name</i>], [edit forwarding-options sampling output cflowd <i>hostname</i>], [edit forwarding-options sampling output interface <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the source address for monitored packets.
Options	<i>address</i> —Interface source address.
Usage Guidelines	See “Configuring Discard Accounting” on page 837, “Configuring Flow Monitoring” on page 809, or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

stamp

Syntax	(stamp no-stamp);
Hierarchy Level	[edit forwarding-options sampling output file]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Include a timestamp with each line in the output file.
Options	no-stamp—Do not include timestamps. This is the default. stamp—Include a timestamp with each line of packet sampling information. Default: No timestamp is included.
Usage Guidelines	See “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

syslog

Syntax	(syslog no-syslog);
Hierarchy Level	[edit interfaces <i>mo-fpc/pic/port</i> multiservice-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>System logging is enabled by default. The system log information of the Monitoring Services PIC is passed to the kernel for logging in the <code>/var/log</code> directory.</p> <ul style="list-style-type: none">■ <code>syslog</code>—Enable PIC system logging.■ <code>no-syslog</code>—Disable PIC system logging.
Usage Guidelines	See “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

template

See the following sections:

- `template` (Forwarding Options) on page 893
- `template` (Services) on page 894

template (Forwarding Options)

Syntax `template template-name;`

Hierarchy Level [edit forwarding-options sampling output cflowd version9]

Release Information Statement introduced in JUNOS Release 8.3.

Description Specify flow aggregation version 9 template to be used for output of sampling records.

Options *template-name*—Name of version 9 template.

Usage Guidelines See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

template (Services)

Syntax `template template-name {`
 `flow-active-timeout seconds;`
 `flow-inactive-timeout seconds;`
 `ipv4-template;`
 `ipv6-template;`
 `mpls-template {`
 `label-position [positions];`
 `}`
 `mpls-ipv4-template {`
 `label-position [positions];`
 `}`
 `option-refresh-rate packets packets seconds seconds;`
 `template-refresh-rate packets packets seconds seconds;`
 `}`

Hierarchy Level [edit services flow-monitoring version9]

Release Information Statement introduced in JUNOS Release 8.3.

Description Specify the flow aggregation version 9 template properties. The remaining statements are explained separately.

Options *template-name*—Name of version 9 template.

Usage Guidelines See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

template-refresh-rate

Syntax	template-refresh-rate packets <i>packets</i> seconds <i>seconds</i> ;
Hierarchy Level	[edit services flow-monitoring version9 template <i>template-name</i>]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify the refresh rate, in either packets or seconds.
Options	<p><i>packets</i>—Refresh rate, in number of packets. Range: 1 through 480,000 Default: 4800</p> <p><i>seconds</i>—Refresh rate, in number of seconds. Range: 10 through 600 Default: 60</p>
Usage Guidelines	See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

traceoptions

Syntax	<pre>traceoptions { file <i>filename</i> <files <i>number</i> <size <i>bytes</i>> <world-readable no-world-readable>; }</pre>
Hierarchy Level	[edit forwarding-options port-mirroring], [edit forwarding-options sampling]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure traffic sampling tracing operations. The statements are explained separately.
Usage Guidelines	See “Tracing Traffic Sampling Operations” on page 805.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

unit

Syntax `unit logical-unit-number {
 family inet {
 address address {
 destination destination-address;
 }
 filter {
 group filter-group-number;
 input filter-name;
 output filter-name;
 }
 sampling direction;
 }
 }`

Hierarchy Level [edit interfaces *interface-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.

Options *logical-unit-number*—Number of the logical unit.
 Range: 0 through 16,384

The remaining statements are explained separately.

Usage Guidelines For general information, see the *JUNOS Network Interfaces Configuration Guide*.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

version

Syntax	<code>version <i>format</i>;</code>
Hierarchy Level	[edit forwarding-options accounting <i>name</i> output cflowd <i>hostname</i>], [edit forwarding-options sampling output cflowd <i>hostname</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the version format of the aggregated flows exported to a cflowd server.
Options	<i>format</i> —Format of the flows. Values: 5 or 8 Default: 5
Usage Guidelines	See “Enabling Flow Aggregation” on page 813.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	export-format

version9

See the following sections:

- version9 (Forwarding Options) on page 898
- version9 (Services) on page 899

version9 (Forwarding Options)

Syntax version9 {
 template *template-name*;
 }

Hierarchy Level [edit forwarding-options sampling output cflowd]

Release Information Statement introduced in JUNOS Release 8.3.

Description Specify flow aggregation version 9 properties to apply to output sampling records. The remaining statements are explained separately.

Usage Guidelines See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

version9 (Services)

Syntax

```

version9 {
    template template-name {
        flow-active-timeout seconds;
        flow-inactive-timeout seconds;
        ipv4-template;
        ipv6-template;
        mpls-template {
            label-position [ positions ];
        }
        mpls-ipv4-template {
            label-position [ positions ];
        }
        option-refresh-rate packets packets seconds seconds;
        template-refresh-rate packets packets seconds seconds;
    }
}

```

Hierarchy Level [edit services flow-monitoring]

Release Information Statement introduced in JUNOS Release 8.3.

Description Specify flow aggregation version 9 template properties. The remaining statements are explained separately.

Usage Guidelines See “Configuring Flow Aggregation to Use Version 9 Flow Templates” on page 816.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

world-readable

Syntax	(world-readable no-world-readable);
Hierarchy Level	[edit forwarding-options port-mirroring traceoptions file], [edit forwarding-options sampling output file], [edit forwarding-options sampling traceoptions file]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable unrestricted file access.
Options	no-world-readable—Restrict file access to owner. This is the default. world-readable—Enable unrestricted file access. Default: no-world-readable
Usage Guidelines	See “Configuring Port Mirroring” on page 825 or “Configuring Traffic Sampling” on page 801.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 48

Flow Collection Configuration Guidelines

You can process and export multiple cflowd records with a flow collector interface. You create a flow collector interface on a Monitoring Services II or MultiServices 400 PIC. The flow collector interface combines multiple cflowd records into a compressed ASCII data file and exports the file to an FTP server. To convert a services PIC into a flow collector interface, include the **flow-collector** statement at the [edit chassis fpc fpc-slot pic pic-slot monitoring-services application] hierarchy level.

You can use the services PIC for either flow collection or monitoring, but not for both types of service simultaneously. When converting the PIC between service types, you must configure the **flow-collector** statement, take the PIC offline, and then bring the PIC back online. Restarting the router does not enable the new service type.

A flow collector interface, designated by the *cp-fpc/pic/port* interface name, requires three logical interfaces for correct operation. Units 0 and 1 are used to send the compressed ASCII data files to an FTP server, while Unit 2 is used to receive cflowd records from a monitoring services interface.



NOTE: Unlike conventional interfaces, the **address** statement at the [edit interfaces *cp-fpc/pic/port* unit *unit-number* family inet] hierarchy level corresponds to the IP address of the Routing Engine. Likewise, the **destination** statement at the [edit interfaces *cp-fpc/pic/port* unit *unit-number* family inet address *ip-address*] hierarchy level corresponds to the IP address of the flow collector interface. As a result, you must configure the **destination** statement for Unit 0 and 1 with *local* addresses that can reach the FTP server. Similarly, configure the **destination** statement for Unit 2 with a *local* IP address so it can reach the monitoring services interface that sends cflowd records.

To activate flow collector services after the services PIC is converted into a flow collector, include the **flow-collector** statement at the [edit services] hierarchy level. After you activate the flow collector, you need to configure the following components:

- Destination of the FTP server
- File specifications
- Input interface-to-flow collector interface mappings
- Transfer log settings

To configure flow collection, include the **flow-collector** statement at the [edit services] hierarchy level:

```

flow-collector {
  analyzer-address address;
  analyzer-id name;
  destinations {
    ftp:url {
      password "password";
    }
    file-specification {
      variant variant-number {
        data-format format;
        name-format format;
        transfer {
          record-level number;
          timeout seconds;
        }
      }
    }
  }
  interface-map {
    collector interface-name;
    file-specification variant-number;
    interface-name {
      collector interface-name;
      file-specification variant-number;
    }
  }
  retry number;
  retry-delay seconds;
  transfer-log-archive {
    archive-sites {
      ftp:url {
        password "password";
        username username;
      }
    }
    filename-prefix prefix;
    maximum-age minutes;
  }
}

```

This chapter contains the following sections:

- Configuring Flow Collection on page 903
- Sending cflowd Records to Flow Collector Interfaces on page 906
- Configuring Flow Collection Mode and Interfaces on Services PICs on page 906
- Example: Configuring Flow Collection on page 907

Configuring Flow Collection

This section describes the following tasks for configuring flow collection:

- Configuring Destination FTP Servers for Flow Records on page 903
- Configuring a Packet Analyzer on page 904
- Configuring File Formats on page 904
- Configuring Interface Mappings on page 905
- Configuring Transfer Logs on page 905
- Configuring Retry Attempts on page 906

Configuring Destination FTP Servers for Flow Records

Flow collection destinations are where the compressed ASCII data files are sent after the cflowd records are collected and processed. To specify the destination FTP server, include the **destinations** statement at the [edit services flow-collector] hierarchy level. You can specify up to two FTP server destinations and include the password for each configured server. If two FTP servers are configured, the first server in the configuration is the primary server and the second is a backup server.

To configure a destination for flow collection files, include the **destinations** statement at the [edit services flow-collector] hierarchy level:

```
[edit services flow-collector]
destinations {
  ftp:url {
    password "password";
  }
}
```

To specify the destination FTP server, include the **ftp:url** statement. The value *url* is the FTP server address for the primary flow collection destination and can include macros.

When you include macros in the **ftp:url** statement, a directory can be created only for a single level. For example, the path **ftp://10.2.2.2/%m/%Y** expands to **ftp://10.2.2.2/01/2005**, and the software attempts to create the directory **01/2005** on the destination FTP server. If the **01/** directory already exists on the destination FTP server, the software creates the **/2005/** directory one level down. If the **01/** directory does not exist on the destination FTP server, the software cannot create the **/2005/** directory, and the FTP server destination will fail. For more information about macros, see **ftp**.

To specify the FTP server password, include the **password "password"** statement. The password must be enclosed in quotation marks. You can specify up to two destination FTP servers. The first destination specified is considered the primary destination.

Configuring a Packet Analyzer

You can specify values for the IP address and identifier of a packet analyzer to which the flow collector interface sends traffic for analysis. The values you specify here override any default values configured elsewhere.

To configure an IP address and identifier for the packet analyzer, include the `analyzer-address` and `analyzer-id` statements at the `[edit services flow-collector]` hierarchy level:

```
[edit services flow-collector]
analyzer-address address;
analyzer-id name;
```

Configuring File Formats

You configure data file formats, name formats, and transfer characteristics for the flow collection files. File records are sent to the destination FTP server when the timer expires or when a preset number of records are received, whichever comes first.

To configure the flow collection file format, include the `file-specification` statement at the `[edit services flow-collector]` hierarchy level:

```
[edit services flow-collector]
file-specification {
  variant variant-number {
    data-format format;
    name-format format;
    transfer {
      record-level number;
      timeout seconds;
    }
  }
}
```

To set the data file format, include the `data-format` statement. To set the file name format, include the `name-format` statement. To set the export timer and file size thresholds, include the `transfer` statement and specify values for the `timeout` and `record-level` options.

For example, you can specify the name format as follows:

```
[edit services flow-collector file-specification variant variant-number]
name-format "cFlowd-py69Ni69-0-%D_%T-%I_%N.bcp.bi.gz";
```

In this example, `cFlowd-py69Ni69-0` is the static portion used verbatim, `%D` is the date in `YYYYMMDD` format, `%T` is the time in `HHMMSS` format, `%I` is the value of `ifAlias`, `%N` is the generation number, and `bcp.bi.gz` is a user-configured string. A number of macros are supported for expressing the date and time information in different ways; for a complete list, see the summary section for `name-format`.

Configuring Interface Mappings

You can match an input interface with a flow collector interface and apply the preset file specifications to the input interface.

To configure an interface mapping, include the **interface-map** statement at the [edit services flow-collector] hierarchy level:

```
[edit services flow-collector]
interface-map {
  collector interface-name;
  file-specification variant-number;
  interface-name {
    collector interface-name;
    file-specification variant-number;
  }
}
```

To configure the default flow collector and file specifications for all input interfaces, include the **file-specification** and **collector** statements at the [edit services flow-collector interface-map] hierarchy level. To override the default settings and apply flow collector and file specifications to a specific input interface, include the **file-specification** and **collector** statements at the [edit services flow-collector interface-map *interface-name*] hierarchy level.

Configuring Transfer Logs

You can configure the filename, export interval, maximum size, and destination FTP server for log files containing the transfer activity history for a flow collector interface.

To configure a transfer log, include the **transfer-log-archive** statement at the [edit services flow-collector] hierarchy level:

```
[edit services flow-collector]
transfer-log-archive {
  archive-sites {
    ftp:url {
      password "password";
      username username;
    }
  }
  filename-prefix prefix;
  maximum-age minutes;
}
```

To configure the destination for archiving files, include the **archive-sites** statement. Specify the filename as follows:

```
[edit services flow-collector transfer-log]
filename "cFlowd-py69Ni69-0-%D_%T";
```

where cFlowd-py69Ni69-0 is the static portion used verbatim, %D is the date in YYYYMMDD format, and %T is the time in HHMMSS format.

You can optionally include the following statements:

- `filename-prefix`—Sets a standard prefix for all the logged files.
- `maximum-age`—Specifies the duration a file remains on the server. The range is 1 through 360 minutes.

Configuring Retry Attempts

You can specify values for situations in which the flow collector interface needs more than one attempt to transfer log files to the FTP server:

- Maximum number of retry attempts
- Amount of time the flow collector interface waits between successive retries

To configure retry settings, include the `retry` and `retry-delay` statements at the `[edit services flow-collector]` hierarchy level:

```
retry number;
retry-delay seconds;
```

The `retry` value can be from 0 through 10. The `retry-delay` value can be from 0 through 60 seconds.

Sending cflowd Records to Flow Collector Interfaces

To specify a flow collector interface as the destination for cflowd records coming from a services PIC, include the `collector-pic` statement at the `[edit forwarding-options monitoring group-name family inet output flow-export-destination]` hierarchy level:

```
[edit forwarding-options monitoring group-name family inet output
 flow-export-destination]
collector-pic;
```

You can select either the flow collector interface or a cflowd server as the destination for cflowd records, but not both at the same time.

Configuring Flow Collection Mode and Interfaces on Services PICs

You can select the services PIC to run in either flow collection mode or monitoring mode, but not both.

To set the services PIC to run in flow collection mode, include the `flow-collector` statement at the `[edit chassis fpc slot-number pic pic-number monitoring-services application]` hierarchy level:

```
[edit chassis fpc slot-number pic pic-number monitoring-services application]
flow-collector;
```

For further information on configuring chassis properties, see the *JUNOS System Basics Configuration Guide*.


To specify flow collection interfaces, you configure the `cp` interface at the `[edit interfaces]` hierarchy level:

```
[edit interfaces]
cp-fpc/pic/port {
  ...
}
```

Example: Configuring Flow Collection

Figure 10 on page 907 shows the path traveled by monitored traffic as it passes through the router. Packets arrive at input interfaces `so-0/1/0`, `so-3/0/0`, and `so-3/1/0`. The raw packets are directed into a filter-based forwarding routing instance and processed into cflowd records by the monitoring services interfaces `mo-7/1/0`, `mo-7/2/0`, and `mo-7/3/0`. The cflowd records are compressed into files at the flow collector interfaces `cp-6/0/0` and `cp-7/0/0` and sent to the FTP server for analysis. Finally, a mandatory class-of-service (CoS) configuration is applied to export channels 0 and 1 on the flow collector interfaces to manage the outgoing processed files.

Figure 10: Flow Collector Interface Topology Diagram



```
[edit]
chassis {
  fpc 6 {
    pic 0 {
      monitoring-services {
        application flow-collector; # This converts a Monitoring Services II or
                                   # MultiServices 400 PIC into a flow collector interface.
      }
    }
  }
  fpc 7 {
    pic 0 {
      monitoring-services {
        application flow-collector; # This converts a Monitoring Services II or
```

```

# MultiServices 400 PIC into a flow collector interface.
    }
  }
}
interfaces {
  cp-6/0/0 {
    unit 0 { # Logical interface .0 on a flow collector interface is export
      family inet { # channel 0 and sends records to the FTP server.
        filter {
          output cp-ftp; # Apply the CoS filter here.
        }
        address 10.0.0.1/32 {
          destination 10.0.0.2;
        }
      }
    }
    unit 1 { # Logical interface .1 on a flow collector interface is export
      family inet { # channel 1 and sends records to the FTP server.
        filter {
          output cp-ftp; # Apply the CoS filter here.
        }
        address 10.1.1.1/32 {
          destination 10.1.1.2;
        }
      }
    }
    unit 2 { # Logical interface .2 on a flow collector interface is the flow
      family inet { # receive channel that communicates with the Routing Engine.
        address 10.2.2.1/32 { # Do not apply a CoS filter on logical interface .2.
          destination 10.2.2.2;
        }
      }
    }
  }
}
cp-7/0/0 {
  unit 0 { # Logical interface .0 on a flow collector interface is export
    family inet { # channel 0 and sends records to the FTP server.
      filter {
        output cp-ftp; # Apply the CoS filter here.
      }
      address 10.3.3.1/32 {
        destination 10.3.3.2;
      }
    }
  }
  unit 1 { # Logical interface .1 on a flow collector interface is export
    family inet { # channel 1 and sends records to the FTP server.
      filter {
        output cp-ftp; # Apply the CoS filter here.
      }
      address 10.4.4.1/32 {
        destination 10.4.4.2;
      }
    }
  }
}

```

```

    unit 2 {# Logical interface .2 on a flow collector interface is the flow
        family inet {# receive channel that communicates with the Routing Engine.
            address 10.5.5.1/32 {# Do not apply a CoS filter on logical interface .2.
                destination 10.5.5.2;
            }
        }
    }
}
fe-1/3/0 { # This is the exit interface leading to the first FTP server.
    unit 0 {
        family inet {
            address 192.168.56.90/30;
        }
    }
}
ge-1/0/0 { # This is the exit interface leading to the second FTP server.
    unit 0 {
        family inet {
            address 192.168.252.2/24;
        }
    }
}
mo-7/1/0 { # This is the first interface that creates cflowd records.
    unit 0 {
        family inet;
    }
}
mo-7/2/0 { # This is the second interface that creates cflowd records.
    unit 0 {
        family inet;
    }
}
mo-7/3/0 { # This is the third interface that creates cflowd records.
    unit 0 {
        family inet;
    }
}
so-0/1/0 { # This is the first input interface that receives traffic to be monitored.
    encapsulation ppp;
    unit 0 {
        passive-monitor-mode; # This allows the interface to be passively monitored.
        family inet {
            filter {
                input catch; # The filter-based forwarding filter is applied here.
            }
        }
    }
}
so-3/0/0 { # This is the second interface that receives traffic to be monitored.
    encapsulation ppp;
    unit 0 {
        passive-monitor-mode; # This allows the interface to be passively monitored.
        family inet {
            filter {
                input catch; # The filter-based forwarding filter is applied here.
            }
        }
    }
}

```

```

    }
  }
}
so-3/1/0 { # This is the third interface that receives traffic to be monitored.
  encapsulation ppp;
  unit 0 {
    passive-monitor-mode; # This allows the interface to be passively monitored.
    family inet {
      filter {
        input catch; # The filter-based forwarding filter is applied here.
      }
    }
  }
}
forwarding-options {
  monitoring group1 {# Always define your monitoring group here.
    family inet {
      output {
        export-format cflowd-version-5;
        flow-active-timeout 60;
        flow-inactive-timeout 15;
        flow-export-destination collector-pic; # Sends records to the flow collector.
        interface mo-7/1/0.0 {
          source-address 192.168.252.2;
        }
        interface mo-7/2/0.0 {
          source-address 192.168.252.2;
        }
        interface mo-7/3/0.0 {
          source-address 192.168.252.2;
        }
      }
    }
  }
}
firewall {
  family inet {
    filter cp-ftp { # This filter provides CoS for flow collector interface traffic.
      term t1 {
        then forwarding-class expedited-forwarding;
      }
    }
  }
  filter catch { # This firewall filter sends incoming traffic into the
    interface-specific;# filter-based forwarding routing instance.
    term def {
      then {
        count counter;
        routing-instance fbf_instance;
      }
    }
  }
}
routing-options {
  interface-routes {
    rib-group inet common;
  }
}

```

```

rib-groups {
  common {
    import-rib [inet.0 fbf_instance.inet.0];
  }
}
forwarding-table {
  export pplb;
}
}
policy-options {
  policy-statement pplb {
    then {
      load-balance per-packet;
    }
  }
}
routing-instances {
  fbf_instance { # This instance sends traffic to the monitoring services interface.
    instance-type forwarding;
    routing-options {
      static {
        route 0.0.0.0/0 next-hop mo-7/1/0.0;
      }
    }
  }
}
}
class-of-service { # A class-of-service configuration for the flow collector interface
  interfaces { # is required for flow collector services.
    cp-6/0/0 {
      scheduler-map cp-map;
    }
    cp-7/0/0 {
      scheduler-map cp-map;
    }
  }
}
scheduler-maps {
  cp-map {
    forwarding-class best-effort scheduler Q0;
    forwarding-class expedited-forwarding scheduler Q1;
    forwarding-class network-control scheduler Q3;
  }
}
schedulers {
  Q0 {
    transmit-rate remainder;
    buffer-size percent 90;
  }
  Q1 {
    transmit-rate percent 5;
    buffer-size percent 5;
    priority strict-high;
  }
  Q3 {
    transmit-rate percent 5;
    buffer-size percent 5;
  }
}

```

```

    }
  }
  services {
    flow-collector { # Define properties for flow collector interfaces here.
      analyzer-address 10.10.10.1; # This is the IP address of the analyzer.
      analyzer-id server1; # This helps to identify the analyzer.
      retry 3; # Maximum number of attempts by the PIC to send a file transfer log.
      retry-delay 30; # The time interval between attempts to send a file transfer log.
      destinations { # This defines the FTP servers that receive flow collector output.
        "ftp://user@192.168.56.89//tmp/collect1/" { # The primary FTP server.
          password "$9$IXJK8xN-w2oZdbZDHmF3001"; # SECRET-DATA
        }
        "ftp://user@192.168.252.1//tmp/collect2/" { # The secondary FTP server.
          password "$9$elbvL7-dsgaGVwGjkP3nOBI"; # SECRET-DATA
        }
      }
    }
    file-specification { # Define sets of flow collector characteristics here.
      def-spec {
        name-format "default-allInt-0-%D_%T-%I_%N.bcp.bi.gz";
        data-format flow-compressed; # The default compressed output format.
      } # When no overrides are specified, a collector uses default transfer values.
      f1 {
        name-format "cFlowd-py69Ni69-0-%D_%T-%I_%N.bcp.bi.gz";
        data-format flow-compressed; # The default compressed output format.
        transfer timeout 1800 record-level 1000000; # Here are configured values.
      }
    }
    interface-map { # Allows you to map interfaces to flow collector interfaces.
      file-specification def-spec; # Flows generated for default traffic are sent to the
      collector cp-7/0/0; # default flow collector interface "cp-7/0/0".
      so-0/1/0.0 { # Flows generated for the so-0/1/0 interface are sent
        collector cp-6/0/0; # to cp-6/0/0, and the file-specification used is
      } # "default."
      so-3/0/0.0 { # Flows generated for the so-3/0/0 interface are sent
        file-specification f1; # to cp-6/0/0, and the file-specification used is "f1."
        collector cp-6/0/0;
      }
      so-3/1/0.0; # Because no settings are defined, flows generated for this
    } # interface use interface cp-7/0/0 and the default file specification.
    transfer-log-archive { # Sends flow collector interface log files to an FTP server.
      filename-prefix so_3_0_0_log;
      maximum-age 15;
      archive-sites {
        "ftp://user@192.168.56.89//tmp/transfers/" {
          password "$9$IFaEyevMXNVsWLsgaU.m6/C";
        }
      }
    }
  }
}

```


Chapter 49

Summary of Flow Collection Configuration Statements

The following sections explain each of the flow collection configuration statements. The statements are organized alphabetically.

analyzer-address

Syntax	<code>analyzer-address <i>address</i>;</code>
Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure an IP address for the packet analyzer that overrides the default value.
Options	<i>address</i> —IP address for packet analyzer.
Usage Guidelines	See “Configuring a Packet Analyzer” on page 904.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

analyzer-id

Syntax	<code>analyzer-id <i>name</i>;</code>
Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure an identifier for the packet analyzer that overrides the default value.
Options	<i>name</i> —Identifier for packet analyzer.
Usage Guidelines	See “Configuring a Packet Analyzer” on page 904.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

archive-sites

Syntax archive-sites {
 ftp:url {
 password "password";
 username username;
 }
 }

Hierarchy Level [edit services flow-collector transfer-log-archive]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the destination for transfer logs.

Options The statements are explained separately.

Usage Guidelines See “Configuring Transfer Logs” on page 905.

Required Privilege Level interface—To view this statement in the configuration.

collector

Syntax collector *interface-name*;

Hierarchy Level [edit services flow-collector interface-map]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure the default flow collector interface for interface mapping.

Options collector *interface-name*—Default flow collector interface.

Usage Guidelines See “Configuring Interface Mappings” on page 905.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

data-format

Syntax	<code>data-format <i>format</i>;</code>
Hierarchy Level	[edit services flow-collector file-specification variant <i>variant-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the data format for a specific file format variant.
Options	<i>format</i> —Data format. Specify <code>flow-compressed</code> as the data format.
Usage Guidelines	See “Configuring File Formats” on page 904.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destinations

Syntax	<pre>destinations { ftp:url { password "<i>password</i>"; } }</pre>
Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the primary and secondary destination FTP servers.
Options	The statements are explained separately.
Usage Guidelines	See “Configuring Destination FTP Servers for Flow Records” on page 903.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

filename-prefix

Syntax	filename-prefix <i>prefix</i> ;
Hierarchy Level	[edit services flow-collector transfer-log-archive]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the filename prefix for log files.
Options	<i>prefix</i> —Filename identifier.
Usage Guidelines	See “Configuring Transfer Logs” on page 905.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

file-specification

See the following sections:

- file-specification (File Format) on page 917
- file-specification (Interface Mapping) on page 917

file-specification (File Format)

```
Syntax  file-specification {
        variant variant-number {
            data-format format;
            name-format format;
            transfer {
                record-level number;
                timeout seconds;
            }
        }
    }
```

Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the file format for the flow collection files.
Options	The statements are explained separately.
Usage Guidelines	See “Configuring File Formats” on page 904.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

file-specification (Interface Mapping)

```
Syntax  file-specification {
        variant variant-number;
    }
```

Hierarchy Level	[edit services flow-collector interface-map]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the default file specification for interface mapping.
Options	variant <i>variant-number</i> —Default file format variant.
Usage Guidelines	See “Configuring Interface Mappings” on page 905.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

flow-collector

Syntax

```

flow-collector {
  analyzer-address address;
  analyzer-id name;
  destinations {
    ftp:url {
      password "password";
    }
  }
  file-specification {
    variant variant-number {
      data-format format;
      name-format format;
      transfer {
        record-level number;
        timeout seconds;
      }
    }
  }
  interface-map {
    collector interface-name;
    file-specification variant-number;
    interface-name {
      collector interface-name;
      file-specification variant-number;
    }
  }
  retry number;
  retry-delay seconds;
  transfer-log-archive {
    archive-sites {
      ftp:url {
        password "password";
        username username;
      }
    }
    filename-prefix prefix;
    maximum-age minutes;
  }
}

```

Hierarchy Level [edit services]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the flow collection.

Options The statements are explained separately.

Usage Guidelines See “Service Set Configuration Guidelines” on page 443.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

ftp

See the following sections:

- ftp (Flow Collector Files) on page 921
- ftp (Transfer Log Files) on page 922

ftp (Flow Collector Files)

Syntax	<code>ftp:url;</code>
Hierarchy Level	[edit services flow-collector destination]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the primary and secondary destination FTP server addresses.
Options	<p><i>url</i>—FTP server address. The URL can include the following macros, typed in braces:</p> <ul style="list-style-type: none"> ■ <code>{%D}</code>—Date ■ <code>{%T}</code>—Time when the file is created ■ <code>{%I}</code>—Description string for the logical interface configured using the collector <i>interface-name</i> statement at the [edit services flow-collector interface-map] hierarchy ■ <code>{%N}</code>—Unique, sequential number for each new file created ■ <code>{am_pm}</code>—AM or PM ■ <code>{date}</code>—Current date using the <code>{year}</code> <code>{month}</code> <code>{day}</code> macros ■ <code>{day}</code>—From 01 through 31 ■ <code>{day_abbrev}</code>—Sun through Sat ■ <code>{day_full}</code>—Sunday through Saturday ■ <code>{generation number}</code>—Unique, sequential number for each new file created ■ <code>{hour_12}</code>—From 01 through 12 ■ <code>{hour_24}</code>—From 00 through 23 ■ <code>{ifalias}</code>—Description string for the logical interface configured using the collector statement at the [edit services flow-collector interface-map] hierarchy ■ <code>{minute}</code>—From 00 through 59 ■ <code>{month}</code>—From 01 through 12 ■ <code>{month_abbrev}</code>—Jan through Dec ■ <code>{month_full}</code>—January through December ■ <code>{num_zone}</code>—From -2359 to +2359; this macro is not supported ■ <code>{second}</code>—From 00 through 60 ■ <code>{time}</code>—Time the file is created, using the <code>{hour_24}</code> <code>{minute}</code> <code>{second}</code> macros ■ <code>{time_zone}</code>—Time zone code name of the locale; for example, <code>gmt</code> (this macro is not supported). ■ <code>{year}</code>—In the format YYYY; for example, 1970 ■ <code>{year_abbrev}</code>—From 00 through 99

Usage Guidelines See “Configuring Destination FTP Servers for Flow Records” on page 903.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

ftp (Transfer Log Files)

Syntax `ftp:url;`

Hierarchy Level [edit services flow-collector transfer-log-archive archive-sites]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the primary and secondary destination FTP server addresses.

Options *url*—FTP server address.

Usage Guidelines See “Configuring Transfer Logs” on page 905.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

interface-map

Syntax

```
interface-map {
  collector interface-name;
  file-specification variant-number;
  interface-name {
    collector interface-name;
    file-specification variant-number;
  }
}
```

Hierarchy Level [edit services flow-collector]

Release Information Statement introduced before JUNOS Release 7.4.

Description Match an input interface with a flow collector interface and apply the preset file specifications to the input interface.

Options The statements are explained separately.

Usage Guidelines See “Configuring Interface Mappings” on page 905.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

maximum-age

Syntax	maximum-age <i>minutes</i> ;
Hierarchy Level	[edit services flow-collector transfer-log-archive]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Maximum age of transfer log file.
Options	maximum-age <i>minutes</i> —Transfer log file age. Range: 1 through 360
Usage Guidelines	See “Configuring Transfer Logs” on page 905.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

name-format

Syntax	name-format " <i>format</i> ";
Hierarchy Level	[edit services flow-collector file-specification variant <i>variant-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the name format for a specific file format. The files may include supported macros. Use macros to organize files on the external machine to which they are exported from the collector PIC.
Options	<p><i>format</i>—Specify the filename format, within quotation marks. The name format can include the following macros, typed in braces:</p> <ul style="list-style-type: none"> ■ {<i>%D</i>}—Date ■ {<i>%T</i>}—Time when the file is created ■ {<i>%I</i>}—Description string for the logical interface configured using the collector statement at the [edit services flow-collector interface-map] hierarchy level ■ {<i>%N</i>}—Unique, sequential number for each new file created ■ {<i>am_pm</i>}—AM or PM ■ {<i>date</i>}—Current date using the {<i>year</i>} {<i>month</i>} {<i>day</i>} macros ■ {<i>day</i>}—From 01 through 31 ■ {<i>day_abbrev</i>}—Sun through Sat ■ {<i>day_full</i>}—Sunday through Saturday ■ {<i>generation number</i>}—Unique, sequential number for each new file created ■ {<i>hour_12</i>}—From 01 through 12 ■ {<i>hour_24</i>}—From 00 through 23 ■ {<i>ifalias</i>}—Description string for the logical interface configured using the collector statement at the [edit services flow-collector interface-map] hierarchy level ■ {<i>minute</i>}—From 00 through 59 ■ {<i>month</i>}—From 01 through 12 ■ {<i>month_abbrev</i>}—Jan through Dec ■ {<i>month_full</i>}—January through December ■ {<i>num_zone</i>}—From -2359 through +2359; this macro is not supported ■ {<i>second</i>}—From 00 through 60 ■ {<i>time</i>}—Time the file is created, using the {<i>hour_24</i>} {<i>minute</i>} {<i>second</i>} macros ■ {<i>time_zone</i>}—Time zone code name of the locale; for example, gmt (this macro is not supported). ■ {<i>year</i>}—In the format YYYY; for example, 1970

- {year_abbrev}—From 00 through 99

Usage Guidelines See “Configuring File Formats” on page 904.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

password

See the following sections:

- password (Flow Collector File Servers) on page 926
- password (Transfer Log File Servers) on page 926

password (Flow Collector File Servers)

Syntax	password "password";
Hierarchy Level	[edit services flow-collector destination ftp:url]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the primary and secondary destination FTP server password.
Options	<i>password</i> —FTP server password.
Usage Guidelines	See “Configuring Destination FTP Servers for Flow Records” on page 903.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

password (Transfer Log File Servers)

Syntax	password "password";
Hierarchy Level	[edit services flow-collector transfer-log-archive archive-sites]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the primary and secondary destination FTP server password.
Options	<i>password</i> —FTP server password.
Usage Guidelines	See “Configuring Transfer Logs” on page 905.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

retry

Syntax	<code>retry number;</code>
Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the maximum number of attempts the flow collector interface will make to transfer log files to the FTP server.
Options	<i>number</i> —Maximum number of transfer retry attempts. Range: 0 through 10
Usage Guidelines	See “Configuring Retry Attempts” on page 906.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

retry-delay

Syntax	<code>retry-delay seconds;</code>
Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the amount of time the flow collector interface waits between retry attempts.
Options	<i>seconds</i> —Amount of time between transfer retry attempts. Range: 0 through 60
Usage Guidelines	See “Configuring Retry Attempts” on page 906.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

transfer

Syntax	transfer { record-level <i>number</i> ; timeout <i>seconds</i> ; }
Hierarchy Level	[edit services flow-collector file-specification variant <i>variant-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify when to send the flow collection file. The file is sent when either of the two conditions is met.
Options	record-level <i>number</i> —Number of flow collection files collected. timeout <i>seconds</i> —Timeout duration.
Usage Guidelines	See “Configuring File Formats” on page 904.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

transfer-log-archive

Syntax	transfer-log-archive { archive-sites { ftp:url { password " <i>password</i> "; username <i>username</i> ; } } filename-prefix <i>prefix</i> ; maximum-age <i>minutes</i> ; }
Hierarchy Level	[edit services flow-collector]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the filename prefix, maximum age, and destination FTP server for log files containing the transfer activity history for a flow collector interface.
Options	The statements are explained separately.
Usage Guidelines	See “Configuring Transfer Logs” on page 905.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

username

Syntax	<code>username <i>user-name</i>;</code>
Hierarchy Level	[edit services flow-collector transfer-log-archive archive-sites]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the username for the transfer log server.
Options	<i>username</i> —FTP server username.
Usage Guidelines	See “Configuring Transfer Logs” on page 905.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

variant

Syntax	<pre>variant <i>variant-number</i> { data-format <i>format</i>; name-format <i>format</i>; transfer { record-level <i>number</i>; timeout <i>seconds</i>; } }</pre>
Hierarchy Level	[edit services flow-collector file-specification]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure a variant of the file format.
Options	The statements are explained separately.
Usage Guidelines	See “Configuring File Formats” on page 904.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Chapter 50

Dynamic Flow Capture Configuration Guidelines

Dynamic flow capture enables you to capture packet flows on the basis of dynamic filtering criteria. Specifically, you can use this feature to forward passively monitored packet flows that match a particular filter list to one or more destinations using an on-demand control protocol.

This chapter contains the following sections:

- Dynamic Flow Capture Architecture on page 931
- Configuring Dynamic Flow Capture on page 932
- Example: Configuring Dynamic Flow Capture on page 939

Dynamic Flow Capture Architecture

The architecture consists of one or more *control sources* that send requests to a Juniper Networks routing platform to monitor incoming data, and then forward any packets that match specific filter criteria to a set of one or more *content destinations*. The architectural components are defined as follows:


- Control source—A client that monitors electronic data or voice transfer over the network. The control source sends filter requests to the Juniper Networks routing platform using the Dynamic Task Control Protocol (DTCP), specified in draft-cavuto-dtcp-01.txt at <http://www.ietf.org/internet-drafts>. The control source is identified by a unique identifier and an optional list of IP addresses.
- Monitoring platform—A Juniper Networks T-series or M320 routing platform containing one or more Dynamic Flow Capture (DFC) PICs, which support dynamic flow capture processing. The monitoring platform processes the requests from the control sources, creates the filters, monitors incoming data flows, and sends the matched packets to the appropriate content destinations.
- Content destination—Recipient of the matched packets from the monitoring platform. Typically the matched packets are sent using an IP Security (IPsec) tunnel from the monitoring platform to another router connected to the content destination. The content destination and the control source can be physically located on the same host. For more information on IPsec tunnels, see “IPsec Services Configuration Guidelines” on page 209.



NOTE: The DFC PIC (either a Monitoring Services III PIC or MultiServices 400 PIC) forwards the entire packet content to the content destination, rather than to a content record as is done with cflowd or flow aggregation version 9 templates.

Figure 11 on page 932 shows a sample topology. The number of control sources and content destinations is arbitrary.

Figure 11: Dynamic Flow Capture Topology



g017075

Liberal Sequence Windowing

Each DTCP packet (add, delete, list, and refresh packets) contains a 64-bit sequence number to identify the order of the packets. Because the network is connectionless, the DTCP packets can arrive out of order to the router running the DFC application.

The *liberal sequence window* feature implements a negative window for the sequence numbers received in the DTCP packets. It enables the DFC application to accept not only DTCP packets with sequence numbers greater than those previously received, but also DTCP packets with lesser sequence numbers, up to a certain limit. This limit is the negative window size; the positive and negative window sizes are +256 and -256 respectively, relative to the current maximum sequence number received. No configuration is required to activate this feature; the window sizes are hard-coded and nonconfigurable.

Configuring Dynamic Flow Capture

To configure dynamic flow capture, include the `dynamic-flow-capture` statement at the `[edit services]` hierarchy level:

```
[edit services]
dynamic-flow-capture {
```

```

capture-group client-name {
    content-destination identifier {
        address address;
        hard-limit bandwidth;
        hard-limit-target bandwidth;
        soft-limit bandwidth;
        soft-limit-clear bandwidth;
        ttl hops;
    }
    control-source identifier {
        allowed-destinations [ destinations ];
        minimum-priority value;
        no-syslog;
        notification-targets address port port-number;
        service-port port-number;
        shared-key value;
        source-addresses [ addresses ];
    }
    duplicates-dropped-periodicity seconds;
    input-packet-rate-threshold rate;
    interfaces interface-name;
    max-duplicates number;
    pic-memory-threshold percentage percentage;
}
g-duplicates-dropped-periodicity seconds;
g-max-duplicates number;
}

```

This section describes the following tasks for configuring dynamic flow capture:

- Configuring the Capture Group on page 933
- Configuring the Content Destination on page 934
- Configuring the Control Source on page 935
- Configuring the DFC PIC Interface on page 936
- Configuring System Logging on page 937
- Configuring Thresholds on page 937
- Limiting the Number of Duplicates of a Packet on page 938

Configuring the Capture Group

A capture group defines a profile of dynamic flow capture configuration information. The static configuration includes information about control sources, content destinations, and notification destinations. Dynamic configuration is added through interaction with control sources using a control protocol.

To configure a capture group, include the **capture-group** statement at the [edit services dynamic-flow-capture] hierarchy level:

```

capture-group client-name {
    content-destination identifier {
        address address;
        hard-limit bandwidth;

```

```

    hard-limit-target bandwidth;
    soft-limit bandwidth;
    soft-limit-clear bandwidth;
    ttl hops;
}
control-source identifier {
    allowed-destinations [ destinations ];
    minimum-priority value;
    no-syslog;
    notification-targets address port port-number;
    service-port port-number;
    shared-key value;
    source-addresses [ addresses ];
}
duplicates-dropped-periodicity seconds;
input-packet-rate-threshold rate;
interfaces interface-name;
max-duplicates number;
pic-memory-threshold percentage percentage;
}

```

To specify the **capture-group**, assign it a unique *client-name* that associates the information with the requesting control sources.

Configuring the Content Destination

You must specify a destination for the packets that match DFC PIC filter criteria. To configure the content destination, include the **content-destination** statement at the [edit services dynamic-flow-capture capture-group *client-name*] hierarchy level:

```

content-destination identifier {
    address address;
    hard-limit bandwidth;
    hard-limit-target bandwidth;
    soft-limit bandwidth;
    soft-limit-clear bandwidth;
    ttl hops;
}

```

Assign the **content-destination** a unique *identifier*. You must also specify its IP address and you can optionally include additional settings:

- **address**—The DFC PIC interface appends an IP header with this destination address on the matched packet (with its own IP header and contents intact) and sends it out to the content destination.
- **ttl**—The time-to-live (TTL) value for the IP-IP header. By default, the TTL value is 255. Its range is 0 through 255.
- **Congestion thresholds**—You can specify per-content destination bandwidth limits that control the amount of traffic produced by the DFC PIC during periods of congestion. The thresholds are arranged in two pairs: **hard-limit** and **hard-limit-target**, and **soft-limit** and **soft-limit-clear**. You can optionally include one or both of these paired settings. All four settings are 10-second average bandwidth values in bits per second. Typically **soft-limit-clear** < **soft-limit** <

hard-limit-target < **hard-limit**. When the content bandwidth exceeds the **soft-limit** setting:

1. A congestion notification message is sent to each control source of the criteria that point to this content destination
2. If the control source is configured for **syslog**, a system log message is generated.
3. A latch is set, indicating that the control sources have been notified. No additional notification messages are sent until the latch is cleared, when the bandwidth falls below the **soft-limit-clear** value.

When the bandwidth exceeds the **hard-limit** value:

1. The dynamic flow capture application begins deleting criteria until the bandwidth falls below the **hard-limit-target** value.
2. For each criterion deleted, a **CongestionDelete** notification is sent to the control source for that criterion.
3. If the control source is configured for **syslog**, a log message is generated.

The application evaluates criteria for deletion using the following data:

- **Priority**—Lower priority criteria are purged first, after adjusting for control source minimum priority.
- **Bandwidth**—Higher bandwidth criteria are purged first.
- **Timestamp**—The more recent criteria are purged first.

Configuring the Control Source

You configure information about the control source, including allowed source addresses and destinations and authentication key values. To configure the control source information, include the **control-source** statement at the [edit **services dynamic-flow-capture capture-group** *client-name*] hierarchy level:

```
control-source identifier {
  allowed-destinations [ destination-identifiers ];
  minimum-priority value;
  no-syslog;
  notification-targets address port port-number;
  service-port port-number;
  shared-key value;
  source-addresses [ addresses ];
}
```

Assign the **control-source** statement a unique *identifier*. You can also include values for the following statements:

- **allowed-destinations**—One or more content destination identifiers to which this control source can request that matched data be sent in its control protocol requests. If you do not specify any content destinations, all available destinations are allowed.
- **minimum-priority**—Value assigned to the control source that is added to the priority of the criteria in the DTCP ADD request to determine the total priority for the criteria. The lower the value, the higher the priority. By default, **minimum-priority** has a value of 0 and the allowed range is 0 through 254.
- **notification-targets**—One or more destinations to which the DFC PIC interface can log information about control protocol-related events and other events such as PIC bootup messages. You configure each **notification-target** entry with an IP **address** value and a User Datagram Protocol (UDP) **port** number.
- **service-port**—UDP port number to which the control protocol requests are directed. Control protocol requests that are not directed to this port are discarded by DFC PIC interfaces.
- **shared-key**—20-byte authentication key value shared between the control source and the DFC PIC monitoring platform.
- **source-addresses**—One or more allowed IP addresses from which the control source can send control protocol requests to the DFC PIC monitoring platform. These are /32 addresses.

Configuring the DFC PIC Interface

You specify the interface that interacts with the control sources configured in the same capture group. A Monitoring Services III PIC can belong to only one capture group, and you can configure only one PIC for each group.

To configure a DFC PIC interface, include the **interfaces** statement at the [edit services dynamic-flow-capture capture-group *client-name*] hierarchy level:

```
interfaces interface-name;
```

You specify DFC interfaces using the **dfc-** identifier at the [edit interfaces] hierarchy level. You must specify three logical units on each DFC PIC interface, numbered 0, 1, and 2. You cannot configure any other logical interfaces.

- **unit 0** processes control protocol requests and responses.
- **unit 1** receives monitored data.
- **unit 2** transmits the matched packets to the destination address.

The following example shows the configuration necessary to set up a DFC PIC interface:

```
[edit interfaces dfc-0/0/0]
unit 0 {
  family inet {
    address 10.1.0.0/32 { # DFC PIC address
      destination 10.36.100.1; # DFC PIC address used by
        # the control source to correspond with the
```



```

        # monitoring platform
    }
}
unit 1 { # receive data packets on this logical interface
    family inet;
}
unit 2 { # send out copies of matched packets on this logical interface
    family inet;
}

```

In addition, you must configure the dynamic flow capture application to run on the DFC PIC in the correct chassis location. The following example shows this configuration at the [edit chassis] hierarchy level:

```

fpc 0 {
    pic 0 {
        monitoring-services application dynamic-flow-capture;
    }
}

```

For more information on configuring chassis properties, see the *JUNOS System Basics Configuration Guide*.

Configuring System Logging

By default, control protocol activity is logged as a separate system log facility, **dfc**. To modify the filename or level at which control protocol activity is recorded, include the following statements at the [edit syslog] hierarchy level:

```

file dfc.log {
    dfc any;
}

```

To cancel logging, include the **no-syslog** statement at the [edit services dynamic-flow-capture capture-group *client-name* control-source *identifier*] hierarchy level:

```
no-syslog;
```



NOTE: The dynamic flow capture (**dfc**-) interface supports up to 10,000 filter criteria. When more than 10,000 filters are added to the interface, the filters are accepted, but system log messages are generated indicating that the filter is full.

Configuring Thresholds

You can optionally specify threshold values for the following situations in which warning messages will be recorded in the system log:

- Input packet rate to the DFC PIC interfaces
- Memory usage on the DFC PIC interfaces

To configure threshold values, include the `input-packet-rate-threshold` or `pic-memory-threshold` statements at the `[edit services dynamic-flow-capture capture-group client-name]` hierarchy level:

```
input-packet-rate-threshold rate;  
pic-memory-threshold percentage percentage;
```

If these statements are not configured, no threshold messages are logged. The threshold settings are configured for the capture group as a whole.

The range of configurable values for the `input-packet-rate-threshold` statement is 0 through 1 Mpps. The PIC calibrates the value accordingly; the Monitoring Services III PIC caps the threshold value at 300 Kpps and the MultiServices 400 PIC uses the full configured value. The range of values for the `pic-memory-threshold` statement is 0 to 100 percent.

Limiting the Number of Duplicates of a Packet

You can optionally specify the maximum number of duplicate packets the DFC PIC is allowed to generate from a single input packet. This limitation is intended to reduce the load on the PIC when packets are sent to multiple destinations. When the maximum number is reached, the duplicates are sent to the destinations with the highest criteria class priority. Within classes of equal priority, criteria having earlier timestamps are selected first.

To configure this limitation, include the `max-duplicates` statement at the `[edit services dynamic-flow-capture capture-group client-name]` hierarchy level:

```
max-duplicates number;
```

You can also apply the limitation on a global basis for the DFC PIC by including the `g-max-duplicates` statement at the `[edit services dynamic-flow-capture]` hierarchy level:

```
g-max-duplicates number;
```

By default, the maximum number of duplicates is set to 3. The range of allowed values is 1 through 64. A setting for `max-duplicates` for an individual capture-group overrides the global setting.

In addition, you can specify the frequency with which the application sends notifications to the affected control sources that duplicates are being dropped because the threshold has been reached. You configure this setting at the same levels as the maximum duplicates settings, by including the `duplicates-dropped-periodicity` statement at the `[edit services dynamic-flow-capture capture-group client-name]` hierarchy level or the `g-duplicates-dropped-periodicity` statement at the `[edit services dynamic-flow-capture]` hierarchy level:

```
duplicates-dropped-periodicity seconds;  
g-duplicates-dropped-periodicity seconds;
```

As with the `g-max-duplicates` statement, the `g-duplicates-dropped-periodicity` statement applies the setting globally for the application and is overridden by a setting applied at the capture-group level. By default, the frequency for sending notifications is 30 seconds.

Example: Configuring Dynamic Flow Capture

The following example includes all parts of a complete dynamic flow capture configuration.

Configure the DFC PIC interface:

```
interfaces dfc-0/0/0 {
  unit 0 {
    family inet {
      address 2.1.0.0/32 { # DFC PIC address
        destination 10.36.100.1; # DFC PIC address used by
        # the control sources to correspond with
        # the monitoring platform
      }
    }
  }
  unit 1 { # receive data packets on this logical interface
    family inet;
  }
  unit 2 { # send out copies of matched packets on this logical interface
    family inet;
  }
}
```

Configure the capture group:

```
services dynamic-flow-capture {
  capture-group g1 {
    interfaces dfc-0/0/0;
    input-packet-rate-threshold 90k;
    pic-memory-threshold percentage 80;
    control-source cs1 {
      source-addresses 10.36.41.1;
      service-port 2400;
      notification-targets {
        10.36.41.1 port 2100;
      }
      shared-key "$9$ASxdsYoX7wg4aHk";
      allowed-destinations cd1;
    }
    content-destination cd1 {
      address 10.36.70.2;
      ttl 244;
    }
  }
}
```

Configure filter-based forwarding (FBF) to the DFC PIC interface, logical unit 1.

For more information about configuring passive monitoring interfaces, see “Enabling Passive Flow Monitoring” on page 838.

```
interfaces so-1/2/0 {
  encapsulation ppp;
```

```

unit 0 {
    passive-monitor-mode;
    family inet {
        filter {
            input catch;
        }
    }
}

```

Configure the firewall filter:

```

firewall {
    filter catch {
        interface-specific;
        term def {
            then {
                count counter;
                routing-instance fbf_inst;
            }
        }
    }
}

```

Configure a forwarding routing instance. The next hop points specifically to the logical interface corresponding to unit 1, because only this particular logical unit is expected to relay monitored data to the DFC PIC.

```

routing-instances fbf_inst {
    instance-type forwarding;
    routing-options {
        static {
            route 0.0.0.0/0 next-hop dfc-0/0/0.1;
        }
    }
}

```

Configure routing table groups:

```

[edit]
routing-options {
    interface-routes {
        rib-group inet common;
    }
    rib-groups {
        common {
            import-rib [ inet.0 fbf_inst.inet.0 ];
        }
    }
    forwarding-table {
        export pplb;
    }
}

```

Configure interfaces to the control source and content destination:

```

interfaces fe-4/1/2 {
    description "to cs1 from dfc";
}

```

```
unit 0 {  
    family inet {  
        address 10.36.41.2/30;  
    }  
}  
}  
interfaces ge-7/0/0 {  
    description "to cd1 from dfc";  
    unit 0 {  
        family inet {  
            address 10.36.70.1/30;  
        }  
    }  
}
```


Chapter 51

Flow-Tap Configuration Guidelines

Dynamic flow capture enables you to capture packet flows on the basis of dynamic filtering criteria, using Dynamic Tasking Control Protocol (DTCP) requests. The flow-tap application extends the use of this protocol to intercept IPv4 packets in an active monitoring router and send a copy of packets that match filter criteria to one or more content destinations. Flow-tap data can be used in the following applications:

- Flexible trend analysis for detection of new security threats
- Lawful intercept

Flow-tap service is supported on M-series and T-series routing platforms, except M120 routers, M160 routers, and TX Matrix platforms. Flow-tap filters are applied on all IPv4 traffic and do not add any perceptible delay in the forwarding path. For security, filters installed by one client are not visible to others and the CLI configuration does not reveal the identity of the monitored target. A lighter version of the application is supported on MX-series platforms only; for more information, see “Configuring FlowTapLite” on page 947.



NOTE: For information about dynamic flow capture, see “Dynamic Flow Capture Configuration Guidelines” on page 931. For information about DTCP, see draft-cavuto-dtcp-01.txt at <http://www.ietf.org/internet-drafts>.

To configure flow-tap services, include the **flow-tap** statement at the [edit services] hierarchy level:

```
flow-tap {  
    interface interface-name;  
}
```

Other statements are configured at the [edit interfaces] and [edit system] hierarchy levels.

This chapter contains the following sections:

- Flow-Tap Architecture on page 944
- Configuring the Flow-Tap Service on page 945
- Configuring FlowTapLite on page 947
- Examples: Configuring Flow-Tap Services on page 948

Flow-Tap Architecture

The architecture consists of one or more *mediation devices* that send requests to a Juniper Networks routing platform to monitor incoming data and forward any packets that match specific filter criteria to a set of one or more *content destinations*:

- **Mediation device**—A client that monitors electronic data or voice transfer over the network. The mediation device sends filter requests to the Juniper Networks routing platform using the DTCP. The clients are not identified for security reasons, but have permissions defined by a set of special login classes.
- **Monitoring platform**—A Juniper Networks M-series or T-series routing platform containing one or more Adaptive Services (AS) or MultiServices PICs, which are configured to support the flow-tap application. The monitoring platform processes the requests from the mediation devices, applies the dynamic filters, monitors incoming data flows, and sends the matched packets to the appropriate content destinations.
- **Content destination**—Recipient of the matched packets from the monitoring platform. Typically the matched packets are sent using an IP Security (IPsec) tunnel from the monitoring platform to another router connected to the content destination. The content destination and the mediation device can be physically located on the same host. For more information on IPsec tunnels, see “IPsec Services Configuration Guidelines” on page 209.
- **Dynamic filters**—The Packet Forwarding Engine automatically generates a firewall filter that is applied to all IPv4 routing instances. Each term in the filter includes a **flow-tap** action that is similar to the existing **sample** or **port-mirroring** actions. As long as one of the filter terms matches an incoming packet, the router copies the packet and forwards it to the AS or MultiServices PIC that is configured for flow-tap service. The AS or MultiServices PIC runs the packet through the client filters and sends a copy to each matching content destination.

Following is a sample filter configuration; note that it is dynamically generated by the router (no user configuration required):

```
filter combined_LEA_filter {
  term LEA1_filter {
    from {
      source-address 1.2.3.4;
      destination-address 3.4.5.6;
    }
    then {
      flow-tap;
    }
  }
  term LEA2_filter {
    from {
      source-address 10.1.1.1;
      source-port 23;
    }
    then {
      flow-tap;
    }
  }
}
```




```

    }
}

```

Figure 12 on page 945 shows a sample topology that uses two mediation devices and two content destinations.

Figure 12: Flow-Tap Topology



Configuring the Flow-Tap Service

This section describes the following tasks for configuring flow-tap service:

- Configuring the Flow-Tap Interface on page 945
- Strengthening Flow-Tap Security on page 946
- Restrictions on Flow-Tap Services on page 946

Configuring the Flow-Tap Interface

To configure an adaptive services interface for flow-tap service, include the `interface` statement at the `[edit services flow-tap]` hierarchy level:

```
interface sp-fpc/pic/port.unit-number;
```

You can assign any AS or MultiServices PIC in the active monitoring router for flow-tap service, and use any logical unit on the PIC.



NOTE: You cannot configure dynamic flow capture (DFC) and flow-tap features on the same router simultaneously.

You must also configure the logical interface at the `[edit interfaces]` hierarchy level:

```
interface sp-fpc/pic/port {
  unit logical-unit-number {
```

```

        family inet;
    }
}

```

Strengthening Flow-Tap Security

You can add an extra level of security to DTCP transactions between the mediation device and the router by enabling DTCP sessions on top of the SSH layer. To configure SSH settings, include the **flow-tap-dtcp** statement at the **[edit system services]** hierarchy level:

```

flow-tap-dtcp {
  ssh {
    connection-limit value;
    rate-limit value;
  }
}

```

To configure client permissions for viewing and modifying flow-tap configurations and for receiving tapped traffic, include the **permissions** statement at the **[edit system login class class-name]** hierarchy level:

```
permissions [ permissions ];
```

The permissions needed to use flow-tap features are as follows:

- **flow-tap**—Can view flow-tap configuration.
- **flow-tap-control**—Can modify flow-tap configuration.
- **flow-tap-operation**—Can tap flows.

You can also specify user permissions on a RADIUS server, for example:

```

Bob Auth-Type := Local, User-Password = "abc123"
Juniper-User-Permissions = "flow-tap-operation"

```

For details on **[edit system]** and RADIUS configuration, see the *JUNOS System Basics Configuration Guide*.

Restrictions on Flow-Tap Services

The following restrictions apply to flow-tap services:

- You cannot configure dynamic flow capture (DFC) and flow-tap features on the same router simultaneously.
- When the DFC process or the AS or MultiServices PIC configured for flow-tap processing restarts, all filters are deleted and the mediation devices are disconnected.
- Only the first fragment of an IPv4 fragmented packet stream is sent to the content destination.
- Port mirroring might not work in conjunction with flow-tap processing.

- If flow-tap is configured, you cannot configure the filter action **then syslog** for any firewall filter running on the same platform.
- Running the flow-tap application over an IPsec tunnel on the same router can cause packet loops and is not supported.

Configuring FlowTapLite

A lighter version of the flow-tap application is available on MX-series platforms and also on M120 and M320 routers with Enhanced III FPCs. All of the functionality resides in the Packet Forwarding Engine rather than a service PIC or DPC.



NOTE: On M320 routers only, if the replacement of FPCs results in a mode change, you must restart the DFC process manually by disabling and then re-enabling the CLI configuration.

FlowTapLite uses the same DTCP-SSH architecture to install the DTCP filters and authenticate the users as the original flow-tap application and supports up to 3000 filters per chassis.



NOTE: The original flow-tap application and FlowTapLite cannot be used at the same time.

To configure FlowTapLite, include the **flow-tap-lite** statement at the [edit services] hierarchy level:

```
flow-tap-lite {
  tunnel-interface interface-name;
}
```

For the Packet Forwarding Engine to encapsulate of the intercepted packet, it must send the packet to a tunnel logical (vt-) interface. You will need to allocate a tunnel interface and assign it to the dynamic flow control process (dfcd) for FlowTapLite to use. To create the tunnel interface, include the following configuration:

```
chassis {
  fpc number {
    pic number {
      tunnel-services {
        bandwidth (1g | 10g);
      }
    }
  }
}
```



NOTE: Currently FlowTapLite supports only one tunnel interface per instance.

For more information on this configuration, see the *JUNOS System Basics Configuration Guide*.

To configure the logical interfaces and assign them to dfcd, include the following configuration:

```
interfaces {
  vt-fpc/pic/port {
    unit 0 {
      family inet;
    }
  }
}
```



NOTE: If a service PIC or DPC is available, you can use its tunnel interface for the same purpose.

Examples: Configuring Flow-Tap Services

The following example shows all parts of a complete flow-tap configuration.

```
services {
  flow-tap {
    interface sp-1/2/0.100;
  }
}
interfaces {
  sp-1/2/0 {
    unit 100 {
      family inet;
    }
  }
}
system {
  services {
    flow-tap-dtcp {
      ssh {
        connection-limit 5;
        rate-limit 5;
      }
    }
  }
}
login {
  class ft-class {
    permissions flow-tap-operation;
  }
  user ft-user1 {
    class ft-class;
    authentication {
      encrypted-password "xxxx";
    }
  }
}
```

```
}

```

The following example shows a FlowTapLite configuration:

```
system {
  login {
    class flowtap {
      permissions flow-tap-operation;
    }
    user ftap {
      uid 2000;
      class flowtap;
      authentication {
        encrypted-password "$1$nZfwNn4L$TWi/oxFwFZyOyyxN/87Jv0"; ##
        SECRET-DATA
      }
    }
  }
}
services {
  flow-tap-dtcp {
    ssh;
  }
}
chassis {
  fpc 0 {
    pic 0 {
      tunnel-services {
        bandwidth 10g;
      }
    }
  }
}
interfaces {
  vt-0/0/0 {
    unit 0 {
      family inet;
    }
  }
}
services {
  flow-tap-lite {
    tunnel-interface vt-0/0/0.0;
  }
}
}
```


Chapter 52

Summary of Dynamic Flow Capture and Flow-Tap Configuration Statements

The following sections explain each of the dynamic flow capture and flow-tap configuration statements. The statements are organized alphabetically.

address

Syntax	<code>address <i>address</i>;</code>
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> content-destination <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure an IP address for the flow capture destination.
Options	<i>address</i> —IP address for the content destination.
Usage Guidelines	See “Configuring the Content Destination” on page 934.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

allowed-destinations

Syntax	allowed-destinations [<i>identifiers</i>];
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> control-source <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Identify flow capture destinations that are allowed in messages sent from this control source.
Options	<i>identifier</i> —Allowed content destination name.
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

capture-group

Syntax `capture-group client-name {`
 `content-destination identifier {`
 `address address;`
 `hard-limit bandwidth;`
 `hard-limit-target bandwidth;`
 `soft-limit bandwidth;`
 `soft-limit-clear bandwidth;`
 `ttl hops;`
 `}`
 `control-source identifier {`
 `allowed-destinations [destinations];`
 `minimum-priority value;`
 `no-syslog;`
 `notification-targets address port port-number;`
 `service-port port-number;`
 `shared-key value;`
 `source-addresses [addresses];`
 `}`
 `duplicates-dropped-periodicity seconds;`
 `input-packet-rate-threshold rate;`
 `interfaces interface-name;`
 `max-duplicates number;`
 `pic-memory-threshold percentage percentage;`
 `}`

Hierarchy Level [edit services dynamic-flow-capture]

Release Information Statement introduced in JUNOS Release 7.4.

Description Define the capture group values.

Options The remaining statements are explained separately.

Usage Guidelines See “Configuring the Capture Group” on page 933.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

content-destination

Syntax `content-destination identifier {
 address address;
 hard-limit bandwidth;
 hard-limit-target bandwidth;
 soft-limit bandwidth;
 soft-limit-clear bandwidth;
 ttl hops;
 }`

Hierarchy Level [edit services dynamic-flow-capture capture-group *client-name*]

Release Information Statement introduced in JUNOS Release 7.4.

Description Identify the destination for captured packets.

Options *identifier*—Name of the destination.

The remaining statements are explained separately.

Usage Guidelines See “Configuring the Content Destination” on page 934.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

control-source

Syntax	control-source <i>identifier</i> { allowed-destinations [<i>destinations</i>]; minimum-priority <i>value</i> ; no-syslog; notification-targets <i>address</i> port <i>port-number</i> ; service-port <i>port-number</i> ; shared-key <i>value</i> ; source-addresses [<i>addresses</i>]; }
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Identify the source of the dynamic flow capture request.
Options	<i>identifier</i> —Name of control source. The remaining statements are explained separately.
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

duplicates-dropped-periodicity

Syntax	duplicates-dropped-periodicity <i>seconds</i> ;
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify the frequency for sending notifications to affected control sources when transmission of duplicate sets of data is restricted because the max-duplicates threshold has been reached.
Options	<i>seconds</i> —Period for sending DuplicatesDropped notifications. Default: 30 seconds
Usage Guidelines	See “Limiting the Number of Duplicates of a Packet” on page 938.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	g-duplicates-dropped-periodicity, max-duplicates

dynamic-flow-capture

Syntax dynamic-flow-capture {
 capture-group *client-name* {
 content-destination *identifier* {
 address *address*;
 hard-limit *bandwidth*;
 hard-limit-target *bandwidth*;
 soft-limit *bandwidth*;
 soft-limit-clear *bandwidth*;
 ttl *hops*;
 }
 }
 control-source *identifier* {
 allowed-destinations [*destinations*];
 minimum-priority *value*;
 no-syslog;
 notification-targets *address* port *port-number*;
 service-port *port-number*;
 shared-key *value*;
 source-addresses [*addresses*];
 }
 duplicates-dropped-periodicity *seconds*;
 input-packet-rate-threshold *rate*;
 interfaces *interface-name*;
 max-duplicates *number*;
 pic-memory-threshold percentage *percentage*;
 }
 g-duplicates-dropped-periodicity *seconds*;
 g-max-duplicates *number*;
 }

Hierarchy Level [edit services]

Release Information Statement introduced in JUNOS Release 7.4.

Description Define the dynamic flow capture properties to be applied to traffic.

Options The remaining statements are explained separately.

Usage Guidelines See “Dynamic Flow Capture Configuration Guidelines” on page 931.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

flow-tap

Syntax	flow-tap { interface <i>interface-name</i> ; }
Hierarchy Level	[edit services]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Enable the flow-tap application on an interface.
Options	The remaining statements are explained separately.
Usage Guidelines	See “Flow-Tap Configuration Guidelines” on page 943.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

flow-tap-lite

Syntax	flow-tap-lite { tunnel-interface <i>interface-name</i> ; }
Hierarchy Level	[edit services]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Enable the FlowTapLite application on an interface. This is a lighter version of the flow-tap application that is available on MX-series platforms, M120 routers, and M320 routers with Enhanced III FPCs only.
Options	tunnel-interface <i>interface-name</i> —Specify the tunnel interface name.
Usage Guidelines	See “Configuring FlowTapLite” on page 947.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

g-duplicates-dropped-periodicity

Syntax	<code>g-duplicates-dropped-periodicity seconds;</code>
Hierarchy Level	[edit services dynamic-flow-capture]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify the frequency for sending notifications to affected control sources when transmission of duplicate sets of data is restricted because the <code>g-max-duplicates</code> threshold has been reached. This setting is applied globally; the <code>duplicates-dropped-periodicity</code> setting applied at the <code>capture-group</code> level overrides the global setting.
Default	The default period for sending notifications is 30 seconds.
Options	<code>seconds</code> —Period for sending DuplicatesDropped notifications.
Usage Guidelines	See “Limiting the Number of Duplicates of a Packet” on page 938.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<code>duplicates-dropped-periodicity</code>

g-max-duplicates

Syntax	<code>g-max-duplicates number;</code>
Hierarchy Level	[edit services dynamic-flow-capture]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify the maximum number of content destinations to which DFC PICs can send data from a single input set of packets. Limiting the number of duplicates reduces the load on the PIC. This setting is applied globally; the <code>max-duplicates</code> setting applied at the <code>capture-group</code> level overrides the global setting.
Default	If no value is configured, a default setting of 3 is used.
Options	<code>number</code> —Maximum number of content destinations. Range: 1 through 64
Usage Guidelines	See “Limiting the Number of Duplicates of a Packet” on page 938.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<code>max-duplicates</code>

hard-limit

Syntax	<code>hard-limit <i>bandwidth</i>;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group <i>client-name</i> content-destination <i>identifier</i>]</code>
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify a bandwidth threshold at which the dynamic flow capture application begins deleting criteria, until the bandwidth falls below the hard-limit-target value.
Options	<i>bandwidth</i> —Hard limit threshold, in bits per second.
Usage Guidelines	See “Configuring the Content Destination” on page 934.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	hard-limit-target

hard-limit-target

Syntax	<code>hard-limit-target <i>bandwidth</i>;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group <i>client-name</i> content-destination <i>identifier</i>]</code>
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify a bandwidth threshold at which the dynamic flow capture application stops deleting criteria.
Options	<i>bandwidth</i> —Target value, in bits per second.
Usage Guidelines	See “Configuring the Content Destination” on page 934.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	hard-limit

input-packet-rate-threshold

Syntax	<code>input-packet-rate-threshold <i>rate</i>;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group <i>client-name</i>]</code>
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Specify a packet rate threshold value that triggers a system log warning message.
Options	<i>rate</i> —Threshold value.
Usage Guidelines	See “Configuring Thresholds” on page 937.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interface

Syntax	<code>interface <i>sp-fpc/pic/port.logical-unit</i>;</code>
Hierarchy Level	<code>[edit services flow-tap]</code>
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Specify the AS PIC interface used with the flow-tap application. Any AS PIC available in the router can be assigned, and any logical interface on the AS PIC can be used.
Options	<i>interface-name</i> —Name of the DFC interface.
Usage Guidelines	See “Configuring the Flow-Tap Interface” on page 945.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interfaces

Syntax	<code>interfaces interface-name;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group client-name]</code>
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Specify the DFC interface used with the control source configured in the same capture group.
Options	<i>interface-name</i> —Name of the DFC interface.
Usage Guidelines	See “Configuring the DFC PIC Interface” on page 936.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

max-duplicates

Syntax	<code>max-duplicates number;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group client-name]</code>
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify the maximum number of content destinations to which the DFC PIC can send data from a single input set of packets. Limiting the number of duplicates reduces the load on the PIC. This setting overrides the globally applied <code>g-max-duplicates</code> setting.
Default	If no value is configured, a default setting of 3 is used.
Options	<i>number</i> —Maximum number of content destinations. Range: 1 through 64
Usage Guidelines	See “Limiting the Number of Duplicates of a Packet” on page 938.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<code>g-max-duplicates</code>

minimum-priority

Syntax	minimum-priority <i>value</i> ;
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> control-source <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify the minimum priority for the control source.
Options	<i>value</i> —Minimum priority value; if not specified, defaults to 0. Range: 0 through 254
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

no-syslog

Syntax	no-syslog;
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> control-source <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Disable system logging of control protocol requests and responses. By default, these messages are logged.
Usage Guidelines	See “Configuring System Logging” on page 937.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

notification-targets

Syntax	notification-targets <i>address</i> port <i>port-number</i> ;
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> control-source <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	List of destination IP addresses and User Datagram Protocol (UDP) ports to which DFC PICs log exception information and control protocol state transitions, such as timeout values.
Options	<p>address <i>address</i>—Allowed destination IP address.</p> <p>port <i>port-number</i>—Allowed destination UDP port number.</p>
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

pic-memory-threshold

Syntax	pic-memory-threshold percentage <i>percentage</i> ;
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Specify a PIC memory usage percentage that triggers a system log warning message.
Options	percentage <i>percentage</i> —PIC memory threshold value.
Usage Guidelines	See “Configuring Thresholds” on page 937.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

service-port

Syntax	<code>service-port <i>port-number</i>;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group <i>client-name</i> control-source <i>identifier</i>]</code>
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Identify the User Datagram Protocol (UDP) port number for control protocol requests.
Options	<i>port-number</i> —Port number for control protocol request messages.
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

services

Syntax	<code>services dynamic-flow-capture { ... }, services flow-tap {...}</code>
Hierarchy Level	<code>[edit]</code>
Release Information	<code>dynamic-flow-capture</code> statement introduced in JUNOS Release 7.4. <code>flow-tap</code> statement introduced in JUNOS Release 8.1.
Description	Define the services to be applied to traffic.
Options	<code>dynamic-flow-capture</code> —The values configured for dynamic flow capture. <code>flow-tap</code> —The values configured for the flow-tap application. The statements are explained separately.
Usage Guidelines	See “Dynamic Flow Capture Configuration Guidelines” on page 931 or “Flow-Tap Configuration Guidelines” on page 943.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

shared-key

Syntax	<code>shared-key value;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group client-name control-source identifier]</code>
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Configure the authentication key value.
Options	<i>value</i> —Secret authentication value shared between a control source and destination.
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

soft-limit

Syntax	<code>soft-limit bandwidth;</code>
Hierarchy Level	<code>[edit services dynamic-flow-capture capture-group client-name content-destination identifier]</code>
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify a bandwidth threshold at which congestion notifications are sent to each control source of the criteria that point to this content destination. If the control source is configured with the <code>syslog</code> statement, a log message will also be generated.
Options	<i>bandwidth</i> —Soft limit threshold, in bits per second.
Usage Guidelines	See “Configuring the Content Destination” on page 934.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

soft-limit-clear

Syntax	soft-limit-clear <i>bandwidth</i> ;
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> content-destination <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Specify a bandwidth threshold at which the latch set by the soft-limit threshold is cleared.
Options	<i>bandwidth</i> —Soft-limit clear threshold, in bits per second.
Usage Guidelines	See “Configuring the Content Destination” on page 934.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	soft-limit

source-addresses

Syntax	source-addresses [<i>addresses</i>];
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> control-source <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	List of IP addresses from which the control source can send control protocol requests to the Juniper Networks routing platform.
Options	<i>address</i> —Allowed IP source address.
Usage Guidelines	See “Configuring the Control Source” on page 935.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

ttl

Syntax	<code>ttl hops;</code>
Hierarchy Level	[edit services dynamic-flow-capture capture-group <i>client-name</i> content-destination <i>identifier</i>]
Release Information	Statement introduced in JUNOS Release 7.4.
Description	Time-to-live (TTL) value for the IP-IP header.
Options	<i>hops</i> —TTL value.
Usage Guidelines	See “Configuring the Content Destination” on page 934.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Part 7

Link and Multilink Services

- Link and Multilink Services Overview on page 971
- Link and Multilink Services Configuration Guidelines on page 975
- Summary of Multilink and Link Services Configuration Statements on page 1017

Chapter 53

Link and Multilink Services Overview

The Multilink Protocol (MP) enables you to split, recombine, and sequence datagrams across multiple logical data links. The goal of multilink operation is to coordinate multiple independent links between a fixed pair of systems, providing a virtual link with greater bandwidth than any of the members.

The JUNOS software supports several MP-based services PICs: the Multilink Services PIC, the Link Services PIC, and the link services intelligent queuing (IQ) and voice services configured on the Adaptive Services (AS) and MultiServices PICs. For more information about link services IQ, see “Link Services IQ Interfaces Configuration Guidelines” on page 319. For more information about voice services, see “Voice Services Configuration Guidelines” on page 393.



NOTE: The **ml-** interface type is used to configure interfaces on the Multilink Services PIC and does not support class-of-service (CoS) features. The **ls-** interface type is used for limited CoS configurations on the Link Services PIC (except on J-series Services Routers), and the **lsq-** interface type is used for full CoS configurations on the Adaptive Services and MultiServices PICs.

For link services IQ (**lsq**) interfaces, JUNOS CoS components are fully supported and are handled normally on M-series and T-series routing platforms, as described in the *JUNOS Class of Service Configuration Guide*. There are some restrictions on J-series Services Routers; for more information on link services IQ configuration, see “Link Services IQ Interfaces Configuration Guidelines” on page 319.

The Link Services and Multilink Services PICs support the following MP encapsulation types:

- Multilink Point-to-Point Protocol (MLPPP)
- Multilink Frame Relay (MLFR)

MLPPP enables you to bundle multiple PPP links into a single logical link. MLFR enables you to bundle multiple Frame Relay data-link connection identifiers (DLCIs) into a single logical link. MLPPP and MLFR provide service option granularity between low-speed T1 and E1 services and higher-speed T3 and E3 services. You use MLPPP and MLFR to increase bandwidth in smaller, more cost-effective increments. In addition to providing incremental bandwidth, bundling multiple links can add a level of fault tolerance to your dedicated access service, because you can implement bundling across multiple PICs, protecting against the failure of any single PIC.



NOTE: Even if the PIC can support up to 4xDS3 total throughput, each aggregate can only run a volume of traffic equal to one DS3 in bandwidth. Aggregating DS3 links is not supported.

At the logical unit level, the Multilink Services and Link Services PICs support the MLPPP and MLFR Frame Relay Forum (FRF) 15 encapsulation types. At the physical interface level, the Link Services PIC also supports the MLFR FRF.16 encapsulation type.

MLPPP and MLFR FRF.15 are supported on interface types *ml-fpc/pic/port*, *ls-fpc/pic/port*, and *lsq-fpc/pic/port*. For MLFR FRF.15, multiple permanent virtual circuits (PVCs) are combined into one aggregated virtual circuit (AVC). This provides fragmentation over multiple PVCs on one end and reassembly of the AVC on the other end.

MLFR FRF.16 is supported on a channelized interface, *ls-fpc/pic/port:channel*, which denotes a single MLFR FRF.16 bundle. For MLFR FRF.16, multiple links are combined to form one logical link. Packet fragmentation and reassembly occur on a per-VC basis. Each bundle can support multiple VCs. Link Services PICs can support up to 256 DLCIs per MLFR FRF.16 bundle. The physical connections must be E1, T1, channelized DS3-to-DS1, channelized DS3-to-DS0, channelized E1, channelized STM1, or channelized IQ interfaces. When you bundle channelized interfaces using the link services interface, the channelized interfaces require M-series Enhanced Flexible PIC Concentrators (FPCs).



NOTE: When running MLPPP or MLFR on a non-QPP interface, you cannot mix logical units that are members of an aggregate with logical units configured using other families, such as *inet*. For example, the following configuration is not valid:

```
interface e3-0/0/0 {
  encapsulation frame-relay;
  unit 99 {
    dlc1 99;
    family mlfr-end-to-end {
      bundle ls-0/0/0.1;
    }
  }
  unit 100 { ## mixes mlfr with family inet
    dlc1 100;
    family inet {
      address 192.168.164.53/30;
    }
  }
}
```

The standards for MLPPP, MLFR FRF.15, and MLFR FRF.16 are defined in the following specifications:

- RFC 1990, *The PPP Multilink Protocol (MP)*

- FRF.15, *End-to-End Multilink Frame Relay Implementation Agreement*
- FRF.16.1, *Multilink Frame Relay UNI/NNI Implementation Agreement*



NOTE: Endpoint Discriminator Class compatibility checking is enabled on MLPPP interfaces. Prior to JUNOS Release 8.0, when a Juniper Networks router received an unsupported Endpoint Discriminator Class message from an MLPPP session peer, it returned an ACK response.

Chapter 54

Link and Multilink Services Configuration Guidelines

To configure multilink and link services logical interfaces, include the following statements.

```
(ml-fpc/pic/port | ls-fpc/pic/port) {  
    unit logical-unit-number {  
        dlc dlci-identifier;  
        drop-timeout milliseconds;  
        encapsulation type;  
        fragment-threshold bytes;  
        interleave-fragments;  
        minimum-links number;  
        mrru bytes;  
        multicast-dlc dlci-identifier;  
        short-sequence;  
        family family {  
            address address {  
                destination address;  
            }  
            bundle (ml-fpc/pic/port | ls-fpc/pic/port);  
        }  
    }  
}
```

You can include these statements at the following hierarchy levels:

- [edit interfaces]
- [edit logical-systems *logical-system-name* interfaces]

To configure link services physical interfaces, include the `mlfr-uni-nni-bundle-options` statement at the [edit interfaces *ls-fpc/pic/port:channel*] hierarchy level:

```
[edit interfaces ls-fpc/pic/port:channel]  
encapsulation type;  
mlfr-uni-nni-bundle-options {  
    acknowledge-retries number;  
    acknowledge-timer milliseconds;  
    action-red-differential-delay (disable-tx | remove-link);  
    drop-timeout milliseconds;  
    fragment-threshold bytes;  
    hello-timer milliseconds;
```

```

lmi-type (ansi | itu);
minimum-links number;
mrru bytes;
n391 number;
n392 number;
n393 number;
red-differential-delay milliseconds;
t391 number;
t392 number;
yellow-differential-delay milliseconds;
}

```

This chapter contains the following sections:

- Multilink and Link Services PICs Overview on page 976
- Configuring the Number of Bundles on Link Services PICs on page 977
- Configuring the Links in a Multilink or Link Services Bundle on page 978
- Multilink and Link Services Logical Interface Configuration Overview on page 979
- Configuring Encapsulation for Multilink and Link Services Logical Interfaces on page 981
- Configuring the Drop Timeout Period on Multilink and Link Services Logical Interfaces on page 982
- Limiting Packet Payload Size on Multilink and Link Services Logical Interfaces on page 983
- Configuring the Minimum Number of Active Links on Multilink and Link Services Logical Interfaces on page 984
- Configuring MRRU on Multilink and Link Services Logical Interfaces on page 985
- Configuring the Sequence Header Format on Multilink and Link Services Logical Interfaces on page 986
- Configuring DLCIs on Link Services Logical Interfaces on page 986
- Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces on page 988
- Configuring Compressed RTP on J-series Services Routers on page 990
- Configuring Link Services Physical Interfaces on page 993
- Configuring CoS on Link Services Interfaces on page 997
- Examples: Configuring Multilink Interfaces on page 1002
- Examples: Configuring Link Interfaces on page 1006

Multilink and Link Services PICs Overview

Each Multilink Services or Link Services PIC can support a number of *bundles*. A bundle can contain up to eight individual *links*.

For Multilink Services PICs, the links can be T1, E1, or DS0 physical interfaces, and each link is associated with a logical unit number that you configure. For Link Services PICs, the links can be E1, T1, channelized DS3-to-DS1, channelized DS3-to-DS0,

channelized E1, channelized STM1 interfaces, or channelized IQ interfaces. For MLFR FRF.16 bundles, each link is associated with a channel number that you configure.

You must configure a link before it can join a bundle. Each bundle should consist solely of one type of link; the mixing of physical interfaces of differing speeds within a bundle is not supported.



NOTE: On both J-series and M-series platforms, only one DS3 link is allowed in an MLFR bundle. MLPPP bundles can include two DS3 links.

Three versions of Multilink Services and three versions of Link Services PICs are available, as shown in Table 17 on page 977. The PIC hardware is identical, except for different faceplates that enable you to identify which version you are installing. The software limits the unit numbers and maximum number of physical interfaces you assign to the PIC.

Table 17: Multilink Services PIC Capacities

PIC Capacity	Unit Numbers	Maximum Number of T1/DS0 Interfaces	Maximum Number of E1 Interfaces
4-bundle PIC	0 through 3	32 links	32 links
32-bundle PIC	0 through 31	256 links	219 links
128-bundle PIC	0 through 127	292 links	219 links

A single PIC can support an aggregate bandwidth of 450 megabits per second (Mbps).

You can configure a larger number of links, but the Multilink Services and Link Services PICs can reliably process only 450 Mbps of traffic. A higher rate of traffic might degrade performance.

For configuration information, see the following sections:

- Configuring the Number of Bundles on Link Services PICs on page 977
- Configuring the Links in a Multilink or Link Services Bundle on page 978

Configuring the Number of Bundles on Link Services PICs

The default number of bundles per Link Services PIC is 16, ranging from *ls-fpc/pic/port:0* to *ls-fpc/pic/port:15*.

You can combine MLFR FRF.16, MLPPP, and MLFR FRF.15 bundles on a single Link Services PIC. For a sample configuration, see “Example: Configuring a Link Services Interface with Two Links” on page 1006.

To configure the number of bundles on a Link Services PIC, include the `mlfr-uni-nni-bundles` statement at the `[edit chassis fpc slot-number pic pic-number]` hierarchy level:

```
mlfr-uni-nni-bundles number;
```

Each Link Services PIC can accommodate a maximum of 256 MLFR UNI NNI bundles. For more information, see the *JUNOS System Basics Configuration Guide*.

A link can associate with one link services bundle only. All Link Services PICs support up to 256 single-link bundles and up to 256 DLCIs. For an example configuration, see “Examples: Configuring Link Interfaces” on page 1006.




NOTE: When one or more links in a bundle are put in loopback, reassembly buffering and hence processing are reduced so as to not affect other bundles. This prevents packet loss on other bundles, while reducing the reassembly buffers available for the bundle with looped links.

Configuring the Links in a Multilink or Link Services Bundle

To complete a multilink or link services interface configuration, you need to configure both the physical interface and the multilink or link services bundle. For multilink interfaces, you configure the link bundle on the logical unit. For link services interfaces, you configure the link bundle as a channel (see Figure 13 on page 978). The physical interface is usually connected to networks capable of supporting MLPPP or MLFR (FRF.15 or FRF.16).

Figure 13: Multilink Interface Configuration



The following sample configuration refers to the topology in Figure 13 on page 978 and configures a multilink or link services bundle over a T1 connection (for which the T1 physical interface is already configured).

1. To configure a physical T1 link for MLPPP, include the following statements at the `[edit interfaces t1-fpc/pic/port]` hierarchy level:

```
unit 0 {
  family mlppp {
    bundle (ml-fpc/pic/port | ls-fpc/pic/port);
  }
}
```

You do not need to configure an IP address on this link.

To configure a physical T1 link for MLFR FRF.16, include the following statements at the [edit interfaces *t1-fpc/pic/port*] hierarchy level:

```
encapsulation multilink-frame-relay-uni-nni;
unit 0 {
  family mlfr-uni-nni {
    bundle ls-fpc/pic/port:channel;
  }
}
```

You do not need to configure an IP address or a DLCI on this link.

2. To configure the logical address for the MLPPP, MLFR FRF.15, or MLFR FRF.16 bundle, include the **address** and **destination** statements:

```
address address {
  destination address;
}
```

You can include these statements at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number* family inet]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* family inet]

When you add statements such as **mrru** to the configuration and commit, the T1 interface becomes part of the multilink bundle.



NOTE: For MLPPP and MLFR (FRF.15 and FRF.16) links, you must specify the subnet address as /32 or /30. Any other subnet designation is treated as a mismatch.

Multilink and Link Services Logical Interface Configuration Overview

You configure multilink and link services interface properties at the logical unit level. Default settings for multilink and link services logical interface properties are described in the section “Default Settings for Multilink and Link Services Logical Interfaces” on page 980.

For general information about logical unit properties or **family inet** properties, see the *JUNOS Network Interfaces Configuration Guide*. For information about multilink and link services properties you configure at the **family inet** hierarchy level, see “Configuring the Links in a Multilink or Link Services Bundle” on page 978.



NOTE: On DS0, E1, or T1 interfaces in LSQ bundles, you can configure the **bandwidth** statement, but the routing platform does not use the bandwidth value if the interfaces are included in an MLPPP or MLFR bundle. The bandwidth is calculated internally according to the time slots, framing, and byte-encoding of the interface. For more information about logical interface properties, see the *JUNOS Network Interfaces Configuration Guide*.

Default Settings for Multilink and Link Services Logical Interfaces

Table 18 on page 980 lists the default settings for multilink and link services statements, together with the other permitted values or value ranges.

Table 18: Multilink and Link Services Logical Interface Statements

Option	Default Value	Possible Values
DLCI	None	16 through 1022
Drop timeout period	500 ms for bundles greater than or equal to the T1 bandwidth value and 1500 ms for other bundles.	0 through 2000 milliseconds
Encapsulation	For multilink interfaces, multilink-ppp . For link services interfaces, multilink-frame-relay-end-to-end .	multilink-frame-relay-end-to-end , multilink-ppp
Fragmentation threshold	0 bytes	128 through 16,320 bytes (Nx64)
Interleave fragments	disabled	enabled, disabled
Minimum links	1 link	1 through 8 links
Maximum received reconstructed unit (MRRU)	1504 bytes	1500 through 4500 bytes
Sequence ID format for MLPPP	24 bits	12 or 24 bits
Sequence ID format for MLFR FRF.15 and FRF.16	12 bits	12 bits

See Table 19 on page 993 for statements that apply to link services physical interfaces only.

- Related Topics**
- Configuring Encapsulation for Multilink and Link Services Logical Interfaces on page 981
 - Configuring the Drop Timeout Period on Multilink and Link Services Logical Interfaces on page 982

- Limiting Packet Payload Size on Multilink and Link Services Logical Interfaces on page 983
- Configuring the Minimum Number of Active Links on Multilink and Link Services Logical Interfaces on page 984
- Configuring MRRU on Multilink and Link Services Logical Interfaces on page 985
- Configuring the Sequence Header Format on Multilink and Link Services Logical Interfaces on page 986
- Configuring DLCIs on Link Services Logical Interfaces on page 986
- Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces on page 988
- Configuring Compressed RTP on J-series Services Routers on page 990

Configuring Encapsulation for Multilink and Link Services Logical Interfaces

Multilink and link services interfaces support the following logical interface encapsulation types:

- MLPPP
- MLFR end-to-end

By default, the logical interface encapsulation type on multilink interfaces is MLPPP. The default logical interface encapsulation type on link services interfaces is MLFR end-to-end. For general information on encapsulation, see the *JUNOS Network Interfaces Configuration Guide*.

You can also configure physical interface encapsulation on link services interfaces. For more information, see “Configuring Encapsulation for Link Services Physical Interfaces” on page 994.

To configure multilink or link services encapsulation, include the `encapsulation` statement:

```
encapsulation type;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

You must also configure the T1, E1, or DS0 physical interface with the same encapsulation type.



CAUTION: When you configure the first MLFR encapsulated unit or delete the last MLFR encapsulated unit on a port, it triggers an interface encapsulation change on

the port, which causes an interface flap on the other units within the port that are configured with generic Frame Relay.

Configuring the Drop Timeout Period on Multilink and Link Services Logical Interfaces

By default, the drop timeout parameter is disabled. You can configure a drop timeout value to provide a recovery mechanism if individual links in the multilink or link services bundle drop one or more packets. Drop timeout is not a differential delay tolerance setting, and does not limit the overall latency. However, you need to make sure the value you set is larger than the expected differential delay across the links, so that the timeout period does not elapse under normal jitter conditions, but only when there is actual packet loss. You can configure differential delay tolerance for link services interfaces only. For more information, see “Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16” on page 995.

To configure the drop timeout value, include the **drop-timeout** statement:

```
drop-timeout milliseconds;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For link services interfaces, you also can configure the drop timeout value at the physical interface level by including the **drop-timeout** statement at the [edit interfaces *ls-fpc/pic/port:channel* mlfr-uni-nni-bundle-options] hierarchy level:

```
drop-timeout milliseconds;
```

By default, the drop timer has a value of 500 ms for bundles greater than or equal to the T1 bandwidth value, and 1500 ms for other bundles. Any CLI-configured value overrides these defaults. Values can range from 1 through 2000 milliseconds. Values less than 5 milliseconds are not recommended, and a configured value of 0 reverts to the default value of 2000 milliseconds.



NOTE: For multilink or link services interfaces, if a packet or fragment encounters an error condition and is destined for a disabled bundle or link, it does not contribute to the dropped packet and frame counts in the per-bundle statistics. The packet is counted under the global error statistics and is not included in the global output bytes and output packet counts. This unusual accounting happens only if the error conditions are generated inside the multilink interface, not if the packet encounters errors on the wire or elsewhere in the network.

If you configure the **drop-timeout** statement with a value of 0, it disables any resequencing by the PIC for the specified class of MLPPP traffic. Packets are forwarded

with the assumption that they arrived in sequence, and forwarding of fragmented packets is disabled for all classes. Fragments dropped as a result of this setting will increment the counter at the class level.

Alternatively, you can configure the `drop-timeout` statement at the `[edit class-of-service fragmentation-maps map-name forwarding-class class]` hierarchy level. The behavior and the default and range values are identical, but the setting applies only to the specified forwarding class. Configuration at the bundle level overrides configuration at the class-of-service level.

By default, compression of the inner PPP header in the MLPPP payload is enabled. To disable compression, include the `disable-mlppp-inner-ppp-pfc` statement at the `[edit interfaces interface-name unit logical-unit-number]` hierarchy level. For example:

```
interfaces lsq-1/2/0 {
  unit 0 {
    encapsulation multilink-ppp;
    disable-mlppp-inner-ppp-pfc;
    multilink-max-classes 4;
    family inet {
      address 10.50.1.2/30;
    }
  }
}
```

For more information about CoS configuration, see the *JUNOS Class of Service Configuration Guide*. You can view the configured drop-timeout value and the status of inner PPP header compression by issuing the `show interfaces interface-name extensive` command.

Limiting Packet Payload Size on Multilink and Link Services Logical Interfaces

For multilink and link services logical interfaces with MLPPP encapsulation only, you can configure a *fragmentation threshold* to limit the size of packet payloads transmitted across the individual links within the multilink circuit. The software splits any incoming packet that exceeds the fragmentation threshold into smaller units suitable for the circuit size; it reassembles the fragments at the other end, but does not affect the output traffic stream. The threshold value affects the payload only; it does not affect the MLPPP header. By default, the fragmentation threshold parameter is disabled.



NOTE: To ensure proper load balancing:

- For Link Services MLFR (FRF.15 and FRF.16) interfaces, do not include the `fragment-threshold` statement in the configuration.
- For MLPPP interfaces, do not include both the `fragment-threshold` statement and the `short-sequence` statement in the configuration.
- For MLFR (FRF.15 and FRF.16) and MLPPP interfaces, if the MTU of links in a bundle is less than the bundle MTU plus encapsulation overhead, then fragmentation is automatically enabled. You should avoid this situation for MLFR (FRF.15 and FRF.16) interfaces and for MLPPP interfaces on which short-sequencing is enabled.

To configure a fragmentation threshold value, include the `fragment-threshold` statement:

```
fragment-threshold bytes;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For link services interfaces, you also can configure a fragmentation threshold value at the physical interface level by including the `fragment-threshold` statement at the [edit interfaces *ls-fpc/pic/port:channel* *mlfr-uni-nni-bundle-options*] hierarchy level:

```
fragment-threshold bytes;
```

The maximum fragment size can be from 128 through 16,320 bytes. The JUNOS software automatically subdivides packet payloads that exceed this value. Any value you set must be a multiple of 64 bytes ($N \times 64$). The default value, 0, results in no fragmentation.

Configuring the Minimum Number of Active Links on Multilink and Link Services Logical Interfaces

You can set the minimum number of links that must be up for the multilink bundle as a whole to be labeled up. By default, only one link must be up for the bundle to be labeled up. A member link is considered up when the PPP Link Control Protocol (LCP) phase transitions to open state.

The `minimum-links` value should be identical on both ends of the bundle.

To set the minimum number, include the `minimum-links` statement:

```
minimum-links number;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For link services interfaces, you also can configure the minimum number of links at the physical interface level by including the `minimum-links` statement at the [edit interfaces *ls-fpc/pic/port:channel* *mlfr-uni-nni-bundle-options*] hierarchy level:

```
minimum-links number;
```

The number can be from 1 through 8. The maximum number of links supported in a bundle is 8. When 8 is specified, all configured links of a bundle must be up.

Configuring MRRU on Multilink and Link Services Logical Interfaces

The *maximum received reconstructed unit (MRRU)* is similar to a maximum transmission unit (MTU), but applies only to multilink bundles; it is the maximum packet size that the multilink interface can process. By default, the MRRU is set to 1500 bytes; you can configure a different MRRU value if the peer equipment allows this. The MRRU accounts for the original payload, for example the Layer 3 protocol payload, but does not include the 2-byte PPP header or the additional MLPPP or MLFR header applied while the individual multilink packets are traversing separate links in the bundle.

To configure a different MRRU value, include the `mrru` statement:

```
mrru bytes;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For link services interfaces, you also can configure a different MRRU at the physical interface level by including the `mrru` statement at the [edit interfaces *ls-fpc/pic/port:channel* *mlfr-uni-nni-bundle-options*] hierarchy level:

```
mrru bytes;
```

The MRRU size can range from 1500 through 4500 bytes.



NOTE: If you set the MRRU on a bundle to a value larger than the MTU of the individual links within it, you must enable a fragmentation threshold for that bundle. Set the threshold to a value no larger than the smallest MTU of any link included in the bundle.

Determine the appropriate MTU size for the bundle by ensuring that the MTU size does not exceed the sum of the encapsulation overhead and the MTU sizes for the links in the bundle.

You can configure separate **family mtu** values on the following protocol families under bundle interfaces: **inet**, **inet6**, **iso**, and **mpls**. If not configured, the default value of 1500 is used on all except for **mpls** configurations, in which the value 1488 is used.



NOTE: The effective family MTU might be different from the MTU value specified for MLPPP configurations, because it is adjusted downward by the remote MRRU's constraints. The remote MRRU configuration is not supported on M120 routers.

Configuring the Sequence Header Format on Multilink and Link Services Logical Interfaces

For MLPPP, the sequence header format is set to 24 bits by default. You can configure an alternative value of 12 bits, but 24 bits is considered the more robust value for most networks.

To configure a different sequence header value, include the **short-sequence** statement:

```
short-sequence;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For MLFR FRF.15, the sequence header format is set to 24 bits by default. This is the only valid option.

Configuring DLCIs on Link Services Logical Interfaces

For link services interfaces only, you can configure multiple DLCIs for MLFR FRF.16 or MLPPP bundles.

DLCIs are not supported on multilink interfaces.

Configuring Point-to-Point DLCIs for MLFR FRF.16 and MLPPP Bundles

For link services interfaces only, you can configure multiple point-to-point DLCIs for each MLFR FRF.16 or MLPPP bundle. A channelized interface, such as **ls-1/1/1:0**, denotes a single MLFR FRF.16 bundle. To configure a DLCI, include the **dlsi** statement:

```
dlsi dlsi-identifier;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

The DLCI identifier is a value from 16 through 1022. Numbers 1 through 15 are reserved for future use.

When you configure point-to-point connections, the maximum transmission unit (MTU) sizes on both sides of the connection must be the same.

Configuring Multicast-Capable DLCIs for MLFR FRF.16 Bundles

For link services interfaces only, you can configure multiple multicast-capable DLCIs for each MLFR FRF.16 bundle. A channelized interface, such as **ls-1/1/1:0**, denotes a single MLFR FRF.16 bundle. By default, Frame Relay connections assume unicast traffic. If your Frame Relay switch performs multicast replication, you can configure the link services connection to support multicast traffic by including the **multicast-dlsi** statement:

```
multicast-dlsi dlsi-identifier;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

The DLCI identifier is a value from 16 through 1022 that defines the Frame Relay DLCI over which the switch expects to receive multicast packets for replication.

You can configure multicast support only on point-to-multipoint link services connections. Multicast-capable DLCIs are not supported on multilink interfaces.

If keepalives are enabled, causing the interface to send Local Management Interface (LMI) messages during idle times, the number of possible DLCI configurations is limited by the MTU selected for the interface. For more information, see “Configuring Keepalives on Link Services Physical Interfaces” on page 996.

Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces

For link services FRF.15 and MLPPP interfaces only, you can configure link fragment interleaving (LFI). LFI reduces excessive delays of Frame Relay packets by fragmenting long packets into smaller packets and interleaving them with real-time frames. This allows real-time and non-real-time data frames to be carried together on lower-speed links without causing excessive delays to the real-time traffic. When the peer interface receives the smaller fragments, it reassembles the fragments into their original packet. For example, short delay-sensitive packets, such as packetized voice, can race ahead of larger delay-insensitive packets, such as common data packets.



NOTE: All Link Services PICs (4-multilink bundle, 32-multilink bundle, and 128-multilink bundle) support up to 256 link services interfaces with LFI enabled, if those link services interfaces contain only one constituent link each. For the Link Services PIC, multiple-link LFI bundles are simply multilink bundles, and are limited based on the type of PIC (4-multilink bundle, 32-multilink bundle, and 128-multilink bundle).

In addition, the multilink bundles you configure subtract from the total of 256 possible LFI-enabled link services interfaces. For example, if a 32-multilink bundle Link Services PIC has 24 multilink bundles configured and active, then you can configure $256 - 24 = 232$ LFI-enabled link services interfaces, each with a single constituent link.

For link services IQ interfaces (**lsq**), the **interleave-fragments** statement is not valid. Instead, you can enable LFI by configuring fragmentation maps. For more information, see “Configuring CoS Fragmentation by Forwarding Class on LSQ Interfaces” on page 336.

You can configure multiple links in a bundle and configure packet interleaving. However, if you use packet interleaving, high-priority, nonmultilink-encapsulated packets use a hash-based algorithm to choose a single link.

For detailed information about link services CoS, see “Configuring CoS on Link Services Interfaces” on page 997.

Per-bundle CoS queuing is supported on link services IQ interfaces (**lsq**). For more information about link services IQ interfaces, see “Link Services IQ Interfaces Configuration Guidelines” on page 319.

The JUNOS software supports end-to-end fragmentation in compliance with the FRF.12 *Frame Relay Fragmentation Implementation Agreement* standard. Unlike user-to-network interface (UNI) and network-to-network (NNI) fragmentation, end-to-end supports fragmentation only at the endpoints.

By default, packet interleaving is disabled. To enable packet interleaving, include the **interleave-fragments** statement:

```
interleave-fragments;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

Configuring LFI with DLCI Scheduling

For Link Services and Channelized DS3 IQ PICs, you can configure LFI and DLCI scheduling. For channelized DS3 interfaces, LFI is supported with FRF.15 only, and on M10i and M20 platforms only.

Configuring LFI with DLCI scheduling enables packets entering the Link Services PIC to be fragmented before being transmitted to the Channelized DS3 IQ PIC. Once the fragmented packets enter the Channelized DS3 IQ PIC, they are scheduled at the DLCI level, to allow priority transmission for real-time applications.

For more information about associating a scheduler with a DLCI, see the *JUNOS Class of Service Configuration Guide*.

Example: Configuring LFI with DLCI Scheduling

Configure packets entering the Link Services PIC to be fragmented before being transmitted to the Channelized DS3 IQ PIC. Once the fragmented packets enter the Channelized DS3 IQ PIC, they are scheduled at the DLCI level, to allow priority transmission for real-time applications.

```
[edit interfaces]
ls-1/0/0 {
  unit 1 {
    encapsulation multilink-frame-relay-end-to-end;
    interleave-fragments;
    family inet {
      address 192.168.5.2/32 {
        destination 192.168.5.3;
      }
    }
  }
}
t3-1/0/0:1 {
  per-unit-scheduler;
  unit 0 {
    dlci 16;
    encapsulation multilink-frame-relay-end-to-end;
    family mlfr-end-to-end {
      bundle ls-1/0/0.1;
    }
  }
}
[edit class-of-service]
interfaces {
  t3-1/0/0:1 {
    unit 0 {
      scheduler-map sched-map-logical-0;
```

```

        shaping-rate 10m;
    }
    unit 1 {
        scheduler-map sched-map-logical-1;
        shaping-rate 20m;
    }
}
scheduler-maps {
    sched-map-logical-0 {
        forwarding-class best-effort scheduler sched-best-effort-0;
        forwarding-class assured-forwarding scheduler sched-bronze-0;
        forwarding-class expedited-forwarding scheduler sched-silver-0;
        forwarding-class network-control scheduler sched-gold-0;
    }
    sched-map-logical-1 {
        forwarding-class best-effort scheduler sched-best-effort-1;
        forwarding-class assured-forwarding scheduler sched-bronze-1;
        forwarding-class expedited-forwarding scheduler sched-silver-1;
        forwarding-class network-control scheduler sched-gold-1;
    }
}
schedulers {
    sched-best-effort-0 {
        transmit-rate 4m;
    }
    sched-bronze-0 {
        transmit-rate 3m;
    }
    sched-silver-0 {
        transmit-rate 2m;
    }
    sched-gold-0 {
        transmit-rate 1m;
    }
    sched-best-effort-1 {
        transmit-rate 8m;
    }
    sched-bronze-1 {
        transmit-rate 6m;
    }
    sched-silver-1 {
        transmit-rate 4m;
    }
    sched-gold-1 {
        transmit-rate 2m;
    }
}
}
}

```

Configuring Compressed RTP on J-series Services Routers

On J-series Services Routers link services interfaces (ls), you can configure the compressed Real-Time Transport Protocol (CRTP) with either MLPPP or PPP encapsulation.

You can also configure CRTP with MLPPP on link services IQ (**lsq**) interfaces and voice services interfaces. When you configure CRTP with MLPPP, the configuration syntax for J-series Services Routers is the same as the syntax you use on the AS or MultiServices PIC. The only difference is that you use the **ls**- interface descriptor for J-series Services Routers, and you use the **lsq**- interface descriptor for the AS or MultiServices PIC. For more information, see “Configuring Services Interfaces for Voice Services” on page 394.

All CRTP traffic is sent on the LFI queue (**q2**). We recommend that the incoming voice traffic be classified to the appropriate queue.

The configuration syntax for CRTP with PPP encapsulation is much like the syntax you use when you configure CRTP with MLPPP.

To configure CRTP with PPP encapsulation, perform the following steps:

1. On the logical T1 or E1 constituent link, configure the link services interface used for compression by including the **compression-device** statement:

```
compression-device interface-name;
```

The interface name is the link services interface on which the T1 or E1 constituent link is bundled.

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
 - [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]
2. Specify how the link services interface handles voice traffic compression by including the following statements:

```
compression {
  rtp {
    f-max-period number;
    queues [ queue-numbers ];
    port {
      minimum port-number;
      maximum port-number;
    }
  }
}
```

You can include these statements at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For detailed information about these statements, see “Configuring Services Interfaces for Voice Services” on page 394.

Example: Configuring Compressed RTP with MLPPP Encapsulation

Configure compression on a J-series T1 interface with MLPPP encapsulation. Configure fragmentation for all IP packets larger than 128 bytes.

For detailed information about these configuration statements, see “Configuring Services Interfaces for Voice Services” on page 394.

```
[edit interfaces]
t1-1/0/0 {
  unit 0 {
    family mlppp {
      bundle ls-1/1/0.1;
    }
  }
}
ls-1/1/0 {
  unit 1 {
    compression {
      rtp {
        port minimum 16384 maximum 32768;
      }
    }
    encapsulation multilink-ppp;
    family inet {
      address 30.1.1.2/24;
    }
    fragment-threshold 128;
  }
}
```

Example: Configuring Compressed RTP with PPP Encapsulation

Configure compression on a J-series T1 interface with PPP encapsulation. Configure fragmentation for all IP packets larger than 128 bytes.

```
[edit interfaces]
t1-1/0/0 {
  encapsulation ppp;
  unit 0 {
    compression-device ls-0/0/0.1
  }
}
ls-0/0/0.1 {
  compression {
    rtp {
      port minimum 16384 maximum 32768;
    }
  }
  family inet {
    address 10.0.2.3;
    # Other IPv4 parameters here.
  }
}
```


}

Configuring Link Services Physical Interfaces

You configure link services interface properties at the logical unit and physical interface level. Default settings for link services physical interface properties are described in “Default Settings for Link Services Interfaces” on page 993.

The following sections explain how to configure link services physical interfaces:

- Default Settings for Link Services Interfaces on page 993
- Configuring Encapsulation for Link Services Physical Interfaces on page 994
- Configuring Acknowledgment Timers on Link Services Physical Interfaces on page 994
- Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16 on page 995
- Configuring Keepalives on Link Services Physical Interfaces on page 996

For information about link services physical interface properties that can also be configured at the logical unit level, see “Multilink and Link Services Logical Interface Configuration Overview” on page 979.

Default Settings for Link Services Interfaces

Table 19 on page 993 lists the default settings for link services statements, together with the other permitted values or value ranges.

Table 19: Link Services Physical Interface Statements for MLFR FRF.16

Option	Default Value	Possible Values
Action red differential delay	remove-link	disable-tx, remove-link
Red differential delay	120 ms	1 through 2000 ms
Yellow differential delay	72 ms	1 through 2000 ms
Drop timeout period	0 ms	0 through 2000 ms
Encapsulation	multilink-frame-relay-uni-nni	multilink-frame-relay-uni-nni
Fragmentation threshold	0 bytes	128 through 16,320 bytes (Nx64)
LMI type	itu	ansi, itu
Minimum links	1 link	1 through 8 links
MRRU	1504 bytes	1500 through 4500 bytes
n391 (full status polling counter)	6	1 through 255

Table 19: Link Services Physical Interface Statements for MLFR FRF.16 (*continued*)

Option	Default Value	Possible Values
n392 (LMI error threshold)	3	1 through 10
n393 (LMI monitored event count)	4	1 through 10
t391 (link integrity verify polling timer)	10	5 through 30
t392 (polling verification timer)	15	5 through 30
Sequence ID format for MLFR	12 bits	12 bits

Configuring Encapsulation for Link Services Physical Interfaces

Link services interfaces support the physical interface encapsulation MLFR UNI NNI. By default, the physical interface encapsulation on link services interfaces is MLFR UNI NNI. Multilink interfaces do not support physical interface encapsulation.

For more information, see the *JUNOS Network Interfaces Configuration Guide*.

You can also configure logical interface encapsulation on multilink and link services interfaces. For more information, see “Configuring Encapsulation for Multilink and Link Services Logical Interfaces” on page 981.

To explicitly configure link services physical interface encapsulation, include the encapsulation statement at the [edit interfaces *ls-fpc/pic/port:channel*] hierarchy level:

```
encapsulation type;
```

You must also configure the T1, E1, or DS0 physical and physical interface with the same encapsulation type.

Configuring Acknowledgment Timers on Link Services Physical Interfaces

For link services interfaces configured with MLFR FRF.16, each link end point in a bundle initiates a request for bundle operation with its peer by transmitting an add link message. A hello message notifies the peer end point that the local end point is up. Both ends of a link generate a hello message periodically, or as configured with the hello timer. A remove link message notifies the peer that the local end management is removing the link from bundle operation. End points respond to add link, remove link, and hello messages by sending acknowledgment messages.

You can configure the maximum period to wait for an add link acknowledgment, hello acknowledgment, or remove link acknowledgment by including the `acknowledge-timer` statement at the [edit interfaces *ls-fpc/pic/port:channel* *mlfr-uni-nni-bundle-options*] hierarchy level:

```
acknowledge-timer milliseconds;
```

The acknowledgment timer can be from 1 through 10 milliseconds. The default is 4 milliseconds.

For link services interfaces, you can configure the number of retransmission attempts to be made for consecutive hello or remove link messages after the expiration of the acknowledgment timer by including the `acknowledge-retries` statement at the [edit interfaces *ls-fpc/pic/port:channel* mlfr-uni-nni-bundle-options] hierarchy level:

```
acknowledge-retries number;
```

`acknowledgment-retries` can be a value from 1 through 5. The default is 2.

You can configure the rate at which hello messages are sent by including the `hello-timer` statement at the [edit interfaces *ls-fpc/pic/port:channel* mlfr-uni-nni-bundle-options] hierarchy level:

```
hello-timer milliseconds;
```

A hello message is transmitted after the specified period (in milliseconds) has elapsed. The hello timer can be from 1 through 180 milliseconds; the default is 10 milliseconds. When the hello timer expires, a link end point generates an add-link message.

Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16

For link services interfaces configured with MLFR FRF.16, the differential delay between links in a bundle is measured and warning is given when a link has a substantially greater differential delay than other links in the same bundle. The implementing endpoint can determine if the differential delay is in an acceptable range and decide to remove the link from the bundle, or to stop transmission on the link.

You can configure the yellow differential delay for links in a bundle by including the `yellow-differential-delay` statement at the [edit interfaces *ls-fpc/pic/port:channel* mlfr-uni-nni-bundle-options] hierarchy level:

```
yellow-differential-delay milliseconds;
```

The yellow differential delay can be from 1 through 2000 milliseconds. The default is 72 milliseconds.

You can configure the red differential delay for links in a bundle to give warning by including the `red-differential-delay` statements at the [edit interfaces *ls-fpc/pic/port:channel* mlfr-uni-nni-bundle-options] hierarchy level:

```
red-differential-delay milliseconds;
```

The red differential delay can be from 1 through 2000 milliseconds. The default is 120 milliseconds.

You can configure the action to be taken when differential delay exceeds the red limit by including the `action-red-differential-delay` `red` statements at the [edit interfaces *ls-fpc/pic/port:channel* mlfr-uni-nni-bundle-options] hierarchy level:

```
action-red-differential-delay (disable-tx | remove-link);
```

The `disable-tx` option disables transmission on the link. The `remove-link` option removes the link from the bundle. The default action is `remove-link`.

You can view these settings in the output of the `show interfaces extensive lsq-fpc/pic/port:channel` command.

Configuring Keepalives on Link Services Physical Interfaces

You can tune the keepalive settings on the physical link-services interface. By default, the JUNOS software uses ITU Q.933 Annex A LMIs for FRF.16. To use ITU Annex A LMIs, include the `lmi-type ansi` statement at the `[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]` hierarchy level:

```
lmi-type ansi;
```

To configure Frame Relay keepalive parameters on a link services interface, include the `n391`, `n392`, `n393`, `t391` and `t392` statements at the `[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]` hierarchy level:

```
[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]
n391 number;
n392 number;
n393 number;
t391 number;
t392 number;
```

The statements determine the indicated keepalive settings:

- **n391**—Full status polling interval. The data terminal equipment (DTE) sends a status inquiry to the data communication equipment (DCE) at the interval specified by the **t391** statement. This statement sets the frequency at which the DTE requests full status report; for example, the value **10** means that the DTE requests full status report in every tenth inquiry. The intermediate inquiries request a keepalive response only. The range is **1** through **255**, with a default of **6**.
- **n392**—Error threshold, which is the maximum number of errors that can occur during the number of events set by the **n393** statement before the link is marked inoperative. The range is **1** through **10**, with a default of **3**.
- **n393**—Monitored event count. The range is **1** through **10**, with a default of **4**.
- **t391**—The interval at which the DTE requests a keepalive response from the DCE and updates status, depending on the error threshold value. The range is **5** through **30** seconds, with a default of **10** seconds.
- **t392**—The period during which the DCE checks for keepalive responses from the DTE and updates status, depending on the DCE error threshold value. The range is from **5** through **30** seconds, with a default of **15** seconds.



NOTE: For the LMI to work properly, you must configure one side of a link services bundle to be a DCE.

Configuring CoS on Link Services Interfaces

For link services IQ (lsq-) interfaces, JUNOS class of service (CoS) is fully supported and functions as described in the *JUNOS Class of Service Configuration Guide*. For more information and detailed configuration examples, see “Link Services IQ Interfaces Configuration Guidelines” on page 319.

For link services (ls-) interfaces, CoS functions differently depending on whether the interface is configured on a Link Services PIM in a J-series Services Router or on a Link Services PIC in an M-series or T-series routing platform. See the following sections:

- CoS for Link Services Interfaces on J-series Services Routers on page 997
- CoS for Link Services Interfaces on M-series and T-series Routing Platforms on page 997
- Example: Configuring CoS on Link Services Interfaces on page 999

CoS for Link Services Interfaces on J-series Services Routers

Unlike M-series and T-series platforms, J-series Services Routers support per-bundle queuing on link services (ls) interfaces. Link services interfaces for J-series Services Routers behave the same way as link services IQ interfaces (lsq). (For more information, see “Link Services IQ Interfaces Configuration Guidelines” on page 319.) There are some exceptions, as follows:

- Queue 2 is reserved for voice traffic (LFI) on J-series Services Routers, while all other queues perform fragmentation.
- For FRF.15 on J-series Services Routers, the constituent links bundled on the link services interfaces (ls) require a single scheduler with 25 percent transmission rates and buffer sizes for queues 0 through 3. You should assign this scheduler to each constituent link—in other words, to E1 interfaces and T1 interfaces. However, you can configure customized scheduler maps for each associated ls-fpc/pic/port.logical interface.

For FRF.16 and MLPPP, link services (ls-) interfaces on the J-series Services Router work the same way as link services IQ (lsq-) interfaces on M-series platforms.

CoS for Link Services Interfaces on M-series and T-series Routing Platforms

For Link Services PIC interfaces (ls) on M-series and T-series platforms, queue 0 is the only queue that you should configure to receive fragmented packets. Configure all other queues to be higher-priority queues.

Table 20 on page 998 summarizes how CoS queues work on link services (ls) interfaces.

Table 20: Link Services CoS Queues

Supported Bundling Type	Queue 0	Higher-Priority Queues
Hash-based load balancing	No	Yes
MLFR FRF.15	Yes	No
MLFR FRF.16	Yes	No
MLPPP	Yes	No

For M-series and T-series platforms, CoS on link services (ls) interfaces works as follows:

- On all platforms, the Link Services PIC currently supports up to four queues: 0, 1, 2, and 3.
- Queue 0 uses MLFR FRF.15, MLFR FRF.16, or MLPPP to bundle packets.
- Higher-priority queues (1, 2, and 3) use hash-based load balancing to bundle packets. IP and MPLS header information is included in the hash.
- MLPPP packets traversing link services interfaces using queue 0 are fragmented and distributed across the constituent links. Queue 0 packets are sent on the least utilized link, proportional to its bandwidth. The queue 0 load balancer attempts to maintain even distribution of all traffic across all constituent links. In situations with a small number of high-priority traffic flows (queues 1, 2, and 3), queue 0 traffic might be unevenly distributed.
- For the MLFR FRF.16 protocol, only queue 0 works. If you configure a bundled interface to use MLFR FRF.16 with queue 0, then you must ensure the classifier does not send any traffic to queues 1, 2, and 3 on that interface.
- To carry high-priority traffic correctly on MLFR FRF.16 interfaces, you must configure an output firewall filter that forces all traffic into queue 0 on the *ls-fpc/pic/port.channel* interface.
- MLFR FRF.15 and MLPPP interfaces support CoS through packet interleaving. The MLFR FRF.16 standard does not support packet interleaving, so all packets destined for an FRF.16 PVC interface must egress from the same queue.
- For constituent link interfaces of Link Services PICs, you can configure standard scheduler maps.
- For input packets and fragments received from constituent links, you can use regular input firewall filters and standard CoS classifiers on the link services interface.
- For packets that pass through a link services interface and are destined for a constituent link interface, all traffic using queue 0 is fragmented. Traffic using higher-priority queues (1, 2, and 3) is not fragmented.
- For MLFR FRF.15 and MLPPP, routing protocol packets smaller than 128 bytes are sent to queue 3; routing protocol packets that exceed 128 bytes are sent to queue 0 and fragmented accordingly. For MLFR FRF.16, queue 0 is used for all packet sizes.

- You must configure output firewall classification for egress traffic on the link services interface, not directly on the constituent link interface directly.
- Inverse multiplexing for ATM (IMA) is not supported on link services interfaces.

For more information, see “Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces” on page 988 and the *JUNOS Policy Framework Configuration Guide*.

Example: Configuring CoS on Link Services Interfaces

Configure CoS on a link services interface and its constituent link interfaces.



NOTE: This example applies to M-series and T-series platforms. For examples that apply to a Link Services PIC installed on a J-series Services Router, see “Link Services IQ Interfaces Configuration Guidelines” on page 319.

Packets that do not match the firewall filters are sent to a queue that performs load balancing by sending fragments to all constituent links.

Packets that match the firewall filters are sent to a queue that does not support packet fragmentation and reassembly; instead, this traffic is load-balanced by sending each packet flow to a different constituent link. Each packet that matches a firewall filter is subjected to a hash on the IP source address and the IP destination address to determine the packet flow to which each packet belongs.

When you configure the MLPPP encapsulation type or the multilink FRF.15 Frame Relay end-to-end encapsulation type, routing protocol packets smaller than 128 bytes are sent to the network-control queue on the constituent link interface. This keeps routing protocols operating normally, even when low-speed links are congested by regular packets.

```
[edit interfaces]
ls-7/0/0 {
  unit 0 {
    encapsulation multilink-ppp;
    interleave-fragments;
    family inet {
      filter {
        output lfi_ls_filter;
      }
      address 10.54.0.2/32 {
        destination 10.54.0.1;
      }
    }
  }
}
ge-7/2/0 {
  unit 0 {
    family inet {
      address 192.168.1.1/24;
    }
  }
}
```

```

    }
  }
  ce1-7/3/6 {
    no-partition interface-type e1;
  }
  e1-7/3/6 {
    encapsulation ppp;
    unit 0 {
      family mlppp {
        bundle ls-7/0/0.0;
      }
    }
  }
  ce1-7/3/7 {
    no-partition interface-type e1;
  }
  e1-7/3/7 {
    encapsulation ppp;
    unit 0 {
      family mlppp {
        bundle ls-7/0/0.0;
      }
    }
  }
}
[edit class-of-service]
classifiers {
  dscp dscp_default {
    import default;
  }
  inet-precedence inet-precedence_default {
    import default;
  }
}
code-point-aliases {
  dscp {
    af11 001010;
    af12 001100;
    af13 001110;
    af21 010010;
    af22 010100;
    af23 010110;
    af31 011010;
    af32 011100;
    af33 011110;
    af41 100010;
    af42 100100;
    af43 100110;
    be 000000;
    cs1 001000;
    cs2 010000;
    cs3 011000;
    cs4 100000;
    cs5 101000;
    cs6 110000;
    cs7 111000;
    ef 101110;
  }
}

```



```

    }
    inet-precedence {
        af11 001;
        af21 010;
        af31 011;
        af41 100;
        be 000;
        cs6 110;
        cs7 111;
        ef 101;
        nc1 110;
        nc2 111;
    }
}
forwarding-classes {
    queue 0 be;
    queue 1 ef;
    queue 2 af;
    queue 3 nc;
}
interfaces {
    ge-7/2/0 {
        scheduler-map sched-map;
        unit 0 {
            classifiers {
                dscp dscp_default;
            }
        }
    }
    e1-7/3/6 {
        scheduler-map sched-map;
    }
    e1-7/3/7 {
        scheduler-map sched-map;
    }
    ls-7/0/0 {
        scheduler-map sched-map;
        unit 0 {
            classifiers {
                inet-precedence inet-precedence_default;
            }
        }
    }
}
scheduler-maps {
    sched-map {
        forwarding-class af scheduler af-scheduler;
        forwarding-class be scheduler be-scheduler;
        forwarding-class ef scheduler ef-scheduler;
        forwarding-class nc scheduler nc-scheduler;
    }
}
schedulers {
    af-scheduler {
        transmit-rate percent 25;
        buffer-size percent 25;
    }
}

```

```

    }
    be-scheduler {
        transmit-rate percent 25;
        buffer-size percent 25;
    }
    ef-scheduler {
        transmit-rate percent 25;
        buffer-size percent 25;
    }
    nc-scheduler {
        transmit-rate percent 25;
        buffer-size percent 25;
    }
}
[edit firewall]
filter lfi_ls_filter {
    term term0 {
        from {
            destination-address {
                192.168.1.3/32;
            }
            precedence 5;
        }
        then {
            count count-192-168-1-3;
            forwarding-class af;
            accept;
        }
    }
    term default {
        then {
            log;
            forwarding-class best effort;
            accept;
        }
    }
}
}

```

Examples: Configuring Multilink Interfaces

The examples in this section show the following configurations:

The examples in this section include only the configuration of multilink interfaces. For information about configuring the constituent interfaces, see the *JUNOS Network Interfaces Configuration Guide*.

- Example: Configuring a Multilink Interface with MLPPP on page 1003
- Example: Configuring a Multilink Interface with MLPPP over ATM 2 Interfaces on page 1003
- Configuring a Multilink Interface with MLFR FRF.15 on page 1005

Example: Configuring a Multilink Interface with MLPPP

```

[edit interfaces]
ml-1/0/0 {
  unit 1 {
    fragment-threshold 128;
    family inet {
      address 192.168.5.1/32 {
        destination 192.168.200.200;
      }
    }
  }
  unit 10 {
    family inet {
      address 10.1.1.3/32 {
        destination 10.1.1.2;
      }
    }
  }
}
t1-5/1/0 {
  unit 0 {
    family mlppp {
      bundle ml-1/0/0.1;
    }
  }
}
t1-5/1/1 {
  unit 0 {
    family mlppp {
      bundle ml-1/0/0.1;
    }
  }
}
t1-5/1/2 {
  unit 0 {
    family mlppp {
      bundle ml-1/0/0.1;
    }
  }
}
}

```

Example: Configuring a Multilink Interface with MLPPP over ATM 2 Interfaces

```

[edit interfaces]
at-0/0/0 {
  atm-options {
    pic-type atm2;
    vpi 10;
  }
  unit 0 {
    encapsulation atm-mlppp-llc;
    ppp-options {
      chap {

```

```

        access-profile pe-B-ppp-clients;
        local-name "pe-A-at-0/0/0";
    }
}
keepalive interval 5 up-count 6 down-count 4;
vci 10.120;
family mlppp {
    bundle ls-0/3/0.0;
}
}
}
at-0/0/1 {
    atm-options {
        pic-type atm2;
        vpi 11;
    }
    unit 1 {
        encapsulation atm-mlppp-llc;
        ppp-options {
            chap {
                access-profile pe-B-ppp-clients;
                local-name " pe-A-at-0/0/0";
            }
        }
        keepalive interval 5 up-count 6 down-count 4;
        vci 11.120;
        family mlppp {
            bundle ls-0/3/0.0;
        }
    }
}
}
at-1/2/3 {
    atm-options {
        pic-type atm2;
        vpi 12;
    }
    unit 2 {
        encapsulation atm-mlppp-llc;
        ppp-options {
            chap {
                access-profile pe-B-ppp-clients;
                local-name " pe-A-at-0/0/0";
            }
        }
        keepalive interval 5 up-count 6 down-count 4;
        vci 12.120;
        family mlppp {
            bundle ls-0/3/0.0;
        }
    }
}
}
...
ls-0/3/0 {
    encapsulation multilink-ppp;
    interleave-fragments;
    keepalive;
}

```

```

unit 0 {
    mrru 4500;
    short-sequence;
    fragment-threshold 16320;
    drop-timeout 2000;
    encapsulation multilink-ppp;
    interleave-fragments;
    minimum-links 8;
    family inet {
        address 10.10.0.1/32 {
            destination 10.10.0.2;
        }
    }
    family iso;
    family inet6 {
        address 2001:DB8:0:1/32 {
            destination 2001:DB8:0:2;
        }
    }
}
...
}

```

Configuring a Multilink Interface with MLFR FRF.15

```

[edit interfaces]
ml-1/0/0 {
    unit 1 {
        encapsulation multilink-frame-relay-end-to-end;
        family inet {
            address 192.168.5.2/32 {
                destination 192.168.5.3;
            }
        }
    }
    unit 10 {
        encapsulation multilink-frame-relay-end-to-end;
        family inet {
            address 10.1.1.3/32 {
                destination 10.1.1.2;
            }
        }
    }
}
t1-5/1/0 {
    unit 0 {
        dlci 16;
        encapsulation multilink-frame-relay-end-to-end;
        family mlfr-end-to-end {
            bundle ml-1/0/0.1;
        }
    }
}
t1-5/1/1 {
    unit 0 {

```

```

        dlc1 17;
        encapsulation multilink-frame-relay-end-to-end;
        family mlfr-end-to-end {
            bundle ml-1/0/0.10;
        }
    }
}
t1-5/1/2 {
    unit 0 {
        dlc1 26;
        encapsulation multilink-frame-relay-end-to-end;
        family mlfr-end-to-end {
            bundle ml-1/0/0.10;
        }
    }
}
}

```

Examples: Configuring Link Interfaces

The examples in this section include only the configuration of link interfaces. For information about configuring the constituent interfaces, see the *JUNOS Network Interfaces Configuration Guide*.

Example: Configuring a Link Services Interface with Two Links

This example uses the MLFR UNI NNI protocol between Router A and Router B and logically connects link services bundles `ls-1/1/0.3` and `ls-0/0/0.10`, as specified in Table 21 on page 1006.

Table 21: Link Services Bundle

Router A	Router B
t1-0/1/0 (ls-1/1/0:3)	t1-0/3/0 (ls-0/0/0:10)
t1-0/1/1 (ls-1/1/0:3)	t1-0/3/1 (ls-0/0/0:10)

For LMI to work properly, you must configure one router to be a DCE.

Configuration on Router A

```

[edit interfaces]
ls-1/1/0:3 {
    dce;
    encapsulation multilink-frame-relay-uni-nni;
    unit 0 {
        dlc1 16;
        family inet {
            address 10.3.3.1/32 {
                destination 10.3.3.2;
            }
        }
    }
}
}

```

```

t1-0/1/0 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle ls-1/1/0:3;
    }
  }
}
t1-0/1/1 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle ls-1/1/0:3;
    }
  }
}

```

Configuration on Router B

```

[edit interfaces]
ls-0/0/0:10 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    dlci 16;
    family inet {
      address 10.3.3.2/32 {
        destination 10.3.3.1;
      }
    }
  }
}
t1-0/3/0 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle ls-0/0/0:10;
    }
  }
}
t1-0/3/1 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle ls-0/0/0:10;
    }
  }
}

```

Example: Configuring a Link Services Interface with MLPPP

```

[edit interfaces]
t1-0/0/0 {
  encapsulation ppp;
  unit 0 {
    family mlppp {
      bundle ls-0/3/0.0;
    }
  }
}

```

```

    }
  }
}
t1-0/0/1 {
  encapsulation ppp;
  unit 0 {
    family mlppp {
      bundle ls-0/3/0.0;
    }
  }
}
ls-0/3/0 {
  unit 0 {
    encapsulation multilink-ppp;
    family inet {
      address 10.16.1.2/32 {
        destination 10.16.1.1;
      }
    }
    family iso;
    family inet6 {
      address 2001:DB8:1:2/126;
    }
  }
}
}

```

Example: Configuring a Link Services Interface with MLFR FRF.15

```

[edit interfaces]
t1-0/0/0 {
  encapsulation frame-relay;
  unit 0 {
    dlci 16;
    family mlfr-end-to-end {
      bundle ls-0/3/0.0;
    }
  }
}
t1-0/0/1 {
  encapsulation frame-relay;
  unit 0 {
    dlci 16;
    family mlfr-end-to-end {
      bundle ls-0/3/0.0;
    }
  }
}
ls-0/3/0 {
  unit 0 {
    encapsulation multilink-frame-relay-end-to-end;
    family inet {
      address 10.16.1.2/32 {
        destination 10.16.1.1;
      }
    }
  }
}

```



```

        family iso;
        family inet6 {
            address 2001:DB8:1:2/12;
        }
    }
}

```

Example: Configuring a Link Services PIC with MLFR FRF.16

```

[edit chassis]
fpc 1 {
    pic 2 {
        mlfr-uni-nni-bundles 5;
    }
}
[edit interfaces]
t1-0/0/0 {
    encapsulation multilink-frame-relay-uni-nni;
    unit 0 {
        family mlfr-uni-nni {
            bundle ls-1/2/0:0;
        }
    }
}
t1-0/0/1 {
    encapsulation multilink-frame-relay-uni-nni;
    unit 0 {
        family mlfr-uni-nni {
            bundle ls-1/2/0:0;
        }
    }
}
ls-1/2/0:0 {
    dce;
    encapsulation multilink-frame-relay-uni-nni;
    unit 0 {
        dlci 26;
        family inet {
            address 10.26.1.1/32 {
                destination 10.26.1.2;
            }
        }
    }
}
}

```

Example: Configuring Link and Voice Services Interfaces with a Combination of Bundle Types

```

[edit chassis]
fpc 1 {
    pic 3 {
        mlfr-uni-nni-bundles 4;
    }
}

```

```

[edit interfaces]
t1-0/2/0:0 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle ls-1/3/0:0;
    }
  }
}
t1-0/2/0:1 {
  encapsulation multilink-frame-relay-uni-nni;
  unit 0 {
    family mlfr-uni-nni {
      bundle ls-1/3/0:0;
    }
  }
}
t1-0/2/0:5 {
  unit 0 {
    family mlppp {
      bundle ls-1/3/0:2;
    }
  }
}
t1-0/2/0:6 {
  unit 0 {
    family mlppp {
      bundle ls-1/3/0:2;
    }
  }
}
t1-0/2/0:7 {
  encapsulation frame-relay;
  unit 0 {
    dlci 20;
    family mlfr-end-to-end {
      bundle ls-1/3/0:1;
    }
  }
}
t1-0/2/0:8 {
  encapsulation frame-relay;
  unit 0 {
    dlci 20;
    family mlfr-end-to-end {
      bundle ls-1/3/0:1;
    }
  }
}
t1-0/2/0:10 {
  no-keepalives;
  encapsulation ppp;
  unit 0 {
    family mlppp {
      bundle lsq-1/1/0:0;
    }
  }
}

```

```

    }
  }
  t3-1/0/0 {
    no-keepalives;
    encapsulation ppp;
    unit 0 {
      family mlppp {
        bundle lsq-1/1/0.2;
      }
    }
  }
  lsq-1/1/0 {
    unit 0 {
      encapsulation multilink-ppp;
      compression {
        rtp {
          f-max-period 100;
          queues [ q1 q2 ];
          port minimum 2000 maximum 6000;
        }
      }
      family inet {
        address 10.5.5.5/24;
      }
    }
    unit 1 {
      encapsulation multilink-ppp;
      compression {
        rtp {
          port minimum 2000 maximum 6000;
        }
      }
      family inet {
        address 10.6.6.1/24;
      }
    }
    unit 2 {
      encapsulation multilink-ppp;
      compression {
        rtp {
          port minimum 2000 maximum 6000;
        }
      }
      family inet {
        address 10.9.9.1/24;
      }
    }
  }
  t1-1/2/0 {
    no-keepalives;
    unit 0 {
      family mlppp {
        bundle lsq-1/1/0.1;
      }
    }
  }
}

```

```

ls-1/3/0 {
  unit 1 {
    encapsulation multilink-frame-relay-end-to-end;
    family inet {
      address 10.1.4.1/24;
    }
  }
  unit 2 {
    encapsulation multilink-ppp;
    family inet {
      address 10.7.4.1/24;
    }
  }
}
ls-1/3/0:0 {
  encapsulation multilink-frame-relay-uni-nni;
  mlfr-uni-nni-bundle-options {
    debug-flags 15;
  }
  unit 0 {
    dlci 20;
    family inet {
      address 10.5.4.1/24;
    }
  }
}
[edit routing-options]
static {
  route 10.12.12.0/24 next-hop 10.1.1.9;
}

```

On Router B:

```

[edit chassis]
fpc 1 {
  pic 3 {
    mlfr-uni-nni-bundles 4;
  }
}
[edit interfaces]
ge-0/0/0 {
  unit 0 {
    family inet {
      address 10.1.1.1/24;
    }
  }
}
so-0/1/1 {
  encapsulation ppp;
  unit 0 {
    family inet {
      address 10.7.7.7/24;
    }
  }
}
t1-0/2/0:0 {

```

```

encapsulation multilink-frame-relay-uni-nni;
unit 0 {
    family mlfr-uni-nni {
        bundle ls-1/3/0:0;
    }
}
t1-0/2/0:1 {
    encapsulation multilink-frame-relay-uni-nni;
    unit 0 {
        family mlfr-uni-nni {
            bundle ls-1/3/0:0;
        }
    }
}
t1-0/2/0:5 {
    no-keepalives;
    unit 0 {
        family mlppp {
            bundle ls-1/3/0:2;
        }
    }
}
t1-0/2/0:6 {
    no-keepalives;
    unit 0 {
        family mlppp {
            bundle ls-1/3/0:2;
        }
    }
}
t1-0/2/0:7 {
    dce;
    encapsulation frame-relay;
    unit 0 {
        dlci 20;
        family mlfr-end-to-end {
            bundle ls-1/3/0:1;
        }
    }
}
t1-0/2/0:8 {
    dce;
    encapsulation frame-relay;
    unit 0 {
        dlci 20;
        family mlfr-end-to-end {
            bundle ls-1/3/0:1;
        }
    }
}
t1-0/2/0:10 {
    no-keepalives;
    encapsulation ppp;
    unit 0 {
        family mlppp {

```

```

        bundle lsq-1/1/0.0;
    }
}
t3-0/3/0 {
    no-keepalives;
    encapsulation ppp;
    unit 0 {
        family mlppp {
            bundle lsq-1/1/0.2;
        }
    }
}
ge-1/0/0 {
    unit 0 {
        family inet {
            address 10.2.2.1/24;
        }
    }
}
lsq-1/1/0 {
    unit 0 {
        compression {
            rtp {
                port minimum 2000 maximum 6000;
            }
        }
        family inet {
            address 10.5.5.1/24;
        }
    }
    unit 1 {
        encapsulation multilink-ppp;
        compression {
            rtp {
                port minimum 16384 maximum 20102;
            }
        }
        family inet {
            address 10.3.4.1/24;
        }
    }
    unit 2 {
        encapsulation multilink-ppp;
        compression {
            rtp {
                port minimum 2000 maximum 6000;
            }
        }
        family inet {
            address 10.9.9.9/24;
        }
    }
}
t1-1/2/2 {
    no-keepalives;

```

```

    unit 0 {
        family mlppp {
            bundle ls-1/3/0.1;
        }
    }
}
t1-1/2/3 {
    no-keepalives;
    unit 0 {
        family mlppp {
            bundle lsq-1/1/0.1;
        }
    }
}
ls-1/3/0 {
    unit 1 {
        encapsulation multilink-frame-relay-end-to-end;
        family inet {
            address 10.1.4.4/24;
        }
        family iso;
    }
    unit 2 {
        encapsulation multilink-ppp;
        family inet {
            address 10.7.4.4/24;
        }
    }
}
ls-1/3/0:0 {
    dce;
    encapsulation multilink-frame-relay-uni-nni;
    unit 0 {
        dlci 20;
        family inet {
            address 10.5.4.4/24;
        }
    }
}
[edit routing-options]
static {
    route 10.12.12.0/24 next-hop 10.3.4.4;
}

```


Chapter 55

Summary of Multilink and Link Services Configuration Statements

The following sections explain each of the multilink and link services statements. The statements are organized alphabetically.

acknowledge-retries

Syntax	<code>acknowledge-retries <i>number</i>;</code>
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, configure the number of retransmission attempts to be made for consecutive hello or remove link messages following the expiration of the acknowledgment timer.
Options	<i>number</i> —Number of retransmission attempts to be made following the expiration of the acknowledgment timer. Range: 1 through 5 Default: 2
Usage Guidelines	See “Configuring Acknowledgment Timers on Link Services Physical Interfaces” on page 994.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	action-red-differential-delay, hello-timer

acknowledge-timer

Syntax	<code>acknowledge-timer <i>milliseconds</i>;</code>
Hierarchy Level	<code>[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, configure the maximum time, in milliseconds, to wait for an add link acknowledgment, hello acknowledgment, or remove link acknowledgment message.
Options	<p><i>milliseconds</i>—Time to wait for an add link acknowledgment, hello acknowledgment, or remove link acknowledgment message.</p> <p>Range: 1 through 10 milliseconds</p> <p>Default: 4 milliseconds</p>
Usage Guidelines	See “Configuring Acknowledgment Timers on Link Services Physical Interfaces” on page 994.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	address, hello-timer

action-red-differential-delay

Syntax	<code>action-red-differential-delay (disable-tx remove-link);</code>
Hierarchy Level	<code>[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, configure the action to be taken when the differential delay exceeds the red limit.
Options	<p>disable-tx—Disable transmission on the bundle link.</p> <p>remove-link—Remove the bundle link from service.</p> <p>Default: remove-link</p>
Usage Guidelines	See “Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16” on page 995.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	yellow-differential-delay

address

Syntax	<code>address <i>address</i> { destination <i>address</i>; }</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the interface address.
Options	<i>address</i> —Address of the interface. The remaining statements are explained separately.
Usage Guidelines	See “Configuring the Links in a Multilink or Link Services Bundle” on page 978; for a general discussion of address statement options, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other statements that do not affect services interfaces.

bundle

Syntax	<code>bundle (<i>ml-fpc/pic/port</i> <i>ls-fpc/pic/port</i>);</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family mlfr-end-to-end], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family mlfr-uni-nni]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Associate the multilink interface with the logical interface it is joining.
Options	<i>ml-fpc/pic/port</i> —Name of the multilink interface you are linking. <i>ls-fpc/pic/port</i> —Name of the link services interface you are linking.
Usage Guidelines	See “Configuring the Links in a Multilink or Link Services Bundle” on page 978.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

compression-device

Syntax	compression-device <i>name</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For J-series Services Routers with PPP over Ethernet interfaces, configure the name of the access concentrator (AC).
Options	<i>name</i> —Name of the AC.
Usage Guidelines	See “Configuring Compressed RTP on J-series Services Routers” on page 990.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>J-series Services Router Advanced WAN Access Configuration Guide</i>

destination

Syntax	destination <i>destination-address</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i> address <i>address</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i> address <i>address</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For point-to-point interfaces only, specify the address of the interface at the remote end of the connection.
Options	<i>destination-address</i> —Address of the remote side of the connection.
Usage Guidelines	See “Multilink and Link Services Logical Interface Configuration Overview” on page 979.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

disable-mlppp-inner-ppp-pfc

Syntax	disable-mlppp-inner-ppp-pfc;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	For MLPPP interfaces only, disable compression of the inner PPP header in the MLPPP payload. By default, compression is enabled.
Usage Guidelines	See “Configuring the Drop Timeout Period on Multilink and Link Services Logical Interfaces” on page 982.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

dlci

Syntax	dlci <i>dlci-identifier</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For Frame Relay and Multilink Frame Relay user-to-network interface (UNI) network-to-network interface (NNI) encapsulation only, and for link services and point-to-point interfaces only, configure the data-link connection identifier (DLCI) for a permanent virtual circuit (PVC) or a switched virtual circuit (SVC). To configure a DLCI for a point-to-multipoint interface, use the <i>multipoint-destination</i> statement to specify the DLCI.
Options	<i>dlci-identifier</i> —Data-link connection identifier. Range: 16 through 1022
Usage Guidelines	See “Configuring DLCIs on Link Services Logical Interfaces” on page 986; for general information about Frame Relay DLCIs, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

drop-timeout

Syntax	<code>drop-timeout <i>milliseconds</i>;</code>
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options], [edit interfaces (<i>ls-fpc/pic/port</i> <i>ml-fpc/pic/port</i>) unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options], [edit logical-systems <i>logical-system-name</i> interfaces (<i>ls-fpc/pic/port</i> <i>ml-fpc/pic/port</i>) unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For multilink and link services interfaces only, configure the drop timeout period, in milliseconds.
Options	<i>milliseconds</i> —Drop timeout period. Range: 1 through 2000 milliseconds Default: 500 ms for bundles greater than or equal to the T1 bandwidth value, and 1500 ms for other bundles. Any CLI-configured value overrides these defaults. Setting a value of 0 reverts to the default.
Usage Guidelines	See “Configuring the Drop Timeout Period on Multilink and Link Services Logical Interfaces” on page 982.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

encapsulation

See the following sections:

- encapsulation (Logical Interface) on page 1023
- encapsulation (Physical Interface) on page 1024

encapsulation (Logical Interface)

Syntax	encapsulation (atm-mlppp-llc multilink-frame-relay-end-to-end multilink-ppp ...);
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Logical link-layer encapsulation type.
Options	<p>atm-mlppp-llc—For ATM 2 interfaces, use Multilink Point-to-Point Protocol (MLPPP) over ATM Adaptation Layer 5 (AAL5) logical link control (LLC) encapsulation, as described in RFC 2364, <i>PPP over AAL5</i>.</p> <p>multilink-frame-relay-end-to-end—Use Multilink Frame Relay (MLFR) FRF.15 encapsulation. This encapsulation is used only on multilink and link services interfaces and their constituent T1 or E1 interfaces.</p> <p>multilink-ppp—Use MLPPP encapsulation. This encapsulation is used only on multilink and link services interfaces and their constituent T1 or E1 interfaces.</p>
Usage Guidelines	See “Configuring Encapsulation for Multilink and Link Services Logical Interfaces” on page 981; for information about encapsulation statement options used with other interface types, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

encapsulation (Physical Interface)

Syntax	encapsulation (multilink-frame-relay-uni-nni ...);
Hierarchy Level	[edit interfaces <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Physical link-layer encapsulation type.
Default	MLFR UNI NNI encapsulation (on link services interfaces).
Options	multilink-frame-relay-uni-nni—Use MLFR UNI NNI encapsulation. This encapsulation is used only on link services interfaces functioning as FRF.16 bundles and their constituent T1 or E1 interfaces.
Usage Guidelines	See “Configuring Encapsulation for Link Services Physical Interfaces” on page 994; for information about encapsulation statement options used with other interface types, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

family

Syntax	<pre>family family { address address { destination address; } }</pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure protocol family information for the logical interface.
Options	<p><i>family</i>—Protocol family:</p> <ul style="list-style-type: none"> ■ <i>ccc</i>—Circuit cross-connect protocol suite ■ <i>inet</i>—IP version 4 (IPv4) ■ <i>inet6</i>—IP version 6 (IPv6) ■ <i>iso</i>—Open Systems Interconnection (OSI) International Organization for Standardization (ISO) protocol suite ■ <i>mlfr-end-to-end</i>—Multilink Frame Relay FRF.15 ■ <i>mlfr-uni-nni</i>—Multilink Frame Relay FRF.16 ■ <i>multilink-ppp</i>—Multilink Point-to-Point Protocol ■ <i>mpls</i>—MPLS ■ <i>tcc</i>—Translational cross-connect protocol suite ■ <i>tnp</i>—Trivial Network Protocol ■ <i>vpls</i>—Virtual private LAN service <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Link and Multilink Services Configuration Guidelines” on page 975; for a general discussion of <i>family</i> statement options, see the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other statements that do not affect services interfaces.

fragment-threshold

Syntax	fragment-threshold <i>bytes</i> ;
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options], [edit interfaces (<i>ls-fpc/pic/port</i> <i>ml-fpc/pic/port</i>) unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options], [edit logical-systems <i>logical-system-name</i> interfaces (<i>ls-fpc/pic/port</i> <i>ml-fpc/pic/port</i>) unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For multilink and link services interfaces only, set the fragmentation threshold, in bytes.
Options	<i>bytes</i> —Maximum size, in bytes, for multilink packet fragments. Any nonzero value must be a multiple of 64 bytes. Range: 128 through 16,320 bytes Default: 0 bytes (no fragmentation)
Usage Guidelines	See “Limiting Packet Payload Size on Multilink and Link Services Logical Interfaces” on page 983.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

hello-timer

Syntax	hello-timer <i>milliseconds</i> ;
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, configure the rate at which hello messages are sent. A hello message is transmitted after a period defined in milliseconds has elapsed.
Options	<i>milliseconds</i> —The rate at which hello messages are sent. Range: 1 through 180 milliseconds Default: 10 milliseconds
Usage Guidelines	See “Configuring Acknowledgment Timers on Link Services Physical Interfaces” on page 994.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	address, acknowledge-timer

interfaces

Syntax	interfaces { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure interfaces on the router.
Default	The management and internal Ethernet interfaces are automatically configured. You must configure all other interfaces.
Usage Guidelines	See the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

interleave-fragments

Syntax	interleave-fragments;
Hierarchy Level	[edit interfaces ls-fpc/pic/port:channel unit logical-unit-number], [edit logical-systems logical-system-name interfaces ls-fpc/pic/portunit logical-unit-number]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services and voice services interfaces only, interleave long packets with high-priority packets. Allows small delay-sensitive packets, such as voice over IP (VoIP) packets, to interleave with long fragmented packets. This minimizes the latency of delay-sensitive packets.
Usage Guidelines	See “Configuring Delay-Sensitive Packet Interleaving on Link Services Logical Interfaces” on page 988.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

Imi-type

Syntax	<code>Imi-type (ansi itu);</code>
Hierarchy Level	<code>[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the Frame Relay Local Management Interface (LMI) type.
Options	<p><code>ansi</code>—Use American National Standards Institute (ANSI) T1.167 Annex D LMIs.</p> <p><code>itu</code>—Use ITU Q933 Annex A LMIs.</p> <p>Default: <code>itu</code></p>
Usage Guidelines	See “Configuring Keepalives on Link Services Physical Interfaces” on page 996.
Required Privilege Level	<p><code>interface</code>—To view this statement in the configuration.</p> <p><code>interface-control</code>—To add this statement to the configuration.</p>

minimum-links

Syntax	<code>minimum-links number;</code>
Hierarchy Level	<p><code>[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options],</code> <code>[edit interfaces (ls-fpc/pic/port ml-fpc/pic/port) unit logical-unit-number],</code> <code>[edit logical-systems logical-system-name interfaces ls-fpc/pic/port:channel</code> <code>mlfr-uni-nni-bundle-options],</code> <code>[edit logical-systems logical-system-name interfaces (ls-fpc/pic/port ml-fpc/pic/port)</code> <code>unit logical-unit-number]</code></p>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>For multilink or link services interfaces only, set the minimum number of links that must be up for the bundle to be labeled up. A member link is considered up when the PPP Link Control Protocol (LCP) phase transitions to open state.</p> <p>The <code>minimum-links</code> value should be identical on both ends of the bundle.</p>
Options	<p><code>number</code>—Number of links.</p> <p>Range: 1 through 8</p> <p>Default: 1</p>
Usage Guidelines	See “Configuring the Minimum Number of Active Links on Multilink and Link Services Logical Interfaces” on page 984.
Required Privilege Level	<p><code>interface</code>—To view this statement in the configuration.</p> <p><code>interface-control</code>—To add this statement to the configuration.</p>

mlfr-uni-nni-bundle-options

Syntax mlfr-uni-nni-bundle-options {
 acknowledge-retries *number*;
 acknowledge-timer *milliseconds*;
 action-red-differential-delay (disable-tx | remove-link);
 cisco-interoperability send-lip-remove-link-for-link-reject;
 drop-timeout *milliseconds*;
 fragment-threshold *bytes*;
 hello-timer *milliseconds*;
 lmi-type (ansi | itu);
 minimum-links *number*;
 mrru *bytes*;
 n391 *number*;
 n392 *number*;
 n393 *number*;
 red-differential-delay *milliseconds*;
 t391 *number*;
 t392 *number*;
 yellow-differential-delay *milliseconds*;
 }

Hierarchy Level [edit interfaces *ls-fpc/pic/port* :*channel*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure link services interface management properties.

The statements are explained separately.

Usage Guidelines See “Configuring Encapsulation for Link Services Physical Interfaces” on page 994.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

mrru

Syntax	<code>mrru bytes;</code>
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options], [edit interfaces (<i>ml-fpc/pic/port</i> <i>ls-fpc/pic/port</i>) unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options], [edit logical-systems <i>logical-system-name</i> interfaces (<i>ml-fpc/pic/port</i> <i>ls-fpc/pic/port</i>) unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For multilink or link services interfaces only, set the maximum received reconstructed unit (MRRU). The MRRU is similar to the maximum transmission unit (MTU), but is specific to multilink interfaces.
Options	<i>bytes</i> —MRRU size. Range: 1500 through 4500 bytes Default: 1500 bytes
Usage Guidelines	See “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

mtu

Syntax	mtu <i>bytes</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i>], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Maximum transmission unit (MTU) size for the media or protocol. The default MTU size depends on the device type. Not all devices allow you to set an MTU value, and some devices have restrictions on the range of allowable MTU values.
Options	<i>bytes</i> —MTU size. Range: 0 through 5012 bytes Default: 1500 bytes (inet, inet6, and iso families), 1448 bytes (mpls)
Usage Guidelines	See “Configuring MRRU on Multilink and Link Services Logical Interfaces” on page 985.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i>

multicast-dlci

Syntax	multicast-dlci <i>dlci-identifier</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For point-to-multipoint link services interfaces only, enable multicast support on the interface. You can configure multicast support on the interface if the Frame Relay switch performs multicast replication.
Options	<i>dlci-identifier</i> —DLCI identifier, a number from 16 through 1022 that defines the Frame Relay DLCI over which the switch expects to receive multicast packets for replication.
Usage Guidelines	See “Configuring Multicast-Capable DLCIs for MLFR FRF.16 Bundles” on page 987.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

n391

Syntax	<code>n391 number;</code>
Hierarchy Level	<code>[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, set the Frame Relay full status polling interval.
Options	<i>number</i> —Polling interval. Range: 1 through 255 Default: 6
Usage Guidelines	See “Configuring Keepalives on Link Services Physical Interfaces” on page 996.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	n392, n393, t391, and t392

n392

Syntax	<code>n392 number;</code>
Hierarchy Level	<code>[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, set the Frame Relay error threshold, in number of errors.
Options	<i>number</i> —Error threshold. Range: 1 through 10 Default: 3
Usage Guidelines	See “Configuring Keepalives on Link Services Physical Interfaces” on page 996.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	n391, n393, t391, and t392

n393

Syntax	<code>n393 number;</code>
Hierarchy Level	<code>[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, set the Frame Relay monitored event count.
Options	<i>number</i> —Event count. Range: 1 through 255 Default: 6
Usage Guidelines	See “Configuring Keepalives on Link Services Physical Interfaces” on page 996.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	n391, n392, t391, and t392

red-differential-delay

Syntax	<code>red-differential-delay milliseconds;</code>
Hierarchy Level	<code>[edit interfaces ls-fpc/pic/port:channel mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, configure the red differential delay among bundle links to give warning when a link has a differential delay that exceeds the configured threshold.
Options	<i>milliseconds</i> —Red differential delay threshold. Range: 1 through 2000 milliseconds Default: 120 milliseconds
Usage Guidelines	See “Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16” on page 995.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	action-red-differential-delay, yellow-differential-delay

short-sequence

Syntax	short-sequence;
Hierarchy Level	[edit interfaces (<i>ls-fpc/pic/port</i> <i>ml-fpc/pic/port</i>) unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces (<i>ls-fpc/pic/port</i> <i>ml-fpc/pic/port</i>) unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For multilink interfaces only, set the length of the packet sequence identification number to 12 bits.
Default	If not included in the configuration, the length is set to 24 bits.
Usage Guidelines	See “Configuring the Sequence Header Format on Multilink and Link Services Logical Interfaces” on page 986.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

t391

Syntax	t391 <i>number</i> ;
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, set the Frame Relay link integrity polling interval.
Options	<i>number</i> —Link integrity polling interval. Range: 5 through 30 seconds Default: 10 seconds
Usage Guidelines	See “Configuring Keepalives on Link Services Physical Interfaces” on page 996.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	n391, n392, n393, and t392

t392

Syntax	<code>t392 number;</code>
Hierarchy Level	[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, set the Frame Relay polling verification interval.
Options	<i>number</i> —Polling verification interval. Range: 5 through 30 seconds Default: 15 seconds
Usage Guidelines	See “Configuring Keepalives on Link Services Physical Interfaces” on page 996.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	n391, n392, n393, and t391

unit

Syntax unit *logical-unit-number* {
 disable-mlppp-inner-ppp-pfc;
 dlci *dlci-identifier*;
 drop-timeout *milliseconds*;
 encapsulation *type*;
 fragment-threshold *bytes*;
 interleave-fragments;
 minimum-links *number*;
 mrru *bytes*;
 multicast-dlci *dlci-identifier*;
 short-sequence;
 family *family* {
 address *address* {
 destination *address*;
 }
 bundle (ml-fpc/pic/port | ls-fpc/pic/port);
 }

Hierarchy Level [edit interfaces *interface-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.

Options *logical-unit-number*—Number of the logical unit.
 Range: 0 through 16,384

The remaining statements are explained separately.

Usage Guidelines See “Link and Multilink Services Configuration Guidelines” on page 975; for a general discussion of logical interface properties, see the *JUNOS Network Interfaces Configuration Guide* .

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics *JUNOS Network Interfaces Configuration Guide* for other statements that do not affect services interfaces.

yellow-differential-delay

Syntax	<code>yellow-differential-delay <i>milliseconds</i>;</code>
Hierarchy Level	<code>[edit interfaces <i>ls-fpc/pic/port:channel</i> mlfr-uni-nni-bundle-options]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services interfaces only, configure the yellow differential delay among bundle links to give warning when a link has a differential delay that exceeds the configured threshold.
Options	<i>milliseconds</i> —Yellow differential delay threshold. Range: 1 through 2000 milliseconds Default: 72 milliseconds
Usage Guidelines	See “Configuring Differential Delay Alarms on Link Services Physical Interfaces with MLFR FRF.16” on page 995.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<code>action-red-differential-delay</code> , <code>red-differential-delay</code>

Part 8

Real-Time Performance Monitoring Services

- Real-Time Performance Monitoring Services Overview on page 1041
- Real-Time Performance Monitoring Configuration Guidelines on page 1043
- Summary of Real-Time Performance Monitoring Configuration Statements on page 1061

Chapter 56

Real-Time Performance Monitoring Services Overview

Real-Time Performance Monitoring (RPM) enables you to configure active probes to track and monitor traffic. Probes collect packets per destination and per application, including PING Internet Control Message Protocol (ICMP) packets, User Datagram Protocol and Transmission Control Protocol (UDP/TCP) packets with user-configured ports, user-configured Differentiated Services code point (DSCP) type-of-service (ToS) packets, and Hypertext Transfer Protocol (HTTP) packets. RPM provides Management Information Base (MIB) support with extensions for RFC 2925, *Definitions of Managed Objects for Remote Ping, Traceroute, and Lookup Operations*.

You can also configure RPM services to determine automatically whether a path exists between a host router and its configured BGP neighbors. You can view the results of the discovery using an SNMP client. Results are stored in `pingResultsTable`, `jnxPingResultsTable`, `jnxPingProbeHistoryTable`, and `pingProbeHistoryTable`.

Probe configuration and probe results are supported by the command-line interface (CLI) and SNMP.

The following probe types are supported with DSCP marking:

- ICMP echo
- ICMP timestamp
- HTTP get (not available for BGP RPM services)
- UDP echo
- TCP connection
- UDP timestamp

With probes, you can monitor the following:

- Minimum round-trip time
- Maximum round-trip time
- Average round-trip time
- Standard deviation of the round-trip time
- Jitter of the round-trip time—The difference between the minimum and maximum round-trip time

One-way measurements for ICMP timestamp probes include the following:

- Minimum, maximum, standard deviation, and jitter measurements for egress and ingress times
- Number of probes sent
- Number of probe responses received
- Percentage of lost probes

You can configure the following RPM thresholds:

- Round-trip time
- Ingress/egress delay
- Standard deviation
- Jitter
- Successive lost probes
- Total lost probes (per test)

Support is also implemented for user-configured CoS classifiers and for prioritization of RPM packets over regular data packets received on an input interface.

Chapter 57

Real-Time Performance Monitoring Configuration Guidelines

To configure Real-Time Performance Monitoring (RPM) services, include the `rpm` statement at the `[edit services]` hierarchy level:

```
[edit services]
rpm {
  bgp {
    data-fill data;
    data-size size;
    destination-port port;
    history-size size;
    logical-system logical-system-name [routing-instances routing-instance-name];
    probe-count count;
    probe-interval seconds;
    probe-type type;
    routing-instances instance-name;
    test-interval interval;
  }
  probe owner {
    test test-name {
      data-fill data;
      data-size size;
      destination-interface interface-name;
      destination-port port;
      dscp-code-point dscp-bits;
      hardware-timestamp;
      history-size size;
      moving-average-size number;
      one-way-hardware-timestamp;
      probe-count count;
      probe-interval seconds;
      probe-type type;
      routing-instance instance-name;
      source-address address;
      target (url url | address address);
      test-interval interval;
      thresholds thresholds;
      traps traps;
    }
  }
  probe-server {
```

```

    tcp {
        destination-interface interface-name;
        port (RPM) number;
    }
    udp {
        destination-interface interface-name;
        port (RPM) number;
    }
}
probe-limit limit;
twamp {
    server {
        authentication-mode (authenticated | encrypted | none);
        client-list list-name {
            [ address address ];
        }
        inactivity-timeout seconds;
        maximum-connections count;
        maximum-connections-per-client count;
        maximum-sessions count;
        maximum-sessions-per-connection count;
        port number;
    }
}
}

```



NOTE: RPM does not require an Adaptive Services (AS) or MultiServices PIC or MultiServices Dense Port Concentrator (DPC) unless you are configuring RPM timestamping as described in “Configuring RPM Timestamping” on page 1052.

This chapter includes the following sections:

- Configuring BGP Neighbor Discovery Through RPM on page 1044
- Configuring Real-Time Performance Monitoring on page 1046
- Examples: Configuring BGP Neighbor Discovery Through RPM on page 1056
- Examples: Configuring Real-Time Performance Monitoring on page 1057

Configuring BGP Neighbor Discovery Through RPM

BGP neighbors can be configured at the following hierarchy levels:

- [edit protocols bgp group *group-name*]—Default logical system and default routing instance.
- [edit routing-instances *instance-name* protocols bgp group *group-name*]—Default logical system with a specified routing instance.

- `[edit logical-systems logical-system-name protocols bgp group group-name]`—Configured logical system and default routing instance.
- `[edit logical-systems logical-system-name routing-instances instance-name protocols bgp group group-name]`—Configured logical system with a specified routing instance.

When you configure BGP neighbor discovery through RPM, if you do not specify a logical system, the RPM probe applies to configured BGP neighbors for all logical systems. If you do not specify a routing instance, the RPM probe applies to configured BGP neighbors in all routing instances. You can explicitly configure RPM probes to apply only to the default logical system, the default routing instance, or to a particular logical system or routing instance.

To configure BGP neighbor discovery through RPM, configure the probe properties at the `[edit services rpm bgp]` hierarchy:

```
data-fill data;
data-size size;
destination-port port;
history-size size;
logical-system logical-system-name [routing-instances routing-instance-name];
probe-count count;
probe-interval seconds;
probe-type type;
routing-instances instance-name;
test-interval interval;
```

- To specify the contents of the data portion of Internet Control Message Protocol (ICMP) probes, include the `data-fill` statement at the `[edit services rpm bgp]` hierarchy level. The value can be a hexadecimal value.
- To specify the size of the data portion of ICMP probes, include the `data-size` statement at the `[edit services rpm bgp]` hierarchy level. The size can be from 0 through 65507 and the default size is 0.
- To specify the User Datagram Protocol (UDP) port or Transmission Control Protocol (TCP) port to which the probe is sent, include the `destination-port` statement at the `[edit services rpm bgp]` hierarchy level. The `destination-port` statement is used only for the UDP and TCP probe types. The value can be 7 or from 49160 through 65535.
- To specify the number of stored history entries, include the `history-size` statement at the `[edit services rpm bgp]` hierarchy level. Specify a value from 0 to 255. The default is 50.
- To specify the logical system used by ICMP probes, include the `logical-system logical-system-name` statement at the `[edit services rpm bgp]` hierarchy level. If you do not specify a logical system, the RPM probe applies to configured BGP neighbors for all logical systems. To apply the probe to only the default logical system, you must set the value of `logical-system-name` to null.
- To specify the number of probes within a test, include the `probe-count` statement at the `[edit services rpm bgp]` hierarchy level. Specify a value from 1 through 15.

- To specify the time to wait between sending packets, include the **probe-interval** statement at the **[edit services rpm bgp]** hierarchy level. Specify a value from 1 through 255 seconds.
- To specify the packet and protocol contents of the probe, include the **probe-type** statement at the **[edit services rpm bgp]** hierarchy level. The following probe types are supported:
 - **icmp-ping**—Sends ICMP echo requests to a target address.
 - **icmp-ping-timestamp**—Sends ICMP timestamp requests to a target address.
 - **tcp-ping**—Sends TCP packets to a target.
 - **udp-ping**—Sends UDP packets to a target.
 - **udp-ping-timestamp**—Sends UDP timestamp requests to a target address.



NOTE: Some probe types require additional parameters to be configured. For example, when you specify the **tcp-ping** or **udp-ping** option, you must configure the destination port using the **destination-port port** statement. The **udp-ping-timestamp** option requires a minimum data size of 12; any smaller data size results in a commit error. The minimum data size for TCP probe packets is 1.

- To specify the routing instance used by ICMP probes, include the **routing-instances** statement at the **[edit services rpm bgp]** hierarchy level. The default routing instance is Internet routing table **inet.0**. If you do not specify a routing instance, the RPM probe applies to configured BGP neighbors in all routing instances. To apply the RPM probe to only the default routing instance, you must explicitly set the value of **instance-name** to **default**.
- To specify the time to wait between tests, include the **test-interval** statement at the **[edit services bgp probe]** hierarchy level. Specify a value from 0 through 86400 seconds.

Configuring Real-Time Performance Monitoring

This section describes the following tasks for configuring RPM:

- Configuring RPM Probes on page 1046
- Configuring RPM Receiver Servers on page 1051
- Limiting the Number of Concurrent RPM Probes on page 1051
- Configuring RPM Timestamping on page 1052
- Configuring TWAMP on page 1054

Configuring RPM Probes

The owner name and test name identifiers of an RPM probe together represent a single RPM configuration instance. When you specify the test name, you also can configure the test parameters.

To configure the probe owner, test name, and test parameters, include the **probe** statement at the [edit services rpm] hierarchy level:

```
probe owner {
  test test-name {
    data-fill data;
    data-size size;
    destination-interface interface-name;
    destination-port port;
    dscp-code-point dscp-bits;
    hardware-timestamp;
    history-size size;
    moving-average-size number;
    one-way-hardware-timestamp;
    probe-count count;
    probe-interval seconds;
    probe-type type;
    routing-instance instance-name;
    source-address address;
    target (url url | address address);
    test-interval interval;
    thresholds thresholds;
    traps traps;
  }
}
```

- To specify a probe owner, include the **probe** statement at the [edit services rpm] hierarchy level. The probe owner identifier can be up to 32 characters in length.
- To specify a test name, include the **test** statement at the [edit services rpm probe owner] hierarchy level. The test name identifier can be up to 32 characters in length. A test represents the range of probes over which the standard deviation, average, and jitter are calculated.
- To specify the contents of the data portion of Internet Control Message Protocol (ICMP) probes, include the **data-fill** statement at the [edit services rpm probe owner] hierarchy level. The value can be a hexadecimal value. The **data-fill** statement is not valid with the **http-get** or **http-metadata-get** probe types.
- To specify the size of the data portion of ICMP probes, include the **data-size** statement at the [edit services rpm probe owner] hierarchy level. The size can be from 0 through 65507 and the default size is 0. The **data-size** statement is not valid with the **http-get** or **http-metadata-get** probe types.



NOTE: If you configure the hardware timestamp feature (see “Configuring RPM Timestamping” on page 1052), the **data-size** default value is 32 bytes and 32 is the minimum value for explicit configuration. The UDP timestamp probe type is an exception; it requires a minimum data size of 44 bytes.

- To specify the output interface for sending packets to the forwarding plane, include the **destination-interface** statement at the [edit services rpm probe owner test test-name] hierarchy level. This interface must support looping of probe

packets to an input interface without adding any encapsulation by using a pair of logical tunnel interfaces.



NOTE: This usage of the `destination-interface` statement is supported only on J-series Services Routers, for which you should specify an `lt` tunnel interface.

The `destination-interface` statement is required to support classification of RPM probes generated by JUNOS software that are based on a user-configured classifier. The classified packets are sent to the output queue on the output interface specified by the scheduler map configured on that interface. For more information about classifiers and scheduler maps, see the *JUNOS Class of Service Configuration Guide*. For a complete configuration example, see “Examples: Configuring Real-Time Performance Monitoring” on page 1057.



CAUTION: Use this feature with caution, because improper configuration can cause packets to be dropped.

On M-series and T-series routing platforms only, you configure the `destination-interface` statement to enable hardware timestamping of RPM probe packets. You specify an `sp` interface to have the AS or MultiServices PIC add the hardware timestamps; for more information, see “Configuring RPM Timestamping” on page 1052. On J-series Services Routers, you configure hardware timestamping by including the `hardware-timestamp` statement. On all platforms, you can also include the `one-way-hardware-timestamp` statement to enable one-way delay and jitter measurements.

- To specify the User Datagram Protocol (UDP) port or Transmission Control Protocol (TCP) port to which the probe is sent, include the `destination-port` statement at the `[edit services rpm probe owner test test-name]` hierarchy level. The `destination-port` statement is used only for the UDP and TCP probe types. The value can be 7 or from 49160 through 65535.
- To specify the value of the Differentiated Services (DiffServ) field within the IP header, include the `dscp-code-point` statement at the `[edit services rpm probe owner test test-name]` hierarchy level. The DiffServ code point (DSCP) bits value can be set to a valid 6-bit pattern; for example, 001111. It also can be set using an alias configured at the `[edit class-of-service code-point-aliases dscp]` hierarchy level. The default is 000000.
- To specify the number of stored history entries, include the `history-size` statement at the `[edit services rpm probe owner test test-name]` hierarchy level. Specify a value from 0 to 255. The default is 50.
- To specify a number of samples for making statistical calculations, include the `moving-average-size` statement at the `[edit services rpm probe owner test test-name]` hierarchy level. Specify a value from 0 through 255.
- To specify the number of probes within a test, include the `probe-count` statement at the `[edit services rpm probe owner test test-name]` hierarchy level. Specify a value from 1 through 15.

- To specify the time to wait between sending packets, include the **probe-interval** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. Specify a value from 1 through 255 seconds.
- To specify the packet and protocol contents of the probe, include the **probe-type** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. The following probe types are supported:
 - **http-get**—Sends a Hypertext Transfer Protocol (HTTP) get request to a target URL.
 - **http-metadata-get**—Sends an HTTP get request for metadata to a target URL.
 - **icmp-ping**—Sends ICMP echo requests to a target address.
 - **icmp-ping-timestamp**—Sends ICMP timestamp requests to a target address.
 - **tcp-ping**—Sends TCP packets to a target.
 - **udp-ping**—Sends UDP packets to a target.
 - **udp-ping-timestamp**—Sends UDP timestamp requests to a target address.

The following probe types support hardware timestamping of probe packets: **icmp-ping**, **icmp-ping-timestamp**, **udp-ping**, **udp-ping-timestamp**.



NOTE: Some probe types require additional parameters to be configured. For example, when you specify the **tcp-ping** or **udp-ping** option, you must configure the destination port using the **destination-port** statement. The **udp-ping-timestamp** option requires a minimum data size of 12; any smaller data size results in a commit error. The minimum data size for TCP probe packets is 1.

- To specify the routing instance used by ICMP probes, include the **routing-instance** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. The default routing instance is Internet routing table **inet.0**.
- To specify the source IP address used for ICMP probes, include the **source-address** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. If the source IP address is not one of the router's assigned addresses, the packet will use the outgoing interface's address as its source.
- To specify the destination address used for the probes, include the **target** statement at the `[edit services rpm probe owner test test-name]` hierarchy level.
 - For HTTP probe types, specify a fully formed URL that includes **http://** in the URL address.
 - For all other probe types, specify an IP version 4 (IPv4) address for the target host.
- To specify the time to wait between tests, include the **test-interval** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. Specify a value from 0 through 86400 seconds.

- To specify thresholds used for the probes, include the **thresholds** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. A system log message is generated when the configured threshold is exceeded. Likewise, an SNMP trap (if configured) is generated when a threshold is exceeded. The following options are supported:
 - **egress-time**—Measures maximum source-to-destination time per probe.
 - **ingress-time**—Measures maximum destination-to-source time per probe.
 - **jitter-egress**—Measures maximum source-to-destination jitter per test.
 - **jitter-ingress**—Measures maximum destination-to-source jitter per test.
 - **jitter-rtt**—Measures maximum jitter per test, from 0 through 60000000 microseconds.
 - **rtt**—Measures maximum round-trip time per probe, in microseconds.
 - **std-dev-egress**—Measures maximum source-to-destination standard deviation per test.
 - **std-dev-ingress**—Measures maximum destination-to-source standard deviation per test.
 - **std-dev-rtt**—Measures maximum standard deviation per test, in microseconds.
 - **successive-loss**—Measures successive probe loss count, indicating probe failure.
 - **total-loss**—Measures total probe loss count indicating test failure, from 0 through 15.
- Traps are sent if the configured threshold is met or exceeded. To set the trap bit to generate traps, include the **traps** statement at the `[edit services rpm probe owner test test-name]` hierarchy level. The following options are supported:
 - **egress-jitter-exceeded**—Generates traps when the jitter in egress time threshold is met or exceeded.
 - **egress-std-dev-exceeded**—Generates traps when the egress time standard deviation threshold is met or exceeded.
 - **egress-time-exceeded**—Generates traps when the maximum egress time threshold is met or exceeded.
 - **ingress-jitter-exceeded**—Generates traps when the jitter in ingress time threshold is met or exceeded.
 - **ingress-std-dev-exceeded**—Generates traps when the ingress time standard deviation threshold is met or exceeded.
 - **ingress-time-exceeded**—Generates traps when the maximum ingress time threshold is met or exceeded.
 - **jitter-exceeded**—Generates traps when the jitter in round-trip time threshold is met or exceeded.

- **probe-failure**—Generates traps for successive probe loss thresholds crossed.
- **rtt-exceeded**—Generates traps when the maximum round-trip time threshold is met or exceeded.
- **std-dev-exceeded**—Generates traps when the round-trip time standard deviation threshold is met or exceeded.
- **test-completion**—Generates traps when a test is completed.
- **test-failure**—Generates traps when the total probe loss threshold is met or exceeded.

Configuring RPM Receiver Servers

The RPM TCP and UDP probes are proprietary to Juniper Networks and require a receiver to receive the probes. To configure a server to receive the probes, include the **probe-server** statement at the **[edit services rpm]** hierarchy level:

```
[edit services rpm]
probe-server {
  tcp {
    destination-interface interface-name;
    port (RPM) number;
  }
  udp {
    destination-interface interface-name;
    port (RPM) number;
  }
}
```

The port number specified for the UDP and TCP server can be 7 or from 49160 through 65535. The **destination-interface** statement specifies the output interface for the RPM server. This interface should be able to support looping of packets to an input interface without adding any encapsulation.



NOTE: This usage of the **destination-interface** statement is supported only on J-series Services Routers, for which you should specify an **lt** tunnel interface.

The **destination-interface** statement is required to support classification of RPM probes generated by JUNOS software based on a user-configured classifier. The classified packets are sent to the output queue on the output interface specified by the scheduler map configured on that interface. For more information about classifiers and scheduler maps, see the *JUNOS Class of Service Configuration Guide*. For a complete configuration example, see “Examples: Configuring Real-Time Performance Monitoring” on page 1057.

Limiting the Number of Concurrent RPM Probes

To configure the maximum number of concurrent probes allowed, include the **probe-limit** statement at the **[edit services rpm]** hierarchy level:

```
probe-limit limit;
```

Specify a limit from 1 through 500. The default maximum number is 100.

Configuring RPM Timestamping

To account for latency in the communication of probe messages, you can enable timestamping of the probe packets. You can timestamp the following RPM probe types: `icmp-ping`, `icmp-ping-timestamp`, `udp-ping`, and `udp-ping-timestamp`. The configuration is handled in different ways on M-series and T-series routing platforms and on J-series Services Routers, as described in the following sections:

- Configuring RPM Timestamps on M-series, MX-series, and T-series Routing Platforms on page 1052
- Configuring RPM Timestamps on J-series Services Routers on page 1054

Configuring RPM Timestamps on M-series, MX-series, and T-series Routing Platforms

On M-series and T-series routing platforms with an Adaptive Services (AS) or MultiServices PIC, and MX-series routers with a MultiServices DPC, you can enable hardware timestamping of RPM probe messages. The timestamp is applied on both the RPM client router (the router that originates the RPM probes) and the RPM probe server and applies only to IPv4 traffic. It is supported in the Layer 2 service package on all MultiServices PICs and DPCs and in the Layer 3 service package on AS and MultiServices PICs and MultiServices DPCs.

To configure two-way timestamping on M-series, MX-series, and T-series routing platforms, include the `destination-interface` statement at the `[edit services rpm probe probe-owner test test-name]` hierarchy level:

```
destination-interface sp-fpc/pic/port.logical-unit;
```

Specify the RPM client router on the adaptive services logical interface by including the `rpm` statement at the `[edit interfaces interface-name unit logical-unit-number]` hierarchy level:

```
rpm client;
```

The logical interface (unit 0) must be dedicated to the RPM task. It requires configuration of the `family inet` statement and a /32 address, as shown in the example. This configuration is also needed for other services such as NAT and stateful firewall.



NOTE: If you configure RPM time stamping on an AS PIC, you cannot configure the `source-address` statement at the `[edit services rpm probe probe-name test test-name]` hierarchy level.

To configure one-way timestamping, you must also include the `one-way-hardware-timestamp` statement at the `[edit services rpm probe probe-owner test test-name]` hierarchy level:

one-way-hardware-timestamp;



NOTE: If you configure RPM probes for a services interface (sp-), you need to announce local routes in a specific way for the following routing protocols:

- For OSPF, you can announce the local route by including the services interface in the OSPF area. To configure this setting, include the `interface sp-fpc/pic/port` statement at the `[edit protocols ospf area area-number]` hierarchy level.
- For BGP and IS-IS, you must export interface routes and create a policy that accepts the services interface local route. To export interface routes, include the `point-to-point` and `lan` statements at the `[edit routing-options interface-routes family inet export]` hierarchy level. To configure an export policy that accepts the services interface local route, include the `protocol local`, `rib inet.0`, and `route-filter sp-interface-ip-address/32 exact` statements at the `[edit policy-options policy-statement policy-name term term-name from]` hierarchy level and the `accept` action at the `[edit policy-options policy-statement policy-name term term-name then]` hierarchy level. For the export policy to take effect, apply the policy to BGP or IS-IS with the `export policy-name` statement at the `[edit protocols protocol-name]` hierarchy level.

For more information about these configurations, see the *JUNOS Policy Framework Configuration Guide* or the *JUNOS Routing Protocols Configuration Guide*.

Routing the probe packets through the AS or MultiServices PIC also enables you to filter the probe packets to particular queues. The following example shows the RPM configuration and the filter that specifies queuing:

```
services rpm {
  probe p1 {
    test t1 {
      probe-type icmp-ping;
      target address 10.8.4.1;
      probe-count 10;
      probe-interval 10;
      test-interval 10;
      dscp-code-points af11;
      data-size 100;
      destination-interface sp-1/2/0.0;
    }
  }
}
firewall {
  filter f1 {
    term t1 {
      from {
        dscp af11;
      }
      then {
        forwarding-class assured-forwarding;
      }
    }
  }
}
```

```

    }
  }
  interfaces sp-1/2/0 {
    unit 0 {
      rpm client;
      family inet {
        address 10.8.4.2/32;
        filter {
          input f1;
        }
      }
    }
  }
}

```

For more information about firewall filters, see the *JUNOS Policy Framework Configuration Guide*; for more information about queuing, see the *JUNOS Class of Service Configuration Guide*.

Configuring RPM Timestamps on J-series Services Routers

On J-series Services Routers, timestamps are applied by the forwarding (fwdd-rt) process.

- To configure two-way timestamping, include the `hardware-timestamp` statement at the `[edit services rpm probe probe-owner test test-name]` hierarchy level:

```
hardware-timestamp;
```

- To configure one-way timestamping, include both the `hardware-timestamp` and the `one-way-hardware-timestamp` statements at the `[edit services rpm probe probe-owner test test-name]` hierarchy level:

```
hardware-timestamp;
one-way-hardware-timestamp;
```

For more information, see the *J-series Services Router Administration Guide*.



NOTE: You cannot include the `source-address` and `hardware-timestamp` or `one-way-hardware-timestamp` statements at the `[edit services rpm probe probe-name test test-name]` hierarchy level simultaneously.

Configuring TWAMP

You can configure the Two-Way Active Measurement Protocol (TWAMP) on all M-series and T-series routing platforms that support MultiServices PICs (running in either Layer 2 or Layer 3 mode), and on MX-series routers with or without a MultiServices DPC. Only the responder (server) side of TWAMP is supported.

For more information on TWAMP, see RFC 5357, *A Two-Way Active Measurement Protocol (TWAMP)*.

To configure TWAMP properties, include the **twamp** statement at the [edit services rpm] hierarchy level:

```
[edit services rpm]
twamp {
  server {
    client-list list-name {
      [ address address ];
    }
    authentication-mode mode;
    inactivity-timeout seconds;
    maximum-connections count;
    maximum-connections-per-client count;
    maximum-sessions count;
    maximum-sessions-per-connection count;
    port number;
  }
}
```

The TWAMP configuration process includes the following tasks:

- Configuring TWAMP Interfaces on page 1055
- Configuring TWAMP Servers on page 1055

Configuring TWAMP Interfaces

To specify the service PIC logical interface that provides the TWAMP service, include the **twamp-server** statement at the [edit interfaces sp-fpc/pic/port unit *logical-unit-number*] hierarchy level:

```
twamp-server;
```



NOTE: On MX-series platforms that do not include a MultiServices DPC, you can configure TWAMP properties, but you can omit specifying the **twamp-server** statement.

Configuring TWAMP Servers

You can specify a number of TWAMP server properties, some of which are optional, by including the **server** statement at the [edit services rpm twamp] hierarchy level:

```
[edit services rpm twamp]
server {
  client-list list-name {
    [ address address ];
  }
  authentication-mode mode;
  inactivity-timeout seconds;
  maximum-connections count;
  maximum-connections-per-client count;
  maximum-sessions count;
  maximum-sessions-per-connection count;
  port number;
```

```
}
```

- To specify the list of allowed control client hosts that can connect to this server, include the **client-list** statement at the **[edit services rpm twamp server]** hierarchy level. Each value you include must be a Classless Interdomain Routing (CIDR) address (IP address plus mask) that represents a network of allowed hosts. You can include multiple client lists, each of which can contain a maximum of 64 entries. You must configure at least one client address to enable TWAMP.
- You must specify the authentication mode by including the **authentication-mode** statement at the **[edit services rpm twamp server]** hierarchy level. There is no default value. You can configure **authenticated** or **encrypted** mode, based on RFC 4656; if there is no authentication or encryptions mode specified, you should set the value to **none**. This statement is required in the TWAMP configuration.
- To specify the inactivity timeout period in seconds, include the **inactivity-timeout** statement at the **[edit services rpm twamp server]** hierarchy level. By default, the value is **1800**; the range is 0 through 3600 seconds.
- To specify the maximum number of concurrent connections the server can have to client hosts, include the **maximum-connections** statement at the **[edit services rpm twamp server]** hierarchy level. The allowed range of values is 1 through 2048 and the default value is 64. You can also limit the number of connections the server can make to a particular client host by including the **maximum-connections-per-client** statement.
- To specify the maximum number of sessions the server can have running at one time, include the **maximum-sessions** statement at the **[edit services rpm twamp server]** hierarchy level. The allowed range of values is 1 through 2048 and the default value is 64. You can also limit the number of sessions the server can have on a single connection by including the **maximum-sessions-per-connection** statement.
- To specify the TWAMP server listening port, include the **port** statement at the **[edit services rpm twamp server]** hierarchy level. The range is 1 through 65,535. This statement is mandatory.

For examples of TWAMP configuration, see “Examples: Configuring Real-Time Performance Monitoring” on page 1057.

Examples: Configuring BGP Neighbor Discovery Through RPM

Configure BGP neighbor discovery through RPM for all logical systems and all routing instances:

```
[edit services rpm]
bgp {
  probe-type icmp-ping;
  probe-count 5;
  probe-interval 1;
  test-interval 60;
  history-size 10;
  data-size 255;
  data-fill 0123456789;
}
```


Configure BGP neighbor discovery through RPM for only the following logical systems and routing instances: LS1/RI1, LS1/RI2, LS2, and RI3:

```
[edit services rpm]
bgp {
  probe-type icmp-ping;
  probe-count 5;
  probe-interval 1;
  test-interval 60;
  history-size 10;
  data-size 255;
  data-fill 0123456789;
  logical-system {
    LS1 {
      routing-instances {
        RI1;
        RI2;
      }
    }
    LS2;
  }
  routing-instance {
    RI3;
  }
}
```

Configure BGP neighbor discovery through RPM for only the default logical system and default routing instance:

```
[edit services rpm]
bgp {
  probe-type icmp-ping;
  probe-count 5;
  probe-interval 1;
  test-interval 60;
  history-size 10;
  data-size 255;
  data-fill 0123456789;
  logical-system {
    null {
      routing-instances {
        default;
      }
    }
  }
}
```

Examples: Configuring Real-Time Performance Monitoring

Configure an RPM instance identified by the probe name **probe1** and the test name **test1**:

```
[edit services rpm]
probe probe1{
  test test1 {
    dscp-code-points 001111;
    probe-interval 1;
  }
}
```

```

        probe-type icmp-ping;
        target address 172.17.20.182;
        test-interval 20;
        thresholds rtt 10;
        traps rtt-exceeded;
    }
}
probe-server {
    tcp {
        destination-interface lt-0/0/0.0
        port 50000;
    }
    udp {
        destination-interface lt-0/0/0.0
        port 50001;
    }
}
probe-limit 200;

```

Configure packet classification, using `lt-` interfaces to send the probe packets to a logical tunnel input interface. By sending the packet to the logical tunnel interface, you can configure regular and MF classifiers, firewall filters, and header rewriting for the probe packets. To use the existing tunnel framework, the `dlci` and `encapsulation` statements must be configured.

```

[edit services rpm]
probe p1 {
    test t1 {
        probe-type icmp-ping;
        target address 10.8.4.1;
        probe-count 10;
        probe-interval 10;
        test-interval 10;
        source-address 10.8.4.2;
        dscp-code-points ef;
        data-size 100;
        destination-interface lt-0/0/0.0;
    }
}
[edit interfaces]
lt-0/0/0 {
    unit 0 {
        encapsulation frame-relay;
        dlci 10;
        peer-unit 1;
        family inet;
    }
    unit 1 {
        encapsulation frame-relay;
        dlci 10;
        peer-unit 0;
        family inet;
    }
}
[edit class-of-service]
interfaces {

```

```

lt-0/0/0 {
  unit 1 {
    classifiers {
      dscp default;
    }
  }
}

```

Configure an input filter on the interface on which the RPM probes are received. This filter enables prioritization of the received RPM packets, separating them from the regular data packets received on the same interface.

```

[edit firewall]
filter recos {
  term recos {
    from {
      source-address {
        10.8.4.1/32;
      }
      destination-address {
        10.8.4.2/32;
      }
    }
    then {
      loss-priority high;
      forwarding-class network-control;
    }
  }
}
[edit interfaces]
fe-5/0/0 {
  unit 0 {
    family inet {
      filter {
        input recos;
      }
      address 10.8.4.2/24;
    }
  }
}

```

Configure the minimum statements necessary to enable TWAMP:

```

[edit services]
rpm {
  twamp {
    server {
      authentication-mode none;
      port 10000; # Twamp server's listening port
      client-list LIST-1 { # LIST-1 is the name of the client-list. Multiple lists can be
        configured.
        address {
          20.0.0.2/30; # IP address of the control client.
        }
      }
    }
  }
}

```

```

    }
  }
[edit interfaces sp-5/0/0]
unit 0 {
  family inet;
}
unit 10 {
  rpm {
    twamp-server; # You must configure a separate logical interface on the service
                  PIC interface for the TWAMP server.
  }
  family inet {
    address 50.50.50.50/32; # This address must be a host address with a 32-bit
                           mask.
  }
}
[edit chassis]
fpc 5 {
  pic 0 {
    adaptive-services {
      service-package layer-2; # Configure the service PIC to run in Layer 2 mode.
    }
  }
}
}

```

Configure additional TWAMP settings:

```

[edit services]
rpm {
  twamp {
    server {
      inactivity-timeout 20;
      maximum-sessions 5;
      maximum-sessions-per-connection 2;
      maximum-connections 3;
      maximum-connections-per-client 1;
      port 10000;
      client-list LIST-1 {
        address {
          20.0.0.2/30;
        }
      }
    }
  }
}
}

```

Chapter 58

Summary of Real-Time Performance Monitoring Configuration Statements

The following sections explain each of the Real-Time Performance Monitoring (RPM) statements. The statements are organized alphabetically.

authentication-mode

Syntax	authentication-mode (authenticated encrypted none);
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.5.
Description	Specify the authentication or encryption mode support for the TWAMP test protocol. This statement is required in the configuration; if no authentication or encryption is specified, you should set the value to none .
Options	<ul style="list-style-type: none">■ authenticated—Data packets are authenticated.■ encrypted—Data packets are encrypted.■ none—No authentication or encryption.
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

client-list

Syntax	client-list <i>list-name</i> { address <i>address</i> ; }
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	List of allowed control client hosts that can connect to this server. Each entry is a Classless Interdomain Routing (CIDR) address (IP address plus mask) that represents a network of allowed hosts. You can configure more than one list, but you must configure at least one client address to enable TWAMP. Each list can contain up to 64 entries.
Options	<i>list-name</i> —Name of client address list. <i>address</i> —Address and mask for an allowed client.
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

data-fill

Syntax	data-fill <i>data</i> ;
Hierarchy Level	[edit services rpm bgp], [edit services rpm probe <i>owner</i> test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the contents of the data portion of Internet Control Message Protocol (ICMP) probes.
Options	<i>data</i> —A hexadecimal value; for example, 0-9, A-F.
Usage Guidelines	The data-fill statement is not valid with the http-get or http-metadata-get probe types. See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

data-size

Syntax `data-size size;`

Hierarchy Level [edit services rpm bgp],
[edit services rpm probe owner test test-name]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the size of the data portion of ICMP probes.

Options *data*—The size can be from 0 through 65507
Default: 0



NOTE: If you configure the hardware timestamp feature (see “Configuring RPM Timestamping” on page 1052), the **data-size** default value is 32 bytes and 32 is the minimum value for explicit configuration. The UDP timestamp probe type is an exception; it requires a minimum data size of 44 bytes.

Usage Guidelines The **data-size** statement is not valid with the **http-get** or **http-metadata-get** probe type. See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.

Required Privilege Level system—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

destination-interface

Syntax	<code>destination-interface <i>interface-name</i>;</code>
Hierarchy Level	[edit services rpm probe owner test <i>test-name</i>], [edit services rpm probe-server (tcp udp)]
Release Information	Statement introduced in JUNOS Release 7.5.
Description	<p>On J-series Services Routers only, specify the output (lt-) interface used to send packets to the forwarding plane. This interface must support looping of packets to an input interface without adding any encapsulation.</p> <p>On M-series and T-series routing platforms, specify a services (sp-) interface that adds a timestamp to RPM probe messages. This feature is supported only with <code>icmp-ping</code>, <code>icmp-ping-timestamp</code>, <code>udp-ping</code>, and <code>udp-ping-timestamp</code> probe types. You must also configure the <code>rpm</code> statement on the <code>sp-</code> interface and include the <code>unit 0 family inet</code> statement with a <code>/32</code> address.</p>
Options	<i>interface-name</i> —Name of the output interface (J-series Services Routers) or adaptive services interface (M-series and T-series routers).
Usage Guidelines	See “Configuring RPM Probes” on page 1046, “Configuring RPM Receiver Servers” on page 1051, or “Configuring RPM Timestamping” on page 1052.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	hardware-timestamp, rpm

destination-port

Syntax	<code>destination-port <i>port</i>;</code>
Hierarchy Level	[edit services rpm bgp], [edit services rpm probe <i>owner</i> test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the User Datagram Protocol (UDP) or Transmission Control Protocol (TCP) port to which a probe is sent. This statement is used only for TCP or UDP probe types.
Options	<i>port</i> —The port number can be 7 or from 49,160 to 65,535.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

dscp-code-point

Syntax	<code>dscp-code-point <i>dscp-bits</i>;</code>
Hierarchy Level	<code>[edit services rpm probe owner test <i>test-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the value of the Differentiated Services (DiffServ) field within the IP header. The DiffServ code point (DSCP) bits value must be set to a valid 6-bit pattern.
Options	<p><i>dscp-bits</i>—A valid 6-bit pattern; for example, 001111, or one of the following configured DSCP aliases:</p> <ul style="list-style-type: none"> ■ af11—Default: 001010 ■ af12—Default: 001100 ■ af13—Default: 001110 ■ af21—Default: 010010 ■ af22—Default: 010100 ■ af23 —Default: 010110 ■ af31 —Default: 011010 ■ af32 —Default: 011100 ■ af33 —Default: 011110 ■ af41 —Default: 100010 ■ af42 —Default: 100100 ■ af43 —Default: 100110 ■ be—Default: 000000 ■ cs1—Default: 001000 ■ cs2—Default: 010000 ■ cs3—Default: 011000 ■ cs4—Default: 100000 ■ cs5—Default: 101000 ■ cs6—Default: 110000 ■ cs7—Default: 111000 ■ ef—Default: 101110 ■ nc1—Default: 110000 ■ nc2—Default: 111000
Usage Guidelines	See “Configuring RPM Probes” on page 1046.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

hardware-timestamp

Syntax hardware-timestamp;

Hierarchy Level [edit services rpm probe *owner* test *test-name*]

Release Information Statement introduced in JUNOS Release 8.1.

Description On J-series Services Routers only, enable timestamping of RPM probe messages. This feature is supported only with icmp-ping, icmp-ping-timestamp, udp-ping, and udp-ping-timestamp probe types.

Usage Guidelines See “Configuring RPM Timestamping” on page 1052.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

history-size

Syntax history-size *size*;

Hierarchy Level [edit services rpm bgp],
 [edit services rpm probe *owner* test *test-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the number of stored history entries.

Options *size*—A value from 0 to 255.
Default: 50

Usage Guidelines See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

inactivity-timeout

Syntax	<code>inactivity-timeout <i>seconds</i>;</code>
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Inactivity timeout period, in seconds.
Options	<i>seconds</i> —Length of time the session is inactive before it times out. Default: 1800 seconds
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

logical-system

Syntax	<code>logical-system <i>logical-system-name</i> { [routing-instances <i>instance-name</i>]; }</code>
Hierarchy Level	[edit services rpm bgp]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify the logical system used by the probes. The remaining statements are explained separately.
Options	<i>logical-system-name</i> —Logical system name.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

maximum-connections

Syntax	maximum-connections <i>count</i> ;
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Maximum number of allowed connections between the server and all control client hosts.
Options	<i>count</i> —Maximum number of connections. Range: 1 through 2048 Default: 64
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

maximum-connections-per-client

Syntax	maximum-connections-per-client <i>count</i> ;
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Maximum number of allowed connections between the server and a single control client host.
Options	<i>count</i> —Maximum number of connections. Default: 64
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

maximum-sessions

Syntax	maximum-sessions <i>count</i> ;
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Maximum number of allowed test sessions the server can have running at one time.
Options	<i>count</i> —Maximum number of sessions. Range: 1 through 2048 Default: 64
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

maximum-sessions-per-connection

Syntax	maximum-sessions-per-connection <i>count</i> ;
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Maximum number of allowed sessions the server can open on a single client connection.
Options	<i>count</i> —Maximum number of sessions. Default: 64
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

moving-average-size

Syntax	<code>moving-average-size <i>number</i>;</code>
Hierarchy Level	<code>[edit services rpm probe owner test <i>test-name</i>]</code>
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Enable statistical calculation operations to be performed across a configurable number of the most recent samples.
Options	<i>number</i> —Number of samples to be used in calculations. Range: 0 through 255
Usage Guidelines	See “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

one-way-hardware-timestamp

Syntax	<code>one-way-hardware-timestamp;</code>
Hierarchy Level	<code>[edit services rpm probe owner test <i>test-name</i>]</code>
Release Information	Statement introduced in JUNOS Release 8.5.
Description	Enable timestamping of RPM probe messages for one-way delay and jitter measurements. You must configure this statement along with the <code>destination-interface</code> statement (M-series and T-series platforms) or the <code>hardware-timestamp</code> statement (J-series Services Routers) to invoke timestamping. This feature is supported only with <code>icmp-ping</code> , <code>icmp-ping-timestamp</code> , <code>udp-ping</code> , and <code>udp-ping-timestamp</code> probe types.
Usage Guidelines	See “Configuring RPM Timestamps on J-series Services Routers” on page 1054.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<code>destination-interface</code> , <code>hardware-timestamp</code>

port

- port (RPM) on page 1072
- port (TWAMP) on page 1072

port (RPM)

Syntax	port <i>number</i> ;
Hierarchy Level	[edit services rpm probe-server (tcp udp)]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the port number for the probe server.
Options	<i>number</i> —Port number for the probe server. The value can be 7 or 49,160 through 65,535.
Usage Guidelines	See “Configuring RPM Receiver Servers” on page 1051.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

port (TWAMP)

Syntax	port <i>number</i> ;
Hierarchy Level	[edit services rpm twamp server]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	TWAMP server listening port. You must configure this statement to enable TWAMP.
Options	<i>number</i> —Port number. Range: 1 through 65,535
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

probe

Syntax `probe owner {
 test test-name {
 data-fill data;
 data-size size;
 destination-interface interface-name;
 destination-port port;
 dscp-code-point dscp-bits;
 history-size size;
 moving-average-size number;
 one-way-hardware-timestamp;
 probe-count count;
 probe-interval seconds;
 probe-type type;
 routing-instance instance-name;
 source-address address;
 target (url | address);
 test-interval interval;
 thresholds thresholds;
 traps traps;
 }
 }`

Hierarchy Level [edit services rpm]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify an owner name. The owner name combined with the test name represent a single RPM configuration instance.

Options *owner*—Specify an owner name up to 32 characters in length.

The remaining statements are explained separately.

Usage Guidelines See “Configuring RPM Probes” on page 1046.

Required Privilege Level *system*—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

probe-count

Syntax	<code>probe-count <i>count</i>;</code>
Hierarchy Level	[edit services rpm bgp], [edit services rpm probe owner test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the number of probes within a test.
Options	<i>count</i> —A value from 1 through 15.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

probe-interval

Syntax	<code>probe-interval <i>interval</i>;</code>
Hierarchy Level	[edit services rpm bgp], [edit services rpm probe owner test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the time to wait between sending packets, in seconds.
Options	<i>interval</i> —Number of seconds, from 1 through 255.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

probe-limit

Syntax	<code>probe-limit <i>limit</i>;</code>
Hierarchy Level	[edit services rpm]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the maximum number of concurrent probes allowed.
Options	<i>limit</i> —A value from 1 through 500. Default: 100.
Usage Guidelines	See “Limiting the Number of Concurrent RPM Probes” on page 1051.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

probe-server

Syntax	<pre> probe-server { tcp { destination-interface <i>interface-name</i>; port (RPM) <i>number</i>; } udp { destination-interface <i>interface-name</i>; port (RPM) <i>number</i>; } } </pre>
Hierarchy Level	[edit services rpm]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the server to act as a receiver for the probes. The remaining statements are explained separately.
Usage Guidelines	See “Configuring RPM Receiver Servers” on page 1051.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

probe-type

Syntax	probe-type <i>type</i> ;
Hierarchy Level	[edit services rpm bgp], [edit services rpm probe owner test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the packet and protocol contents of a probe.
Options	<i>type</i> —Specify one of the following probe type values: <ul style="list-style-type: none"> ■ http-get—(Not available at the [edit services rpm bgp] hierarchy level.) Sends a Hypertext Transfer Protocol (HTTP) get request to a target URL. ■ http-metadata-get—(Not available at the [edit services rpm bgp] hierarchy level.) Sends an HTTP get request for metadata to a target URL. ■ icmp-ping—Sends ICMP echo requests to a target address. ■ icmp-ping-timestamp—Sends ICMP timestamp requests to a target address. ■ tcp-ping—Sends TCP packets to a target. ■ udp-ping—Sends UDP packets to a target. ■ udp-ping-timestamp—Sends UDP timestamp requests to a target address.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

routing-instance

Syntax	routing-instance <i>instance-name</i> ;
Hierarchy Level	[edit services rpm probe owner test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the routing instance used by the probes.
Options	<i>instance-name</i> —A routing instance configured at the [edit routing-instance] hierarchy level. Default: Internet routing table inet.0.
Usage Guidelines	See “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

routing-instances

Syntax	<code>routing-instances <i>instance-name</i>;</code>
Hierarchy Level	[edit services rpm bgp], [edit services rpm bgp logical-system <i>logical-system-name</i>]
Release Information	Statement introduced in JUNOS Release 7.6.
Description	Specify the routing instance used by the probes.
Options	<i>instance-name</i> —A routing instance configured at the [edit routing-instances] hierarchy level. Default: Internet routing table inet.0.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

rpm

Syntax	<code>rpm <i>client</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Associate an RPM client (router that originates RPM probes) with a specified Adaptive Services interface.
Options	<i>client</i> —Identifier for RPM client router.
Usage Guidelines	See “Configuring RPM Timestamping” on page 1052.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

server

Syntax server {
 client-list *list-name* {
 [address *address*];
 }
 inactivity-timeout *seconds*;
 maximum-connections *count*;
 maximum-connections-per-client *count*;
 maximum-sessions *count*;
 maximum-sessions-per-connection *count*;
 port *number*;
 }

Hierarchy Level [edit services rpm twamp]

Release Information Statement introduced in JUNOS Release 9.3.

Description TWAMP server configuration settings.

Options The remaining statements are described separately.

Usage Guidelines See “Configuring TWAMP” on page 1054.

Required Privilege Level system—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

services

Syntax services rpm { ... }

Hierarchy Level [edit]

Release Information Statement introduced before JUNOS Release 7.4.

Description Define the service rules to be applied to traffic.

Options rpm—Identifies the RPM set of rules statements.

Usage Guidelines See “Real-Time Performance Monitoring Configuration Guidelines” on page 1043.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

source-address

Syntax	<code>source-address <i>address</i>;</code>
Hierarchy Level	<code>[edit services rpm probe owner test <i>test-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the source IP address used for probes. If the source IP address is not one of the router's assigned addresses, the packet will use the outgoing interface's address as its source.
Options	<i>address</i> —Valid IP address.
Usage Guidelines	See “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

target

Syntax	<code>target (url <i>url</i> address <i>address</i>);</code>
Hierarchy Level	<code>[edit services rpm probe owner test <i>test-name</i>]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the destination address used for the probes.
Options	url <i>url</i> —For HTTP probe types, specify a fully formed URL that includes <code>http://</code> in the URL address. address <i>address</i> —For all other probe types, specify an IPv4 address for the target host.
Usage Guidelines	See “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

tcp

Syntax tcp {
 destination-interface *interface-name*;
 port (RPM) *port*;
 }

Hierarchy Level [edit services rpm probe-server]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the port information for the TCP server.

 The remaining statements are explained separately.

Usage Guidelines See “Configuring RPM Receiver Servers” on page 1051.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

test

Syntax `test test-name {
 data-fill data;
 data-size size;
 destination-interface interface-name;
 destination-port port;
 dscp-code-point dscp-bits;
 history-size size;
 moving-average-size number;
 one-way-hardware-timestamp;
 probe-count count;
 probe-interval seconds;
 probe-type type;
 routing-instance instance-name;
 source-address address;
 target (url url | address address);
 test-interval interval;
 thresholds thresholds;
 traps traps;
 }`

Hierarchy Level [edit services rpm probe owner]

Release Information Statement introduced before JUNOS Release 7.4.

Description Represents the range of probes over which the standard deviation, average, and jitter are calculated. The test name combined with the owner name represent a single RPM configuration instance.

Options *test-name*—Specify a test name. The name can be up to 32 characters in length.
 The remaining statements are explained separately.

Usage Guidelines See “Configuring RPM Probes” on page 1046.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

test-interval

Syntax	<code>test-interval <i>frequency</i>;</code>
Hierarchy Level	[edit services rpm bgp], [edit services rpm probe <i>owner</i> test <i>test-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the time to wait between tests, in seconds.
Options	<i>frequency</i> —Number of seconds, from 0 through 86400.
Usage Guidelines	See “Configuring BGP Neighbor Discovery Through RPM” on page 1044 or “Configuring RPM Probes” on page 1046.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

thresholds

Syntax	<code>thresholds thresholds;</code>
Hierarchy Level	<code>[edit services rpm probe owner test test-name]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify thresholds used for the probes. A system log message is generated when the configured threshold is exceeded. Likewise, an SNMP trap (if configured) is generated when a threshold is exceeded.
Options	<p><i>thresholds</i>—Specify one or more threshold measurements. The following options are supported:</p> <ul style="list-style-type: none"> ■ <i>egress-time</i>—Measures maximum source-to-destination time per probe. ■ <i>ingress-time</i>—Measures maximum destination-to-source time per probe. ■ <i>jitter-egress</i>—Measures maximum source-to-destination jitter per test. ■ <i>jitter-ingress</i>—Measures maximum destination-to- source jitter per test. ■ <i>jitter-rtt</i>—Measures maximum jitter per test, from 0 through 60,000,000 microseconds. ■ <i>rtt</i>—Measures maximum round-trip time per probe, in microseconds. ■ <i>std-dev-egress</i>—Measures maximum source-to-destination standard deviation per test. ■ <i>std-dev-ingress</i>—Measures maximum destination-to-source standard deviation per test. ■ <i>std-dev-rtt</i>—Measures maximum standard deviation per test, in microseconds. ■ <i>successive-loss</i>—Measures successive probe loss count, indicating probe failure. ■ <i>total-loss</i>—Measures total probe loss count indicating test failure, from 0 through 15.
Usage Guidelines	See “Configuring RPM Probes” on page 1046.
Required Privilege Level	<p><code>interface</code>—To view this statement in the configuration.</p> <p><code>interface-control</code>—To add this statement to the configuration.</p>

traps

Syntax	<code>traps traps;</code>
Hierarchy Level	<code>[edit services rpm probe owner test test-name]</code>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the trap bit to generate traps for probes. Traps are sent if the configured threshold is met or exceeded.
Options	<p><code>traps</code>—Specify one or more traps. The following options are supported:</p> <ul style="list-style-type: none"> ■ <code>egress-jitter-exceeded</code>—Generates traps when the jitter in egress time threshold is met or exceeded. ■ <code>egress-std-dev-exceeded</code>—Generates traps when the egress time standard deviation threshold is met or exceeded. ■ <code>egress-time-exceeded</code>—Generates traps when the maximum egress time threshold is met or exceeded. ■ <code>ingress-jitter-exceeded</code>—Generates traps when the jitter in ingress time threshold is met or exceeded. ■ <code>ingress-std-dev-exceeded</code>—Generates traps when the ingress time standard deviation threshold is met or exceeded. ■ <code>ingress-time-exceeded</code>—Generates traps when the maximum ingress time threshold is met or exceeded. ■ <code>jitter-exceeded</code>—Generates traps when the jitter in round-trip time threshold is met or exceeded. ■ <code>probe-failure</code>—Generates traps for successive probe loss thresholds crossed. ■ <code>rtt-exceeded</code>—Generates traps when the maximum round-trip time threshold is met or exceeded. ■ <code>std-dev-exceeded</code>—Generates traps when the round-trip time standard deviation threshold is met or exceeded. ■ <code>test-completion</code>—Generates traps when a test is completed. ■ <code>test-failure</code>—Generates traps when the total probe loss threshold is met or exceeded.
Usage Guidelines	See “Configuring RPM Probes” on page 1046.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

twamp

Syntax	<pre>twamp { server { client-list <i>list-name</i> { [address <i>address</i>]; } authentication-mode <i>mode</i>; inactivity-timeout <i>seconds</i>; maximum-connections <i>count</i>; maximum-connections-per-client <i>count</i>; maximum-sessions <i>count</i>; maximum-sessions-per-connection <i>count</i>; port <i>number</i>; } }</pre>
Hierarchy Level	[edit services rpm]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	TWAMP configuration settings.
Options	The remaining statements are described separately.
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

twamp-server

Syntax	twamp-server;
Hierarchy Level	[edit interfaces <i>sp-fpc/pic/port</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Specify the service PIC logical interface to provide the TWAMP service.
Usage Guidelines	See “Configuring TWAMP” on page 1054.
Required Privilege Level	system—To view this statement in the configuration. interface-control—To add this statement to the configuration.

udp

Syntax udp {
 destination-interface *interface-name*;
 port (RPM) *port*;
 }

Hierarchy Level [edit services rpm probe-server]

Release Information Statement introduced before JUNOS Release 7.4.

Description Specify the port information for the UDP server.

 The remaining statements are explained separately.

Usage Guidelines See “Configuring RPM Receiver Servers” on page 1051.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Part 9

Tunnel Services

- Tunnel Services Overview on page 1089
- Tunnel Interfaces Configuration Guidelines on page 1093
- Summary of Tunnel Services Configuration Statements on page 1109

Chapter 59

Tunnel Services Overview

By encapsulating arbitrary packets inside a transport protocol, tunneling provides a private, secure path through an otherwise public network. Tunnels connect discontinuous subnetworks and enable encryption interfaces, virtual private networks (VPNs), and MPLS. If you have a Tunnel Physical Interface Card (PIC) installed in your router, you can configure unicast, multicast, and logical tunnels.

You can configure two types of tunnels for VPNs: one to facilitate routing table lookups and another to facilitate VPN routing and forwarding instance (VRF) table lookups.

For information about encryption interfaces, see “Encryption Interfaces Configuration Guidelines” on page 773 and the *JUNOS System Basics Configuration Guide*. For information about VPNs, see the *JUNOS VPNs Configuration Guide*. For information about MPLS, see the *JUNOS MPLS Applications Configuration Guide*.

The JUNOS software supports the tunnel types shown in Table 22 on page 1089.

Table 22: Tunnel Interface Types

Interface	Description
gr-0/0/0	<p>Configurable generic routing encapsulation (GRE) interface. GRE allows the encapsulation of one routing protocol over another routing protocol.</p> <p>Within a router, packets are routed to this internal interface, where they are first encapsulated with a GRE packet and then re-encapsulated with another protocol packet to complete the GRE. The GRE interface is an internal interface only and is not associated with a physical medium or PIC. You must configure the interface for it to perform GRE.</p>
gre	<p>Internally generated GRE interface. This interface is generated by the JUNOS software to handle GRE. It is not a configurable interface.</p>

Table 22: Tunnel Interface Types *(continued)*

Interface	Description
ip-0/0/0	<p>Configurable IP-over-IP encapsulation (also called IP tunneling) interface. IP tunneling allows the encapsulation of one IP packet over another IP packet.</p> <p>Generally, IP routing allows packets to be routed directly to a particular address. However, in some instances you might need to route an IP packet to one address and then encapsulate it for forwarding to a different address. In a mobile environment in which the location of the end device changes, a different IP address might be used as the end device migrates between networks.</p> <p>Within a router, packets are routed to this internal interface where they are encapsulated with an IP packet and then forwarded to the encapsulating packet's destination address. The IP-IP interface is an internal interface only and is not associated with a physical medium or PIC. You must configure the interface for it to perform IP tunneling.</p>
ipip	<p>Internally generated IP-over-IP interface. This interface is generated by the JUNOS software to handle IP-over-IP encapsulation. It is not a configurable interface.</p>
lt-0/0/0	<p>The lt interface on M-series and T-series routing platforms supports configuration of logical systems—the capability to partition a single physical router into multiple logical devices that perform independent routing tasks.</p> <p>On J-series Services Routers, it has a different function: it provides class-of-service (CoS) support for data link switching (DLSw) traffic and real-time performance monitoring (RPM) probe packets.</p> <p>Within a Services Router, packets are routed to this internal interface for services. The lt interface is an internal interface only and is not associated with a physical medium or PIM. You must configure the interface for it to perform CoS for DLSW and RPM services.</p>
mt-0/0/0	<p>Internally generated multicast tunnel interface. Multicast tunnels filter all unicast packets; if an incoming packet is not destined for a 224/8-or-greater prefix, the packet is dropped and a counter is incremented.</p> <p>Within a router, packets are routed to this internal interface for multicast filtering. The multicast tunnel interface is an internal interface only and is not associated with a physical medium or PIC. If your routing platform has a Tunnel Services PIC, the JUNOS software automatically configures one multicast tunnel interface (mt-) for each virtual private network (VPN) you configure. You do not need to configure multicast tunnel interfaces. However, you can configure properties on mt- interfaces, such as the multicast-only statement.</p>
mtun	<p>Internally generated multicast tunnel interface. This interface is generated by the JUNOS software to handle multicast tunnel services. It is not a configurable interface.</p>

Table 22: Tunnel Interface Types (*continued*)

Interface	Description
pd-0/0/0	<p>Configurable Protocol Independent Multicast (PIM) de-encapsulation interface. In PIM sparse mode, the first-hop routing platform encapsulates packets destined for the rendezvous point router. The packets are encapsulated with a unicast header and are forwarded through a unicast tunnel to the rendezvous point. The rendezvous point then de-encapsulates the packets and transmits them through its multicast tree.</p> <p>Within a router, packets are routed to this internal interface for de-encapsulation. The PIM de-encapsulation interface is an internal interface only and is not associated with a physical medium or PIC. You must configure the interface for it to perform PIM de-encapsulation.</p>
pe-0/0/0	<p>Configurable Protocol Independent Multicast (PIM) encapsulation interface. In PIM sparse mode, the first-hop routing platform encapsulates packets destined for the rendezvous point router. The packets are encapsulated with a unicast header and are forwarded through a unicast tunnel to the rendezvous point. The rendezvous point then de-encapsulates the packets and transmits them through its multicast tree.</p> <p>Within a router, packets are routed to this internal interface for encapsulation. The PIM encapsulation interface is an internal interface only and is not associated with a physical medium or PIC. You must configure the interface for it to perform PIM encapsulation.</p>
pimd	Internally generated Protocol Independent Multicast (PIM) de-encapsulation interface. This interface is generated by the JUNOS software to handle PIM de-encapsulation. It is not a configurable interface.
pime	Internally generated Protocol Independent Multicast (PIM) encapsulation interface. This interface is generated by the JUNOS software to handle PIM encapsulation. It is not a configurable interface.
vt-0/0/0	<p>Configurable virtual loopback tunnel interface. Facilitates VRF table lookup based on MPLS labels. This interface type is supported on M-series and T-series routing platforms, but not on J-series Services Routers.</p> <p>To configure a virtual loopback tunnel to facilitate VRF table lookup based on MPLS labels, you specify a virtual loopback tunnel interface name and associate it with a routing instance that belongs to a particular routing table. The packet loops back through the virtual loopback tunnel for route lookup.</p>

Chapter 60

Tunnel Interfaces Configuration Guidelines

This chapter includes the following tunnel interface configuration tasks and examples:

- Configuring Unicast Tunnels on page 1093
- Restricting Tunnels to Multicast Traffic on page 1098
- Configuring Logical Tunnel Interfaces on page 1098
- Configuring Tunnel Interfaces for Routing Table Lookup on page 1100
- Configuring Virtual Loopback Tunnels for VRF Table Lookup on page 1101
- Configuring PIM Tunnels on page 1102
- Configuring IPv6-over-IPv4 Tunnels on page 1103
- Configuring Dynamic Tunnels on page 1103
- Configuring Tunnel Interfaces on MX-series Routers on page 1104
- Examples: Configuring Unicast Tunnels on page 1104
- Example: Configuring a Virtual Loopback Tunnel for VRF Table Lookup on page 1105
- Example: Configuring an IPv6-over-IPv4 Tunnel on page 1106
- Example: Configuring Logical Tunnels on page 1106

Configuring Unicast Tunnels

To configure a unicast tunnel, you configure a `gr-` interface (to use GRE encapsulation) or an `ip-` interface (to use IP-IP encapsulation) and include the `tunnel` and `family` statements:

```
gr-fpc/pic/port or ip-fpc/pic/port {  
  unit logical-unit-number {  
    copy-tos-to-outer-ip-header;  
    reassemble-packets;  
    tunnel {  
      allow-fragmentation;  
      backup-destination address;  
      destination destination-address;  
      do-not-fragment;  
      key number;  
      routing-instance {  
        destination routing-instance-name;  
      }  
    }  
  }  
}
```

```

    }
    source address;
    ttl number;
  }
  family family {
    address address {
      destination address;
    }
  }
}

```

You can configure these statements at the following hierarchy levels:

- [edit interfaces]
- [edit logical-systems *logical-system-name* interfaces]

You can configure multiple logical units for each GRE or IP-IP interface, and you can configure only one tunnel per unit.

Each tunnel interface must be a point-to-point interface. Point to point is the default interface connection type, so you do not need to include the **point-to-point** statement in the logical interface configuration.

You must specify the tunnel's destination and source addresses. The remaining statements are optional.



NOTE: For transit packets exiting the tunnel, forwarding path features, such as reverse path forwarding (RPF), forwarding table filtering, source class usage, destination class usage, and stateless firewall filtering, are not supported on the interfaces you configure as tunnel sources.

However, class-of-service (CoS) information obtained from the GRE or IP-IP header is carried over the tunnel and is used by the re-entering packets. For more information, see the *JUNOS Class of Service Configuration Guide*.

To prevent an invalid configuration, the JUNOS software disallows setting the address specified by the **source** or **destination** statement at the [edit interfaces *gr-fpc/pic/port* unit *logical-unit-number* tunnel] hierarchy level to be the same as the interface's own subnet address, specified by the **address** statement at the [edit interfaces *gr-fpc/pic/port* unit *logical-unit-number* family *family-name*] hierarchy level.

To set the time-to-live (TTL) field that is included in the encapsulating header, include the **ttl** statement. If you explicitly configure a TTL value for the tunnel, you must configure it to be one larger than the number of hops in the tunnel. For example, if the tunnel has seven hops, you must configure a TTL value of 8.

You must configure at least one family on the logical interface. To enable MPLS over GRE tunnel interfaces, you must include the **family mpls** statement in the GRE interface configuration. In addition, you must include the appropriate statements at the [edit

protocols] hierarchy level to enable Resource Reservation Protocol (RSVP), MPLS, and label-switched paths (LSPs) over GRE tunnels. Unicast tunnels are bidirectional.

A configured tunnel cannot go through Network Address Translation (NAT) at any point along the way to the destination. For more information, see “Examples: Configuring Unicast Tunnels” on page 1104 and the *JUNOS MPLS Applications Configuration Guide*.

For a GRE tunnel, the default is to set the ToS bits in the outer IP header to all zeros. To have the Routing Engine copy the ToS bits from the inner IP header to the outer, include the **copy-tos-bits-to-outer-ip-header** statement. (This inner-to-outer ToS bits copying is already the default behavior for IP-IP tunnels.)

For GRE tunnel interfaces on Adaptive Services or MultiServices interfaces, you can configure additional tunnel attributes, as described in the following sections:

- Configuring a Key Number on GRE Tunnels on page 1095
- Enabling Fragmentation on GRE Tunnels on page 1096
- Specifying an MTU Setting for the Tunnel on page 1096
- Configuring a GRE Tunnel to Copy ToS Bits to the Outer IP Header on page 1097
- Configuring Packet Reassembly on page 1097

Configuring a Key Number on GRE Tunnels

For Adaptive Services and MultiServices interfaces on M-series and T-series routing platforms, you can assign a key value to identify an individual traffic flow within a GRE tunnel, as defined in RFC 2890, *Key and Sequence Number Extensions to GRE*. However, only one key is allowed for each tunnel source and destination pair.

Each IP version 4 (IPv4) packet entering the tunnel is encapsulated with the GRE tunnel key value. Each IPv4 packet exiting the tunnel is verified by the GRE tunnel key value and de-encapsulated. The Adaptive Services or MultiServices PIC drops packets that do not match the configured key value.

To assign a key value to a GRE tunnel interface, include the **key** statement:

```
key number;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number* tunnel]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* tunnel]

The key number can be 0 through 4,294,967,295. You must configure the same GRE tunnel key value on tunnel endpoints.

The following example illustrates the use of the key statement in a GRE tunnel configuration:

```
interfaces {
  gr-1/2/0 {
```

```

    unit 0 {
      tunnel {
        source 10.58.255.193;
        destination 10.58.255.195;
        key 1234;
      }
      ...
      family inet {
        mtu 1500;
        address 10.200.0.1/30;
        ...
      }
    }
  }
}

```

Enabling Fragmentation on GRE Tunnels

For GRE tunnel interfaces on Adaptive Services and MultiServices interfaces only, you can enable fragmentation of IPv4 packets in GRE tunnels.

By default, IPv4 traffic transmitted over GRE tunnels is not fragmented. To enable fragmentation of IPv4 packets in GRE tunnels, include the `clear-dont-fragment-bit` statement:

```
clear-dont-fragment-bit;
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

When you include the `clear-dont-fragment-bit` statement in the configuration, the don't-fragment (DF) bit is cleared on all packets, even packets that do not exceed the tunnel maximum transmission unit (MTU). If the packet's size exceeds the tunnel's MTU value, the packet is fragmented before encapsulation. If the packet's size does not exceed the tunnel's MTU value, the packet is not fragmented.

You can also clear the DF bit in packets transmitted over IP Security (IPsec) tunnels. For more information, see “Enabling IPsec Packet Fragmentation” on page 235.

Specifying an MTU Setting for the Tunnel

To enable key numbers and fragmentation on GRE tunnels (as described in “Configuring a Key Number on GRE Tunnels” on page 1095 and “Enabling Fragmentation on GRE Tunnels” on page 1096), you must also specify an MTU setting for the tunnel.

To specify an MTU setting for the tunnel, include the `mtu` statement:

```
mtu bytes;
```


You can include this statement at the following hierarchy levels:

- [edit interfaces *gr-fpc/pic/port* unit *logical-unit-number* family inet]
- [edit logical-system *logical-system-name* interfaces *gr-fpc/pic/port* unit *logical-unit-number* family inet]

For more information about MTU settings, see the *JUNOS Network Interfaces Configuration Guide*.

Configuring a GRE Tunnel to Copy ToS Bits to the Outer IP Header

Unlike IP-IP tunnels, GRE tunnels do not copy the ToS bits to the outer IP header by default. To have the Routing Engine copy the inner ToS bits to the outer IP header (which is required for some tunneled routing protocols) on packets sent by the Routing Engine, include the **copy-tos-to-outer-ip-header** statement at the logical unit hierarchy level of a GRE interface. This example copies the inner ToS bits to the outer IP header on a GRE tunnel:

```
[edit interfaces]
gr-0/0/0 {
  unit 0 {
    copy-tos-to-outer-ip-header;
    family inet;
  }
}
```

Configuring Packet Reassembly

On GRE tunnel interfaces only, you can enable reassembly of fragmented tunnel packets. To activate this capability, include the **reassemble-packets** statement:

```
reassemble-packets;
```

You can configure this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

For each tunnel you configure on the interface, you can enable or disable fragmentation of GRE packets by including the **allow-fragmentation** or **do-not-fragment** statement:

```
allow-fragmentation;
do-not-fragment;
```

You can configure these statements at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number* tunnel]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* tunnel]

If you configure **allow-fragmentation** on a tunnel, it clears the DF bit in the outer IP header, enabling post fragmentation of GRE-encapsulated packets if the packet size exceeds the maximum transmission unit (MTU) value for the egress interface. By default, packets that exceed the MTU size are dropped and post fragmentation of GRE packets is disabled.



NOTE: Whenever you configure **allow-fragmentation** on a tunnel, you must also include either the **tunnel key** or the **clear-dont-fragment-bit** statement. This configuration enables the router to send affected packets to the PIC so that the correct IP header can be placed in the fragments. Otherwise, on the reassembly side some packets might be lost when fragments arrive in the PIC out of sequence at high speeds.

Restricting Tunnels to Multicast Traffic

For interfaces that carry IPv4 or IP version 6 (IPv6) traffic, you can configure a tunnel interface to allow multicast traffic only. To configure a multicast-only tunnel, include the **multicast-only** statement:

```
multicast-only;
```

You can configure this statement at the following hierarchy levels:

- [edit interfaces *interface-name* unit *logical-unit-number* family *family*]
- [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* family *family*]

Multicast tunnels filter all unicast packets; if an incoming packet is not destined for a 224/8 or greater prefix, the packet is dropped and a counter is incremented.

You can configure this property on GRE, IP-IP, PIM, and multicast tunnel (mt) interfaces only.



NOTE: If your routing platform has a Tunnel Services PIC, the JUNOS software automatically configures one multicast tunnel interface (**mt**) for each virtual private network (VPN) you configure. You do not need to configure multicast tunnel interfaces.

Configuring Logical Tunnel Interfaces

Logical tunnel (lt-) interfaces provide quite different services depending on the host routing platform:

- On M-series and T-series routing platforms, logical tunnel interfaces allow you to connect logical systems, virtual routers, or VPN instances. The router must be equipped with a Tunnel Services PIC or an Adaptive Services Module (only available on M7i routers). For more information on the latter applications, see the *JUNOS VPNs Configuration Guide*.

- On J-series Services Routers, *lt*-interfaces have a completely different function; they enable you to change class-of-service (CoS) classifications and header bits.

For more information, see the following sections:

- Connecting Logical Systems on page 1099
- Configuring Logical Tunnels on J-series Platforms on page 1100

Connecting Logical Systems

To connect two logical systems, you configure a logical tunnel interface on both logical systems. Then you configure a peer relationship between the logical tunnel interfaces, thus creating a point-to-point connection.

To configure a point-to-point connection between two logical systems, configure the logical tunnel interface by including the *lt-fpc/pic/port* statement:

```
lt-fpc/pic/port {
  unit logical-unit-number {
    encapsulation encapsulation;
    peer-unit unit-number; # peering logical system unit number
    dlci dlci-number;
    family (inet | inet6 | iso | mpls);
  }
}
```

You can include this statement at the following hierarchy levels:

- [edit interfaces]
- [edit logical-systems *logical-system-name* interfaces]

When configuring logical tunnel interfaces, note the following:

- You can configure each logical tunnel interface with one of the following encapsulation types: Ethernet, Ethernet circuit cross-connect (CCC), Ethernet VPLS, Frame Relay, Frame Relay CCC, VLAN, VLAN CCC, or VLAN VPLS.
- You can configure the IP, IPv6, International Organization for Standardization (ISO), or MPLS protocol family.
- The peering logical interfaces must belong to the same logical tunnel interface derived from the Tunnel Services PIC or Adaptive Services Module.
- You can configure only one peer unit for each logical interface. For example, unit 0 cannot peer with both unit 1 and unit 2.
- To enable the logical tunnel interface, you must configure at least one physical interface statement.
- Logical tunnels are not supported with Adaptive Services, MultiServices, or Link Services PICs (but they are supported on the Adaptive Services Module on M7i routers, as noted above).
- On M-series routers other than the M40e router, logical tunnel interfaces require an Enhanced Flexible PIC Concentrator (FPC).

For more information about configuring logical systems, see the *JUNOS Routing Protocols Configuration Guide*.

Configuring Logical Tunnels on J-series Platforms

On J-series Services Routers, you can configure the `lt` interface to provide class-of-service (CoS) support for data link switching (DLSw) traffic and real-time performance monitoring (RPM) probe packets.

Within a J-series Services Router, packets are routed to this internal interface for services. The `lt` interface is an internal interface only and is not associated with a physical medium or PIM. You must configure the interface for it to perform CoS for DLSW and RPM services. For more information, see the *J-series Services Router Advanced WAN Access Configuration Guide*.



NOTE: The `lt` interface on the J-series Services Router does not support logical systems.

Configuring Tunnel Interfaces for Routing Table Lookup

To configure tunnel interfaces to facilitate routing table lookups for VPNs, you specify a tunnel's endpoint IP addresses and associate them with a routing instance that belongs to a particular routing table. This enables the JUNOS software to search in the appropriate routing table for the route prefix, because the same prefix can appear in multiple routing tables. To configure the destination VPN, include the `routing-instance` statement:

```
routing-instance {
  destination routing-instance-name;
}
```

You can include this statement at the following hierarchy levels:

- [edit interfaces *gr-fpc/pic/port* unit *logical-unit-number* tunnel]
- [edit logical-systems *logical-system-name* interfaces *gr-fpc/pic/port* unit *logical-unit-number* tunnel]

This configuration indicates that the tunnel's destination address is in routing instance *routing-instance-name*. By default, the tunnel route prefixes are assumed to be in the default Internet routing table `inet.0`.



NOTE: If you configure a virtual loopback tunnel interface and the `vrf-table-label` statement on the same routing instance, the `vrf-table-label` statement takes precedence over the virtual loopback tunnel interface. For more information, see “Configuring Virtual Loopback Tunnels for VRF Table Lookup” on page 1101.

For more information about VPNs, see the *JUNOS VPNs Configuration Guide*.

Configuring Virtual Loopback Tunnels for VRF Table Lookup

To enable egress filtering, you can either configure filtering based on the IP header, or you can configure a virtual loopback tunnel on routers equipped with a Tunnel PIC. Table 23 on page 1101 describes each method.

Table 23: Methods for Configuring Egress Filtering

Method	Interface Type	Configuration Guidelines	Comments
Filter traffic based on the IP header	Nonchannelized Point-to-Point Protocol / High Level Data Link Control (PPP/HDLC) core-facing SONET/SDH interfaces	Include the <code>vrf-table-label</code> statement at the [edit <code>routing-instances instance-name</code>] hierarchy level. For more information, see the <i>JUNOS VPNs Configuration Guide</i> .	You cannot include the <code>vrf-table-label</code> statement when configuring the 10-port E1 PIC, aggregated interfaces, Fast Ethernet 12-port and 48-port PIC, Gigabit Ethernet 4-port PIC, or Gigabit Ethernet intelligent queuing (IQ) PIC. There is no restriction on customer-edge (CE) router-to-provider edge (PE) router interfaces.
Configure a virtual loopback tunnel on routers equipped with a Tunnel PIC	All interfaces	See the guidelines in this section.	Router must be equipped with a Tunnel PIC. There is no restriction on the type of core-facing interface used or CE router-to-PE router interface used. You cannot configure a virtual loopback tunnel and the <code>vrf-table-label</code> statement at the same time.

You can configure a virtual loopback tunnel to facilitate VRF table lookup based on MPLS labels. You might want to enable this functionality so you can do either of the following:

- Forward traffic on a PE router to CE device interface, in a shared medium, where the CE device is a Layer 2 switch without IP capabilities (for example, a metro Ethernet switch).

The first lookup is done based on the VPN label to determine which VRF table to refer to, and the second lookup is done on the IP header to determine how to forward packets to the correct end hosts on the shared medium.

- Perform egress filtering at the egress PE router.

The first lookup on the VPN label is done to determine which VRF table to refer to, and the second lookup is done on the IP header to determine how to filter and forward packets. You can enable this functionality by configuring output filters on the VRF interfaces.

To configure a virtual loopback tunnel to facilitate VRF table lookup based on MPLS labels, you specify a virtual loopback tunnel interface name and associate it with a routing instance that belongs to a particular routing table. The packet loops back through the virtual loopback tunnel for route lookup. To specify a virtual loopback tunnel interface name, you configure the virtual loopback tunnel interface at the `[edit interfaces]` hierarchy level and include the `family inet` and `family mpls` statements:

```
vt-fpc/pic/port {
  unit 0 {
    family inet;
    family mpls;
  }
  unit 1 {
    family inet;
  }
}
```

To associate the virtual loopback tunnel with a routing instance, include the virtual loopback tunnel interface name at the `[edit routing-instances]` hierarchy level:

```
interface vt-fpc/pic/port;
```



NOTE: For the virtual loopback tunnel interface, none of the logical interface statements are valid, except for the `family` statement; in particular, you cannot configure IPv4 or IPv6 addresses on these interfaces. Also, virtual loopback tunnels do not support class-of-service (CoS) configurations.

Configuring PIM Tunnels

PIM tunnels are enabled automatically on routers that have a tunnel PIC and on which you enable PIM sparse mode. You do not need to configure the tunnel interface.

PIM tunnels are unidirectional.

In PIM sparse mode, the first-hop router encapsulates packets destined for the rendezvous point (RP) router. The packets are encapsulated with a unicast header and are forwarded through a unicast tunnel to the RP. The RP then de-encapsulates the packets and transmits them through its multicast tree. To perform the encapsulation and de-encapsulation, the first-hop and RP routers must be equipped with Tunnel PICs.

The JUNOS software creates two interfaces to handle PIM tunnels:

- **pe**—Encapsulates packets destined for the RP. This interface is present on the first-hop router.
- **pd**—De-encapsulates packets at the RP. This interface is present on the RP.



NOTE: The `pe` and `pd` interfaces do not support class-of-service (CoS) configurations.

Configuring IPv6-over-IPv4 Tunnels

If you have a Tunnel PIC installed in your router, you can configure IPv6-over-IPv4 tunnels. To do this, you configure a unicast tunnel across an existing IPv4 network infrastructure. IPv6 packets are encapsulated in IPv4 headers and sent across the IPv4 infrastructure through the configured tunnel. You manually configure configured tunnels on each end point.

IPv6-over-IPv4 tunnels are defined in RFC 2893, *Transition Mechanisms for IPv6 Hosts and Routers*. For information about configuring a unicast tunnel, see “Configuring Unicast Tunnels” on page 1093. For an IPv6-over-IPv4 tunnel configuration example, see “Example: Configuring an IPv6-over-IPv4 Tunnel” on page 1106.

Configuring Dynamic Tunnels

A VPN that travels through a non-MPLS network requires a GRE tunnel. This tunnel can be either a static tunnel or a dynamic tunnel. A static tunnel is configured manually between two PE routers. A dynamic tunnel is configured using BGP route resolution.

When a router receives a VPN route that resolves over a BGP next hop that does not have an MPLS path, a GRE tunnel can be created dynamically, allowing the VPN traffic to be forwarded to that route. Only GRE IPv4 tunnels are supported.

To configure a dynamic tunnel between two PE routers, include the `dynamic-tunnels` statement:

```
dynamic-tunnels tunnel-name {
    destination-networks prefix;
    source-address address;
    tunnel-type type-of-tunnel;
}
```

You can configure this statement at the following hierarchy levels:

- [edit routing-options]
- [edit routing-instances *routing-instance-name* routing-options]
- [edit logical-systems *logical-system-name* routing-options]
- [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* routing-options]

For more information about configuring routing options or BGP, see the *JUNOS Routing Protocols Configuration Guide*. For more information about VPNs, see the *JUNOS VPNs Configuration Guide*.

Configuring Tunnel Interfaces on MX-series Routers

The MX-series Ethernet Services Routers support Dense Port Concentrators (DPCs) with built-in Ethernet ports and does not support Tunnel Services PICs. To create tunnel interfaces on an MX-series router, you configure a DPC and the corresponding Packet Forwarding Engine by including the **tunnel-services** statement at the **[edit chassis fpc slot-number pic pic-number]** hierarchy level. For *slot-number*, specify the number of the DPC, and for *pic-number*, specify the number of the Packet Forwarding Engine. Each DPC includes four Packet Forwarding Engines.

You can also specify the amount of bandwidth to allocate for tunnel traffic on each Packet Forwarding Engine by including the **bandwidth** statement at the **[edit chassis fpc slot-number pic pic-number]** hierarchy level. For more information, see the *JUNOS System Basics Configuration Guide*.

Examples: Configuring Unicast Tunnels

Configure two unnumbered IP-IP tunnels:

```
[edit interfaces]
ip-0/3/0 {
  unit 0 {
    tunnel {
      source 192.168.4.18;
      destination 192.168.4.253;
    }
    family inet;
  }
  unit 1 {
    tunnel {
      source 192.168.4.18;
      destination 192.168.4.254;
    }
    family inet;
  }
}
```

Configure numbered tunnel interfaces by including an address at the **[edit interfaces ip-0/3/0 unit (0 | 1) family inet]** hierarchy level:

```
[edit interfaces]
ip-0/3/0 {
  unit 0 {
    tunnel {
      source 192.168.4.18;
      destination 192.168.4.253;
    }
    family inet {
      address 10.5.5.1/30;
    }
  }
  unit 1 {
    tunnel {
```



```

        source 192.168.4.18;
        destination 192.168.4.254;
    }
    family inet {
        address 10.6.6.100/30;
    }
}

```

Configure an MPLS over GRE tunnel by including the `family mpls` statement at the [edit interfaces gr-1/2/0 unit 0] hierarchy level:

```

[edit interfaces]
gr-1/2/0 {
    unit 0 {
        tunnel {
            source 192.168.1.1;
            destination 192.168.1.2;
        }
        family inet {
            address 10.1.1.1/30;
        }
        family mpls;
    }
}

```

Example: Configuring a Virtual Loopback Tunnel for VRF Table Lookup

Configure a virtual loopback tunnel for VRF table lookup:

```

[edit routing-instances]
routing-instance-1 {
    instance-type vrf;
    interface vt-1/0/0.0;
    interface so-0/2/2.0;
    route-distinguisher 2:3;
    vrf-import VPN-A-import;
    vrf-export VPN-A-export;
    routing-options {
        static {
            route 10.0.0.0/8 next-hop so-0/2/2.0;
        }
    }
}
routing-instance-2 {
    instance-type vrf;
    interface vt-1/0/0.1;
    interface so-0/3/2.0;
    route-distinguisher 4:5;
    vrf-import VPN-B-import;
    vrf-export VPN-B-export;
    routing-options {
        static {
            route 10.0.0.0/8 next-hop so-0/3/2.0;
        }
    }
}

```

```

    }
  }
[edit interfaces]
vt-1/0/0 {
  unit 0 {
    family inet;
    family mpls;
  }
  unit 1 {
    family inet;
  }
}

```

Example: Configuring an IPv6-over-IPv4 Tunnel

Configure a tunnel on both sides of the connection.

Configuration on Router 1

```

[edit]
interfaces {
  gr-1/0/0 {
    unit 0 {
      tunnel {
        source 10.19.2.1;
        destination 10.19.3.1;
      }
      family inet6 {
        address 2001:DB8:1:1/126;
      }
    }
  }
}

```

Configuration on Router 2

```

[edit]
interfaces {
  gr-1/0/0 {
    unit 0 {
      tunnel {
        source 10.19.3.1;
        destination 10.19.2.1;
      }
      family inet6 {
        address 2001:DB8:2:1/126;
      }
    }
  }
}

```

Example: Configuring Logical Tunnels

Configure three logical tunnels:

```

[edit interfaces]
lt-4/2/0 {

```

```

    description "Logical tunnel interface connects three logical systems";
}
[edit logical-systems]
lr1 {
  interfaces lt-4/2/0 {
    unit 12 {
      peer-unit 21; #Peering with lr2
      encapsulation frame-relay;
      dlci 612;
      family inet;
    }
    unit 13 {
      peer-unit 31; #Peering with lr3
      encapsulation frame-relay-ccc;
      dlci 613;
    }
  }
}
lr2 {
  interfaces lt-4/2/0 {
    unit 21 {
      peer-unit 12; #Peering with lr1
      encapsulation frame-relay-ccc;
      dlci 612;
    }
    unit 23 {
      peer-unit 32; #Peering with lr3
      encapsulation frame-relay;
      dlci 623;
    }
  }
}
lr3 {
  interfaces lt-4/2/0 {
    unit 31 {
      peer-unit 13; #Peering with lr1
      encapsulation frame-relay;
      dlci 613;
      family inet;
    }
    unit 32 {
      peer-unit 23; #Peering with lr2
      encapsulation frame-relay-ccc;
      dlci 623;
    }
  }
}
}

```


Chapter 61

Summary of Tunnel Services Configuration Statements

The following sections explain each of the tunnel services statements. The statements are organized alphabetically.

allow-fragmentation

Syntax	allow-fragmentation;
Hierarchy Level	[edit interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Enable fragmentation of generic routing encapsulation (GRE) encapsulated packets regardless of maximum transmission unit (MTU) value.
Default	By default, the GRE-encapsulated packets are dropped if the packet size exceeds the MTU setting of the egress interface.
Usage Guidelines	See “Configuring Packet Reassembly” on page 1097.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	reassemble-packets

backup-destination

Syntax	backup-destination <i>address</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For tunnel interfaces, specify the remote address of the backup tunnel.
Options	<i>address</i> —Address of the remote side of the connection.
Usage Guidelines	See “Configuring IPsec Tunnel Redundancy” on page 781.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	destination

copy-tos-to-outer-ip-header

Syntax	copy-tos-to-outer-ip-header;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 8.2.
Description	For GRE tunnel interfaces only, enable the inner IP header’s ToS bits to be copied to the outer IP packet header.
Default	If you omit this statement, the ToS bits in the outer IP header are set to 0.
Usage Guidelines	See “Configuring a GRE Tunnel to Copy ToS Bits to the Outer IP Header” on page 1097.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination

See the following sections:

- destination (Tunnel Remote End) on page 1111
- destination (Routing Instance) on page 1111

destination (Tunnel Remote End)

Syntax	<code>destination address;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For tunnel interfaces, specify the remote address of the tunnel.
Options	<i>destination-address</i> —Address of the remote side of the connection.
Usage Guidelines	See “Configuring Unicast Tunnels” on page 1093, “Configuring Traffic Sampling” on page 801, and “Configuring Flow Monitoring” on page 809.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination (Routing Instance)

Syntax	<code>destination routing-instance-name;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel routing-instance]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the destination routing instance that points to the routing table containing the tunnel destination address.
Default	The default Internet routing table <code>inet.0</code> .
Usage Guidelines	See “Configuring Tunnel Interfaces for Routing Table Lookup” on page 1100.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

destination-networks

Syntax	<code>destination-networks prefix;</code>
Hierarchy Level	[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit logical-systems <i>logical-system-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit routing-instances <i>routing-instance-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit routing-options dynamic-tunnels <i>tunnel-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Create a tunnel for routes in these destination networks.
Options	<i>prefix</i> —Destination prefix of network.
Usage Guidelines	See “Configuring Dynamic Tunnels” on page 1103.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

do-not-fragment

Syntax	<code>do-not-fragment;</code>
Hierarchy Level	[edit interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Disable fragmentation of GRE-encapsulated packets.
Default	By default, fragmentation is disabled.
Usage Guidelines	See “Configuring Packet Reassembly” on page 1097.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	reassemble-packets

dynamic-tunnels

Syntax	dynamic-tunnels <i>tunnel-name</i> { destination-networks <i>prefix</i> ; source-address <i>address</i> ; tunnel-type <i>type-of-tunnel</i> ; }
Hierarchy Level	[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> routing-options], [edit logical-systems <i>logical-system-name</i> routing-options], [edit routing-instances <i>routing-instance-name</i> routing-options], [edit routing-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure a dynamic tunnel between two provider edge (PE) routers.
Options	<i>tunnel-name</i> —Name of the dynamic tunnel. The statements are explained separately in this chapter.
Usage Guidelines	See “Configuring Dynamic Tunnels” on page 1103.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

interfaces

Syntax	interfaces { ... }
Hierarchy Level	[edit]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure interfaces on the br.
Default	The management and internal Ethernet interfaces are automatically configured. You must configure all other interfaces.
Usage Guidelines	See the <i>JUNOS Network Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

key

Syntax	<code>key number;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For Adaptive Services and MultiServices interfaces on M-series and T-series routing platforms, identify an individual traffic flow within a tunnel, as defined in RFC 2890, <i>Key and Sequence Number Extensions to GRE</i> .
Options	<i>number</i> —Value of the key. Range: 0 through 4,294,967,295
Usage Guidelines	See “Configuring a Key Number on GRE Tunnels” on page 1095.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

multicast-only

Syntax	<code>multicast-only;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the unit and family so that the interface can transmit and receive multicast traffic only. You can configure this property on the IP family only.
Usage Guidelines	See “Restricting Tunnels to Multicast Traffic” on page 1098.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	tunnel

peer-unit

Syntax	<code>peer-unit <i>unit-number</i>;</code>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure a peer relationship between two logical systems.
Options	<i>unit-number</i> —Peering logical system unit number.
Usage Guidelines	See “Configuring Logical Tunnel Interfaces” on page 1098.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

reassemble-packets

Syntax	<code>reassemble-packets;</code>
Hierarchy Level	[edit interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>gr-fpc/pic/port</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Enable reassembly of fragmented tunnel packets on generic routing encapsulation (GRE) tunnel interfaces.
Usage Guidelines	See “Configuring Packet Reassembly” on page 1097.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

routing-instance

Syntax	routing-instance { destination <i>routing-instance-name</i> ; }
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the destination routing instance that points to the routing table containing the tunnel destination address.
Default	The default Internet routing table inet.0.
Usage Guidelines	See “Configuring Tunnel Interfaces for Routing Table Lookup” on page 1100.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

routing-instances

Syntax	routing-instances <i>routing-instance-name</i> { ... }
Hierarchy Level	[edit], [edit logical-systems <i>logical-system-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure an additional routing entity for a router. You can create multiple instances of BGP, IS-IS, OSPF, OSPF version 3 (OSPFv3), and RIP for a router.
Default	Routing instances are disabled for the router.
Options	<i>routing-instance-name</i> —Name of the routing instance, a maximum of 31 characters. The remaining statements are explained separately.
Usage Guidelines	See the <i>JUNOS Routing Protocols Configuration Guide</i> and the <i>JUNOS Policy Framework Configuration Guide</i> .
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

routing-options

Syntax	routing-options { ... }
Hierarchy Level	[edit], [edit logical-systems <i>logical-system-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i>], [edit routing-instances <i>routing-instance-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure protocol-independent routing properties.
Usage Guidelines	See the <i>JUNOS Routing Protocols Configuration Guide</i> .
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

source

Syntax	source <i>source-address</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Specify the source address of the tunnel.
Default	If you do not specify a source address, the tunnel uses the unit's primary address as the source address of the tunnel.
Options	<i>source-address</i> —Address of the local side of the tunnel. This is the address that is placed in the outer IP header's source field.
Usage Guidelines	See “Tunnel Interfaces Configuration Guidelines” on page 1093.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

source-address

Syntax	source-address <i>address</i> ;
Hierarchy Level	[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit logical-systems <i>logical-system-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit routing-instances <i>routing-instance-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit routing-options dynamic-tunnels <i>tunnel-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure the tunnel source address.
Options	<i>address</i> —Name of the source address.
Usage Guidelines	See “Configuring Dynamic Tunnels” on page 1103.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

ttl

Syntax	ttl <i>value</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>number</i> tunnel]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Set the time-to-live value bit in the header of the outer IP packet.
Options	<i>value</i> —Time-to-live value. Range: 0 through 255 Default: 64
Usage Guidelines	See “Tunnel Interfaces Configuration Guidelines” on page 1093.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

tunnel

Syntax	<pre>tunnel { allow-fragmentation; backup-destination <i>address</i>; destination <i>destination-address</i>; do-not-fragment; key <i>number</i>; routing-instance { destination <i>routing-instance-name</i>; } source <i>source-address</i>; ttl <i>number</i>; }</pre>
Hierarchy Level	<pre>[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]</pre>
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>Configure a tunnel. You can use the tunnel for unicast and multicast traffic or just for multicast traffic. You can also use tunnels for encrypted traffic or virtual private networks (VPNs).</p> <p>The statements are explained separately.</p>
Usage Guidelines	See “Encryption Interfaces Configuration Guidelines” on page 773 and “Tunnel Interfaces Configuration Guidelines” on page 1093.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	<i>JUNOS VPNs Configuration Guide</i>

tunnel-type

Syntax	tunnel-type <i>type</i> ;
Hierarchy Level	[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit logical-systems <i>logical-system-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit routing-instances <i>routing-instance-name</i> routing-options dynamic-tunnels <i>tunnel-name</i>], [edit routing-options dynamic-tunnels <i>tunnel-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Select the dynamic tunnel type.
Options	<i>type</i> —Tunnel type. Generic routing encapsulation (GRE) is supported.
Usage Guidelines	See “Configuring Dynamic Tunnels” on page 1103.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.

unit

Syntax	<pre> unit <i>logical-unit-number</i> { peer-unit <i>unit-number</i>; reassemble-packets; tunnel { allow-fragmentation; backup-destination <i>address</i>; destination <i>destination-address</i>; do-not-fragment; key <i>number</i>; routing-instance { destination <i>routing-instance-name</i>; } source <i>source-address</i>; ttl <i>number</i>; } } </pre>
Hierarchy Level	[edit interfaces <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Configure a logical interface on the physical device. You must configure a logical interface to be able to use the physical device.
Options	<p><i>logical-unit-number</i>—Number of the logical unit.</p> <p>Range: 0 through 16,384</p> <p>The remaining statements are explained separately.</p>
Usage Guidelines	See “Tunnel Interfaces Configuration Guidelines” on page 1093.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Network Interfaces Configuration Guide</i> for other statements that do not affect services interfaces.

Part 10

Index

- Index on page 1125
- Index of Statements and Commands on page 1145

Index

Symbols

#, comments in configuration statements.....	liv
(), in syntax descriptions.....	liv
< >, in syntax descriptions.....	liv
[], in configuration statements.....	liv
{ }, in configuration statements.....	liv
(pipe), in syntax descriptions.....	liv

A

AACL	
action statements.....	708
applications.....	707
example configuration.....	709
match conditions.....	707
rules.....	709
aacl-fields statement.....	728
accept	
action.....	801
accounting statement	
flow monitoring.....	846
usage guidelines.....	837
acknowledge-retries statement.....	1017
usage guidelines.....	994
acknowledge-timer statement.....	1018
usage guidelines.....	994
action-red-differential-delay statement.....	1018
usage guidelines.....	995
activation priority.....	401
activation-priority statement.....	407
usage guidelines.....	401
adaptive-services-pics statement.....	457
usage guidelines.....	906
address statement	
APPID	
usage guidelines.....	678
application rule.....	685
DFC.....	951
usage guidelines.....	934
encryption.....	783
usage guidelines.....	773
flow monitoring.....	847
usage guidelines.....	801

interfaces.....	489
usage guidelines.....	478
link services.....	1019
usage guidelines.....	978
NAT.....	151
usage guidelines.....	130
voice services.....	408
usage guidelines.....	394
VoIP	
usage guidelines.....	399
address-range statement	
NAT.....	152
administrative statement	
BGF.....	514
admission-control statement.....	620
advertise-interval statement.....	749
aggregate-export-interval statement.....	847
usage guidelines.....	837
aggregation statement.....	187
flow monitoring.....	848
usage guidelines.....	180, 814
alert (system logging severity level).....	295, 452, 480
algorithm statement.....	515
ALGs	
application protocols.....	59
configuring.....	60
definition.....	59
allow-fragmentation statement.....	1109
usage guidelines.....	1097
allow-ip-options statement.....	118
usage guidelines.....	110
allow-multicast statement.....	458
usage guidelines.....	453
allowed-destinations statement.....	952
usage guidelines.....	935
analyzer-address statement.....	913
usage guidelines.....	904
analyzer-id statement.....	913
usage guidelines.....	904
anomaly checklist.....	42
anti-replay-window-size statement	
usage guidelines.....	236
any (system logging severity level).....	295, 452, 479
APPID	
example configuration.....	683
application layer gateways <i>See</i> ALGs	

application protocol		
definition.....	59	
application statement.....	97, 686	
APPID		
usage guidelines.....	676	
usage guidelines.....	60	
application-data-inactivity-detection statement.....	516	
application-group statement.....	687	
APPID		
usage guidelines.....	679	
application-group-any statement.....	712	
AACL		
usage guidelines.....	707	
application-groups statement.....	687, 712	
AACL		
usage guidelines.....	707	
APPID		
usage guidelines.....	679	
application-profile statement.....	429	
usage guidelines.....	424	
application-protocol statement.....	98	
usage guidelines.....	60	
application-set statement.....	99	
usage guidelines.....	70	
application-sets statement		
CoS.....	430	
usage guidelines.....	422	
IDS.....	188	
usage guidelines.....	179	
NAT.....	152	
usage guidelines.....	136	
stateful firewall.....	119	
usage guidelines.....	109	
application-system-cache-timeout statement.....	688	
APPID		
usage guidelines.....	680	
applications.....	179	
example configuration.....	93	
applications statement		
AACL.....	711	
usage guidelines.....	707	
APPID		
usage guidelines.....	679	
applications hierarchy.....	99	
usage guidelines.....	59	
applications identification.....	688	
CoS.....	430	
usage guidelines.....	422	
IDS.....	188	
usage guidelines.....	179	
NAT.....	153	
usage guidelines.....	136	
stateful firewall.....	119	
usage guidelines.....	109	
applying service set to interface.....	444	
archive-sites statement.....	914	
usage guidelines.....	905	
AS PIC		
multicast traffic.....	453	
redundancy.....	298, 483, 843	
attack detection.....	175	
audit-observed-events-returns statement.....	516	
authentication statement.....	253	
usage guidelines.....	215	
authentication-algorithm statement		
IKE.....	254	
usage guidelines.....	219	
IPsec.....	254	
usage guidelines.....	227	
authentication-method statement.....	255	
usage guidelines.....	219	
authentication-mode statement		
RPM.....	1061	
automatic statement.....	689	
APPID		
usage guidelines.....	680	
autonomous-system-type statement.....	849	
usage guidelines.....	814	
auxiliary-spi statement.....	255	
usage guidelines.....	215	
Avaya VoIP product.....	399	
B		
backup AS PIC.....	483	
backup Link Services IQ PIC.....	324	
backup-destination statement.....	784, 1110	
usage guidelines.....	781	
backup-interface statement.....	784	
usage guidelines.....	780	
backup-remote-gateway statement.....	256	
usage guidelines.....	235	
bandwidth		
and delay buffer allocation.....	340	
guaranteed.....	340, 343	
base-root statement.....	517	
bearer bandwidth limit.....	401	
bearer-bandwidth-limit statement.....	409	
usage guidelines.....	401	
bgf-core statement.....	518	
BGP		
router identifier.....	1117	
braces, in configuration statements.....	liv	
brackets		
angle, in syntax descriptions.....	liv	
square, in configuration statements.....	liv	
bundle statement.....	409, 1019	
usage guidelines.....	398, 978	
by-destination statement.....	189	
usage guidelines.....	180	

by-pair statement.....	190
usage guidelines.....	180
by-source statement.....	191
usage guidelines.....	180

C

call admission control.....	401
cancel-graceful statement.....	519
capture-group statement.....	953
usage guidelines.....	933
cflowd statement.....	850
usage guidelines.....	813
CIR.....	343
circuit-weight statement.....	750
usage guidelines.....	738
cisco-interoperability statement.....	381
usage guidelines.....	323
cleanup-timeout statement.....	520
clear-don't-fragment-bit statement	
IPsec	
usage guidelines.....	234
clear-dont-fragment-bit statement	
GRE tunnel.....	490
IPsec.....	256
usage guidelines.....	235, 480, 1096
clear-ike-sas-on-pic-restart statement.....	257
usage guidelines.....	218
clear-ipsec-sas-on-pic-restart statement.....	257
usage guidelines.....	218
client-list statement.....	1062
collector statement.....	914
usage guidelines.....	905
collector-pic statement	
usage guidelines.....	906
comments, in configuration statements.....	liv
committed-burst-size statement.....	621
committed-information-rate statement.....	621
compressed RTP.....	990
example configuration.....	992
compression statement.....	410
usage guidelines.....	395, 396
compression-device statement.....	410, 1020
usage guidelines.....	398, 990
configuration	
dynamic flow capture interface.....	939
flow collector interface.....	907
flow-tap application.....	948
connection-idle-timeout statement.....	750
usage guidelines.....	741
content destinations	
DFC.....	931
flow-tap.....	944
content-destination statement.....	954
usage guidelines.....	934
context-indications statement.....	521

control source	
DFC.....	931
control-association-indications statement.....	522
control-source statement.....	955
usage guidelines.....	935
controller-address statement.....	522
controller-failure statement.....	523
controller-port statement.....	523
conventions	
text and syntax.....	liii
copy-tos-to-outer-ip-header statement.....	1110
usage guidelines.....	1097
core-dump statement.....	851
usage guidelines.....	809
CoS	
action statements.....	423
applications.....	422
example configuration.....	425
for tunnels	
GRE TOS bits.....	1097
link services interfaces.....	336, 338, 997
link services IQ interfaces.....	319
match conditions.....	422
rules.....	425
scheduler map	
configuration example.....	989
cost statement.....	751
usage guidelines.....	738
critical (system logging severity level).....	295, 452, 480
curly braces, in configuration statements.....	liv
customer support.....	lv
contacting JTAC.....	lv

D

Data inactivity detection.....	586
data link switching <i>See</i> DLSw	
data-fill statement.....	1062
data-format statement.....	915
usage guidelines.....	904
data-inactivity-detection statement.....	524
data-size statement.....	1063
usage guidelines.....	1046
datastore statement.....	622
dead peer detection (DPD) protocol.....	235
default statement.....	525
delay buffer	
calculating.....	340, 343
shaping rate.....	340, 343
delay-buffer-rate statement	
usage guidelines.....	340
delivery-function statement.....	526

description statement		
IKE.....	258	
usage guidelines.....	225	
IPsec.....	258	
usage guidelines.....	227, 230	
destination statement		
APPID		
usage guidelines.....	678	
application identification rule.....	689	
DLSw.....	751	
encryption.....	785	
usage guidelines.....	773, 781	
flow monitoring.....	852	
usage guidelines.....	801	
link services.....	1020	
usage guidelines.....	978	
tunnel.....	1111	
usage guidelines.....	1093, 1100	
VoIP		
usage guidelines.....	399	
destination-address statement		
AACL.....	713	
usage guidelines.....	707	
BGF.....	526	
CoS.....	431	
usage guidelines.....	422	
IDS.....	192	
usage guidelines.....	179	
IPsec.....	258	
usage guidelines.....	233	
NAT.....	153	
usage guidelines.....	136	
stateful firewall.....	120	
usage guidelines.....	109	
destination-address-range statement		
AACL.....	713	
usage guidelines.....	707	
IDS.....	192	
usage guidelines.....	179	
NAT.....	154	
usage guidelines.....	136	
stateful firewall.....	120	
usage guidelines.....	109	
destination-interface statement		
DLSw.....	752	
RPM.....	1064	
usage guidelines.....	1046, 1052	
destination-networks statement		
tunnel.....	1112	
usage guidelines.....	1103	
destination-pool statement.....	154	
usage guidelines.....	137	
destination-port statement		
applications.....	99	
BGF.....	527	
RPM.....	100, 1065	
usage guidelines.....	65	
destination-prefix statement.....	155, 193	
usage guidelines.....	180	
destination-prefix-ipv6 statement.....	193	
usage guidelines.....	180	
destination-prefix-list statement		
AACL.....	714	
usage guidelines.....	707	
CoS.....	431	
IDS.....	194	
NAT.....	155	
stateful firewall.....	121	
usage guidelines.....	109	
destinations statement		
flow collection.....	915	
usage guidelines.....	903	
detect statement.....	527	
DFC		
architecture.....	931	
capture group.....	933	
control source configuration.....	935	
destination configuration.....	934	
example configuration.....	939	
interface configuration.....	936	
system logging.....	937	
threshold configuration.....	937	
dh-group statement.....	259	
usage guidelines.....	220	
dial-options statement.....	491	
interfaces		
usage guidelines.....	296	
dialogs statement.....	623	
diffserv statement.....	528	
direction statement.....	260	
usage guidelines.....	213	
disable statement		
APPID		
usage guidelines.....	676, 679	
application.....	690	
application-group.....	690	
flow monitoring.....	852	
port mapping.....	690	
traffic sampling		
usage guidelines.....	803	
disable-mlppp-inner-ppp-pfc statement.....	1021	
usage guidelines.....	982	
disable-session-mirroring statement.....	528	
discard accounting		
usage guidelines.....	837	
disconnect statement.....	529	
dici statement.....	1021	
usage guidelines.....	986	

DLCIs	
multicast-capable connections.....	987
point-to-point connections.....	986
DLSw	
configuration statements.....	737
load balancing.....	738
standards supported.....	735
timers.....	739
tracing operations.....	743
dlsw statement.....	752
usage guidelines.....	738
dlsw-cos statement.....	753
usage guidelines.....	741
do-not-fragment statement	
tunnel.....	1112
usage guidelines.....	1097
documentation set	
comments on.....	lv
down statement.....	529
download statement	
APPID.....	691
usage guidelines.....	680
drop-timeout statement.....	1022
usage guidelines.....	982
dscp statement.....	432
BGF.....	530
BSG.....	624
usage guidelines.....	423
dscp-code-point statement	
RPM.....	1066
usage guidelines.....	1046
DTCP.....	931, 943
duplicates-dropped-periodicity statement.....	955
usage guidelines.....	938
dynamic authentication.....	238
dynamic CAC configuration.....	401
dynamic flow capture <i>See</i> DFC	
dynamic route insertion.....	239
dynamic rules.....	239
dynamic security associations	
usage guidelines.....	217, 218
dynamic statement.....	261
usage guidelines.....	217
Dynamic Tasking Control Protocol <i>See</i> DTCP	
dynamic tunnels	
destination.....	1112
source.....	1118
dynamic-call-admission-control statement.....	411
usage guidelines.....	401
dynamic-flow-capture statement.....	956
dynamic-tunnels statement.....	1113
usage guidelines.....	1103

E

egress-service-point statement.....	624
-------------------------------------	-----

embedded-spdf statement.....	625
emergency (system logging severity level).....	295, 452, 479
enable flow collection mode.....	906
encapsulation statement.....	412
link services.....	1023
usage guidelines.....	981
voice services	
usage guidelines.....	397
encoding statement.....	530
encryption interface.....	773
applying inbound filter.....	779
example configuration.....	779
applying outbound filter.....	778
example configuration.....	777, 778
configuring inbound filter.....	778
example configuration.....	779
configuring MTU.....	774
encryption statement.....	262
usage guidelines.....	216
encryption-algorithm statement	
IKE.....	263
usage guidelines.....	220
IPsec.....	263
usage guidelines.....	228
engine-id statement	
flow monitoring.....	853
engine-type statement.....	853
error (system logging severity level).....	295, 452, 480
ES interfaces	
example configuration.....	774
ES PIC	
apply inbound filter.....	779
PIC redundancy.....	780
redundancy	
example configuration.....	781
tunnel redundancy.....	781
es-options statement.....	785
usage guidelines.....	780
event policy	
all (tracing flag).....	455
APPID.....	683
configuration (tracing flag).....	455
database (tracing flag).....	455
events (tracing flag).....	455
policy (tracing flag).....	455
event-timestamp-notification statement.....	531
explorer-wait-time statement.....	753
usage guidelines.....	739
export-format statement.....	854
usage guidelines.....	811

F

f-max-period statement.....	412
usage guidelines.....	395

facility-override statement.....	305, 458, 492
usage guidelines.....	451
failover-cold statement.....	531
failover-warm statement.....	532
failure statement.....	533
family statement	
encryption.....	786
usage guidelines.....	773
flow monitoring.....	855
usage guidelines.....	801
interfaces.....	493
usage guidelines.....	478
link services.....	413, 1025
usage guidelines.....	978
fast-update-filters statement.....	534
file statement.....	858
BGF.....	535
border signaling gateway.....	626
traffic sampling.....	858
traffic sampling output	
usage guidelines.....	803, 805
file-specification statement.....	917
usage guidelines.....	904, 905
filename statement.....	859
filename-prefix statement.....	916
usage guidelines.....	905
files	
logging information output file.....	805
traffic sampling output files.....	803
var/log/sampled file.....	805
var/tmp/sampled.pkts file.....	803
files statement.....	859
usage guidelines.....	803
filter statement	
encryption.....	787
usage guidelines.....	779
flow monitoring.....	860
usage guidelines.....	801
filters	
used with services.....	444
firewall filters	
actions.....	801
in traffic sampling.....	801
service filters.....	482
flag statement.....	536, 627
flow aggregation.....	813
multiple flow servers.....	822
flow collector	
analyzer configuration.....	904
destination configuration.....	903
example configuration.....	907
file format configuration.....	904
interface mapping.....	905
transfer log.....	905
flow limiting.....	451
flow monitoring	
example configuration	
multiple port mirroring.....	830
next-hop groups.....	830
load balancing.....	833
overview.....	793
redundancy.....	843
flow server	
replicating flows to multiple servers.....	822
flow-active-timeout statement.....	861
usage guidelines.....	811
flow-collector statement.....	918
usage guidelines.....	901, 906
flow-export-destination statement.....	862
usage guidelines.....	811
flow-inactive-timeout statement.....	862
usage guidelines.....	811
flow-monitoring statement.....	863
flow-tap	
application.....	943
architecture.....	944
interface.....	945
permissions statement.....	946
RADIUS configuration.....	946
restrictions.....	946
security.....	946
flow-tap application	
example configuration.....	948
flow-tap statement.....	957
flow-tap-dtcp statement.....	946
flow-tap-lite statement.....	957
font conventions.....	liii
force-entry statement.....	194
usage guidelines.....	180
forwarding classes	
fragmentation.....	336
forwarding-class statement.....	382, 432
usage guidelines.....	336, 423
forwarding-options statement.....	864
usage guidelines.....	797
fragment-threshold statement	
link services.....	1026
usage guidelines.....	983
LSQ.....	383
usage guidelines.....	336
voice services.....	414
usage guidelines.....	396
fragmentation	
forwarding classes.....	336
GRE tunnels.....	1096
multiclass MLPPP.....	338
fragmentation and reassembly.....	396, 988
example configuration.....	989
fragmentation-map statement.....	383
usage guidelines.....	336

fragmentation-maps statement.....	384
usage guidelines.....	336
Frame Relay connections	
point-to-point connections.....	986
Frame Relay encapsulation	
multicast-capable connections.....	987
framework statement.....	629
FRF.12.....	396
example configuration.....	369
LFI.....	988
LSQ.....	366
FRF.15 and FRF.16.....	975
FRF.16.....	356
configuration example.....	359
from statement	
AACL.....	714
usage guidelines.....	706
border signaling gateway	
new call usage policy.....	632
new transaction policy.....	633
service class.....	634
CoS.....	433
usage guidelines.....	420
IDS.....	195
usage guidelines.....	177, 179
IPsec.....	264
usage guidelines.....	231, 233
NAT.....	156
usage guidelines.....	133, 136
stateful firewall.....	121
usage guidelines.....	108, 109
ftp statement	
flow collection.....	920
usage guidelines.....	903, 905
FTP traffic, sampling.....	808
full-cone NAT.....	135

G

g-duplicates-dropped-periodicity statement.....	958
usage guidelines.....	938
g-max-duplicates statement.....	958
usage guidelines.....	938
gateway statement	
BGF.....	537
border signaling gateway.....	635
gateway-address statement.....	541
gateway-controller statement.....	542
gateway-port statement.....	543
graceful statement.....	544
graceful-restart statement.....	545
GRE tunnels	
fragmentation.....	1096
key number.....	1095
guaranteed rate.....	343

guaranteed-rate statement	
usage guidelines.....	343

H

H.248	
properties.....	548, 567, 568, 569, 570, 571, 572, 573, 574, 577, 578
BFG.....	528
BGF.....	530
h248-options statement.....	546
h248-properties statement.....	548
h248-stack statement.....	551
h248-timers statement.....	552
hanging-termination-detection statement.....	552
hard-limit statement.....	959
usage guidelines.....	934
hard-limit-target statement.....	959
usage guidelines.....	934
hardware requirements.....	3
hardware-timestamp statement.....	1067
usage guidelines.....	1054
hello-interval statement	
L2TP.....	306
usage guidelines.....	294
hello-timer statement	
link services.....	1026
usage guidelines.....	994
hide-avps statement.....	306
usage guidelines.....	295
hint statement.....	157
history-size statement.....	1067
usage guidelines.....	1045, 1046
hold-time statement	
DLSw.....	754
host statement.....	459, 494
L2TP.....	307
usage guidelines.....	295, 451, 479
hot-standby statement.....	384

I

icmp-code statement.....	100
usage guidelines.....	63
icmp-type statement.....	101
usage guidelines.....	63
icons defined, notice.....	liii
idle-timeout statement.....	691
APPID	
usage guidelines.....	676
IDS	
action statements.....	180
applications.....	179
example configurations.....	184
match conditions.....	179
rules.....	177

ids-rule-sets statement		
usage guidelines	448	
ids-rules statement	459	
usage guidelines	448	
ignore-entry statement	194	
usage guidelines	180	
IKE	46, 218	
authentication algorithm		
usage guidelines	219	
authentication-method statement		
usage guidelines	219	
DH (Diffie-Hellman) group		
usage guidelines	220	
dynamic SAs	218	
encryption-algorithm statement		
usage guidelines	220	
lifetime		
usage guidelines	221	
mode statement		
usage guidelines	223	
policy	221	
example	226	
policy statement		
usage guidelines	221	
pre-shared-key statement		
usage guidelines	223	
proposals statement		
usage guidelines	223	
IKE security associations		
clearing	218	
ike statement	265	
usage guidelines	218	
ike-access-profile statement	460	
usage guidelines	241, 450	
inactivity-delay statement	553	
inactivity-duration statement	553	
inactivity-timeout statement	101	
BGF	554	
flow monitoring	494	
RPM	1068	
usage guidelines	68, 478	
inactivity-timer statement	554	
index statement	692	
APPID		
usage guidelines	676, 679	
info (system logging severity level)	296, 452, 480	
initial-average-ack-delay statement	555	
initiate-dead-peer-detection statement	266	
usage guidelines	236	
input statement		
flow monitoring	865	
interfaces	495	
usage guidelines	444, 481	
input-interface-index statement	866	
input-packet-rate-threshold statement	960	
usage guidelines	937	
inside and outside interfaces	446	
inside-service-interface statement		
usage guidelines	444	
interchassis LSQ failover	322	
interface preservation	327	
interface statement		
BGF	555	
DLSw	755	
encryption		
usage guidelines	773	
flow monitoring	867	
usage guidelines	827	
flow-tap	960	
usage guidelines	945	
service interface pool	613	
interface style service sets	447	
interface-map statement	922	
usage guidelines	905	
interface-service statement	460	
usage guidelines	444	
interfaces		
naming	476	
interfaces statement		
DFC	961	
usage guidelines	936	
encryption	787	
usage guidelines	773	
flow monitoring	869	
usage guidelines	801	
interfaces hierarchy	495	
usage guidelines	475	
link services	1027	
usage guidelines	975	
tunnel	1113	
usage guidelines	1093	
voice services	414	
interim-ah-scheme statement	556	
interleave-fragments statement	1027	
usage guidelines	988	
Internet Key Exchange <i>See</i> IKE		
intrachassis LSQ failover	324	
intrusion detection		
example configurations	184	
rule set	183	
tasks	175	
IP addresses		
sampling traffic from single IP addresses	807	
ip statement		
APPID		
usage guidelines	678	
application identification	692	
ip-flow-stop-detection statement	556	
IPsec		
action statements	234	
authentication statement		
usage guidelines	215	

authentication-algorithm statement	
usage guidelines.....	227
direction	
usage guidelines.....	213
dynamic authentication.....	238
dynamic endpoints interface configuration.....	242
dynamic rules.....	239
dynamic security associations	
usage guidelines.....	217
encryption	
usage guidelines.....	216
encryption-algorithm statement	
usage guidelines.....	228
ES PIC.....	773
example configuration.....	244
inbound traffic.....	779
outbound traffic.....	777
IKE.....	46
lifetime of SA.....	228
lifetime-seconds statement.....	228
match conditions.....	233
minimum configurations	
dynamic SA	211
manual SA	211
overview	46
perfect-forward-secrecy statement	
usage guidelines.....	230
policy	
overview.....	229
policy statement	
usage guidelines.....	229
proposal statement	
usage guidelines.....	227
proposals statement	
usage guidelines.....	230
protocol statement (dynamic SA)	
usage guidelines.....	229
protocol statement (manual SA)	
usage guidelines.....	214
rule sets.....	237
security associations.....	46
security parameter index	
usage guidelines.....	215
service set dynamic endpoints	
configuration.....	241
traffic.....	775
ipsec statement.....	266
usage guidelines.....	227
ipsec-inside-interface	
usage guidelines.....	239
ipsec-inside-interface statement.....	267
usage guidelines.....	233
ipsec-interface-id statement	
usage guidelines.....	242
ipsec-sa statement	
encryption.....	788
usage guidelines.....	773
ipsec-vpn-options statement.....	461
usage guidelines.....	449
ipsec-vpn-rule-sets statement	
usage guidelines.....	448
ipsec-vpn-rules statement.....	461
usage guidelines.....	448
ipv4-template statement.....	869
IPv6	
transition	
configured tunnel.....	1103
ipv6-multicast-filter statement	
usage guidelines.....	133
ipv6-multicast-interfaces statement.....	157
IPv6-over-IPv4 tunnel	
example configuration.....	1106
standards supported.....	1103
ipv6-template statement.....	869
IS-IS	
tracing operations.....	765
K	
key statement	
tunnel.....	1114
usage guidelines.....	1095
L	
L2TP	
access profile.....	292, 293
attribute-value pairs.....	295
example configuration.....	300
redundancy.....	298
timers.....	294
l2tp statement	
usage guidelines.....	287
l2tp-access-profile statement.....	307
usage guidelines.....	293
l2tp-interface-id statement	
usage guidelines.....	296
l2tp-profile statement	
usage guidelines.....	292
label-position statement.....	870
latch-deadlock-delay statement.....	557
lawful intercept architecture.....	944
learn-sip-register statement.....	102
usage guidelines.....	68
LFI.....	362, 366, 396, 988
example configuration.....	364, 369, 989

lifetime-seconds statement		logging statement.....196, 463
IKE.....267		usage guidelines.....180
usage guidelines.....221		logical interfaces
IPsec.....267		multicast-capable connections.....987
usage guidelines.....228		logical tunnels.....1098
limiting flows per service set.....451		example configuration.....1106
link fragmentation and interleaving <i>See</i> LFI		logical-system statement
link PIC redundancy.....327		RPM.....1068
link services interfaces		usage guidelines.....1045
CoS components.....336, 338, 997		loopback tunnels.....1101
example configuration.....999, 1006		LSQ bandwidth
interleave fragments.....988		oversubscribing.....340
example configuration.....989		LSQ failover
link services IQ interfaces.....364		interchassis.....322
CoS components.....319		stateful intrachassis.....324
example configuration.....354, 359		stateless intrachassis.....324
link state replication.....327		LSQ PICs.....327
link-layer overhead.....338		redundancy.....324
link services protocols.....971		lsq-failure-options statement.....385
link state replication		usage guidelines.....322
LSQ PICs.....327		
link-layer overhead		M
link services IQ interfaces.....338		manual security association.....213
link-layer-overhead statement.....385		manual statement.....269
usage guidelines.....334, 338, 347		usage guidelines.....213
link-loss statement.....557		manuals
lmi-type statement.....1028		comments on.....lv
usage guidelines.....996		map statement.....757
load balancing		match direction usage in service sets.....446
on monitoring interfaces.....833		match-direction statement
load-balance statement		AACL.....715
DLSw.....755		usage guidelines.....706
usage guidelines.....738		CoS.....433
local-certificate statement.....268		usage guidelines.....422
usage guidelines.....224		IDS.....196
local-dump statement.....870		usage guidelines.....177
usage guidelines.....824		IPsec.....269
local-gateway address statement.....308		usage guidelines.....231
usage guidelines.....293		NAT.....158
local-gateway statement.....462		usage guidelines.....133
usage guidelines.....449		stateful firewall.....122
local-id statement.....268		usage guidelines.....109
usage guidelines.....225		max-burst-size statement.....558
local-mac statement.....756		max-checked-bytes statement.....693
usage guidelines.....744		APPID
local-peer statement		usage guidelines.....680
DLSw.....756		max-concurrent-calls statement.....560
usage guidelines.....740		max-duplicates statement.....961
log output		usage guidelines.....938
adaptive services.....454		max-flows statement.....463
APPID.....682		usage guidelines.....451
traffic sampling.....805		max-packets-per-second statement.....871
log-prefix statement.....462, 496		usage guidelines.....802
L2TP.....308		maximum-age statement.....923
usage guidelines.....295, 451, 479		usage guidelines.....905

- maximum-connections statement.....1069
 - maximum-connections-per-client statement.....1069
 - maximum-contexts statement.....415
 - usage guidelines.....395
 - maximum-fuf-percentage statement.....561
 - maximum-inactivity-time statement.....562
 - maximum-net-propagation-delay statement.....563
 - maximum-send-window statement.....309
 - usage guidelines.....294
 - maximum-sessions statement.....1070
 - maximum-sessions-per-connection statement.....1070
 - maximum-synchronization-mismatches
 - statement.....563
 - maximum-synchronization-time statement.....564
 - maximum-terms statement.....564
 - maximum-waiting-delay statement.....565
 - Media Gateway Controller
 - definition.....399
 - list configuration.....400
 - media statement.....565
 - media-policy statement.....638
 - media-service statement.....566
 - media-type statement.....638
 - mediation devices
 - flow-tap.....944
 - mg-maximum-pdu-size statement.....567
 - mg-originated-pending-limit statement.....568
 - mg-provisional-response-timer-value statement.....569
 - mg-segmentation-timer statement.....570
 - mgc-maximum-pdu-size statement.....571
 - mgc-originated-pending-limit statement.....572
 - mgc-provisional-response-timer-value statement.....573
 - mgc-segmentation-timer statement.....574
 - min-checked-bytes statement.....693
 - APPID
 - usage guidelines.....680
 - minimum links
 - link services interfaces.....984
 - multilink interfaces.....984
 - minimum statement
 - BGF.....639
 - minimum-links statement.....1028
 - usage guidelines.....984
 - minimum-priority statement.....962
 - usage guidelines.....935
 - MLFR and MLPPP.....975
 - mlfr-uni-nni-bundle-options statement.....1029
 - usage guidelines.....993, 996
 - MLPPP.....351, 362
 - configuration example.....354
 - example configuration.....364
 - mode statement.....270
 - usage guidelines.....223
 - monitor statement.....575
 - monitoring statement.....872
 - usage guidelines.....810
 - moving-average-size statement.....1071
 - usage guidelines.....1046
 - MPLS
 - packets
 - passive flow monitoring.....839
 - mpls-ipv4-template statement.....873
 - mpls-template statement.....873
 - mrru statement.....1030
 - usage guidelines.....985
 - mss statement.....197
 - usage guidelines.....180
 - mtu statement.....1031
 - multicast filters
 - for IPv6 NAT.....133
 - multicast traffic
 - AS PIC.....453
 - multicast tunnels.....1098
 - multicast-address statement.....757
 - usage guidelines.....741
 - multicast-capable connections
 - Frame Relay encapsulation.....987
 - multicast-dlci statement.....1031
 - usage guidelines.....987
 - multicast-only statement.....1114
 - usage guidelines.....1098
 - multiclass MLPPP
 - fragmentation.....338
 - multilink bundles
 - fractional T1.....362
 - example configuration.....364, 366, 369
 - FRF.12.....366
 - example configuration.....369
 - MLPPP.....362
 - example configuration.....364
 - NxT1.....351, 356
 - configuration example.....354, 359
 - multilink interfaces
 - example configuration.....1002
 - minimum links.....984
 - multilink-class statement.....386
 - usage guidelines.....338
 - multilink-max-classes statement.....386
 - usage guidelines.....338
 - multiservice-options statement.....874
 - MultiServices PIC
 - hardware requirements.....33
- N**
- n391 statement.....1032
 - usage guidelines.....996
 - n392 statement.....1032
 - usage guidelines.....996
 - n393 statement.....1033
 - usage guidelines.....996

name-format statement.....	924	no-local-dump statement.....	870
usage guidelines.....	904	usage guidelines.....	824
NAT		no-preempt statement.....	759
action statements.....	137	usage guidelines.....	744
address configuration.....	130	no-rtcp-check statement.....	576
applications.....	136	no-signature-based statement.....	695
example configuration.....	139	APPID	
match conditions.....	136	usage guidelines.....	680
rule sets.....	139	no-stamp statement.....	891
twice NAT		usage guidelines.....	803
description.....	45	no-syslog statement	
type.....	135	DFC.....	962
nat-pool statement.....	575	flow monitoring.....	892
nat-rule-sets statement		usage guidelines.....	937
usage guidelines.....	448	no-termination-request statement.....	387
nat-rules statement.....	464	usage guidelines.....	322
usage guidelines.....	448	no-translation statement.....	159
nat-type statement.....	158	usage guidelines.....	137
usage guidelines.....	135	no-world-readable statement	
neighbor discovery using IPv6 NAT.....	133	flow monitoring.....	900
network-operator-id statement.....	576	usage guidelines.....	803
new-call-usage-policies statement.....	639	normal-mg-execution-time statement.....	577
new-call-usage-policy statement.....	640	normal-mgc-execution-time statement.....	578
new-call-usage-policy-set statement.....	641	notice (system logging severity level).....	296, 452, 480
new-transaction-policies statement.....	641	notice icons defined.....	liii
new-transaction-policy statement.....	642	Notification behavior.....	579
new-transaction-policy-set statement.....	643	notification-behavior statement.....	579
next-hop groups.....	825	notification-rate-limit statement.....	579
next-hop statement.....	874	notification-regulation statement.....	580
border signaling gateway.....	644	notification-targets statement.....	963
next-hop groups		usage guidelines.....	935
usage guidelines.....	827	NxT1 bundles	
usage guidelines.....	825	FRF.16.....	356
next-hop style service sets.....	447	configuration example.....	359
next-hop-group statement.....	875	MLPPP.....	351
usage guidelines.....	825, 827	configuration example.....	354
next-hop-service statement.....	465		
usage guidelines.....	444	O	
no-anti-replay statement.....	270	one-way-hardware-timestamp statement.....	1071
usage guidelines.....	236	usage guidelines.....	1052, 1054
no-application-identification statement.....	694	open-timeout statement.....	496
APPID		usage guidelines.....	478
usage guidelines.....	680	option-refresh-rate statement.....	877
no-application-system-cache statement.....	694	order statement.....	695
APPID		APPID	
usage guidelines.....	680	usage guidelines.....	678
no-clear-application-system-cache statement.....	694	output files	
APPID		logging information output file.....	805
usage guidelines.....	680	traffic sampling output files.....	803
no-core-dump statement.....	851	output statement.....	497
usage guidelines.....	809	discard accounting.....	878
no-dscp-bit-mirroring statement.....	580	flow monitoring.....	879
no-filter-check statement.....	876	port mirroring.....	879
usage guidelines.....	825	sampling.....	880
no-fragmentation statement.....	387	usage guidelines.....	444, 481
usage guidelines.....	336		

output-interface-index statement.....	881
outside-service-interface statement	
usage guidelines.....	444
overload-control statement.....	581
overload-pool statement.....	159
usage guidelines.....	137
overload-prefix statement.....	160
usage guidelines.....	137
oversubscription.....	340

P

parentheses, in syntax descriptions.....	liv
passive flow monitoring.....	793
MPLS packets.....	839
passive-monitor-mode statement.....	881
usage guidelines.....	838
password statement	
flow collection.....	926
usage guidelines.....	903, 905
peak-data-rate statement.....	582
peer statement	
DLSw.....	758
peer-unit statement	
tunnel.....	1115
usage guidelines.....	1098
per-unit-scheduler statement.....	388
usage guidelines.....	340, 343, 351, 356
perfect-forward-secrecy statement.....	271
usage guidelines.....	230
performance, monitoring.....	1046
pgcp statement	
NAT.....	160
pgcp-rule-sets statement	
usage guidelines.....	448
pgcp-rules statement	
service-set.....	466
usage guidelines.....	448
PIC types for services.....	3
pic-memory-threshold statement.....	963
usage guidelines.....	937
PIM	
tunnels.....	1102
PIR.....	340
platforms, supported.....	4
point-to-point connections	
Frame Relay encapsulation.....	986
policy statement	
IKE.....	272
usage guidelines.....	221
IPsec.....	273
usage guidelines.....	229
policy-decision-statistics-profile statement.....	729
pool statement.....	161
service interface pool.....	614
usage guidelines.....	130
pop-all-labels statement.....	882
usage guidelines.....	840
port mirroring.....	825
port statement	
cflowd	
usage guidelines.....	814
flow monitoring.....	882
NAT.....	162
usage guidelines.....	130
RPM.....	1072
TWAMP.....	1072
voice services.....	415
usage guidelines.....	395
port-mapping statement.....	696
port-mirroring statement.....	883
usage guidelines.....	825
port-range statement.....	696
APPID	
usage guidelines.....	678
ports-per-session statement.....	162
post-service-filter statement.....	497
usage guidelines.....	444
ppp-access-profile statement.....	309
usage guidelines.....	293
ppp-profile statement	
usage guidelines.....	292
pre-shared-key statement.....	273
usage guidelines.....	223
preempt statement.....	759
usage guidelines.....	744
preserve-interface statement.....	388
usage guidelines.....	327
primary statement	
link services.....	389
usage guidelines.....	325
services PIC.....	498
usage guidelines.....	483
priority statement	
DLSw.....	760
usage guidelines.....	744
probe statement	
RPM.....	1073
usage guidelines.....	1046
probe-count statement.....	1074
usage guidelines.....	1046
probe-interval statement.....	1074
usage guidelines.....	1046
probe-limit statement.....	1075
usage guidelines.....	1051, 1052
probe-server statement.....	1075
usage guidelines.....	1051
probe-type statement.....	1076
usage guidelines.....	1046
probes, for monitoring traffic.....	1046
procedural overview.....	39

profile statement	
APPID	
usage guidelines.....	679
profile statement, application identification.....	697
promiscuous statement	
DLSw.....	760
usage guidelines.....	738
proposal statement	
IKE.....	274
usage guidelines.....	218
IPsec.....	275
usage guidelines.....	227
proposals statement	
IKE.....	275
usage guidelines.....	223
IPsec.....	275
usage guidelines.....	230
protocol statement	
applications.....	103
usage guidelines.....	62
IPsec.....	276
usage guidelines.....	214, 229
protocols statement	
DLSW.....	761

Q

queue-limit-percentage statement.....	584
queues statement.....	416
usage guidelines.....	395

R

random-allocation statement.....	162
rate statement.....	884
usage guidelines.....	802, 825
reachability-cache-timeout statement.....	761
usage guidelines.....	739
Real-Time Performance Monitoring <i>See</i> RPM	
Real-Time Transport Protocol.....	990
example configuration.....	992
reassemble-packets statement.....	1115
usage guidelines.....	1097
receive-initial-pacing statement.....	762
usage guidelines.....	740
receive-options-packets statement.....	884
usage guidelines.....	838
receive-ttl-exceeded statement.....	885
usage guidelines.....	838
receive-window statement.....	310
usage guidelines.....	294
reconnect statement.....	585
red-differential-delay statement.....	1033
usage guidelines.....	995

redundancy	
AS PIC.....	483
flow monitoring.....	843
L2TP.....	298
redundancy-group statement	
DLSw.....	763
redundancy-options statement.....	389, 498
usage guidelines.....	483
reflexive reverse statement.....	434
usage guidelines.....	424
remote-gateway statement.....	276
usage guidelines.....	235
remote-id statement.....	277
usage guidelines.....	225
remote-mac statement.....	756
remote-peer statement.....	764
usage guidelines.....	738
remotely-controlled statement.....	163
report-service-change statement.....	586
request-timestamp statement.....	587
required-depth statement.....	885
usage guidelines.....	840
retransmit-interval statement.....	310
usage guidelines.....	294
retry statement.....	927
usage guidelines.....	906
retry-delay statement.....	927
usage guidelines.....	906
RFC 2890.....	1095
route statement.....	645
router identifier.....	1117
routing-instance statement	
BGF.....	587
RPM.....	1076
tunnel.....	1116
usage guidelines.....	1100
routing-instances statement	
RPM.....	1077
usage guidelines.....	1046
rpc-program-number statement.....	104
usage guidelines.....	69
RPM.....	1041, 1043
example configuration.....	1057
rpm statement.....	1077
usage guidelines.....	1052
rtp statement.....	416, 588
usage guidelines.....	395
rule statement	
AACL.....	716
usage guidelines.....	706
APPID	
usage guidelines.....	678
application identification.....	698
BGF.....	589
CoS.....	435
usage guidelines.....	420

IDS.....	198
usage guidelines.....	177
IPsec.....	278
usage guidelines.....	231
NAT.....	164
usage guidelines.....	133
stateful firewall.....	123
usage guidelines.....	108
rule-set statement	
ACL.....	717
usage guidelines.....	709
APPID	
usage guidelines.....	678
application identification.....	699
BGF.....	589
CoS.....	436
usage guidelines.....	425
IDS.....	199
usage guidelines.....	183
IPsec.....	279
usage guidelines.....	237
NAT.....	165
usage guidelines.....	139
stateful firewall.....	124
usage guidelines.....	112
run-length statement.....	886
usage guidelines.....	802, 825
 S	
sample (firewall filter action).....	801
sampled file.....	805
sampled.pkts file.....	803
sampling	
logical interface.....	802
monitoring interface.....	809
sampling rate.....	802
sampling statement	
flow monitoring.....	889
usage guidelines.....	801
sbc-utils statement.....	590, 646
scheduler map	
CoS	
configuration example.....	989
secondary statement	
link services.....	390
usage guidelines.....	325
services PIC.....	499
usage guidelines.....	483
security associations	
clearing.....	218
segmentation statement.....	591
send cflowd records to flow collector.....	906
send-notification-on-delay statement.....	592
server statement.....	1078
service filters.....	482

service interface configuration.....	444
service packages.....	35
service rules configuration.....	448
service sets	
example configuration.....	456
overview.....	34
service statement.....	499
usage guidelines.....	481
service-change statement.....	593
service-change-type statement.....	594
service-class statement.....	647
service-domain statement.....	500
usage guidelines.....	446
service-filter statement	
firewall	
usage guidelines.....	482
interfaces.....	500
usage guidelines.....	444
service-interface statement.....	311, 466
BGF.....	594
border signaling gateway	
gateway.....	648
service point.....	648
usage guidelines.....	293, 444
service-interface-pools statement.....	614
service-point statement.....	649
service-point-type statement.....	649
service-policies statement.....	650
service-port statement.....	964
usage guidelines.....	935
service-set statement.....	467, 501
usage guidelines.....	443, 481
service-state statement	
virtual BGF.....	595
virtual interface in BGF.....	596
services configuration overview.....	39
services PICs.....	3
services statement	
ACL	
usage guidelines.....	705
APPID	
usage guidelines.....	675
BGF.....	596
border signaling gateway.....	650
CoS.....	436
usage guidelines.....	419
DFC.....	964
usage guidelines.....	932
flow monitoring	
usage guidelines.....	800
flow-monitoring.....	889
IDS.....	199
usage guidelines.....	175
interfaces.....	502
usage guidelines.....	479

IPsec.....	279	source-address statement	
usage guidelines.....	209	AACL.....	718
L2TP.....	312	usage guidelines.....	707
usage guidelines.....	295	BGF.....	597
NAT.....	165	CoS.....	438
usage guidelines.....	129	usage guidelines.....	422
RPM.....	1078	flow monitoring.....	891
usage guidelines.....	1043	usage guidelines.....	810
service sets.....	468	IDS.....	201
usage guidelines.....	451	usage guidelines.....	179
stateful firewall.....	124	IPsec.....	280
usage guidelines.....	107	usage guidelines.....	233
services-options statement.....	503	NAT.....	166
usage guidelines.....	295, 478, 479	usage guidelines.....	136
session-limit statement.....	200	RPM.....	1079
usage guidelines.....	180	usage guidelines.....	1046
session-mirroring statement.....	597	stateful firewall.....	125
session-timeout statement.....	700	usage guidelines.....	109
APPID		tunnel.....	1118
usage guidelines.....	676	tunnel services	
session-trace statement.....	651	usage guidelines.....	1103
shaping-rate statement		source-address-range statement	
usage guidelines.....	334, 340, 343	AACL.....	718
shared-key statement.....	965	usage guidelines.....	707
usage guidelines.....	935	IDS.....	201
short-sequence statement.....	1034	usage guidelines.....	179
usage guidelines.....	986	NAT.....	166
signaling statement.....	652	usage guidelines.....	136
SIP configuration.....	68	stateful firewall.....	125
sip statement.....	654	usage guidelines.....	109
sip-call-hold-timeout statement.....	104	source-addresses statement	
usage guidelines.....	68	DFC.....	966
sip-stack statement.....	656	usage guidelines.....	935
sip-text statement.....	437	source-pool statement.....	167
usage guidelines.....	424	usage guidelines.....	137
sip-video statement.....	437	source-port statement	
usage guidelines.....	424	BGF.....	598
sip-voice statement.....	438	RPM.....	105
usage guidelines.....	424	usage guidelines.....	65
size statement.....	890	source-prefix statement.....	167, 202
usage guidelines.....	805	usage guidelines.....	180
snmp-command statement.....	105	source-prefix-ipv6 statement.....	202
usage guidelines.....	69	usage guidelines.....	180
soft-limit statement.....	965	source-prefix-list statement	
usage guidelines.....	934	AACL.....	719
soft-limit-clear statement.....	966	usage guidelines.....	707
usage guidelines.....	934	CoS.....	439
SONET interfaces		IDS.....	203
sampling SONET interfaces.....	806	NAT.....	168
source statement		stateful firewall.....	126
APPID		usage guidelines.....	109
usage guidelines.....	678	spi statement.....	280
application identification rule.....	701	usage guidelines.....	215
encryption.....	788	stamp option.....	805
tunnel.....	1117	stamp statement.....	891
usage guidelines.....	781, 1093	usage guidelines.....	803

state-loss statement.....	598
stateful firewall	
action statements.....	110
anomalies.....	42
applications.....	109
example configuration.....	112
match conditions.....	109
rules.....	112
stateful-firewall-rule-sets statement	
usage guidelines.....	448
stateful-firewall-rules statement.....	470
usage guidelines.....	448
statement-name statement.....	585, 586, 620
stop-detection-on-drop statement.....	599
support, technical <i>See</i> technical support	
sustained-data-rate statement.....	600
gate in packet gateway.....	601
syn-cookie statement.....	203
usage guidelines.....	180
syntax conventions.....	liii
syslog statement	
CoS.....	439
usage guidelines.....	423
flow monitoring.....	892
IDS.....	204
usage guidelines.....	180
interfaces.....	504
usage guidelines.....	479
IPsec.....	281
usage guidelines.....	234, 237
L2TP.....	314
usage guidelines.....	295
NAT.....	168
usage guidelines.....	137
service sets.....	470
usage guidelines.....	451
stateful firewall.....	126
usage guidelines.....	110
T	
t391 statement.....	1034
usage guidelines.....	996
t392 statement.....	1035
usage guidelines.....	996
target statement.....	1079
target-url statement	
usage guidelines.....	1046
tcp statement	
RPM.....	1080
tcp-mss statement.....	471
technical support	
contacting JTAC.....	lv
telephony products for J-series Services Routers.....	399
template statement	
flow monitoring.....	893

template-refresh-rate statement.....	895
term statement	
AACL.....	720
usage guidelines.....	706
border signaling gateway	
new call usage policy.....	658
new transaction policy.....	659
service-class.....	660
CoS.....	440
usage guidelines.....	420
IDS.....	205
usage guidelines.....	177
IPsec.....	282
usage guidelines.....	231
NAT.....	169
usage guidelines.....	133
stateful firewall.....	127
usage guidelines.....	108
test statement	
RPM.....	1081
usage guidelines.....	1046
test-interval statement.....	1082
usage guidelines.....	1046
TGM550 VoIP product.....	399
then statement	
AACL.....	721
usage guidelines.....	706
AACLl	
usage guidelines.....	706
border signaling gateway	
new call usage policy.....	661
new transaction policy.....	662
service-class.....	663
CoS.....	441
usage guidelines.....	420
IDS.....	207
usage guidelines.....	177
IPsec.....	283
usage guidelines.....	231
NAT.....	170
usage guidelines.....	133
stateful firewall.....	128
usage guidelines.....	108, 110
threshold statement.....	208
usage guidelines.....	180
thresholds statement	
RPM.....	1083
usage guidelines.....	1046
TIM VoIP product.....	399
time-to-live threshold.....	69
timer-c statement.....	663
timers statement.....	664
timerx statement.....	602
timestamp option.....	805
tmax-retransmission-delay statement.....	602

trace-options		
server (tracing flag)	455	
timer-events (tracing flag)	455	
traceoptions statement	665	
application identification	702	
BGF	603	
DLSw	765	
usage guidelines	743	
flow monitoring	895	
usage guidelines	805	
IPsec	284	
usage guidelines	243	
L-PDF	730	
L2TP	315	
usage guidelines	299	
services	472	
usage guidelines	906	
tracing flags		
event policy		
all	455, 683	
configuration	455	
database	455	
events	455	
policy	455	
server	455	
timer-events	455	
tracing operations		
adaptive services	453	
APPID	681	
DLSw	743	
track statement	767	
traffic	775	
inbound (decryption)	779	
IPsec, configuring	775	
monitoring	1046	
outbound (encryption)	777	
traffic sampling		
configuring	801	
disabling	803, 852	
example configurations	806	
flow aggregation	813	
FTP traffic	808	
logging information output file	805	
output files	803	
SONET interfaces	806	
traffic from single IP addresses	807	
traffic-control-profiles statement		
usage guidelines	340, 343	
traffic-management statement	604	
transactions statement	666	
transfer statement	928	
usage guidelines	904	
transfer-log-archive statement	928	
usage guidelines	905	
translated statement	171	
usage guidelines	137	
translation-type statement	172	
usage guidelines	137	
transport statement		
NAT	173	
transport-details statement	667	
traps statement	1084	
usage guidelines	1046	
trigger-link-failure statement	390	
usage guidelines	322	
trusted-ca statement	473	
usage guidelines	450	
ttl statement		
DFC	967	
usage guidelines	934	
tunnel	1118	
usage guidelines	1093	
ttl-threshold statement	106	
usage guidelines	69	
tunnel interfaces		
configuration statements	1093, 1098, 1101	
dynamic tunnels	1103	
example configuration	1104	
logical tunnels	1098	
loopback tunnels	1101	
multicast tunnels	1098	
PIM tunnels	1102	
unicast tunnels	1093	
tunnel statement	1119	
encryption	789	
usage guidelines	773	
redundancy		
usage guidelines	781	
unicast		
usage guidelines	1093	
tunnel-group statement	317	
usage guidelines	292	
tunnel-mtu statement	285	
usage guidelines	237	
tunnel-timeout statement	318	
usage guidelines	294	
tunnel-type statement	1120	
usage guidelines	1103	
tunnels		
definition	1089	
GRE		
fragmentation of	1096	
key number	1095	
interface types	1089	
twamp statement	1085	
twamp-server statement	1085	
twice NAT	45	
type statement	703	
APPID		
usage guidelines	676	

type-of-service statement.....	703, 768
APPID	
usage guidelines.....	676
usage guidelines.....	741

U

udp statement	
RPM.....	1086
unicast tunnels.....	1093
unit statement	
encryption.....	790
usage guidelines.....	773
flow monitoring.....	896
usage guidelines.....	801
interfaces.....	505
usage guidelines.....	475
link services.....	417, 1036
usage guidelines.....	975
tunnel.....	1121
usage guidelines.....	1093
Universal Unique Identifier.....	70
up statement	
BGF.....	605
url statement.....	704
APPID	
usage guidelines.....	680
use-lower-case statement.....	605
use-wildcard-response statement.....	606
username statement	
flow collection.....	929
usage guidelines.....	905
uuid statement.....	106
usage guidelines.....	70

V

var/log/sampled file.....	805
var/tmp/sampled.pkts file.....	803
variant statement.....	929
usage guidelines.....	904
version statement	
flow monitoring.....	897
usage guidelines.....	814
version9 statement.....	898
virtual loopback tunnel	
configuration guidelines.....	1100
VRF table lookup	
example configuration.....	1105
virtual-interface statement.....	606
virtual-interface-down statement.....	607
virtual-interface-indications statement.....	608
virtual-interface-up statement.....	608
voice services	
bundles.....	398
configuration.....	393

encapsulation.....	397
example configuration.....	402
interface type.....	394
voice services interfaces	
interleave fragments.....	396
VoIP	
configuration on J-series Services Routers.....	398
interface configuration.....	399

W

warm standby	
AS PIC.....	483
LSQ PIC.....	324
warm statement.....	609
warm-standby statement.....	391
warning (system logging severity level).....	296, 452, 480
world-readable statement	
flow monitoring.....	900
usage guidelines.....	803

Y

yellow-differential-delay statement.....	1037
usage guidelines.....	995

Index of Statements and Commands

A

aac1-fields statement.....	728
accounting statement	
flow monitoring.....	846
acknowledge-retries statement.....	1017
acknowledge-timer statement.....	1018
action-red-differential-delay statement.....	1018
activation-priority statement.....	407
adaptive-services-pics statement.....	457
address statement	
application rule.....	685
DFC.....	951
encryption.....	783
flow monitoring.....	847
interfaces.....	489
link services.....	1019
NAT.....	151
voice services.....	408
address-range statement	
NAT.....	152
administrative statement	
BGF.....	514
admission-control statement.....	620
advertise-interval statement.....	749
aggregate-export-interval statement.....	847
aggregation statement.....	187
flow monitoring.....	848
algorithm statement.....	515
allow-fragmentation statement.....	1109
allow-ip-options statement.....	118
allow-multicast statement.....	458
allowed-destinations statement.....	952
analyzer-address statement.....	913
analyzer-id statement.....	913
application statement.....	97, 686
application-data-inactivity-detection statement.....	516
application-group statement.....	687
application-group-any statement.....	712
application-groups statement.....	687, 712
application-profile statement.....	429
application-protocol statement.....	98
application-set statement.....	99

application-sets statement	
CoS.....	430
IDS.....	188
NAT.....	152
stateful firewall.....	119
application-system-cache-timeout statement.....	688
applications statement	
AACL.....	711
applications hierarchy.....	99
applications identification.....	688
CoS.....	430
IDS.....	188
NAT.....	153
stateful firewall.....	119
archive-sites statement.....	914
audit-observed-events-returns statement.....	516
authentication statement.....	253
authentication-algorithm statement	
IKE.....	254
IPsec.....	254
authentication-method statement.....	255
authentication-mode statement	
RPM.....	1061
automatic statement.....	689
autonomous-system-type statement.....	849
auxiliary-spi statement.....	255

B

backup-destination statement.....	784, 1110
backup-interface statement.....	784
backup-remote-gateway statement.....	256
base-root statement.....	517
bearer-bandwidth-limit statement.....	409
bfg-core statement.....	518
bundle statement.....	409, 1019
by-destination statement.....	189
by-pair statement.....	190
by-source statement.....	191

C

cancel-graceful statement.....	519
capture-group statement.....	953
cflowd statement.....	850
circuit-weight statement.....	750

cisco-interoperability statement.....	381
cleanup-timeout statement.....	520
clear-dont-fragment-bit statement	
GRE tunnel.....	490
IPsec.....	256
clear-ike-sas-on-pic-restart statement.....	257
clear-ipsec-sas-on-pic-restart statement.....	257
client-list statement.....	1062
collector statement.....	914
committed-burst-size statement.....	621
committed-information-rate statement.....	621
compression statement.....	410
compression-device statement.....	410, 1020
connection-idle-timeout statement.....	750
content-destination statement.....	954
context-indications statement.....	521
control-association-indications statement.....	522
control-source statement.....	955
controller-address statement.....	522
controller-failure statement.....	523
controller-port statement.....	523
copy-tos-to-outer-ip-header statement.....	1110
core-dump statement.....	851
cost statement.....	751

D

data-fill statement.....	1062
data-format statement.....	915
data-inactivity-detection statement.....	524
data-size statement.....	1063
datastore statement.....	622
default statement.....	525
delivery-function statement.....	526
description statement	
IKE.....	258
IPsec.....	258
destination statement	
application identification rule.....	689
DLSw.....	751
encryption.....	785
flow monitoring.....	852
link services.....	1020
tunnel.....	1111
destination-address statement	
ACL.....	713
BGF.....	526
CoS.....	431
IDS.....	192
IPsec.....	258
NAT.....	153
stateful firewall.....	120
destination-address-range statement	
ACL.....	713
IDS.....	192

NAT.....	154
stateful firewall.....	120
destination-interface statement	
DLSw.....	752
destination-networks statement	
tunnel.....	1112
destination-pool statement.....	154
destination-port statement	
applications.....	99
BGF.....	527
RPM.....	100, 1065
destination-prefix statement.....	155, 193
destination-prefix-ipv6 statement.....	193
destination-prefix-list statement	
ACL.....	714
CoS.....	431
IDS.....	194
NAT.....	155
stateful firewall.....	121
destinations statement	
flow collection.....	915
detect statement.....	527
dh-group statement.....	259
dial-options statement.....	491
dialogs statement.....	623
diffserv statement.....	528
direction statement.....	260
disable statement	
application.....	690
application-group.....	690
flow monitoring.....	852
port mapping.....	690
disable-mlppp-inner-ppp-pfc statement.....	1021
disable-session-mirroring statement.....	528
disconnect statement.....	529
dlci statement.....	1021
dlsd statement.....	752
dlsd-cos statement.....	753
do-not-fragment statement	
tunnel.....	1112
down statement.....	529
download statement	
APPID.....	691
drop-timeout statement.....	1022
dscp statement.....	432
BGF.....	530
BSG.....	624
dscp-code-point statement	
RPM.....	1066
duplicates-dropped-periodicity statement.....	955
dynamic route insertion.....	239
dynamic statement.....	261
dynamic-call-admission-control statement.....	411
dynamic-flow-capture statement.....	956
dynamic-tunnels statement.....	1113

E

egress-service-point statement.....	624
embedded-spdf statement.....	625
encapsulation statement.....	412
link services.....	1023
encoding statement.....	530
encryption statement.....	262
encryption-algorithm statement	
IKE.....	263
IPsec.....	263
engine-id statement	
flow monitoring.....	853
engine-type statement.....	853
es-options statement.....	785
event-timestamp-notification statement.....	531
explorer-wait-time statement.....	753
export-format statement.....	854

F

f-max-period statement.....	412
facility-override statement.....	305, 458, 492
failover-cold statement.....	531
failover-warm statement.....	532
failure statement.....	533
family statement	
encryption.....	786
flow monitoring.....	855
interfaces.....	493
link services.....	413, 1025
fast-update-filters statement.....	534
file statement.....	858
BGF.....	535
border signaling gateway.....	626
traffic sampling.....	858
file-specification statement.....	917
filename statement.....	859
filename-prefix statement.....	916
files statement.....	859
filter statement	
encryption.....	787
flow monitoring.....	860
flag statement.....	536, 627
flow-active-timeout statement.....	861
flow-collector statement.....	918
flow-export-destination statement.....	862
flow-inactive-timeout statement.....	862
flow-monitoring statement.....	863
flow-tap statement.....	957
flow-tap-lite statement.....	957
force-entry statement.....	194
forwarding-class statement.....	382, 432
forwarding-options statement.....	864

fragment-threshold statement	
link services.....	1026
LSQ.....	383
voice services.....	414
fragmentation-map statement.....	383
fragmentation-maps statement.....	384
framework statement.....	629
from statement	
AACL.....	714
border signaling gateway	
new call usage policy.....	632
new transaction policy.....	633
service class.....	634
CoS.....	433
IDS.....	195
IPsec.....	264
NAT.....	156
stateful firewall.....	121
ftp statement	
flow collection.....	920

G

g-duplicates-dropped-periodicity statement.....	958
g-max-duplicates statement.....	958
gateway statement	
BGF.....	537
border signaling gateway.....	635
gateway-address statement.....	541
gateway-controller statement.....	542
gateway-port statement.....	543
graceful statement.....	544
graceful-restart statement.....	545

H

h248-options statement.....	546
h248-properties statement.....	548
h248-stack statement.....	551
h248-timers statement.....	552
hanging-termination-detection statement.....	552
hard-limit statement.....	959
hard-limit-target statement.....	959
hardware-timestamp statement.....	1067
hello-interval statement	
L2TP.....	306
hello-timer statement	
link services.....	1026
hide-avps statement.....	306
hint statement.....	157
history-size statement.....	1067
hold-time statement	
DLSw.....	754
host statement.....	459, 494
L2TP.....	307
hot-standby statement.....	384

I

icmp-code statement.....	100
icmp-type statement.....	101
idle-timeout statement.....	691
ids-rules statement.....	459
ignore-entry statement.....	194
ike statement.....	265
ike-access-profile statement.....	460
inactivity-delay statement.....	553
inactivity-duration statement.....	553
inactivity-timeout statement.....	101
BGF.....	554
flow monitoring.....	494
RPM.....	1068
inactivity-timer statement.....	554
index statement.....	692
initial-average-ack-delay statement.....	555
initiate-dead-peer-detection statement.....	266
input statement	
flow monitoring.....	865
interfaces.....	495
input-interface-index statement.....	866
input-packet-rate-threshold statement.....	960
interface statement	
BGF.....	555
DLSw.....	755
flow monitoring.....	867
flow-tap.....	960
service interface pool.....	613
interface-map statement.....	922
interface-service statement.....	460
interfaces statement	
DFC.....	961
encryption.....	787
flow monitoring.....	869
interfaces hierarchy.....	495
link services.....	1027
tunnel.....	1113
voice services.....	414
interim-ah-scheme statement.....	556
interleave-fragments statement.....	1027
ip statement	
application identification.....	692
ip-flow-stop-detection statement.....	556
ipsec statement.....	266
ipsec-inside-interface statement.....	267
ipsec-sa statement	
encryption.....	788
ipsec-vpn-options statement.....	461
ipsec-vpn-rules statement.....	461
ipv4-template statement.....	869
ipv6-multicast-interfaces statement.....	157
ipv6-template statement.....	869

K

key statement	
tunnel.....	1114

L

l2tp-access-profile statement.....	307
label-position statement.....	870
latch-deadlock-delay statement.....	557
learn-sip-register statement.....	102
lifetime-seconds statement	
IKE.....	267
IPsec.....	267
link-layer-overhead statement.....	385
link-loss statement.....	557
lmi-type statement.....	1028
load-balance statement	
DLSw.....	755
local-certificate statement.....	268
local-dump statement.....	870
local-gateway address statement.....	308
local-gateway statement.....	462
local-id statement.....	268
local-mac statement.....	756
local-peer statement	
DLSw.....	756
log-prefix statement.....	462, 496
L2TP.....	308
logging statement.....	196, 463
logical-system statement	
RPM.....	1068
lsq-failure-options statement.....	385

M

manual statement.....	269
map statement.....	757
match-direction statement	
AACL.....	715
CoS.....	433
IDS.....	196
IPsec.....	269
NAT.....	158
stateful firewall.....	122
max-burst-size statement.....	558
max-checked-bytes statement.....	693
max-concurrent-calls statement.....	560
max-duplicates statement.....	961
max-flows statement.....	463
max-packets-per-second statement.....	871
maximum-age statement.....	923
maximum-connections statement.....	1069
maximum-connections-per-client statement.....	1069
maximum-contexts statement.....	415
maximum-fuf-percentage statement.....	561
maximum-inactivity-time statement.....	562

maximum-net-propagation-delay statement.....	563
maximum-send-window statement.....	309
maximum-sessions statement.....	1070
maximum-sessions-per-connection statement.....	1070
maximum-synchronization-mismatches statement.....	563
maximum-synchronization-time statement.....	564
maximum-terms statement.....	564
maximum-waiting-delay statement.....	565
media statement.....	565
media-policy statement.....	638
media-service statement.....	566
media-type statement.....	638
mg-maximum-pdu-size statement.....	567
mg-originated-pending-limit statement.....	568
mg-provisional-response-timer-value statement.....	569
mg-segmentation-timer statement.....	570
mgc-maximum-pdu-size statement.....	571
mgc-originated-pending-limit statement.....	572
mgc-provisional-response-timer-value statement.....	573
mgc-segmentation-timer statement.....	574
min-checked-bytes statement.....	693
minimum statement BGF.....	639
minimum-links statement.....	1028
minimum-priority statement.....	962
mlfr-uni-nni-bundle-options statement.....	1029
mode statement.....	270
monitor statement.....	575
monitoring statement.....	872
moving-average-size statement.....	1071
mpls-ipv4-template statement.....	873
mpls-template statement.....	873
mrru statement.....	1030
mss statement.....	197
mtu statement.....	1031
multicast-address statement.....	757
multicast-dlci statement.....	1031
multicast-only statement.....	1114
multilink-class statement.....	386
multilink-max-classes statement.....	386
multiservice-options statement.....	874

N

n391 statement.....	1032
n392 statement.....	1032
n393 statement.....	1033
name-format statement.....	924
nat-pool statement.....	575
nat-rules statement.....	464
nat-type statement.....	158
network-operator-id statement.....	576
new-call-usage-policies statement.....	639
new-call-usage-policy statement.....	640
new-call-usage-policy-set statement.....	641

new-transaction-policies statement.....	641
new-transaction-policy statement.....	642
new-transaction-policy-set statement.....	643
next-hop statement.....	874
border signaling gateway.....	644
next-hop-group statement.....	875
next-hop-service statement.....	465
no-anti-replay statement.....	270
no-application-identification statement.....	694
no-application-system-cache statement.....	694
no-clear-application-system-cache statement.....	694
no-core-dump statement.....	851
no-dscp-bit-mirroring statement.....	580
no-filter-check statement.....	876
no-fragmentation statement.....	387
no-local-dump statement.....	870
no-preempt statement.....	759
no-rtcp-check statement.....	576
no-signature-based statement.....	695
no-stamp statement.....	891
no-syslog statement DFC.....	962
flow monitoring.....	892
no-termination-request statement.....	387
no-translation statement.....	159
no-world-readable statement flow monitoring.....	900
normal-mg-execution-time statement.....	577
normal-mgc-execution-time statement.....	578
notification-behavior statement.....	579
notification-rate-limit statement.....	579
notification-regulation statement.....	580
notification-targets statement.....	963

O

one-way-hardware-timestamp statement.....	1071
open-timeout statement.....	496
option-refresh-rate statement.....	877
order statement.....	695
output statement.....	497
discard accounting.....	878
flow monitoring.....	879
port mirroring.....	879
sampling.....	880
output-interface-index statement.....	881
overload-control statement.....	581
overload-pool statement.....	159
overload-prefix statement.....	160

P

passive-monitor-mode statement.....	881
password statement flow collection.....	926
peak-data-rate statement.....	582

peer statement		
DLSw.....	758	
peer-unit statement		
tunnel.....	1115	
per-unit-scheduler statement.....	388	
perfect-forward-secrecy statement.....	271	
pgcp statement		
NAT.....	160	
pgcp-rules statement		
service-set.....	466	
pic-memory-threshold statement.....	963	
policy statement		
IKE.....	272	
policy-decision-statistics-profile statement.....	729	
pool statement.....	161	
service interface pool.....	614	
pop-all-labels statement.....	882	
port statement		
flow monitoring.....	882	
NAT.....	162	
RPM.....	1072	
TWAMP.....	1072	
voice services.....	415	
port-mapping statement.....	696	
port-mirroring statement.....	883	
port-range statement.....	696	
ports-per-session statement.....	162	
post-service-filter statement.....	497	
ppp-access-profile statement.....	309	
pre-shared-key statement.....	273	
preempt statement.....	759	
preserve-interface statement.....	388	
primary statement		
link services.....	389	
services PIC.....	498	
priority statement		
DLSw.....	760	
probe statement		
RPM.....	1073	
probe-count statement.....	1074	
probe-interval statement.....	1074	
probe-limit statement.....	1075	
probe-server statement.....	1075	
probe-type statement.....	1076	
profile statement, application identification.....	697	
promiscuous statement		
DLSw.....	760	
proposal statement		
IKE.....	274	
IPsec.....	275	
proposals statement		
IKE.....	275	
IPsec.....	275	
protocol statement		
applications.....	103	
IPsec.....	276	
protocols statement		
DLSw.....	761	
Q		
queue-limit-percentage statement.....	584	
queues statement.....	416	
R		
random-allocation statement.....	162	
rate statement.....	884	
reachability-cache-timeout statement.....	761	
reassemble-packets statement.....	1115	
receive-initial-pacing statement.....	762	
receive-options-packets statement.....	884	
receive-ttl-exceeded statement.....	885	
receive-window statement.....	310	
reconnect statement.....	585	
red-differential-delay statement.....	1033	
redundancy-group statement		
DLSw.....	763	
redundancy-options statement.....	389, 498	
reflexive reverse statement.....	434	
remote-gateway statement.....	276	
remote-id statement.....	277	
remote-mac statement.....	756	
remote-peer statement.....	764	
remotely-controlled statement.....	163	
report-service-change statement.....	586	
request-timestamp statement.....	587	
required-depth statement.....	885	
retransmit-interval statement.....	310	
retry statement.....	927	
retry-delay statement.....	927	
route statement.....	645	
routing-instance statement		
BGF.....	587	
RPM.....	1076	
tunnel.....	1116	
routing-instances statement		
RPM.....	1077	
rpc-program-number statement.....	104	
rpm statement.....	1077	
rtp statement.....	416, 588	
rule statement		
AACL.....	716	
application identification.....	698	
BGF.....	589	
CoS.....	435	
IDS.....	198	
IPsec.....	278	
NAT.....	164	
stateful firewall.....	123	

rule-set statement	
AACL.....	717
application identification.....	699
BGF.....	589
CoS.....	436
IDS.....	199
IPsec.....	279
NAT.....	165
stateful firewall.....	124
run-length statement.....	886

S

sampling statement	
flow monitoring.....	889
sbc-utils statement.....	590, 646
secondary statement	
link services.....	390
services PIC.....	499
segmentation statement.....	591
send-notification-on-delay statement.....	592
server statement.....	1078
service statement.....	499
service-change statement.....	593
service-change-type statement.....	594
service-class statement.....	647
service-domain statement.....	500
service-filter statement	
interfaces.....	500
service-interface statement.....	311, 466
BGF.....	594
border signaling gateway	
gateway.....	648
service point.....	648
service-interface-pools statement.....	614
service-point statement.....	649
service-point-type statement.....	649
service-policies statement.....	650
service-port statement.....	964
service-set statement.....	467, 501
service-state statement	
virtual BGF.....	595
virtual interface in BGF.....	596
services statement	
BGF.....	596
border signaling gateway.....	650
CoS.....	436
DFC.....	964
flow-monitoring.....	889
IDS.....	199
interfaces.....	502
IPsec.....	279
L2TP.....	312
NAT.....	165
RPM.....	1078
service sets.....	468
stateful firewall.....	124
services-options statement.....	503
session-limit statement.....	200
session-mirroring statement.....	597
session-timeout statement.....	700
session-trace statement.....	651
shared-key statement.....	965
short-sequence statement.....	1034
signaling statement.....	652
sip statement.....	654
sip-call-hold-timeout statement.....	104
sip-stack statement.....	656
sip-text statement.....	437
sip-video statement.....	437
sip-voice statement.....	438
size statement.....	890
snmp-command statement.....	105
soft-limit statement.....	965
soft-limit-clear statement.....	966
source statement	
application identification rule.....	701
encryption.....	788
tunnel.....	1117
source-address statement	
AACL.....	718
BGF.....	597
CoS.....	438
flow monitoring.....	891
IDS.....	201
IPsec.....	280
NAT.....	166
RPM.....	1079
stateful firewall.....	125
tunnel.....	1118
source-address-range statement	
AACL.....	718
IDS.....	201
NAT.....	166
stateful firewall.....	125
source-addresses statement	
DFC.....	966
source-pool statement.....	167
source-port statement	
BGF.....	598
RPM.....	105
source-prefix statement.....	167, 202
source-prefix-ipv6 statement.....	202
source-prefix-list statement	
AACL.....	719
CoS.....	439
IDS.....	203
NAT.....	168
stateful firewall.....	126
spi statement.....	280
stamp statement.....	891

state-loss statement.....	598
stateful-firewall-rules statement.....	470
statement-name statement.....	585, 586, 620
stop-detection-on-drop statement.....	599
sustained-data-rate statement.....	600
gate in packet gateway.....	601
syn-cookie statement.....	203
syslog statement	
CoS.....	439
flow monitoring.....	892
IDS.....	204
interfaces.....	504
IPsec.....	281
L2TP.....	314
NAT.....	168
service sets.....	470
stateful firewall.....	126

T

t391 statement.....	1034
t392 statement.....	1035
target statement.....	1079
tcp statement	
RPM.....	1080
tcp-mss statement.....	471
template statement	
flow monitoring.....	893
template-refresh-rate statement.....	895
term statement	
ACL.....	720
border signaling gateway	
new call usage policy.....	658
new transaction policy.....	659
service-class.....	660
CoS.....	440
IDS.....	205
IPsec.....	282
NAT.....	169
stateful firewall.....	127
test statement	
RPM.....	1081
test-interval statement.....	1082
then statement	
ACL.....	721
border signaling gateway	
new call usage policy.....	661
new transaction policy.....	662
service-class.....	663
CoS.....	441
IDS.....	207
IPsec.....	283
NAT.....	170
stateful firewall.....	128
threshold statement.....	208

thresholds statement	
RPM.....	1083
timer-c statement.....	663
timers statement.....	664
timerx statement.....	602
tmax-retransmission-delay statement.....	602
traceoptions statement.....	665
application identification.....	702
BGF.....	603
DLSw.....	765
flow monitoring.....	895
IPsec.....	284
L-PDF.....	730
L2TP.....	315
services.....	472
track statement.....	767
traffic-management statement.....	604
transactions statement.....	666
transfer statement.....	928
transfer-log-archive statement.....	928
translated statement.....	171
translation-type statement.....	172
transport statement	
NAT.....	173
transport-details statement.....	667
traps statement.....	1084
trigger-link-failure statement.....	390
trusted-ca statement.....	473
ttl statement	
DFC.....	967
tunnel.....	1118
ttl-threshold statement.....	106
tunnel statement.....	1119
encryption.....	789
tunnel-group statement.....	317
tunnel-mtu statement.....	285
tunnel-timeout statement.....	318
tunnel-type statement.....	1120
twamp statement.....	1085
twamp-server statement.....	1085
type statement.....	703
type-of-service statement.....	703, 768

U

udp statement	
RPM.....	1086
unit statement	
encryption.....	790
flow monitoring.....	896
interfaces.....	505
link services.....	417, 1036
tunnel.....	1121
up statement	
BGF.....	605
url statement.....	704

use-lower-case statement.....	605
use-wildcard-response statement.....	606
username statement	
flow collection.....	929
uuid statement.....	106

V

variant statement.....	929
version statement	
flow monitoring.....	897
version9 statement.....	898
virtual-interface statement.....	606
virtual-interface-down statement.....	607
virtual-interface-indications statement.....	608
virtual-interface-up statement.....	608

W

warm statement.....	609
warm-standby statement.....	391
world-readable statement	
flow monitoring.....	900

Y

yellow-differential-delay statement.....	1037
--	------

