

# Using CESoPSN Bundles to Group DSOs on IP Circuits

Release

6.0



---

Published: 2010-06-27

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, California 94089  
USA  
408-745-2000  
www.juniper.net

Copyright © 2010, Juniper Networks, Inc. All rights reserved.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

*Using CESoPSN Bundles to Group DSOs on IP Circuits*

Copyright © 2010, Juniper Networks, Inc.

All rights reserved. Printed in USA.

#### Revision History

June 2010—Using CESoPSN Bundles to Group DSOs on IP Circuits CTP Release 6.0, CTPView Release 4.0

The information in this document is current as of the date listed in the revision history.

## END USER LICENSE AGREEMENT

**READ THIS END USER LICENSE AGREEMENT ("AGREEMENT") BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE.** BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. **The Parties.** The parties to this Agreement are (i) Juniper Networks, Inc. (if the Customer's principal office is located in the Americas) or Juniper Networks (Cayman) Limited (if the Customer's principal office is located outside the Americas) (such applicable entity being referred to herein as "Juniper"), and (ii) the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software ("Customer") (collectively, the "Parties").

2. **The Software.** In this Agreement, "Software" means the program modules and features of the Juniper or Juniper-supplied software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller, or which was embedded by Juniper in equipment which Customer purchased from Juniper or an authorized Juniper reseller. "Software" also includes updates, upgrades and new releases of such software. "Embedded Software" means Software which Juniper has embedded in or loaded onto the Juniper equipment and any updates, upgrades, additions or replacements which are subsequently embedded in or loaded onto the equipment.

3. **License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

- a. Customer shall use Embedded Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller.
- b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees; provided, however, with respect to the Steel-Belted Radius or Odyssey Access Client software only, Customer shall use such Software on a single computer containing a single physical random access memory space and containing any number of processors. Use of the Steel-Belted Radius or IMS AAA software on multiple computers or virtual machines (e.g., Solaris zones) requires multiple licenses, regardless of whether such computers or virtualizations are physically contained on a single chassis.
- c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer's use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, realms, devices, links, ports or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. In addition, such limits may restrict the use of the Software to managing certain kinds of networks or require the Software to be used only in conjunction with other specific Software. Customer's use of the Software shall be subject to all such limitations and purchase of all applicable licenses.
- d. For any trial copy of the Software, Customer's right to use the Software expires 30 days after download, installation or use of the Software. Customer may operate the Software after the 30-day trial period only if Customer pays for a license to do so. Customer may not extend or create an additional trial period by re-installing the Software after the 30-day trial period.
- e. The Global Enterprise Edition of the Steel-Belted Radius software may be used by Customer only to manage access to Customer's enterprise network. Specifically, service provider customers are expressly prohibited from using the Global Enterprise Edition of the Steel-Belted Radius software to support any commercial network access services.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. **Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any 'locked' or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the

Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use Embedded Software on non-Juniper equipment; (j) use Embedded Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. **Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. **Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. **Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. **Warranty, Limitation of Liability, Disclaimer of Warranty.** The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. **Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. **Taxes.** All license fees payable under this agreement are exclusive of tax. Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software. If applicable, valid exemption documentation for each taxing jurisdiction shall be provided to Juniper prior to invoicing, and Customer shall promptly notify Juniper if their exemption is revoked or modified. All payments made by Customer shall be net of any applicable withholding tax. Customer will provide reasonable assistance to Juniper in connection with such withholding taxes by promptly: providing Juniper with valid tax receipts and other required documentation showing Customer's payment of any withholding taxes; completing appropriate applications that would reduce the amount of withholding tax to be paid; and notifying and assisting Juniper in any audit or tax proceeding related to transactions hereunder. Customer shall comply with all applicable tax laws and regulations, and Customer will promptly pay or reimburse Juniper for all costs and damages related to any liability incurred by Juniper as a result of Customer's non-compliance or delay with its responsibilities herein. Customer's obligations under this Section shall survive termination or expiration of this Agreement.

11. **Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. **Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14 (ALT III) as applicable.

13. **Interface Information.** To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. **Third Party Software.** Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License ("GPL") or the GNU Library General Public License ("LGPL")), Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. **Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).



# Table of Contents

<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Using Bundles to Create Logical Configurations for Physical Interfaces</b>	
	<b>Overview</b> .....	<b>3</b>
	Types of Bundles Overview .....	3
	Interface Naming Conventions .....	4
<b>Chapter 2</b>	<b>CESoPSN Bundle Overview</b> .....	<b>5</b>
	CESoPSN Bundle Overview .....	5
	Providing QoS for CTP Bundles by Using Service Type Overview .....	5
<b>Part 2</b>	<b>Configuration</b>	
<b>Chapter 3</b>	<b>Adding Bundles</b> .....	<b>11</b>
	Adding a Bundle (CTPView) .....	11
	Adding a Bundle (CTP Menu) .....	11
<b>Chapter 4</b>	<b>Configuring CESoPSN Bundles (CTP Menu)</b> .....	<b>13</b>
	Configuring T1 and E1 Port Parameters for CESoPSN Bundles (CTP Menu) .....	13
	Configuring DS0 Time Slots for CESoPSN Bundles (CTP Menu) .....	15
	Configuring IP Parameters for CESoPSN Bundles (CTP Menu) .....	16
<b>Chapter 5</b>	<b>Configuring CESoPSN Bundles (CTPView)</b> .....	<b>19</b>
	Configuring T1 and E1 Port Parameters for CESoPSN Bundles (CTPView) .....	19
	Configuring DS0 Time Slots for CESoPSN Bundles (CTPView) .....	21
	Configuring IP Parameters for CESoPSN Bundles (CTPView) .....	21



# List of Tables

<b>Part 1</b>	<b>Overview</b>
<b>Chapter 1</b>	<b>Using Bundles to Create Logical Configurations for Physical Interfaces</b>
	<b>Overview . . . . . 3</b>
	Table 1: Bundle Types and Supported Interfaces . . . . . 3
	Table 2: Interface Type Specifiers . . . . . 4
<b>Chapter 2</b>	<b>CESoPSN Bundle Overview . . . . . 5</b>
	Table 3: DSCP Classes and Service Type . . . . . 6
<b>Part 2</b>	<b>Configuration</b>
<b>Chapter 4</b>	<b>Configuring CESoPSN Bundles (CTP Menu) . . . . . 13</b>
	Table 4: CESoPSN Bundle T1/E1 Port Parameter Settings in the CTP Menu . . . . . 13
	Table 5: CESoPSN Bundle DS0 Time Slot Settings in the CTP Menu . . . . . 15
	Table 6: CESoPSN Bundle IP Parameter Settings in the CTP Menu . . . . . 16
<b>Chapter 5</b>	<b>Configuring CESoPSN Bundles (CTPView) . . . . . 19</b>
	Table 7: CESoPSN Bundle T1 and E1 Port Parameter Settings in CTPView . . . . . 19
	Table 8: CESoPSN Bundle DS0 Time Slot Settings in CTPView . . . . . 21
	Table 9: CESoPSN Bundle IP Parameter Settings in CTPView . . . . . 22



## PART 1

# Overview

- Using Bundles to Create Logical Configurations for Physical Interfaces  
Overview on page 3
- CESoPSN Bundle Overview on page 5



## CHAPTER 1

# Using Bundles to Create Logical Configurations for Physical Interfaces Overview

- Types of Bundles Overview on page 3
- Interface Naming Conventions on page 4

### Types of Bundles Overview

---

Table 1 on page 3 shows the typical application for each bundle type, and lists the interfaces that each type of bundle supports.

**Table 1: Bundle Types and Supported Interfaces**

Bundle Type	Generally Used For	Interface Types Supported
CTP (circuit-to-packet)	Connecting legacy serial interfaces to the IP network	<ul style="list-style-type: none"><li>• CTP150<ul style="list-style-type: none"><li>• Serial interface</li><li>• T1/E1 interface</li></ul></li><li>• CTP2000<ul style="list-style-type: none"><li>• Serial interface</li><li>• Serial interface with T1/E1 daughter card</li><li>• Serial interface with 4WTO daughter card</li><li>• Serial interface with IRIG-B daughter card</li><li>• T1/E1 interface</li></ul></li></ul>
SAToP (structure-agnostic TDM over IP)	Connecting single T1 or E1 interfaces to an IP network	<ul style="list-style-type: none"><li>• CTP150<ul style="list-style-type: none"><li>• T1/E1 interface</li></ul></li><li>• CTP2000<ul style="list-style-type: none"><li>• Serial interface with T1/E1 daughter card</li><li>• T1/E1 interface</li></ul></li></ul>

Table 1: Bundle Types and Supported Interfaces (*continued*)

Bundle Type	Generally Used For	Interface Types Supported
CESoPSN (circuit emulation services over a packet-switched network)	Group multiple DS0s to one IP circuit	<ul style="list-style-type: none"> <li>CTP2000 <ul style="list-style-type: none"> <li>T1/E1 interface with unused DS0s</li> </ul> An unused DS0 is a DS0 not assigned to another bundle. When a CESoPSN bundle is attached to a port, by default all unused DS0s are assigned to the bundle. </li> </ul>
VCOMP (voice compression)	Group multiple analog circuits (channels) into one IP circuit.	<ul style="list-style-type: none"> <li>CTP2000 <ul style="list-style-type: none"> <li>T1/E1 interface</li> <li>4W-E&amp;M interface</li> <li>Voice compression module</li> </ul> </li> </ul>

## Interface Naming Conventions

In the CTP software, interfaces are specified in the format:

*type-slot/port*

where

type—Type of interface. A 2-character abbreviation.

slot—Slot number on the CTP device.

port—Port number on the CTP device.

If the interface module has a daughter card installed, the interface format is as follows:

*type-slot/port w/daughter-card*

Table 2: Interface Type Specifiers

Interface Type	Type Specifier
4WE&M	4w
4WTO	4w
E1	e1
IRIG	irig
Serial	se
T1	t1
T1E1	t1e1

## CHAPTER 2

# CESoPSN Bundle Overview

- CESoPSN Bundle Overview on page 5
- Providing QoS for CTP Bundles by Using Service Type Overview on page 5

## CESoPSN Bundle Overview

---

A CESoPSN bundle represents an IP circuit emulation flow. With CESoPSN bundles, you can group multiple DSOs on one IP circuit, and you can have more than one circuit emulation IP flow created from a single physical interface. For example, some DSO channels from a T1 interface can go in an IP flow to destination A, and other DSO channels from that same T1 interface can go to destination B. This feature allows for payload optimization.

CESoPSN bundles comply with *RFC 5086, Structure-Aware Time Division Multiplexed (TDM) Circuit Emulation Service over Packet Switched Network (CESoPSN), December 2007*. RFC-5086 defines a standard for transporting multiple bundles of DSOs from a single physical interface to different network destinations.

CESoPSN bundles are supported on CTP2000 T1/E1 interfaces with unused DSOs. An unused DSO is a DSO not assigned to another bundle. When you create a CESoPSN bundle all unused DSOs are assigned to the bundle by default.

CESoPSN bundles support the following signaling:

- T1 interfaces support channel associated signaling (CAS).
- E1 interfaces support CAS and common channel signaling (CCS).

## Providing QoS for CTP Bundles by Using Service Type Overview

---

In IP networks, the IP flow is typically classified based on the Differentiated Services Code Point (DSCP) setting in the Type of Service (TOS) byte of the IP header. DSCP is a scalable solution for classifying flows in a large IP network based on the class of service desired on specific IP traffic flows.

With the CTP device, you can configure DSCP settings for each circuit's IP flow. For example, some circuits could be configured for the expedited forwarding (EF) class. When the network routers receive this EF marked flow from the CTP device, they place the marked traffic into a high priority queue, enabling this traffic to be serviced before

lower priority traffic. As an EF marked flow transverses the IP network, routers can use its classification to provide the flow a more predictable level of performance across the network

When you configure the service type of a bundle, you specify the ToS byte to be used in IP headers of packets sent from the CTP device to the IP network. The ToS setting is applied to circuits created by the bundle for which the service type is configured.

Table 3 on page 6 shows the mapping for each DSCP class and setting to the ToS setting that you configure as the service type for a bundle. The expedited forwarding (EF) class (ToS setting 184) is commonly used for circuit traffic.

**Table 3: DSCP Classes and Service Type**

DSCP Class	DSCP Setting	ToS Setting
CS7	56	224
CS6	48	192
EF	46	184
CS5	40	160
AF43	38	152
AF42	36	144
AF41	34	136
CS4	32	128
AF33	30	120
AF32	28	112
AF31	26	104
CS3	24	96
AF23	22	88
AF22	20	80
AF21	18	72
CS2	16	64
AF13	13	52
AF12	12	48

Table 3: DSCP Classes and Service Type (*continued*)

DSCP Class	DSCP Setting	ToS Setting
AF11	10	40
CS1	8	32

- Related Topics**
- [Configuring IP Parameters for CTP Bundles \(CTPView\)](#)
  - [Configuring IP Parameters for CTP Bundles \(CTP Menu\)](#)



## PART 2

# Configuration

- Adding Bundles on page 11
- Configuring CESoPSN Bundles (CTP Menu) on page 13
- Configuring CESoPSN Bundles (CTPView) on page 19



## CHAPTER 3

# Adding Bundles

- Adding a Bundle (CTPView) on page 11
- Adding a Bundle (CTP Menu) on page 11

### Adding a Bundle (CTPView)

---

Before you begin:

- Log in to the CTPView software at least at the Net\_Admin level.
- Connect the CTPView server to the CTP device for which you want to configure bundles.
- Disable the bundle before you modify the bundle options.

To add a bundle using CTPView:

1. In the side pane, select **Bundle > Configuration**.
2. Run your mouse over the **Open Add Bundles Display** bar.
3. Under **New Bndl Number**, select a bundle number.
4. Under the type of bundle you want to add, select a source port, and click the button for the type of bundle.
5. Enter the parameters, and **Click to Submit Bundle AND Port Changes**.

### Adding a Bundle (CTP Menu)

---

To add a bundle using the CTP Menu:

1. From the Main Menu, select **1) Bundle Operations**.
2. Select the type of bundle that you want to configure.
  - CTP (circuit-to-packet)—Used for serial interfaces.
  - SAToP (structure-agnostic TDM over IP)—Used for single T1 or E1 interfaces.
  - CESoPSN (circuit emulation services over a packet-switched network)—Used for DSO transport over an IP network.
  - VCOMP (voice compression)—Used for T1/E1 interfaces, 4W-E&M interfaces.

3. Enter **add** to add a new bundle.
4. Select the port you want to attach the bundle to.

CHAPTER 4

# Configuring CESoPSN Bundles (CTP Menu)

- Configuring T1 and E1 Port Parameters for CESoPSN Bundles (CTP Menu) on page 13
- Configuring DS0 Time Slots for CESoPSN Bundles (CTP Menu) on page 15
- Configuring IP Parameters for CESoPSN Bundles (CTP Menu) on page 16

## Configuring T1 and E1 Port Parameters for CESoPSN Bundles (CTP Menu)

This topic describes how to configure port parameters for T1/E1 interfaces.

Before you begin:

- Disable the bundle before you modify the bundle options.

To configure port parameters for T1/E1 interfaces for CESoPSN bundles using the CTP Menu:

1. From the Main Menu, select **1) Bundle Operations**.
2. Select **3) CESoPSN**.
3. Select a bundle from the list.  
  
If you select an active bundle, you are prompted to disable the bundle before configuring it.
4. Select **3) Port Config**.
5. Follow the onscreen instructions, and configure the options as described in Table 4 on page 13.

The options vary depending on whether the bundle is T1 or E1.

Table 4: CESoPSN Bundle T1/E1 Port Parameter Settings in the CTP Menu

Field	Function	Your Action
Port descriptor	Specifies a description for the port.	Enter a description of up to 62 alphanumeric characters. Do not use the following characters:  ( ; ' " ) ]

Table 4: CESoPSN Bundle T1/E1 Port Parameter Settings in the CTP Menu (*continued*)

Field	Function	Your Action
Type	Specifies the type of interface.  The type of interface that you select affects the default packet size and buffer sizes for the bundle.	Select one: <ul style="list-style-type: none"> <li>• T1</li> <li>• E1</li> </ul>
Option (for T1)	Specifies the T1 encoding method used on this bundle.	Select one: <ul style="list-style-type: none"> <li>• B8ZS</li> <li>• AMI</li> </ul>
Option (for E1)	For E1 interfaces, configure the termination to work with either coax or RJ-48.	Select one: <ul style="list-style-type: none"> <li>• RJ48</li> <li>• COAX</li> </ul>
BuildOut	For T1 interfaces, specifies the line buildout.	Select one: <ul style="list-style-type: none"> <li>• 0) ~133 ft</li> <li>• 1) ~266 ft</li> <li>• 2) ~399 ft</li> <li>• 3) ~533 ft</li> <li>• 4) ~655 ft</li> <li>• 5) ~7.5dB CSU</li> <li>• 6) ~15dB CSU</li> <li>• 7) ~22.5dB CSU</li> </ul>
Clock synthesizer	The following clock synthesizer settings are set by the software, and you cannot change them: <ul style="list-style-type: none"> <li>• For T1, the clock synthesizer is set to 1544 KHz.</li> <li>• For E1 the clock synthesizer is set to 2048 KHz.</li> </ul>	
Clock Config	Specifies the type of clocking for the port.	Select one: <ul style="list-style-type: none"> <li>• CTP is Clock Source—The PBX either returns the clock received from the CTP or it returns a clock that is traceable to the same source as the CTP node clock reference. You typically use this configuration when you configure the CTP device with a clock reference input.</li> <li>• CTP is Loop Timed—The PBX provides the clock and the CTP returns the same clock to the PBX. You typically use this configuration when the PBX has the more accurate clock source. You can configure the far end of the circuit with adaptive clocking to recover this clock if necessary.</li> <li>• CTP is Clock Source (Adaptive End)—The PBX returns the clock received from the CTP, and the CTP uses the adaptive recovered clock. You typically use this configuration when the CTP does not have a reference input and the PBX typically requires clock from the distant PBX.</li> </ul>

Table 4: CESoPSN Bundle T1/E1 Port Parameter Settings in the CTP Menu (*continued*)

Field	Function	Your Action
Signal	For T1 interfaces, specifies whether or not CAS signaling is used.	Enter one: <ul style="list-style-type: none"> <li>On—Signaling is on.</li> <li>Off—Signaling is off.</li> </ul>

- Related Topics**
- CESoPSN Bundle Overview on page 5
  - Configuring IP Parameters for CESoPSN Bundles (CTP Menu) on page 16

## Configuring DSO Time Slots for CESoPSN Bundles (CTP Menu)

This topic describes how to configure the DSO time slots used by the bundle. By default, all unused DSOs are attached to a bundle. An unused DSO is a DSO not assigned to another bundle.

Before you begin:

- Disable the bundle before you modify the bundle options.

To configure time slots for CESoPSN bundles using the CTP Menu:

1. From the Main Menu, select **1) Bundle Operations**.
2. Select **3) CESoPSN**.
3. Select a bundle from the list.

If you select an active bundle, you are prompted to disable the bundle before configuring it.

4. Select **2) Config** to configure the bundle.
5. Configure the options as described in Table 5 on page 15.

Table 5: CESoPSN Bundle DSO Time Slot Settings in the CTP Menu

Field	Function	Your Action
Time Slots	Specifies the time slots assigned to this bundle.  The number of time slots that you select affects the default packet size and packet buffer set size for the bundle.	Enter the number of the time slots that you want to configure for the bundle. <ul style="list-style-type: none"> <li>• To enter a list of time slots, separate the list with commas.</li> <li>• To enter a range of time slots, separate the range with a hyphen (-).</li> </ul>

- Related Topics**
- CESoPSN Bundle Overview on page 5
  - Configuring IP Parameters for CESoPSN Bundles (CTP Menu) on page 16

## Configuring IP Parameters for CESoPSN Bundles (CTP Menu)

The CTP software uses the IP parameters to create IP packets.

Before you begin:

- Disable the bundle before you modify the bundle options.

To configure IP parameters for CESoPSN bundles using the CTP Menu:

1. From the Main Menu, select **1) Bundle Operations**.
2. Select **3) CESoPSN**.
3. Select a bundle from the list.

If you select an active bundle, you are prompted to disable the bundle before configuring it.

4. Select **2) Config** to configure the bundle.
5. Configure the options as described in Table 6 on page 16.

**Table 6: CESoPSN Bundle IP Parameter Settings in the CTP Menu**

Field	Function	Your Action
Destination IP	Specifies the name and IP address of the remote CTP device.	Enter the address of the remote CTP device.
Source UDP port	Specifies the source UDP port.  The source UDP port is used as the circuit identifier; you must configure both circuit endpoints to use the same UDP port. The UDP port must be unique on the CTP device. You will not be able to activate a port if another port is using the same source UDP port number.	Enter a number from 1 through 65535.
Max Buffer (ms)	Specifies the maximum buffer size.  The maximum buffer size setting is based on the number of packets in the buffer and the number of milliseconds that it takes the packets to go through the buffer. For example, a setting of 10.000 ms - 2 packets means that it will take 10 ms for 2 packets to go through the buffer.  We recommend that you use the default setting unless you require changes because of network performance.	Select a buffer size. The software displays a list of possible buffer sizes. The list varies depending on the type of interface (T1 or E1), and the type of signaling (CSS or CAS).  For example, the following are the available buffer sizes for an E1 interface with CSS signaling: <ul style="list-style-type: none"> <li>• 10.000 ms 2 packets</li> <li>• 20.000 ms 4 packets</li> <li>• 40.000 ms 8 packets</li> <li>• 80.000 ms 16 packets</li> <li>• 160.000 ms 32 packets</li> <li>• 320.000 ms 64 packets</li> <li>• 640.000 ms 128 packets</li> </ul>

Table 6: CESoPSN Bundle IP Parameter Settings in the CTP Menu (*continued*)

Field	Function	Your Action
Pkt Buffer Set (ms)	<p>Specifies the buffer size when the circuit enters a running state.</p> <p>The CTP software calculates a default setting based on the type of interface (T1 or E1), the type of signaling (CSS or CAS), and the packet size.</p> <p>We recommend that you use the default setting unless you require changes because of network performance.</p>	<p>Enter a number from the range displayed on the screen.</p> <p>This number must be divisible by the packet size. If you enter a number that is not divisible by the packet size, the software changes the setting to the closest number that is divisible by the packet size.</p>
Packet Size	<p>Specifies the size of IP packets that are created from data received at the port.</p> <p>The CTP software calculates a default packet size based on the number of time slots configured, the type of interface (T1 or E1), and the type of signaling (CSS or CAS).</p> <p>We recommend that you use the default setting unless you require changes because of network performance.</p> <p>If you choose to change the signaling, use the following guidelines:</p> <ul style="list-style-type: none"> <li>For CSS signaling, the packet size must be divisible by the number of time slots.</li> <li>For CAS signaling, use the following formula:  <math display="block">\text{packet size} = \text{number-of-slots} * 24 + \text{signaling-size}</math> <p>where</p> <math display="block">\text{signaling-size} = \text{number-of-slots}/2 + \text{number-of-slots}\%2</math> <p>frames-per-packet for E1 = 16</p> <p>frames-per-packet for T1 = 24</p> </li> </ul>	Enter a packet size.
Service Type	<p>Specifies the ToS byte to be used in the IP headers of packets sent from the CTP device to the IP network.</p> <p>For a mapping of ToS byte values to DSCP classes and settings, see “Providing QoS for CTP Bundles by Using Service Type Overview” on page 5.</p> <p>You do not need to set the ToS value to the same value on local and remote bundles.</p>	Enter a number from 0 through 255.
Time to Live	<p>Specifies the maximum number of router hops that a packet can traverse. The CTP device sets the TTL value in IP packets that it sends to the IP network. The IP network does not alter or optimize the packet routing based on the TTL setting. You do not need to set the same TTL value on local and remote ports.</p>	Enter a number from 0 through 255.
Bundle Description	Specifies identifying information about the bundle.	Type a description for the bundle.

**Related Topics** • CESoPSN Bundle Overview on page 5



## CHAPTER 5

# Configuring CESoPSN Bundles (CTPView)

- Configuring T1 and E1 Port Parameters for CESoPSN Bundles (CTPView) on page 19
- Configuring DS0 Time Slots for CESoPSN Bundles (CTPView) on page 21
- Configuring IP Parameters for CESoPSN Bundles (CTPView) on page 21

### Configuring T1 and E1 Port Parameters for CESoPSN Bundles (CTPView)

This topic describes how to configure port parameters for T1/E1 interfaces.

Before you begin:

- Log in to the CTPView software at least at the Net\_Admin level.
- Connect the CTPView server to the CTP device for which you want to configure bundles.
- Disable the bundle before you modify the bundle options.

To configure T1 and E1 port parameters using CTPView:

1. In the side pane, select **Bundle > Configuration**.
2. Run your mouse over the **Display and Select an Existing Bundle** bar.
3. In the table of bundles, select the bundle that you want to modify.
4. Under **Port Options**, configure the parameters described in Table 7 on page 19.

The options vary depending on whether the bundle is T1 or E1.

5. Click **Click to Submit Bundle AND Port Changes**.

**Table 7: CESoPSN Bundle T1 and E1 Port Parameter Settings in CTPView**

Field	Function	Your Action
Port Description	Specifies a description for the port.	Enter a description of up to 62 alphanumeric characters. Do not use the following characters:  ( ; ' " ) ]
T1/E1 Choice	Specifies the type of interface.  The type of interface that you select affects the default packet size and buffer sizes for the bundle.	Select one: <ul style="list-style-type: none"><li>• T1</li><li>• E1</li></ul>

Table 7: CESoPSN Bundle T1 and E1 Port Parameter Settings in CTPView (*continued*)

Field	Function	Your Action
T1 Line Coding	For T1 interfaces, specifies the T1 encoding method used on this bundle.	Select one: <ul style="list-style-type: none"> <li>• B8ZS</li> <li>• AMI</li> </ul>
E1 Connector Type	For E1 interfaces, configure the termination to work with either coax or RJ-48.	Select one: <ul style="list-style-type: none"> <li>• RJ48</li> <li>• COAX</li> </ul>
Line Buildout	For T1 interfaces, specifies the line buildout.	Select one: <ul style="list-style-type: none"> <li>• ~133 ft</li> <li>• ~266 ft</li> <li>• ~399 ft</li> <li>• ~533 ft</li> <li>• ~655 ft</li> <li>• -7.5dB CSU</li> <li>• -15dB CSU</li> <li>• -22.5dBCSU</li> </ul>
Signaling	For T1 interfaces, specifies whether or not CAS signaling is used.	Select one: <ul style="list-style-type: none"> <li>• On—Signaling is on.</li> <li>• Off—Signaling is off.</li> </ul>
Clock Cfg	Specifies the type of clocking for the port.	Select one: <ul style="list-style-type: none"> <li>• CTP is Clock Source—The PBX either returns the clock received from the CTP or it returns a clock that is traceable to the same source as the CTP node clock reference. You typically use this configuration when you configure the CTP device with a clock reference input.</li> <li>• CTP is Looped Timed—The PBX provides the clock and the CTP returns the same clock to the PBX. You typically use this configuration when the PBX has the more accurate clock source. You can configure the far end of the circuit with adaptive clocking to recover this clock if necessary.</li> <li>• CTP is Clock Source – Adap—The PBX returns the clock received from the CTP, and the CTP uses the adaptive recovered clock. You typically use this configuration when the CTP does not have a reference input and the PBX typically requires clock from the distant PBX.</li> </ul>

- Related Topics**
- CESoPSN Bundle Overview on page 5
  - Configuring IP Parameters for CESoPSN Bundles (CTPView) on page 21

## Configuring DSO Time Slots for CESoPSN Bundles (CTPView)

This topic describes how to configure the DSO time slots used by the bundle. By default, all unused DSOs are attached to a bundle. An unused DSO is a DSO not assigned to another bundle.

Before you begin:

- Log in to the CTPView software at least at the Net\_Admin level.
- Connect the CTPView server to the CTP device for which you want to configure bundles.
- Disable the bundle before you modify the bundle options.

To configure time slots for CESoPSN bundles using CTPView:

1. In the side pane, select **Bundle > Configuration**.
2. Run your mouse over the **Display and Select an Existing Bundle** bar.
3. In the table of bundles, select the bundle that you want to modify.
4. Under **Bundle Options**, configure the parameters described in Table 8 on page 21, and click **Click to Submit Bundle AND Port Changes**.

**Table 8: CESoPSN Bundle DSO Time Slot Settings in CTPView**

Field	Function	Your Action
Time Slots [ Selected are green. ] [ . ]	Specifies the time slots that are assigned to the bundle.  Specifies the time slots assigned to this bundle.  The number of time slots that you select affects the default packet size and packet buffer set size for the bundle.	Click on a time slot to select it for the bundle. Green time slots are selected. Gray time slots are not selected.

- Related Topics**
- CESoPSN Bundle Overview on page 5
  - Configuring IP Parameters for CESoPSN Bundles (CTPView) on page 21

## Configuring IP Parameters for CESoPSN Bundles (CTPView)

The CTP software uses the IP parameters to create IP packets.

Before you begin:

- Log in to the CTPView software at least at the Net\_Admin level.
- Connect the CTPView server to the CTP device for which you want to configure bundles.
- Disable the bundle before you modify the bundle options.

To configure IP parameters for CESoPSN bundles using CTPView:

1. In the side pane, select **Bundle > Configuration**.
2. Run your mouse over the **Display and Select an Existing Bundle** bar.
3. In the table of bundles, select the bundle that you want to modify.
4. Under **Bundle Options**, configure the parameters described in Table 9 on page 22, and click **Click to Submit Bundle AND Port Changes**.

**Table 9: CESoPSN Bundle IP Parameter Settings in CTPView**

Field	Function	Your Action
Bundle Description	Specifies identifying information about the bundle.	Type a description for the bundle.
State	Specifies whether the bundle is active or disabled.	Select DISABLED or ACTIVE.
Remote Address	Specifies the name and IP address of the remote CTP device.	In the first field, select the CTP device.  In the second field, select an interface on the CTP device.
Packet Size	<p>Specifies the size of IP packets that are created from data received at the port.</p> <p>The CTP software calculates a default packet size based on the number of time slots configured, the type of interface (T1 or E1), and the type of signaling (CSS or CAS).</p> <p>We recommend that you use the default setting unless you require changes because of network performance.</p> <p>If you choose to change the signaling, use the following guidelines:</p> <ul style="list-style-type: none"> <li>• For CSS signaling, the packet size must be divisible by the number of time slots.</li> <li>• For CAS signaling, use the following formula:  <math display="block">\text{packet size} = \text{number-of-slots} * 24 + \text{signaling-size}</math>           where  <math display="block">\text{signaling-size} = \text{number-of-slots}/2 + \text{number-of-slots}\%2</math> <math display="block">\text{frames-per-packet for E1} = 16</math> <math display="block">\text{frames-per-packet for T1} = 24</math> </li> </ul>	Enter a packet size.
Service Type	<p>Specifies the ToS byte to be used in the IP headers of packets sent from the CTP device to the IP network.</p> <p>For a mapping of ToS byte values to DSCP classes and settings, see "Providing QoS for CTP Bundles by Using Service Type Overview" on page 5.</p> <p>You do not need to set the ToS value to the same value on local and remote bundles.</p>	Enter a number from 0 through 255.

Table 9: CESoPSN Bundle IP Parameter Settings in CTPView (*continued*)

Field	Function	Your Action
Time to Live	Specifies the maximum number of router hops that a packet can traverse. The CTP device sets the TTL value in IP packets that it sends to the IP network. The IP network does not alter or optimize the packet routing based on the TTL setting. You do not need to set the same TTL value on local and remote ports.	Enter a number from 0 through 255.
Source UDP Port	Specifies the source UDP port.  The source UDP port is used as the circuit identifier; you must configure both circuit endpoints to use the same UDP port. The UDP port must be unique on the CTP device. You will not be able to activate a port if another port is using the same source UDP port number.	Enter a number from 1 through 65535.
Max Buffer	Specifies the maximum buffer size.  The maximum buffer size setting is based on the number of packets in the buffer and the number of milliseconds that it takes the packets to go through the buffer. For example, a setting of 10 ms with a packet equivalent of 2 means that it will take 10 ms for 2 packets to go through the buffer.  The CTP software calculates a default buffer size based on the type of interface (T1 or E1), and the type of signaling (CSS or CAS).  We recommend that you use the default setting unless you require changes because of network performance.	Enter the number of ms. The number that you can enter varies depending on the type of interface and signaling. When you enter a number, the software adjusts the number to the closest acceptable number, and it displays the packet equivalent.  When you enter the number of milliseconds, the software displays the packet equivalent, which is the number of packets that can go through the buffer within the number of milliseconds.
Buffer Set	Specifies the buffer size when the circuit enters a running state.  The CTP software calculates a default setting based on the type of interface (T1 or E1), the type of signaling (CSS or CAS), and the packet size.  We recommend that you use the default setting unless you require changes because of network performance.	Enter the number of ms. The number must be divisible by the packet size. If you enter a number that is not divisible by the packet size, the software changes the setting to the closest number that is divisible by the packet size.  When you enter the number of milliseconds, the software displays the packet equivalent, which is the number of packets that can go through the buffer within the number of milliseconds.
Bundle Description	Specifies identifying information about the bundle.	Type a description for the bundle.

**Related Topics** • CESoPSN Bundle Overview on page 5

